



## Unsupported Commands in Cisco IOS Release 12.1(19)EA1

---

This appendix lists some of the command-line interface (CLI) commands that appear when you enter the question mark (?) at the Catalyst 2970 switch prompt but are not supported in this release, either because they are not tested, or because of Catalyst 2970 hardware limitations. This is not a complete list. The unsupported commands are listed by software feature and command mode.

### Access Control Lists

#### Unsupported Privileged EXEC Commands

`access-enable [host] [timeout minutes]`

`access-template [access-list-number | name] [dynamic-name] [source] [destination] [timeout minutes]`

`clear access-template [access-list-number | name] [dynamic-name] [source] [destination].`

#### Unsupported Global Configuration Commands

`access-list rate-limit acl-index {precedence | mask prec-mask}`

`access-list dynamic extended`

#### Unsupported Debug Commands

`debug platform cli-redirection main`

`debug platform configuration`

# IGMP Snooping Commands

## Unsupported Global Configuration Commands

```
ip igmp snooping source-only-learning
ip igmp snooping tcn
```

## Interface Commands

## Unsupported Privileged EXEC Commands

```
show interfaces [interface-id | vlan vlan-id] [crb | fair-queue | irb | mac-accounting | precedence | irb
| random-detect | rate-limit | shape]
```

## Unsupported Global Configuration Commands

```
interface tunnel
```

## Unsupported Interface Configuration Commands

```
switchport broadcast level
switchport multicast level
switchport unicast level
```


**Note**


---

These commands have been replaced by the **storm-control** {**broadcast** | **multicast** | **unicast**} **level** *level* [*level*] interface configuration command.

---

# Network Address Translation (NAT) Commands

## Unsupported User EXEC Commands

```
clear ip nat translation
show ip nat statistics
show ip nat translations
```

## Unsupported Global Configuration Commands

ip nat inside destination  
ip nat inside source  
ip nat outside source  
ip nat pool

## Unsupported Interface Configuration Commands

ip nat

# RADIUS

## Unsupported Global Configuration Commands

aaa nas port extended  
radius-server attribute nas-port  
radius-server configure  
radius-server extended-portnames

# SNMP

## Unsupported Global Configuration Commands

snmp-server enable informs  
snmp-server enable traps flash insertion  
snmp-server enable traps flash removal  
snmp-server ifindex persist

# Spanning Tree

## Unsupported Global Configuration Commands

spanning-tree etherchannel guard misconfig  
spanning-tree pathcost method {long | short}

## Unsupported Interface Configuration Commands

spanning-tree stack-port

## VLAN

### Unsupported vlan-config Commands

private-vlan

### Unsupported User EXEC Commands

show running-config vlan

show vlan ifindex

show vlan private-vlan

## VTP

### Unsupported Privileged EXEC Commands

vtp {password *password* | pruning | version *number*}private-vlan



#### Note

---

This command has been replaced by the **vtp** global configuration command.

---

## Miscellaneous

### Unsupported Global Configuration Commands

errdisable detect cause dhcp-rate-limit

errdisable recovery cause dhcp-rate-limit

errdisable recovery cause unicast flood

service compress-config