



A

- administrative group 23
- assigning switch ports to VLANs 17
- auto mode 23
- autonegotiating
 - duplex mode 5
 - port speed 5

B

- banner, login 21

C

- cd command 31
- CDP
 - configuring 25
- Cisco Discovery Protocol
 - See CDP
- configuration files
 - managing 27
- configuring
 - CDP 25
 - DNS 24

- EtherChannel 22
 - switch 2
 - VLANs 15
 - VLAN trunks 18
- console port 2, 37
- copy command 29
- copy config command 32
- copy tftp command 32
- creating VLANs 16

D

- default configuration settings
 - Ethernet ports 38
 - Fast Ethernet ports 38
 - Gigabit Ethernet ports 38
 - trunking 40
 - VLANs 39
 - VTP 39
- default gateway 4
- delete command 34
- desirable mode 23
- dir command 34
- dir deleted command 35
- DNS, configuring 24

Domain Name System

See DNS

duplex mode 5

E

enable command 3

encapsulation

IEEE 802.1Q 18

ISL 18

EtherChannel

administrative group 23

configuring 22

enabling (caution) 23

Ethernet ports

configuring 5

default configuration settings 38

exit command 22

F

Fast Ethernet ports

configuring 5

default configuration settings 38

trunking configuration 40

Flash PC cards

formatting 31

full-duplex mode 5

G

Gigabit Ethernet ports

configuring 5

default configuration settings 38

trunking configuration 40

global system settings

configuring 7

default 37

H

half-duplex mode 5

host names 24

I

IEEE 802.1Q

encapsulation 18

in-band (sc0) interface 4

Inter-Switch Link

See ISL

IP address

assigning 4

default 38

ISL

encapsulation 18

L

login banner 21

M

managing configuration files 27

message of the day 21

module, resetting 36

N

netmask 4

P

PAgP 23

PCMCIA cards

 See Flash PC cards

ping command 4, 8

Port Aggregation Protocol

 See PAgP

port speed 5

privileged mode 3

pwd command 31

R

reset command 29

resetting module 36

resetting switch 36

S

set banner motd command 21

set boot system flash command 29

set cdp enable command 25

set cdp holdtime command 26

set cdp interval command 25

set enablepass command 7

set interface sc0 command 4

set ip dns domain command 24

set ip dns enable command 24

set ip dns server command 24

set ip route default command 4

set password command 7

set port duplex command 6

set port enable command 6

set port name command 6

set port speed command 6

set prompt command 7

set system name command 7

set time command 7

set trunk command 19

set vlan command 16, 17

set vtp domain command 12

set vtp mode client command 13
set vtp mode server command 12
set vtp mode transparent command 14
show cdp neighbors command 26
show cdp port command 26
show configuration command 22, 27
show flash command 29
show interface command 4, 8
show ip dns command 24
show ip route command 4, 8
show port command 6, 17
show trunk command 19
show vlan command 16, 17
show vtp domain command 12, 14
software features
 related documentation vi
software images
 downloading from TFTP server 29
 managing 29
squeeze command 35
subnet mask
 See netmask
supervisor engine configuration
 default settings 37
switch
 configuring 2
 configuring as VTP client 13
 configuring as VTP server 12
 resetting 36
switch ports, assigning to VLANs 17

T

TFTP servers
 downloading software images from 29
traceroute command 8
trunking
 default configuration settings 40

U

undelete command 35

V

VLANs
 configuring 15
 creating 16
 default configuration settings 39
VLAN Trunk Protocol
 See VTP
VLAN trunks, configuring 18
VTP
 client 12, 13
 default configuration settings 39
 server 11, 12
 transparent mode 14
 transparent switches 12