



Configuring Port Security

This chapter describes how to configure port security on the Catalyst 6000 family switches.



Note

For complete syntax and usage information for the commands used in this chapter, refer to the *Catalyst 6000 Family Command Reference* publication.

This chapter consists of these sections:

- [Understanding How Port Security Works, page 35-1](#)
- [Port Security Configuration Guidelines, page 35-3](#)
- [Configuring Port Security, page 35-3](#)

Understanding How Port Security Works

You can use port security to block input to an Ethernet, Fast Ethernet, or Gigabit Ethernet port when the MAC address of the station attempting to access the port is different from any of the MAC addresses specified for that port. Alternatively, you can use port security to filter traffic destined to or received from a specific host based on the host MAC address.

This section describes the following traffic filtering methods:

- [Allowing Traffic Based on the Host MAC Address, page 35-1](#)
- [Restricting Traffic Based on the Host MAC Address, page 35-2](#)

Allowing Traffic Based on the Host MAC Address

The total number of MAC addresses that can be specified per port is limited to the global resource of 1024 plus one default MAC address. The total number of MAC addresses on any port cannot exceed 1025.

Allocation of the maximum number of MAC addresses for each port depends on your network configuration. The following combinations are examples of valid allocations:

- 1025 (1 + 1024) addresses on 1 port and 1 address each on the rest of the ports.
- 513 (1 + 512) each on 2 ports in a system and 1 address each on the rest of the ports.
- 901 (1 + 900) on one port, 101 (1 + 100) on another port, 25 (1 + 24) on the third port, and 1 address each on the rest of the ports.

After you allocate the maximum number of MAC addresses on a port, you can either specify the secure MAC address for the port manually or you can have the port dynamically configure the MAC address of the connected devices. Out of an allocated number of maximum MAC addresses on a port, you can manually configure all, allow all to be autoconfigured, or configure some manually and allow the rest to be autoconfigured. Once you manually configure or autoconfigure the addresses, they are stored in NVRAM and maintained after a reset.

After you allocate a maximum number of MAC addresses on a port, you can specify how long addresses on the port will remain secure. After the age time expires, the MAC addresses on the port become insecure. By default, all addresses on a port are secured permanently.

If a security violation occurs, you can configure the port to go into shutdown mode or restrictive mode. The shutdown mode option allows you to specify whether the port is permanently disabled or disabled for only a specified time. The default is for the port to shut down permanently. The restrictive mode allows you to configure the port to remain enabled during a security violation and drop only packets that are coming in from insecure hosts.

**Note**

If you configure a secure port in restrictive mode, and a station is connected to the port whose MAC address is already configured as a secure MAC address on another port on the switch, the port in restrictive mode shuts down instead of restricting traffic from that station. For example, if you configure MAC-1 as the secure MAC address on port 2/1 and MAC-2 as the secure MAC address on port 2/2 and then connect the station with MAC-1 to port 2/2 when port 2/2 is configured for restrictive mode, port 2/2 shuts down instead of restricting traffic from MAC-1.

When a secure port receives a packet, the source MAC address of the packet is compared to the list of secure source addresses that were manually configured or autoconfigured (learned) on the port. If a MAC address of a device attached to the port differs from the list of secure addresses, the port either shuts down permanently (default mode), shuts down for the time you have specified, or drops incoming packets from the insecure host. The port's behavior depends on how you configure it to respond to a security violation.

If a security violation occurs, the Link LED for that port turns orange, and a link-down trap is sent to the Simple Network Management Protocol (SNMP) manager. An SNMP trap is not sent if you configure the port for restrictive violation mode. A trap is sent only if you configure the port to shut down during a security violation.

Restricting Traffic Based on the Host MAC Address

You can filter traffic based on a host MAC address so that packets that are tagged with a specific source MAC address are discarded. When you specify a MAC address filter with the **set cam filter** command, incoming traffic from that host MAC address is dropped and packets addressed to that host are not forwarded.

**Note**

The **set cam filter** command allows filtering for unicast addresses only. You cannot filter traffic for multicast addresses with this command.

Port Security Configuration Guidelines

Follow these guidelines when configuring port security:

- You cannot configure port security on a trunk port.
- You cannot enable port security on a SPAN destination port and vice versa.
- You cannot configure dynamic, static, or permanent CAM entries on a secure port.
- When you enable port security on a port, any static or dynamic CAM entries associated with the port are cleared; any currently configured permanent CAM entries are treated as secure.

Configuring Port Security

These sections describe how to configure port security:

- [Enabling Port Security, page 35-3](#)
- [Setting the Maximum Number of Secure MAC Addresses, page 35-4](#)
- [Setting the Port Security Age Time, page 35-5](#)
- [Clearing MAC Addresses, page 35-5](#)
- [Specifying the Security Violation Action, page 35-6](#)
- [Setting the Shutdown Timeout, page 35-6](#)
- [Disabling Port Security, page 35-7](#)
- [Restricting Traffic Based on a Host MAC Address, page 35-7](#)
- [Displaying Port Security, page 35-8](#)

Enabling Port Security

To enable port security, perform this task in privileged mode:

	Task	Command
Step 1	Enable port security on the desired ports. If desired, specify the secure MAC address.	set port security <i>mod/port</i> enable [<i>mac_addr</i>]
Step 2	You can add MAC addresses to the list of secure addresses.	set port security <i>mod/port</i> <i>mac_addr</i>
Step 3	Verify the configuration.	show port [<i>mod[/port]</i>]

This example shows how to enable port security using the learned MAC address on a port and verify the configuration:

```

Console> (enable) set port security 2/1 enable
Port 2/1 port security enabled with the learned mac address.
Trunking disabled for Port 2/1 due to Security Mode
Console> (enable) show port 2/1
Port Name                Status      Vlan      Level Duplex Speed Type
-----
2/1                      connected  522      normal half   100 100BaseTX

```

```

Port  Security  Secure-Src-Addr  Last-Src-Addr  Shutdown  Trap  IfIndex
-----
2/1  enabled  00-90-2b-03-34-08  00-90-2b-03-34-08  No  disabled  1081

Port  Broadcast-Limit  Broadcast-Drop
-----
2/1  -  0

Port  Align-Err  FCS-Err  Xmit-Err  Rcv-Err  UnderSize
-----
2/1  0  0  0  0  0

Port  Single-Col  Multi-Coll  Late-Coll  Excess-Col  Carri-Sen  Runts  Giants
-----
2/1  0  0  0  0  0  0  0

Last-Time-Cleared
-----
Fri Jul 10 1998, 17:53:38

```

This example shows how to enable port security on a port and manually specify the secure MAC address:

```

Console> (enable) set port security 2/1 enable 00-90-2b-03-34-08
Port 2/1 port security enabled with 00-90-2b-03-34-08 as the secure mac address
Trunking disabled for Port 2/1 due to Security Mode
Console> (enable)

```

Setting the Maximum Number of Secure MAC Addresses

You can set the number of MAC addresses to secure on a port. By default, at least one MAC address per port can be secured. In addition to this default, a global resource of up to 1024 MAC addresses is available to be shared by the ports. This means that if the entire global resource of 1024 MAC addresses is used on some ports, you can still enable port security on the rest of the ports with a maximum of one MAC per port.

If you reduce the maximum number of MAC addresses, the system clears the specified number of MAC addresses and displays the list of removed addresses.

To set a number of MAC addresses to be secured for a particular port, perform this task in privileged mode:

Task	Command
Set the number of MAC addresses to be secured on a port.	set port security <i>mod/port maximum num_of_mac</i>

This example shows how to set the number of MAC addresses to be secured:

```

Console> (enable) set port security 7/7 maximum 20
Maximum number of secure addresses set to 20 for port 7/7.
Console> (enable)

```

This example shows how to reduce the number of MAC addresses and the list that displays the cleared MAC addresses:

```
Console> (enable) set port security 7/7 maximum 18
Maximum number of secure addresses set to 18 for port 7/7
00-11-22-33-44-55 cleared from secure address list for port 7/7
00-11-22-33-44-66 cleared from secure address list for port 7/7
Console> (enable)
```

Setting the Port Security Age Time

The age time on a port specifies how long all addresses on that port will be secured. This age time is activated when a MAC address initiates traffic on the port. After the age time expires for a MAC address, the entry for that MAC address on the port is removed from the secure address list. The valid range is 10–1440 minutes. Setting the age time to zero disables aging of secure addresses.

To set the age time on a port, perform this task in privileged mode:

Task	Command
Set the age time for which addresses on a port will be secured.	set port security mod/port age time

This example shows how to set the age time on port 7/7:

```
Console> (enable) set port security 7/7 age 600
Secure address age time set to 600 minutes for port 7/7.
Console> (enable)
```

Clearing MAC Addresses

Enter the **clear port security** command to clear MAC addresses from a list of secure addresses on a port.



Note

If the **clear** command is executed on a MAC address that is in use, that MAC address may be learned and made secure again. We recommend that you disable port security before you clear MAC addresses.

To clear all or a particular MAC address from the list of secure MAC addresses, perform this task in privileged mode:

Task	Command
Clear all or a particular MAC address from the list of secure MAC addresses.	clear port security mod/port {mac_addr all}

This example shows how to clear one MAC address from the secure address list on port 7/7:

```
Console> (enable) clear port security 7/7 00-11-22-33-44-55
00-11-22-33-44-55 cleared from secure address list for port 7/7
Console> (enable)
```

This example shows how to clear all MAC addresses from ports 7/5-7:

```
Console> (enable) clear port security 7/5-7 all
All addresses cleared from secure address list for ports 7/5-7
Console> (enable)
```

Specifying the Security Violation Action

You can set the port for the following two modes to handle a security violation:

- Shutdown—Shuts down the port permanently or for a specified time. Permanent shutdown is the default mode.
- Restrictive—Drops all packets from insecure hosts but remains enabled.

To specify the security violation action to be taken, perform this task in privileged mode:

Task	Command
Specify the violation action on a port.	set port security mod/port violation {shutdown restrict}

This example shows how to specify that port 7/7 drop all packets from insecure hosts:

```
Console> (enable) set port security 7/7 violation restrict
Port security violation on port 7/7 will cause insecure packets to be dropped.
Console> (enable)
```



Note

If you restrict the number of secure MAC addresses on a port to one and additional hosts attempt to connect to that port, port security blocks these additional hosts from connecting to that port and to any other port in the same VLAN for the duration of the VLAN aging time. By default, the VLAN aging time is five minutes. If a host is blocked from joining a port in the same VLAN as the secured port, allow the VLAN aging time to expire before you attempt to connect the host to the port again.

Setting the Shutdown Timeout

You can set the time a port remains disabled in case of a security violation. By default, the port is shut down permanently. The valid range is 10–1440 minutes.

If the time is set to zero, the shutdown is disabled for this port.



Note

When the shutdown timeout expires, the port is reenabled and all port security-related configuration is maintained.

To set the shutdown timeout, perform this task in privileged mode:

Task	Command
Set the shutdown timeout on a port.	set port security mod/port shutdown time

This example shows how to set the shutdown timeout to 600 minutes on port 7/7:

```
Console> (enable) set port security 7/7 shutdown 600
Secure address shutdown time set to 600 minutes for port 7/7.
Console> (enable)
```

Disabling Port Security

To disable port security, perform this task in privileged mode:

	Task	Command
Step 1	Disable port security on the desired ports.	set port security <i>mod/port</i> disable
Step 2	Verify the configuration.	show port security [<i>mod/port</i>]

This example shows how to disable security on a port:

```
Console> (enable) set port security 2/1 disable
Port 2/1 port security disabled.
Console> (enable)
Console> (enable) show port security 2/1
Port Security Violation Shutdown-Time Age-Time Max-Addr Trap IfIndex
-----
3/24 disabled restrict 20 300 10 disabled 921

Port Num-Addr Secure-Src-Addr Age-Left Last-Src-Addr Shutdown/Time-Left
-----
3/24 1 00-e0-4f-ac-b4-00 - - -
Console> (enable)
```

Restricting Traffic Based on a Host MAC Address

To restrict incoming or outgoing traffic for a specific MAC address, perform this task in privileged mode:

	Task	Command
Step 1	Restrict traffic destined to or originating from a specific MAC address.	set cam static permanent filter <i>unicast_mac</i> <i>vlan</i>
Step 2	Remove the filter.	clear cam <i>mac_address</i> <i>vlan</i>
Step 3	Verify the configuration.	show cam static

This example shows how to create a filter that restricts traffic for a specific MAC address:

```
Console> (enable) set cam static filter 00-02-03-04-05-06 1
Filter entry added to CAM table.
Console> (enable)
```

This example shows how to clear the filter:

```
Console> (enable) clear cam 00-02-03-04-05-06 1
CAM entry cleared.
Console> (enable)
```

This example shows how to display the static CAM entries:

```
Console> show cam static

VLAN  Dest MAC/Route Des      [CoS]  Destination Ports or VCs / [Protocol Type]
-----
3      04-04-05-06-07-08  *      FILTER
```

Displaying Port Security

The **show port security** command displays the following information:

- List of secure MAC addresses for a port
- Maximum number of secure addresses allowed on a port
- Total number of secure MAC addresses
- Age
- Age left and shutdown timeout left
- Shutdown/security mode
- Statistics related to port security

To display port security configuration information and statistics, perform this task in privileged mode:

	Task	Command
Step 1	Display the configuration.	show port security [statistics] <i>mod/port</i>
Step 2	Display the port security statistics.	show port security statistics [system] [<i>mod/port</i>]

This example shows how to display port security configuration information and statistics:

```
Console> (enable) show port security 3/24
Port  Security Violation Shutdown-Time Age-Time Max-Addr Trap      IfIndex
-----
3/24  enabled  shutdown          300      60      10 disabled  921

Port  Num-Addr  Secure-Src-Addr  Age-Left  Last-Src-Addr  Shutdown/Time-Left
-----
3/24      4  00-e0-4f-ac-b4-00  60  00-e0-4f-ac-b4-00  no  -
      00-11-22-33-44-55  0
      00-11-22-33-44-66  0
      00-11-22-33-44-77  0

Console> (enable) show port security statistics 3/24
Port  Total-Addrs  Maximum-Addrs
-----
3/24      4              10
Console> (enable)
Port  Total-Addrs  Maximum-Addrs
-----
3/24      1              10
Console> (enable)
```

This example shows how to display port security statistics on a module:

```

Console> (enable) show port security statistics 7
Port  Total-Addr  Maximum-Addr
-----
7/1      0             1
7/2      0             1
7/3      0             1
7/4      0             1
7/5      0             1
7/6      0             1
7/7      0             1
7/8      0             1
7/9      0             1
7/10     0            200
7/11     0             1
7/12     0             1
7/13     0             1
7/14     0             1
7/15     0             1
7/16     0             1
7/17     0             1
7/18     0             1
7/19     0             1
7/20     0             1
7/21     0             1
7/22     0             1
7/23     0             1
7/24     0             1
Module 7:
  Total ports: 24
  Total MAC address(es): 223
  Total global address space used (out of 1024): 199
  Status: installed
Console> (enable)

```

This example shows how to display port security statistics on the system:

```

Console> (enable) show port security statistics system
Module 1:
  Total ports: 2
  Total MAC address(es): 2
  Total global address space used (out of 1024): 0
  Status: installed
Module 3:
  Module does not support port security feature
Module 6:
  Total ports: 48
  Total MAC address(es): 48
  Total global address space used (out of 1024): 0
  Status: installed
Module 7:
  Total ports: 24
  Total MAC address(es): 223
  Total global address space used (out of 1024): 199
  Status: installed
Console> (enable)

```

