



---

## A

- adding a device [1-1](#)
- audio echo cancellation
  - CTS 500-32, [1-21](#)

---

## B

- BFCP [2-9](#)
- BFCP profile [2-9](#)
  - VCS Zone settings [2-9](#)
- BFCP SIP Profile [5-7](#)

---

## C

- CAPF Information window
  - configuration fields
    - Authentication Mode [1-16](#)
    - Authentication String [1-16](#)
    - Certificate Operation [1-16](#)
    - Certificate Operation Status [1-16](#)
    - Key Size (Bits) [1-16](#)
    - Operation Completes By [1-16](#)
- Cisco Unified IP Phones
  - synchronizing configuration [4-7, 5-28](#)
- Cisco WebEx Participant List
  - Display (Internal Caller ID) fields [1-37](#)
- codec
  - restoring connectivity [4-8](#)
- configure the Search User Limit [3-23](#)
- configuring the directory
  - directory service [3-22](#)
- CTS 3x00 configuration

second-row conference room seats [1-21](#)

- CTS 500 - Product Specific Configuration Layout fields
  - Quality (per Display) [1-18](#)

---

## D

- Device Information window
  - configuration fields
    - Active Load ID [1-13](#)
    - Allow Control of Device from CTI [1-15](#)
    - Always Use Prime Line [1-14](#)
    - Always Use Prime Line for Voice Message [1-14](#)
    - Calling Party Transformation CSS [1-14](#)
    - Calling Search Space [1-14](#)
    - Common Device Configuration [1-14](#)
    - Common Phone Profile [1-14](#)
    - Description [1-13](#)
    - Device Mobility Mode [1-14](#)
    - Device Pool [1-13](#)
    - Ignore Presentation Indicators [1-15](#)
    - IP Address [1-13](#)
    - Locale [1-14](#)
    - Location [1-14](#)
    - Logged Into Hunt Group [1-15](#)
    - MAC Address [1-13](#)
    - Media Resource Group List [1-14](#)
    - Network Locale [1-14](#)
    - Owner User ID [1-14](#)
    - Phone Button Template [1-14](#)
    - Phone Load Name [1-14](#)
    - Registration [1-13](#)
    - Remote Device [1-15](#)
    - Retry Video Call as Audio [1-14](#)

- Softkey Template [1-14](#)
  - Use Device Pool Calling Party Transformation CSS [1-14](#)
  - Use Trusted Relay Point [1-14](#)
  - Directory Numbers
    - AAR Settings fields
      - AAR [1-34](#)
    - Assigning Shared Lines
      - adding new directory number [5-22](#)
      - call forward and pickup settings [5-23](#)
      - configuring [5-22](#)
      - directory number information [5-23](#)
      - directory number information fields
        - Alerting Name [5-23](#)
        - ASCII Alerting Name [5-23](#)
        - Description [5-23](#)
        - Directory Number [5-23](#)
        - Route Partition [5-23](#)
      - MLPP information [5-24](#)
    - Call/Call Waiting Settings fields
      - Busy Trigger [1-38](#)
      - Maximum Number of Calls [1-38](#)
    - Call Forward and Pickup Settings fields
      - Calling Search Space Activation Policy [1-35](#)
      - Secondary Calling Search Space for Fall Forward [1-35](#)
    - Call Information Display [1-38](#)
    - Directory Number Configuration window
      - directory number information [1-32](#)
    - Directory Number Configuration window fields
      - Alerting Name [1-33](#)
      - ASCII Alerting Name [1-33](#)
      - Description [1-33](#)
      - Directory Number [1-33](#)
      - Route Partition [1-33](#)
    - Directory Number Settings fields
      - Auto Answer [1-34](#)
      - Calling Search Space [1-33](#)
      - Network Hold MOH Audio Source [1-34](#)
      - Presence Group [1-33](#)
      - User Hold MOH Audio Source [1-33](#)
      - Voice Mail Profile [1-33](#)
    - Line and Devices Settings fields
      - ASCII Display (Internal Caller ID) [1-37](#)
      - Audible Message Waiting Indicator Policy [1-37](#)
      - Call Pickup Group Audio Alert Setting (Phone Idle) [1-37](#)
      - Display (Internal Caller ID) [1-37](#)
      - External Phone Number Mask [1-37](#)
      - Monitoring Calling Search Space [1-37](#)
      - Recording Option [1-37](#)
      - Recording Profile [1-37](#)
      - Ring Setting (Phone Active) [1-37](#)
      - Ring Setting (Phone Idle) [1-37](#)
      - Visual Message Waiting Indicator Policy [1-37](#)
    - Line Settings for All Devices fields
      - Hold Reversion Notification Interval (seconds) [1-36](#)
      - Hold Reversion Ring Duration (seconds) [1-36](#)
    - MLPP Alternate Party Settings fields
      - AARMLPP No Answer Ring Duration (seconds) [1-36](#)
      - MLPP Calling Search Space [1-36](#)
      - Target (Destination) [1-36](#)
- 
- ## E
- enable Cisco User Data Services [3-23](#)
- 
- ## I
- idle display default screen [3-24](#)
- 
- ## L
- Locale Installers [2-19](#)
  - Locale Packs [2-19](#)

## M

### MIDlets

adding a new phone [5-2](#)

configuring

CAPF Information window fields

Authentication Mode [5-8](#)

Authentication String [5-8](#)

Certificate Operation [5-8](#)

Certificate Operation Status [5-8](#)

Key Size (Bits) [5-8](#)

Operation Completes By [5-8](#)

Device Information window fields

AAR Calling Search Space [5-5](#)

AAR Group [5-5](#)

Active Load ID [5-4](#)

Allow Control of Device from CTI [5-6](#)

Always Use Prime Line [5-5](#)

Always Use Prime Line for Voice  
Message [5-6](#)

BLF Audible Alert Setting (Phone Busy) [5-5](#)

BLF Audible Alert Setting (Phone Idle) [5-5](#)

Built In Bridge [5-5](#)

Calling Party Transformation CSS [5-6](#)

Calling Search Space [5-5](#)

Common Device Configuration [5-4](#)

Common Phone Profile [5-5](#)

Description [5-4](#)

Device Mobility Mode [5-5](#)

Device Pool [5-4](#)

Geolocation [5-6](#)

Hot Line Device [5-6](#)

Ignore Presentation Indicators [5-6](#)

IP Address [5-4](#)

Join Across Lines [5-5](#)

Location [5-5](#)

Logged Into Hunt Group [5-6](#)

MAC Address [5-4](#)

Media Resource Group List [5-5](#)

Network Hold MOH Audio Source [5-5](#)

Network Locale [5-5](#)

Owner User ID [5-5](#)

Phone Button Template [5-5](#)

Phone Load Name [5-5](#)

Phone Personalization [5-5](#)

Privacy [5-5](#)

Protected Device [5-6](#)

Registration [5-4](#)

Remote Device [5-6](#)

Retry Video Call as Audio [5-6](#)

Services Provisioning [5-5](#)

Single Button Barge [5-5](#)

Softkey Template [5-5](#)

Use Device Pool Calling Party Transformation  
CSS [5-6](#)

User Hold MOH Audio Source [5-5](#)

User Locale [5-5](#)

Use Trusted Relay Point [5-5](#)

Device is active [5-4](#)

Device is trusted [5-4](#)

Do Not Disturb settings

DND Incoming Call Alert [5-10](#)

DND Option [5-10](#)

Do Not Disturb [5-10](#)

Expansion Module Information window [5-8](#)

Extension Information window [5-9](#)

External Data Locations Information window  
fields

Authentication Server [5-9](#)

Directory [5-9](#)

Idle [5-9](#)

Idle Timer (seconds) [5-9](#)

Information [5-9](#)

Messages [5-9](#)

Proxy Server [5-9](#)

Secure Authentication URL [5-9](#)

Secure Directory URL [5-9](#)

Secure Idle URL [5-9](#)

Secure Information URL [5-9](#)

Secure Message URL [5-9](#)

Secure Services URL [5-9](#)

Services [5-9](#)

Product Specific Configuration Layout settings

802.1x Authentication [5-17](#)

- Advertise G.722 Codec [5-15](#)
  - Auto Call Select [5-15](#)
  - Auto Line Select [5-12](#)
  - Cisco Discovery Protocol (CDP)
    - PC Port [5-16](#)
    - Switch Port [5-16](#)
  - Days Display Not Active [5-12](#)
  - Detect Unified CM Connection Failure [5-17](#)
  - Disable Speakerphone [5-11](#)
  - Disable Speakerphone and Headset [5-11](#)
  - Display Idle Timeout [5-13](#)
  - Display On Duration [5-13](#)
  - Display On Time [5-13](#)
  - Display On When Incoming Call [5-14](#)
  - Enbloc Dialing [5-18](#)
  - Forwarding Delay [5-11](#)
  - Gratuitous ARP [5-12](#)
  - Handset/Headset Monitor [5-18](#)
  - HTTPS Server [5-18](#)
  - IPv6 Load Server [5-17](#)
  - IPv6 Log Server [5-17](#)
  - Link Layer Discovery Protocol (LLDP)
    - PC Port [5-16](#)
  - Link Layer Discovery Protocol - Media End-point Discover (LLDP-MED)
    - Switch Port [5-16](#)
  - LLDP Asset ID [5-16](#)
  - LLDP Power Priority [5-16](#)
  - Load Server [5-14](#)
  - Logging Display [5-13](#)
  - Log Server [5-15](#)
  - Minimum Ring Volume [5-18](#)
  - More Softkey Timer [5-15](#)
  - PC Port [5-11](#)
  - PC Voice VLAN Access [5-12](#)
  - Peer Firmware Sharing [5-16](#)
  - Recording Tone [5-14](#)
  - Recording Tone Duration [5-14](#)
  - Recording Tone Local Volume [5-14](#)
  - Recording Tone Remote Volume [5-14](#)
  - RTCP [5-14](#)
  - Settings Access [5-11](#)
  - Span to PC Port [5-13](#)
  - Video Capabilities [5-12](#)
  - Web Access [5-12](#)
  - Wideband Headset [5-15](#)
  - Wideband Headset UI Control [5-15](#)
  - Wireless Headset Hookswitch Control [5-16](#)
  - Protocol Specific Information window fields
    - Device Security Profile [5-7](#)
    - Digest User [5-7](#)
    - Media Termination point Required [5-7](#)
    - MTP Preferred Originating Codec [5-7](#)
    - Packet Capture Duration [5-7](#)
    - Packet Capture Mode [5-7](#)
    - Presence Group [5-7](#)
    - Require DTMF Reception [5-7](#)
    - Rerouting Calling Search Space [5-7](#)
    - SIP Dial Rules [5-7](#)
    - SIP Profile [5-7](#)
    - SUBSCRIBE Calling Search Space [5-7](#)
    - Unattended Port [5-7](#)
  - Secure Shell Information settings
    - Secure Shell Password [5-10](#)
    - Secure Shell User [5-10](#)
  - managing the phone [5-3](#)
  - software download [5-1](#)
  - MIDlets, configuring
    - MLPP Information window [5-10](#)
  - MIDlets features
    - configuring [2-1](#)
    - CCP VPN Security [2-14](#)
    - Self View [2-13](#)
    - Self View, behavior [2-14](#)
  - MLPP Domain field [1-17](#)
- 
- P**
- Passwords
    - Characters and digits
      - MLPP Alternate Party Settings [i-vi](#)
      - Speed Dial and Abbreviated Dial Configuration [i-vi](#)
    - Characters and digits, supported [i-vi](#)

- resetting in CTS [4-5](#)
- Unified CM secure shell [4-5](#)
- Phone
  - configuring MIDlets [5-18](#)
    - configuring phone interface [5-20](#)
    - creating phone service [5-19](#)
    - setting phone parameters [5-20](#)
- Phone reset
  - If you lose connectivity [4-8](#)
  - Information about [4-7, 5-28](#)
  - phone firmware
    - reset the phone to the factory image [5-29](#)
  - Resetting a Cisco Unified IP Phone [5-28](#)
  - Synchronizing a phone [4-7, 5-28](#)
- phones
  - synchronizing configuration [4-7, 5-28](#)
- Phone Security Profile
  - adding a new profile [1-8](#)
  - CAPF information [1-11](#)
  - CAPF information fields
    - Authentication Mode [1-11](#)
    - Key Size (Bits) [1-11](#)
  - configuring [1-8](#)
  - parameters used in phone field [1-11](#)
    - SIP Phone Port [1-12](#)
  - SIP phone security [1-9](#)
  - SIP phone security fields
    - Description [1-9](#)
    - Device Security Mode [1-10](#)
    - Enable Digest Authentication [1-10](#)
    - Exclude Digest Credentials in Configuration File [1-11](#)
    - Name [1-9](#)
    - Nonce Validity Time [1-9](#)
    - TFTP Encrypted Config [1-11](#)
    - Transport Type [1-10](#)
- phone services
  - Cisco-provided default services [2-7](#)
- Product Specific Configuration Layout
  - auxiliary control unit [1-22](#)
  - dial plan information [1-23](#)
    - International Dialing Digits [1-23](#)
    - Inter Site Access Code [1-23](#)
    - National Dialing Digits [1-23](#)
    - Off-Net Access Code [1-23](#)
    - Site Access Code [1-23](#)
  - directory number [1-23](#)
    - Area Code [1-24](#)
    - Country Code [1-24](#)
    - Local Number [1-24](#)
  - external CTS log destination [1-26](#)
    - External CTS Log Address [1-28](#)
    - External CTS Log User Name [1-28](#)
    - External CTS Log User Password [1-28](#)
    - Log Period [1-28](#)
    - Log Start Time [1-28](#)
  - external CTS log destination, Protocol [1-28](#)
  - global location [1-24](#)
    - Latitude [1-24](#)
    - Longitude [1-24](#)
  - secure shell information [1-25](#)
    - Secure Shell Password [1-25](#)
    - Secure Shell User [1-25](#)
    - SSH Admin Life [1-26](#)
    - SSH Helpdesk Life [1-26](#)
    - SSH Helpdesk Password [1-26](#)
    - SSH Helpdesk User [1-26](#)
  - SNMP configuration parameters [1-28](#)
    - Enable SNMP [1-29](#)
    - SNMP (v2c) Community Read Only [1-30](#)
    - SNMP (v2c) Community Read Write [1-30](#)
    - SNMP (v3) Auth. Algorithm [1-29](#)
    - SNMP (v3) Auth. Password [1-30](#)
    - SNMP (v3) Privacy Algorithm [1-30](#)
    - SNMP (v3) Privacy Password [1-30](#)
    - SNMP (v3) Security Level [1-29](#)
    - SNMP System Contact [1-30](#)
    - SNMP System Location [1-30](#)

- SNMP trap receive parameter
    - SNMP (v3) Trap Username [1-31](#)
  - SNMP trap receive parameters [1-30](#)
    - SNMP(v2c) Community String [1-31](#)
    - SNMP (v3) Auth. Algorithm [1-31](#)
    - SNMP (v3) Auth. Password [1-31](#)
    - SNMP (v3) Privacy Algorithm [1-31](#)
    - SNMP (v3) Privacy Password [1-31](#)
    - SNMP (v3) Trap Receiver Address [1-31](#)
    - SNMP Security Level [1-31](#)
  - Product Specific Configuration Layout check boxes
    - Enable Audio Echo Cancellation (AEC) [1-21](#)
    - Enable Call Termination Ring [1-21](#)
    - Enable Single Microphone Mute [1-21](#)
  - Product Specific Configuration Layout fields
    - Admin. Web Access [1-17](#)
    - Advertise G.722 Codec [1-19](#)
    - Alternate Unified CM for Directory Lookup [1-19](#)
    - Auto Answer off [1-21](#)
    - Cisco TelePresence Recording Server Address [1-19](#)
    - Cisco TelePresence Type [1-17](#)
    - CTS Auto Answer [1-21](#)
    - Days Display Not Active [1-20](#)
    - Display On Duration [1-20](#)
    - Display On Time [1-20](#)
    - External SYSLOG Address [1-19](#)
    - Idle Display [1-20](#)
    - Lights [1-19](#)
    - Live Desk Number [1-20](#)
    - Maximum Call Duration (in minutes) [1-17](#)
    - Presentation Frames Per Second [1-20](#)
    - Presentation Input Device [1-18](#)
    - Presentation Output Device [1-19](#)
    - Room Name (from Exchange(R)) [1-17](#)
    - Second Row Capacity [1-21](#)
    - Table Microphone Count [1-21](#)
  - Protocol Specific Information window
    - configuration fields
      - Allow Presentation Sharing using BFCP [1-16](#)
      - Device Security Profile [1-15](#)
      - Digest User [1-15](#)
      - Media Termination point Required [1-15](#)
      - MTP Preferred Originating Codec [1-15](#)
      - Packet Capture Duration [1-15](#)
      - Packet Capture Mode [1-15](#)
      - Presence Group [1-15](#)
      - Rerouting Calling Search Space [1-15](#)
      - SIP Dial Rules [1-15](#)
      - SIP Profile [1-15](#)
      - SUBSCRIBE Calling Search Space [1-15](#)
      - Unattended Port [1-16](#)
- 
- ## S
- Screen [2-16](#)
  - Security
    - Cluster Security Mode [i-vi, 1-8](#)
    - Device Security Mode [i-vi](#)
    - Media is Encrypted icon (closed lock) [i-vi](#)
  - Setting up Directory
    - Show Directory [2-6](#)
  - Speed dial
    - adding numbers, administration [2-1](#)
    - adding numbers, end user [2-3](#)
- 
- ## T
- Troubleshooting
    - Authentication Issues [5-27](#)
    - correct typos in URL [5-25](#)
    - CTL File Issues [4-2](#)
    - CTS 32x0
      - Second Row Capacity setting [4-4](#)
    - CTS 32x0 microphones
      - Orange question mark error [4-4](#)
    - CTS does not auto answer [5-26](#)
    - CTS IP Address Issues [5-26](#)

disable Speaker/Headset [5-26](#)

#### Firmware

Cisco Unified IP Phone goes dead [5-27](#)

Cisco Unified IP Phone rejects a direct firmware upgrade [5-27](#)

#### MIDlet Issues

Cannot establish TCP connections with the CTS [5-26](#)

MIDlet does not find Authentication Server URL [5-27](#)

MIDlets fails to initialize [5-27](#)

MIDlets fails to start up properly [5-26](#)

MIDlet upgrade hangs [5-26](#)

MIDlet Upgrade Issues [5-26](#)

phon does not register [5-25](#)

phone does not display Cisco TelePresence idle screen [5-25](#)

Phone Firmware Issues [5-27](#)

#### Registration

CTS does not register with Unified CM [4-3](#)

CTS status shows unregistered or unknown [4-3](#)

##### CTS Unknown Issues

CTS MAC address is entered incorrectly [4-3](#)

CTS unregisters from time to time [4-3](#)

CTS was moved to a different Unified CM [4-2](#)

Directory Number Issues [4-3](#)

Hostname Issues [4-3](#)

Network Issues [4-3](#)

Profile or Provisioning Issues [4-3](#)

SIP Issues [4-3](#)

TFTP Issues [4-3](#)

XML Issues [4-3](#)

Supported Characters Issues [5-27](#)

TCP Issues [5-26](#)

verify phone in the system [5-25](#)

verify phone registration [5-25](#)

NTP settings [4-4](#)

time does not show correctly on the CTS or phone [4-4](#)

#### upgrading

codec type [3-3](#)

connecting a Touch device [3-20](#)

from a phone to the Touch device [3-3](#)

software CTS 1.7.4 and above [3-5](#)

software prior to CTS 1.7.4 [3-12](#)

Touch device kits [3-5](#)

---

## V

#### Verifying

registered devices [5-24](#)

---

## W

#### watermark removal

broadcast license [2-16](#)

#### WebEx

Adding a New Phone with MIDlets Capability [5-2](#)

---

## U

#### Unified CM Administration

