



Preface

This preface describes the organization and conventions of the *Cisco UCS Server Configuration Utility, Release 2.1*. It also provides information on how to obtain related documentation and submit a service request.

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in server, storage, and network administration and network security.

Organization

This guide is organized as follows:

Chapter	Title	Description
Chapter 1	Introduction to Cisco UCS-Server Configuration Utility	Provides an introduction to the utility and the features it provides.
Chapter 2	Getting Started with UCS-Server Configuration Utility	Contains information on getting started with the utility.
Chapter 3	Using UCS-Server Configuration Utility	Contains detailed instructions on using the utility.
Chapter 4	Troubleshooting and FAQs	Contains troubleshooting information and frequently asked questions.

Related Documentation

The documentation set for the Cisco Unified Computing System (UCS) C-Series rack-mount servers is described in the roadmap document at the following link:

[Cisco UCS C-Series Documentation Roadmap](#)

Send document comments to ucs-docfeedback@cisco.com

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.