



Preface

Revised: September 10, 2008, OL-15975-04

This document serves as the PacketCable Subscriber Provisioning (PCSP) Programmer's Guide for the Cisco BTS 10200 Softswitch.

Organization

This document is divided into the following chapters and appendixes:

- Chapter 1—[Overview](#)
- Chapter 2—[SOAP/XML Environment](#)
- Chapter 3—[Data Model](#)
- Chapter 4—[PCSP SOAP API](#)
- Chapter 5—[PCSP Rules and Mapping](#)
- Chapter 6—[PCSP Objects – XML Example \(PUT\)](#)
- Chapter 7—[Performance Considerations](#)
- Chapter 8—[Troubleshooting Guide](#)
- Appendix A—[Cisco BTS 10200 Extensions for PcsP Objects](#)
- Appendix B—[Sample Entity Encodings](#)

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Document Change History

The following table lists the revision history for the *Cisco BTS 10200 Softswitch PCSP Programmer's Guide, Release 6.0.x*.

Version Number	Issue Date	Status	Reason for Change
OL-15975-01	31 Mar 2008	Initial	Initial document for Release 6.0
OL-15975-02	9 Apr 2008	Revised	Removed capacity information
OL-15975-03	31 Jul 2008	Revised	Updated naming conventions
OL-15975-04	10 Sep 2008	Revised	Added provisioning chapter