



## INDEX

---

### A

- abbreviated dialing [3](#)
- About window, build versions might vary [15](#)
- adjunct licensing [9](#)
- administration tool
  - for audio IP address detection [9](#)
  - for unsupported VPN clients [9](#)
- advanced audio settings [11](#)
- alarms, displaying [17](#)
- application performance
  - degraded [14](#)
  - monitoring [19](#)
- audience, for this document [9](#)
- audio devices
  - installing [1](#)
  - selecting and tuning [1,5](#)
  - selection for audio modes [5](#)
  - supported [1](#)
  - tuning [5](#)
- audio formats, supported [12](#)
- audio IP address
  - and Administration Tool [9](#)
  - auto-detection of [9,10](#)
  - reflector web page for [9,10](#)
  - resolving problems with [9,10](#)
  - with VPN, how detected [9](#)
- audio modes, selecting devices for [5](#)
- audio port range, selections for [11](#)
- audio quality, troubleshooting [1](#)
- audio settings
  - common tuning mistakes [6](#)
  - configuring advanced [11](#)

- for remote use [12](#)
- audio tuning wizard
  - and Windows 2000 [15](#)
  - microphone tuning restrictions [15](#)
  - using [1,5](#)
- authenticated calls [14](#)
- authentication
  - certificate for device [13](#)
  - providing Quick Search information to users [13](#)
  - security profiles [14](#)
  - signaling [13](#)
- auto answer [3](#)
- auto-registration
  - for SIP devices [5](#)
  - using [6](#)
  - with TAPS [7](#)

---

### B

- background images
  - See custom background images
- background noise, reducing [11](#)
- barge [3](#)
- BAT, adding Cisco IP Communicator with [8](#)
- block external-to-external transfer [3](#)

---

### C

- caller ID [3](#)
- call-forward alternate party
  - See CFAP
- call forward display, configuring [4](#)
- call park [3](#)

- call pickup [3](#)
- call preferences, displaying [6](#)
- calls
  - authenticated [14](#)
  - digits not recognized [14](#)
  - display restrictions [3](#)
- Call Statistics screen, viewing locally [13](#)
- call waiting [3](#)
- CAPF, described [13](#)
- CDP [2](#)
- Certificate Authority Proxy Function
  - See CAPF
- certificate for device authentication [13](#)
- certificate trust list
  - See CTL [4](#)
- CFAP [5](#)
- checklist
  - for configuring after installation [1](#)
  - for deploying [2](#)
- Cisco Call Back [3](#)
- Cisco Discovery Protocol
  - See CDP
- Cisco IP Communicator
  - adding manually [8](#)
  - auto-registering [6](#)
  - configuring [1](#)
  - deploying [2](#)
  - deploying in SCCP and SIP environments [11](#)
  - described [1](#)
  - device web page for [14](#)
  - methods for adding [6](#)
  - registering [6](#)
  - resetting unexpectedly [14](#)
- Cisco IP Manager Assistant [4](#)
- Cisco IP Telephony Locale Installer [3](#)
- Cisco TAC Case Collection tool [2](#)
- Cisco Unified Communications Manager
  - configuring features for [1](#)
  - directory servers for [9](#)
  - interaction with Cisco IP Communicator [4](#)
  - releases supported [5](#)
  - requirements for Cisco IP Communicator [1](#)
  - with auto-registration and TAPS [7](#)
  - with BAT [8](#)
- client matter codes
  - See CMC
- client PC
  - deploying on [4](#)
  - requirements of [1](#)
- CMC [4](#)
- codecs
  - mismatches between IP Communicator and another device [10](#)
  - poor audio quality with low-bandwidth codecs and cell phones [10](#)
- command-line options
  - allowing SIP devices to auto-register [5](#)
  - displaying a dialog box that users must manually dismiss [6](#)
  - for the MSI package [4](#)
  - installing a language locale [5](#)
  - specifying a device name
    - free-form [5](#)
    - free-form and TFTP server addresses [5](#)
    - network interface [5](#)
    - network interface and TFTP server addresses [5](#)
  - specifying a TFTP server
    - multiple [5](#)
    - single [5](#)
  - specifying device name with [7](#)
  - specifying network interface with [7](#)
- common tuning mistakes [6](#)
- conference [4](#)
- configurable call forward display [4](#)
- configuration files
  - cnf.xml, described [6](#)
  - CTLFile.tlv, described [6](#)
  - damage to [6](#)
  - described [7](#)

- requesting at startup 6
  - requests for 7
  - types generated by TFTP server 8
  - xmldefault.cnf.xml, described 6
  - configuration server, locating at startup 5
  - conventions, use of 10
  - credentials
    - for Quick Search 13
    - providing to users 13
  - CTL file
    - and TLS connection 7
    - described 13
    - erasing 19
    - information displayed in Cisco IP Communicator 8
    - request for it during startup process 5
  - CTL File screen 8
  - custom background images
    - configuring 5
    - described 3
    - List.xml file format requirements 4
    - PNG file requirements 5
  - custom phone rings
    - described 1
    - PCM file requirements 2
- 
- ## D
- debug messages, displaying 17
  - deployment
    - checklist 2
    - methods 3
    - tools
      - for software updates 6
      - using 4
  - detailed logs, described 4
  - device authentication 13
  - device information
    - displaying call preferences 6
    - displaying line settings information 5
    - displaying SIP configuration information 4
    - viewing from web page 15
    - viewing locally 2
  - device logs, viewing remotely 17
  - device names
    - and docking station 8
    - and laptops 8
    - and MAC address 7
    - and network interface 7
    - and wireless interface 8
    - derivation of 7
    - for switching between SCCP and SIP configurations 12
    - selecting
      - after disabled or removed interface 8
      - described 7
      - multiple network interfaces 8
      - shared PCs 8
    - specifying
      - free-form name with command-line options 5
      - network interface with command-line options 5
    - troubleshooting 7
  - DHCP
    - at startup 5
    - described 2
  - dialing rules
    - for Quick Search 14
    - for SIP 8
  - directories
    - button 8
    - configuring 8
    - integrating 9
  - directory numbers, assigning
    - manually 8
    - with auto-registration 6
    - with BAT 8
    - with TAPS and auto-registration 7
  - directory search methods, overview 8
  - directory wizard

configuring Quick Search with [10](#)  
 tips for configuring [11](#)  
 direct transfer [4](#)  
 disk space, insufficient [5](#)  
 docking stations, and network interfaces [8](#)  
 do not disturb [4](#)  
 Dynamic Host Configuration Protocol  
     See DHCP

---

## E

echoes, resolving problems with [11](#)  
 enable logging setting [4](#)  
 Ethernet interface, and device name [8](#)  
 executable installer, using [2](#)  
 Extensible Markup Language  
     See XML

---

## F

FAC [4](#)  
 features, described [1](#)  
 firewalls, selecting port range for [11](#)  
 forced authorization codes  
     See FAC  
 forward [4](#)

---

## G

getIP.asp, creating for audio IP address detection [9](#)  
 group call pickup [4](#)  
 guide, conventions [10](#)

---

## H

hardware requirements [1](#)  
 headsets  
     See audio devices

hold [4](#)  
 HTTP  
     use of [3](#)  
 HyperText Transfer Protocol  
     See HTTP

---

## I

idle display, configuring [6](#)  
 immediate divert [4](#)  
 information needed by users [1](#)  
 installation  
     adding devices to the database [6](#)  
     checklist [2](#)  
     client PC requirements [1](#)  
     network requirements [1](#)  
     prerequisites [1](#)  
     requirements [1](#)  
 installer packages, described [3](#)  
 internal web server, disabling [14](#)  
 IP, described [3](#)

---

## J

join [4](#)

---

## L

language locale  
     prompted for during installation [4](#)  
     specifying with command-line option [5](#)  
 languages, support for [3](#)  
 laptops, and network interfaces [8](#)  
 LDAP  
     and personal directories [15](#)  
     use of [3](#)  
     with Quick Search [9](#)  
 licensing, adjunct

- configuring [9](#)
- described [9](#)
- restrictions [9](#)

Lightweight Directory Access Protocol

- See LDAP

line buttons, templates for [6](#)

line settings, displaying [5](#)

local configuration, understanding [13](#)

localization, installing Cisco IP Telephony Locale Installer [3](#)

Locally Significant Certificate

- See LSC

local settings access, disabling [13](#)

locked configuration options

- described [18](#)
- locked padlock icon [18](#)
- unlocking [18](#)

logging, enabling [4](#)

logs

- capturing detailed [4](#)
- collecting when the application crashes [3](#)

low bandwidth

- and digital cell phones [10](#)
- enabling [12](#)

LSC

- described [12](#)
- does not install issue [8](#)

---

## M

MAC address

- and device name [7](#)
- and network interface [7](#)

malicious caller identification

- See MCID

MCID [5](#)

meet-me conference [5](#)

message waiting [5](#)

Microsoft Windows Installer package (MSI), using [2](#)

MLPP [5](#)

model information [7](#)

multilevel precedence and preemption

- See MLPP

music-on-hold [5](#)

---

## N

network, disabling settings [13](#)

Network Configuration web page [16](#)

networking protocols

- BootP [2](#)
- CDP [2](#)
- DHCP [2](#)
- HTTP [3](#)
- IP [3](#)
- LDAP [3](#)
- RTP [3](#)
- SCCP [3](#)
- SDP [3](#)
- SIP [3](#)
- TCP [3](#)
- TFTP [4](#)
- TLS [4](#)
- UDP [4](#)
- XML [4](#)

network interface

- and device name [7](#)
- and docking stations [8](#)
- and laptops [8](#)
- and MAC address [7](#)
- Ethernet [8](#)
- removing or disabling [7](#)
- selecting [7](#)
- specifying with command-line options [7](#)
- troubleshooting [7](#)
- wireless [8](#)

network requirements, for installing [1](#)

noise suppression [11](#)

**O**

## one-way audio

- resolving problems with [11](#)
- with unsupported VPN clients [9](#)

## operational information

- overview [1](#)
- viewing locally [2](#)
- viewing remotely [14](#)

**P**passwords, providing to users [13](#)

## PCM

- custom ring type file requirements [2](#)
- described [1](#)

PC requirements [1](#)performance, improving for remote users [12](#)performance degraded from detailed logs [4](#)performance monitoring [19](#)

## personal address book service

- configuring [15](#)
- using Quick Search with [15](#)
- using synchronizer with [15](#)

personal directories [15](#)personal fast dial service [15](#)phone button templates, modifying [6](#)phone load information [7](#)

## phone screen

- configuring idle display [6](#)
- configuring images [3](#)

platform requirements [1](#)port range, selecting [11](#)

## post-installation tasks

- recommended [4](#)
- required [2](#)

privacy [5](#)

## privileges

- for deploying [3,4](#)

## Problem Reporting Tool

- caveats for roaming users [3](#)
- described [3](#)

## protocols

- call control running on Cisco IP Communicator [7](#)
- supported [2](#)

## pulse code modulation

See PCM

**Q**

## QoS

- network modifications to prioritize voice traffic [9](#)
- restricted range of RTP ports [11](#)

QRT [5](#)

- described [2](#)
- softkey [5,3](#)

## quality of service

See QoS

## Quality Reporting Tool

See QRT

## Quick Search

- described [9](#)
- dialing rules for [14](#)
- resolving problems with [14](#)
- specifying authentication information for [13](#)
- specifying credentials for [13](#)
- supported releases [11](#)
- with external directories [12](#)
- with the personal address book service [15](#)

**R**

## Real-Time Transport Protocol

See RTP

redial [5](#)

## registration

- failure [6,7](#)

- methods of [6](#)
- preparing for [2](#)
- with auto-registration [6](#)
- with BAT [8](#)
- with TAPS [7](#)

remote configuration, versus local [13](#)

remote use, settings for [12](#)

ring activity [5](#)

ringer

- customizing [3](#)
- selecting devices for [5](#)

RingList.xml

- described [1](#)
- file format requirements [2](#)

route patterns, with Quick Search [14](#)

RTP

- described [3](#)
- selecting audio port range [11](#)

## S

### SCCP

- converting existing IP Communicator installation to [11](#)
- described [3](#)
- using a device name to switch to SIP [12](#)

SDP, described [3](#)

secondary licensing

See licensing, adjunct

security

CTLFile.tlv, described [6](#)

resolving

- configuring IP error message [9](#)
- LSC does not install on client PC [8](#)
- registration rejected, security error message [8](#)

security and cryptographic features [12](#)

security configuration information, described [7](#)

security features

CAPF, described [13](#)

configuring with Release 4.x [15](#)

configuring with Release 5.x [16](#)

CTL file, described [13](#)

function of [12](#)

list of related topics [19](#)

locked padlock icon [18](#)

LSC, described [12](#)

supported [13](#)

verifying the configuration [18](#)

services

adding or deleting [8](#)

button [9](#)

configuring [7](#)

description [5](#)

subscribing to [8](#)

Services URL button [5](#)

Session Description Protocol

See SDP

Session Initiation Protocol

See SIP

settings button, disabling [13](#)

shared location, deploying to a [3](#)

shared PC

specifying device name for [8](#)

specifying network interface for [8](#)

specifying TFTP server for [7](#)

signaling authentication [13](#)

SIP

allowing auto-registration with command-line options [5](#)

converting

existing IP Communicator installation to [11](#)

new IP Communicator installation to [10](#)

described [3](#)

dialing rules [8](#)

using a device name to switch to SCCP [12](#)

SIP configuration information, displaying [4](#)

Skinny Client Control Protocol

See SCCP

- softkey templates, configuring 7
  - software
    - download site 6
  - software deployment tool
    - described 4
    - for updates 6
  - speed dial
    - described 5
    - templates for 6
  - SRST, IP address of router 9
  - startup
    - configuration tasks after 1
    - configuring audio devices after 5
    - improving performance for remote users 12
    - overview of 5
    - resolving problems with 5
    - resolving when unresponsive or slow 6
    - selecting device name after 7
    - selecting network interface after 7
    - specifying TFTP server after 6
  - statistics
    - call 13
    - sound sample mismatch 10
    - streaming 18
  - Status menu 9
  - Status Messages
    - screen, viewing locally 9
    - web page, viewing remotely 17
  - streaming statistics, viewing remotely 18
  - Survivable Remote Site Telephony
    - See SRST
- 
- T**
- TAC Case Collection tool 2
  - TAPS, with auto-registration 7
  - TCP, described 3
  - telephony features
    - abbreviated dialing 3
    - auto answer 3
    - barge 3
    - block external-to-external transfer 3
    - call display restrictions 3
    - caller ID 3
    - call park 3
    - call pickup 3
    - call waiting 3
    - Cisco Call Back 3
    - Cisco IP Manager Assistant 4
    - client matter codes 4
    - conference 4
    - configurable call forward display 4
    - direct transfer 4
    - do not disturb 4
    - forced authorization codes 4
    - forward 4
    - group call pickup 4
    - hold 4
    - immediate divert 4
    - join 4
    - malicious caller identification 5
    - meet-me conference 5
    - message waiting 5
    - multilevel precedence and preemption 5
    - music-on-hold 5
    - overview of 2
    - privacy 5
    - Quality Reporting Tool 5
    - redial 5
    - ring activity 5
    - services 5
    - Services URL button 5
    - speed dial 5
    - Time-of-Day Routing 6
    - transfer 6
    - video support 6
    - voice messaging system 6
  - TFTP

- at startup [5](#)
- described [4](#)
- use of [5](#)

TFTP server, specifying [6](#)

third-party headsets and handsets [2](#)

Time-of-Day Routing [6](#)

TLS

- described [4](#)
- establishing a connection [7](#)

tools

- Problem Reporting [3](#)
- Quality Report [2](#)

transfer [6](#)

Transmission Control Protocol

- See TCP

Transport Layer Security

- See TLS

Trivial File Transfer Protocol

- See TFTP

troubleshooting

- security problems [8](#)
- startup problems [5](#)
- viewing device logs [17](#)

trust list information, described [8](#)

Trust List screen [8](#)

tuning audio devices [5](#)

---

## U

UDP, described [4](#)

uninstall problem, all files not removed [5](#)

User Datagram Protocol

- See UDP

user information, providing [1](#)

users

- access to documentation and online help [4](#)
- adding [1](#)
- contact names to provide assistance [4](#)
- helping with configuration [14](#)

- how to report problems [4](#)
- information to complete configuration tasks [1](#)
- instructions for accessing voice messaging system [4](#)
- password information for [13](#)
- personal directory username and password [2](#)
- required information for [1](#)
- username and password for User Options web pages [2](#)

---

## V

video support [6](#)

voice messaging system [6](#)

voice quality

- disruptions, silences, jittery sounds [12](#)
- echoes [11](#)
- gaps in calls [10](#)
- no audio [10](#)
- QRT [2](#)
- robotic or distorted [12](#)
- with low-bandwidth codec and cell phone [10](#)

voice quality and voice gateways, diagnosing [2](#)

volume, for audio devices [5](#)

VPN clients

- audio IP address, how detected [9](#)
- supported software [9](#)
- support for [2](#)
- with audio IP address detection [9, 10](#)

---

## W

web page

- about [14](#)
- accessing [15](#)
- Device Information [15](#)
- for Cisco IP Communicator devices [14](#)
- Network Configuration [16](#)
- Status Messages [17](#)

web server, disabling [14](#)

Windows Performance Tool

setting up on Windows 2000 and XP [19](#)

setting up on Windows Vista [21](#)

wireless interface, and device name [8](#)

---

**X**

XML

use of [4](#)

with Quick Search [9](#)