



Release 1.1(1)



Cisco Unity Connection at a Glance for the Standard Conversation

Published November 11, 2005

This quick-reference card provides instructions for accessing Cisco Unity Connection by phone and for accessing the Cisco Unity web tools.

The card also illustrates the main Connection menus available to you as you manage your messages by phone using touchtone keys.



Tip

The first-time enrollment conversation plays automatically when you call Connection for the first time. You do not need to refer to this card during enrollment. Listen carefully, and respond as prompted.

To Access Connection by Phone

Step 1 Call Cisco Unity Connection.
From your desk phone, dial:

From another phone within your organization, dial:

From outside your organization, dial:

Step 2 If you are calling from another phone within your organization or from outside your organization, press * when Cisco Unity Connection answers.

Step 3 If prompted, enter your Cisco Unity Connection ID (usually your desk phone extension), and press #.

Step 4 Enter your Cisco Unity Connection password, and press #.
(If you forget your password, log on to the Cisco PCA and browse to the Personal Preferences page in the Cisco Unity Assistant to change it.)

In the following procedure, you use the Cisco Personal Communications Assistant (PCA) website to access the Cisco Unity Assistant, Cisco Unity Inbox, and Cisco Unity Personal Call Transfer Rules web tools.

To Access the Cisco Unity Web Tools

Step 1 In your web browser, go to <http://<Cisco Unity Connection server>/ciscopca>. (Note that the URL is case-sensitive.)

Step 2 Log on to the Cisco PCA.

Step 3 Browse to the applicable web tool.

Reference Information

Your Cisco Unity Connection ID

Cisco PCA Website

Cisco Unity Connection Server

Connection Administrator and/or Technical Support Contact Information

Additional Cisco Unity Connection Documentation

Cisco Unity Connection User Guide

Connection Phone Menus and Shortcuts

Connection Voice Commands

Corporate Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100




Cisco, Cisco IOS, Cisco Systems, and the Cisco Systems logo are registered trademarks of Cisco Systems, Inc. or its affiliates in the United States and certain other countries. All other brands, names, or trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0501R)

© 2005 Cisco Systems, Inc. All rights reserved.

01-8631-01
For Cisco Unity Connection Standard Conversation

Retrieve Messages




During Message

- 1 Restart message
- 2 Save
- 3 Delete
- 4 Slow playback
- 5 Change volume*
- 6 Fast playback
- 7 Rewind message
- 8 Pause/Resume
- 9 Fast-forward
- # Fast-forward to end
- # # Skip message, save as is

After Message


- 1 Replay message
- 2 Save/Restore as saved*
- 3 Delete
- 4 Reply
- 4 2 Reply to all
- 4 4 Call the user*
- 5 Forward message
- 6 Save as new/Restore as new*
- 7 Rewind message
- 9 Play message properties
- # Save as is

Find Voice Messages




- 1 From another user
- 2 From all outside callers
- 3 From a specific outside caller

Send a Message



Change Preferences



Use These Keys Anytime



*Not available on some systems.