



Release 1.2(1)

Cisco Unity Connection at a Glance for Optional Conversation 1

Published June 14, 2006

This quick-reference card provides instructions for accessing Cisco Unity Connection by phone and for accessing the Cisco Unity web tools.

The card also illustrates the main Connection menus available to you as you manage your messages by phone using touchtone keys.



Tip

The first-time enrollment conversation plays automatically when you call Connection for the first time. You do not need to refer to this card during enrollment. Listen carefully, and respond as prompted.

To Access Connection by Phone

Step 1 Call Cisco Unity Connection.
From your desk phone, dial:

From another phone within your organization, dial:

From outside your organization, dial:

Step 2 If you are calling from another phone within your organization or from outside your organization, press * when Cisco Unity Connection answers.

Step 3 If prompted, enter your Cisco Unity Connection ID (usually your desk phone extension), and press #.

Step 4 Enter your Cisco Unity Connection password, and press #.

(If you forget your password, log on to the Cisco PCA and browse to the Personal Preferences page in the Cisco Unity Assistant to change it.)

In the following procedure, you use the Cisco Personal Communications Assistant (PCA) website to access the Cisco Unity Assistant, Cisco Unity Inbox, and Cisco Unity Personal Call Transfer Rules web tools.

To Access the Cisco Unity Web Tools

Step 1 In your web browser, go to `http://<Cisco Unity Connection server>/ciscopca`. (Note that the URL is case-sensitive.)

Step 2 Log on to the Cisco PCA.

Step 3 Browse to the applicable web tool.

Reference Information

Your Cisco Unity Connection ID

Cisco PCA Website

Cisco Unity Connection Server

Connection Administrator and/or Technical Support Contact Information

Additional Cisco Unity Connection Documentation

Cisco Unity Connection User Guide

Connection Voice Commands

Corporate Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100



Cisco, Cisco IOS, Cisco Systems, and the Cisco Systems logo are registered trademarks of Cisco Systems, Inc. or its affiliates in the United States and certain other countries. All other brands, names, or trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0501R)

© 2006 Cisco Systems, Inc. All rights reserved.

Retrieve Messages

- 1 New
- 3 1 Saved
- 3 2 Deleted*

- ### During Message
- 1 1 Rewind message
 - 2 2 Pause/Resume
 - 3 3 Fast-forward
 - 3 3 Fast-forward to end
 - 4 4 Slow playback
 - 4 4 Slower playback
 - 5 5 Play message properties
 - 6 6 Fast playback
 - 6 6 Faster playback
 - 7 7 Decrease volume*
 - 8 8 Reset volume*
 - 9 9 Increase volume*
 - # Skip message, save as is
 - # Skip message, save as new (new and saved messages)


- ### After Message
- 1 1 Skip back
 - 4 4 Replay message
 - 5 5 Play message properties
 - 6 6 Forward message
 - 7 7 Delete
 - 8 8 Reply
 - 8 2 Reply to all
 - 8 8 Call the user*
 - 9 9 Save/Restore as saved*
 - # Save as is
 - # Save as new/Restore as new*

Find Voice Messages


- 5 Find messages*

- 1 From another user
- 2 From all outside callers
- 3 From a specific outside caller

Send a Message



Change Preferences



Use These Keys Anytime

- 0 Help
- * Cancel or back up

*Not available on some systems.