



A

adding

- Catalyst 6000 FXS ports [6-22](#)
 - Catalyst 6000 FXS ports to Cisco CallManager [6-29](#)
 - CTI ports [3-2](#)
 - lines to phone template [3-4](#)
 - phones [3-2](#)
 - phone template [3-3](#)
 - services to phone template [3-5](#)
 - speed dial settings to phone template [3-6](#)
 - user device profiles [5-2, 5-10](#)
 - users [4-1](#)
 - users to Cisco CallManager [4-8](#)
 - VG200 FXS or FXO gateways to Cisco CallManager [6-17](#)
 - VG200 gateways and ports [6-2](#)
 - VG200 T1-CAS, T1-PRI, or E1-PRI gateways to Cisco CallManager [6-17](#)
- auto-registration [7-1](#)

B

BAT

- browser requirements [1-4](#)

- default location of log files [8-13](#)
- error messages [8-15](#)
- installation overview [2-1](#)
- installing [2-3](#)
- log files [8-13](#)
- logging on [1-5](#)
- online help [1-5](#)
- overview [1-1](#)
- specifications [1-3](#)
- starting [1-4](#)
- stopping [1-6](#)
- troubleshooting [8-13, 8-15](#)
- uninstalling [2-8](#)
- upgrading [2-2](#)
- using [1-4](#)
- version [1-5](#)
- viewing log files [8-14](#)

BAT.xlt

- create CSV for CTI ports [3-8](#)
- create CSV for CTI ports-users [3-8](#)
- create CSV for phones [3-8](#)
- create CSV for phones-users [3-8](#)
- create CSV for users [4-3, 4-12](#)
- creating Catalyst 6000 FXS ports [6-26](#)
- file location [2-3](#)

browser requirements [1-4](#)

C

Cisco CallManager

- adding Catalyst 6000 FXS ports [6-29](#)
- adding CTI ports [3-18](#)
- adding phones [3-18, 3-20](#)
- adding phones and users [3-20](#)
- adding users [4-8](#)
- adding VG200 FXS or FXO gateways [6-17](#)
- adding VG200 T1-CAS, T1-PRI, or E1-PRI gateways [6-17](#)
- auto-registration must be enabled for TAPS [7-1](#)

Cisco Catalyst 6000 FXS ports

- adding or updating ports [6-22](#)
- adding ports [6-22](#)
- adding to Cisco CallManager [6-29](#)
- creating BAT template [6-23](#)
- creating CSV file [6-24](#)
- deleting ports [6-35](#)
- deleting template [6-38](#)
- field descriptions [6-64](#)
- limit of 500 [6-26](#)
- overview [6-1, 6-21](#)
- updating [6-32](#)

Cisco CRA

- required for TAPS [7-2](#)
- troubleshooting TAPS [8-19](#)

uninstalling TAPS [2-9](#)

uploading TAPS [2-7](#)

Cisco IP IVR

required for TAPS [7-2](#)

Cisco VG200

- adding gateways and ports [6-2](#)
- adding to Cisco CallManager (FXS or FXO) [6-17](#)
- adding to Cisco CallManager (T1-CAS, T1-PRI, or E1-PRI) [6-17](#)
- configure using CLI prior to adding gateways in BAT [6-1](#)
- copying a template [6-19](#)
- creating a template [6-3](#)
- creating CSV file for FXS or FXO [6-8](#)
- creating CSV file for T1-CAS, T1-PRI, or E1-PRI [6-10](#)
- delete only selected gateways [6-20](#)
- deleting BAT template [6-38](#)
- deleting gateways [6-20](#)
- field descriptions for E1-PRI [6-51](#)
- field descriptions for FXO [6-42](#)
- field descriptions for FXS [6-40](#)
- field descriptions for T1-CAS [6-45](#)
- field descriptions for T1-PRI [6-51](#)
- overview [6-1](#)
- updating endpoint identifiers [6-7](#)

CLI [6-1](#)

command line interface [6-1](#)

configure TAPS [7-3](#)

configuring

- user device profiles [5-2](#)
- configuring TAPS [7-3](#)
- copying
 - Catalyst 6000 FXS ports template [6-31](#)
 - gateway directory number template [6-37](#)
 - phone template [3-23](#)
 - VG200 template [6-19](#)
- create dummy MAC address [3-12](#), [3-19](#), [3-21](#)
- creating
 - Catalyst 6000 FXS ports template [6-23](#)
 - CSV file for Catalyst 6000 FXS ports [6-24](#)
 - CSV file for phones [3-7](#)
 - CSV file for user device profile [5-4](#)
 - CSV file for VG200 FXS or FXO [6-8](#)
 - CSV file for VG200 T1-CAS, T1-PRI, or E1-PRI [6-10](#)
 - phone template [3-3](#)
 - template for gateway directory number [6-36](#)
 - user device profiles template [5-2](#)
 - VG200 template [6-3](#)
- CSV
 - Catalyst 6000 FXS ports [6-24](#)
 - creating a BAT.xlt for users [4-3](#), [4-12](#)
 - creating a text-based file for Catalyst 6000 FXS ports [6-28](#)
 - creating a text-based file for phones, phones-users combination, CTI ports, or CTI ports-users combination [3-13](#)
 - creating a text-based file for update users [4-14](#)
 - creating a text-based file for user device profiles [5-7](#)
 - creating a text-based file for users [4-5](#)
 - creating a text-based file for VG200 gateways and ports [6-13](#)
 - creating for user device profile [5-4](#)
 - CTI ports [3-7](#)
 - no blank lines [3-10](#), [5-5](#)
 - phone [3-7](#)
 - required location for saving files [4-6](#), [4-14](#), [5-7](#)
 - retaining stored values [4-16](#)
 - text file for phones [3-13](#), [6-13](#), [6-28](#)
 - tips for creating text-based CSV for user device profiles [5-8](#)
 - tips for creating text-based CSV for user device profiles with two lines [5-9](#)
 - tips for creating text-based CSV for users [4-7](#), [4-15](#)
 - tips for creating text-based file for phones, phones-users, CTI ports, or CTI ports-users [3-14](#)
 - using BAT.xlt for Catalyst 6000 FXS ports [6-26](#)
 - using BAT.xlt for phones [3-8](#), [3-9](#)
 - using BAT.xlt for phone-user combination [3-8](#), [3-9](#)
 - using BAT.xlt for update users [4-11](#)
 - using BAT.xlt for users [4-2](#)
 - VG200 for FXS or FXO [6-8](#)
 - VG200 for T1-CAS, T1-PRI, or E1-PRI [6-10](#)
- CTI ports
 - adding [3-2](#)

- adding CTI ports-users combination to Cisco CallManager [3-20](#)
- adding to Cisco CallManager [3-18](#)
- associating new port to existing user [3-7](#)
- creating CSV file [3-7](#)
- directory number must match number of lines in template [3-8](#)
- enable authentication proxy rights [3-21](#)
- enable CTI application use [3-19, 3-21](#)
- using BAT.xlt to create CSV [3-8, 3-9](#)
- using BAT.xlt to create CSV for CTI ports-users combination [3-8, 3-9](#)
- using dummy MAC address option [3-19, 3-21](#)

D

deleting

- Catalyst 6000 FXS ports [6-35](#)
- Catalyst 6000 FXS ports template [6-38](#)
- gateway directory number template [6-38](#)
- phones [3-31](#)
- selected VG200 gateways [6-20](#)
- user device profiles [5-11](#)
- users [4-18](#)
- VG200 gateways [6-20](#)
- VG200 template [6-38](#)

directory number

- creating gateway template [6-36](#)
- securing from TAPS [7-7](#)

downloading

- phone configuration using TAPS [7-12](#)
- dummy MAC address [3-12, 3-19, 3-21](#)
 - generate a list of phones with [3-29](#)
 - MAC address [3-29](#)

E

E1-PRI

- adding VG200 gateways to Cisco CallManager [6-17](#)
- creating the CSV file for VG200 gateways [6-10](#)
- field descriptions for VG200 [6-51](#)
- enable authentication proxy rights
 - adding users [4-9](#)
 - for CTI ports and users [3-21](#)
 - for phones and users [3-21](#)
- enable CTI application use
 - adding users [4-9](#)
 - CTI ports [3-19](#)
 - CTI ports and users [3-21](#)
 - phones [3-19](#)
 - phones and users [3-21](#)
- endpoint identifiers, updating [6-7](#)
- error messages, BAT [8-15](#)
- Export to BAT Format button does not work in BAT.xlt file [8-15](#)

F

field descriptions

- adding or updating lines [3-41](#)

- adding or updating lines to UDP template [5-13](#)

- Catalyst 6000 FXS ports [6-64](#)

- gateway directory number template [6-66](#)

- ground start [6-42](#)

- loop start [6-42](#)

- phone template [3-34, 3-47](#)

- VG200 - E1-PRI [6-51](#)

- VG200 - FXO [6-42](#)

- VG200 - FXS [6-40](#)

- VG200 - T1-CAS [6-45](#)

- VG200 - T1-PRI [6-51](#)

FXO

- adding VG200 gateways to Cisco CallManager [6-17](#)

- field descriptions [6-42](#)

FXS

- adding Catalyst 6000 ports to Cisco CallManager [6-29](#)

- adding or updating ports for Catalyst 6000 ports [6-22](#)

- adding VG200 gateways to Cisco CallManager [6-17](#)

- creating BAT template for Catalyst 6000 ports [6-23](#)

- creating CSV file for Catalyst 6000 ports [6-24, 6-26](#)

- creating CSV file for VG200 gateways [6-8](#)

- creating the CSV file for VG200 gateways [6-8](#)

- deleting Catalyst 6000 ports [6-35](#)

- field descriptions for Catalyst 6000 ports [6-64](#)

- field descriptions for VG200 [6-40](#)

- updating Catalyst 6000 ports [6-32](#)

G

gateway

- Cisco Catalyst 6000 FXS ports [6-1](#)

- Cisco VG200

- overview [6-1](#)

gateway directory number

- copying template [6-37](#)

- deleting template [6-38](#)

- field descriptions for template [6-66](#)

- template [6-36](#)

gateway directory number template

- required if you specified directory numbers [6-36](#)

- ground start, field descriptions [6-42](#)

H

- halting TAPS [7-7](#)

- help [1-5](#)

I

inserting

- user device profiles [5-10](#)

installing

- BAT/TAPS [2-3](#)

- BAT/TAPS prerequisites [2-3](#)

- completing TAPS installation [2-7](#)

- no backward template migration [2-2](#)

- no template migration when upgrading from release 3.0(3) [2-2](#)

- overview [2-1](#)

- TAPS [2-5](#)

- TAPS after BAT has already been installed [2-5](#)

- TAPS prerequisites [2-5](#)

- template migration during upgrade [2-2](#)

- instructions, TAPS for end-users [7-12](#)

L

lines

- adding or updating [3-4](#)

- field descriptions for adding or updating [3-41](#)

- field descriptions for adding or updating to UDP template [5-13](#)

- maximum number [3-5](#)

- updating [3-27](#)

log files

- BAT [8-13](#)

- explanation of file naming convention [8-14](#)

- viewing [8-14](#)

- logging on to BAT [1-5](#)

- loop start,field descriptions [6-42](#)

M

MAC address

- dummy MAC address [3-29](#)

- generate a list of phones with dummy [3-29](#)

- module in slot [6-4](#)

N

- NM-1V [6-4](#)

- NM-2V [6-4](#)

- NM-HDV [6-4](#)

O

overview

- adding or updating FXS ports for Catalyst 6000 modules [6-22](#)

- adding VG200 gateways and ports [6-2](#)

- BAT [1-1](#)

- Catalyst 6000 FXS ports [6-21](#)

- creating CSV files for FXS ports on Catalyst 6000 modules [6-24](#)

- gateway directory number [6-36](#)

- TAPS [7-1, 7-2](#)

working with gateways and ports [6-1](#)

P

password, value is mandatory [3-17](#)

phone

adding [3-2](#)

adding a template [3-3](#)

adding or updating lines [3-4](#)

adding or updating services [3-5](#)

adding or updating speed dial settings [3-6](#)

adding phones-users combination to Cisco CallManager [3-20](#)

adding to Cisco CallManager [3-18, 3-20](#)

BAT reaction if line information fails during insert [3-23](#)

copying a template [3-23](#)

creating CSV file [3-7](#)

CSV text file [3-13, 6-13, 6-28](#)

deleting [3-31](#)

deleting templates [3-32](#)

enable authentication proxy rights [3-21](#)

enable CTI application use [3-19, 3-21](#)

field descriptions for phone template [3-34, 3-47](#)

generate a list of phones with dummy MAC addresses [3-29](#)

updating [3-25](#)

updating lines [3-27](#)

using BAT.xlt to create CSV for phone [3-8, 3-9](#)

using dummy MAC address option [3-12, 3-19, 3-21](#)

PIN, value is mandatory [3-17](#)

ports

adding CTI [3-2](#)

adding VG200 [6-2](#)

prerequisites

BAT/TAPS [2-3](#)

TAPS [2-5](#)

Q

query

updating lines [3-27](#)

updating phones [3-25](#)

R

removing

user device profiles [5-11](#)

repository manager [2-7](#)

reset devices after update [3-26](#)

restart devices after update [3-26](#)

S

secure TAPS [7-7](#)

securing directory numbers from TAPS [7-7](#)

services, adding or updating [3-5](#)

specifications [1-3](#)
 speed dial settings, adding or updating [3-6](#)
 starting
 BAT [1-4](#)
 TAPS [7-6](#)
 stopping
 BAT [1-6](#)
 TAPS [7-7](#)
 sub-unit [6-4](#)

T

T1-CAS

adding VG200 gateways to Cisco CallManager [6-17](#)
 creating the CSV file for VG200 gateways [6-10](#)
 field descriptions for VG200 [6-45](#)

T1-PRI

adding VG200 gateways to Cisco CallManager [6-17](#)
 creating the CSV file for VG200 gateways [6-10](#)
 field descriptions for VG200 [6-51](#)

TAPS

auto-registration must be enabled [7-1](#)
 Cisco CRA required [7-2](#)
 Cisco IP IVR required [7-2](#)
 completing installation [2-7](#)
 completing uninstallation [2-9](#)

configuring [7-3](#)
 halting [7-7](#)
 installing [2-3, 2-5](#)
 installing once BAT is already installed [2-5](#)
 instructions for end-users [7-12](#)
 overview [7-1, 7-2](#)
 securing directory numbers [7-7](#)
 starting [7-6](#)
 stopping [7-7](#)
 taps.aef [2-7](#)
 troubleshooting [8-13, 8-19](#)
 troubleshooting on the Cisco CRA server [8-19](#)
 uninstalling [2-8](#)
 uploading to Cisco CRA Administration server [2-7](#)
 version [1-6](#)
 taps.aef [2-7](#)
 template
 adding or updating lines [3-4](#)
 adding or updating services [3-5](#)
 adding or updating speed dial settings [3-6](#)
 BAT.xlt file location [2-3](#)
 copying Catalyst 6000 FXS ports [6-31](#)
 copying gateway directory number [6-37](#)
 copying phone [3-23](#)
 copying VG200 [6-19](#)
 creating Catalyst 6000 FXS ports [6-23](#)
 creating VG200 [6-3](#)
 deleting Catalyst 6000 FXS ports [6-38](#)

- deleting gateway directory number [6-38](#)
- deleting phone [3-32](#)
- deleting VG200 [6-38](#)
- field descriptions for adding or updating lines [3-41](#)
- field descriptions for adding or updating lines to UDP template [5-13](#)
- field descriptions for Catalyst 6000 ports [6-64](#)
- field descriptions for gateway directory number [6-66](#)
- field descriptions for phone [3-34](#), [3-47](#)
- field descriptions for VG200 - E1-PRI or T1-PRI [6-51](#)
- field descriptions for VG200 - FXO [6-42](#)
- field descriptions for VG200 - FXS [6-40](#)
- field descriptions for VG200 - T1-CAS [6-45](#)
- gateway directory number [6-36](#)
- gateway directory number is required if you specified directory numbers [6-36](#)
- migration during upgrade [2-2](#)
- no backward migration [2-2](#)
- overview of gateway directory number [6-36](#)
- phone [3-3](#)
- user device profiles [5-2](#)
- troubleshooting
 - BAT [8-15](#)
 - BAT and TAPS [8-13](#)
 - couldn't create user object. Check if DC Directory is running [8-18](#)
 - data files (CSV) format do not match phone template/sample file [8-15](#)
 - directory number cannot be added without at least one MAC address [8-18](#)
 - errors occur when using the dummy MAC address option [8-16](#)
 - Export to BAT Format button does not work in BAT.xlt file [8-15](#)
 - MAC address values are not allowed in the file if dummy MAC address values are desired [8-18](#)
 - null value for mandatory field is not allowed [8-16](#)
 - partition details can be added only with corresponding directory number [8-16](#)
 - port data in record number n does not match the corresponding sample file/number of lines and speed dials in phone template chosen [8-17](#)
 - port identifier contains invalid endpoint prefix [8-17](#)
 - port identifier contains invalid port number [8-17](#)
 - port number not configured in the template [8-17](#)
 - preprocess exception [8-20](#)
 - provider exception [8-21](#)
 - same directory number cannot be assigned twice to a device in the same partition [8-18](#)
 - selected template does not contain DN details for directory number [8-16](#)
 - TAPS [8-19](#)
 - TAPS on the Cisco CRA server [8-19](#)
 - the page cannot be displayed [8-15](#)

when the Cisco CRA server starts, the JTAPI subsystem shows partial service or out of service [8-19](#)

U

uninstalling

BAT/TAPS [2-8](#)

removing TAPS from Cisco CRA Administration server [2-9](#)

update users

creating CSV file [4-11](#)

creating text-based CSV file [4-14](#)

updating

Catalyst 6000 FXS ports [6-22, 6-32](#)

endpoint identifiers [6-7](#)

lines [3-27](#)

lines for phone template [3-4](#)

phone configuration using TAPS [7-12](#)

phones [3-25](#)

services to phone template [3-5](#)

speed dial settings to phone template [3-6](#)

users [4-10](#)

upgrading BAT [2-2](#)

uploading TAPS to the Cisco CRA Administration server [2-7](#)

user

using BAT.xlt for phone-user combination [3-9](#)

user device profile

CSV file [5-4](#)

user device profiles

adding [5-2, 5-10](#)

configuring [5-2](#)

creating a template [5-2](#)

creating text-based CSV file [5-7](#)

deleting [5-11](#)

inserting [5-10](#)

removing [5-11](#)

users

adding [4-1](#)

adding to Cisco CallManager [4-8](#)

BAT.xlt [4-3, 4-12](#)

creating CSV file [4-2](#)

creating text-based CSV file [4-5](#)

deleting [4-18](#)

updating [4-10](#)

using BAT.xlt for phone-user combination [3-8](#)

V

version [1-5, 1-6](#)

VIC-2FXO [6-5](#)

VIC-2FXS [6-5](#)

Viewing log files [8-14](#)

VWIC-1MFT-E1 [6-5](#)

VWIC-1MFT-T1 [6-5](#)

VWIC-2MFT-E1 [6-5](#)

VWIC-2MFT-T1 [6-5](#)