



A

adding lines

field descriptions for BAT spreadsheet [3-84](#)

field descriptions for template [3-25](#)

to existing phones [3-81](#)

to existing phones using BAT
spreadsheet [3-83](#)

to existing user device profiles [3-81](#)

to phone template [3-4](#)

associating file format for text-based CSV
file [3-55, 6-25](#)

authentication proxy rights

adding phones with users [4-27](#)

enable when adding users [4-7](#)

updating users [4-14](#)

auto-registration, enabled for Unified CM
Auto-Register Phone Tool [12-3](#)

auto-registration options, configuring [12-12](#)

B

BAT

application overview [1-1](#)

browser requirements [1-16](#)

configuration process overview [1-3](#)

error messages [13-3](#)

installation overview [2-1](#)

installing [2-2](#)

location of export log files [10-18](#)

location of report log files [11-15](#)

log files location [13-1](#)

logging on [1-17](#)

online help [1-18](#)

specifications [1-15](#)

starting [1-16](#)

stopping transactions [1-19](#)

troubleshooting [13-3](#)

troubleshooting performance [13-8](#)

uninstalling [2-4](#)

upgrading [2-2](#)

user interface, navigating [1-17](#)

using the menus [1-17](#)

version [1-19](#)

BAT.xlt, see BAT spreadsheet

BAT export utility, see exporting

BAT Performance [1](#)

BAT spreadsheet

adding lines to existing phones [3-83](#)

BAT.xlt file location [2-3](#)

Catalyst 6000 FXS ports [7-20](#)

- Cisco Unified CallManager Assistant custom manager assistant for proxy mode [5-17](#)
 - Cisco Unified CallManager Assistant default manager assistant [5-15](#)
 - field descriptions
 - adding lines [3-84](#)
 - updating users [4-12](#)
 - user device profile [6-10](#)
 - installing BAT.xlt [2-3](#)
 - IP telephony devices [3-40](#)
 - manager assistant associations [5-14](#)
 - overview [1-11](#)
 - phones [3-40](#)
 - phones with users [4-24](#)
 - user device profile [6-8](#)
 - users [4-2](#)
 - using for CSV data file [1-11](#)
 - VG200 gateway (FXS or FXO) [7-11](#)
 - VG200 gateway for T1 CAS or T1/E1 PRI [7-13](#)
 - BAT spreadsheet (BAT.xlt) file location [2-3](#)
 - browser requirements [1-16](#)
-
- C
- calling party number modification
 - adding phones with users [4-27](#)
 - enable when adding users [4-8](#)
 - updating users [4-15](#)
 - call park retrieval
 - adding phones with users [4-27](#)
 - enable when adding users [4-7](#)
 - updating users [4-14](#)
 - Call Pickup Groups
 - BAT considerations [9-1](#)
 - BAT settings for inserting CSV file (table) [9-9](#)
 - creating a CSV file (BAT.xlt) [9-2](#)
 - creating custom CSV file (text-based) [A-31](#)
 - CSV file settings (table) [9-6](#)
 - inserting CSV file in BAT [9-8](#)
 - updating existing CSV file [9-4](#)
 - using query to delete call pickup groups [9-5](#)
 - Catalyst 6000 FXS ports
 - creating CSV data file [7-20](#)
 - creating template [7-19](#)
 - deleting ports [7-25](#)
 - field descriptions for template [7-62](#)
 - inserting to Cisco Unified CallManager [7-22](#)
 - overview [7-18, 7-19](#)
 - text-based CSV file, creating [A-25](#)
 - text-based CSV file format [A-26](#)
 - updating [7-23](#)
 - Cisco Catalyst 6000 FXS Analog Interface Modules, see Catalyst 6000 FXS ports
 - Cisco CRS
 - configuring Unified CM Auto-Register Phone Tool [12-8](#)
 - required for Unified CM Auto-Register Phone Tool [12-2](#)

- troubleshooting Unified CM Auto-Register Phone Tool [13-10](#)
- uninstalling Unified CM Auto-Register Phone Tool [12-10](#)
- Cisco Customer Response Solutions, see Cisco CRS
- Cisco Unified CallManager
 - configuring Unified CM Auto-Register Phone Tool [12-7](#)
 - enable auto-registration for Unified CM Auto-Register Phone Tool [12-3](#)
 - inserting
 - Catalyst 6000 FXS ports [7-22](#)
 - Cisco Unified CallManager Assistant manager-assistant associations [5-19](#)
 - CTI ports [3-57](#)
 - H.323 clients [3-57](#)
 - phones [3-57](#)
 - phones with users [4-25](#)
 - user device profiles [6-27](#)
 - users [4-6](#)
 - VG200 gateway (FXS or FXO) [7-15](#)
 - VG200 gateway (T1 CAS or T1/E1 PRI) [7-15](#)
 - overview of inserting records [1-13](#)
 - phones
 - shared line example [5-13](#)
- Cisco Unified CallManager Assistant
 - assistant template for proxy mode [5-4](#)
 - creating CSV data file [5-14](#)
 - deleting assistants
 - described [5-25](#)
 - using custom file [5-27](#)
 - using query [5-25](#)
 - deleting manager-assistant associations [5-20](#)
 - deleting managers
 - described [5-22](#)
 - using custom file [5-24](#)
 - using query [5-22](#)
 - generating reports [11-13](#)
 - inserting manager-assistant associations [5-19](#)
 - manager and assistant line configurations, proxy mode [5-5](#)
 - manager and assistant shared line configurations [5-13](#)
 - manager template for proxy mode [5-4](#)
 - overview [5-1](#)
 - phones
 - assistant configuration options [5-7](#)
 - manager configuration options [5-7](#)
 - proxy line example [5-8](#)
 - proxy lines on existing [5-10](#)
 - proxy lines on new [5-9](#)
 - proxy mode [5-2](#)
 - shared line mode [5-11](#)
 - setting up phones and lines [5-2](#)
 - text-based CSV file, creating [A-20](#)
 - text-based CSV file custom format [A-22](#)
- Cisco Unified CallManager Auto-Register Phone Tool
 - Cisco CRS required [12-2](#)

- Cisco Unified IP-IVR required [12-2](#)
- completing uninstallation [12-10](#)
- configuring auto-registration options [12-12](#)
- configuring in Cisco Unified CallManager [12-7](#)
- configuring on Cisco CRS server [12-8](#)
- enable auto-registration [12-3](#)
- installation overview [12-5](#)
- instructions for end-users [12-18](#)
- language prompts [12-5](#)
 - adding [12-17](#)
 - removing [12-18](#)
- log files location [13-8](#)
- overview [12-1](#)
- reloading configurations [12-4](#)
- requirements [12-2](#)
- securing directory numbers [12-4, 12-13](#)
- setting options for using [12-12](#)
- setting user locales [12-17](#)
- starting [12-11](#)
- stopping [12-11](#)
- troubleshooting [13-8](#)
- uninstalling [12-9](#)
- Cisco Unified IP-IVR
 - required for Unified CM Auto-Register Phone Tool [12-2](#)
- Cisco VG200 gateway, see VG200 gateway
- Client Matter Codes
 - BAT considerations [8-3](#)
 - BAT settings for inserting CSV file (table) [8-14](#)
 - configuration checklist (table) [8-2](#)
 - creating a CSV file (BAT.xlt) [8-4](#)
 - creating custom CSV file (text-based) [A-28](#)
 - CSV file settings (table) [8-10](#)
 - deleting code settings (BAT) [8-7](#)
 - inserting CSV file in BAT [8-12](#)
 - updating existing CSV file [8-6](#)
- configuring Cisco Unified CallManager records, process [1-3](#)
- copying
 - file format for text-based CSV [6-23](#)
 - file format for text-based CSV file [3-53](#)
 - phone template [3-8](#)
 - template [6-6](#)
- Couldn [13-6](#)
- CSV, comma separated values text file [1-2, A-1](#)
- CSV, text-based
 - Catalyst 6000 FXS ports, creating [A-25](#)
 - Catalyst 6000 FXS ports format [A-26](#)
 - CMC
 - options [8-5](#)
 - CPG
 - options [9-4](#)
 - CTI ports format [A-5](#)
 - CTI ports-users format [A-6](#)
 - FAC
 - options [8-5](#)
 - FXO or FXS ports format [A-23](#)

- H.323 clients format [A-5](#)
 - H.323 client-users format [A-6](#)
 - IP phone, VGC phone, VGC Virtual Phone format [A-4](#)
 - manager assistant associations
 - creating [A-20](#)
 - custom format [A-22](#)
 - manager assistant default formats [A-21](#)
 - overview [A-1](#)
 - phones
 - creating [A-2](#)
 - export file, all details [A-7](#)
 - options [3-51](#)
 - tips for creating [A-3](#)
 - with users format [A-5](#)
 - T1 CAS, T1/E1 PRI format [A-24](#)
 - user device profile format [A-16](#)
 - user device profile options [6-21](#)
 - user device profiles
 - creating [A-15](#)
 - export file [A-18](#)
 - two lines format [A-17](#)
 - users
 - creating [A-11](#)
 - format [A-12](#)
 - updating [A-13, A-30, A-31, A-33](#)
 - VG200 gateways, creating [A-22](#)
- CSV data file
- adding new devices [1-7](#)
 - overview [1-6](#)
 - updating existing devices [1-7](#)
 - using BAT spreadsheet (BAT.xlt) [1-11](#)
- CTI application use
- adding phones with users [4-27](#)
 - enable when adding users [4-7](#)
 - phones [3-57](#)
 - updating users [4-14](#)
- CTI ports
- deleting [3-87](#)
 - dummy MAC address, using [3-58, 4-26](#)
 - enable CTI application use [3-57](#)
 - text-based CSV format [A-5](#)
- CTI ports-users
- text-based CSV format [A-6](#)
- custom file
- deleting Cisco Unified CallManager Assistant managers [5-24, 5-27](#)
 - deleting phones [3-89](#)
 - deleting users [4-18](#)
 - updating phones [3-61](#)
 - using [1-8](#)
 - using to reset password and PIN [4-21](#)
-
- D
- deleting
- call pickup groups [9-5](#)
 - Catalyst 6000 FXS ports [7-25](#)
 - Cisco Unified CallManager Assistant assistants [5-25](#)

- Cisco unified CallManager Assistant managers [5-22](#)
 - file format for text-based CSV file [3-54, 6-25](#)
 - manager-assistant associations [5-20](#)
 - phones using custom files [3-89](#)
 - phones using query [3-87](#)
 - phone template [3-9](#)
 - template [6-7](#)
 - user device profiles [6-31](#)
 - users [4-16](#)
 - VG200 gateway [7-16](#)
 - directory number
 - lifting restrictions [12-15](#)
 - list of restricted [12-16](#)
 - remove all restrictions from Unified CM Auto-Register Phone Tool [12-16](#)
 - restricting from Unified CM Auto-Register Phone Tool [12-14](#)
 - securing from Unified CM Auto-Register Phone Tool [12-13](#)
 - template for gateway [7-3](#)
 - downloading phone configuration using Unified CM Auto-Register Phone Tool [12-18](#)
 - dummy MAC address [3-42, 3-58, 4-26](#)
 - generate a list [11-6](#)
 - field descriptions for VG200 gateway template [7-46](#)
 - text-based CSV file format [A-24](#)
 - endpoint identifiers, updating [7-9](#)
 - error messages, BAT [13-3](#)
 - exported fields
 - all phone details [10-4](#)
 - all user device profile details [10-14](#)
 - default phone details [10-3](#)
 - default user device profile details [10-16](#)
 - exporting
 - fields
 - all phone details [10-4](#)
 - all user device profile details [10-14](#)
 - default phone details [10-3](#)
 - default user device profile details [10-16](#)
 - locating log files [10-18](#)
 - locating phone records [10-9](#)
 - moving records from one Cisco Unified CallManager to another [10-2](#)
 - overview [10-1](#)
 - phone records options [10-3](#)
 - phones with more than one user [10-9](#)
 - steps for exporting phone records [10-7](#)
 - user device profile options [10-17](#)
 - user device profile records format [10-13](#)
 - user records format [10-10](#)
 - user records options [10-11](#)
 - using export files [1-8](#)
-
- E
- E1 PRI
 - creating CSV file for VG200 gateway [7-13](#)

F

field descriptions

adding or updating lines [3-25](#)

BAT spreadsheet

adding lines [3-84](#)

updating users [4-12](#)

user device profile [6-10](#)

Catalyst 6000 FXS ports template [7-62](#)

gateway directory number template [7-27](#)

ground start [7-38](#)

loop start [7-38](#)

phone template [3-9](#)

updating lines [3-73](#)

updating users with BAT spreadsheet [4-12](#)

user device profile template [6-3](#)

VG200 gateway - FXO template [7-38](#)

VG200 gateway- FXS template [7-36](#)

VG200 gateway - T1/E1 PRI template [7-46](#)

VG200 gateway - T1 CAS template [7-40](#)

field descriptions for template [7-36](#)

file format for text-based CSV file

associating [3-55](#), [6-25](#)

copying [3-53](#), [6-23](#)

creating phone [3-51](#)

creating user device profile [6-22](#)

deleting [3-54](#), [6-25](#)

modifying [3-53](#), [6-24](#)

overview [1-8](#)

Forced Authorization Codes

BAT considerations [8-3](#)

BAT settings for inserting CSV file
(table) [8-14](#)

configuration checklist (table) [8-2](#)

creating a CSV file (BAT.xlt) [8-4](#)

creating custom CSV file (text-based) [A-28](#)

CSV file settings (table) [8-10](#)

deleting code settings (BAT) [8-7](#)

inserting CSV file in BAT [8-12](#)

updating existing CSV file [8-6](#)

FXO

creating CSV file for VG200 gateways [7-11](#)

field descriptions for template [7-38](#)

inserting VG200 gateway to Cisco Unified
CallManager [7-15](#)

text-based CSV file format for VG200
gateway [A-23](#)

FXS

Catalyst 6000 ports

creating CSV data file [7-20](#)

deleting [7-25](#)

field descriptions for template [7-62](#)

inserting to Cisco Unified
CallManager [7-22](#)

text-based CSV format [A-26](#)

updating [7-23](#)

creating template for Catalyst 6000
ports [7-19](#)

gateway directory number template,
creating [7-3](#)

VG200 gateways [7-36](#)
 creating CSV file [7-11](#)
 inserting to Cisco Unified
 CallManager [7-15](#)
 text-based CSV file format [A-23](#)

G

gateway directory number template
 creating [7-3](#)
 field descriptions [7-27](#)

gateways
 Cisco Catalyst 6000 FXS ports
 overview [7-18](#)

Cisco VG200 overview [7-1](#)

ground start, field description [7-38](#)

H

H.323 clients
 deleting [3-87](#)
 text-based CSV format [A-5](#)

H.323 client-users
 text-based CSV format [A-6](#)

help, online [1-18](#)

I

inserting records to Cisco Unified
 CallManager, overview [1-13](#)

installing
 BAT overview [2-2](#)
 BAT prerequisites [2-2](#)
 no backward template migration [2-2](#)
 no template migration when upgrading from
 release 3.0(3) [2-2](#)
 overview [2-1](#)
 template migration during upgrade [2-2](#)
 Unified CM Auto-Register Phone Tool
 overview [12-5](#)
 Unified CM Auto-Register Phone Tool
 prerequisites [12-6](#)

instructions, Unified CM Auto-Register Tool
 for end-users [12-18](#)

IP telephony devices
 supported with BAT [3-1](#)
 text-based CSV file format [A-4](#)

IP telephony devices, see phones

L

language prompts for Unified CM
 Auto-Register Phone Tool [12-5](#), [12-17](#)

lines
 adding or updating on template [3-4](#)
 field descriptions in template for adding or
 updating [3-25](#)
 master phone template [1-5](#)
 maximum number [3-5](#)
 updating [3-71](#)
 updating to user device profiles [6-31](#)

log files

- export log files [10-18](#)
- file naming convention [11-15, 13-2](#)
- locations [13-2](#)
- report log files [11-15](#)
- viewing [13-2](#)

logging on to BAT [1-17](#)loop start, field description [7-38](#)LSC [3-94](#)

Mmaster phone template [1-5](#)

modifying

- file format for text-based CSV [6-24](#)
- file format for text-based CSV file [3-53](#)
- phone template [3-7](#)

NNM-1V [7-5](#)NM-2V [7-5](#)NM-HDV [7-5](#)

Ooverriding template values [1-6](#)

overview

- BAT application [1-1](#)

BAT spreadsheet [1-11](#)Catalyst 6000 FXS ports [7-19](#)Cisco Unified CallManager Assistant [5-1](#)CSV data file [1-6](#)exporting records [10-1](#)file formats for text-based CSV files [1-8](#)inserting records to Cisco Unified
CallManager [1-13](#)installing BAT [2-1](#)reports [11-1](#)templates [1-5](#)text-based CSV files [A-1](#)troubleshooting BAT and Cisco Unified
CallManager Auto-Register Phone
Tool [13-1](#)Unified CM Auto-Register Phone tool [12-1](#)user device profiles [6-1](#)users [4-1](#)validating [1-13](#)VG200 gateways and ports [7-2](#)

P

passwords

- phones with users, adding [4-27](#)
- resetting [4-19](#)

phones

adding

- IP services [3-5](#)
- lines [3-4](#)

- lines to existing [3-81](#)
 - new [3-2](#)
 - speed dial settings [3-6](#)
 - with users [4-22](#)
 - Cisco Unified CallManager Assistant [5-7](#)
 - Cisco Unified CallManager Assistant manager configuration [5-7](#)
 - configuring CAPF [3-93](#)
 - upgrading LSC [3-94](#)
 - creating text-based CSV file [A-2](#)
 - deleting [3-87](#)
 - dummy MAC address, using [3-42](#), [3-58](#), [4-26](#)
 - dummy MAC addresses list [11-6](#)
 - enable CTI application use [3-57](#)
 - export file with all details [A-7](#)
 - exporting records options [10-3](#)
 - exporting records steps [10-7](#)
 - generating reports [11-1](#)
 - insert to Cisco Unified CallManager [3-57](#)
 - locating export records [10-9](#)
 - proxy mode for Cisco Unified CallManager Assistant [5-2](#)
 - reloading configurations [12-4](#)
 - report options [11-3](#)
 - steps for adding [3-2](#)
 - template
 - copying [3-8](#)
 - creating new [3-4](#)
 - deleting [3-9](#)
 - field descriptions [3-9](#)
 - for IP telephony devices [3-4](#)
 - modifying [3-7](#)
 - text-based CSV format [A-4](#)
 - updating [3-59](#)
 - updating lines [3-71](#)
 - updating with custom file [3-61](#)
 - updating with query [3-60](#)
 - using Unified CM Auto-Register Phone Tool to configure [12-3](#)
 - validating records [3-56](#)
 - phones with users
 - inserting to Cisco Unified CallManager [4-25](#)
 - text-based CSV format [A-5](#)
 - using BAT spreadsheet [4-24](#)
 - validating records [4-24](#)
 - PINs
 - phones with users, adding [4-27](#)
 - resetting [4-19](#)
 - prerequisites
 - BAT [2-2](#)
 - Unified CM Auto-Register Phone Tool [12-6](#)
-
- ## Q
- query
 - customizing a filter [1-7](#)
 - deleting call pickup groups [9-5](#)
 - deleting Cisco Unified CallManager Assistant assistants [5-25](#)

- deleting Cisco Unified CallManager Assistant managers [5-22](#)
- deleting phones [3-87](#)
- deleting users [4-16](#)
- updating lines [6-31](#)
- updating lines, using [3-71](#)
- updating phones [3-60](#)
- using to reset password and PIN [4-19](#)

R

reports

- Cisco Unified CallManager Assistant [11-13](#)
- dummy MAC addresses [11-6](#)
- locating log files [11-15](#)
- overview [11-1](#)
- phone options [11-3](#)
- phones [11-1](#)
- user device profile [11-8](#)
- user device profile options [11-10](#)
- users [11-6](#)
- VG200 gateway [11-11](#)

resetting password and PIN

- for all users [4-15](#)
- using custom file [4-21](#)
- using query [4-19](#)

resetting phones

- after update [3-90](#)
- using custom file [3-92](#)
- using query [3-91](#)

restarting phones

- after update [3-90](#)
- using custom file [3-92](#)
- using query [3-91](#)

- retaining user records when updating [4-11](#)

S

- securing directory numbers from Unified CM Auto-Register Phone Tool [12-4](#), [12-13](#)

- services, adding or updating [3-5](#)

- specifications for BAT [1-15](#)

- speed dial settings, adding or updating [3-6](#)

starting

- BAT [1-16](#)
- Unified CM Auto-Register Phone Tool [12-11](#)

stopping

- BAT transactions [1-19](#)
- Unified CM Auto-Register Phone Tool [12-11](#)

- sub-unit [7-6](#)

T

T1 CAS

- creating CSV data file for VG200 gateway [7-13](#)
- field descriptions for VG200 template [7-40](#)
- text-based CSV file format [A-24](#)

T1 PRI

- creating CSV file for VG200 gateway [7-13](#)

- field descriptions for VG200 gateway
 - template [7-46](#)
- text-based CSV file format [A-24](#)
- template
 - migration during upgrade [2-2](#)
 - no backward migration [2-2](#)
- templates
 - adding or updating IP services [3-5](#)
 - adding or updating lines [3-4](#)
 - adding or updating speed dial settings [3-6](#)
 - BAT template overview [1-5](#)
 - copying [6-6](#)
 - copying phone [3-8](#)
 - deleting [6-7](#)
 - deleting phone [3-9](#)
 - field descriptions
 - adding or updating lines [3-25](#)
 - Catalyst 6000 FXS ports [7-62](#)
 - gateway directory number [7-27](#)
 - phone [3-9](#)
 - user device profiles [6-3](#)
 - VG200 gateway - FXO template [7-38](#)
 - VG200 gateway - FXS [7-36](#)
 - VG200 gateway - T1 CAS gateway [7-40](#)
 - master phone [1-5](#)
 - modifying [6-6](#)
 - modifying phone [3-7](#)
 - overriding values [1-6](#)
- template type
 - Catalyst 6000 FXS ports [7-19](#)
 - Cisco Unified CallManager Assistant
 - assistant for proxy mode [5-4](#)
 - Cisco Unified CallManager Assistant
 - manager for proxy mode [5-4](#)
 - gateway directory number [7-3](#)
 - IP telephony devices [3-4](#)
 - phones [3-4](#)
 - user device profiles [6-3](#)
 - VG200 gateway [7-4](#)
- troubleshooting
 - BAT [13-3](#)
 - BAT performance [13-8](#)
 - Cisco Unified CallManager Auto-Register
 - Phone Tool [13-8](#)
 - overview [13-1](#)
- Troubleshooting message
 - Couldn't create user object. Check if DC
 - Directory is running. [13-6](#)
- troubleshooting message
 - BAT.xlt spreadsheet will not work with Excel
 - XP (Office XP) [13-6](#)
 - BAT spreadsheet gives a compilation error
 - while exporting data [13-3](#)
 - CSV data files do not match phone
 - template/sample file [13-4](#)
 - errors occur when using dummy MAC
 - address option [13-4](#)
 - export to BAT does not work in BAT.xlt
 - file [13-3](#)
 - MAC address values are not allowed in CSV
 - file if dummy MAC address option
 - selected [13-6](#)

- port identifier contains invalid endpoint prefix [13-5](#)
- port identifier contains invalid port number [13-5](#)
- port number not configured in template [13-5](#)
- selected template does not contain DN details for directory number [13-5](#)
- the page cannot be displayed [13-4](#)
- when Cisco CRS starts, JTAPI shows partial service or out of service [13-10](#)
- when dialing Unified CM Auto-Register Phone Tool number, caller hears busy [13-9](#)

U

- UDP, see user device profiles
- uninstalling
 - BAT [2-4](#)
 - removing Unified CM Auto-Register Phone Tool from Cisco CRS server [12-10](#)
 - Unified CM Auto-Register Phone Tool [12-9](#)
- Update Statistics [1](#)
- updating
 - lines to user device profiles [6-31](#)
 - phone configuration using Unified CM Auto-Register PhoneTool [12-18](#)
- updating lines
 - field descriptions [3-73](#)
- upgrading BAT [2-2](#)
- user device profiles
 - adding lines to existing [3-81](#)
- BAT spreadsheet
 - field descriptions [6-10](#)
 - using [6-8](#)
- creating CSV data file [6-8](#)
- deleting [6-31](#)
- export file format [10-13](#)
- export file with all details [A-18](#)
- exporting record options [10-17](#)
- inserting to Cisco Unified CallManager [6-27](#)
- overview [6-1](#)
- removing [6-31](#)
- report options [11-10](#)
- reports, generating [11-8](#)
- steps for adding [6-1](#)
- template
 - copying [6-6](#)
 - creating [6-3](#)
 - deleting [6-7](#)
 - modifying [6-6](#)
- text-based CSV file, creating [A-15](#)
- text-based CSV file format [A-16](#)
- updating lines [6-31](#)
- validating records [6-26](#)
- users
 - adding overview [4-1](#)
 - adding with phones [4-22](#)
 - authentication proxy rights [4-7](#)
 - calling party number modification [4-8](#)
 - call park retrieval [4-7](#)

- creating CSV data file [4-2](#)
- CTI application use [4-7](#)
- deleting [4-16](#)
 - using custom file [4-18](#)
 - using query [4-16](#)
- exported records format [10-10](#)
- exporting records [10-11](#)
- field descriptions for updating with BAT spreadsheet [4-12](#)
- generating reports [11-6](#)
- inserting to Cisco Unified CallManager [4-6](#)
- resetting passwords and PINs [4-19](#)
- retaining stored values [4-11](#)
- text-based CSV file, creating [A-11](#)
- text-based CSV file, updating [A-13, A-30, A-31, A-33](#)
- text-based CSV format [A-12](#)
- updating [4-10](#)
- updating users field descriptions [4-12](#)
- users with phones
 - inserting to Cisco Unified CallManager [4-25](#)
 - using BAT spreadsheet [4-24](#)
 - validating records [4-24](#)
- phone records [3-56](#)
- user device profile records [6-26](#)
- version, finding [1-19](#)
- VG200 gateway
 - adding gateways and ports [7-2](#)
 - creating CSV data file for FXS or FXO [7-11](#)
 - creating CSV data file for T1 CAS or T1/E1 PRI [7-13](#)
 - creating template [7-4](#)
 - creating text-based CSV file [A-22](#)
 - deleting gateway [7-16](#)
 - field descriptions
 - FXO template [7-38](#)
 - FXS template [7-36](#)
 - T1/E1 PRI template [7-46](#)
 - T1 CAS template [7-40](#)
 - generating reports [11-11](#)
 - inserting to Cisco Unified CallManager (FXS or FXO) [7-15](#)
 - inserting to Cisco Unified CallManager (T1 CAS or T1/E1 PRI) [7-15](#)
 - overview [7-1](#)
 - updating endpoint identifiers [7-9](#)
- VIC-2FXO [7-6](#)
- VIC-2FXS [7-6](#)
- viewing log files [13-2](#)
- VWIC-1MFT-E1 [7-6](#)
- VWIC-1MFT-T1 [7-6](#)
- VWIC-2MFT-E1 [7-6](#)
- VWIC-2MFT-T1 [7-6](#)

V

- validating
 - options [1-13](#)
 - overview [1-13](#)
 - phone and user records [4-24](#)