



## INDEX

---

### A

- activating services
  - BPS [67-1](#)
  - TAPS [65-6](#)
- adding intercom templates
  - field descriptions [3-46](#)
- adding lines
  - field descriptions for BAT spreadsheet [10-10, 43-3](#)
  - field descriptions for template [3-30](#)
  - to existing phones [10-8, 43-1](#)
  - to existing phones using BAT spreadsheet [10-9, 43-2](#)
  - to existing user device profiles [10-8, 43-1](#)
  - to phone template [3-4](#)
- associating file format for text-based CSV file [4-5, 25-1, 37-1, 58-10](#)
- auto-registration, enabled for Cisco Unified CallManager
  - enable auto-registration for TAPS [65-2](#)
- auto-registration options, configuring [65-7](#)

---

### B

#### BAT

- application overview [1-1](#)
- browser requirements [1-11](#)
- configuration process overview [1-3](#)
- data input files [1-2](#)
- error messages [68-3](#)
- installation [1-2](#)
- log files location [68-3](#)
- online help [1-11](#)
- scheduling jobs [67-1](#)
- troubleshooting [68-3](#)

- troubleshooting performance [68-7](#)
- version [1-12](#)

BAT.xlt, see BAT spreadsheet

BAT Performance [B-1](#)

BAT spreadsheet

- adding lines to existing phones [10-9, 43-2](#)

Catalyst 6000 FXS ports [49-3](#)

field descriptions

- adding lines [10-10, 43-3](#)

- updating users [18-2](#)

- user device profile [34-4](#)

IP telephony devices [3-48](#)

manager assistant associations [28-9](#)

overview [1-8](#)

phone migration

- creating CSV data file for phone migration [63-1](#)

phones [3-48](#)

phones with users [24-1](#)

Unified CM Assistant custom manager assistant for proxy mode [28-11](#)

Unified CM Assistant default manager assistant [28-10](#)

user device profile [34-2](#)

users [15-2](#)

using for CSV data file [1-8](#)

VG200 gateway for T1 CAS or T1/E1 PRI [49-1](#)

VG202 and VG204 gateway for FXS or VG202 and VG204 gateway

creating CSV data file for FXS

- creating CSV data file for VG202 or VG204 gateway [49-6](#)

VG224 gateway for FXS or VG224 gateway

creating CSV data file for FXS

- creating CSV data file for VG224

gateway [49-4](#)  
 browser requirements [1-11](#)

### Bulk Provisioning Service

activating BPS [67-1](#)  
 deactivating BPS [67-2](#)

## C

### Call Pickup Groups

BAT considerations [53-1](#)  
 BAT settings for inserting CSV file (table) [53-5](#)  
 creating a CSV file (BAT.xlt) [53-2](#)  
 creating custom CSV file (text-based) [A-22](#)  
 CSV file settings (table) [53-4](#)  
 inserting CSV file in BAT [53-4](#)  
 updating existing CSV file [53-3](#)  
 using query to delete call pickup groups [54-1](#)

### Catalyst 6000 FXS ports

creating CSV data file [49-3](#)  
 text-based CSV file, creating [A-17](#)  
 text-based CSV file format [A-17](#)

### Cisco CRS

configuring TAPS [65-5](#)  
 required for TAPS [65-2](#)  
 troubleshooting TAPS [68-8](#)

Cisco Customer Response Solutions, see Cisco CRS

### Cisco Unified CallManager

enable auto-registration for TAPS [65-2](#)  
 inserting  
   CTI ports [6-1, 17-1, 39-1, 49-1](#)  
   H.323 clients [6-1, 17-1, 39-1, 49-1](#)  
   phones [6-1, 17-1, 39-1, 49-1](#)  
   phones with users [27-1](#)  
   Unified CM Assistant manager-assistant associations [29-1](#)  
   users [17-1](#)  
   VG200 gateway (FXS or FXO) [49-8](#)  
   VG200 gateway (T1 CAS or T1/E1 PRI) [49-8](#)  
 overview of inserting records [1-10](#)

Cisco Unified CallManager Assistant, see Unified CM Assistant

Cisco Unified CM Assistant Configuration Wizard [28-2](#)

### Cisco Unified IP-IVR

required for TAPS [65-2](#)

### Cisco VG202 or VG204 Gateway Template

create [46-11](#)

### Client Matter Codes

BAT considerations [51-2](#)  
 BAT settings for inserting CSV file (table) [51-7](#)  
 configuration checklist (table) [51-1](#)  
 creating a CSV file (BAT.xlt) [51-3](#)  
 creating custom CSV file (text-based) [A-19](#)  
 CSV file settings (table) [51-5](#)  
 deleting code settings (BAT) [52-1](#)  
 inserting CSV file in BAT [51-6](#)  
 updating existing CSV file [51-4](#)

### CMC

text-based CSV file, updating [A-20](#)

configuring Cisco Unified CallManager records, process [1-3](#)

configuring gateway file format [47-2](#)

### copying

file format for text-based CSV [36-3](#)  
 file format for text-based CSV file [4-3, 47-3, 58-9](#)  
 phone template [3-9](#)  
 template [35-5](#)  
 user template [16-3](#)

### CPG

text-based CSV file, updating [A-23](#)

### creating

Cisco VG202 or VG204 Gateway Template [46-11](#)

CSV, comma separated values text file [1-2, A-1](#)

### CSV, text-based

Catalyst 6000 FXS ports, creating [A-17](#)  
 Catalyst 6000 FXS ports format [A-17](#)

### CMC

options [51-4](#)  
 updating [A-20](#)

- CPG
    - options [53-3](#)
    - updating [A-23](#)
  - CTI ports format [A-3](#)
  - CTI ports-users format [A-4](#)
  - FAC
    - options [51-4](#)
    - updating [A-21](#)
  - FXO or FXS ports format [A-14](#)
  - H.323 clients format [A-3](#)
  - H.323 client-users format [A-4](#)
  - manager assistant associations
    - creating [A-12](#)
    - custom format [A-13](#)
  - manager assistant default formats [A-13](#)
  - overview [A-1](#)
  - phones
    - creating [A-2](#)
    - export file, all details [A-4](#)
    - options [4-1](#)
    - tips for creating [A-2](#)
    - with users format [A-3](#)
  - T1 CAS, T1/E1 PRI format [A-15](#)
  - user device profile format [A-9](#)
  - user device profile options [36-1](#)
  - user device profiles
    - creating [A-9](#)
    - export file [A-11](#)
    - two lines format [A-10](#)
  - users
    - creating [A-6](#)
    - format [A-7](#)
    - updating [A-8](#)
  - VG200 gateways, creating [A-14](#)
  - VG202 and VG204 gateways, creating [A-18](#)
  - VG224 gateways, creating [A-16](#)
  - CSV data file
    - adding new devices [1-5](#)
    - overview [1-5](#)
    - updating existing devices [1-6](#)
    - using BAT spreadsheet (BAT.xlt) [1-8](#)
  - CTI ports
    - deleting [8-1, 13-1, 40-1](#)
    - dummy MAC address, using [6-2, 27-1, 39-2](#)
    - text-based CSV format [A-3](#)
  - CTI ports-users
    - text-based CSV format [A-4](#)
  - custom file
    - deleting phones [8-3, 40-2](#)
    - deleting Unified CM Assistant managers [31-2, 32-2](#)
    - deleting users [19-2](#)
    - updating phones [7-2](#)
    - using [1-6](#)
    - using to reset password and PIN [21-3](#)
- 
- ## D
- delete
    - time of day access [57-2](#)
  - deleting
    - call pickup groups [54-1](#)
    - file format for text-based CSV file [4-5, 36-4, 47-4](#)
    - manager-assistant associations [30-1](#)
    - phones using custom files [8-3, 40-2](#)
    - phones using query [8-1, 13-1](#)
    - phone template [3-10](#)
    - remote destination file format for text-based CSV file [58-10](#)
    - Remote Destination Profiles using query [58-12](#)
    - template [35-6](#)
    - Unified CM Assistant assistants [32-1](#)
    - Unified CM Assistant managers [31-1](#)
    - user device profiles [40-1](#)
    - users [19-1](#)
    - user template [16-3](#)
    - VG200 gateway [48-1](#)
  - dialed number analyzer
    - trace configuration files [68-1](#)

## directory number

- finding secure directory numbers from TAPS [65-8](#)
- lifting restrictions [65-9](#)
- restricting from TAPS [65-9](#)
- securing from TAPS [65-8](#)

downloading phone configuration using Unified TAPS [66-2](#)

- dummy MAC address [3-50, 6-2, 27-1, 39-2](#)
  - generate a list [12-6](#)

**E**

## E1 PRI

- creating CSV file for VG200 gateway [49-1](#)
- field descriptions for VG200 gateway template [46-29](#)
- text-based CSV file format [A-15](#)

E1 PRI ports [46-8](#)error messages, BAT [68-3](#)

## export

- time of day access [57-3](#)

exported fields [58-15](#)

- all phone details [9-2](#)
- all user device profile details [41-1](#)
- default phone details [9-2](#)
- default user device profile details [41-2](#)

## exporting

## fields

- all phone details [9-2](#)
- all user device profile details [41-1](#)
- default phone details [9-2](#)
- Default Remote Destination Profile file format details [58-15](#)
- default user device profile details [41-2](#)

line appearance [23-2](#)moving records from one Cisco Unified CallManager to another [9-1](#)

- phone records options [9-1](#)
- phones with more than one user [9-5](#)
- remote destination profile records options [58-13](#)

- steps for exporting phone records [9-3](#)
- user device profile options [41-3](#)
- user device profile records format [41-1](#)
- user records format [20-1](#)
- user records options [20-1](#)
- using export files [1-6](#)

**F**

## FAC

- text-based CSV file, updating [A-21](#)

## field descriptions

- adding or updating intercom template [3-46](#)
- adding or updating lines [3-30](#)

## BAT spreadsheet

- adding lines [10-10, 43-3](#)
- updating users [18-2](#)
- user device profile [34-4](#)

phone template [3-10](#)

- updating lines [10-3, 42-3](#)
- updating users with BAT spreadsheet [18-2](#)
- user device profile template [35-2](#)
- user template [16-4](#)
- VG200 gateway - T1/E1 PRI template [46-29](#)
- VG200 gateway - T1 CAS template [46-26](#)

## file format for gateway

- finding [47-1](#)

## file format for text-based CSV file

- associating [4-5, 25-1, 37-1, 58-10](#)
- copying [4-3, 36-3, 47-3, 58-9](#)
- creating phone [4-2, 47-2](#)
- creating remote destination profile [58-8](#)
- creating user device profile [36-2](#)
- deleting [4-5, 36-4, 47-4](#)
- finding [4-2, 36-1, 58-7](#)
- modifying [4-4, 36-4, 47-3](#)
- overview [1-7](#)

## file format for text-based CSV file gateway

- associating [47-5](#)

## finding

- file [2-1](#)
- gateway file format [47-1](#)
- gateway templates [46-3](#)
- gateway file format [47-1](#)
- jobs [67-3](#)
- line appearances [23-1](#)
- phone file format [4-2](#)
- phone template [3-2](#)
- remote destination file format [58-7](#)
- secure directory numbers from TAPS [65-8](#)
- UDP file format for text-based CSV [36-1](#)
- UDP template [35-1](#)
- user template [16-1](#)

## Forced Authorization Codes

- BAT considerations [51-2](#)
- BAT settings for inserting CSV file (table) [51-7](#)
- configuration checklist (table) [51-1](#)
- creating a CSV file (BAT.xlt) [51-3](#)
- creating custom CSV file (text-based) [A-19](#)
- CSV file settings (table) [51-5](#)
- deleting code settings (BAT) [52-1](#)
- inserting CSV file in BAT [51-6](#)
- updating existing CSV file [51-4](#)

## FXO

- inserting VG200 gateway to Cisco Unified CallManager [49-8](#)
- text-based CSV file format for VG200 gateway [A-14](#)

FXO ports [46-7](#)

## FXS

- Catalyst 6000 ports
  - creating CSV data file [49-3](#)
  - text-based CSV format [A-17](#)
- creating template for Catalyst 6000 ports [46-9](#)
- VG200 gateways
  - inserting to Cisco Unified CallManager [49-8](#)
  - text-based CSV file format [A-14](#)

**G**

## gateway

- associating file format for text-based CSV file [47-5](#)

## gateway file format

- configuring [47-2](#)
- finding [47-1](#)

## gateway template

- adding or editing [46-4](#)
- Catalyst 6000 FXS ports
  - creating template [46-9](#)
- configuration settings [46-13](#)
- finding [46-3](#)
- port configuration settings (table) [46-43](#)
- POTS port configuration settings (table) [46-43](#)
- VG200 gateway template
  - creating template [46-5, 46-10, 46-11](#)
  - FXO ports, adding [46-7](#)
  - T1-CAS ports, adding [46-8](#)
  - T1 PRI or E1 PRI ports, adding [46-8](#)
  - VG202 and VG204 create [46-11](#)

**H**

## H.323 clients

- deleting [8-1, 13-1, 40-1](#)
- text-based CSV format [A-3](#)

## H.323 client-users

- text-based CSV format [A-4](#)

help, online [1-11](#)**I**

## import/export

- validate [62-1](#)

## insert

- time of day access [57-1](#)

inserting records to Cisco Unified CallManager, overview [1-10](#)

## installing

- TAPS overview [65-4](#)

- TAPS prerequisites [65-4](#)

- instructions, TAPS for end-users [66-2](#)

## Intercom DNs

- Add [45-2](#)

## Intercom Templates

- adding or updating on template [3-7](#)

## IP telephony devices

- supported with BAT [16-1](#)

- IP telephony devices, see phones

---

**J**

## jobs

- activating BPS [67-1](#)

- deactivating BPS [67-2](#)

- finding [67-3](#)

- scheduling [67-4](#)

- viewing log files [67-6](#)

---

**L**

- language prompts for TAPS [65-4](#)

## line appearance

- export [23-2](#)

- update [23-3](#)

## line appearances

- find [23-1](#)

## lineappearances

- view [23-1](#)

## lines

- adding or updating on template [3-4](#)

- field descriptions in template for adding or updating [3-30, 3-46](#)

- master phone template [1-5](#)

- maximum number [3-5, 3-8](#)

- updating to user device profiles [42-1](#)

## log files

- BAT [68-3](#)

- file naming convention [68-3](#)

- report log files [12-6, 22-2, 33-2, 50-2](#)

- viewing job log files [67-6](#)

---

**M**

- master phone template [1-5](#)

## MGCP

- T1-CAS ports [46-8](#)

- T1 PRI or E1 PRI ports, adding [46-8](#)

## migrating phones

- phone migration procedure [63-2](#)

## modifying

- file format for text-based CSV [36-4](#)

- file format for text-based CSV file [4-4, 47-3](#)

- phone template [3-8](#)

- remote destination file format for text-based CSV file [58-9](#)

- user template [16-3](#)

---

**N**

- NM-1V [46-14](#)

- NM-2V [46-14](#)

- NM-HDV [46-14](#)

---

**O**

- overriding template values [1-5](#)

## overview

- BAT application [1-1](#)

- BAT spreadsheet [1-8](#)

- Cisco Unified CM Assistant [28-1](#)

- CSV data file [1-5](#)

- data input files [1-2](#)

- file formats for text-based CSV files [1-7](#)

- inserting records to Cisco Unified CallManager [1-10](#)

- installation [1-2](#)

reports [12-1, 22-1, 44-1](#)

TAPS [65-1](#)

templates [1-4](#)

text-based CSV files [A-1](#)

user device profiles [34-1](#)

users [15-1](#)

validating [1-10](#)

## P

passwords

resetting [21-1](#)

phone migration

creating CSV data file [63-1](#)

phones

adding

Intercom template [3-7](#)

IP services [3-5](#)

lines [3-4](#)

lines to existing [10-8, 43-1](#)

speed dial settings [3-6, 3-7](#)

with users [24-1](#)

configuring CAPF [3-70, 16-6](#)

creating text-based CSV file [A-2](#)

deleting [8-1, 13-1, 40-1](#)

dummy MAC address, using [3-50, 6-2, 27-1, 39-2](#)

dummy MAC addresses list [12-6](#)

export file with all details [A-4](#)

exporting records options [9-1](#)

exporting records steps [9-3](#)

generating reports [12-1](#)

insert to Cisco Unified CallManager [6-1, 17-1, 39-1, 49-1](#)

proxy mode for Unified CM Assistant [28-2](#)

reloading configurations [65-3](#)

report options [12-3](#)

template

copying [3-9](#)

creating new [3-4](#)

deleting [3-10](#)

field descriptions [3-10](#)

finding template [3-2](#)

for IP telephony devices [3-4](#)

modifying [3-8](#)

Unified CM Assistant assistant [28-5](#)

Unified CM Assistant manager configuration [28-4](#)

updating [7-1, 18-1, 19-1](#)

updating with custom file [7-2](#)

updating with query [7-1](#)

using TAPS to configure [65-2](#)

enable auto-registration [65-2](#)

validating records [5-1, 38-1](#)

phones with users

inserting to Cisco Unified CallManager [27-1](#)

text-based CSV format [A-3](#)

using BAT spreadsheet [24-1](#)

validating records [26-1](#)

PINs

resetting [21-1](#)

prerequisites

TAPS [65-4](#)

## Q

query

customizing a filter [1-6](#)

deleting call pickup groups [54-1](#)

deleting phones [8-1, 13-1](#)

deleting Remote Destination Profiles [58-12](#)

deleting Unified CM Assistant managers [31-1, 32-1](#)

deleting users [19-1](#)

updating lines [42-1](#)

updating phones [7-1](#)

using to reset password and PIN [21-1](#)

**R**

- remote destination file format for text-based CSV file
  - deleting [58-10](#)
  - modifying [58-9](#)
- remote destination profile
  - exporting records options [58-13](#)
- Remote Destination Profile template [58-1](#)
- reports
  - dummy MAC addresses [12-6](#)
  - overview [12-1, 22-1, 44-1](#)
  - phone options [12-3](#)
  - phones [12-1](#)
  - Unified CM Assistant manager assistant [33-1](#)
  - user device profile [44-1](#)
  - users [22-1](#)
  - VG200 gateway [50-1](#)
- resetting password and PIN
  - using custom file [21-3](#)
  - using query [21-1](#)
- resetting phones
  - after update [11-1](#)
  - using custom file [11-2](#)
  - using query [11-1](#)
- restarting phones
  - after update [11-1](#)
  - using custom file [11-2](#)
  - using query [11-1](#)
- retaining user records when updating [18-2](#)

**S**

- securing directory numbers from TAPS [65-3, 65-8](#)
- services, adding or updating [3-5](#)
- speed dial settings, adding or updating [3-6, 3-7](#)
- sub-unit [46-5, 46-10](#)

**T**

- T1 CAS
  - creating CSV data file for VG200 gateway [49-1](#)
  - field descriptions for VG200 template [46-26](#)
  - text-based CSV file format [A-15](#)
- T1-CAS ports, adding [46-8](#)
- T1 PRI
  - creating CSV file for VG200 gateway [49-1](#)
  - field descriptions for VG200 gateway template [46-29](#)
  - text-based CSV file format [A-15](#)
- T1 PRI ports [46-8](#)
- TAPS
  - activating TAPS service [65-6](#)
  - Cisco CRS required [65-2](#)
  - Cisco Unified IP-IVR required [65-2](#)
  - configuring auto-registration options [65-7](#)
  - configuring on Cisco CRS server [65-5](#)
  - finding secure directory numbers [65-8](#)
  - installation overview [65-4](#)
  - instructions for end-users [66-2](#)
  - language prompts [65-4](#)
    - removing [66-2](#)
  - lifting restriction on directory numbers [65-9](#)
  - log files location [68-7](#)
  - overview [65-1](#)
  - reloading configurations [65-3](#)
  - requirements [65-1](#)
  - restarting service [65-6](#)
  - restricting directory numbers [65-9](#)
  - securing directory numbers [65-3, 65-8](#)
  - setting options for using [65-7](#)
  - starting service [65-6](#)
  - stopping service [65-6](#)
  - troubleshooting [68-7](#)
  - uninstalling [65-5](#)
- templates
  - adding or updating intercom templates [3-7](#)
  - adding or updating IP services [3-5](#)

- adding or updating lines [3-4](#)
- adding or updating speed dial settings [3-6, 3-7](#)
- BAT template overview [1-4](#)
- copying [35-5](#)
- copying phone [3-9](#)
- copying users [16-3](#)
- deleting [35-6](#)
- deleting phone [3-10](#)
- deleting users [16-3](#)
- field descriptions
  - adding or updating intercom templates [3-46](#)
  - adding or updating lines [3-30](#)
  - phone [3-10](#)
  - user device profiles [35-2](#)
  - users [16-4](#)
  - VG200 gateway - T1 CAS gateway [46-26](#)
- finding [35-1](#)
- master phone [1-5](#)
- modifying [35-5](#)
- modifying phone [3-8](#)
- modifying users [16-3](#)
- overriding values [1-5](#)
- template type
  - Catalyst 6000 FXS ports [46-9](#)
  - IP telephony devices [3-4](#)
  - phones [3-4](#)
  - Unified CM Assistant assistant for proxy mode [28-3](#)
  - Unified CM Assistant manager for proxy mode [28-3](#)
  - user device profiles [35-2](#)
  - users [16-2](#)
  - VG200 gateway template [46-5, 46-10, 46-11](#)
- time of day access [57-1](#)
  - delete [57-2](#)
  - export [57-3](#)
  - insert [57-1](#)
- trace configuration files
  - viewing [68-1](#)
- troubleshooting
  - BAT [68-3](#)
  - BAT log files [68-3](#)
  - BAT performance [68-7](#)
  - TAPS [68-7](#)
- troubleshooting message
  - BAT.xlt spreadsheet does not work with Excel XP (Office XP) [68-6](#)
  - BAT excel sheet does not respond to actions [68-4](#)
  - BAT menu does not display in Cisco Unified CallManager [68-3](#)
  - BAT spreadsheet gives a compilation error while exporting data [68-4](#)
  - cannot access complete BAT functionality [68-3](#)
  - CSV data files do not match phone template/sample file [68-4](#)
  - export to BAT does not work in BAT.xlt file [68-4](#)
  - job does not display in find and list job window [68-5](#)
  - jobs remain in hold state [68-5](#)
  - jobs remain in pending state [68-5](#)
  - MAC address values are not allowed in CSV file if dummy MAC address option selected [68-6](#)
  - port number not configured in template [68-6](#)
  - Record does not match the file format selected [68-6](#)
  - uploaded csv file does not display [68-5](#)
  - when Cisco CRS starts, JTAPI shows partial service or out of service [68-8](#)
  - when dialing TAPS number, caller hears busy [68-8](#)

---

## U

- UDP, see user device profiles
- Unified CM Assistant
  - assistant template for proxy mode [28-3](#)
  - creating CSV data file [28-9](#)
  - deleting assistants
    - described [32-1](#)
    - using custom file [32-2](#)
  - deleting manager-assistant associations [30-1](#)
  - deleting managers
    - described [31-1](#)
    - using custom file [31-2](#)

- using query [31-1, 32-1](#)
- generating reports [33-1](#)
- inserting manager-assistant associations [29-1](#)
- manager and assistant line configurations, proxy mode [28-3](#)
- manager and assistant shared line configurations [28-8](#)
- manager template for proxy mode [28-3](#)
- overview [28-1](#)
- phones
  - assistant configuration options [28-5](#)
  - manager configuration options [28-4](#)
  - proxy line example [28-5](#)
  - proxy lines on existing [28-6](#)
  - proxy lines on new [28-6](#)
  - proxy mode [28-2](#)
  - shared line example [28-8](#)
  - shared line mode [28-7](#)
- setting up phones and lines [28-1](#)
- text-based CSV file, creating [A-12](#)
- text-based CSV file custom format [A-13](#)
- Unified CM Assistant Configuration Wizard [28-2](#)
- uninstalling
  - TAPS [65-5](#)
- update
  - line appearance [23-3](#)
- updating
  - lines to user device profiles [42-1](#)
  - phone configuration using TAPS [66-2](#)
- updating lines
  - field descriptions [10-3, 42-3](#)
- uploading/downloading file
  - delete [2-3](#)
  - download [2-2](#)
  - finding [2-1](#)
  - upload [2-3](#)
- user device profiles
  - adding lines to existing [10-8, 43-1](#)
  - BAT spreadsheet
    - field descriptions [34-4](#)
  - using [34-2](#)
  - creating CSV data file [34-2](#)
  - deleting [40-1](#)
  - export file format [41-1](#)
  - export file with all details [A-11](#)
  - exporting record options [41-3](#)
  - overview [34-1](#)
  - removing [40-1](#)
  - reports, generating [44-1](#)
  - steps for adding [34-1](#)
  - template
    - copying [35-5](#)
    - creating [35-2](#)
    - deleting [35-6](#)
    - finding [35-1](#)
    - modifying [35-5](#)
  - text-based CSV file, creating [A-9](#)
  - text-based CSV file format [A-9](#)
  - updating lines [42-1](#)
  - validating records [38-1](#)
- users
  - adding overview [15-1](#)
  - adding with phones [24-1](#)
  - creating CSV data file [15-2](#)
  - deleting [19-1](#)
    - using custom file [19-2](#)
    - using query [19-1](#)
  - exported records format [20-1](#)
  - exporting records [20-1](#)
  - field descriptions for updating with BAT spreadsheet [18-2](#)
  - generating reports [22-1](#)
  - inserting to Cisco Unified CallManager [17-1](#)
  - resetting passwords and PINs [21-1](#)
  - retaining stored values [18-2](#)
  - template
    - copying [16-3](#)
    - creating new [16-2](#)
    - deleting [16-3](#)

- field descriptions [16-4](#)
    - finding [16-1](#)
    - for users [16-2](#)
    - modifying [16-3](#)
  - text-based CSV file, creating [A-6](#)
  - text-based CSV file, updating [A-8](#)
  - text-based CSV format [A-7](#)
  - updating [18-1](#)
  - updating users field descriptions [18-2](#)
  - users with phones
    - inserting to Cisco Unified CallManager [27-1](#)
    - using BAT spreadsheet [24-1](#)
    - validating records [26-1](#)
- 
- ## V
- validate
    - import/export [62-1](#)
  - validate import file [62-1](#)
  - validating
    - options [1-10](#)
    - overview [1-10](#)
    - phone and user records [26-1](#)
    - phone records [5-1, 38-1](#)
    - user device profile records [38-1](#)
  - version, finding [1-12](#)
  - VG200 gateway
    - creating CSV data file for T1 CAS or T1/E1 PRI [49-1](#)
    - creating template [46-5, 46-10, 46-11](#)
    - creating text-based CSV file [A-14](#)
    - deleting gateway [48-1](#)
    - field descriptions
      - T1/E1 PRI template [46-29](#)
      - T1 CAS template [46-26](#)
    - generating reports [50-1](#)
    - inserting to Cisco Unified CallManager (FXS or FXO) [49-8](#)
    - inserting to Cisco Unified CallManager (T1 CAS or T1/E1 PRI) [49-8](#)
    - VG200 gateway template
      - FXO ports, adding [46-7](#)
    - VG202 and VG04 gateway
      - creating text-based CSV file [A-18](#)
    - VG224 gateway
      - creating text-based CSV file [A-16](#)
    - VIC-2FXO [46-5](#)
    - VIC-2FXS [46-5, 46-10](#)
    - viewing
      - line appearances [23-1](#)
    - viewing trace configuration files [68-1](#)
    - VWIC-1MFT-E1 [46-6](#)
    - VWIC-1MFT-T1 [46-5](#)
    - VWIC-2MFT-E1 [46-6](#)
    - VWIC-2MFT-T1 [46-6](#)

