



A

- accessing dialed number analyzer 3-1
- additional information xv
- additional publications xv
- alternate matches 4-41
- analysis
 - simple analysis using DNA 4-3
 - understanding output 4-27
 - using gateways 4-11
 - using phones 4-5
 - using trunks 4-23
- analysis output
 - directory number information 4-40
 - route list information 4-38
 - route pattern information 4-37
 - translation pattern information 4-36
 - understanding call flow details 4-36
 - understanding results summary 4-34
- analysis results
 - example 1 4-28
 - example 2 4-31
 - examples 4-28
- analysis using gateways
 - entering analysis input 4-13
 - finding a gateway 4-11
 - performing analysis 4-21
 - selecting Analog Access Gateways for analysis 4-19
 - selecting Cisco IOS H.323 Gateways for analysis 4-18
 - selecting Cisco IOS MGCP Gateways for analysis 4-14
 - selecting Cisco VG248 Phone Gateways for analysis 4-20
 - selecting gateway endpoints 4-13

- selecting non-IOS MGCP Gateways for analysis 4-16
- analysis using phones
 - choosing a phone line 4-8
 - finding a phone 4-6
 - performing analysis 4-9
- analysis using trunks
 - finding a trunk 4-23
 - performing analysis 4-26
 - selecting a trunk 4-25
- audience viii

C

- call flow details 4-36
- CD-ROM documentation xi
- choosing a phone line 4-8
- Cisco.com
 - documentation xi
 - technical assistance xiii
- Cisco TAC Escalation Center xv
- Cisco TAC Web Site xiv
- conventions ix

D

- database synchronization
 - disabling 4-3
 - with Cisco CallManager 4-2
- dialed number analyzer
 - accessing 3-1
 - analysis 1-2
 - analysis output 1-3
 - analyze using gateways 4-11

analyze using phones [4-5](#)
 analyzing Cisco CallManager dial plan configuration [4-1](#)
 database synchronization [4-2](#)
 dialing patterns [1-3](#)
 digit discard instructions [1-3](#)
 features [1-2](#)
 installing [2-1](#)
 introduction [1-1](#)
 logging on [3-1](#)
 logging out [3-5](#)
 more information [1-3](#)
 performing simple analysis [4-3](#)
 starting the DNA service [3-3](#)
 stopping the DNA service [3-5](#)
 trace configuration files [4-44](#)
 uninstalling [2-3](#)
 using trunks for analysis [4-23](#)
 viewing output files [4-43](#)

dialing patterns
 dumping [4-42](#)

digit discard instructions
 dumping [4-42](#)

document
 audience [viii](#)
 conventions [ix](#)
 obtaining [xi](#)
 organization [viii](#)
 purpose [vii](#)

documentation
 CD-ROM [xi](#)
 Cisco.com [xi](#)
 feedback [xii](#)
 ordering [xii](#)
 related [viii](#)

dumping dialing patterns [4-42](#)
 dumping digit discard instructions [4-42](#)

E

examples [4-28](#)

F

features [1-2](#)
 feedback on documentation [xii](#)
 finding a gateway [4-11](#)
 finding a phone [4-6](#)
 finding a trunk [4-23](#)

I

installing dialed number analyzer [2-1](#)

L

logging on to dialed number analyzer [3-1](#)
 logging out from dialed number analyzer [3-5](#)

M

more information [2-4](#)

O

obtaining documentation [xi](#)
 ordering documentation [xii](#)
 organization [viii](#)
 output files, viewing [4-43](#)

P

performing analysis using a trunk [4-26](#)
 performing analysis using gateways [4-21](#)
 performing analysis using phones [4-9](#)
 preface [vii](#)

purpose [vii](#)

R

related documentation [viii](#)

results summary [4-34](#)

S

selecting a trunk [4-25](#)

selecting gateway endpoints [4-13](#)

simple analysis using DNA [4-3](#)

starting the DNA service [3-3](#)

starting the DNA service from Cisco CallManager
Serviceability [3-4](#)

T

technical assistance

 Cisco.com [xiii](#)

 Cisco TAC Escalation Center [xv](#)

 Cisco TAC Web Site [xiv](#)

 obtaining [xiii](#)

 Technical Assistance Center (TAC) [xiii](#)

Technical Assistance Center (TAC) [xiii](#)

trace configuration files

 viewing [4-44](#)

U

understanding analysis output

 alternate matches [4-41](#)

uninstalling DNA [2-3](#)

V

viewing analysis output files [4-43](#)

viewing trace configuration files [4-44](#)

