



---

## A

### authentication

- configuring devices for [5-2](#)
- configuring for SIP trunk [14-2, 14-3](#)
- device security mode configuration settings (table) [5-3, 5-5](#)
- interactions [1-5, 1-6](#)
- overview [1-14](#)
- restrictions [1-5](#)
- with CTI/JTAPI/TAPI applications [11-2](#)

### authentication string [6-2, 11-4](#)

- entering on phone [6-9](#)
- finding phones using [6-8](#)

### authorization [1-14](#)

- configuring for SIP trunk [14-2, 14-3](#)
- interactions [1-6](#)
- overview [1-14](#)

---

## B

### barge

- encryption restrictions with [1-11](#)

### BAT

- configuring with phone packet capturing [16-7](#)

---

## C

### Certificate Authority Proxy Function (CAPF)

- activating service [6-5, 11-8](#)
- authentication string [6-2](#)
  - entering on phone [6-9](#)
- Cisco CAPF service [3-4](#)

### Cisco Unified CallManager Serviceability configuration [6-4](#)

- configuration checklist (table) [6-4](#)
  - configuration settings (table)
    - for CTI/JTAPI/TAPI applications [11-11](#)
  - configuring an application user or end user CAPF profile [11-10](#)
  - deleting an application user or end user CAPF profile [11-13](#)
  - finding an application user or end user CAPF profile [11-9](#)
  - finding phones using LSC or authentication string [6-8](#)
  - generating CAPF report [6-8](#)
  - installation [1-11](#)
  - interactions and requirements [6-3](#)
    - with CTI/JTAPI/TAPI applications [11-5](#)
  - interaction with Cisco Unified IP Phone [6-2](#)
  - overview [6-2](#)
  - overview for CTI/JTAPI/TAPI applications [11-4](#)
  - phone configuration settings (table) [6-7](#)
  - troubleshooting [16-5](#)
    - LSC validation fails [16-6](#)
    - verifying CAPF certificate installation [16-6](#)
    - verifying MIC exists [16-7](#)
  - updating service parameters [6-6](#)
    - for CTI/JTAPI/TAPI [11-9](#)
  - using for phone certificate operations [6-6](#)
  - viewing certificate operation status for application user or end user [11-14](#)
- ### certificates
- Internet Explorer certificate [2-2](#)
  - Netscape certificate [2-5](#)
  - troubleshooting [16-4](#)
  - types [1-12](#)
- ### Cisco CTL client

- Cisco CAPF service [3-4](#)
- Cisco CTL Provider service [3-3](#)
- clusterwide security mode
  - updating [3-11](#)
- configuration checklist (table) [3-2](#)
- configuration settings (table) [3-11](#)
- configuring [3-7](#)
- configuring TLS ports [3-4](#)
- deleting CTL file on phone [3-14](#)
- installation [1-11](#)
- installing [3-5](#)
- migrating [3-7](#)
- overview [3-1](#)
- security token password
  - changing [3-13](#)
- setting the Smart Card service [3-13](#)
- troubleshooting [16-4](#)
- uninstalling [3-15](#)
- upgrading [3-7](#)
- verifying [3-15](#)
- verifying security mode [3-12](#)
- version
  - determining [3-15](#)
- Cisco TFTP services [3-1](#)
- Cisco Unified IP Phone
  - CAPF configuration settings (table) [6-7](#)
  - deleting CTL file [3-14](#)
  - disabling the GARP setting [9-1](#)
  - disabling the PC Port setting [9-2](#)
  - disabling the PC Voice VLAN Access setting [9-2](#)
  - disabling the Setting Access setting [9-2](#)
  - disabling the Web Access setting [9-1](#)
  - encrypted configuration file [7-1](#)
    - configuration checklist (table) [7-4](#)
    - configuring manual key distribution [7-5](#)
    - disabling [7-7](#)
    - enabling [7-4](#)
    - entering symmetric key [7-6](#)
    - manual key configuration checklist (table) [7-6](#)
    - manual key distribution [7-2](#)
    - phone support [7-3](#)
    - symmetric key encryption with public key [7-3](#)
    - using symmetric key encryption w/public key [7-6](#)
    - verifying [7-7](#)
  - entering authentication string [6-9](#)
  - interaction with CAPF [6-2](#)
  - security configuration checklist (table) [4-2](#)
  - security icon restrictions [1-9](#)
  - security icons [1-5](#)
  - troubleshooting
    - authentication string [16-6](#)
    - verifying LSC [16-6](#)
  - understanding security [4-1](#)
  - viewing security settings [4-2](#)
- cluster security mode
  - verifying [3-12](#)
- computer telephony integration (CTI)
  - secure user groups
    - adding application users and end users [11-7](#)
  - securing
    - configuration checklist (table) [11-5](#)
- configuration file encryption [1-18](#)
- CTL client
  - Cisco CAPF service [3-4](#)
  - Cisco CTL Provider service [3-3](#)
  - clusterwide security mode
    - updating [3-11](#)
  - configuration checklist (table) [3-2](#)
  - configuration settings (table) [3-11](#)
  - configuring [3-7](#)
  - configuring TLS ports [3-4](#)
  - deleting CTL file on phone [3-14](#)
  - installing [3-5](#)
  - migrating [3-7](#)
  - overview [3-1](#)
  - security token password
    - changing [3-13](#)
  - setting the Smart Card service [3-13](#)

- troubleshooting [16-4](#)
- uninstalling [3-15](#)
- upgrading [3-7](#)
- verifying [3-15](#)
- verifying security mode [3-12](#)
- version
  - determining [3-15](#)

#### CTL file

- deleting entry [3-10](#)
- deleting on phone [3-14](#)
- updating [3-9](#)

## D

- device authentication [1-14](#)
  - configuring devices for [5-2](#)
- digest authentication [1-14](#)
  - application user digest credential settings (table) [15-3](#)
  - associating digest user with a phone [8-4](#)
  - cluster ID [15-2](#)
  - configuration checklist (table) for phones [8-1](#)
  - configuration settings (table) for end user [8-3](#)
  - configuring a SIP realm [15-4](#)
  - configuring digest credentials for application user [15-2](#)
  - configuring digest credentials for end user [8-3](#)
  - configuring for SIP trunk [14-2, 14-3](#)
  - configuring service parameters [8-2](#)
  - deleting a SIP realm [15-5](#)
  - finding a SIP realm [15-3](#)
  - SIP realm configuration settings (table) [15-5](#)
  - trunk configuration checklist (table) [15-1](#)
- document
  - audience [xii](#)
  - conventions [xiv](#)
  - organization [xii](#)
  - purpose [xii](#)
  - related documentation [xiv](#)

## E

- encryption
  - configuring devices for [5-2](#)
  - configuring SRTP allowed check box [13-6](#)
  - configuring with barge [1-11](#)
  - device security mode configuration settings (table) [5-3, 5-5](#)
  - encrypted configuration file [7-1](#)
    - configuration checklist (table) [7-4](#)
    - configuring manual key distribution [7-5](#)
    - disabling [7-7](#)
    - enabling [7-4](#)
    - entering symmetric key [7-6](#)
    - manual key configuration checklist (table) [7-6](#)
    - manual key distribution [7-2](#)
    - phone support [7-3](#)
    - symmetric key encryption with public key [7-3](#)
    - using symmetric key encryption w/public key [7-6](#)
    - verifying [7-7](#)
  - encrypted signaling
    - configuring for SIP trunk [14-2](#)
  - gateway and trunk configuration checklist (table) [13-4](#)
  - installation [1-11](#)
  - interactions [1-5, 1-6](#)
  - overview [1-18](#)
  - overview for H.323/H.225/H.245 trunk [13-2](#)
  - overview for H.323 gateway [13-2](#)
  - overview for MGCP gateway [13-1](#)
  - overview for SIP trunk [13-3](#)
  - restrictions [1-5, 1-6](#)
    - with authentication [1-7](#)
    - with barge [1-7](#)
    - with media resources [1-8](#)
    - with packet capturing [1-9](#)
    - with phone and trunk devices [1-8](#)
    - with security icons [1-9](#)
  - signaling
    - configuring for SIP trunk [14-3](#)

troubleshooting  
 with packet capturing [16-7](#)  
 with CTI/JTAPI/TAPI applications [11-3](#)

etoken  
 changing password [3-13](#)  
 troubleshooting [16-4](#)

---

## F

file authentication [1-14](#)  
 configuring devices for [5-2](#)

---

## H

### HTTPS

overview [2-1](#)  
 virtual directories (table) [2-1](#)  
 with Internet Explorer [2-2](#)  
 with Netscape [2-5](#)

---

## I

image authentication [1-14](#)

integrity  
 overview [1-14](#)

IP Phone  
 CAPF configuration settings (table) [6-7](#)  
 deleting CTL file [3-14](#)  
 disabling the GARP setting [9-1](#)  
 disabling the PC Port setting [9-2](#)  
 disabling the PC Voice VLAN Access setting [9-2](#)  
 disabling the Setting Access setting [9-2](#)  
 disabling the Web Access setting [9-1](#)  
 encrypted configuration file [7-1](#)  
 configuration checklist (table) [7-4](#)  
 configuring manual key distribution [7-5](#)  
 disabling [7-7](#)  
 enabling [7-4](#)

entering symmetric key [7-6](#)  
 manual key configuration checklist (table) [7-6](#)  
 manual key distribution [7-2](#)  
 phone support [7-3](#)  
 symmetric key encryption with public key [7-3](#)  
 using symmetric key encryption w/public key [7-6](#)  
 verifying [7-7](#)

entering authentication string [6-9](#)  
 interaction with CAPF [6-2](#)  
 security configuration checklist (table) [4-2](#)  
 security icon restrictions [1-9](#)  
 security icons [1-5](#)  
 troubleshooting  
 authentication string [16-6](#)  
 verifying LSC [16-6](#)  
 understanding security [4-1](#)  
 viewing security settings [4-2](#)

### IPSec

configuration checklist (table) [13-4](#)  
 configuring [13-5](#)  
 gateway or trunk considerations [13-5](#)  
 infrastructure considerations [13-5](#)  
 recommendations [13-5](#)

---

## J

### JTAPI

configuring security service parameters [11-14](#)  
 securing  
 configuration checklist (table) [11-5](#)

---

## L

### locally significant certificate (LSC)

finding phones using [6-8](#)  
 troubleshooting  
 validation fails [16-6](#)  
 verifying installation [16-6](#)

with CTI/JTAPI/TAPI applications [11-4](#)

log files

troubleshooting [16-4](#)

---

## M

manufacture-installed certificate (MIC)

verifying [16-7](#)

media encryption

configuring devices for [5-2](#)

overview [1-18](#)

MGCP gateway

configuring [13-5](#)

security configuration checklist (table) [13-4](#)

mode

mixed [1-9](#)

nonsecure [1-9](#)

---

## P

phone

deleting CTL file [3-14](#)

phone hardening

configuring [9-3](#)

disabling the GARP setting [9-1](#)

disabling the PC Port setting [9-2](#)

disabling the PC Voice VLAN Access setting [9-2](#)

disabling the Setting Access setting [9-2](#)

disabling the Web Access setting [9-1](#)

port

Cisco CTL Provider [3-4](#)

Ethernet phone [3-4](#)

SIP secure [3-4](#)

---

## S

secure sockets layer (SSL)

installation [1-11](#)

with HTTPS [2-1](#)

security

authentication overview [1-14](#)

authorization overview [1-14](#)

best practices [1-10](#)

certificate types [1-12](#)

Cisco CTL client overview [3-1](#)

configuration checklist for authentication and encryption  
(table) [1-20](#)

encryption overview [1-18](#)

features list [1-4](#)

features list (table) [1-5](#)

files

backup and restore [16-4](#)

HTTPS [2-1](#)

installation [1-11](#)

interactions [1-5, 1-6](#)

rebooting the cluster [1-10](#)

rebooting the server [1-10](#)

resetting devices [1-10](#)

restarting Cisco Unified CallManager service [1-10](#)

restrictions [1-5, 1-6](#)

cluster and device modes [1-9](#)

system requirements [1-4](#)

terminology (table) [1-2](#)

tokens [3-1, 3-5, 3-7, 3-9, 3-13, 16-4](#)

using barge with encryption [1-11](#)

where to find more information [1-23](#)

security mode

clusterwide

configuring [3-11](#)

security profile

configuration settings (table) for SIP trunk [14-3](#)

configuring for SIP trunk [14-2](#)

finding for SIP trunk [14-1](#)

overview for SIP trunk [14-1](#)

signaling authentication [1-14](#)

configuring devices for [5-2](#)

signaling encryption

configuring devices for [5-2](#)  
 overview [1-18](#)  
 Site Administrator Security Token (SAST) [3-1](#)

## SRST

configuration checklist (table) [12-2](#)  
 configuring references [12-3](#)  
 overview [12-1](#)  
 security settings (table) [12-4](#)  
 troubleshooting [12-5](#)

- certificate deleted on gateway [12-5](#)
- deleting secured reference [12-5](#)
- security messages [12-5](#)

## SRST reference

configuring [12-3](#)  
 security settings (table) [12-4](#)  
 troubleshooting
 

- certificate deleted on gateway [12-5](#)
- deleting secured reference [12-5](#)
- security messages [12-5](#)

## T

### TAPI

configuring security service parameters [11-14](#)  
 securing
 

- configuration checklist (table) [11-5](#)

### TFTP services [3-1](#)

### trace files

troubleshooting [16-4](#)

### transport layer security (TLS) [1-12](#)

port [3-4](#)  
 transport security
 

- and real-time protocol (RTP) [1-12](#)
- and secure real-time protocol (SRTP) [1-12](#)
- configuring for SIP trunk [14-2, 14-3](#)

IPSec [1-12](#)

TLS [1-12](#)

### troubleshooting

alarms [16-2](#)

authentication string entered incorrectly on phone [16-6](#)

CAPF [16-5](#)

certificates [16-4](#)

Cisco CTL client [16-4](#)

configuring BAT with phone packet capturing [16-7](#)

CTL security tokens [16-4](#)

deleting CTL file on phone [3-14](#)

log files [16-4](#)

LSC validation fails [16-6](#)

packet capturing [16-7](#)

packet capturing with encryption [16-7](#)

performance monitor counter descriptions (table) [16-3](#)

performance monitor counters [16-2](#)

SRST certificate deleted on gateway [12-5](#)

SRST messages [12-5](#)

SRST references [12-5](#)

trace files [16-4](#)

using the CLI [16-2](#)

verifying CAPF certificate installation [16-6](#)

verifying LSC installation [16-6](#)

verifying MIC exists [16-7](#)

## V

### voice messaging

security configuration checklist (table) [10-2](#)

security overview [10-1](#)

security requirements [10-1](#)

### voice messaging port

applying a security profile [10-3](#)

applying a security profile using the Wizard [10-3](#)

security configuration checklist (table) [10-2](#)

security overview [10-1](#)