



A

administrators, CAR [14-3](#)

Alarm configuration checklist [7-11](#)

Alarm definition checklist [7-12](#)

Alarms

applications using registry-based alarm
interfaces [7-8](#)

configuration overview [7-2](#)

definitions

catalogs [7-6](#)

definitions window [7-10](#)

described [7-6](#)

editing [7-8](#)

event properties window [7-9](#)

example [7-8](#)

described [7-1](#)

destinations [7-3](#)

event levels [7-4](#)

Event Viewer [7-3](#)

filters [7-4](#)

monitors [7-3](#)

NT Event Viewer [7-3](#)

overview [7-1](#)

SDI trace library [7-3](#)

SDL trace library [7-3](#)

Syslog [7-3](#)

viewing information

overview [7-6](#)

alert menu [9-26](#)

alert notification

configuration

for a counter [9-49](#)

e-mail

for counter [9-49](#)

window [9-50](#)

message [9-49](#)

schedule [9-49](#)

thresholds [9-49](#)

alerts

setting CDR and CAR database [14-39](#)

Appendices

described [1-5](#)

application menu [9-33](#)

authenticate and show CAR pages [14-48](#)

authorization code name report [14-11](#)

authorization level report [14-11](#)

automatic report generation [14-43](#)

B

base rate [14-41](#)

bill

department [14-5](#)

individual [14-4](#)

Bulk Trace Analysis

checklist [13-2](#)

list of topics [13-1](#)

C

call activities category [9-5](#)

Call Detail Records (CDR) [20-2](#)

call details

conference bridge [14-20](#)

call precedence level

CDR search by [14-26](#)

call process activity monitoring [9-39](#)

call termination

CDR search by [14-25](#)

call types, QoS by [14-9](#)

CAR

administrators, managers, users [14-3](#)

CDR search

overview [14-23](#)

checklist [14-50](#)

configuring database purge [14-39](#)

described [14-2](#)

device reports

overview [14-16](#)

list of topics [14-1](#)

report config

overview [14-40](#)

setting database alert [14-39](#)

starting or stopping scheduler [14-40](#)

system [14-33](#)

system reports

overview [14-7](#)

user reports [14-4](#)

category tabs

Real-Time Monitoring Tool [9-46](#)

CCM_SNMP_MIB counters [A-1](#)

CDP

access CDP driver control [22-2](#)

advertisement support [22-1](#)

alter CDP setting [22-2](#)

checklist [22-3](#)

Cisco device support [22-1](#)

default settings [22-2](#)

driver

system prerequisites [22-2](#)

usage [22-2](#)

install CDP protocol driver [22-3](#)

list of topics [22-1](#)

locate updated driver [22-3](#)

periodic messages [22-1](#)

- protocol driver
 - installing [22-3](#)
 - settings [22-2](#)
- CDR
 - configuring database purge [14-39](#)
 - error report [14-16](#)
 - export
 - export CDR/CMR report [14-32](#)
 - load records [14-35](#)
 - logging
 - set up [20-2](#)
 - search
 - by call precedence level report [14-26](#)
 - by cause for call termination report [14-25](#)
 - by gateway report [14-25](#)
 - by user extension report [14-24](#)
 - CAR [14-23](#)
 - for malicious calls report [14-28](#)
 - setting database alert [14-39](#)
 - CDR/CMR export [14-32](#)
 - CDR analysis and reporting
 - general information [14-49](#)
 - internationalization [14-46, 14-48](#)
 - chart
 - counters
 - adding [9-49](#)
 - described [9-47](#)
 - performance monitoring [9-48](#)
 - Cisco ACB Device
 - perfmon object [C-2](#)
 - Cisco Analog Access
 - perfmon object [C-4](#)
 - Cisco Annunciator Device
 - perfmon object [C-5](#)
 - Cisco CallManager
 - perfmon object [C-5](#)
 - Cisco CallManager
 - object counters (figure) [12-2](#)
 - Syslog components [21-3](#)
 - Cisco CallManager service [3-1, 3-2](#)
 - overview [1-1](#)
 - Cisco CallManager System Performance
 - perfmon object [C-20](#)
 - Cisco CDR Insert service [3-2](#)
 - Cisco CTI Manager
 - perfmon object [C-25](#)
 - Cisco CTIManager service [3-7](#)
 - Cisco Database Layer Monitor service [3-3](#)
 - Cisco Discovery Protocol (CDP) [19-3](#)
 - list of topics [22-1](#)
 - Cisco Extension Mobility
 - perfmon object [C-26](#)
 - Cisco Gatekeeper
 - perfmon object [C-26](#)
 - Cisco H.323
 - perfmon object [C-27](#)

- Cisco Hunt Lists
 - perfmon object [C-28](#)
- Cisco HW Conference Bridge Device
 - perfmon object [C-30](#)
- Cisco IP manager/assistant
 - assistant [14-6](#)
 - manager [14-6](#)
- Cisco IP manager/assistant report [14-6](#)
- Cisco IP Manager Assistant Service
 - perfmon object [C-31](#)
- Cisco IP Phone services report [14-7](#)
- Cisco IP Voice Media Streaming Application service [3-6](#)
- Cisco Lines
 - perfmon object [C-32](#)
- Cisco Locations
 - perfmon object [C-33](#)
- Cisco Media Streaming Application
 - perfmon object [C-34](#)
- Cisco Messaging Interface
 - perfmon object [C-44](#)
- Cisco Messaging Interface service [3-6](#)
- Cisco MGCP BRI Device
 - perfmon object [C-46](#)
- Cisco MGCP FXO Device
 - perfmon object [C-47](#)
- Cisco MGCP FXS Device
 - perfmon object [C-48](#)
- Cisco MGCP Gateways
 - perfmon object [C-48](#)
- Cisco MGCP PRI Device
 - perfmon object [C-50](#)
- Cisco MGCP T1CAS Device
 - perfmon object [C-51](#)
- Cisco MOH Audio Translator service [3-7](#)
- Cisco MOH Device
 - perfmon object [C-52](#)
- Cisco MTP Device
 - perfmon object [C-55](#)
- Cisco Phones
 - perfmon object [C-56](#)
- Cisco QSIG features
 - perfmon object [C-57](#)
- Cisco RIS Data Collector service [3-7](#)
- Cisco Secure Telnet
 - checklist [16-4](#)
 - design [16-2](#)
 - list of topics [16-1](#)
 - structure [16-3](#)
 - system design [16-2](#)
 - system diagram [16-3](#)
- Cisco SIP
 - perfmon object [C-58](#)
- Cisco SW Conf Bridge Device
 - perfmon object [C-59](#)
- Cisco Syslog Analysis
 - Cisco Syslog Analyzer [21-1](#)
 - Cisco Syslog Analyzer Collector [21-1](#)

- Cisco Syslog Analyzer Collector
 - function [21-3](#)
 - process [21-3](#)
 - stopping and starting [21-3](#)
- Cisco Syslog Analyzer described [21-3](#)
- Cisco TcdSrv
 - perfmon object [C-61](#)
- Cisco Telephony Call Dispatcher service [3-6](#)
- Cisco TFTP Server
 - perfmon object [C-63](#)
- Cisco TFTP service [3-3](#)
- Cisco Transcode Device
 - perfmon object [C-67](#)
- Cisco Video Conference Bridge
 - perfmon object [C-68](#)
- Cisco WebDialer
 - perfmon object [C-70](#)
- CiscoWorks2000
 - adding devices [21-2](#)
 - Campus Manager [20-1](#)
 - checklist [19-4](#)
 - device information displayed [21-2](#)
 - list of topics [19-1](#)
 - requirements [19-2](#)
 - SNMP requests [21-4](#)
- client matter code report [14-11](#)
- commands
 - show.exe [17-1](#)
 - show command
 - list of topics [17-1](#)
- conference bridges counter information (table) [A-15](#)
- conference bridge utilization report [14-23](#)
- conference call details report [14-20](#)
- configuration
 - alarms
 - overview [7-2](#)
- configuration checklist
 - Alarm configuration [7-11](#)
 - Alarm definition [7-12](#)
 - Bulk Trace Analysis [13-2](#)
 - CAR [14-50](#)
 - CDP [22-3](#)
 - Cisco Secure Telnet [16-4](#)
 - CiscoWorks2000 [19-4](#)
 - Microsoft Performance [12-3](#)
 - path analysis [20-2](#)
 - performance monitoring [9-52](#)
 - Q931 translator [8-14](#)
 - Real-Time Monitoring Tool window [9-13](#)
 - SNMP [18-6](#)
 - system log management [21-5](#)
 - Trace analysis [8-13](#)
 - Trace collection [8-13](#)
 - Trace configuration [8-11](#)
 - troubleshooting trace setting [8-15](#)
- Control Center
 - list of topics [6-1](#)

- service status [6-2](#)
- status icons [6-3](#)
- stop or start a service described [6-3](#)
- conventions [xxiii](#)
- counters
 - add a counter to monitor [9-49](#)
 - CCM_SNMP_MIB [A-1](#)
 - chart view [9-47](#)
 - Cisco CallManager [2-1](#)
 - conference bridge-related information (table) [A-15](#)
 - configure alert notification [9-49](#)
 - CTI-related information (table) [A-14](#)
 - data sample [9-51](#)
 - gateway-related information (table) [A-3](#)
 - H.323-related information (table) [A-12](#)
 - Microsoft PerfMon [A-1](#)
 - MOH-related information (table) [A-17](#)
 - monitoring performance [12-2](#)
 - MTP-related information (table) [A-16](#)
 - object (figure) [12-2](#)
 - perfmon [2-1](#)
 - phone-related information (table) [A-2](#)
 - properties [9-50](#)
 - Real-Time Monitoring Tool [A-1](#)
 - similarities [2-5](#)
 - table view [9-47](#)
 - voice-mail-related information (table) [A-13](#)
 - zoom [9-50](#)

CTI

- application user enabled report [14-7](#)
- counter information (table) [A-14](#)
- CTI monitoring [9-45](#)
- CTI search [9-21](#)
- customizing reports for automatic generation [14-44, 14-45](#)

D

- daily charges
 - setting notification limits for [14-46](#)
- daily reports
 - restoring default schedule [14-38](#)
 - scheduling [14-37](#)
- database
 - configuring CAR and CDR purge [14-39](#)
 - setting alerts [14-39](#)
- data sample, Real-Time Monitoring Tool [9-51](#)
- debug trace levels
 - Trace configuration filter settings [8-10](#)
 - Trace configuration output settings [8-11](#)
- definitions
 - alarms [7-6](#)
 - serviceability [1-6](#)
- department bill report, detail [14-5](#)
- department bill report, summary [14-5](#)
- described [C-2, C-4, C-5, C-20, C-25, C-26, C-27, C-28, C-30, C-31, C-32, C-33, C-34, C-44, C-46, C-47, C-48, C-50, C-51, C-52, C-55, C-56, C-57, C-58, C-59, C-61, C-63, C-67, C-68, C-70](#)

detail

- department bill [14-5](#)
- gateway [14-17](#)
- individual bill report [14-4](#)
- QoS [14-8](#)

device menu [9-24](#)device monitoring [9-45](#)device reports, CAR [14-16](#)devices category [9-3](#)device search [9-18](#)

dial plan

- configuring [14-34](#)

document

- audience [xx](#)
- conventions [xxiii](#)
- organization [xx](#)
- purpose [xix](#)

documentation

- related [xxiii](#)

driver

CDP driver

- control [22-2](#)
- locating interface files [22-3](#)
- locating updated CDP driver [22-3](#)
- using [22-2](#)

CDP protocol

- installing [22-3](#)

CDP system prerequisites [22-2](#)duration [14-41](#)**E**edit menu [9-22](#)enabling reports for automatic generation [14-44, 14-45](#)error, CDR report [14-16](#)error log, generating [14-40](#)event levels for alarms [7-4](#)event log, generating [14-40](#)extension, CDR search by [14-24](#)**F**FAC CMC [14-10](#)features, remote network management [19-2](#)filters, alarms [7-4](#)**G**

gateway

CDR search by [14-25](#)configuration [14-34](#)QoS by [14-9](#)gateway detail report [14-17](#)

gateways

counter information (table) [A-3](#)gateway summary report [14-18](#)gateway utilization report [14-18](#)

H

H.323 counter information (table) [A-12](#)

help menu [9-33](#)

I

individual bill, summary [14-4](#)

individual bill report, detail [14-4](#)

internationalization for CDR analysis and reporting [14-46](#)

IP path analysis [19-2](#)

IP Phone Problem Reports

information included [10-2](#)

L

load, CDR data [14-35](#)

logon page [14-48](#)

M

mail server parameters [14-34](#)

malicious call details [14-11](#)

malicious calls

CDR search for [14-28](#)

Management Information Base (MIB) [18-2](#)

managers, CAR [14-3](#)

manual database purge

configuring [14-39](#)

messages

CDP [22-1](#)

Syslog [21-4](#)

MIB

control of CDP driver [22-2](#)

defined [18-2](#)

enable device discovery [22-2](#)

Microsoft PerfMon

counters [A-1](#)

Microsoft Performance

checklist [12-3](#)

list of topics [12-1](#)

MOH

counter information (table) [A-17](#)

monitoring

performance

add a counter [9-49](#)

Cisco CallManager [12-1](#)

Real-Time Monitoring Tool [9-48](#)

SNMP MIB [2-3](#)

monitor menu [9-16](#)

monitors, alarms [7-3](#)

monthly reports

restoring default schedules [14-38](#)

scheduling [14-38](#)

MTP counter information (table) [A-16](#)

N

notification limits [14-46](#)

NT Event Viewer [7-3](#)

O

objects, Cisco CallManager [2-1](#)

options checklist, remote serviceability [15-2](#)

organization [xx](#)

overview

 administrator rights [14-33](#)

 automatic report generation [14-43](#)

 department bill reports [14-5](#)

 error and event logs [14-39](#)

 individual bill reports [14-4](#)

 of Cisco CallManager [1-1](#)

 of remote serviceability [1-3](#)

 of serviceability [1-1, 1-2](#)

 scheduling reports [14-36](#)

 system report [14-10, 14-16](#)

P

parameters [14-41](#)

 configuring mail server [14-34](#)

 configuring system [14-33](#)

 factoring time of day for rating [14-41](#)

 factoring voice quality for rating [14-42](#)

 restoring default values for rating [14-42](#)

 setting the base rate and duration for rating [14-41](#)

path analysis

 checklist [20-2](#)

 list of topics [20-1](#)

 operation [20-1](#)

 trace [20-1](#)

PathTool [19-2](#)

perfmon

 counters [2-1](#)

 counter similarities [2-5](#)

perfmon counters [C-46, C-47](#)

perfmon menu [9-25](#)

perfmon monitoring [9-45](#)

performance

 data structure [12-2](#)

 monitoring

 Cisco CallManager [12-1](#)

 SNMP MIB [2-3](#)

 objects and counters [12-2](#)

 tool

 function [12-1](#)

 statistics monitor and display [12-1](#)

performance monitoring

 checklist [9-52](#)

Performance Objects and Counters

 described [C-1](#)

 perfmon counters [2-1](#)

performance objects and counters,
described [2-1](#)

permon counters [C-2](#), [C-4](#), [C-5](#), [C-20](#), [C-25](#), [C-26](#),
[C-27](#), [C-28](#), [C-30](#), [C-31](#), [C-32](#), [C-33](#), [C-34](#), [C-44](#),
[C-48](#), [C-50](#), [C-51](#), [C-52](#), [C-55](#), [C-56](#), [C-57](#), [C-58](#),
[C-59](#), [C-61](#), [C-63](#), [C-67](#), [C-68](#), [C-70](#)

Phone Problem Reports Viewer
device management [10-6](#)

phones
counter information (table) [A-2](#)

polling intervals
sample rate [9-47](#)

precedence call summary [14-13](#)

preferences
configuring system [14-35](#)

prerequisites, CDP driver system [22-2](#)

properties, counter [9-50](#)

purge [14-39](#)
configuring CAR and CDR database [14-39](#)

Q

Q931 translator checklist [8-14](#), [8-15](#)

QoS
defining values [14-42](#)
setting notification limits for [14-46](#)

QoS by call types report [14-9](#)

QoS by gateway report [14-9](#)

QoS detail report [14-8](#)

QoS summary report [14-9](#)

Quality Report Tool
list of topics [10-1](#)
understanding [10-1](#)

R

rating parameters
factoring time of day [14-41](#)
factoring voice quality [14-42](#)
restoring default values [14-42](#)
setting the base rate and duration [14-41](#)

Real-Time Information Server (RIS) data
collector [18-6](#)

Real-Time Information Server overview [3-7](#)

Real-Time Monitoring Tool
alert action configuration [9-57](#)
alert customization [9-53](#)
alert summary report [11-20](#)
call activities report [11-15](#)
category tabs, described [9-46](#)
chart view [9-47](#)
checklist [9-13](#)
Cisco serviceability reports archive [11-3](#)
configure alert notification for counter [9-49](#)
counter properties [9-50](#)
counters
add [9-49](#)
alert notify [9-49](#)
chart view [9-47](#)
data sample [9-51](#)

- monitor [9-49](#)
- properties [9-50](#)
- table view [9-47](#)
- zoom [9-50](#)
- data samples [9-51](#)
- default configuration [9-11](#)
- device statistics report [11-4](#)
- directory servers [9-44](#)
- list of topics [9-1](#)
- logging and report generation
 - alert log [9-60](#)
 - call log [9-62](#)
 - device log [9-64](#)
 - logger [9-59](#)
 - perfmon log [9-65](#)
 - server log [9-61](#)
 - service log [9-61](#)
- logging in RIS [9-59](#)
- logon [9-9](#)
- menu bar [9-15, 9-16, 9-17, 9-22, 9-24, 9-25, 9-26, 9-32, 9-33](#)
- monitoring objects [9-2, 9-3, 9-4, 9-5](#)
- monitor performance [2-3, 9-48](#)
- overview [9-2](#)
- performance monitoring
 - described [2-3](#)
 - window [9-48](#)
- polling interval [9-47](#)
- preconfigured alerts [9-58](#)
- remove chart/table entry [9-48](#)
- sample rate [9-47](#)
- search menu [9-18, 9-21](#)
- server statistics report [11-8](#)
- service parameters [9-7](#)
- service statistics report [11-11](#)
- status bar [9-11](#)
- table view [9-47](#)
- window
 - displayed [8-7, 8-8, 8-9, 9-11](#)
 - menu bar [9-14](#)
 - monitor window [9-34](#)
 - alert tab [9-52](#)
 - view tab [9-35, 9-36, 9-39, 9-43, 9-44, 9-45](#)
 - overview [9-11](#)
 - window components [9-14](#)
 - zoom a counter [9-50](#)
- related documentation [xxiii](#)
- remote access methodology [16-2](#)
- remote network management features [19-2](#)
- remote serviceability [1-3](#)
 - checklist [15-2](#)
 - list of topics [15-1](#)
 - tools [1-3](#)
 - tools and programs [15-1](#)
- report [14-11, 14-13](#)
 - authorization code name
 - FAC CMC [14-11](#)
 - authorization level
 - FAC CMC [14-11](#)

- CDR
 - search
 - by user extension [14-24](#)
- CDR error [14-16](#)
- CDR search by call precedence level [14-26](#)
- CDR search by cause for call termination [14-25](#)
- CDR search by gateway [14-25](#)
- CDR search for malicious calls [14-28](#)
- Cisco IP manager/assistant [14-6](#)
- Cisco IP Phone services [14-7](#)
- client matter code
 - FAC CMC [14-11](#)
- conference bridge utilization [14-23](#)
- department bill report [14-5](#)
- forced authorization codes and client matter codes [14-10](#)
- gateway detail [14-17](#)
- gateway summary [14-18](#)
- gateway utilization [14-18](#)
- individual bill report [14-4](#)
- QoS by call types [14-9](#)
- QoS by gateway [14-9](#)
- QoS detail [14-8](#)
- QoS summary [14-9](#)
- route/hunt list utilization [14-19](#)
- route and line group utilization [14-19](#)
- route pattern/hunt pilot utilization [14-20](#)
- system overview [14-16](#)
- top N by charge [14-5](#)
- top N by duration [14-5](#)
- top N by number of calls [14-6](#)
- traffic summary [14-10](#)
- traffic summary by extensions [14-10](#)
- users configured for using CTI applications [14-7](#)
- voice messaging utilization [14-23](#)
- report config, CAR [14-40](#)
- reporting tools [1-5](#)
- reports [14-48](#)
 - automatic generation [14-43](#)
 - customizing for automatic generation [14-44, 14-45](#)
 - customizing parameters [14-45](#)
 - enabling for automatic generation [14-44, 14-45](#)
 - restoring default schedules [14-38](#)
 - scheduling [14-36](#)
 - scheduling daily [14-37](#)
 - scheduling monthly [14-38](#)
 - scheduling weekly [14-37](#)
 - user, CAR [14-4](#)
- requirements
 - of CiscoWorks2000 [19-2](#)
- resource usage
 - view directory server status [9-44](#)
- restoring
 - default schedule for daily, weekly, and monthly reports [14-38](#)
 - default values for rating parameters [14-42](#)
- RIS data collector [18-6](#)

route/hunt list utilization report [14-19](#)
 route and line group utilization report [14-19](#)
 route pattern/hunt pilot utilization report [14-20](#)

S

sample rate [9-47](#)
 scheduler, starting or stopping CAR
 service [14-40](#)
 scheduling
 daily reports [14-37](#)
 monthly reports [14-38](#)
 weekly reports [14-37](#)
 scheduling reports [14-36](#)
 SDI log files, overview [4-4](#)
 SDL log files, overview [4-4](#)
 search
 CDR by call precedence level [14-26](#)
 CDR by cause for call termination [14-25](#)
 CDR by gateway [14-25](#)
 CDR by user extension [14-24](#)
 CDR for malicious calls [14-28](#)
 search menu [9-17](#)
 security, firewall integrity [16-2](#)
 server, mail parameters [14-34](#)
 servers category [9-4](#)
 server status monitoring [9-36](#)
 service
 Cisco CallManager [3-2](#)
 Cisco CDR Insert [3-2](#)
 Cisco Certificate Authority Proxy Function (CAPF) [3-7](#)
 Cisco CTIManager [3-7](#)
 Cisco CTL Provider [3-3](#)
 Cisco Database Layer Monitor [3-3](#)
 Cisco Extended Functions [3-2](#)
 Cisco Extension Mobility [3-5](#)
 Cisco IP Manager Assistant [3-4](#)
 Cisco IP Voice Media Streaming Application [3-6](#)
 Cisco Messaging Interface [3-6](#)
 Cisco MOH Audio Translator [3-7](#)
 Cisco RIS Data Collector [3-7](#)
 Cisco Serviceability Reporter [3-4](#)
 Cisco Telephony Call Dispatcher [3-6](#)
 Cisco TFTP [3-3](#)
 Cisco WebDialer [3-5](#)
 starting or stopping CAR scheduler [14-40](#)
 serviceability
 alarms [1-2](#)
 analyzing tools, overview [4-3](#)
 Cisco CallManager services [3-1](#)
 control center [1-2](#)
 definitions [1-6](#)
 device monitoring tools, overview [4-2](#)
 introduction [1-1](#)
 list of topics [1-1](#)
 performance monitoring tools, overview [4-2](#)
 real-time monitoring [1-2](#)
 remote [1-3](#)

- remote serviceability tools [15-1](#)
- reporting tools [1-5](#)
- SDI, overview [4-4](#)
- SDL, overview [4-4](#)
- service activation [1-2](#)
- terms [1-6](#)
- tools
 - log files [4-3](#)
 - overview [4-1](#)
- trace [1-2](#)
- Serviceability Reports Archive
 - described [11-1](#)
- Service Activation
 - delete services [5-4](#)
 - list of topics [5-1](#)
 - service installation [5-3](#)
 - service status [5-3](#)
 - understanding [5-1](#)
 - view status described [5-4](#)
- service monitoring [9-43](#)
 - Cisco TFTP [9-44](#)
 - directory servers [9-44](#)
 - heartbeat feature [9-44](#)
- service parameters [11-3](#)
- services
 - checking status using Control Center [6-2](#)
 - checking status using Service Activation [5-3](#)
 - status icons [6-3](#)
 - stopping or starting [6-3](#)
 - viewing status [5-4](#)
- services category [9-5](#)
- show command
 - list of topics [17-1](#)
 - syntax [17-1](#)
- Simple Network Management Protocol (SNMP) [18-1](#)
- SNMP
 - agent, enabling [21-4](#)
 - agent defined [18-4](#)
 - basics [18-2](#)
 - checklist [18-6](#)
 - community strings [18-4](#)
 - defined [18-1](#)
 - implementation diagram [18-5](#)
 - MIB [18-2](#)
 - remote monitoring with [18-1](#)
 - RIS data collector [18-6](#)
 - support [19-3](#)
 - traps [18-3](#)
- SNMP MIB [2-3](#)
- starting CAR scheduler service [14-40](#)
- status bar [9-11](#)
- stopping CAR scheduler service [14-40](#)
- summary [9-35](#), [14-13](#)
 - department bill [14-5](#)
 - gateway [14-18](#)
 - individual bill [14-4](#)
 - QoS [14-9](#)

- traffic [14-10](#)
- traffic by extensions [14-10](#)
- syntax
 - show command [17-1](#)
- Syslog
 - analyzer [19-2](#)
 - collector [19-2](#)
 - configuring components [21-3](#)
 - direct messages [21-4](#)
- syslog
 - analysis
 - components (figure) [21-2](#)
 - described [21-1](#)
- system, CAR [14-33](#)
- system logging
 - components (figure) [21-2](#)
 - described [21-1](#)
- system log management [19-2](#)
 - checklist [21-5](#)
 - list of topics [21-1](#)
- system menu [9-15](#)
- system overview report [14-16](#)
- system parameters
 - configuring [14-33](#)
- system preferences
 - configuring [14-35](#)
- system reports, CAR [14-7](#)

T

- Telnet, Cisco Secure
 - design [16-2](#)
 - list of topics [16-1](#)
 - structure [16-3](#)
 - system design [16-2](#)
 - system diagram [16-3](#)
- terms, serviceability [1-6](#)
- time of day [14-41](#)
- top N
 - by charge [14-5](#)
 - by duration [14-5](#)
 - by number of calls [14-6](#)
- top N by charge report [14-5](#)
- top N by duration report [14-5](#)
- top N by number of calls report [14-6](#)
- Trace
 - analysis
 - described [8-6](#)
 - collection procedure [B-3](#)
 - configuration
 - described [8-2](#)
 - filter settings [8-10](#)
 - output settings [8-11](#)
 - configuration verification procedure [B-2](#)
 - example [B-1](#)
 - list of topics [8-1](#)
 - overview [8-2](#)

Q931 translator

described [8-6](#)

reviewing results [B-4](#)

setup procedure [B-3](#)

trace collection tool

described [8-4](#)

troubleshooting example [B-1](#)

troubleshooting trace setting

described [8-7](#)

Trace analysis checklist [8-13](#)

Trace collection checklist [8-13](#)

Trace configuration checklist [8-11](#)

traffic summary by extensions report [14-10](#)

traffic summary report [14-10](#)

traps, SNMP [18-3](#)

U

user reports, CAR [14-4](#)

users, CAR [14-3](#)

utilization

conference bridge [14-23](#)

gateway [14-18](#)

route/hunt list [14-19](#)

route and line group [14-19](#)

route pattern/hunt pilot [14-20](#)

voice messaging [14-23](#)

V

voice mail counter information (table) [A-13](#)

voice messaging utilization report [14-23](#)

voice quality [14-42](#)

W

weekly reports

restoring default schedule [14-38](#)

scheduling [14-37](#)

window menu [9-32](#)

windows

device monitoring [9-11](#)

options

sample rate [9-47](#)

performance monitoring [9-11](#)

Real-Time Monitoring Tool

checklist [9-13](#)

displayed [8-7, 8-8, 8-9, 9-11](#)

overview [9-11](#)

status bar [9-11](#)

Z

zoom a counter [9-50](#)