



Dial Plans and Routing Issues

This section addresses the following common problems that you may experience with dial plans, route partitions, and calling search spaces.

- [Route Partitions and Calling Search Spaces](#)
- [Group Pickup Configuration](#)
- [Dial Plan Issues](#)

Route Partitions and Calling Search Spaces

Route partitions inherit the error-handling capabilities for the Cisco Unified CallManager software. This means that a console and SDI file trace are provided for logging information and error messages. These messages will be part of the digit analysis component of the traces. You must know how the Partitions and Calling Search Spaces are configured and what devices are in each partition and its associated calling search space to determine the source of the problem. The Calling Search Space determines what numbers are available for making a call. The Partition determines allowable calls to a device or route list.

Refer to the route plan chapters in the *Cisco Unified CallManager Administration Guide* and the *Cisco Unified CallManager System Guide* for more information.

The following trace shows an example of a dialed number that is in the device Calling Search Space. For more detailed explanations about SDI traces, review the case studies in this document.

```
08:38:54.968 Cisco CallManager|StationInit - InboundStim -  
OffHookMessageID tcpHandle=0x6b88028
```

```

08:38:54.968 Cisco CallManager|StationD - stationOutputDisplayText
tcpHandle=0x6b88028, Display= 5000
08:38:54.968 Cisco CallManager|StationD - stationOutputSetLamp stim:
9=Line instance=1 lampMode=LampOn tcpHandle=0x6b88028
08:38:54.968 Cisco CallManager|StationD - stationOutputCallState
tcpHandle=0x6b88028
08:38:54.968 Cisco CallManager|StationD -
stationOutputDisplayPromptStatus tcpHandle=0x6b88028
08:38:54.968 Cisco CallManager|StationD - stationOutputSelectSoftKeys
tcpHandle=0x6b88028
08:38:54.968 Cisco CallManager|StationD -
stationOutputActivateCallPlane tcpHandle=0x6b88028
08:38:54.968 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="")

```

In the Digit Analysis component of the previous trace, the pss (Partition Search Space, also known as Calling Search Space) gets listed for the device that is placing the call.

In the following trace, RTP_NC_Hardwood;RTP_NC_Woodland;Local_RTP represent the partitions that this device is allowed to call.

```

08:38:54.968 Cisco CallManager|Digit analysis:
potentialMatches=PotentialMatchesExist
08:38:54.968 Cisco CallManager|StationD - stationOutputStartTone:
33=InsideDialTone tcpHandle=0x6b88028
08:38:55.671 Cisco CallManager|StationInit - InboundStim -
KeypadButtonMessageID kpButton: 5 tcpHandle=0x6b88028
08:38:55.671 Cisco CallManager|StationD - stationOutputStopTone
tcpHandle=0x6b88028
08:38:55.671 Cisco CallManager|StationD - stationOutputSelectSoftKeys
tcpHandle=0x6b88028
08:38:55.671 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="5")
08:38:55.671 Cisco CallManager|Digit analysis:
potentialMatches=PotentialMatchesExist
08:38:56.015 Cisco CallManager|StationInit - InboundStim -
KeypadButtonMessageID kpButton: 0 tcpHandle=0x6b88028
08:38:56.015 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="50")
08:38:56.015 Cisco CallManager|Digit analysis:
potentialMatches=PotentialMatchesExist
08:38:56.187 Cisco CallManager|StationInit - InboundStim -
KeypadButtonMessageID kpButton: 0 tcpHandle=0x6b88028
08:38:56.187 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="500")
08:38:56.187 Cisco CallManager|Digit analysis:
potentialMatches=PotentialMatchesExist

```

```

08:38:56.515 Cisco CallManager|StationInit - InboundStim -
KeypadButtonMessageID kpButton: 3 tcpHandle=0x6b88028
08:38:56.515 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="5003")
08:38:56.515 Cisco CallManager|Digit analysis: analysis results
08:38:56.515 Cisco CallManager||PretransformCallingPartyNumber=5000

```

Be aware that `PotentialMatchesExist` is the result of digit analysis of the numbers that were dialed until the exact match is found and the call is routed accordingly.

The following trace describes what happens when the Cisco Unified CallManager is attempting to dial the directory number 1001 and it is not in the Calling Search Space for that device. Again, be aware that the digit analysis routine had potential matches until only the first digit was dialed. The route pattern that is associated with the digit 1 resides in a partition that is not in the device calling search space, `RTP_NC_Hardwood;RTP_NC_Woodland;Local RTP`. Therefore, the phone received a reorder tone (busy signal).

```

08:38:58.734 Cisco CallManager|StationInit - InboundStim -
OffHookMessageID tcpHandle=0x6b88028
08:38:58.734 Cisco CallManager|StationD - stationOutputDisplayText
tcpHandle=0x6b88028, Display= 5000
08:38:58.734 Cisco CallManager|StationD - stationOutputSetLamp stim:
9=Line instance=1 lampMode=LampOn tcpHandle=0x6b88028
08:38:58.734 Cisco CallManager|StationD - stationOutputCallState
tcpHandle=0x6b88028
08:38:58.734 Cisco CallManager|StationD -
stationOutputDisplayPromptStatus tcpHandle=0x6b88028
08:38:58.734 Cisco CallManager|StationD - stationOutputSelectSoftKeys
tcpHandle=0x6b88028
08:38:58.734 Cisco CallManager|StationD -
stationOutputActivateCallPlane tcpHandle=0x6b88028
08:38:58.734 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="")
08:38:58.734 Cisco CallManager|Digit analysis:
potentialMatches=PotentialMatchesExist
08:38:58.734 Cisco CallManager|StationD - stationOutputStartTone:
33=InsideDialTone tcpHandle=0x6b88028
08:38:59.703 Cisco CallManager|StationInit - InboundStim -
KeypadButtonMessageID kpButton: 1 tcpHandle=0x6b88028
08:38:59.703 Cisco CallManager|StationD - stationOutputStopTone
tcpHandle=0x6b88028
08:38:59.703 Cisco CallManager|StationD - stationOutputSelectSoftKeys
tcpHandle=0x6b88028
08:38:59.703 Cisco CallManager|Digit analysis: match(fqcn="5000",
cn="5000", pss="RTP_NC_Hardwood:RTP_NC_Woodland:Local RTP", dd="1")
08:38:59.703 Cisco CallManager|Digit analysis:
potentialMatches=NoPotentialMatchesExist

```

```
08:38:59.703 Cisco CallManager|StationD - stationOutputStartTone:  
37=ReorderTone tcpHandle=0x6b88028
```

Route partitions work by associating a partition name with every directory number in the system. The directory number can be called only if the calling device contains the partition within a list of partitions to which it is permitted to place calls—its partition search space. This provides for extremely powerful control over routing.

When a call is being placed, digit analysis attempts to resolve the dialed address only in those partitions that the partition search space specifies. Each partition name comprises a discrete subset of the global dialable address space. From each listed partition, digit analysis retrieves the pattern that best matches the sequence of dialed digits. Then, from among the matching patterns, digit analysis chooses the best match. If two patterns equally match the sequence of dialed digits, digit analysis breaks the tie by choosing the pattern that is associated with the partition that is listed first in the partition search space.

Group Pickup Configuration

Symptom

Group pickup feature does not work for a group that is configured with a partition.

Possible Cause

The Calling Search Space (CSS) may not be configured correctly for each Directory Number (DN) in the group

Example

The following steps provide an example of correct group pickup configuration with partitioning:

1. Configure a pickup group named *Marketing/5656*, where *Marketing* is the partition and *5656* is the pickup number.
2. On the configuration for DNs 6000 and 7000, respectively, add these DNs to the pickup group that is named *Marketing/5656*.

Recommended Action

If group pickup fails, check the CSS of each domain name (DNs 6000 and 7000 in this example). If the partition that is called *Marketing* is not contained in each CSS in this example, then the configuration is incorrect and may cause a failed pickup.

Dial Plan Issues

This section addresses the following dial plan issues:

- [Problem When Dialing a Number](#)
- [Secure Dial Plan](#)

Problem When Dialing a Number

Symptom

Problems occur when a number is dialed.

Possible Cause

A Dial Plan comprises a list of numbers and groups of numbers that tell the Cisco Unified CallManager to what devices (such as phones and gateways) to send calls when a certain string of digits is collected. Consider this setup as analogous to a static routing table in a router.

Be sure that your dial plan concepts, basic call routing, and planning are carefully considered and properly configured before trying to troubleshoot a potential dial plan issue. Often, the problem lies with planning and configuration. Refer to the route plan configuration chapters in the *Cisco Unified CallManager Administration Guide* for more information.

Recommended Action

1. Identify the Directory Number (DN) that is originating the call.
2. Identify the Calling Search Space for this DN.



Tip The Calling Search Space determines what numbers are available for making a call.

3. If applicable, identify devices with which the Calling Search Space associates with this DN. Make sure that you identify the correct device; because multiple line appearances are supported, you can have the same DN on multiple devices. Keep track of the device calling search space.

If this is a Cisco Unified IP Phone that is originating the call, remember that a particular line (DN) and the device with which a line is associated have calling search spaces. They will get combined when a call is made. For example, if line instance 1000 has a Calling Search Space of AccessLevelX and the Cisco Unified IP Phone that has extension 1000 configured on it has AccessLevelY as its Calling Search Space, then when making a call from that line appearance, Cisco Unified CallManager will search through partitions that are contained in Calling Search Space AccessLevelX and AccessLevelY.

4. Identify which Partitions associate with the Calling Search Space(s).



Tip The Partition determines allowable calls to a device or route list.

5. Identify to which Partition of the device the call should (or should not) go.
6. Identify which number is being dialed. Keep track of if and when the user is getting a secondary dial tone. Also keep track of what they receive after all the digits have been entered (reorder, fast-busy). Does the user get the progress tones before expecting to receive anything? Make sure that callers wait at least 10 seconds after entering the last digit because they may have to wait for the interdigit timer to expire.
7. Generate a Route Plan Report in Cisco Unified CallManager Administration and use it to examine all the route patterns for the partitions that are in the Calling Search Space for the problem call.
8. If necessary, add or modify the Route Patterns or Route Filters.
9. If you can find the Route Pattern to which the call is being sent, keep track of the Route List or Gateway to which the pattern points.
10. If it is a Route List, check which Route Groups are part of the list and which gateway(s) is part of the Route Groups.
11. Verify that the applicable devices are registered with Cisco Unified CallManager.
12. If a gateway has no access to Cisco Unified CallManager, use the show tech command to capture and verify this information.
13. Pay attention to the @ sign. This macro can expand to include many different things. It gets often used in combination with filtering options.
14. If a device is not part of a partition, consider it to be part of the Null or default partition. Every user should be able to call that device. The system always searches the Null partition last.
15. If you dial an outside number that is matching a 9.@ pattern and it takes 10 seconds before the call goes through, check the filtering options. By default, with a 9.@ pattern, when a 7-digit number is dialed, the Cisco Unified IP Phone will wait 10 seconds before placing the call. You

need to apply a Route Filter to the pattern that displays
LOCAL-AREA-CODE DOES-NOT- EXIST and END-OF-DIALING
DOES-NOT-EXIST.

Secure Dial Plan

Use partitions and calling search spaces, in addition to more common filtering based on sections of the @ macro (which stands for the North American Numbering Plan) in a route pattern, to configure Cisco Unified CallManager to create a secure dialing plan for users. Partitions and Calling Search Spaces provide an integral part of security and are especially useful for multitenant environments and for creating an individual user level. Filtering, a subset of the Calling Search Space/Partition concept, can add additional granularity to the security plan.

Be advised that usually the last thing that you want to do when you try to fix a filtering problem is to run an SDI trace. Not enough information exists, and the potential for causing more harm is too great.