




## Uobičajene radnje sa telefonom

Pregledanje pomoći na mreži za telefon	Pritisnite  , a zatim odaberite <b>Pomoć</b> .
Upućivanje poziva	Podignite slušalicu pre ili posle biranja broja.
Ponovno biranje broja	Pritisnite <b>PonBir</b> .
Razgovaranje korišćenjem ručne slušalice, uz slušanje tona na zvučniku	(Samo u režimu grupnog slušanja.) Pritisnite <b>GListen</b> .
Slušanje tona samo na zvučniku	(Samo u režimu monitora.) Pritisnite <b>Monitor</b> .
Korišćenje evidencije poziva	Pritisnite  , a zatim izaberite <b>Katalozi &gt; Propušteni pozivi, Pozvani brojevi</b> ili <b>Primljeni pozivi</b> . Izaberite broj i pritisnite <b>Biraj</b> .
Uređivanje broja	Pritisnite <b>UredBr</b> , << ili >>.
Stavljanje poziva na čekanje/preuzimanje poziva	Istaknite poziv da biste ga stavili na čekanje ili preuzeli sa čekanja, a zatim pritisnite  .
Prenos poziva na novi broj	Pritisnite <b>Prenesi</b> , unesite broj, a zatim ponovo pritisnite <b>Prenesi</b> .
Započinjanje standardnog (ad hok) konferencijskog poziva	Pritisnite <b> dodatno &gt; Konfer</b> , izaberite broj učesnika, a zatim ponovo pritisnite <b>Konfer</b> .



Cisco, Cisco Systems, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0610R)

© 2007 Cisco Systems, Inc. All rights reserved.

OL-13366-01



### KRATKE INFORMACIJE



## Cisco Unified IP telefon 7906G i 7911G za Cisco Unified Communications Manager 6.0 (SCCP i SIP)

Definicije softverskih tastera

Ikone ekrana telefona

Ikone dugmadi

Brzo biranje

Uobičajene radnje sa telefonom

## Definicije softverskih tastera

<b>Ažuriraj</b>	Osvežavanje sadržaja
<b>Biraj</b>	Biranje broja telefona
<b>Detalji</b> (samo za SCCP)	Otvaranje zapisa „Detalji“ za poziv sa više strana u evidencijama „Propušteni pozivi“ i „Primljeni pozivi“
<b>DirPren</b> (samo za SCCP)	Prenos dva poziva jednog drugome
<b>dodatno</b>	Prikaz dodatnih softverskih tastera
<b>DodSebe</b>	Dodavanje sebe u poziv na deljenoj liniji
<b>GJaviSe</b>	Odgovor na poziv u drugoj grupi
<b>GListen</b>	Razgovaranje korišćenjem ručne slušalice, uz ton na zvučniku (grupno slušanje)
<b>GLOff</b>	Onemogućavanje grupnog slušanja
<b>IskljMon</b>	Onemogućavanje funkcije „Monitor“
<b>Izadi</b>	Povratak na prethodni ekran
<b>Izbriši</b>	Uklanjanje znakova desno od kursora pri korišćenju funkcije „UredBr“
<b>JaviSe</b>	Odgovor na poziv u svojoj grupi
<b>kDodSebe</b>	Dodavanje sebe u poziv na deljenoj liniji i uspostavljanje konferencije
<b>Konfer</b>	Kreiranje konferencijskog poziva
<b>MeetMe</b>	Uspostavljanje „Meet-Me“ konferencije
<b>Monitor</b>	Slušanje poziva preko zvučnika
<b>NeUzn</b>	Uključivanje/isključivanje funkcije „Ne uznemiravaj“ (NeUzn)
<b>NoviPoz</b>	Upućivanje novog poziva
<b>Obriši</b>	Brisanje zapisa ili podešavanja
<b>Odgovori</b>	Odgovor na poziv
<b>OJaviSe</b>	Odgovor na poziv koji zvuči u pridruženoj grupi




<b>Otkazi</b>	Otkazivanje radnje ili napuštanje ekrana bez primene izmena
<b>Park</b>	Skladištenje aktivnog poziva pomoću opcije parkiranja poziva
<b>PočVredn</b>	Vraćanje podešavanja na podrazumevano stanje
<b>PonBir</b>	Pozivanje poslednjeg biranog broja
<b>Por.</b>	Pristup sistemu glasovne pošte
<b>PrekPoz</b>	Prekid tekućeg poziva
<b>Prenesi</b>	Prenos poziva
<b>Pretraži</b>	Pretraživanje kataloga
<b>PrimObav</b>	Primanje obaveštenja kad lokal koji je zauzet postane dostupan
<b>PrSve</b>	Podešavanje/otkazivanje prosleđivanja poziva
<b>QRT</b>	Prosleđivanje problema vezanih za pozive administratoru sistema
<b>SkrBir</b>	Pozivanje korišćenjem broja indeksa brzog biranja
<b>Spoji</b> (samo za SCCP)	Spajanje više poziva na jednoj liniji da bi se uspostavila konferencija
<b>tSkreni</b>	Slanje ili preusmeravanje poziva na sistem za razmenu glasovnih poruka
<b>Učesnici</b>	Pregled učesnika konferencije
<b>Ukloni</b>	Uklanjanje učesnika konferencije
<b>UkIPUč</b>	Odbacivanje poslednjeg učesnika dodatog konferencijskom pozivu
<b>UredBr</b>	Uređivanje broja u evidenciji poziva
<b>VidRežim</b> (samo za SCCP)	Biranje režima video ekrana
<b>Zatvori</b>	Zatvaranje tekućeg prozora
<<	Brisanje unetih znakova
>>	Kretanje kroz unete znakove

## Ikone ekrana telefona





### Status linije i poziva

	Prosleđivanje poziva omogućeno
	Poziv stavljen na čekanje
	Uspostavljena veza
	Podignuta slušalica
	Spuštena slušalica
	Dolazni poziv
	Deljena linija se koristi
	Autorizovani poziv
	Šifrovani poziv
	Prioritetan poziv
	Poziv srednjeg prioriteta
	Poziv visokog prioriteta
	Poziv najvišeg prioriteta
<b>Ostale funkcije</b>	
	Brzo biranje konfigurisano
	Poruka čeka
	Opcija izabrana
	Funkcija omogućena
	Stavka URL adrese u evidenciji poziva je spremna za uređivanje (samo za SIP)

### Audio ili Video režim

	Ručna slušalica se koristi
	Zvučnik se koristi (funkcija „Monitor“ uključena)
	Video omogućen (Cisco Unified IP telefon 7911G samo za SCCP)

## Ikone dugmadi



	Jačina tona
	Navigacija
	Čekanje
	Meni aplikacija

## Brzo biranje

### Ako želite da...

Pozovete broj pomoću brzog biranja

### Uradite sledeće...

- Pritisnite  i izaberite broj koji želite da pozovete.
- Pritisnite , a zatim odaberite **Katalozi > Brza biranja**. Izaberite broj koji ćete pozvati.
- Unesite broj brzog biranja dok je slušalica spuštena, a zatim pritisnite **SkrBir**.