



## INDEX

---

### Numerics

- 802.11a standard [2-3](#)
- 802.11b standard [2-3](#)
- 802.11g standard [2-3](#)

---

### A

- active mode [3-17](#)
- AES
  - encryption description [2-18](#)
- AP
  - associating [2-11](#)
  - Cisco Aironet Access Point [2-10](#)
  - description [2-10](#)
  - troubleshooting [10-2](#)
- AP settings, identifying [10-7](#)
- audience, for this document [1-xi](#)
- authenticated call [1-14](#)
- authentication [5-12](#)
  - selecting type [5-9](#)
  - wireless network setting [5-9](#)
- auto-pickup [7-2](#)
- auto-registration
  - using [3-3](#)
  - using with TAPS [3-3](#)
- auxiliary VLAN, description [2-11](#)

---

### B

- barge [1-15, 7-3](#)
- BAT (Bulk Administration Tool) [3-4](#)
- battery

- charging times with power supply [3-8](#)
- description [3-8](#)
- installing and removing [3-8](#)
- types available [3-8](#)
- battery caution [3-6](#)
  - charging [3-7](#)
  - damaged [3-7](#)
  - disposal [3-7](#)
  - replacement re [3-7](#)
  - temperature [3-7](#)
- battery safety notices [3-6](#)
- battery warning
  - disposal [3-6](#)
  - explosion [3-6](#)
- block external to external transfer [7-3](#)
- Bluetooth
  - qualified device ID [1-1, 1-2](#)
- Bluetooth qualified device [1-6](#)
- Bluetooth technology
  - adaptive frequency hopping [1-6](#)
  - overview [1-6](#)
  - pairing headsets [3-14](#)
  - power and range by class [1-6](#)
  - unlicensed band [1-6](#)
  - using Bluetooth wireless headsets [3-14](#)
- Busy Lamp Field (BLF) speed dial [7-3](#)

---

### C

- call
  - authenticated [1-14](#)
  - encrypted [1-14](#)
  - protected [1-14](#)

- Call Back [7-3](#)
  - call display restrictions [7-4](#)
  - caller ID [7-5](#)
  - call forward
    - all calls [7-4](#)
    - display, configuring [7-4](#)
    - loop breakout [7-4](#)
    - loop prevention [7-4](#)
  - call forward display, configuring [7-4, 7-6](#)
  - call park [7-5](#)
  - call pickup [7-5](#)
  - call statistics screen [8-1, 8-13](#)
  - call waiting [7-5](#)
  - CAPF (Certificate Authority Proxy Function) [1-13, 5-12](#)
  - cautions
    - for battery pack [3-6](#)
    - for charging battery pack [3-7](#)
    - for damaged battery [3-7](#)
    - for disposing of battery pack [3-7](#)
    - for exposing battery pack to high temperatures [3-7](#)
    - for replacing battery pack [3-7](#)
    - for replacing power supply [3-7](#)
    - translations [3-5](#)
  - CDP
    - description [2-9](#)
  - CDP settings [5-7](#)
  - change password web page [4-39](#)
  - Cisco Discovery Protocol, See CDP
  - Cisco Unified Communications Manager
    - adding phone to database of [3-2](#)
    - configuring DHCP settings [2-14](#)
    - interacting with [2-13](#)
    - restricting phone settings access [5-1, 5-2, 5-10](#)
    - verifying settings [10-6](#)
  - Cisco Unified Communications Manager Administration
    - adding telephony features [7-2](#)
  - Cisco Unified IP Phone
    - configuration requirements [D-1](#)
    - installation overview [D-1](#)
    - installation requirements [D-1](#)
    - online help for [A-3](#)
    - using LDAP directories [7-20](#)
  - Cisco Unified Wireless IP Phone
    - overview [1-1](#)
    - web page [4-1, 9-1](#)
  - Cisco Unified Wireless IP Phone, See also wireless IP phone
  - Cisco Unified Wireless IP Phone specifications [C-1](#)
  - client matter codes [7-6](#)
  - conference [7-6](#)
  - configurable call forward display [7-6](#)
  - configuration file
    - creating new [10-6](#)
    - encrypted [1-13](#)
    - overview [2-13](#)
    - SEPXXXXXXXXXXXX.cnf.xml [2-13](#)
    - XMLDefault.cnf.xml [2-13](#)
  - configuring
    - LDAP directories [7-20](#)
    - overview [D-1](#)
    - personal directories [7-20](#)
    - phone book [4-30](#)
    - softkey templates [7-17](#)
    - user features [7-21](#)
    - Wavelink settings [4-29, 6-1](#)
  - CTL file
    - unlocking [8-3](#)
  - CTL file screen [8-2](#)
  - current configuration
    - viewing [8-9, 8-11](#)
- 
- D**
- data VLAN [2-11](#)
  - device authentication [1-12](#)
  - device information menu, about [8-1](#)
  - device information web page [9-6](#)
  - DHCP

- description [2-9](#)
- displaying settings [5-5](#)
- enable, network setting [5-4](#)
- gateway [2-14](#)
- interacting with [2-14](#)
- IP address [2-14](#)
- modifying settings [5-5](#)
- priority for TFTP server [2-14](#)
- scope settings [2-14](#)
- subnet mask [2-14](#)
- troubleshooting [10-8](#)

directed call park [7-7](#)

directory numbers, assigning manually [3-4](#)

direct-sequence spread spectrum (DSSS) [2-6](#)

direct transfer [7-7](#)

displaying, network statistics [8-12](#)

disposal warning [3-6](#)

DNS server

- settings for TFTP server [2-14](#)
- troubleshooting [10-9](#)
- verifying settings [10-5](#)

documentation

- additional [1-xiii](#)
- for users [A-3](#)
- localized versions [B-1](#)

dynamic host configuration protocol, See DHCP

---

## E

- editing configuration values, guidelines [5-4](#)
- encrypted call [1-14](#)
- encrypted configuration file [1-13](#)
- encryption

  - media [1-12](#)
  - signaling [1-13](#)
  - WEP key [4-16](#)

- erase configuration, procedure [10-17](#)
- explosive gas warning [3-5](#)
- extension mobility, description [7-8](#)

---

## F

- features

  - configuring with Cisco Unified Communications Manager [1-9](#)
  - See also telephony features

- file

  - creating new configuration [10-6](#)

- file authentication [1-12](#)
- firmware

  - verifying version [8-16](#)

- forced authorization codes [7-9](#)

---

## G

- group call pickup [7-9](#)

---

## H

- help, using [A-3](#)
- hold [7-9](#)
- hold reversion [7-9](#)
- hunt group [7-9](#)

---

## I

- icon

  - lock [1-14](#)
  - padlock [1-14](#)
  - shield [1-14](#)

- image authentication [1-12](#)
- immediate divert [7-9](#)
- Immediate Divert enhanced feature [7-10](#)
- installation

  - network requirements [3-1](#)
  - preparing [3-2](#)

- installation warning [3-5](#)
- installing

  - requirements, overview [D-1](#)

intercom [7-10](#)  
 International Call Logging [B-2](#)  
 Internet Protocol (IP) [2-9](#)  
 IP, description [2-9](#)  
 IP address [2-15, 4-24, 5-6](#)  
     troubleshooting [10-5](#)

---

## J

join [7-10](#)  
 join across lines [7-10](#)

---

## L

LDAP directories, using with Cisco Unified IP  
 Phone [7-20](#)  
 LEAP  
     description [2-17](#)  
 light extensible authentication protocol, See LEAP  
 local configuration, erasing [10-17](#)  
 Locale Installer [B-1](#)  
 localization  
     Installing the Cisco Unified Communications Manager  
     Locale Installer [B-1](#)  
 Locally Significant Certificate (LSC) [5-12](#)  
 lock icon [1-14](#)

---

## M

MAC address  
     determining [3-2](#)  
 malicious caller identification (MCID) [7-10](#)  
 manufacturing installed certificate (MIC) [1-12](#)  
 media encryption [1-12](#)  
 meet-me conference [7-10](#)  
 message waiting [7-11](#)  
 metrics, voice quality [8-15, 9-11](#)  
 MIC [1-12](#)  
 model information screen [8-1](#)

music-on-hold [7-11](#)

---

## N

native VLAN [2-11](#)  
 neighbor list utility [2-21](#)  
 network configuration menu  
     displaying [5-2](#)  
     displaying WLAN configuration menu [5-8](#)  
     editing options [5-4](#)  
 network configuration web page [9-2, 9-3](#)  
 network connectivity, verifying [10-4](#)  
 networking protocol  
     CDP [2-9](#)  
     DHCP [2-9](#)  
     IP [2-9](#)  
     RTP [2-9](#)  
     SCCP [2-10](#)  
     supported [2-9](#)  
     TCP [2-10](#)  
     TFTP [2-10](#)  
     TLS [2-10](#)  
     UDP [2-10](#)  
 network outages, identifying [10-8](#)  
 network protocol  
     LEAP [2-17](#)  
     RTCP [2-9](#)  
 network requirements, for installation [3-1](#)  
 network settings  
     accessing on phone [5-1](#)  
     configuring [5-1](#)  
     DHCP enable [5-4](#)  
 network statistics [9-9](#)  
 network statistics, viewing [8-12](#)  
 network statistics web page [9-2](#)

---

**O**

on-hook call transfer [7-11](#)

online help, using [A-3](#)  
 open authentication, description [2-15](#)  
 open authentication with WEP, description [2-15](#)  
 orthogonal frequency division multiplexing (OFDM) [2-3](#),  
[2-6](#)  
 other group pickup [7-11](#)

## P

padlock icon [1-14](#)  
 personal directories, configuring [7-20](#)  
 phone book, using [4-30](#)  
 phone mode  
     active [3-17](#)  
     standby [3-17](#)  
 phone operation for users [A-1](#)  
 phone resets, resolving problems [10-7](#)  
 phones, installing [1-16](#)  
 phone settings  
     access restrictions [5-1](#), [5-2](#), [5-10](#)  
     menu [5-10](#)  
 phone upgrade web page [4-38](#)  
 phone web page  
     about [4-1](#), [9-1](#)  
     accessing [4-5](#), [9-1](#)  
     change password [4-39](#)  
     device information [9-6](#)  
     installing drivers [4-1](#)  
     network configuration [9-3](#)  
     network statistics [9-2](#), [9-9](#)  
     phone upgrade [4-38](#)  
     profile settings [4-8](#)  
     summary information [4-7](#), [9-2](#)  
     system settings [4-35](#)  
     trace logs [4-35](#)  
     trace settings [4-27](#)  
     USB settings [4-26](#)  
 plug-socket warning [3-5](#)  
 power outage warning [3-5](#)

power supply  
     figure, connected [3-11](#)  
 power supply replacement caution [3-7](#)  
 power supply warning [3-6](#)  
 presence-enabled directories [7-11](#)  
 primary DNS server [2-15](#), [4-24](#), [5-6](#)  
 primary gateway [2-15](#), [4-24](#), [5-6](#)  
 primary TFTP server [5-6](#)  
 privacy [7-11](#)  
 profile settings web page [4-8](#)  
 protected call [1-14](#)  
     description [1-14](#)  
 Protected Calls [1-14](#)  
 Push to Talk service [7-11](#)

## Q

QDID [1-6](#)  
 QRT softkey [7-12](#)  
 Quality of Service (QoS) [2-11](#)  
 Quality Reporting Tool (QRT) [7-12](#)

## R

RADIUS server authentication, description [2-16](#), [2-17](#)  
 real-time control protocol, See RTCP  
 real-time transport protocol, See RTP  
 received signal strength indicator, See RSSI  
 redial [7-12](#)  
 resetting, phones [10-8](#)  
 resolving startup problems [10-1](#) to [10-6](#)  
 resolving voice quality problems [10-7](#) to [10-11](#)  
 ring activity [7-12](#)  
 ringlist.xml [7-23](#)  
 ring tone, creating custom [7-23](#)  
 roaming [2-7](#)  
     fast and secure with CCKM [2-7](#)  
     layer 3 [2-7](#)  
     Layer 3 with WLSM [2-7](#)

- mid-call [2-7](#)
- pre-call [2-7](#)
- resolving problems [10-7](#)
- RSSI, description [2-11](#)
- RTCP, description [2-9](#)
- RTP description [2-9](#)

## S

- SCCP description [2-10](#)
- secure SRST reference [1-12](#)
- security
  - AES encryption [2-18](#)
  - CAPF (Certificate Authority Proxy Function) [1-13](#), [5-12](#)
  - device authentication [1-12](#)
  - encrypted configuration file [1-13](#)
  - file authentication [1-12](#)
  - image authentication [1-12](#)
  - manufacturing installed certificate (MIC) [1-12](#)
  - media encryption [1-12](#)
  - open authentication [2-15](#)
  - open authentication with WEP [2-15](#)
  - RADIUS server authentication [2-16](#), [2-17](#)
  - secure SRST reference [1-12](#)
  - security profiles [1-13](#)
  - shared key authentication [2-15](#)
  - signaling authentication [1-12](#)
  - signaling encryption [1-13](#)
  - static WEP encryption [2-17](#)
  - TKIP encryption [2-18](#)
  - WLAN overview [2-15](#)
  - WPA authentication [2-17](#)
- security configuration menu, about [8-1](#)
- security profiles [1-13](#)
- SEPxxxxxxxxxxxx.cnf.xml configuration file [2-13](#)
- services
  - description [7-12](#)
  - subscribing to [7-19](#)
- service set identifier, See SSID
- shared key authentication, description [2-15](#)
- shared lines [7-12](#)
- shield icon [1-14](#)
- short circuit protection warning [3-6](#)
- signaling authentication [1-12](#)
- signaling encryption [1-13](#)
- site survey
  - performing [2-20](#)
  - verification steps [2-20](#)
- site survey utility
  - display values [2-21](#)
- skinny client control protocol, See SCCP
- softkey templates, configuring [7-17](#)
- specifications
  - operating environment [C-1](#)
  - physical [C-1](#)
- speed dial
  - default buttons for [7-18](#)
  - hot key, assigning [4-34](#)
- speed dialing [7-2](#), [7-13](#)
- SRST [9-5](#)
  - secure reference [1-12](#)
- SSID
  - description [5-9](#)
  - wireless network setting [5-9](#)
- standby mode [3-17](#)
- startup
  - resolving problems with [10-1](#)
- startup process
  - contacting Cisco Unified Communications Manager [3-19](#)
  - DHCP disabled [2-14](#)
- static settings
  - IP address [2-15](#), [4-24](#), [5-6](#)
  - primary DNS server [2-15](#), [4-24](#), [5-6](#)
  - primary gateway [2-15](#), [4-24](#), [5-6](#)
  - primary TFTP server [5-6](#)
  - subnet mask [2-15](#), [4-24](#), [5-6](#)

- statistics
    - call [8-13](#)
    - network [9-9](#)
  - statistics, network [8-12](#)
  - status information [8-9, 8-11](#)
  - status menu [8-1, 8-8](#)
  - subnet mask [2-15, 4-24, 5-6](#)
  - summary information web page [4-7](#)
  - survivable remote site telephony (SRST)
    - IP address of router [8-4](#)
  - symptom
    - phone resets [10-7](#)
  - system log server [10-17](#)
- 
- T**
- TAPS (Tool for Auto-Registered Phones Support) [3-3](#)
  - TCP
    - description [2-10](#)
  - telephone receiver warning [3-6](#)
  - telephony features
    - auto-pickup [7-2](#)
    - barge [1-15, 7-3](#)
    - block external to external transfer [7-3](#)
    - Busy Lamp Field (BLF) speed dial [7-3](#)
    - call display restrictions [7-4](#)
    - caller ID [7-5](#)
    - call forward [7-4](#)
    - call forward configurable display [7-4](#)
    - call park [7-5](#)
    - call pickup [7-5](#)
    - call waiting [7-5](#)
    - Cisco Call Back [7-3](#)
    - client matter codes [7-6](#)
    - conference [7-6](#)
    - configurable call forward display [7-6](#)
    - configuration references [7-2](#)
    - descriptions [7-2](#)
    - directed call park [7-7](#)
    - direct transfer [7-7](#)
    - extension mobility [7-8](#)
    - forced authorization codes [7-9](#)
    - group call pickup [7-9](#)
    - hold [7-9](#)
    - hold reversion [7-9](#)
    - hunt group [7-9](#)
    - immediate divert [7-9](#)
    - join [7-10](#)
    - malicious caller identification (MCID) [7-10](#)
    - meet-me conference [7-10](#)
    - music-on-hold [7-11](#)
    - no not disturb (DND) [7-8](#)
    - on-hook call transfer [7-11](#)
    - other group pickup [7-11](#)
    - presence-enabled directories [7-11](#)
    - Push to Talk service (XML application) [7-11](#)
    - redial [7-12](#)
    - ring activity [7-12](#)
    - services [7-12](#)
    - shared lines [7-12](#)
    - speed dialing [7-13](#)
    - supported [7-2](#)
    - Time-of-Day Routing [7-13](#)
    - transfer [7-13](#)
    - voice messaging system [7-13](#)
  - template
    - phone button, modifying [7-18](#)
  - TFTP
    - description [2-10](#)
    - troubleshooting [10-4](#)
  - TFTP server
    - assigning to phone [4-25, 5-7](#)
    - options [4-25, 5-7](#)
  - Time-of-Day Routing [7-13](#)
  - TKIP
    - encryption description [2-18](#)
  - trace logs web page [4-35](#)
  - trace route

option on phone [10-17](#)

trace settings web page [4-27](#)

transfer [7-13](#)

transmission control protocol, See TCP

transport layer security  
See TLS

trivial file transfer protocol, See TFTP

troubleshooting

- AP settings [10-2, 10-7](#)
- Cisco Unified Communications Manager settings [10-6](#)
- DHCP [10-8](#)
- DNS [10-9](#)
- DNS settings [10-5](#)
- general information [10-13](#)
- IP addressing and routing [10-5](#)
- logging information [10-16](#)
- network connectivity [10-4](#)
- network outages [10-8](#)
- phones resetting [10-8](#)
- TFTP settings [10-4](#)
- VLAN configuration [10-8](#)
- wireless IP phone [10-1](#)

Trust List screen [8-3](#)

---

## U

UDP description [2-10](#)

USB configuration [4-1](#)

- displaying menu [5-13](#)

USB settings web page [4-26](#)

user datagram protocol, See UDP

User Options web page

- description [7-22](#)
- giving users access to [7-22](#)
- specifying options that appear [7-22](#)

users

- accessing voice messages [A-4](#)
- documentation for [A-3](#)

- international, supporting [B-1](#)
- required information [A-1](#)
- wireless IP phone information [A-1](#)

---

## V

verifying

- Cisco Unified Communications Manager settings [10-6](#)
- firmware version [8-16](#)
- network settings [10-4](#)

VLAN

- assigning separate SSIDs [2-11](#)
- auxiliary, for voice traffic [2-11](#)
- native, for data traffic [2-11](#)
- separate voice for QoS [2-11](#)
- verifying [10-8](#)

voice messaging system [7-13](#)

voice quality, resolving problems [10-7](#)

voice quality metrics [8-15, 9-11](#)

voice VLAN [2-11](#)

---

## W

warnings

- definition [3-5](#)
- for battery disposal [3-6](#)
- for battery explosion [3-6](#)
- for disposal [3-6](#)
- for explosive gas [3-5](#)
- for installation [3-5](#)
- for plug socket [3-5](#)
- for power outages [3-5](#)
- for power supply [3-6](#)
- for short circuit protection [3-6](#)
- for telephone receiver [3-6](#)
- translations [3-5](#)

Wavelink software, using [4-29, 6-1](#)

WDS, wireless domain server [2-8](#)



- web page
    - configuring phone settings [4-1](#)
  - WEP encryption, description [2-17](#)
  - WEP key
    - setting up encryption [4-16](#)
  - Wi-Fi (802.11b) [2-3](#)
  - wireless domain server (WDS) [2-8](#)
  - wireless IP phone
    - adding manually to Cisco Unified Communications Manager [3-4](#)
    - adding to Cisco Unified Communications Manager [3-2](#)
    - adding using auto-registration [3-3](#)
    - adding using auto-registration with TAPS [3-3](#)
    - adding using BAT [3-4](#)
    - battery [3-8](#)
    - configuration file [2-14](#)
    - feature overview [1-8](#)
    - figure [1-3](#)
    - keys [1-3](#)
    - phone modes, active and standby [3-16](#)
    - registering [3-2](#)
    - registering with Cisco Unified Communications Manager [3-3, 3-4](#)
    - supported networking protocols [2-9](#)
    - troubleshooting [10-1](#)
    - troubleshooting tips [10-13](#)
  - wireless IP phone, See also Cisco Unified Wireless IP Phone
  - wireless local area network, See WLAN
  - wireless network settings
    - authentication [5-9](#)
    - SSID [5-9](#)
  - WLAN
    - components [2-8](#)
    - security [2-15](#)
    - voice quality [2-11](#)
  - WLAN configuration menu [5-8](#)
  - WLSM, wireless LAN services module [2-7](#)
  - WPA
    - encryption with TKIP, description [2-18](#)
    - WPA authentication, description [2-17](#)
- 
- X**
- XMLDefault.cnf.xml configuration file [2-13](#)

