



A

Access Control List

See ACL

accessibility

accessing buttons and icons [1-7](#)

ACL

incoming

configuration settings (table) [12-2](#)

configuring [12-2](#)

deleting entries [12-3](#)

described [12-1](#)

finding entries [12-1](#)

related topics [12-3](#)

privacy

configuration settings (table) [13-2](#)

configuring [13-2](#)

deleting entries [13-3](#)

described [13-1](#)

finding entries [13-1](#)

related topics [13-3](#)

activating services

BPS [40-15](#)

application user

adding [36-2](#)

application profiles [36-7](#)

associating devices to an application user [36-7](#)

changing password [36-6](#)

configuration [36-1](#)

configuration settings (table) [36-3](#)

finding [36-1](#)

related topics [36-8](#)

AXL

configuration [18-1](#)

configuring settings [18-1](#)

B

backend gateways

configuration settings (table) [14-2](#)

configuring [14-2](#)

deleting [14-3](#)

finding [14-1](#)

related topics [14-3](#)

BPS

activating [40-15](#)

deactivating [40-16](#)

starting/stopping/restarting [40-16](#)

browsers [1-2](#)

browsing

Cisco Unified Presence Server [1-2](#)

security

hypertext transfer protocol [1-3](#)

Bulk Provisioning Service

See BPS

C

Cisco MeetingPlace

profile

configuration settings (table) [28-3](#)

configuring [28-2](#)

deleting [28-4](#)

finding [28-1](#)

overview [28-1](#)

related topics [28-4](#)

- server
 - configuration settings (table) [27-3](#)
 - configuring [27-2](#)
 - deleting [27-3](#)
 - finding [27-1](#)
 - overview [27-1](#)
 - related topics [27-4](#)
 - Cisco Unified Presence Server
 - exporting users [42-1](#)
 - server configuration [2-1](#)
 - updating users [41-1](#)
 - users [41-1](#)
 - Cisco Unified Presence Server Administration
 - browsing into [1-2](#)
 - introduction [1-1](#)
 - log off [1-3](#)
 - logon [1-2](#)
 - more information [1-7](#)
 - navigating [1-6](#)
 - navigation (figure) [1-6](#)
 - overview [1-1](#)
 - related topics [1-8](#)
 - Cisco Unified Presence Server Administration Guide
 - audience [xiii](#)
 - conventions [xiv](#)
 - organization [xiv](#)
 - purpose [xiii](#)
 - related documentation [xiv](#)
 - Cisco Unity
 - configuring a host [25-2](#)
 - Cisco Unity Profile
 - configuration settings (table) [26-3](#)
 - configuring [26-2](#)
 - deleting [26-4](#)
 - finding [26-1](#)
 - overview [26-1](#)
 - related topics [26-4](#)
 - Cisco Unity Server
 - configuration settings (table) [25-3](#)
 - deleting [25-3](#)
 - finding [25-1](#)
 - overview [25-1](#)
 - related topics [25-4](#)
 - conventions [xiv](#)
 - CTI
 - gateway profile
 - configuration settings (table) [30-3](#)
 - configuring [30-2](#)
 - deleting [30-4](#)
 - finding [30-1](#)
 - overview [30-1](#)
 - related topics [30-4](#)
 - gateway server
 - configuration settings (table) [29-3](#)
 - configuring [29-2](#)
 - deleting [29-3](#)
 - finding [29-1](#)
 - overview [29-1](#)
 - related topics [29-4](#)
-
- ## D
- deleting files [39-13](#)
 - document
 - audience [xiii](#)
 - conventions [xiv](#)
 - organization [xiv](#)
 - purpose [xiii](#)
 - documentation
 - related [xiv](#)
 - Domain Name System (DNS) [2-1](#)
 - downloading files
 - overview [39-11](#)
 - procedure [39-12](#)
 - related topics [39-14](#)

E

exporting user records [42-1](#)

F

files

deleting [39-13](#)

downloading [39-12](#)

finding [39-11](#)

related topics [39-14](#)

uploading [39-13](#)

finding jobs [40-17](#)

H

HTTPS

and IE

using with Cisco Unified Presence Server
Administration [1-4](#)

and Netscape

using with Cisco Unified Presence Server
Administration [1-5](#)

HTTP over secure sockets layer [1-3](#)

I

IE and HTTPS

using with Cisco Unified Presence Server
Administration [1-4](#)

Internet Explorer and HTTPS

using with Cisco Unified Presence Server
Administration [1-4](#)

introduction to Cisco Unified Presence Server
Administration [1-1](#)

IP address [2-1](#)

IP Phone Messenger

See IPPM

IPPM

logging out end user [20-2](#)

related topics [20-3](#), [35-3](#)

response messages

configuring [22-2](#)

deleting [22-2](#)

finding [22-1](#)

overview [22-1](#)

related topics [22-3](#)

settings

configuration settings (table) [21-1](#)

configuring [21-1](#)

overview [21-1](#)

status

finding [20-1](#)

overview [20-1](#)

J

jobs

activating BPS [40-15](#)

deactivating BPS [40-16](#)

finding [40-17](#)

scheduling [40-15](#), [40-18](#)

starting/stopping/restarting BPS [40-16](#)

viewing log files [40-20](#)

L

LDAP

profile

configuration settings (table) [32-3](#)

configuring [32-2](#)

deleting [32-4](#)

finding [32-1](#)

overview [32-1](#)

related topics [32-5](#)

server

configuration settings (table) [31-3](#)

configuring [31-2](#)

- deleting [31-3](#)
- finding [31-1](#)
- overview [31-1](#)
- related topics [31-3](#)

licensing

- license file
 - contents [4-2](#)
 - obtaining license file [4-1](#)
 - related topics [4-4](#)
 - sample license files [4-2](#)
 - uploading [4-1, 4-3](#)
- license unit report
 - generating [5-1](#)
 - overview [5-1](#)
 - related topics [5-1](#)

log files

- viewing job log files [40-20](#)

log off

- Cisco Unified Presence Server Administration [1-3](#)

login

- Cisco Unified Presence Server Administration [1-2](#)

M

method/event routes

- configuration settings (table) [10-3](#)
- configuring [10-2](#)
- deleting [10-3](#)
- finding [10-1](#)
- overview [10-1](#)
- related topics [10-4](#)

N

navigating

- Cisco Unified Presence Server Administration [1-6](#)

Netscape and HTTPS

- using with Cisco Unified Presence Server Administration [1-5](#)

O

- organization [xiv](#)

- overview of Cisco Unified Presence Server Administration [1-1](#)

P

parameters

- configuration window (figure) [3-2](#)
- configuring [3-1](#)
- configuring for a service [3-1](#)
- displaying for a service [3-3](#)
- related topics [3-4](#)

plugins

- configuring [19-1](#)
- installing [19-1](#)
- updating the URL [19-2](#)
- URL configuration settings (table) [19-3](#)

preface [xiii](#)

presence engine

- backend gateways [14-1](#)
- transport listeners
 - configuration settings (table) [15-3](#)
 - configuring [15-2](#)
 - deleting [15-3](#)
 - finding [15-1](#)
 - overview [15-1](#)
 - related topics [15-4](#)

proxy profile

- configuration settings (table) [33-3](#)
- configuring [33-2](#)
- deleting [33-4](#)
- finding [33-1](#)
- overview [33-1](#)
- related topics [33-4](#)

proxy server

- configuration settings (table) [8-1](#)
- related topics [8-2](#)

settings [8-1](#)

transport listeners

configuration settings (table) [11-3](#)

configuring [11-2](#)

deleting [11-3](#)

described [11-1](#)

overview [11-1](#)

related topics [11-4](#)

proxy services

restarting [8-2](#)

R

related documentation [xiv](#)

roles

assigning to user groups [38-6](#)

configuration settings (table) [37-4](#)

configuring [37-3](#)

deleting [37-4](#)

finding [37-2](#)

overview [37-1](#)

related topics [37-5](#)

viewing user groups and permissions [38-7](#)

S

scheduling jobs [40-15, 40-18](#)

servers

configuration settings (table) [2-4](#)

configuring [2-1, 2-2](#)

deleting [2-3](#)

finding [2-1](#)

related topics [2-5](#)

service parameters

configuration window (figure) [3-2](#)

configuring [3-1](#)

configuring for a service [3-1](#)

displaying for a service [3-3](#)

related topics [3-4](#)

static routes

configuration settings (table) [9-3](#)

configuring [9-2](#)

deleting [9-4](#)

finding [9-1](#)

overview [9-1](#)

related topics [9-4](#)

status

sync [6-3](#)

parameters (table) [6-3](#)

viewing [6-3](#)

sync status [6-3](#)

parameters (table) [6-3](#)

viewing [6-3](#)

T

TLS

contexts

configuration overview [16-1](#)

configuration settings (table) [16-3](#)

configuring [16-2](#)

deleting [16-3](#)

finding [16-1](#)

related topics [16-4](#)

peer subjects

configuration settings (table) [17-3](#)

configuring [17-2](#)

deleting [17-3](#)

finding [17-1](#)

overview [17-1](#)

related topics [17-3](#)

transport layer security

See TLS

U

Unified Personal Communicator

configuration settings (table) [23-1](#)configuring a user [24-2](#)deleting a user [24-3](#)finding a user [24-1](#)LDAP attribute mapping (table) [23-2](#)related topics [24-3](#)

settings

 configuring [23-1](#) overview [23-1](#)user configuration settings (table) [24-2](#)user settings [24-1](#)

uploading files

overview [39-11](#)procedure [39-13](#)related topics [39-14](#)

user

application

 adding [36-2](#) application profiles [36-7](#) associating devices to an application user [36-7](#) changing password [36-6](#) configuration [36-1](#) configuration settings (table) [36-3](#) finding [36-1](#) related topics [36-8](#)

user groups

adding users [38-4](#)assigning roles [38-6](#)configuring [38-3](#)deleting [38-3](#)deleting users [38-6](#)finding [38-1](#)overview [38-1](#)related topics [38-8](#)viewing user's roles, user groups, and permissions [38-7](#)

users

exporting [42-1](#)exporting records [42-1](#)related topics [41-2, 42-2](#)updating [41-1](#)user settings [24-1](#)

Wweb browsers [1-2](#)