



A

- access lists **37**
- activity timer **41**
- Administration menu **67**
- administration, differences **29**
- administrator
 - Cisco CallManager **29, 39**
 - Cisco Unity Express **29, 39**
 - password **37**
 - user ID **37**
 - web **29, 39**
- Administrator field **50**
- alphabetizing data **72**
- alternate welcome greeting **37**
- Authentication screen **42**
- auto attendant
 - GMS **38**
 - recording a greeting **38**
 - telephone number **40**
- Auto Attendant Access Number field **52**
- Auto Attendant Operator Extension field **52**
- Auto Attendants option **67**
- auto-provisioning **31**

B

- backup
 - manual **26**
 - restrictions **31**
 - selective **31**
 - troubleshooting **77**
- Backup History report option **69**

- Backup/Restore option **67**
- Blank Password field **51**
- Blank PIN field **51**
- broadcast messaging restrictions **30**
- bulk provisioning **26**
- buttons, initialization wizard screens **41**

C

- Call Handling option **67**
- Call Handling screen **52**
- call processing **37**
- CallManager option **66**
- centralized message storage **31**
- Cisco CallManager
 - CTI ports **36**
 - database **28**
 - description **28**
 - JTAPI user **36**
 - route point **36**
 - router clock **69**
 - software version **30**
- Cisco IOS release **30**
- Cisco Unity Express
 - administrator **39**
 - database **28**
 - description **28**
 - icons **70**
- Cisco Unity Express screen **42**
- CiscoWorks configmaker **31**
- CLI **27**
- CNS/SNAP **31**
- command-line interface **27**

Commit screen **53**
 Configure menu **65, 66**
 Confirm new password field **59**
 CTI ports **36**
 CTI Ports option **67**
 Current password field **59**
 Current Settings screen **43**

D

data
 search **71**
 sort **72**
 database **28**
 Cisco CallManager **28**
 Cisco Unity Express **28**
 date and time
 restrictions **30**
 troubleshooting **78**
 default
 mailbox size **27, 40**
 message length **40**
 message storage time **40**
 default mailbox size **27**
 Defaults menu **68**
 Defaults screen **50**
 deployment
 Cisco CallManager **28**
 Cisco Unity Express **28**
 Device option **36**
 differences
 administration **29**
 administrators **29**
 Cisco Unity Express and Cisco CallManager **28**
 passwords **29**
 user IDs **29**
 users **29**
 distribution lists restrictions **30**
 DNS server **37, 67**

documentation, additional sources **32**
 domain name **67**
 Domain Name Settings option **67**

E

editor for scripts **38**

F

factory-set system limits **27**
 Fast Ethernet ports **31**
 field
 Administrator **50**
 Auto Attendant Access Number **52**
 Auto Attendant Operator Extension **52**
 Blank Password **51**
 Blank PIN **51**
 Confirm new password **59**
 Current password **59**
 JTAPI Password **45**
 JTAPI User Name **45**
 Mailbox **50**
 Mailbox Size **51**
 Maximum Caller Message Size **51**
 Message Expiry Time **52**
 New password **59**
 Password **42**
 Password & PIN options **51**
 Primary **50**
 Primary CallManager **45**
 Secondary CallManager **45**
 Tertiary CallManager **45**
 User Name **42**
 Voice Mail Number **52**
 Voice Mail Operator Extension **52**
 Web Password **45**
 Web User Name **45**

find data **71**
 Find icon **71**
 first time log in **57**
 FTP server **26, 67**

G

G.711 U-law **38**
 GMS, recording a greeting **38**
 graphical user interface **27**
 greetings
 recording alternate **37**
 restrictions **30**
 Groups option **66**
 GUI **27**
 troubleshooting **79**
 web browser URL **42**
 GUI URL **60**

H

H.323 interface **30**
 hard disk, replacement restrictions **31**
 hardware platforms **29**
 Help menu **69**
 Home screen **65**
 host name **67**

I

icon
 Find **71**
 list of **70**
 Sort **72**
 Import CCM Users screen **46, 48**
 initialization wizard
 required data **38**
 screen buttons **41**

Initialization Wizard Status screen **55**
 installation, troubleshooting **78**
 interface
 H.323 **30**
 JTAPI **30**
 MGCP **30**
 Internet Explorer
 patches **30, 35**
 software version **30**
 version **28, 35**
 IP
 addressing, troubleshooting **77**
 network access **26**
 IP address of module **39**
 IP address, Cisco Unity Express module **37**

J

JTAPI
 interface **30**
 user **36**
 JTAPI Password field **45**
 JTAPI traffic, prioritizing **37**
 JTAPI User Name field **45**

L

language, restrictions **30**
 license, SKUs **26**
 Linux
 software on network module card **26**
 system access restrictions **31**
 log files, system **26**
 log in, first time **57**
 log out, voice mail **62**
 Logged Out screen **59**

M

Mailbox defaults option **68**

Mailbox field **50**

mailbox size

- default **27**

Mailbox Size field **51**

mailbox size, default **27**

mailboxes

- default size **40**
- number of **27**

Mailboxes option **67**

manual backup **26**

manual restore **26**

Maximum Caller Message Size field **51**

menu

- Administration **67**
- Configure **65, 66**
- Defaults **68**
- Help **69**
- Reports **68**
- Voice Mail **66**

message

- default length **40**
- default storage time **40**
- storage restrictions **31**

Message Expiry Time field **52**

MGCP interface **30**

missing data

- troubleshooting **78**

module

- IP address **39**

module IP address **37**

modules restrictions **30**

MWI lights, troubleshooting **78**

My Profile option **66**

N

network module

- description **28**
- restrictions **31**
- spare **26**

network module card

- processor **26**
- software **26**

Network Time & Time Zone Settings option **68**

Network Time Protocol report option **69**

networking restrictions **30**

New password field **59**

NTP server **37, 68, 69**

number of

- concurrent administrators **30**
- concurrent users **30**
- mailboxes **27**
- ports **27**

O

OIR, restrictions **31**

online help **74**

online insertion and replacement, restrictions **31**

operator extension **40**

option

- Auto Attendants **67**
- Backup History report **69**
- Backup/Restore **67**
- Call Handling **67**
- CallManager **66**
- CTI Ports **67**
- Device **36**
- Domain Name Settings **67**
- Groups **66**
- Mailbox defaults **68**
- Mailboxes **67**
- My Profile **66**

Network Time & Time Zone Settings **68**
 Network Time Protocol report **69**
 Prompts **67**
 Refresh Message Waiting Indicators **67**
 Restore History report **69**
 Save Configuration **68**
 Scripts **67**
 System report **69**
 User **36**
 User defaults **68**
 Users **66**
 Voice Mail defaults **68**
 Voice Mail report **69**

P

password
 characters allowed **29**
 policy for new users **39, 40**
 random **40, 56**
 Password & PIN options field **51**
 Password Expired screen **57, 58**
 Password field **42**
 PIN
 policy for new users **39, 40**
 random **40**
 platforms
 hardware **29**
 software **29**
 policy
 passwords **40**
 PINs **40**
 security **40**
 ports
 Fast Ethernet **31**
 number of **27**
 restrictions **31**
 Primary CallManager field **45**
 Primary field **50**

Prompts option **67**
 provisioning, bulk **26**

R

random
 password **40, 56**
 PIN **40**
 user ID **56**
 recording a greeting
 auto attendant **38**
 GMS **38**
 Refresh Message Waiting Indicators option **67**
 report
 Backup History **69**
 Network Time Protocol **69**
 Restore History **69**
 System **69**
 troubleshooting feature **26**
 Voice Mail **69**
 Reports menu **68**
 restore
 manual **26**
 restrictions **31**
 selective **31**
 troubleshooting **77**
 Restore History report option **69**
 restrictions
 administrators **30**
 auto-provisioning with CNS/SNAP **31**
 backups **31**
 broadcast messaging **30**
 centralized message storage **31**
 CiscoWorks configmaker **31**
 date and time **30**
 distribution lists **30**
 greetings **30**
 language **30**
 Linux system access **31**

managing with SNMP **31**
 modules **30**
 OIR **31**
 replacing hard disk **31**
 restores **31**
 selective backup **31**
 selective restore **31**
 users **30**
 voice mail **30**
 route point **36**

S

Save Configuration option **68**
 screen
 Authentication **42**
 Call Handling **52**
 Cisco Unity Express **42**
 Commit **53**
 Current Settings **43**
 Defaults **50**
 Home **65**
 Import CCM Users **46, 48**
 Initialization Wizard Status **55**
 Logged Out **59**
 Password Expired **57, 58**
 Search Results **47**
 scripts
 creating **38**
 editor software **38**
 file size **38**
 Scripts option **67**
 search for data **71**
 Search Results screen **47**
 Secondary CallManager field **45**
 security policy **40**
 selective backup restrictions **31**
 selective restore restrictions **31**
 servers

DNS **37**
 NTP **37**
 SKUs **27**
 SNMP **31**
 software
 Cisco IOS release **30**
 platforms **29**
 Sort icon **72**
 sorting data **72**
 spare network modules **26**
 storage hours **27**
 system access using IP network **26**
 system capacities **27**
 system CPU **69**
 system hardware **69**
 system limits, factory set **27**
 system log files **26**
 System report option **69**
 system reports **26**

T

Table
 Table 1 Cisco Unity Express GUI Administrator Guide Conventions **iv**
 Table 2 System Capacities on the NM **27**
 Table 3 System Capacities for the AIM **27**
 telephone number
 auto attendant **40**
 operator **40**
 voice mail **40**
 Tertiary CallManager field **45**
 timer, system **41**
 total storage hours **27**
 troubleshooting
 backup **77**
 date and time **78**
 GUI **79**
 installation **78**

- IP addressing **77**
- missing data **78**
- MWI lights **78**
- restore **77**

TUI, recording a greeting **38**

U

- URL for GUI access **60**
- URL, GUI web browser **42**
- User defaults option **68**
- user IDs
 - characters allowed **29**
 - random **56**
- User Name field **42**
- User option **36**
- Users option **66**

V

- voice mail
 - log out **62**
 - telephone number **40**
- Voice Mail defaults option **68**
- Voice Mail menu **66**
- Voice Mail Number field **52**
- Voice Mail Operator Extension field **52**
- Voice Mail report option **69**

W

- wav file **38**
- web
 - administrator **29, 39**
 - browser software **28, 35**
 - browser URL **42**
- Web Password field **45**
- Web User Name field **45**

