



A

- activity timer **18**
- administration
 - CLI **4**
 - GUI **4**
- Administration menu **39**
- administrator
 - Cisco Unity Express **16**
- Administrator field **23**
- administrator, Cisco CME **6**
- administrator, Cisco Unity Express **6**
- administrator, web **6**
- alphabetizing data **45**
- alternate welcome greeting **14**
- Authentication screen **19**
- auto attendant
 - GMS **14**
 - recording a greeting **14**
 - telephone number **17**
- Auto Attendant Access Number field **25**
- Auto Attendant Operator Extension field **25**
- Auto Attendant option **39**
- auto-provisioning **8**

B

- backup
 - manual **2**
 - restrictions **7**
 - troubleshooting **50**
- Backup History report option **41**
- Backup/Restore option **39**

- Blank Password field **24**
- Blank PIN field **24**
- broadcast messaging restrictions **7**
- bulk provisioning **2**
- buttons
 - initialization wizard screens **18**

C

- call agent **5**
- Call Handling option **39**
- Call Handling screen **25**
- Call History report option **41**
- centralized message storage **8**
- Cisco CME
 - description **5**
 - Flash memory files **12**
 - IP path command **12**
 - router clock **41**
 - web administrator **13**
- Cisco CME router **5**
- Cisco Unity Express
 - administrator **16**
 - description **5**
 - icons **43**
- Cisco Unity Express screen **19**
- CiscoWorks configmaker **8**
- CLI
 - administration **4**
 - CLI administration **4**
 - CME Password field **21**
 - CNS/SNAP **8**
 - command

- IP path 12
- Commit screen 26
- Configure menu 37, 38
- configuring
 - dial peer 13
 - ephone-dn 13
- Confirm new password field 31
- creating users and telephones 13
- Current password field 31
- Current Settings screen 20

D

- data
 - sort 45
- data search 44
- databases
 - synchronization 13
- date and time
 - troubleshooting 50
- date and time restrictions 7
- daylight savings time 50
- default
 - mailbox size 17
 - message length 17
 - message storage time 17
- default mailbox size 3, 4
- Defaults menu 40
- Defaults screen 24
- deployment
 - Cisco CME 5
 - Cisco Unity Express 5
- dial peer 13
- differences
 - Cisco Unity Express and Cisco CME 5
 - passwords 6
 - user IDs 6
- differences in voice applications 6
- distribution lists restrictions 7

- DNS server 40
- documentation
 - additional sources 9
- domain name 40
- Domain Name Settings option 40

E

- ephone 13
- ephone-dn 13
- extensions
 - MWI 15
- Extensions option 38

F

- factory-set system limits 3
- Fast Ethernet ports 7
- field
 - Administrator 23
 - Auto Attendant Access Number 25
 - Auto Attendant Operator Extension 25
 - Blank Password 24
 - Blank PIN 24
 - CME Password 21
 - Confirm new password 31
 - Current password 31
 - Greeting Management Number 25
 - Hostname 21
 - Mailbox 23
 - Mailbox Size 24
 - Maximum Caller Message Size 24
 - Message Expiry Time 25
 - MWI off Number 26
 - MWI on Number 25
 - New password 31
 - Password 19
 - Password & PIN options 24

- Primary Extension 23
- User Name 19, 21
- Voice Mail Number 25
- Voice Mail Operator Extension 25

find data 44

Find icon 44

first time log in 30

FTP server 2, 39

G

- G.711 ulaw 13
- G711 ulaw 14
- GMS
 - recording a greeting 14
- graceful shutdown 2, 12
- greeting
 - recording alternate 14
- Greeting Management Number field 25
- greetings restrictions 7
- Groups option 38
- GUI
 - troubleshooting 51
 - web browser URL 19
- GUI administration 4
- GUI URL 30, 32

H

- hard disk
 - replacing restrictions 7
- hardware platforms 6
- Help menu 41
- Home screen 37
- hostname 40
- Hostname field 21

I

- icon
 - Find 44
 - Sort 45
- icons 43
- Import CME Users screen 21
- initialization wizard
 - required data 15
 - screen buttons 18
- Initialization Wizard Status screen 28
- installation, troubleshooting 50
- integration
 - Cisco Unity Express and Cisco CME 5
- interaction
 - Cisco Unity Express and Cisco CME 5
- Internet Explorer
 - version 11
- Internet Explorer patches 11
- IP
 - addressing, troubleshooting 49
- IP address of module 16
- IP address, Cisco Unity Express module 14
- IP network access 2
- IP path for Cisco CME 12

L

- language restrictions 7
- license
 - SKUs 2
- Linux software 2
- Linux system access 8
- log files
 - system 2
- log in, first time 30
- log out, voice mail 34
- Logged Out screen 31

M

Mailbox defaults option **40**

Mailbox field **23**

mailbox size

- default **3, 4, 17**

Mailbox Size field **24**

mailboxes

- number of **3, 4**

Mailboxes option **39**

manual backup **2**

manual restore **2**

Maximum Caller Message Size field **24**

menu

- Administration **39**
- Configure **37, 38**
- Defaults **40**
- Help **41**
- Reports **41**
- Voice Mail **38**

Message Expiry Time field **25**

message length

- default **17**

message storage

- restrictions **8**

message storage time

- default **17**

Message Waiting Indicators option **39**

missing data

- troubleshooting **51**

module

- IP address **16**

module IP address **14**

modules restrictions **7**

MWI

- on and off extensions **17**

MWI extensions **14, 15**

MWI lights

- troubleshooting **51**

MWI off Number field **26**

MWI on Number field **25**

My Profile option **38**

N

network module

- restrictions **7**
- spare **2**

network module card

- processor **2**
- software **2**

Network Time & Time Zone Settings option **40**

Network Time Protocol report option **41**

networking restrictions **7**

New password field **31**

NTP server **40, 41**

number of

- mailboxes **3, 4**
- ports **3, 4**

number of concurrent administrators **7**

number of concurrent users **7**

O
OIR

- restrictions **7**

online help **47**

online insertion and replacement

- restrictions **7**

operator

- extension **17**

option

- Auto Attendant **39**
- Backup History report **41**
- Backup/Restore **39**
- Call Handling **39**
- Call History report **41**

- Domain Name Settings 40
- Extensions 38
- Groups 38
- Mailbox defaults 40
- Mailboxes 39
- Message Waiting Indicators 39
- My Profile 38
- Network Time & Time Zone Settings 40
- Network Time Protocol report 41
- Phones 38
- Prompts 39
- Restore History report 41
- Save Configuration 40
- Scripts 39
- Synchronize Information 39
- System Parameters 38
- System report 41
- User defaults 40
- Users 38
- Voice Mail defaults 40
- Voice Mail report 41

P

- password
 - policy 16
 - random 16, 29
- Password & PIN options field 24
- Password Expired screen 30, 31
- Password field 19
- passwords 15
 - characters allowed 6
- Phones option 38
- PIN
 - policy 16
 - random 16
- PINs 15
- platforms
 - hardware 6

- software 6
- policy
 - security 16
- ports
 - Fast Ethernet 7
 - number of 3, 4
 - restrictions 7
- Primary Extension field 23
- Prompts option 39
- provisioning
 - bulk 2

R

- random
 - password 16, 29
 - PIN 16
 - user ID 29
- recording
 - GMS 14
- recording a greeting
 - auto attendant 14
- report
 - Backup History 41
 - Call History 41
 - Network Time Protocol 41
 - Restore History 41
 - System 41
 - Voice Mail 41
- reports
 - system 2
- Reports menu 41
- restore
 - manual 2
 - restrictions 7
 - selective 8
 - troubleshooting 50
- Restore History report option 41
- restrictions

- administrators 7
- auto-provisioning with CNS/SNAP 8
- backups 7
- broadcast messaging 7
- centralized message storage 8
- CiscoWorks configmaker 8
- date and time 7
- distribution lists 7
- greetings 7
- language 7
- Linux system access 8
- managing with SNMP 8
- modules 7
- OIR 7
- replacing hard disk 7
- restores 7
- selective backup 8
- selective restore 8
- users 7
- voice mail 7
- router
 - call agent 5
- router, Cisco CME 5

S

- Save Configuration option 40
- screen
 - Authentication 19
 - Call Handling 25
 - Cisco Unity Express 19
 - Commit 26
 - Current Settings 20
 - Defaults 24
 - Home 37
 - Import CME Users 21
 - Initialization Wizard Status 28
 - Logged Out 31
 - Password Expired 30, 31

- Scripts option 39
- search for data 44
- selective backup restrictions 8
- selective restore restrictions
 - backup
 - selective 8
 - setting daylight savings time 50
- SIP dial peer 13
- SKUs 3, 4
- SNMP 8
- software platforms 6
- Sort icon 45
- sorting data 45
- spare network modules 2
- storage hours 3, 4
- synchronization of databases 13
- Synchronize Information option 39
- system access using IP network 2
- system capacities 3, 4
- system CPU 41
- system hardware 41
- system limits
 - factory set 3
- system log files 2
- System Parameters option 38
- System report option 41
- system reports 2

T

- telephone number
 - auto attendant 17
 - operator 17
 - voice mail 17
- timer
 - system 18
- total storage hours 3, 4
- troubleshooting
 - backup 50
 - date and time 50

- GUI 51
 - installation 50
 - IP addressing 49
 - missing data 51
 - MWI lights 51
 - restore 50
- TUI
 - recording a greeting 14
- web administrator 6
- web administrator 13
- web browser 11
- web browser URL 19

U

- uninterruptible power supply 2, 12
- UPS 2, 12
- URL
 - GUI web browser 19
- URL for GUI access 30, 32
- User defaults option 40
- user ID
 - random 29
- user IDs
 - characters allowed 6
- User Name field 19, 21
- Users option 38

V

- voice mail
 - log out 34
 - telephone number 17
- Voice Mail defaults option 40
- Voice Mail menu 38
- Voice Mail Number field 25
- Voice Mail Operator Extension field 25
- Voice Mail report option 41

W

- wav file 14

