



Numerics

- 1130AG series indicators [22-6](#)
- 1240AG access point support [1-8](#)
- 1240AG series indicators [22-9](#)
- 1300 outdoor access point/bridge indicators [22-10](#)
- 350 series bridge interoperability [8-3](#)
- 802.11d [6-18](#)
- 802.11e [15-2](#)
- 802.11g [6-28](#)
- 802.11i [6-22](#)
- 802.1H [6-23](#)
- 802.1x authentication [9-2](#)
- 802.1X Supplicant
 - applying credentials to interface or SSID [2-28](#)
 - configuring [2-27](#)
 - creating a credentials profile [2-27](#)
 - creating and applying EAP method profiles [2-30](#)

A

- AAA authentication/authorization cache and profile [1-9](#)
- abbreviating commands [4-3](#)
- Access point link role flexibility [1-8](#)
- access point security settings, matching client devices [11-19](#)
- accounting
 - with RADIUS [13-13](#)
 - with TACACS+ [13-22, 13-27](#)
- accounting command [7-5](#)
- Address Resolution Protocol (ARP) [6-23](#)
- AES-CCMP [1-8, 10-2](#)
- Aironet Client Utility (ACU) [22-15](#)

- Aironet extensions [6-10, 6-22](#)
- antenna
 - selection [6-20](#)
- antenna command [6-21](#)
- Apply button [3-4](#)
- ARP
 - caching [5-26](#)
 - description [1-7](#)
- associations, limiting by MAC address [16-6](#)
- attributes, RADIUS
 - sent by the access point [13-19](#)
 - vendor-proprietary [13-16](#)
 - vendor-specific [13-15](#)
- authentication [4-9](#)
 - local mode with AAA [5-19](#)
- RADIUS
 - key [13-5](#)
 - login [5-10, 13-7](#)
- SSID [7-2](#)
- TACACS+
 - defined [13-22](#)
 - key [13-24](#)
 - login [5-15, 13-25](#)
- authentication client command [7-5](#)
- authentication server
 - configuring access point as local server [9-2](#)
 - described [1-7](#)
 - EAP [11-4, 13-3](#)
- authentication types
 - Network-EAP [11-4](#)
 - open [11-2](#)
 - shared key [11-3](#)
- authenticator [9-1](#)

authorization

- with RADIUS [5-14, 13-11](#)
- with TACACS+ [5-17, 13-22, 13-26](#)

B
Back button [3-4](#)backoff [6-28](#)backup authenticator, local [9-1](#)bandwidth [6-11](#)

banners

- configuring
 - login [5-37](#)
 - message-of-the-day login [5-35](#)
- default configuration [5-35](#)
- when displayed [5-35](#)

basic settings

- checking [22-15](#)

beacon dtim-period command [6-26](#)beacon period command [6-26](#)bit-flip attack [6-22](#)blocking communication between clients [6-24](#)BR350 interoperability [8-3](#)bridge-group command [6-25](#)bridge virtual interface (BVI) [2-26](#)broadcast-key command [11-15](#)broadcast key rotation [10-1, 10-3](#)BSSIDs [7-7](#)

buttons

- management pages [3-4](#)
- web-browser [3-2](#)

C
caching MAC authentications [11-15](#)call admission control [1-4](#)

Called-Station-ID

- See CSID

Cancel button [3-4](#)capture frames [12-29](#)carrier busy test [6-28](#)Catalyst 6500 Series [12-1](#)CCKM [11-6](#)

- authenticated clients [11-6](#)
- described [1-7](#)

CCK modulation [6-9](#)

CDP

- disabling for routing device [17-4](#)
- enabling and disabling
 - on an interface [17-4](#)
- monitoring [17-4](#)

cdp enable command [17-4](#)cdp run command [17-3](#)

Cisco Centralized Key Management (CCKM)

- See CCKM

Cisco Discovery Protocol (CDP) [17-1](#)Cisco Key Integrity Protocol (CKIP) [6-22](#)Cisco TAC [22-1](#)CiscoWorks 2000 [18-4](#)clear command [4-2](#)CLI [4-1](#)

- abbreviating commands [4-3](#)
- command modes [4-2](#)
- editing features
 - enabling and disabling [4-6](#)
 - keystroke editing [4-6](#)
 - wrapped lines [4-7](#)

error messages [4-4](#)filtering command output [4-8](#)getting help [4-3](#)history [4-4](#)

- changing the buffer size [4-5](#)

described [4-4](#)disabling [4-5](#)recalling commands [4-5](#)no and default forms of commands [4-4](#)Secure Shell (SSH) [4-9](#)

- Telnet 4-9
- terminal emulator settings 2-5, 2-6, 2-7
- client ARP caching 5-26
- client communication, blocking 6-24
- client power level, limiting 6-10
- command-line interface
 - See CLI
- command modes 4-2
- commands
 - abbreviating 4-3
 - accounting 7-5
 - antenna 6-21
 - authentication client 7-5
 - beacon dtim-period 6-26
 - beacon period 6-26
 - bridge-group 6-25
 - broadcast-key 11-15
 - cdp enable 17-4
 - cdp run 17-3
 - clear 4-2
 - countermeasure tkip hold-time 11-17
 - debug 21-2
 - default form 4-4
 - del 22-18
 - dot11 aaa mac-authen filter-cache 11-15
 - dot11 extension aironet 6-22
 - dot11 holdoff-time 11-16
 - dot11 interface-number carrier busy 6-28
 - dot1x client-timeout 11-16
 - dot1x reauth-period 11-17
 - edit 4-6
 - encapsulation dot1q 14-6
 - encryption 10-4
 - fragment-threshold 6-27
 - guest-mode 7-5
 - help 4-3
 - infrastructure-client 6-24
 - infrastructure-ssid 7-5
 - interface dot11radio 1-9, 6-2
 - ip domain-name 5-34
 - ip redirect 7-12
 - no and default 4-4
 - no shutdown 4-4
 - packet retries 6-27
 - payload-encapsulation 6-23
 - permit tcp-port 7-12
 - power client 6-10
 - power local 6-9
 - recall 4-5
 - rts retries 6-26
 - rts threshold 6-26
 - set 22-22
 - set BOOT 22-22
 - setting privilege levels 5-8
 - show 4-2
 - show dot11 associations 7-6
 - show ip interface 2-4
 - slot-time-short 6-28
 - sort 4-8
 - speed 6-7
 - ssid 7-4, 11-10, 14-6
 - switchport protected 6-25
 - terminal history 4-5
 - terminal width 4-8
 - tftp_init 22-21
 - vlan 7-5, 14-6
 - world-mode 6-19
 - wpa-psk 11-14
- commands station role 6-3
- community strings
 - configuring 18-6
 - overview 18-4
- Complementary Code Keying (CCK)
 - See CCK
- configuration files
 - creating using a text editor 20-10
 - deleting a stored configuration 20-18
 - downloading

- preparing [20-10, 20-13, 20-16](#)
- reasons for [20-8](#)
- using FTP [20-13](#)
- using RCP [20-16](#)
- using TFTP [20-11](#)
- guidelines for creating and using [20-9](#)
- invalid combinations when copying [20-5](#)
- system contact and location information [18-10](#)
- types and location [20-9](#)
- uploading
 - preparing [20-10, 20-13, 20-16](#)
 - reasons for [20-8](#)
 - using FTP [20-14](#)
 - using RCP [20-17](#)
 - using TFTP [20-11](#)
- connections, secure remote [5-25](#)
- countermeasure tkip hold-time command [11-17](#)
- crypto software image [5-25](#)
- CSID format, selecting [13-14](#)

D

- Data Beacon Rate [6-26](#)
- data rate setting [6-5](#)
- data retries [6-27](#)
- data volume [2-12](#)
- daylight saving time [5-30](#)
- debug command [21-2](#)
- default commands [4-4](#)
- default configuration
 - banners [5-35](#)
 - DNS [5-33](#)
 - password and privilege level [5-4](#)
 - RADIUS [5-10, 13-4](#)
 - resetting [22-16](#)
 - SNMP [18-5](#)
 - system message logging [21-3](#)
 - system name and prompt [5-32](#)
 - TACACS+ [5-15, 13-24](#)

- default gateway [2-12](#)
- default username [2-3](#)
- del command [22-18](#)
- delivery traffic indication message (DTIM) [6-26](#)
- DFS [1-5, 6-15](#)
- DHCP server
 - configuring access point as [5-22](#)
 - receiving IP settings from [2-11](#)
- directories
 - changing [20-4](#)
 - creating and removing [20-4](#)
 - displaying the working [20-4](#)
- disable web-based management [3-14](#)
- diversity [6-20](#)
- DNS
 - default configuration [5-33](#)
 - displaying the configuration [5-35](#)
 - overview [5-33](#)
 - setting up [5-34](#)
- domain names
 - DNS [5-33](#)
- Domain Name System
 - See DNS
- dot11 aaa mac-authen filter-cache command [11-15](#)
- dot11 extension aironet command [6-22](#)
- dot11 holdoff-time commands [11-16](#)
- dot11 interface-number carrier busy command [6-28](#)
- dot1x client-timeout command [11-16](#)
- dot1x reauth-period command [11-17](#)
- downloading
 - configuration files
 - preparing [20-10, 20-13, 20-16](#)
 - reasons for [20-8](#)
 - using FTP [20-13](#)
 - using RCP [20-16](#)
 - using TFTP [20-11](#)
 - image files
 - deleting old image [20-22](#)
 - preparing [20-20, 20-23, 20-27](#)

- reasons for [20-18](#)
 - using FTP [20-24](#)
 - using RCP [20-29](#)
 - using TFTP [20-21](#)
- DTIM [6-26](#)
- duplex, Ethernet port [5-18](#)
- Dynamic Frequency Selection [6-15](#)
-
- ## E
- EAP authentication, overview [11-4](#)
 - EAP-FAST [1-3](#), [9-1](#), [9-2](#)
 - EAP-FAST authentication [11-20](#)
 - EAP-MD5 authentication
 - setting on client and access point [11-21](#)
 - EAP-SIM authentication
 - setting on client and access point [11-22](#)
 - EAP-TLS [1-3](#)
 - applying EAP method profiles to [11-17](#)
 - EAP-TLS authentication
 - setting on client and access point [11-21](#)
 - edit CLI commands [4-6](#)
 - editing features
 - enabling and disabling [4-6](#)
 - keystrokes used [4-6](#)
 - wrapped lines [4-7](#)
 - enable password [5-6](#)
 - enable secret password [5-6](#)
 - encapsulation dot1q command [14-6](#)
 - encapsulation method [6-23](#)
 - encrypted software image [5-25](#)
 - encryption command [10-4](#)
 - encryption for passwords [5-6](#)
 - error and event messages [C-1](#)
 - error messages
 - 802.11 subsystem messages [C-5](#)
 - association management messages [C-4](#)
 - CLI [4-4](#)
 - during command entry [4-4](#)
 - explained [C-2](#)
 - inter-access point protocol messages [C-17](#)
 - local authenticator messages [C-18](#)
 - setting the display destination device [21-5](#)
 - severity levels [21-7](#)
 - software auto upgrade messages [C-3](#)
 - system message format [21-2](#)
 - unzip messages [C-5](#)
 - Ethernet indicator [22-4](#)
 - Ethernet speed and duplex settings [5-18](#)
 - Ethertype filter [16-1](#)
 - event log [3-4](#)
 - event messages [C-1](#)
 - Express Security page [3-4](#), [2-14](#)
 - Express Setup page [3-4](#)
-
- ## F
- fallback role [6-3](#)
 - fast secure roaming [12-1](#)
 - files
 - copying [20-5](#)
 - deleting [20-5](#)
 - displaying the contents of [20-8](#)
 - tar
 - creating [20-6](#)
 - displaying the contents of [20-6](#)
 - extracting [20-7](#)
 - image file format [20-19](#)
 - file system
 - displaying available file systems [20-2](#)
 - displaying file information [20-3](#)
 - local file system names [20-2](#)
 - network file system names [20-5](#)
 - setting the default [20-3](#)
 - filtering
 - Ethertype filters [16-11](#)
 - IP filters [16-8](#)
 - MAC address filters [16-3](#)

- show and more command output [4-8](#)
- filter output (CLI commands) [4-8](#)
- firmware
 - upgrade [3-1](#)
 - version [3-4](#)
- Flash [20-1](#)
- Flash device, number of [20-2](#)
- forward-delay time
 - STP [8-7](#)
- fragmentation threshold [6-27](#)
- fragment-threshold command [6-27](#)
- frequencies [6-12, 6-13, 6-14](#)
- FTP
 - accessing MIB files [B-2](#)
 - configuration files
 - downloading [20-13](#)
 - overview [20-12](#)
 - preparing the server [20-13](#)
 - uploading [20-14](#)
 - image files
 - deleting old image [20-26](#)
 - downloading [20-24](#)
 - preparing the server [20-23](#)
 - uploading [20-26](#)

G

- gain [6-20](#)
- get-bulk-request operation [18-3](#)
- get-next-request operation [18-3, 18-4](#)
- get-request operation [18-3, 18-4](#)
- get-response operation [18-3](#)
- global configuration mode [4-2](#)
- gratuitous probe response [1-4](#)
- Gratuitous Probe Response (GPR)
 - enabling and disabling [6-21](#)
- group key updates [11-14](#)
- guest-mode command [7-5](#)
- guest SSID [7-2](#)

H

- help [3-13](#)
- help, for the command line [4-3](#)
- history
 - changing the buffer size [4-5](#)
 - described [4-4](#)
 - disabling [4-5](#)
 - recalling commands [4-5](#)
- history (CLI) [4-4](#)
- history table, level and number of syslog messages [21-8](#)
- Home button [3-4](#)
- HTTPS [3-5](#)
- HTTP Web Server v1.1 [1-8](#)

I

- IBNS 802.1x [1-3](#)
- IEEE 802.1X local authentication service for EAP-FAST [1-8](#)
- image, operating system [22-18](#)
- indicators [22-2](#)
- infrastructure-client command [6-24](#)
- infrastructure device [7-5](#)
- infrastructure-ssid command [7-5](#)
- inter-client communication, blocking [6-24](#)
- interface
 - CLI [4-1](#)
 - web-browser [3-1](#)
- interface configuration mode [4-2](#)
- interface dot11radio command [1-9, 6-2](#)
- interfaces [3-4](#)
- intrusion detection [12-1](#)
- invalid characters in [14-6](#)
- IP address, finding and setting [2-25](#)
- ip domain-name command [5-34](#)
- IP filters [16-8](#)
- IP-Redirect [1-8](#)
- ip redirect command [7-12](#)

IP redirection [7-11, 7-12](#)

IPSU [2-25](#)

IP subnet mask [2-12](#)

ISO designators for protocols [A-1](#)

J

jitter [15-2](#)

K

key features [1-2](#)

keystrokes (edit CLI commands) [4-6](#)

L

latency [15-2](#)

Layer 3 mobility [12-5](#)

LBS [6-17](#)

LEAP

described [1-6](#)

LEAP authentication

local authentication [9-1](#)

setting on client and access point [11-20](#)

LED indicators

Ethernet [22-4](#)

radio traffic [22-4](#)

status [22-4](#)

Light Extensible Authentication Protocol

See LEAP

limiting client associations by MAC address [16-6](#)

limiting client power level [6-10](#)

line configuration mode [4-2](#)

load balancing [6-22](#)

local authenticator, access point as [9-1](#)

Location-Based Services [6-17](#)

login authentication

with RADIUS [5-10, 13-7](#)

with TACACS+ [5-15, 13-25](#)

login banners [5-35](#)

log messages

See system message logging

low power condition [22-14](#)

M

MAC address [2-26](#)

ACLs, blocking association with [16-6](#)

filter [16-1, 16-3](#)

troubleshooting [22-15](#)

MAC authentication caching [11-15](#)

MAC-based authentication [9-1, 9-2](#)

management

CLI [4-1](#)

map,network [3-4](#)

maximum data retries [6-27](#)

Maximum RTS Retries [6-26](#)

Media Access Control (MAC) address [2-4](#)

Message Integrity Check (MIC) [1-6, 6-22, 10-1, 22-15](#)

message-of-the-day (MOTD) [5-35](#)

messages

to users through banners [5-35](#)

metrics

VoWLAN [1-5](#)

MIBs

accessing files with FTP [B-2](#)

location of files [B-2](#)

overview [18-2](#)

SNMP interaction with [18-4](#)

MIC [10-1](#)

Microsoft IAS servers [11-2](#)

Microsoft WPS IE SSIDL [1-8](#)

migration mode, WPA [11-13](#)

mobility groups [1-3](#)

mode (role) [6-3](#)

mode button [22-18](#)

disabling [5-2](#)

- enabling [5-2](#)
- modes
 - global configuration [4-2](#)
 - interface configuration [4-2](#)
 - line configuration [4-2](#)
 - privileged EXEC [4-2](#)
 - user EXEC [4-2](#)
- monitoring
 - CDP [17-4](#)
- monitor mode [12-29](#)
- move the cursor (CLI) [4-6](#)
- multicast
 - IGMP snooping-based [1-3](#)
- multicast messages [6-23](#)
- multiple basic SSIDs [7-7](#)

N

- names, VLAN [14-7](#)
- Network Admission Control (NAC) [1-9](#)
- Network-EAP [11-4](#)
- network map [3-4](#)
- no commands [4-4](#)
- non-root [2-12](#)
- no shutdown command [4-4](#)
- notification [3-4](#)

O

- OFDM [6-9](#)
- OK button [3-4](#)
- optional ARP caching [5-26](#)
- Orthogonal Frequency Division Multiplexing (OFDM)
 - See OFDM

P

- packet handling

- VoIP [1-4](#)
- packet of disconnect (PoD)
 - configuring [13-12](#)
- packet retries command [6-27](#)
- packet size (fragment) [6-27](#)
- password reset [22-16](#)
- passwords
 - default configuration [5-4](#)
 - encrypting [5-6](#)
 - overview [5-3](#)
 - setting
 - enable [5-4](#)
 - enable secret [5-6](#)
 - with usernames [5-7](#)
- payload-encapsulation command [6-23](#)
- PEAP authentication
 - setting on client and access point [11-22](#)
- permit tcp-port command [7-12](#)
- per-VLAN Spanning Tree (PVST) [8-2](#)
- ports, protected [6-25](#)
- positioning packets [6-17](#)
- power client command [6-10](#)
- power level
 - on client devices [6-10](#)
 - radio [6-22](#)
- power local command [6-9](#)
- power-save client device [6-26](#)
- preferential treatment of traffic
 - See QoS
- pre-shared key [11-14](#)
- preventing unauthorized access [5-3](#)
- print [3-13](#)
- prioritization [15-2](#)
- privileged EXEC mode [4-2](#)
- privilege levels
 - exiting [5-9](#)
 - logging into [5-9](#)
 - overview [5-3, 5-8](#)
 - setting a command with [5-8](#)

protected ports [6-25](#)
 protocol filters [16-2](#)
 Public Secure Packet Forwarding (PSPF) [6-24](#)

Q

QBSS [15-3](#)
 dot11e parameter [15-3](#)
 QBSS Basic Service Set [1-8](#)
 QoS
 configuration guidelines [15-5](#)
 described [1-6](#)
 dot11e command [15-9](#)
 overview [15-2](#)
 Qos
 QBSS Load IE [15-9](#)
 quality of service
 See QoS

R

radar [1-5](#)
 radio
 activity [6-28](#)
 congestion [6-11](#)
 indicator [22-4](#)
 interface [6-2](#)
 management [1-7](#)
 preamble [6-19](#)
 radio management [12-1](#)
 RADIUS
 attributes
 CSID format, selecting [13-14](#)
 sent by the access point [13-19](#)
 vendor-proprietary [13-16](#)
 vendor-specific [13-15](#)
 WISPr [13-17](#)
 configuring

 access point as local server [9-2](#)
 accounting [13-13](#)
 authentication [5-10, 13-7](#)
 authorization [5-14, 13-11](#)
 communication, global [13-5, 13-15](#)
 communication, per-server [13-5](#)
 multiple UDP ports [13-5](#)
 default configuration [5-10, 13-4](#)
 defining AAA server groups [5-12, 13-9](#)
 displaying the configuration [5-15, 13-18](#)
 identifying the server [13-5](#)
 limiting the services to the user [5-14, 13-11](#)
 local authentication [9-2](#)
 method list, defined [13-4](#)
 operation of [13-3](#)
 overview [13-2](#)
 SSID [7-2](#)
 suggested network environments [13-2](#)
 tracking services accessed by user [13-13](#)
 RADIUS accounting [1-6](#)
 range [2-12](#)
 rate limit, logging [21-9](#)
 RCP
 configuration files
 downloading [20-16](#)
 overview [20-15](#)
 preparing the server [20-16](#)
 uploading [20-17](#)
 image files
 deleting old image [20-31](#)
 downloading [20-29](#)
 preparing the server [20-27](#)
 uploading [20-31](#)
 reauthentication requests [11-2](#)
 recall commands [4-5](#)
 redirection, IP [7-11](#)
 regulatory
 domains [6-12, 6-13, 6-14](#)
 reloading access point image [22-18](#)

Remote Authentication Dial-In User Service

See RADIUS

Remote Copy Protocol

See RCP

repeater 1-6

as a LEAP client 19-6

as a WPA client 19-7

chain of access points 19-2

request to send (RTS) 6-26

Resilient Tunnel Recovery 1-3

restricting access

overview 5-3

passwords and privilege levels 5-3

RADIUS 5-10, 13-1

TACACS+ 5-15

RFC

1042 6-23

1157, SNMPv1 18-2

1901, SNMPv2C 18-2

1902 to 1907, SNMPv2 18-2

RM21A & RM22A support 1-8

roaming 1-9

fast secure roaming using CCKM 12-1

rogue access point detection 1-7

role (mode) 6-3

role in radio network 6-2

root 2-12

rotation, broadcast key 10-1

rts retries command 6-26

RTS threshold 6-26

rts threshold command 6-26

S

secure remote connections 5-25

Secure Shell

See SSH

security 3-4

troubleshooting 22-15

security features 1-6

synchronizing 11-19

security settings, Express Security page 2-14

self-healing wireless LAN 1-7, 12-5

sequence numbers in log messages 21-6

serial

serial port connector 22-13

service set identifiers (SSIDs)

See SSID

service-type attribute 11-2

set BOOT command 22-22

set command 22-22

set-request operation 18-4

severity levels, defining in system messages 21-7

shared key 11-6

short slot time 6-28

show cdp traffic command 17-5

show command 4-2

show dot11 associations command 7-6

show ip interface command 2-4

Simple Network Management Protocol

See SNMP

Simple Network Time Protocol

See SNTP

slot-time-short command 6-28

SNMP

accessing MIB variables with 18-4

agent

described 18-3

disabling 18-5

community name 2-13

community strings

configuring 18-6

overview 18-4

configuration examples 18-10

default configuration 18-5

limiting system log messages to NMS 21-8

manager functions 18-3

overview 18-2, 18-4

- server groups [18-7](#)
- shutdown mechanism [18-8](#)
- snmp-server view [18-10](#)
- status, displaying [18-12](#)
- system contact and location [18-10](#)
- trap manager, configuring [18-9](#)
- traps
 - described [18-3](#)
 - enabling [18-8](#)
 - overview [18-2, 18-4](#)
 - types of [18-8](#)
 - versions supported [18-2](#)
- SNMP, FTP MIB files [B-2](#)
- snmp-server group command [18-7](#)
- SNMP versions supported [18-2](#)
- SNTP
 - overview [5-27](#)
- software image [22-18](#)
 - upload and download [20-1](#)
- software images
 - location in Flash [20-19](#)
 - tar file format, described [20-19](#)
- software upgrade
 - error and event messages [C-3](#)
- sort (CLI commands) [4-8](#)
- spaces in an SSID [7-6](#)
- speed, Ethernet port [5-18](#)
- speed command [6-7](#)
- SSH [4-9](#)
 - configuring [5-26](#)
 - crypto software image [5-25](#)
 - described [5-25](#)
 - displaying settings [5-26](#)
 - SSH Communications Security, Ltd. [4-9](#)
- SSID [7-2, 14-6](#)
 - guest mode [7-2](#)
 - invalid characters in [7-4, 11-10](#)
 - multiple SSIDs [7-1](#)
 - support [1-6](#)
 - troubleshooting [22-15](#)
 - using spaces in [7-6](#)
 - VLAN [7-2](#)
- ssid command [7-4, 11-10, 14-6](#)
 - rules for [11-10](#)
- SSL [3-5](#)
- standby mode [1-6](#)
- static WEP
 - with open authentication, setting on client and access point [11-19](#)
 - with shared key authentication, setting on client and access point [11-19](#)
- station role command [6-3](#)
- statistics
 - CDP [17-4](#)
 - SNMP input and output [18-12](#)
- status indicators [22-4](#)
- status page [3-4](#)
- STP
 - BPDU message exchange [8-3](#)
 - designated port, defined [8-4](#)
 - designated switch, defined [8-4](#)
 - displaying status [8-14](#)
 - inferior BPDU [8-4](#)
 - interface states
 - blocking [8-7](#)
 - disabled [8-8](#)
 - forwarding [8-6, 8-8](#)
 - learning [8-7](#)
 - listening [8-7](#)
 - overview [8-5](#)
 - overview [8-2](#)
 - root port, defined [8-4](#)
 - superior BPDU [8-4](#)
 - timers, described [8-5](#)
- summer time [5-30](#)
- switchport protected command [6-25](#)
- syslog
 - See system message logging

- system clock
 - configuring
 - daylight saving time [5-30](#)
 - manually [5-28](#)
 - summer time [5-30](#)
 - time zones [5-29](#)
 - displaying the time and date [5-29](#)
- system management page [3-2](#)
- system message logging
 - default configuration [21-3](#)
 - defining error message severity levels [21-7](#)
 - disabling [21-4](#)
 - displaying the configuration [21-12](#)
 - enabling [21-4](#)
 - facility keywords, described [21-11](#)
 - level keywords, described [21-8](#)
 - limiting messages [21-8](#)
 - message format [21-2](#)
 - overview [21-2](#)
 - rate limit [21-9](#)
 - sequence numbers, enabling and disabling [21-6](#)
 - setting the display destination device [21-5](#)
 - timestamps, enabling and disabling [21-6](#)
 - UNIX syslog servers
 - configuring the daemon [21-10](#)
 - configuring the logging facility [21-10](#)
 - facilities supported [21-11](#)
- system name
 - default configuration [5-32](#)
 - manual configuration [5-32](#)
 - See also DNS
- system prompt
 - default setting [5-32](#)
- authentication, defined [13-22](#)
- authorization, defined [13-22](#)
- configuring
 - accounting [13-27](#)
 - authentication key [13-24](#)
 - authorization [5-17, 13-26](#)
 - login authentication [5-15, 13-25](#)
- default configuration [5-15, 13-24](#)
- described [1-6](#)
- displaying the configuration [5-17, 13-28](#)
- identifying the server [13-24](#)
- limiting the services to the user [5-17, 13-26](#)
- operation of [13-23](#)
- overview [13-22](#)
- tracking services accessed by user [13-27](#)
- tar files
 - creating [20-6](#)
 - displaying the contents of [20-6](#)
 - extracting [20-7](#)
 - image file format [20-19](#)
- Telnet [4-9, 2-27](#)
- Temporal Key Integrity Protocol (TKIP) [10-1](#)
 - See TKIP
- Terminal Access Controller Access Control System Plus
 - See TACACS+
- terminal emulator [2-5](#)
- terminal history command [4-5](#)
- terminal width command [4-8](#)
- TFTP [22-21](#)
 - configuration files
 - downloading [20-11](#)
 - preparing the server [20-10](#)
 - uploading [20-11](#)
 - image files
 - deleting [20-22](#)
 - downloading [20-21](#)
 - preparing the server [20-20](#)
 - uploading [20-22](#)
 - password [5-6](#)

T

TAC [22-1](#)

TACACS+

- accounting, defined [13-22](#)

- tftp_init command [22-21](#)
 - TFTP server [22-18](#)
 - throughput [2-12](#)
 - time
 - See SNTP and system clock
 - timestamps in log messages [21-6](#)
 - time zones [5-29](#)
 - TKIP [1-7](#), [6-22](#), [10-1](#), [10-2](#)
 - traps [3-4](#)
 - configuring managers [18-8](#)
 - defined [18-3](#)
 - enabling [18-8](#)
 - notification types [18-8](#)
 - overview [18-2](#), [18-4](#)
 - Trivial File Transfer Protocol (TFTP)
 - See TFTP
 - troubleshooting [22-1](#), [22-6](#), [22-9](#), [22-14](#)
 - 1300 outdoor access point/bridge indicators [22-10](#)
 - 1300 outdoor access point/bridge power injector [22-13](#)
 - error messages (CLI) [4-4](#)
 - system message logging [21-2](#)
 - with CiscoWorks [18-4](#)
-
- U**
- U-APSD [1-4](#)
 - unauthorized access [5-3](#)
 - UNIX syslog servers
 - daemon configuration [21-10](#)
 - facilities supported [21-11](#)
 - message logging configuration [21-10](#)
 - upgrading software images
 - See downloading
 - uploading
 - configuration files
 - preparing [20-10](#), [20-13](#), [20-16](#)
 - reasons for [20-8](#)
 - using FTP [20-14](#)
 - using RCP [20-17](#)
 - using TFTP [20-11](#)
 - image files
 - preparing [20-20](#), [20-23](#), [20-27](#)
 - reasons for [20-18](#)
 - using FTP [20-26](#)
 - using RCP [20-31](#)
 - using TFTP [20-22](#)
 - user EXEC mode [4-2](#)
 - username, default [2-3](#)
 - username-based authentication [5-7](#)
-
- V**
- VLAN
 - local authentication [9-2](#)
 - names [14-7](#)
 - SSID [1-6](#), [7-2](#)
 - VLAN assignment by name [1-8](#)
 - vlan command [7-5](#), [14-6](#)
 - voice [1-7](#)
-
- W**
- W52 [1-5](#)
 - WDS [12-1](#), [12-9](#)
 - Web-based interface
 - common buttons [3-4](#)
 - compatible browsers [3-1](#)
 - web-browser buttons [3-2](#)
 - web-browser interface [1-9](#), [3-1](#)
 - web site
 - Cisco Software Center [2-25](#)
 - WEP
 - key example [10-5](#)
 - key hashing [1-6](#)
 - with EAP [11-4](#)
 - WEP key [22-15](#)
 - troubleshooting [22-15](#)

WIDS [12-6](#)

Wi-Fi Multimedia [15-4](#)

Wi-Fi Multimedia (WMM) [1-8](#)

Wi-Fi Protected Access

- See WPA

Wi-Fi Protected Access (WPA) [1-7, 2-17](#)

wireless domain services (WDS) [1-7](#)

Wireless Internet Service Provider (WISP) [1-7](#)

wireless intrusion detection services [12-1](#)

Wireless LAN Services Module [12-2](#)

wireless repeater [1-6](#)

WISPr [1-7](#)

WISPr RADIUS attributes [13-17](#)

WLSM

- active and standby [1-3](#)
- MIB support [1-3](#)

WMM [15-4](#)

workgroup bridge [6-23](#)

- maximum number of clients allowed [6-3](#)

world mode [1-6, 6-18, 6-22](#)

world-mode command [6-19](#)

WPA [11-7](#)

WPA migration mode [11-13](#)

wpa-psk command [11-14](#)

wraparound (CLI commands) [4-7](#)