



## INDEX

---

### Symbols

/tftpboot/public directory [47](#)

---

### Numerics

802.11a radio  
    configuring [29](#)  
    definition [1](#)  
802.11b/g/n radio  
    configuring [20](#)

---

### A

AAA, definition [1](#)  
AAA-accounting.log file [28](#)  
AAA-cli.log file [28](#)  
AAA-daemon-manager.log file [28](#)  
AAA-database.log file [28](#)  
AAA server, external  
    ACS failed login report [58](#)  
    AP 1100 or AP 1210 used as AAA server [16](#)  
    Cisco ACS, ports used by [1](#)  
    faults [1](#)  
    monitoring [15](#)  
    services supported [16](#)  
    summary report [81](#)  
    using both interfaces on WLSE [14](#)  
AAA server, internal  
    backup and restore, about [5](#)  
    certificates, about [5](#)  
    Cisco-PEAP  
        configuring, using CLI [32](#)

    configuring, using UI [18](#)  
clients  
    managing, using CLI [33](#)  
    managing, using UI [23](#)  
configuring  
    overview [6](#)  
    using CLI commands [30](#)  
    using UI [7](#)  
database, reinitializing [42](#)  
domain authentication  
    configuring, using CLI [45](#)  
    configuring, using UI [15](#)  
domain authentication, port used for [2](#)  
EAP-FAST  
    configuring, using CLI [35](#)  
    configuring, using UI [21](#)  
EAP services supported [4](#)  
EAP-TLS  
    configuring, using CLI [21](#)  
    configuring, using UI [21](#)  
fault monitoring [5](#)  
faults [1](#)  
groups  
    defining [26](#)  
    mapping, using CLI [34](#)  
    mapping, using UI [15](#)  
LDAP central server  
    configuring, using CLI [37](#)  
    configuring, using UI [11](#)  
LDAP local server  
    configuring, using CLI [37](#)  
    configuring, using UI [12](#)  
LDAP parameters, about [13](#)

- LEAP
  - configuring, using CLI [39](#)
  - configuring, using UI [18](#)
- local user database
  - configuring, using CLI [45](#)
  - configuring, using UI [24](#)
- logging
  - configuring [40](#)
  - local [40](#)
  - syslog [40](#)
- logs [28](#)
- monitoring [28](#)
- MS-PEAP
  - configuring, using CLI [41](#)
  - configuring, using UI [19](#)
- naming guidelines [6](#)
- overview [1](#)
- ports used [5](#)
- processes [9](#)
- RADIUS attributes of the AAA server [46](#)
- reports
  - about [5](#)
  - enabling [28](#)
- RSA keys, about [5](#)
- sessions
  - managing, using CLI [43](#)
  - managing, using UI [27](#)
- software upgrade, about [5](#)
- starting and stopping [43](#)
- status
  - displaying, using CLI [9](#)
  - displaying, using UI [44](#)
- summary report [81](#)
- syslog, using [40](#)
- trace levels
  - setting, using the CLI [44](#)
  - setting, using the UI [10](#)
  - trace log [28](#)
- tunneling attributes [50](#)
- users
  - database, methods for storing [3](#)
  - local database, configuring using CLI [45](#)
  - local database, configuring using UI [24](#)
- AAA-server.log file [28](#)
- aaa-server cisco-peap command (WLSE Express) [32](#)
- aaa-server client command (WLSE Express) [33](#)
- aaa-server domain-auth command (WLSE Express) [34](#)
- aaa-server ldap command (WLSE Express) [37](#)
- aaa-server leap command (WLSE Express) [39](#)
- aaa-server logging command (WLSE Express) [40](#)
- aaa-server reinit command (WLSE Express) [42](#)
- aaa-server start command (WLSE Express) [43](#)
- aaa-server status command (WLSE Express) [44](#)
- AAA-server-trace.log file [28](#)
- aaa-server trace command (WLSE Express) [44](#)
- aaa-server user command (WLSE Express) [45](#)
- aaa-server usergroup command (WLSE Express) [45](#)
- AAA-status.log file [28](#)
- access point
  - category types [12](#)
  - configured as an AAA server [16](#)
  - configuring
    - ports used for [1](#)
    - updating firmware [3](#)
    - using Deployment Wizard [1](#)
    - using Deployment Wizard templates [1](#)
    - using IOS templates [1](#)
    - using radio manager assisted configuration [71](#)
    - using WLSM templates [1](#)
- credentials
  - entering on WLSE [5](#)
- definition [1](#)
- duplicate IP addresses, handling [64](#)
- faults
  - displaying [4](#)
  - notification settings [56](#)
  - policy settings [10](#)
  - thresholds settings [10](#)

- firmware
  - updating [3](#)
- friendly to rogue reclassification [12](#)
- infrastructure AP, definition [6](#)
- replacing [64](#)
- reports [47](#)
- rogue AP detection [12](#)
- scanning-only APs [19](#)
- specific settings
  - configuring [104](#)
  - exporting [48](#)
  - importing [46](#)
  - managing [46](#)
  - report [50](#)
  - viewing [49](#)
- SSH passwords, entering on WLSE [11](#)
- system-defined groups for [77](#)
- Telnet passwords, entering on WLSE [11](#)
- user-defined groups for [80](#)
- viewing in Location Manager [2](#)
- WDS access point [8](#)
- access point reports
  - AP and bridge connected to router report [80](#)
  - AP and bridge connected to switch report [78](#)
  - associated client statistics real-time report [102](#)
  - associations report [69](#)
  - auto config retry report [63, 64](#)
  - CPU utilization real-time report [100](#)
  - detailed report [67](#)
  - EAP and MAC failed authentications report [75](#)
  - Ethernet transmission statistics report [92](#)
  - failed authentication and login attempt per AP report [76](#)
  - group CDP inline power report [59](#)
  - group client association report [49](#)
  - group client port [56](#)
  - group identity report [57](#)
  - group inventory [60](#)
  - group MBSSID report [53](#)
  - group performance report
    - Ethernet utilization [86](#)
    - RF utilization [86](#)
  - group security report [50](#)
  - group security violation report [58](#)
  - group serial number report [58](#)
  - group SSID report [52](#)
  - group VLAN report [54](#)
  - hot standby report [74](#)
  - LBS [61](#)
  - MBSSID report [72](#)
  - memory utilization real-time report [99](#)
  - packet errors real-time report [101](#)
  - packet statistics real-time report [100](#)
  - per VLAN client (group) report [55](#)
  - per VLAN client (individual) report [74](#)
  - QoS report [70](#)
  - radio utilization real-time report [102](#)
  - RF and Ethernet utilization graph [93](#)
  - RF and Ethernet utilization tabular report [93](#)
  - RF transmission statistics report [90](#)
  - SSID report [71](#)
  - summary report [65](#)
  - top n busiest clients report [94](#)
  - top n client MIC error rate report [95](#)
  - top n number of associations graph report [88](#)
  - top n number of associations tabular report [87](#)
  - top n percentage errors report [89](#)
  - version summary report [62](#)
  - VLAN report [73](#)
- ACS Failed Login report
  - running [61](#)
- ad-hoc network detection [37](#)
  - disabled faults [4](#)
  - faults [46](#)
  - guidelines [37](#)
  - managing faults [39](#)
  - understanding [37](#)
- admin access

- setting 38
  - advanced
    - security, configuring 63
  - aggregation data for reports, intervals
    - about 72
    - resetting 69
    - understanding 72
  - apptyp command 7
  - AP radio scans 43
  - AP summary report 65
  - AP usage report, displaying 82
  - archives
    - managing, configuration 1
  - ARP, definition 1
  - ARP cache, configuring 93
  - assisted configuration, radio manager
    - guidelines 72
    - jobs 73
      - calculating parameters 79
      - copying 75
      - deleting 75
      - editing 74
      - filtering 74
      - refreshing job list 75
      - viewing details 75
      - viewing run log 75
  - assisted site survey
    - client walkabout 19
    - performing radio scan 17
    - radio parameters, generating 19
    - selecting APs 17
  - audience for this document 24
  - auth command 7
  - authentication (WLSE)
    - CLI
      - displaying 44
      - enabling 7
    - external authentication of WLSE users 16
    - HTTPS
      - displaying 44
      - enabling 7
    - modules supported 16
    - overview 16
    - setting up
      - using CLI command 4
      - using Web interface 17
  - authentication, access point
    - failed and login attempt per AP report 76
    - failed for EAP and MAC report, displaying 75
  - authentication/protection attack detection 65
    - enabling, disabling 67
    - faults 81
    - guidelines 66
    - policies and thresholds 67
    - understanding 65
  - auto config retry group report 63, 64
  - auto-managed configuration 42
    - assigning 42
    - options for email 45
  - automatic configurations, creating 38
  - auto re-site survey 6
    - checking for performance degradations 10
    - collecting baseline data 8
    - disabled faults 4
    - enabling, disabling 8
    - guidelines for running 7
    - monitoring AP performance 10
    - reviewing run log 8
    - running 8
    - selecting floors 8
    - understanding 6
  - AVVID, definition 1
- 
- B**
- backing up and restoring WLSE configuration
    - backing up
      - using CLI commands 6

- using SCP (secure copy) [23](#)
  - using Web interface [24](#)
- backup and restore log
  - clearing [22](#)
  - displaying [5](#)
- backup CLI command [8](#)
- backupconfig CLI command [9](#)
- backup location, configuring
  - on Windows server [24](#)
  - using the CLI [5](#)
  - using the Web interface [22](#)
- files in /tftpboot/public directory [47](#)
- listbackup CLI command [28](#)
- pre-released to released software not allowed [21](#)
- redundant nodes, backup and restore on [38](#)
- restore CLI command [41](#)
- restoring
  - from one WLSE to another [9](#)
  - using the CLI [7](#)
  - using Web interface [26](#)
- secure copy (SCP) [23](#)
- show backupconfig CLI command [44](#)
- backup command [8](#)
- backupconfig command [9](#)
- backup VLANs [51, 52](#)
- basic security template, configuring
  - IOS template [13](#)
- basic template, configuring
  - IOS template [8](#)
- BDPU, definition [10](#)
- beta software, on WLSE
  - upgrade not allowed [8](#)
- black hole mitigation
  - definition [2](#)
  - enabling [79](#)
- booting, WLSE
  - boot messages, displaying [45](#)
  - from the maintenance image [18](#)
  - from Web interface [7](#)
- reload command [38](#)
- BOOTP
  - definition [2](#)
- bridge
  - definition [2](#)
  - firmware, updating [3](#)
  - IOS, configuring [1](#)
- bridge reports
  - AP and bridge connected to router report [80](#)
  - AP and bridge connected to switch report [78](#)
  - associations report [69](#)
  - detailed report [67](#)
  - Ethernet transmission statistics report [92](#)
  - group auto config retry report [63, 64](#)
  - group client association report [49](#)
  - group client report [56](#)
  - group identity report [57](#)
  - group inventory report [60](#)
  - group LBS report [61](#)
  - group MBSSID report [53](#)
  - group performance report
    - Ethernet utilization [86](#)
    - RF utilization [86](#)
  - group security report [50](#)
  - group serial number report [58](#)
  - group SSID report [52](#)
  - group version summary report [62](#)
  - group VLAN report [54](#)
  - per VLAN client (group) report [55](#)
  - per VLAN client (individual) report [74](#)
  - RF and Ethernet utilization graph [93](#)
  - RF transmission statistics report [90](#)
  - top n number associations graph report [88](#)
  - top n number associations tabular report [87](#)
  - top n percentage errors report [89](#)
- browser
  - configuring [4](#)
  - date and time display [10](#)
  - supported browsers [4](#)

BSS, definition [2](#)

## BSSID

definition [2](#)

multiple [14](#)

---

## C

### cautions

backup from pre-released to released software on WLSE not allowed [21](#)

configuring for redundancy [34](#)

erase config command [18](#)

losing data

jobs, configuration [11, 53](#)

jobs, firmware [12](#)

NAT, not supported on WLSE [1](#)

radiomanager command [35](#)

reload command [38](#)

shutdown command, failure to run [66](#)

significance of [24](#)

upgrading from pre-release software not allowed [8](#)

CCK, definition [2](#)

CCKM, definition [2](#)

CCMP, definition [2](#)

### CDP (Cisco Discovery Protocol)

alternatives to [29](#)

configuring [72](#)

definition [2](#)

individual device seeding [29](#)

neighbors of WLSE, displaying [46](#)

status on WLSE, displaying [47](#)

understanding [27](#)

CDPbrdcast process (on WLSE) [43](#)

cdp command [10](#)

### CDP distance

definition [3](#)

specifying [40](#)

### channel load data

determining [19](#)

historical [21](#)

reviewing [19](#)

channels, monitoring [4](#)

character set, allowable (in WLSE UI) [1](#)

ciscoinstall.log [5](#)

### CiscoWorks server

adding links to a WLSE [3](#)

exporting devices to [74](#)

importing devices from

procedure for [42](#)

understanding [33](#)

linking to CiscoWorks server [58](#)

CKIP, definition [2](#)

clearbackuphosts command [11](#)

clear command [11](#)

### CLI

access to, configuring [53](#)

command history feature [2](#)

command privileges [2](#)

commands [1](#)

command summary (table) [3](#)

conventions [2](#)

definition [3](#)

help for commands [2](#)

logging into [2](#)

maintenance image commands [73](#)

erase config [73](#)

fsck [73](#)

reload [74](#)

Privilege Level 0 commands [7](#)

apptyp [7](#)

exit [18](#)

ping [34](#)

show clock [47](#)

show domain-name [50](#)

show interfaces [53](#)

show version [63](#)

traceroute [71](#)

Privilege Level 15 commands [7](#)

- aaa-server cisco-peap (WLSE Express) [32](#)
- aaa-server client (WLSE Express) [33](#)
- aaa-server domain-auth (WLSE Express) [34](#)
- aaa-server ldap (WLSE Express) [37](#)
- aaa-server leap (WLSE Express) [39](#)
- aaa-server logging (WLSE Express) [40](#)
- aaa-server reinit (WLSE Express) [42](#)
- aaa-server session (WLSE Express) [43](#)
- aaa-server start (WLSE Express) [43](#)
- aaa-server status (WLSE Express) [44](#)
- aaa-server trace (WLSE Express) [44](#)
- aaa-server user (WLSE Express) [45](#)
- aaa-server usergroup (WLSE Express) [45](#)
- auth [7](#)
- backup [8](#)
- backupconfig [9](#)
- cdp [10](#)
- clear [11](#)
- clearbackuphosts [11](#)
- clock [12](#)
- debug [13](#)
- diagnostic-info [15](#)
- dumpcores [15](#)
- dumptcp [16](#)
- dumptech [17](#)
- erase config [17](#)
- firewall [19](#)
- gethostbyname [20](#)
- hostname [21](#)
- http-server [21](#)
- import [22](#)
- interface [25](#)
- ip domain-name [26](#)
- ip name-server [27](#)
- listbackup [28](#)
- mail [28](#)
- mailcntrl clear [30](#)
- mailroute [30](#)
- mkcert [31](#)
- nslookup [32](#)
- ntp server [32](#)
- ps [35](#)
- radiomanager [35](#)
- redundancy [36](#)
- reload [38](#)
- repository [38](#)
- reset device-snmp [40](#)
- restore [41](#)
- route [42](#)
- services [42](#)
- setup [43](#)
- show auth-cli [44](#)
- show auth-http [44](#)
- show backupconfig [44](#)
- show backuplog [45](#)
- show bootlog [45](#)
- show cdp-neighbor [46](#)
- show cdp-run [47](#)
- show config [48](#)
- show import [51, 53](#)
- show process [55](#)
- show redundancy [56](#)
- show route [58](#)
- show ssh-server [59](#)
- show ssh-version [60](#)
- show syslog [60](#)
- show tech [61](#)
- show time [62](#)
- shutdown [66](#)
- snmp-server [66](#)
- ssh host [67](#)
- ssh-server accept [67](#)
- ssh-version [68](#)
- tarlog [68](#)
- telnetenable [69](#)
- tftpsrvr [70](#)
- username [71](#)
- webtimeout [73](#)

- wlseconfig (do not use this command) [6](#)
- syntax, checking [2](#)
- timeout period [2](#)
- typographical conventions [3](#)
- use of quotes in commands [2](#)
- using [1](#)
- client
  - inventory of associations [66](#)
  - of internal AAA server [23](#)
  - tracking, through WDS [20](#)
  - unregistered clients, detecting [60](#)
- client polling interval, setting [71](#)
- client reports
  - access failure report, displaying [42](#)
  - associated clients statistics real-time report, displaying [102](#)
  - detail report, displaying [37](#)
  - enhanced (WDS) client tracking [20](#)
  - group association report, displaying [49](#)
  - group report [56](#)
  - historical association report [40](#)
  - per VLAN (group) report, displaying [55](#)
  - per VLAN (individual) report, displaying [74](#)
  - RADIUS username in [23](#)
  - statistics report [39](#)
  - top n busiest clients [94](#)
  - top n busiest report, displaying [94](#)
  - top n client MIC error rate report [95](#)
  - top n MIC error rate report, displaying [95](#)
  - voice client detail report, displaying [44](#)
- client tracking, WDS
  - about [21](#)
  - configuring [20](#)
- client walkabout
  - AP locations, viewing [60](#)
  - AP power setting, choosing [63](#)
  - client MAC addresses, entering [63](#)
  - guidelines for running [55](#)
  - jobs
    - checking status [57](#)
    - creating [61](#)
    - deleting [59](#)
    - details, viewing [59](#)
    - managing [59](#)
    - refreshing job list [60](#)
    - run logs [65](#)
    - running [64](#)
    - starting and stopping [59](#)
    - viewing [60](#)
  - radio location data, collecting [54](#)
  - results
    - viewing [59](#)
    - understanding [54](#)
- clock set command [12](#)
- CMIC, definition [3](#)
- collector log, displaying [48](#)
- command reference, WLSE CLI [1](#)
- community strings
  - definition [3](#)
  - guidelines [9](#)
  - recommendations [8](#)
  - requirement for [6](#)
  - specifying [6](#)
- community strings, WLSE
  - configuring [66](#)
  - displaying [59](#)
  - resetting [40](#)
- configbackup.log [5](#)
- configexport.log [5](#)
- configuration, access points
  - configuration history, viewing device's [7](#)
  - configuration history report [14](#)
  - radio manager assisted configuration [71](#)
- configuration, WLSE
  - backing up
    - by using the CLI [5](#)
    - using Web interface [21](#)
  - copying to another WLSE [9](#)

- Ethernet interfaces [12](#)
- high availability [34](#)
- master configuration file (WLSE Express) [27](#)
- redundancy [34](#)
- restoring
  - by using the CLI [7](#)
  - using Web interface [21](#)
- using DHCP for [27](#)
- configuration archives
  - recommendations for using [26](#)
- configured radio parameters report [16](#)
- connectivity (WLSE), testing [49](#)
- console, using with WLSE [2](#)
- conventions
  - CLI [2](#)
  - in command descriptions [3](#)
- core files, command for saving [15](#)
- CoS (class of service)
  - definition [3](#)
- CPU (WLSE), displaying [64](#)
- credentials, devices
  - configuring
    - Deployment Wizard [4](#)
  - credentials verification job [15](#)
  - entering on WLSE
    - manually [5](#)
    - entering on WLSE, using Deployment Wizard [4](#)
  - HTTP port [13](#)
  - SNMP [6](#)
  - Telnet/SSH [11](#)
  - WLCCP [14](#)
- CSR, definition [3](#)
- CSV
  - definition [3](#)
  - files, about
    - device [31](#)
- CSV files, about
  - device specific settings [47](#)
- Current Logins [20](#)
- current reports [45](#)
  - AP and bridge connected to router report [80](#)
  - AP and bridge connected to switch report [78](#)
  - AP summary [65](#)
  - AP usage report [82](#)
  - associations [69](#)
  - detailed [67](#)
  - EAP and MAC failed authentications report [75](#)
  - failed authentications and login attempt per AP report [76](#)
  - group auto config retry report [63, 64](#)
  - group CDP inline power report [59](#)
  - group client association [49](#)
  - group client report [56](#)
  - group identity report [57](#)
  - group inventory report [60](#)
  - group LBS report [61](#)
  - group MBSSID [53](#)
  - group mobility ID report [61](#)
  - group security [50](#)
  - group security violation report [58](#)
  - group serial number report [58](#)
  - group SSID [52](#)
  - group version summary report [62](#)
  - group VLAN [54](#)
  - hot standby report [74](#)
  - MBSSID report [72](#)
  - per VLAN (group) client report [55](#)
  - per VLAN client (individual) report [74](#)
  - QoS report [70](#)
  - RADIUS authentication [70](#)
  - router summary [80](#)
  - server summary report [81](#)
  - SSID report [71](#)
  - switch summary [77](#)
  - VLAN report [73](#)
  - WLSM modules [79](#)
- current users of WLSE, listing [20](#)
- custom values, configuring

IOS template 104  
 WLSM template 10  
 cwexport.log 5

## D

daemon log, displaying

using CLI command 48  
 using Web interface 5

daemon manager log, displaying

using CLI command 49  
 using Web interface 5

daemons.log file 5

database

backing up 21  
 purging 18  
 reinitializing 37  
 restoring 21

dataUpdate.log 5

date and time

in WLSE displays 10  
 setting  
   browser time 45  
   by using CLI command 12  
   by using NTP 11  
   current local time 45  
 synchronizing to a time server  
   using CLI command 32  
   using Web interface 45

db2runstatlast.log 5

db2runstattimes.log 5

db2uext2.log file 5

debug command 13

Deployment Wizard

about 1  
 deploying devices 10  
 launch at login, enable or disable 3  
 requirements 4  
 templates, creating 4

templates, managing 1

wlsestartup.ini file 3

detailed report 67

device\_events.log 5

device center 7

Device Credentials option 5

device name

characters allowed in 2  
 display of, configuring 45  
 display of, effects of reverse DNS lookup 47  
 format of 45

devices

adding to location manager 14  
 auto-management 48  
 configuring  
   archive jobs 32  
   configuration jobs 10  
   Deployment Wizard 1  
   Deployment Wizard templates, managing 1  
   firmware, updating 1  
   IOS templates, using 1  
   managing configuration jobs 7  
   managing Deployment Wizard templates 1  
   using IOS templates 1  
   using WLSM templates 1

connectivity, testing 49

credentials, setting manually 5

deleting 63

device history report, displaying 13

device identifier, selecting the type 45

device name, display of 10

specifying the format 45

exporting

to a file 76  
 to CiscoWorks server 74

fault summary, viewing 7

firmware, updating 1

grouping 77

history viewing 7

- how WLSE communicates with devices [3](#)
- managing
  - auto-management [48](#)
  - device detail display [60](#)
  - limitation on number of [63](#)
  - limitations, displaying [63](#)
  - management state, changing [57](#)
  - understanding [25](#)
- unmanaged [57](#)
- DFS, definition [3](#)
- DHCP
  - definition [3](#)
  - used with Deployment Wizard [1](#)
  - using for initial configuration of WLSE Express [27](#)
- dhcp.log [5](#)
- diagnostic-info.log [5](#)
- diagnostic-info command [15](#)
- diagnostics, WLSE
  - log files [4](#)
  - processes, viewing [44](#)
  - self-test [41](#)
  - status reports [40](#)
- discovery
  - advanced options [44](#)
  - after WLSE restarts [7](#)
  - CDP discovery, running [37](#)
  - device import
    - running [41](#)
    - understanding [30](#)
  - Discovery Run Details window [51](#)
  - filtering
    - by IP address [50](#)
    - by MAC address (access points) [48](#)
  - history [72](#)
  - individual device seeding [29](#)
  - logs
    - deleting [68](#)
    - viewing [51](#)
  - messages [53](#)
  - port used for [1](#)
  - troubleshooting, common problems [55](#)
  - understanding [25](#)
  - wizard [35](#)
- Discovery Run Details window [51](#)
- disk
  - capacity, displaying [63](#)
  - checking and repairing [73](#)
  - usage, viewing [13](#)
- dmgtd.log file [6](#)
- DNS
  - configuring [73](#)
  - definition [4](#)
  - name servers, specifying
    - using CLI command [27](#)
    - using Web interface [46](#)
  - port for IOS AP configuration [1](#)
  - reverse lookup
    - effect on device name display [47](#)
    - enabling [47](#)
- documentation [24](#)
  - audience for this [24](#)
  - locating on Cisco.com [24](#)
  - typographical conventions in [24](#)
- domain name
  - default, defining [26](#)
  - displaying [50](#)
- DSCP, definition [4](#)
- DTIM, definition [4](#)
- dumpcores
  - command description [15](#)
- dumptcp
  - command description [16](#)
  - log file [6](#)
- dumptech.tgz [6](#)
- dumptech command [17](#)
- Duplicate IP folder (Managed Devices)
  - contents of [64](#)
  - description [59](#)

duplicate IP detection, fault policy for 49

## E

EAP and MAC failed authentications

report, displaying 75

EAP-FAST

definition 4

server

adding to WLSE 17

prerequisites for adding to WLSE 16

EAP-MD5 server

AP usage report, displaying 82

definition 4

summary report, displaying 81

EAPOL, definition 4

EAPOL flooding

understanding 66

EAPOL flooding thresholds

EAPOL detection (IOS) policy 74

EAPOL settings (IOS) policy 73

EAP-TLS

configuring 21

definition 4

email

automatic configuration results 45

fault notifications 62

logs and queues

managing 30

viewing, using CLI command 54

viewing, using Web interface 4

mail server

specifying by using the CLI 15

mail server, specifying

by using Web interface 47

redundancy messages 33

report 3

scheduling 5

testing and debugging 28

EMF (excessive management frame transmissions), detecting 47

EMF detection 47

displaying faults 50

enabling, disabling 49, 6

guidelines 48

reports 50

understanding 47

viewing EMF statistics 50

encryption failures

understanding 65

erase config command 17

erasing system configuration

CLI command for 17

procedure for 18

error.log file 6

Ethernet, configuring Fast/Gigabit 19

Ethernet, WLSE

firewall CLI command 19

interface CLI command 25

ports, configuring 12

Ethertype filters, configuring 79

event

log, configuring 100

ExcepReporter process (on WLSE) 43

excessive management frame transmissions (EMF) 47

exit command 18

exporting

Deployment Wizard templates 4

devices 74

IOS templates 5

reports

GUI-based, using 2

URL-based, using 2

WLSM templates 5

## F

failed authentication and login attempt per AP

- report, displaying 76
- Fast/Gigabit Ethernet, configuring 19
- fast secure roaming, definition 5
- faults
  - access/point bridge thresholds
    - CPU utilization 31
    - Ethernet port packet errors 33
    - Ethernet port status 32
    - Ethernet port utilization 33
    - memory utilization 31
    - SNMP reachable 30
  - access point/bridge policies 15
    - disabled 4
    - EAP per SSID, Enforced for Cisco-Supplicant 18
    - EAP per SSID Enforced, for Mixed-Cisco-Supplicant 20
    - EAP per SSID Enforced, for Non-Cisco-Supplicant 19
    - firmware version 17
    - hotstandby status 17
    - HTTP disabled 16
    - Key Rotation per VLAN 22
    - MIC per VLAN 20
    - PSPF per Vlan 23
    - registration error 18
    - Telnet disabled 16
    - WEP Encryption per VLAN 23
    - WEP per VLAN 21
  - acknowledging 7
  - ad hoc network detection 41
  - ad hoc network faults 39
  - authentication and protection attack 81
  - clearing 6
  - current 51
  - defined 2
  - displaying 4
  - displaying details 7
  - Duplicate IP fault 64
  - emailing 62
  - EMF detection 50
  - exception, definition of 4
  - faults log (WLSE), displaying 5
  - fault status report, displaying 13
  - IDS 4
    - assigning devices to profile 9
    - copying profiles 7
    - creating profiles 6
    - deleting profiles 8
    - disabled 4
    - displaying 4
    - editing profiles 8
    - renaming profiles 7
    - viewing fault profile summary 9
  - interference detection 43
  - MFP detection 55
  - notification, ports used for 1
  - notification settings
    - email 62
    - syslog 60
    - trap notification 56
    - types of 56
  - policies
    - radio-802.11x policies 24
    - WLSE 49
  - policy profiles 10
  - process for 43
  - radio-801.11x thresholds 34
    - associated clients 40
    - association rate 40
    - max retry count 39
    - RF port AdminStatus 35
    - RF port packet errors 37
    - RF port status 34
    - RF port utilization 36
    - RF port WEP errors 38
    - voice bandwidth 41
    - voice QoS status 42
  - radio-811x policies

- Broadcast Disabled 26
- Broadcast SSID 24
  - disabled 4
- Dynamic Frequency Selection 29
- EAP Enforced-Cisco Supplicant 27
- EAP Enforced-Mixed Supplicant 28
- EAP Enforced-Other Supplicant 28
- Infrastructure SSID 25
- PSPF Enabled 26
- WEP Key Length 27
- rogue AP detection 19
- rogue AP faults 19
- router thresholds
  - SNMP reachable 48
- security policy, specifying 10
- security policy monitoring, understanding 2
- settings
  - assigning to devices 14
  - copying 11
  - creating 11
  - deleting 13
  - editing 12
  - notifications 56
  - policies and thresholds 14
  - renaming 12
  - understanding 10
  - viewing 13
- states, understanding 2
- switch thresholds
  - CPU utilization 43
  - memory utilization 44
  - module status threshold 46
  - port status 45
  - port utilization 45
  - SNMP reachable 43
- threshold-related, understanding 3
- thresholds 50
  - AAA server response time 49
  - access point/bridge 30
    - radio-802.11x thresholds 34
  - router 48
    - specifying 10
  - switch 42
    - WLSM 46
- trap notification settings 56
- understanding 2
- unregistered clients 60
- WDS
  - disabled 4
- WDS policies
  - authentication failures 50
  - WLSE-WDS link status 51
- WLSE policies
  - duplicate IP detection 49
- faults.log file 6
- files
  - managing with WLSE TFTP server 47
  - master configuration file (WLSE Express) 27
  - WLSE log files 4
- filters
  - discovery
    - by IP Address 50
    - by MAC address (access points) 48
  - Ethertype, configuring 79
  - IP, configuring 76
  - MAC address, configuring 74
- firewall
  - firewall CLI command 19
  - ports on WLSE 1
- firmware
  - "not verified" status 26
  - estimating change window 2
  - firmware history report, displaying 14
  - history, viewing device's 7
  - how firmware upgrades work 1
- images
  - deleting 5
  - editing on WLSE 4

- importing [6](#)
- storing on remote TFTP server [9](#)
- transfer, ports used for [1](#)
- viewing [4](#)
- jobs
  - copying [24](#)
  - creating [12](#)
  - deleting [23](#)
  - details, displaying [24](#)
  - displaying [22](#)
  - editing [23](#)
  - failures [26](#)
  - job choices [12](#)
  - parameters for [10](#)
  - protocol, changing [24](#)
  - scheduling [14](#)
  - status, checking [20](#)
  - status, details [26](#)
  - validating [15](#)
- supported versions, displaying [50](#)
- upgrading
  - about [1](#)
  - procedures [3](#)
- frame monitoring [19](#)
  - configuring [20](#)
  - displaying APs [23](#)
  - enabling, disabling [20](#)
  - guidelines for running [19](#)
  - scanning-only APs [19](#)
  - selecting APs [20](#)
  - selecting radio types [20](#)
  - understanding [19](#)
- frame transmissions (EMF), detecting [47](#)
- friendly AP
  - reclassifying to rogue [18](#)
  - reports, viewing [28](#)
- fsck command [73](#)
- FTP
  - port for IOS AP configuration [1](#)

---

## G

- gethostbyname command [20](#)
- getting started
  - with device management [1](#)
  - with WLSE [1](#)
- GRE, definition [5](#)
- group reports [46](#)
  - auto config retry report, displaying [63, 64](#)
  - CDP inline power report, displaying [59](#)
  - client association report, displaying [49](#)
  - client report, displaying [56](#)
  - group client association report, displaying [49](#)
  - identity report, displaying [57](#)
  - inventory report, displaying [60](#)
  - LBS report, displaying [61](#)
  - MBSSID report, displaying [53](#)
  - mobility ID report, displaying [61](#)
  - performance report for Ethernet utilization, displaying [86](#)
  - performance report for RF utilization, displaying [86](#)
  - per VLAN client report, displaying [55](#)
  - security report, displaying [50](#)
  - security violation report, displaying [58](#)
  - serial number report, displaying [58](#)
  - SSID report, displaying [52](#)
  - top number of associations graph report, displaying [88](#)
  - top number of associations tabular report, displaying [87](#)
  - top percentage errors report, displaying [89](#)
  - version summary report, displaying [62](#)
  - VLAN report, displaying [54](#)
- groups
  - copying
    - rule-based [86](#)
    - static [85](#)
  - creating
    - rules-based [84](#)
    - static [83](#)

- deleting [89](#)
  - editing
    - rule-based [88](#)
    - static [87](#)
  - overview [77](#)
  - rule-based
    - copying [86](#)
    - creating [84](#)
    - deleting [89](#)
    - editing [88](#)
  - static
    - creating [83](#)
    - creating by copying [85](#)
    - deleting [89](#)
    - editing [87](#)
  - system-defined [77](#)
  - understanding [77](#)
  - user-defined [80](#)
- GUI, WLSE
- About button [9](#)
  - dashboard [7](#)
  - device name display [10](#)
  - Help button [9](#)
  - Logout button [9](#)
  - Overview button [9](#)
  - tabs and subtabs [7](#)
  - time display [10](#)
  - timeout period
    - default [13](#)
    - resetting [46](#)
  - Wizard button [9](#)
- 
- H**
- HaMibDaemon process (on WLSE) [43](#)
  - hardware type (WLSE), displaying [7](#)
  - help
    - CLI, displaying [2](#)
    - Web interface [9](#)
  - high availability, WLSE [29](#)
  - host file
    - displaying, show hosts command [50](#)
    - displaying, show import command [51, 53](#)
    - importing [22](#)
  - hostname (WLSE)
    - characters allowed [21](#)
  - hostname command [21](#)
  - hostnames (in WLSE dialogs), characters allowed in [2](#)
  - hostnames, translating to IP addresses [32](#)
  - hot standby
    - configuring [71](#)
    - report, displaying [74](#)
  - HTTP
    - access to WLSE, configuring [21](#)
    - configuring [81](#)
    - definition [5](#)
    - http-server command [21](#)
    - port for VxWorks access point configuration [1](#)
    - WLSE HTTP port, configuring [21](#)
    - WLSE Web port for [2](#)
  - HTTPS
    - access to WLSE, configuring [21](#)
    - certificate signed request, obtaining [18, 31](#)
    - definition [6](#)
    - http-server command [21](#)
    - log, viewing [4](#)
    - port used for [2](#)
    - using to export devices [76](#)
  - http-server command
    - description of [21](#)
    - on redundant WLSEs [40](#)
- 
- I**
- IBSS, definition [6](#)
  - ICMP, definition [6](#)
  - IDS (Intrusion Detection System)
    - ad-hoc networks, detecting [37](#)

- authentication attacks, detecting [65](#)
- EMF, detecting [47](#)
- enable/disable [35](#)
- fault profiles [6](#)
- interference, detecting [43](#)
- MIC failure
  - definition [7](#)
- network-wide settings [11](#)
- policies and thresholds [10](#)
- protection attacks, detecting [65](#)
- reports [5](#)
- rogue AP detection [12](#)
- settings [6](#)
- settings, remaining [11](#)
- summary of intrusions [2](#)
- switch ports, detecting and suppressing [30](#)
- understanding [2](#)
- unregistered clients, detecting [60](#)
- IGMP, definition [6](#)
- images
  - access point firmware [1](#)
  - using WLSE TFTP server to download [47](#)
  - WLSE software [8](#)
- import command [22](#)
- importing
  - device firmware [6](#)
  - devices
    - about CSV files [31](#)
    - from CiscoWorks server [42](#)
    - from file [41](#)
    - understanding [30](#)
  - templates
    - IOS [4](#)
    - WLSM [4](#)
- infrastructure access point, definition [6](#)
- installation (WLSE)
  - configuring the web browser [4](#)
  - installing a replacement WLSE [8](#)
- interface command [25](#)
- interference detection [43](#)
  - disabled faults [4](#)
  - understanding [43](#)
  - viewing faults [46](#)
- intrusion detection
  - enable/disable [35](#)
  - using [1](#)
- inventory
  - after WLSE restarts [7](#)
  - automatic
    - polling interval [67](#)
    - understanding [66](#)
  - client associations inventory [66](#)
  - group report, displaying [60](#)
  - history [72](#)
  - immediate [68](#)
  - logs
    - deleting [68](#)
    - viewing [72](#)
  - performance inventory [66](#)
  - polling intervals
    - guidelines for [68](#)
    - setting [69](#)
  - port used for [1](#)
  - run by Radio Manager [73](#)
  - running [68](#)
  - scheduled [66](#)
  - troubleshooting
    - common problems [74](#)
- IOS
  - access point reports [47](#)
  - templates, using [1](#)
- IP address (WLSE), changing [14](#)
- IP addresses
  - in UI, display of [10](#)
  - of devices
    - displaying [47](#)
    - display of [45](#)
  - translating to hostnames [32](#)

IP chains, displaying [50](#)  
 ip domain-name command [26](#)  
 IP filters, configuring [76](#)  
 ip name-server command [27](#)

---

## J

### Java Plugin

general requirement [5](#)  
 requirement for Windows XP repository [11](#)

job history truncation interval, setting [71](#)

jobs, AP radio scan [48](#)

### jobs, archive

copying [36, 60](#)  
 creating [32](#)  
 deleting [36, 60](#)  
 editing [35, 59](#)  
 filtering [34, 58](#)  
 job run details, viewing [36, 60](#)  
 managing [1](#)  
 overview [25](#)  
 recommendations [26](#)  
 running again [36, 60](#)  
 viewing status [32, 56](#)

jobs, client walkabout [59](#)

### jobs, configuration

copying [23](#)  
 creating [18](#)  
 deleting [23](#)  
 editing [22](#)  
 filtering [22](#)  
 managing [7](#)  
 naming guidelines [1](#)  
 overview [8](#)  
 recommendations [9](#)  
 running again [22](#)  
 undoing [23](#)  
 viewing status [18](#)

### jobs, discovery

CDP discovery, running [35](#)  
 import from CiscoWorks server [42](#)  
 job run log [51](#)  
 server time discrepancy message [11](#)

jobs, email [5](#)

### jobs, firmware

copying [24](#)  
 creating [11](#)  
 deleting [23](#)  
 duration [18](#)  
 editing [23](#)  
 filtering [22](#)  
 job run details [24](#)  
 managing [11](#)  
 naming guidelines [1](#)  
 parameters for [10](#)  
 server time discrepancy message [11](#)  
 viewing [20](#)

jobs, radio manager assisted configuration [74](#)

jobs log (jobvm.log), displaying [6](#)

---

## K

Key Rotation [55, 58, 51, 54](#)

---

## L

Last 10 Logins [20](#)

### LBS

group report, displaying [61](#)

### LDAP

definition [6](#)  
 in built-in AAA server (WLSE Express) [3](#)

### LEAP server

AP usage report, displaying [82](#)  
 definition [6](#)  
 monitoring [10](#)  
 summary report, displaying [81](#)

- Links subtab [58](#)
- listbackup command [28](#)
- location manager
  - editing antenna placement [28](#)
  - enabling/disabling [35](#)
  - interference reports [34](#)
  - locating devices [27](#)
  - measuring tool [35](#)
  - prerequisites for using [2](#)
  - server information, obtaining [34](#)
  - setting up [3](#)
  - system-defined groups for [79](#)
  - viewing [1](#)
  - view modes [29](#)
  - window
    - tools [34](#)
    - understanding [36](#)
- log file rotation [6](#)
- logging in (to the WLSE)
  - from Web interface [13](#)
  - splash screen, adding a message [44](#)
  - via the CLI [2](#)
- logging out (from the WLSE)
  - from the CLI [3](#)
  - from the Web interface [13](#)
- logs, WLSE
  - AAA server logs (WLSE Express) [28](#)
  - archiving [68](#)
  - ciscoinstall.log [5](#)
  - collector log [48](#)
  - configbackup.log [5](#)
  - configexport.log [5](#)
  - cwexport.log [5](#)
  - daemon manager log, viewing
    - from Web interface [4](#)
    - show dmgtldlog command [49](#)
  - daemons log, viewing
    - from the Web interface [4](#)
    - show daemonslog command [48](#)
  - database logs [5](#)
  - dataUpdate.log [5](#)
  - db2runstatlast.log [5](#)
  - db2runstattimes.log [5](#)
  - device\_events.log [5](#)
  - dhcp.log [5](#)
  - diagnostic-info.log [5](#)
  - discovery logs
    - deleting [68](#)
    - viewing [51](#)
  - displaying, using the CLI [15](#)
  - displaying, using Web interface [4](#)
  - downloading [4](#)
  - dumptcp log [6](#)
  - dumptech.tgz [6](#)
  - emailing [4](#)
  - faults [6](#)
  - HTTPS events [6](#)
  - install logs [51](#)
  - inventory logs
    - deleting [68](#)
    - viewing [72](#)
  - jobvm log [6](#)
  - logs\_tgz.log [6](#)
  - procs\_last.log [6](#)
  - radio management [6](#)
  - redundancy.log [6](#)
  - redundancy logs
    - redundancy.log [6](#)
    - systemCheck.log [6](#)
  - redundancy events [37](#)
  - Repository.log [5](#)
  - runstats.log [6](#)
  - searching [4](#)
  - SNMP agent [6](#)
  - software installation [6](#)
  - syslog [60](#)
  - systemCheck.log [6](#)
  - system log [44](#)

- fttp.log 6
    - Tomcat log 4, 62
    - trace logging, enabling (WLSE Express) 10
    - var\_logs\_tgz.log 6
    - View Log File option 4
    - web access log
      - viewing from CLI 64
      - viewing from UI 5
    - Web error log
      - viewing from CLI 64
      - viewing from Web interface 4
    - web SSL access log
      - viewing, from CLI 65
      - viewing, from Web interface 5
- 
- M**
- MAC address
    - filters (discovery) 48
    - filters, configuring 74
    - WLSE MAC address, displaying 53
  - MAC spoofing
    - policy 72
    - understanding 65
  - mailctrl clear command 30
  - mail command 28
  - mailroute command 30
  - mail server
    - specifying by using the CLI 15
    - specifying by using Web interface 47
  - maintenance image, WLSE
    - booting from 18
    - CLI commands for 73
    - using 18
  - Managed folder (Managed Devices) 58
  - management frame protection
    - displaying faults 55
    - enabling/disabling 54
    - understanding 53
  - viewing MFP events 57, 58
  - management services (WLSE), stopping/starting 15
  - Manage Roles option 51
  - Manage Users option 53
  - managing devices
    - auto-manage options 48
    - changing device state 59
    - deleting devices 63
    - device descriptions, entering 62
    - device details
      - understanding 60
      - viewing 60
    - Managed Devices folders 58
    - using the Deployment Wizard 1
  - MBSSID
    - report, displaying 72
    - understanding 14
  - memory (WLSE), displaying 63
  - mfgtest.log file 6
  - MFP
    - capabilities, reports 56
    - events, reports 57, 58
  - MHAE, definition 7
  - MIC/encryption failure thresholds
    - CcmpDecryptErrorsClient policy 71
    - CcmpReplaysClient policy 70
    - TkipLocalMicFailureClient policy 68, 72
    - TkipRemoteMicFailureClient policy 69
    - TkipReplayClient Policy 67
  - MIC failures
    - understanding 65
  - mkcert command 31
  - mobility groups report, displaying 82
  - mobility ID report, displaying 83
  - mod\_jk.log file 6
  - MOK, definition 7

---

**N**

name servers, specifying

- ip name-server command [27](#)
- using Web interface [46](#)

names of devices

- display of [45](#)
- rules for [2](#)

naming guidelines [1](#)

- built-in AAA server (WLSE Express) [3](#)
- descriptions [2](#)
- device names [2](#)
- hostnames [2](#)
- other names [2](#)
- roles [1](#)
- users [1](#)

NAT, not supported by WLSE [1](#)

neighbors (of WLSE), displaying [46](#)

Network Address Translation (NAT), not supported by WLSE [1](#)

network connectivity, testing [49](#)

network interfaces

- configuring
  - Fast/Gigabit Ethernet [19](#)
  - radio-802.11a/n [29](#)
  - radio-802.11b/g/n [20](#)
- on WLSE
  - configuring, interface CLI command [25](#)
  - configuring, procedures for [12](#)
  - information about, displaying [53](#)
  - IP chains, displaying [50](#)
  - using both interfaces [14](#)
- template [19](#)

network management systems, integrating with WLSE [3](#)

New folder (Managed Devices) [58](#)

non-serving channels

- definition [7](#)
- monitoring [4](#)

notification settings, faults [56](#)

notification settings, IDS faults [12](#)

nslookup

- definition [7](#)
- from CLI [32](#)
- from Web interface [49](#)

NTP (Network Time Protocol)

- configuring time servers on WLSE
  - ntp server CLI command [32](#)
  - using Web interface [45](#)
- definition [7](#)
- setting current date and time [45](#)
- setting system date and time [11](#)

ntp server command [32](#)

---

**O**

OFDM, definition [7](#)

Open source acknowledgements [31](#)

Open Source License Acknowledgements [31](#)

OpenSSL [31](#)

---

**P**

PAC

- definition [8](#)
- provisioning, on internal AAA server [18](#)

packet content, command for displaying [16](#)

packet handling template, configuring [96](#)

passwords (WLSE)

- changing your password [57](#)
- loss of, recovering from [21](#)
- WLSE users [53](#)

passwords, devices

- SSH password, entering on WLSE [1, 11](#)
- Telnet password, entering on WLSE [1, 11](#)

path loss data

- historical [19](#)
- reviewing [17](#)

PEAP server, external

- definition [8](#)
- monitoring [15](#)

performance

- inventory [66](#)
- polling interval, setting [71](#)

per VLAN client (group) report, displaying [55](#)

ping

- definition [8](#)
- from CLI [34](#)
- from Web interface [49](#)

polling

- aggregation parameters [71](#)
- fault and job data truncation parameters [71](#)
- inventory parameters [70](#)

pop-up blocker software [4](#)

ports, on the WLSE

- HTTP access port, configuring [21](#)
- port filtering, configuring [19](#)
- ports hosted by WLSE [2](#)
- ports used by WLSE [1](#)

processes

- failure of [41](#)

processes, WLSE

- AAA server processes (WLSE express) [9](#)
- active statistics, displaying [55](#)
- displaying
  - using CLI [35](#)
  - using Web interface [41](#)
- starting and stopping
  - from the CLI [42](#)
  - from the UI [41, 42](#)

procs\_last.log [6](#)

protection attacks, detecting [65](#)

protocols, on WLSE

- configuring Ethernet interface [13](#)
- ports used for [1](#)

proxy mobile IP

- definition [8](#)

proxy server, for firmware import [8](#)

ps CLI command [35](#)

PSPF, definition [8](#)

---

## Q

quality of service (QoS)

- configuring
  - 802.11b/g [86](#)
  - policies [82](#)
- definition [8](#)
- report, displaying [70](#)

---

## R

radio

- 802.11a, configuring [29](#)
- 802.11b/g, configuring [20](#)
- AP/client relationships [10](#)
- coverage and capacity [10](#)
- performance regions [11](#)
- reports, displaying [15](#)
- uplink contention regions [12](#)

radio interference thresholds

- authentication error rate policy [75](#)
- CCMP replays discarded policy [80](#)
- TKIP counter measure invoked policy [78](#)
- TKIP local MIC failures policy [76](#)
- TKIP remote MIC failures policy [77](#)
- TKIP replays detected policy [79](#)

radio location data

- collecting [14](#)
- radio monitoring data, collecting [1](#)

Radio Management

- CLI command [4](#)
- disabled faults [4](#)
- disabled fault settings [11](#)
- enabling/disabling [4](#)

- radio management
  - network, configuring for [5](#)
  - overview [1](#)
  - radio management capability, verifying [27](#)
  - understanding [7](#)
- radio manager
  - assisted configuration [71](#)
  - auto re-site survey [6](#)
  - client walkabout [54](#)
  - enable/disable [35](#)
  - frame monitoring [19](#)
  - getting started [1,2](#)
  - location manager [2](#)
  - log file for [6](#)
  - managing data [81](#)
  - processes for [43](#)
  - radio monitoring [1](#)
  - radio performance [6](#)
  - reports, displaying [25](#)
  - self healing [11](#)
  - understanding [7](#)
  - WLSE, configuring for [14](#)
- radiomanager command [35](#)
- radio measurement aggregation, definition [8](#)
- radio monitoring [1](#)
  - enabling, disabling [4](#)
  - guidelines for running [3](#)
  - selecting APs [4](#)
  - understanding [2](#)
- radio parameters, generating [66](#)
- radio performance
  - evaluating [6](#)
  - understanding [10](#)
- radio scans
  - filtering [49](#)
  - guidelines for running [45](#)
  - jobs
    - copying [49](#)
    - creating [50](#)
    - deleting [49](#)
    - editing [49](#)
    - job run logs [53](#)
    - managing [48](#)
    - naming [51](#)
    - run logs, viewing [53](#)
    - running [49](#)
    - scheduling [52](#)
    - stopping [49](#)
    - selecting devices [51](#)
    - selecting radio types [51](#)
    - understanding [44](#)
    - viewing results [48](#)
- RADIUS
  - attributes for internal AAA server (WLSE Express) [46](#)
  - authentication module [17](#)
  - definition [9](#)
  - port for WLCCP authentication [2](#)
- RADIUS server
  - AP usage report, displaying [82](#)
  - authentication report, displaying [70](#)
  - built-in (on WLSE Express) [1](#)
  - monitoring [10](#)
  - ports for [1](#)
  - summary report, displaying [81](#)
- RAM (WLSE), displaying [63](#)
- real-time reports
  - AP CPU utilization [100](#)
  - AP memory utilization [99](#)
  - AP packet errors [101](#)
  - AP packet statistics [100](#)
  - AP radio utilization [102](#)
  - associated client statistics [102](#)
  - WLSM roaming statistics [103](#)
- rebooting, WLSE
  - using the CLI [38](#)
  - using Web interface [7](#)
- recovery (WLSE)

- maintenance image [18](#)
  - recovery CD
    - creating [19](#)
    - using [19](#)
  - reimaging the WLSE [19](#)
  - rescue image, using [21](#)
  - resetting WLSE to factory defaults [18](#)
- redundancy, WLSE
  - backup and restore on redundant nodes [38](#)
  - checking settings [36](#)
  - configuring [34](#)
  - email messages [33](#)
  - event log [37](#)
  - files in /tftpboot/public directory [47](#)
  - hardware requirements [30](#)
  - http-server accept command, using [40](#)
  - manual failover [37](#)
  - message log [6](#)
  - nodes, replacing [38](#)
  - prerequisites for [30](#)
  - redundancy CLI command [36](#)
  - show redundancy CLI command [56](#)
  - software, upgrading [38](#)
  - system check log [6](#)
  - system check timeout period [35](#)
  - web timeout period, resetting [39](#)
- redundancy.log [6](#)
- redundancy command [36](#)
- reimaging the WLSE [19](#)
- reload, configuring [102](#)
- reload command [38](#)
- replacement WLSE, installing [8](#)
- reports
  - ACS failed login report [61](#)
  - ad-hoc network [41](#)
  - AP and bridge connected to router [80](#)
  - AP and bridge connected to switch [78](#)
  - AP CPU utilization, real-time [100](#)
  - AP memory utilization, real-time [99](#)
  - AP packet errors, real-time [101](#)
  - AP packet statistics, real-time [100](#)
  - AP radio scan results, viewing [48](#)
  - AP radio utilization, real-time [102](#)
  - APs registered with WDS [12](#)
  - AP summary [65](#)
  - AP usage, displaying [82](#)
  - associated client statistics, real-time [102](#)
  - associations [69](#)
  - auto config retry [15](#)
  - channel loading [19](#)
  - channel loading, historical [21](#)
  - client access failure [42](#)
  - client detail [37](#)
  - client historical association [40](#)
  - client roaming statistics [97](#)
  - client statistics [39](#)
  - configuration history [14](#)
  - configured radio parameters [16](#)
  - current [45](#)
  - detailed [67](#)
  - device center, using [7](#)
  - device fault status [13](#)
  - device history [13](#)
  - device specific [50](#)
  - EAP and MAC failed authentication [75](#)
  - emailing [3](#)
  - EMF detection [50](#)
  - Ethernet transmission statistics [92](#)
  - exporting [2](#)
  - failed authentication and login attempt per AP [76](#)
  - firmware history [14](#)
  - friendly AP reports [28](#)
  - group auto config retry [63, 64](#)
  - group CDP inline power [59](#)
  - group client [56](#)
  - group client association [49](#)
  - group identity [57](#)
  - group inventory [60](#)

- group LBS [61](#)
- group MBSSID [53](#)
- group mobility ID [61](#)
- group performance, Ethernet utilization [86](#)
- group performance, RF utilization [86](#)
- group security [50](#)
- group security violation [58](#)
- group serial number [58](#)
- group SSID [52](#)
- group version summary [62](#)
- group VLAN [54](#)
- hot standby [74](#)
- IDS
  - viewing [5](#)
- interference reports (Location Manager) [34](#)
- links to from Group Details display [82](#)
- MBSSID [72](#)
- MFP capabilities [56](#)
- MFP events [57, 58](#)
- mobility groups, displaying [82](#)
- mobility ID, displaying [83](#)
- path loss between managed APs [17](#)
- path loss between managed APs, historical [19](#)
- per VLAN client [55, 74](#)
- QoS [70](#)
- radio manager reports [15](#)
- RADIUS authentication [70](#)
- real-time, displaying [98](#)
- RF and Ethernet utilization, tabular [93](#)
- RF and utilization, graph [93](#)
- RF transmission statistics [90](#)
- router summary [80](#)
- scheduling email [5](#)
- server response time, graph [96](#)
- server summary [81](#)
- SSID [71](#)
- switch summary [77](#)
- top n busiest clients [94](#)
- top n client MIC error rate [95](#)
- top n number of associations graph [88](#)
- top n number of associations tabular [87](#)
- top n percentage errors [89](#)
- trend, using for capacity planning [85](#)
- trends, displaying [84](#)
- unregistered clients [63](#)
- VLAN [73](#)
- voice client detail [44](#)
- WDS summary [10](#)
- wireless client [37](#)
- WLSM modules [79](#)
- repository
  - browsing [13](#)
  - defining
    - using CLI [38](#)
    - using Web interface [11](#)
  - definition [9](#)
  - install configure CLI command [23](#)
  - install list CLI command [24](#)
  - port for [1](#)
  - repository CLI command [38](#)
  - show repository CLI command [57](#)
- Repository.log [5](#)
- rescue image, WLSE [21](#)
- reset device-snmp command [40](#)
- resetting WLSE to factory defaults [18](#)
- restarting (rebooting) WLSE
  - bootlog, displaying [45](#)
  - from Web interface [7](#)
  - reload command [38](#)
- restore command [41](#)
- restoring data from backups
  - from pre-released to released not allowed [21](#)
  - restoring from one WLSE to another [9](#)
  - using the CLI
    - procedure for [7](#)
    - restore command reference [41](#)
  - using Web interface [26](#)
- reverse DNS lookup [47](#)

roaming, client statistics report [97](#)

rogue AP

- automatic suppression [30](#)
- changing to friendly [24](#)
- detection, enabling/disabling [16](#)
- detection guidelines [14](#)
- disabled faults [4](#)
- displaying information about [22](#)
- displaying location of [22](#)
- fault history [23](#)
- managing [24](#)
- maximum limit [14](#)
- reclassification, enabling/disabling [18](#)
- reports [26](#)

rogue APs

- detecting [12](#)

roles

- creating and modifying [52](#)
- debug tools privilege [52](#)
- deleting [51](#)
- for users created by using the CLI [3](#)
- naming guidelines [1](#)
- predefined [51](#)
- XML API privileges [51](#)

route command [42](#)

router

- AP and Bridge connected to, displaying [80](#)
- fault monitoring [1](#)
- fault thresholds, setting [10](#)
- summary report, displaying [80](#)
- system-defined group for [77](#)

routes (WLSE)

- adding or deleting [42](#)
- displaying
  - show route CLI command [58](#)

RSA, definition [9](#)

RSSI, definition [9](#)

runstats.log [6](#)

## S

scanning AP

- system group for [79](#)
- using [47](#)

scheduling

- archive jobs [30](#)
- backups [24](#)
- configuration jobs [15](#)
- discovery [35](#)
- email [5](#)
- firmware jobs [11](#)

SCP

- definition [9](#)
- using for backups [23](#)

searching for devices [12](#)

security

- last 10 logged in users, viewing [20](#)
- SSL
  - certificate signed request, obtaining [18](#)
  - Telnet, enabling or disabling [19](#)

security (devices)

- advanced, configuring [63](#)
- templates [38](#)
  - admin access [38](#)
  - advanced [63](#)
  - local RADIUS server [66](#)
  - server manager [59](#)
  - SSID 802.11b/g [40](#)
  - WEP 802.11a [55](#)
  - WEP 802.11b/g [53](#)

security, WLSE

- authentication
  - enabling [7](#)
  - modules [16](#)
- HTTP access to WLSE, controlling [21](#)
- HTTPS [18](#)
- log, displaying [58](#)
- SSH [19](#)

- access to WLSE, controlling [68](#)
  - access to WLSE, enabling [68](#)
- seed
  - CDP-based discovery [27](#)
  - definition [9](#)
  - individual device seeding [29](#)
- self healing
  - assigning severity level [15](#)
  - clearing faults [17](#)
  - enabling, disabling [15](#)
  - guidelines for running [14](#)
  - reviewing history [17](#)
  - running [17](#)
  - selecting floors [15](#)
  - tracking progress [17](#)
  - understanding [11](#)
- server
  - AAA server, internal [1](#)
  - local RADIUS server, configuring [66](#)
  - manager, configuring [59](#)
  - SMTP server [15](#)
- server, AAA
  - response time graph report, displaying [96](#)
- server manager, configuring
  - WLSM template [7](#)
- services (WLSE)
  - managing
    - procedure for [15](#)
    - using CLI services command [42](#)
  - ports used for [1](#)
  - reintdb command, effect on [37](#)
  - stopping and starting [15](#)
  - time reset, requirement for stopping services [13](#)
- services, configuring [69](#)
  - ARP cache [93](#)
  - CDP [72](#)
  - DNS [73](#)
  - Ethertype filters [79](#)
  - hot standby [71](#)
  - HTTP [81](#)
  - IP filters [76](#)
  - MAC address filters [74](#)
  - packet handling [96](#)
  - QoS 802.11b/g [86](#)
  - QoS policies [82](#)
  - SNMP [87](#)
  - SNTP [90](#)
  - STP [94](#)
  - Telnet/SSH [69](#)
  - VLAN [91](#)
- services command [42](#)
- serving channels
  - definition [9](#)
  - monitoring [4](#)
- setting system date and time
  - using the CLI [11](#)
  - using the Web interface [45](#)
- setup command [43](#)
- show auth-cli command [44](#)
- show auth-http [44](#)
- show backupconfig command [44](#)
- show backuplog command [45](#)
- show bootlog command [45](#)
- show cdp-neighbor [46](#)
- show cdp-run command [47](#)
- show clock command [47](#)
- show config command [48](#)
- show domain-name command [50](#)
- show import command [51, 53](#)
- show interfaces command [53](#)
- show process command [55](#)
- show redundancy CLI command [56](#)
- show route command [58](#)
- show ssh-server command [59](#)
- show ssh-version command [60](#)
- show syslog command [60](#)
- show tech command [61](#)
- show time command [62](#)

- show version command [63](#)
- shutdown command [66](#)
- shutting down (WLSE)
  - from the CLI [10](#)
  - using CLI [66](#)
- Sites tab options
  - AP radio scan, using [43](#)
  - assisted configuration, using [66](#)
  - client walkabouts, using [54](#)
  - enabling/disabling [35](#)
  - location manager, using [2](#)
  - radio manager data, managing [81](#)
- SMTP
  - definition [9](#)
  - port for fault notification [1](#)
  - server, specifying by using the CLI [15](#)
  - server, specifying by using the Web interface [47](#)
- SNMP
  - agent, configuring [66](#)
  - agent log, displaying [5](#)
  - community strings
    - for WLSE server, displaying [59](#)
    - for WLSE server, resetting [40](#)
    - for WLSE server, setting [66](#)
  - community strings, for devices
    - entering on WLSE [6](#)
    - guidelines for [9](#)
    - recommendations [8](#)
  - configuring [87](#)
  - definition [9](#)
  - faults
    - trap notification settings [56](#)
    - trap version supported [56](#)
  - port for for discovery, inventory, and AP configuration [1](#)
  - port for SNMPTRAP [1](#)
  - port on trap receiver for traps from APs [1](#)
  - port on WLSE for traps from APs [2](#)
  - reachability, testing [49](#)
  - retries, recommendations for [10](#)
  - timeouts, recommendations for [10](#)
  - traps, version supported [56](#)
  - traps supported [3](#)
  - variables, querying [50](#)
- snmp-server command [66](#)
- SNMPv2c [9](#)
- SNMPv3 [9](#)
- SNTP (Simple Network Time Protocol)
  - configuring [90](#)
- software, on devices
  - firmware, managing [1](#)
  - groups for [77](#)
- software, on WLSE
  - installation logs, displaying [5](#)
  - maintenance image [73](#)
  - overview [8](#)
  - recovery CD
    - creating [19](#)
    - using to reimage [19](#)
  - reimaging the WLSE
    - locally [19](#)
    - remotely [20](#)
  - repository
    - browsing [13](#)
    - port for [1](#)
  - status, viewing [8](#)
  - updates
    - data preserved [15](#)
    - history, viewing [14](#)
    - installing, by using Web interface [12](#)
    - not allowed from pre-released version [8](#)
    - transferring to WLSE [38](#)
  - upgrading on a redundancy (high availability) cluster [38](#)
  - version, viewing
    - from Web interface [10](#)
    - using the CLI [63](#)
- spanning tree protocol

- configuring [94](#)
  - definition [10](#)
- specific settings, device
  - configuring [104](#)
  - exporting [48](#)
  - importing [46](#)
  - managing [46](#)
  - report [50](#)
  - viewing [49](#)
- splash screen, adding a message [44](#)
- SSH, definition [9](#)
- SSH access to WLSE
  - access control
    - displaying [59](#)
  - controlling [67](#)
  - enabling [68](#)
  - show ssh-server command [59](#)
  - show ssh-version command [60](#)
  - ssh-server accept command [67](#)
  - ssh-version command [68](#)
  - type, displaying [60](#)
  - version, displaying [60](#)
  - version, setting
    - using CLI [68](#)
    - using Web interface [19](#)
- ssh host command [67](#)
- SSH on access points
  - credentials, entering on WLSE [11](#)
  - port for IOS AP configuration [1](#)
- ssh-server accept command [67](#)
- ssh-version command [68](#)
- SSID
  - 802.11b/g, configuring [40](#)
  - definition [9](#)
  - report, displaying [71](#)
  - system-defined groups for [77](#)
- SSL
  - definition [10](#)
  - log, displaying [5](#)
  - web SSL access log, displaying [65](#)
- SSL certificate
  - certificate signed request, viewing [18](#)
  - for built-in AAA server [5](#)
  - mkcert CLI command [31](#)
  - signed, obtaining [18](#)
  - unsigned certificate, obtaining [31](#)
- STA, definition [10](#)
- startup configuration
  - assigning [40](#)
  - creating a template for [38](#)
- startup configuration, WLSE
  - configbackup.log file [5](#)
- STP
  - configuring [94](#)
  - definition [10](#)
- subnet, system-defined group for [77](#)
- summary report
  - access point, displaying [65](#)
  - router [80](#)
  - server [81](#)
  - switch [77](#)
- SWAN
  - configuring, using Deployment Wizard [1](#)
  - definition [10](#)
- switch
  - AP and bridge connected to report, displaying [78](#)
  - fault monitoring [1](#)
  - fault thresholds, setting [10](#)
  - summary report, displaying [77](#)
  - system-defined group for [77](#)
  - WLSM modules report, displaying [79](#)
- switch port
  - guidelines for detecting and suppressing [31](#)
  - locating and detecting [30](#)
  - viewing suppressed ports [32](#)
- syntax of commands, checking [2](#)
- syslog
  - displaying [60](#)

- faults
  - notification settings [60](#)
  - port for [1](#)
  - using for AAA server logging (WLSE express) [40](#)
- sysName
  - display of [10](#)
  - effect of single quote on display [10](#)
  - reverse DNS lookup, effect on display [47](#)
- system (WLSE)
  - configuration
    - displaying [48](#)
    - erasing [17](#)
  - date and time [12, 32](#)
  - information, viewing [15](#)
  - logs, displaying [15](#)
  - processes, managing [41](#)
  - rebooting
    - from the Web interface [7](#)
    - using the CLI [10](#)
  - shutting down
    - procedure for [10](#)
    - shutdown CLI command [66](#)
  - status, displaying [41](#)
  - storage usage, displaying [14](#)
  - system log, using [44](#)
- systemCheck.log [6](#)
- system time, setting
  - using CLI [12](#)
  - using Web interface [45](#)

---

## T

- TAC (Technical Assistance Center), obtaining information for [61](#)
- TACACS+ (for WLSE login)
  - authentication module [16](#)
  - definition [10](#)
- tarlog command [68](#)
- TCP/IP packet content, displaying [16](#)

- TCP Port Scan tool [49](#)
- TCP ports used by WLSE [1](#)
- Telnet
  - credentials for IOS access points, entering [11](#)
  - port for IOS AP configuration [1](#)
- Telnet/SSH services, configuring [69](#)
- Telnet access to WLSE
  - access from selected IP addresses, specifying [69](#)
  - enabling/disabling
    - using CLI [69](#)
    - using Web interface [19](#)
  - status, displaying [62](#)
- telnetenable command [69](#)
- templates
  - automatic configurations [38](#)
  - copying
    - Deployment Wizard [2](#)
    - IOS [3](#)
    - WLSM [2](#)
  - creating
    - Deployment Wizard [4, 2](#)
    - IOS [2](#)
    - WLSM [2](#)
  - deleting
    - Deployment Wizard [3](#)
    - IOS [4](#)
    - WLSM [3](#)
  - editing
    - IOS [3](#)
    - WLSM [3](#)
  - exporting
    - Deployment Wizard [4](#)
    - IOS [5](#)
    - WLSM [5](#)
  - for Deployment Wizard, defined [1](#)
  - for IOS configuration, defined [1](#)
  - for WLSM configuration, defined [1](#)
  - importing
    - IOS [4](#)

- WLSM [4](#)
  - using
    - [1](#)
- TFTP
  - definition [10](#)
  - ports used for firmware upgrade [2](#)
- tftp.log [6](#)
- TFTP process (on WLSE) [43](#)
- TFTP server, on WLSE Express
  - managing from Web interface [47](#)
  - tftpserver CLI command [70](#)
- tftpserver command [70](#)
- threshold, definition [10](#)
- time
  - browser time, setting [45](#)
  - display of, on WLSE [10](#)
  - server time discrepancy when scheduling jobs [11](#)
  - synchronizing to an NTP server [45](#)
- UTC
  - definition [11](#)
  - display of [10](#)
- timeout period
  - WLSE CLI [2](#)
  - WLSE web interface
    - default [13](#)
    - resetting, from Web interface [46](#)
    - resetting, using CLI [73](#)
- TKIP
  - counter measure invoked policy [78](#)
  - definition [10](#)
  - local MIC failures policy [76](#)
  - remote MIC failures policy [77](#)
  - replays detected policy [79](#)
- tomcat.log file [6](#)
- tomcat log, displaying
  - from Web interface [5](#)
  - using CLI [62](#)
- Tomcat process [43](#)
- tomcat process, failure of [40](#)
- traceroute
  - definition [10](#)
  - from CLI [71](#)
  - from Web interface [49](#)
- transmission statistics
  - displaying Ethernet report [92](#)
  - displaying RF [90](#)
- traps
  - notification settings [56](#)
  - received from APs, port for [2](#)
  - version supported [56](#)
- trending data
  - aggregation parameters [71](#)
  - data retention parameters [71](#)
- trend reports, using for capacity planning [85](#)
- trends, displaying [84](#)
  - client roaming statistics report [97](#)
  - Ethernet transmission statistics report [92](#)
  - group performance report, Ethernet utilization [86](#)
  - group performance report, RF utilization [86](#)
  - RF and Ethernet tabular report [93](#)
  - RF and Ethernet utilization graph [93](#)
  - RF transmission statistics report [90](#)
  - server response time graph report [96](#)
  - top n busiest clients report [94](#)
  - top n client MIC error rate report [95](#)
  - top n number of associations graph report [88](#)
  - top n number of associations tabular report [87](#)
  - top n percentage errors report [89](#)
- troubleshooting (WLSE)
  - diagnostics tools [40](#)
  - passwords, loss of [21](#)
  - process management [41](#)
  - recovery procedures [17](#)
- troubleshooting guide
  - displaying from online help [9](#)
  - locating on Cisco.com [15](#)
- typographical conventions
  - in command descriptions [3](#)

in this document [24](#)

## U

UDP ports used by WLSE [1](#)

undoing a job [23](#)

unknown radio, displaying [22](#)

Unmanaged folder (Managed Devices) [58](#)

unregistered client detection [60](#)

displaying faults [62](#)

enabling, disabling [61](#)

guidelines [53, 60](#)

reports [63](#)

understanding [60](#)

updateWLSE-x.x.x.log file [6](#)

upgrade

access point firmware [1](#)

WLSE software (by using the CLI) [10](#)

WLSE software (by using Web interface) [8](#)

WLSE software, data preserved [15](#)

usage report, AP [82](#)

user-defined

groups [80](#)

roles [51](#)

user guide

displaying from online help [9](#)

locating on Cisco.com [15](#)

username command [71](#)

users (WLSE)

authentication servers [17](#)

CLI access [53](#)

creating

using the CLI [3, 71](#)

using Web interface [53](#)

current users, listing [20](#)

deleting

from Web interface [56](#)

using the CLI [71](#)

home page, modifying [58](#)

last 10 logged in users, viewing [20](#)

last 10 logged in users. viewing [20](#)

modifying

using the CLI [71](#)

using the Web interface [53](#)

naming guidelines [1](#)

of internal AAA server (WLSE Express) [24](#)

roles

assigning to users [54](#)

managing [51](#)

username CLI command [71](#)

UTC

definition [11](#)

displayed on WLSE [10](#)

utilization

RF and Ethernet graph, displaying [93](#)

RF and Ethernet tabular report, displaying [93](#)

## V

version summary

group report, displaying [62](#)

VLAN

configuring [91](#)

definition [11](#)

group report, displaying [54](#)

per client report (group), displaying [55](#)

per client report (individual), displaying [55](#)

report, displaying [73](#)

VLAN ID, definition [11](#)

voice

bandwidth in use threshold, enabling [41](#)

QoS status [53](#)

status, viewing [53](#)

voice QoS status threshold, enabling [42](#)

## W

WDC, definition [11](#)

### WDS

access points [8](#)

and radio manager [8](#)

configuring

using a template [98](#)

using Deployment Wizard [1](#)

definition [11](#)

discovery through [28](#)

enhanced client tracking [20](#)

fault thresholds for [50](#)

infrastructure access point, definition [6](#)

registered APs report [12](#)

summary report [10](#)

system-defined groups for [79](#)

understanding [8](#)

WDS access points

understanding [8](#)

WDS device, definition [11](#)

### WLCCP

credentials, configuring manually [14](#)

port for [2](#)

### WLSM

understanding [8](#)

Web access log, displaying

from CLI (show webaccesslog command) [64](#)

from Web interface [5](#)

Web error log, displaying

from CLI (show weberrorlog command) [64](#)

from Web interface [5](#)

Web interface (WLSE)

browsers, configuring [4](#)

browsers, supported [4](#)

overview [4](#)

Web session timeout (WLSE)

default [13](#)

resetting from Web interface [46](#)

Web session timeout, WLSE

resetting, using the CLI [73](#)

Web SSL log, displaying [65](#)

webtimeout command [73](#)

WEP 802.11a, configuring [55](#)

WEP 802.11b/g, configuring [53](#)

WEP keys, definition [12](#)

WGB, definition [12](#)

WHISK port [1](#)

Windows server

as backup location [24](#)

as repository [11](#)

WINS, definition [12](#)

wireless client reports

access failure, displaying [42](#)

client detail, displaying [37](#)

client historical association, displaying [40](#)

client statistics, displaying [39](#)

displaying [37](#)

polling interval, setting [71](#)

voice client detail, displaying [44](#)

WirelessSvcMgr process [43](#)

WISPr, definition [12](#)

wizard

assisted site survey [17](#)

Deployment Wizard [2](#)

Discovery wizard [35](#)

WLCCP

credentials, adding from Deployment Wizard [6](#)

credentials, entering on WLSE [14](#)

definition [12](#)

discovery through [28](#)

WLSE

device limit, displaying [63](#)

memory

amount of displaying [63](#)

WLSE 1030 Express

built-in AAA server on [1](#)

documentation for [24](#)

- number of devices managed [64](#)
- redundancy, hardware requirements [30](#)
- WLSE 1130
  - redundancy, hardware requirements [30](#)
- WLSE 1130 series
  - Ethernet port labelling [13](#)
- wlseconfig command (do not use this command) [6](#)
- WLSEFaults process [43](#)
- WLSEIdleServer process (on WLSE) [43](#)
- WLSEjobvm process [43](#)
- WLSERepository process (on WLSE) [43](#)
- wlsestartup.ini file [3](#)
- WLSM
  - configuring
    - using Deployment Wizard [1](#)
    - using templates [1](#)
  - definition [12](#)
  - fault thresholds, setting [46](#)
  - group report, mobility ID [61](#)
  - mobility groups report, displaying [82](#)
  - mobility ID report, displaying [83](#)
  - modules report [79](#)
- WNM, definition [12](#)
- workgroup bridge, definition [12](#)
- WPA, definition [12](#)
- WPA-PSK Keys [51](#)

---

## X

- XML API, privileges in roles [51](#)