



Set Up a Catalyst Switch

[Home](#) > [Work With My Switches](#) > [Cisco Catalyst Switches](#) > Set Up a Catalyst Switch

Service Requests

[Open a service request](#)

[Update a service request](#)

Download and Install Cisco Network Assistant

Step 1: [Cisco SMB Support Assistant Site Survey](#)

Step 2: [Hardware Setup Procedure for the Catalyst Switch](#)
[Hardware Setup Procedure for the Catalyst 2955 Switch](#)

Step 3: Download and Install Cisco Network Assistant

[Introduction](#)

[Requirements](#)

[Download CNA](#)

[Next Step](#)

[Troubleshoot the Procedure](#)

[Related Information](#)

Step 4: [Configure the Catalyst Switch with Cisco Network Assistant](#)

Download PDF



[Step 3: Download and Install Cisco Network Assistant](#)



[Set Up a Catalyst Switch](#)

Feedback

Please rate this site:

++ + +/- - --

Suggestions for improvement:

Introduction

This document describes how to download and install Cisco Network Assistant (CNA), a PC-based application used to configure Catalyst switches.

Note: If you already have CNA on your computer, you need not do this procedure. CNA is located at **Start > Programs > Cisco Network Assistant > Cisco Network Assistant**.

[Back to Top](#)

If Cisco may contact you for more details or for future feedback opportunities, please enter your contact information:

Full

Name:

Email:

Requirements

To perform this procedure, you need a Windows PC connected to the Internet. The PC must have these minimum requirements:

- A PC with 80 MB of hard disk space
- 256 MB RAM for Windows (recommended)
- Windows 2000 or Windows XP with SP 1 Minimum

[Back to Top](#)

Download CNA

To download CNA, follow these steps:

1. Go to the [CNA home page](#).
2. Click the link for "Download Software" from the Technical Documentation & Tools box.

Technical Documentation & Tools

Review support information for [Cisco Network Assistant](#) in Technical Support & Documentation.

[General Information](#)
[Download Software](#)
[Install and Upgrade](#)

3. Click **Latest Cisco Network Assistant** in Software Download page.
4. When prompted, enter your SMB user name and password.



Enter Network Password

Please type your user name and password.

Site: tools.cisco.com

Realm: CCO

User Name:

Password:

Save this password in your password list

OK Cancel

Click **OK**.

You need to go through a series of tabs to download CNA. Follow these steps to download CNA:

Tools & Resources

Downloads


1 Select Device > 2 Select Software Type > 3 Select Software > 4 Download

1. On the Select Device tab, click **Lan Network Management > Cisco Network Assistant > Cisco Network Assistant Version 4.0**.

Select a Device

Find Device

[Expand all](#) | [Close all](#)



[Requires a service contract](#)

2. On the Select Software Type tab, click **Cisco Network Assistant**.
3. On the Select Software tab, click **Available Releases > 4 > 4.1**.



4. Click on the Network Assistant Installer executable file (.exe file) **cna.windows.k9.installer.4.1.en.exe**.

[Release Notes for release 4.1](#)

[cna-windows-k9-installer-4-1-fr.exe](#)

Published 30/Aug/2006

Network Assistant 4.1 French Installer

Size: 32397.9 KB

Minimum Memory: DRAM:-- Flash:--

[cna-windows-k9-installer-4-1-es.exe](#)

Published 30/Aug/2006

Network Assistant 4.1 Spanish Installer

Size: 32362.7 KB

Minimum Memory: DRAM:-- Flash:--

[cna-windows-k9-installer-4-1-en.exe](#)

Published 30/Aug/2006

Network Assistant 4.1 English Installer

Size: 32318.48 KB

Minimum Memory: DRAM:-- Flash:--

5. Verify the software image that you want to download, and click **Download**.
6. Read the Software Download Rules, and click **Agree**.
7. When prompted, enter your SMB user name and password again, and click **OK**.
8. When the File Download dialog box appears, click **Save** to download the executable to your desktop.
9. On your PC desktop, double-click the CNA Installer icon to run the installer. Follow the instructions to install CNA on your PC.

[Back to Top](#)

Next Step

After you have installed the CNA software, you can use it to configure your switch. Refer to [Configure a Catalyst Switch with Cisco Network Assistant](#).

[Back to Top](#)

Troubleshoot the Procedure

If you have problems with your login or with the CNA download process, contact the [SMB Technical Assistance Center \(SMB TAC\)](#) for assistance.

[Back to Top](#)

Related Information

- [Configure a Catalyst Switch with Cisco Network Assistant](#)
- [Site Survey](#)

