

# Cisco IOS™ 3600 Series 11.1 to 11.2 Upgrade Path

For Customers With SMARTnet Contracts

**Table 9:** 3600 Upgrade Path from 11.1 to 11.2 for Increased Functionality

		From: 11.1								
		IP	IP/IBM	IP/IPX	IP/IPX/IBM	IP/IPX/ IBM/ APPN	Desktop	Desktop/ IBM	Enterprise	Enterprise/ APPN
To: 112	IP	—	—	—	—	—	—	—	—	—
	IP Plus	FL36-P=	FL36-CS-C= and FL36-IBM-P=	—	—	—	—	—	—	—
	IP Plus 40	FL36-W=	FL36-CS-C= and FL36-IBM-P= and FL36-P-W=	—	—	—	—	—	—	—
	IP Plus 56	FL36-Y=	FL36-CS-C= and FL36-IBM-P= and FL36-P-Y=	—	—	—	—	—	—	—
	IP/IPX/IBM/ APPN	FL36-C-DS=	FL36-CS-DS= and FL36-APPN=	FL36-D-DS= and FL36-APPN=	FL36-APPN=	—	—	—	—	—
	IP/IPX/AT/DEC	FL36-C-B=	FL36-CS-B=	FL36-D-B=	FL36-DS-B=	FL36-DS-B=	—	—	—	—
	IP/IPX/AT/DEC Plus	FL36-C-B= and FL36-P=	FL36-CS-B= and FL36-IBM-P=	FL36-D-B= and FL36-P=	FL36-DS-B= and FL36-IBM-P=	FL36-DS-B= and FL36-IBM-P=	FL36-P=	FL36-BS-B= and FL36-IBM-P=	—	—

From: 11.1 (Continued)										
	IP	IP/IBM	IP/IPX	IP/IPX/IBM	IP/IPX/IBM/APPN	Desktop	Desktop/IBM	Enterprise	Enterprise/APPN	
To: 11.2 (Continued)	IP/IPX/AT/DEC Plus 40	FL36-C-B= and FL36-W=	FL36-CS-B= and FL36-IBM-P= and FL36-P=W=	FL36-D-B= and FL36-W=	FL36-DS-B= and FL36-IBM-P= and FL36-IBM-W=	FL36-DS-B= and FL36-IBM-P and FL36-P-W=	FL36-W=	FL36-BS-B= and FL36-IBM-P and FL36-P-W=	—	—
	IP/IPX/AT/DEC Plus 56	FL36-C-B= and FL36-Y=	FL36-CS-B= and FL36-IBM-P= and FL36-P=Y=	FL36-D-B= and FL36-Y=	FL36-DS-B= and FL36-IBM-P= and FL36-IBM-Y=	FL36-DS-B= and FL36-IBM-P= and FL36-P-Y=	FL36-Y=	FL36-BS-B= and FL36-IBM-P= and FL36-P-Y=	—	—
	Enterprise	FL36-C-A=	FL36-CS-A=	FL36-D-A=	FL36-DS-A=	FL36-DS-A=	FL36-B-A=	FL36-BS-A=	—	—
	Enterprise Plus	FL36-C-A= and FL36-P=	FL36-CS-A= and FL36-IBM-P=	FL36-D-A= and FL36-P=	FL36-DS-A= and FL36-IBM-P=	FL36-DS-A= and FL36-IBM-P=	FL36-B-A= and FL36-P=	FL36-BS-A= and FL36-IBM-P=	FL36-P=	—
	Enterprise Plus 40	FL36-C-A= and FL36-W=	FL36-CS-A= and FL36-IBM-P= and FL36-P-W=	FL36-D-A= and FL36-W=	FL36-DS-A= and FL36-IBM-P= and FL36-P-W=	FL36-DS-A= and FL36-IBM-P= and FL36-P-W=	FL36-B-A= and FL36-W=	FL36-BS-A= and FL36-IBM-P= and FL36-P-W=	FL36-W=	—
	Enterprise Plus 56	FL36-C-A= and FL36-Y=	FL36-CS-A= and FL36-IBM-P= and FL36-P-Y=	FL36-D-A= and FL36-Y=	FL36-DS-A= and FL36-IBM-P= and FL36-P-Y=	FL36-DS-A= and FL36-IBM-P= and FL36-P-Y=	FL36-B-A= and FL36-Y=	FL36-BS-A= and FL36-IBM-P= and FL36-P-Y=	FL36-Y=	—
	Enterprise/APPN Plus	FL36-C-A= and FL36-APPN= and FL36-P=	FL36-CS-A= and FL36-APPN= and FL36-IBM-P=	FL36-D-A= and FL-APPN= and FL36-P=	FL36-DS-A= and FL36-APPN= and FL36-IBM-P=	FL36-DS-A= and FL36-IBM-P=	FL36-B-A= and FL36-APPN= and FL36-P=	FL36-BS-A= and FL36-APPN=	FL36-APPN= and FL36-P=	FL36-P=
	Enterprise/APPN Plus 40	FL36-C-A= and FL36-APPN= and FL36-W=	FL36-CS-A= and FL36-APPN= and FL36-IBM-P= and FL36-P-W=	FL36-D-A= and FL-APPN= and FL36-W=	FL36-DS-A= and FL36-APPN= and FL36-IBM-W=	FL36-DS-A= and FL36-IBM-P and FL36-P-W=	FL36-B-A= and FL36-APPN= and FL36-W=	FL36-BS-A= and FL36-APPN= and FL36-IBM-P and FL36-P-W=	FL36-APPN= and FL36-W=	FL36-W=
Enterprise/APPN Plus 56	FL36-C-A= and FL36-APPN= and FL36-Y=	FL36-CS-A= and FL36-APPN= and FL36-IBM-P= and FL36-P-Y=	FL36-D-A= and FL-APPN= and FL36-Y=	FL36-DS-A= and FL36-APPN= and FL36-IBM-Y=	FL36-DS-A= and FL36-IBM-P= and FL36-P-Y=	FL36-B-A= and FL36-APPN= and FL36-Y=	FL36-BS-A= and FL36-APPN= and FL36-IBM-P= and FL36-P-Y=	FL36-APPN= and FL36-Y=	FL36-APPN= and FL36-Y=	

**Note:**

- “Plus” feature sets include NAT, IBM, MMP, and VPDN/L2F.

**Corporate Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 526-4100

**European Headquarters**

Cisco Systems Europe s.a.r.l.  
Parc Evolic, Batiment L1/L2  
16 Avenue du Quebec  
Villebon, BP 706  
91961 Courtaboeuf Cedex  
France  
<http://www-europe.cisco.com>  
Tel: 33 1 6918 61 00  
Fax: 33 1 6928 83 26

**Americas**

**Headquarters**  
Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-7660  
Fax: 408 527-0883

**Asia Headquarters**

Nihon Cisco Systems K.K.  
Fuji Building, 9th Floor  
3-2-3 Marunouchi  
Chiyoda-ku, Tokyo 100  
Japan  
<http://www.cisco.com>  
Tel: 81 3 5219 6250  
Fax: 81 3 5219 6001

**Cisco Systems has more than 200 offices in the following countries. Addresses, phone numbers, and fax numbers are listed on the Cisco Connection Online Web site at <http://www.cisco.com>.**

Argentina • Australia • Austria • Belgium • Brazil • Canada • Chile • China (PRC) • Colombia • Costa Rica • Czech Republic • Denmark • England • France • Germany • Greece • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico • The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Russia • Saudi Arabia • Scotland • Singapore • South Africa • Spain • Sweden • Switzerland • Taiwan, ROC • Thailand • Turkey • United Arab Emirates • United States • Venezuela

Copyright © 1997 Cisco Systems, Inc. All rights reserved. Printed in USA. AccessPath, AtmDirector, Cache Director System, CD-PAC, Cisco IOS, the Cisco IOS logo, CiscoLink, the Cisco Powered Network logo, ClickStart, ControlStream, Fast Step, FragmentFree, IGX, JumpStart, LAN<sup>2</sup>LAN Enterprise, LAN<sup>2</sup>LAN Remote Office, MICA, NetBeyond, NetFlow, Netsys Technologies, Packet, PIX, Point and Click Internetworking, RouteStream, SMARTnet, StrataSphere, StrataSphere BILLder, StrataSphere Connection Manager, StrataSphere Modeler, StrataSphere Optimizer, Stratum, StreamView, SwitchProbe, The Cell, TokenSwitch, TrafficDirector, VirtualStream, VlanDirector, Workgroup Director, Workgroup Stack, and XCI are trademarks; The Network Works. No Excuses. is a service mark; and BPX, Catalyst, Cisco, Cisco Systems, the Cisco Systems logo, EtherChannel, FastHub, FastPacket, ForeSight, IPX, LightStream, OptiClass, Phase/IP, StrataCom, and StrataView Plus are registered trademarks of Cisco Systems, Inc. in the U.S. and certain other countries. All other trademarks mentioned in this document are the property of their respective owners. 978R