

Cisco IOS™ 4000 Series 11.1 to 11.3 Upgrade Path

For Customers With SMARTnet Contracts

Table 12: 4000 Upgrade Path from 11.1 to 11.3 for Increased Functionality

		From: 11.1							
		IP	IP/IPX	IP/IPX/IBM	IP/IPX/IBM/ APPN	Desktop	Desktop/IBM	Enterprise	Enterprise/ APPN
To: 11.3	IP	—	—	—	—	—	—	—	—
	IP Plus	FL4x-P=	—	—	—	—	—	—	—
	IP Plus 40	FL4x-W=	—	—	—	—	—	—	—
	IP Plus 56	FL4x-Y=	—	—	—	—	—	—	—
	IP/IPX/AT/ DEC	FL4x-C-B=	FL4x-D-B=	FL4x-DS-B=	—	—	—	—	—
	IP/IPX/AT/ DEC Plus	FL4x-C-B= and FL4x-P=	FL4x-D-B= and FL4x-P=	FL4x-DS-B= and FL4x-IBM-P=	FL4x-DS-B= and FL4x-IBM-P=	FL4x-P=	FL4x-BS-B=	—	—
	Enterprise Plus	FL4x-C-A= and FL4x-P=	FL4x-D-A= and FL4x-P=	FL4x-DS-A= and FL4x-IBM-P=	FL4x-DS-A= and FL4x-IBM-P=	FL4x-B-A= and FL4x-P=	FL4x-BS-A= and FL4x-IBM-P=	FL4x-P=	—
	Enterprise Plus 40	FL4x-C-A= and FL4x-W=	FL4x-D-A= and FL4x-W=	FL4x-DS-A= and FL4x-IBM-P= and FL4x-P-W=	FL4x-DS-A= and FL4x-IBM-P= and FL4x-P-W=	FL4x-B-A= and FL4x-W=	FL4x-BS-A= and FL4x-IBM-P= and FL4x-P-W=	FL4x-W=	—
Enterprise Plus 56	FL4x-C-A= and FL4x-Y=	FL4x-D-A= and FL4x-Y=	FL4x-DS-A= and FL4x-IBM-P= and FL4x-P-Y=	FL4x-DS-A= and FL4x-IBM-P= and FL4x-P-Y=	FL4x-B-A= and FL4x-Y=	FL4x-BS-A= and FL4x-IBM-P= and FL4x-P-Y=	FL4x-Y=	—	

From: 11.1 (Continued)									
	IP	IP/IPX	IP/IPX/IBM	IP/IPX/IBM/ APPN	Desktop	Desktop/IBM	Enterprise	Enterprise/ APPN	
To: 11.3 (Continued)	Enterprise/ APPN Plus	FL4x-C-A= and FL4x-APPN= and FL4x-P=	FL4x-D-A= and FL4x-APPN= and FL4x-P=	FL4x-DS-A= and FL4x-APPN= and FL4x-IBM-P=	FL4x-DS-A= and FL4x-IBM-P=	FL4x-B-A= and FL4x-APPN= and FL4x-P=	FL4x-BS-A= and FL4x-APPN= and FL4x-P=	FL4x-APPN= and FL4x-P=	FL4x-P=
	Enterprise/ APPN Plus 40	FL4x-C-A= and FL4x-APPN= and FL4x-W=	FL4x-D-A= and FL4x-APPN= and FL4x-W=	FL4x-D-A= and FL4x-APPN= and FL4x-IBM-P= and FL4x-P-W=	FL4x-D-A= and FL4x-IBM-P= and FL4x-P-W=	FL4x-B-A= and FL4x-APPN= and FL4x-W=	FL4x-BS-A= and FL4x-APPN= and FL4x-IBM-P= and FL4x-P-W=	FL4x-APPN= and FL4x-W=	FL4x-W=
	Enterprise/ APPN Plus 56	FL4x-C-A= and FL4x-APPN= and FL4x-Y=	FL4x-D-A= and FL4x-APPN= and FL4x-Y=	FL4x-DS-A= and FL4x-APPN= and FL4x-IBM-P= and FL4x-P-Y=	FL4x-DS-A= and FL4x-IBM-P= and FL4x-P-Y=	FL4x-B-A= and FL4x-APPN= and FL4x-Y=	FL4x-BS-A= and FL4x-APPN= and FL4x-IBM-P= and FL4x-P-Y=	FL4x-APPN= and FL4x-Y=	FL4x-Y=

Notes:

- For the 4000 series, "Plus" feature sets include: NAT, IBM and MMP.
- For the 4500/4700 series, "Plus" feature sets include: NAT, ISL, LANE, IBM, AND MMP.



Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

European Headquarters

Cisco Systems Europe s.a.r.l.
Parc Evolic, Batiment L1/L2
16 Avenue du Quebec
Villebon, BP 706
91961 Courtaboeuf Cedex
France
<http://www-europe.cisco.com>
Tel: 33 1 6918 61 00
Fax: 33 1 6928 83 26

Americas

Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-7660
Fax: 408 527-0883

Asia Headquarters

Nihon Cisco Systems K.K.
Fuji Building, 9th Floor
3-2-3 Marunouchi
Chiyoda-ku, Tokyo 100
Japan
<http://www.cisco.com>
Tel: 81 3 5219 6250
Fax: 81 3 5219 6001

Cisco Systems has more than 200 offices in the following countries. Addresses, phone numbers, and fax numbers are listed on the Cisco Connection Online Web site at <http://www.cisco.com>.

Argentina • Australia • Austria • Belgium • Brazil • Canada • Chile • China (PRC) • Colombia • Costa Rica • Czech Republic • Denmark • England • France • Germany • Greece • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico • The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Russia • Saudi Arabia • Scotland • Singapore • South Africa • Spain • Sweden • Switzerland • Taiwan, ROC • Thailand • Turkey • United Arab Emirates • United States • Venezuela