



Cisco Nexus 3400-S Series NX-OS Command Reference (Show Commands), Release 9.2(2)

First Published: 2019-07-03

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

PREFACE

Preface	ixv
Audience	ixv
Documentation Conventions	ixv
Documentation Feedback	ixvi
Communications, Services, and Additional Information	ixvi

CHAPTER 1

Notice	1
Notice	2

PART I

All Show Commands	3
--------------------------	----------

CHAPTER 2

A Show Commands	5
show aaa accounting	6
show aaa authentication	7
show aaa authentication login	8
show aaa authentication login ascii-authentication	9
show aaa authentication login error-enable	10
show aaa authentication login invalid-username-log	11
show aaa authorization	12
show aaa bypass-user	13
show aaa groups	14
show aaa local user blocked	15
show aaa user default-role	16
show access-list	17
show access-list database	20
show access-list resource	21

show access-lists	23
show access-lists	28
show accounting log	30
show accounting log all	31
show accounting log last-index	32
show accounting log nvram	33
show accounting log nvram last-index	34
show accounting log nvram start-seqnum	35
show accounting log start-seqnum	36
show acl status	37
show amt process	38
show amt vrf all	40
show archive log config	41
show arp access-lists	42

CHAPTER 3**B Show Commands 45**

show background	47
show banner exec	48
show banner motd	49
show bash-shell	50
show bfd-app session status	51
show bfd addrmap	52
show bfd clients	53
show bfd discrimap	54
show bfd intfipmap	55
show bfd neighbors	56
show bfd scalar	60
show bfd session	61
show bgp	64
show bgp	70
show bgp	73
show bgp	81
show bgp	82
show bgp	88

show bgp	91
show bgp bmp server	93
show bgp community	96
show bgp convergence	102
show bgp convergence private	104
show bgp dampening dampened	105
show bgp dampening flap-statistics	111
show bgp dampening parameters	114
show bgp event-history	117
show bgp evi	118
show bgp extcommunity	120
show bgp l3vpn	126
show bgp neighbors	128
show bgp neighbors	134
show bgp neighbors commands	143
show bgp neighbors flap-statistics	145
show bgp neighbors paths	147
show bgp paths	149
show bgp peer-template	150
show bgp peer	154
show bgp prefix-list	156
show bgp private	161
show bgp private attr	162
show bgp private damp	163
show bgp private debug history	164
show bgp process	165
show bgp received-paths	170
show bgp regexp	176
show bgp self-originated	181
show bgp sessions	186
show bgp statistics	188
show bgp summary	189
show bgp summary	193
show boot	198

show boot auto-copy	199
show boot auto-copy list	200
show boot current	201
show boot mode	202
show boot order	203
show boot sup-1	204
show boot sup-2	205
show boot timings	206
show boot variables	207

CHAPTER 4**C Show Commands 209**

show callhome	212
show callhome destination-profile	214
show callhome destination-profile profile	215
show callhome destination-profile profile CiscoTAC-1	216
show callhome destination-profile profile full-txt-destination	217
show callhome destination-profile profile short-txt-destination	218
show callhome transport-email	219
show callhome transport	220
show callhome user-def-cmds	222
show catena	223
show catena analytics	224
show cdp	225
show cdp all	227
show cdp global	228
show cdp neighbors	229
show cdp neighbors detail	230
show cdp traffic interface2	232
show cfs application	233
show cfs lock	234
show cfs merge status	235
show cfs peers	237
show cfs regions	238
show cfs status	240

show checkpoint	241
show checkpoint	242
show checkpoint summary	243
show class-map	244
show class-map type control-plane	246
show class-map type network-qos	247
show cli alias	248
show cli dynamic-cmd	249
show cli dynamic integers	250
show cli dynamic strings	251
show cli history	252
show cli interface table	253
show cli list	254
show cli syntax	255
show cli variables	256
show clock	257
show config-profile	258
show config-profile applied	259
show config-replace log exec	260
show config-replace status	261
show config-template	262
show configuration session	263
show configuration session	264
show configuration session global-info	265
show configuration session status	266
show configuration session summary	267
show consistency-checker copp	268
show consistency-checker egress-xlate private-vlan	269
show consistency-checker forwarding ipv6 show forwarding ipv6 inconsistency	270
show consistency-checker forwarding show forwarding inconsistency	271
show consistency-checker forwarding single-route ipv4 vrf	273
show consistency-checker kim	274
show consistency-checker l2-tahoe module	275
show consistency-checker l2-tahoe switchport interface	276

show consistency-checker l2 multicast group source vlan	277
show consistency-checker l3-interface module	278
show consistency-checker l3 multicast group source vrf	279
show consistency-checker link-state fabric-ieth	280
show consistency-checker link-state module	281
show consistency-checker membership port-channels	282
show consistency-checker membership vlan	283
show consistency-checker pacl module	284
show consistency-checker pacl port-channels	285
show consistency-checker racl module	286
show consistency-checker racl port-channels	287
show consistency-checker stp-state vlan	288
show consistency-checker vacl	289
show consistency-checker vpc	290
show controller accounting log	291
show copp diff profile profile2	292
show copp profile	293
show copp status	298
show copyright	299
show cores	300
show crypto ca certificates	301
show crypto ca certificates	302
show crypto ca certstore	303
show crypto ca crl	304
show crypto ca remote-certstore	305
show crypto ca trustpoints	306
show crypto ca trustpool	307
show crypto ca trustpool last download status	308
show crypto ca trustpool policy	309
show crypto certificatemap	310
show crypto key mypubkey rsa	311
show crypto ssh-auth-map	312
show crypto ssh-auth-map	313
show cts	314

show current 315

CHAPTER 5**D Show Commands 317**

show dampening interface 318
show diagnostic bootup level 319
show diagnostic content module 320
show diagnostic description module test all 321
show diagnostic events 322
show diagnostic ondemand setting 323
show diagnostic result module 324
show diagnostic result module all 326
show diagnostic simulation module 328
show diagnostic status module 329
show diff rollback-patch 330
show dot1q-tunnel 331
show dot1q-tunnel interface 332
show dot1x 333
show dot1x all 334
show dot1x all details 336
show dot1x all statistics 338
show dot1x all summary 340
show dot1x interface 341
show dot1x interface client statistics 345
show dot1x interface client statistics address 347
show dummy 348

CHAPTER 6**E Show Commands 349**

show ecp 350
show elam report 352
show email 353
show encryption service stat 354
show environment 355
show errdisable detect 361
show errdisable flap 362

show evb	363
show evb hosts	364
show evb vsi	366
show event manager environment	368
show event manager event-types	369
show event manager events action-log	370
show event manager history events	371
show event manager policy-state	372
show event manager script system	373
show event manager system-policy	374

CHAPTER 7**F Show Commands 375**

show fabric database dc1	378
show fabric database dc1	379
show fabric database host	381
show fabric database host statistics	385
show fabric database host summary	388
show fabric database profile-map	389
show fabric database static-host	390
show fabric database statistics	391
show fabric forwarding host-db	393
show fabric forwarding ip local	395
show fabric forwarding ipv6 local	396
show fabric multicast	397
show fabric multicast event-history	399
show fabric multicast globals	400
show fabric multicast ipv4 l2 vni	401
show fabric multicast ipv4 rp	402
show fabric multicast statistics	403
show fabric multicast vrf	404
show fc2 bind	405
show fc2 classf	406
show fc2 exchange	408
show fc2 exchresp	410

show fc2 flogi	412
show fc2 nport	413
show fc2 plogi	415
show fc2 plogi_pwwn	417
show fc2 port brief	418
show fc2 port drops	421
show fc2 port state	424
show fc2 socket	426
show fc2 sockexch	427
show fc2 socknotify	428
show fc2 socknport	429
show fc2 vsan	430
show fedroplateny	431
show fcoe-npv issu-impact	432
show fcoe	433
show fcoe database	434
show fctimer	435
show fctimer D_S_TOV	436
show fctimer E_D_TOV	437
show fctimer F_S_TOV	438
show fctimer R_A_TOV	439
show fctimer last action status	440
show fctimer pending-diff	441
show fctimer pending	442
show fctimer session status	443
show fctimer status	444
show fctimer vsan	445
show feature-set	446
show feature-set services	447
show feature	448
show fhrp	449
show fhrp verbose	450
show file	452
show fips status	453

show flow cache	454
show flow cache	456
show flow exporter	458
show flow interface	460
show flow monitor	461
show flow record	462
show flow timeout	465
show flow tracer	466
show forwarding	467
show forwarding adjacency	468
show forwarding distribution clients	471
show forwarding distribution fib-state	472
show forwarding distribution ip igmp snooping	473
show forwarding distribution ipv6 multicast route	474
show forwarding distribution l2 multicast	476
show forwarding distribution lisp counters	478
show forwarding distribution lisp vrf enabled	479
show forwarding distribution multicast	480
show forwarding distribution multicast client-ack-db	481
show forwarding distribution multicast client	482
show forwarding distribution multicast download	483
show forwarding distribution multicast mfib	484
show forwarding distribution multicast outgoing-interface-list	485
show forwarding distribution multicast resp-ack-timer-msgs	486
show forwarding distribution multicast route	487
show forwarding distribution peer-id	489
show forwarding distribution trace	490
show forwarding ecmp	491
show forwarding ecmp recursive	493
show forwarding interfaces	496
show forwarding ipv6 adjacency	497
show forwarding ipv6 multicast route	499
show forwarding ipv6 route	501
show forwarding kvfib cache on	504

show forwarding l2 multicast	505
show forwarding l2vpn ipv6 multicast route	507
show forwarding l2vpn label vpls	508
show forwarding l2vpn label xconnect	509
show forwarding l2vpn multicast outgoing-interface-list	510
show forwarding l2vpn multicast route	511
show forwarding l2vpn service vpls	512
show forwarding l2vpn service xconnect	513
show forwarding l2vpn vlan	514
show forwarding multicast-sr loopback interface	515
show forwarding multicast outgoing-interface-list	516
show forwarding multicast route	517
show forwarding security group-tag	520
show forwarding security mac	522
show forwarding trace	524
show forwarding trace profile	525
show forwarding trace profile funcstats	526
show fte event	527
show fte exporter	528
show fte monitor	529
show fte record	530

CHAPTER 8
G Show Commands 531

show guestshell	532
-----------------	-----

CHAPTER 9
H Show Commands 535

show hardware	537
show hardware access-list lou resource threshold	539
show hardware access-list resource pooling	540
show hardware access-list team	541
show hardware capacity	542
show hardware capacity eobc	543
show hardware capacity fabric-utilization	544
show hardware capacity forwarding	545

show hardware capacity interface	546
show hardware capacity module	547
show hardware capacity power	549
show hardware feature-capability	550
show hardware flow aging	551
show hardware flow entry address type	552
show hardware flow ip	553
show hardware flow ipv6	554
show hardware flow l2	555
show hardware flow sampler	556
show hardware flow utilization	557
show hardware forwarding interface statistics mode	558
show hardware forwarding memory health detail	559
show hardware forwarding memory health summary	562
show hardware ip verify	564
show hardware profile buffer monitor show hardware profile buffer monitor internal	565
show hardware profile forwarding-mode	569
show hardware profile latency monitor sampling show hardware profile latency monitor	570
show hardware profile module	572
show hardware profile packet-drop	573
show hardware profile status	574
show hardware profile team region	576
show hardware qos afd profile	577
show hardware qos burst-detect max-records	578
show hardware qos eoq stats-class	579
show hardware qos include ipg	580
show hardware qos ing-pg-hdrm-reserve	581
show hardware qos ing-pg-no-min	582
show hardware qos ing-pg-share	583
show hardware qos min-buffer	584
show hardware qos ns-buffer-profile	585
show hardware qos ns-mcq3-alias	586
show hardware rate-limiter	587
show hardware rate-limiter	589

[show hardware rate-limiter span-egress](#) 591
[show hardware rl snmp class-id](#) 592
[show hardware rl snmp global class-id](#) 593
[show hardware rl snmp local snmp-index class-id](#) 594
[show hostname](#) 595
[show hosts](#) 596
[show hsrp](#) 598
[show hsrp anycast](#) 602
[show hsrp anycast interface vlan](#) 603
[show hsrp anycast remote-db](#) 604
[show hsrp anycast summary](#) 605
[show hsrp bfd-sessions](#) 606
[show hsrp bfd-sessions](#) 608
[show hsrp delay](#) 609
[show hsrp mgo](#) 610
[show hsrp summary](#) 611

CHAPTER 10
I Show Commands 613

[show icam entries acl module inst](#) 623
[show icam health](#) 625
[show icam itd](#) 626
[show icam prediction entries acl module inst](#) 627
[show icam prediction resource acl_team module inst](#) 629
[show icam prediction resource acl_team module inst trend](#) 631
[show icam prediction scale](#) 633
[show icam resource acl_team module inst](#) 635
[show icam scale](#) 638
[show ieth-header-decode](#) 641
[show imp client](#) 642
[show imp client sa](#) 643
[show inband-telemetry exporter](#) 644
[show inband-telemetry flow-profile](#) 645
[show inband-telemetry monitor](#) 646
[show inband-telemetry queue-profile](#) 647

show inband-telemetry record	648
show inband-telemetry sessions	649
show inband-telemetry watchlist	650
show incompatibility-all system	651
show incompatibility system	652
show install	653
show install all failed-standby	654
show install all failure-reason	655
show install all impact	656
show install all impact epld	657
show install all status	658
show install all time-stats	659
show install epld status	660
show install log	661
show install mode	662
show install packages	663
show install patches	664
show interface	665
show interface	685
show interface	690
show interface	695
show interface	703
show interface	707
show interface	711
show interface	713
show interface	719
show interface	721
show interface aggregate-counters	725
show interface aggregate-counters	728
show interface aggregate-counters	731
show interface bbcredit	734
show interface brief	735
show interface brief	743
show interface brief	744

show interface brief	746
show interface brief	747
show interface brief	749
show interface brief	750
show interface brief	751
show interface brief	752
show interface cable-diagnostics-tdr	753
show interface capabilities	754
show interface capabilities	756
show interface capabilities	758
show_interface	760
show interface counters	761
show interface counters	765
show interface counters	766
show interface counters	768
show interface counters	770
show interface counters	772
show interface counters	774
show interface counters	776
show interface counters brief	777
show interface counters brief	779
show interface counters detailed	781
show interface counters detailed	784
show interface counters detailed	796
show interface counters detailed	798
show interface counters detailed all	804
show interface counters detailed all	805
show interface counters detailed all	806
show interface counters detailed all	809
show interface counters detailed all	811
show interface counters detailed cached	819
show interface counters details	827
show interface counters details	828
show interface counters errors	832

show interface counters errors	833
show interface counters errors	835
show interface counters snmp	837
show interface counters snmp	839
show interface counters storm-control	841
show interface counters storm-control	842
show interface counters table	843
show interface counters trunk	844
show interface dampening	845
show interface debounce	846
show interface debounce	847
show interface description	848
show interface description	849
show interface description	850
show interface description	851
show interface description	852
show interface description	853
show interface description	854
show interface description	855
show interface detail-counters	856
show interface fcoe	860
show interface fec	861
show interface flowcontrol	862
show interface flowcontrol	863
show interface hardware-mappings	864
show interface mac-address	865
show interface mac-address	866
show interface priority-flow-control	867
show interface private-vlan mapping	868
show interface pruning	869
show interface snmp-ifindex	870
show interface status	871
show interface status	872
show interface status	873

show interface status	875
show interface status	876
show interface status	877
show interface status	878
show interface status err-disabled	879
show interface status err-disabled	880
show interface status err-vlans	881
show interface status err-vlans	882
show interface switchport	883
show interface switchport	885
show interface switchport backup	887
show interface transceiver	889
show interface transceiver	899
show interface transceiver	903
show interface trunk	911
show interface trunk	913
show interface trunk vsan	915
show interface trunk vsan	916
show interface trunk vsan	917
show interface untagged-cos	918
show interface vlan mapping	919
show inventory	920
show ip adjacency	921
show ip amt relay	924
show ip amt route	925
show ip amt tunnel	926
show ip arp	928
show ip arp anycast topo-info	930
show ip arp client	931
show ip arp controller-statistics	932
show ip arp esi	933
show ip arp inspection	934
show ip arp inspection interfaces	935
show ip arp inspection log	936

show ip arp inspection statistics	937
show ip arp inspection vlan	938
show ip arp multihoming-statistics	939
show ip arp off-list	941
show ip arp open-flow error-statistics	942
show ip arp statistics	944
show ip arp suppression-cache	948
show ip arp suppression topo-info	951
show ip arp tunnel-statistics	952
show ip arp vpc-statistics	954
show ip as-path-access-list	957
show ip client	958
show ip community-list	959
show ip debug	960
show ip dhcp global statistics	961
show ip dhcp option82 suboption info interface	963
show ip dhcp relay	964
show ip dhcp relay address	966
show ip dhcp relay information trusted-sources	967
show ip dhcp relay statistics	968
show ip dhcp snooping	972
show ip dhcp snooping binding	973
show ip dhcp snooping statistics	974
show ip dhcp status	975
show ip dns source-interface	976
show ip dns source-interface vrf all	977
show ip eigrp	978
show ip eigrp accounting	980
show ip eigrp event-history	982
show ip eigrp event-history bfd	983
show ip eigrp interfaces	984
show ip eigrp route-map statistics	986
show ip eigrp traffic	988
show ip extcommunity-list	990

show ip fib distribution	991
show ip fib distribution clients	992
show ip fib distribution mroute	993
show ip fib distribution multicast	995
show ip fib distribution multicast outgoing-interface-list	996
show ip fib distribution state	997
show ip fib mroute	998
show ip fib mroute	1000
show ip fib route	1002
show ip fib route	1005
show ip fib route recovered	1007
show ip ftp source-interface	1008
show ip ftp source-interface vrf all	1009
show ip http source-interface	1010
show ip http source-interface vrf all	1011
show ip igmp event-history	1012
show ip igmp groups	1013
show ip igmp interface	1015
show ip igmp local-groups	1019
show ip igmp policy statistics reports	1021
show ip igmp snooping	1022
show ip igmp snooping event-history	1024
show ip igmp snooping explicit-tracking	1025
show ip igmp snooping filter details	1027
show ip igmp snooping groups	1028
show ip igmp snooping lookup-mode	1031
show ip igmp snooping mac-oif	1032
show ip igmp snooping mrouter	1033
show ip igmp snooping pw vlan brief	1035
show ip igmp snooping querier	1036
show ip igmp snooping report statistics	1038
show ip igmp snooping statistics	1039
show ip igmp vrf all	1042
show ip interface	1043

show ip lisp	1048
show ip lisp data-cache	1049
show ip lisp locator-hash	1050
show ip lisp map-cache	1051
show ip lisp statistics	1052
show ip lisp translate-cache	1053
show ip load-sharing	1054
show ip local policy	1055
show ip logging	1056
show ip mbgp	1057
show ip mbgp	1058
show ip mbgp community	1060
show ip mbgp dampening	1061
show ip mbgp extcommunity	1062
show ip mbgp flap-statistics	1063
show ip mbgp neighbors	1064
show ip mbgp nexthop-database	1066
show ip mbgp nexthop	1067
show ip mbgp prefix-list	1068
show ip mbgp received-paths	1069
show ip mroute	1070
show ip msdp count	1074
show ip msdp event-history	1075
show ip msdp mesh-group	1076
show ip msdp peer	1077
show ip msdp policy statistics sa-policy in	1080
show ip msdp rpf	1082
show ip msdp sa	1083
show ip msdp sources	1085
show ip msdp statistics	1086
show ip msdp summary	1088
show ip nat-alias	1090
show ip nat max	1091
show ip nat statistics	1092

show ip nat timeout	1095
show ip nat translations	1096
show ip ospf	1098
show ip ospf border-routers	1103
show ip ospf database	1105
show ip ospf database database-summary	1108
show ip ospf database detail	1110
show ip ospf event-history	1116
show ip ospf event-history detail	1118
show ip ospf interface	1119
show ip ospf interface brief	1122
show ip ospf lsa-content-changed-list	1124
show ip ospf neighbors	1126
show ip ospf neighbors detail	1128
show ip ospf neighbors summary	1131
show ip ospf policy statistics	1133
show ip ospf request-list	1135
show ip ospf retransmission-list	1137
show ip ospf route	1139
show ip ospf route summary	1141
show ip ospf sham-links	1143
show ip ospf statistics	1147
show ip ospf summary-address	1151
show ip ospf traffic	1152
show ip ospf virtual-links	1156
show ip ospf virtual-links brief	1160
show ip pim config-sanity	1161
show ip pim df	1163
show ip pim event-history	1165
show ip pim fabric info	1166
show ip pim fabric legacy-vlans	1167
show ip pim group-range	1168
show ip pim host-proxy	1169
show ip pim interface	1170

show ip pim mdt	1174
show ip pim mdt bgp	1176
show ip pim mdt history interval	1177
show ip pim mdt receive	1178
show ip pim mdt send	1179
show ip pim neighbor	1180
show ip pim oif-list	1181
show ip pim policy statistics	1183
show ip pim policy statistics jp	1185
show ip pim route	1186
show ip pim rp-hash	1190
show ip pim rp	1191
show ip pim statistics	1194
show ip pim vrf	1196
show ip ping source-interface	1197
show ip ping source-interface vrf all	1198
show ip policy	1199
show ip prefix-list	1200
show ip process	1201
show ip rip	1203
show ip rip interface	1205
show ip rip neighbor	1207
show ip rip policy statistics redistribute	1209
show ip rip route	1211
show ip rip statistics	1213
show ip route	1215
show ip sla application	1218
show ip sla configuration	1219
show ip sla enhanced-history collection-statistics	1222
show ip sla enhanced-history distribution-statistics	1226
show ip sla group schedule	1227
show ip sla history	1228
show ip sla reaction-configuration	1230
show ip sla reaction-trigger	1231

show ip sla responder	1232
show ip sla statistics	1234
show ip sla twamp connection detail	1240
show ip sla twamp connection requests	1241
show ip sla twamp session	1242
show ip sla twamp standards	1243
show ip ssh source-interface	1244
show ip ssh source-interface vrf all	1245
show ip static-route	1246
show ip tcp mss	1248
show ip telnet source-interface	1249
show ip telnet source-interface vrf all	1250
show ip tftp source-interface	1251
show ip tftp source-interface vrf all	1252
show ip traceroute source-interface	1253
show ip traceroute source-interface vrf all	1254
show ip traffic	1255
show ip udp relay	1262
show ip udp relay interface	1263
show ip udp relay object-group	1264
show ip verify source	1265
show ipv6 adjacency	1266
show ipv6 amt tunnel	1269
show ipv6 bgp	1271
show ipv6 bgp	1272
show ipv6 bgp	1273
show ipv6 bgp community	1274
show ipv6 bgp dampening	1275
show ipv6 bgp extcommunity	1276
show ipv6 bgp flap-statistics	1277
show ipv6 bgp neighbors	1278
show ipv6 bgp nexthop-database	1279
show ipv6 bgp nexthop	1280
show ipv6 bgp received-paths	1281

show ipv6 bgp regexp	1282
show ipv6 bgp summary	1283
show ipv6 client	1284
show ipv6 dhcp guard policy	1286
show ipv6 dhcp relay	1287
show ipv6 dhcp relay statistics	1288
show ipv6 eigrp route-map statistics	1292
show ipv6 fragments	1294
show ipv6 icmp	1295
show ipv6 icmp global traffic	1297
show ipv6 icmp interface	1300
show ipv6 icmp off-list	1306
show ipv6 icmp vaddr	1307
show ipv6 icmp vpc-statistics	1311
show ipv6 interface	1314
show ipv6 lisp data-cache	1319
show ipv6 local policy	1320
show ipv6 mld groups	1321
show ipv6 mld local-groups	1323
show ipv6 mroute	1324
show ipv6 mtu	1327
show ipv6 nd ra dns search-list	1329
show ipv6 nd ra dns server	1330
show ipv6 nd rguard policy	1332
show ipv6 neighbor binding	1333
show ipv6 neighbor binding mac	1334
show ipv6 neighbor static	1335
show ipv6 pim df	1336
show ipv6 pim event-history	1338
show ipv6 pim fabric info	1339
show ipv6 pim fabric legacy-vlans	1340
show ipv6 pim group-range	1341
show ipv6 pim interface show ipv6 pim interface	1342
show ipv6 pim neighbor	1345

show ipv6 pim oif-list	1346
show ipv6 pim policy statistics jp	1348
show ipv6 pim route	1349
show ipv6 pim rp-hash	1351
show ipv6 pim rp	1352
show ipv6 pim statistics	1354
show ipv6 pim vrf	1356
show ipv6 policy	1357
show ipv6 prefix-list	1358
show ipv6 process	1359
show ipv6 rguard statistics	1361
show ipv6 rip policy statistics redistribute	1362
show ipv6 route	1364
show ipv6 routers	1367
show ipv6 snooping capture-policy	1369
show ipv6 snooping counters vlan	1370
show ipv6 snooping events	1372
show ipv6 snooping features	1373
show ipv6 snooping messages	1374
show ipv6 snooping policies	1375
show ipv6 snooping policy	1376
show ipv6 snooping pss database	1378
show ipv6 static-route	1379
show ipv6 traffic	1381
show isis	1384
show isis adjacency	1388
show isis csnp	1391
show isis database	1393
show isis distribute-ls	1398
show isis event-history	1402
show isis hostname	1403
show isis interface	1404
show isis ipv6 redistribute route	1409
show isis ipv6 route-map statistics	1411

show isis ipv6 route	1413
show isis ipv6 summary-address	1417
show isis lslib	1419
show isis lsp free-list	1421
show isis mesh-group	1422
show isis non tlv overflow-list	1423
show isis redistribute route	1424
show isis route-map statistics	1426
show isis route	1428
show isis rrm	1432
show isis spf-log	1434
show isis srm	1436
show isis ssn	1437
show isis statistics	1438
show isis summary-address	1439
show isis topology	1441
show isis traffic	1443
show itd	1445
show itd	1449
show itd session device-group	1453
show itd statistics	1454
show itd vrf	1456

CHAPTER 11**K Show Commands** 1457

show key chain	1458
show key chain mode decrypt	1459
show keystore	1460
show kim inconsistency	1461
show kubernetes containers	1462

CHAPTER 12**L Show Commands** 1463

show l2 mroute	1469
show l2 multicast ftag	1471
show l2 multicast trees	1472

show l2 route	1474
show l2fwder l2rib info	1476
show l2fwder statistics	1477
show l2rib clients	1478
show l2rib producers	1479
show l2rib registrations	1481
show l2route evpn ead all	1482
show l2route evpn ethernet-segment esi	1483
show l2route evpn fl all	1484
show l2route evpn fl evi	1485
show l2route evpn imet all	1486
show l2route evpn imet evi	1487
show l2route evpn mac-ip all	1488
show l2route evpn mac-ip evi	1490
show l2route evpn mac all	1492
show l2route evpn mac evi	1494
show l2route evpn path-list all	1496
show l2route evpn startup-route all	1497
show l2route evpn startup-route evi	1498
show l2route fl topology	1499
show l2route peerid	1500
show l2route summary	1501
show l2route topology	1502
show l2route topology	1504
show l2route topology	1506
show lacp counters	1508
show lacp interface	1509
show lacp issu-impact	1512
show lacp neighbor	1513
show lacp port-channel	1514
show lacp system-identifier	1515
show ldap-search-map	1516
show ldap-server	1517
show ldap-server groups	1518

show ldap-server statistics	1520
show license	1522
show license brief	1523
show license default	1524
show license feature package mapping	1525
show license file	1526
show license host-id	1527
show license tech support	1528
show license usage	1529
show line	1530
show line console	1531
show line console connected	1532
show line console user-input-string	1533
show lisp ddt	1534
show lisp ddt queue	1535
show lisp ddt referral-cache	1536
show lisp dynamic-eid	1537
show lisp elp	1538
show lisp negative-prefix	1539
show lisp proxy-itr	1540
show lisp site	1541
show lisp site instance-id	1542
show lldp all	1543
show lldp dcba interface	1544
show lldp entry	1546
show lldp interface	1548
show lldp neighbors	1550
show lldp neighbors detail	1552
show lldp neighbors system-detail	1554
show lldp portid-subtype	1555
show lldp timers	1556
show lldp tlv-select	1557
show lldp traffic	1558
show lldp traffic interface	1559

show locator-led status	1560
show logging	1561
show logging console	1562
show logging info	1563
show logging ip access-list cache	1565
show logging ip access-list status	1567
show logging last	1568
show logging level	1569
show logging level	1571
show logging level aaa	1572
show logging level acllog	1573
show logging level aclmgr	1574
show logging level adbm	1575
show logging level adjmgr	1576
show logging level amt	1577
show logging level arp	1578
show logging level ascii-cfg	1579
show logging level assoc_mgr	1580
show logging level backup	1581
show logging level bfd	1582
show logging level bgp	1583
show logging level bloggerd	1584
show logging level bootvar	1585
show logging level callhome	1586
show logging level capability	1587
show logging level catena	1588
show logging level cdp	1589
show logging level cert_enroll	1590
show logging level cfs	1591
show logging level clis	1592
show logging level clk_mgr	1593
show logging level confcheck	1594
show logging level copp	1595
show logging level core	1596

show logging level cts	1597
show logging level dhcp_snoop	1598
show logging level diagnostic diagclient	1599
show logging level diagnostic diagmgr	1600
show logging level dot1x	1601
show logging level ecp	1602
show logging level eigrp	1603
show logging level eltm	1604
show logging level epp	1605
show logging level ethdstats	1606
show logging level ethpm	1607
show logging level evb	1608
show logging level evmc	1609
show logging level evmed	1610
show logging level evms	1611
show logging level fabric forwarding	1612
show logging level fcoe_mgr	1613
show logging level feature-mgr	1614
show logging level fs-daemon	1615
show logging level gpixm	1616
show logging level hardware-telemetry	1617
show logging level hsrp	1618
show logging level icam	1619
show logging level im	1620
show logging level imp	1621
show logging level interface-vlan	1622
show logging level ip igmp	1623
show logging level ip msdp	1624
show logging level ip sla responder	1625
show logging level ip sla sender	1626
show logging level ip sla twamp-server	1627
show logging level ipconf	1628
show logging level ipfib	1629
show logging level ipqos	1630

show logging level ipv6 icmp	1631
show logging level iscm	1632
show logging level iscm	1633
show logging level isis	1634
show logging level keystore	1635
show logging level l2fm	1636
show logging level l3vm	1637
show logging level lacp	1638
show logging level ldap	1639
show logging level license	1640
show logging level lim	1641
show logging level lisp	1642
show logging level lldp	1643
show logging level m2rib	1644
show logging level mfdm	1645
show logging level mfwd	1646
show logging level mmode	1647
show logging level module	1648
show logging level monitor	1649
show logging level mvsh	1650
show logging level nat	1651
show logging level nbm	1652
show logging level netstack	1653
show logging level nfm	1654
show logging level ngoam	1655
show logging level npv	1656
show logging level ntp	1657
show logging level nxsdk	1658
show logging level openflow	1659
show logging level ospf	1660
show logging level ospfv3	1661
show logging level pfstat	1662
show logging level pim	1663
show logging level pim	1664

show logging level pixm	1665
show logging level pktmgr	1666
show logging level platform	1667
show logging level plbm	1668
show logging level plcmgr	1669
show logging level pltfm_config	1670
show logging level plugin	1671
show logging level poap	1672
show logging level poed	1673
show logging level port-channel	1674
show logging level port-profile	1675
show logging level port-resources	1676
show logging level port-security	1677
show logging level port	1678
show logging level private-vlan	1679
show logging level ptp	1680
show logging level radius	1681
show logging level res_mgr	1682
show logging level rip	1683
show logging level routing ipv6 multicast	1684
show logging level routing multicast	1685
show logging level rpm	1686
show logging level rsvp	1687
show logging level sal	1688
show logging level san-port-channel	1689
show logging level san-port-channel	1690
show logging level scheduler	1691
show logging level security	1692
show logging level session-mgr	1693
show logging level sflow	1694
show logging level smartc	1695
show logging level smm	1696
show logging level snmpd	1697
show logging level snmpmib_proc	1698

show logging level spanning-tree	1699
show logging level spm	1700
show logging level stripcl	1701
show logging level sysmgr	1702
show logging level tacacs	1703
show logging level track	1704
show logging level tunnel	1705
show logging level u2rib	1706
show logging level u6rib	1707
show logging level udld	1708
show logging level ufdm	1709
show logging level urib	1710
show logging level vdc_mgr	1711
show logging level virtual-service	1712
show logging level vlan_mgr	1713
show logging level vmm	1714
show logging level vmtracker	1715
show logging level vpc	1716
show logging level vrrp-cfg	1717
show logging level vrrp-eng	1718
show logging level vrrpv3	1719
show logging level vsan	1720
show logging level vshd	1721
show logging level vtp	1722
show logging level wwn	1723
show logging level xbar	1724
show logging logfile	1725
show logging logfile duration	1726
show logging logfile last-index	1727
show logging logfile start-seqn	1728
show logging logfile start-time	1729
show logging loopback	1730
show logging module	1731
show logging monitor	1732

show logging nvram	1733
show logging onboard	1734
show logging onboard	1735
show logging onboard kernel-trace	1738
show logging origin-id	1739
show logging pending-diff	1740
show logging pending	1741
show logging rate-limit	1742
show logging server	1743
show logging session status	1744
show logging source-interface	1745
show logging status	1746
show logging timestamp	1747
show login on-failure log	1748
show login on-successful log	1749

CHAPTER 13**M Show Commands 1751**

show mac-list	1752
show mac address-table	1753
show mac address-table	1755
show mac address-table aging-time	1757
show mac address-table count	1758
show mac address-table count es	1760
show mac address-table learning-mode	1761
show mac address-table limit	1762
show mac address-table loop-detect	1763
show mac address-table multicast	1764
show mac address-table notification mac-move	1765
show maintenance maint-delay	1766
show maintenance on-reload reset-reasons	1767
show maintenance profile	1768
show maintenance snapshot-delay	1769
show maintenance timeout	1770
show module	1771

show module bandwidth-fairness	1774
show module uptime	1775
show monitor	1776
show monitor session	1777
show mvpn bgp mdt	1780
show mvpn mdt encap	1781
show mvpn mdt route	1782
show mvr	1783
show mvr groups	1784
show mvr interface	1785
show mvr members	1786
show mvr members count	1787
show mvr members vlan	1788
show mvr receiver-ports	1789
show mvr source-ports	1790

CHAPTER 14
N Show Commands 1791

show nbm defaults	1793
show nbm flow-policy	1794
show nbm flows	1795
show nbm flows bandwidth	1798
show nbm flows statistics	1799
show nbm flows summary	1800
show nbm host-policy all	1801
show nbm host-policy applied	1802
show nbm host-policy applied receiver	1803
show nbm interface bandwidth	1804
show ngoam interface statistics	1805
show ngoam loopback	1806
show ngoam pathtrace	1808
show ngoam probe	1812
show ngoam traceroute statistics	1814
show ngoam xconnect session	1816
show npv external-interface-usage	1818

show npv flogi-table	1819
show npv status	1820
show npv traffic-map	1822
show ntp access-groups	1823
show ntp authentication-keys	1824
show ntp authentication-status	1825
show ntp information	1826
show ntp logging-status	1827
show ntp peer-status	1828
show ntp peers	1829
show ntp rts-update	1830
show ntp session status	1831
show ntp source-interface	1832
show ntp source	1833
show ntp statistics	1834
show ntp status	1837
show ntp trusted-keys	1838
show nxapi-server logs	1839
show nxapi	1840
show nxapi syntax	1841

CHAPTER 15
O Show Commands 1843

show object-group	1844
show openflow hardware capabilities	1845
show openflow switch	1846
show openflow switch flows	1847
show ospfv3	1848
show ospfv3 border-routers	1853
show ospfv3 database	1855
show ospfv3 database database-summary	1858
show ospfv3 database detail	1860
show ospfv3 event-history	1865
show ospfv3 event-history detail	1866
show ospfv3 interface	1867

show ospfv3 interface brief	1870
show ospfv3 memory	1872
show ospfv3 neighbors	1874
show ospfv3 neighbors detail	1876
show ospfv3 neighbors summary	1879
show ospfv3 policy statistics	1881
show ospfv3 request-list	1883
show ospfv3 retransmission-list	1885
show ospfv3 route	1887
show ospfv3 route summary	1889
show ospfv3 statistics	1891
show ospfv3 summary-address	1895
show ospfv3 traffic	1896
show ospfv3 virtual-links	1900
show ospfv3 virtual-links brief	1904

CHAPTER 16**P Show Commands 1905**

show param-list	1908
show password secure-mode	1909
show password strength-check	1910
show pending	1911
show plb	1912
show plb analytics	1916
show plb vrf	1918
show pmap-int-br interface br	1919
show pmap-int	1920
show policy-map	1921
show policy-map interface control-plane	1925
show policy-map system	1928
show policy-map type control-plane	1932
show policy-map type network-qos	1935
show port-channel capacity	1937
show port-channel compatibility-parameters	1938
show port-channel database	1939

show port-channel fast-convergence	1941
show port-channel load-balance	1942
show port-channel load-balance forwarding-path1 interface src-interface	1943
show port-channel load-balance forwarding-path interface	1945
show port-channel load-balance hardware forwarding-path interface source	1947
show port-channel rbh-distribution	1949
show port-channel scale-fanout	1950
show port-channel summary	1951
show port-channel traffic	1952
show port-channel usage	1953
show port-license	1954
show port-profile	1955
show port-profile brief	1957
show port-profile expand-interface	1958
show port-profile sync-status	1959
show port-profile usage	1960
show port-security	1961
show port-security address	1962
show port-security address interface	1963
show port-security interface	1964
show port-security state	1965
show port naming	1966
show postcard-telemetry exporter	1967
show postcard-telemetry flow-profile	1968
show postcard-telemetry monitor	1969
show postcard-telemetry queue-profile	1970
show postcard-telemetry sessions	1971
show postcard-telemetry watchlist	1972
show power inline	1973
show power inline	1974
show power inline police	1975
show power inline priority	1976
show privilege	1977
show processes	1978

show processes cpu 1979
show processes cpu history 1980
show processes cpu history data 1981
show processes cpu module 1982
show processes log 1983
show processes log details 1984
show processes log pid 1985
show processes log vdc-all 1986
show processes memory 1987
show processes memory physical 1988
show processes memory shared 1989
show processes vdc 1992
show processes vdc cpu 1993
show processes vdc log 1994
show processes vdc log details 1995
show processes vdc log pid 1996
show processes vdc memory 1997
show processes version 1998
show pss debug 1999
show ptp brief 2000
show ptp clock 2001
show ptp clock foreign-masters record 2003
show ptp corrections 2004
show ptp cost 2005
show ptp counters interface 2006
show ptp delay summary 2007
show ptp domain data 2008
show ptp interface domain 2009
show ptp packet-trace 2010
show ptp parent 2011
show ptp port interface 2012
show ptp time-property 2014

show qos dcbxp incompatibility interface 2016
show qos dcbxp info 2017
show qos dcbxp interface 2018
show qos shared-policer 2020
show queuing 2022
show queuing burst-detect 2024
show queuing pfc-queue 2025
show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex 2027
show queuing pfc-queue snmp ifIndex 2029
show queuing tabular 2030
show queuing tah-pfc-queue 2032

CHAPTER 18**R Show Commands 2033**

show radius-cfs 2037
show radius-server 2038
show radius-server 2039
show radius-server directed-request 2041
show radius-server groups 2042
show radius-server sorted 2043
show radius-server statistics 2044
show radius status 2046
show redundancy status 2047
show regexp 2049
show reload 2050
show resource 2051
show rmon 2052
show role 2054
show role feature-group 2056
show role feature 2057
show rollback log exec 2058
show rollback status 2059
show route-map 2060
show route-map pbr-statistics 2061
show router-guard 2062

show routing-context	2063
show routing	2064
show routing clients	2067
show routing event-history	2069
show routing hash	2071
show routing hidden-nh	2074
show routing ipv6	2075
show routing ipv6 clients	2078
show routing ipv6 event-history	2082
show routing ipv6 hash	2083
show routing ipv6 hidden-nh	2085
show routing ipv6 memory estimate	2086
show routing ipv6 memory statistics	2088
show routing ipv6 multicast	2090
show routing ipv6 multicast clients	2093
show routing ipv6 multicast event-history	2096
show routing ipv6 multicast memory estimate	2097
show routing ipv6 nexthop info	2099
show routing ipv6 nhlfe	2100
show routing ipv6 recursive-next-hop	2102
show routing memory estimate	2103
show routing memory statistics	2105
show routing multicast	2107
show routing multicast clients	2111
show routing multicast event-history	2115
show routing multicast lisp encap	2116
show routing multicast mdt encapsulation	2117
show routing multicast memory estimate	2118
show routing multicast sr	2120
show routing nhlfe	2122
show routing recursive-next-hop	2124
show routing unresolved-next-hop	2126
show running-config	2127
show running-config aaa	2128

show running-config acllog	2129
show running-config aclmgr	2130
show running-config aclmgr active	2131
show running-config adjmgr	2132
show running-config all	2133
show running-config arp	2134
show running-config assoc	2135
show running-config backup	2136
show running-config bfd	2137
show running-config bgp	2138
show running-config bloggerd	2139
show running-config callhome	2140
show running-config catena	2141
show running-config cdp	2142
show running-config cert-enroll	2143
show running-config cfs	2144
show running-config clock_manager	2145
show running-config config-profile	2146
show running-config config-template	2147
show running-config controller	2148
show running-config copp	2149
show running-config dhcp	2150
show running-config diagnostic	2151
show running-config diff	2152
show running-config dot1x	2153
show running-config ecp	2154
show running-config eem	2155
show running-config eigrp	2156
show running-config eltm	2157
show running-config evb	2158
show running-config exclude	2159
show running-config expand-port-profile	2160
show running-config fabric forwarding	2161
show running-config fabric multicast	2162

show running-config fcoe_mgr	2163
show running-config hardware-telemetry	2164
show running-config hsrp	2165
show running-config icam	2166
show running-config icmpv6	2167
show running-config igmp	2168
show running-config imp	2169
show running-config interface	2170
show running-config interface	2171
show running-config ip	2172
show running-config ipqos	2173
show running-config ipqos active	2174
show running-config ipv6	2175
show running-config isis	2176
show running-config l3vm	2177
show running-config ldap	2178
show running-config license	2179
show running-config lisp	2180
show running-config lldp	2181
show running-config mmode	2182
show running-config monitor	2183
show running-config msdp	2184
show running-config nat	2185
show running-config nbm	2186
show running-config ngoam	2187
show running-config ntp	2188
show running-config nv overlay	2189
show running-config nxsdk	2190
show running-config openflow	2191
show running-config ospf	2192
show running-config ospfv3	2193
show running-config param-list	2194
show running-config pim	2195
show running-config pim6	2196

show running-config plb-services	2197
show running-config poe	2198
show running-config port-profile	2199
show running-config port-security	2200
show running-config ptp	2201
show running-config radius	2202
show running-config rip	2203
show running-config routing ip multicast	2204
show running-config routing ipv6 multicast	2205
show running-config rpm	2206
show running-config rsvp	2207
show running-config section	2208
show running-config security	2209
show running-config services	2210
show running-config services	2211
show running-config sflow	2212
show running-config sla responder	2213
show running-config sla sender	2214
show running-config sla twamp-server	2215
show running-config smart-channel	2216
show running-config snmp	2217
show running-config spanning-tree	2218
show running-config srte	2219
show running-config switch	2220
show running-config tacacs	2221
show running-config track	2222
show running-config uddl	2223
show running-config vdc-all	2224
show running-config vdc	2225
show running-config virtual-service	2226
show running-config vlan	2227
show running-config vlan	2228
show running-config vlan	2229
show running-config vmtracker	2230

show running-config vpc	2231
show running-config vrf	2232
show running-config vrf default	2233
show running-config vrrp	2234
show running-config vrrpv3	2235
show running-config vshd	2236
show running-config vtp	2237
show running-config wwnm	2238

CHAPTER 19
S Show Commands 2239

show san-port-channel compatibility-parameters	2244
show san-port-channel consistency	2245
show san-port-channel consistency detail	2246
show san-port-channel database	2248
show san-port-channel summary	2250
show san-port-channel usage	2251
show scheduler config	2252
show scheduler job	2254
show scheduler logfile	2255
show scheduler schedule	2256
show sflow	2257
show sflow statistics	2258
show smart-channel	2259
show snapshots	2263
show snapshots compare	2264
show snapshots compare ipv4routes	2266
show snapshots compare ipv6routes	2267
show snapshots compare summary	2268
show snapshots dump	2269
show snapshots dump	2270
show snapshots sections	2271
show snmp	2272
show snmp community	2275
show snmp context	2276

show snmp engineID	2277
show snmp group	2278
show snmp host	2279
show snmp mib igmpCacheTable	2280
show snmp mib igmpInterfaceTable	2281
show snmp nms-statistics	2283
show snmp oid-statistics	2284
show snmp roledebug	2285
show snmp sessions	2286
show snmp source-interface	2287
show snmp trap	2288
show snmp user	2289
show sockets client	2290
show sockets connection	2298
show sockets local-port-range	2301
show sockets ns-port-kiosk	2302
show sockets statistics	2303
show sockets tcp keychain binding	2313
show spanning-tree	2314
show spanning-tree blockedports	2318
show spanning-tree bridge	2319
show spanning-tree inconsistentports	2321
show spanning-tree interface	2322
show spanning-tree interface	2323
show spanning-tree issu-impact	2326
show spanning-tree mst	2327
show spanning-tree mst configuration	2332
show spanning-tree mst configuration digest	2333
show spanning-tree mst interface	2334
show spanning-tree pathcost method	2337
show spanning-tree root	2338
show spanning-tree summary	2340
show spanning-tree summary totals	2343
show sprom	2345

show srte pce ipv4 peer	2354
show srte policy	2355
show srte policy fh	2357
show ssh key	2358
show ssh server	2359
show ssx details	2360
show ssx exporter	2361
show ssx monitor	2362
show ssx record	2363
show startup-config	2364
show startup-config aaa	2365
show startup-config acllog	2366
show startup-config aclmgr	2367
show startup-config adjmgr	2368
show startup-config arp	2369
show startup-config assoc	2370
show startup-config backup	2371
show startup-config bfd	2372
show startup-config bgp	2373
show startup-config bloggerd	2374
show startup-config callhome	2375
show startup-config catena	2376
show startup-config cdp	2377
show startup-config cert-enroll	2378
show startup-config cfs	2379
show startup-config config-profile	2380
show startup-config copp	2381
show startup-config dhcp	2382
show startup-config diagnostic	2383
show startup-config dot1x	2384
show startup-config ecp	2385
show startup-config eem	2386
show startup-config eigrp	2387
show startup-config eltm	2388

show startup-config evb	2389
show startup-config exclude	2390
show startup-config expand-port-profile	2391
show startup-config fabric forwarding	2392
show startup-config fabric multicast	2393
show startup-config fcoe_mgr	2394
show startup-config hardware-telemetry	2395
show startup-config hsrp	2396
show startup-config icam	2397
show startup-config icmpv6	2398
show startup-config igmp	2399
show startup-config imp	2400
show startup-config interface	2401
show startup-config interface	2402
show startup-config ip	2403
show startup-config ipqos	2404
show startup-config ipv6	2405
show startup-config isis	2406
show startup-config l3vm	2407
show startup-config ldap	2408
show startup-config license	2409
show startup-config lisp	2410
show startup-config lldp	2411
show startup-config log	2412
show startup-config mmode	2413
show startup-config monitor	2414
show startup-config msdp	2415
show startup-config nat	2416
show startup-config nbm	2417
show startup-config ngoam	2418
show startup-config ntp	2419
show startup-config nv overlay	2420
show startup-config nxsdk	2421
show startup-config openflow	2422

show startup-config ospf	2423
show startup-config ospfv3	2424
show startup-config param-list	2425
show startup-config pim	2426
show startup-config pim6	2427
show startup-config plb-services	2428
show startup-config poe	2429
show startup-config port-profile	2430
show startup-config port-security	2431
show startup-config ptp	2432
show startup-config radius	2433
show startup-config rip	2434
show startup-config routing ip multicast	2435
show startup-config routing ipv6 multicast	2436
show startup-config rpm	2437
show startup-config rsvp	2438
show startup-config security	2439
show startup-config services	2440
show startup-config sflow	2441
show startup-config sla responder	2442
show startup-config sla sender	2443
show startup-config sla twamp-server	2444
show startup-config smart-channel	2445
show startup-config snmp	2446
show startup-config srte	2447
show startup-config switch	2448
show startup-config tacacs	2449
show startup-config track	2450
show startup-config udld	2451
show startup-config vdc-all	2452
show startup-config vdc	2453
show startup-config virtual-service	2454
show startup-config vlan	2455
show startup-config vlan	2456

show startup-config vmtracker	2457
show startup-config vpc	2458
show startup-config vrf	2459
show startup-config vrf default	2460
show startup-config vrrpv3	2461
show startup-config vshd	2462
show startup-config vtp	2463
show startup-config wwnm	2464
show summary	2465
show sup-monitor drops session	2466
show switch-profile	2467
show switch-profile	2469
show switch-profile buffer	2470
show switch-profile peer	2471
show switch-profile status	2472
show switch-scope controller	2474
show switching-mode	2475
show switching-mode fabric-speed	2476
show system acl	2477
show system auto-collect tech-support	2478
show system boottime	2479
show system clis event-history	2480
show system config reload-pending	2481
show system cores	2482
show system default switchport	2483
show system error-id	2484
show system exception-info	2485
show system fabric-mode	2486
show system fast-reload stabilization-timer	2487
show system image-verification	2488
show system inband queuing statistics	2489
show system inband queuing status	2491
show system login	2492
show system login failures	2493

show system memory-thresholds	2494
show system mode	2495
show system poap	2496
show system pss shrink status	2497
show system redundancy ha status	2498
show system redundancy status	2499
show system reset-reason	2500
show system reset-reason	2501
show system reset-reason module	2502
show system resources	2503
show system resources	2504
show system resources module	2505
show system resources module all	2506
show system routing mode	2507
show system security	2508
show system simulate fan-presence	2509
show system standby manual-boot	2510
show system switch-mode	2511
show system uptime	2512
show system verify bios flash	2513
show system vlan reserved	2514

CHAPTER 20**T Show Commands 2515**

show table-map	2521
show tacacs-server	2522
show tacacs-server	2523
show tacacs-server directed-request	2524
show tacacs-server groups	2525
show tacacs-server sorted	2526
show tacacs-server statistics	2527
show tech-support	2529
show tech-support aaa	2530
show tech-support acmgrp	2531
show tech-support acmgrp compressed	2532

show tech-support aclqos	2533
show tech-support aclqos compressed	2534
show tech-support adjmgr	2535
show tech-support all-binary	2536
show tech-support all	2537
show tech-support analytics	2538
show tech-support arp	2539
show tech-support ascii-cfg	2540
show tech-support assoc_mgr	2541
show tech-support backup	2542
show tech-support bcm	2543
show tech-support bfd	2544
show tech-support bgp	2545
show tech-support biosd	2546
show tech-support bloggerd-all	2547
show tech-support bloggerd	2548
show tech-support bootvar	2549
show tech-support brief	2550
show tech-support callhome	2551
show tech-support cdp	2552
show tech-support cert-enroll	2553
show tech-support cfs	2554
show tech-support cli	2555
show tech-support clis	2556
show tech-support clock_manager	2557
show tech-support commands	2558
show tech-support controller	2559
show tech-support copp	2560
show tech-support dcbx	2561
show tech-support details	2562
show tech-support dhclient	2563
show tech-support dhcp	2564
show tech-support dme	2565
show tech-support dot1x	2566

show tech-support ecp	2567
show tech-support eem	2568
show tech-support eigrp	2569
show tech-support eltm	2570
show tech-support ethpm	2571
show tech-support ethport	2572
show tech-support evb	2573
show tech-support fabric forwarding	2574
show tech-support fabric multicast	2575
show tech-support fast-reload	2576
show tech-support fc2	2577
show tech-support fcoe	2578
show tech-support fips	2579
show tech-support forwarding l2 multicast	2580
show tech-support forwarding l2 multicast vdc-all	2581
show tech-support forwarding l2 unicast	2582
show tech-support forwarding l3 multicast	2583
show tech-support forwarding l3 multicast detail vdc-all	2584
show tech-support forwarding l3 multicast detail	2585
show tech-support forwarding l3 multicast vdc-all	2586
show tech-support forwarding l3 unicast	2587
show tech-support forwarding l3 unicast detail	2588
show tech-support forwarding l3 unicast detail vdc-all	2589
show tech-support forwarding l3 unicast vdc-all	2590
show tech-support forwarding multicast	2591
show tech-support gold	2592
show tech-support gpixm	2593
show tech-support ha	2594
show tech-support ha module	2595
show tech-support ha standby	2596
show tech-support hardware-telemetry	2597
show tech-support hsrp	2598
show tech-support hsrp brief	2599
show tech-support icam	2600

show tech-support icmpv6	2601
show tech-support im	2602
show tech-support imp	2603
show tech-support inband counters	2604
show tech-support include-time	2605
show tech-support install	2606
show tech-support interface-vlan	2607
show tech-support ip	2608
show tech-support ip igmp	2609
show tech-support ip igmp snooping	2610
show tech-support ip msdp	2611
show tech-support ip pim	2612
show tech-support ipqos	2613
show tech-support ipv6	2614
show tech-support ipv6 mld	2615
show tech-support ipv6 multicast	2616
show tech-support ipv6 pim	2617
show tech-support isis	2618
show tech-support issu	2619
show tech-support kstack	2620
show tech-support l2	2621
show tech-support l2fm	2622
show tech-support l2fm clients	2623
show tech-support l2fm detail	2624
show tech-support l2fm l2dbg	2625
show tech-support l2fm l2dbg	2626
show tech-support l2rib	2627
show tech-support l3vm	2628
show tech-support l3vpn	2629
show tech-support lacp	2630
show tech-support ldap	2631
show tech-support license	2632
show tech-support lim	2633
show tech-support lisp	2634

show tech-support lldp	2635
show tech-support logging	2636
show tech-support m2rib	2637
show tech-support mfw	2638
show tech-support mmode	2639
show tech-support module	2640
show tech-support module all	2641
show tech-support monitor	2642
show tech-support monitor erspan	2643
show tech-support monitorc-all	2644
show tech-support multicast-vxlan-evpn	2645
show tech-support multicast	2646
show tech-support mvpn	2647
show tech-support nat	2648
show tech-support nbm	2649
show tech-support netstack	2650
show tech-support netstack detail	2651
show tech-support ngoam	2652
show tech-support npacl	2653
show tech-support npv	2654
show tech-support ns	2655
show tech-support ntp	2656
show tech-support nxapi	2657
show tech-support nxsdk	2658
show tech-support object-store	2659
show tech-support openflow	2660
show tech-support ospf	2661
show tech-support ospfv3	2662
show tech-support page	2663
show tech-support patch	2664
show tech-support pbr	2665
show tech-support pfstat	2666
show tech-support pixm-all	2667
show tech-support pixm	2668

show tech-support pixmc-all	2669
show tech-support pktmgr	2670
show tech-support platform-sdk	2671
show tech-support platform	2672
show tech-support platform	2673
show tech-support plb-services	2674
show tech-support plcmgr	2675
show tech-support pltfm-config	2676
show tech-support poe	2677
show tech-support port-channel	2678
show tech-support port-client-all	2679
show tech-support port-profile	2680
show tech-support port-security	2681
show tech-support port	2682
show tech-support private-vlan	2683
show tech-support ptp	2684
show tech-support radius	2685
show tech-support rip	2686
show tech-support routing	2687
show tech-support routing ipv6	2688
show tech-support routing ipv6 multicast	2689
show tech-support routing multicast	2690
show tech-support rpm	2691
show tech-support sal	2692
show tech-support san-port-channel	2693
show tech-support san	2694
show tech-support satmgr	2695
show tech-support security	2696
show tech-support services	2697
show tech-support session-mgr	2698
show tech-support sflow	2699
show tech-support single-gericho	2700
show tech-support sksd	2701
show tech-support sla responder	2702

show tech-support sla sender	2703
show tech-support sla twamp-server	2704
show tech-support smartc	2705
show tech-support smm	2706
show tech-support snmp	2707
show tech-support sockets	2708
show tech-support spm	2709
show tech-support srte	2710
show tech-support statsclient	2711
show tech-support stp	2712
show tech-support sup-filesys	2713
show tech-support sysmgr	2714
show tech-support tacacs	2715
show tech-support track	2716
show tech-support tunnel	2717
show tech-support u2rib	2718
show tech-support udld	2719
show tech-support usd-all	2720
show tech-support vdc	2721
show tech-support virtual-service	2722
show tech-support vlan	2723
show tech-support vmtracker	2724
show tech-support vpc	2725
show tech-support vrrp	2726
show tech-support vrrp brief	2727
show tech-support vrrpv3	2728
show tech-support vsan	2729
show tech-support vshd	2730
show tech-support vtp	2731
show tech-support vvlan	2732
show tech-support xbar	2733
show tech-support xml	2734
show tech-support xos	2735
show telnet server	2736

show terminal 2737
show terminal output xml version 2738
show time-range 2739
show time-stamp running-config last-changed 2741
show track 2742
show track brief 2744
show troubleshoot l2 mac vlan 2746
show troubleshoot l3 ipv4 vrf 2747
show trunk protocol 2748
show ttag brief 2749
show ttag brief 2750

CHAPTER 21**U Show Commands 2751**

show udld 2752
show udld global 2754
show udld neighbors 2755
show user-account 2756
show username keypair 2757
show userpassphrase 2758
show users 2759

CHAPTER 22**V Show Commands 2761**

show vdc 2763
show vdc current-vdc 2765
show vdc fcoe-vlan-range 2766
show vdc resource 2767
show vdc resource 2768
show vdc resource template 2769
show version 2770
show version epld 2772
show version image 2773
show version module 2774
show version module epld 2775
show virtual-service 2776

[show virtual-service storage pool list](#) 2778

[show virtual-service tech-support](#) 2779

[show virtual-service utilization name](#) 2780

[show virtual-service version](#) 2781

[show vlan](#) 2782

[show vlan access-list](#) 2784

[show vlan access-map](#) 2788

[show vlan all-ports](#) 2789

[show vlan counters](#) 2790

[show vlan dot1Q tag native](#) 2791

[show vlan fcoe](#) 2792

[show vlan filter](#) 2793

[show vlan id](#) 2794

[show vlan id counters](#) 2796

[show vlan id vn-segment](#) 2798

[show vlan name](#) 2799

[show vlan private-vlan](#) 2801

[show vlan private-vlan type](#) 2802

[show vlan xbrief](#) 2803

[show vlan xsummary](#) 2804

[show vmtracker](#) 2805

[show vmtracker certificate](#) 2806

[show vmtracker fabric auto-config](#) 2807

[show vmtracker status](#) 2808

[show vpc](#) 2809

[show vpc](#) 2810

[show vpc consistency-parameters](#) 2813

[show vpc consistency-parameters vlans](#) 2814

[show vpc orphan-ports](#) 2815

[show vpc peer-keepalive](#) 2816

[show vpc role](#) 2817

[show vpc statistics peer-keepalive](#) 2818

[show vpc statistics vpc](#) 2819

[show vrf](#) 2820

show vrf	2822
show vrrp	2823
show vrrp bfd-sessions	2826
show vrrpv3	2827
show vrrs client	2831
show vrrs pathway	2832
show vrrs pathway address	2833
show vrrs server	2834
show vrrs tag	2835
show vsan	2836
show vsan membership	2837
show vsan membership interface	2838
show vsan usage	2839
show vtp counters	2840
show vtp interface	2841
show vtp password	2842
show vtp status	2843

CHAPTER 23**W Show Commands** 2845

show wred-queue qos-group-map	2846
show wrr-queue qos-group-map	2847
show wrr unicast-bandwidth	2848
show wwn status	2849
show wwn switch	2850
show wwn test	2851
show wwn vsan-wwn	2853

CHAPTER 24**X Show Commands** 2855

show	2856
show xml server logging configuration	2857
show xml server status	2858

PART II**XML Support** 2859

CHAPTER 25	Commands with XML/JSON Support	2861
	XML Support for Show Commands	2862



Preface

This preface includes the following sections:

- [Audience, on page lxxv](#)
- [Documentation Conventions, on page lxxv](#)
- [Documentation Feedback, on page lxxvi](#)
- [Communications, Services, and Additional Information, on page lxxvi](#)

Audience

This publication is for network administrators who install, configure, and maintain Cisco Nexus switches.

Documentation Conventions

Command descriptions use the following conventions:

Convention	Description
bold	Bold text indicates the commands and keywords that you enter literally as shown.
<i>Italic</i>	Italic text indicates arguments for which the user supplies the values.
[x]	Square brackets enclose an optional element (keyword or argument).
[x y]	Square brackets enclosing keywords or arguments separated by a vertical bar indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a vertical bar indicate a required choice.
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
variable	Indicates a variable for which you supply values, in context where italics cannot be used.

Convention	Description
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Examples use the following conventions:

Convention	Description
<code>screen font</code>	Terminal sessions and information the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
<>	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to . We appreciate your feedback.

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



Notice

- [Notice, on page 2](#)

Notice



Warning

This document should be used only as a glossary reference for possible commands. The listing of a command in this document does not guarantee that the command is available or supported for your platform or application.

The command information in this reference document is auto-generated from the NX-OS source code. While we attempt to manually remove unsupported, deprecated, or internal-use commands, such commands may occasionally appear in this document. Also, with the large variety of hardware platform combinations using NX-OS software, some listed commands may not be applicable or recommended for a specific platform. Platform-based dependency information is not provided in this command reference.

We strongly encourage you to refer to the configuration guides for appropriate commands to configure and operate a feature. Command limitations, restrictions, and recommendations are documented only in the configuration guides. When in doubt, please consult your Cisco representative.



PART I

All Show Commands

- [A Show Commands, on page 5](#)
- [B Show Commands, on page 45](#)
- [C Show Commands, on page 209](#)
- [D Show Commands, on page 317](#)
- [E Show Commands, on page 349](#)
- [F Show Commands, on page 375](#)
- [G Show Commands, on page 531](#)
- [H Show Commands, on page 535](#)
- [I Show Commands, on page 613](#)
- [K Show Commands, on page 1457](#)
- [L Show Commands, on page 1463](#)
- [M Show Commands, on page 1751](#)
- [N Show Commands, on page 1791](#)
- [O Show Commands, on page 1843](#)
- [P Show Commands, on page 1905](#)
- [Q Show Commands, on page 2015](#)
- [R Show Commands, on page 2033](#)
- [S Show Commands, on page 2239](#)
- [T Show Commands, on page 2515](#)
- [U Show Commands, on page 2751](#)
- [V Show Commands, on page 2761](#)
- [W Show Commands, on page 2845](#)
- [X Show Commands, on page 2855](#)



A Show Commands

- [show aaa accounting](#), on page 6
- [show aaa authentication](#), on page 7
- [show aaa authentication login](#), on page 8
- [show aaa authentication login ascii-authentication](#), on page 9
- [show aaa authentication login error-enable](#), on page 10
- [show aaa authentication login invalid-username-log](#), on page 11
- [show aaa authorization](#), on page 12
- [show aaa bypass-user](#), on page 13
- [show aaa groups](#), on page 14
- [show aaa local user blocked](#), on page 15
- [show aaa user default-role](#), on page 16
- [show access-list](#), on page 17
- [show access-list database](#), on page 20
- [show access-list resource](#), on page 21
- [show access-lists](#), on page 23
- [show access-lists](#), on page 28
- [show accounting log](#), on page 30
- [show accounting log all](#), on page 31
- [show accounting log last-index](#), on page 32
- [show accounting log nvram](#), on page 33
- [show accounting log nvram last-index](#), on page 34
- [show accounting log nvram start-seqnum](#), on page 35
- [show accounting log start-seqnum](#), on page 36
- [show acl status](#), on page 37
- [show amt process](#), on page 38
- [show amt vrf all](#), on page 40
- [show archive log config](#), on page 41
- [show arp access-lists](#), on page 42

show aaa accounting

```
show aaa accounting [ __readonly__ [ TABLE_acctMethods <service> <methods> ] ]
```

Syntax Description

show	Show running system information
aaa	Show aaa information
accounting	Show accounting configuration
__readonly__	(Optional)
TABLE_acctMethods	(Optional)
<i>service</i>	(Optional) service type
<i>methods</i>	(Optional) Accounting methods configured for the application

Command Mode

- /exec

show aaa authentication

show aaa authentication [*__readonly__* [*TABLE_AuthenMethods* <service> <method>]]

Syntax Description

<i>show</i>	Show running system information
<i>aaa</i>	Show aaa information
<i>authentication</i>	Show authentication configuration
<i>__readonly__</i>	(Optional)
<i>TABLE_AuthenMethods</i>	(Optional)
<i>service</i>	(Optional) Service for which authentication is needed
<i>method</i>	(Optional) Authentication method used for the service

Command Mode

- /exec

show aaa authentication login

```
show aaa authentication login { mschap | mschapv2 | chap } [ __readonly__ [ <mschap_status> ] [
<mschapv2_status> ] [ <chap_status> ] ]
```

Syntax Description

show	Show running system information
aaa	Show aaa information
authentication	Show authentication configuration
login	Show authentication login error message configuration
mschap	Show authentication login MSCHAP enable configuration
mschapv2	Show authentication login MSCHAP V2 enable configuration
chap	Show authentication login CHAP enable configuration
<i>__readonly__</i>	(Optional)
<i>mschap_status</i>	(Optional) mschap enabled or disabled
<i>mschapv2_status</i>	(Optional) mschapv2 enabled or disabled
<i>chap_status</i>	(Optional) chap enabled or disabled

Command Mode

- /exec

show aaa authentication login ascii-authentication

```
show aaa authentication login ascii-authentication [ __readonly__ { <ascii_authen_status> } ]
```

Syntax Description

show	Show running system information
aaa	Show aaa information
authentication	Show authentication configuration
login	Show authentication login message configuration
ascii-authentication	Show ascii-authentication configuration
<i>__readonly__</i>	(Optional)
<i>ascii_authen_status</i>	(Optional) ascii authentication status

Command Mode

- /exec

show aaa authentication login error-enable

show aaa authentication login error-enable [__readonly__ [<status>]]

Syntax Description

show	Show running system information
aaa	Show aaa information
authentication	Show authentication configuration
login	Show authentication login error message configuration
error-enable	Show authentication login error message enable configuration
__readonly__	(Optional)
<i>status</i>	(Optional) login error-enable enabled or disabled

Command Mode

- /exec

show aaa authentication login invalid-username-log

```
show aaa authentication login invalid-username-log [ __readonly__ [ <status> ] ]
```

Syntax Description

show	Show running system information
aaa	Show aaa information
authentication	Show authentication configuration
login	Show authentication login message configuration
invalid-username-log	Show invalid username log configuration
<i>__readonly__</i>	(Optional)
<i>status</i>	(Optional) login invalid-username-log enabled or disabled

Command Mode

- /exec

show aaa authorization

```
show aaa authorization [ all ] [ __readonly__ [ <pki_ssh_cert_author> <pki_ssh_pubkey_author> ] [
TABLE_cmd_methods <appl_subtype> <cmd_type> <methods> ] [ TABLE_app_methods <appl> <methods>
] ]
```

Syntax Description

show	Show running system information
aaa	Show aaa information
authorization	Show authorization configuration
all	(Optional) Show all(include defaults configurations) authorization info
__readonly__	(Optional)
<i>pki_ssh_cert_author</i>	(Optional)
<i>pki_ssh_pubkey_author</i>	(Optional)
TABLE_cmd_methods	(Optional) table containing command authorization methods
<i>appl_subtype</i>	(Optional)
<i>cmd_type</i>	(Optional)
<i>methods</i>	(Optional)
TABLE_app_methods	(Optional) table containing application authorization methods
<i>appl</i>	(Optional)
<i>methods</i>	(Optional)

Command Mode

- /exec

show aaa bypass-user

```
show aaa bypass-user [ <s0> ] [ __readonly__ [ <num_bypass_users> ] [ TABLE_bypassUsers <username>
<account> <author> ] ]
```

Syntax Description

show	Show running system information
aaa	Show aaa information
bypass-user	Show bypass user information
<i>s0</i>	(Optional) Enter the username
<i>__readonly__</i>	(Optional)
<i>num_bypass_users</i>	(Optional) Number of bypass users configured
TABLE_bypassUsers	(Optional)
<i>username</i>	(Optional) Username
<i>account</i>	(Optional) Accounting Bypass
<i>author</i>	(Optional) Authorization bypass

Command Mode

- /exec

show aaa groups

show aaa groups [__readonly__ { TABLE_groups <group> }]

Syntax Description

show	Show running system information
aaa	Show aaa information
groups	Show configured groups
__readonly__	(Optional)
TABLE_groups	(Optional) Table showing aaa groups
<i>group</i>	(Optional) Name of the group

Command Mode

- /exec

show aaa local user blocked

```
show aaa local user blocked [ __readonly__ { TABLE_sessions <u_name> <u_state> } ]
```

Syntax Description

show	Show running system information
aaa	Configure aaa functions
local	Local username
user	Local system user
blocked	Display Blocked users
<i>__readonly__</i>	(Optional)
<i>TABLE_sessions</i>	(Optional) aaa local users blocked table
<i>u_name</i>	(Optional) Name of the user
<i>u_state</i>	(Optional) State of the user

Command Mode

- /exec

show aaa user default-role

show aaa user default-role [__readonly__ { default_role_status <udr_status> }]

Syntax Description

show	Show running system information
aaa	Show aaa information
user	Remotely authenticated user
default-role	Default role assigned by aaa-admin for remote authentication
__readonly__	(Optional)
default_role_status	(Optional) user default role status
<i>udr_status</i>	(Optional) Status of user default role

Command Mode

- /exec

show access-list

```
show { system internal | hardware } access-list { summary | [ vdc <vdc_id> ] { [ interface <if_name> | vlan
<vlan_id> | inband table <table> ] [ { input | output } { config | { { entries | merge } [ detail ] } | statistics |
l4ops | redirect | sampler } ] } } [ module <module> ] [ __readonly__ <type> <feature> <ply_id> <src_ip>
<src_mask> <dst_ip> <dst_mask> <proto> <l4ops> <action> <mac> <cos> <vlan> <l2_proto> <ethertype>
[ TABLE_vdc <vdc-no> <vdc-type> <dir> <policy-type> <policy-id> <policy-name> ] [ TABLE_instance
<inst> [ TABLE_tcam_resource_usage <tcam-no> <lbl> <hw-lbl-id> <bank> ] [ TABLE_class <class-type>
<policies> <netflow-profile> <netflow-deny-profile> <tcam-entries> ] <l4-protocol-cam-entries>
<mac-etype-proto-cam-entries> <lous> <tcp-flags-table-entries> <adjacency-entries> ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
internal	Commands for internal use
hardware	Show hardware information
access-list	Access Control List
summary	summary
vdc	(Optional) vdc id
<i>vdc_id</i>	(Optional) vdc_id
interface	(Optional) interface name
<i>if_name</i>	(Optional) display access list for the interface
vlan	(Optional) vlan_id
<i>vlan_id</i>	(Optional) vlan_id
inband	(Optional) inband interface
table	(Optional) vrf table number
<i>table</i>	(Optional) vrf table number
input	(Optional) input/ingress policies
output	(Optional) output/egress policies
config	(Optional) parsed policy software database
entries	(Optional) tcam entries
statistics	(Optional) aggregate statistics
l4ops	(Optional) l4 operations information

redirect	(Optional) redirect resource information
sampler	(Optional) with sampler details
merge	(Optional) tcam entries merge information
detail	(Optional) detailed information
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
<i>__readonly__</i>	(Optional)
<i>type</i>	(Optional) policy type eg: ACL, QOS
<i>feature</i>	(Optional) feature type eg: RACL, VACL
<i>plcy_id</i>	(Optional) policy id
<i>src_ip</i>	(Optional) src ipv4 address
<i>src_mask</i>	(Optional) src mask
<i>dst_ip</i>	(Optional) dst ipv4 address
<i>dst_mask</i>	(Optional) dst mask
<i>proto</i>	(Optional) protocol eg: TCP, UDP ...
<i>l4ops</i>	(Optional) layer 4 operations
<i>action</i>	(Optional) action
<i>mac</i>	(Optional) mac address
<i>cos</i>	(Optional) acos value
<i>vlan</i>	(Optional) vlan id
<i>l2_proto</i>	(Optional) L2 protocol
<i>ethertype</i>	(Optional) ethertype
TABLE_vdc	(Optional) show for vdc
<i>vdc-no</i>	(Optional) vdc number
<i>vdc-type</i>	(Optional) VDC type-COPP etc
<i>dir</i>	(Optional) Policy Direction
<i>policy-type</i>	(Optional) Policy type
<i>policy-id</i>	(Optional) Policy id
<i>policy-name</i>	(Optional) Policy name

TABLE_instance	(Optional) show for an instance
<i>inst</i>	(Optional) instance number
TABLE_tcam_resource_usage	(Optional) TCAM resource usage
<i>tcam-no</i>	(Optional) tcam number
<i>lbl</i>	(Optional) lbl name
<i>hw-lbl-id</i>	(Optional) hw lbl id
<i>bank</i>	(Optional) bank number
TABLE_class	(Optional) table class
<i>class-type</i>	(Optional) Class type
<i>policies</i>	(Optional) Policy name
<i>netflow-profile</i>	(Optional) Netflow Profile
<i>netflow-deny-profile</i>	(Optional) Netflow Deny Profile
<i>tcam-entries</i>	(Optional) No. of TCAM entries
<i>l4-protocol-cam-entries</i>	(Optional) L4 protocol cam entries
<i>mac-etype-proto-cam-entries</i>	(Optional) No. of mac etype/proto cam entries
<i>lous</i>	(Optional) No. of LOU's
<i>tcp-flags-table-entries</i>	(Optional) No. of CP flags table entries
<i>adjacency-entries</i>	(Optional) No. of adjacency entries

Command Mode

- /exec

show access-list database

```
show { system internal | hardware } access-list [ vdc <vdc_id> ] database { interface | vlan | policy | process
} [ module <module> ] [ __readonly__ <if_idx> <vlan> <plcy_id> <process_info> ]
```

Syntax Description

show	Show running system information
system	System-related show commands
internal	Commands for internal use
hardware	Show hardware information
access-list	Access Control List
vdc	(Optional) vdc id
<i>vdc_id</i>	(Optional) vdc_id
database	Show memory database
interface	display interfaces/vlans in a vdc with policies
policy	display policies in a vdc
vlan	display vlans in a vdc
process	display process database in a vdc
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
<i>__readonly__</i>	(Optional)
<i>if_idx</i>	(Optional) interface
<i>vlan</i>	(Optional) vlan
<i>plcy_id</i>	(Optional) policy id
<i>process_info</i>	(Optional) process information

Command Mode

- /exec

show access-list resource

```
show { system internal | hardware } access-list resource { { { entries | l4ops | redirect | ipv6-compression |
mac-compression | aqm-d | aqm-q | oq | opool | prm | hardware-telemetry } [ detail ] } | utilization [ per-feature
] | { entry tcam <tcam_id> bank <bank_id> index <index> } | { default-tcam-allocation } } [ no-header ] [
module <module> ] [ __readonly__ [ TABLE_instance <inst> [ TABLE_resource_util_info <resource_hdr>
<ents_use> [ <ents_free> ] [ <ents_pctage> ] ] ] ] ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
internal	Commands for internal use
hardware	Show hardware information
access-list	Access Control List
resource	hardware resource
entries	tcam entries
l4ops	l4 operations information
redirect	redirect resource information
entry	display hardware information of a tcam entry
tcam	tcam id
<i>tcam_id</i>	tcam_id
bank	bank id
<i>bank_id</i>	bank_id
index	index within bank
<i>index</i>	index withing bank
default-tcam-allocation	default tcam allocation
utilization	utilization matrix
per-feature	(Optional) feature wise utilization
ipv6-compression	ipv6 compression
mac-compression	mac compression table info
aqm-d	aqm d params
aqm-q	aqm q params

oq	oq profiles
opool	opool profiles
prm	prm profiles
hardware-telemetry	hardware-telemetry resources
detail	(Optional) detailed information
no-header	(Optional) Do not print header
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
__readonly__	(Optional)
TABLE_instance	(Optional) show for an instance
<i>inst</i>	(Optional) instance number
TABLE_resource_util_info	(Optional) resource utilization information
<i>resource_hdr</i>	(Optional) resource header
<i>ents_use</i>	(Optional) entries in use
<i>ents_free</i>	(Optional) free tcam entries
<i>ents_pctage</i>	(Optional) tcam entries usage percentage

Command Mode

- /exec

show access-lists

```
show [ <ip_ipv6_mac> ] access-lists [ <name> ] [ capture session <capture_session> ] [ <expanded> |
<summary> | <private> | <brief> | <stats-detail> ] [ __readonly__ TABLE_ip_ipv6_mac <op_ip_ipv6_mac>
<show_summary> <acl_name> [ <statistics> ] [ <frag_opt_permit_deny> ] [ <global_capture_session> ] [
TABLE_seqno <seqno> { <permitdeny> [ <proto_str> | <proto> | <ip> | <ipv6> ] { <src_any> | <src_ip_prefix>
| <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> | <src_ipv6_addr> <src_ipv6_mask> | <mac_src>
<mac_src_wild> | <src_addrgrp> } [ <src_port_op> [ <src_port1_str> ] { <src_port1_num> } [ <src_port2_str>
| <src_port2_num> ] | <src_portgrp> ] { <dest_any> | <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> |
<dest_ipv6_prefix> | <dest_ipv6_addr> <dest_ipv6_mask> | <mac_dest> <mac_dest_wild> | <dest_addrgrp>
} [ <dest_port_op> [ <dest_port1_str> ] { <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] |
<dest_portgrp> ] [ { <icmp_type> [ <icmp_code> ] | <icmp_str> } | { <icmpv6_type> [ <icmpv6_code> ] |
<icmpv6_str> } ] [ <igmp_type> | <igmp_type_str> ] [ [ <precedence> | <precedence_str> ] [ <tos> | <tos_str>
] | [ <dscp> | <dscp_str> ] | [ <ttl> ] ] [ <log> ] [ <udfs> ] [ <capture_session> ] [ <fragments> ] [ <plen_op>
<plen1> [ <plen2> ] ] [ <urg> ] [ <ack> ] [ <psh> ] [ <rst> ] [ <syn> ] [ <fin> ] [ <established> ] [
<http-method> | <http_opt_str> ] [ <tcp-option-length> ] [ <tcp-flags-mask> ] [ <flow_label> ] [ <timerange>
] [ <eth_proto> | <eth_proto_str> ] [ <vlan> ] [ <cos> ] [ <match_count> ] [ TABLE_match <module>
<module_match_count> ] [ <nve_vni> ] | <remark> [ <action> <actionid> ] } ] [ ethertype <ethertypeid> |
vlan <vlanid> | ingress_intf { <intfid> | <intfname> } | vlan_priority <vlanpriorityid> ] + [ <action> <actionid>
] [ [ <stats_enabled> ] [ <frag_option> ] { <num_ace> } { <conf_if_header> } [ <conf_if> ] {
<active_if_header> } [ <active_if> ] ] ] ]
```

Syntax Description

show	Show running system information
<i>name</i>	(Optional) List name
<i>ip_ipv6_mac</i>	(Optional) IP/IPv6/MAC
capture	(Optional) capture
session	(Optional) session
<i>capture_session</i>	(Optional) session id
<i>op_ip_ipv6_mac</i>	(Optional) IP/IPv6/MAC
access-lists	List access lists
<i>show_summary</i>	(Optional)
<i>acl_name</i>	(Optional) List name
<i>__readonly__</i>	(Optional)
TABLE_ip_ipv6_mac	(Optional)
<i>frag_opt_permit_deny</i>	(Optional) frag_op_type
ethertype	(Optional) Configure match based on ethertype
vlan	(Optional) Configure match based on vlan

<i>ingress_intf</i>	(Optional) Configure match based on ingress interface
<i>vlan_priority</i>	(Optional) Configure match based on priority
<i>ethertypeid</i>	(Optional) Configure the ethertype value
<i>vlanid</i>	(Optional) VLAN number
<i>intfid</i>	(Optional) Interface index
<i>intfname</i>	(Optional) Interface name
<i>vlanpriorityid</i>	(Optional) Vlan Priority
<i>seqno</i>	(Optional) Sequence number
<i>permitdeny</i>	(Optional) Permit/deny
<i>proto</i>	(Optional) A protocol number
TABLE_seqno	(Optional)
<i>proto_str</i>	(Optional) Protocol name
<i>ip</i>	(Optional) IP
<i>ipv6</i>	(Optional) IPV6
<i>src_any</i>	(Optional) SRCAny
<i>dest_any</i>	(Optional) DESTAny
<i>src_ip_prefix</i>	(Optional) Source IP prefix
<i>src_ip_addr</i>	(Optional) Source IP address
<i>src_ip_mask</i>	(Optional) Source IP mask
<i>mac_src</i>	(Optional) Source MAC address
<i>mac_src_wild</i>	(Optional) Source MAC mask
<i>dest_ip_prefix</i>	(Optional) Destination IP prefix
<i>dest_ip_addr</i>	(Optional) Destination IP address
<i>dest_ip_mask</i>	(Optional) Destination IP mask
<i>mac_dest</i>	(Optional) Destination MAC address
<i>mac_dest_wild</i>	(Optional) Destination MAC mask
<i>src_port_op</i>	(Optional) Source Port operator
<i>dest_port_op</i>	(Optional) Destination Port operator
<i>src_port1_str</i>	(Optional) Source port name

<i>src_port1_num</i>	(Optional) Source port number
<i>src_port2_str</i>	(Optional) Source port name
<i>src_port2_num</i>	(Optional) Source port number
<i>dest_port1_str</i>	(Optional) Destination port name
<i>dest_port1_num</i>	(Optional) Destination port number
<i>dest_port2_str</i>	(Optional) Destination port name
<i>dest_port2_num</i>	(Optional) Destination port number
<i>icmp_type</i>	(Optional) ICMP type
<i>icmp_code</i>	(Optional) ICMP code
<i>icmp_str</i>	(Optional) ICMP message
<i>icmpv6_type</i>	(Optional) ICMP type
<i>icmpv6_code</i>	(Optional) ICMP code
<i>icmpv6_str</i>	(Optional) ICMP message
<i>igmp_type</i>	(Optional) IGMP type
<i>igmp_type_str</i>	(Optional) IGMP type String
<i>precedence</i>	(Optional) precedence
<i>precedence_str</i>	(Optional) precedence string
<i>tos</i>	(Optional) tos
<i>tos_str</i>	(Optional) tos string
<i>dscp</i>	(Optional) dscp
<i>dscp_str</i>	(Optional) dscp string
<i>udfs</i>	(Optional) udfs string
<i>ttl</i>	(Optional) ttl
<i>capture_session</i>	(Optional) capture session
<i>global_capture_session</i>	(Optional) capture session
<i>log</i>	(Optional) Log
<i>fragments</i>	(Optional) Fragments
<i>urg</i>	(Optional) URG
<i>ack</i>	(Optional) ACK

<i>psh</i>	(Optional) PSH
<i>rst</i>	(Optional) RST
<i>syn</i>	(Optional) SYN
<i>fin</i>	(Optional) FIN
<i>established</i>	(Optional) ESTABLISHED
<i>http-method</i>	(Optional) http-method
<i>http_opt_str</i>	(Optional) http_option string
<i>tcp-option-length</i>	(Optional) TCP Option size
<i>tcp-flags-mask</i>	(Optional) TCP Flags mask
<i>flow_label</i>	(Optional) IPv6 flow label
<i>timerange</i>	(Optional) Time-range
<i>eth_proto</i>	(Optional) MAC protocol number
<i>eth_proto_str</i>	(Optional) MAC protocol name
<i>vlan</i>	(Optional) VLAN number
<i>cos</i>	(Optional) CoS value
<i>match_count</i>	(Optional) Number of packets matching the ACL
TABLE_match	(Optional)
<i>module</i>	(Optional) Module name
<i>module_match_count</i>	(Optional) Number of packets matching the ACL per module
<i>nve_vni</i>	(Optional) nve vni
<i>remark</i>	(Optional) Remark String
<i>statistics</i>	(Optional) STATISTICS
<i>src_addrgrp</i>	(Optional) Source address group
<i>dest_addrgrp</i>	(Optional) Destination address group
<i>src_portgrp</i>	(Optional) Source port group
<i>dest_portgrp</i>	(Optional) Destination port group
<i>plen_op</i>	(Optional) Source Port operator
<i>plen1</i>	(Optional) Packet length minimum
<i>plen2</i>	(Optional) packet length maximum

<i>action</i>	(Optional) Action
<i>actionid</i>	(Optional) redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63> set-erspan-gre-PROTO: <1-65535>
<i>stats_enabled</i>	(Optional)
<i>frag_option</i>	(Optional)
<i>num_ace</i>	(Optional) Total number of ACEs
<i>conf_if_header</i>	(Optional)
<i>conf_if</i>	(Optional) Configured Interfaces
<i>active_if_header</i>	(Optional)
<i>active_if</i>	(Optional) Active interfaces
<i>expanded</i>	(Optional) EXPANDED
<i>summary</i>	(Optional) SUMMARY
<i>private</i>	(Optional) PRIVATE
<i>brief</i>	(Optional) BRIEF
<i>stats-detail</i>	(Optional) STATS-DETAIL

Command Mode

- /exec

show access-lists

```
show <mpls_acl> access-lists [ <mpls_name> ] [ __readonly__ TABLE_mpls <mpls_name> [ <statistics> ]
[ TABLE_seqno <seqno> { <permitdeny> <mpls> [ <mpls_option> ] { <label1_any> | { <label1> [ mask
<label1_mask> ] } } [ <label2_any> | { <label2> [ mask <label2_mask> ] } } ] [ <label3_any> | { <label3> [
mask <label3_mask> ] } ] [ <label4_any> | { <label4> [ mask <label4_mask> ] } } ] <mplsaction> <mplsactionid>
} | <remark> ] ]
```

Syntax Description

show	Show running system information
<i>mpls_acl</i>	mpls acl value
access-lists	List access lists
<i>mpls_name</i>	(Optional) List name
<i>__readonly__</i>	(Optional)
<i>mpls_name</i>	(Optional) Name of the MPLS ACL
<i>seqno</i>	(Optional) Sequence number
<i>permitdeny</i>	(Optional) Permit/deny
<i>mplsaction</i>	(Optional) mpls ACL Action
<i>mplsactionid</i>	(Optional) redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63> set-erspan-gre-proto: <1-65535>
<i>statistics</i>	(Optional) STATISTICS
mask	(Optional) mask
<i>label1</i>	(Optional) mpls label one
<i>label2</i>	(Optional) mpls label two
<i>label3</i>	(Optional) mpls label three
<i>label4</i>	(Optional) mpls label three
<i>label1_mask</i>	(Optional) mpls label one mask
<i>label2_mask</i>	(Optional) mpls label two mask
<i>label3_mask</i>	(Optional) mpls label three mask
<i>label4_mask</i>	(Optional) mpls label four mask
<i>label1_any</i>	(Optional) label one Any
<i>label2_any</i>	(Optional) label two Any

<i>label3_any</i>	(Optional) label three Any
<i>label4_any</i>	(Optional) label four Any
<i>mpls</i>	(Optional) mpls keyword
<i>mpls_option</i>	(Optional) mpls option
TABLE_mpls	(Optional)
TABLE_seqno	(Optional)
<i>remark</i>	(Optional) Remark String

Command Mode

- /exec

show accounting log

```
show accounting log [ { <i0> | start-time <SYYYY> <SMonth> <SDate> <STime> [ end-time <EYYYY>
<EMonth> <EDate> <ETime> ] } ] [ __readonly__ [ TABLE_acctlog_time <accountlog_starttime> ] ]
```

Syntax Description

show	Show running system information
accounting	Show Accounting Information
log	Show Accounting Log
<i>i0</i>	(Optional) Log Size(in bytes)
start-time	(Optional) Show messages from a given start-time
<i>SYYYY</i>	(Optional) Enter year in YYYY format
<i>SMonth</i>	(Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>SDate</i>	(Optional) Enter day of month in dd format
<i>STime</i>	(Optional) Enter hour, minutes, seconds as HH:MM:SS
end-time	(Optional) Show messages from a given end-time
<i>EYYYY</i>	(Optional) Enter year in YYYY format
<i>EMonth</i>	(Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>EDate</i>	(Optional) Enter day of month in dd format
<i>ETime</i>	(Optional) Enter hour, minutes, seconds as HH:MM:SS
__readonly__	(Optional)
TABLE_acctlog_time	(Optional)
<i>accountlog_starttime</i>	(Optional) accounting log starttime

Command Mode

- /exec

show accounting log all

```
show accounting log all [ __readonly__ [ TABLE_acctlog <accountlog_all> ] ]
```

Syntax Description

show	Show running system information
accounting	Show accounting configuration
log	Show Accounting Log
all	Display accounting log including show commands (Use <terminal log-all> to enable show command accounting)
__readonly__	(Optional)
TABLE_acctlog	(Optional)
<i>accountlog_all</i>	(Optional) accounting log all

Command Mode

- /exec

show accounting log last-index

show accounting log last-index [__readonly__ { <last_index> }]

Syntax Description

show	Show running system information
accounting	Show accounting configuration
log	Show Accounting Log
last-index	Show accounting log last index information
__readonly__	(Optional)
<i>last_index</i>	(Optional) accounting log last index

Command Mode

- /exec

show accounting log nvram

```
show accounting log nvram [ { <i0> | start-time <SYYYY> <SMonth> <SDate> <STime> [ end-time
<EYYYY> <EMonth> <EDate> <ETime> ] } ] [ __readonly__ [ TABLE_acctnvramlog_time
<accountnvramlog_starttime> ] ]
```

Syntax Description

show	Show running system information
accounting	Show Accounting Information
log	Show Accounting Log
nvram	present in nvram
<i>i0</i>	(Optional) Log Size(in bytes)
start-time	(Optional) Show messages from a given start-time
<i>SYYYY</i>	(Optional) Enter year in YYYY format
<i>SMonth</i>	(Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>SDate</i>	(Optional) Enter day of month in dd format
<i>STime</i>	(Optional) Enter hour, minutes, seconds as HH:MM:SS
end-time	(Optional) Show messages from a given end-time
<i>EYYYY</i>	(Optional) Enter year in YYYY format
<i>EMonth</i>	(Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>EDate</i>	(Optional) Enter day of month in dd format
<i>ETime</i>	(Optional) Enter hour, minutes, seconds as HH:MM:SS
__readonly__	(Optional)
TABLE_acctnvramlog_time	(Optional)
<i>accountnvramlog_starttime</i>	(Optional) accounting log nvram starttime

Command Mode

- /exec

show accounting log nvram last-index

show accounting log nvram last-index [*__readonly__* { <last_index> }]

Syntax Description

show	Show running system information
accounting	Show accounting configuration
log	Show Accounting Log
nvram	present in nvram
last-index	Show accounting log last index information
<i>__readonly__</i>	(Optional)
<i>last_index</i>	(Optional) accounting log last index

Command Mode

- /exec

show accounting log nvram start-seqnum

```
show accounting log nvram start-seqnum <SSEQNUM> [ end-seqnum <ESEQNUM> ] [ __readonly__ [
TABLE_acctnvramlog_seq <accountnvramlog_seq> ] ]
```

Syntax Description

show	Show running system information
accounting	Show Accounting Information
log	Show Accounting Log
nvram	present in nvram
start-seqnum	Show messages starting from a given sequence number
end-seqnum	(Optional) Show messages ending with a given sequence number
<i>SSEQNUM</i>	Enter Starting Sequence Number
<i>ESEQNUM</i>	(Optional) Enter Starting Sequence Number
<i>__readonly__</i>	(Optional)
<i>TABLE_acctnvramlog_seq</i>	(Optional)
<i>accountnvramlog_seq</i>	(Optional) accounting log nvram seqnum

Command Mode

- /exec

show accounting log start-seqnum

```
show accounting log start-seqnum <SSEQNUM> [ end-seqnum <ESEQNUM> ] [ __readonly__ [
TABLE_acctlog_seq <accountlog_seq> ] ]
```

Syntax Description

show	Show running system information
accounting	Show Accounting Information
log	Show Accounting Log
start-seqnum	Show messages starting from a given sequence number
end-seqnum	(Optional) Show messages ending with a given sequence number
<i>SSEQNUM</i>	Enter Starting Sequence Number
<i>ESEQNUM</i>	(Optional) Enter Starting Sequence Number
<i>__readonly__</i>	(Optional)
<i>TABLE_acctlog_seq</i>	(Optional)
<i>accountlog_seq</i>	(Optional) accounting log seqnum

Command Mode

- /exec

show acl status

```
show acl status [ __readonly__ [ <status_log_string> ] ]
```

Syntax Description

show	Show running system information
acl	Show information about acl
status	Shows the status of last acl operation
<i>__readonly__</i>	(Optional)
<i>status_log_string</i>	(Optional) ppf entry string

Command Mode

- /exec

show amt process

```
show amt process [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ TABLE_vrf <vrf> <pid> <uid>
<q> <re4> <ge4> <re6> <ge6> <pi4> <ar4> <ag4> <ra4> <ga4> <dra4> <pi6> <ar6> <ag6> <ra6> <ga6>
<dra6> <qqic4> <tc4> <tl4> <rc4> <rl4> <jp4> <qqic6> <tc6> <tl6> <rc6> <rl6> <jp6> <grm4> <gjp4>
<gslp4> <gsl4> <grm6> <gjp6> <gslp6> <gsl6> ]
```

Syntax Description

show	Show running system information
amt	AMT show commands
vrf	(Optional) Display information for VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
process	Display AMT process information
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>pid</i>	(Optional)
<i>uid</i>	(Optional)
<i>q</i>	(Optional)
<i>re4</i>	(Optional)
<i>ge4</i>	(Optional)
<i>re6</i>	(Optional)
<i>ge6</i>	(Optional)
<i>pi4</i>	(Optional)
<i>ar4</i>	(Optional)
<i>ag4</i>	(Optional)
<i>ra4</i>	(Optional)
<i>ga4</i>	(Optional)
<i>dra4</i>	(Optional)
<i>pi6</i>	(Optional)

<i>qqic4</i>	(Optional)
<i>tc4</i>	(Optional)
<i>tl4</i>	(Optional)
<i>rc4</i>	(Optional)
<i>rl4</i>	(Optional)
<i>jp4</i>	(Optional)
<i>qqic6</i>	(Optional)
<i>tc6</i>	(Optional)
<i>tl6</i>	(Optional)
<i>rc6</i>	(Optional)
<i>rl6</i>	(Optional)
<i>jp6</i>	(Optional)
<i>grm4</i>	(Optional)
<i>gjp4</i>	(Optional)
<i>gslp4</i>	(Optional)
<i>gsl4</i>	(Optional)
<i>grm6</i>	(Optional)
<i>gjp6</i>	(Optional)
<i>gslp6</i>	(Optional)
<i>gsl6</i>	(Optional)

Command Mode

- /exec

show amt vrf all

show amt vrf all [__readonly__ TABLE_vrf <vrf> <cid> <ip_tid> <ipv6_tid>]

Syntax Description

show	Show running system information
amt	AMT show commands
vrf	Display all VRFs AMT is configured in
all	Display all VRFs AMT is configured in
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>cid</i>	(Optional)
<i>ip_tid</i>	(Optional)
<i>ipv6_tid</i>	(Optional)

Command Mode

- /exec

show archive log config

```
show archive log config { all | [ user <username> ] [ first-index <first_index> [ last-index <last_index> ] ] }
[ __readonly__ [ TABLE_archivelog_time [ <archivelog_firstindex> ] ] ]
```

Syntax Description

show	Show running system information
archive	Show archive configuration
log	Show Archive Log
config	Show Config Logger information
all	List all the records in the config log
user	(Optional) List records for specific user in the config log
<i>username</i>	(Optional) Username
first-index	(Optional) The first record number to display
last-index	(Optional) The last record number to display
<i>first_index</i>	(Optional) config log first index
<i>last_index</i>	(Optional) config log last index
__readonly__	(Optional)
TABLE_archivelog_time	(Optional)
<i>archivelog_firstindex</i>	(Optional) archive log startindex

Command Mode

- /exec

show arp access-lists

```
show arp access-lists [ <name> ] [ __readonly__ TABLE_arp <arp_name> [ TABLE_seqno <seqno> {
<permitdeny> <reqresp> ip { { <sender_ip_any> | { { <sender_host> <sender_ip> | { <sender_net_ip>
<sender_ip_mask> } } } } [ { <target_ip_any> | { { <target_host> <target_ip> | { <target_net_ip>
<target_ip_mask> } } } ] } mac { { <sender_mac_any> | { { <sender_mac_host> <sender_mac> | {
<sender_net_mac> <sender_mac_mask> } } } } [ { <target_mac_any> | { { <target_mac_host> <target_mac>
| { <target_net_mac> <target_mac_mask> } } } ] } [ <arp_log> ] | <remark> ] ] [ capture session
<session-id> ]
```

Syntax Description

show	Show running system information
arp	ARP access-lists
access-lists	List access lists
<i>name</i>	(Optional) List name
<i>__readonly__</i>	(Optional)
<i>arp_name</i>	(Optional) Name of the ARP ACL
<i>seqno</i>	(Optional) Sequence number
<i>permitdeny</i>	(Optional) Permit/deny
ip	(Optional) Any IP protocol
TABLE_arp	(Optional)
TABLE_seqno	(Optional)
<i>reqresp</i>	(Optional) ARP_Request
<i>sender_ip_any</i>	(Optional) Any
<i>sender_host</i>	(Optional) Host
<i>sender_ip</i>	(Optional) IP address <a.b.c.d>
<i>sender_net_ip</i>	(Optional) IP address <a.b.c.d>
<i>sender_ip_mask</i>	(Optional) IP mask <a.b.c.d>
<i>target_ip_any</i>	(Optional) Any
<i>target_host</i>	(Optional) Host
<i>target_ip</i>	(Optional) IP address <a.b.c.d>
<i>target_net_ip</i>	(Optional) IP address <a.b.c.d>
<i>target_ip_mask</i>	(Optional) IP mask <a.b.c.d>

<i>mac</i>	(Optional) MAC configuration commands
<i>sender_mac_any</i>	(Optional) Any
<i>sender_mac_host</i>	(Optional) Host
<i>sender_mac</i>	(Optional) MAC address EEEE.EEEE.EEEE
<i>sender_net_mac</i>	(Optional) MAC address EEEE.EEEE.EEEE
<i>sender_mac_mask</i>	(Optional) MAC mask EEEE.EEEE.EEEE
<i>target_mac_any</i>	(Optional) Any
<i>target_mac_host</i>	(Optional) Host
<i>target_mac</i>	(Optional) MAC address EEEE.EEEE.EEEE
<i>target_net_mac</i>	(Optional) MAC address EEEE.EEEE.EEEE
<i>target_mac_mask</i>	(Optional) MAC mask EEEE.EEEE.EEEE
<i>remark</i>	(Optional) Remark String
<i>arp_log</i>	(Optional) Log
<i>capture</i>	(Optional) Enable packet capture on this filter for session
<i>session</i>	(Optional) Session ID <1-48> for this session
<i>session-id</i>	(Optional) Session ID <1-48> for this session

Command Mode

- /exec



B Show Commands

- [show background](#), on page 47
- [show banner exec](#), on page 48
- [show banner motd](#), on page 49
- [show bash-shell](#), on page 50
- [show bfd-app session status](#), on page 51
- [show bfd addrmap](#), on page 52
- [show bfd clients](#), on page 53
- [show bfd discrmap](#), on page 54
- [show bfd intfipmap](#), on page 55
- [show bfd neighbors](#), on page 56
- [show bfd scalar](#), on page 60
- [show bfd session](#), on page 61
- [show bgp](#), on page 64
- [show bgp](#), on page 70
- [show bgp](#), on page 73
- [show bgp](#), on page 81
- [show bgp](#), on page 82
- [show bgp](#), on page 88
- [show bgp](#), on page 91
- [show bgp bmp server](#), on page 93
- [show bgp community](#), on page 96
- [show bgp convergence](#), on page 102
- [show bgp convergence private](#), on page 104
- [show bgp dampening dampened](#), on page 105
- [show bgp dampening flap-statistics](#), on page 111
- [show bgp dampening parameters](#), on page 114
- [show bgp event-history](#), on page 117
- [show bgp evi](#), on page 118
- [show bgp extcommunity](#), on page 120
- [show bgp l3vpn](#), on page 126
- [show bgp neighbors](#), on page 128
- [show bgp neighbors](#), on page 134
- [show bgp neighbors commands](#), on page 143

- [show bgp neighbors flap-statistics](#), on page 145
- [show bgp neighbors paths](#), on page 147
- [show bgp paths](#), on page 149
- [show bgp peer-template](#), on page 150
- [show bgp peer](#), on page 154
- [show bgp prefix-list](#), on page 156
- [show bgp private](#), on page 161
- [show bgp private attr](#), on page 162
- [show bgp private damp](#), on page 163
- [show bgp private debug history](#), on page 164
- [show bgp process](#), on page 165
- [show bgp received-paths](#), on page 170
- [show bgp regexp](#), on page 176
- [show bgp self-originated](#), on page 181
- [show bgp sessions](#), on page 186
- [show bgp statistics](#), on page 188
- [show bgp summary](#), on page 189
- [show bgp summary](#), on page 193
- [show boot](#), on page 198
- [show boot auto-copy](#), on page 199
- [show boot auto-copy list](#), on page 200
- [show boot current](#), on page 201
- [show boot mode](#), on page 202
- [show boot order](#), on page 203
- [show boot sup-1](#), on page 204
- [show boot sup-2](#), on page 205
- [show boot timings](#), on page 206
- [show boot variables](#), on page 207

show background

show background

Syntax Description

show	Show running system information
background	show background processes (started with 'source background <file>' command)

Command Mode

- /exec

show banner exec

```
show banner exec [ __readonly__ { banner_msg <b_msg> } ]
```

Syntax Description

show	Show running system information
banner	Show current banner message
exec	Show current exec banner message
__readonly__	(Optional)
banner_msg	(Optional) The banner message
<i>b_msg</i>	(Optional) The banner message

Command Mode

- /exec

show banner motd

```
show banner motd [ __readonly__ { banner_msg <b_msg> } ]
```

Syntax Description

show	Show running system information
banner	Show current banner message
motd	Show current motd banner message
__readonly__	(Optional)
banner_msg	(Optional) The banner message
<i>b_msg</i>	(Optional) The banner message

Command Mode

- /exec

show bash-shell

```
show bash-shell [ __readonly__ { operation_status <o_status> } ]
```

Syntax Description

show	Show running system information
bash-shell	Show bash shell status
<i>__readonly__</i>	(Optional)
<i>operation_status</i>	(Optional) Bash shell status
<i>o_status</i>	(Optional) operational status of bash shell

Command Mode

- /exec

show bfd-app session status

```
show bfd-app session status { src-ip { <src_ip> dest-ip <dest_ip> | <src_ipv6> dest-ip <dest_ipv6> } { iod
<iod_id> | intf <intf_id> } | <all> }
```

Syntax Description

show	Show running system information
bfd-app	BFD application commands
session	session operation
src-ip	Source ip
<i>src_ip</i>	Source ip value
dest-ip	Destination ip
<i>dest_ip</i>	Destination ip value
iod	interface iod
<i>iod_id</i>	Interface iod in hex
intf	interface
<i>intf_id</i>	Interface Id
status	status of sessions
<i>all</i>	All sessions

Command Mode

- /exec

show bfd addrmap

```
show bfd addrmap [ application <appid> discriminator <discr> address-type <addrtype> address <addr> ] [
__readonly__ TABLE_bfdSessMapTable <ciscoBfdSessApplicationId> <ciscoBfdSessDiscriminator>
<ciscoBfdSessAddrType> <ciscoBfdSessAddr> <ciscoBfdSessMapBfdIndex> ]
```

Syntax Description

show	Show running system information
bfd	BFD commands
addrmap	Session
application	(Optional)
discriminator	(Optional)
address-type	(Optional)
address	(Optional)
<i>appid</i>	(Optional)
<i>discr</i>	(Optional)
<i>addrtype</i>	(Optional)
<i>addr</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_bfdSessMapTable	(Optional) Address Map table
<i>ciscoBfdSessApplicationId</i>	(Optional)
<i>ciscoBfdSessDiscriminator</i>	(Optional)
<i>ciscoBfdSessAddrType</i>	(Optional)
<i>ciscoBfdSessAddr</i>	(Optional)
<i>ciscoBfdSessMapBfdIndex</i>	(Optional)

Command Mode

- /exec

show bfd clients

show bfd clients [*__readonly__* <header> TABLE-bfdClients <client_name> <num_sess>]

Syntax Description

show	Show running system information
bfd	BFD commands
clients	bfd client list
<i>__readonly__</i>	(Optional)
<i>header</i>	(Optional) print header
TABLE-bfdClients	(Optional) BFD Client table
<i>client_name</i>	(Optional) client name
<i>num_sess</i>	(Optional) Number of sessions

Command Mode

- /exec

show bfd discrmap

show bfd discrmap [<discr>] [__readonly__ TABLE_bfdDiscMapTable <ciscoBfdSessDiscMapIndex>]

Syntax Description

show	Show running system information
bfd	BFD commands
discrmap	Session
<i>discr</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_bfdDiscMapTable	(Optional) Discriminator map table
<i>ciscoBfdSessDiscMapIndex</i>	(Optional)

Command Mode

- /exec

show bfd intfipmap

```
show bfd intfipmap [ interface <intf> address-type <addrtype> address <addr> ] [ __readonly __
TABLE_ipMapTable <ciscoBfdSessInterface> <ciscoBfdSessAddrType> <ciscoBfdSessAddr>
<ciscoBfdSessIpMapIndex> ]
```

Syntax Description

show	Show running system information
bfd	BFD commands
intfipmap	Session
interface	(Optional)
address-type	(Optional)
address	(Optional)
<i>intf</i>	(Optional)
<i>addrtype</i>	(Optional)
<i>addr</i>	(Optional)
<i>__readonly __</i>	(Optional)
<i>TABLE_ipMapTable</i>	(Optional) ip map table
<i>ciscoBfdSessInterface</i>	(Optional)
<i>ciscoBfdSessAddrType</i>	(Optional)
<i>ciscoBfdSessAddr</i>	(Optional)
<i>ciscoBfdSessIpMapIndex</i>	(Optional)

Command Mode

- /exec

show bfd neighbors

```
show bfd { [ vrf { <vrf-name> | <vrf-known-name> | all } ] } { [ <ip_type> ] } neighbors { [ multihop ] | [
module <module_no> ] | [ interface <intf_id> ] | [ application <bfd_cli_client_names> ] | [ { src-ip <src_ip>
| src-ipv6 <src_ipv6> } ] | [ { dest-ip <dest_ip> | dest-ipv6 <dest_ipv6> } ] | [ vrf { <vrf-name> |
<vrf-known-name> | all } ] } + [ details ] [ __readonly__ TABLE_bfdNeighbor <local_disc> [ <header> ] [
<sess_type> ] [ <vrf_name> ] [ <src_ip_addr> ] [ <src_ipv6_addr> ] [ <dest_ip_addr> ] [ <dest_ipv6_addr>
] [ <remote_disc> ] [ <local_state> ] [ <remote_state> ] [ <holddown> ] [ <cur_detect_mult> ] [ <intf> ] [
<echo> ] [ <echo_tx> ] [ <local_diag> ] [ <demand> ] [ <poll> ] [ <min_tx> ] [ <min_rx> ] [ <local_multi>
] [ <detect_timer> ] [ <down_count> ] [ <tx_interval> ] [ <rx_count> ] [ <rx_avg> ] [ <rx_min> ] [ <rx_max>
] [ <last_rx> ] [ <tx_count> ] [ <tx_avg> ] [ <tx_min> ] [ <tx_max> ] [ <last_tx> ] [ <app> ] [ <up_time> ]
[ <version> ] [ <diag> ] [ <state_bit> ] [ <demand_bit> ] [ <poll_bit> ] [ <final_bit> ] [ <multiplier> ] [
<length> ] [ <my_disc> ] [ <your_disc> ] [ <min_tx_interval> ] [ <req_min_rx> ] [ <min_echo_interval> ] [
<out_str> ] [ <host_lc> ] [ <down_reason> ] [ <no_host_reason> ] [ <parent> ] [ <per_link_str> ] [ <auth> ]
[ <auth_bit> ] [ <print_details> ] ]
```

Syntax Description

show	Show running system information
bfd	BFD commands
<i>ip_type</i>	(Optional) ipv4 or ipv6
neighbors	neighbors
multihop	(Optional) Display Multihop sessions only
module	(Optional) module
<i>module_no</i>	(Optional) module number
interface	(Optional) interface
<i>intf_id</i>	(Optional) show bfd sessions based on interface id
application	(Optional) application
<i>bfd_cli_client_names</i>	(Optional) __nil__ Clients need to register with bfd for this list
src-ip	(Optional) Source ip
src-ipv6	(Optional) Source ip
<i>src_ip</i>	(Optional) Source ip value
dest-ip	(Optional) Destination ip
dest-ipv6	(Optional) Destination ip
<i>dest_ip</i>	(Optional) Destination ip value
vrf	(Optional) Display per-VRF information

<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
details	(Optional) details
<i>__readonly__</i>	(Optional)
TABLE_bfdNeighbor	(Optional) BFD Neighbor table
<i>header</i>	(Optional) Header
<i>sess_type</i>	(Optional) Session type
<i>vrf_name</i>	(Optional) vrf name
<i>src_ip_addr</i>	(Optional) Source IPV4 address
<i>dest_ip_addr</i>	(Optional) Destination IPV4 address
<i>local_disc</i>	(Optional) Local Discriminator
<i>remote_disc</i>	(Optional) Remote Discriminator
<i>local_state</i>	(Optional) Local State
<i>remote_state</i>	(Optional) Remote State
<i>holddown</i>	(Optional) Hold Down Time
<i>cur_detect_mult</i>	(Optional) Current Detection Multiplier
<i>intf</i>	(Optional) Interface
<i>echo</i>	(Optional) Echo enabled
<i>echo_tx</i>	(Optional) Echo Tx Interval
<i>local_diag</i>	(Optional) Local Diag
<i>demand</i>	(Optional) Demand Mode
<i>poll</i>	(Optional) Poll Bit
<i>min_tx</i>	(Optional) Local Min Tx Interval
<i>min_rx</i>	(Optional) Local Min Rx Interval
<i>local_multi</i>	(Optional) Local Detection Multiplier
<i>detect_timer</i>	(Optional) Current Detection Timer
<i>down_count</i>	(Optional) Session Down Count
<i>tx_interval</i>	(Optional) Tx Interval

<i>rx_count</i>	(Optional) Tx Count
<i>rx_avg</i>	(Optional) Rx Interval Avg
<i>rx_min</i>	(Optional) Rx Interval Min
<i>rx_max</i>	(Optional) Rx Interval Max
<i>last_rx</i>	(Optional) Last Rx time
<i>tx_count</i>	(Optional) Tx Count
<i>tx_avg</i>	(Optional) Tx Interval Avg
<i>tx_min</i>	(Optional) Tx Interval Min
<i>tx_max</i>	(Optional) Tx Interval Max
<i>last_tx</i>	(Optional) Last Tx time
<i>app</i>	(Optional) App name
<i>up_time</i>	(Optional) Up time
<i>version</i>	(Optional) Version in Last Packet
<i>diag</i>	(Optional) diag in Last Packet
<i>state_bit</i>	(Optional) State Bit in Last Packet
<i>demand_bit</i>	(Optional) Demand Bit in Last Packet
<i>poll_bit</i>	(Optional) Poll Bit in Last Packet
<i>final_bit</i>	(Optional) Final Bit in Last Packet
<i>multiplier</i>	(Optional) Detection Multiplier in Last Packet
<i>length</i>	(Optional) Length in Last Packet
<i>my_disc</i>	(Optional) My Discriminator in Last Packet
<i>your_disc</i>	(Optional) Your Discriminator in Last Packet
<i>min_tx_interval</i>	(Optional) Min Tx Interval in Last Packet
<i>req_min_rx</i>	(Optional) Required Rx Interval in Last Packet
<i>min_echo_interval</i>	(Optional) Min Echo Interval in Last Packet
<i>out_str</i>	(Optional) No Host LC string
<i>parent</i>	(Optional) Parent Session
<i>per_link_str</i>	(Optional) Per Link string
<i>host_lc</i>	(Optional) Host LC

<i>down_reason</i>	(Optional) Session Down Reason
<i>no_host_reason</i>	(Optional) Not Hosted Reason
<i>auth</i>	(Optional) Authentication Mode
<i>auth_bit</i>	(Optional) Auth Bit in Last Packet
<i>print_details</i>	(Optional) print details

Command Mode

- /exec

show bfd scalar

show bfd scalar [__readonly__ <adminStatus> <version> <notifEnable>]

Syntax Description

show	Show running system information
bfd	BFD commands
scalar	bfd mib scalars
__readonly__	(Optional)
<i>adminStatus</i>	(Optional) bfd admin status
<i>version</i>	(Optional) bfd version number
<i>notifEnable</i>	(Optional) Enable bfd traps

Command Mode

- /exec

show bfd session

```
show bfd session { [ discriminator <sessionIndex> ] [ interface <intf_id> ] [ application <app_name> ] [ [ src-ip <src_ip> ] [ dest-ip <dest_ip> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ] } + [ __readonly__ <vrf_name_header> TABLE_bfdSessTable <ciscoBfdSessIndex> <isMember> <ciscoBfdSessApplicationId> <ciscoBfdSessDiscriminator> <ciscoBfdSessRemoteDiscr> <ciscoBfdSessUdpPort> <ciscoBfdSessState> <remoteBfdSessState> <ciscoBfdSessRemoteHeardFlag> <ciscoBfdSessDiag> <remoteBfdSessDiag> <ciscoBfdSessOperMode> <ciscoBfdSessDemandModeDesiredFlag> <ciscoBfdSessEchoFuncModeDesiredFlag> <ciscoBfdSessControlPlanIndepFlag> <ciscoBfdSessAddrType> <ciscoBfdSessAddr> <localBfdSessAddr> <ciscoBfdSessDesiredMinTxInterval> <ciscoBfdSessReqMinRxInterval> <ciscoBfdSessReqMinEchoRxInterval> <ciscoBfdSessDetectMult> <remoteBfdSessDesiredMinTxInterval> <remoteBfdSessReqMinRxInterval> <remoteBfdSessReqMinEchoRxInterval> <remoteBfdSessDetectMult> <ciscoBfdSessStorType> <ciscoBfdSessRowStatus> <ciscoBfdSessAuthPresFlag> <ciscoBfdSessAuthenticationType> <ciscoBfdSessVersionNumber> <ciscoBfdSessType> <ciscoBfdSessInterface> <ciscoBfdSessPerfPktIn> <ciscoBfdSessPerfPktOut> <ciscoBfdSessUpTime> <ciscoBfdSessPerfLastSessDownTime> <ciscoBfdSessPerfLastCommLostDiag> <ciscoBfdSessPerfSessUpCount> <ciscoBfdSessPerfDiscTime> <ciscoBfdSessPerfPktInHC> <ciscoBfdSessPerfPktOutHC> <effasyncdt> <effechodt> ]
```

Syntax Description

show	Show running system information
bfd	BFD commands
session	Session
discriminator	(Optional) Session local discriminator
<i>sessionIndex</i>	(Optional)
interface	(Optional) interface
<i>intf_id</i>	(Optional) show bfd sessions based on interface id
application	(Optional) application
<i>app_name</i>	(Optional) show bfd session based on application name
src-ip	(Optional) Source ip
<i>src_ip</i>	(Optional) Source ip value
dest-ip	(Optional) Destination ip
<i>dest_ip</i>	(Optional) Destination ip value
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs

<i>__readonly__</i>	(Optional)
<i>vrf_name_header</i>	(Optional)
TABLE_bfdSessTable	(Optional) BFD Session table
<i>ciscoBfdSessIndex</i>	(Optional)
<i>isMember</i>	(Optional)
<i>ciscoBfdSessApplicationId</i>	(Optional)
<i>ciscoBfdSessDiscriminator</i>	(Optional)
<i>ciscoBfdSessRemoteDiscr</i>	(Optional)
<i>ciscoBfdSessUdpPort</i>	(Optional)
<i>ciscoBfdSessState</i>	(Optional) Session state
<i>remoteBfdSessState</i>	(Optional) Session state
<i>ciscoBfdSessRemoteHeardFlag</i>	(Optional)
<i>ciscoBfdSessDiag</i>	(Optional) Session diagnostic code
<i>remoteBfdSessDiag</i>	(Optional) Session diagnostic code
<i>ciscoBfdSessOperMode</i>	(Optional) ciscoBfdSessOperMode
<i>ciscoBfdSessDemandModeDesiredFlag</i>	(Optional)
<i>ciscoBfdSessEchoFuncModeDesiredFlag</i>	(Optional)
<i>ciscoBfdSessControlPlanIndepFlag</i>	(Optional)
<i>ciscoBfdSessAddrType</i>	(Optional) ciscoBfdSessAddrType
<i>localBfdSessAddr</i>	(Optional)
<i>ciscoBfdSessAddr</i>	(Optional)
<i>ciscoBfdSessDesiredMinTxInterval</i>	(Optional)
<i>ciscoBfdSessReqMinRxInterval</i>	(Optional)
<i>ciscoBfdSessReqMinEchoRxInterval</i>	(Optional)
<i>ciscoBfdSessDetectMult</i>	(Optional)
<i>remoteBfdSessDesiredMinTxInterval</i>	(Optional)
<i>remoteBfdSessReqMinRxInterval</i>	(Optional)
<i>remoteBfdSessReqMinEchoRxInterval</i>	(Optional)
<i>remoteBfdSessDetectMult</i>	(Optional)

<i>ciscoBfdSessStorType</i>	(Optional) ciscoBfdSessStorType
<i>ciscoBfdSessRowStatus</i>	(Optional)
<i>ciscoBfdSessAuthPresFlag</i>	(Optional)
<i>ciscoBfdSessAuthenticationType</i>	(Optional) ciscoBfdSessAuthenticationType
<i>ciscoBfdSessVersionNumber</i>	(Optional)
<i>ciscoBfdSessType</i>	(Optional) ciscoBfdSessType
<i>ciscoBfdSessInterface</i>	(Optional)
<i>ciscoBfdSessPerfPktIn</i>	(Optional)
<i>ciscoBfdSessPerfPktOut</i>	(Optional)
<i>ciscoBfdSessUpTime</i>	(Optional)
<i>ciscoBfdSessPerfLastSessDownTime</i>	(Optional)
<i>ciscoBfdSessPerfLastCommLostDiag</i>	(Optional)
<i>ciscoBfdSessPerfSessUpCount</i>	(Optional)
<i>ciscoBfdSessPerfDiscTime</i>	(Optional)
<i>ciscoBfdSessPerfPktInHC</i>	(Optional)
<i>ciscoBfdSessPerfPktOutHC</i>	(Optional)
<i>effasyncdt</i>	(Optional)
<i>effechodt</i>	(Optional)

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } { route-map {
<rmap-name> | <rmap-name> } | filter-list { <fltrlist-name> | <test_pol_name> } | { community-list {
<commlist-name> | <test_pol_name> } | extcommunity-list { <extcommlist-name> | <test_pol_name> } } [
exact-match ] } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__
TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id>
] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> |
<nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed>
<needsresync> <locked> ] [ <export-on-newlist> <export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ]
[ <mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> {
<ipnexthop> | <ipv6nexthop> } { <inlabel> <outlabel> <vpn> <hold_down> } } { <weight> <aspath>
<origin> [ <metric> ] [ <localpref> ] } } } | [ <policyincomplete> <pathvalid> <pathbest> <pathdeleted>
<pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath> <pathnolabelednrh> ] [ <importsourc>
[ <originalimportsourc> ] ] [ <importdestscout> ] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> |
<ipv6nexthop> } <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ]
<localpref> <weight> [ <aggregator> <aggregatoras> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ {
TABLE_community <community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> {
TABLE_clusterlist <clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags>
<flapindex> <flaphalflife> <flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd>
<con_ip> ] [ <psid_len> [ <psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid>
] [ <psid_origsrgrb_len> <psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh>
<remotenh_encap> <remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr>
<link-state-attr-len> ] [ <mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto
<scheduledto> ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
route-map	Display routes matching the route-map
<i>rmap-name</i>	Route-map name
<i>rmap-name</i>	Known route-map name
filter-list	Display routes matching the filter-list

<i>fltrlist-name</i>	Name of filter-list
community-list	Display routes matching the community-list
<i>commlist-name</i>	Name of community-list
extcommunity-list	Display routes matching the extcommunity-list
<i>extcommlist-name</i>	Name of extcommunity-list
<i>test_pol_name</i>	An existing test-list policy
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
ipv4	Display BGP information for IPv4 address family
vpn4	Display BGP information for VPNv4 address family
vpn6	Display BGP information for VPNv6 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
labeled-unicast	Display BGP information for labeled-unicast address family
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
exact-match	(Optional) Exact match of the communities
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)

TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)

TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)

<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalf-life</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)

<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } policy statistics { { redistribute [ { { eigrp | isis | ospf | rip } <tag> } | static | direct | amt | lisp |
hmm | am ] } | { neighbor <neighbor-id> [ default-originate | { route-map | filter-list | prefix-list } { in | out }
] } | { dampening } | { network { <ip-addr> mask <ip-mask> | <ip-prefix> } } | { aggregate-address { <ip-addr>
<ip-mask> | <ip-prefix> } { suppress-map | advertise-map } } } | vpnv4 unicast policy statistics { neighbor
<neighbor-id> [ { route-map | filter-list | prefix-list } { in | out } ] } | ipv6 { unicast | multicast } policy statistics
{ { redistribute [ { { eigrp | isis | ospfv3 | rip } <tag> } | static | direct | amt | lisp | hmm | am ] } | { neighbor
{ <neighbor-id> | <ipv6-neighbor-id> } [ default-originate | { route-map | filter-list | prefix-list } { in | out }
] } | { dampening } | { network <ipv6-prefix> } | { aggregate-address <ipv6-prefix> { suppress-map |
advertise-map } } } } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [
__readonly__ TABLE_vrf <vrf-name-polstats> [ <rpm-handle-count> ] [ { TABLE_rmap <name> <action>
<seqnum> [ { TABLE_cmd <command> <comparecount> <matchcount> } ] [ <totalacceptcount> ] [
<totalrejectcount> ] } ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
policy	Display policy related information
statistics	Display Route Filter statistics
redistribute	Statistics for redistribution
isis	(Optional) ISO IS-IS
ospf	(Optional) Open Shortest Path First
ospfv3	(Optional) Open Shortest Path First v3
rip	(Optional) Routing Information Protocol
eigrp	(Optional) Enhanced Interior Gateway Protocol

static	(Optional) Static routes
direct	(Optional) Directly connected
amt	(Optional) AMT anycast prefix
lisp	(Optional) LISP EID-prefixes in the non-default VRF
hmm	(Optional) HMM prefix
am	(Optional) AM routes (learned via ARP)
<i>tag</i>	(Optional) Source protocol tag
neighbor	Show neighbor specific counters
<i>neighbor-id</i>	Neighbor IPv4 address
route-map	(Optional) Neighbor route-map
prefix-list	(Optional) Neighbor prefix-list
filter-list	(Optional) Neighbor filter-list
out	(Optional) Outbound policy
in	(Optional) Inbound policy
default-originate	(Optional) Default-originate policy
dampening	Show dampening info
network	Configured IP prefix to advertise
mask	Configured mask of the IP prefix advertised
aggregate-address	Configured BGP aggregate prefixes
suppress-map	Statistics of suppress policy
advertise-map	Statistics of advertise policy
<i>ip-addr</i>	IP network advertised
<i>ip-mask</i>	Dotted 4-octet mask
<i>ip-prefix</i>	IP prefix in CIDR format
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-polstats</i>	(Optional)
<i>rpm-handle-count</i>	(Optional)
TABLE_rmap	(Optional)

<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seqnum</i>	(Optional)
TABLE_cmd	(Optional)
<i>command</i>	(Optional)
<i>comparecount</i>	(Optional)
<i>matchcount</i>	(Optional)
<i>totalacceptcount</i>	(Optional)
<i>totalrejectcount</i>	(Optional)

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { { ipv4 { unicast |
multicast } | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast
} [ <ip-addr> [ <ip-mask> [ longer-prefixes ] ] [ detail ] | <ip-prefix> [ longer-prefixes ] [ detail ] | labels |
exported | imported | detail ] | { ipv6 { unicast | multicast } | vpnv6 unicast [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast } [ <ipv6-prefix> [ longer-prefixes ] [ detail ] | labels |
exported | imported | detail ] | { ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] } [
<ip-addr> [ <ip-mask> ] | <ip-prefix> | labels | mdt-group <mdt-group> ] | { ipv4 | ipv6 } unicast [
injected-routes ] | link-state [ route-type <rt-type> | <ipv4-ls-rt> | <ipv6-ls-rt> ] | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } [ { <ip-addr> [ <ip-mask> ] | <ip-prefix> } ] | { ve-id
<ve-id> block-offset <ve-bs> } ] ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } [
join <v4src-addr> <v4grp-addr> <src-asn> | rp <v4src-addr> <grp-v4prefix> <pe-addr> <rp-flags> <rp-priority>
<hashlen> | sa <grp-v4prefix> | sa-ad <v4src-addr> <v4grp-addr> | route-type { 1 | 2 | 3 | 4 | 5 | 6 | 7 } [ detail
] ] | route-type { 1 | 2 | 3 | 4 | 5 | 6 | 7 } [ detail ] | join [ detail ] | sa-ad [ detail ] | i-pmsi [ detail ] ] | ipv6 mvpn
[ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } [ join <v6src-addr> <v6grp-addr> <src-asn> | rp
<v6src-addr> <grp-v6prefix> <pe-addr> <rp-flags> <rp-priority> <hashlen> | sa <grp-v6prefix> | sa-ad
<v6src-addr> <v6grp-addr> | route-type { 1 | 2 | 3 | 4 | 5 | 6 | 7 } [ detail ] ] | route-type { 1 | 2 | 3 | 4 | 5 | 6 | 7
} [ detail ] | join [ detail ] | sa-ad [ detail ] | i-pmsi [ detail ] ] | l2vpn evpn [ route-type <rtype> [ etid <et> ] |
rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } [ route-type <rtype> [ etid <et> ] | <ipv4-evpn-rt> |
<ipv6-evpn-rt> | <mac-address> ] | vni-id <vni_id> [ route-type <rtype> ] | es <es-id> [ route-type <rtype> [
etid <et> ] ] | <ipv4-evpn-rt> | <ipv6-evpn-rt> | <mac-address> ] | all [ detail ] ] [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out>
TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [
<rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion>
<totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [
<export-on-newlist> <export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path
<pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop>
} } { <inlabel> <outlabel> <vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref>
] } } } | { <policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory>
<pathovermaxaslimit> <pathmultipath> <pathnolabeledrn> ] [ <importsourc> [ <originalimportsourc> ]
] [ <importdestscout> ] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> }
<nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight>
[ <aggregator> <aggregatoras> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community
<community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist
<clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife>
<flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [
<psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origrsrgb_len>
<psid_origrsrgb_flag> <psid_origrsrgb_base> <psid_origrsrgb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> } } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context

<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>ip-addr</i>	(Optional) Display one particular network from the BRIB in detail
<i>ip-mask</i>	(Optional) Mask for one particular prefix in the BRIB
<i>ip-prefix</i>	(Optional) Display one particular prefix from the BRIB in detail
longer-prefixes	(Optional) Display route and more specific routes
labels	(Optional) Display BGP labels for prefixes
exported	(Optional) Display only exported prefixes
imported	(Optional) Display only imported prefixes
injected-routes	(Optional) Display only injected prefixes
mdt-group	(Optional) Display prefixes with MDT group address
<i>mdt-group</i>	(Optional) MDT group address
rd	(Optional) Display information for a route distinguisher
ve-id	(Optional) VPLS VE ID
<i>ve-id</i>	(Optional) VPLS VE ID
route-type	(Optional) EVPN Route Type number
<i>rtype</i>	(Optional) EVPN route type number
1	(Optional) Inter-AS PMSI AD
2	(Optional) Intra-AS PMSI AD
3	(Optional) SPMSI AD
4	(Optional) LEAF AD
5	(Optional) Source-Active AD
6	(Optional) Shared C-Multicast
7	(Optional) Source C-Multicast
vni-id	(Optional) EVPN VNI ID number
<i>vni_id</i>	(Optional) EVPN VNI ID number
<i>rt-type</i>	(Optional) Link-State route-type
es	(Optional) Ethernet Segment
<i>es-id</i>	(Optional) ESID

<i>etid</i>	(Optional) Ethernet Tag-ID for L2VPN EVPN route
<i>et</i>	(Optional) Ethernet Tag-ID
<i>ipv4-evpn-rt</i>	(Optional) EVPN IPv4 address
<i>ipv4-ls-rt</i>	(Optional) Link-State NLRI with descriptor including IPv4 address
<i>mac-address</i>	(Optional) MAC address
<i>block-offset</i>	(Optional) VPLS VE Block offset
<i>ve-bs</i>	(Optional) VPLS VE Block offset
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
<i>ipv4</i>	Display BGP information for IPv4 address family
<i>vpn4</i>	Display BGP information for VPNv4 address family
<i>vpn6</i>	Display BGP information for VPNv6 address family
<i>ipv6</i>	Display BGP information for IPv6 address family
<i>unicast</i>	Display BGP information for unicast address family
<i>multicast</i>	Display BGP information for multicast address family
<i>mdt</i>	Display BGP information for multicast distribution tree
<i>link-state</i>	Display BGP information for link-state address family
<i>l2vpn</i>	Display BGP information for L2VPN address family
<i>vpls</i>	Display BGP information for L2VPN VPLS address family
<i>labeled-unicast</i>	Display BGP information for labeled-unicast address family
<i>mvpn</i>	Display BGP information for MVPN address family
<i>evpn</i>	Display BGP information for L2VPN EVPN address family
<i>all</i>	Display BGP information for all address families
<i>join</i>	(Optional) Display Multicast Join route
<i>detail</i>	(Optional) Display detailed path info for routes
<i>sa</i>	(Optional) Display Multicast Source Active AD route
<i>sa-ad</i>	(Optional) Display Multicast Source Active AD route
<i>i-pmsi</i>	(Optional) Display Multicast Intra-AS I-PMSI route
<i>rp</i>	(Optional) Display Multicast Group to RP route

<i>v4src-addr</i>	(Optional) Source IP Address
<i>src-asn</i>	(Optional) Source ASN
<i>v4grp-addr</i>	(Optional) Group IP Address
<i>grp-v4prefix</i>	(Optional) Group IP prefix
<i>pe-addr</i>	(Optional) PE IP Address
<i>rp-flags</i>	(Optional) Flags
<i>rp-priority</i>	(Optional) RP Priority
<i>hashlen</i>	(Optional) Hash mask length
<i>l</i>	(Optional) vrf
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)

TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)

<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)

<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)

<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } { rib-install | rib-uninstall | rib-pending } [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
rib-install	Routes installed in RIB
rib-uninstall	Routes not installed in RIB
rib-pending	Routes not acknowledged by RIB

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { { ipv4 { unicast |
multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv4 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | link-state | l2vpn vpls [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | l2vpn evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4
mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast } nexthop <ipnexthop>
| { ipv6 { unicast | multicast } | vpnv6 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] |
ipv6 labeled-unicast | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] } nexthop
<ipvnexthop> } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__
TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id>
] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> |
<nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed>
<needsresync> <locked> ] [ <export-on-newlist> <export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ]
[ <mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> } {
<ipnexthop> | <ipv6nexthop> } { { <inlabel> <outlabel> <vpn> <hold_down> } } { <weight> <aspath>
<origin> [ <metric> ] [ <localpref> ] } } } | [ <policyincomplete> <pathvalid> <pathbest> <pathdeleted>
<pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath> <pathnolabelednrh> ] [ <importsourc>
[ <originalimportsourc> ] ] [ <importdestscout> ] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> |
<ipv6nexthop> } <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ]
<localpref> <weight> [ <aggregator> <aggregatoras> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ {
TABLE_community <community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> {
TABLE_clusterlist <clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags>
<flapindex> <flaphalf-life> <flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd>
<con_ip> ] [ <psid_len> [ <psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid>
] [ <psid_origsr-gb_len> <psid_origsr-gb_flag> <psid_origsr-gb_base> <psid_origsr-gb_end> ] ] [ <remotenh>
<remotenh_encap> <remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr>
<link-state-attr-len> ] [ <mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto
<scheduledto> ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
nexthop	Display routes matching the nexthop
<i>ipnexthop</i>	Nexthop address

ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
evpn	Display BGP information for L2VPN EVPN address family
mvpn	Display BGP information for MVPN address family
labeled-unicast	Display BGP information for labeled-unicast address family
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)

<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_ <i>advertisedto</i>	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_ <i>scheduledto</i>	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_ <i>path</i>	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)

<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappeny</i>	(Optional)

<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)

<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { { { ipv4 { unicast
| multicast } | vpnv4 unicast | ipv4 mdt | link-state | l2vpn vpls | l2vpn evpn | ipv4 mvpn } nexthop-database
[ <ipnexthop> ] } | { { ipv6 { unicast | multicast } | vpnv6 unicast | ipv6 mvpn } nexthop-database [
<ipv6nexthop> ] } | { all nexthop-database } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_nhvrif <nhvrif-name-out> TABLE_nhafi <nhafi>
TABLE_nhsafi <nhsafi> <af-name> <nhcriticaldelay> <nhnoncriticaldelay> [ { TABLE_nexthop {
<ipnexthop-out> | <ipv6nexthop-out> } <refcount> <igpmetric> <multipath> <igptype> <igppref> [ {
TABLE_attachedhops { <attachedhop> | <ipv6attachedhop> } <interface> [ { TABLE_labels <index> <label>
} ] } ] <attached> <local> <reachable> <labeled> <filtered> <resolvetime> { <ribroute> | <ipv6ribroute> }
{ <pendingupdate> | <pendingtime> } <nextadvertise> <rnhepoch> [ <pendingrnhepoch> ] } ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
nexthop-database	Display nexthop database
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
mdt	Display BGP information for multicast distribution tree
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
<i>ipnexthop</i>	(Optional) Nexthop address

<i>__readonly__</i>	(Optional)
TABLE_nhvr	(Optional)
<i>nhvr-name-out</i>	(Optional)
TABLE_nhafi	(Optional)
<i>nhafi</i>	(Optional)
TABLE_nhsafi	(Optional)
<i>nhsafi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>nhcriticaldelay</i>	(Optional)
<i>nhnoncriticaldelay</i>	(Optional)
TABLE_nexthop	(Optional)
<i>ipnexthop-out</i>	(Optional)
<i>refcount</i>	(Optional)
<i>igpmetric</i>	(Optional)
<i>multipath</i>	(Optional)
<i>igptype</i>	(Optional)
<i>igppref</i>	(Optional)
TABLE_attachedhops	(Optional)
<i>attachedhop</i>	(Optional)
<i>interface</i>	(Optional)
TABLE_labels	(Optional)
<i>index</i>	(Optional)
<i>label</i>	(Optional)
<i>attached</i>	(Optional)
<i>local</i>	(Optional)
<i>reachable</i>	(Optional)
<i>labeled</i>	(Optional)
<i>filtered</i>	(Optional)
<i>resolvetime</i>	(Optional)

<i>pendingupdate</i>	(Optional)
<i>pendingtime</i>	(Optional)
<i>ribroute</i>	(Optional)
<i>nextadvertise</i>	(Optional)
<i>rnhepoch</i>	(Optional)
<i>pendingrnhepoch</i>	(Optional)

Command Mode

- /exec

show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } flap-statistics [ <ip-prefix> | <ip-addr> [ <ip-mask> ] ] | ipv6 { unicast | multicast } flap-statistics
[ <ipv6-prefix> ] | all flap-statistics } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234
} ] [ __readonly__ TABLE_vrf <vrf-name-out> [ TABLE_afi <afi> TABLE_safi <safi> <af-name> [
TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [ <dampening> <historypaths> <dampenedpaths> ] [
TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <status> ] [ <pathtype> ] [ <peer> | <ipv6peer>
] [ <flapcount> ] [ <duration> ] [ <reuse> ] [ <penalty> ] [ <suppresslimit> ] [ <reuselimit> ] [ <best> ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
flap-statistics	Display route flap statistics
<i>ip-prefix</i>	(Optional) Display flap statistics for one prefix
<i>ip-addr</i>	(Optional) Display flap statistics for one network
<i>ip-mask</i>	(Optional) Network mask
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)

<i>af-name</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
<i>dampening</i>	(Optional)
<i>historypaths</i>	(Optional)
<i>dampenedpaths</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>status</i>	(Optional)
<i>best</i>	(Optional)
<i>pathtype</i>	(Optional)
<i>peer</i>	(Optional)
<i>flapcount</i>	(Optional)
<i>duration</i>	(Optional)
<i>reuse</i>	(Optional)
<i>penalty</i>	(Optional)
<i>suppresslimit</i>	(Optional)
<i>reuselimit</i>	(Optional)

Command Mode

- /exec

show bgp bmp server

```
show bgp bmp server [ <server-id> ] [ detail ] [ __readonly__ { system_name <sys_name> } {
system_description <sys_description> } [ { TABLE_servers <server_id> <server_addr> <port> <admin_state>
<oper_state> [ <description> ] <vrf> [ <update_src> ] <initial_delay> <refresh_interval> <stats_interval> [
{ <initiation> <termination> <peer_up> <peer_down> <route_monitor> <route_mirror> <stats>
<messages_dropped> } ] [ <monitored_peers> ] [ { TABLE_peer <peer_addr> [ { <refresh_interval> <peer_up>
<peer_down> <route_monitor> <route_mirror> <stats> <messages_dropped> } ] [ <prefixes_denied>
<dup_pfx_advmnt> <pfx_dup_wdr_count> <cluster_list_loops> <as_path_loops> <as_confed_loops>
<invalid_originator> <adj_rib_in> <loc-rib> } } ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
bmp	Display BMP state
server	Display BMP server information
<i>server-id</i>	(Optional) Display server specific information
detail	(Optional) Display detailed information
<u>__readonly__</u>	(Optional)
system_name	(Optional) bmp-server global information
<i>sys_name</i>	(Optional) system name
system_description	(Optional) bmp-server global information
<i>sys_description</i>	(Optional) system description
TABLE_servers	(Optional) all bmp servers
<i>server_id</i>	(Optional) server id number of bmp server
<i>server_addr</i>	(Optional) ip address of the bmp server
<i>port</i>	(Optional) port number of the bmp server
<i>admin_state</i>	(Optional) administrative status of bmp server
<i>oper_state</i>	(Optional) operational status of bmp server
<i>description</i>	(Optional) description for bmp server
<i>vrf</i>	(Optional) vrf context for bmp server
<i>update_src</i>	(Optional) updated source for bmp server
<i>initial_delay</i>	(Optional) initial delay for bmp server

<i>refresh_interval</i>	(Optional) refresh delay for bmp server
<i>stats_interval</i>	(Optional) frequency of stat updates
<i>initiation</i>	(Optional) number of initiation messages
<i>termination</i>	(Optional) number of termination messages
<i>peer_up</i>	(Optional) number of peer up messages
<i>peer_down</i>	(Optional) number of peer down messages
<i>route_monitor</i>	(Optional) number of route monitor messages
<i>route_mirror</i>	(Optional) number of route mirror messages
<i>stats</i>	(Optional) number of stats messages
<i>messages_dropped</i>	(Optional) number of dropped messages
<i>monitored_peers</i>	(Optional) number of monitored peers for the bmp server
TABLE_peer	(Optional) monitored peer for the bmp server
<i>peer_addr</i>	(Optional) ip address of the peer
<i>refresh_interval</i>	(Optional) refresh delay for the peer
<i>peer_up</i>	(Optional) number of peer up messages for the peer
<i>peer_down</i>	(Optional) number of peer down messages for the peer
<i>route_monitor</i>	(Optional) number of route monitor messages for the peer
<i>route_mirror</i>	(Optional) number of route mirror messages for the peer
<i>stats</i>	(Optional) number of stats messages for the peer
<i>messages_dropped</i>	(Optional) number of dropped messages for the peer
<i>prefixes_denied</i>	(Optional) prefixes denied for the peer
<i>dup_pfx_advmnt</i>	(Optional) dup pfx advmnt for the peer
<i>pfx_dup_wdr_count</i>	(Optional) pfx dup wdr count for the peer
<i>cluster_list_loops</i>	(Optional) cluster list loops for the peer
<i>as_path_loops</i>	(Optional) as path loops for the peer
<i>as_confed_loops</i>	(Optional) as confed loops for the peer
<i>invalid_originator</i>	(Optional) invalid originator for the peer
<i>adj_rib_in</i>	(Optional) adj-rib-in for the peer
<i>loc-rib</i>	(Optional) loc-rib for the peer

Command Mode

- /exec

show bgp community

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] |
vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } community {
<regex-str> | { { <comm-id> | <wellknown-id> } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name>
| ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi>
TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [
<rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths>
<bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <export-on-newlist>
<export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status>
<best> <type> <statuscode> <bestcode> <typecode> { { <ipnexthop> | <ipv6nexthop> } } { <inlabel> <outlabel>
<vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref> ] } } } | { {
<policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit>
<pathmultipath> <pathnolabeledrn> ] [ <importsourc> [ <originalimportsourc> ] ] [ <importdestscount>
] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> |
<ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras>
<atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> } ] [ {
TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origsrgrb_len>
<psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmssi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family

vpn4	Display BGP information for VPNv4 address family
vpn6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
labeled-unicast	Display BGP information for labeled-unicast address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
community	Display routes matching the BGP communities
<i>regexp-str</i>	Regular expression to match the communities
<i>comm-id</i>	BGP community value
<i>wellknown-id</i>	BGP wellknown community
exact-match	(Optional) Exact match of the communities
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)

<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)

<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregators</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)

<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)

<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp convergence

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] convergence [ detail
] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ <starttime>
<configdonetime> <juststarted> [ <initwaittime> ] [ <ldpconverged> ] [ <ulibconvergenesent> ] [ TABLE_vrf
<vrf-name-out> <bestpathtimeout> <configuredtimeout> <updatedelay> [ <firstpeerup> ] <timerrunning> [
<timerexpires> ] [ TABLE_afi <afi> TABLE_safi <safi> <af-name> <total_configured_peers>
<total_capable_peers> <firstbestpathsignalled> [ <firstbestpathsignalledtime> ] <firstbestpathdone> [
<firstbestpathdonetime> [ <lastbestpathsignalledtime> <lastbestpathdonetime> ] ] [ <riblicconvergenesent>
] [ <importtimerrunning> ] [ <importtimerexpires> ] [ { TABLE_rcvdpeers [ <peer> ] [ <ipv6peer> ] [
<signalledtimepeer> } ] [ { TABLE_notrcvdpeers [ <notpeer> ] [ <notipv6peer> ] [ <nokeepalive> ] [
<notsignalledtime> } ] } ] }
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
convergence	Display information about convergence
detail	(Optional) Display detailed information about convergence
__readonly__	(Optional)
<i>starttime</i>	(Optional)
<i>configdonetime</i>	(Optional)
<i>juststarted</i>	(Optional)
<i>initwaittime</i>	(Optional)
<i>ldpconverged</i>	(Optional)
<i>ulibconvergenesent</i>	(Optional)
TABLE_vrf	(Optional)
<i>total_configured_peers</i>	(Optional)
<i>total_capable_peers</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>bestpathtimeout</i>	(Optional)
<i>configuredtimeout</i>	(Optional)

<i>updatedelay</i>	(Optional)
<i>firstpeerup</i>	(Optional)
<i>timerrunning</i>	(Optional)
<i>timerexpires</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>firstbestpathsignalled</i>	(Optional)
<i>firstbestpathsignalledtime</i>	(Optional)
<i>firstbestpathdone</i>	(Optional)
<i>firstbestpathdonetime</i>	(Optional)
<i>lastbestpathsignalledtime</i>	(Optional)
<i>lastbestpathdonetime</i>	(Optional)
<i>ribbibconvergencesent</i>	(Optional)
<i>importtimerrunning</i>	(Optional)
<i>importtimerexpires</i>	(Optional)
TABLE_rcvdpeers	(Optional)
<i>peer</i>	(Optional)
<i>signalledtimepeer</i>	(Optional)
TABLE_notrcvdpeers	(Optional)
<i>notpeer</i>	(Optional)
<i>nokeepalive</i>	(Optional)
<i>notsignalledtime</i>	(Optional)

Command Mode

- /exec

show bgp convergence private

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] convergence private
[ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
convergence	Display information about convergence
private	Display private information about convergence

Command Mode

- /exec

show bgp dampening dampened

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } dampening {
dampened-paths [ regexp <regexp-str> ] | history-paths [ regexp <regexp-str> ] } [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out>
TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [
<rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion>
<totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [
<export-on-newlist> <export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path
<pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop>
} } { <inlabel> <outlabel> <vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref>
] } } } | { [ <policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory>
<pathovermaxaslimit> <pathmultipath> <pathnolabeledrnh> ] [ <importsourc> [ <originalimportsourc> ]
] [ <importdestscout> ] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> }
<nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight>
[ <aggregator> <aggregatoras> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community
<community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist
<clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife>
<flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [
<psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origrsgb_len>
<psid_origrsgb_flag> <psid_origrsgb_base> <psid_origrsgb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
dampened-paths	Display all dampened paths
history-paths	Display all history paths
dampening	Display dampening info
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format

<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
vpn4	Display BGP information for VPNv4 address family
vpn6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
labeled-unicast	Display BGP information for labeled-unicast address family
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
regex	(Optional) Display routes matching the AS path regular expression
<i>regex-str</i>	(Optional) Regular expression to match the AS paths
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)

<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)

<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)

<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)

<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
<i>dampening</i>	(Optional)
<i>historypaths</i>	(Optional)
<i>dampenedpaths</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>status</i>	(Optional)
<i>best</i>	(Optional)
<i>pathtype</i>	(Optional)
<i>peer</i>	(Optional)
<i>flapcount</i>	(Optional)
<i>duration</i>	(Optional)

<i>reuse</i>	(Optional)
<i>penalty</i>	(Optional)
<i>suppresslimit</i>	(Optional)
<i>reuselimit</i>	(Optional)

Command Mode

- /exec

show bgp dampening parameters

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } dampening
parameters [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__
TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ TABLE_rd [ <rd_val> ] [
<rd_vrf> ] [ <rd_vniid> ] [ <rpmname> ] [ TABLE_rpm <rpmindex> <rpmdamphalflife> <rpm dampsuppress>
<rpm dampreuse> <rpm dampsuppressstime> <rpm dampmaxpenalty> ] [ <dampconfigured> <damp halflife>
<damp suppress> <damp reuse> <damp suppressstime> <damp maxpenalty> ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
dampening	Display dampening info
parameters	Display dampening parameters
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
labeled-unicast	Display BGP information for labeled-unicast address family
link-state	Display BGP information for link-state address family

l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional) VRF RD
<i>rd_vniid</i>	(Optional)
TABLE_rpm	(Optional)
<i>rpmname</i>	(Optional)
<i>rpmindex</i>	(Optional)
<i>rpmdamphalflife</i>	(Optional)
<i>rpm damp suppress</i>	(Optional)
<i>rpm damp reuse</i>	(Optional)
<i>rpm damp suppress time</i>	(Optional)
<i>rpm damp max penalty</i>	(Optional)
<i>damp configured</i>	(Optional)
<i>damp halflife</i>	(Optional)
<i>damp suppress</i>	(Optional)
<i>damp reuse</i>	(Optional)

show bgp dampening parameters

<i>dampsuppresstime</i>	(Optional)
<i>dampmaxpenalty</i>	(Optional)

Command Mode

- /exec

show bgp event-history

show bgp [internal] event-history { <bgp-event-hist> | events | errors | msgs | detail | periodic | objstore | developer }

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
internal	(Optional) Commands for internal use
event-history	Show various event logs of BGP
<i>bgp-event-hist</i>	Show BGP event log
detail	Show detailed event logs
events	Show event logs of BGP
errors	Show error logs of BGP
msgs	Show various message logs of BGP
objstore	Show objstore logs of BGP
developer	Show developer logs of BGP
periodic	Show periodic logs of BGP

Command Mode

- /exec

show bgp evi

```
show bgp evi [ <evi-id> ] [ __readonly__ [ TABLE_ctx <eid> <rd> <numlocalprefixes> <numtotalprefixes>
<created> <lastoperup> <lastoperdown> <enabled> [ <associatedvrf> ] [ TABLE_activeexportrts <exportrt>
] [ TABLE_activeimportrts <importrt> ] [ TABLE_evpnactiveexportrts <evpnexportrt> ] [
TABLE_evpnactiveimportrts <evpnimportrt> ] [ TABLE_mvnpactiveexportrts <mvpnexportrt> ] [
TABLE_mvnpactiveimportrts <mvpnimportrt> ] [ TABLE_activeexportrtsv6 <exportrtv6> ] [
TABLE_activeimportrtsv6 <importrtv6> ] [ TABLE_evpnactiveexportrtsv6 <evpnexportrtv6> ] [
TABLE_evpnactiveimportrtsv6 <evpnimportrtv6> ] [ TABLE_mvnpactiveexportrtsv6 <mvpnexportrtv6> ]
[ TABLE_mvnpactiveimportrtsv6 <mvpnimportrtv6> ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
evi	Display information about EVI database
<i>evi-id</i>	(Optional) EVI Id
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>eid</i>	(Optional)
<i>rd</i>	(Optional)
<i>numlocalprefixes</i>	(Optional)
<i>numtotalprefixes</i>	(Optional)
<i>created</i>	(Optional)
<i>lastoperup</i>	(Optional)
<i>lastoperdown</i>	(Optional)
<i>enabled</i>	(Optional)
<i>associatedvrf</i>	(Optional)
TABLE_activeexportrts	(Optional)
TABLE_activeimportrts	(Optional)
TABLE_evpnactiveexportrts	(Optional)
TABLE_evpnactiveimportrts	(Optional)
TABLE_mvnpactiveexportrts	(Optional)
TABLE_mvnpactiveimportrts	(Optional)

TABLE_activeexportrtsv6	(Optional)
TABLE_activeimportrtsv6	(Optional)
TABLE_evpnactiveexportrtsv6	(Optional)
TABLE_evpnactiveimportrtsv6	(Optional)
TABLE_mvpnactiveexportrtsv6	(Optional)
TABLE_mvpnactiveimportrtsv6	(Optional)
<i>importrt</i>	(Optional)
<i>exportrt</i>	(Optional)
<i>evpnimportrt</i>	(Optional)
<i>evpnexportrt</i>	(Optional)
<i>mvpnimportrt</i>	(Optional)
<i>mvpnexportrt</i>	(Optional)
<i>importrtv6</i>	(Optional)
<i>exportrtv6</i>	(Optional)
<i>evpnimportrtv6</i>	(Optional)
<i>evpnexportrtv6</i>	(Optional)
<i>mvpnimportrtv6</i>	(Optional)
<i>mvpnexportrtv6</i>	(Optional)

Command Mode

- /exec

show bgp extcommunity

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } extcommunity
{ <regex-str> | { { 4byteas-generic { transitive <ext-comm-gen-trans> | non-transitive
<ext-comm-gen-nontrans> } } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi
<safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [
TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [
<on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <export-on-newlist>
<export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status>
<best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop> } { <inlabel> <outlabel>
<vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref> ] } } } | { {
<policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit>
<pathmultipath> <pathnolabeledrn> ] [ <importsourc> [ <originalimportsourc> ] ] [ <importdestscount>
] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> |
<ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras>
<atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> } ] [ {
TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origsrgrb_len>
<psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmssi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
ipv4	Display BGP information for IPv4 address family

ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
link-state	Display BGP information for link-state address family
labeled-unicast	Display BGP information for labeled-unicast address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
extcommunity	Display routes matching the BGP extcommunities
4byteas-generic	Generic extended community
<i>regexp-str</i>	Regular expression to match the extcommunities
transitive	Transitive extcommunity
non-transitive	Non-Transitive extcommunity
<i>ext-comm-gen-trans</i>	Extcommunity number aa4:nn format
<i>ext-comm-gen-nontrans</i>	Extcommunity number aa4:nn format
exact-match	(Optional) Exact match of the extcommunities
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)

<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)

<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)

<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)

<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp l3vpn

```
show bgp l3vpn [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [
__readonly__ TABLE_vrf <vrf-name-out> [ <vrf-id> ] [ <vrf-rd> ] [ <vrf-state> ] [ <vrf-state-rsn> ] [
<vrf-pending-rd> ] [ { TABLE_af <af-id> [ <af-name> ] [ <af-table-id> ] [ <af-state> ] [ <af-state-rsn> ] [
<af-num-peers> ] [ <af-num-active-peers> ] [ <af-peer-routes> ] [ <af-peer-paths> ] [ <af-peer-networks> ]
[ <af-peer-aggregates> ] [ <af-export-rmap> ] [ <af-import-rmap> ] [ <af-retain-rt> ] [ TABLE_export_rt
<export-rt> ] [ TABLE_import_rt <import-rt> ] [ TABLE_evpn_export_rt <evpn-export-rt> ] [
TABLE_evpn_import_rt <evpn-import-rt> ] [ TABLE_mvpn_export_rt <mvpn-export-rt> ] [
TABLE_mvpn_import_rt <mvpn-import-rt> ] [ <af-label-mode> ] [ <af-aggregate-label> ] } ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
l3vpn	BGP l3vpn information
vrf	(Optional) Virtual Router Context
detail	(Optional) Detailed information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional) Read Only
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional) VRF name
<i>vrf-id</i>	(Optional) VRF ID
<i>vrf-state</i>	(Optional) VRF State
<i>vrf-state-rsn</i>	(Optional) VRF State Reason
<i>vrf-rd</i>	(Optional) VRF RD
<i>vrf-pending-rd</i>	(Optional) VRF pending RD
TABLE_af	(Optional)
<i>af-id</i>	(Optional) AF ID
<i>af-table-id</i>	(Optional) AF table
<i>af-name</i>	(Optional) AF table name
<i>af-state</i>	(Optional) AF table state
<i>af-state-rsn</i>	(Optional) AF table state reason

<i>af-num-peers</i>	(Optional) No. of peers
<i>af-num-active-peers</i>	(Optional) No. of active peers
<i>af-peer-routes</i>	(Optional) No. of peer routes
<i>af-peer-paths</i>	(Optional) No. of peer paths
<i>af-peer-networks</i>	(Optional) No. of peer networks
<i>af-peer-aggregates</i>	(Optional) No. of aggregates
<i>af-export-rmap</i>	(Optional) Export route-map
<i>af-import-rmap</i>	(Optional) Import route-map
<i>af-retain-rt</i>	(Optional) Retain RT
TABLE_export_rt	(Optional)
<i>export-rt</i>	(Optional) Export route-target
TABLE_import_rt	(Optional)
<i>import-rt</i>	(Optional) Import route-target
TABLE_evpn_export_rt	(Optional)
<i>evpn-export-rt</i>	(Optional) Export EVPN route-target
TABLE_evpn_import_rt	(Optional)
<i>evpn-import-rt</i>	(Optional) Import EVPN route-target
TABLE_mvpn_export_rt	(Optional)
<i>mvpn-export-rt</i>	(Optional) Export MVPN route-target
TABLE_mvpn_import_rt	(Optional)
<i>mvpn-import-rt</i>	(Optional) Import MVPN route-target
<i>af-label-mode</i>	(Optional) Label allocation mode
<i>af-aggregate-label</i>	(Optional) Aggregate Label

Command Mode

- /exec

show bgp neighbors

```
show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] } { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | ipv6 labeled-unicast | ipv4
labeled-unicast | l2vpn evpn } neighbors { <neighbor-id> | <ipv6-neighbor-id> } { routes [ advertised | received
| dampened ] | advertised-routes | received-routes } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi
<safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [
TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [
<on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <export-on-newlist>
<export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status>
<best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop> } { { <inlabel> <outlabel>
<vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref> ] } } } | { [
<policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit>
<pathmultipath> <pathnolabeledrn> ] [ <importsource> [ <originalimportsource> ] ] [ <importdestscount>
] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> |
<ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras>
<atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> } ] [ {
TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflaps> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origsrgrb_len>
<psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
neighbors	Display all configured BGP neighbors
<i>neighbor-id</i>	Display one particular BGP neighbor
ipv4	Display BGP information for IPv4 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
labeled-unicast	Display BGP information for labeled-unicast address family
ipv6	Display BGP information for IPv6 address family

unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
l2vpn	Display BGP information for L2VPN address family
evpn	Display BGP information for L2VPN EVPN address family
routes	Display all routes advertised/received to/from peer
advertised	(Optional) Display all routes advertised to this peer
received	(Optional) Display all routes received from this peer
advertised-routes	Display all the routes advertised to this peer
received-routes	Display all the routes received from this peer
dampened	(Optional) Display all dampened routes received from this peer
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)

<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_ <i>advertisedto</i>	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_ <i>scheduledto</i>	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_ <i>path</i>	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)

<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregadoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)

<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)

<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp neighbors

```
show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | ipv6 labeled-unicast |
link-state | l2vpn vpls | l2vpn evpn | ipv4 mvpn | ipv6 mvpn | ipv4 labeled-unicast } neighbors [ { <neighbor-id>
| <ipv6-neighbor-id> | <neighbor-prefix-id> | <ipv6-neighbor-prefix-id> } ] [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ [ TABLE_neighbor { <neighbor>
| <ipv6neighbor> | <templatepeer> | <ipv4prefixneighbor> | <ipv6prefixneighbor> } ] [ <remoteas> ] [ <localas>
] [ <link> ] [ <peertype> ] [ <index> ] [ TABLE_peer <peer> ] [ <maxprefixpeers> ] [ <configpeer> ] [
<inherit-template> ] [ <inherit-session-template> ] [ { <prefix-parent> | <ipv6prefix-parent> } ] [ <description>
] [ <version> <remote-id> <state> <up> [ <elapsedtime> ] [ <restarttime> ] ] [ <sourcecif> ] [ <connectedif>
] [ <connectedcheck> ] [ <lowmemexempt> ] [ <bfd> ] [ <bfdmintxinterval> ] [ <bfdminrxinterval> ] [
<bfdmultiplier> ] [ <bfdauthenticationtype> ] [ <ttlsecurity> ] [ <ttllimit> ] [ <password> ] [ <passiveonly>
] [ <activepeers> <closingpeers> <maxconcurrentpeers> ] [ <allocatedpeers> ] [ <totalpeersaccepted> ] [
<localas-inactive> ] <remove-privateas> { { [ <lastread> ] <holdtime> <keepalivetime> [ <lastwrite> ] [
<keepalive> ] <msgrecvd> <notificationsrcvd> <rcvbufbytesinq> <msgsent> <notificationssent>
<sentbytesoutstanding> <sentbytespacked> <connsestablished> <connsdropped> [ <connattempts> ] } { [
<peerresettime> ] <peerresetreason> [ <resettime> ] <resetreason> } } { [ <resettime> ] <resetreason> [
<peerresettime> ] <peerresetreason> } } [ <capsnegotiated> <capmpadvertised> [ <caprefreshadvertised>
<capgrdynamicadvertised> ] [ <capmprecvd> <caprefreshrecvd> <capgrdynamicrecvd> ] [
<capolddynamicadvertised> <capolddynamicrecvd> <caprradvertised> <caprrrecvd> <capoldrradvertised>
<capoldrrrecvd> <capas4advertised> <capas4recvd> ] [ { TABLE_af <af-afi> TABLE_saf <af-safi>
<af-advertised> <af-recvd> <af-name> } ] [ <capgradvertised> <capgrrecvd> ] [ { TABLE_graf <gr-afi>
TABLE_grsaf <gr-safi> <gr-af-name> <gr-adv> <gr-recv> <gr-fwd> } ] [ <grrestarttime> <grstaletime> ] [
<grrecvrestarttime> ] [ [ { TABLE_addpathscapaf <addpathscap-afi> TABLE_addpathscapsaf
<addpathscap-safi> <addpathscap-af-name> <addpathssendcap-adv> <addpathsrecvcap-adv>
<addpathssendcap-recv> <addpathsrecvcap-recv> } ] [ <capaddpathsadvertised> <capaddpathsrecvd> ] ] [
<capextendednhadvertised> <capextendednhrecvd> ] [ { TABLE_capextendednhaf <capextendednh-afi>
TABLE_capextendednhsaf <capextendednh-safi> <capextendednh-af-name> } ] ] } [ <configholdtime>
<configkeepalivetime> ] } ] [ <epe> ] [ <epe-adj-sids> ] [ <epe-peer-rpc-set> ] [ <epe-peer-sid> ] [
<epe-peer-set-name> ] [ <epe-peer-set-rpc-set> ] [ <epe-peer-set-sid> ] [ { TABLE_epe-adj { {
<epe-adj-ip-local> <epe-adj-ip-remote> } } { <epe-adj-ipv6-local> <epe-adj-ipv6-remote> } } ] [
<epe-adj-ifindex> <epe-adj-rpc-set> <epe-adj-sid> } ] [ <grstate> <grexpiry> ] [ <firstkeepalive> ] [
<openssent> <opensrecvd> <updatesent> <updatesrecvd> <keepalivesent> <keepaliverecvd> <rtrefreshsent>
<rtrefreshrecvd> <capabilitiesent> <capabilitiesrecvd> <bytesent> <bytesrecvd> ] [ TABLE_peraf <per-afi>
TABLE_persaf <per-safi> <per-af-name> [ <tableversion> ] [ <neighbortableversion> ] [ <pfxrecvd> ] [
<pathsrecvd> ] [ <pfxbytes> ] [ <pfxsent> ] [ <pathssent> ] [ <conditionmap> <advertisemap>
<advertisemapstatus> ] [ <insoftreconfigallowed> [ <insoftreconfigallowedalways> ] [ <sendcommunity> ] [
<sendextcommunity> ] [ { <localnexthop> | <ipv6localnexthop> } ] [ <thirdpartynexthop> ] [ <maxpfx> ] [
<maxpfx_threshold> ] [ <soo> ] [ <weight> ] [ <allowasin> ] <asoverride> <peerascheckdisabled> [
<vplssignalingprotocol> ] [ { TABLE_inpolicy <inpolicynr> <inpolicytype> <inpolicyname> [
<inpolicyhandle> } ] ] [ { TABLE_outpolicy <outpolicynr> <outpolicytype> <outpolicyname> [
<outpolicyhandle> } ] ] <rrconfigured> <defaultoriginate> [ <defaultoriginatemap> ] [ <defaultsent> ] [
<grpathsaved> ] [ <firsteorrecvd> ] [ <firsteortime> ] [ <pathsflushed> ] [ <lasteorrecvtime> ] [
<lasteorsenttime> ] [ <firstconvgttime> ] [ <pfxsentfirsteor> ] [ <unsuppress-map> ] [ { TABLE_policy_template
<preference> <inherit-policy-template> } ] ] [ <threadid> ] [ <passivethreadid> <passivefd> ] [ { <localaddr>
| <ipv6localaddr> } <localport> { <remoteaddr> | <ipv6remoteaddr> } <remoteport> <fd> } ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
neighbors	Display all configured BGP neighbors
<i>neighbor-id</i>	(Optional) Display one particular BGP neighbor
<i>neighbor-prefix-id</i>	(Optional) Display details for a prefix peering
ipv4	Display BGP information for IPv4 address family
vpn4	Display BGP information for VPNv4 address family
vpn6	Display BGP information for VPNv6 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
labeled-unicast	Display BGP information for labeled-unicast address family
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
<i>__readonly__</i>	(Optional)
<i>TABLE_neighbor</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>templatepeer</i>	(Optional)
<i>ipv4prefixneighbor</i>	(Optional)
<i>remoteas</i>	(Optional)
<i>localas</i>	(Optional)
<i>link</i>	(Optional)

<i>index</i>	(Optional)
TABLE_peer	(Optional)
<i>peer</i>	(Optional)
<i>maxprefixpeers</i>	(Optional)
<i>configpeer</i>	(Optional)
<i>inherit-template</i>	(Optional)
<i>inherit-session-template</i>	(Optional)
<i>prefix-parent</i>	(Optional)
<i>description</i>	(Optional)
<i>version</i>	(Optional)
<i>remote-id</i>	(Optional)
<i>state</i>	(Optional)
<i>up</i>	(Optional)
<i>elapsedtime</i>	(Optional)
<i>restarttime</i>	(Optional)
<i>peertype</i>	(Optional)
<i>sourceif</i>	(Optional)
<i>connectedif</i>	(Optional)
<i>connectedcheck</i>	(Optional)
<i>lowmemexempt</i>	(Optional)
<i>bfd</i>	(Optional)
<i>bfdmintxinterval</i>	(Optional)
<i>bfdminrxinterval</i>	(Optional)
<i>bfdmultiplier</i>	(Optional)
<i>bfdauthenticationtype</i>	(Optional)
<i>ttlsecurity</i>	(Optional)
<i>tllimit</i>	(Optional)
<i>localas-inactive</i>	(Optional)
<i>passiveonly</i>	(Optional)

<i>activepeers</i>	(Optional)
<i>closingpeers</i>	(Optional)
<i>maxconcurrentpeers</i>	(Optional)
<i>allocatedpeers</i>	(Optional)
<i>totalpeersaccepted</i>	(Optional)
<i>password</i>	(Optional)
<i>remove-privateas</i>	(Optional)
<i>lastread</i>	(Optional)
<i>holdtime</i>	(Optional)
<i>keepalivetime</i>	(Optional)
<i>lastwrite</i>	(Optional)
<i>keepalive</i>	(Optional)
<i>msgrecvd</i>	(Optional)
<i>notificationsrcvd</i>	(Optional)
<i>rcvbufbytesinq</i>	(Optional)
<i>msgsent</i>	(Optional)
<i>notificationssent</i>	(Optional)
<i>sentbytesoutstanding</i>	(Optional)
<i>sentbytespacked</i>	(Optional)
<i>connsestablished</i>	(Optional)
<i>connsdropped</i>	(Optional)
<i>connattempts</i>	(Optional)
<i>peerresettime</i>	(Optional)
<i>peerresetreason</i>	(Optional)
<i>resettime</i>	(Optional)
<i>resetreason</i>	(Optional)
<i>configholdtime</i>	(Optional)
<i>configkeepalivetime</i>	(Optional)
<i>grstate</i>	(Optional)

<i>gexpiry</i>	(Optional)
<i>firstkeepalive</i>	(Optional)
<i>epe</i>	(Optional)
<i>epe-adj-sids</i>	(Optional)
<i>epe-peer-rpc-set</i>	(Optional)
<i>epe-peer-sid</i>	(Optional)
<i>epe-peer-set-name</i>	(Optional)
<i>epe-peer-set-rpc-set</i>	(Optional)
<i>epe-peer-set-sid</i>	(Optional)
TABLE_ <i>epe-adj</i>	(Optional)
<i>epe-adj-ip-local</i>	(Optional)
<i>epe-adj-ip-remote</i>	(Optional)
<i>epe-adj-ifindex</i>	(Optional)
<i>epe-adj-rpc-set</i>	(Optional)
<i>epe-adj-sid</i>	(Optional)
<i>openssent</i>	(Optional)
<i>opensrcvd</i>	(Optional)
<i>updatesent</i>	(Optional)
<i>updatesrcvd</i>	(Optional)
<i>keepalivesent</i>	(Optional)
<i>keepaliverecvd</i>	(Optional)
<i>rtrefreshsent</i>	(Optional)
<i>rtrefreshrcvd</i>	(Optional)
<i>capabilitiesent</i>	(Optional)
<i>capabilitiesrcvd</i>	(Optional)
<i>bytessent</i>	(Optional)
<i>bytesrcvd</i>	(Optional)
<i>threadid</i>	(Optional)
<i>fd</i>	(Optional)

<i>passivethreadid</i>	(Optional)
<i>passivefd</i>	(Optional)
<i>localaddr</i>	(Optional)
<i>localport</i>	(Optional)
<i>remoteaddr</i>	(Optional)
<i>remoteport</i>	(Optional)
<i>capsnegotiated</i>	(Optional)
<i>capmpadvertising</i>	(Optional)
<i>capgrdynamicadvertising</i>	(Optional)
<i>capaddpathsadvertising</i>	(Optional)
<i>caprefreshadvertising</i>	(Optional)
<i>capmprecvd</i>	(Optional)
<i>capgrdynamicrecvd</i>	(Optional)
<i>capaddpathsrecvd</i>	(Optional)
<i>caprefreshrecvd</i>	(Optional)
<i>capolddynamicadvertising</i>	(Optional)
<i>capolddynamicrecvd</i>	(Optional)
<i>caprradvertising</i>	(Optional)
<i>caprrrecvd</i>	(Optional)
<i>capoldrradvertising</i>	(Optional)
<i>capoldrrrecvd</i>	(Optional)
<i>capas4advertising</i>	(Optional)
<i>capas4recvd</i>	(Optional)
TABLE_af	(Optional)
<i>af-afi</i>	(Optional)
TABLE_saf	(Optional)
<i>af-safi</i>	(Optional)
<i>af-advertising</i>	(Optional)
<i>af-recvd</i>	(Optional)

<i>af-name</i>	(Optional)
<i>capgradvertised</i>	(Optional)
<i>capgrrecvd</i>	(Optional)
TABLE_graf	(Optional)
<i>gr-afi</i>	(Optional)
TABLE_grsaf	(Optional)
<i>gr-safi</i>	(Optional)
<i>gr-af-name</i>	(Optional)
<i>gr-adv</i>	(Optional)
<i>gr-recv</i>	(Optional)
<i>gr-fwd</i>	(Optional)
<i>grrestarttime</i>	(Optional)
<i>grstaletime</i>	(Optional)
<i>grrecvdrestarttime</i>	(Optional)
TABLE_addpathscapaf	(Optional)
<i>addpathscap-afi</i>	(Optional)
TABLE_addpathscapsaf	(Optional)
<i>addpathscap-safi</i>	(Optional)
<i>addpathscap-af-name</i>	(Optional)
<i>addpathssendcap-adv</i>	(Optional)
<i>addpathsrecvcap-adv</i>	(Optional)
<i>addpathssendcap-recv</i>	(Optional)
<i>addpathsrecvcap-recv</i>	(Optional)
<i>capextendednhadvertised</i>	(Optional)
<i>capextendednhrecvd</i>	(Optional)
TABLE_capextendednhaf	(Optional)
<i>capextendednh-afi</i>	(Optional)
TABLE_capextendednhsaf	(Optional)
<i>capextendednh-safi</i>	(Optional)

<i>capextendednh-af-name</i>	(Optional)
TABLE_peraf	(Optional)
<i>per-afi</i>	(Optional)
TABLE_persaf	(Optional)
<i>per-safi</i>	(Optional)
<i>per-af-name</i>	(Optional)
<i>tableversion</i>	(Optional)
<i>neighbortableversion</i>	(Optional)
<i>pfxrcvd</i>	(Optional)
<i>pathsrcvd</i>	(Optional)
<i>pfxbytes</i>	(Optional)
<i>pfxsent</i>	(Optional)
<i>pathsstent</i>	(Optional)
<i>conditionmap</i>	(Optional)
<i>advertisemap</i>	(Optional)
<i>advertisemapstatus</i>	(Optional)
<i>insoftreconfigallowed</i>	(Optional)
<i>insoftreconfigallowedalways</i>	(Optional)
<i>sendcommunity</i>	(Optional)
<i>sendextcommunity</i>	(Optional)
<i>maxpfx</i>	(Optional)
<i>maxpfx_threshold</i>	(Optional)
<i>localnethop</i>	(Optional)
TABLE_inpolicy	(Optional)
<i>inpolicynr</i>	(Optional)
<i>inpolicytype</i>	(Optional)
<i>inpolicyname</i>	(Optional)
<i>inpolicyhandle</i>	(Optional)
TABLE_outpolicy	(Optional)

<i>outpolicynr</i>	(Optional)
<i>outpolicytype</i>	(Optional)
<i>outpolicyname</i>	(Optional)
<i>outpolicyhandle</i>	(Optional)
<i>rrconfigured</i>	(Optional)
<i>defaultoriginate</i>	(Optional)
<i>defaultoriginatemap</i>	(Optional)
<i>defaultsent</i>	(Optional)
<i>grpathssaved</i>	(Optional)
<i>firsteorrecvd</i>	(Optional)
<i>firsteortime</i>	(Optional)
<i>pathsflushed</i>	(Optional)
<i>lasteorrecvtime</i>	(Optional)
<i>lasteorsenttime</i>	(Optional)
<i>firstconvgtime</i>	(Optional)
<i>pfxsentfirsteor</i>	(Optional)
<i>unsuppress-map</i>	(Optional)
<i>thirdpartynexthop</i>	(Optional)
<i>soo</i>	(Optional)
<i>weight</i>	(Optional)
<i>allowasin</i>	(Optional)
<i>asoverride</i>	(Optional)
<i>peerascheckdisabled</i>	(Optional)
<i>vplssignalingprotocol</i>	(Optional)
TABLE_policy_template	(Optional)
<i>preference</i>	(Optional)
<i>inherit-policy-template</i>	(Optional)

Command Mode

- /exec

show bgp neighbors commands

```
show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | l2vpn evpn } neighbors {
<neighbor-id> | <ipv6-neighbor-id> } commands [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ [ { TABLE_sesscmd <sessioncmd> <sessioncmdstatus>
[ <sessioncmdtemplate> ] } ] [ TABLE_af <af-afi> TABLE_saf <af-safi> <af-name> [ { TABLE_polcmd
<polycycmd> <polycycmdstatus> [ <polycycmdtemplate> ] } ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>neighbor-id</i>	Display one particular BGP neighbor
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
l2vpn	Display BGP information for L2VPN address family
evpn	Display BGP information for L2VPN EVPN address family
neighbors	Display all configured BGP neighbors
commands	Display details on commands
<i>__readonly__</i>	(Optional)
<i>TABLE_sesscmd</i>	(Optional)
<i>sessioncmd</i>	(Optional)
<i>sessioncmdstatus</i>	(Optional)
<i>sessioncmdtemplate</i>	(Optional)

TABLE_af	(Optional)
<i>af-afi</i>	(Optional)
TABLE_saf	(Optional)
<i>af-safi</i>	(Optional)
<i>af-name</i>	(Optional)
TABLE_polcmd	(Optional)
<i>polycmd</i>	(Optional)
<i>polycmdstatus</i>	(Optional)
<i>polycmdtemplate</i>	(Optional)

Command Mode

- /exec

show bgp neighbors flap-statistics

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } neighbors { <neighbor-id> | <ipv6-neighbor-id> } flap-statistics
[ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf
<vrf-name-out> [ TABLE_afi <afi> TABLE_safi <safi> <af-name> [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [
<rd_vniid> ] ] [ <dampening> <historypaths> <dampenedpaths> ] [ TABLE_prefix { <ipprefix> | <ipv6prefix>
| <nonipprefix> } ] [ <status> ] [ <pathtype> ] [ <peer> | <ipv6peer> ] [ <flapcount> ] [ <duration> ] [ <reuse>
] [ <penalty> ] [ <suppresslimit> ] [ <reuselimit> ] [ <best> ] ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
neighbors	Display all configured BGP neighbors
<i>neighbor-id</i>	Display one particular BGP neighbor
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
flap-statistics	Display flap statistics for routes received from this peer
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
TABLE_rd	(Optional)

<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
<i>dampening</i>	(Optional)
<i>historypaths</i>	(Optional)
<i>dampenedpaths</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>status</i>	(Optional)
<i>best</i>	(Optional)
<i>pathtype</i>	(Optional)
<i>peer</i>	(Optional)
<i>flapcount</i>	(Optional)
<i>duration</i>	(Optional)
<i>reuse</i>	(Optional)
<i>penalty</i>	(Optional)
<i>suppresslimit</i>	(Optional)
<i>reuselimit</i>	(Optional)

Command Mode

- /exec

show bgp neighbors paths

```
show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | ipv6 labeled-unicast | ipv4
labeled-unicast | link-state | l2vpn evpn } neighbors { <neighbor-id> | <ipv6-neighbor-id> } paths [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf
<vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ TABLE_id <id> <hashvalue> <refcount>
<metric> <aspath> ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
neighbors	Display all configured BGP neighbors
<i>neighbor-id</i>	Display one particular BGP neighbor
ipv4	Display BGP information for IPv4 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
labeled-unicast	Display BGP information for labeled-unicast address family
link-state	Display BGP information for link-state address family
all	Display BGP information for all address families
l2vpn	Display BGP information for L2VPN address family
evpn	Display BGP information for L2VPN EVPN address family
paths	Display AS paths learned from this peer
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)

TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
TABLE_id	(Optional)
<i>id</i>	(Optional)
<i>hashvalue</i>	(Optional)
<i>refcount</i>	(Optional)
<i>metric</i>	(Optional)
<i>aspath</i>	(Optional)

Command Mode

- /exec

show bgp paths

```
show [ ip ] bgp paths [ __readonly__ TABLE_id <id> <hashvalue> <refcount> <metric> <aspath> <origin> ]
```

Syntax Description

show	Show running system information
ip	(Optional) Display IP information
bgp	Display BGP status and configuration
paths	Display Path information
__readonly__	(Optional)
TABLE_id	(Optional)
<i>id</i>	(Optional)
<i>hashvalue</i>	(Optional)
<i>refcount</i>	(Optional)
<i>metric</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)

Command Mode

- /exec

show bgp peer-template

```
show [ ip ] bgp peer-template [ <peer-template-name> ] [ __readonly__ { TABLE_neighbor <templatepeer>
[ <remoteas> ] [ <inherit-template> ] [ <inherit-session-template> ] [ { <prefix-parent> | <ipv6prefix-parent>
} ] [ <description> ] [ <sourceif> ] [ <connectedcheck> ] [ <lowmemexempt> ] [ <bfd> ] [ <bfdmintxinterval>
] [ <bfdminrxinterval> ] [ <bfdmultiplier> ] [ <bfdauthenticationtype> ] [ <ttlsecurity> ] [ <ttllimit> ] [
<password> ] [ <passiveonly> ] <localas-inactive> [ <remove-privateas> ] [ <configholdtime>
<configkeepalivetime> ] [ TABLE_peraf <per-afi> TABLE_persaf <per-safi> <per-af-name> [ <tableversion>
] [ <neighbortableversion> ] [ <pfxrcvd> ] [ <pathsrecvd> ] [ <pfxbytes> ] [ <pfxsent> ] [ <pathsstent> ] [
<conditionmap> <advertisemap> <advertisemapstatus> ] [ <insoftreconfigallowed> ] [
<insoftreconfigallowedalways> ] [ <sendcommunity> ] [ <sendextcommunity> ] [ { <localnexthop> |
<ipv6localnexthop> } ] [ <thirdpartynexthop> ] [ <maxpfx> ] [ <maxpfx_threshold> ] [ <soo> ] [ <weight>
] [ <allowasin> ] [ <asoverride> ] [ <peerascheckdisabled> ] [ <vplssignalingprotocol> ] [ { TABLE_inpolicy
<inpolicynr> <inpolicytype> <inpolicyname> [ <inpolicyhandle> } ] [ { TABLE_outpolicy <outpolicynr>
<outpolicytype> <outpolicyname> [ <outpolicyhandle> } ] ] [ <rrconfigured> <defaultoriginate> [
<defaultoriginatormap> ] [ <defaultsent> ] [ <grpathssaved> ] [ <firsteorrecvd> ] [ <firsteortime> ] [
<pathsflushed> ] [ <lasteorrecvtime> ] [ <lasteorsenttime> ] [ <firstconvgtime> ] [ <pfxsentfirsteor> ] [
<unsuppress-map> ] [ { TABLE_policy_template <preference> <inherit-policy-template> } ] [ TABLE_vrf
<vrf-name> [ TABLE_inheritingpeer <inheritingpeer> ] ] }
```

Syntax Description

show	Show running system information
ip	(Optional) Display IP information
bgp	Display BGP status and configuration
peer-template	Display information about a peer-template
<i>peer-template-name</i>	(Optional) Peer-template name
<i>__readonly__</i>	(Optional)
TABLE_neighbor	(Optional)
<i>templatepeer</i>	(Optional)
<i>remoteas</i>	(Optional)
<i>inherit-template</i>	(Optional)
<i>inherit-session-template</i>	(Optional)
<i>prefix-parent</i>	(Optional)
<i>description</i>	(Optional)
<i>sourceif</i>	(Optional)
<i>connectedcheck</i>	(Optional)
<i>lowmemexempt</i>	(Optional)

<i>bfd</i>	(Optional)
<i>bfdmintxinterval</i>	(Optional)
<i>bfdminrxinterval</i>	(Optional)
<i>bfdmultiplier</i>	(Optional)
<i>bfdauthenticationtype</i>	(Optional)
<i>ttlsecurity</i>	(Optional)
<i>tllimit</i>	(Optional)
<i>passiveonly</i>	(Optional)
<i>password</i>	(Optional)
<i>localas-inactive</i>	(Optional)
<i>remove-privateas</i>	(Optional)
<i>configholdtime</i>	(Optional)
<i>configkeepalivetime</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_inheritingpeer	(Optional)
<i>inheritingpeer</i>	(Optional)
TABLE_peraf	(Optional)
<i>per-afi</i>	(Optional)
TABLE_persaf	(Optional)
<i>per-safi</i>	(Optional)
<i>per-af-name</i>	(Optional)
<i>tableversion</i>	(Optional)
<i>neighbortableversion</i>	(Optional)
<i>pfxrcvd</i>	(Optional)
<i>pathsrcvd</i>	(Optional)
<i>pfxbytes</i>	(Optional)
<i>pfxsent</i>	(Optional)
<i>pathssent</i>	(Optional)

<i>conditionmap</i>	(Optional)
<i>advertisemap</i>	(Optional)
<i>advertisemapstatus</i>	(Optional)
<i>insoftreconfigallowed</i>	(Optional)
<i>insoftreconfigallowedalways</i>	(Optional)
<i>sendcommunity</i>	(Optional)
<i>sendextcommunity</i>	(Optional)
<i>maxpfx</i>	(Optional)
<i>maxpfx_threshold</i>	(Optional)
<i>localnexthop</i>	(Optional)
TABLE_inpolicy	(Optional)
<i>inpolicynr</i>	(Optional)
<i>inpolicytype</i>	(Optional)
<i>inpolicyname</i>	(Optional)
<i>inpolicyhandle</i>	(Optional)
TABLE_outpolicy	(Optional)
<i>outpolicynr</i>	(Optional)
<i>outpolicytype</i>	(Optional)
<i>outpolicyname</i>	(Optional)
<i>outpolicyhandle</i>	(Optional)
<i>rrconfigured</i>	(Optional)
<i>defaultoriginate</i>	(Optional)
<i>defaultoriginatermap</i>	(Optional)
<i>defaultsent</i>	(Optional)
<i>grpathssaved</i>	(Optional)
<i>firsteorrecvd</i>	(Optional)
<i>firsteortime</i>	(Optional)
<i>pathsflushed</i>	(Optional)
<i>lasteorrecvtime</i>	(Optional)

<i>lasteorsenttime</i>	(Optional)
<i>firstconvgtme</i>	(Optional)
<i>pfxsentfirsteor</i>	(Optional)
<i>unsuppress-map</i>	(Optional)
<i>thirdpartynexthop</i>	(Optional)
<i>soo</i>	(Optional)
<i>weight</i>	(Optional)
<i>allowasin</i>	(Optional)
<i>asoverride</i>	(Optional)
<i>peerascheckdisabled</i>	(Optional)
<i>vplssignalingprotocol</i>	(Optional)
TABLE_policy_template	(Optional)
<i>preference</i>	(Optional)
<i>inherit-policy-template</i>	(Optional)

Command Mode

- /exec

show bgp peer

```
show [ ip ] bgp { peer-session [ <session-template-name> ] | peer-policy [ <policy-template-name> ] } [
__readonly__ TABLE_template <template> <present> [ { TABLE_command <command> [ <polarity> ] [
<updatesource> ] [ <description> ] [ <multihop> ] [ <holdtime> ] [ <keepalive> ] [ <routemapin> ] [
<routemapout> ] [ <filterlistin> ] [ <filterlistout> ] [ <prefixlistin> ] [ <prefixlistout> ] [ <maxprefixlimit> ]
[ <defaultorigin> ] } ] [ { TABLE_vrf <vrf-name> { TABLE_peer <inheritingpeer> } } ] ] ]
```

Syntax Description

show	Show running system information
ip	(Optional) Display IP information
bgp	Display BGP status and configuration
peer-session	Display information about a peer-session
peer-policy	Display information about a peer-policy
<i>session-template-name</i>	(Optional) Peer-session name
<i>policy-template-name</i>	(Optional) Peer-policy name
<i>__readonly__</i>	(Optional)
TABLE_template	(Optional)
<i>template</i>	(Optional)
<i>present</i>	(Optional)
TABLE_command	(Optional)
<i>command</i>	(Optional)
<i>polarity</i>	(Optional)
<i>updatesource</i>	(Optional)
<i>description</i>	(Optional)
<i>multihop</i>	(Optional)
<i>holdtime</i>	(Optional)
<i>keepalive</i>	(Optional)
<i>routemapin</i>	(Optional)
<i>routemapout</i>	(Optional)
<i>filterlistin</i>	(Optional)
<i>filterlistout</i>	(Optional)

<i>prefixlistin</i>	(Optional)
<i>prefixlistout</i>	(Optional)
<i>maxprefixlimit</i>	(Optional)
<i>defaultorigin</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_peer	(Optional)
<i>inheritingpeer</i>	(Optional)

Command Mode

- /exec

show bgp prefix-list

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } } prefix-list { <prfxlist-name> | <test_pol_name> } [ vrf { <vrf-name>
| <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out>
TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [
<rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion>
<totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [
<export-on-newlist> <export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path
<pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop>
} { { <inlabel> <outlabel> <vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref>
] } } } | [ <policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory>
<pathovermaxaslimit> <pathmultipath> <pathnolabeledrn> ] [ <importsource> [ <originalimportsource> ]
] [ <importdstscount> ] [ <existpath> ] [ <aspath> <source> ] [ <ipnexthop> | <ipv6nexthop> }
<nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight>
[ <aggregator> <aggregators> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community
<community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist
<clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife>
<flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [
<psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origrsgb_len>
<psid_origrsgb_flag> <psid_origrsgb_base> <psid_origrsgb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmssi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
prefix-list	Display routes matching the prefix-list
<i>prfxlist-name</i>	Name of prefix-list
<i>test_pol_name</i>	An existing test-list policy
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
__readonly__	(Optional)

TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)

<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)

<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)

<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp private

```
show bgp private [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { all_private
| session | ipc | rnh | lists | rpm-info [ route-map <rpm-name> { <ip-prefix> | <ipv6-prefix> } ] | attr [ {
<ip-prefix> } ] | rpm-attribute-cache | rpm-comm-attr-cache | virtual [ summary ] } [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
private	Show BGP information intended for developer eyes only
all_private	Show all info
session	Show session info
lists	Show BGP internal lists
route-map	(Optional) Show information for route-map
rpm-info	Show BGP policy outbound info
<i>ip-prefix</i>	(Optional) Show attribute for a prefix
<i>rpm-name</i>	(Optional) Route-map name
attr	Show attribute information
ipc	Show ipc information
rnh	Show recursive next hops
rpm-attribute-cache	Show rpm attribute cache statistics
rpm-comm-attr-cache	Show rpm community attribute cache statistics
summary	(Optional) Summary only
virtual	Virtualization related
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show bgp private attr

```
show bgp private attr [ remote-nh ] [ [ [ ipv4 { unicast | multicast } <ip-prefix> ] ] [ ipv6 { unicast | multicast } <ipv6-prefix> ] ] [ detail ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
private	Show BGP information intended for developer eyes only
attr	Show BGP attributes
remote-nh	(Optional) Show Remote NH Attr
ipv4	(Optional) Display BGP information for IPv4 address family
ipv6	(Optional) Display BGP information for IPv6 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
detail	(Optional) Show detailed info
<i>ip-prefix</i>	(Optional) Show attribute for a prefix

Command Mode

- /exec

show bgp private damp

```
show bgp private [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 {
unicast | multicast } | ipv6 { unicast | multicast } | all } damp [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
private	Show BGP information intended for developer eyes only
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
damp	Show dampening info

Command Mode

- /exec

show bgp private debug history

show bgp private debug history { all | ead-es | es | mac }

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
private	Show BGP information intended for developer eyes only
debug	Debug
history	history
all	all
ead-es	ead-es
es	es
mac	mac

Command Mode

- /exec

show bgp process

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] process [ detail ] [
vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ [ <processid>
<protocolstartedreason> <protocoltag> <protocolstate> [ <isolatemode> ] <mmode> <memorystate> [
<mallocmemorystate> ] [ <platformmemorystate> ] [ <lowmemorytimer> ] [ <issu> ] <forwardingstatesaved>
<asformat> [ <fabricsoo> ] [ <srgbmin> <srgbmax> ] [ <epeconfiguredpeers> <epeactivepeers> ]
<attributeentries> <hwmattributeentries> <bytesused> <entriespendingdelete> <hwmentriespendingdelete>
<pathsperattribute> <aspathentries> <aspathbytes> ] TABLE_vrf <vrf-name-out> [ <vrf-id> ] [ <vrf-state>
] [ <vrf-state-rsn> ] [ <vrf-delete-pending> ] [ <vrf-evpn-mpls> ] [ <vrf-vni-id> ] [ <vrf-vni-id-valid> ] [
<vrf-topo-id> ] [ <vrf-encap-type> ] [ <vrf-vtep-ip> ] [ <vrf-vtep-virtual-ip> ] [ <vrf-vtep-vipr> ] [
<vrf-router-mac> ] [ <vrf-vip-router-mac> ] [ <vrf-vipr-router-mac> ] [ <vrf-router-id> ] [ <vrf-cfgd-id> ] [
<vrf-local-as> ] [ <vrf-confed-id> ] [ <vrf-cluster-id> ] [ <vrf-reconnect-interval> ] [ <vrf-peers> ] [
<vrf-pending-peers> ] [ <vrf-est-peers> ] [ <vrf-cfgd-max-as-limit> ] [ <vrf-max-as-limit> ] [
<vrf-rd-configured> ] [ <vrf-rd> ] [ <vrf-pending-rd> ] [ { TABLE_af <af-id> [ <af-name> ] [ <af-table-id> ]
[ <af-state> ] [ <af-state-rsn> ] [ <af-num-peers> ] [ <af-num-active-peers> ] [ <af-peer-routes> ] [
<af-peer-paths> ] [ <af-peer-networks> ] [ <af-peer-aggregates> ] [ <af-export-rmap> ] [ <af-import-rmap>
] [ <af-retain-rt> ] [ { TABLE_redist <protocol> <route-map> } ] <wait-igp-convergence> [ {
TABLE_add_paths_selection <route-map> } ] [ TABLE_export_rt <export-rt> ] [ TABLE_import_rt
<import-rt> ] [ TABLE_evpn_export_rt <evpn-export-rt> ] [ TABLE_evpn_import_rt <evpn-import-rt> ] [
TABLE_mvpn_export_rt <mvpn-export-rt> ] [ TABLE_mvpn_import_rt <mvpn-import-rt> ] [ <af-label-mode>
] [ <af-aggregate-label> ] [ <importdefault_prefixlimit> <importdefault_prefixcount> <importdefault_map>
] [ <exportdefault_prefixlimit> <exportdefault_prefixcount> <exportdefault_map> ] <af-rr>
<default-information-enabled> [ <default-information-rd> <default-information-rt> ]
<nexthop-trigger-delay-critical> <nexthop-trigger-delay-non-critical> [ <nexthop-route-map> ] } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
process	BGP global information
detail	(Optional) Detailed information
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional) Read Only
<i>processid</i>	(Optional)
<i>protocolstartedreason</i>	(Optional)
<i>protocoltag</i>	(Optional)
<i>protocolstate</i>	(Optional)
<i>isolatemode</i>	(Optional)

<i>mmode</i>	(Optional)
<i>memorystate</i>	(Optional)
<i>mallocmemorystate</i>	(Optional)
<i>platformmemorystate</i>	(Optional)
<i>lowmemorytimer</i>	(Optional)
<i>issu</i>	(Optional)
<i>forwardingstatesaved</i>	(Optional)
<i>asformat</i>	(Optional)
<i>attributeentries</i>	(Optional)
<i>fabricsoo</i>	(Optional)
<i>srgbmin</i>	(Optional)
<i>srgbmax</i>	(Optional)
<i>epeconfiguredpeers</i>	(Optional)
<i>epeactivepeers</i>	(Optional)
<i>hwmattributeentries</i>	(Optional)
<i>bytesused</i>	(Optional)
<i>entriespendingdelete</i>	(Optional)
<i>hwmentriespendingdelete</i>	(Optional)
<i>pathsperattribute</i>	(Optional)
<i>aspathentries</i>	(Optional)
<i>aspathbytes</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional) VRF name
<i>vrf-id</i>	(Optional) VRF ID
<i>vrf-state</i>	(Optional) VRF State
<i>vrf-state-rsn</i>	(Optional) VRF State Reason
<i>vrf-delete-pending</i>	(Optional) VRF delete pending
<i>vrf-evpn-mpls</i>	(Optional) VRF EVPN L3 MPLS
<i>vrf-vni-id</i>	(Optional) VRF VNI ID

<i>vrf-vni-id-valid</i>	(Optional) VRF VNI ID validity
<i>vrf-topo-id</i>	(Optional) VRF Topo ID
<i>vrf-encap-type</i>	(Optional) VRF encapsulation type
<i>vrf-vtep-ip</i>	(Optional) VRF VTEP IP
<i>vrf-vtep-virtual-ip</i>	(Optional) VRF VTEP Virtual IP
<i>vrf-vtep-vipr</i>	(Optional) VRF VTEP Virtual IP for Re-origination
<i>vrf-router-mac</i>	(Optional) VRF Router MAC
<i>vrf-vip-router-mac</i>	(Optional) VRF VIP Router MAC
<i>vrf-vipr-router-mac</i>	(Optional) VRF VIPR Router MAC
<i>vrf-router-id</i>	(Optional) Router ID
<i>vrf-cfgd-id</i>	(Optional) Configured Router-ID
<i>vrf-local-as</i>	(Optional) Local AS
<i>vrf-confed-id</i>	(Optional) Cluster-ID
<i>vrf-cluster-id</i>	(Optional) Cluster-ID
<i>vrf-reconnect-interval</i>	(Optional) VRF reconnect interval
<i>vrf-peers</i>	(Optional) No. of configured peers
<i>vrf-pending-peers</i>	(Optional) No. of pending peers
<i>vrf-est-peers</i>	(Optional) No. of established peers
<i>vrf-cfgd-max-as-limit</i>	(Optional) Configured maxas-limit
<i>vrf-max-as-limit</i>	(Optional) Active maxas-limit
<i>vrf-rd-configured</i>	(Optional) VRF RD Configured
<i>vrf-rd</i>	(Optional) VRF RD
<i>vrf-pending-rd</i>	(Optional) VRF pending RD
TABLE_af	(Optional)
<i>af-id</i>	(Optional) AF ID
<i>af-table-id</i>	(Optional) AF table
<i>af-name</i>	(Optional) AF table name
<i>af-state</i>	(Optional) AF table state
<i>af-state-rsn</i>	(Optional) AF table state reason

<i>af-num-peers</i>	(Optional) No. of peers
<i>af-num-active-peers</i>	(Optional) No. of active peers
<i>af-peer-routes</i>	(Optional) No. of peer routes
<i>af-peer-paths</i>	(Optional) No. of peer paths
<i>af-peer-networks</i>	(Optional) No. of peer networks
<i>af-peer-aggregates</i>	(Optional) No. of aggregates
<i>af-export-rmap</i>	(Optional) Export route-map
<i>af-import-rmap</i>	(Optional) Import route-map
<i>af-retain-rt</i>	(Optional) Retain RT
TABLE_redist	(Optional)
<i>protocol</i>	(Optional) Protocol
<i>route-map</i>	(Optional) Route Map
<i>wait-igp-convergence</i>	(Optional)
TABLE_add_paths_selection	(Optional)
<i>route-map</i>	(Optional) Route Map
TABLE_export_rt	(Optional)
<i>export-rt</i>	(Optional) Export route-target
TABLE_import_rt	(Optional)
<i>import-rt</i>	(Optional) Import route-target
TABLE_evpn_export_rt	(Optional)
<i>evpn-export-rt</i>	(Optional) Export EVPN route-target
TABLE_evpn_import_rt	(Optional)
<i>evpn-import-rt</i>	(Optional) Import EVPN route-target
TABLE_mvpn_export_rt	(Optional)
<i>mvpn-export-rt</i>	(Optional) Export MVPN route-target
TABLE_mvpn_import_rt	(Optional)
<i>mvpn-import-rt</i>	(Optional) Import MVPN route-target
<i>af-label-mode</i>	(Optional) Label allocation mode
<i>af-aggregate-label</i>	(Optional) Aggregate Label

<i>importdefault_prefixlimit</i>	(Optional) Maximum number of prefixes allowed
<i>importdefault_prefixcount</i>	(Optional) Current number of prefixes
<i>importdefault_map</i>	(Optional) Configured route-map
<i>exportdefault_prefixlimit</i>	(Optional) Maximum number of prefixes allowed
<i>exportdefault_prefixcount</i>	(Optional) Current number of prefixes
<i>exportdefault_map</i>	(Optional) Configured route-map
<i>af-rr</i>	(Optional) Is a Route-reflector
<i>default-information-enabled</i>	(Optional) Default-information originate is enabled
<i>default-information-rd</i>	(Optional) Default-information originate RD
<i>default-information-rt</i>	(Optional) Default-information originate RT
<i>nexthop-trigger-delay-critical</i>	(Optional)
<i>nexthop-trigger-delay-non-critical</i>	(Optional)
<i>nexthop-route-map</i>	(Optional)

Command Mode

- /exec

show bgp received-paths

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } received-paths
[ private ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__
TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id>
] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> |
<nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed>
<needsresync> <locked> ] [ <export-on-newlist> <export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ]
[ <mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> {
<ipnexthop> | <ipv6nexthop> } { <inlabel> <outlabel> <vpn> <hold_down> } } { <weight> <aspath>
<origin> [ <metric> ] [ <localpref> ] } } } | [ <policyincomplete> <pathvalid> <pathbest> <pathdeleted>
<pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath> <pathnolabelednrh> ] [ <importsourc>
[ <originalimportsourc> ] ] [ <importdestscout> ] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> |
<ipv6nexthop> } <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ]
<localpref> <weight> [ <aggregator> <aggregatoras> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ {
TABLE_community <community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> {
TABLE_clusterlist <clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags>
<flapindex> <flaphalflife> <flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd>
<con_ip> ] [ <psid_len> [ <psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid>
] [ <psid_origsrgrb_len> <psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh>
<remotenh_encap> <remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr>
<link-state-attr-len> ] [ <mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto
<scheduledto> ] ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
received-paths	Display paths stored for soft-reconfig
rd	(Optional) Display information for a route distinguisher
<i>ext-comm-rd-aa4nn2</i>	(Optional) VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	(Optional) VPN route distinguisher in aa:nn format
ipv4	Display BGP information for IPv4 address family

ipv6	Display BGP information for IPv6 address family
vpnv4	Display BGP information for VPNv4 address family
vpnv6	Display BGP information for VPNv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
mdt	Display BGP information for multicast distribution tree
labeled-unicast	Display BGP information for labeled-unicast address family
link-state	Display BGP information for link-state address family
l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
private	(Optional) private
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)

show bgp received-paths

<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)

<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)

<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)

<i>psid</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp regexp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } regexp <regexp-str> [ vrf { <vrf-name> | <vrf-known-name>
| ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi>
TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [
<rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths>
<bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <export-on-newlist>
<export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status>
<best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop> } { <inlabel> <outlabel>
<vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric> ] [ <localpref> ] } } } | { [
<policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit>
<pathmultipath> <pathnolabeledrn> ] [ <importsourc> [ <originalimportsourc> ] ] [ <importdestscount>
] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> |
<ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras>
<atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> } ] [ {
TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origsrgrb_len>
<psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
regexp	Display routes matching the AS path regular expression
<i>regexp-str</i>	Regular expression to match the AS paths
__readonly__	(Optional)

TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)

<i>export-on-newlist</i>	(Optional)
<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)

<i>pathstaled</i>	(Optional)
<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)

<i>evpn-esi</i>	(Optional)
<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origrsrb_len</i>	(Optional)
<i>psid_origrsrb_flag</i>	(Optional)
<i>psid_origrsrb_base</i>	(Optional)
<i>psid_origrsrb_end</i>	(Optional)

Command Mode

- /exec

show bgp self-originated

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } self-originated [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi
<safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [
TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [
<on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <export-on-newlist>
<export-on-xmitlist> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status>
<best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop> } { { <inlabel> <outlabel>
<vpn> <hold_down> } } { <weight> <aspath> <origin> [ <metric> ] [ <localpref> ] } } } | { [
<policyincomplete> <pathvalid> <pathbest> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit>
<pathmultipath> <pathnolabelednrh> ] [ <importsource> [ <originalimportsource> ] ] [ <importdestscount>
] [ <existpath> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> |
<ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras>
<atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> } ] [ {
TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_v6sid> ] [ <psid_origsrgrb_len>
<psid_origsrgrb_flag> <psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<mdt_grp_addr> } } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ]
]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv4	Display BGP information for IPv4 address family
ipv6	Display BGP information for IPv6 address family
unicast	Display BGP information for unicast address family
multicast	Display BGP information for multicast address family
all	Display BGP information for all address families
self-originated	Self originated routes
__readonly__	(Optional)
TABLE_vrf	(Optional)

<i>vrf-name-out</i>	(Optional)
TABLE_afi	(Optional)
<i>afi</i>	(Optional)
TABLE_safi	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>table-version</i>	(Optional)
<i>router-id</i>	(Optional)
TABLE_rd	(Optional)
<i>rd_val</i>	(Optional)
<i>rd_vrf</i>	(Optional)
<i>rd_vniid</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>nonipprefix</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>bestpathnr</i>	(Optional)
<i>mpath</i>	(Optional)
TABLE_advertisedto	(Optional)
<i>advertisedto</i>	(Optional)
TABLE_scheduledto	(Optional)
<i>scheduledto</i>	(Optional)
<i>prefixversion</i>	(Optional)
<i>on-newlist</i>	(Optional)
<i>on-xmitlist</i>	(Optional)
<i>suppressed</i>	(Optional)
<i>needsresync</i>	(Optional)
<i>locked</i>	(Optional)
<i>export-on-newlist</i>	(Optional)

<i>export-on-xmitlist</i>	(Optional)
<i>locallabel</i>	(Optional)
<i>labelhldwstr</i>	(Optional)
TABLE_path	(Optional)
<i>pathnr</i>	(Optional)
<i>best</i>	(Optional)
<i>status</i>	(Optional)
<i>type</i>	(Optional)
<i>statuscode</i>	(Optional)
<i>bestcode</i>	(Optional)
<i>typecode</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>neighbor</i>	(Optional)
<i>neighborid</i>	(Optional)
<i>metric</i>	(Optional)
<i>localpref</i>	(Optional)
<i>weight</i>	(Optional)
<i>importsource</i>	(Optional)
<i>originalimportsource</i>	(Optional)
<i>importdestscount</i>	(Optional)
<i>existpath</i>	(Optional)
<i>aspath</i>	(Optional)
<i>origin</i>	(Optional)
<i>source</i>	(Optional)
<i>policyincomplete</i>	(Optional)
<i>pathvalid</i>	(Optional)
<i>pathbest</i>	(Optional)
<i>pathdeleted</i>	(Optional)
<i>pathstaled</i>	(Optional)

<i>pathhistory</i>	(Optional)
<i>pathmultipath</i>	(Optional)
<i>pathovermaxaslimit</i>	(Optional)
<i>pathnolabeledrn</i>	(Optional)
<i>nexthopmetric</i>	(Optional)
<i>aggregator</i>	(Optional)
<i>aggregatoras</i>	(Optional)
<i>atomicaggregate</i>	(Optional)
<i>inlabel</i>	(Optional)
<i>originflag</i>	(Optional)
<i>vpn</i>	(Optional)
<i>hold_down</i>	(Optional)
<i>outlabel</i>	(Optional)
<i>flappenalty</i>	(Optional)
<i>dampenedtime</i>	(Optional)
<i>flaps</i>	(Optional)
<i>flaptime</i>	(Optional)
<i>flapflags</i>	(Optional)
<i>flapindex</i>	(Optional)
<i>flaphalflife</i>	(Optional)
<i>flapreuse</i>	(Optional)
<i>flapsuppress</i>	(Optional)
<i>flapmax</i>	(Optional)
<i>con_type</i>	(Optional)
<i>con_len</i>	(Optional)
<i>con_rd</i>	(Optional)
<i>con_ip</i>	(Optional)
<i>mdt_grp_addr</i>	(Optional)
<i>evpn-esi</i>	(Optional)

<i>link-state-attr</i>	(Optional)
<i>link-state-attr-len</i>	(Optional)
TABLE_community	(Optional)
<i>community</i>	(Optional)
TABLE_extcommunity	(Optional)
<i>extcommunity</i>	(Optional)
<i>originatorid</i>	(Optional)
TABLE_clusterlist	(Optional)
<i>clusterlist</i>	(Optional)
<i>remotenh</i>	(Optional)
<i>remotenh_encap</i>	(Optional)
<i>remotenh_vnid</i>	(Optional)
<i>remotenh_mac</i>	(Optional)
<i>pmsi</i>	(Optional)
<i>psid_len</i>	(Optional)
<i>psid_lindx_len</i>	(Optional)
<i>psid_lindx_flag</i>	(Optional)
<i>psid_lindx</i>	(Optional)
<i>psid_v6sid_len</i>	(Optional)
<i>psid_origsrgb_len</i>	(Optional)
<i>psid_origsrgb_flag</i>	(Optional)
<i>psid_origsrgb_base</i>	(Optional)
<i>psid_origsrgb_end</i>	(Optional)

Command Mode

- /exec

show bgp sessions

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] sessions [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ <totalpeers>
<totalestablishedpeers> <localas> TABLE_vrf <vrf-name-out> <local-as> <vrfpeers> <vrfestablishedpeers>
<router-id> [ TABLE_neighbor <neighbor-id> <connectionsdropped> <remotemas> [ <lastflap> ] [ <lastread>
] [ <lastwrite> ] <state> <localport> <remoteport> <notificationssent> <notificationreceived> ] ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
sessions	Display session information for all peers
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>local-as</i>	(Optional)
<i>totalpeers</i>	(Optional)
<i>totalestablishedpeers</i>	(Optional)
<i>router-id</i>	(Optional)
<i>localas</i>	(Optional)
<i>vrfpeers</i>	(Optional)
<i>vrfestablishedpeers</i>	(Optional)
TABLE_neighbor	(Optional)
<i>neighbor-id</i>	(Optional)
<i>connectionsdropped</i>	(Optional)
<i>remotemas</i>	(Optional)
<i>lastflap</i>	(Optional)
<i>lastread</i>	(Optional)
<i>lastwrite</i>	(Optional)

<i>state</i>	(Optional)
<i>localport</i>	(Optional)
<i>remoteport</i>	(Optional)
<i>notificationssent</i>	(Optional)
<i>notificationsreceived</i>	(Optional)

Command Mode

- /exec

show bgp statistics

```
show bgp statistics [ __readonly__ <msgsent> <msgrcvd> <bytesent> <bytercvd> <opensent> <openrcvd>
<updatesent> <updaterecvd> <kasent> <karecvd> <notifsent> <notifrcvd> <rrefreshsent> <rrefreshrcvd>
<capsent> <caprcvd> ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
statistics	BGP global statistics
__readonly__	(Optional)
<i>msgsent</i>	(Optional)
<i>msgrcvd</i>	(Optional)
<i>bytesent</i>	(Optional)
<i>bytercvd</i>	(Optional)
<i>opensent</i>	(Optional)
<i>openrcvd</i>	(Optional)
<i>updatesent</i>	(Optional)
<i>updaterecvd</i>	(Optional)
<i>kasent</i>	(Optional)
<i>karecvd</i>	(Optional)
<i>notifsent</i>	(Optional)
<i>notifrcvd</i>	(Optional)
<i>rrefreshsent</i>	(Optional)
<i>rrefreshrcvd</i>	(Optional)
<i>capsent</i>	(Optional)
<i>caprcvd</i>	(Optional)

Command Mode

- /exec

<i>vrf-state</i>	(Optional) VRF State
<i>vrf-state-rsn</i>	(Optional) VRF State Reason
<i>vrf-delete-pending</i>	(Optional) VRF delete pending
<i>vrf-evpn-mpls</i>	(Optional) VRF EVPN L3 MPLS
<i>vrf-vni-id</i>	(Optional) VRF VNI ID
<i>vrf-vni-id-valid</i>	(Optional) VRF VNI ID validity
<i>vrf-topo-id</i>	(Optional) VRF Topo ID
<i>vrf-encap-type</i>	(Optional) VRF encapsulation type
<i>vrf-vtep-ip</i>	(Optional) VRF VTEP IP
<i>vrf-vtep-virtual-ip</i>	(Optional) VRF VTEP Virtual IP
<i>vrf-vtep-vipr</i>	(Optional) VRF VTEP Virtual IP for Re-origination
<i>vrf-router-mac</i>	(Optional) VRF Router MAC
<i>vrf-vip-router-mac</i>	(Optional) VRF VIP Router MAC
<i>vrf-vipr-router-mac</i>	(Optional) VRF VIPR Router MAC
<i>vrf-router-id</i>	(Optional) Router ID
<i>vrf-cfgd-id</i>	(Optional) Configured Router-ID
<i>vrf-local-as</i>	(Optional) Local AS
<i>vrf-confed-id</i>	(Optional) Cluster-ID
<i>vrf-cluster-id</i>	(Optional) Cluster-ID
<i>vrf-reconnect-interval</i>	(Optional) VRF reconnect interval
<i>vrf-peers</i>	(Optional) No. of configured peers
<i>vrf-pending-peers</i>	(Optional) No. of pending peers
<i>vrf-est-peers</i>	(Optional) No. of established peers
<i>vrf-cfgd-max-as-limit</i>	(Optional) Configured maxas-limit
<i>vrf-max-as-limit</i>	(Optional) Active maxas-limit
<i>vrf-rd-configured</i>	(Optional) VRF RD Configured
<i>vrf-rd</i>	(Optional) VRF RD
<i>vrf-pending-rd</i>	(Optional) VRF pending RD
TABLE_af	(Optional)

<i>af-id</i>	(Optional) AF ID
<i>af-table-id</i>	(Optional) AF table
<i>af-name</i>	(Optional) AF table name
<i>af-state</i>	(Optional) AF table state
<i>af-state-rsn</i>	(Optional) AF table state reason
<i>af-num-peers</i>	(Optional) No. of peers
<i>af-num-active-peers</i>	(Optional) No. of active peers
<i>af-peer-routes</i>	(Optional) No. of peer routes
<i>af-peer-paths</i>	(Optional) No. of peer paths
<i>af-peer-networks</i>	(Optional) No. of peer networks
<i>af-peer-aggregates</i>	(Optional) No. of aggregates
<i>af-export-rmap</i>	(Optional) Export route-map
<i>af-import-rmap</i>	(Optional) Import route-map
<i>af-retain-rt</i>	(Optional) Retain RT
TABLE_saf	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>tableversion</i>	(Optional)
<i>configuredpeers</i>	(Optional)
<i>capablepeers</i>	(Optional)
<i>totalnetworks</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>memoryused</i>	(Optional)
<i>numberattrs</i>	(Optional)
<i>bytesattrs</i>	(Optional)
<i>numberpaths</i>	(Optional)
<i>bytespaths</i>	(Optional)
<i>numbercommunities</i>	(Optional)
<i>bytescommunities</i>	(Optional)

<i>numberclusterlist</i>	(Optional)
<i>bytesclusterlist</i>	(Optional)
<i>dampening</i>	(Optional)
<i>historypaths</i>	(Optional)
<i>dampenedpaths</i>	(Optional)
<i>softreconfigrecvdpaths</i>	(Optional)
<i>softreconfigidenticalpaths</i>	(Optional)
<i>softreconfigcombopaths</i>	(Optional)
<i>softreconfigfilteredrecvd</i>	(Optional)
<i>softreconfigbytes</i>	(Optional)
TABLE_neighbor	(Optional)
<i>neighborid</i>	(Optional)
<i>neighborversion</i>	(Optional)
<i>neighboras</i>	(Optional)
<i>msgrecvd</i>	(Optional)
<i>msgsent</i>	(Optional)
<i>neighbortableversion</i>	(Optional)
<i>inq</i>	(Optional)
<i>outq</i>	(Optional)
<i>time</i>	(Optional)
<i>state</i>	(Optional)
<i>prefixreceived</i>	(Optional)

Command Mode

- /exec

l2vpn	Display BGP information for L2VPN address family
vpls	Display BGP information for L2VPN VPLS address family
mvpn	Display BGP information for MVPN address family
evpn	Display BGP information for L2VPN EVPN address family
all	Display BGP information for all address families
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional) VRF name
<i>vrf-id</i>	(Optional) VRF ID
<i>vrf-state</i>	(Optional) VRF State
<i>vrf-state-rsn</i>	(Optional) VRF State Reason
<i>vrf-delete-pending</i>	(Optional) VRF delete pending
<i>vrf-evpn-mpls</i>	(Optional) VRF EVPN L3 MPLS
<i>vrf-vni-id</i>	(Optional) VRF VNI ID
<i>vrf-vni-id-valid</i>	(Optional) VRF VNI ID validity
<i>vrf-topo-id</i>	(Optional) VRF Topo ID
<i>vrf-encap-type</i>	(Optional) VRF encapsulation type
<i>vrf-vtep-ip</i>	(Optional) VRF VTEP IP
<i>vrf-vtep-virtual-ip</i>	(Optional) VRF VTEP Virtual IP
<i>vrf-vtep-vipr</i>	(Optional) VRF VTEP Virtual IP for Re-origination
<i>vrf-router-mac</i>	(Optional) VRF Router MAC
<i>vrf-vip-router-mac</i>	(Optional) VRF VIP Router MAC
<i>vrf-vipr-router-mac</i>	(Optional) VRF VIPR Router MAC
<i>vrf-router-id</i>	(Optional) Router ID
<i>vrf-cfgd-id</i>	(Optional) Configured Router-ID
<i>vrf-local-as</i>	(Optional) Local AS
<i>vrf-confed-id</i>	(Optional) Cluster-ID
<i>vrf-cluster-id</i>	(Optional) Cluster-ID
<i>vrf-reconnect-interval</i>	(Optional) VRF reconnect interval

<i>vrf-peers</i>	(Optional) No. of configured peers
<i>vrf-pending-peers</i>	(Optional) No. of pending peers
<i>vrf-est-peers</i>	(Optional) No. of established peers
<i>vrf-cfgd-max-as-limit</i>	(Optional) Configured maxas-limit
<i>vrf-max-as-limit</i>	(Optional) Active maxas-limit
<i>vrf-rd-configured</i>	(Optional) VRF RD Configured
<i>vrf-rd</i>	(Optional) VRF RD
<i>vrf-pending-rd</i>	(Optional) VRF pending RD
TABLE_af	(Optional)
<i>af-id</i>	(Optional) AF ID
<i>af-table-id</i>	(Optional) AF table
<i>af-name</i>	(Optional) AF table name
<i>af-state</i>	(Optional) AF table state
<i>af-state-rsn</i>	(Optional) AF table state reason
<i>af-num-peers</i>	(Optional) No. of peers
<i>af-num-active-peers</i>	(Optional) No. of active peers
<i>af-peer-routes</i>	(Optional) No. of peer routes
<i>af-peer-paths</i>	(Optional) No. of peer paths
<i>af-peer-networks</i>	(Optional) No. of peer networks
<i>af-peer-aggregates</i>	(Optional) No. of aggregates
<i>af-export-rmap</i>	(Optional) Export route-map
<i>af-import-rmap</i>	(Optional) Import route-map
<i>af-retain-rt</i>	(Optional) Retain RT
TABLE_saf	(Optional)
<i>safi</i>	(Optional)
<i>af-name</i>	(Optional)
<i>tableversion</i>	(Optional)
<i>configuredpeers</i>	(Optional)
<i>capablepeers</i>	(Optional)

<i>totalnetworks</i>	(Optional)
<i>totalpaths</i>	(Optional)
<i>memoryused</i>	(Optional)
<i>numberattrs</i>	(Optional)
<i>bytesattrs</i>	(Optional)
<i>numberpaths</i>	(Optional)
<i>bytespaths</i>	(Optional)
<i>numbercommunities</i>	(Optional)
<i>bytescommunities</i>	(Optional)
<i>numberclusterlist</i>	(Optional)
<i>bytesclusterlist</i>	(Optional)
<i>dampening</i>	(Optional)
<i>historypaths</i>	(Optional)
<i>dampenedpaths</i>	(Optional)
<i>softreconfigrecvdpaths</i>	(Optional)
<i>softreconfigidenticalpaths</i>	(Optional)
<i>softreconfigcombopath</i>	(Optional)
<i>softreconfigfilteredrecvd</i>	(Optional)
<i>softreconfigbytes</i>	(Optional)
TABLE_neighbor	(Optional)
<i>neighborid</i>	(Optional)
<i>neighborversion</i>	(Optional)
<i>neighboras</i>	(Optional)
<i>msgrecvd</i>	(Optional)
<i>msgsent</i>	(Optional)
<i>neighbortableversion</i>	(Optional)
<i>inq</i>	(Optional)
<i>outq</i>	(Optional)
<i>time</i>	(Optional)

<i>state</i>	(Optional)
<i>prefixreceived</i>	(Optional)

Command Mode

- /exec

show boot

```
show boot [ __readonly__ { [ TABLE_bootvar_show <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
__readonly__	(Optional)
TABLE_bootvar_show	(Optional) Bootvar table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot auto-copy

```
show boot auto-copy [ __readonly__ { [ TABLE_auto_copy <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
auto-copy	See if autocopy is turned on
__readonly__	(Optional)
TABLE_auto_copy	(Optional) Auto copy table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot auto-copy list

```
show boot auto-copy list [ __readonly__ { [ TABLE_auto_copy_list <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
auto-copy	See if autcopy is turned on
list	Show the list of files to be auto-copied
__readonly__	(Optional)
TABLE_auto_copy_list	(Optional) Auto copy table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot current

```
show boot current [ __readonly__ { [ TABLE_bootvar_current <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
current	Show Current Bootvar Variables
__readonly__	(Optional)
TABLE_bootvar_current	(Optional) Bootvar current table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot mode

```
show boot mode [ __readonly__ { [ TABLE_mode <Str1> ] } ]
```

Syntax Description

show	Show boot mode information
boot	Show boot mode
mode	See if lxc boot is turned on
__readonly__	(Optional)
TABLE_mode	(Optional) boot mode table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot order

```
show boot order [ __readonly__ { [ TABLE_bootvar_order <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
order	Show Boot Order
__readonly__	(Optional)
TABLE_bootvar_order	(Optional) Boot order table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot sup-1

```
show boot sup-1 [ __readonly__ { [ TABLE_show_sup1 <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
sup-1	Enter sup-1 to show the 1st sup config
__readonly__	(Optional)
TABLE_show_sup1	(Optional) Show Sup-1 bootvar table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot sup-2

```
show boot sup-2 [ __readonly__ { [ TABLE_show_sup2 <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
sup-2	Enter sup-2 to show the 2nd sup config
__readonly__	(Optional)
TABLE_show_sup2	(Optional) Show Sup-22 bootvar table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show boot timings

show boot timings

Syntax Description

show	Show running system information
boot	show boot information
timings	show boot timings

Command Mode

- /exec

show boot variables

```
show boot variables [ __readonly__ { [ TABLE_boot_vars <Str1> ] } ]
```

Syntax Description

show	Show running system information
boot	Show Bootvar Variables
variables	Display the list of boot variables
__readonly__	(Optional)
TABLE_boot_vars	(Optional) Show boot variables table
<i>Str1</i>	(Optional)

Command Mode

- /exec



C Show Commands

- [show callhome](#), on page 212
- [show callhome destination-profile](#), on page 214
- [show callhome destination-profile profile](#), on page 215
- [show callhome destination-profile profile CiscoTAC-1](#), on page 216
- [show callhome destination-profile profile full-txt-destination](#), on page 217
- [show callhome destination-profile profile short-txt-destination](#), on page 218
- [show callhome transport-email](#), on page 219
- [show callhome transport](#), on page 220
- [show callhome user-def-cmds](#), on page 222
- [show catena](#), on page 223
- [show catena analytics](#), on page 224
- [show cdp](#), on page 225
- [show cdp all](#), on page 227
- [show cdp global](#), on page 228
- [show cdp neighbors](#), on page 229
- [show cdp neighbors detail](#), on page 230
- [show cdp traffic interface2](#), on page 232
- [show cfs application](#), on page 233
- [show cfs lock](#), on page 234
- [show cfs merge status](#), on page 235
- [show cfs peers](#), on page 237
- [show cfs regions](#), on page 238
- [show cfs status](#), on page 240
- [show checkpoint](#), on page 241
- [show checkpoint](#), on page 242
- [show checkpoint summary](#), on page 243
- [show class-map](#), on page 244
- [show class-map type control-plane](#), on page 246
- [show class-map type network-qos](#), on page 247
- [show cli alias](#), on page 248
- [show cli dynamic-cmd](#), on page 249
- [show cli dynamic integers](#), on page 250
- [show cli dynamic strings](#), on page 251

- [show cli history](#), on page 252
- [show cli interface table](#), on page 253
- [show cli list](#), on page 254
- [show cli syntax](#), on page 255
- [show cli variables](#), on page 256
- [show clock](#), on page 257
- [show config-profile](#), on page 258
- [show config-profile applied](#), on page 259
- [show config-replace log exec](#), on page 260
- [show config-replace status](#), on page 261
- [show config-template](#), on page 262
- [show configuration session](#), on page 263
- [show configuration session](#), on page 264
- [show configuration session global-info](#), on page 265
- [show configuration session status](#), on page 266
- [show configuration session summary](#), on page 267
- [show consistency-checker copp](#), on page 268
- [show consistency-checker egress-xlate private-vlan](#), on page 269
- [show consistency-checker forwarding ipv6 show forwarding ipv6 inconsistency](#), on page 270
- [show consistency-checker forwarding show forwarding inconsistency](#), on page 271
- [show consistency-checker forwarding single-route ipv4 vrf](#), on page 273
- [show consistency-checker kim](#), on page 274
- [show consistency-checker l2-tahoe module](#), on page 275
- [show consistency-checker l2-tahoe switchport interface](#), on page 276
- [show consistency-checker l2 multicast group source vlan](#), on page 277
- [show consistency-checker l3-interface module](#), on page 278
- [show consistency-checker l3 multicast group source vrf](#), on page 279
- [show consistency-checker link-state fabric-ieth](#), on page 280
- [show consistency-checker link-state module](#), on page 281
- [show consistency-checker membership port-channels](#), on page 282
- [show consistency-checker membership vlan](#), on page 283
- [show consistency-checker pacl module](#), on page 284
- [show consistency-checker pacl port-channels](#), on page 285
- [show consistency-checker racl module](#), on page 286
- [show consistency-checker racl port-channels](#), on page 287
- [show consistency-checker stp-state vlan](#), on page 288
- [show consistency-checker vacl](#), on page 289
- [show consistency-checker vpc](#), on page 290
- [show controller accounting log](#), on page 291
- [show copp diff profile profile2](#), on page 292
- [show copp profile](#), on page 293
- [show copp status](#), on page 298
- [show copyright](#), on page 299
- [show cores](#), on page 300
- [show crypto ca certificates](#), on page 301
- [show crypto ca certificates](#), on page 302

- [show crypto ca certstore](#), on page 303
- [show crypto ca crt](#), on page 304
- [show crypto ca remote-certstore](#), on page 305
- [show crypto ca trustpoints](#), on page 306
- [show crypto ca trustpool](#), on page 307
- [show crypto ca trustpool last download status](#), on page 308
- [show crypto ca trustpool policy](#), on page 309
- [show crypto certificatemap](#), on page 310
- [show crypto key mypubkey rsa](#), on page 311
- [show crypto ssh-auth-map](#), on page 312
- [show crypto ssh-auth-map](#), on page 313
- [show cts](#), on page 314
- [show current](#), on page 315

show callhome

```
show callhome [ __readonly__ <output_state> <info> <per_name> [ <name> ] <email_info> [ <email_conf>
] <ph_info> [ <ph_conf> ] <str_addr> [ <str_conf> ] <site_id> [ <site_id_conf> ] <cust_id> [ <cus_id_conf>
] <contr_id> [ <contr_id_conf> ] <swi_pri> [ <swi_pri_value> ] <dup_mess> <per_inv> <per_time>
<per_timeofday> <dist> ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
<i>__readonly__</i>	(Optional)
<i>output_state</i>	(Optional)
<i>info</i>	(Optional)
<i>per_name</i>	(Optional)
<i>name</i>	(Optional)
<i>email_info</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>ph_info</i>	(Optional)
<i>ph_conf</i>	(Optional)
<i>str_addr</i>	(Optional)
<i>str_conf</i>	(Optional)
<i>site_id</i>	(Optional)
<i>site_id_conf</i>	(Optional)
<i>cust_id</i>	(Optional)
<i>cus_id_conf</i>	(Optional)
<i>contr_id</i>	(Optional)
<i>contr_id_conf</i>	(Optional)
<i>swi_pri</i>	(Optional)
<i>swi_pri_value</i>	(Optional)
<i>dup_mess</i>	(Optional)
<i>per_inv</i>	(Optional)

<i>per_time</i>	(Optional)
<i>per_timeofday</i>	(Optional)
<i>dist</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile

```
show callhome destination-profile [ __readonly__ { TABLE_call_info [ <dest_full_info> ] [ <dest_short_info> ] [ <dest_xml_info> ] [ <dest_def_info> ] <max_mess_size> <mess_format> <mess_level> <trans_method> <email_info> [ <email_conf> ] <url_info> [ <url_conf> ] <alert_groups> [ <alert_conf> ] } ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
<i>__readonly__</i>	(Optional)
<i>TABLE_call_info</i>	(Optional)
<i>dest_full_info</i>	(Optional)
<i>dest_short_info</i>	(Optional)
<i>dest_xml_info</i>	(Optional)
<i>dest_def_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_format</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile

```
show callhome destination-profile profile <s0> [ __readonly__ <user_txt_info> <max_mess_size>
<mess_format> <mess_level> <trans_method> <email_info> [ TABLE_email [ <email_conf> ] ] <url_info>
[ TABLE_url [ <url_conf> ] ] <alert_groups> [ TABLE_alert [ <alert_conf> ] ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
<i>s0</i>	Show information for user defined destination profile
<i>__readonly__</i>	(Optional)
<i>user_txt_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_format</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
TABLE_email	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
TABLE_url	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
TABLE_alert	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile CiscoTAC-1

```
show callhome destination-profile profile CiscoTAC-1 [ __readonly__ <tac_xml_info> <max_mess_size>
<mess_level> <trans_method> <email_info> [ <email_conf> ] <url_info> [ <url_conf> ] <alert_groups> [
<alert_conf> ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
CiscoTAC-1	Show information for CiscoTAC-1 destination profile
<i>__readonly__</i>	(Optional)
<i>tac_xml_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile full-txt-destination

```
show callhome destination-profile profile full-txt-destination [ __readonly__ <full_txt_info> <max_mess_size>
<mess_level> <trans_method> <email_info> [ <email_conf> ] <url_info> [ <url_conf> ] <alert_groups> [
<alert_conf> ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
full-txt-destination	Show information for full-txt-destination destination profile
<i>__readonly__</i>	(Optional)
<i>full_txt_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile short-txt-destination

```
show callhome destination-profile profile short-txt-destination [ __readonly__ <shrt_txt_info>
<max_mess_size> <mess_level> <trans_method> <email_info> [ <email_conf> ] <url_info> [ <url_conf> ]
<alert_groups> [ <alert_conf> ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
short-txt-destination	Show information for short-txt-destination destination profile
<i>__readonly__</i>	(Optional)
<i>shrt_txt_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome transport-email

```
show callhome transport-email [ __readonly__ { <from_email> } [ <reply_to_email> ] [ <return_receipt_addr>
] { <smtp_server> } [ <smtp_server_port> ] ]
```

Syntax Description

<i>__readonly__</i>	(Optional)
show	Show running system information
callhome	Show callhome information
transport-email	Show callhome email transport configuration
<i>from_email</i>	(Optional)
<i>reply_to_email</i>	(Optional)
<i>return_receipt_addr</i>	(Optional)
<i>smtp_server</i>	(Optional)
<i>smtp_server_port</i>	(Optional)

Command Mode

- /exec

show callhome transport

```
show callhome transport [ __readonly__ <vrf> <from_email> [ <rep_email> ] [ <ret_email> ] [ <smtp_ser>
] [ <smtp_ser_port> ] [ <smtp_ser_vrf> ] [ <smtp_ser_prior> ] [ <smtp_ser_do> ] [ <smtp_ser_port_do> ] [
<smtp_ser_vrf_do> ] [ <smtp_ser_prior_do> ] [ <smtp_ser_got> ] [ <smtp_ser_port_got> ] [
<smtp_ser_vrf_got> ] [ <smtp_ser_prior_got> ] <http_prox> <http_port> <http_state> ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
transport	Show callhome transport configuration (email and http)
<i>__readonly__</i>	(Optional)
<i>vrf</i>	(Optional)
<i>from_email</i>	(Optional)
<i>rep_email</i>	(Optional)
<i>ret_email</i>	(Optional)
<i>smtp_ser</i>	(Optional)
<i>smtp_ser_port</i>	(Optional)
<i>smtp_ser_vrf</i>	(Optional)
<i>smtp_ser_prior</i>	(Optional)
<i>smtp_ser_do</i>	(Optional)
<i>smtp_ser_port_do</i>	(Optional)
<i>smtp_ser_vrf_do</i>	(Optional)
<i>smtp_ser_prior_do</i>	(Optional)
<i>smtp_ser_got</i>	(Optional)
<i>smtp_ser_port_got</i>	(Optional)
<i>smtp_ser_vrf_got</i>	(Optional)
<i>smtp_ser_prior_got</i>	(Optional)
<i>http_prox</i>	(Optional)
<i>http_port</i>	(Optional)
<i>http_state</i>	(Optional)

Command Mode

- /exec

show callhome user-def-cmds

```
show callhome user-def-cmds [ __readonly__ { <user_configured_cmds> } [ { TABLE_user_def_cmds
<alert_group> <user_defined_cmds> } ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
user-def-cmds	Show the cli commands configured for each alert group
<i>__readonly__</i>	(Optional)
<i>user_configured_cmds</i>	(Optional) List of user configured commands
TABLE_user_def_cmds	(Optional)
<i>alert_group</i>	(Optional)
<i>user_defined_cmds</i>	(Optional)

Command Mode

- /exec

show catena

```
show catena <instance-name> [ brief ] [ __readonly__ <instance_name> <state> { TABLE_chain <chain> [
TABLE_rule <seqno> <aclname> <whichconfig> [ <vlan_group> ] [ <ingress_port> ] [ <egress_port> ] [
<egress_device> ] [ <mode> ] [ <l2_lb> ] ] } ]
```

Syntax Description

show	Show running system information
catena	catena
<i>instance-name</i>	instance name
brief	(Optional) brief
__readonly__	(Optional) Read Only
<i>instance_name</i>	(Optional) instance_name
<i>state</i>	(Optional) status
TABLE_chain	(Optional)
<i>chain</i>	(Optional) chain
TABLE_rule	(Optional)
<i>seqno</i>	(Optional) seqno
<i>aclname</i>	(Optional) aclname
<i>whichconfig</i>	(Optional) whichconfig
<i>vlan_group</i>	(Optional) vlangrp
<i>ingress_port</i>	(Optional) ingress_portgrp
<i>egress_port</i>	(Optional) egress_portgrp
<i>egress_device</i>	(Optional) egress_device
<i>mode</i>	(Optional) mode
<i>l2_lb</i>	(Optional) L2 Load Balance

Command Mode

- /exec

show catena analytics

```
show catena analytics { per-acl { per-node | per-device-group } | per-catena-instance <instance-name> [
per-chain [ <chain-id> ] ] } [ __readonly__ <instance_name> <per_node> <per_node_total>
<per_node_total_val> <chain_id> <per_device_group> <per_device_group_hdr> <per_device_group_val>
<stats_counter> ]
```

Syntax Description

show	Show running system information
catena	catena
analytics	show analytics for catena
per-acl	per ACL
per-node	per Node
per-device-group	per Device group
per-catena-instance	per Catena Instance
<i>instance-name</i>	Name of Catena Instance
per-chain	(Optional) per Chain
<i>chain-id</i>	(Optional) chain ID
<i>__readonly__</i>	(Optional) Read Only
<i>instance_name</i>	(Optional) Catena Instance name
<i>chain_id</i>	(Optional) Chain ID
<i>per_node</i>	(Optional) per Node
<i>per_node_total</i>	(Optional) per Node total
<i>per_node_total_val</i>	(Optional) per Node total val
<i>per_device_group</i>	(Optional) per Device Group
<i>per_device_group_hdr</i>	(Optional) per Device Group Header
<i>per_device_group_val</i>	(Optional) per Device Group Val
<i>stats_counter</i>	(Optional) stats_counter

Command Mode

- /exec

show cdp

```
show cdp { entry { all1 | name <s0> } } [ __readonly__ TABLE_cdp_entry_all <device_id> [ <sysname> ]
[ { <v4addr> | <v6addr> } + ] <platform_id> <capability> + <intf_id> <port_id> <ttl> <version> <version_no>
[ <nativevlan> ] [ <vtpname> ] [ <duplexmode> ] [ <syslocation> ] [ { <v4mgmtaddr> | <v6mgmtaddr> } +
]]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
entry	Show CDP entries in database
all1	Show all CDP entries in database
name	Show a specific CDP entry matching a name
<i>s0</i>	
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_cdp_entry_all</i>	(Optional) output of show cdp entry all
<i>device_id</i>	(Optional) Device Identifier
<i>sysname</i>	(Optional) System Name
<i>v4addr</i>	(Optional) Interface IP V4 Address
<i>v6addr</i>	(Optional) Interface IP V6 Address
<i>platform_id</i>	(Optional) Platform Id
<i>capability</i>	(Optional) Capability
<i>intf_id</i>	(Optional) Interface Id
<i>port_id</i>	(Optional) Port Identifier
<i>ttl</i>	(Optional) Hold Time
<i>version</i>	(Optional) Software Version
<i>version_no</i>	(Optional) CDP version number
<i>nativevlan</i>	(Optional) NativeVLAN
<i>vtpname</i>	(Optional) Vtp Management Domain Name
<i>duplexmode</i>	(Optional) Duplex Mode
<i>syslocation</i>	(Optional) System Location

<i>v4mgmtaddr</i>	(Optional) IP V4 Mgmt Address
<i>v6mgmtaddr</i>	(Optional) IP V6 Mgmt Address

Command Mode

- /exec

show cdp all

```
show cdp { all | interface <if0> } [ __readonly__ TABLE_cdp_all <intf_id> <port_up> [ <cdp_global_enabled> ] <cdp_intf_enabled> [ <oper_mode> ] <refresh_time> <ttl> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
all	Show all interfaces in CDP database
interface	Show CDP parameters for an interface
<i>if0</i>	
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_cdp_all</i>	(Optional) output of show cdp all
<i>intf_id</i>	(Optional) Interface Id
<i>port_up</i>	(Optional) Port status
<i>cdp_global_enabled</i>	(Optional) CDP global status
<i>cdp_intf_enabled</i>	(Optional) CDP interface status
<i>oper_mode</i>	(Optional) CDP operation mode
<i>refresh_time</i>	(Optional) Refresh Time
<i>ttl</i>	(Optional) Hold Time

Command Mode

- /exec

show cdp global

```
show cdp global [ __readonly__ <cdp_global_enabled> <refresh_time> <ttl> <v2_advertisement>
<deviceid_format> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
global	Show CDP global parameters
<i>__readonly__</i>	(Optional) Read only
<i>cdp_global_enabled</i>	(Optional) CDP global status
<i>refresh_time</i>	(Optional) Refresh Time
<i>ttl</i>	(Optional) Hold Time
<i>v2_advertisement</i>	(Optional) Show v2 advertisement
<i>deviceid_format</i>	(Optional) Show deviceId Format

Command Mode

- /exec

show cdp neighbors

```
show cdp neighbors [ interface <if> ] [ __readonly__ { TABLE_cdp_neighbor_brief_info <ifindex>
<device_id> <intf_id> <ttl> <capability> + <platform_id> <port_id> } { <neigh_count> } ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
neighbors	Show CDP neighbors
interface	(Optional) Show CDP neighbors on an interface
<i>if</i>	(Optional) Specify Interface
<i>__readonly__</i>	(Optional) Read only
TABLE_cdp_neighbor_brief_info	(Optional) output of show cdp neighbor - in brief
<i>ifindex</i>	(Optional) Interface index
<i>device_id</i>	(Optional) System Name (or) Device Identifier
<i>intf_id</i>	(Optional) Interface Id
<i>port_id</i>	(Optional) Port Identifier
<i>platform_id</i>	(Optional) Platform Id
<i>ttl</i>	(Optional) Hold Time
<i>capability</i>	(Optional) Capability
<i>neigh_count</i>	(Optional) Neighbor Count

Command Mode

- /exec

show cdp neighbors detail

```
show cdp neighbors [ interface <if> ] detail [ __readonly__ TABLE_cdp_neighbor_detail_info <ifindex>
<device_id> [ <sysname> ] [ <vtpname> ] <numaddr> [ { <v4addr> | <v6addr> } + ] <platform_id>
<capability> + <intf_id> <port_id> <ttl> <version> <version_no> [ <nativevlan> ] [ <duplexmode> ] [ <mtu>
] [ <syslocation> ] [ <num_mgmtaddr> [ { <v4mgmtaddr> | <v6mgmtaddr> } + ] ] ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
neighbors	Show CDP neighbors
detail	Show CDP neighbors detailed
interface	(Optional) Show CDP neighbors on an interface
<i>if</i>	(Optional) Specify Interface
<i>__readonly__</i>	(Optional) Read only
TABLE_cdp_neighbor_detail_info	(Optional) output of show cdp neighbor detail
<i>ifindex</i>	(Optional) Interface index
<i>device_id</i>	(Optional) Device Identifier
<i>sysname</i>	(Optional) System Name
<i>vtpname</i>	(Optional) Vtp Management Domain Name
<i>numaddr</i>	(Optional) No of IP Address configured
<i>v4addr</i>	(Optional) Interface IP V4 Address
<i>v6addr</i>	(Optional) Interface IP V6 Address
<i>platform_id</i>	(Optional) Platform Id
<i>capability</i>	(Optional) Capability
<i>intf_id</i>	(Optional) Interface Id
<i>port_id</i>	(Optional) Port Identifier
<i>ttl</i>	(Optional) Hold Time
<i>version</i>	(Optional) Software Version
<i>version_no</i>	(Optional) CDP version number
<i>nativevlan</i>	(Optional) NativeVLAN

<i>duplexmode</i>	(Optional) Duplex Mode
<i>mtu</i>	(Optional) MTU
<i>syslocation</i>	(Optional) System Location
<i>num_mgmtaddr</i>	(Optional) No of Mgmt Address configured
<i>v4mgmtaddr</i>	(Optional) IP V4 Mgmt Address
<i>v6mgmtaddr</i>	(Optional) IP V6 Mgmt Address

Command Mode

- /exec

show cdp traffic interface2

```
show cdp traffic interface2 <if2> [ __readonly__ <intf_id> <total_input_packets> <valid_cdp_packets>
<input_v1_packets> <input_v2_packets> <invalid_cdp_packets> <unsupported_version> <checksum_errors>
<malformed_packets> <total_output_packets> <output_v1_packets> <output_v2_packets> <send_errors> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
traffic	Show CDP traffic statistics
interface2	Show CDP traffic statistics on an interface
<i>if2</i>	
<i>__readonly__</i>	(Optional) Read only
<i>intf_id</i>	(Optional) Interface Id
<i>total_input_packets</i>	(Optional) Total input cdp packets
<i>valid_cdp_packets</i>	(Optional) Total valid cdp packets
<i>input_v1_packets</i>	(Optional) Input vesrion1 packets
<i>input_v2_packets</i>	(Optional) Input vesrion2 packets
<i>invalid_cdp_packets</i>	(Optional) Invalid cdp packets
<i>unsupported_version</i>	(Optional) Packets having unsupported version
<i>checksum_errors</i>	(Optional) Packets having checksum errors
<i>malformed_packets</i>	(Optional) Total malformed packets
<i>total_output_packets</i>	(Optional) Total output packets
<i>output_v1_packets</i>	(Optional) Output vesrion1 packets
<i>output_v2_packets</i>	(Optional) Output vesrion2 packets
<i>send_errors</i>	(Optional) Number of send errors

Command Mode

- /exec

show cfs application

```
show cfs application [ { name <cfs-dyn-app-name> | sap <i0> } ] [ __readonly__ [ { enabled <enabled> } {
timeout <timeout> } { merge_capable <merge_capable> } { scope <scope> } { region <region> } ] [ {
TABLE_apps <app_name> <app_enabled> <app_scope> } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
application	Show locally registered applications
name	(Optional) Show local application information by name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
sap	(Optional) Show local application information by sap
<i>i0</i>	(Optional) Registered sap of the local application
<i>__readonly__</i>	(Optional)
enabled	(Optional) whether application is CFS enabled
<i>enabled</i>	(Optional) whether application is CFS enabled
timeout	(Optional) timeout
<i>timeout</i>	(Optional) timeout
merge_capable	(Optional) merge_capable
<i>merge_capable</i>	(Optional) merge_capable
scope	(Optional) scope
<i>scope</i>	(Optional) scope
region	(Optional) region
<i>region</i>	(Optional) region
TABLE_apps	(Optional) all cfs applications
<i>app_name</i>	(Optional) name of cfs application
<i>app_enabled</i>	(Optional) whether application is cfs enabled
<i>app_scope</i>	(Optional) distribution scope of cfs application

Command Mode

- /exec

show cfs lock

```
show cfs lock [ { name <cfs-dyn-app-name> | sap <i1> } ] [ __readonly__ [ { TABLE_locks [ <app_name> ] <app_scope> [ <vsan> ] [ <domain> ] [ <wwn> ] <ip_addr> <u_name> <u_type> [ <hostname> ] } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
lock	Show state of application's logical/physical locks
name	(Optional) Application name for which the lock status is required
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
sap	(Optional) Application sap for which the lock status is required
<i>i1</i>	(Optional) Application SAP
<code>__readonly__</code>	(Optional)
TABLE_locks	(Optional) table of all CFS locks
<i>app_name</i>	(Optional) name of CFS application
<i>app_scope</i>	(Optional) scope of CFS application
<i>vsan</i>	(Optional) vsan
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn of switch holding CFS lock
<i>ip_addr</i>	(Optional) ip address of switch holding CFS lock
<i>u_name</i>	(Optional) user name
<i>u_type</i>	(Optional) user type
<i>hostname</i>	(Optional) hostname

Command Mode

- /exec

show cfs merge status

```
show cfs merge status [ { name <cfs-dyn-app-name> [ detail ] | sap <i1> [ detail2 ] } ] [ __readonly__ [ {
scope <scope> } ] [ { merge_status <status> } ] [ { failure_reason <reason> } ] [ { TABLE_all_merge
<app_name> <scope> <vsan> <status> } ] [ { TABLE_local_fabric [ <domain> ] <wwn> <ip_addr>
<app_scope> [ <master> ] [ <hostname> ] } ] [ { TABLE_remote_fabric [ <domain> ] <wwn> <ip_addr>
<app_scope> [ <master> ] [ <hostname> ] } ] [ { TABLE_remaining_fabric [ <domain> ] <wwn> <ip_addr>
[ <hostname> ] } ] ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
merge	Show cfs merge information
status	Show status of merge
name	(Optional) Show merge status by name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
detail	(Optional) Show merge status by name in detail
sap	(Optional) Show merge status by sap
<i>i1</i>	(Optional) Application sap
detail2	(Optional) Show merge status by sap in detail
__readonly__	(Optional)
scope	(Optional) distribution scope of application
<i>scope</i>	(Optional) scope
merge_status	(Optional) status
<i>status</i>	(Optional) status
failure_reason	(Optional) reason
<i>reason</i>	(Optional) reason
TABLE_all_merge	(Optional) all
<i>app_name</i>	(Optional) name
<i>scope</i>	(Optional) scope
<i>vsan</i>	(Optional) vsan
<i>status</i>	(Optional) status

TABLE_local_fabric	(Optional) local fabric
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>app_scope</i>	(Optional) scope
<i>master</i>	(Optional) master
<i>hostname</i>	(Optional) hname
TABLE_remote_fabric	(Optional) remote fabric
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>app_scope</i>	(Optional) scope
<i>master</i>	(Optional) master
<i>hostname</i>	(Optional) hname
TABLE_remaining_fabric	(Optional) remote fabric
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>hostname</i>	(Optional) hname

Command Mode

- /exec

show cfs peers

```
show cfs peers [ { name <cfs-dyn-app-name> | sap <i1> } ] [ __readonly__ [ { scope <scope> } ] ] [ {
TABLE_peers <wwn> <ip_addr> [ <local> ] [ <hostname> ] [ <domain> ] } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
peers	Show all the peers in the physical fabric
name	(Optional) Show peers for given application name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
sap	(Optional) Show peers for given application sap
<i>i1</i>	(Optional) Application sap
__readonly__	(Optional)
scope	(Optional) scope
<i>scope</i>	(Optional) scope
TABLE_peers	(Optional) all peers
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>local</i>	(Optional) local
<i>hostname</i>	(Optional) hname
<i>domain</i>	(Optional) domain

Command Mode

- /exec

show cfs regions

```
show cfs regions [ { brief [ region <i0> ] | name <cfs-dyn-app-name> | region1 <i1> } ] [ __readonly__ [ {
region <id> } ] [ { application <name> } ] [ { scope <scope> } ] [ { TABLE_PEERS <wwn> <ip_addr>
<local> [ <hostname> ] [ <domain> } ] ] [ { TABLE_switches [ <wwn> ] [ <ip_addr> ] <region> <app_name>
<enabled> [ <scope> } ] ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
regions	Show all the applications with peers and region information
brief	(Optional) Show all configured regions and applications(no peers)
region	(Optional) Show all configured applications(no peers)
<i>i0</i>	(Optional) Region Id
name	(Optional) Show peers and region information for a given application
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
region1	(Optional) Show all configured applications with peers
<i>i1</i>	(Optional) Region Id
__readonly__	(Optional)
region	(Optional) region
<i>id</i>	(Optional) id
application	(Optional) app
<i>name</i>	(Optional) name
scope	(Optional) scope
<i>scope</i>	(Optional) scope
TABLE_PEERS	(Optional) all region peers
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_address
<i>local</i>	(Optional) local
<i>hostname</i>	(Optional) hname
<i>domain</i>	(Optional) domain

<i>TABLE_switches</i>	(Optional) all switches in region
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>region</i>	(Optional) region
<i>app_name</i>	(Optional) name
<i>enabled</i>	(Optional) enabled
<i>scope</i>	(Optional) scope

Command Mode

- /exec

show cfs status

```
show cfs status [ __readonly__ { distribution <distribution> } { distribution_over_ip <dist_over_ip> } {
  ipv4_multicast_address <ipv4_mcast_addr> } { ipv6_multicast_address <ipv6_mcast_addr> } {
  distribution_over_ethernet <dist_over_eth> } ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
status	Show current status of CFS
<i>__readonly__</i>	(Optional)
distribution	(Optional) runtime status of CFS distribution
<i>distribution</i>	(Optional) operational status of CFS distribution
distribution_over_ip	(Optional) runtime information of CFS over IP
<i>dist_over_ip</i>	(Optional) operational status of CFS over IP
ipv4_multicast_address	(Optional) ipv4 multicast address
<i>ipv4_mcast_addr</i>	(Optional) ipv4 multicast address
ipv6_multicast_address	(Optional) ipv6 multicast address
<i>ipv6_mcast_addr</i>	(Optional) ipv6 multicast address
distribution_over_ethernet	(Optional) runtime status if CFS over Ethernet
<i>dist_over_eth</i>	(Optional) operations status of CFS over Ethernet

Command Mode

- /exec

show checkpoint

```
show checkpoint [ all ] [ user | system ] [ __readonly__ TABLE_checkpoint_details <name>
<checkpoint_config> + ]
```

Syntax Description

show	Show running system information
checkpoint	Show configuration rollback checkpoints
all	(Optional) Show default config
user	(Optional) Show only user configuration rollback checkpoints
system	(Optional) Show only system configuration rollback checkpoints
__readonly__	(Optional) Read only
TABLE_checkpoint_details	(Optional) checkpoint details
<i>name</i>	(Optional) Checkpoint name
<i>checkpoint_config</i>	(Optional) Configuration entry from checkpoint

Command Mode

- /exec

show checkpoint

show checkpoint <chkpoint_name> [all] [__readonly__ TABLE_checkpoint_details <name1>
<checkpoint_config> +]

Syntax Description

show	Show running system information
checkpoint	Show configuration rollback checkpoint contents
<i>chkpoint_name</i>	Checkpoint name
all	(Optional) Show default config
__readonly__	(Optional) Read only
TABLE_checkpoint_details	(Optional) Checkpoint details
<i>name1</i>	(Optional) Checkpoint name
<i>checkpoint_config</i>	(Optional) Configuration entry from checkpoint

Command Mode

- /exec

show checkpoint summary

```
show checkpoint summary [ user | system ] [ __readonly__ TABLE_checkpoint_header_info <name>
<user_name> <timestamp> <file_path> <chkpt_type> <description> ]
```

Syntax Description

show	Show running system information
checkpoint	Show configuration rollback checkpoints
summary	Show configuration rollback checkpoints summary
user	(Optional) Show only user configuration rollback checkpoints summary
system	(Optional) Show only system configuration rollback checkpoints summary
__readonly__	(Optional) Read only
TABLE_checkpoint_header_info	(Optional) Checkpoint header info
<i>user_name</i>	(Optional) Username
<i>name</i>	(Optional) Checkpoint name
<i>file_path</i>	(Optional) Checkpoint name
<i>timestamp</i>	(Optional) Timestamp of checkpoint creation
<i>chkpt_type</i>	(Optional) Type of checkpoint either user or system
<i>description</i>	(Optional) Checkpoint description

Command Mode

- /exec

show class-map

```
show class-map [ { [ type qos ] [ <cmmap-name> | xxx <color-map-enum-name> ] } | { type queuing [ yyy
<cmmap-enum-name> | zzz <default-cmap-enum-name> | <cmmap-dce-name> | <cmmap-name-hque> ] } ] [
__readonly__ { [ <display-all> ] [ TABLE_cmap <cmmap-key> [ <id> ] <xqos-or-q> [ <any_or_all> ]
<cmmap-name-out> [ <desc> ] [ TABLE_match <match-key> [ <not> ] [ <dscp-list> ] [ <precedence-list> ] [
<cos-list> ] [ <qos-group-list> ] [ <discard-class-list> ] [ <vlan-list> ] [ <match-cmap-name> ] [
<match-acl-name> ] [ <note-string> ] [ <pkt-len-list> ] [ <rtp-port-list> ] [ <roce-port-list> ] [ <prot> ] [
<input-iface-list> ] [ <exp-list> ] [ <cl-def> ] ] ] ] }
```

Syntax Description

xxx	(Optional) xxx
yyy	(Optional) yyy
zzz	(Optional) zzz
show	Show running system information
class-map	Show class maps
type	(Optional) Type of the class-map
qos	(Optional) type qos
queuing	(Optional) type queuing
<i>cmmap-name</i>	(Optional) class map name
<i>cmmap-enum-name</i>	(Optional)
<i>default-cmap-enum-name</i>	(Optional)
<i>cmmap-dce-name</i>	(Optional) Queuing class-map name
<i>cmmap-name-hque</i>	(Optional) Hierarchical class-map name
<i>color-map-enum-name</i>	(Optional)
<i>__readonly__</i>	(Optional)
<i>display-all</i>	(Optional) Display all kinds of class-maps
TABLE_cmap	(Optional) all cmap xml sessions
<i>cmmap-key</i>	(Optional) Class-map name: xml key
TABLE_match	(Optional) all match xml sessions
<i>match-key</i>	(Optional) match count: xml key
<i>cmmap-name-out</i>	(Optional) Class-map name
<i>xqos-or-q</i>	(Optional)

<i>any_or_all</i>	(Optional) Enter match-any or match-all
<i>id</i>	(Optional) Class-map ID
<i>desc</i>	(Optional) Description string
<i>not</i>	(Optional) Negate this match result
<i>dscp-list</i>	(Optional) List of DSCP values
<i>precedence-list</i>	(Optional) List of precedence values
<i>cos-list</i>	(Optional) List of class-of-service values
<i>qos-group-list</i>	(Optional) List of qos-group values
<i>discard-class-list</i>	(Optional) List of discard-class values
<i>vlan-list</i>	(Optional) List of vlan-ids
<i>match-cmap-name</i>	(Optional) class-map name
<i>match-acl-name</i>	(Optional) Match class-map name
<i>note-string</i>	(Optional) Placeholder string param to display any info in string format
<i>pkt-len-list</i>	(Optional) Packet length multi-range
<i>rtp-port-list</i>	(Optional) IP RTP UDP port multi-range
<i>roce-port-list</i>	(Optional) IP ROCE UDP port multi-range
<i>prot</i>	(Optional) Protocol
<i>input-iface-list</i>	(Optional) Input Interface multi-range
<i>exp-list</i>	(Optional) List of MPLS exp values
<i>cl-def</i>	(Optional) Match any criteria for class-default only

Command Mode

- /exec

show class-map type control-plane

```
show class-map type control-plane [ <imap-name> ] [ __readonly__ [ { TABLE_cmap <imap-key>
<imap-name-out> <opt_any_or_all> [ TABLE_match <match-key> [ access_grp <acc_grp_name> ] [ redirect
<opt_match_redirect> ] [ exception <opt_match_except> ] [ protocol <opt_match_protocol> ] } ] ] ]
```

Syntax Description

show	Show running system information
class-map	Show class maps
type	Type of the class-map
control-plane	This is for copp policy
<i>imap-name</i>	(Optional) Name of the class-map
<i>__readonly__</i>	(Optional)
TABLE_cmap	(Optional) all cmap xml sessions
<i>imap-name-out</i>	(Optional) Name of the class-map
<i>imap-key</i>	(Optional) Class-map name: xml key
<i>opt_any_or_all</i>	(Optional) Enter match-any or match-all
TABLE_match	(Optional) all match xml sessions
<i>match-key</i>	(Optional) match count: xml key
access_grp	(Optional)
<i>acc_grp_name</i>	(Optional)
redirect	(Optional)
<i>opt_match_redirect</i>	(Optional) Match criteria for redirected packets
exception	(Optional)
<i>opt_match_except</i>	(Optional) Match criteria for exception packets
protocol	(Optional)
<i>opt_match_protocol</i>	(Optional) Match criteria for protocol packets

Command Mode

- /exec

show class-map type network-qos

```
show class-map type network-qos [ < cmap-name-nq > ] [ __readonly__ { [ < display-all > ] [ TABLE_ cmap
< cmap-key > < xmap-name > [ < desc > ] [ < cos-list > ] [ < qos-group-list > ] [ < protocol > ] ] } ]
```

Syntax Description

show	Show running system information
class-map	Show class maps
type	Type of the class-map
<i>cmap-name-nq</i>	(Optional) Class-map name
network-qos	type network-qos
<i>__readonly__</i>	(Optional)
<i>display-all</i>	(Optional) Display all network-qos class-maps
TABLE_ cmap	(Optional) all network-qos cmap xml sessions
<i>cmap-key</i>	(Optional) Class-map name: xml key
<i>desc</i>	(Optional) Description string
<i>xmap-name</i>	(Optional) Class-map name
<i>protocol</i>	(Optional) protocol
<i>cos-list</i>	(Optional) List of class-of-service values
<i>qos-group-list</i>	(Optional) List of qos-group values

Command Mode

- /exec

show cli alias

```
show cli alias [ name <s0> ] [ __readonly__ { TABLE_cli_alias <alias> <name> } ]
```

Syntax Description

show	Show running system information
cli	Show CLI information
alias	Display the alias configuration
name	(Optional) Display a specific alias
s0	(Optional) Specify the alias
__readonly__	(Optional)
TABLE_cli_alias	(Optional) cli alias table
alias	(Optional) alias
name	(Optional) name

Command Mode

- /exec

show cli dynamic-cmd

show cli dynamic-cmd

Syntax Description

show	Show running system information
cli	CLI commands
dynamic-cmd	Display the list of dynamic commands(cli)

Command Mode

- /exec

show cli dynamic integers

```
show cli dynamic integers [ <name> ] [ __readonly__ TABLE_dynamic_integers <name-o> <min> <max> ]
```

Syntax Description

show	Show running system information
cli	CLI commands
dynamic	Display current range of dynamic parameters
integers	Display current range of dynamic integer parameters
<i>name</i>	(Optional) name of the dynamic parameter
<i>__readonly__</i>	(Optional)
TABLE_dynamic_integers	(Optional)
<i>name-o</i>	(Optional)
<i>min</i>	(Optional)
<i>max</i>	(Optional)

Command Mode

- /exec

show cli dynamic strings

```
show cli dynamic strings [ <name> ] [ __readonly__ TABLE_dynamic_strings <name-o> <value> + ]
```

Syntax Description

show	Show running system information
cli	CLI commands
dynamic	Display current range of dynamic parameters
strings	Display current range of dynamic string parameters
<i>name</i>	(Optional) name of the dynamic parameter
<i>__readonly__</i>	(Optional)
<i>TABLE_dynamic_strings</i>	(Optional)
<i>name-o</i>	(Optional)
<i>value</i>	(Optional)

Command Mode

- /exec

show cli history

show cli history [this-mode-only | exec-mode | config-mode] [<count> | unformatted] +

Syntax Description

show	Show running system information
cli	debug cli
history	history of cli commands
<i>count</i>	(Optional) number of lines to display (from end)
unformatted	(Optional) display just the commands
this-mode-only	(Optional) display history from current mode only
exec-mode	(Optional) display history of exec commands only
config-mode	(Optional) display history of config commands only

Command Mode

- /exec

show cli interface table

show cli interface table

Syntax Description

show	show
cli	cli
interface	interface
table	table

Command Mode

- /exec

show cli list

show cli list [detail | recurse | <component> | <max-per-cmd> | has-xml-out] +

Syntax Description

show	Show running system information
cli	Show CLI information
list	show
<i>component</i>	(Optional) component
<i>max-per-cmd</i>	(Optional) max
has-xml-out	(Optional) show
recurse	(Optional) go
detail	(Optional) formats

Command Mode

- /exec

show cli syntax

```
show cli syntax [ long | recurse ] + [ has-xml-out | has-no-xml-out | is-data-modeled ] [ roles [ network-admin
| network-operator | <roles-mask> ] ]
```

Syntax Description

show	Show running system information
cli	Show CLI information
syntax	show
long	(Optional) use
recurse	(Optional) also
has-xml-out	(Optional) show
has-no-xml-out	(Optional) show
is-data-modeled	(Optional) show
roles	(Optional) show
network-admin	(Optional) show
network-operator	(Optional) show
<i>roles-mask</i>	(Optional) show

Command Mode

- /exec

show cli variables

```
show cli variables [ __readonly__ <switchname> <timestamp> [ { TABLE_variable <key> <value> } ] [ {
TABLE_session_variable <key> <value> } ] ]
```

Syntax Description

show	Show running system information
cli	Show CLI information
variables	Show CLI variables
<i>__readonly__</i>	(Optional)
<i>switchname</i>	(Optional) Switch Name
<i>timestamp</i>	(Optional) Timestamp
TABLE_variable	(Optional) Variable table
<i>key</i>	(Optional) key
<i>value</i>	(Optional) value
TABLE_session_variable	(Optional) Session variable table
<i>key</i>	(Optional) key
<i>value</i>	(Optional) value

Command Mode

- /exec

show clock

```
show clock [ detail ] [ __readonly__ { <simple_time> <time_source> [ <daylight_zone> <daylight_start_week>
<daylight_start_weekday> <daylight_start_month> <daylight_start_time> <daylight_end_week>
<daylight_end_weekday> <daylight_end_month> <daylight_end_time> <daylight_utc_min_offset> ] } ]
```

Syntax Description

show	Show running system information
clock	Display current Date
detail	(Optional) Display current date and summertime configuration
<i>__readonly__</i>	(Optional)
<i>simple_time</i>	(Optional) simple clock format
<i>time_source</i>	(Optional) Time source
<i>daylight_zone</i>	(Optional) summer-time daylight zone
<i>daylight_start_week</i>	(Optional) daylight start week
<i>daylight_start_weekday</i>	(Optional) daylight start weekday
<i>daylight_start_month</i>	(Optional) daylight start month
<i>daylight_start_time</i>	(Optional) daylight start time
<i>daylight_end_week</i>	(Optional) daylight end week
<i>daylight_end_weekday</i>	(Optional) daylight end weekday
<i>daylight_end_month</i>	(Optional) daylight end month
<i>daylight_end_time</i>	(Optional) daylight end time
<i>daylight_utc_min_offset</i>	(Optional) daylight utc offset

Command Mode

- /exec

show config-profile

```
show config-profile [ name <all_conf_profile_name> ] [ __readonly__ TABLE_conf_profile_all
<conf_profile_name> { [ <conf_profile_desc> ] <conf_profile_cfg> + [ <conf_profile_applied> ] + [
<conf_profile_include> ] + } ]
```

Syntax Description

show	Show running system information
config-profile	Show config-profiles
name	(Optional) config-profile name
<i>all_conf_profile_name</i>	(Optional) Enter the name of configuration profile
<i>__readonly__</i>	(Optional)
<i>TABLE_conf_profile_all</i>	(Optional)
<i>conf_profile_name</i>	(Optional)
<i>conf_profile_desc</i>	(Optional)
<i>conf_profile_cfg</i>	(Optional)
<i>conf_profile_applied</i>	(Optional)
<i>conf_profile_include</i>	(Optional)

Command Mode

- /exec

show config-profile applied

```
show config-profile { applied [ auto | manually ] | non-applied } [ match-name <profile_substring> ] [
__readonly__ [ <profiles> ] + ]
```

Syntax Description

show	Show running system information
config-profile	Show config-profiles
applied	List of config-profiles that are applied
auto	(Optional) List of config-profiles that are applied via auto-config
manually	(Optional) List of all config-profiles which were applied directly from cli
non-applied	List of config-profiles that are not applied
match-name	(Optional) List of all config-profiles that have matching sub-string
__readonly__	(Optional)
<i>profiles</i>	(Optional)
<i>profile_substring</i>	(Optional) Enter a substring to match with config-profile name

Command Mode

- /exec

show config-replace log exec

show config-replace log { exec | verify } [__readonly__ [<log_entry> +]]

Syntax Description

show	Show running system information
config-replace	Show config-replace
log	show config-replace log
exec	show config-replace execution log
verify	show config-replace verify log
__readonly__	(Optional) Read only
<i>log_entry</i>	(Optional) log entry from configure replace log

Command Mode

- /exec

show config-replace status

```
show config-replace status [ __readonly__ <last_operation> [ <config_replace_type> ] [ <name> ] [
<start_time> ] [ <end_time> ] [ <operation_status> ] [ <commit_status> ] [ <commit_timeout_remaining> ]
]
```

Syntax Description

show	Show running system information
config-replace	show config-replace
status	show status of last configure replace operation
<i>__readonly__</i>	(Optional) Read only
<i>last_operation</i>	(Optional) last operation
<i>config_replace_type</i>	(Optional) config-replace type
<i>name</i>	(Optional) name
<i>start_time</i>	(Optional) start time
<i>end_time</i>	(Optional) end time
<i>operation_status</i>	(Optional) operation status
<i>commit_status</i>	(Optional) Commit status
<i>commit_timeout_remaining</i>	(Optional) commit timeout remaining

Command Mode

- /exec

show config-template

```
show config-template [ [ <template-name> ] [ status [ { vrf <vrf-name> } ] ] ] [ __readonly__ { TABLE_profile
<name> <refcount> <type> [ TABLE_cfg <cfg> ] [ TABLE_status <vrfname> <status> } ] ]
```

Syntax Description

show	Show running system information
config-template	config-template
<i>template-name</i>	(Optional) config-template name
status	(Optional) config-template status
vrf	(Optional) VRF referencing config-template
<i>vrf-name</i>	(Optional) config-template name
__readonly__	(Optional)
TABLE_profile	(Optional)
<i>name</i>	(Optional) config-template name
<i>refcount</i>	(Optional) Ref count of VRFs using this config-template
<i>type</i>	(Optional) config-template type
TABLE_cfg	(Optional)
<i>cfg</i>	(Optional) profile config
TABLE_status	(Optional)
<i>vrfname</i>	(Optional) profile config
<i>status</i>	(Optional) profile status

Command Mode

- /exec

show configuration session

```
show configuration session [ __readonly__ [ TABLE_session_all <ssn-name> [ TABLE_session_all_cmd [
<ssn-cmd-num> ] [ <command> ] ] ] <activesesscnt> ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_session_all</i>	(Optional) Show session table
<i>ssn-name</i>	(Optional)
<i>TABLE_session_all_cmd</i>	(Optional) Show session related commands
<i>ssn-cmd-num</i>	(Optional)
<i>command</i>	(Optional)
<i>activesesscnt</i>	(Optional) Number of active configuration sessions

Command Mode

- /exec

show configuration session

```
show configuration session <s3> [ __readonly__ <ssn-name> [ TABLE_session_details [ <ssn-cmd-num> ]
[ <command> ] ] ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
s3	Shows configuration session given a name
__readonly__	(Optional) Read only
ssn-name	(Optional)
TABLE_session_details	(Optional) Show session details for given name
ssn-cmd-num	(Optional)
command	(Optional)

Command Mode

- /exec

show configuration session global-info

```
show configuration session global-info [ __readonly__ <max-ssns> <max-cmds> <curr-num-ssns>
<curr-num-cmds> ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
global-info	Show configuration sessions global-info
__readonly__	(Optional) Read only
<i>max-ssns</i>	(Optional)
<i>max-cmds</i>	(Optional)
<i>curr-num-ssns</i>	(Optional)
<i>curr-num-cmds</i>	(Optional)

Command Mode

- /exec

show configuration session status

```
show configuration session status [ <s3> ] [ __readonly__ [ TABLE_session_status <ssn-name> <last-action>
<ac-status> <ac-reason> <ac-tstamp> [ <failed-cmd-num> ] [ <failed-cmd> ] [ <last-vfy-cmd-num> ] [
<last-vfy-cmd> ] [ <last-vfy-tstamp> ] [ <rollback-status> ] ] ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
status	Show configuration session-mgr status
s3	(Optional) Shows configuration session status given a name
__readonly__	(Optional) Read only
TABLE_session_status	(Optional) Show session status table
ssn-name	(Optional)
last-action	(Optional) Last Action
ac-status	(Optional) Last Action Status
ac-reason	(Optional) Last Action Reason
ac-tstamp	(Optional) Last Action Timestamp
failed-cmd-num	(Optional) Failed Command Number
failed-cmd	(Optional) Failed Command
last-vfy-cmd-num	(Optional) Last Verified Command Number
last-vfy-cmd	(Optional) Last Verified Command
last-vfy-tstamp	(Optional) Last Verified Command Timestamp
rollback-status	(Optional) Rollback Status

Command Mode

- /exec

show configuration session summary

```
show configuration session summary [ __readonly__ [ TABLE_session_summary <ssn-name> <username>
<tstamp> ] [ <activesesscnt> ] ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
summary	Show summary of the active configuration sessions
__readonly__	(Optional) Read only
TABLE_session_summary	(Optional) Show session summary table
<i>ssn-name</i>	(Optional)
<i>username</i>	(Optional) Session Owner
<i>tstamp</i>	(Optional) Creation Time
<i>activesesscnt</i>	(Optional) Number of active configuration sessions

Command Mode

- /exec

show consistency-checker copp

show consistency-checker copp

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
copp	Verify copp programming from software context

Command Mode

- /exec

show consistency-checker egress-xlate private-vlan

show consistency-checker egress-xlate private-vlan <vlan>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
egress-xlate	Check PVLAN egress-xlate
private-vlan	Verifies private-vlan egress-xlate in the hardware
<i>vlan</i>	Enter private-vlan id

Command Mode

- /exec

show consistency-checker forwarding ipv6 show forwarding ipv6 inconsistency

```
show consistency-checker forwarding ipv6 [ unicast ] [ vrf { <vrf-name> | all_vrfs } ] [ module { <module>
| all_modules } ] | show forwarding ipv6 [ unicast ] inconsistency [ vrf { <vrf-name> | all_vrfs } ] [ module
{ <module> | all_modules } ] [ __readonly__ TABLE_inconsistency <idipv6> <slotipv6> [ <unitipv6> ]
<vrfipv6> [ <ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> ]
```

Syntax Description

show	show
consistency-checker	Consistency Checker
forwarding	Display Forwarding Information
inconsistency	route inconsistency check
ipv6	ipv6
unicast	(Optional) unicast
vrf	(Optional) check routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
module	(Optional) check routes for a specific module
<i>module</i>	(Optional) module number
all_modules	(Optional) all module's
all_vrfs	(Optional) all vrf's
__readonly__	(Optional)
TABLE_inconsistency	(Optional)
<i>idipv6</i>	(Optional)
<i>slotipv6</i>	(Optional)
<i>unitipv6</i>	(Optional)
<i>vrfipv6</i>	(Optional)
<i>interfaceipv6</i>	(Optional)
<i>reasonipv6</i>	(Optional)

Command Mode

- /exec

show consistency-checker forwarding show forwarding inconsistency

```
show consistency-checker forwarding [ ip | ipv4 ] [ unicast ] [ vrf { <vrf-name> | all_vrfs } ] [ module {
<module> | all_modules } ] | show forwarding [ ip | ipv4 ] [ unicast ] inconsistency [ vrf { <vrf-name> | all_vrfs
} ] [ module { <module> | all_modules } ] [ __readonly__ TABLE_inconsistency <id> <slot> [ <unit> ] <vrf>
[ <ipaddr> ] [ <ipprefix> ] [ <interface> ] <reason> ]
```

Syntax Description

show	show
consistency-checker	Consistency Checker
forwarding	Display Forwarding Information
inconsistency	route inconsistency check
ip	(Optional) ipv4
ipv4	(Optional) ipv4
unicast	(Optional) unicast
vrf	(Optional) check routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
module	(Optional) check routes for a specific module
<i>module</i>	(Optional) module number
all_modules	(Optional) all module's
all_vrfs	(Optional) all vrf's
__readonly__	(Optional)
TABLE_inconsistency	(Optional)
<i>id</i>	(Optional)
<i>slot</i>	(Optional)
<i>unit</i>	(Optional)
<i>vrf</i>	(Optional)
<i>ipaddr</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>interface</i>	(Optional)

<i>reason</i>	(Optional)
---------------	------------

Command Mode

- /exec

show consistency-checker forwarding single-route ipv4 vrf

show consistency-checker forwarding single-route { ipv4 | ipv6 } <ip-prefix> vrf <vrf-name>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
forwarding	Display Forwarding Information
single-route	Run the consistency checker for a single route
ipv4	IPv4 address
ipv6	IPv6 address
<i>ip-prefix</i>	Specify an IP prefix/mask
vrf	check routes for a specific VRF
<i>vrf-name</i>	vrf name

Command Mode

- /exec

show consistency-checker kim

show consistency-checker kim

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
kim	Kernel Interface

Command Mode

- /exec

show consistency-checker l2-tahoe module

show consistency-checker l2-tahoe module <module> [unit <unit>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	l2 consistency
module	Module to run the consistency-checker on
<i>module</i>	Enter module number
unit	(Optional) Unit to run the consistency checker on
<i>unit</i>	(Optional) Enter unit number

Command Mode

- /exec

show consistency-checker l2-tahoe switchport interface

show consistency-checker l2-tahoe switchport interface <if_name>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	l2 consistency
switchport	Switchport Interface
interface	interface
<i>if_name</i>	Physical or Logical interface

Command Mode

- /exec

show consistency-checker l2 multicast group source vlan

show consistency-checker l2 multicast group <grp-address> source <src-address> vlan <vlan-id>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2	l2 consistency
multicast	multicast related information
group	Do consistency check for group
<i>grp-address</i>	group IP address
source	Do consistency check for source
<i>src-address</i>	source IP address
vlan	Do consistency check for vlan
<i>vlan-id</i>	vlan number

Command Mode

- /exec

show consistency-checker l3-interface module

show consistency-checker l3-interface module <moduleid>

Syntax Description

show	Show running system information
module	Limit display to interfaces on module
<i>moduleid</i>	Enter module number
consistency-checker	Consistency Checker
l3-interface	Compares software and hardware properties of L3 interfaces

Command Mode

- /exec

show consistency-checker l3 multicast group source vrf

show consistency-checker l3 multicast group <grp-address> source <src-address> vrf <vrf-string>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l3	l3 consistency
multicast	multicast related information
group	Do consistency check for group
<i>grp-address</i>	group IP address
source	Do consistency check for source
<i>src-address</i>	source IP address
vrf	Do consistency check for vrf
<i>vrf-string</i>	Vrf string

Command Mode

- /exec

show consistency-checker link-state fabric-ieth

```
show consistency-checker link-state fabric-ieth { [ module <module> ] }
```

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
link-state	Compares software and hardware link state of interfaces
fabric-ieth	Internal Fabric ports
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number

Command Mode

- /exec

show consistency-checker link-state module

show consistency-checker link-state module <module>

Syntax Description

show	Show running system information
module	Limit display to interfaces on module
<i>module</i>	Enter module number
consistency-checker	Consistency Checker
link-state	Compares software and hardware link state of interfaces

Command Mode

- /exec

show consistency-checker membership port-channels

show consistency-checker membership port-channels [interface <ch-id>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
membership	Check various memberships
port-channels	Verifies port channel membership in the hardware
interface	(Optional) Port-channel number
<i>ch-id</i>	(Optional) Port-Channel name

Command Mode

- /exec

show consistency-checker membership vlan

```
show consistency-checker membership vlan <vlanid> [ private-vlan [ interface [ <int-id> | <ch-id> ] ] ] [ native-vlan ]
```

Syntax Description

show	Show running system information
vlan	Verifies vlan membership in the hardware
<i>vlanid</i>	Enter vlan id
consistency-checker	Consistency Checker
membership	Check various memberships
private-vlan	(Optional) Check private-vlan primary vlan
interface	(Optional) Interface
<i>int-id</i>	(Optional) Interface name
<i>ch-id</i>	(Optional) Port-Channel name
native-vlan	(Optional) Check for native vlans

Command Mode

- /exec

show consistency-checker pacl module

show consistency-checker pacl module <module>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
module	Limit display to L2 interfaces on this module
<i>module</i>	Enter module number

Command Mode

- /exec

show consistency-checker pacl port-channels

show consistency-checker pacl port-channels [interface <ch-id>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
port-channels	Verifies port channel pacl programming in the hardware
interface	(Optional) Port-channel number
<i>ch-id</i>	(Optional) Port-Channel name

Command Mode

- /exec

show consistency-checker racl module

show consistency-checker racl module <module>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
module	Limit display to L3 interfaces on this module
<i>module</i>	Enter module number

Command Mode

- /exec

show consistency-checker racl port-channels

show consistency-checker racl port-channels [interface <ch-id>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
port-channels	Verifies port channel racl programming in the hardware
interface	(Optional) Port-channel number
<i>ch-id</i>	(Optional) Port-Channel name

Command Mode

- /exec

show consistency-checker stp-state vlan

show consistency-checker stp-state vlan <vlan>

Syntax Description

show	Show running system information
vlan	Verifies spanning tree state in the hardware for all interfaces in the vlan
<i>vlan</i>	Enter vlan id
consistency-checker	Consistency Checker
stp-state	Verify spanning tree state in the hardware

Command Mode

- /exec

show consistency-checker vacl

show consistency-checker vacl

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vacl	Verify vacl programming in the hardware

Command Mode

- /exec

show consistency-checker vpc

show consistency-checker vpc [source-interface [<int-id> | <ch-id>]]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vpc	vPC related information
source-interface	(Optional) Source vPC member
<i>int-id</i>	(Optional) Eth Interface
<i>ch-id</i>	(Optional) Port-Channel

Command Mode

- /exec

show controller accounting log

show controller <ctrl-id> accounting log

Syntax Description

show	Show running system information
controller	Controller command
<i>ctrl-id</i>	Controller id value
accounting	Accounting
log	Show log information

Command Mode

- /exec

show copp diff profile profile2

show copp diff profile <profile_type> [prior-ver] profile2 <profile_type2>

Syntax Description

show	Show running system information
copp	Control-Plane Policing
diff	Difference between CoPP Profiles
profile	CoPP Profile
<i>profile_type</i>	CoPP Profile Types
prior-ver	(Optional) Previous Configured Version
profile2	CoPP Profile
<i>profile_type2</i>	CoPP Profile Types

Command Mode

- /exec

show copp profile

```
show copp profile { strict | moderate | lenient | dense } [ __readonly__ { TABLE_copp prof <acl-type> {
<acl-grp-name> { TABLE_sequence <permitdeny> [ { <proto_str> | <proto> | <ip> | <ipv6> } ] [ { <src_any>
| <src_ip_prefix> | <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> | <src_addrgrp> | <src_mac_any> |
<src_mac_addr> <src_mac_mask> } ] [ <src_port_op> { <src_port1_str> | <src_port1_num> } [ <src_port2_str>
| <src_port2_num> ] | <src_portgrp> } ] { <dest_any> | <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> |
<dest_ipv6_prefix> | <dest_addrgrp> | <dest_mac_any> | <dest_mac_addr> <dest_mac_mask> } [
<dest_port_op> { <dest_port1_str> | <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] |
<dest_portgrp> } ] [ { <icmp_type> [ <icmp_code> ] | <icmp_str> } ] [ { <icmpv6_type> [ <icmpv6_code> ] |
<icmpv6_str> } ] [ <eth_proto> ] } } } <newline> [ { TABLE_classmap <opt_any_or_all> [ <map_name>
] [ { access_grp <acc_grp_name> + } ] [ { redirect <opt_match_redirect> + } ] [ { exception <opt_match_excpt>
+ } ] [ { protocol <opt_match_protocol> + } ] } ] [ { TABLE_policymap [ <class-name> ] [ <pmap_name>
] [ <set_vld_flg> ] [ { cos [ inner ] <cos-val> } ] [ { dscp [ tunnel ] [ <dscp-val> } ] } ] [ { precedence [ tunnel1
] [ <prec-val> ] } ] [ <policer_show_flags> ] [ <cir> ] [ <opt_kbps_mbps_gbps_pps_cir> ] [ { percent <cir-perc>
} ] [ <bc> + ] [ <opt_kbytes_mbytes_gbytes_bc> + ] [ <pir> ] [ <opt_kbps_mbps_gbps_pps_pir> ] [ { percent1
<pir-perc> } ] [ <be> ] [ <opt_kbytes_mbytes_gbytes_be> ] [ <opt_drop_transmit_conform> ] [
<opt_drop_transmit_violate> ] [ { [ <opt_drop_transmit_conform1> ] } ] [ { set-cos-transmit [ <set-cos-val>
] } ] [ { set-dscp-transmit [ <set-dscp-val> ] } ] [ { set-prec-transmit [ <set-prec-val> ] } ] } ] [ { { [
<opt_drop_transmit_exceed> ] } ] [ { set dscp1 dscp2 table cir-markdown-map } } ] [ { { [
<opt_drop_transmit_violate1> ] } ] [ { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] }
```

Syntax Description

show	Show running system information
copp	Control-Plane Policing
profile	CoPP Profile
strict	display strict profile
moderate	display moderate profile
lenient	display lenient profile
dense	display dense profile
__readonly__	(Optional) Read Only
acl-type	(Optional) access-list type
TABLE_copp prof	(Optional) copp profile
acl-grp-name	(Optional) name of the access-list
TABLE_sequence	(Optional) ACE RULE SYNTAX TABLE
permitdeny	(Optional) permit/deny
proto	(Optional) A protocol number
proto_str	(Optional) Protocol name

<i>ip</i>	(Optional) IP
<i>ipv6</i>	(Optional) IPV6
<i>src_any</i>	(Optional) SRCAny
<i>dest_any</i>	(Optional) DESTAny
<i>src_ip_prefix</i>	(Optional) Source IP prefix
<i>src_ip_addr</i>	(Optional) Source IP address
<i>src_ip_mask</i>	(Optional) Source IP mask
<i>src_mac_addr</i>	(Optional) Source MAC address
<i>src_mac_mask</i>	(Optional) Source MAC mask
<i>src_mac_any</i>	(Optional) SRCMACAny
<i>dest_ip_prefix</i>	(Optional) Destination IP prefix
<i>dest_ip_addr</i>	(Optional) Destination IP address
<i>dest_ip_mask</i>	(Optional) Destination IP mask
<i>dest_mac_addr</i>	(Optional) Destination MAC address
<i>dest_mac_mask</i>	(Optional) Destination MAC mask
<i>dest_mac_any</i>	(Optional) DESTMACAny
<i>src_port_op</i>	(Optional) Source Port operator
<i>dest_port_op</i>	(Optional) Destination Port operator
<i>src_port1_str</i>	(Optional) Source port name
<i>src_port1_num</i>	(Optional) Source port number
<i>src_port2_str</i>	(Optional) Source port name
<i>src_port2_num</i>	(Optional) Source port number
<i>dest_port1_str</i>	(Optional) Destination port name
<i>dest_port1_num</i>	(Optional) Destination port number
<i>dest_port2_str</i>	(Optional) Destination port name
<i>dest_port2_num</i>	(Optional) Destination port number
<i>icmp_type</i>	(Optional) ICMP type
<i>icmp_code</i>	(Optional) ICMP code
<i>icmp_str</i>	(Optional) ICMP message

<i>icmpv6_type</i>	(Optional) ICMP type
<i>icmpv6_code</i>	(Optional) ICMP code
<i>icmpv6_str</i>	(Optional) ICMP message
<i>src_addrgrp</i>	(Optional) Source address group
<i>dest_addrgrp</i>	(Optional) Destination address group
<i>src_portgrp</i>	(Optional) Source port group
<i>dest_portgrp</i>	(Optional) Destination port group
<i>eth_proto</i>	(Optional) MAC protocol number
<i>newline</i>	(Optional) newline between access-list and cmaps
TABLE_classmap	(Optional) Class Map
<i>opt_any_or_all</i>	(Optional) Enter match-any or match-all
<i>cmap_name</i>	(Optional) Name of the class-map
access_grp	(Optional) Access Group
<i>acc_grp_name</i>	(Optional)
redirect	(Optional)
<i>opt_match_redirect</i>	(Optional) Match criteria for redirected packets
exception	(Optional)
<i>opt_match_excpt</i>	(Optional) Match criteria for exception packets
protocol	(Optional)
<i>opt_match_protocol</i>	(Optional) Match criteria for protocol packets
TABLE_policymap	(Optional) Policy Map table
<i>class-name</i>	(Optional) Name if the policy member
<i>pmap_name</i>	(Optional) Name of the Policy-map
<i>set_vld_flg</i>	(Optional) Set valid flag
<i>cos-val</i>	(Optional) Set cos val
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	(Optional)
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
<i>opt_drop_transmit_conform</i>	(Optional) Set the action

<i>opt_drop_transmit_violate</i>	(Optional) Set the action
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional)
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
<i>opt_drop_transmit_conform1</i>	(Optional) Set the action
set-cos-transmit	(Optional)
<i>set-cos-val</i>	(Optional) Conform action cos val
set-dscp-transmit	(Optional)
<i>set-dscp-val</i>	(Optional) Conform action dscp val
set-prec-transmit	(Optional)
<i>set-prec-val</i>	(Optional) Conform action prec val
<i>policer_show_flags</i>	(Optional) Policer show flags
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional)
dscp1	(Optional)
dscp2	(Optional)
table	(Optional)
cir-markdown-map	(Optional)
<i>opt_drop_transmit_violate1</i>	(Optional) Set the action
set1	(Optional)
dscp3	(Optional)
dscp4	(Optional)
table1	(Optional)
pir-markdown-map	(Optional)
cos	(Optional)
inner	(Optional)
dscp	(Optional)
tunnel	(Optional)
<i>dscp-val</i>	(Optional) Set dscp val

precedence	(Optional)
tunnell	(Optional)
<i>prec-val</i>	(Optional) Set prec val

Command Mode

- /exec

show copp status

```
show copp status [ __readonly__ { last_config_operation <last_cfg_oper> } { last_config_operation_time
<last_cfg_oper_time> } { last_config_operation_status <last_cfg_oper_status> } [
last_config_operation_error_time <last_cfg_oper_error_time> ] [ last_config_operation_error
<last_cfg_oper_error> ] { service_policy <srv_policy> } ]
```

Syntax Description

show	Show running system information
copp	Control-Plane Policing
status	Show the internal status of CoPP
<i>__readonly__</i>	(Optional)
last_config_operation	(Optional) last config operation
<i>last_cfg_oper</i>	(Optional) last config operation
last_config_operation_time	(Optional) timestamp of last config operation
<i>last_cfg_oper_time</i>	(Optional) timestamp of last config operation
last_config_operation_status	(Optional) status of last config operation
<i>last_cfg_oper_status</i>	(Optional) status of last config operation
last_config_operation_error_time	(Optional) timestamp of last config operation's error
<i>last_cfg_oper_error_time</i>	(Optional) timestamp of last config operation's error
last_config_operation_error	(Optional) last config operation's error
<i>last_cfg_oper_error</i>	(Optional) last config operation's error
service_policy	(Optional) policy-map attached to control-plane
<i>srv_policy</i>	(Optional) policy-map attached to control-plane

Command Mode

- /exec

show copyright

show copyright [*__readonly__* { <content> }]

Syntax Description

show	Show running system information
copyright	Copyright information
<i>__readonly__</i>	(Optional)
<i>content</i>	(Optional) Copyright information

Command Mode

- /exec

show cores

```
show cores [ vdc-all | { vdc [ <e-vdc2> | <vdc-id> ] } ] [ __readonly__ { [ TABLE_cores <vdc_id>
<module_id> <instance> <process_name> <pid> <sys_time> ] } ]
```

Syntax Description

show	Show running system information
cores	show all core dumps for the current vdc
vdc-all	(Optional) show core dumps from all vdes
vdc	(Optional) show all core dumps for the vdc
__readonly__	(Optional)
TABLE_cores	(Optional)
<i>vdc_id</i>	(Optional) vdc id
<i>module_id</i>	(Optional) module id
<i>instance</i>	(Optional) instance number
<i>process_name</i>	(Optional) name of the process
<i>pid</i>	(Optional) process id
<i>sys_time</i>	(Optional) core generate time
<i>e-vdc2</i>	(Optional) Enter VDC <vdc-id>
<i>vdc-id</i>	(Optional) vdc number

Command Mode

- /exec

show crypto ca certificates

```
show crypto ca certificates [ __readonly__ [ { TABLE_ca_certificates <trustpoint> [ <certificate> ] [ {
TABLE_ca_cert_chains <index> <ca_certificate> } ] } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
certificates	show various certificates
<i>__readonly__</i>	(Optional)
<i>TABLE_ca_certificates</i>	(Optional) Table of CA certificates
<i>trustpoint</i>	(Optional) Trustpoint name
<i>certificate</i>	(Optional) Certificate
<i>TABLE_ca_cert_chains</i>	(Optional) Table of CA certificates in chain
<i>index</i>	(Optional) CA Certificate Index
<i>ca_certificate</i>	(Optional) CA certificate

Command Mode

- /exec

show crypto ca certificates

```
show crypto ca certificates <s0> [ __readonly__ { Trustpoint <trustpoint> } [ { Certificate <certificate> } ]
[ { TABLE_ca_cert_chains <index> <ca_certificate> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
certificates	show various certificates
<i>s0</i>	trustpoint label
<i>__readonly__</i>	(Optional)
Trustpoint	(Optional) Trustpoint
<i>trustpoint</i>	(Optional) Trustpoint
Certificate	(Optional) Certificate
<i>certificate</i>	(Optional) Certificate
TABLE_ca_cert_chains	(Optional) Table of CA certificates in chain
<i>index</i>	(Optional) CA Certificate Index
<i>ca_certificate</i>	(Optional) CA certificate

Command Mode

- /exec

show crypto ca certstore

```
show crypto ca certstore [ __readonly__ { certstore_lookup <lookup_type> } ]
```

Syntax Description

show	Show running system information
crypto	Show crypto configuration
ca	show crypto ca configuration
certstore	Show the configured certstore
__readonly__	(Optional)
certstore_lookup	(Optional) Certificate store lookup
<i>lookup_type</i>	(Optional) Lookup type

Command Mode

- /exec

show crypto ca crl

```
show crypto ca crl <s0> [ __readonly__ { Trustpoint <trustpoint> } [ { CRL <crl> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
crl	show CRL
<i>s0</i>	trustpoint label
<i>__readonly__</i>	(Optional)
Trustpoint	(Optional) Trustpoint
<i>trustpoint</i>	(Optional) Trustpoint
CRL	(Optional) Certificate Revocation List
<i>crl</i>	(Optional) Certificate Revocation List

Command Mode

- /exec

show crypto ca remote-certstore

```
show crypto ca remote-certstore [ __readonly__ { remote_cert_store <rem_cert_store> } [ { crl_timer <crltimer>
} { ldap_server_group <ldap_server_grp> } ] ]
```

Syntax Description

show	Show running system information
crypto	Show crypto configuration
ca	show crypto ca configuration
remote-certstore	Show remote certstore configuration
__readonly__	(Optional)
remote_cert_store	(Optional) Remote cert store
<i>rem_cert_store</i>	(Optional) Remote certificate store
crl_timer	(Optional) CRL timer
<i>crltimer</i>	(Optional) CRL timer
ldap_server_group	(Optional) LDAP Server Group
<i>ldap_server_grp</i>	(Optional) LDAP Server Group

Command Mode

- /exec

show crypto ca trustpoints

```
show crypto ca trustpoints [ __readonly__ [ { TABLE_ca_truspoints <trustpoint> <key-pair> [ {
TABLE_revocation_methods <revocation-method> } ] [ <ocsp-url> ] } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
trustpoints	show trustpoint configuration
<i>__readonly__</i>	(Optional)
<i>trustpoint</i>	(Optional) Trustpoint
<i>key-pair</i>	(Optional) Key pair
TABLE_revocation_methods	(Optional) Table of revocation methods
<i>revocation-method</i>	(Optional) Revocation mehtod
<i>ocsp-url</i>	(Optional) OCSP URL
TABLE_ca_truspoints	(Optional) Table of CA trustpoints

Command Mode

- /exec

show crypto ca trustpool

```
show crypto ca trustpool [ __readonly__ [ { TABLE_ca_trustpool <serial-number> <subject> <issued-by>
<validity-start> <validity-end> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto information
ca	show trustpool data
trustpool	trustpool contents
<i>__readonly__</i>	(Optional)
<i>TABLE_ca_trustpool</i>	(Optional) Table of CA trustpool
<i>serial-number</i>	(Optional) Serial number
<i>subject</i>	(Optional) subject
<i>issued-by</i>	(Optional) Issued by
<i>validity-start</i>	(Optional) validity start date
<i>validity-end</i>	(Optional) validity end date

Command Mode

- /exec

show crypto ca trustpool last download status

```
show crypto ca trustpool last download status [ __readonly__ [ http_url <http_url> ] [ download_time
<download_time> ] [ trustpool_download_status <status> ] [ download_failure <reason> ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto information
ca	show trustpool data
trustpool	trustpool data
last	last trustpool download status
download	download of trustpool
status	download status
<i>__readonly__</i>	(Optional)
http_url	(Optional) http url configured
<i>http_url</i>	(Optional) HTTP url
download_time	(Optional) Download time
<i>download_time</i>	(Optional) Download time
trustpool_download_status	(Optional) Status of trustpool policy download
<i>status</i>	(Optional) Download status
download_failure	(Optional) Download failure
<i>reason</i>	(Optional) Download failure reason

Command Mode

- /exec

show crypto ca trustpool policy

```
show crypto ca trustpool policy [ __readonly__ [ http_url <http_url> ] [ config_vrf [ <config_vrf> ] [ <src_intf>
] ] [ proxy_server [ <proxy_server> ] [ <proxy_server_port> ] ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto information
ca	show Certificate authority related config
trustpool	show trustpool policy
policy	trustpool configuration
<i>__readonly__</i>	(Optional)
http_url	(Optional) http url configured
<i>http_url</i>	(Optional) HTTP url
config_vrf	(Optional) Configured vrf
<i>config_vrf</i>	(Optional) vrf configured
<i>src_intf</i>	(Optional) source interface for vrf
proxy_server	(Optional) Configured proxy server
<i>proxy_server</i>	(Optional) proxy server
<i>proxy_server_port</i>	(Optional) proxy server port

Command Mode

- /exec

show crypto certificatemap

```
show crypto certificatemap [ __readonly__ [ { TABLE_certmap <map_name> <subject_name>
<alternate_email> <alternate_upn> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
certificatemap	show certificatemap filters
<i>__readonly__</i>	(Optional)
<i>TABLE_certmap</i>	(Optional) Table of Certificate Map
<i>map_name</i>	(Optional) Map name
<i>subject_name</i>	(Optional) Subject name
<i>alternate_email</i>	(Optional) Alternate Email
<i>alternate_upn</i>	(Optional) Alternate UPN

Command Mode

- /exec

show crypto key mypubkey rsa

```
show crypto key mypubkey rsa [ __readonly__ [ { TABLE_rsa_keys <key_label> <key_size> <exportable>
<err_string> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
key	show key configuration
mypubkey	show my public keys configuration
rsa	show my rsa public keys configuration
<i>__readonly__</i>	(Optional)
<i>TABLE_rsa_keys</i>	(Optional) Table of RSA keys
<i>key_label</i>	(Optional) Key Label
<i>key_size</i>	(Optional) Key size
<i>exportable</i>	(Optional) Exportable
<i>err_string</i>	(Optional) Error String

Command Mode

- /exec

show crypto ssh-auth-map

```
show crypto ssh-auth-map [ __readonly__ [ { TABLE_ssh_auth_map <issuer_name> <map1> [ <map2> ] } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ssh-auth-map	show mapping filters applied for ssh authentication
__readonly__	(Optional)
TABLE_ssh_auth_map	(Optional) Table of SSH Auth MAP
<i>issuer_name</i>	(Optional) Issuer Name
<i>map1</i>	(Optional) Map 1
<i>map2</i>	(Optional) Map 2

Command Mode

- /exec

show crypto ssh-auth-map

show crypto ssh-auth-map

Syntax Description

show	Show running system information
crypto	show crypto configuration
ssh-auth-map	show mapping filters applied for ssh authentication

Command Mode

- /exec

show cts

show cts [*__readonly__* <device-id> <cache_en> <num-dot1x> <num-man> <sgt>]

Syntax Description

<i>cts</i>	Show CTS global configuration
<i>__readonly__</i>	(Optional)
<i>device-id</i>	(Optional) name
<i>cache_en</i>	(Optional) enable/disable
<i>num-dot1x</i>	(Optional) number of interfaces in dot1x mode
<i>num-man</i>	(Optional) number of interfaces in manual mode
<i>sgt</i>	(Optional)

Command Mode

- /exec

show current

show current

Syntax Description

show	Display region configurations
current	Display mst configuration currently used

Command Mode

- /exec/configure/spanning-tree/mst/configuration



D Show Commands

- [show dampening interface](#), on page 318
- [show diagnostic bootup level](#), on page 319
- [show diagnostic content module](#), on page 320
- [show diagnostic description module test all](#), on page 321
- [show diagnostic events](#), on page 322
- [show diagnostic ondemand setting](#), on page 323
- [show diagnostic result module](#), on page 324
- [show diagnostic result module all](#), on page 326
- [show diagnostic simulation module](#), on page 328
- [show diagnostic status module](#), on page 329
- [show diff rollback-patch](#), on page 330
- [show dot1q-tunnel](#), on page 331
- [show dot1q-tunnel interface](#), on page 332
- [show dot1x](#), on page 333
- [show dot1x all](#), on page 334
- [show dot1x all details](#), on page 336
- [show dot1x all statistics](#), on page 338
- [show dot1x all summary](#), on page 340
- [show dot1x interface](#), on page 341
- [show dot1x interface client statistics](#), on page 345
- [show dot1x interface client statistics address](#), on page 347
- [show dummy](#), on page 348

show dampening interface

show dampening interface

Syntax Description

show	Show running system information
dampening	Display dampening information
interface	Display interface dampening general information

Command Mode

- /exec

show diagnostic bootup level

show diagnostic bootup level [*__readonly__* <bootup_level>]

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
bootup	Show diagnostic bootup information
level	Show diagnostic bootup level information
<i>__readonly__</i>	(Optional)
<i>bootup_level</i>	(Optional) Bootup level

Command Mode

- /exec

show diagnostic content module

```
show diagnostic content module { all | <module> } [ __readonly__ <attr_descr> { TABLE_Module
<module_id> <module_type> { TABLE_test <test_id> <testname> <test_attr> <test_interval> } } ]
```

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
content	Show diagnostic test content
module	Module Keyword
all	Select all module ID
<i>module</i>	Module number
<i>__readonly__</i>	(Optional)
<i>attr_descr</i>	(Optional) Attribute description
TABLE_Module	(Optional) All modules table
<i>module_id</i>	(Optional) Module Number
<i>module_type</i>	(Optional) module type description
TABLE_test	(Optional) All tests table
<i>test_id</i>	(Optional) Test id
<i>testname</i>	(Optional) Test name
<i>test_attr</i>	(Optional) Test Attribute
<i>test_interval</i>	(Optional) HM test interval

Command Mode

- /exec

show diagnostic description module test all

```
show diagnostic description module <module> test { all | <name> | <test-id> } [ __readonly__ { TABLE_desc
<testname> <testdesc> } ]
```

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
description	Show diagnostic test desc
module	Module keyword
<i>module</i>	Module Number
test	Diagnostic test selection
all	Select all test ID
<i>name</i>	Test name
<i>test-id</i>	
__readonly__	(Optional)
TABLE_desc	(Optional) Table of test description
<i>testname</i>	(Optional) Test name
<i>testdesc</i>	(Optional) Description of the test

Command Mode

- /exec

show diagnostic events

show diagnostic events [error | info] [__readonly__ { TABLE_events <event_text> }]

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
events	Diagnostic events
error	(Optional) Error event-type
info	(Optional) Information event-type
__readonly__	(Optional)
TABLE_events	(Optional) list of events logged
<i>event_text</i>	(Optional) Text of one event

Command Mode

- /exec

show diagnostic ondemand setting

show diagnostic ondemand setting [*__readonly__* <test_iteration_count> <action_on_failure>]

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
ondemand	Show diagnostic on demand information
setting	Show diagnostic on demand settings
<i>__readonly__</i>	(Optional)
<i>test_iteration_count</i>	(Optional) Iteration Count
<i>action_on_failure</i>	(Optional) Action on failure

Command Mode

- /exec

show diagnostic result module

```
show diagnostic result module <module> [ test { <name> | <test-id> } ] [ [ detail ] | [ statistics ] ] [
__readonly__ <module_id> <curr_diag_level> <module_name> [ <bootup_diag_level> ] [ { TABLE_TestStat
<stat_testid> <stat_testname> { TABLE_StatDetail <port_no> <packet_tx> <packet_rx> <packet_loss> } }
] [ { TABLE_Test <test_id> <testname> [ <testresult> ] [ { <passed_ports> <failed_ports> <incomplete_ports>
<untested_ports> <aborted_ports> <err_disabled_ports> } ] [ { <err_code> <total_run_count>
<last_execution_time> <first_failure_time> <last_failure_time> <last_pass_time> <total_fail_count>
<consecutive_fail_count> <last_fail_reason> <next_execution_time> } } ] ] ]
```

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
result	Show diagnostic test result
module	Module keyword
<i>module</i>	Module number
test	(Optional) Diagnostic test selection
<i>test-id</i>	(Optional)
<i>name</i>	(Optional) Test name
detail	(Optional) Detailed result
statistics	(Optional) Result statistics
<i>__readonly__</i>	(Optional)
<i>module_id</i>	(Optional) Module ID
<i>curr_diag_level</i>	(Optional) Current diag level
<i>module_name</i>	(Optional) Module name
<i>bootup_diag_level</i>	(Optional) Diagnostic level at bootup
TABLE_TestStat	(Optional) Statistics table
<i>stat_testid</i>	(Optional) Test id
<i>stat_testname</i>	(Optional) Test name
TABLE_StatDetail	(Optional) Table stats detail
<i>port_no</i>	(Optional) Port Number
<i>packet_tx</i>	(Optional) Packet Tx
<i>packet_rx</i>	(Optional) Packet Rx

<i>packet_loss</i>	(Optional) Packet lost
TABLE_Test	(Optional) Table of tests in module
<i>test_id</i>	(Optional) Test id of tests
<i>testname</i>	(Optional) Test name
<i>testresult</i>	(Optional) Test Results
<i>passed_ports</i>	(Optional) List passed ports
<i>failed_ports</i>	(Optional) List failed ports
<i>incomplete_ports</i>	(Optional) List of Incompletely tested ports
<i>untested_ports</i>	(Optional) List of untested ports
<i>aborted_ports</i>	(Optional) List of aborted ports
<i>err_disabled_ports</i>	(Optional) List error disabled ports
<i>err_code</i>	(Optional) Error code
<i>total_run_count</i>	(Optional) Total run count
<i>last_execution_time</i>	(Optional) Last execution time
<i>first_failure_time</i>	(Optional) First test failure time
<i>last_failure_time</i>	(Optional) Last test failure time
<i>last_pass_time</i>	(Optional) Last test pass time
<i>total_fail_count</i>	(Optional) Total fail count
<i>consecutive_fail_count</i>	(Optional) Consecutive failure count
<i>last_fail_reason</i>	(Optional) Last failure reason
<i>next_execution_time</i>	(Optional) Next test execution time

Command Mode

- /exec

show diagnostic result module all

```
show diagnostic result module all [ detail ] [ __readonly__ { TABLE_Module <module_id> <curr_diag_level>
<module_name> [ <bootup_diag_level> ] { TABLE_Test <test_id> <testname> [ <testresult> ] [ {
<passed_ports> <failed_ports> <incomplete_ports> <untested_ports> <aborted_ports> <err_disabled_ports>
} ] [ { <err_code> <total_run_count> <last_execution_time> <first_failure_time> <last_failure_time>
<last_pass_time> <total_fail_count> <consecutive_fail_count> <last_fail_reason> <next_execution_time>
} ] } ] }
```

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
result	Show diagnostic test result
module	Module keyword
all	Select all test ID
detail	(Optional) Detailed result
__readonly__	(Optional)
TABLE_Module	(Optional) Table of modules
<i>module_id</i>	(Optional) Module ID
<i>curr_diag_level</i>	(Optional) Current diag level
<i>module_name</i>	(Optional) Module name
<i>bootup_diag_level</i>	(Optional) Diagnostic level at bootup
TABLE_Test	(Optional) Table of tests in module
<i>test_id</i>	(Optional) Test id of tests
<i>testname</i>	(Optional) Test name
<i>testresult</i>	(Optional) Test Results
<i>passed_ports</i>	(Optional) List passed ports
<i>failed_ports</i>	(Optional) List failed ports
<i>incomplete_ports</i>	(Optional) List of Incompletely tested ports
<i>untested_ports</i>	(Optional) List of untested ports
<i>aborted_ports</i>	(Optional) List of aborted ports
<i>err_disabled_ports</i>	(Optional) List error disabled ports

<i>err_code</i>	(Optional) Error code
<i>total_run_count</i>	(Optional) Total run count
<i>last_execution_time</i>	(Optional) Last execution time
<i>first_failure_time</i>	(Optional) First test failure time
<i>last_failure_time</i>	(Optional) Last test failure time
<i>last_pass_time</i>	(Optional) Last test pass time
<i>total_fail_count</i>	(Optional) Total fail count
<i>consecutive_fail_count</i>	(Optional) Consecutive failure count
<i>last_fail_reason</i>	(Optional) Last failure reason
<i>next_execution_time</i>	(Optional) Next test execution time

Command Mode

- /exec

show diagnostic simulation module

```
show diagnostic simulation module <module> [ __readonly__ <module_id> <module_name> [ { TABLE_detail
<serial_no> <testid> [ <portid> ] <mode> } ] ]
```

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
simulation	Simulating Diagnostic result
module	Module keyword
<i>module</i>	Module Number
<i>__readonly__</i>	(Optional)
<i>module_id</i>	(Optional) Module ID
<i>module_name</i>	(Optional) Module Name
TABLE_detail	(Optional) Table of simulation details
<i>serial_no</i>	(Optional) serial no
<i>testid</i>	(Optional) Test id
<i>portid</i>	(Optional) Port id
<i>mode</i>	(Optional) Simulation mode

Command Mode

- /exec

show diagnostic status module

```
show diagnostic status module <module> [ __readonly__ <test_runby_mapping> <module_id> <module_name>
{ TABLE_current <cur_test_name> <cur_run_by> } { TABLE_enqueued <enq_test_name> <enq_run_by> }
]
```

Syntax Description

show	Show running system information
diagnostic	Diagnostic commands
status	Show test status(running/enqueued)
module	Module keyword
<i>module</i>	Module number
<i>__readonly__</i>	(Optional)
<i>test_runby_mapping</i>	(Optional) Test type expansion
<i>module_id</i>	(Optional) Module Id
<i>module_name</i>	(Optional) Module name
TABLE_current	(Optional) Table of currently running test
<i>cur_test_name</i>	(Optional) Currently running test
<i>cur_run_by</i>	(Optional) Test Run By
TABLE_enqueued	(Optional) Table of enqueued tests
<i>enq_test_name</i>	(Optional) Enqueued test name
<i>enq_run_by</i>	(Optional) Test enqueued by

Command Mode

- /exec

show diff rollback-patch

```
show diff rollback-patch { src-checkpoint <chkpoint_name> | src-running-cfg | src-startup-cfg | src-file
<srcfile_uri> } { dst-checkpoint <chkpoint_name> | dst-running-cfg | dst-startup-cfg | dst-file <dstfile_uri>
} [ __readonly__ [ <patch_entry> ] + ]
```

Syntax Description

show	Show running system information
diff	Show diff between configuration files or checkpoints
rollback-patch	Show rollback patch between configuration files or checkpoints
src-checkpoint	Use checkpoint as source configuration
<i>chkpoint_name</i>	Checkpoint name
src-running-cfg	Use running configuration as source
src-startup-cfg	Use startup configuration as source
src-file	Src Checkpoint file
<i>srcfile_uri</i>	Src Checkpoint file path
dst-checkpoint	Use checkpoint as destination configuration
<i>chkpoint_name</i>	Checkpoint name
dst-running-cfg	Use running configuration as destination
dst-startup-cfg	Use startup configuration as destination
dst-file	Dst Checkpoint file
<i>dstfile_uri</i>	Src Checkpoint file path
<i>__readonly__</i>	(Optional) Read only
<i>patch_entry</i>	(Optional) rollback patch entry

Command Mode

- /exec

show dot1q-tunnel

```
show dot1q-tunnel [ __readonly__ TABLE_interface <interface> ]
```

Syntax Description

show	Show running system information
dot1q-tunnel	Show if port mode is dot1q-tunnel
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface

Command Mode

- /exec

show dot1q-tunnel interface

show dot1q-tunnel interface <ifid_eth_dot1q_tunnel> [__readonly__ TABLE_interface <interface>]

Syntax Description

show	Show running system information
dot1q-tunnel	Show if port mode is dot1q-tunnel
interface	Show interface status and information
<i>ifid_eth_dot1q_tunnel</i>	Enter interface type and number in module/slot format
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface

Command Mode

- /exec

show dot1x

```
show dot1x [ __readonly__ <sys_auth_ctrl> <proto_ver> <mac_move> ]
```

Syntax Description

dot1x	dot1x configuration commands
__readonly__	(Optional)
<i>sys_auth_ctrl</i>	(Optional) show system auth control
<i>proto_ver</i>	(Optional) show protocol version
<i>mac_move</i>	(Optional) show mac move

Command Mode

- /exec

show dot1x all

```
show dot1x all [ __readonly__ <sys_auth_ctrl> <proto_ver> <mac_move> TABLE_all <if_index>
TABLE_allpae <pae_type> [ <port_control> ] [ <host_mode> ] [ <quiet_period> ] [ <inactivity_period> ] [
<tx_period> ] [ <max_req> ] [ <reauth> ] [ <rate_limit_period> ] [ <supp_timeout> ] [ <server_timeout> ] [
<reauth_server> ] [ <reauth_period> ] [ <reauth_max> ] [ <mac_auth_bypass> ] [ <start_period> ] [
<auth_period> ] [ <held_period> ] [ <max_start> ] ]
```

Syntax Description

dot1x	dot1x configuration commands
all	Show information for all interfaces
<i>__readonly__</i>	(Optional)
TABLE_all	(Optional)
TABLE_allpae	(Optional)
<i>if_index</i>	(Optional) Interface Index
<i>sys_auth_ctrl</i>	(Optional) Show System Auth Control
<i>proto_ver</i>	(Optional) Show Protocol Version
<i>mac_move</i>	(Optional) Show Mac Move
<i>pae_type</i>	(Optional) Show PAE Type
<i>port_control</i>	(Optional) Show Port Control
<i>host_mode</i>	(Optional) Show Host Mode
<i>reauth</i>	(Optional) Show Reauth Enabled Status
<i>quiet_period</i>	(Optional) Show Quiet Period
<i>inactivity_period</i>	(Optional) Show Inactivity Period
<i>server_timeout</i>	(Optional) Show Server Timeout
<i>supp_timeout</i>	(Optional) Show Supp Timeout
<i>reauth_period</i>	(Optional) Show Reauth Period
<i>reauth_max</i>	(Optional) Show Reauth Max
<i>max_req</i>	(Optional) Show Max Req
<i>tx_period</i>	(Optional) Show Tx Period
<i>rate_limit_period</i>	(Optional) Show Rate Limit Period
<i>reauth_server</i>	(Optional) Show Reauth Server Enabled Status

<i>mac_auth_bypass</i>	(Optional) Show MAC Auth Bypass Enabled Status
<i>start_period</i>	(Optional) Show Supplicant Start Period
<i>auth_period</i>	(Optional) Show Supplicant Auth Period
<i>held_period</i>	(Optional) Show Supplicant Held Period
<i>max_start</i>	(Optional) Show Supplicant Max Start

Command Mode

- /exec

show dot1x all details

```
show dot1x all details [ __readonly__ <sys_auth_ctrl> <proto_ver> <mac_move> TABLE_alldetail <if_index>
TABLE_allpaedetail <pae_type> [ <port_control> ] [ <host_mode> ] [ <quiet_period> ] [ <inactivity_period>
] [ <tx_period> ] [ <max_req> ] [ <reauth> ] [ <rate_limit_period> ] [ <supp_timeout> ] [ <server_timeout>
] [ <reauth_server> ] [ <reauth_period> ] [ <reauth_max> ] [ <mac_auth_bypass> ] [ <no_of_clients> ] [
<port_status_no_clients> ] [ { TABLE_if_auth_clients [ <supp_mac_addr> ] [ <auth_domain> ] [
<auth_sm_state> ] [ <auth_bend_sm_state> ] [ <port_status> ] [ <authentication_method> ] [
<authenticated_by> ] [ <reauth_period_client> ] [ <reauth_action> ] [ <time_to_next_reauth> ] [ <auth_vlan>
] } ] [ <start_period> ] [ <auth_period> ] [ <held_period> ] [ <max_start> ] [ <no_of_supp_clients> ] [
<auth_mac_addr> ] [ <supp_sm_state> ] [ <supp_bend_sm_state> ] [ <supp_port_status> ] ]
```

Syntax Description

dot1x	dot1x configuration commands
all	Show information for all interfaces
details	802.1x details
<i>__readonly__</i>	(Optional)
TABLE_alldetail	(Optional)
TABLE_allpaedetail	(Optional)
TABLE_if_auth_clients	(Optional)
<i>if_index</i>	(Optional) Interface Index
<i>sys_auth_ctrl</i>	(Optional) Show System Auth Control
<i>proto_ver</i>	(Optional) Show Protocol Version
<i>mac_move</i>	(Optional) Show Mac Move
<i>pae_type</i>	(Optional) Show PAE Type
<i>port_control</i>	(Optional) Show Port Control
<i>host_mode</i>	(Optional) Show Host Mode
<i>reauth</i>	(Optional) Show Reauth Enabled Status
<i>quiet_period</i>	(Optional) Show Quiet Period
<i>server_timeout</i>	(Optional) Show Server Timeout
<i>supp_timeout</i>	(Optional) Show Supp Timeout
<i>reauth_period</i>	(Optional) Show Reauth Period
<i>reauth_max</i>	(Optional) Show Reauth Max
<i>max_req</i>	(Optional) Show Max Req

<i>tx_period</i>	(Optional) Show Tx Period
<i>rate_limit_period</i>	(Optional) Show Rate Limit Period
<i>inactivity_period</i>	(Optional) Show Inactivity Period
<i>reauth_server</i>	(Optional) Show Reauth Server Enabled Status
<i>mac_auth_bypass</i>	(Optional) Show MAC Auth Bypass Enabled Status
<i>no_of_clients</i>	(Optional) Show Supplicant Clients
<i>port_status_no_clients</i>	(Optional) Show Port Status if there are no clients
<i>supp_mac_addr</i>	(Optional) Show Supplicant MAC Address
<i>auth_domain</i>	(Optional) Show Supplicant Auth Domain
<i>auth_sm_state</i>	(Optional) Show Authenticator SM State
<i>auth_bend_sm_state</i>	(Optional) Show Authenticator Backend State
<i>port_status</i>	(Optional) Show Port Status
<i>authentication_method</i>	(Optional) show authentication method
<i>authenticated_by</i>	(Optional) show authenticated by
<i>reauth_period_client</i>	(Optional) Show Reauth Period
<i>reauth_action</i>	(Optional) Show Reauthentication Action
<i>time_to_next_reauth</i>	(Optional) Show Time to Next Reauth
<i>auth_vlan</i>	(Optional) Show Vlan
<i>start_period</i>	(Optional) Show Supplicant Start Period
<i>auth_period</i>	(Optional) Show Supplicant Auth Period
<i>held_period</i>	(Optional) Show Supplicant Held Period
<i>max_start</i>	(Optional) Show Supplicant Max Start
<i>no_of_supp_clients</i>	(Optional) Show Supplicant Clients
<i>auth_mac_addr</i>	(Optional) Show Authenticator MAC Address
<i>supp_sm_state</i>	(Optional) Show Supplicant SM State
<i>supp_bend_sm_state</i>	(Optional) Show Supplicant Backend SM State
<i>supp_port_status</i>	(Optional) Show Supplicant Port Status

Command Mode

- /exec

show dot1x all statistics

```
show dot1x all statistics [ __readonly__ TABLE_allstat <if_index> TABLE_allpaestat <pae_type> [ <rxstart>
] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [ <rxlenerr> ] [ <rxtotal> ] [ <txreq> ] [ <txreqid>
] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemaac> ] [ <rxreq> ] [ <rxsuppinvalid> ] [ <rxsupplennerr> ] [
<rxsupptotal> ] [ <txstart> ] [ <txlogoff> ] [ <txresp> ] [ <txsupptotal> ] [ <rxsuppverson> ] [ <lastrxsrccmac>
] ]
```

Syntax Description

dot1x	dot1x configuration commands
all	Show information for all interfaces
statistics	802.1x statistics
__readonly__	(Optional)
TABLE_allstat	(Optional)
TABLE_allpaestat	(Optional)
<i>if_index</i>	(Optional) Interface Index
<i>pae_type</i>	(Optional) Show PAE Type
<i>rxstart</i>	(Optional) Show Received EAPOL-Start
<i>rxlogoff</i>	(Optional) Show Received EAPOL-Logoff
<i>rxresp</i>	(Optional) Show Received EAP-Response
<i>rxrespid</i>	(Optional) Show Received EAP-ResponseID
<i>rxinvalid</i>	(Optional) Show Received Invalid EAPOL Frame
<i>rxlenerr</i>	(Optional) Show Received EAPOL Bad Length Frame
<i>rxtotal</i>	(Optional) Show Received Total EAPOL Frame
<i>txreq</i>	(Optional) Show Transmitted EAP-Request
<i>txreqid</i>	(Optional) Show Transmitted EAP-RequestID
<i>txtotal</i>	(Optional) Show Transmitted Total EAPOL Frame
<i>rxversion</i>	(Optional) Show Received EAPOL Version
<i>lastrxsourcemaac</i>	(Optional) Show Last Source MAC
<i>rxreq</i>	(Optional) Show Received EAP-Request
<i>rxsuppinvalid</i>	(Optional) Show received Invalid EAPOL Frame
<i>rxsupplennerr</i>	(Optional) Show received EAPOL Bad Length Frame

<i>rxsupptotal</i>	(Optional) Show Received Total EAPOL Frame
<i>txstart</i>	(Optional) Show transmitted EAPOL-Start
<i>txlogoff</i>	(Optional) Show transmitted EAPOL-Logoff
<i>txresp</i>	(Optional) Show transmitted EAP-Response
<i>txsupptotal</i>	(Optional) Show transmitted Total EAPOL Frame
<i>rxsuppversion</i>	(Optional) Show Received EAPOL Version
<i>lastrxsrmac</i>	(Optional) Show Last Source MAC received

Command Mode

- /exec

show dot1x all summary

```
show dot1x all summary [ __readonly__ TABLE_allsummary <if_index> <pae_type> [
<port_status_no_clients> ] [ { TABLE_if_auth_clients [ <auth_mac_addr> ] [ <port_status> ] } ] ]
```

Syntax Description

dot1x	dot1x configuration commands
all	Show information for all interfaces
summary	802.1x summary
<i>__readonly__</i>	(Optional)
<i>TABLE_allsummary</i>	(Optional)
<i>TABLE_if_auth_clients</i>	(Optional)
<i>if_index</i>	(Optional) Interface Index
<i>pae_type</i>	(Optional) Show PAE Type
<i>auth_mac_addr</i>	(Optional) Show Authenticator MAC Address
<i>port_status_no_clients</i>	(Optional) Show Port Status if there are no clients
<i>port_status</i>	(Optional) Show Port Status

Command Mode

- /exec

show dot1x interface

```
{ show dot1x interface <if> [ __readonly__ <if_index> <pae_type> [ <port_control> ] [ <host_mode> ] [
<quiet_period> ] [ <inactivity_period> ] [ <tx_period> ] [ <max_req> ] [ <reauth> ] [ <rate_limit_period> ] [
<supp_timeout> ] [ <server_timeout> ] [ <reauth_server> ] [ <reauth_period> ] [ <reauth_max> ] [
<mac_auth_bypass> ] [ <start_period> ] [ <auth_period> ] [ <held_period> ] [ <max_start> ] ] } | { show
dot1x interface <if> details [ __readonly__ <if_index_detail> <pae_type_detail> [ <port_control_detail> ] [
<host_mode_detail> ] [ <quiet_period_detail> ] [ <inactivity_period_detail> ] [ <tx_period_detail> ] [
<max_req_detail> ] [ <reauth_detail> ] [ <rate_limit_period_detail> ] [ <supp_timeout_detail> ] [
<server_timeout_detail> ] [ <reauth_server_detail> ] [ <reauth_period_detail> ] [ <reauth_max_detail> ] [
<mac_auth_bypass_detail> ] [ <no_of_clients> ] [ <port_status_no_clients_detail> ] [ {
TABLE_if_auth_clients_detail [ <supp_mac_addr_detail> ] [ <auth_domain> ] [ <auth_sm_state> ] [
<auth_bend_sm_state> ] [ <port_status> ] [ <authentication_method> ] [ <authenticated_by> ] [
<reauth_period_client> ] [ <reauth_action> ] [ <time_to_next_reauth> ] [ <auth_vlan> ] } ] [
<start_period_detail> ] [ <auth_period_detail> ] [ <held_period_detail> ] [ <max_start_detail> ] [
<no_of_supp_clients> ] [ <auth_mac_addr_detail> ] [ <supp_sm_state> ] [ <supp_bend_sm_state> ] [
<supp_port_status> ] ] } | { show dot1x interface <if> statistics [ __readonly__ <if_index_stat> <pae_type_stat>
[ <rxstart> ] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [ <rxlenerr> ] [ <rxtotal> ] [ <txreq> ]
[ <txreqid> ] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemac> ] [ <rxreq> ] [ <rxsuppinvalid> ] [ <rxsupplennerr>
] [ <rxsupptotal> ] [ <txstart> ] [ <txlogoff> ] [ <txresp> ] [ <txsupptotal> ] [ <rxsuppversion> ] [ <lastrxsrcmac>
] ] } | { show dot1x interface <if> summary [ __readonly__ <if_index_summary> <pae_type_summary> [
<port_status_no_clients_summary> ] [ { TABLE_if_auth_clients_summary [ <auth_mac_addr> ] [
<port_status_summary> ] } ] [ <supp_mac_addr> ] [ <supp_port_status_summary> ] ] }
```

Syntax Description

dot1x	dot1x configuration commands
<i>if</i>	
details	802.1x details
statistics	802.1x statistics
summary	802.1x summary
TABLE_if_auth_clients_detail	(Optional)
TABLE_if_auth_clients_summary	(Optional)
__readonly__	(Optional)
<i>if_index</i>	(Optional) Interface Index
<i>if_index_detail</i>	(Optional) Interface Index
<i>if_index_stat</i>	(Optional) Interface Index
<i>if_index_summary</i>	(Optional) Interface Index
<i>pae_type</i>	(Optional) Show PAE Type
<i>port_control</i>	(Optional) Show Port Control

<i>host_mode</i>	(Optional) Show Host Mode
<i>reauth</i>	(Optional) Show Reauth Enabled Status
<i>quiet_period</i>	(Optional) Show Quiet Period
<i>inactivity_period</i>	(Optional) Show Inactivity Period
<i>server_timeout</i>	(Optional) Show Server Timeout
<i>supp_timeout</i>	(Optional) Show Supp Timeout
<i>reauth_period</i>	(Optional) Show Reauth Period
<i>reauth_max</i>	(Optional) Show Reauth Max
<i>max_req</i>	(Optional) Show Max Req
<i>tx_period</i>	(Optional) Show Tx Period
<i>rate_limit_period</i>	(Optional) Show Rate Limit Period
<i>start_period</i>	(Optional) Show Supplicant Start Period
<i>auth_period</i>	(Optional) Show Supplicant Auth Period
<i>held_period</i>	(Optional) Show Supplicant Held Period
<i>max_start</i>	(Optional) Show Supplicant Max Start
<i>reauth_server</i>	(Optional) Show Reauth Server Enabled Status
<i>mac_auth_bypass</i>	(Optional) Show MAC Auth Bypass Enabled Status
<i>pae_type_detail</i>	(Optional) Show PAE Type
<i>port_control_detail</i>	(Optional) Show Port Control
<i>host_mode_detail</i>	(Optional) Show Host Mode
<i>reauth_detail</i>	(Optional) Show Reauth Enabled Status
<i>quiet_period_detail</i>	(Optional) Show Quiet Period
<i>inactivity_period_detail</i>	(Optional) Show Inactivity Period
<i>server_timeout_detail</i>	(Optional) Show Server Timeout
<i>supp_timeout_detail</i>	(Optional) Show Supp Timeout
<i>reauth_period_detail</i>	(Optional) Show Reauth Period
<i>reauth_max_detail</i>	(Optional) Show Reauth Max
<i>max_req_detail</i>	(Optional) Show Max Req
<i>tx_period_detail</i>	(Optional) Show Tx Period

<i>rate_limit_period_detail</i>	(Optional) Show Rate Limit Period
<i>reauth_server_detail</i>	(Optional) Show Reauth Server Enabled Status
<i>mac_auth_bypass_detail</i>	(Optional) Show MAC Auth Bypass Enabled Status
<i>no_of_clients</i>	(Optional) Show Supplicant Clients
<i>port_status_no_clients_detail</i>	(Optional) Show Port Status if there are no clients
<i>supp_mac_addr_detail</i>	(Optional) Show Supplicant MAC Address
<i>auth_domain</i>	(Optional) Show Supplicant Auth Domain
<i>auth_sm_state</i>	(Optional) Show Authenticator SM State
<i>auth_bend_sm_state</i>	(Optional) Show Authenticator Backend State
<i>port_status</i>	(Optional) Show Port Status
<i>authentication_method</i>	(Optional) show authentication method
<i>authenticated_by</i>	(Optional) show authenticated by
<i>reauth_period_client</i>	(Optional) Show Reauth Period
<i>reauth_action</i>	(Optional) Show Reauthentication Action
<i>time_to_next_reauth</i>	(Optional) Show Time to Next Reauth
<i>auth_vlan</i>	(Optional) Show vlan
<i>start_period_detail</i>	(Optional) Show Supplicant Start Period
<i>auth_period_detail</i>	(Optional) Show Supplicant Auth Period
<i>held_period_detail</i>	(Optional) Show Supplicant Held Period
<i>max_start_detail</i>	(Optional) Show Supplicant Max Start
<i>no_of_supp_clients</i>	(Optional) Show Supplicant Clients
<i>auth_mac_addr_detail</i>	(Optional) Show Authenticator MAC Address
<i>supp_sm_state</i>	(Optional) Show Supplicant SM State
<i>supp_bend_sm_state</i>	(Optional) Show Supplicant Backend SM State
<i>supp_port_status</i>	(Optional) Show Supplicant Port Status
<i>pae_type_stat</i>	(Optional) Show PAE Type
<i>rxstart</i>	(Optional) Show Received EAPOL-Start
<i>rxlogoff</i>	(Optional) Show Received EAPOL-Logoff
<i>rxresp</i>	(Optional) Show Received EAP-Response

<i>rxrespid</i>	(Optional) Show Received EAP-ResponseID
<i>rxinvalid</i>	(Optional) Show Received Invalid EAPOL Frame
<i>rxlenerr</i>	(Optional) Show Received EAPOL Bad Length Frame
<i>rxtotal</i>	(Optional) Show Received Total EAPOL Frame
<i>txreq</i>	(Optional) Show Transmitted EAP-Request
<i>txreqid</i>	(Optional) Show Transmitted EAP-RequestID
<i>txtotal</i>	(Optional) Show Transmitted Total EAPOL Frame
<i>rxversion</i>	(Optional) Show Received EAPOL Version
<i>lastrxsourcema</i>	(Optional) Show Last Source MAC
<i>rxreq</i>	(Optional) Show Received EAP-Request
<i>rxsuppinvalid</i>	(Optional) Show received Invalid EAPOL Frame
<i>rxsupplenerr</i>	(Optional) Show received EAPOL Bad Length Frame
<i>rxsupptotal</i>	(Optional) Show Received Total EAPOL Frame
<i>txstart</i>	(Optional) Show transmitted EAPOL-Start
<i>txlogoff</i>	(Optional) Show transmitted EAPOL-Logoff
<i>txresp</i>	(Optional) Show transmitted EAP-Response
<i>txsupptotal</i>	(Optional) Show transmitted Total EAPOL Frame
<i>rxsuppversion</i>	(Optional) Show Received EAPOL Version
<i>lastrxsrca</i>	(Optional) Show Last Source MAC received
<i>pae_type_summary</i>	(Optional) Show PAE Type
<i>port_status_no_clients_summary</i>	(Optional) Show Port Status if there are no clients
<i>port_status_summary</i>	(Optional) Show Port Status
<i>supp_port_status_summary</i>	(Optional) Show Port Status
<i>supp_mac_addr</i>	(Optional) Show Supplicant Client MAC Address
<i>auth_mac_addr</i>	(Optional) Show Auth Client MAC Address

Command Mode

- /exec

show dot1x interface client statistics

```
show dot1x interface <if> client statistics [ __readonly__ <if_index_stat> <pae_type_stat> [ {
TABLE_mac_address [ <macaddr> ] [ <rxstart> ] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [
<rxlenerr> ] [ <rxtotal> ] [ <txreq> ] [ <txreqid> ] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemac> } ] [
<spurious_rxstart> ] [ <spurious_rxlogoff> ] [ <spurious_rxresp> ] [ <spurious_rxrespid> ] [
<spurious_rxinvalid> ] [ <spurious_rxlenerr> ] [ <spurious_rxtotal> ] [ <spurious_txreq> ] [ <spurious_txreqid>
] [ <spurious_txtotal> ] [ <spurious_rxversion> ] [ <spurious_lastrxsourcemac> ] ]
```

Syntax Description

dot1x	dot1x configuration commands
<i>if</i>	
client	802.1x client
statistics	802.1x statistics
__readonly__	(Optional)
TABLE_mac_address	(Optional)
<i>if_index_stat</i>	(Optional) Interface Index
<i>pae_type_stat</i>	(Optional) Show PAE Type
<i>macaddr</i>	(Optional) mac-address of the client
<i>rxstart</i>	(Optional) Show Received EAPOL-Start
<i>rxlogoff</i>	(Optional) Show Received EAPOL-Logoff
<i>rxresp</i>	(Optional) Show Received EAP-Response
<i>rxrespid</i>	(Optional) Show Received EAP-ResponseID
<i>rxinvalid</i>	(Optional) Show Received Invalid EAPOL Frame
<i>rxlenerr</i>	(Optional) Show Received EAPOL Bad Length Frame
<i>rxtotal</i>	(Optional) Show Received Total EAPOL Frame
<i>txreq</i>	(Optional) Show Transmitted EAP-Request
<i>txreqid</i>	(Optional) Show Transmitted EAP-RequestID
<i>txtotal</i>	(Optional) Show Transmitted Total EAPOL Frame
<i>rxversion</i>	(Optional) Show Received EAPOL Version
<i>lastrxsourcemac</i>	(Optional) Show Last Source MAC
<i>spurious_rxstart</i>	(Optional) Show Received EAPOL-Start of spurious macs

<i>spurious_rxlogoff</i>	(Optional) Show Received EAPOL-Logoff of spurious macs
<i>spurious_rxresp</i>	(Optional) Show Received EAP-Response of spurious macs
<i>spurious_rxrespid</i>	(Optional) Show Received EAP-ResponseID of spurious macs
<i>spurious_rxinvalid</i>	(Optional) Show Received Invalid EAPOL Frame of spurious macs
<i>spurious_rxlennerr</i>	(Optional) Show Received EAPOL Bad Length Frame of spurious macs
<i>spurious_rxtotal</i>	(Optional) Show Received Total EAPOL Frame of spurious macs
<i>spurious_txreq</i>	(Optional) Show Transmitted EAP-Request of spurious macs
<i>spurious_txreqid</i>	(Optional) Show Transmitted EAP-RequestID of spurious macs
<i>spurious_txtotal</i>	(Optional) Show Transmitted Total EAPOL Frame of spurious macs
<i>spurious_rxversion</i>	(Optional) Show Received EAPOL Version of spurious macs
<i>spurious_lastrxsourcemac</i>	(Optional) Show Last Source MAC of spurious macs

Command Mode

- /exec

show dot1x interface client statistics address

```
show dot1x interface <if> client statistics address <mac-address> [ __readonly__ <if_index_stat>
<pae_type_stat> [ <rxstart> ] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [ <rxlenerr> ] [ <rxtotal>
] [ <txreq> ] [ <txreqid> ] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemac> ] ]
```

Syntax Description

dot1x	dot1x configuration commands
<i>if</i>	
client	802.1x client
statistics	802.1x statistics
address	802.1x client address
<i>mac-address</i>	mac address EE:EE:EE:EE:EE:EE
<i>__readonly__</i>	(Optional)
<i>if_index_stat</i>	(Optional) Interface Index
<i>pae_type_stat</i>	(Optional) Show PAE Type
<i>rxstart</i>	(Optional) Show Received EAPOL-Start
<i>rxlogoff</i>	(Optional) Show Received EAPOL-Logoff
<i>rxresp</i>	(Optional) Show Received EAP-Response
<i>rxrespid</i>	(Optional) Show Received EAP-ResponseID
<i>rxinvalid</i>	(Optional) Show Received Invalid EAPOL Frame
<i>rxlenerr</i>	(Optional) Show Received EAPOL Bad Length Frame
<i>rxtotal</i>	(Optional) Show Received Total EAPOL Frame
<i>txreq</i>	(Optional) Show Transmitted EAP-Request
<i>txreqid</i>	(Optional) Show Transmitted EAP-RequestID
<i>txtotal</i>	(Optional) Show Transmitted Total EAPOL Frame
<i>rxversion</i>	(Optional) Show Received EAPOL Version
<i>lastrxsourcemac</i>	(Optional) Show Last Source MAC

Command Mode

- /exec

show dummy

show dummy

Syntax Description

show	Show running system information
dummy	Show dummy debug information

Command Mode

- /exec



E Show Commands

- [show ecp, on page 350](#)
- [show elam report, on page 352](#)
- [show email, on page 353](#)
- [show encryption service stat, on page 354](#)
- [show environment, on page 355](#)
- [show errdisable detect, on page 361](#)
- [show errdisable flap, on page 362](#)
- [show evb, on page 363](#)
- [show evb hosts, on page 364](#)
- [show evb vsi, on page 366](#)
- [show event manager environment, on page 368](#)
- [show event manager event-types, on page 369](#)
- [show event manager events action-log, on page 370](#)
- [show event manager history events, on page 371](#)
- [show event manager policy-state, on page 372](#)
- [show event manager script system, on page 373](#)
- [show event manager system-policy, on page 374](#)

show ecp

```
show ecp [ detail ] [ __readonly__ <ecp_rte> <ecp_retries> [ <ecp_mode> ] <ecp_cnt_rx_pkt>
<ecp_cnt_tx_pkt> [ { TABLE_ecp_plugin <plugin_id> <plugin_desc> <plugin_status> } ] [ {
TABLE_ecp_session <session_id> <session_interface> <session_svlan> [ <session_peer_mac> ]
<session_rx_seq> <session_tx_seq> [ <session_cnt_rx_pkt> ] [ <session_cnt_rx_dup> ] [
<session_cnt_rx_drop> ] [ <session_cnt_tx_pkt> ] [ <session_cnt_tx_retry> ] [ <session_cnt_tx_err> ] } ] ]
```

Syntax Description

show	Show running system information
ecp	ECP (Edge Control Protocol)
detail	(Optional) Detailed information
__readonly__	(Optional)
<i>ecp_rte</i>	(Optional) Retransmission timer init exponent
<i>ecp_retries</i>	(Optional) Maximal number of retransmissions
<i>ecp_mode</i>	(Optional) ECP mode
<i>ecp_cnt_rx_pkt</i>	(Optional) No. received packet
<i>ecp_cnt_tx_pkt</i>	(Optional) No. transmitted packet
TABLE_ecp_plugin	(Optional) ECP plugin table
<i>plugin_id</i>	(Optional) Plugin id
<i>plugin_desc</i>	(Optional) Plugin description
<i>plugin_status</i>	(Optional) Plugin status
TABLE_ecp_session	(Optional) ECP session table
<i>session_id</i>	(Optional) Session id
<i>session_svlan</i>	(Optional) S-Vlan
<i>session_peer_mac</i>	(Optional) Peer mac
<i>session_interface</i>	(Optional) Interface
<i>session_rx_seq</i>	(Optional) Receive sequence
<i>session_tx_seq</i>	(Optional) Transmit sequence
<i>session_cnt_rx_pkt</i>	(Optional) No. receive packet
<i>session_cnt_rx_dup</i>	(Optional) No. receive duplicate
<i>session_cnt_rx_drop</i>	(Optional) No. receive drop

<i>session_cnt_tx_pkt</i>	(Optional) No. transmit packet
<i>session_cnt_tx_retry</i>	(Optional) No. transmit retry
<i>session_cnt_tx_err</i>	(Optional) No. transmit error

Command Mode

- /exec

show elam report

show elam report [l2 | l3 | l4 | aclqos | mcast] [detail | summary]

Syntax Description

show	Show running system information
elam	elam
report	Show ELAM report
l2	(Optional) Layer 2 header report
l3	(Optional) Layer 3 header report
l4	(Optional) Layer 4 header report
aclqos	(Optional) Aclqos report
mcast	(Optional) Multicast report
detail	(Optional) Detailed report
summary	(Optional) Summary of the report

Command Mode

- /exec

show email

```
show email [ __readonly__ [ <ipv4> ] [ <ipv6> ] [ <host> ] [ <port> ] [ <reply> ] [ <from> ] [ <vrfname> ] ]
```

Syntax Description

<code>show</code>	Show running system information
<code>email</code>	Pipe email configuration
<code>__readonly__</code>	(Optional)
<code>ipv4</code>	(Optional)
<code>host</code>	(Optional)
<code>port</code>	(Optional)
<code>reply</code>	(Optional)
<code>from</code>	(Optional)
<code>vrfname</code>	(Optional)

Command Mode

- /exec

show encryption service stat

```
show encryption service stat [ __readonly__ [ <encryptionService> <MasterKeyEncryption>
<Type6Encryption> ] ]
```

Syntax Description

show	Show running system information
encryption	Encryption service
service	Encryption service
stat	Encryptpin service status
<i>__readonly__</i>	(Optional)
<i>encryptionService</i>	(Optional) Encryption service status
<i>MasterKeyEncryption</i>	(Optional) Master key status
<i>Type6Encryption</i>	(Optional) Is type 6 encryption used?

Command Mode

- /exec

show environment

```
show environment [ fan [ detail1 ] | power [ detail ] [ ampere ] [ input ] | temperature [ module <module> | <s0> <santa-cruz-range> | psu ] [ _readonly_ [ { TABLE_clockinfo <clockname> <clkmmodel> <clkhwver> <clkstatus> <act_standby> } ] [ { fandetails [ { TABLE_faninfo <fanname> <fanmodel> <fanhwver> <fandir> <fanstatus> } ] [ { TABLE_fan_zone_speed <zone> <zonespeed> } <fan_filter_status> [ { TABLE_fantray <fanname> <trayfannum> <fandir> <fanperc> <fanrpm> } ] [ { TABLE_psufan <fanname> <fan1rpm> <fan2rpm> } ] ] ] [ { powersup <voltage_level> { TABLE_psinfo <psnum> <psmodel> [ <actual_out> ] [ <actual_input> ] [ <tot_capa> ] [ <input_type> ] [ <watts> ] [ <amps> ] [ <ps_status> ] [ <ps_status_3k> } ] [ { TABLE_mod_pow_info <modnum> <mod_model> [ <actual_draw> ] [ <allocated> ] [ <watts_requested> ] [ <amps_requested> ] [ <watts_allcoked> ] [ <amps_allcoked> ] [ <modstatus> ] [ <modstatus_3k> } ] ] [ { power_summary [ <ps_redun_mode> ] [ <ps_redun_mode_3k> ] [ <ps_oper_mode> ] [ <ps_redun_op_mode> ] [ <tot_pow_capacity> ] [ <tot_gridA_capacity> ] [ <tot_gridB_capacity> ] [ <cumulative_power> ] [ <tot_pow_out_actual_draw> ] [ <tot_pow_input_actual_draw> ] [ <tot_pow_alloc_budgeted> ] [ <reserve_sup> ] [ <pow_used_by_mods> ] [ <available_pow> } ] ] [ { powersup_detail <reserve_sup> <reserve_xbar> <reserve_fan> <reserve_supxbarfan> <pow_used_by_mods> } ] [ <all_inlets_connected> [ { TABLE_ps_detail_info <det_name> <det_total_cap> <det_volt> <det_pintot> [ <det_pina> ] [ <det_vin> <det_iin> <det_pout> <det_vout> <det_iout> [ <det_pinb> ] [ <det_iinb> ] [ <det_vinb> ] [ <det_cord> ] [ <det_sw_alarm> ] [ { TABLE_det_hw_alarm_regval <regnum> <regval> } ] [ { TABLE_det_hw_alarm_str <regnumstr> <bitnumstr> <alarm_str> } ] ] ] [ { TABLE_psinputinfo_n3k <ps_slot> <ps_input_voltage> <ps_input_current> <ps_in_power> <ps_output_voltage> <ps_output_current> <ps_state> } ] ] ] [ { fandetails_3k [ { TABLE_faninfo <fanname> <fanmodel> <fanhwver> <fandir> <fanstatus> } ] [ { TABLE_fan_zone_speed <zone> <speed> } <fan_filter_status> [ { TABLE_fantray <fanname> <fannum> <fandir> <fanperc> <fanrpm> } ] ] [ { TABLE_psufan <fanname> <fan1rpm> <fan2rpm> } ] ] ] [ { TABLE_tempinfo <tempmod> <sensor> <majthres> <minthres> <curtemp> <alarmstatus> [ <temptype> ] ] ] [ { TABLE_psutempinfo <psumod> <inlet_temp> <outlet_temp> <heatsink_temp> } ] ] ]
```

Syntax Description

show	Show running system information
environment	system environment information
fan	(Optional) Fan information
power	(Optional) Power capacity and power distribution information
detail	(Optional) Detail Fan-tray information when used with Fan. Detail Power capacity and power distribution information when used with Power
detail1	(Optional) Detail Fan-tray information when used with Fan
ampere	(Optional) Ampere Power capacity and power distribution information
input	(Optional) Power supply power input
temperature	(Optional) temperature sensor information
module	(Optional) enter a module number
<i>module</i>	(Optional) please enter the module number
<i>s0</i>	(Optional) xbar

<i>santa-cruz-range</i>	(Optional) please enter the xbar number
psu	(Optional) psu temperature
__readonly__	(Optional)
TABLE_clockinfo	(Optional) Environment Clock
<i>clockname</i>	(Optional) Clock Instance (A or B)
<i>clkmodel</i>	(Optional) Model number of clock
<i>clkhwver</i>	(Optional) Hardware version of the clock
<i>clkstatus</i>	(Optional) Present/Absent Status of the clock
<i>act_standby</i>	(Optional) Active/Standby Status of clock
fanetails	(Optional) Environment Fan
TABLE_faninfo	(Optional) Fan Info
<i>fanname</i>	(Optional) Fan Instance
<i>fanmodel</i>	(Optional) Model number of fan
<i>fanhwver</i>	(Optional) Hardware version of the fan
<i>fandir</i>	(Optional) Air-flow direction of the fan-tray
<i>fanstatus</i>	(Optional) Present/Absent Status of the fan
TABLE_fan_zone_speed	(Optional) Fan Zone Speeds
<i>zone</i>	(Optional) Zone Number
<i>zonespeed</i>	(Optional) Zone Speed
<i>fan_filter_status</i>	(Optional) Present/Absent Status of fan filter
TABLE_fantray	(Optional) Fan Tray Details table
<i>fanname</i>	(Optional) Fan Tray Instance
<i>trayfannum</i>	(Optional) Fan number in the tray
<i>fandir</i>	(Optional) Air-flow direction of the fan-tray
<i>fanperc</i>	(Optional) FAN Speed percentage
<i>fanrpm</i>	(Optional) FAN Speed RPM
TABLE_psufan	(Optional) PSU Fan Details table
<i>fanname</i>	(Optional) PSU Fan Instance
<i>fan1rpm</i>	(Optional) FAN1 Speed RPM

<i>fan2rpm</i>	(Optional) FAN2 Speed RPM
<i>fandetails_3k</i>	(Optional) Environment Fan
TABLE_faninfo	(Optional) Fan Info
<i>fanname</i>	(Optional) Fan Instance
<i>fanmodel</i>	(Optional) Model number of fan
<i>fanhwver</i>	(Optional) Hardware version of the fan
<i>fandir</i>	(Optional) Air-flow direction of the fan-tray
<i>fanstatus</i>	(Optional) Present/Absent Status of the fan
TABLE_fan_zone_speed	(Optional) Fan Zone Speeds
<i>zone</i>	(Optional) Zone Number
<i>speed</i>	(Optional) Zone Speed
<i>fan_filter_status</i>	(Optional) Present/Absent Status of fan filter
TABLE_fantray	(Optional) Fan Tray Details table
<i>fanname</i>	(Optional) Fan Tray Instance
<i>fannum</i>	(Optional) Fan number in the tray
<i>fandir</i>	(Optional) Air-flow direction of the fan-tray
<i>fanperc</i>	(Optional) FAN Speed percentage
<i>fanrpm</i>	(Optional) FAN Speed RPM
TABLE_psufan	(Optional) PSU Fan Details table
<i>fanname</i>	(Optional) PSU Fan Instance
<i>fan1rpm</i>	(Optional) FAN1 Speed RPM
<i>fan2rpm</i>	(Optional) FAN2 Speed RPM
<i>powersup</i>	(Optional) Environment Power
<i>voltage_level</i>	(Optional) Voltage Level
TABLE_psinfo	(Optional) Power Supply Info
<i>psnum</i>	(Optional) Power Supply Number
<i>psmodel</i>	(Optional) Power Supply Model
<i>actual_out</i>	(Optional) Actual Output
<i>actual_input</i>	(Optional) Actual Input

<i>tot_capa</i>	(Optional) Total Capacity
<i>input_type</i>	(Optional) Power Supply Input Type
<i>watts</i>	(Optional) Power in Watts
<i>amps</i>	(Optional) Power in Amps
<i>ps_status</i>	(Optional) Power Supply Status
<i>ps_status_3k</i>	(Optional) Power Supply Status
TABLE_mod_pow_info	(Optional) Module Power Info
<i>modnum</i>	(Optional) Module number
<i>mod_model</i>	(Optional) Model ProductID number
<i>actual_draw</i>	(Optional) Actual Draw
<i>allocated</i>	(Optional) Power allocated
<i>watts_requested</i>	(Optional) Power requested in Watts
<i>amps_requested</i>	(Optional) Power requested in Amps
<i>watts_alloced</i>	(Optional) Power allocated in Watts
<i>amps_alloced</i>	(Optional) Power allocated in Amps
<i>modstatus</i>	(Optional) Module Status
<i>modstatus_3k</i>	(Optional) Module status
<i>power_summary</i>	(Optional) Power Usage Summary
<i>ps_redun_mode</i>	(Optional) Mode: Redundant or Non-redundant
<i>ps_redun_mode_3k</i>	(Optional) Mode: Redundant or Non-redundant
<i>ps_redun_op_mode</i>	(Optional) Operational mode: Redundant or Non-redundant
<i>ps_oper_mode</i>	(Optional) Operational Mode
<i>tot_pow_capacity</i>	(Optional) Total Power Capacity
<i>tot_gridA_capacity</i>	(Optional) Total Grid-A Capacity
<i>tot_gridB_capacity</i>	(Optional) Total Grid-B Capacity
<i>cumulative_power</i>	(Optional) Total Power of all Inputs
<i>tot_pow_out_actual_draw</i>	(Optional) Total Power Output, Actuals
<i>tot_pow_input_actual_draw</i>	(Optional) Total Power Input, Actuals
<i>tot_pow_alloc_budgeted</i>	(Optional) Total Power Allocated/budgeted

<i>reserve_sup</i>	(Optional) Power reserved for Supervisors
<i>pow_used_by_mods</i>	(Optional) Power currently used by Modules
<i>available_pow</i>	(Optional) Remaining Power Available
<i>powersup_detail</i>	(Optional) PowerSupply Details
<i>reserve_sup</i>	(Optional) Power reserved for Supervisors
<i>reserve_xbar</i>	(Optional) Power reserved for Xbars
<i>reserve_fan</i>	(Optional) Power reserved for Fans
<i>reserve_supxbarfan</i>	(Optional) Total Power reserved for Sups,Xbars,Fans
<i>pow_used_by_mods</i>	(Optional) Power currently used by Modules
<i>all_inlets_connected</i>	(Optional) Are all inlet cords connected
TABLE_ps_detail_info	(Optional) Power supply detail information
<i>det_name</i>	(Optional) Power supply name
<i>det_total_cap</i>	(Optional) Power supply total capacity
<i>det_volt</i>	(Optional) Power supply voltage
<i>det_pintot</i>	(Optional) Power supply pin A total power
<i>det_pina</i>	(Optional) PS pin A
<i>det_vin</i>	(Optional) PS Vin
<i>det_iin</i>	(Optional) PS Iin
<i>det_pout</i>	(Optional) PS Power out
<i>det_vout</i>	(Optional) PS voltaget out
<i>det_iout</i>	(Optional) PS current in
<i>det_pinb</i>	(Optional) PS pin B
<i>det_iinb</i>	(Optional) PS Iin B
<i>det_vinb</i>	(Optional) PS Vin B
<i>det_cord</i>	(Optional) PS cord
<i>det_sw_alarm</i>	(Optional) PS software alarm
TABLE_det_hw_alarm_regval	(Optional) PS hardware alarm
<i>regnum</i>	(Optional) HW alarm register
<i>regval</i>	(Optional) Alarm reg value

TABLE_det_hw_alarm_str	(Optional) PS Hardware alarm string
<i>regnumstr</i>	(Optional) Alarm reg number
<i>bitnumstr</i>	(Optional) Alarm register bit
<i>alarm_str</i>	(Optional) Alarm cause
TABLE_psinputinfo_n3k	(Optional) Power Supply power input
<i>ps_slot</i>	(Optional) Power Supply Number
<i>ps_input_voltage</i>	(Optional) Power Supply input volatage
<i>ps_input_current</i>	(Optional) Power Supply input current
<i>ps_in_power</i>	(Optional) Power Supply input power
<i>ps_output_voltage</i>	(Optional) Power Supply output volatage
<i>ps_output_current</i>	(Optional) Power Supply output current
<i>ps_state</i>	(Optional) Power Supply status
TABLE_tempinfo	(Optional) Environment Temperature
<i>tempmod</i>	(Optional) Module
<i>sensor</i>	(Optional) Sensor name
<i>majthres</i>	(Optional) Major Threshold
<i>minthres</i>	(Optional) Minor Threshold
<i>curtemp</i>	(Optional) Current temperature
<i>alarmstatus</i>	(Optional) Alarm Status
<i>temptype</i>	(Optional) Control or Monitor temperature
TABLE_psutempinfo	(Optional) PSU temperature info table
<i>psumod</i>	(Optional) PSU Module
<i>inlet_temp</i>	(Optional) Inlet Temperature
<i>outlet_temp</i>	(Optional) Outlet Temperature
<i>heatsink_temp</i>	(Optional) Heatsink Temperature

Command Mode

- /exec

show errdisable detect

```
show errdisable { detect | recovery } [ __readonly__ TABLE_errdisable <cause> <state> [ <time_interval> ] ]
```

Syntax Description

show	Show running system information
errdisable	Error disable
detect	Show errdisable detect
recovery	Show errdisable recovery
__readonly__	(Optional) Read Only
TABLE_errdisable	(Optional) show errdisable
<i>cause</i>	(Optional) errdisable cause
<i>state</i>	(Optional) Interface state
<i>time_interval</i>	(Optional) err recovery time interval

Command Mode

- /exec

show errdisable flap

show errdisable flap

Syntax Description

show	Show running system information
errdisable	Error disable
flap	linkstate flapping

Command Mode

- /exec

show evb

```
show evb [ __readonly__ <evb_role> <evb_vdp_mac> [ <evb_cisco_mac> ] [ <evb_user_mac> ] <evb_rwd>
<evb_rka> <evb_cnt_recv_vdpdu> <evb_cnt_drop_vdpdu> <evb_cnt_recv_tlv> <evb_cnt_recv_mgr_tlv>
<evb_cnt_recv_assoc_tlv> <evb_cnt_recv_cmd> ]
```

Syntax Description

show	Show running system information
evb	EVB (Edge Virtual Bridge)
<i>__readonly__</i>	(Optional)
<i>evb_role</i>	(Optional) EVB role
<i>evb_vdp_mac</i>	(Optional) VDP Mac address
<i>evb_cisco_mac</i>	(Optional) Cisco Mac address
<i>evb_user_mac</i>	(Optional) User mac address
<i>evb_rwd</i>	(Optional) Resource wait init exponent
<i>evb_rka</i>	(Optional) Keep-alive init exponent
<i>evb_cnt_recv_vdpdu</i>	(Optional) No. received vdpdu
<i>evb_cnt_drop_vdpdu</i>	(Optional) No. dropped vdpdu
<i>evb_cnt_recv_tlv</i>	(Optional) No. received tlv
<i>evb_cnt_recv_mgr_tlv</i>	(Optional) No. received mgr tlv
<i>evb_cnt_recv_assoc_tlv</i>	(Optional) No. received assoc tlv
<i>evb_cnt_recv_cmd</i>	(Optional) No. received commands

Command Mode

- /exec

show evb hosts

```
show evb hosts [ { summary | detail | internal-info } ] [ { [ mac <mac-addr> | interface <intf-name> | vlan
<vlan-id> | vni <vni-id> | ip <ip-addr> | ipv6 <ipv6-addr> | name <host-name> ] + } ] [ __readonly__
<evb_cnt_host> <evb_cnt_assoc_vsi> [ { TABLE_evb_host <host_row_id> <host_name> [ <host_uuid> ] [
{ TABLE_evb_vsi <vsi_row_id> <mgr_id> <vsi_id> [ <vsi_host_name> ] <interface> [ <vpc> ] [ <s_channel>
] [ <station_mac> ] [ <m_state> ] [ <e_state> ] [ <reason> ] [ <timer> ] [ <profile_id> ] [ {
TABLE_evb_vsi_filter <filter_row_id> [ <filter_group> ] [ <filter_vid> ] [ <filter_bd> ] [ <filter_mac> ] [
<filter_ip> ] } ] } ] } ] ] ]
```

Syntax Description

show	Show running system information
evb	EVB (Edge Virtual Bridge)
hosts	Host information
summary	(Optional) Display summary information
detail	(Optional) Display detailed information
internal-info	(Optional) Display detailed and internal information
mac	(Optional) Display hosts by MAC address
<i>mac-addr</i>	(Optional) MAC Address
interface	(Optional) Display hosts by interface
<i>intf-name</i>	(Optional) Interface name
vlan	(Optional) Display hosts by VLAN
<i>vlan-id</i>	(Optional) VLAN ID
vni	(Optional) Display hosts by Virtual Network Identifier
<i>vni-id</i>	(Optional) VNI
ip	(Optional) Display hosts by IP address
ipv6	(Optional) Display hosts by IPv6 address
<i>ip-addr</i>	(Optional) IP address
name	(Optional) Display hosts by host name
<i>host-name</i>	(Optional) Host name substring
<i>__readonly__</i>	(Optional)
<i>evb_cnt_host</i>	(Optional) No. host entries
<i>evb_cnt_assoc_vsi</i>	(Optional) No. associated VSI entire

TABLE_evb_host	(Optional) EVB host table
<i>host_row_id</i>	(Optional) Host row id
<i>host_name</i>	(Optional) Host name
<i>host_uuid</i>	(Optional) Host uuid
TABLE_evb_vsi	(Optional) EVB vsi table
<i>vsi_row_id</i>	(Optional) VSI row id
<i>mgr_id</i>	(Optional) Manager id
<i>vsi_id</i>	(Optional) VSI id
<i>vsi_host_name</i>	(Optional) Host name
<i>interface</i>	(Optional) Interface
<i>vpc</i>	(Optional) VPC
<i>s_channel</i>	(Optional) S-Channel
<i>station_mac</i>	(Optional) Station mac address
<i>profile_id</i>	(Optional) Profile id
<i>m_state</i>	(Optional) Machine state
<i>e_state</i>	(Optional) Entry state
<i>reason</i>	(Optional) State reason
<i>timer</i>	(Optional) Countdown timer
TABLE_evb_vsi_filter	(Optional) EVB filter table
<i>filter_row_id</i>	(Optional) Filter row id
<i>filter_group</i>	(Optional) Group id
<i>filter_vid</i>	(Optional) Vlan id
<i>filter_bd</i>	(Optional) Bridge-domain id
<i>filter_mac</i>	(Optional) Mac address
<i>filter_ip</i>	(Optional) IP address

Command Mode

- /exec

show evb vsi

```
show evb vsi [ { summary | detail | internal-info } ] [ { [ mac <mac-addr> | interface <intf-name> | vlan
<vlan-id> | vni <vni-id> | ip <ip-addr> | ipv6 <ipv6-addr> ] + } ] [ __readonly__ <evb_cnt_vsi>
<evb_cnt_assoc_vsi> [ { TABLE_evb_vsi <vsi_row_id> <mgr_id> <vsi_id> [ <vsi_host_name> ] <interface>
[ <vpc> ] [ <s_channel> ] [ <station_mac> ] [ <m_state> ] [ <e_state> ] [ <reason> ] [ <timer> ] [ <profile_id>
] [ { TABLE_evb_vsi_filter <filter_row_id> [ <filter_group> ] [ <filter_vid> ] [ <filter_bd> ] [ <filter_mac>
] [ <filter_ip> ] } } ] ] ]
```

Syntax Description

show	Show running system information
evb	EVB (Edge Virtual Bridge)
vsi	Virtual Station Interface (VSI) information
summary	(Optional) Display summary information
detail	(Optional) Display detailed information
internal-info	(Optional) Display detailed and internal information
mac	(Optional) Display VSI by MAC address
<i>mac-addr</i>	(Optional) MAC Address
interface	(Optional) Display VSI by interface
<i>intf-name</i>	(Optional) Interface name
vlan	(Optional) Display VSI by VLAN
<i>vlan-id</i>	(Optional) VLAN ID
vni	(Optional) Display VSI by Virtual Network Identifier
<i>vni-id</i>	(Optional) VNI
ip	(Optional) Display VSI by IP address
ipv6	(Optional) Display VSI by IPv6 address
<i>ip-addr</i>	(Optional) IP address
<i>__readonly__</i>	(Optional)
<i>evb_cnt_vsi</i>	(Optional) No. VSI entries
<i>evb_cnt_assoc_vsi</i>	(Optional) No. associated VSI entries
TABLE_evb_vsi	(Optional) EVB vsi table
<i>vsi_row_id</i>	(Optional) VSI row id

<i>mgr_id</i>	(Optional) Manager id
<i>vsi_id</i>	(Optional) VSI id
<i>vsi_host_name</i>	(Optional) Host name
<i>interface</i>	(Optional) Interface
<i>vpc</i>	(Optional) VPC
<i>s_channel</i>	(Optional) S-Channel
<i>station_mac</i>	(Optional) Station mac address
<i>profile_id</i>	(Optional) Profile id
<i>m_state</i>	(Optional) Machine state
<i>e_state</i>	(Optional) Entry state
<i>reason</i>	(Optional) State reason
<i>timer</i>	(Optional) Countdown timer
TABLE_evb_vsi_filter	(Optional) EVB filter table
<i>filter_row_id</i>	(Optional) Filter row id
<i>filter_group</i>	(Optional) Group id
<i>filter_vid</i>	(Optional) Vlan id
<i>filter_bd</i>	(Optional) Bridge-domain id
<i>filter_mac</i>	(Optional) Mac address
<i>filter_ip</i>	(Optional) IP address

Command Mode

- /exec

show event manager environment

show event manager environment { all | <varname> } [__readonly__ <environment-details>]

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
environment	Show information about environment variables
all	Show information about all the configured environment variables
<i>varname</i>	The environment variable name on which information is required
__readonly__	(Optional)
<i>environment-details</i>	(Optional) Show information about environment variables

Command Mode

- /exec

show event manager event-types

```
show event manager event-types [ all | <event-type-name> ] [ module <module-id> ] [ __readonly__ {
<event-types> } ]
```

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
event-types	Show information about registered event types
all	(Optional) Show information about advanced event types as well
<i>event-type-name</i>	(Optional) Show information about the specified event type
module	(Optional) Show information about event types on other modules
<i>module-id</i>	(Optional) Module Id
__readonly__	(Optional)
<i>event-types</i>	(Optional) Show information about registered event types

Command Mode

- /exec

show event manager events action-log

```
show event manager events action-log [ policy <policy-name> | event-type <event-type-name> ] [ __readonly__
{ <action-log-data> } ]
```

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
events	Show information about the history of past events
action-log	Show policy action logs
policy	(Optional) Name of policy
<i>policy-name</i>	(Optional) Enter policy name
event-type	(Optional) Name of event
<i>event-type-name</i>	(Optional) Enter event type
__readonly__	(Optional)
<i>action-log-data</i>	(Optional) Show information about the policy action logs

Command Mode

- /exec

show event manager history events

```
show event manager history events [ detail ] [ maximum <n-events> ] [ severity <sev> ] [ __readonly__ {
<history-events> } ]
```

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
history	Show information about the history of past activity
events	Show information about the history of past events
detail	(Optional) Show information about the event parameters as well
maximum	(Optional) Specify an upper limit on the number of events to be shown
<i>n-events</i>	(Optional) Specify the maximum number of events to be shown
severity	(Optional) Show only those events whose severity is >= specified severity
<i>sev</i>	(Optional) Enter the severity threshold
__readonly__	(Optional)
<i>history-events</i>	(Optional) Show information about the history of past events

Command Mode

- /exec

show event manager policy-state

show event manager policy-state <name> [module <module-id>] [__readonly__ { <policy-state> }]

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
policy-state	Show information about the state of a policy
<i>name</i>	Name of the policy
module	(Optional) Get the information from a module
<i>module-id</i>	(Optional) Module Id
__readonly__	(Optional)
<i>policy-state</i>	(Optional) Show information about the state of a policy

Command Mode

- /exec

show event manager script system

```
show event manager script system { all | <script-name> } [ __readonly__ <script_system_details> ]
```

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
script	Show information about a script policy
system	Show information about a system script policy
all	Show all the available system script policies
<i>script-name</i>	Name of the system script policy
<i>__readonly__</i>	(Optional)
<i>script_system_details</i>	(Optional) Show Information about system script policies

Command Mode

- /exec

show event manager system-policy

```
show event manager system-policy [ all | <policy-name> ] [ __readonly__ { [ TABLE_eem [ <thresh_min> ] [ <thresh_max> ] <event_name> <event_description> <event_overridable> ] } ]
```

Syntax Description

show	Show running system information
event	Event Manager commands
manager	Event Manager commands
system-policy	Show information about default system policies
all	(Optional) Show all policies (including advanced and non-overridable ones)
<i>policy-name</i>	(Optional) Show detailed information about the specified policy
<i>__readonly__</i>	(Optional)
TABLE_eem	(Optional)
<i>thresh_min</i>	(Optional)
<i>thresh_max</i>	(Optional)
<i>event_name</i>	(Optional)
<i>event_description</i>	(Optional)
<i>event_overridable</i>	(Optional)

Command Mode

- /exec



F Show Commands

- [show fabric database dci](#), on page 378
- [show fabric database dci](#), on page 379
- [show fabric database host](#), on page 381
- [show fabric database host statistics](#), on page 385
- [show fabric database host summary](#), on page 388
- [show fabric database profile-map](#), on page 389
- [show fabric database static-host](#), on page 390
- [show fabric database statistics](#), on page 391
- [show fabric forwarding host-db](#), on page 393
- [show fabric forwarding ip local](#), on page 395
- [show fabric forwarding ipv6 local](#), on page 396
- [show fabric multicast](#), on page 397
- [show fabric multicast event-history](#), on page 399
- [show fabric multicast globals](#), on page 400
- [show fabric multicast ipv4 l2 vni](#), on page 401
- [show fabric multicast ipv4 rp](#), on page 402
- [show fabric multicast statistics](#), on page 403
- [show fabric multicast vrf](#), on page 404
- [show fc2 bind](#), on page 405
- [show fc2 classf](#), on page 406
- [show fc2 exchange](#), on page 408
- [show fc2 exchresp](#), on page 410
- [show fc2 flogi](#), on page 412
- [show fc2 nport](#), on page 413
- [show fc2 plogi](#), on page 415
- [show fc2 plogi_pwwn](#), on page 417
- [show fc2 port brief](#), on page 418
- [show fc2 port drops](#), on page 421
- [show fc2 port state](#), on page 424
- [show fc2 socket](#), on page 426
- [show fc2 sockexch](#), on page 427
- [show fc2 socknotify](#), on page 428
- [show fc2 socknport](#), on page 429

- [show fc2 vsan](#), on page 430
- [show fcdroplateny](#), on page 431
- [show fcoe-npv issu-impact](#), on page 432
- [show fcoe](#), on page 433
- [show fcoe database](#), on page 434
- [show fctimer](#), on page 435
- [show fctimer D_S_TOV](#), on page 436
- [show fctimer E_D_TOV](#), on page 437
- [show fctimer F_S_TOV](#), on page 438
- [show fctimer R_A_TOV](#), on page 439
- [show fctimer last action status](#), on page 440
- [show fctimer pending-diff](#), on page 441
- [show fctimer pending](#), on page 442
- [show fctimer session status](#), on page 443
- [show fctimer status](#), on page 444
- [show fctimer vsan](#), on page 445
- [show feature-set](#), on page 446
- [show feature-set services](#), on page 447
- [show feature](#), on page 448
- [show fhrp](#), on page 449
- [show fhrp verbose](#), on page 450
- [show file](#), on page 452
- [show fips status](#), on page 453
- [show flow cache](#), on page 454
- [show flow cache](#), on page 456
- [show flow exporter](#), on page 458
- [show flow interface](#), on page 460
- [show flow monitor](#), on page 461
- [show flow record](#), on page 462
- [show flow timeout](#), on page 465
- [show flow tracer](#), on page 466
- [show forwarding](#), on page 467
- [show forwarding adjacency](#), on page 468
- [show forwarding distribution clients](#), on page 471
- [show forwarding distribution fib-state](#), on page 472
- [show forwarding distribution ip igmp snooping](#), on page 473
- [show forwarding distribution ipv6 multicast route](#), on page 474
- [show forwarding distribution l2 multicast](#), on page 476
- [show forwarding distribution lisp counters](#), on page 478
- [show forwarding distribution lisp vrf enabled](#), on page 479
- [show forwarding distribution multicast](#), on page 480
- [show forwarding distribution multicast client-ack-db](#), on page 481
- [show forwarding distribution multicast client](#), on page 482
- [show forwarding distribution multicast download](#), on page 483
- [show forwarding distribution multicast mfib](#), on page 484
- [show forwarding distribution multicast outgoing-interface-list](#), on page 485

- [show forwarding distribution multicast resp-ack-timer-msgs](#), on page 486
- [show forwarding distribution multicast route](#), on page 487
- [show forwarding distribution peer-id](#), on page 489
- [show forwarding distribution trace](#), on page 490
- [show forwarding ecmp](#), on page 491
- [show forwarding ecmp recursive](#), on page 493
- [show forwarding interfaces](#), on page 496
- [show forwarding ipv6 adjacency](#), on page 497
- [show forwarding ipv6 multicast route](#), on page 499
- [show forwarding ipv6 route](#), on page 501
- [show forwarding kvfib cache on](#), on page 504
- [show forwarding l2 multicast](#), on page 505
- [show forwarding l2vpn ipv6 multicast route](#), on page 507
- [show forwarding l2vpn label vpls](#), on page 508
- [show forwarding l2vpn label xconnect](#), on page 509
- [show forwarding l2vpn multicast outgoing-interface-list](#), on page 510
- [show forwarding l2vpn multicast route](#), on page 511
- [show forwarding l2vpn service vpls](#), on page 512
- [show forwarding l2vpn service xconnect](#), on page 513
- [show forwarding l2vpn vlan](#), on page 514
- [show forwarding multicast-sr loopback interface](#), on page 515
- [show forwarding multicast outgoing-interface-list](#), on page 516
- [show forwarding multicast route](#), on page 517
- [show forwarding security group-tag](#), on page 520
- [show forwarding security mac](#), on page 522
- [show forwarding trace](#), on page 524
- [show forwarding trace profile](#), on page 525
- [show forwarding trace profile funcstats](#), on page 526
- [show fte event](#), on page 527
- [show fte exporter](#), on page 528
- [show fte monitor](#), on page 529
- [show fte record](#), on page 530

show fabric database dci

```
show fabric database dci [ { vrf <vrf-name> [ peer-id <peer-ip-address> ] [ detail ] } ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
dci	DCI Profile Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
peer-id	(Optional) management ip address of peer
<i>peer-ip-address</i>	(Optional) IP address in CIDR format
detail	(Optional) Show detailed information

Command Mode

- /exec

show fabric database dci

```
show fabric database dci [ { vrf { <vrf-name> | <vrf-known-name> } [ peer-id <peer-ip-address> ] [ detail ]
} ] [ __readonly__ [ TABLE_database_dci <vrf_name> <state> <flags> <profile> <instance> ] [
TABLE_database_dci_detail <packet_arrival_time> <sent_to_database_manager_at>
<received_parameters_from_database_manager_at> <sent_apply_to_configuration_manager_at>
<completed_executing_all_commands_at> <sent_un_apply_to_configuration_manager_at>
<completed_unapplying_all_commands_at> ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
dci	DCI Profile Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
peer-id	(Optional) management ip address of peer
<i>peer-ip-address</i>	(Optional) IP address in CIDR format
detail	(Optional) Show detailed information
<i>__readonly__</i>	(Optional) Read Only
TABLE_database_dci	(Optional) table show fabric database dci
<i>vrf_name</i>	(Optional)
<i>state</i>	(Optional)
<i>flags</i>	(Optional)
<i>profile</i>	(Optional)
<i>instance</i>	(Optional)
TABLE_database_dci_detail	(Optional) detail for table show fabric database dci
<i>packet_arrival_time</i>	(Optional) Profile request time
<i>sent_to_database_manager_at</i>	(Optional) Profile request sent to DCNM
<i>received_parameters_from_database_manager_at</i>	(Optional) Profile downloaded from DCNM
<i>sent_apply_to_configuration_manager_at</i>	(Optional) Profile sent to PPM to apply

<i>completed_executing_all_commands_at</i>	(Optional) Profile applied by PPM
<i>sent_un_apply_to_configuration_manager_at</i>	(Optional) Profile un-apply sent to PPM
<i>completed_unapplying_all_commands_at</i>	(Optional) Profile un-applied by PPM

Command Mode

- /exec

show fabric database host

```
show fabric database host [ detail ] [ { vni <vni-id> } | { dot1q <vlan-id> } ] [ __readonly__ [
TABLE_database_host [ <trigger_source> ] [ <client_type> ] [ <got_trigger_at> ] [ <number_of_client_hosts>
] [ <number_of_associated_interfaces> ] [ <profile_be_un_applied_in_seconds> ] [
<new_vdp_requests_be_accepted_in_seconds> ] [ <recovered_profile_be_checked_for_validity_in_seconds>
] [ <mac_aging_checked_in_seconds> ] [ <sent_to_database_manager_at> ] [
<received_parameters_from_database_manager_at> ] [ <displaying_parameters_for_profile> ] [
<displaying_parameters_for_instance> ] [ <no_parameters_for_the_profile> ] [
<displaying_re_written_parameters_for_vpc_role> ] [ TABLE_parameter [ <parameter_index> ] [ <parameter>
] ] [ TABLE_static_profile <profile> <instance> <no_parameters_for_the_profile> ] [ TABLE_migrated_profile
<profile> <instance_index> <previous_profile> <previous_instance_index> ] [ TABLE_rollback_profile
<profile> <instance_index> ] [ <got_vlan_allocated_from_vlan_manager_at> ] [
<sent_apply_to_configuration_manager_at> ] [ <completed_executing_all_commands_at> ] [
<sent_to_vpc_peer_at> ] [ <completed_executing_all_commands_on_vpc_peer_at> ] [
<sent_un_apply_to_configuration_manager_at> ] [ <completed_unapplying_all_commands_at> ] ] [
TABLE_database_host_vni { [ <vni_id> ] [ <vlan_id> ] [ <state> <flag> <profile_name> <instance_name>
] [ <packet_arrival_time> <request_profile_time> <got_profile_time> <sent_to_PPM_time>
<profile_apply_time> <del_to_PPM_time> ] [ { TABLE_database_host_detail <interface> <encap> <flags>
<state> [ <vsi_id> ] [ <client> ] [ <host> ] } } ] [ TABLE_database_host_vlan { [ <vlan_id> ] [ <vni_id> ]
[ <state> <flag> <profile_name> <instance_name> ] [ <packet_arrival_time> <request_profile_time>
<got_profile_time> <sent_to_PPM_time> <profile_apply_time> <del_to_PPM_time> ] [ {
TABLE_database_host_detail <interface> <encap> <flags> <state> [ <vsi_id> ] } } ] [
TABLE_extranet_vrf_entries { <vrf> <13_vni> <state> <profile> <instance> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
host	Host to profile mapping
detail	(Optional) Show hosts and interfaces
vni	(Optional) Virtual Network Identifier
vni-id	(Optional)
dot1q	(Optional) Dot1Q Encapsulation
vlan-id	(Optional)
__readonly__	(Optional) Read Only
TABLE_database_host	(Optional) table show fabric database host {dot1q vni}
trigger_source	(Optional) TODO
client_type	(Optional) TODO

<i>got_trigger_at</i>	(Optional) TODO
<i>number_of_client_hosts</i>	(Optional) TODO
<i>number_of_associated_interfaces</i>	(Optional) TODO
<i>profile_be_un_applied_in_seconds</i>	(Optional) TODO
<i>new_vdp_requests_be_accepted_in_seconds</i>	(Optional) TODO
<i>recovered_profile_be_checked_for_validity_in_seconds</i>	(Optional) TODO
<i>mac_aging_checked_in_seconds</i>	(Optional) TODO
<i>sent_to_database_manager_at</i>	(Optional) TODO
<i>received_parameters_from_database_manager_at</i>	(Optional) TODO
<i>displaying_parameters_for_profile</i>	(Optional) TODO
<i>displaying_parameters_for_instance</i>	(Optional) TODO
<i>no_parameters_for_the_profile</i>	(Optional) TODO
<i>displaying_re_written_parameters_for_vpc_role</i>	(Optional) TODO
TABLE_parameter	(Optional) table show the parameters
<i>parameter_index</i>	(Optional) TODO
<i>parameter</i>	(Optional) TODO
TABLE_static_profile	(Optional) show static profile
<i>profile</i>	(Optional) TODO
<i>instance</i>	(Optional) TODO
<i>no_parameters_for_the_profile</i>	(Optional) TODO
TABLE_migrated_profile	(Optional) show migrated profile
<i>profile</i>	(Optional) TODO
<i>instance_index</i>	(Optional) TODO
<i>previous_profile</i>	(Optional) TODO
<i>previous_instance_index</i>	(Optional) TODO
TABLE_rollback_profile	(Optional) show rollback profile
<i>profile</i>	(Optional) TODO
<i>instance_index</i>	(Optional) TODO
<i>got_vlan_allocated_from_vlan_manager_at</i>	(Optional) TODO

<i>sent_apply_to_configuration_manager_at</i>	(Optional) TODO
<i>completed_executing_all_commands_at</i>	(Optional) TODO
<i>sent_to_vpc_peer_at</i>	(Optional) TODO
<i>completed_executing_all_commands_on_vpc_peer_at</i>	(Optional) TODO
<i>sent_un_apply_to_configuration_manager_at</i>	(Optional) TODO
<i>completed_unapplying_all_commands_at</i>	(Optional) TODO
TABLE_database_host_vni	(Optional) table show fabric database host vni based
<i>vni_id</i>	(Optional) TODO Add comment
<i>vlan_id</i>	(Optional) TODO Add comment
<i>state</i>	(Optional) TODO Add comment
<i>flag</i>	(Optional) TODO
<i>profile_name</i>	(Optional) TODO
<i>instance_name</i>	(Optional) TODO
<i>packet_arrival_time</i>	(Optional) TODO
<i>request_profile_time</i>	(Optional) TODO
<i>got_profile_time</i>	(Optional) TODO
<i>sent_to_PPM_time</i>	(Optional) TODO
<i>profile_apply_time</i>	(Optional) TODO
<i>del_to_PPM_time</i>	(Optional) TODO
TABLE_database_host_detail	(Optional) table show fabric database host detail
<i>interface</i>	(Optional) TODO
<i>encap</i>	(Optional) TODO
<i>flags</i>	(Optional) TODO
<i>state</i>	(Optional) TODO
<i>vsi_id</i>	(Optional) TODO
<i>client</i>	(Optional) TODO
<i>host</i>	(Optional) TODO
TABLE_database_host_vlan	(Optional) table show fabric database host vlan based
<i>vlan_id</i>	(Optional) TODO Add comment

<i>vni_id</i>	(Optional) TODO Add comment
<i>state</i>	(Optional) TODO Add comment
<i>flag</i>	(Optional) TODO
<i>profile_name</i>	(Optional) TODO
<i>instance_name</i>	(Optional) TODO
<i>packet_arrival_time</i>	(Optional) TODO
<i>request_profile_time</i>	(Optional) TODO
<i>got_profile_time</i>	(Optional) TODO
<i>sent_to_PPM_time</i>	(Optional) TODO
<i>profile_apply_time</i>	(Optional) TODO
<i>del_to_PPM_time</i>	(Optional) TODO
TABLE_database_host_detail	(Optional) table show fabric database host detail
<i>interface</i>	(Optional) TODO
<i>encap</i>	(Optional) TODO
<i>flags</i>	(Optional) TODO
<i>state</i>	(Optional) TODO
<i>vsi_id</i>	(Optional) TODO
TABLE_extranet_vrf_entries	(Optional) table extranet VRF entries
<i>vrf</i>	(Optional) TODO
<i>l3_vni</i>	(Optional) TODO
<i>state</i>	(Optional) TODO
<i>profile</i>	(Optional) TODO
<i>instance</i>	(Optional) TODO

Command Mode

- /exec

show fabric database host statistics

```
show fabric database host statistics [ __readonly__ [ TABLE_database_host_statistics { [ <data_snoop_triggers>
] [ <data_snoop_deletes> ] [ <data_snoop_responses> ] [ <vdp_association_requests> ] [
<vdp_deassociation_requests> ] [ <vdp_association_responses> ] [ <vdp_error_responses> ] [
<unsupported_interfaces> ] [ <no_profile_map_errors> ] [ <outstanding_delete_retry_add> ] [
<duplicate_add_existing_host> ] [ <hmm_api_error_cannot_add_host> ] [ <existing_profile_new_host> ] [
<profile_apply_from_vpc_peer> ] [ <profile_un_apply_from_vpc_peer> ] [ <host_apply_from_vpc_peer> ]
[ <host_un_apply_from_vpc_peer> ] [ <early_delete_cancel_add> ] [ <dhcp_requests> ] [ <dhcp_responses>
] [ <dhcp_error_responses> ] [ <adbm_requests> ] [ <adbm_responses> ] [ <adbm_error_responses> ] [
<adbm_error_requests> ] [ <adbm_db_notifications> ] [ <vnseg_no_bridge_domain> ] [
<vnseg_encap_responses> ] [ <vnseg_vni_responses> ] [ <vnseg_unknown_responses> ] [
<vnseg_bd_down_notif> ] [ <bd_mgr_requests> ] [ <bd_mgr_success_responses> ] [
<bd_mgr_failure_responses> ] [ <bd_mgr_unreserve> ] [ <bd_mgr_inconsistencies> ] [ <no_mac_on_bd_notif>
] [ <refresh_failures> ] [ <profile_apply_received> ] [ <profile_vpc_queued> ] [ <profile_local_apply_queued>
] [ <profile_local_unapply_queued> ] [ <profile_apply_sent> ] [ <profile_apply_responses> ] [
<profile_apply_success> ] [ <profile_unapply_success> ] [ <profile_apply_failure> ] [ <profile_commands>
] [ <profile_error_incomplete_configs> ] [ <profile_api_error> ] [ <profile_unapply_sent> ] [
<profile_top_queue_adds> ] [ <profile_high_queue_adds> ] [ <profile_low_queue_adds> ] [
<profile_unapply_failure> ] [ <outstanding_vlan_requests> ] [ <outstanding_adbm_requests> ] [
<outstanding_profile_applies> ] [ <outstanding_vpc_profile_applies> ] [ <node_recon_pending> ] [
<node_recon_attempts> ] [ <node_recon_failures> ] } ] ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
host	Auto-configured Hosts
statistics	Statistics - Mostly shows non-zero values
<u>__readonly__</u>	(Optional) Read Only
TABLE_database_host_statistics	(Optional) table show fabric database host statistics
<i>data_snoop_triggers</i>	(Optional) TODO
<i>data_snoop_deletes</i>	(Optional) TODO
<i>data_snoop_responses</i>	(Optional) TODO
<i>vdp_association_requests</i>	(Optional) TODO
<i>vdp_deassociation_requests</i>	(Optional) TODO
<i>vdp_association_responses</i>	(Optional) TODO
<i>vdp_error_responses</i>	(Optional) TODO

<i>unsupported_interfaces</i>	(Optional) TODO
<i>no_profile_map_errors</i>	(Optional) TODO
<i>outstanding_delete_retry_add</i>	(Optional) TODO
<i>duplicate_add_existing_host</i>	(Optional) TODO
<i>hmm_api_error_cannot_add_host</i>	(Optional) TODO
<i>existing_profile_new_host</i>	(Optional) TODO
<i>profile_apply_from_vpc_peer</i>	(Optional) TODO
<i>profile_un_apply_from_vpc_peer</i>	(Optional) TODO
<i>host_apply_from_vpc_peer</i>	(Optional) TODO
<i>host_un_apply_from_vpc_peer</i>	(Optional) TODO
<i>early_delete_cancel_add</i>	(Optional) TODO
<i>dhcp_requests</i>	(Optional) TODO
<i>dhcp_responses</i>	(Optional) TODO
<i>dhcp_error_responses</i>	(Optional) TODO
<i>adbm_requests</i>	(Optional) TODO
<i>adbm_responses</i>	(Optional) TODO
<i>adbm_error_responses</i>	(Optional) TODO
<i>adbm_error_requests</i>	(Optional) TODO
<i>adbm_db_notifications</i>	(Optional) TODO
<i>vnseg_no_bridge_domain</i>	(Optional) TODO
<i>vnseg_encap_responses</i>	(Optional) TODO
<i>vnseg_vni_responses</i>	(Optional) TODO
<i>vnseg_unknown_responses</i>	(Optional) TODO
<i>vnseg_bd_down_notif</i>	(Optional) TODO
<i>bd_mgr_requests</i>	(Optional) TODO
<i>bd_mgr_success_responses</i>	(Optional) TODO
<i>bd_mgr_failure_responses</i>	(Optional) TODO
<i>bd_mgr_unreserve</i>	(Optional) TODO
<i>bd_mgr_inconsistencies</i>	(Optional) TODO

<i>no_mac_on_bd_notif</i>	(Optional) TODO
<i>refresh_failures</i>	(Optional) TODO
<i>profile_apply_received</i>	(Optional) TODO
<i>profile_vpc_queued</i>	(Optional) TODO
<i>profile_local_apply_queued</i>	(Optional) TODO
<i>profile_local_unapply_queued</i>	(Optional) TODO
<i>profile_apply_sent</i>	(Optional) TODO
<i>profile_apply_responses</i>	(Optional) TODO
<i>profile_apply_success</i>	(Optional) TODO
<i>profile_unapply_success</i>	(Optional) TODO
<i>profile_apply_failure</i>	(Optional) TODO
<i>profile_commands</i>	(Optional) TODO
<i>profile_error_incomplete_configs</i>	(Optional) TODO
<i>profile_api_error</i>	(Optional) TODO
<i>profile_unapply_sent</i>	(Optional) TODO
<i>profile_top_queue_adds</i>	(Optional) TODO
<i>profile_high_queue_adds</i>	(Optional) TODO
<i>profile_low_queue_adds</i>	(Optional) TODO
<i>profile_unapply_failure</i>	(Optional) TODO
<i>outstanding_vlan_requests</i>	(Optional) TODO
<i>outstanding_adbm_requests</i>	(Optional) TODO
<i>outstanding_profile_applies</i>	(Optional) TODO
<i>outstanding_vpc_profile_applies</i>	(Optional) TODO
<i>node_recon_pending</i>	(Optional) TODO
<i>node_recon_attempts</i>	(Optional) TODO
<i>node_recon_failures</i>	(Optional) TODO

Command Mode

- /exec

show fabric database host summary

```
show fabric database host summary [ __readonly__ [ TABLE_database_host_summary {
<number_of_instances_applied> <number_of_client_hosts> <recovery_timeout_minute>
<cleanup_timeout_minute> <client_add_suppression_timeout_minute> <mac_aging_timeout_minute>
<autoid_support> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
host	Auto-configured Hosts
summary	Summary
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_database_host_summary</i>	(Optional) table show fabric database host summary
<i>number_of_instances_applied</i>	(Optional) TODO
<i>number_of_client_hosts</i>	(Optional) TODO
<i>recovery_timeout_minute</i>	(Optional) TODO
<i>cleanup_timeout_minute</i>	(Optional) TODO
<i>client_add_suppression_timeout_minute</i>	(Optional) TODO
<i>mac_aging_timeout_minute</i>	(Optional) TODO
<i>autoid_support</i>	(Optional) List of supported auto-generate ids

Command Mode

- /exec

show fabric database profile-map

```
show fabric database profile-map { global | [ <id> | interface <interface-id> ] } [ __readonly__ [
TABLE_database_profile_map { <map> <proto> <vni> <dot1q> <flags> <profile_name> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
profile-map	Profile Map
global	Global profile (apply to all interfaces)
<i>id</i>	(Optional) Profile Map ID
interface	(Optional) Specified interface to display
<i>interface-id</i>	(Optional) Name of interface
<i>__readonly__</i>	(Optional) Read Only
TABLE_database_profile_map	(Optional) table show fabric database profile-map
<i>map</i>	(Optional) TODO
<i>proto</i>	(Optional) TODO
<i>vni</i>	(Optional) TODO
<i>dot1q</i>	(Optional) TODO
<i>flags</i>	(Optional) TODO
<i>profile_name</i>	(Optional) TODO

Command Mode

- /exec

show fabric database static-host

```
show fabric database static-host [ __readonly__ [ TABLE_database_static_host { <host_key> <interface>
<state> <retry_delay> <retry_attempts> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
static-host	Configured Static Hosts
__readonly__	(Optional) Read Only
TABLE_database_static_host	(Optional) table show fabric database static-host
<i>host_key</i>	(Optional) static-host key
<i>interface</i>	(Optional) interface name
<i>state</i>	(Optional) static-host state
<i>retry_delay</i>	(Optional) seconds until next retry
<i>retry_attempts</i>	(Optional) cumulative retry attempts

Command Mode

- /exec

show fabric database statistics

```
show fabric database statistics [ type { network | profile | cabling | partition | bl-dci | host } ] [ __readonly__
{ TABLE_types <dbtype> <requests> <dispatched> <not_dispatched> <re_dispatched> } [ { TABLE_dbs
<is_active> <type> <prot> <serverdb> [ <reqs> <ok> <nores> <err> <tmout> <pend> ] } ] { LastPollTime
<poll_time> } { LastUpdateTime <update_time> } [ { TABLE_updates <update_type> <update_status> } ]
]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Show Fabric Database
statistics	Show database statistics
type	(Optional) Enter database type
network	(Optional) Network Database
profile	(Optional) Port or Switch Profile Database
cabling	(Optional) Cable Management Database
partition	(Optional) Partition Database
bl-dci	(Optional) Border Leaf - DCI
host	(Optional) Host
__readonly__	(Optional)
TABLE_types	(Optional) totals by type
<i>dbtype</i>	(Optional) type of database
<i>requests</i>	(Optional) number of requests
<i>dispatched</i>	(Optional) number dispatched
<i>not_dispatched</i>	(Optional) number not dispatched
<i>re_dispatched</i>	(Optional) number re-dispatched
TABLE_dbs	(Optional) per-database stats
<i>is_active</i>	(Optional) active/inactive
<i>type</i>	(Optional) database type
<i>prot</i>	(Optional) database protocol
<i>serverdb</i>	(Optional) server database

<i>reqs</i>	(Optional) requests
<i>ok</i>	(Optional) OK
<i>nores</i>	(Optional) nores
<i>err</i>	(Optional) err
<i>tmout</i>	(Optional) tmout
<i>pend</i>	(Optional) pend
LastPollTime	(Optional) last poll time
<i>poll_time</i>	(Optional) poll time
LastUpdateTime	(Optional) last update time for db status change
<i>update_time</i>	(Optional) update time
TABLE_updates	(Optional) totals ty type
<i>update_type</i>	(Optional) db type
<i>update_status</i>	(Optional) db status

Command Mode

- /exec

show fabric forwarding host-db

```
show fabric forwarding host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ __readonly__ [
TABLE_forwarding_host_db_vrf { <vrf> <vrf_id> <vrf_state> <vrf_reason> <vni_id> <refcount>
<conversational_learning> [ TABLE_limit_type <limit_type> <enable> <threshold> <action> ] [ TABLE_ipv4
<address_family> <vrf> <table_id> <table_state> <refcount> <local_hosts> <remote_hosts> <aggregates>
[ TABLE_aggregate_list <aggregate_subnet_prefix_list> <aggregate_subnet_prefix_state> ] ] [ TABLE_ipv6
<address_family> <vrf> <table_id> <table_state> <refcount> <local_hosts> <remote_hosts> <aggregates>
[ TABLE_aggregate_list <aggregate_subnet_prefix_list> <aggregate_subnet_prefix_state> ] ] } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
host-db	Host Database info
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional) Read Only
TABLE_forwarding_host_db_vrf	(Optional) table show fabric forwarding host-db vrf
<i>vrf</i>	(Optional) TODO
<i>vrf_id</i>	(Optional) TODO
<i>vrf_state</i>	(Optional) TODO
<i>vrf_reason</i>	(Optional) TODO
<i>vni_id</i>	(Optional) TODO
<i>refcount</i>	(Optional) TODO
<i>conversational_learning</i>	(Optional) TODO
TABLE_limit_type	(Optional) table for limit type
<i>limit_type</i>	(Optional) TODO
<i>enable</i>	(Optional) TODO
<i>threshold</i>	(Optional) TODO
<i>action</i>	(Optional) TODO

TABLE_ipv4	(Optional) Information for address family IPv4
<i>address_family</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>table_id</i>	(Optional) TODO
<i>table_state</i>	(Optional) TODO
<i>refcount</i>	(Optional) TODO
<i>local_hosts</i>	(Optional) TODO
<i>remote_hosts</i>	(Optional) TODO
<i>aggregates</i>	(Optional) TODO
TABLE_aggregate_list	(Optional) table for aggregate subnet prefix list
<i>aggregate_subnet_prefix_list</i>	(Optional) TODO
TABLE_ipv6	(Optional) Information for address family IPv6
<i>address_family</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>table_id</i>	(Optional) TODO
<i>table_state</i>	(Optional) TODO
<i>refcount</i>	(Optional) TODO
<i>local_hosts</i>	(Optional) TODO
<i>remote_hosts</i>	(Optional) TODO
<i>aggregates</i>	(Optional) TODO
TABLE_aggregate_list	(Optional) table for aggregate subnet prefix list
<i>aggregate_subnet_prefix_list</i>	(Optional) TODO
<i>aggregate_subnet_prefix_state</i>	(Optional) TODO

Command Mode

- /exec

show fabric forwarding ip local

```
show fabric forwarding ip { local-host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ <ip-prefix>
] } [ __readonly__ [ TABLE_forwarding_ip_local_host_db_vrf { <hmm_host> <vrf> <status_in> {
TABLE_hosts <host> <mac_address> <svi> <flags_0x> <physical_interface> <status> } } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
ip	Display IP information
local-host-db	HMM Local Host Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>ip-prefix</i>	(Optional) IP prefix in CIDR format
<i>__readonly__</i>	(Optional) Read Only
TABLE_forwarding_ip_local_host_db_vrf	(Optional) table show fabric forwarding ip local-host-db vrf
<i>hmm_host</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>status_in</i>	(Optional) TODO
TABLE_hosts	(Optional) table show information for each hosts
<i>host</i>	(Optional) TODO
<i>mac_address</i>	(Optional) TODO
<i>svi</i>	(Optional) TODO
<i>flags_0x</i>	(Optional) TODO
<i>physical_interface</i>	(Optional) TODO
<i>status</i>	(Optional) *-valid, x-deleted, a-aged out, c-cleaned

Command Mode

- /exec

show fabric forwarding ipv6 local

```
show fabric forwarding ipv6 { local-host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ <ipv6-prefix>
] } [ __readonly__ [ TABLE_forwarding_ipv6_local_host_db_vrf { <hmm_host> <vrf> <status_in> {
TABLE_hosts <host> <mac_address> <svi> <flags_0x> <physical_interface> <status> } } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
ipv6	Display IPv6 information
local-host-db	HMM Local Host Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional) Read Only
TABLE_forwarding_ipv6_local_host_db_vrf	(Optional) table show fabric forwarding ipv6 local-host-db vrf
<i>hmm_host</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>status_in</i>	(Optional) TODO
TABLE_hosts	(Optional) table show information for each hosts
<i>host</i>	(Optional) TODO
<i>mac_address</i>	(Optional) TODO
<i>svi</i>	(Optional) TODO
<i>flags_0x</i>	(Optional) TODO
<i>physical_interface</i>	(Optional) TODO
<i>status</i>	(Optional) *-valid, x-deleted, a-aged out, c-cleaned

Command Mode

- /exec

show fabric multicast

```
show fabric multicast { ipv4 { mroute [ { <v4_group> [ <v4_source> ] } ] | ssm-range | rp-grange | sa-ad-route
[ { <v4_group> [ <v4_source> ] } ] } | ipv6 { mroute [ { <v6_group> [ <v6_source> ] } ] | ssm-range | rp-grange
| sa-ad-route [ { <v4_group> [ <v4_source> ] } ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_vrf <context_name> <nlri_type> <vnid> [ TABLE_mroute <mroute> <mroute_uptime>
{ TABLE_node <node_addr> <node_uptime> <real_join> <sim_join> <rpf_nbr> } ] [ TABLE_rp
<border_leaf_addr> { TABLE_rp_grange <rp_grange_desc> } ] [ TABLE_ssm <border_leaf_addr> {
TABLE_ssm_range <ssm_range_desc> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
ipv4	Display IP information
ipv6	Display IPv6 information
mroute	display fabric mroutes
sa-ad-route	display Src Active AD routes
ssm-range	display SSM ranges
rp-grange	display RP granges
<i>v4_group</i>	(Optional) IPV4 Group address to display
<i>v4_source</i>	(Optional) IPV4 Source address to display
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs NGMVPN is aware of
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>context_name</i>	(Optional)
<i>nlri_type</i>	(Optional)
<i>vnid</i>	(Optional)
TABLE_mroute	(Optional)
<i>mroute</i>	(Optional)

<i>mroute_uptime</i>	(Optional)
TABLE_node	(Optional)
<i>node_addr</i>	(Optional)
<i>node_uptime</i>	(Optional)
<i>real_join</i>	(Optional)
<i>sim_join</i>	(Optional)
<i>rpf_nbr</i>	(Optional)
TABLE_rp	(Optional)
<i>border_leaf_addr</i>	(Optional)
TABLE_rp_grange	(Optional)
<i>rp_grange_desc</i>	(Optional)
TABLE_ssm	(Optional)
<i>border_leaf_addr</i>	(Optional)
TABLE_ssm_range	(Optional)
<i>ssm_range_desc</i>	(Optional)

Command Mode

- /exec

show fabric multicast event-history

```
show fabric multicast [ internal ] event-history { errors | msgs | <ngmvpn-event-hist-buf-name> | statistics }
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
internal	(Optional) Commands for internal use
event-history	Show various event logs of NGMVPN
errors	Show error logs of NGMVPN
msgs	Show various message logs of NGMVPN
<i>ngmvpn-event-hist-buf-name</i>	Show event hist buffer name
statistics	Show the state and size of the buffer

Command Mode

- /exec

show fabric multicast globals

```
show fabric multicast globals [ __readonly__ <pruning> <switch_role> <fabric_control_seg>
<peer_fabric_ctrl_addr> <advertise_vpc_rpf_routes> <created_vni_list> <fwd_encap> ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
globals	show the global settings
<i>__readonly__</i>	(Optional)
<i>pruning</i>	(Optional)
<i>switch_role</i>	(Optional)
<i>fabric_control_seg</i>	(Optional)
<i>peer_fabric_ctrl_addr</i>	(Optional)
<i>advertise_vpc_rpf_routes</i>	(Optional)
<i>created_vni_list</i>	(Optional)
<i>fwd_encap</i>	(Optional)

Command Mode

- /exec

show fabric multicast ipv4 l2 vni

```
show fabric multicast { ipv4 | ipv6 } { l2-mroute } vni { <vni-id> | all } [ __readonly__ TABLE_vni <vnid>
[ TABLE_mroute <mroute_desc> [ TABLE_fabric <fabric_node_addr> ] ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
ipv4	Display IP information
ipv6	Display IPv6 information
l2-mroute	display l2-mroute status
vni	Virtual Network Identifier
<i>vni-id</i>	VNI number
all	Display all L2 VNI NGMVPN is aware of
__readonly__	(Optional)
TABLE_vni	(Optional)
<i>vnid</i>	(Optional)
TABLE_mroute	(Optional)
<i>mroute_desc</i>	(Optional)
TABLE_fabric	(Optional)
<i>fabric_node_addr</i>	(Optional)

Command Mode

- /exec

show fabric multicast ipv4 rp

show fabric multicast { ipv4 | ipv6 } { rp-route } [vrf { <vrf-name> | <vrf-known-name> | all }]

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
ipv4	Display IP information
ipv6	Display IPv6 information
rp-route	display fabric rp-routes
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs NGMVPN is aware of

Command Mode

- /exec

show fabric multicast statistics

show fabric multicast [internal] statistics

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
internal	(Optional) Commands for internal use
statistics	Show the state and size of the buffer

Command Mode

- /exec

show fabric multicast vrf

```
show fabric multicast vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_vrf
<context_name><context_id><vprime_iod><vnid> } ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
vrf	Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs NGMVPN is aware of
__readonly__	(Optional)
TABLE_vrf	(Optional)

Command Mode

- /exec

show fc2 bind

```
show fc2 bind [ __readonly__ { TABLE_fc2bind <SOCKET> <FLAGS> <NLEVEL> <RULE> <SINDEX>
<VSAN> <D_ID> <MASK> <TYPE> <SUBTYPE> <M_VALUES> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
bind	show fc2 socket bindings
__readonly__	(Optional) Read only
TABLE_fc2bind	(Optional) show fc2 bind
<i>SOCKET</i>	(Optional) socket
<i>FLAGS</i>	(Optional) flags
<i>NLEVEL</i>	(Optional) nlevel
<i>RULE</i>	(Optional) rule
<i>SINDEX</i>	(Optional) sidnex
<i>VSAN</i>	(Optional) vsan
<i>D_ID</i>	(Optional) d_id
<i>MASK</i>	(Optional) mask
<i>TYPE</i>	(Optional) type
<i>SUBTYPE</i>	(Optional) subtype
<i>M_VALUES</i>	(Optional) m_values

Command Mode

- /exec

show fc2 classf

```
show fc2 classf [ __readonly__ { TABLE_fc2classf <HIX> <VSAN> <S_ID> <D_ID> <IFIDX> <R_A_TOV>
<E_D_TOV> <F-SO> <RC> <RS> <CS> <EE> <2-SO> <RS> <3-SO> <RS> <EECNT> <TCCNT> <FCNT>
<REFCNT> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
classf	show fc2 classf sessions
__readonly__	(Optional) Read only
TABLE_fc2classf	(Optional) show fc2 classf
HIX	(Optional) hix
VSAN	(Optional) vsan
S_ID	(Optional) sid
D_ID	(Optional) did
IFIDX	(Optional) ifidx
R_A_TOV	(Optional) r_a_tov
E_D_TOV	(Optional) e_d_tov
F-SO	(Optional) f-so
RC	(Optional) rc
RS	(Optional) rs
CS	(Optional) cs
EE	(Optional) ee
2-SO	(Optional) 2-so
RS	(Optional) rs
3-SO	(Optional) 3-so
RS	(Optional) rs
EECNT	(Optional) eecnt
TCCNT	(Optional) tcnt
FCNT	(Optional) fcnt

<i>REFCNT</i>	(Optional) refcnt
---------------	-------------------

Command Mode

- /exec

show fc2 exchange

```
show fc2 exchange [ __readonly__ { TABLE_ExchngInfo [ <ECB_INUSE> ] [ <ECB_DROPPED> ] [
<ECB_TOTAL> ] [ <ECB_MAX> ] } [ TABLE_fc2exchange <HIX> <VSAN> <X_ID> <OX_ID> <RX_ID>
<O_ID> <R_ID> <ESTAT> <STATE> <SOCKET> <DIFINDEX> <CS> <TYPE> <SEQID> <TCNT>
<RCNT> <LO> <HI> <SSTAT> <LOGIN> ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
exchange	show fc2 active exchanges
<i>__readonly__</i>	(Optional) Read only
TABLE_ExchngInfo	(Optional) ecb info
<i>ECB_INUSE</i>	(Optional) ecb in use
<i>ECB_DROPPED</i>	(Optional) ecb dropped
<i>ECB_TOTAL</i>	(Optional) ecb total
<i>ECB_MAX</i>	(Optional) ecb threshold
TABLE_fc2exchange	(Optional) show fc2 exchange
<i>HIX</i>	(Optional) hix
<i>VSAN</i>	(Optional) vsan
<i>X_ID</i>	(Optional) xid
<i>OX_ID</i>	(Optional) oxid
<i>RX_ID</i>	(Optional) rxid
<i>O_ID</i>	(Optional) o_id
<i>R_ID</i>	(Optional) r_id
<i>ESTAT</i>	(Optional) estat
<i>STATE</i>	(Optional) state
<i>SOCKET</i>	(Optional) socket
<i>DIFINDEX</i>	(Optional) dIFINDEX
<i>CS</i>	(Optional) cs
<i>TYPE</i>	(Optional) type

<i>SEQID</i>	(Optional) seqid
<i>TCNT</i>	(Optional) tcnt
<i>RCNT</i>	(Optional) rcnt
<i>LO</i>	(Optional) lo
<i>HI</i>	(Optional) hi
<i>SSTAT</i>	(Optional) sstat
<i>LOGIN</i>	(Optional) login

Command Mode

- /exec

show fc2 exchresp

```
show fc2 exchresp [ __readonly__ { TABLE_fc2exchresp <HIX> <VSAN> <OX_ID> <S_ID> <CS>
<SIFINDEX> <OX_ID2> <RX_ID2> <O_ID> <R_ID> <ESTAT> <STATE> <SOCKET> <TYPE> <SEQID>
<TCNT> <RCNT> <LO> <HI> <SSTAT> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
exchresp	show fc2 active responder exchanges
__readonly__	(Optional) Read only
TABLE_fc2exchresp	(Optional) show fc2 exchresp
<i>HIX</i>	(Optional) hix
<i>VSAN</i>	(Optional) vsan
<i>OX_ID</i>	(Optional) oxid
<i>S_ID</i>	(Optional) sid
<i>CS</i>	(Optional) cs
<i>SIFINDEX</i>	(Optional) sifindex
<i>OX_ID2</i>	(Optional) oxid
<i>RX_ID2</i>	(Optional) rxid
<i>O_ID</i>	(Optional) oid
<i>R_ID</i>	(Optional) rid
<i>ESTAT</i>	(Optional) estat
<i>STATE</i>	(Optional) state
<i>SOCKET</i>	(Optional) socket
<i>TYPE</i>	(Optional) type
<i>SEQID</i>	(Optional) seqid
<i>TCNT</i>	(Optional) tcnt
<i>RCNT</i>	(Optional) rcnt
<i>LO</i>	(Optional) lo
<i>HI</i>	(Optional) hi

<i>SSTAT</i>	(Optional) sstat
--------------	------------------

Command Mode

- /exec

show fc2 flogi

```
show fc2 flogi [ __readonly__ { TABLE_fc2flogi <HIX> <VSAN> <S_ID> <FLOGI> <IFINDEX> <TYPE>
} ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
flogi	show fc2 flogi table
__readonly__	(Optional) Read only
TABLE_fc2flogi	(Optional) show fc2 flogi
<i>HIX</i>	(Optional) hix
<i>VSAN</i>	(Optional) vsan
<i>S_ID</i>	(Optional) sid
<i>FLOGI</i>	(Optional) flogi
<i>IFINDEX</i>	(Optional) ifindex
<i>TYPE</i>	(Optional) type

Command Mode

- /exec

show fc2 nport

```
show fc2 nport [ __readonly__ { TABLE_fc2nport <REF> <VSAN> <D_ID> <MASK> <FL> <ST>
<IFINDEX> <CF> <TC> <2-SO> <IC> <RC> <RS> <CS> <EE> <3-SO> <3-SO-IC> <3-SO-RC> <3-SO-RS>
<3-SO-CS> <3-SO-EE> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
nport	show fc2 local nports
__readonly__	(Optional) Read only
TABLE_fc2nport	(Optional) show fc2 nport
REF	(Optional) ref
VSAN	(Optional) vsan
D_ID	(Optional) did
MASK	(Optional) mask
FL	(Optional) fl
ST	(Optional) st
IFINDEX	(Optional) ifindex
CF	(Optional) cf
TC	(Optional) tc
2-SO	(Optional) 2so
IC	(Optional) ic
RC	(Optional) rc
RS	(Optional) rs
CS	(Optional) cs
EE	(Optional) ee
3-SO	(Optional) 3so
3-SO-IC	(Optional) 3so-ic
3-SO-RC	(Optional) 3so-rc
3-SO-RS	(Optional) 3so-rs

<i>3-SO-CS</i>	(Optional) 3so-cs
<i>3-SO-EE</i>	(Optional) 3so-ee

Command Mode

- /exec

show fc2 plogi

```
show fc2 plogi [ __readonly__ { TABLE_fc2plogi <HIX> <ADDRESS> <VSAN> <S_ID> <D_ID>
<IF_INDEX> <FL> <STATE> <CF> <TC> <2-SO> <IC> <RC> <RS> <CS> <EE> <3-SO> <3SO_IC>
<3SO_RC> <3SO_RS> <3SO_CS> <3SO_EE> <EECNT> <TCCNT> <2CNT> <3CNT> <REFCNT> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
plogi	show fc2 plogi sessions
__readonly__	(Optional) Read only
TABLE_fc2plogi	(Optional) show fc2 plogi
<i>HIX</i>	(Optional) hix
<i>ADDRESS</i>	(Optional) address
<i>VSAN</i>	(Optional) vsan
<i>S_ID</i>	(Optional) sid
<i>D_ID</i>	(Optional) did
<i>IF_INDEX</i>	(Optional) ifindex
<i>FL</i>	(Optional) fl
<i>STATE</i>	(Optional) state
<i>CF</i>	(Optional) cf
<i>TC</i>	(Optional) tc
<i>2-SO</i>	(Optional) 2so
<i>IC</i>	(Optional) ic
<i>RC</i>	(Optional) rc
<i>RS</i>	(Optional) rs
<i>CS</i>	(Optional) cs
<i>EE</i>	(Optional) ee
<i>3-SO</i>	(Optional) 3so
<i>3SO_IC</i>	(Optional) ic
<i>3SO_RC</i>	(Optional) rc

<i>3SO_RS</i>	(Optional) rs
<i>3SO_CS</i>	(Optional) cs
<i>3SO_EE</i>	(Optional) ee
<i>EECNT</i>	(Optional) eecnt
<i>TCCNT</i>	(Optional) TCCNT
<i>2CNT</i>	(Optional) 2cnt
<i>3CNT</i>	(Optional) 3cnt
<i>REFCNT</i>	(Optional) refcnt

Command Mode

- /exec

show fc2 plogi_pwwn

```
show fc2 plogi_pwwn [ __readonly__ { TABLE_fc2plogi_pwwn <HIX> <ADDRESS> <VSAN> <S_ID>
<D_ID> <IFINDEX> <FL> <STATE> <PWWN> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
plogi_pwwn	show fc2 plogi pwwn entries
__readonly__	(Optional) Read only
TABLE_fc2plogi_pwwn	(Optional) show fc2 plogi_pwwn
<i>HIX</i>	(Optional) hix
<i>ADDRESS</i>	(Optional) address
<i>VSAN</i>	(Optional) vsan
<i>S_ID</i>	(Optional) s_id
<i>D_ID</i>	(Optional) d_id
<i>IFINDEX</i>	(Optional) ifindex
<i>FL</i>	(Optional) fl
<i>STATE</i>	(Optional) state
<i>PWWN</i>	(Optional) pwwn

Command Mode

- /exec

show fc2 port brief

```
show fc2 port brief [ __readonly__ { TABLE_fc2portbrief <BAD_FRAME_RX> } [ TABLE_FCSTAT <IX>
<ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_LBSTAT
<IX> <ST> <MOD> <EMUL> <TXLBPCKTS> <TXLBDROP> <RXLBPCKTS> <RXLBDROP> ] [
TABLE_VFCSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS>
<RXDROP> ] [ TABLE_VFCPOSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR>
<RXPKTS> <RXDROP> ] [ TABLE_VFCslotstat <IX> <ST> <MOD> <EMUL> <TXPKTS>
<TXDROP> <TXERR> <RXPKTS> <RXDROP> ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
port	show fc2 physical port table
brief	display only active port counters
__readonly__	(Optional) Read only
TABLE_fc2portbrief	(Optional) bad frames received
<i>BAD_FRAME_RX</i>	(Optional) fc2 bad frames rx
TABLE_FCSTAT	(Optional) FC Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
TABLE_LBSTAT	(Optional) LB Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul

<i>TXLBPKTS</i>	(Optional) tx lb packets
<i>TXLBDROP</i>	(Optional) tx lb drops
<i>RXLBPKTS</i>	(Optional) rx lb packets
<i>RXLBDROP</i>	(Optional) rx lb drop
TABLE_VFCSTAT	(Optional) VFC Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrornt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
TABLE_VFCPOSTAT	(Optional) VFC po Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrornt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
TABLE_VFCSLOTSTAT	(Optional) VFC slot Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul

<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop

Command Mode

- /exec

show fc2 port drops

```
show fc2 port drops [ __readonly__ [ TABLE_FCSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS>
<TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_LBSTAT <IX> <ST> <MOD> <EMUL>
<TXLBPKTS> <TXLBDROP> <RXLBPKTS> <RXLBDROP> ] [ TABLE_VFCSTAT <IX> <ST> <MOD>
<EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_VFCPOSTAT <IX>
<ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [
TABLE_VFCSLOTSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS>
<RXDROP> ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
port	show fc2 physical port table
drops	display active port drop counters
__readonly__	(Optional) Read only
TABLE_FCSTAT	(Optional) FC Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
TABLE_LBSTAT	(Optional) LB Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXLBPKTS</i>	(Optional) tx lb packets
<i>TXLBDROP</i>	(Optional) tx lb drops

<i>RXLBPCKTS</i>	(Optional) rx lb packets
<i>RXLBDROP</i>	(Optional) rx lb drop
TABLE_VFCSTAT	(Optional) VFC Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPCKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
TABLE_VFCPOSTAT	(Optional) VFC po Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPCKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
TABLE_VFCSLOTSTAT	(Optional) VFC slot Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops

<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop

Command Mode

- /exec

show fc2 port state

```
show fc2 port state [ __readonly__ [ TABLE_FCPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [
<UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME> ] + [ <DOWN_STRING>
] + [ <DOWN_TIME> ] + [ <DOWN_REFTIME> ] + ] ] ] [ TABLE_VFCPORTSTATE [ <PORT_STRING>
] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME>
] + [ <DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFTIME> ] + ] ] ] [
TABLE_VFCPOPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [
<UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME> ] + [ <DOWN_STRING> ] + [ <DOWN_TIME>
] + [ <DOWN_REFTIME> ] + ] ] ] [ TABLE_VFCPORTSLOTSTATE [ <PORT_STRING> ] [ <PORT_NO>
] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME> ] + [
<DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFTIME> ] + ] ] ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
port	show fc2 physical port table
state	display port state history
__readonly__	(Optional) Read only
TABLE_FCPORTSTATE	(Optional) fc port state change history
PORT_STRING	(Optional) port name
PORT_NO	(Optional) port number
UP_DOWN_CNTR	(Optional) up-down counter
UP_STRING	(Optional) up
UP_TIME	(Optional) up time
UP_REFTIME	(Optional) up from
DOWN_STRING	(Optional) down string
DOWN_TIME	(Optional) down time
DOWN_REFTIME	(Optional) down from
TABLE_VFCPORTSTATE	(Optional) vfc port state change history
PORT_STRING	(Optional) port name
PORT_NO	(Optional) port number
UP_DOWN_CNTR	(Optional) up-down counter
UP_STRING	(Optional) up

<i>UP_TIME</i>	(Optional) up time
<i>UP_REFTIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFTIME</i>	(Optional) down from
TABLE_VFCPOPORSTATE	(Optional) vfc po port state change history
<i>PORT_STRING</i>	(Optional) port name
<i>PORT_NO</i>	(Optional) port number
<i>UP_DOWN_CNTR</i>	(Optional) up-down counter
<i>UP_STRING</i>	(Optional) up
<i>UP_TIME</i>	(Optional) up time
<i>UP_REFTIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFTIME</i>	(Optional) down from
TABLE_VFCPORTSLOTSTATE	(Optional) vfc port slot state change history
<i>PORT_STRING</i>	(Optional) port name
<i>PORT_NO</i>	(Optional) port number
<i>UP_DOWN_CNTR</i>	(Optional) up-down counter
<i>UP_STRING</i>	(Optional) up
<i>UP_TIME</i>	(Optional) up time
<i>UP_REFTIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFTIME</i>	(Optional) down from

Command Mode

- /exec

show fc2 socket

```
show fc2 socket [ __readonly__ { TABLE_fc2socket <SOCKET> <REFCNT> <PROTOCOL> <FLAGS>
<PID> <RCVBUF> <RMEM_USED> <QLEN> <NOTSK> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
socket	show fc2 active sockets
__readonly__	(Optional) Read only
TABLE_fc2socket	(Optional) show fc2 socket
<i>SOCKET</i>	(Optional) socket
<i>REFCNT</i>	(Optional) refcnt
<i>PROTOCOL</i>	(Optional) protocol
<i>FLAGS</i>	(Optional) flags
<i>PID</i>	(Optional) pid
<i>RCVBUF</i>	(Optional) rcvbuf
<i>RMEM_USED</i>	(Optional) rmem_used
<i>QLEN</i>	(Optional) qlen
<i>NOTSK</i>	(Optional) not_sk

Command Mode

- /exec

show fc2 sockexch

```
show fc2 sockexch [ __readonly__ { TABLE_fc2sockexch <SOCKET> <VSAN> <X_ID> <OX_ID>
<RX_ID> <O_ID> <R_ID> <ESTAT> <STATE> <CS> <TYPE> <SK> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
sockexch	show fc2 active exchanges for each socket
__readonly__	(Optional) Read only
TABLE_fc2sockexch	(Optional) show fc2 sockexch
SOCKET	(Optional) socket
VSAN	(Optional) vsan
X_ID	(Optional) x_id
OX_ID	(Optional) oxid
RX_ID	(Optional) rxid
O_ID	(Optional) o_id
R_ID	(Optional) r_id
ESTAT	(Optional) estat
STATE	(Optional) state
CS	(Optional) cs
TYPE	(Optional) type
SK	(Optional) sk

Command Mode

- /exec

show fc2 socknotify

```
show fc2 socknotify [ __readonly__ { TABLE_fc2socknotify <SOCKET> <ADDRESS> <REF> <VSAN>
<D_ID> <MASK> <FL> <ST> <IFINDEX> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
socknotify	show fc2 local nport plogi/logo notifications per each socket
__readonly__	(Optional) Read only
TABLE_fc2socknotify	(Optional) show fc2 socknotify
SOCKET	(Optional) socket
ADDRESS	(Optional) address
REF	(Optional) ref
VSAN	(Optional) vsan
D_ID	(Optional) d_id
MASK	(Optional) mask
FL	(Optional) fl
ST	(Optional) st
IFINDEX	(Optional) ifindex

Command Mode

- /exec

show fc2 socknport

```
show fc2 socknport [ __readonly__ { TABLE_fc2socknport <SOCKET> <ADDRESS> <REF> <VSAN>
<D_ID> <MASK> <FL> <ST> <IFINDEX> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
socknport	show fc2 local nports per each socket
__readonly__	(Optional) Read only
TABLE_fc2socknport	(Optional) show fc2 socknport
<i>SOCKET</i>	(Optional) socket
<i>ADDRESS</i>	(Optional) address
<i>REF</i>	(Optional) ref
<i>VSAN</i>	(Optional) vsan
<i>D_ID</i>	(Optional) d_id
<i>MASK</i>	(Optional) mask
<i>FL</i>	(Optional) fl
<i>ST</i>	(Optional) st
<i>IFINDEX</i>	(Optional) ifindex

Command Mode

- /exec

show fc2 vsan

```
show fc2 vsan [ __readonly__ { TABLE_fc2vsan <VSAN> <X_ID> <E_D_TOV> <R_A_TOV> <WWN>
<IOP_MODE> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
vsan	show fc2 vsan table
__readonly__	(Optional) Read only
TABLE_fc2vsan	(Optional) show fc2 vsan
<i>VSAN</i>	(Optional) vsan
<i>X_ID</i>	(Optional) xid
<i>E_D_TOV</i>	(Optional) e_d_tov
<i>R_A_TOV</i>	(Optional) r_a_tov
<i>WWN</i>	(Optional) wwn
<i>IOP_MODE</i>	(Optional) iop_mode

Command Mode

- /exec

show fcdroplateny

```
show fcdroplateny [ { network | switch } ] [ __readonly__ [ <switch_latency> ] [ <global_network_latency> ] ] [ TABLE_vsan_network_latency { <vsan-no> <network-latency> } ] ]
```

Syntax Description

show	Show running system information
fcdroplateny	show switch or network latency
network	(Optional) network latency in milliseconds
switch	(Optional) switch latency in milliseconds
__readonly__	(Optional)
<i>switch_latency</i>	(Optional) Switch latency value
<i>global_network_latency</i>	(Optional) global network latency value
TABLE_vsan_network_latency	(Optional) VSAN specific network latency settings
<i>vsan-no</i>	(Optional) vsan number
<i>network-latency</i>	(Optional) VSAN specific network latency

Command Mode

- /exec

show fcoe-npv issu-impact

```
show fcoe-npv issu-impact [ __readonly__ { <is_impact> } [ TABLE_interface <vfc_intf> <fc_id> ] ]
```

Syntax Description

show	Show running system information
fcoe-npv	feature fcoe-npv
issu-impact	Show feature fcoe-npv config issues if attempting to do non-disruptive ISSU
__readonly__	(Optional) Read Only
<i>is_impact</i>	(Optional) show issu impact
TABLE_interface	(Optional) show fcoe database
<i>vfc_intf</i>	(Optional) vfc port Interface index
<i>fc_id</i>	(Optional) vfc port FCID

Command Mode

- /exec

show fcoe

```
show fcoe [ __readonly__ { TABLE_fcf <fcf_if_index> <fcf_mac> <fc_map> <fcf_priority>
<fka_Advertisement> } [ TABLE_vfc <vfc_name> <vfcf_mac> ] ]
```

Syntax Description

show	Show running system information
fcoe	Show FCOE paramaters
__readonly__	(Optional) Read Only
TABLE_fcf	(Optional) fcf table
<i>fcf_if_index</i>	(Optional) fcf if index
<i>fcf_mac</i>	(Optional) fcf mac
<i>fc_map</i>	(Optional) fc map
<i>fcf_priority</i>	(Optional) fcf priority
<i>fka_Advertisement</i>	(Optional) fka Advertisement
TABLE_vfc	(Optional) vfc details table for sup
<i>vfc_name</i>	(Optional) vfc name
<i>vfcf_mac</i>	(Optional) vfcf mac

Command Mode

- /exec

show fcoe database

```
show fcoe database [ __readonly__ { TABLE_interface <interface> [ <fcid> ] [ <port_name> ] <mac_address>
} <flogi_count> [ TABLE_veport <interface> <mac_address> <vsan> ] ]
```

Syntax Description

show	Show running system information
fcoe	Show FCOE paramaters
database	Show FCOE database
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show fcoe database
<i>fcid</i>	(Optional) fcid
<i>port_name</i>	(Optional) port name
<i>mac_address</i>	(Optional) mac address
<i>interface</i>	(Optional) ve port Interface index
TABLE_veport	(Optional) ve port details
<i>mac_address</i>	(Optional) ve port mac address
<i>flogi_count</i>	(Optional) flogi_count
<i>vsan</i>	(Optional) ve port VSAN trunking

Command Mode

- /exec

show fctimer

```
show fctimer [ __readonly__ { <F_S_TOV> <D_S_TOV> <E_D_TOV> <R_A_TOV> } ]
```

Syntax Description

show	show running system information
fctimer	show Fibre Channel timers
__readonly__	(Optional) Read only
<i>F_S_TOV</i>	(Optional) F_S_TOV
<i>D_S_TOV</i>	(Optional) D_S_TOV
<i>E_D_TOV</i>	(Optional) E_D_TOV
<i>R_A_TOV</i>	(Optional) R_A_TOV

Command Mode

- /exec

show fctimer D_S_TOV

```
show fctimer D_S_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_D_S_TOV [ <vsan-no> ] <D_S_TOV> ] [
<non-exist-vsan> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
D_S_TOV	D_S_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
__readonly__	(Optional)
TABLE_D_S_TOV	(Optional) table D_S_TOV
<i>vsan-no</i>	(Optional) vsan number
<i>D_S_TOV</i>	(Optional) D_S_TOV
<i>non-exist-<i>vsan</i></i>	(Optional) non configured vsans

Command Mode

- /exec

show fctimer E_D_TOV

```
show fctimer E_D_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_E_D_TOV [ <vsan-no> ] <E_D_TOV> ] [ <non-exist-vsan> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
E_D_TOV	E_D_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
<i>__readonly__</i>	(Optional)
TABLE_E_D_TOV	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>E_D_TOV</i>	(Optional) E_D_TOV
<i>non-exist-<i>vsan</i></i>	(Optional) not exist vsans

Command Mode

- /exec

show fctimer F_S_TOV

```
show fctimer F_S_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_F_S_TOV [ <vsan-no> ] <F_S_TOV> ] [ <non-exist-vsan> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
F_S_TOV	F_S_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
<i>__readonly__</i>	(Optional)
TABLE_F_S_TOV	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>F_S_TOV</i>	(Optional) F_S_TOV
<i>non-exist-<i>vsan</i></i>	(Optional) not exist vsans

Command Mode

- /exec

show fctimer R_A_TOV

```
show fctimer R_A_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_R_A_TOV [ <vsan-no> ] <R_A_TOV> ] [ <non-exist-vsan> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
R_A_TOV	R_A_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
__readonly__	(Optional)
TABLE_R_A_TOV	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>R_A_TOV</i>	(Optional) R_A_TOV
<i>non-exist-<i>vsan</i></i>	(Optional) non exist vsans

Command Mode

- /exec

show fctimer last action status

```
show fctimer last action status [ __readonly__ [ <vsan> ] <last_action_timestamp> <last_action>
<last_action_result> <last_action_failure_reason> ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
last	Show the status of the last cfs commit/abort operation
action	Show the status of the last cfs commit/abort operation
status	Show the status of the last cfs commit/abort operation
<i>__readonly__</i>	(Optional) Readonly
<i>vsan</i>	(Optional) Vsan
<i>last_action_timestamp</i>	(Optional) Last action timestamp
<i>last_action</i>	(Optional) Last action
<i>last_action_result</i>	(Optional) Last action result
<i>last_action_failure_reason</i>	(Optional) Last action failure reason

Command Mode

- /exec

show fctimer pending-diff

```
show fctimer pending-diff [ __readonly__ <status_fctimer> ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
pending-diff	Show the difference between pending database and running config
__readonly__	(Optional)
<i>status_fctimer</i>	(Optional) Show the difference between pending database and running config

Command Mode

- /exec

show fctimer pending

show fctimer pending [__readonly__ <status_fctimer>]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
pending	Show the status of pending fctimer commands
__readonly__	(Optional)
<i>status_fctimer</i>	(Optional) Show the status of pending fctimer commands

Command Mode

- /exec

show fctimer session status

```
show fctimer session status [ __readonly__ [ <vsan> ] <last_action_timestamp> <last_action>
<last_action_result> <last_action_failure_reason> ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
session	Show the state of fctimer cfs session
status	Show the status of the last cfs commit/abort operation
<i>__readonly__</i>	(Optional) Readonly
<i>vsan</i>	(Optional) Vsan
<i>last_action_timestamp</i>	(Optional) Last action timestamp
<i>last_action</i>	(Optional) Last action
<i>last_action_result</i>	(Optional) Last action result
<i>last_action_failure_reason</i>	(Optional) Last action failure reason

Command Mode

- /exec

show fctimer status

show fctimer status [__readonly__ <Distribution>]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
status	cfs distribution is enabled or disabled
__readonly__	(Optional) read only
<i>Distribution</i>	(Optional) distribution

Command Mode

- /exec

show fctimer vsan

```
show fctimer vsan <i0> [ __readonly__ { TABLE_fctimer <vsan-no> <F_S_TOV> <D_S_TOV> <E_D_TOV>
<R_A_TOV> } [ <non-exist-vsans> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
vsan	Specify VSAN id
<i>i0</i>	VSAN id range
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_fctimer</i>	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>F_S_TOV</i>	(Optional) F_S_TOV
<i>D_S_TOV</i>	(Optional) D_S_TOV
<i>E_D_TOV</i>	(Optional) E_D_TOV
<i>R_A_TOV</i>	(Optional) R_A_TOV
<i>non-exist-vsans</i>	(Optional) non exist vsans

Command Mode

- /exec

show feature-set

```
show feature-set [ <name> ] [ <id> ] [ __readonly__ TABLE_cfcFeatureSetTable <cfcFeatureSetIndex>
<cfcFeatureSetName> <cfcFeatureSetAction> <cfcFeatureSetLastAction> <cfcFeatureSetLastActionResult>
<cfcFeatureSetLastFailureReason> <cfcFeatureSetOpStatus> <cfcFeatureSetOpStatusReason> ]
```

Syntax Description

show	Show running system information
feature-set	Show feature set status
<i>name</i>	(Optional) feature-set name
<i>id</i>	(Optional) feature-set id
<i>__readonly__</i>	(Optional)
<i>TABLE_cfcFeatureSetTable</i>	(Optional) feature-set table
<i>cfcFeatureSetIndex</i>	(Optional) feature-set table index
<i>cfcFeatureSetName</i>	(Optional) feature-set name
<i>cfcFeatureSetAction</i>	(Optional) action
<i>cfcFeatureSetLastAction</i>	(Optional) last action
<i>cfcFeatureSetLastActionResult</i>	(Optional) last action result
<i>cfcFeatureSetLastFailureReason</i>	(Optional) last failure reason
<i>cfcFeatureSetOpStatus</i>	(Optional) operation status
<i>cfcFeatureSetOpStatusReason</i>	(Optional) operation status

Command Mode

- /exec

show feature-set services

```
show feature-set services <s0> [ __readonly__ [ { TABLE_services <service_name> } ] { <count>
<feature_set> } ]
```

Syntax Description

show	Show running system information
feature-set	Show feature set status
services	Show services in feature set
<i>__readonly__</i>	(Optional)
<i>TABLE_services</i>	(Optional) all service names in feature set
<i>service_name</i>	(Optional) name of the service
<i>count</i>	(Optional) number of services in the feature set
<i>feature_set</i>	(Optional) feature set name
<i>s0</i>	Name of feature set

Command Mode

- /exec

show feature

```
show feature [ __readonly__ [ { TABLE_cfcFeatureCtrlTable <cfcFeatureCtrlIndex2>
<cfcFeatureCtrlInstanceNum2> <cfcFeatureCtrlName2> <cfcFeatureCtrlAction2> <cfcFeatureCtrlLastAction2>
<cfcFeatureCtrlLastActionResult2> <cfcFeatureCtrlLastFailureReason2> <cfcFeatureCtrlOpStatus2>
<cfcFeatureCtrlOpStatusReason2> <cfcFeatureCtrlTag2> } ] ]
```

Syntax Description

show	Show running system information
feature	Show feature status
__readonly__	(Optional)
TABLE_cfcFeatureCtrlTable	(Optional) feature table
<i>cfcFeatureCtrlIndex2</i>	(Optional) feature table index
<i>cfcFeatureCtrlInstanceNum2</i>	(Optional) instance number
<i>cfcFeatureCtrlName2</i>	(Optional) feature name
<i>cfcFeatureCtrlAction2</i>	(Optional) Action to be triggered for the feature
<i>cfcFeatureCtrlLastAction2</i>	(Optional) Last action triggered for the feature
<i>cfcFeatureCtrlLastActionResult2</i>	(Optional) The result of execution of the last action
<i>cfcFeatureCtrlLastFailureReason2</i>	(Optional) Failure Reason
<i>cfcFeatureCtrlOpStatus2</i>	(Optional) operation status
<i>cfcFeatureCtrlOpStatusReason2</i>	(Optional) Reason for current operation status
<i>cfcFeatureCtrlTag2</i>	(Optional) Name of the instance in string format in case of multinstance feature

Command Mode

- /exec

show fhrp

```
show fhrp [ <intf> ] [ __readonly__ { TABLE_brief <intf_name> <intf_state> <ipv4_state> <ipv6_state>
<hardware_status> <refcount> } ]
```

Syntax Description

<code>fhrp</code>	FHRP Show commands
<code>show</code>	Show running system information
<code>intf</code>	(Optional) Specify a single interface
<code>__readonly__</code>	(Optional)
<code>TABLE_brief</code>	(Optional) Show brief FHRP interface information
<code>intf_name</code>	(Optional) Interface name
<code>intf_state</code>	(Optional) Interface state
<code>ipv4_state</code>	(Optional) Interface IPv4 state
<code>ipv6_state</code>	(Optional) Interface IPv6 state
<code>hardware_status</code>	(Optional) Interface hardware status
<code>refcount</code>	(Optional) Interface refcount

Command Mode

- /exec

show fhrp verbose

```
show fhrp [ <intf> ] verbose [ __readonly__ { TABLE_det <intf_name> <handle> <refcount> { TABLE_clients
<client_id> <client_name> } <running> <expired> <v_retries> <v_time> <r_delay> <min_delay>
<remaining_delay> <i_state> <ipv4_state> <ipv6_state> <h_state> <int_l2> } ]
```

Syntax Description

fhrp	FHRP Show commands
show	Show running system information
<i>intf</i>	(Optional) Specify a single interface
verbose	Display detailed information
<i>__readonly__</i>	(Optional)
TABLE_det	(Optional) Detailed FHRP interface information
<i>intf_name</i>	(Optional) Interface name
<i>handle</i>	(Optional) Interface handle
<i>refcount</i>	(Optional) Reference count
TABLE_clients	(Optional) FHRP clients present on interface
<i>client_id</i>	(Optional) FHRP client id
<i>client_name</i>	(Optional) FHRP client name
<i>running</i>	(Optional) Time verify up timer running
<i>expired</i>	(Optional) Verify up timer has expired
<i>v_retries</i>	(Optional) Verify retries
<i>v_time</i>	(Optional) Verify remaining time
<i>r_delay</i>	(Optional) Reload delay
<i>min_delay</i>	(Optional) Min delay
<i>remaining_delay</i>	(Optional) Remaining delay
<i>i_state</i>	(Optional) Interface state
<i>ipv4_state</i>	(Optional) Interface IPv4 state
<i>ipv6_state</i>	(Optional) Interface IPv6 state
<i>h_state</i>	(Optional) Interface hardware state
<i>int_l2</i>	(Optional) Interface is L2-only

Command Mode

- /exec

show file

```
show file <uri0> [ cksum | md5sum | sha256sum | sha512sum ] [ __readonly__ { [ <file_content> ] + [ <file_content_cksum> ] [ <file_content_md5sum> ] [ <file_content_sha256sum> ] [ <file_content_sha512sum> ] } ]
```

Syntax Description

show	Show running system information
file	Displays content of files
<i>uri0</i>	Filename to be displayed
cksum	(Optional) Displays CRC checksum for a file
md5sum	(Optional) Displays MD5 checksum for a file
sha256sum	(Optional) Displays SHA256 checksum for a file
sha512sum	(Optional) Displays SHA512 checksum for a file
<i>__readonly__</i>	(Optional) Read only
<i>file_content</i>	(Optional) uri file content buffer string
<i>file_content_cksum</i>	(Optional) uri file content checksum
<i>file_content_md5sum</i>	(Optional) uri file content md5sum
<i>file_content_sha256sum</i>	(Optional) uri file content sha256sum
<i>file_content_sha512sum</i>	(Optional) uri file content sha512sum

Command Mode

- /exec

show fips status

```
show fips status [ __readonly__ { operation_status <o_status> } { mode_state <m_state> } [ TABLE_sessions
<lc_num> <lc_status> ] ]
```

Syntax Description

show	Show running system information
fips	Show if FIPS mode is enabled or disabled
status	Whether FIPS mode is enabled or disabled
__readonly__	(Optional)
operation_status	(Optional) run-time information about fips
<i>o_status</i>	(Optional) operational status of fips
mode_state	(Optional) mode state
<i>m_state</i>	(Optional) fips or non-fips state
TABLE_sessions	(Optional) all lc status
<i>lc_num</i>	(Optional) the lc number
<i>lc_status</i>	(Optional) the lc status

Command Mode

- /exec

show flow cache

```
show flow cache [ ipv4 | ipv6 | ce ] [ __readonly__ ] [ { TABLE_flow_cache <flow-cache-index> [ <flow-type> ] [ <source-ip> ] [ <destination-ip> ] [ <source-mac> ] [ <destination-mac> ] [ <bridge-domain-id> ] [ <ether-type> ] [ <source-port> ] [ <destination-port> ] [ <protocol> ] [ <ipv6-flowlabel> ] [ <byte-count> ] [ <packet-count> ] [ <tcp-flags> ] [ <tos> ] [ <if-id> ] [ <output-if-id> ] [ <flow-start> ] [ <flow-end> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
cache	Show NetFlow Exporter Cache
ipv4	(Optional) Show ipv4 cache entries
ipv6	(Optional) Show ipv6 cache entries
ce	(Optional) Show ce cache entries
__readonly__	(Optional)
TABLE_flow_cache	(Optional) The XML flow cache table
<i>flow-cache-index</i>	(Optional) Flow Index
<i>flow-type</i>	(Optional) Flow type - v4,v6 or MAC
<i>source-ip</i>	(Optional) Source IP
<i>destination-ip</i>	(Optional) Destination IP
<i>source-mac</i>	(Optional) Source MAC
<i>destination-mac</i>	(Optional) Destination MAC
<i>bridge-domain-id</i>	(Optional) Bridge Domain ID
<i>ether-type</i>	(Optional) Ether Type
<i>source-port</i>	(Optional) Source Port
<i>destination-port</i>	(Optional) Destination Port
<i>protocol</i>	(Optional) Protocol
<i>ipv6-flowlabel</i>	(Optional) Ipv6 flowlabel
<i>byte-count</i>	(Optional) Byte Count
<i>packet-count</i>	(Optional) Packet Count
<i>tcp-flags</i>	(Optional) TCP Flags

<i>tos</i>	(Optional) TOS
<i>if-id</i>	(Optional) IF ID
<i>output-if-id</i>	(Optional) OUTPUT IF ID
<i>flow-start</i>	(Optional) Flow Start Time
<i>flow-end</i>	(Optional) Flow End Time

Command Mode

- /exec

show flow cache

```
show flow cache [ ipv4 | ipv6 | ce ] [ __readonly__ TABLE_flow_cache <flow-type> <source-ip>
<destination-ip> <bridge-domain-id> <source-port> <destination-port> <protocol> <ipv6-flowlabel>
<byte-count> <packet-count> <tcp-flags> <tos> <if-id> <flow-start> <flow-end> <source-mac>
<destination-mac> <ether-type> ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
cache	Show NetFlow Exporter Cache
ipv4	(Optional) Show ipv4 cache entries
ipv6	(Optional) Show ipv6 cache entries
ce	(Optional) Show ce cache entries
__readonly__	(Optional)
TABLE_flow_cache	(Optional) The XML flow cache table
<i>flow-type</i>	(Optional) Flow type - v4,v6 or MAC
<i>source-ip</i>	(Optional) Source IP
<i>destination-ip</i>	(Optional) Destination IP
<i>bridge-domain-id</i>	(Optional) Bridge Domain ID
<i>source-port</i>	(Optional) Source Port
<i>destination-port</i>	(Optional) Destination Port
<i>protocol</i>	(Optional) Protocol
<i>ipv6-flowlabel</i>	(Optional) Ipv6 flowlabel
<i>byte-count</i>	(Optional) Byte Count
<i>packet-count</i>	(Optional) Packet Count
<i>tcp-flags</i>	(Optional) TCP Flags
<i>tos</i>	(Optional) TOS
<i>if-id</i>	(Optional) IF ID
<i>flow-start</i>	(Optional) Flow Start Time
<i>flow-end</i>	(Optional) Flow End Time

<i>source-mac</i>	(Optional) Source MAC
<i>destination-mac</i>	(Optional) Destination MAC
<i>ether-type</i>	(Optional) Ether Type

Command Mode

- /exec

show flow exporter

```
show flow exporter [ name ] [ <exporter> ] [ __readonly__ { TABLE_flow_exporter <exporter> <description>
<dest> <vrf> <vrf_id> <vrf_resolved> <dest_udp> <source_intf> <source_ip> <dscp> <exp_vers> <seqnum>
<samp_table_to> <if_table_to> <stats_to> <temp_to> <rec_sent> <temp_sent> <pkts_sent> <bytes_sent>
<dest_unreach> <buff_events> <pkts_drop_no_route> <pkts_drop_other> <pkts_drop_lc_rp>
<pkts_drop_op_drops> <time_last_cleared> } ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
exporter	Show NetFlow Exporter Configuration and Statistics
name	(Optional) Show a specific Flow Exporter
<i>exporter</i>	(Optional) Specify an exporter
<i>__readonly__</i>	(Optional)
TABLE_flow_exporter	(Optional)
<i>exporter</i>	(Optional)
<i>description</i>	(Optional)
<i>dest</i>	(Optional)
<i>vrf</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_resolved</i>	(Optional)
<i>dest_udp</i>	(Optional)
<i>source_intf</i>	(Optional)
<i>source_ip</i>	(Optional)
<i>dscp</i>	(Optional)
<i>seqnum</i>	(Optional)
<i>exp_vers</i>	(Optional)
<i>samp_table_to</i>	(Optional)
<i>if_table_to</i>	(Optional)
<i>stats_to</i>	(Optional)
<i>temp_to</i>	(Optional)

<i>rec_sent</i>	(Optional)
<i>temp_sent</i>	(Optional)
<i>pkts_sent</i>	(Optional)
<i>bytes_sent</i>	(Optional)
<i>dest_unreach</i>	(Optional)
<i>buff_events</i>	(Optional)
<i>pkts_drop_no_route</i>	(Optional)
<i>pkts_drop_other</i>	(Optional)
<i>pkts_drop_lc_rp</i>	(Optional)
<i>pkts_drop_op_drops</i>	(Optional)
<i>time_last_cleared</i>	(Optional)

Command Mode

- /exec

show flow interface

```
show flow { interface [ <intf> ] | vlan [ <vlan> ] } [ __readonly__ [ { TABLE_flow_interface [ <intf_name> ] [ <vlan_id> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [ <v4in_profile_id> ] [ <v6in_mon_name> ] [ <v6in_direction> ] [ <v6in_profile_id> ] [ <l2in_mon_name> ] [ <l2in_direction> ] [ <l2in_profile_id> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
interface	Flow interface information
<i>intf</i>	(Optional) Interface
vlan	Flow vlan information
<i>vlan</i>	(Optional) Vlan number
<i>__readonly__</i>	(Optional)
TABLE_flow_interface	(Optional) flow interface data
<i>intf_name</i>	(Optional) Interface
<i>vlan_id</i>	(Optional) VLAN ID
<i>v4in_mon_name</i>	(Optional) IPv4 Input monitor name
<i>v4in_direction</i>	(Optional) IPv4 Input direction
<i>v4in_profile_id</i>	(Optional) IPv4 Input profile id
<i>v6in_mon_name</i>	(Optional) IPv6 Input monitor name
<i>v6in_direction</i>	(Optional) IPv6 Input direction
<i>v6in_profile_id</i>	(Optional) IPv6 Input profile id
<i>l2in_mon_name</i>	(Optional) l2 Input monitor name
<i>l2in_direction</i>	(Optional) l2 Input direction
<i>l2in_profile_id</i>	(Optional) l2 Input profile id

Command Mode

- /exec

show flow monitor

```
show flow monitor [ name ] [ <monitor> [ cache [ detailed ] ] ] [ __readonly__ [ { TABLE_flow_monitor
<monitor> <use_count> [ <description> ] <record> <exporter1> <exporter2> <bucket_id> <src_addr>
<dest_addr> <direction> <pkt_count> <byte_count> } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
monitor	Show Monitor Configuration
name	(Optional) Show a specific Flow Monitor
<i>monitor</i>	(Optional) Specify a monitor
cache	(Optional) Flow monitor cache contents
detailed	(Optional) Show the entire cache contents
<i>__readonly__</i>	(Optional)
TABLE_flow_monitor	(Optional)
<i>monitor</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>record</i>	(Optional)
<i>exporter1</i>	(Optional)
<i>exporter2</i>	(Optional)
<i>bucket_id</i>	(Optional)
<i>src_addr</i>	(Optional)
<i>dest_addr</i>	(Optional)
<i>direction</i>	(Optional)
<i>pkt_count</i>	(Optional)
<i>byte_count</i>	(Optional)

Command Mode

- /exec

show flow record

```
show flow record [ name ] [ { <record> } | { netflow-original } | { netflow { protocol-port | layer2-switched
{ input } | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ [ { TABLE_flow_record <record> [
<description> ] <use_count> <template> [ <match_ip_src> ] [ <match_ip_dst> ] [ <match_proto> ] [
<match_tos> ] [ <match_l4_src> ] [ <match_l4_dst> ] [ <match_ingress> ] [ <match_egress> ] [
<match_src_as_peer> ] [ <match_dst_as_peer> ] [ <match_ipv6_src> ] [ <match_ipv6_dst> ] [
<match_ipv6_flow> ] [ <match_ipv6_option> ] [ <match_ipv6_traffic> ] [ <match_l2_src> ] [ <match_l2_dst>
] [ <match_l2_src_vlan> ] [ <match_l2_dst_vlan> ] [ <match_l2_lq> ] [ <match_l2_cos> ] [ <match_l2_etype>
] [ <match_flow_dir_match> ] [ <match_ipv4v6_src> ] [ <match_ipv4v6_dst> ] [ <collect_src_as> ] [
<collect_dst_as> ] [ <collect_src_as_peer> ] [ <collect_dst_as_peer> ] [ <collect_fwd_status> ] [
<collect_ipv4_next_hop> ] [ <collect_ipv4_bgp_next> ] [ <collect_ipv6_next_hop> ] [
<collect_ipv6_bgp_next> ] [ <collect_tcp_flags> ] [ <collect_flow_dir> ] [ <collect_bytes> ] [
<collect_bytes_long> ] [ <collect_packets> ] [ <collect_packets_long> ] [ <collect_time_first> ] [
<collect_time_last> ] [ <collect_ingress_coll> ] [ <collect_egress_coll> ] [ <collect_sampler_id> ] [
<collect_ip_ver> ] [ <collect_packet_disp> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
record	Show Record Configuration
name	(Optional) Show the configuration for a specific Flow Record
<i>record</i>	(Optional) Specify a record
netflow-original	(Optional) Traditional IPv4 input NetFlow with origin ASs
netflow	(Optional) Traditional NetFlow collection schemes
ipv4	(Optional) IPv4 collection schemes
ipv6	(Optional) IPv6 collection schemes
l2	(Optional) L2 collection schemes
layer2-switched	(Optional) Layer2-Switched collection schemes
original-input	(Optional) Input NetFlow
input	(Optional) Input NetFlow
protocol-port	(Optional) Protocol and Ports aggregation scheme
__readonly__	(Optional)
TABLE_flow_record	(Optional) flow record data
<i>record</i>	(Optional)
<i>description</i>	(Optional)

<i>use_count</i>	(Optional)
<i>template</i>	(Optional)
<i>match_ip_src</i>	(Optional)
<i>match_ip_dst</i>	(Optional)
<i>match_proto</i>	(Optional)
<i>match_tos</i>	(Optional)
<i>match_l4_src</i>	(Optional)
<i>match_l4_dst</i>	(Optional)
<i>match_ingress</i>	(Optional)
<i>match_egress</i>	(Optional)
<i>match_src_as_peer</i>	(Optional)
<i>match_dst_as_peer</i>	(Optional)
<i>match_ipv6_src</i>	(Optional)
<i>match_ipv6_dst</i>	(Optional)
<i>match_ipv6_flow</i>	(Optional)
<i>match_ipv6_option</i>	(Optional)
<i>match_ipv6_traffic</i>	(Optional)
<i>match_l2_src</i>	(Optional)
<i>match_l2_dst</i>	(Optional)
<i>match_l2_src_vlan</i>	(Optional)
<i>match_l2_dst_vlan</i>	(Optional)
<i>match_l2_lq</i>	(Optional)
<i>match_l2_cos</i>	(Optional)
<i>match_l2_etype</i>	(Optional)
<i>match_flow_dir_match</i>	(Optional)
<i>match_ipv4v6_src</i>	(Optional)
<i>match_ipv4v6_dst</i>	(Optional)
<i>collect_src_as</i>	(Optional)
<i>collect_dst_as</i>	(Optional)

<i>collect_src_as_peer</i>	(Optional)
<i>collect_dst_as_peer</i>	(Optional)
<i>collect_fwd_status</i>	(Optional)
<i>collect_ipv4_next_hop</i>	(Optional)
<i>collect_ipv4_bgp_next</i>	(Optional)
<i>collect_ipv6_next_hop</i>	(Optional)
<i>collect_ipv6_bgp_next</i>	(Optional)
<i>collect_tcp_flags</i>	(Optional)
<i>collect_flow_dir</i>	(Optional)
<i>collect_bytes</i>	(Optional)
<i>collect_bytes_long</i>	(Optional)
<i>collect_packets</i>	(Optional)
<i>collect_packets_long</i>	(Optional)
<i>collect_time_first</i>	(Optional)
<i>collect_time_last</i>	(Optional)
<i>collect_ingress_coll</i>	(Optional)
<i>collect_egress_coll</i>	(Optional)
<i>collect_sampler_id</i>	(Optional)
<i>collect_ip_ver</i>	(Optional)
<i>collect_packet_disp</i>	(Optional)

Command Mode

- /exec

show flow timeout

```
show flow timeout [ __readonly__ [ <active_to> ] [ <inactive_to> ] [ <fast_to> ] [ <th_pkts> ] [ <agg_age_to> ] [ <flush_cache_to> ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
timeout	Show NetFlow flow cache timeout values
<i>__readonly__</i>	(Optional)
<i>active_to</i>	(Optional)
<i>inactive_to</i>	(Optional)
<i>fast_to</i>	(Optional)
<i>th_pkts</i>	(Optional)
<i>agg_age_to</i>	(Optional)
<i>flush_cache_to</i>	(Optional)

Command Mode

- /exec

show flow tracer

show flow tracer

Syntax Description

show	Show running system information
flow	Show NetFlow information
tracer	Show packet tracer information

Command Mode

- /exec

show forwarding

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ table <table_id> ] [ ipv4 ] [ route |
mhdb ] [ recursive ] [ summary ] [ [ detail | platform | partial | ipsg ] [ max-display-count <display_count> ]
] | [ <prefix> [ longer-prefixes ] [ detail | platform ] ] <address> [ detail | platform ] |
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table id in hex
ipv4	(Optional) ipv4
route	(Optional) display IP routing table
ipsg	(Optional) display IPv4 IPSG routes
mhdb	(Optional) rnh-db
recursive	(Optional) display routes with recursive next hops
partial	(Optional) display routes with partial ECMPs
summary	(Optional) display route counts
<i>prefix</i>	(Optional) display single exact match route
longer-prefixes	(Optional) display longer prefixes
<i>address</i>	(Optional) display single longest match route
detail	(Optional) show detailed information about the routes
platform	(Optional) one command to show pi and pd info together
max-display-count	(Optional) displays max # of routes
<i>display_count</i>	(Optional) count

Command Mode

- /exec

show forwarding adjacency

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ipv4 ] adjacency [ mpls ] [ lisp ] [
nve ] [ <aif> ] [ <anh> ] [ detail | stats | platform ] [ module <module> ] [ __readonly__ [ <adj-count> ] [
TABLE_adj { <fec> <nexthop> <rewinfo> <interface> <bgp_rnh> <bgp_orig_as> <bgp_peer_as> <pkts>
<bytes> <exp> <src_addr> <dest_addr> <lisp_flags> <lisp_inst_id> <pltfm_key> <hh> <refcount> } ] [
TABLE_ip_adjacency { [ <nh> ] [ <rwinfo> ] [ <intf> ] [ <intf_idx> ] [ <hhandle> ] [ <refcnt> ] [ <flags> ]
[ <holder> ] [ <pbr_cnt> ] [ <wccp_cnt> ] [ <rewrite-p> ] [ TABLE_index { [ <hw_adj> ] [ <cmn-idx> ] [
<lif> ] [ <buf-idx> } } ] ] ] ] ] ]
```

Syntax Description

show	
forwarding	display fib information
ipv4	(Optional) ipv4
adjacency	display adjacency information
platform	(Optional) one command to show pi and pd info together
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
mpls	(Optional) mpls adjacency information
lisp	(Optional) LISP adjacency information
nve	(Optional) VxLAN tunnel adjacency information
<i>aif</i>	(Optional) adjacency output interface
<i>anh</i>	(Optional) adjacency next hop
detail	(Optional) detail
stats	(Optional) adjacency statistics
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>adj-count</i>	(Optional) total adj count
TABLE_adj	(Optional) Table Adjacency
<i>fec</i>	(Optional) FEC info

<i>nexthop</i>	(Optional) next hop address
<i>rewinfo</i>	(Optional) rewrite information
<i>interface</i>	(Optional) output interface
<i>bgp_rnh</i>	(Optional) next hop address
<i>bgp_orig_as</i>	(Optional) bgp orig as
<i>bgp_peer_as</i>	(Optional) bgp peer as
<i>exp</i>	(Optional) exp mapping
<i>pkts</i>	(Optional) packet stats
<i>bytes</i>	(Optional) bytes stats
<i>src_addr</i>	(Optional) src address
<i>dest_addr</i>	(Optional) dest address
<i>lisp_flags</i>	(Optional) lisp flags
<i>lisp_inst_id</i>	(Optional) lisp instance id
<i>pltfm_key</i>	(Optional) platform key
<i>hh</i>	(Optional) Hardware Handle
<i>refcount</i>	(Optional) reference count
TABLE_ip_adjacency	(Optional) Table ip adjacency
<i>nh</i>	(Optional) next hop address
<i>rwinfo</i>	(Optional) rewrite information
<i>intf</i>	(Optional) output interface
<i>intf_idx</i>	(Optional) Interface index
<i>hhandle</i>	(Optional) Hw Handle
<i>refcnt</i>	(Optional) reference count
<i>flags</i>	(Optional) Adjacency flags
<i>holder</i>	(Optional) Holder bitmap
<i>pbr_cnt</i>	(Optional) PBR count
<i>wccp_cnt</i>	(Optional) WCCP count
<i>rewrite-p</i>	(Optional) Rewrite pointer
TABLE_index	(Optional) HW index table

<i>hw_adj</i>	(Optional) v4 adj hw index
<i>cmn-idx</i>	(Optional) CMN Index
<i>lif</i>	(Optional) LIF
<i>buf-idx</i>	(Optional) Buffer index

Command Mode

- /exec

show forwarding distribution clients

show forwarding distribution clients [__readonly__ <id><pid><name><shms><shme><shmn>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution info
clients	unicast client information
__readonly__	(Optional)

Command Mode

- /exec

show forwarding distribution fib-state

```
show forwarding distribution fib-state [ __readonly__ <slot> <state><ttc><tprc><tv4ac><tv6ac> {
TABLE_fib_state <tid><tafi><prc><pc><tname> } ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution info
fib-state	unicast fib state info
__readonly__	(Optional)
<i>slot</i>	(Optional) slot number
TABLE_fib_state	(Optional) fib-state table

Command Mode

- /exec

show forwarding distribution ip igmp snooping

```
show forwarding distribution ip igmp snooping [ vlan <vlan-id> [ group [ <grpaddr> | <mac-grpaddr> ] [
source <srcaddr> ] ] ] [ detail ] [ __readonly__ <refcount> <oiflist_id> <last_oiflist_id> <ftag-id> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
ip	IPV4 information
igmp	MFDM IGMP information
snooping	L2 mcast snooping related information
vlan	(Optional) Info specific to a vlan
<i>vlan-id</i>	(Optional) Vlan id value
group	(Optional) Group specific information
<i>grpaddr</i>	(Optional) Group address
<i>mac-grpaddr</i>	(Optional) Group MAC address
source	(Optional) (G,S) specific information
<i>srcaddr</i>	(Optional) Source address
detail	(Optional) Detailed display
<i>__readonly__</i>	(Optional)
<i>refcount</i>	(Optional) Reference Count
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>last_oiflist_id</i>	(Optional) Last OIF list Identifier
<i>ftag-id</i>	(Optional) ftag Id

Command Mode

- /exec

show forwarding distribution ipv6 multicast route

```
show forwarding distribution ipv6 multicast route [ table <table_id> | vrf <vrf-name> ] [ [ group { <group>
} ] [ source { <source> } ] | summary ] [ __readonly__ <table_type> <num_routes> <num_starg_routes>
<num_sg_routes> <num_gprefix_routes> <num_groups> <num_sources> <src_len> <grp_len> <df_ordinal>
<rpfit> <address> <flag> <route_pkts> <route_bytes> <mti_src_if> <mti_grp_ip> <mti_src_ip> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	display fib distribution information
ipv6	IPV6 related information
multicast	display IPv6 multicast information
route	display routing table
vrf	(Optional) display routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
table	(Optional) table
<i>table_id</i>	(Optional) table number
group	(Optional) Multicast IPv6 Group Address
source	(Optional) Multicast IPv6 Source Address
summary	(Optional) display route counts
__readonly__	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>address</i>	(Optional) Ipv6 address string
<i>src_len</i>	(Optional) Source Address Mask

<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>flag</i>	(Optional) Route type flag
<i>route_pkts</i>	(Optional) Route packet count
<i>route_bytes</i>	(Optional) Route bytes
<i>mti_src_if</i>	(Optional) MTI Source Ifindex
<i>mti_grp_ip</i>	(Optional) MTI Group IP Address
<i>mti_src_ip</i>	(Optional) MTI Source IP Address

Command Mode

- /exec

show forwarding distribution l2 multicast

```
show forwarding distribution l2 multicast [ ip-based | mac-based ] [ vlan <vlan-id> [ { group <grpaddr> [
source <srcaddr> ] } | destination-mac <dmac> ] ] [ summary ] [ __readonly__ <refcount> <oiflist_id>
<last_oiflist_id> <ftag-id> <src_str> <grp_str> <vlan> <num_routes> <num_starg_routes> <num_sg_routes>
<num_gprefix_routes> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
l2	L2 information
multicast	L2 multicast information
ip-based	(Optional) IPv4 based
mac-based	(Optional) MAC based
vlan	(Optional) Info specific to a vlan
<i>vlan-id</i>	(Optional) Vlan id value
group	(Optional) Group specific information
<i>grpaddr</i>	(Optional) Group address
source	(Optional) (G,S) specific information
<i>srcaddr</i>	(Optional) Source address
destination-mac	(Optional) Destination MAC specific information
<i>dmac</i>	(Optional) Destination MAC address
summary	(Optional) display route counts
<i>__readonly__</i>	(Optional)
<i>refcount</i>	(Optional) Reference Count
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>last_oiflist_id</i>	(Optional) Last OIF list Identifier
<i>ftag-id</i>	(Optional) ftag Id
<i>src_str</i>	(Optional) Source
<i>grp_str</i>	(Optional) Group

<i>vlan</i>	(Optional) <i>vlan_id</i>
<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes

Command Mode

- /exec

show forwarding distribution lisp counters

show forwarding distribution lisp counters [*__readonly__* <count>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution information
lisp	for lisp application
counters	counters
<i>__readonly__</i>	(Optional)
<i>count</i>	(Optional) count

Command Mode

- /exec

show forwarding distribution lisp vrf enabled

```
show forwarding distribution lisp vrf enabled [ __readonly__ { TABLE_lisp_vrf_enabled <vrf> <lisp_enabled>
<req_id> <operation> } ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution information
lisp	for lisp application
vrf	vrf
enabled	enabled
<i>__readonly__</i>	(Optional)
TABLE_lisp_vrf_enabled	(Optional)
<i>vrf</i>	(Optional) vrf key
<i>lisp_enabled</i>	(Optional) lisp enabled status
<i>req_id</i>	(Optional) req id
<i>operation</i>	(Optional) operation

Command Mode

- /exec

show forwarding distribution multicast

```
show forwarding distribution multicast [ messages ] [ __readonly__ <fibstate> <slot> <accepting_routes>
<num_accepting_routes> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
messages	(Optional) Outstanding Message Information
<i>__readonly__</i>	(Optional)
<i>fibstate</i>	(Optional) IP Multicast FIB process state
<i>slot</i>	(Optional) Slot
<i>accepting_routes</i>	(Optional) Indicates whether FIB is accepting routes
<i>num_accepting_routes</i>	(Optional) Number of fibs accepting routes

Command Mode

- /exec

show forwarding distribution multicast client-ack-db

```
show forwarding distribution multicast client-ack-db [ __readonly__ <xid> <num_recepients> <num_responses>
]
```

Syntax Description

show	show
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast
client-ack-db	Displays the client ack db
<i>__readonly__</i>	(Optional)
<i>xid</i>	(Optional) XID
<i>num_recepients</i>	(Optional) Number of recepients
<i>num_responses</i>	(Optional) Number of responses

Command Mode

- /exec

show forwarding distribution multicast client

show forwarding distribution multicast client [*__readonly__* <num-clients> <client-name> <client-id> <shmem-name>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
client	Show multicast distribution client information
<i>__readonly__</i>	(Optional)
<i>num-clients</i>	(Optional) Number of Clients registered
<i>client-name</i>	(Optional) Client Name
<i>client-id</i>	(Optional) Client-id
<i>shmem-name</i>	(Optional) Shared Memory Segment Name

Command Mode

- /exec

show forwarding distribution multicast download

show forwarding distribution multicast download

Syntax Description

show	
forwarding	forwarding information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
download	show download queues

Command Mode

- /exec

show forwarding distribution multicast mfib

```
show forwarding distribution multicast { mfib-txlist [ vrf <vrf-name> ] | mfib-buffers } [ __readonly__
<no-free-buffers> <no-used-buffers> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
mfib-txlist	Show MFIB transmission-list information
vrf	(Optional) Specify VRF
<i>vrf-name</i>	(Optional) Specify VRF name
mfib-buffers	Show MFIB route buffer information
__readonly__	(Optional)
<i>no-free-buffers</i>	(Optional) Number of Free txlist MFIB buffers
<i>no-used-buffers</i>	(Optional) Number of Used txlist MFIB buffers

Command Mode

- /exec

show forwarding distribution multicast outgoing-interface-list

```
show forwarding distribution multicast outgoing-interface-list { L2 | L3 | OTV } [ <index> ] [ __readonly__
<platform_index> <ref_count> <num_oif> <oif> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
outgoing-interface-list	Outgoing interface list
L2	Layer 2 oiflist
L3	Layer 3 oiflist
OTV	OTV oiflist
<i>index</i>	(Optional) Outgoing Interface List index
<i>__readonly__</i>	(Optional)
<i>platform_index</i>	(Optional) Platform index
<i>ref_count</i>	(Optional) Reference count
<i>num_oif</i>	(Optional) Number of outgoing interfaces
<i>oif</i>	(Optional) OIF name

Command Mode

- /exec

show forwarding distribution multicast resp-ack-timer-msgs

show forwarding distribution multicast resp-ack-timer-msgs

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
resp-ack-timer-msgs	show response ack timers for MFDM

Command Mode

- /exec

show forwarding distribution multicast route

```
show forwarding distribution [ ip ] multicast route [ table <id> | vrf { <vrf_name> | all } ] [ [ group { <gaddr>
[ <mask> ] | <gprefix> } ] [ source { <saddr> [ <smask> ] | <sprefix> } ] | summary ] [ __readonly__
<table_name> <num_routes> <num_starg_routes> <num_sg_routes> <num_gprefix_routes> <src_len>
<grp_len> <df_ordinal> <rpfif> <rpf_ifname> <flag> <flag_value> <num_groups> <num_sources> <refcount>
<oiflist_id> <oif_count> <oif_name> <oif_ifindex> <bytecnt> <pktcnt> <mti_src_if> <mti_grp_ip>
<mti_src_ip> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
ip	(Optional) IPV4 information
multicast	Multicast information
route	Multicast route related information
vrf	(Optional) Specify VRF
<i>vrf_name</i>	(Optional) Specify VRF name
all	(Optional) Display information for all VRFs
table	(Optional) Specify Multicast Routing Table
<i>id</i>	(Optional) Multicast Routing Table Identifier
group	(Optional) IPv4 Multicast Group specific
<i>gaddr</i>	(Optional) IPv4 Multicast Group Address
<i>mask</i>	(Optional) mask for group ip address
<i>gprefix</i>	(Optional) IPv4 Multicast Group Prefix
source	(Optional) IPv4 Multicast Source specific
<i>saddr</i>	(Optional) IPv4 Source Address
<i>smask</i>	(Optional) mask for group ip address
<i>sprefix</i>	(Optional) IPv4 Multicast Source Prefix
summary	(Optional) display route counts
__readonly__	(Optional)
<i>table_name</i>	(Optional) Table name

<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifname</i>	(Optional) RPF Interface ifName
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>refcount</i>	(Optional) Reference Count
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>oif_count</i>	(Optional) Number of OIFs
<i>oif_name</i>	(Optional) OIF Name
<i>oif_ifindex</i>	(Optional) OIF ifIndex
<i>bytecnt</i>	(Optional) Current Byte counter
<i>pktcnt</i>	(Optional) Current Packet counter
<i>mti_src_if</i>	(Optional) MTI Source Ifindex
<i>mti_grp_ip</i>	(Optional) MTI Group IP Address
<i>mti_src_ip</i>	(Optional) MTI Source IP Address

Command Mode

- /exec

show forwarding distribution peer-id

show forwarding distribution peer-id [vpls | otv] [__readonly__ <header> TABLE_peer_id <app> <vlan> <id> <peer_id>]

Syntax Description

show	Show running system information
forwarding	forwarding information
distribution	fib distribution info
peer-id	HW Peer-id allocation info
vpls	(Optional) VPLS
otv	(Optional) OTV
__readonly__	(Optional)
<i>header</i>	(Optional) Header
TABLE_peer_id	(Optional) Peer ID table
<i>app</i>	(Optional) OTV/VPLS
<i>vlan</i>	(Optional) VLAN
<i>id</i>	(Optional) ID
<i>peer_id</i>	(Optional) Peer-ID

Command Mode

- /exec

show forwarding distribution trace

show forwarding distribution trace

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution info
trace	unicast trace information

Command Mode

- /exec

show forwarding ecmp

```
show forwarding ecmp [ { [ vrf { <vrf-name> | <vrf-known-name> } ] lisp } ] [ platform ] [ module <module> ] [ partial ] [ __readonly__ [ <header> <ecmp_hash> <intf> <nh> <v6nh> <hw_index> <num_mpls> <holder> <refcount> <num_paths> <sw_ptr> <ecmp_partial> ] [ TABLE_ecmp { [ <hash> ] [ <num_paths> ] [ <hwinde> ] [ <ecmppartial> ] [ TABLE_index { [ <ecmp_idx> ] [ <cmn_idx> ] } ] [ <refcnt> ] [ <ecmp_holder> ] } ] [ TABLE_adjacency { [ <intf> ] [ <nh> ] [ <v6nh> ] [ <hw_adj_idx> ] [ <hw_cmn_idx> ] [ <lif> ] [ <hw_nve_adj_idx> ] [ <hw_nve_cmn_idx> ] [ <nve_lif> ] } ] [ <vobj_count> ] [ <vxlan_vobj_count> ] [ <vxlan> ] [ <vobj_list_header> ] [ <vobj-id> ] ] ] ]
```

Syntax Description

show	
forwarding	Display fib information
ecmp	Show information about ECMPs
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
lisp	(Optional) Show information about LISP ECMPs
platform	(Optional) one command to show pi and pd info together
module	(Optional) slot
<i>module</i>	(Optional) slot number
partial	(Optional) Show partially installed ECMPs
<i>__readonly__</i>	(Optional)
<i>header</i>	(Optional) o/p header
<i>ecmp_hash</i>	(Optional) ecmp hash
<i>intf</i>	(Optional) interface
<i>nh</i>	(Optional) next hop
<i>v6nh</i>	(Optional) V6 next hop
<i>hw_index</i>	(Optional) Hw index
<i>num_mpls</i>	(Optional) No of MPLS ecmp
<i>holder</i>	(Optional) holder bitmap
<i>refcount</i>	(Optional) refcount
<i>sw_ptr</i>	(Optional) Software pointer

<i>num_paths</i>	(Optional) No of paths
<i>ecmp_partial</i>	(Optional) partial ecmp
TABLE_ecmp	(Optional) ecmp table
<i>hash</i>	(Optional) ecmp hash
<i>num_paths</i>	(Optional) No of paths
<i>hwindex</i>	(Optional) Hw index
<i>ecmppartial</i>	(Optional) partial ecmp
TABLE_index	(Optional) index table
<i>ecmp_idx</i>	(Optional) hw ecmp index
<i>cmn_idx</i>	(Optional) cmn index
<i>refcnt</i>	(Optional) refcount
<i>ecmp_holder</i>	(Optional) holder bitmap
TABLE_adjacency	(Optional) adjacency table
<i>intf</i>	(Optional) interface
<i>nh</i>	(Optional) next hop
<i>v6nh</i>	(Optional) v6 next hop
<i>hw_adj_idx</i>	(Optional) hw adj index
<i>hw_cmn_idx</i>	(Optional) hw cmn index
<i>lif</i>	(Optional) lif
<i>hw_nve_adj_idx</i>	(Optional) nve adj index
<i>hw_nve_cmn_idx</i>	(Optional) nve cmn index
<i>nve_lif</i>	(Optional) nve lif
<i>vobj_count</i>	(Optional) vobj count
<i>vxlan_vobj_count</i>	(Optional) vxlan vobj count
<i>vxlan</i>	(Optional) vxlan
<i>vobj_list_header</i>	(Optional) vobj list header
<i>vobj-id</i>	(Optional) vobj id

Command Mode

- /exec

show forwarding ecmp recursive

```
show forwarding ecmp recursive [ platform ] [ max-display-count <display_count> ] [ module <module> ] [
partial ] [ __readonly__ [ TABLE_vobj { [ <header_vobj> ] [ <header_ecmp> } ] [ TABLE_vobj_idx { [
<hw_vobj_index> ] [ <cmn_index> } ] ] [ <num_pfxs> ] [ <ecmp_partial> ] [ <activepath_hdr> ] [
TABLE_activepath { [ <ap_nh> ] [ <ap_v6nh> ] [ <ap_rnh_len> ] [ <ap_nh_vpn_label> ] [ <ap_rnh_table_id>
] [ <ap_nh_weight> } ] ] [ <backuppath_hdr> ] [ TABLE_backuppath { [ <bp_nh> ] [ <bp_v6nh> ] [
<bp_nh_vpn_label> ] [ <bp_rnh_table_id> ] [ <bp_nh_weight> } ] ] [ <cnh_hdr> ] [ TABLE_cnh { [ <nh>
] [ <v6nh> ] [ <intf> ] [ TABLE_cnh_adj { [ <hw_adj> ] [ <hw_cmn_index> ] [ <lif> } ] ] ] [ <hw_inst_n>
] [ <ls_count_n> ] [ <hw_inst_o> ] [ <ls_count_o> ] [ <fec_type> ] [ <header_fec_ecmp> ] [
<hw_vobj_fec_idx> ] [ <cmn_idx> ] [ <vobj_hw_inst_n> ] [ <vobj_ls_count_n> ] [ <vobj_hw_inst_o> ] [
<vobj_ls_count_o> ] [ <vobj_refcount> ] ] <header> <num_pfxs> <rn timer_id> <nh> <rn timer_len> <v6nh>
<hw_instance> <nh_vpn_label> <nh_weight> <cnh_intf> <ecmp_partial> ]
```

Syntax Description

show	
forwarding	Display fib information
ecmp	Show information about ECMPs
recursive	Show information about recursive ECMPs
platform	(Optional) one command to show pi and pd info together
module	(Optional) slot
partial	(Optional) Show partially installed ECMPs
<i>module</i>	(Optional) slot number
max-display-count	(Optional) displays max # of routes
<i>display_count</i>	(Optional) count
<i>__readonly__</i>	(Optional)
TABLE_vobj	(Optional) Table vobj
<i>header_vobj</i>	(Optional) vobj o/p header
<i>header_ecmp</i>	(Optional) ecmp o/p header
TABLE_vobj_idx	(Optional) Table vobj index
<i>hw_vobj_index</i>	(Optional) HW VOBJ Index
<i>cmn_index</i>	(Optional) cmn index
<i>num_pfxs</i>	(Optional) Number of prefixes using this virtual object
<i>ecmp_partial</i>	(Optional) partial ecmp

<i>activepath_hdr</i>	(Optional) o/p header
TABLE_activepath	(Optional) table active path
<i>ap_nh</i>	(Optional) Next hop info
<i>ap_v6nh</i>	(Optional) v6 Next hop info
<i>ap_rnh_len</i>	(Optional) Next hop mask length
<i>ap_nh_vpn_label</i>	(Optional) NH VPN label
<i>ap_rnh_table_id</i>	(Optional) The table id where the RNHs are present
<i>ap_nh_weight</i>	(Optional) weighted ecmp info
<i>backuppath_hdr</i>	(Optional) o/p header
TABLE_backuppath	(Optional) backup path table
<i>bp_nh</i>	(Optional) Next hop info
<i>bp_v6nh</i>	(Optional) v6 Next hop info
<i>bp_nh_vpn_label</i>	(Optional) NH VPN label
<i>bp_rnh_table_id</i>	(Optional) The table id where the RNHs are present
<i>bp_nh_weight</i>	(Optional) weighted ecmp info
<i>cnh_hdr</i>	(Optional) o/p header
TABLE_cnh	(Optional) cnh table
<i>nh</i>	(Optional) Next hop info
<i>v6nh</i>	(Optional) v6 Next hop info
<i>intf</i>	(Optional) cnh output interface
TABLE_cnh_adj	(Optional) Table cnh adjacency
<i>hw_adj</i>	(Optional) cnh hw adjacency
<i>hw_cmn_index</i>	(Optional) cnh hw cmn idx
<i>lif</i>	(Optional) lif
<i>hw_inst_n</i>	(Optional) Hardware instance info new
<i>ls_count_n</i>	(Optional) ls count new
<i>hw_inst_o</i>	(Optional) Hardware instance info old
<i>ls_count_o</i>	(Optional) ls count old
<i>fec_type</i>	(Optional) fec type

<i>header_fec_ecmp</i>	(Optional) o/p header
<i>hw_vobj_fec_idx</i>	(Optional) hw fec idx
<i>cmn_idx</i>	(Optional) cmn idx
<i>vobj_hw_inst_n</i>	(Optional) vobj hw instance
<i>vobj_ls_count_n</i>	(Optional) ls count new
<i>vobj_hw_inst_o</i>	(Optional) hw instnace info old
<i>vobj_ls_count_o</i>	(Optional) ls count old
<i>vobj_refcount</i>	(Optional) vobj refcount
<i>header</i>	(Optional) o/p header
<i>num_pfxs</i>	(Optional) Number of prefixes using this virtual object
<i>rnh_table_id</i>	(Optional) The table id where the RNHs are present
<i>nh</i>	(Optional) Next hop info
<i>rnh_len</i>	(Optional) Next hop mask length
<i>v6nh</i>	(Optional) V6 Next hop info
<i>hw_instance</i>	(Optional) Hardware instance info
<i>nh_vpn_label</i>	(Optional) NH VPN label
<i>nh_weight</i>	(Optional) weighted ecmp info
<i>cnh_intf</i>	(Optional) cnh output interface
<i>ecmp_partial</i>	(Optional) partial ecmp

Command Mode

- /exec

show forwarding interfaces

```
show forwarding interfaces [ module <module> ] [ __readonly__ <intf> <v4adjcnt> <v6adjcnt> <rpfmode>
<mac> ]
```

Syntax Description

show	
forwarding	fib information
interfaces	show fib interface info
__readonly__	(Optional)
<i>intf</i>	(Optional) interface name
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>v4adjcnt</i>	(Optional) count of v4 adjacencies
<i>v6adjcnt</i>	(Optional) count of v6 adjacencies
<i>mac</i>	(Optional) mac address
<i>rpfmode</i>	(Optional) uRPF mode

Command Mode

- /exec

show forwarding ipv6 adjacency

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 adjacency [ mpls ] [ <aif> ] [ <anh> ] [ detail | stats | platform ] [ module <module> ] [ __readonly__ [ <adj-count> ] [ TABLE_adj { <fec> <nexthop> <rewinfo> <interface> <pkts> <bytes> <bgp_rnh> <bgp_orig_as> <bgp_peer_as> <hh> <refcount> } ] [ TABLE_v6_adj { [ <nh> ] [ <rwinf> ] [ <intf> ] [ <intf_idx> ] [ <hh> ] [ <refcnt> ] [ <flags> ] [ <holder> ] [ <pbr_cnt> ] [ <wccp_cnt> ] [ TABLE_index { [ <hw_adj> ] [ <cmn-idx> ] [ <lif> ] } } ] ] ] ]
```

Syntax Description

show	
forwarding	display fib information
ipv6	ipv6
adjacency	display adjacency information
platform	(Optional) one command to show pi and pd info together
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
mpls	(Optional) mpls adjacency information
<i>aif</i>	(Optional) adjacency output interface
detail	(Optional) detail
stats	(Optional) adjacency statistics
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>adj-count</i>	(Optional) total adj count
TABLE_adj	(Optional) Table Adjacency
<i>fec</i>	(Optional) FEC info
<i>nexthop</i>	(Optional) next hop address
<i>rewinfo</i>	(Optional) rewrite information
<i>interface</i>	(Optional) output interface
<i>pkts</i>	(Optional) packet stats

<i>bytes</i>	(Optional) bytes stats
<i>bgp_rnh</i>	(Optional) next hop address
<i>bgp_orig_as</i>	(Optional) bgp orig as
<i>bgp_peer_as</i>	(Optional) bgp peer as
<i>hh</i>	(Optional) Hardware Handle
<i>refcount</i>	(Optional) reference count
TABLE_v6_adj	(Optional) Table Adjacency
<i>nh</i>	(Optional) next hop address
<i>rwinfo</i>	(Optional) rewrite information
<i>intf</i>	(Optional) output interface
<i>intf_idx</i>	(Optional) Interface index
<i>hh</i>	(Optional) Hardware Handle
<i>refcnt</i>	(Optional) reference count
<i>flags</i>	(Optional) Adjacency flags
<i>holder</i>	(Optional) Holder bitmap
<i>pbr_cnt</i>	(Optional) PBR count
<i>wccp_cnt</i>	(Optional) WCCP count
TABLE_index	(Optional) HW index table
<i>hw_adj</i>	(Optional) v4 adj hw index
<i>cmn-idx</i>	(Optional) CMN Index
<i>lif</i>	(Optional) LIF

Command Mode

- /exec

show forwarding ipv6 multicast route

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | all } | table <tab_id> ] ipv6 multicast route { [
group { <group> | <group_addr> } | source { <source> | <source_addr> } | module <module> | vrf { <vrf-name>
| all } ] + | summary [ module <module> | vrf { <vrf-name> | <vrf-known-name> | all } ] + } [ __readonly__
<table_type> <num_routes> <num_starg_routes> <num_sg_routes> <num_gprefix_routes>
<num_prefix_insert_fail> <num_groups> <num_sources> <src_len> <grp_len> <df_ordinal> <rpflf> <address>
<flag> <route_pkts> <route_bytes> ]
```

Syntax Description

show	
forwarding	display fib information
ipv6	ipv6
multicast	IPV6 related Multicast information
route	Multicast route information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>tab_id</i>	(Optional) table number
group	(Optional) Multicast IPv6 Group Address
source	(Optional) Multicast IPv6 Source Address
summary	display route counts
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes

<i>num_prefix_insert_fail</i>	(Optional) Prefix insert fail count
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>address</i>	(Optional) Ipv6 address string
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>flag</i>	(Optional) Route type flag
<i>route_pkts</i>	(Optional) Route packet count
<i>route_bytes</i>	(Optional) Route bytes

Command Mode

- /exec

show forwarding ipv6 route

```

show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] ipv6 { route | rnhdb
} [ recursive ] [ detail | summary | platform | partial | <prefix> [ longer-prefixes ] [ detail | platform ] | <address>
 [ detail | platform ] | interface <interface> | next-hop <n timer> | attached | unresolved | adjacency { <aif> <anh>
 | drop | glean | punt } ] [ max-display-count <display_count> ] [ module <module> | vrf { <vrf-name> |
<vrf-known-name> | <vrf-all> } ] + [ __readonly__ [ TABLE_vrf { [ <vrfname> ] [ <tblname> ] [ <tableid>
] [ <prefix_count> ] [ TABLE_prefix { [ <pxfx> ] [ TABLE_path { [ <nexthop> | <special> ] [ <intf> ] [
<route_count> ] [ <path_count> ] [ <mask_length> ] [ <routes_per_mask> ] } ] [ <hw_handle> ] [ <flags> ]
 [ <holder> ] [ <nxt_obj_type> ] [ <hw_idx_v6adj> ] [ <cmn-idx> ] [ <lif> ] [ <buf-idx> ] } } } ] ]

```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table id in hex
ipv6	ipv6
route	display IP routing table
platform	(Optional) one command to show pi and pd info together
rnhdb	rnhdb
recursive	(Optional) display routes with recursive next hops
detail	(Optional) show detailed information about the routes
summary	(Optional) display route counts
partial	(Optional) display routes with partial ECMPs
longer-prefixes	(Optional) display longer prefixes
interface	(Optional) display routes with this output i/f only
<i>interface</i>	(Optional) output interface
next-hop	(Optional) display routes with this next-hop only
attached	(Optional) display directly connected routes

unresolved	(Optional) display unresolved routes
adjacency	(Optional) display routes via specified adjacency
<i>aif</i>	(Optional) adjacency output interface
drop	(Optional) display routes via drop adjacency
glean	(Optional) display routes via glean adjacency
punt	(Optional) display routes via punt adjacency
module	(Optional) slot
<i>module</i>	(Optional) slot number
max-display-count	(Optional) displays max # of routes
<i>display_count</i>	(Optional) count
__readonly__	(Optional)
TABLE_vrf	(Optional) vrf table
<i>vrfname</i>	(Optional) VRF name
<i>tblname</i>	(Optional) table name
<i>tableid</i>	(Optional) table id
<i>prefix_count</i>	(Optional) total number of prefix in VRF
TABLE_prefix	(Optional) all xml prefix entries
<i>px</i>	(Optional) ipv6 prefix
TABLE_path	(Optional) path table
<i>nexthop</i>	(Optional) next hop address
<i>special</i>	(Optional) special adjacencies
<i>intf</i>	(Optional) output interface
<i>hw_handle</i>	(Optional) hw handle
<i>flags</i>	(Optional) flags
<i>holder</i>	(Optional) holder
<i>nxt_obj_type</i>	(Optional) next obj type
<i>hw_idx_v6adj</i>	(Optional) v6 adj hw idx
<i>cmn-idx</i>	(Optional) cmn idx
<i>lif</i>	(Optional) lif

<i>buf-idx</i>	(Optional) buf idx
<i>route_count</i>	(Optional) total number of routes in VRF
<i>path_count</i>	(Optional) total number of paths in VRF
<i>mask_length</i>	(Optional) length of mask
<i>routes_per_mask</i>	(Optional)

Command Mode

- /exec

show forwarding kvfib cache on

show forwarding kvfib cache { on | off }

Syntax Description

show	
forwarding	fib information
kvfib	kvfib
cache	cache
on	set variable
off	reset variable

Command Mode

- /exec

show forwarding l2 multicast

```
show forwarding l2 multicast { [ { vlan <vlan-id> [ { group <grpaddr> source <srcaddr> } | destination-mac
<dstmac> ] } ] } [ vdc <vdc-id> ] [ module <num> ] [ __readonly__ <epoch> <resource_id> <dest_index>
<hw_handle> <dmac> <text> <value> ]
```

Syntax Description

show	Show running system information
forwarding	Forwarding information
l2	L2 related information
multicast	Multicast related information
vlan	(Optional) Information Specific to a Vlan
<i>vlan-id</i>	(Optional) Vlan id value
group	(Optional) (S,G) specific information
<i>grpaddr</i>	(Optional) Group address
source	(Optional) source specific information
<i>srcaddr</i>	(Optional) Source address
destination-mac	(Optional) Destination MAC address
<i>dstmac</i>	(Optional) Ethernet MAC address
vdc	(Optional) VDC
<i>vdc-id</i>	(Optional) VDC id
module	(Optional) Slot
<i>num</i>	(Optional) Slot number
<i>__readonly__</i>	(Optional)
<i>resource_id</i>	(Optional) Resource Identifier
<i>dest_index</i>	(Optional) Destination Index Identifier
<i>epoch</i>	(Optional) Epoch number
<i>hw_handle</i>	(Optional) Hardware Handle
<i>dmac</i>	(Optional) Destination MAC address
<i>text</i>	(Optional) String
<i>value</i>	(Optional) Value

Command Mode

- /exec

show forwarding l2vpn ipv6 multicast route

```
show forwarding l2vpn ipv6 multicast route [ [ vlan <vlan-id> ] | [ softwarebd <software-bd> ] ] [ module
<module> ]
```

Syntax Description

show	show
forwarding	forwarding
l2vpn	Layer 2 VPN
ipv6	ipv6
multicast	Multicast IPv6 information
route	Mcast route information
vlan	(Optional) vlan
softwarebd	(Optional) Software Bridge Domain
<i>vlan-id</i>	(Optional) vlan id
<i>software-bd</i>	(Optional) Software bd
module	(Optional) slot
<i>module</i>	(Optional) slot number

Command Mode

- /exec

show forwarding l2vpn label vpls

show forwarding l2vpn label [<label_id>] vpls [module module] [__readonly__ <label_id>]

Syntax Description

show	show
forwarding	forwarding
l2vpn	l2vpn forwarding
label	VC label
<i>label_id</i>	(Optional) VC label
vpls	VPLS
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>label_id</i>	(Optional) Label ID

Command Mode

- /exec

show forwarding l2vpn label xconnect

show forwarding l2vpn label [<label_id>] xconnect [module module] [__readonly__ <label_id>]

Syntax Description

show	show
forwarding	forwarding
l2vpn	l2vpn forwarding
label	VC label
<i>label_id</i>	(Optional) VC label
xconnect	xconnect or VPWS
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>label_id</i>	(Optional) Label ID

Command Mode

- /exec

show forwarding l2vpn multicast outgoing-interface-list

show forwarding l2vpn multicast outgoing-interface-list [index <oiflist-index>]

Syntax Description

show	
forwarding	Forwarding information
l2vpn	Layer 2 VPN
multicast	Multicast IPv4 information
outgoing-interface-list	show outgoing interface list info
index	(Optional) oiflist index
<i>oiflist-index</i>	(Optional) oiflist-index

Command Mode

- /exec

show forwarding l2vpn multicast route

```
show forwarding l2vpn multicast route [ [ vlan <vlan-id> ] ] [ softwarebd <software-bd> ] [ module <module> ]
```

Syntax Description

show	show
forwarding	forwarding
l2vpn	Layer 2 VPN
multicast	Multicast IPv4 information
route	Meast route information
vlan	(Optional) vlan
softwarebd	(Optional) Software Bridge Domain
<i>vlan-id</i>	(Optional) vlan id
<i>software-bd</i>	(Optional) Software bd
module	(Optional) slot
<i>module</i>	(Optional) slot number

Command Mode

- /exec

show forwarding l2vpn service vpls

```
show forwarding l2vpn service vpls { { service_id { <service_id> | all } } | { vlan { <vlan_id> | vlan_all } }
| { peer { { interface <intf-name> | next-hop <addr> | peer_all } } } } [ module <module> ] [ detail ]
```

Syntax Description

show	show
forwarding	display fib information
l2vpn	l2vpn forwarding
service	Services
vpls	Vpls
service_id	Specifies a service_id
<i>service_id</i>	service ID
all	all VPLS services
vlan	VLAN info
<i>vlan_id</i>	VLAN number
vlan_all	all VPLS services
peer	define the peer
peer_all	all peers
interface	PW interface for peer
<i>intf-name</i>	interface name
next-hop	Next hop to reach the peer
<i>addr</i>	IP address
module	(Optional) slot
<i>module</i>	(Optional) slot number
detail	(Optional) Display detailed information

Command Mode

- /exec

show forwarding l2vpn service xconnect

```
show forwarding l2vpn service xconnect { service_id { <service_id> | all } } [ module <module> ] [ detail ]
```

Syntax Description

show	show
forwarding	display fib information
l2vpn	l2vpn forwarding
service	Services
xconnect	xconnect or VPWS
service_id	Specify a service_id in hex
<i>service_id</i>	service ID
all	All service-id will be displayed
module	(Optional) slot
<i>module</i>	(Optional) slot number
detail	(Optional) Display detailed information

Command Mode

- /exec

show forwarding l2vpn vlan

show forwarding l2vpn vlan [<vlan_id>] [module <module>] [__readonly__ <vlan>]

Syntax Description

show	show
forwarding	forwarding
l2vpn	l2vpn forwarding
vlan	vlan
<i>vlan_id</i>	(Optional) vlan id
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>vlan</i>	(Optional) vlan

Command Mode

- /exec

show forwarding multicast-sr loopback interface

show forwarding multicast-sr loopback interface

Syntax Description

show	
forwarding	display fib information
multicast-sr	multicast service reflect information
interface	loopback interface
loopback	loopback interface

Command Mode

- /exec

show forwarding multicast outgoing-interface-list

```
show forwarding multicast outgoing-interface-list { L2 | L3 | vxlan-encap } [ platform ] [ module <module>
] [ <index> ] [ __readonly__ <refcount> <num_oif> <intf> <encap_id>
<slot><total_l2_oiflist><total_l3_oiflist><oiflist_idx> <hw_oiflist_idx><mcidx> ]
```

Syntax Description

show	
forwarding	Forwarding information
multicast	Multicast IPv4 information
outgoing-interface-list	show outgoing interface list info
L2	Layer 2 oiflist
L3	Layer 3 oiflist
vxlan-encap	vxlan-encap oiflist
platform	(Optional) Display PI/PD
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>index</i>	(Optional) Outgoing Interface List Index
<i>__readonly__</i>	(Optional)
<i>refcount</i>	(Optional) Reference count
<i>num_oif</i>	(Optional) Number of outgoing interfaces
<i>intf</i>	(Optional) OIF name
<i>encap_id</i>	(Optional) encap_id

Command Mode

- /exec

show forwarding multicast route

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | all } | table <table_id> ] [ ipv4 ] multicast route [
platform ] { [ group { <gaddr> [ <mask> ] | <gprefix> } | source { <saddr> [ <smask> ] | <sprefix> } | module
<module> | vrf { <vrf-name> | <vrf-known-name> | all } ]+ | summary [ module <module> | vrf { <vrf-name>
| <vrf-known-name> | all } ]+ } [ __readonly__ <table_type> <vrfname> <num_routes> <num_starg_routes>
<num_sg_routes> <num_gprefix_routes> <num_prefix_insert_fail> <num_groups> <num_sources> <src_len>
<grp_len> <df_ordinal> <rpfif> <rpf_ifindex> <flag> <flag_value> <route_pkts> <route_bytes> <oiflist_id>
<platform_id> <oif_count> <refcount> <oifname> <oifindex> <oif_pkts> <oif_bytes> ]
```

Syntax Description

show	
forwarding	Forwarding information
ipv4	(Optional) ipv4
multicast	Multicast IPv4 information
route	Meast route information
platform	(Optional) Platform Details
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
group	(Optional) Multicast IPv4 Group specific info
<i>gaddr</i>	(Optional) Multicast IPv4 Group Address
<i>mask</i>	(Optional) Multicast IPv4 Group Address mask
<i>gprefix</i>	(Optional) Multicast IPv4 Group Prefix
source	(Optional) Multicast IPv4 Source specific info
<i>saddr</i>	(Optional) Multicast IPv4 Source Address
<i>smask</i>	(Optional) Multicast IPv4 Source Address mask
<i>sprefix</i>	(Optional) Multicast IPv4 Source Prefix
summary	display route counts
module	(Optional) slot

<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>vrfname</i>	(Optional) VRF name
<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes
<i>num_prefix_insert_fail</i>	(Optional) Prefix insert fail count
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifindex</i>	(Optional) RPF Interface ifIndex
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>route_pkts</i>	(Optional) Route packet count
<i>route_bytes</i>	(Optional) Route bytes
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>platform_id</i>	(Optional) Platform-index
<i>oif_count</i>	(Optional) Number of OIFs
<i>refcount</i>	(Optional) OIF list Reference Count
<i>oifname</i>	(Optional) OIF Interface name
<i>oifindex</i>	(Optional) OIF Interface ifIndex
<i>oif_pkts</i>	(Optional) OIF packets
<i>oif_bytes</i>	(Optional) OIF bytes

Command Mode

- /exec

show forwarding security group-tag

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> | vlan <vlan_id> ] [
ipv4 ] security group-tag [ <addr> ] [ module <num> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ]
+ [ __readonly__ <header> <vrfname> <tid> <pfx-count> <ipa> <tag> <tv> <vid> ]
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
vlan	(Optional) vlan
<i>vlan_id</i>	(Optional) vlan number
ipv4	(Optional) ipv4
security	display IP security information
group-tag	ip_address->security_group_tag
<i>addr</i>	(Optional) specific ip address
module	(Optional) slot
<i>__readonly__</i>	(Optional)
<i>header</i>	(Optional) header string
<i>vrfname</i>	(Optional) VRF name
<i>tid</i>	(Optional) table identifier
<i>num</i>	(Optional) module number
<i>pfx-count</i>	(Optional) total prefix count in VRF
<i>ipa</i>	(Optional) ip address
<i>tag</i>	(Optional) security group tag
<i>tv</i>	(Optional) sgt valid

<i>vid</i>	(Optional) vlan indentifier
------------	-----------------------------

Command Mode

- /exec

show forwarding security mac

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ ipv4 ] security
mac [ <addr> ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] + [ __readonly__
<header> <vrfname> <tid> <pfx-count> <ipa> <mac> <p> <m> <v> <intf> ]
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
ipv4	(Optional) ipv4
security	display IP security information
mac	ip_address->mac_address
<i>addr</i>	(Optional) specific ip address
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>header</i>	(Optional) header string
<i>vrfname</i>	(Optional) VRF name
<i>tid</i>	(Optional) table identifier
<i>pfx-count</i>	(Optional) total prefix count in VRF
<i>ipa</i>	(Optional) ip address
<i>mac</i>	(Optional) mac address
<i>p</i>	(Optional) 1 => ip->port binding
<i>m</i>	(Optional) 1 => ip->mac binding
<i>v</i>	(Optional) 1 => ip->vlan binding

<i>intf</i>	(Optional) ip->port interface
-------------	-------------------------------

Command Mode

- /exec

show forwarding trace

```
show forwarding trace [ clear ] [ module <module> ] [ __readonly__ <op> ]
```

Syntax Description

show	
forwarding	display fib information
trace	display trace buffer
clear	(Optional) clear the trace buffer
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>op</i>	(Optional) output

Command Mode

- /exec

show forwarding trace profile

show forwarding trace profile

Syntax Description

show	
forwarding	display fib information
trace	display trace buffer
profile	show the collection profiling information

Command Mode

- /exec

show forwarding trace profile funcstats

show forwarding trace profile funcstats [enable | disable] [module <module>] [__readonly__ <op>]

Syntax Description

show	
forwarding	display fib information
trace	display trace buffer
profile	show the collection profiling information
funcstats	function statistics
enable	(Optional) enable function statistics
disable	(Optional) disable function statistics
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>op</i>	(Optional) output

Command Mode

- /exec

show fte event

```
show fte event [ name ] [ { <eventname> } ] [ __readonly__ <event> <description> <use_count>
<latency_threshold> <latency_unit> <analytics_changed_flow_count> <latency_flow_count> ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
event	Show Event Configuration
name	(Optional) Show the configuration for a specific FTE Event
<i>eventname</i>	(Optional) Specify a event
<i>__readonly__</i>	(Optional)
<i>event</i>	(Optional)
<i>description</i>	(Optional)
<i>use_count</i>	(Optional)
<i>latency_threshold</i>	(Optional)
<i>latency_unit</i>	(Optional)
<i>analytics_changed_flow_count</i>	(Optional)
<i>latency_flow_count</i>	(Optional)

Command Mode

- /exec

show fte exporter

```
show fte exporter [ name ] [ <exportername> ] [ __readonly__ <exporter> <description> <dest> <vrf> <vrf_id>
<vrf_resolved> <dest_udp> <source_intf> <source_ip> <exporter-id> ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
exporter	Show FTE Exporter Configuration
name	(Optional) Show a specific FTE Exporter
<i>exportername</i>	(Optional) Specify an exporter
<i>__readonly__</i>	(Optional)
<i>exporter</i>	(Optional)
<i>description</i>	(Optional)
<i>dest</i>	(Optional)
<i>vrf</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_resolved</i>	(Optional)
<i>dest_udp</i>	(Optional)
<i>source_intf</i>	(Optional)
<i>source_ip</i>	(Optional)
<i>exporter-id</i>	(Optional)

Command Mode

- /exec

show fte monitor

```
show fte monitor [ name ] [ <monitorname> [ cache [ detailed ] ] ] [ __readonly__ <monitor> <use_count>
<description> <record> <event> <exporter1> <exporter2> <bucket_id> <src_addr> <dest_addr> ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
monitor	Show Monitor Configuration
name	(Optional) Show a specific FTE Monitor
<i>monitorname</i>	(Optional) Specify a monitor
cache	(Optional) Flow monitor cache contents
detailed	(Optional) Show the entire cache contents
<i>__readonly__</i>	(Optional)
<i>monitor</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>record</i>	(Optional)
<i>event</i>	(Optional)
<i>exporter1</i>	(Optional)
<i>exporter2</i>	(Optional)
<i>bucket_id</i>	(Optional)
<i>src_addr</i>	(Optional)
<i>dest_addr</i>	(Optional)

Command Mode

- /exec

show fte record

```
show fte record [ name ] [ { <recordname> } | { fte-original } | { fte { protocol-port | layer2-switched { input
} | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ <record> <description> <use_count> ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
record	Show Record Configuration
name	(Optional) Show the configuration for a specific FTE Record
<i>recordname</i>	(Optional) Specify a record
fte-original	(Optional) Traditional IPv4 input FTE with origin ASs
fte	(Optional) Traditional FTE collection schemes
ipv4	(Optional) IPv4 collection schemes
ipv6	(Optional) IPv6 collection schemes
l2	(Optional) L2 collection schemes
layer2-switched	(Optional) Layer2-Switched collection schemes
original-input	(Optional) Input FTE
input	(Optional) Input FTE
protocol-port	(Optional) Protocol and Ports aggregation scheme
__readonly__	(Optional)
<i>record</i>	(Optional)
<i>description</i>	(Optional)
<i>use_count</i>	(Optional)

Command Mode

- /exec



G Show Commands

- [show guestshell](#), on page 532

show guestshell

```
show guestshell [ { detail } ] [ __readonly__ [ TABLE_detail <name> <state> <package_name> <ova_path>
<application_name> <application_version> <application_description> <key_type> <signing_method>
<licensing_name> <licensing_version> <disk_reservation> <memory_reservation> <cpu_reservation>
TABLE_attached_devices <type> <name> <alias> ] ]
```

Syntax Description

show	Show running system information
guestshell	Display guest shell service information
detail	(Optional) Detailed guest shell service information
__readonly__	(Optional) Read Only
TABLE_detail	(Optional) Virtual service detail table
<i>name</i>	(Optional) Virtual service name
<i>package_name</i>	(Optional) Virtual service package name
<i>application_name</i>	(Optional) Name of the application
<i>application_version</i>	(Optional) Version of the application
<i>application_description</i>	(Optional) Description of the application
<i>key_type</i>	(Optional) Virtual service key type
<i>signing_method</i>	(Optional) Method used to sign the package
<i>licensing_name</i>	(Optional) Name of the license
<i>licensing_version</i>	(Optional) Version of the license
<i>ova_path</i>	(Optional) Virtual service OVA path
<i>state</i>	(Optional) Virtual service state
<i>disk_reservation</i>	(Optional) Virtual service disk reservation
<i>memory_reservation</i>	(Optional) Virtual service memory reservation
<i>cpu_reservation</i>	(Optional) Virtual service CPU reservation
TABLE_attached_devices	(Optional) Attached devices table
<i>type</i>	(Optional) Type of the attached device
<i>name</i>	(Optional) Name of the attached device
<i>alias</i>	(Optional) Alias for the attached device

Command Mode

- /exec



H Show Commands

- [show hardware](#), on page 537
- [show hardware access-list lou resource threshold](#), on page 539
- [show hardware access-list resource pooling](#), on page 540
- [show hardware access-list tcam](#), on page 541
- [show hardware capacity](#), on page 542
- [show hardware capacity eobc](#), on page 543
- [show hardware capacity fabric-utilization](#), on page 544
- [show hardware capacity forwarding](#), on page 545
- [show hardware capacity interface](#), on page 546
- [show hardware capacity module](#), on page 547
- [show hardware capacity power](#), on page 549
- [show hardware feature-capability](#), on page 550
- [show hardware flow aging](#), on page 551
- [show hardware flow entry address type](#), on page 552
- [show hardware flow ip](#), on page 553
- [show hardware flow ipv6](#), on page 554
- [show hardware flow l2](#), on page 555
- [show hardware flow sampler](#), on page 556
- [show hardware flow utilization](#), on page 557
- [show hardware forwarding interface statistics mode](#), on page 558
- [show hardware forwarding memory health detail](#), on page 559
- [show hardware forwarding memory health summary](#), on page 562
- [show hardware ip verify](#), on page 564
- [show hardware profile buffer monitor show hardware profile buffer monitor internal](#), on page 565
- [show hardware profile forwarding-mode](#), on page 569
- [show hardware profile latency monitor sampling show hardware profile latency monitor](#), on page 570
- [show hardware profile module](#), on page 572
- [show hardware profile packet-drop](#), on page 573
- [show hardware profile status](#), on page 574
- [show hardware profile tcam region](#), on page 576
- [show hardware qos afd profile](#), on page 577
- [show hardware qos burst-detect max-records](#), on page 578
- [show hardware qos eqq stats-class](#), on page 579

- [show hardware qos include ipg](#), on page 580
- [show hardware qos ing-pg-hdrm-reserve](#), on page 581
- [show hardware qos ing-pg-no-min](#), on page 582
- [show hardware qos ing-pg-share](#), on page 583
- [show hardware qos min-buffer](#), on page 584
- [show hardware qos ns-buffer-profile](#), on page 585
- [show hardware qos ns-mcq3-alias](#), on page 586
- [show hardware rate-limiter](#), on page 587
- [show hardware rate-limiter](#), on page 589
- [show hardware rate-limiter span-egress](#), on page 591
- [show hardware rl snmp class-id](#), on page 592
- [show hardware rl snmp global class-id](#), on page 593
- [show hardware rl snmp local snmp-index class-id](#), on page 594
- [show hostname](#), on page 595
- [show hosts](#), on page 596
- [show hsrp](#), on page 598
- [show hsrp anycast](#), on page 602
- [show hsrp anycast interface vlan](#), on page 603
- [show hsrp anycast remote-db](#), on page 604
- [show hsrp anycast summary](#), on page 605
- [show hsrp bfd-sessions](#), on page 606
- [show hsrp bfd-sessions](#), on page 608
- [show hsrp delay](#), on page 609
- [show hsrp mgo](#), on page 610
- [show hsrp summary](#), on page 611

show hardware

```
show hardware [ __readonly__ <header_str> <bios_ver_str> [ <loader_ver_str> ] <kickstart_ver_str> [
<sys_ver_str> ] <bios_cmpl_time> <kick_file_name> <kick_cmpl_time> <kick_tmstamp> [ <isan_file_name>
][ <isan_cmpl_time> ] [ <isan_tmstamp> ] <chassis_id> [ <module_id> ] <cpu_name> <memory> <mem_type>
<proc_board_id> [ <host_name> ] <bootflash_size> [ <slot0_size> ] [ <slot1_size> ] <kern_uptm_days>
<kern_uptm_hrs> <kern_uptm_mins> <kern_uptm_secs> [ <rr_usecs> ] [ <rr_ctime> ] <rr_reason> [
<rr_sys_ver> ] [ <rr_service> ] [ <manufacturer> ] { TABLE_slot [ TABLE_slot_info [ [ <num_slot_str> ]
[ <status_ok_empty> ] [ <type> [ <num_submods> ] ] <model_num> <hw_ver> <part_num> <part_revision>
<manuf_date> <serial_num> <CLEI_code> [ <num_slot_str> ] ] ] ] }
```

Syntax Description

show	Show running system information
hardware	Show hardware information
<i>__readonly__</i>	(Optional)
<i>header_str</i>	(Optional)
<i>bios_ver_str</i>	(Optional)
<i>loader_ver_str</i>	(Optional)
<i>kickstart_ver_str</i>	(Optional)
<i>sys_ver_str</i>	(Optional)
<i>bios_cmpl_time</i>	(Optional)
<i>kick_file_name</i>	(Optional)
<i>kick_cmpl_time</i>	(Optional)
<i>kick_tmstamp</i>	(Optional)
<i>isan_file_name</i>	(Optional)
<i>isan_cmpl_time</i>	(Optional)
<i>isan_tmstamp</i>	(Optional)
<i>chassis_id</i>	(Optional)
<i>module_id</i>	(Optional)
<i>cpu_name</i>	(Optional)
<i>memory</i>	(Optional)
<i>mem_type</i>	(Optional)
<i>proc_board_id</i>	(Optional)

<i>bootflash_size</i>	(Optional)
<i>slot0_size</i>	(Optional)
<i>slot1_size</i>	(Optional)
<i>host_name</i>	(Optional)
<i>kern_uptm_days</i>	(Optional)
<i>kern_uptm_hrs</i>	(Optional)
<i>kern_uptm_mins</i>	(Optional)
<i>kern_uptm_secs</i>	(Optional)
<i>rr_usecs</i>	(Optional)
<i>rr_ctime</i>	(Optional)
<i>rr_reason</i>	(Optional)
<i>rr_sys_ver</i>	(Optional)
<i>rr_service</i>	(Optional)
<i>manufacturer</i>	(Optional)
TABLE_slot	(Optional) Slot
<i>num_slot_str</i>	(Optional) Number of elements
TABLE_slot_info	(Optional) Slot Info
<i>status_ok_empty</i>	(Optional) Status (Present or Absent)
<i>type</i>	(Optional) Description of the element
<i>num_submods</i>	(Optional) Number of Submodules
<i>model_num</i>	(Optional) Model Number
<i>hw_ver</i>	(Optional) Hardware version
<i>part_num</i>	(Optional) Part Number
<i>part_revision</i>	(Optional) Part revision
<i>manuf_date</i>	(Optional) Manufacturing date
<i>serial_num</i>	(Optional) Serial Number
<i>CLEI_code</i>	(Optional) CLEI code

Command Mode

- /exec

show hardware access-list lou resource threshold

```
show hardware access-list lou resource threshold [ __readonly__ { current [ { lou [ { resource [ { threshold [
{ <threshold_value> } ] } ] } ] } ] } ] }
```

Syntax Description

show	Show running system information
hardware	Show hardware information
access-list	Access Control List
lou	LOU
resource	hardware resource
threshold	port expansion threshold
<i>__readonly__</i>	(Optional)
current	(Optional)
lou	(Optional)
resource	(Optional)
threshold	(Optional)
<i>threshold_value</i>	(Optional)

Command Mode

- /exec

show hardware access-list resource pooling

show hardware access-list resource pooling [*__readonly__* <mod-num> <status>]

Syntax Description

show	Show running system information
hardware	Show hardware information
access-list	Access Control List
resource	Hardware resource
pooling	ACL programming across TCAM banks
<i>__readonly__</i>	(Optional)
<i>mod-num</i>	(Optional) module number
<i>status</i>	(Optional) Banchaining status

Command Mode

- /exec

show hardware access-list tcam

```
show hardware access-list tcam { { template { nfe | nfe2 | l2-l3 | l3 | <name> | all } } | { region } } [
__readonly__ { TCAM_Region [ { TABLE_Sizes <type> <tcam_size> <tcam_width> } ] } ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
access-list	Access Control List
tcam	Show tcam parameters
region	Show tcam region sizes
__readonly__	(Optional)
TCAM_Region	(Optional)
TABLE_Sizes	(Optional)
<i>type</i>	(Optional)
<i>tcam_size</i>	(Optional)
<i>tcam_width</i>	(Optional)
template	Specify template name
nfe	NFE (Trident2) TCAM template
nfe2	NFE2 (Tomahawk) tcam template
l2-l3	L2-L3 default tcam template
l3	L3 default tcam template
<i>name</i>	Name of custom template to be displayed
all	Display all custom templates

Command Mode

- /exec

show hardware capacity

show hardware capacity

Syntax Description

show	Show running system information
hardware	Hardware related
capacity	Hardware usage levels for Power, Switching Fabric, Flash, etc

Command Mode

- /exec

show hardware capacity eobc

```
show hardware capacity eobc [ __readonly__ { eobc_usage [ <eobc_tx_pps> ] [ <eobc_tx_packets> ] [ <eobc_tx_dropped> ] [ <eobc_rx_pps> ] [ <eobc_rx_packets> ] [ <eobc_rx_dropped> ] } ]
```

Syntax Description

show	Show running system information
hardware	Hardware related
capacity	resource inventory and/or usage level
eobc	EOBC resources
<i>__readonly__</i>	(Optional)
<i>eobc_usage</i>	(Optional)
<i>eobc_tx_packets</i>	(Optional)
<i>eobc_tx_dropped</i>	(Optional)
<i>eobc_tx_pps</i>	(Optional)
<i>eobc_rx_packets</i>	(Optional)
<i>eobc_rx_dropped</i>	(Optional)
<i>eobc_rx_pps</i>	(Optional)

Command Mode

- /exec

show hardware capacity fabric-utilization

```
show hardware capacity fabric-utilization [ __readonly__ { TABLE_fabutil <mod> <bandwidth> <ingress>
<egress> } ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
capacity	resource inventory and/or usage level
fabric-utilization	Show per module Fabric utilization
__readonly__	(Optional)
TABLE_fabutil	(Optional) fabric utilization table
<i>mod</i>	(Optional)
<i>bandwidth</i>	(Optional)
<i>ingress</i>	(Optional)
<i>egress</i>	(Optional)

Command Mode

- /exec

show hardware capacity forwarding

show hardware capacity forwarding

Syntax Description

show	Show running system information
hardware	Hardware related
capacity	Hardware usage levels for Power, Switching Fabric, Flash, etc
forwarding	L2/L3 Forwarding resources

Command Mode

- /exec

show hardware capacity interface

```
show hardware capacity interface [ __readonly__ { TABLE_moddrops <mod_num_drops> <tx_drops>
<rx_drops> <max_tx_port> <max_rx_port> } { TABLE_modbuffers <mod_num_buffers> <tx_buffers>
<rx_buffers> } ]
```

Syntax Description

show	Show running system information
hardware	Hardware related
capacity	Usage levels
interface	Interface Resources - Tx/Rx drops and Tx/Rx buffers
<i>__readonly__</i>	(Optional) Read Only
<i>mod_num_drops</i>	(Optional) Module number for Tx/Rx drops
<i>TABLE_moddrops</i>	(Optional) show module
<i>tx_drops</i>	(Optional) Tx drops
<i>rx_drops</i>	(Optional) Rx drops
<i>max_tx_port</i>	(Optional) Port with max Tx drops
<i>max_rx_port</i>	(Optional) Port with max Rx drops
<i>mod_num_buffers</i>	(Optional) Module number for Tx/Rx buffers
<i>TABLE_modbuffers</i>	(Optional) show module
<i>tx_buffers</i>	(Optional) Tx buffers
<i>rx_buffers</i>	(Optional) Rx buffers

Command Mode

- /exec

show hardware capacity module

```
show hardware capacity module [ __readonly__ { sup_ha_status [ <sup_ha_admin_status> ] [
<sup_ha_oper_status> ] [ <dual_sup_hw_state> ] [ <redundancy_state> ] } { switch_resouces { TABLE_linfo
<mod_num> <model_num> <part_num> <serial_num> } [ { TABLE_xbarinfo <mod_num1> <model_num1>
<part_num1> <serial_num1> } ] } { TABLE_flash_nvram_info <mod_num2> <dev_name> <total_bytes>
<free_bytes> <percent_used> } ]
```

Syntax Description

show	Show running system information
hardware	Hardware related
capacity	resource inventory and/or usage level
module	SUP, LC, XBAR
<i>__readonly__</i>	(Optional)
<i>sup_ha_status</i>	(Optional)
<i>sup_ha_admin_status</i>	(Optional)
<i>sup_ha_oper_status</i>	(Optional)
<i>dual_sup_hw_state</i>	(Optional)
<i>redundancy_state</i>	(Optional)
<i>switch_resouces</i>	(Optional)
TABLE_linfo	(Optional)
<i>mod_num</i>	(Optional)
<i>model_num</i>	(Optional)
<i>part_num</i>	(Optional)
<i>serial_num</i>	(Optional)
TABLE_xbarinfo	(Optional)
<i>mod_num1</i>	(Optional)
<i>model_num1</i>	(Optional)
<i>part_num1</i>	(Optional)
<i>serial_num1</i>	(Optional)
TABLE_flash_nvram_info	(Optional)
<i>mod_num2</i>	(Optional)

<i>dev_name</i>	(Optional)
<i>total_bytes</i>	(Optional)
<i>free_bytes</i>	(Optional)
<i>percent_used</i>	(Optional)

Command Mode

- /exec

show hardware capacity power

```
show hardware capacity power [ __readonly__ { power_summary <ps_redun_mode_admin>
<ps_redun_mode_oper> <power_total> <power_rsvd> <power_rsvd_percent> <power_given_mod>
<power_given_mod_percent> <power_avail> <power_avail_percent> <power_out_actual_draw>
<power_input_actual_draw> } ]
```

Syntax Description

show	Show running system information
hardware	Hardware related
capacity	resource inventory and/or usage level
power	power summary
__readonly__	(Optional)
power_summary	(Optional)
<i>ps_redun_mode_admin</i>	(Optional) Mode: Redundant or Non-redundant
<i>ps_redun_mode_oper</i>	(Optional) Mode: Redundant or Non-redundant
<i>power_total</i>	(Optional)
<i>power_rsvd</i>	(Optional)
<i>power_rsvd_percent</i>	(Optional)
<i>power_given_mod</i>	(Optional)
<i>power_given_mod_percent</i>	(Optional)
<i>power_avail</i>	(Optional)
<i>power_avail_percent</i>	(Optional)
<i>power_out_actual_draw</i>	(Optional) Total Power Output, Actuals
<i>power_input_actual_draw</i>	(Optional) Total Power Input, Actuals

Command Mode

- /exec

show hardware feature-capability

```
show hardware feature-capability [ detailed ] [ __readonly__ [ TABLE_feature_support <feature_name> [
TABLE_module_support <mod_inst> <support> ] ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
feature-capability	show registered features supported
detailed	(Optional) detailed
__readonly__	(Optional)
TABLE_feature_support	(Optional) show features supported
<i>feature_name</i>	(Optional) feature name
TABLE_module_support	(Optional) show registered features supported
<i>mod_inst</i>	(Optional) module instance
<i>support</i>	(Optional) support details

Command Mode

- /exec

show hardware flow aging

```
show hardware flow aging [ instance <inst> ] [ module <num> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
aging	Aging Info
instance	(Optional) Instance
<i>inst</i>	(Optional) Earl Instance
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware flow entry address type

show hardware flow entry address <addr> type { ip | ipv6 | l2 | mpls } [instance <inst>] [module <num>]

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
entry	Netflow Table Entry
address	Netflow Table Address
<i>addr</i>	Netflow Table Address
type	Flow Type
ip	Internet Protocol Version 4
ipv6	Internet Protocol Version 6
l2	Layer 2 Protocol
mpls	MPLS Protocol
instance	(Optional) Instance
<i>inst</i>	(Optional) Earl Instance
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware flow ip

```
show hardware flow ip [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } | { interface
<interface> } } ] [ instance <inst> ] [ detail ] [ module <num> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
ip	Internet Protocol Version 4
monitor	(Optional) Netflow Flow Monitor
<i>mname</i>	(Optional) Netflow Flow Monitor Name
profile	(Optional) Flow Profile
<i>prof_id</i>	(Optional) Netflow Profile ID
vlan	(Optional) Vlan commands
<i>vlan_id</i>	(Optional) VLAN ID 1-4094
interface	(Optional) Interface
<i>interface</i>	(Optional) Interface Name
instance	(Optional) Instance
<i>inst</i>	(Optional) Earl Instance
detail	(Optional) Detailed Output Display
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware flow ipv6

```
show hardware flow ipv6 [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } | { interface
<interface> } } ] [ instance <inst> ] [ detail ] [ module <num> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
ipv6	Internet Protocol Version 6
monitor	(Optional) Netflow Flow Monitor
<i>mname</i>	(Optional) Netflow Flow Monitor Name
profile	(Optional) Flow Profile
<i>prof_id</i>	(Optional) Netflow Profile ID
vlan	(Optional) Vlan commands
<i>vlan_id</i>	(Optional) VLAN ID 1-4094
interface	(Optional) Interface
<i>interface</i>	(Optional) Interface Name
instance	(Optional) Instance
<i>inst</i>	(Optional) Earl Instance
detail	(Optional) Detailed Output Display
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware flow l2

```
show hardware flow l2 [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } } ] [ instance
<inst> ] [ detail ] [ module <num> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
l2	Layer 2 Protocol
monitor	(Optional) Netflow Flow Monitor
<i>mname</i>	(Optional) Netflow Flow Monitor Name
profile	(Optional) Flow Profile
<i>prof_id</i>	(Optional) Netflow Profile ID
vlan	(Optional) Vlan commands
<i>vlan_id</i>	(Optional) VLAN ID 1-4094
instance	(Optional) Instance
<i>inst</i>	(Optional) Earl Instance
detail	(Optional) Detailed Output Display
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware flow sampler

```
show hardware flow sampler { all | count | index <index> | name <sname> } [ detail ] [ instance <inst> ] [
module <num> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
sampler	Flow Sampler
all	Netflow Sampler Usage
count	Netflow Sampler Utilization
index	Netflow Sampler Index
<i>index</i>	Netflow Sampler Index
name	Netflow Sampler Name
<i>sname</i>	Netflow Sampler Name
detail	(Optional) Detailed Output Display
instance	(Optional) Instance
<i>inst</i>	(Optional) Clipper Instance
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware flow utilization

show hardware flow utilization [instance <inst>] [module <num>]

Syntax Description

show	Show running system information
hardware	Show hardware information
flow	Netflow Module
utilization	NT Table Utilization
instance	(Optional) Instance
<i>inst</i>	(Optional) Earl Instance
module	(Optional) Line card module
<i>num</i>	(Optional) slot number

Command Mode

- /exec

show hardware forwarding interface statistics mode

```
show hardware forwarding interface statistics mode [ __readonly__ { system [ { <sysmode> } ] [ {
TABLE_module <module> <modmode> } ] ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
forwarding	Show hardware information for forwarding path
interface	Interface
statistics	Statistics
mode	Statistics mode
__readonly__	(Optional)
system	(Optional)
<i>sysmode</i>	(Optional)
TABLE_module	(Optional)
<i>module</i>	(Optional) Specify a module number
<i>modmode</i>	(Optional)

Command Mode

- /exec

show hardware forwarding memory health detail

```
show hardware forwarding memory health detail [ __readonly__ { memscan_interval <mscan_interval> } {
memscan_rate <mscan_rate> } [ TABLE_ser <table_name> <entry_count> <table_head> <table_tail> [
TABLE_ser_entry_new <n_entry_index> [ <reg_id> ] [ <reg_port> ] [ <reg_index> ] [ <table_id> ] [
<table_index> ] <detections> <corrections> [ <last_detection_ts> ] [ <last_correction_ts> ] ] [
TABLE_ser_entry_old <o_entry_index> <mem_addr> <cause_bits> <event_type> <last_event> <last_time>
] ] [ { parity_detect_counter <parity_detect_cnt> } ] [ { parity_correct_counter <parity_correct_cnt> } ] [ {
reg_parity_detect_counter <reg_parity_detect_cnt> } ] [ { reg_parity_correct_counter <reg_parity_correct_cnt>
} ] [ { tcam_parity_detect_counter <tcam_parity_detect_cnt> } ] [ { tcam_parity_correct_counter
<tcam_parity_correct_cnt> } ] [ { sram_parity_detect_counter <sram_parity_detect_cnt> } ] [ {
sram_parity_correct_counter <sram_parity_correct_cnt> } ] [ { TABLE_ser_tbl_parity <table_id> <detections>
<corrections> } ] ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
forwarding	forwarding information
memory	memory information
health	memory health information
detail	show the detail
__readonly__	(Optional) Read Only
memscan_interval	(Optional) memory scan interval value
<i>mscan_interval</i>	(Optional) mem scan interval
memscan_rate	(Optional) memory scan rate value
<i>mscan_rate</i>	(Optional) mem scan rate
TABLE_ser	(Optional) ser table list
<i>table_name</i>	(Optional) table name
<i>entry_count</i>	(Optional) total entries in table
<i>table_head</i>	(Optional) start of entry index
<i>table_tail</i>	(Optional) end of entry index
TABLE_ser_entry_new	(Optional) ser table entry with new format
<i>n_entry_index</i>	(Optional) entry index
<i>reg_id</i>	(Optional) register id

<i>reg_port</i>	(Optional) port
<i>reg_index</i>	(Optional) register index
<i>table_id</i>	(Optional) table id
<i>table_index</i>	(Optional) table_index
<i>detections</i>	(Optional) parity detetction count
<i>corrections</i>	(Optional) parity correction count
<i>last_detection_ts</i>	(Optional) last detetction timestamp
<i>last_correction_ts</i>	(Optional) last correction timestamp
TABLE_ser_entry_old	(Optional) ser table entry with new format
<i>o_entry_index</i>	(Optional) table entry index
<i>mem_addr</i>	(Optional) memory address
<i>cause_bits</i>	(Optional) cause bit
<i>event_type</i>	(Optional) type of event
<i>last_event</i>	(Optional) last event that occurred
<i>last_time</i>	(Optional) last time of event
parity_detect_counter	(Optional) parity detect count
<i>parity_detect_cnt</i>	(Optional) count of parity detect
parity_correct_counter	(Optional) parity correct count
<i>parity_correct_cnt</i>	(Optional) count of parity correct
reg_parity_detect_counter	(Optional) reg parity detect count
<i>reg_parity_detect_cnt</i>	(Optional) count of reg parity detect
reg_parity_correct_counter	(Optional) reg parity correct count
<i>reg_parity_correct_cnt</i>	(Optional) count of reg parity correct
tcam_parity_detect_counter	(Optional) tcam parity detect count
<i>tcam_parity_detect_cnt</i>	(Optional) count of tcam parity detect
tcam_parity_correct_counter	(Optional) tcam parity correct count
<i>tcam_parity_correct_cnt</i>	(Optional) count of tcam parity correct
sram_parity_detect_counter	(Optional) sram parity detect count
<i>sram_parity_detect_cnt</i>	(Optional) count of sram parity detect

<code>sram_parity_correct_counter</code>	(Optional) sram parity correct count
<code>sram_parity_correct_cnt</code>	(Optional) count of sram parity correct
<code>TABLE_ser_tbl_parity</code>	(Optional) all ser tables
<code>table_id</code>	(Optional) table name
<code>detections</code>	(Optional) parity detection count for ser table
<code>corrections</code>	(Optional) parity correction count for ser table

Command Mode

- /exec

show hardware forwarding memory health summary

```
show hardware forwarding memory health summary [ __readonly__ [ { parity_detect_counter
<parity_detect_cnt> } ] [ { parity_correct_counter <parity_correct_cnt> } ] [ { reg_parity_detect_counter
<reg_parity_detect_cnt> } ] [ { reg_parity_correct_counter <reg_parity_correct_cnt> } ] [ {
tcam_parity_detect_counter <tcam_parity_detect_cnt> } ] [ { tcam_parity_correct_counter
<tcam_parity_correct_cnt> } ] [ { sram_parity_detect_counter <sram_parity_detect_cnt> } ] [ {
sram_parity_correct_counter <sram_parity_correct_cnt> } ] [ { TABLE_ser_tbl_parity <table_id> <detections>
<corrections> } ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
forwarding	forwarding information
memory	memory information
health	memory health information
summary	show the summary
<i>__readonly__</i>	(Optional) Read Only
<i>parity_detect_counter</i>	(Optional) parity detect count
<i>parity_detect_cnt</i>	(Optional) count of parity detect
<i>parity_correct_counter</i>	(Optional) parity correct count
<i>parity_correct_cnt</i>	(Optional) count of parity correct
<i>reg_parity_detect_counter</i>	(Optional) reg parity detect count
<i>reg_parity_detect_cnt</i>	(Optional) count of reg parity detect
<i>reg_parity_correct_counter</i>	(Optional) reg parity correct count
<i>reg_parity_correct_cnt</i>	(Optional) count of reg parity correct
<i>tcam_parity_detect_counter</i>	(Optional) tcam parity detect count
<i>tcam_parity_detect_cnt</i>	(Optional) count of tcam parity detect
<i>tcam_parity_correct_counter</i>	(Optional) tcam parity correct count
<i>tcam_parity_correct_cnt</i>	(Optional) count of tcam parity correct
<i>sram_parity_detect_counter</i>	(Optional) sram parity detect count
<i>sram_parity_detect_cnt</i>	(Optional) count of sram parity detect
<i>sram_parity_correct_counter</i>	(Optional) sram parity correct count

<i>sram_parity_correct_cnt</i>	(Optional) count of sram parity correct
TABLE_ser_tbl_parity	(Optional) all ser tables
<i>table_id</i>	(Optional) table name
<i>detections</i>	(Optional) parity detection count for ser table
<i>corrections</i>	(Optional) parity correction count for ser table

Command Mode

- /exec

show hardware ip verify

```
show hardware [ forwarding ] ip verify [ module <module> ] [ __readonly__ <info_str> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
forwarding	(Optional) Show hardware information for forwarding path
ip	IP
verify	Show IP packet verification checks enabled in hardware
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
<i>info_str</i>	(Optional) IDS Check Stats

Command Mode

- /exec

show hardware profile buffer monitor show hardware profile buffer monitor internal

```
show hardware profile buffer monitor [ interface <intf-num> | buffer-block <buf-blk> | multicast <mcst-blk>
] { brief | detail [ last <samples-per-intf> ] | sampling } [ module <module> ] | show hardware profile buffer
monitor { internal-raw | summary [ module <module> ] } [ __readonly__ <cmd_name> <cmd_issue_time>
[ TABLE_summary <summary_util_name> <summary_1sec_util> <summary_5sec_util>
<summary_60sec_util> <summary_5min_util> <summary_1hr_util> <summary_total_buffer>
<summary_class_threshold> ] [ TABLE_ucst_hdr <ucst_hdr_util_name> <ucst_hdr_1sec_util>
<ucst_hdr_5sec_util> <ucst_hdr_60sec_util> <ucst_hdr_5min_util> <ucst_hdr_1hr_util>
<ucst_hdr_total_buffer> <ucst_hdr_class_threshold> ] [ TABLE_brief_entry <brief_util_name>
<brief_1sec_util> <brief_5sec_util> <brief_60sec_util> <brief_5min_util> <brief_1hr_util> ] [
TABLE_mcst_hdr <mcst_hdr_util_name> <mcst_hdr_1sec_util> <mcst_hdr_5sec_util> <mcst_hdr_60sec_util>
<mcst_hdr_5min_util> <mcst_hdr_1hr_util> <mcst_hdr_total_buffer> <mcst_hdr_class_threshold> ] [
TABLE_detail_entry <detail_util_name> <detail_util_state> <time_stamp> <384k_util> <768k_util>
<1152k_util> <1536k_util> <1920k_util> <2304k_util> <2688k_util> <3072k_util> <3456k_util>
<3840k_util> <4224k_util> <4608k_util> <4992k_util> <5376k_util> <5760k_util> <6144k_util> ] [
TABLE_sampling <sampling_interval> ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware profile buffer monitor data
profile	profile buffer monitor data
buffer	buffer
monitor	buffer monitor
interface	(Optional) show buffer monitoring data of an interface
<i>intf-num</i>	(Optional) show buffer monitoring data of an interface
buffer-block	(Optional) buffer block
<i>buf-blk</i>	(Optional) buffer block
multicast	(Optional) multicast buffer block
<i>mcst-blk</i>	(Optional) multicast buffer block
brief	show brief buffer monitor data
detail	show detail buffer monitor data
internal-raw	show buffer monitoring internal raw data
summary	show summary buffer monitor data
sampling	show sampling interval

last	(Optional) show detail buffer monitor data for last N intervals
<i>samples-per-intf</i>	(Optional) number of samples per interface, max 300
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
<u>__readonly__</u>	(Optional) Read Only
<i>cmd_name</i>	(Optional) Command Name
<i>cmd_issue_time</i>	(Optional) Command Issue Time
TABLE_summary	(Optional) Table Summary
<i>summary_util_name</i>	(Optional) Names of Summary Utilization
<i>summary_1sec_util</i>	(Optional) Summary 1sec Buffer Utilization
<i>summary_5sec_util</i>	(Optional) Summary 5sec Buffer Utilization
<i>summary_60sec_util</i>	(Optional) Summary 60sec Buffer Utilization
<i>summary_5min_util</i>	(Optional) Summary 5min Buffer Utilization
<i>summary_1hr_util</i>	(Optional) Summary 1hour Buffer Utilization
<i>summary_total_buffer</i>	(Optional) Summary Total Buffer Available
<i>summary_class_threshold</i>	(Optional) Summary Buffer Threshold of Default Class
TABLE_ucst_hdr	(Optional) Table Ucst Header
<i>ucst_hdr_util_name</i>	(Optional) Names of Utilization
<i>ucst_hdr_1sec_util</i>	(Optional) Ucst 1sec Buffer Utilization
<i>ucst_hdr_5sec_util</i>	(Optional) Ucst 5sec Buffer Utilization
<i>ucst_hdr_60sec_util</i>	(Optional) Ucst 60sec Buffer Utilization
<i>ucst_hdr_5min_util</i>	(Optional) Ucst 5min Buffer Utilization
<i>ucst_hdr_1hr_util</i>	(Optional) Ucst 1hour Buffer Utilization
<i>ucst_hdr_total_buffer</i>	(Optional) Ucst Total Buffer Available
<i>ucst_hdr_class_threshold</i>	(Optional) Ucst Buffer Threshold of Default Class
TABLE_brief_entry	(Optional) Table Brief Entry
<i>brief_util_name</i>	(Optional) Brief Names of Utilization
<i>brief_1sec_util</i>	(Optional) Brief 1sec Buffer Utilization
<i>brief_5sec_util</i>	(Optional) Brief 5sec Buffer Utilization

<i>brief_60sec_util</i>	(Optional) Brief 60sec Buffer Utilization
<i>brief_5min_util</i>	(Optional) Brief 5min Buffer Utilization
<i>brief_1hr_util</i>	(Optional) Brief 1hour Buffer Utilization
TABLE_mcst_hdr	(Optional) Table Mcst Header
<i>mcst_hdr_util_name</i>	(Optional) Mcst Buffer Block Names of Utilization
<i>mcst_hdr_1sec_util</i>	(Optional) Mcst Buffer Block 1sec Buffer Utilization
<i>mcst_hdr_5sec_util</i>	(Optional) Mcst Buffer Block 5sec Buffer Utilization
<i>mcst_hdr_60sec_util</i>	(Optional) Mcst Buffer Block 60sec Buffer Utilization
<i>mcst_hdr_5min_util</i>	(Optional) Mcst Buffer Block 5min Buffer Utilization
<i>mcst_hdr_1hr_util</i>	(Optional) Mcst Buffer Block 1hour Buffer Utilization
<i>mcst_hdr_total_buffer</i>	(Optional) Mcst Total Buffer Available
<i>mcst_hdr_class_threshold</i>	(Optional) Mcst Buffer Threshold of Default Class
TABLE_detail_entry	(Optional) Table Detail Entry
<i>detail_util_name</i>	(Optional) Detail Names of Utilization
<i>detail_util_state</i>	(Optional) Detail State of Utilization
<i>time_stamp</i>	(Optional) Time Stamp of Entry
<i>384k_util</i>	(Optional) 384KB Buffer Utilization
<i>768k_util</i>	(Optional) 768KB Buffer Utilization
<i>1152k_util</i>	(Optional) 1152KB Buffer Utilization
<i>1536k_util</i>	(Optional) 1536KB Buffer Utilization
<i>1920k_util</i>	(Optional) 1920KB Buffer Utilization
<i>2304k_util</i>	(Optional) 2304KB Buffer Utilization
<i>2688k_util</i>	(Optional) 2688KB Buffer Utilization
<i>3072k_util</i>	(Optional) 3072KB Buffer Utilization
<i>3456k_util</i>	(Optional) 3456KB Buffer Utilization
<i>3840k_util</i>	(Optional) 3840KB Buffer Utilization
<i>4224k_util</i>	(Optional) 4224KB Buffer Utilization
<i>4608k_util</i>	(Optional) 4608KB Buffer Utilization
<i>4992k_util</i>	(Optional) 4992KB Buffer Utilization

show hardware profile buffer monitor show hardware profile buffer monitor internal

<i>5376k_util</i>	(Optional) 5376KB Buffer Utilization
<i>5760k_util</i>	(Optional) 5760KB Buffer Utilization
<i>6144k_util</i>	(Optional) 6144KB Buffer Utilization
TABLE_sampling	(Optional) Table Sampling
<i>sampling_interval</i>	(Optional) Sampling Interval

Command Mode

- /exec

show hardware profile forwarding-mode

show hardware profile forwarding-mode

Syntax Description

show	Show running system information
hardware	Show hardware profile forwarding-mode
profile	profile forwarding-mode
forwarding-mode	forwarding-mode

Command Mode

- /exec

show hardware profile latency monitor sampling show hardware profile latency monitor

```
show hardware profile latency monitor { sampling | threshold } [ module <module> ] | show hardware profile
latency monitor { { summary [ detail | clear-timestamp ] } [ interface <intf-num> ] | { summary [ brief | sort
| top ] } | { raw [ verbose ] } [ module <module> ] } [ __readonly__ <cmd_issue_time> <device_instance> [
TABLE_sampling <sampling_interval> ] [ TABLE_threshold <threshold_avg> <threshold_max> ] [
TABLE_summary <summary_egress_port> <summary_sampling_interval> <summary_min_latency>
<summary_max_latency> <summary_avg_latency> <summary_std_deviation> ] [ TABLE_detail
<detail_timestamp> <detail_ifindex> <detail_fcnt> <detail_min_latency> <detail_max_latency>
<detail_avg_latency> ] [ TABLE_brief <brief_egress_port> <brief_avg_latency> ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware profile latency monitor data
profile	profile latency monitor data
latency	latency
monitor	latency monitor
sampling	show sampling interval
threshold	show threshold configured
summary	show switch-wide latency monitor data
detail	(Optional) show switch-wide or per-interface raw latency monitor data
clear-timestamp	(Optional) show switch-wide or per-interface latency clear timestamp
interface	(Optional) show per-interface latency monitor data
<i>intf-num</i>	(Optional) show per-interface latency monitor data
brief	(Optional) show switch-wide average latency
sort	(Optional) show switch-wide average latency in descending order
top	(Optional) show switch-wide top ten average latency
raw	show switch-wide or per-interface raw latency monitor data
verbose	(Optional) show switch-wide or per-interface raw latency monitor data
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
<i>__readonly__</i>	(Optional) Read only

<i>cmd_issue_time</i>	(Optional) Command issue time
<i>device_instance</i>	(Optional) Device instance
TABLE_sampling	(Optional) Table Sampling
<i>sampling_interval</i>	(Optional) Sampling Interval
TABLE_threshold	(Optional) Table Threshold
<i>threshold_avg</i>	(Optional) Threshold Average
<i>threshold_max</i>	(Optional) Threshold Max
TABLE_summary	(Optional) Table summary
<i>summary_egress_port</i>	(Optional) Summary Egress Port
<i>summary_sampling_interval</i>	(Optional) Summary Sampling Interval
<i>summary_min_latency</i>	(Optional) Summary Min latency
<i>summary_max_latency</i>	(Optional) Summary Max latency
<i>summary_avg_latency</i>	(Optional) Summary Avg latency
<i>summary_std_deviation</i>	(Optional) Summary Std Deviation
TABLE_detail	(Optional) Table summary detail
<i>detail_timestamp</i>	(Optional) Detail Timestamp
<i>detail_ifindex</i>	(Optional) Detail ifindex
<i>detail_fcnt</i>	(Optional) Detail fcnt
<i>detail_min_latency</i>	(Optional) Detail Min latency
<i>detail_max_latency</i>	(Optional) Detail Max latency
<i>detail_avg_latency</i>	(Optional) Detail Avg latency
TABLE_brief	(Optional) Table summary brief
<i>brief_egress_port</i>	(Optional) Brief Egress Port
<i>brief_avg_latency</i>	(Optional) Brief Avg latency

Command Mode

- /exec

show hardware profile module

show hardware profile module <module>

Syntax Description

show	Show running system information
hardware	Show hardware profile
profile	Profile settings
module	Enter module number
<i>module</i>	

Command Mode

- /exec

show hardware profile packet-drop

```
show hardware profile packet-drop { status | data [ instance <cap_instance> ] | event [ instance <cap_instance> ] }
```

Syntax Description

show	Show running system information
hardware	Change hardware usage settings
profile	Profile settings
packet-drop	Packet Drop parameters
status	Packet Drop status
data	Packet Drop circular-buffer data
instance	(Optional) Packet Drop captured instance
<i>cap_instance</i>	(Optional) Value 1-5
event	Packet Drop event-buffer data
instance	(Optional) Packet Drop captured instance
<i>cap_instance</i>	(Optional) Value 1-5

Command Mode

- /exec

show hardware profile status

```
show hardware profile status [ module <module> ] [ detail ] [ __readonly__ { <total_lpm> <total_host>
<reserved_lpm> <max_host4_limit> <max_host6_limit> <max_mcast_limit> <max_mcast6_limit>
<used_lpm_total> <used_v4_lpm> <used_v6_lpm> <used_v6_lpm_128> <used_host_lpm_total>
<used_host_v4_lpm> <used_host_v6_lpm> <used_mcast> <used_mcast6> <used_mcast_oifl>
<used_host_in_host_total> <used_host4_in_host> <used_host6_in_host> <mfib_fd_status>
<mfib_fd_maxroute> <mfib_fd_count> <max_v6_lpm_65_to_127_limit> <max_v6_lpm_limit>
<max_ecmp_table_limit> <used_ecmp_table> <lpm_to_host_migrate_table> <host_to_lpm_migrate_table>
<max_mcast_transit_route_limit> <used_mcast_transit_routes> <max_ecmp_nh_table_limit>
<used_ecmp_nh_table> } ]
```

Syntax Description

show	Show running system information
hardware	Show hardware usage settings
profile	Show current table usage
status	Show status of dynamic resource allocation
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
detail	(Optional) Show detailed information
<i>__readonly__</i>	(Optional) Read only
<i>total_lpm</i>	(Optional) Total LPM Entries
<i>total_host</i>	(Optional) Total Host Entries
<i>reserved_lpm</i>	(Optional) Reserved LPM Entries
<i>max_host4_limit</i>	(Optional) Max Host4 Limit Entries
<i>max_host6_limit</i>	(Optional) Max Host6 Limit Entries
<i>max_mcast_limit</i>	(Optional) Max Mcast Limit Entries
<i>max_mcast6_limit</i>	(Optional) Max IPv6 Mcast Limit Entries
<i>used_lpm_total</i>	(Optional) Used LPM Entries (Total)
<i>used_v4_lpm</i>	(Optional) Used IPv4 LPM Entries
<i>used_v6_lpm</i>	(Optional) Used IPv6 LPM Entries
<i>used_v6_lpm_128</i>	(Optional) Used IPv6 LPM_128 Entries
<i>used_host_lpm_total</i>	(Optional) Used Host Entries in LPM (Total)
<i>used_host_v4_lpm</i>	(Optional) Used Host4 Entries in LPM

<i>used_host_v6_lpm</i>	(Optional) Used Host6 Entries in LPM
<i>used_mcast</i>	(Optional) Used Mcast Entries
<i>used_mcast6</i>	(Optional) Used IPv6 Mcast Entries
<i>used_mcast_oifl</i>	(Optional) Used Mcast OIFL Entries
<i>used_host_in_host_total</i>	(Optional) Used Host Entries in Host (Total)
<i>used_host4_in_host</i>	(Optional) Used Host4 Entries in Host
<i>used_host6_in_host</i>	(Optional) Used Host6 Entries in Host
<i>mfib_fd_status</i>	(Optional) MFIB fd status
<i>mfib_fd_maxroute</i>	(Optional) MFIB fd maxroute
<i>mfib_fd_count</i>	(Optional) MFIB fd count
<i>max_v6_lpm_65_to_127_limit</i>	(Optional) Max Ucast IPv6 LPM_65_to_127 Limit Entries
<i>max_v6_lpm_limit</i>	(Optional) Max Ucast IPv6 LPM Limit Entries
<i>max_ecmp_table_limit</i>	(Optional) Max ECMP table Limit Entries
<i>used_ecmp_table</i>	(Optional) Used ECMP Table Entries
<i>lpm_to_host_migrate_table</i>	(Optional) Times Route Migrated from LPM to Host Table
<i>host_to_lpm_migrate_table</i>	(Optional) Times Route Migrated from Host to LPM Table
<i>max_mcast_transit_route_limit</i>	(Optional) Max Mcast Transit Route Limit Entries
<i>used_mcast_transit_routes</i>	(Optional) Used Mcast Transit Routes
<i>max_ecmp_nh_table_limit</i>	(Optional) Max ECMP NH table Limit Entries
<i>used_ecmp_nh_table</i>	(Optional) Used ECMP NH Table Entries

Command Mode

- /exec

show hardware profile tcam region

```
show hardware profile tcam region [ __readonly__ { TCAM_Region [ { TABLE_Sizes <tcam_compat_type>
<tcam_compat_size> <tcam_compat_width> } ] } ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
profile	profile
tcam	Show tcam parameters
region	Show tcam region sizes
<i>__readonly__</i>	(Optional)
TCAM_Region	(Optional)
TABLE_Sizes	(Optional)
<i>tcam_compat_type</i>	(Optional)
<i>tcam_compat_size</i>	(Optional)
<i>tcam_compat_width</i>	(Optional)

Command Mode

- /exec

show hardware qos afd profile

```
show hardware qos afd profile [ module <module> ] [ __readonly__ TABLE_qos_afd_profile <module>
<prof-desc> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
afd	Show Approximate Fair Dropping config
profile	Show AFD profile config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_afd_profile	(Optional) the xml qos_afd_profile configuration
<i>prof-desc</i>	(Optional) profile description

Command Mode

- /exec

show hardware qos burst-detect max-records

show hardware qos burst-detect max-records [__readonly__ TABLE_qos_burstdetect_maxrecords]

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
burst-detect	Show oobst burst-detect info
max-records	Show oobst burst-detect max-records
__readonly__	(Optional)
TABLE_qos_burstdetect_maxrecords	(Optional) the xml qos_burst-detect max-records configuration

Command Mode

- /exec

show hardware qos eoq stats-class

```
show hardware qos eoq stats-class [ module <module> ] [ __readonly__ TABLE_qos_eoq_stats_class <module>
<eoq-stats-class-desc> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show QoS related information
eoq	Show Extended Output Queue(EOQ) related information
stats-class	Show EOQ Statistics class selection config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_eoq_stats_class	(Optional) the xml qos_eoq_stats_class configuration
<i>eoq-stats-class-desc</i>	(Optional) selected class description

Command Mode

- /exec

show hardware qos include ipg

show hardware qos include ipg [module <module>] [__readonly__ TABLE_qos_include_ipg <module>]

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
include	Show include config
ipg	Show whether to include IPG in Shaping/Policing config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_include_ipg	(Optional) the xml qos_include_ipg configuration

Command Mode

- /exec

show hardware qos ing-pg-hdrm-reserve

```
show hardware qos ing-pg-hdrm-reserve [ module <module> ] [ __readonly__
TABLE_qos_ing_pg_hdrm_reserve <module> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
ing-pg-hdrm-reserve	Show ing-pg-hdrm-reserve config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
__readonly__	(Optional)
TABLE_qos_ing_pg_hdrm_reserve	(Optional) the xml qos_ing_pg_hdrm_reserve configuration

Command Mode

- /exec

show hardware qos ing-pg-no-min

```
show hardware qos ing-pg-no-min [ module <module> ] [ __readonly__ TABLE_qos_ing_pg_no_min
<module> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
ing-pg-no-min	Show ing-pg-no-min config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_ing_pg_no_min	(Optional) the xml qos_ing_pg_no_min configuration

Command Mode

- /exec

show hardware qos ing-pg-share

```
show hardware qos ing-pg-share [ module <module> ] [ __readonly__ TABLE_qos_ing_pg_share <module> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
ing-pg-share	Show ing-pg-share config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_ing_pg_share	(Optional) the xml qos_ing_pg_share configuration

Command Mode

- /exec

show hardware qos min-buffer

```
show hardware qos min-buffer [ module <module> ] [ __readonly__ TABLE_qos_min_buffer_profile
<module> <buff-prof-desc> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
min-buffer	Show min-buffer config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_min_buffer_profile	(Optional) the xml qos_min_buffer_profile configuration
<i>buff-prof-desc</i>	(Optional) buffer profile description

Command Mode

- /exec

show hardware qos ns-buffer-profile

```
show hardware qos ns-buffer-profile [ module <module> ] [ __readonly__ TABLE_qos_ns_buffer_profile
<module> <buff-prof-desc> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show qos related information
ns-buffer-profile	Show ns-buffer-profile config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_ns_buffer_profile	(Optional) the xml qos_ns_buffer_profile configuration
<i>buff-prof-desc</i>	(Optional) buffer profile description

Command Mode

- /exec

show hardware qos ns-mcq3-alias

```
show hardware qos ns-mcq3-alias [ module <module> ] [ __readonly__ TABLE_qos_ns_mcq3_alias <module>
<ns-mcq3-alias-desc> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
qos	Show QoS related information
ns-mcq3-alias	Show NS mc-queue-3 alias class selection config
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE_qos_ns_mcq3_alias	(Optional) the xml qos_ns_mcq3_alias configuration
<i>ns-mcq3-alias-desc</i>	(Optional) selected class description

Command Mode

- /exec

show hardware rate-limiter

```
show hardware rate-limiter [ module <module> ] [ layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2
<l2-opts> | <opts> | fl <fl-opts> | span-egress | urpf-fail ] [ __readonly__ TABLE hardware_rate_limiter
<rate-limit-class> <class-descr> <module> <rate-limit-configured> [ <rate-limit-allowed> ] [
<rate-limit-dropped> ] [ <rate-limit-total> ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
rate-limiter	Show Rate-Limiter configs and statistics
layer-3	(Optional) Layer-3 control and Routed packets
<i>l3-opts</i>	(Optional)
multicast	(Optional) Multicast data packets
<i>mcast-opts</i>	(Optional)
layer-2	(Optional) Layer-2 control and Bridged packets
<i>l2-opts</i>	(Optional)
<i>opts</i>	(Optional)
fl	(Optional) Control packets from F1 modules to supervisor
<i>fl-opts</i>	(Optional)
span-egress	(Optional) SPAN/ERSPAN egress packets
urpf-fail	(Optional) URPF fail packets
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE hardware_rate_limiter	(Optional) the xml Rate-Limiter configuration and statistics
<i>rate-limit-class</i>	(Optional) the xml rate limiter class
<i>class-descr</i>	(Optional) class description
<i>module</i>	(Optional) the xml module number
<i>rate-limit-configured</i>	(Optional) the xml rate-limit-configured
<i>rate-limit-allowed</i>	(Optional) the xml rate-limit-allowed

<i>rate-limit-dropped</i>	(Optional) the xml rate-limit-dropped
<i>rate-limit-total</i>	(Optional) the xml rate-limit-total

Command Mode

- /exec

show hardware rate-limiter

```
show hardware rate-limiter [ module <module> ] [ layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2
<l2-opts> | <opts> | fl <fl-opts> | span-egress | urpf-fail ] [ __readonly__ TABLE hardware_rate_limiter
<rate-limit-class> <class-descr> <module> <rate-limit-configured> [ <rate-limit-allowed> ] [
<rate-limit-dropped> ] [ <rate-limit-total> ] ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
rate-limiter	Show Rate-Limiter configs and statistics
layer-3	(Optional) Layer-3 control and Routed packets
<i>l3-opts</i>	(Optional)
multicast	(Optional) Multicast data packets
<i>mcast-opts</i>	(Optional)
layer-2	(Optional) Layer-2 control and Bridged packets
<i>l2-opts</i>	(Optional)
<i>opts</i>	(Optional)
fl	(Optional) Control packets from F1 modules to supervisor
<i>fl-opts</i>	(Optional)
span-egress	(Optional) SPAN/ERSPAN egress packets
urpf-fail	(Optional) URPF fail packets
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
<i>__readonly__</i>	(Optional)
TABLE hardware_rate_limiter	(Optional) the xml Rate-Limiter configuration and statistics
<i>rate-limit-class</i>	(Optional) the xml rate limiter class
<i>class-descr</i>	(Optional) class description
<i>module</i>	(Optional) the xml module number
<i>rate-limit-configured</i>	(Optional) the xml rate-limit-configured
<i>rate-limit-allowed</i>	(Optional) the xml rate-limit-allowed

<i>rate-limit-dropped</i>	(Optional) the xml rate-limit-dropped
<i>rate-limit-total</i>	(Optional) the xml rate-limit-total

Command Mode

- /exec

show hardware rate-limiter span-egress

```
show hardware rate-limiter span-egress [ __readonly__ TABLE hardware_rate_limiter <rate-limit-class>
<class-descr> <module> <rate-limit-configured> <rate-limit-allowed> <rate-limit-dropped> <rate-limit-total>
]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
rate-limiter	Show Rate-Limiter configs and statistics
span-egress	SPAN/ERSPAN egress packets
__readonly__	(Optional)
TABLE hardware_rate_limiter	(Optional) the xml Rate-Limiter configuration and statistics
<i>rate-limit-class</i>	(Optional) the xml rate limiter class
<i>class-descr</i>	(Optional) class description
<i>module</i>	(Optional) the xml module number
<i>rate-limit-configured</i>	(Optional) the xml rate-limit-configured
<i>rate-limit-allowed</i>	(Optional) the xml rate-limit-allowed
<i>rate-limit-dropped</i>	(Optional) the xml rate-limit-dropped
<i>rate-limit-total</i>	(Optional) the xml rate-limit-total

Command Mode

- /exec

show hardware rl snmp class-id

```
show hardware rl snmp class-id <class-id> [ __readonly__ TABLE-classRateLimiterTable <class-id-out>
<class-descr> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
rl	Show Rate-Limiter configs and statistics
snmp	Show Rate-Limiter snmp information
class-id	rate-limiter class-id
<i>class-id</i>	rate-limiter class
<i>__readonly__</i>	(Optional)
TABLE-classRateLimiterTable	(Optional) Class Rate Limiter Table
<i>class-id-out</i>	(Optional) class if out
<i>class-descr</i>	(Optional) class description

Command Mode

- /exec

show hardware rl snmp global class-id

```
show hardware rl snmp global class-id <class-id> [ __readonly__ TABLE-globalRateLimiterTable
<class-id-out> <rate-limit-configured> <rate-limit-allowed> <rate-limit-dropped> <rate-limit-total> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
rl	Show Rate-Limiter configs and statistics
snmp	Show Rate-Limiter snmp information
global	Show Global information
class-id	rate-limiter class-id
<i>class-id</i>	rate-limiter class
<i>__readonly__</i>	(Optional)
TABLE-globalRateLimiterTable	(Optional) Global Rate Limiter Table
<i>class-id-out</i>	(Optional) class if out
<i>rate-limit-configured</i>	(Optional) rate-limit-configured
<i>rate-limit-allowed</i>	(Optional) rate-limit-allowed
<i>rate-limit-dropped</i>	(Optional) rate-limit-dropped
<i>rate-limit-total</i>	(Optional) rate-limit-total

Command Mode

- /exec

show hardware rl snmp local snmp-index class-id

```
show hardware rl snmp local snmp-index <snmp-index> class-id <class-id> [ __readonly__
TABLE-localRateLimiterTable <snmp-index-out> <class-id-out> <rate-limit-configured>
<rate-limit-configured-source> <rate-limit-allowed> <rate-limit-dropped> <rate-limit-total> ]
```

Syntax Description

show	Show running system information
hardware	Show hardware information
rl	Show Rate-Limiter configs and statistics
snmp	Show Rate-Limiter snmp information
local	Show Local information
snmp-index	snmp physical index
<i>snmp-index</i>	physical index
class-id	rate-limiter class-id
<i>class-id</i>	rate-limiter class
__readonly__	(Optional)
TABLE-localRateLimiterTable	(Optional) Local Rate Limiter Table
<i>snmp-index-out</i>	(Optional) snmp index out
<i>class-id-out</i>	(Optional) class if out
<i>rate-limit-configured</i>	(Optional) rate-limit-configured
<i>rate-limit-configured-source</i>	(Optional) rate-limit-configured-source
<i>rate-limit-allowed</i>	(Optional) rate-limit-allowed
<i>rate-limit-dropped</i>	(Optional) rate-limit-dropped
<i>rate-limit-total</i>	(Optional) rate-limit-total

Command Mode

- /exec

show hostname

```
show { hostname | switchname } [ __readonly__ { <hostname> } ]
```

Syntax Description

show	Show running system information
hostname	show the system's hostname
switchname	show the system's hostname
__readonly__	(Optional) Read Only
<i>hostname</i>	(Optional)

Command Mode

- /exec

show hosts

```
show hosts [ __readonly__ [ <dnslookup> ] [ <dnsnameservice> ] [ { TABLE_vrf <vrfname> [
<defaultdomains> ] [ <additionaldomainserver> ] [ <domainservers> ] [ <nameservice> ] [ <dhcpdomains>
] [ <dhcpdomainservers> ] } ] [ { TABLE_dnsconfigvrf <dnsvrfname> [ <usevrf> ] [ <token> ] [ {
TABLE_dnsconfigvrfconfig <config> } ] } ] [ { TABLE_hosts <host> [ <address> ] } ] ]
```

Syntax Description

show	Show running system information
hosts	Show information about DNS
__readonly__	(Optional)
<i>dnslookup</i>	(Optional) dns lookup enable status
<i>dnsnameservice</i>	(Optional) name service
TABLE_vrf	(Optional) vrf domain servers
<i>vrfname</i>	(Optional) vrf name
<i>defaultdomains</i>	(Optional) default domain
<i>additionaldomainserver</i>	(Optional) additionaldomain
<i>domainservers</i>	(Optional) domain server
<i>nameservice</i>	(Optional) name service
<i>dhcpdomains</i>	(Optional) dhcp domains
<i>dhcpdomainservers</i>	(Optional) dhcpservers
TABLE_dnsconfigvrf	(Optional) dns config vrf
<i>dnsvrfname</i>	(Optional) vrfname
<i>usevrf</i>	(Optional) usevrf
<i>token</i>	(Optional) token
TABLE_dnsconfigvrfconfig	(Optional) dns config vrf config
<i>config</i>	(Optional) token
TABLE_hosts	(Optional) all configured dns hosts
<i>host</i>	(Optional) xml host information
<i>address</i>	(Optional) xml address information

Command Mode

- /exec

show hsrp

```
show hsrp [ interface <interface-id> ] [ group <group-number> ] [ active | init | learn | listen | speak | standby
] + [ all ] [ brief [ all ] | detail ] [ ipv4 | ipv6 ] [ __readonly__ <show_hsrp_start> { TABLE_grp_detail
<sh_if_index> <sh_group_num> <sh_group_type> <sh_group_version> <sh_group_state> [ <sh_state_reason>
] <sh_prio> <sh_cfg_prio> <sh_fwd_lower_threshold> <sh_fwd_upper_threshold> <sh_can_forward>
<sh_preempt> [ <sh_preempt_min_delay> ] [ <sh_preempt_min_delay_active> ] [ <sh_preempt_reload_delay>
] [ <sh_preempt_reload_delay_active> ] [ <sh_preempt_sync_delay> ] [ <sh_preempt_sync_delay_active> ]
<sh_cur_hello> <sh_cur_hello_attr> [ <sh_cfg_hello> ] [ <sh_cfg_hello_attr> ] [ <sh_active_hello> ]
<sh_cur_hold> <sh_cur_hold_attr> [ <sh_cfg_hold> ] [ <sh_cfg_hold_attr> ] [ <sh_vip> | <sh_vip_v6> ]
<sh_vip_attr> <sh_num_vip_sec> { [ TABLE_grp_vip_sec <sh_vip_sec> ] } [ <sh_active_router_addr> |
<sh_active_router_addr_v6> ] <sh_active_router_prio> [ <sh_active_router_timer> ] [
<sh_standby_router_addr> | <sh_standby_router_addr_v6> ] <sh_standby_router_prio>
<sh_authentication_type> <sh_authentication_data> [ <sh_keystring_attr> ] [ <sh_keystring_timeout> ] [
<sh_keystring_cur_valid> ] <sh_vmac> <sh_vmac_attr> <sh_num_of_state_changes> [ <sh_last_state_change>
] <sh_num_of_total_state_changes> [ <sh_last_total_state_change> ] { [ TABLE_grp_track_obj <sh_track_obj>
<sh_track_obj_state> <sh_track_obj_prio> ] } <sh_num_track_obj> <sh_ip_redund_name>
<sh_ip_redund_name_attr> } <show_hsrp_end> ]
```

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
interface	(Optional) Groups on this interface
<i>interface-id</i>	(Optional) Interface
active	(Optional) Groups in active state
init	(Optional) Groups in init state
listen	(Optional) Groups in listen state
standby	(Optional) Groups in standby state
learn	(Optional) Groups in learn state
speak	(Optional) Groups in speak state
group	(Optional) Group number
<i>group-number</i>	(Optional) Group Number
all	(Optional) Include groups in disabled state
brief	(Optional) Brief output
detail	(Optional) Detailed output
ipv4	(Optional) HSRP V4 Groups
ipv6	(Optional) HSRP V6 Groups

<i>all</i>	(Optional) Display all VIPs
<i>__readonly__</i>	(Optional) Read only
<i>show_hsrp_start</i>	(Optional) Show hsrp start
<i>TABLE_grp_detail</i>	(Optional) Group table detail
<i>sh_if_index</i>	(Optional) Interface type and number
<i>sh_group_num</i>	(Optional) Group number
<i>sh_group_state</i>	(Optional) HSRP state
<i>sh_state_reason</i>	(Optional) Reason
<i>sh_group_type</i>	(Optional) Group type
<i>sh_group_version</i>	(Optional) Group version
<i>sh_prio</i>	(Optional) Priority
<i>sh_cfg_prio</i>	(Optional) Configured priority
<i>sh_fwd_lower_threshold</i>	(Optional) Lower threshold value
<i>sh_fwd_upper_threshold</i>	(Optional) Upper threshold value
<i>sh_can_forward</i>	(Optional) Current forwarding status
<i>sh_preempt</i>	(Optional) Preemption enabled/not
<i>sh_preempt_min_delay</i>	(Optional) Preemption min delay
<i>sh_preempt_min_delay_active</i>	(Optional) Active preemption min delay
<i>sh_preempt_reload_delay</i>	(Optional) Preemption reload delay
<i>sh_preempt_reload_delay_active</i>	(Optional) Active preemption reload delay
<i>sh_preempt_sync_delay</i>	(Optional) Preemption sync delay
<i>sh_preempt_sync_delay_active</i>	(Optional) Active preemption sync delay
<i>sh_cur_hello</i>	(Optional) Current hello time
<i>sh_cur_hello_attr</i>	(Optional) Hello time in ms/not
<i>sh_cfg_hello</i>	(Optional) Configured hello time
<i>sh_cfg_hello_attr</i>	(Optional) Hello time in ms/not
<i>sh_active_hello</i>	(Optional) Active hello time
<i>sh_cur_hold</i>	(Optional) Current hold time
<i>sh_cur_hold_attr</i>	(Optional) Hello time in ms/not

<i>sh_cfg_hold</i>	(Optional) Configured hold time
<i>sh_cfg_hold_attr</i>	(Optional) Hello time in ms/not
<i>sh_vip</i>	(Optional) Virtual IP address
<i>sh_vip_attr</i>	(Optional) Virtual IP address attribute
<i>sh_num_vip_sec</i>	(Optional) Number of Secondary virtual IP address
TABLE_grp_vip_sec	(Optional) Group secondary ip address
<i>sh_vip_sec</i>	(Optional) Secondary virtual IP address
<i>sh_active_router_addr</i>	(Optional) Active router address
<i>sh_active_router_prio</i>	(Optional) Active router priority
<i>sh_active_router_timer</i>	(Optional) Active router expiry timer
<i>sh_standby_router_addr</i>	(Optional) Standby router address
<i>sh_standby_router_prio</i>	(Optional) Standby router priority
<i>sh_authentication_type</i>	(Optional) Authentication type
<i>sh_authentication_data</i>	(Optional) Authentication data
<i>sh_keystring_attr</i>	(Optional) Keysting attribute
<i>sh_keystring_timeout</i>	(Optional) Keysting timeout
<i>sh_keystring_cur_valid</i>	(Optional) Keysting current valid time
<i>sh_vmac</i>	(Optional) Virtual MAC
<i>sh_vmac_attr</i>	(Optional) Virtual MAC attribute
<i>sh_num_of_state_changes</i>	(Optional) Number of state changes
<i>sh_last_state_change</i>	(Optional) Last state change time
<i>sh_num_of_total_state_changes</i>	(Optional) Number of total state changes
<i>sh_last_total_state_change</i>	(Optional) Last total state change time
<i>sh_num_track_obj</i>	(Optional) Number of tracked objects
TABLE_grp_track_obj	(Optional) Group tracked objects
<i>sh_track_obj</i>	(Optional) Tracked object
<i>sh_track_obj_state</i>	(Optional) State of tracked object
<i>sh_track_obj_prio</i>	(Optional) Tracked object priority decrement
<i>sh_ip_redund_name</i>	(Optional) IP redundancy name

<i>sh_ip_redund_name_attr</i>	(Optional) IP redundancy name attribute
<i>show_hsrp_end</i>	(Optional) End of Group

Command Mode

- /exec

show hsrp anycast

show hsrp anycast [<id> { ipv4 | ipv6 | both }] [brief]

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
anycast	Anycast related commands
<i>id</i>	(Optional) Bundle number
ipv4	(Optional) Associate IP Version 4 for the bundle
ipv6	(Optional) Associate IP Version 6 for the bundle
both	(Optional) Associate IP Version 4 and 6 for the bundle
brief	(Optional) Brief output

Command Mode

- /exec

show hsrp anycast interface vlan

show hsrp anycast interface { vlan | bdi } <id>

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
anycast	Anycast related commands
interface	Bundle on this interface Interface
vlan	VLAN interface
bdi	Bridge-Domain interface
<i>id</i>	VLAN number

Command Mode

- /exec

show hsrp anycast remote-db

show hsrp anycast remote-db [<id> { ipv4 | ipv6 | both }]

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
anycast	Anycast related commands
remote-db	Remote data base for the bundle
<i>id</i>	(Optional) Bundle number
ipv4	(Optional) Associate IP Version 4 for the bundle
ipv6	(Optional) Associate IP Version 6 for the bundle
both	(Optional) Associate IP Version 4 and 6 for the bundle

Command Mode

- /exec

show hsrp anycast summary

show hsrp anycast summary

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
anycast	Anycast related commands
summary	Show HSRP summary

Command Mode

- /exec

show hsrp bfd-sessions

```
show hsrp bfd-sessions [ interface <interface-id> [ to <ipaddress> ] ] [ __readonly__ [ TABLE_bfd_sess [
<interface> ] [ <list_size> ] { [ <src_addr> ] [ <src_addr_v6> ] } { [ <dst_addr> ] [ <dst_addr_v6> ] } [
<ref_count> ] { [ TABLE_ref_groups [ <ref_group_id> ] ] } { [ TABLE_hist_groups [ <hist_group_id> ] [
<hist_operation> ] [ <hist_rel_time> ] [ <hist_abs_time> ] [ <hist_ref_count> ] [ <hist_group_state> ] [
<hist_status> ] [ <hist_op_reason> ] ] } ] ]
```

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
bfd-sessions	BFD sessions
interface	(Optional) Groups on this interface
<i>interface-id</i>	(Optional) Interface
to	(Optional) To IP address
<i>ipaddress</i>	(Optional) Sessions to IP address
<i>__readonly__</i>	(Optional)
TABLE_bfd_sess	(Optional)
<i>interface</i>	(Optional) Interface
<i>list_size</i>	(Optional) List size
<i>src_addr</i>	(Optional) IPv4 Source address
<i>dst_addr</i>	(Optional) IPv4 Destination address
<i>ref_count</i>	(Optional) Ref count
TABLE_ref_groups	(Optional)
<i>ref_group_id</i>	(Optional) Group id
TABLE_hist_groups	(Optional)
<i>hist_group_id</i>	(Optional) Group id
<i>hist_operation</i>	(Optional) Operation
<i>hist_rel_time</i>	(Optional) Relative time
<i>hist_abs_time</i>	(Optional) Absolute time
<i>hist_ref_count</i>	(Optional) Ref count
<i>hist_group_state</i>	(Optional) Group state

<i>hist_status</i>	(Optional) Status
<i>hist_op_reason</i>	(Optional) Op reason

Command Mode

- /exec

show hsrp bfd-sessions

show hsrp bfd-sessions [interface <interface-id> [to <ipaddress>]]

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
bfd-sessions	BFD sessions
interface	(Optional) Groups on this interface
<i>interface-id</i>	(Optional) Interface
to	(Optional) To IP address
<i>ipaddress</i>	(Optional) Sessions to IP address

Command Mode

- /exec

show hsrp delay

```
show hsrp delay [ interface <interface-id> ] [ __readonly__ TABLE_delay <interface> <min_delay>
<reload_delay> ]
```

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
delay	Group initialisation delay
interface	(Optional) Groups on this interface
<i>interface-id</i>	(Optional) Interface
<i>__readonly__</i>	(Optional)
<i>TABLE_delay</i>	(Optional)
<i>interface</i>	(Optional) Interface
<i>min_delay</i>	(Optional) Min delay
<i>reload_delay</i>	(Optional) Reload delay

Command Mode

- /exec

show hsrp mgo

```
show hsrp mgo [ name <name> | brief ] [ __readonly__ TABLE_hsrp_mgo <master_name> <master_interface>
<master_address_family> <master_group_id> [ <master_version> ] <master_state> [ <master_down_reason>
] [ { TABLE_slave <slave_interface> <slave_group_id> <slave_state> [ <slave_down_reason> } ] [
<num_slave_group> ] ]
```

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
mgo	Show HSRP mgo details
name	(Optional) Redundancy name string
<i>name</i>	(Optional) name string
brief	(Optional) show HSPR mgo brief
<i>__readonly__</i>	(Optional)
TABLE_hsrp_mgo	(Optional)
<i>master_name</i>	(Optional) HSRP master name
<i>master_interface</i>	(Optional) HSRP master interface
<i>master_address_family</i>	(Optional) HSRP master AF
<i>master_group_id</i>	(Optional) HSRP master group ID
<i>master_version</i>	(Optional) HSRP master version
<i>master_state</i>	(Optional) HSRP master state
<i>master_down_reason</i>	(Optional) HSRP master down reason
TABLE_slave	(Optional) Slave table
<i>slave_interface</i>	(Optional) HSRP slave interface
<i>slave_group_id</i>	(Optional) HSRP slave group id
<i>slave_state</i>	(Optional) HSRP slave state
<i>slave_down_reason</i>	(Optional) HSRP slave down reason
<i>num_slave_group</i>	(Optional) HSRP number of slave groups

Command Mode

- /exec

show hsrp summary

```
show hsrp summary [ __readonly__ <switchover_notify_rxed> <bfd_enabled> <num_of_groups>
<num_of_v4_v1_groups> <num_of_v4_v2_groups> <num_of_v6_v2_groups> <num_of_active_groups>
<num_of_standby_groups> <num_of_listen_groups> <num_of_v6_active_groups>
<num_of_v6_standby_groups> <num_of_v6_listen_groups> <num_of_hsrp_enabled_ifs> <counter_pkts_tx>
<counter_pkts_tx_failure> <counter_pkts_in> <counter_pkts_bad_vr> <counter_mts_rx> ]
```

Syntax Description

show	Show running system information
hsrp	Hot Standby Router Protocol (HSRP) information
summary	Show HSRP summary
<i>__readonly__</i>	(Optional)
<i>switchover_notify_rxed</i>	(Optional) Switchover notification received (1 => active)
<i>bfd_enabled</i>	(Optional) BFD status
<i>num_of_groups</i>	(Optional) Total number of groups
<i>num_of_v4_v1_groups</i>	(Optional) Number of IPv4 V1 groups
<i>num_of_v4_v2_groups</i>	(Optional) Number of IPv4 V2 groups
<i>num_of_v6_v2_groups</i>	(Optional) Number of IPv6 V2 groups
<i>num_of_active_groups</i>	(Optional) Number of active groups
<i>num_of_standby_groups</i>	(Optional) Number of standby groups
<i>num_of_listen_groups</i>	(Optional) Number of listen groups
<i>num_of_v6_active_groups</i>	(Optional) Number of IPv6 active groups
<i>num_of_v6_standby_groups</i>	(Optional) Number of IPv6 standby groups
<i>num_of_v6_listen_groups</i>	(Optional) Number of IPv6 listen groups
<i>num_of_hsrp_enabled_ifs</i>	(Optional) Number of HSRP enabled interfaces
<i>counter_pkts_tx</i>	(Optional) Number of packet transmission successes
<i>counter_pkts_tx_failure</i>	(Optional) Number of packet transmission failure
<i>counter_pkts_in</i>	(Optional) Number of packets received successfully
<i>counter_pkts_bad_vr</i>	(Optional) Number of packets for unknown groups
<i>counter_mts_rx</i>	(Optional) Number of MTS messages received

Command Mode

- /exec



I Show Commands

- [show icam entries acl module inst](#), on page 623
- [show icam health](#), on page 625
- [show icam itd](#), on page 626
- [show icam prediction entries acl module inst](#), on page 627
- [show icam prediction resource acl_tcam module inst](#), on page 629
- [show icam prediction resource acl_tcam module inst trend](#), on page 631
- [show icam prediction scale](#), on page 633
- [show icam resource acl_tcam module inst](#), on page 635
- [show icam scale](#), on page 638
- [show ieth-header-decode](#), on page 641
- [show imp client](#), on page 642
- [show imp client sa](#), on page 643
- [show inband-telemetry exporter](#), on page 644
- [show inband-telemetry flow-profile](#), on page 645
- [show inband-telemetry monitor](#), on page 646
- [show inband-telemetry queue-profile](#), on page 647
- [show inband-telemetry record](#), on page 648
- [show inband-telemetry sessions](#), on page 649
- [show inband-telemetry watchlist](#), on page 650
- [show incompatibility-all system](#), on page 651
- [show incompatibility system](#), on page 652
- [show install](#), on page 653
- [show install all failed-standby](#), on page 654
- [show install all failure-reason](#), on page 655
- [show install all impact](#), on page 656
- [show install all impact epld](#), on page 657
- [show install all status](#), on page 658
- [show install all time-stats](#), on page 659
- [show install epld status](#), on page 660
- [show install log](#), on page 661
- [show install mode](#), on page 662
- [show install packages](#), on page 663
- [show install patches](#), on page 664

- [show interface](#), on page 665
- [show interface](#), on page 685
- [show interface](#), on page 690
- [show interface](#), on page 695
- [show interface](#), on page 703
- [show interface](#), on page 707
- [show interface](#), on page 711
- [show interface](#), on page 713
- [show interface](#), on page 719
- [show interface](#), on page 721
- [show interface aggregate-counters](#), on page 725
- [show interface aggregate-counters](#), on page 728
- [show interface aggregate-counters](#), on page 731
- [show interface bbcredit](#), on page 734
- [show interface brief](#), on page 735
- [show interface brief](#), on page 743
- [show interface brief](#), on page 744
- [show interface brief](#), on page 746
- [show interface brief](#), on page 747
- [show interface brief](#), on page 749
- [show interface brief](#), on page 750
- [show interface brief](#), on page 751
- [show interface brief](#), on page 752
- [show interface cable-diagnostics-tdr](#), on page 753
- [show interface capabilities](#), on page 754
- [show interface capabilities](#), on page 756
- [show interface capabilities](#), on page 758
- [show_interface](#), on page 760
- [show interface counters](#), on page 761
- [show interface counters](#), on page 765
- [show interface counters](#), on page 766
- [show interface counters](#), on page 768
- [show interface counters](#), on page 770
- [show interface counters](#), on page 772
- [show interface counters](#), on page 774
- [show interface counters](#), on page 776
- [show interface counters brief](#), on page 777
- [show interface counters brief](#), on page 779
- [show interface counters detailed](#), on page 781
- [show interface counters detailed](#), on page 784
- [show interface counters detailed](#), on page 796
- [show interface counters detailed](#), on page 798
- [show interface counters detailed all](#), on page 804
- [show interface counters detailed all](#), on page 805
- [show interface counters detailed all](#), on page 806
- [show interface counters detailed all](#), on page 809

- [show interface counters detailed all, on page 811](#)
- [show interface counters detailed cached, on page 819](#)
- [show interface counters details, on page 827](#)
- [show interface counters details, on page 828](#)
- [show interface counters errors, on page 832](#)
- [show interface counters errors, on page 833](#)
- [show interface counters errors, on page 835](#)
- [show interface counters snmp, on page 837](#)
- [show interface counters snmp, on page 839](#)
- [show interface counters storm-control, on page 841](#)
- [show interface counters storm-control, on page 842](#)
- [show interface counters table, on page 843](#)
- [show interface counters trunk, on page 844](#)
- [show interface dampening, on page 845](#)
- [show interface debounce, on page 846](#)
- [show interface debounce, on page 847](#)
- [show interface description, on page 848](#)
- [show interface description, on page 849](#)
- [show interface description, on page 850](#)
- [show interface description, on page 851](#)
- [show interface description, on page 852](#)
- [show interface description, on page 853](#)
- [show interface description, on page 854](#)
- [show interface description, on page 855](#)
- [show interface detail-counters, on page 856](#)
- [show interface fcoe, on page 860](#)
- [show interface fec, on page 861](#)
- [show interface flowcontrol, on page 862](#)
- [show interface flowcontrol, on page 863](#)
- [show interface hardware-mappings, on page 864](#)
- [show interface mac-address, on page 865](#)
- [show interface mac-address, on page 866](#)
- [show interface priority-flow-control, on page 867](#)
- [show interface private-vlan mapping, on page 868](#)
- [show interface pruning, on page 869](#)
- [show interface snmp-ifindex, on page 870](#)
- [show interface status, on page 871](#)
- [show interface status, on page 872](#)
- [show interface status, on page 873](#)
- [show interface status, on page 875](#)
- [show interface status, on page 876](#)
- [show interface status, on page 877](#)
- [show interface status, on page 878](#)
- [show interface status err-disabled, on page 879](#)
- [show interface status err-disabled, on page 880](#)
- [show interface status err-vlans, on page 881](#)

- [show interface status err-vlans](#), on page 882
- [show interface switchport](#), on page 883
- [show interface switchport](#), on page 885
- [show interface switchport backup](#), on page 887
- [show interface transceiver](#), on page 889
- [show interface transceiver](#), on page 899
- [show interface transceiver](#), on page 903
- [show interface trunk](#), on page 911
- [show interface trunk](#), on page 913
- [show interface trunk vsan](#), on page 915
- [show interface trunk vsan](#), on page 916
- [show interface trunk vsan](#), on page 917
- [show interface untagged-cos](#), on page 918
- [show interface vlan mapping](#), on page 919
- [show inventory](#), on page 920
- [show ip adjacency](#), on page 921
- [show ip amt relay](#), on page 924
- [show ip amt route](#), on page 925
- [show ip amt tunnel](#), on page 926
- [show ip arp](#), on page 928
- [show ip arp anycast topo-info](#), on page 930
- [show ip arp client](#), on page 931
- [show ip arp controller-statistics](#), on page 932
- [show ip arp esi](#), on page 933
- [show ip arp inspection](#), on page 934
- [show ip arp inspection interfaces](#), on page 935
- [show ip arp inspection log](#), on page 936
- [show ip arp inspection statistics](#), on page 937
- [show ip arp inspection vlan](#), on page 938
- [show ip arp multihoming-statistics](#), on page 939
- [show ip arp off-list](#), on page 941
- [show ip arp open-flow error-statistics](#), on page 942
- [show ip arp statistics](#), on page 944
- [show ip arp suppression-cache](#), on page 948
- [show ip arp suppression topo-info](#), on page 951
- [show ip arp tunnel-statistics](#), on page 952
- [show ip arp vpc-statistics](#), on page 954
- [show ip as-path-access-list](#), on page 957
- [show ip client](#), on page 958
- [show ip community-list](#), on page 959
- [show ip debug](#), on page 960
- [show ip dhcp global statistics](#), on page 961
- [show ip dhcp option82 suboption info interface](#), on page 963
- [show ip dhcp relay](#), on page 964
- [show ip dhcp relay address](#), on page 966
- [show ip dhcp relay information trusted-sources](#), on page 967

- [show ip dhcp relay statistics](#), on page 968
- [show ip dhcp snooping](#), on page 972
- [show ip dhcp snooping binding](#), on page 973
- [show ip dhcp snooping statistics](#), on page 974
- [show ip dhcp status](#), on page 975
- [show ip dns source-interface](#), on page 976
- [show ip dns source-interface vrf all](#), on page 977
- [show ip eigrp](#), on page 978
- [show ip eigrp accounting](#), on page 980
- [show ip eigrp event-history](#), on page 982
- [show ip eigrp event-history bfd](#), on page 983
- [show ip eigrp interfaces](#), on page 984
- [show ip eigrp route-map statistics](#), on page 986
- [show ip eigrp traffic](#), on page 988
- [show ip extcommunity-list](#), on page 990
- [show ip fib distribution](#), on page 991
- [show ip fib distribution clients](#), on page 992
- [show ip fib distribution mroute](#), on page 993
- [show ip fib distribution multicast](#), on page 995
- [show ip fib distribution multicast outgoing-interface-list](#), on page 996
- [show ip fib distribution state](#), on page 997
- [show ip fib mroute](#), on page 998
- [show ip fib mroute](#), on page 1000
- [show ip fib route](#), on page 1002
- [show ip fib route](#), on page 1005
- [show ip fib route recovered](#), on page 1007
- [show ip ftp source-interface](#), on page 1008
- [show ip ftp source-interface vrf all](#), on page 1009
- [show ip http source-interface](#), on page 1010
- [show ip http source-interface vrf all](#), on page 1011
- [show ip igmp event-history](#), on page 1012
- [show ip igmp groups](#), on page 1013
- [show ip igmp interface](#), on page 1015
- [show ip igmp local-groups](#), on page 1019
- [show ip igmp policy statistics reports](#), on page 1021
- [show ip igmp snooping](#), on page 1022
- [show ip igmp snooping event-history](#), on page 1024
- [show ip igmp snooping explicit-tracking](#), on page 1025
- [show ip igmp snooping filter details](#), on page 1027
- [show ip igmp snooping groups](#), on page 1028
- [show ip igmp snooping lookup-mode](#), on page 1031
- [show ip igmp snooping mac-oif](#), on page 1032
- [show ip igmp snooping mrouter](#), on page 1033
- [show ip igmp snooping pw vlan brief](#), on page 1035
- [show ip igmp snooping querier](#), on page 1036
- [show ip igmp snooping report statistics](#), on page 1038

- [show ip igmp snooping statistics](#), on page 1039
- [show ip igmp vrf all](#), on page 1042
- [show ip interface](#), on page 1043
- [show ip lisp](#), on page 1048
- [show ip lisp data-cache](#), on page 1049
- [show ip lisp locator-hash](#), on page 1050
- [show ip lisp map-cache](#), on page 1051
- [show ip lisp statistics](#), on page 1052
- [show ip lisp translate-cache](#), on page 1053
- [show ip load-sharing](#), on page 1054
- [show ip local policy](#), on page 1055
- [show ip logging](#), on page 1056
- [show ip mbgp](#), on page 1057
- [show ip mbgp](#), on page 1058
- [show ip mbgp community](#), on page 1060
- [show ip mbgp dampening](#), on page 1061
- [show ip mbgp extcommunity](#), on page 1062
- [show ip mbgp flap-statistics](#), on page 1063
- [show ip mbgp neighbors](#), on page 1064
- [show ip mbgp nexthop-database](#), on page 1066
- [show ip mbgp nexthop](#), on page 1067
- [show ip mbgp prefix-list](#), on page 1068
- [show ip mbgp received-paths](#), on page 1069
- [show ip mroute](#), on page 1070
- [show ip msdp count](#), on page 1074
- [show ip msdp event-history](#), on page 1075
- [show ip msdp mesh-group](#), on page 1076
- [show ip msdp peer](#), on page 1077
- [show ip msdp policy statistics sa-policy in](#), on page 1080
- [show ip msdp rpf](#), on page 1082
- [show ip msdp sa](#), on page 1083
- [show ip msdp sources](#), on page 1085
- [show ip msdp statistics](#), on page 1086
- [show ip msdp summary](#), on page 1088
- [show ip nat-alias](#), on page 1090
- [show ip nat max](#), on page 1091
- [show ip nat statistics](#), on page 1092
- [show ip nat timeout](#), on page 1095
- [show ip nat translations](#), on page 1096
- [show ip ospf](#), on page 1098
- [show ip ospf border-routers](#), on page 1103
- [show ip ospf database](#), on page 1105
- [show ip ospf database database-summary](#), on page 1108
- [show ip ospf database detail](#), on page 1110
- [show ip ospf event-history](#), on page 1116
- [show ip ospf event-history detail](#), on page 1118

- [show ip ospf interface](#), on page 1119
- [show ip ospf interface brief](#), on page 1122
- [show ip ospf lsa-content-changed-list](#), on page 1124
- [show ip ospf neighbors](#), on page 1126
- [show ip ospf neighbors detail](#), on page 1128
- [show ip ospf neighbors summary](#), on page 1131
- [show ip ospf policy statistics](#), on page 1133
- [show ip ospf request-list](#), on page 1135
- [show ip ospf retransmission-list](#), on page 1137
- [show ip ospf route](#), on page 1139
- [show ip ospf route summary](#), on page 1141
- [show ip ospf sham-links](#), on page 1143
- [show ip ospf statistics](#), on page 1147
- [show ip ospf summary-address](#), on page 1151
- [show ip ospf traffic](#), on page 1152
- [show ip ospf virtual-links](#), on page 1156
- [show ip ospf virtual-links brief](#), on page 1160
- [show ip pim config-sanity](#), on page 1161
- [show ip pim df](#), on page 1163
- [show ip pim event-history](#), on page 1165
- [show ip pim fabric info](#), on page 1166
- [show ip pim fabric legacy-vlans](#), on page 1167
- [show ip pim group-range](#), on page 1168
- [show ip pim host-proxy](#), on page 1169
- [show ip pim interface](#), on page 1170
- [show ip pim mdt](#), on page 1174
- [show ip pim mdt bgp](#), on page 1176
- [show ip pim mdt history interval](#), on page 1177
- [show ip pim mdt receive](#), on page 1178
- [show ip pim mdt send](#), on page 1179
- [show ip pim neighbor](#), on page 1180
- [show ip pim oif-list](#), on page 1181
- [show ip pim policy statistics](#), on page 1183
- [show ip pim policy statistics jp](#), on page 1185
- [show ip pim route](#), on page 1186
- [show ip pim rp-hash](#), on page 1190
- [show ip pim rp](#), on page 1191
- [show ip pim statistics](#), on page 1194
- [show ip pim vrf](#), on page 1196
- [show ip ping source-interface](#), on page 1197
- [show ip ping source-interface vrf all](#), on page 1198
- [show ip policy](#), on page 1199
- [show ip prefix-list](#), on page 1200
- [show ip process](#), on page 1201
- [show ip rip](#), on page 1203
- [show ip rip interface](#), on page 1205

- [show ip rip neighbor](#), on page 1207
- [show ip rip policy statistics redistribute](#), on page 1209
- [show ip rip route](#), on page 1211
- [show ip rip statistics](#), on page 1213
- [show ip route](#), on page 1215
- [show ip sla application](#), on page 1218
- [show ip sla configuration](#), on page 1219
- [show ip sla enhanced-history collection-statistics](#), on page 1222
- [show ip sla enhanced-history distribution-statistics](#), on page 1226
- [show ip sla group schedule](#), on page 1227
- [show ip sla history](#), on page 1228
- [show ip sla reaction-configuration](#), on page 1230
- [show ip sla reaction-trigger](#), on page 1231
- [show ip sla responder](#), on page 1232
- [show ip sla statistics](#), on page 1234
- [show ip sla twamp connection detail](#), on page 1240
- [show ip sla twamp connection requests](#), on page 1241
- [show ip sla twamp session](#), on page 1242
- [show ip sla twamp standards](#), on page 1243
- [show ip ssh source-interface](#), on page 1244
- [show ip ssh source-interface vrf all](#), on page 1245
- [show ip static-route](#), on page 1246
- [show ip tcp mss](#), on page 1248
- [show ip telnet source-interface](#), on page 1249
- [show ip telnet source-interface vrf all](#), on page 1250
- [show ip tftp source-interface](#), on page 1251
- [show ip tftp source-interface vrf all](#), on page 1252
- [show ip traceroute source-interface](#), on page 1253
- [show ip traceroute source-interface vrf all](#), on page 1254
- [show ip traffic](#), on page 1255
- [show ip udp relay](#), on page 1262
- [show ip udp relay interface](#), on page 1263
- [show ip udp relay object-group](#), on page 1264
- [show ip verify source](#), on page 1265
- [show ipv6 adjacency](#), on page 1266
- [show ipv6 amt tunnel](#), on page 1269
- [show ipv6 bgp](#), on page 1271
- [show ipv6 bgp](#), on page 1272
- [show ipv6 bgp](#), on page 1273
- [show ipv6 bgp community](#), on page 1274
- [show ipv6 bgp dampening](#), on page 1275
- [show ipv6 bgp extcommunity](#), on page 1276
- [show ipv6 bgp flap-statistics](#), on page 1277
- [show ipv6 bgp neighbors](#), on page 1278
- [show ipv6 bgp nexthop-database](#), on page 1279
- [show ipv6 bgp nexthop](#), on page 1280

- [show ipv6 bgp received-paths](#), on page 1281
- [show ipv6 bgp regexp](#), on page 1282
- [show ipv6 bgp summary](#), on page 1283
- [show ipv6 client](#), on page 1284
- [show ipv6 dhcp guard policy](#), on page 1286
- [show ipv6 dhcp relay](#), on page 1287
- [show ipv6 dhcp relay statistics](#), on page 1288
- [show ipv6 eigrp route-map statistics](#), on page 1292
- [show ipv6 fragments](#), on page 1294
- [show ipv6 icmp](#), on page 1295
- [show ipv6 icmp global traffic](#), on page 1297
- [show ipv6 icmp interface](#), on page 1300
- [show ipv6 icmp off-list](#), on page 1306
- [show ipv6 icmp vaddr](#), on page 1307
- [show ipv6 icmp vpc-statistics](#), on page 1311
- [show ipv6 interface](#), on page 1314
- [show ipv6 lisp data-cache](#), on page 1319
- [show ipv6 local policy](#), on page 1320
- [show ipv6 mld groups](#), on page 1321
- [show ipv6 mld local-groups](#), on page 1323
- [show ipv6 mroute](#), on page 1324
- [show ipv6 mtu](#), on page 1327
- [show ipv6 nd ra dns search-list](#), on page 1329
- [show ipv6 nd ra dns server](#), on page 1330
- [show ipv6 nd rguard policy](#), on page 1332
- [show ipv6 neighbor binding](#), on page 1333
- [show ipv6 neighbor binding mac](#), on page 1334
- [show ipv6 neighbor static](#), on page 1335
- [show ipv6 pim df](#), on page 1336
- [show ipv6 pim event-history](#), on page 1338
- [show ipv6 pim fabric info](#), on page 1339
- [show ipv6 pim fabric legacy-vlans](#), on page 1340
- [show ipv6 pim group-range](#), on page 1341
- [show ipv6 pim interface show ipv6 pim interface](#), on page 1342
- [show ipv6 pim neighbor](#), on page 1345
- [show ipv6 pim oif-list](#), on page 1346
- [show ipv6 pim policy statistics jp](#), on page 1348
- [show ipv6 pim route](#), on page 1349
- [show ipv6 pim rp-hash](#), on page 1351
- [show ipv6 pim rp](#), on page 1352
- [show ipv6 pim statistics](#), on page 1354
- [show ipv6 pim vrf](#), on page 1356
- [show ipv6 policy](#), on page 1357
- [show ipv6 prefix-list](#), on page 1358
- [show ipv6 process](#), on page 1359
- [show ipv6 rguard statistics](#), on page 1361

- [show ipv6 rip policy statistics redistribute](#), on page 1362
- [show ipv6 route](#), on page 1364
- [show ipv6 routers](#), on page 1367
- [show ipv6 snooping capture-policy](#), on page 1369
- [show ipv6 snooping counters vlan](#), on page 1370
- [show ipv6 snooping events](#), on page 1372
- [show ipv6 snooping features](#), on page 1373
- [show ipv6 snooping messages](#), on page 1374
- [show ipv6 snooping policies](#), on page 1375
- [show ipv6 snooping policy](#), on page 1376
- [show ipv6 snooping pss database](#), on page 1378
- [show ipv6 static-route](#), on page 1379
- [show ipv6 traffic](#), on page 1381
- [show isis](#), on page 1384
- [show isis adjacency](#), on page 1388
- [show isis csnp](#), on page 1391
- [show isis database](#), on page 1393
- [show isis distribute-ls](#), on page 1398
- [show isis event-history](#), on page 1402
- [show isis hostname](#), on page 1403
- [show isis interface](#), on page 1404
- [show isis ipv6 redistribute route](#), on page 1409
- [show isis ipv6 route-map statistics](#), on page 1411
- [show isis ipv6 route](#), on page 1413
- [show isis ipv6 summary-address](#), on page 1417
- [show isis lslib](#), on page 1419
- [show isis lsp free-list](#), on page 1421
- [show isis mesh-group](#), on page 1422
- [show isis non tlv overflow-list](#), on page 1423
- [show isis redistribute route](#), on page 1424
- [show isis route-map statistics](#), on page 1426
- [show isis route](#), on page 1428
- [show isis rrm](#), on page 1432
- [show isis spf-log](#), on page 1434
- [show isis srm](#), on page 1436
- [show isis ssn](#), on page 1437
- [show isis statistics](#), on page 1438
- [show isis summary-address](#), on page 1439
- [show isis topology](#), on page 1441
- [show isis traffic](#), on page 1443
- [show itd](#), on page 1445
- [show itd](#), on page 1449
- [show itd session device-group](#), on page 1453
- [show itd statistics](#), on page 1454
- [show itd vrf](#), on page 1456

show icam entries acl module inst

```
show icam entries acl module <module> inst <inst> [ history <num_intervals> ] [ sort { top <top_x> | sort-order
{ ascending | descending } | filter <f_f> [ exact ] | top <top_x> sort-order { ascending | descending } | top
<top_x> filter <f_f> [ exact ] | top <top_x> sort-order { ascending | descending } filter <f_f> [ exact ] | top
<top_x> filter <f_f> [ exact ] sort-order { ascending | descending } | sort-order { ascending | descending } top
<top_x> | sort-order { ascending | descending } filter <f_f> [ exact ] | sort-order { ascending | descending }
filter <f_f> [ exact ] top <top_x> | sort-order { ascending | descending } top <top_x> filter <f_f> [ exact ] |
filter <f_f> [ exact ] top <top_x> | filter <f_f> [ exact ] sort-order { ascending | descending } | filter <f_f> [
exact ] top <top_x> sort-order { ascending | descending } | filter <f_f> [ exact ] sort-order { ascending |
descending } top <top_x> } ] [ __readonly__ <module> <instance> [ <num_intervals> ] [ {
TABLE_ACL_entries <Feature> <Pkt_Type> <SourceIP_Mask_DestIP_Mask> <Action> <Intf_name>
<Stats> [ <Rate> ] } ] ]
```

Syntax Description

show	Show running system information
icam	intelligent CAM
entries	TCAM Entries with result and stats
acl	ACL entries
module	Module Number
<i>module</i>	Enter Module Number
inst	ASIC/Forwarding Engine Instance Number
<i>inst</i>	Enter Instance Number
sort	(Optional) Sorted display
top	(Optional) Show top x% entries (Default:100%)
<i>top_x</i>	(Optional) x% of entries to be displayed
sort-order	(Optional) Choose the order of displaying sorted entries (Default:descending)
ascending	(Optional) Sort in Ascending order of Stats
descending	(Optional) Sort in Descending order of Stats
filter	(Optional) Feature to be filtered (Default:All)
<i>f_f</i>	(Optional) Enter feature to be filtered
exact	(Optional) Exact match for feature filter
history	(Optional) Show entries history
<i>num_intervals</i>	(Optional) Number of intervals to display

<i>__readonly__</i>	(Optional) Read Only
<i>module</i>	(Optional) Module number
<i>instance</i>	(Optional) Instance number
<i>num_intervals</i>	(Optional) Number of intervals displayed
TABLE_ACL_entries	(Optional) Table for ACL entries
<i>Feature</i>	(Optional) Feature name
<i>Pkt_Type</i>	(Optional) Packet type
<i>SourceIP_Mask_DestIP_Mask</i>	(Optional) IP addresses
<i>Action</i>	(Optional) Action
<i>Intf_name</i>	(Optional) Interface name
<i>Stats</i>	(Optional) Total stats
<i>Rate</i>	(Optional) Rate packets/sec

Command Mode

- /exec

show icam health

```
show icam health [ __readonly__ { <Version> } [ { TABLE_cpu <CpuTypeName> <CpuTypeValue> } ] [
{ TABLE_mem <MemTypeName> <MemTypeValue> } ] [ { TABLE_ps <PsTypeName> <PsTypeValue>
} ] ]
```

Syntax Description

show	Show running system information
icam	iCAM - intelligent CAM
health	Health status
<i>__readonly__</i>	(Optional)
<i>Version</i>	(Optional) Version of output format
TABLE_cpu	(Optional) Table CPU Usage
<i>CpuTypeName</i>	(Optional) CPU Usage Type
<i>CpuTypeValue</i>	(Optional) CPU Usage Value
TABLE_mem	(Optional) Table Memory Usage
<i>MemTypeName</i>	(Optional) Memory Usage Type
<i>MemTypeValue</i>	(Optional) Memory Usage Value
TABLE_ps	(Optional) Table Power Supply Usage
<i>PsTypeName</i>	(Optional) Power Supply Information Type
<i>PsTypeValue</i>	(Optional) Power Supply Information Value

Command Mode

- /exec

show icam itd

```
show icam itd [ __readonly__ { <Version> } [ { TABLE_svc <Svc> <DG> [ { TABLE_stats <OrigNode>
<AssignTo> <Mode> <PktCnt> <PktPct> } ] } ] ] ]
```

Syntax Description

show	Show running system information
icam	iCAM - intelligent CAM
itd	Intelligent Traffic Director
<i>__readonly__</i>	(Optional)
<i>Version</i>	(Optional) Version of output format
TABLE_svc	(Optional) Table service
<i>Svc</i>	(Optional) Service
<i>DG</i>	(Optional) Device Group
TABLE_stats	(Optional) Table stats
<i>OrigNode</i>	(Optional) Original Node
<i>AssignTo</i>	(Optional) Assigned to
<i>Mode</i>	(Optional) Mode
<i>PktCnt</i>	(Optional) Packet Count
<i>PktPct</i>	(Optional) Packet Percentage

Command Mode

- /exec

show icam prediction entries acl module inst

```
show icam prediction entries acl module <module> inst <inst> <YYYY> <Month> <Date> <Time> [ top
<top_x> ] [ __readonly__ <module> <instance> [ { TABLE_PREDICTION_ACL_entries <Feature>
<Pkt_Type> <Value_Mask> <Action> <Intf_name> <Stats> <Prediction> } ] ]
```

Syntax Description

show	Show running system information
icam	intelligent CAM
prediction	Machine learning prediction
entries	TCAM Entries with result and stats
acl	ACL entries
module	Module Number
<i>module</i>	Enter Module Number
inst	ASIC/Forwarding Engine Instance Number
<i>inst</i>	Enter Instance Number
<i>YYYY</i>	Enter year in YYYY format
<i>Month</i>	Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>Date</i>	Enter day of month in dd format
<i>Time</i>	Enter hour, minutes, seconds as HH:MM:SS
top	(Optional) Show top x% entries (Default:1%)
<i>top_x</i>	(Optional) x% of entries to be displayed
<i>__readonly__</i>	(Optional) Read Only
<i>module</i>	(Optional) Module number
<i>instance</i>	(Optional) Instance number
TABLE_PREDICTION_ACL_entries	(Optional) Table for ACL entries prediction
<i>Feature</i>	(Optional) Feature name
<i>Pkt_Type</i>	(Optional) Packet type
<i>Value_Mask</i>	(Optional) Value mask
<i>Action</i>	(Optional) Action
<i>Intf_name</i>	(Optional) Interface name

<i>Stats</i>	(Optional) Current stats
<i>Prediction</i>	(Optional) Prediction

Command Mode

- /exec

show icam prediction resource acl_tcaml module inst

```
show icam prediction resource { acl_tcaml | fib_tcaml } module <module> inst <inst> <YYYY> <Month>
<Date> <Time> [ __readonly__ <module> <instance> [ { TABLE_PREDICTION_ACL_feature <Feature>
<Dir> <TCAM> <BANK> <Feature_Entries> <Free_Entries> <Percent_Util> } ] [ <mod> <inst> {
TABLE_PREDICTION_ACL_tcaml <Tcam_no> <Bank_no> <Used> <Free> <Percent_Util> } ] [ {
TABLE_PREDICTION_FIB_tcaml <Class> <Used_Entries> <Max_Entries> <Percent_Util> } ] ]
```

Syntax Description

show	Show running system information
icam	intelligent CAM
prediction	Machine learning prediction
resource	TCAM Resource utilization
acl_tcaml	ACL TCAM resource
fib_tcaml	FIB TCAM resource
module	Module Number
<i>module</i>	Enter Module Number
inst	ASIC/Forwarding Engine Instance Number
<i>inst</i>	Enter Instance Number
<i>YYYY</i>	Enter year in YYYY format
<i>Month</i>	Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>Date</i>	Enter day of month in dd format
<i>Time</i>	Enter hour, minutes, seconds as HH:MM:SS
<i>__readonly__</i>	(Optional) Read Only
<i>module</i>	(Optional) Module number
<i>instance</i>	(Optional) Instance number
TABLE_PREDICTION_ACL_feature	(Optional) ACL Feature utilization predictions
<i>Feature</i>	(Optional) Feature name
<i>Dir</i>	(Optional) Direction
<i>TCAM</i>	(Optional) TCAM entry
<i>BANK</i>	(Optional) BANK entry
<i>Feature_Entries</i>	(Optional) Feature_Entries

<i>Free_Entries</i>	(Optional) Free_Entries
<i>Percent_Util</i>	(Optional) Percent_Util
<i>mod</i>	(Optional) Module number
<i>inst</i>	(Optional) Instance number
TABLE_PREDICTION_ACL_tcam	(Optional) ACL TCAM utilization predictions
<i>Tcam_no</i>	(Optional) Tcam number
<i>Bank_no</i>	(Optional) Bank number
<i>Used</i>	(Optional) Used
<i>Free</i>	(Optional) Free
<i>Percent_Util</i>	(Optional) Percent_Util
TABLE_PREDICTION_FIB_tcam	(Optional) FIB TCAM utilization predictions
<i>Class</i>	(Optional) FIB class
<i>Used_Entries</i>	(Optional) Used entries
<i>Max_Entries</i>	(Optional) Max entries
<i>Percent_Util</i>	(Optional) Percent_Util

Command Mode

- /exec

show icam prediction resource acl_tcam module inst trend

```
show icam prediction resource acl_tcam module <module> inst <inst> trend [ __readonly__ <module>
<instance> [ { TABLE_PREDICTION_ACL_feature <Feature> <Dir> <TCAM> <BANK> <Feature_Entries1>
<Free_Entries1> <Percent_Util1> <Feature_Entries2> <Free_Entries2> <Percent_Util2> <Feature_Entries3>
<Free_Entries3> <Percent_Util3> } ] [ <mod> <inst> { TABLE_PREDICTION_ACL_tcam <Tcam_no>
<Bank_no> <Used1> <Free1> <Util1> <Used2> <Free2> <Util2> <Used3> <Free3> <Util3> } ] ]
```

Syntax Description

show	Show running system information
icam	intelligent CAM
prediction	Machine learning prediction
resource	TCAM Resource utilization
acl_tcam	ACL TCAM resource
module	Module Number
<i>module</i>	Enter Module Number
inst	ASIC/Forwarding Engine Instance Number
<i>inst</i>	Enter Instance Number
trend	ACL Prediction Trend
<i>__readonly__</i>	(Optional) Read Only
<i>module</i>	(Optional) Module number
<i>instance</i>	(Optional) Instance number
TABLE_PREDICTION_ACL_feature	(Optional) ACL Feature utilization predictions
<i>Feature</i>	(Optional) Feature name
<i>Dir</i>	(Optional) Direction
<i>TCAM</i>	(Optional) TCAM entry
<i>BANK</i>	(Optional) BANK entry
<i>Feature_Entries1</i>	(Optional) +24Hr Feature_Entries
<i>Free_Entries1</i>	(Optional) +24Hr Free_Entries
<i>Percent_Util1</i>	(Optional) +24Hr Percent_Util
<i>Feature_Entries2</i>	(Optional) +48Hr Feature_Entries
<i>Free_Entries2</i>	(Optional) +48Hr Free_Entries

<i>Percent_Util2</i>	(Optional) +48Hr Percent_Util
<i>Feature_Entries3</i>	(Optional) +1wk Feature_Entries
<i>Free_Entries3</i>	(Optional) +1wk Free_Entries
<i>Percent_Util3</i>	(Optional) +1wk Percent_Util
<i>mod</i>	(Optional) Module number
<i>inst</i>	(Optional) Instance number
TABLE_PREDICTION_ACL_tcam	(Optional) ACL TCAM utilization predictions
<i>Tcam_no</i>	(Optional) Tcam number
<i>Bank_no</i>	(Optional) Bank number
<i>Used1</i>	(Optional) +24Hr Used
<i>Free1</i>	(Optional) +24Hr Free
<i>Util1</i>	(Optional) +24Hr Percent_Util
<i>Used2</i>	(Optional) +48Hr Used
<i>Free2</i>	(Optional) +48Hr Free
<i>Util2</i>	(Optional) +48Hr Percent_Util
<i>Used3</i>	(Optional) +1wk Used
<i>Free3</i>	(Optional) +1wk Free
<i>Util3</i>	(Optional) +1wk Percent_Util

Command Mode

- /exec

show icam prediction scale

```
show icam prediction scale [ { { l2-switching [ mac-addresses | mst-instances | mst-vports | rpvst-vports |
rpvst-vlans | total-vlans-x-ports | vlans ] } | { multicast-routing [ multicast-routes | igmp-groups | pim-neighbors
| outgoing-interfaces ] } | { unicast-routing [ bfd-sessions | eigrp-routes | ipv4-arp | ipv4-host-routes |
ipv6-host-routes | ipv4-isis-routes | ospf-nbr | ospf-lsa | ospf-area | ospf-vrf | ospf-passive-intf ] } | { vxlan [
test ] } } ] <YYYY> <Month> <Date> <Time> [ __readonly__ [ <Info_Thres> <Warn_Thres> <Crit_Thres>
] [ { TABLE_technology <Technology> [ { TABLE_feature <Feature> <Verified_Scale> <Config_Scale>
[ { TABLE_feature_stats <Used_Entries> [ <Cur_Util> ] } } ] } ] ] ] ]
```

Syntax Description

show	Show running system information
icam	intelligent CAM
scale	Verified scale
prediction	Machine learning prediction
l2-switching	(Optional) Layer 2 switching
multicast-routing	(Optional) Multicast routing
unicast-routing	(Optional) Unicast routing
vxlan	(Optional) VxLAN
mac-addresses	(Optional) MAC addresses
mst-instances	(Optional) MST instances
mst-vports	(Optional) MST virtual ports
rpvst-vports	(Optional) RPVST virtual ports
rpvst-vlans	(Optional) RPVST VLANs
total-vlans-x-ports	(Optional) Total number of VLANs x ports with switchport isolated
vlans	(Optional) VLANs
multicast-routes	(Optional) Multicast routes
igmp-groups	(Optional) IGMP groups
pim-neighbors	(Optional) PIM neighbors
outgoing-interfaces	(Optional) Outgoing interfaces
bfd-sessions	(Optional) BFD sessions
eigrp-routes	(Optional) EIGRP routes
ipv4-arp	(Optional) IPv4 ARP

ipv4-host-routes	(Optional) IPv4 host routes
ipv6-host-routes	(Optional) IPv6 host routes
ipv4-isis-routes	(Optional) IPv4 IS-IS routes
ospf-nbr	(Optional) OSPF neighbors
ospf-lsa	(Optional) OSPF LSAs
ospf-area	(Optional) OSPF Areas
ospf-vrf	(Optional) OSPF VRFs
ospf-passive-intf	(Optional) OSPF passive interfaces
test	(Optional) VxLAN test
__readonly__	(Optional) Read Only
<i>Info_Thres</i>	(Optional) Configured info threshold percent
<i>Warn_Thres</i>	(Optional) Configured warning threshold percent
<i>Crit_Thres</i>	(Optional) Configured critical threshold percent
TABLE_technology	(Optional) Table technology
<i>Technology</i>	(Optional) Technology name
TABLE_feature	(Optional) Table feature
<i>Feature</i>	(Optional) Feature name
<i>Verified_Scale</i>	(Optional) Verified scale
<i>Config_Scale</i>	(Optional) Configured scale
TABLE_feature_stats	(Optional) Table feature stats
<i>Used_Entries</i>	(Optional) Used entries
<i>Cur_Util</i>	(Optional) Current utilization
YYYY	Enter year in YYYY format
Month	Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
Date	Enter day of month in dd format
Time	Enter hour, minutes, seconds as HH:MM:SS

Command Mode

- /exec

show icam resource acl_tcam module inst

```
show icam resource { acl_tcam | fib_tcam } module <module> inst <inst> [ history <num_intervals> ] [
__readonly__ <module> <instance> [ { TABLE_feature_resource <Feature> <TCAM> <BANK> [ {
TABLE_ingress_stats <Feature_Entries> <Free_Entries> <Percent_Util> <Timestamp> } ] } ] [ {
TABLE_egress_feature_resource <Feature> <TCAM> <BANK> [ { TABLE_egress_stats <Feature_Entries>
<Free_Entries> <Percent_Util> <Timestamp> } ] } ] [ <mod> <inst> { TABLE_tcam_bank_utilization
<Tcam_no> <Bank_no> [ { TABLE_tcam_bank_stats <Used> <Free> <Percent_Util> <Timestamp> } ] } ]
[ { TABLE_global_configs <Atomic_Update> <Bank_Chain_Mode> <Dynamic_Bank_Mapping>
<LOU_Threshold_Value> } ] [ { TABLE_fib_resource <Class> [ { TABLE_fib_stats <Used_Entries>
<Max_Entries> <Percent_Util> <Timestamp> } ] } ] ] ]
```

Syntax Description

show	Show running system information
icam	intelligent CAM
resource	TCAM Resource utilization
acl_tcam	ACL TCAM resource
fib_tcam	FIB TCAM resource
module	Module Number
<i>module</i>	Enter Module Number
inst	ASIC/Forwarding Engine Instance Number
<i>inst</i>	Enter Instance Number
history	(Optional) Show resource history
<i>num_intervals</i>	(Optional) Number of intervals in history
<i>__readonly__</i>	(Optional) Read Only
<i>module</i>	(Optional) Module number
<i>instance</i>	(Optional) Instance number
TABLE_feature_resource	(Optional) Table for ingress feature resources
<i>Feature</i>	(Optional) Feature name
<i>TCAM</i>	(Optional) TCAM entry
<i>BANK</i>	(Optional) BANK entry
TABLE_ingress_stats	(Optional) Table for ingress feature stats
<i>Feature_Entries</i>	(Optional) Feature_Entries
<i>Free_Entries</i>	(Optional) Free_Entries

<i>Percent_Util</i>	(Optional) Percent_Util
<i>Timestamp</i>	(Optional) Timestamp
TABLE_egress_feature_resource	(Optional) Table for egress feature resources
<i>Feature</i>	(Optional) Feature name
<i>TCAM</i>	(Optional) TCAM entry
<i>BANK</i>	(Optional) BANK entry
TABLE_egress_stats	(Optional) Table for egress feature stats
<i>Feature_Entries</i>	(Optional) Feature_Entries
<i>Free_Entries</i>	(Optional) Free_Entries
<i>Percent_Util</i>	(Optional) Percent_Util
<i>Timestamp</i>	(Optional) Timestamp
<i>mod</i>	(Optional) Module number
<i>inst</i>	(Optional) Instance number
TABLE_tcam_bank_utilization	(Optional) Table for tcam and bank utilization
<i>Tcam_no</i>	(Optional) Tcam number
<i>Bank_no</i>	(Optional) Bank number
TABLE_tcam_bank_stats	(Optional) Table for tcam and bank stats
<i>Used</i>	(Optional) Used
<i>Free</i>	(Optional) Free
<i>Percent_Util</i>	(Optional) Percent_Util
<i>Timestamp</i>	(Optional) Timestamp
TABLE_global_configs	(Optional) TABLE_global_configs
<i>Atomic_Update</i>	(Optional) Atomic_Update
<i>Bank_Chain_Mode</i>	(Optional) Bank_Chain_Mode
<i>Dynamic_Bank_Mapping</i>	(Optional) Dynamic_Bank_Mapping
<i>LOU_Threshold_Value</i>	(Optional) LOU_Threshold_Value
TABLE_fib_resource	(Optional) Table for fib resources
<i>Class</i>	(Optional) FIB class
TABLE_fib_stats	(Optional) Table for fib resource stats

<i>Used_Entries</i>	(Optional) Used entries
<i>Max_Entries</i>	(Optional) Max entries
<i>Percent_Util</i>	(Optional) Percent_Util
<i>Timestamp</i>	(Optional) Timestamp

Command Mode

- /exec

ipv4-arp	(Optional) IPv4 ARP
ipv4-host-routes	(Optional) IPv4 host routes
ipv6-host-routes	(Optional) IPv6 host routes
ipv4-isis-routes	(Optional) IPv4 IS-IS routes
ospf-nbr	(Optional) OSPF neighbors
ospf-lsa	(Optional) OSPF LSAs
ospf-area	(Optional) OSPF Areas
ospf-vrf	(Optional) OSPF VRFs
ospf-passive-intf	(Optional) OSPF passive interfaces
test	(Optional) VxLAN test
history	(Optional) Show scale history
<i>num_intervals</i>	(Optional) Number of intervals in history
utilization	(Optional) Show utilization statistics
thresholds	(Optional) Show thresholds statistics
<u>__readonly__</u>	(Optional) Read Only
<i>Info_Thres</i>	(Optional) Configured info threshold percent
<i>Warn_Thres</i>	(Optional) Configured warning threshold percent
<i>Crit_Thres</i>	(Optional) Configured critical threshold percent
TABLE_technology	(Optional) Table technology
<i>Technology</i>	(Optional) Technology name
TABLE_feature	(Optional) Table feature
<i>Feature</i>	(Optional) Feature name
<i>Verified_Scale</i>	(Optional) Verified scale
<i>Config_Scale</i>	(Optional) Configured scale
TABLE_feature_stats	(Optional) Table feature stats
<i>Used_Entries</i>	(Optional) Used entries
<i>Cur_Util</i>	(Optional) Current utilization
<i>Thres_Exceeded</i>	(Optional) Threshold type exceeded
<i>Polled_TS</i>	(Optional) Polled timestamp

<i>Avg_Util</i>	(Optional) Average utilization
<i>Week_Util</i>	(Optional) 1 week utilization
<i>Week_TS</i>	(Optional) 1 week peak utilization timestamp
<i>Peak_Util</i>	(Optional) Peak utilization
<i>Peak_TS</i>	(Optional) Peak utilization timestamp
<i>Info_Thres_Exceed</i>	(Optional) Number of times info threshold exceeded
<i>Info_Thres_Exceed_TS</i>	(Optional) Last info threshold exceeded timestamp
<i>Warn_Thres_Exceed</i>	(Optional) Number of times warning threshold exceeded
<i>Warn_Thres_Exceed_TS</i>	(Optional) Last warning threshold exceeded timestamp
<i>Crit_Thres_Exceed</i>	(Optional) Number of times critical threshold exceeded
<i>Crit_Thres_Exceed_TS</i>	(Optional) Last critical threshold exceeded timestamp

Command Mode

- /exec

show ieth-header-decode

show ieth-header-decode <ieth>

Syntax Description

show	Show running system information
ieth-header-decode	Show decode of ieth header
<i>ieth</i>	ieth header in hex (0xFF...) or string (FF..) form

Command Mode

- /exec

show imp client

show imp client

Syntax Description

show	Show running system information
imp	ipsec management process
client	Show ipsec clients name

Command Mode

- /exec

show imp client sa

show imp client sa

Syntax Description

show	Show running system information
imp	IPSec management process
client	IMP client
sa	Display all SAs

Command Mode

- /exec

show inband-telemetry exporter

```
show inband-telemetry exporter [ <exportername> ] [ __readonly__ <exporter> <description> <dest> <vrf>
<vrf_id> <vrf_resolved> <dest_udp> <source_intf> <source_ip> <dscp> ]
```

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
exporter	Show INT Exporter Configuration
<i>exportername</i>	(Optional) Specify an exporter
<i>__readonly__</i>	(Optional)
<i>exporter</i>	(Optional)
<i>description</i>	(Optional)
<i>dest</i>	(Optional)
<i>vrf</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_resolved</i>	(Optional)
<i>dest_udp</i>	(Optional)
<i>source_intf</i>	(Optional)
<i>source_ip</i>	(Optional)
<i>dscp</i>	(Optional)

Command Mode

- /exec

show inband-telemetry flow-profile

```
show inband-telemetry flow-profile [ <flow-profilename> ] [ __readonly__ <flow-profile> <description>
<dscp> <age> <latency> ]
```

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
flow-profile	Show INT flow Profile Configuration
<i>flow-profilename</i>	(Optional) Specify an flow Profile
<i>__readonly__</i>	(Optional)
<i>flow-profile</i>	(Optional)
<i>description</i>	(Optional)
<i>dscp</i>	(Optional)
<i>age</i>	(Optional)
<i>latency</i>	(Optional)

Command Mode

- /exec

show inband-telemetry monitor

```
show inband-telemetry monitor [ <monitorname> [ cache [ detailed ] ] ] [ __readonly__ <monitor> <use_count>
<description> <record> <event> <exporter> <bucket_id> <src_addr> <dest_addr> <watchlist> ]
```

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
monitor	Show Monitor Configuration
<i>monitorname</i>	(Optional) Specify a monitor
cache	(Optional) Flow monitor cache contents
detailed	(Optional) Show the entire cache contents
<i>__readonly__</i>	(Optional)
<i>monitor</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>record</i>	(Optional)
<i>event</i>	(Optional)
<i>exporter</i>	(Optional)
<i>bucket_id</i>	(Optional)
<i>src_addr</i>	(Optional)
<i>dest_addr</i>	(Optional)
<i>watchlist</i>	(Optional)

Command Mode

- /exec

show inband-telemetry queue-profile

```
show inband-telemetry queue-profile [ <queue-profilename> | queue-profile-default ] [ __readonly__
<queue-profile> <description> <depth> <latency> ]
```

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
queue-profile	Show INT Queue Profile Configuration
<i>queue-profilename</i>	(Optional) Specify an Queue Profile
queue-profile-default	(Optional) Show INT Queue Profile Default Configuration
__readonly__	(Optional)
<i>queue-profile</i>	(Optional)
<i>description</i>	(Optional)
<i>depth</i>	(Optional)
<i>latency</i>	(Optional)

Command Mode

- /exec

show inband-telemetry record

show inband-telemetry record [{ <recordname> }] [__readonly__ <record> <description> <use_count>]

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
record	Show Record Configuration
<i>recordname</i>	(Optional) Specify a record
__readonly__	(Optional)
<i>record</i>	(Optional)
<i>description</i>	(Optional)
<i>use_count</i>	(Optional)

Command Mode

- /exec

show inband-telemetry sessions

show inband-telemetry sessions [<monitorname>] [__readonly__ <monitor>]

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
sessions	Show Session Configuration
<i>monitorname</i>	(Optional) Specify a monitor
<i>__readonly__</i>	(Optional)
<i>monitor</i>	(Optional)

Command Mode

- /exec

show inband-telemetry watchlist

```
show inband-telemetry watchlist [ { <watchlistname> } ] [ __readonly__ <watchlist> <use_count>
<description> <num_aces> <ace_seq_num> <ace_action> <ace_type> <ace_sip> <ace_sip_len> <ace_dip>
<ace_dip_len> ]
```

Syntax Description

show	Show running system information
inband-telemetry	Show INT information
watchlist	Show watchlist Configuration
<i>watchlistname</i>	(Optional) Specify a watchlist
<i>__readonly__</i>	(Optional)
<i>watchlist</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>num_aces</i>	(Optional)
<i>ace_seq_num</i>	(Optional)
<i>ace_action</i>	(Optional)
<i>ace_type</i>	(Optional)
<i>ace_sip</i>	(Optional)
<i>ace_sip_len</i>	(Optional)
<i>ace_dip</i>	(Optional)
<i>ace_dip_len</i>	(Optional)

Command Mode

- /exec

show incompatibility-all system

```
show incompatibility-all { system <uri0> | nxos <uri1> } [ __readonly__ { [ TABLE_incompat_all <Str1> [
<Serv> ] [ <Cap> ] [ <Desc> ] [ <Req> ] [ <Enable> ] ] [ <Dynamic> ] } ]
```

Syntax Description

show	Show running system information
incompatibility-all	Show incompatible configurations for the entire system
system	show incompatibilities with an image
<i>uri0</i>	Enter image uri
nxos	show incompatibilities with an image
<i>uri1</i>	Enter image uri
<i>__readonly__</i>	(Optional)
TABLE_incompat_all	(Optional) Show incompatibility system table
<i>Str1</i>	(Optional)
<i>Serv</i>	(Optional)
<i>Cap</i>	(Optional)
<i>Desc</i>	(Optional)
<i>Req</i>	(Optional)
<i>Enable</i>	(Optional)
<i>Dynamic</i>	(Optional)

Command Mode

- /exec

show incompatibility system

```
show incompatibility { system <uri0> | nxos <uri1> } [ __readonly__ { [ TABLE_incompat <Str1> [ <Serv>
] [ <Cap> ] [ <Desc> ] [ <Req> ] [ <Enable> ] [ <Dynamic> ] } ]
```

Syntax Description

show	Show running system information
incompatibility	Show incompatible configurations
system	show incompatibilities with an image
<i>uri0</i>	Enter image uri
nxos	show incompatibilities with an image
<i>uri1</i>	Enter image uri
<i>__readonly__</i>	(Optional)
TABLE_incompat	(Optional) Show incompatibility system table
<i>Str1</i>	(Optional)
<i>Serv</i>	(Optional)
<i>Cap</i>	(Optional)
<i>Desc</i>	(Optional)
<i>Req</i>	(Optional)
<i>Enable</i>	(Optional)
<i>Dynamic</i>	(Optional)

Command Mode

- /exec

show install

```
show install { inactive | active [ brief ] | committed } [ __readonly__ { <curr_nxos_image> [ TABLE_smu_list
<install_smu_id> + ] [ TABLE_package_list <package_id> ] [ TABLE_base_package_list <base_package_id>
] } ]
```

Syntax Description

show	Show running system information
install	Install related show commands
inactive	Inactive packages
active	Active packages
brief	(Optional) Brief
committed	Committed packages
__readonly__	(Optional)
<i>curr_nxos_image</i>	(Optional) NXOS image
TABLE_smu_list	(Optional)
<i>install_smu_id</i>	(Optional) install operation smu identifier
TABLE_package_list	(Optional)
<i>package_id</i>	(Optional) Package name
TABLE_base_package_list	(Optional)
<i>base_package_id</i>	(Optional) Base package name

Command Mode

- /exec

show install all failed-standby

show install all failed-standby [__readonly__ { [TABLE_installFailStandby <Str1>] }]

Syntax Description

show	Show running system information
install	Show the software install impact between two images
all	Show install all information
failed-standby	show log from failed standby
__readonly__	(Optional)
TABLE_installFailStandby	(Optional) Install failed-standby table
<i>Str1</i>	(Optional)

Command Mode

- /exec

show install all failure-reason

```
show install all failure-reason [ __readonly__ { [ TABLE_installFailReason <installFailReasonStr> ] } ]
```

Syntax Description

show	Show running system information
install	Show the software install impact between two images
all	show install all information
failure-reason	Show failure reason for the last install all
__readonly__	(Optional)
TABLE_installFailReason	(Optional) Install failure-reason table
<i>installFailReasonStr</i>	(Optional)

Command Mode

- /exec

show install all impact

show install all impact [nxos <uri>] + [non-disruptive]

Syntax Description

show	Show running system information
install	Show the software install impact between two images
all	show install all information
impact	show impact of the install all command
nxos	(Optional) boot-variable name
<i>uri</i>	(Optional) Enter image uri
non-disruptive	(Optional) non-disruptive show install

Command Mode

- /exec

show install all impact epld

```
show install all impact epld <uri1> [ __readonly__ [ { TABLE_compat <module> <type> <upgradable>
<impact> <reason> } ] ]
```

Syntax Description

show	Show running system information
install	Show the software install status
all	show install all information
impact	show impact of the install all epld command
epld	Show EPLD install information
<i>uri1</i>	Local URI containing EPLD Image
<i>__readonly__</i>	(Optional)
TABLE_compat	(Optional)
<i>module</i>	(Optional)
<i>type</i>	(Optional)
<i>upgradable</i>	(Optional)
<i>impact</i>	(Optional)
<i>reason</i>	(Optional)

Command Mode

- /exec

show install all status

show install all status

Syntax Description

show	Show running system information
install	Show the software install impact between two images
all	show install all information
status	show status of the current or last install all

Command Mode

- /exec

show install all time-stats

show install all time-stats [detail | handshake]

Syntax Description

show	Show running system information
install	Show the software install impact between two images
all	show install all information
time-stats	show overall time statistics of the last install all
detail	(Optional) show detailed time statistics of the last install all
handshake	(Optional) show handshake time statistics for sysmgr and lc processes of the last install all

Command Mode

- /exec

show install epld status

```
show install epld status [ __readonly__ { <header_info> <entry_num> <module_num> <time> <status>
<reason> <curr_ver> <old_ver> <epld_name> <epld_install_name> } ]
```

Syntax Description

show	Show running system information
install	Show the software install status
epld	Show EPLD install information
status	Show status of previous EPLD upgrades
<i>__readonly__</i>	(Optional)
<i>header_info</i>	(Optional)
<i>entry_num</i>	(Optional)
<i>module_num</i>	(Optional)
<i>time</i>	(Optional)
<i>status</i>	(Optional)
<i>reason</i>	(Optional)
<i>curr_ver</i>	(Optional)
<i>old_ver</i>	(Optional)
<i>epld_name</i>	(Optional)
<i>epld_install_name</i>	(Optional)

Command Mode

- /exec

show install log

```
show install log { [ <id> | from <id1> ] [ detail ] [ reverse ] [ last ] } [ __readonly__ { current_time <curr_time>
[ TABLE_show_log_output <install_id> <install_log_entry> + ] } ]
```

Syntax Description

show	Show running system information
install	Install related show commands
log	log
<i>id</i>	(Optional) Install Identifies
from	(Optional) Starting at this install identifier
<i>id1</i>	(Optional) Install Identifier
detail	(Optional) Detailed information including impacted processes
reverse	(Optional) Displays the logs in reverse order
last	(Optional) Display the logs for last install operation
__readonly__	(Optional)
current_time	(Optional) current time
<i>curr_time</i>	(Optional) current time
TABLE_show_log_output	(Optional)
<i>install_id</i>	(Optional) install operation id
<i>install_log_entry</i>	(Optional) install log entry

Command Mode

- /exec

show install mode

```
show install mode [ __readonly__ { <install_mode> <image_type> } ]
```

Syntax Description

show	Show running system information
install	Install related show commands
mode	Display mode and type of booted image
<i>__readonly__</i>	(Optional)
<i>install_mode</i>	(Optional) install mode
<i>image_type</i>	(Optional) image type

Command Mode

- /exec

show install packages

```
show install packages [ __readonly__ { <curr_nxos_image> [ TABLE_package_list <package_name>
<version> <state> <signature> ] } ]
```

Syntax Description

show	Show running system information
install	Install related show commands
packages	All packages
<i>__readonly__</i>	(Optional)
<i>curr_nxos_image</i>	(Optional) NXOS image
TABLE_package_list	(Optional)
<i>package_name</i>	(Optional) Package name
<i>version</i>	(Optional) Package version
<i>state</i>	(Optional) package state
<i>signature</i>	(Optional) Signature

Command Mode

- /exec

show install patches

```
show install patches [ __readonly__ { <curr_nxos_image> [ TABLE_smu_list <install_smu_id>
<install_smu_state> [ TABLE_module_list <install_modno> <install_mod_smu_state> ] ] } ]
```

Syntax Description

show	Show running system information
install	Install related show commands
patches	All Patches
<i>__readonly__</i>	(Optional)
<i>TABLE_smu_list</i>	(Optional)
<i>curr_nxos_image</i>	(Optional) NXOS image
<i>install_smu_id</i>	(Optional) install operation smu identifier
<i>install_smu_state</i>	(Optional) install operation smu state
<i>TABLE_module_list</i>	(Optional)
<i>install_modno</i>	(Optional) install operation module number
<i>install_mod_smu_state</i>	(Optional) install operation module state

Command Mode

- /exec

show interface

```

show interface [ controller | quick ] [ __readonly__ TABLE_interface <interface> [ <state> ] [ <state_rsn_desc>
] [ <state_rsn> ] [ <vsan_brief> ] [ <oper_port_state> ] [ <port_state> ] [ <bound_interface> ] [ <port_desc>
] [ <port_des> ] [ <mgmt_hw_desc1> ] [ <mgmt_hw_addr1> ] [ <port_name> ] [ <hardware> ] [ <sfp> ] [
<port_wnn> ] [ <peer_port_wnn> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <snmp_trap> ] [ <status>
] [ <state_rsn1> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_mac> ] [ <bind_type> ] [ <port_mode> ] [ <fcid>
] [ <cfg_port_vsan> ] [ <vsan> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <admin_speed> ] [ <port_channel>
] [ <ip_addr1> ] [ <oper_txbbcredit> ] [ <oper_rxbbcredit> ] [ <port_bb_scn> ] [ <admin_rxbufsize> ] [
<admin_port_encap> ] [ <admin_beacon_mode> ] [ <admin_fec_state> ] [ <oper_fec_state> ] [
<bundle_if_index> ] [ <trkd_if_index> ] [ <trk_cfg_vsans> ] [ <trkd_port_state> ] [ <num_ports> ] [
TABLE_trk_intf [ <trk_intf> ] ] [ <info_type_num> ] [ <info_model_num> ] [ <info_manufacturer> ] [
<info_port_id> ] [ <active_vsan> ] [ <trunk_vsan_up> ] [ <trunk_vsan_isolated> ] [ <trunk_vsan_initializing>
] [ <in_bps> ] [ <in_byps> ] [ <in_fps> ] [ <out_bps> ] [ <out_byps> ] [ <out_fps> ] [ <total_in_frames> ] [
<total_in_bytes> ] [ <total_in_discards> ] [ <total_in_errors> ] [ <invalid_crc> ] [ <unknown_class_frames>
] [ <frames_too_long> ] [ <frames_too_short> ] [ <total_out_frames> ] [ <total_out_bytes> ] [
<total_out_discards> ] [ <total_out_errors> ] [ <in_ols> ] [ <in_lrr> ] [ <in_nos> ] [ <in_loop_inits> ] [
<out_ols> ] [ <out_lrr> ] [ <out_nos> ] [ <out_loop_inits> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [
<tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] [ <fcoe_in_pkts> ] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [
<fcoe_out_octets> ] [ TABLE_members [ <port_channel_member> ] ] [ <interface_last_changed> ] [
<time_last_cleared> ] [ <interface_quick> ] [ <vsan_brief_quick> ] [ <oper_port_state_quick> ] [
<port_state_quick> ] [ <bound_interface_quick> ] [ <port_desc_quick> ] [ <port_des_quick> ] [
<mgmt_hw_desc1_quick> ] [ <mgmt_hw_addr1_quick> ] [ <port_name_quick> ] [ <hardware_quick> ] [
<sfp_quick> ] [ <port_wnn_quick> ] [ <peer_port_wnn_quick> ] [ <admin_mode_quick> ] [
<admin_trunk_mode_quick> ] [ <snmp_trap_quick> ] [ <status_quick> ] [ <state_rsn1_quick> ] [
<fcot_info_quick> ] [ <bind_info_quick> ] [ <bind_mac_quick> ] [ <bind_type_quick> ] [ <port_mode_quick>
] [ <fcid_quick> ] [ <cfg_port_vsan_quick> ] [ <vsan_quick> ] [ <port_rate_mode_quick> ] [
<oper_speed_quick> ] [ <admin_speed_quick> ] [ <port_channel_quick> ] [ <ip_addr1_quick> ] [
<oper_txbbcredit_quick> ] [ <oper_rxbbcredit_quick> ] [ <port_bb_scn_quick> ] [ <admin_rxbufsize_quick>
] [ <admin_port_encap_quick> ] [ <admin_beacon_mode_quick> ] [ <admin_fec_state_quick> ] [
<oper_fec_state_quick> ] [ <bundle_if_index_quick> ] [ <trkd_if_index_quick> ] [ <trk_cfg_vsans_quick>
] [ <trkd_port_state_quick> ] [ <num_ports_quick> ] [ TABLE_trk_intf_quick [ <trk_intf_quick> ] ] [
<info_type_num_quick> ] [ <info_model_num_quick> ] [ <info_manufacturer_quick> ] [ <info_port_id_quick>
] [ <active_vsan_quick> ] [ <trunk_vsan_up_quick> ] [ <trunk_vsan_isolated_quick> ] [
<trunk_vsan_initializing_quick> ] [ <in_bps_quick> ] [ <in_byps_quick> ] [ <in_fps_quick> ] [
<out_bps_quick> ] [ <out_byps_quick> ] [ <out_fps_quick> ] [ <total_in_frames_quick> ] [
<total_in_bytes_quick> ] [ <total_in_discards_quick> ] [ <total_in_errors_quick> ] [ <invalid_crc_quick> ] [
<unknown_class_frames_quick> ] [ <frames_too_long_quick> ] [ <frames_too_short_quick> ] [
<total_out_frames_quick> ] [ <total_out_bytes_quick> ] [ <total_out_discards_quick> ] [
<total_out_errors_quick> ] [ <in_ols_quick> ] [ <in_lrr_quick> ] [ <in_nos_quick> ] [ <in_loop_inits_quick>
] [ <out_ols_quick> ] [ <out_lrr_quick> ] [ <out_nos_quick> ] [ <out_loop_inits_quick> ] [
<rx_b2b_perf_buff_quick> ] [ <rx_b2b_credit_quick> ] [ <tx_b2b_credit_quick> ] [
<tx_b2b_low_pri_cre_quick> ] [ <fcoe_in_pkts_quick> ] [ <fcoe_in_octets_quick> ] [ <fcoe_out_pkts_quick>
] [ <fcoe_out_octets_quick> ] [ TABLE_members_quick [ <port_channel_member_quick> ] ] [
<interface_last_changed_quick> ] [ <time_last_cleared_quick> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [
<admin_state> ] [ <share_state> ] [ <parent_interface> ] [ <vpc_status> ] [ <eth_bundle> ] [ <eth_hw_desc>
] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [ <eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix> ]
[ <eth_mtu> ] + [ <eth_bw> ] [ <eth_bw_str> ] [ <eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [
<eth_rxload> ] [ <eth_encap_vlan> ] [ <encapsulation> ] [ <medium> ] [ <eth_mode> ] [ <eth_duplex> ] [
<eth_speed> ] [ <eth_media> ] [ <eth_beacon> ] [ <eth_autoneg> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl>

```

```

][ <eth_mdix> ][ <eth_ratemode> ][ <eth_sw_t_monitor> ][ <eth_ethertype> ][ <eth_eee_state> ][
<eth_admin_fec_state> ][ <eth_oper_fec_state> ][ <eth_members> ][ <eth_link_flapped> ][
<eth_clear_counters> ][ <eth_reset_cntr> ][ <eth_load_interval1_rx> ][ <eth_inrate1_bits> ][
<eth_inrate1_pkts> ][ <eth_load_interval1_tx> ][ <eth_outrate1_bits> ][ <eth_outrate1_pkts> ][
<eth_inrate1_summary_bits> ][ <eth_inrate1_summary_pkts> ][ <eth_outrate1_summary_bits> ][
<eth_outrate1_summary_pkts> ][ <eth_load_interval2_rx> ][ <eth_inrate2_bits> ][ <eth_inrate2_pkts> ][
<eth_load_interval2_tx> ][ <eth_outrate2_bits> ][ <eth_outrate2_pkts> ][ <eth_inrate2_summary_bits> ][
<eth_inrate2_summary_pkts> ][ <eth_outrate2_summary_bits> ][ <eth_outrate2_summary_pkts> ][
<eth_load_interval3_rx> ][ <eth_inrate3_bits> ][ <eth_inrate3_pkts> ][ <eth_load_interval3_tx> ][
<eth_outrate3_bits> ][ <eth_outrate3_pkts> ][ <eth_inrate3_summary_bits> ][ <eth_inrate3_summary_pkts> ][
<eth_outrate3_summary_bits> ][ <eth_outrate3_summary_pkts> ][ <eth_l2_ucastpkts> ][
<eth_l2_ucastbytes> ][ <eth_l2_mcastpkts> ][ <eth_l2_mcastbytes> ][ <eth_l2_bcastpkts> ][
<eth_l2_bcastbytes> ][ <eth_l3in_routed_pkts> ][ <eth_l3in_routed_bytes> ][ <eth_l3out_routed_pkts> ][
<eth_l3out_routed_bytes> ][ <eth_l3in_ucastpkts> ][ <eth_l3in_ucastbytes> ][ <eth_l3in_mcastpkts> ][
<eth_l3in_mcastbytes> ][ <eth_l3in_bcastpkts> ][ <eth_l3in_bcastbytes> ][ <eth_l3out_ucastpkts> ][
<eth_l3out_ucastbytes> ][ <eth_l3out_mcastpkts> ][ <eth_l3out_mcastbytes> ][ <eth_l3out_bcastpkts> ][
<eth_l3out_bcastbytes> ][ <eth_l3avg1_inbytes> ][ <eth_l3avg1_inpkts> ][ <eth_l3avg1_outbytes> ][
<eth_l3avg1_outpkts> ][ <eth_inucast> ][ <eth_inmcast> ][ <eth_inbcast> ][ <eth_inpkts> ][ <eth_inbytes> ][
<eth_jumbo_inpkts> ][ <eth_storm_supp> ][ <eth_runts> ][ <eth_giants> ][ <eth_crc> ][ <eth_nobuf> ][
<eth_inerr> ][ <eth_frame> ][ <eth_overrun> ][ <eth_underrun> ][ <eth_ignored> ][ <eth_watchdog> ][
<eth_bad_eth> ][ <eth_bad_proto> ][ <eth_in_ifdown_drops> ][ <eth_dribble> ][ <eth_indiscard> ][
<eth_inpause> ][ <eth_outucast> ][ <eth_outmcast> ][ <eth_outbcast> ][ <eth_outpkts> ][ <eth_outbytes> ][
<eth_jumbo_outpkts> ][ <eth_outerr> ][ <eth_coll> ][ <eth_deferred> ][ <eth_latecoll> ][
<eth_lostcarrier> ][ <eth_nocarrier> ][ <eth_babbles> ][ <eth_outdiscard> ][ <eth_outpause> ][
<mgmt_hw_desc> ][ <mgmt_hw_addr> ][ <mgmt_ip_addr> ][ <mgmt_ip_mask> ][ <mgmt_mtu> ][
<mgmt_speed> ][ <mgmt_duplex> ][ <vdc_lvl_in_avg_bits> ][ <vdc_lvl_in_avg_pkts> ][
<vdc_lvl_out_avg_bits> ][ <vdc_lvl_out_avg_pkts> ][ <vdc_lvl_in_pkts> ][ <vdc_lvl_in_ucast> ][
<vdc_lvl_in_mcast> ][ <vdc_lvl_in_bcast> ][ <vdc_lvl_in_bytes> ][ <vdc_lvl_in_bps> ][ <vdc_lvl_in_pps> ][
<vdc_lvl_out_pkts> ][ <vdc_lvl_out_ucast> ][ <vdc_lvl_out_mcast> ][ <vdc_lvl_out_bcast> ][
<vdc_lvl_out_bytes> ][ <vdc_lvl_out_bps> ][ <vdc_lvl_out_pps> ][ <mgmt_in_pkts> ][ <mgmt_in_bytes> ][
<mgmt_in_mcast> ][ <mgmt_in_compressed> ][ <mgmt_in_errors> ][ <mgmt_in_frame> ][
<mgmt_in_overrun> ][ <mgmt_in_fifo> ][ <mgmt_out_pkts> ][ <mgmt_out_bytes> ][
<mgmt_out_underruns> ][ <mgmt_out_errors> ][ <mgmt_out_collisions> ][ <mgmt_out_fifo> ][
<mgmt_out_carrier> ][ <mgmt_align_err> ][ <mgmt_fcs_err> ][ <mgmt_xmit_err> ][ <mgmt_rcv_err> ][
<mgmt_undersize> ][ <mgmt_outdisc> ][ <mgmt_single_col> ][ <mgmt_multi_col> ][ <mgmt_late_col> ][
<mgmt_excess_col> ][ <mgmt_carri_sen> ][ <mgmt_runts> ][ <mgmt_giants> ][ <mgmt_sqetest_err> ][
<mgmt_deferred_tx> ][ <mgmt_inmactx_err> ][ <mgmt_inmacrx_err> ][ <mgmt_symbol_err> ][
<loop_in_pkts> ][ <loop_in_bytes> ][ <loop_in_mcast> ][ <loop_in_compressed> ][ <loop_in_errors> ][
<loop_in_frame> ][ <loop_in_overrun> ][ <loop_in_fifo> ][ <loop_out_pkts> ][ <loop_out_bytes> ][
<loop_out_underruns> ][ <loop_out_errors> ][ <loop_out_collisions> ][ <loop_out_fifo> ][
<loop_out_carriers> ] <admin-state> { <tunnel-ipv4> | <tunnel-ipv6> } <mtu> <bandwidth> <encap-type>
<keepalive-period> <keepalive-retries> { <src-ipv4> | <src-ipv6> } <src-intf> { <dest-ipv4> | <dest-ipv6> }
<dest-hostname> <vrf_name> <tunnel_vrf_name> <wccp_header> <ttl_val> <tunnel_pmtud_age_time>
<tunnel_pmtud_min_mtu> <tunnel_pmtud> <tunnel_pgm_mtu> <tunnel_rx_pkt_count>
<tunnel_rx_byte_count> <tunnel_rx_rate> <tunnel_tx_pkt_count> <tunnel_tx_byte_count> <tunnel_tx_rate>
<tunnel_clear_counter> [ <svi_if_index> ] [ <svi_admin_state> ] [ <oper_state> ] [ <svi_rsn_desc> ] [
<svi_line_proto> ] [ <svi_hw> ] [ <svi_mac> ] [ <svi_desc> ] [ <svi_ip_addr> ] [ <svi_ip_mask> ] [ <svi_mtu> ]
[ <svi_bw> ] [ <svi_delay> ] [ <vlan_id> ] [ <type> ] [ <svi_tx_load> ] [ <svi_rx_load> ] [
<svi_carrier_delay_sec> ] [ <svi_carrier_delay_msec> ] [ <svi_arp_type> ] [ <svi_arp_timeout> ] [
<svi_time_last_cleared> ] { [ TABLE_sec_vlan ] [ <sec_vlan> ] [ <sec_vlan_type> ] } [ <svi_routed_pkts_in> ]
[ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out> ] [ <svi_routed_bytes_out> ] [ <svi_ucast_pkts_in> ] [

```

```

<svi_ucast_bytes_in> ][ <svi_mcast_pkts_in> ][ <svi_mcast_bytes_in> ][ <svi_ucast_pkts_out> ][
<svi_ucast_bytes_out> ][ <svi_mcast_pkts_out> ][ <svi_mcast_bytes_out> ][ <svi_ipv4_ucast_pkts_in> ]
[ <svi_ipv4_ucast_bytes_in> ][ <svi_ipv4_ucast_pkts_out> ][ <svi_ipv4_ucast_bytes_out> ][
<svi_ipv4_mcast_pkts_in> ][ <svi_ipv4_mcast_bytes_in> ][ <svi_ipv4_mcast_pkts_out> ][
<svi_ipv4_mcast_bytes_out> ][ <svi_ipv6_ucast_pkts_in> ][ <svi_ipv6_ucast_bytes_in> ][
<svi_ipv6_ucast_pkts_out> ][ <svi_ipv6_ucast_bytes_out> ][ <svi_ipv6_mcast_pkts_in> ][
<svi_ipv6_mcast_bytes_in> ][ <svi_ipv6_mcast_pkts_out> ][ <svi_ipv6_mcast_bytes_out> ][
<svi_average_input_bits> ][ <svi_average_input_packets> ][ <svi_average_output_bits> ][
<svi_average_output_packets> ][ <svi_rate_in_mins> ][ <svi_reliability> ][ <overlay_addr> ][
<overlay_addr_mask> ][ <overlay_mtu> ][ <overlay_bandwidth> ][ <overlay_encap_str> ][ <overlay_vrf>
][ <overlay_src_addr> ][ <overlay_dst_addr> ][ <overlay_last_link_flap> ][ <overlay_clear_counters> ][
<overlay_load_interval> ][ <overlay_rx_ucastpkts> ][ <overlay_rx_ucastbytes> ][ <overlay_rx_mcastpkts>
][ <overlay_rx_mcastbytes> ][ <overlay_rx_pkts> ][ <overlay_rx_bytes> ][ <overlay_rx_bcastpkts> ][
<overlay_rx_bcastbytes> ][ <overlay_rx_bitrate> ][ <overlay_rx_pktrate> ][ <overlay_tx_ucastpkts> ][
<overlay_tx_ucastbytes> ][ <overlay_tx_mcastpkts> ][ <overlay_tx_mcastbytes> ][ <overlay_tx_bcastpkts>
][ <overlay_tx_bcastbytes> ][ <overlay_tx_pkts> ][ <overlay_tx_bytes> ][ <overlay_tx_bitrate> ][
<overlay_tx_pktrate> ] <switchport> ]

```

Syntax Description

show	Show running system information
interface	Show interface status and information
controller	(Optional) Show controller configured interfaces
quick	(Optional) Show info of interface skipping stats
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>state_rsn</i>	(Optional) Interface state reason
<i>vsan_brief</i>	(Optional) vsan for brief
<i>oper_port_state</i>	(Optional) oper port state
<i>port_state</i>	(Optional) port state
<i>bound_interface</i>	(Optional) bound interface
<i>port_desc</i>	(Optional) port description
<i>port_des</i>	(Optional) port description
<i>mgmt_hw_desc1</i>	(Optional) HW description
<i>mgmt_hw_addr1</i>	(Optional) HW address

<i>port_name</i>	(Optional) port description
<i>hardware</i>	(Optional) Hardware is
<i>sfp</i>	(Optional) sfp
<i>port_wwn</i>	(Optional) port wwn
<i>peer_port_wwn</i>	(Optional) peer port wwn
<i>admin_mode</i>	(Optional) admin mode
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>snmp_trap</i>	(Optional) snmp trap
<i>status</i>	(Optional) Status
<i>state_rsnl</i>	(Optional) state reason
<i>fcot_info</i>	(Optional) fcot info
<i>bind_info</i>	(Optional) bind interface
<i>bind_mac</i>	(Optional) bind mac
<i>bind_type</i>	(Optional) bind type
<i>port_mode</i>	(Optional) port mode
<i>fcid</i>	(Optional) fcid
<i>cfg_port_vsan</i>	(Optional) config port vsan
<i>vsan</i>	(Optional) vsan for brief
<i>port_rate_mode</i>	(Optional) operation port rate mode
<i>oper_speed</i>	(Optional) speed
<i>admin_speed</i>	(Optional) admin speed
<i>port_channel</i>	(Optional) port channel
<i>ip_addr1</i>	(Optional) Ip address
<i>oper_txbbcredit</i>	(Optional) oper tx bbcredit
<i>oper_rxbbcredit</i>	(Optional) oper rx bbcredit
<i>port_bb_scn</i>	(Optional) port bb scn
<i>admin_rxbufsize</i>	(Optional) admin rx bufsize
<i>admin_port_encap</i>	(Optional) admin port encap
<i>admin_beacon_mode</i>	(Optional) admin beacon mode

<i>admin_fec_state</i>	(Optional) admin fec state
<i>oper_fec_state</i>	(Optional) oper fec state
<i>bundle_if_index</i>	(Optional) bundle if index
<i>trkd_if_index</i>	(Optional) Trunk interfaces
<i>trk_cfg_vsans</i>	(Optional) Trunk vsans
<i>trkd_port_state</i>	(Optional) trunk port state
<i>num_ports</i>	(Optional) number of ports
TABLE_trk_intf	(Optional) trunk interfaces
<i>trk_intf</i>	(Optional) track interface
<i>info_type_num</i>	(Optional) info type num
<i>info_model_num</i>	(Optional) info model num
<i>info_manufacturer</i>	(Optional) info manufacturer
<i>info_port_id</i>	(Optional) info port id
<i>active_vsan</i>	(Optional) allowed and active vsan
<i>trunk_vsan_up</i>	(Optional) trunk vsan up
<i>trunk_vsan_isolated</i>	(Optional) trunk vsan isolated
<i>trunk_vsan_initializing</i>	(Optional) trunk vsan initializing
<i>in_bps</i>	(Optional) input bits/sec
<i>in_byyps</i>	(Optional) input bytes/sec
<i>in_fps</i>	(Optional) input frames/sec
<i>out_bps</i>	(Optional) output bits/sec
<i>out_byyps</i>	(Optional) output bytes/sec
<i>out_fps</i>	(Optional) output frames/sec
<i>total_in_frames</i>	(Optional) total in frames
<i>total_in_bytes</i>	(Optional) total in bytes
<i>total_in_discards</i>	(Optional) total in discards
<i>total_in_errors</i>	(Optional) total in errors
<i>invalid_crc</i>	(Optional) invalid crc
<i>unknown_class_frames</i>	(Optional) unknown class frames

<i>frames_too_long</i>	(Optional) frames too long
<i>frames_too_short</i>	(Optional) frames too short
<i>total_out_frames</i>	(Optional) total out frames
<i>total_out_bytes</i>	(Optional) total out bytes
<i>total_out_discards</i>	(Optional) total out discards
<i>total_out_errors</i>	(Optional) total out errors
<i>in_ols</i>	(Optional) input OLS
<i>in_lrr</i>	(Optional) input LRR
<i>in_nos</i>	(Optional) input NOS
<i>in_loop_inits</i>	(Optional) input loop inits
<i>out_ols</i>	(Optional) output OLS
<i>out_lrr</i>	(Optional) output LRR
<i>out_nos</i>	(Optional) output NOS
<i>out_loop_inits</i>	(Optional) output loop inits
<i>rx_b2b_perf_buff</i>	(Optional) rx b2b performance buff
<i>rx_b2b_credit</i>	(Optional) rx b2b credit
<i>tx_b2b_credit</i>	(Optional) tx b2b credit
<i>tx_b2b_low_pri_cre</i>	(Optional) tx b2b low pri credit
<i>fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>fcoe_in_octets</i>	(Optional) fcoe in octets
<i>fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>fcoe_out_octets</i>	(Optional) fcoe out octets
TABLE_members	(Optional) table for port-channel member interface
<i>port_channel_member</i>	(Optional) port-channel member interface
<i>interface_last_changed</i>	(Optional) interface last changed
<i>time_last_cleared</i>	(Optional) counters last cleared
<i>interface_quick</i>	(Optional) Interface index
<i>vsan_brief_quick</i>	(Optional) vsan for brief
<i>oper_port_state_quick</i>	(Optional) oper port state

<i>port_state_quick</i>	(Optional) port state
<i>bound_interface_quick</i>	(Optional) bound interface
<i>port_desc_quick</i>	(Optional) port description
<i>port_des_quick</i>	(Optional) port description
<i>mgmt_hw_desc1_quick</i>	(Optional) HW description
<i>mgmt_hw_addr1_quick</i>	(Optional) HW address
<i>port_name_quick</i>	(Optional) port description
<i>hardware_quick</i>	(Optional) Hardware is
<i>sfp_quick</i>	(Optional) sfp
<i>port_wwn_quick</i>	(Optional) port wwn
<i>peer_port_wwn_quick</i>	(Optional) peer port wwn
<i>admin_mode_quick</i>	(Optional) admin mode
<i>admin_trunk_mode_quick</i>	(Optional) admin trunk mode
<i>snmp_trap_quick</i>	(Optional) snmp trap
<i>status_quick</i>	(Optional) Status
<i>state_rsn1_quick</i>	(Optional) state reason
<i>fcot_info_quick</i>	(Optional) fcot info
<i>bind_info_quick</i>	(Optional) bind interface
<i>bind_mac_quick</i>	(Optional) bind mac
<i>bind_type_quick</i>	(Optional) bind type
<i>port_mode_quick</i>	(Optional) port mode
<i>fcid_quick</i>	(Optional) fcid
<i>cfg_port_vsan_quick</i>	(Optional) config port vsan
<i>vsan_quick</i>	(Optional) vsan for brief
<i>port_rate_mode_quick</i>	(Optional) operation port rate mode
<i>oper_speed_quick</i>	(Optional) speed
<i>admin_speed_quick</i>	(Optional) admin speed
<i>port_channel_quick</i>	(Optional) port channel
<i>ip_addr1_quick</i>	(Optional) Ip address

<i>oper_txbbcredit_quick</i>	(Optional) oper tx bbcredit
<i>oper_rxbbcredit_quick</i>	(Optional) oper rx bbcredit
<i>port_bb_scn_quick</i>	(Optional) port bb scn
<i>admin_rxbufsize_quick</i>	(Optional) admin rx bufsize
<i>admin_port_encap_quick</i>	(Optional) admin port encap
<i>admin_beacon_mode_quick</i>	(Optional) admin beacon mode
<i>admin_fec_state_quick</i>	(Optional) admin fec state
<i>oper_fec_state_quick</i>	(Optional) oper fec state
<i>bundle_if_index_quick</i>	(Optional) bundle if index
<i>trkd_if_index_quick</i>	(Optional) Trunk interfaces
<i>trk_cfg_vsans_quick</i>	(Optional) Trunk vsans
<i>trkd_port_state_quick</i>	(Optional) trunk port state
<i>num_ports_quick</i>	(Optional) number of ports
TABLE_trk_intf_quick	(Optional) trunk interfaces
<i>trk_intf_quick</i>	(Optional) track interface
<i>info_type_num_quick</i>	(Optional) info type num
<i>info_model_num_quick</i>	(Optional) info model num
<i>info_manufacturer_quick</i>	(Optional) info manufacturer
<i>info_port_id_quick</i>	(Optional) info port id
<i>active_vsan_quick</i>	(Optional) allowed and active vsan
<i>trunk_vsan_up_quick</i>	(Optional) trunk vsan up
<i>trunk_vsan_isolated_quick</i>	(Optional) trunk vsan isolated
<i>trunk_vsan_initializing_quick</i>	(Optional) trunk vsan initializing
<i>in_bps_quick</i>	(Optional) input bits/sec
<i>in_byps_quick</i>	(Optional) input bytes/sec
<i>in_fps_quick</i>	(Optional) input frames/sec
<i>out_bps_quick</i>	(Optional) output bits/sec
<i>out_byps_quick</i>	(Optional) output bytes/sec
<i>out_fps_quick</i>	(Optional) output frames/sec

<i>total_in_frames_quick</i>	(Optional) total in frames
<i>total_in_bytes_quick</i>	(Optional) total in bytes
<i>total_in_discards_quick</i>	(Optional) total in discards
<i>total_in_errors_quick</i>	(Optional) total in errors
<i>invalid_crc_quick</i>	(Optional) invalid crc
<i>unknown_class_frames_quick</i>	(Optional) unknown class frames
<i>frames_too_long_quick</i>	(Optional) frames too long
<i>frames_too_short_quick</i>	(Optional) frames too short
<i>total_out_frames_quick</i>	(Optional) total out frames
<i>total_out_bytes_quick</i>	(Optional) total out bytes
<i>total_out_discards_quick</i>	(Optional) total out discards
<i>total_out_errors_quick</i>	(Optional) total out errors
<i>in_ols_quick</i>	(Optional) input OLS
<i>in_lrr_quick</i>	(Optional) input LRR
<i>in_nos_quick</i>	(Optional) input NOS
<i>in_loop_inits_quick</i>	(Optional) input loop inits
<i>out_ols_quick</i>	(Optional) output OLS
<i>out_lrr_quick</i>	(Optional) ouput LRR
<i>out_nos_quick</i>	(Optional) output NOS
<i>out_loop_inits_quick</i>	(Optional) output loop inits
<i>rx_b2b_perf_buff_quick</i>	(Optional) rx b2b performance buff
<i>rx_b2b_credit_quick</i>	(Optional) rx b2b credit
<i>tx_b2b_credit_quick</i>	(Optional) tx b2b credit
<i>tx_b2b_low_pri_cre_quick</i>	(Optional) tx b2b low pri credit
<i>fcoe_in_pkts_quick</i>	(Optional) fcoe in pkts
<i>fcoe_in_octets_quick</i>	(Optional) fcoe in octets
<i>fcoe_out_pkts_quick</i>	(Optional) fcoe out pkts
<i>fcoe_out_octets_quick</i>	(Optional) fcoe out octets
TABLE_members_quick	(Optional) table for port-channel member interface

<i>port_channel_member_quick</i>	(Optional) port-channel member interface
<i>interface_last_changed_quick</i>	(Optional) interface last changed
<i>time_last_cleared_quick</i>	(Optional) counters last cleared
<i>eth_rsn_fac</i>	(Optional) State reason facility
<i>eth_rsn_code</i>	(Optional) State reason code
<i>admin_state</i>	(Optional) admin state
<i>share_state</i>	(Optional) Interface ownership
<i>parent_interface</i>	(Optional) parent interface
<i>vpc_status</i>	(Optional) VPC status
<i>eth_bundle</i>	(Optional) Belongs to bundle
<i>eth_hw_desc</i>	(Optional) HW description
<i>eth_hw_addr</i>	(Optional) HW address
<i>eth_bia_addr</i>	(Optional) bia address
<i>desc</i>	(Optional) Interface description
<i>eth_ip_addr</i>	(Optional) IP Address
<i>eth_ip_mask</i>	(Optional) IP address mask
<i>eth_ip_prefix</i>	(Optional) IP address prefix
<i>eth_mtu</i>	(Optional) MTU
<i>eth_bw</i>	(Optional) Bandwidth
<i>eth_bw_str</i>	(Optional) Bandwidth
<i>eth_dly</i>	(Optional) Delay
<i>eth_reliability</i>	(Optional) Reliability
<i>eth_txload</i>	(Optional) Tx load
<i>eth_rxload</i>	(Optional) Rx load
<i>eth_encap_vlan</i>	(Optional) Encapsulation Vlan
<i>encapsulation</i>	(Optional) Encapsulation
<i>medium</i>	(Optional) medium type
<i>eth_mode</i>	(Optional) Port mode
<i>eth_duplex</i>	(Optional) Duplex

<i>eth_speed</i>	(Optional) Speed
<i>eth_media</i>	(Optional) Media type
<i>eth_beacon</i>	(Optional) Beacon
<i>eth_autoneg</i>	(Optional) Autonegotiation
<i>eth_in_flowctrl</i>	(Optional) Input flowcontrol
<i>eth_out_flowctrl</i>	(Optional) Output flowcontrol
<i>eth_mdix</i>	(Optional) Mdix
<i>eth_ratemode</i>	(Optional) Rate mode
<i>eth_swt_monitor</i>	(Optional) Switchport Monitor
<i>eth_etherstype</i>	(Optional) EtherType
<i>eth_eee_state</i>	(Optional) EEE state
<i>eth_admin_fec_state</i>	(Optional) Admin FEC state
<i>eth_oper_fec_state</i>	(Optional) Oper FEC state
<i>eth_members</i>	(Optional) Members in this channel
<i>eth_link_flapped</i>	(Optional) Last link flapped
<i>eth_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>eth_reset_cntr</i>	(Optional) Interface resets
<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec

<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec
<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts

<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes
<i>eth_l3out_ucastpkts</i>	(Optional) L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes
<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_jumbo_inpkts</i>	(Optional) Incoming jumbo pkts
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_runts</i>	(Optional) runts
<i>eth_giants</i>	(Optional) giants
<i>eth_crc</i>	(Optional) CRC
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_inerr</i>	(Optional) input errors
<i>eth_frame</i>	(Optional) frame
<i>eth_overrun</i>	(Optional) overrun

<i>eth_underrun</i>	(Optional) underruns
<i>eth_ignored</i>	(Optional) ignored
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_indiscard</i>	(Optional) discards
<i>eth_inpause</i>	(Optional) pause input
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_jumbo_outpkts</i>	(Optional) Outgoing jumbo pkts
<i>eth_outerr</i>	(Optional) output errors
<i>eth_coll</i>	(Optional) collisions
<i>eth_deferred</i>	(Optional) deferred
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_babbles</i>	(Optional) babbles
<i>eth_outdiscard</i>	(Optional) output discard
<i>eth_outpause</i>	(Optional) PAUSE output
<i>mgmt_hw_desc</i>	(Optional) HW description
<i>mgmt_hw_addr</i>	(Optional) HW address
<i>mgmt_ip_addr</i>	(Optional) IP address
<i>mgmt_ip_mask</i>	(Optional) IP address mask
<i>mgmt_mtu</i>	(Optional) MTU

<i>mgmt_speed</i>	(Optional) Speed
<i>mgmt_duplex</i>	(Optional) Duplex
<i>vdc_lvl_in_avg_bits</i>	(Optional) VDC level average input bits
<i>vdc_lvl_in_avg_pkts</i>	(Optional) VDC level average input packets
<i>vdc_lvl_out_avg_bits</i>	(Optional) VDC level average output bits
<i>vdc_lvl_out_avg_pkts</i>	(Optional) VDC level average output packets
<i>vdc_lvl_in_pkts</i>	(Optional) VDC level input packets
<i>vdc_lvl_in_ucast</i>	(Optional) VDC level input unicast packets
<i>vdc_lvl_in_mcast</i>	(Optional) VDC level input multicast packets
<i>vdc_lvl_in_bcast</i>	(Optional) VDC level input broadcast packets
<i>vdc_lvl_in_bytes</i>	(Optional) VDC level input bytes
<i>vdc_lvl_in_bps</i>	(Optional) VDC level input bytes per second
<i>vdc_lvl_in_pps</i>	(Optional) VDC level input packets per second
<i>vdc_lvl_out_pkts</i>	(Optional) VDC level output packets
<i>vdc_lvl_out_ucast</i>	(Optional) VDC level output unicast packets
<i>vdc_lvl_out_mcast</i>	(Optional) VDC level output multicast packets
<i>vdc_lvl_out_bcast</i>	(Optional) VDC level output broadcast packets
<i>vdc_lvl_out_bytes</i>	(Optional) VDC level output bytes
<i>vdc_lvl_out_bps</i>	(Optional) VDC level output bytes per second
<i>vdc_lvl_out_pps</i>	(Optional) VDC level output packets per second
<i>mgmt_in_pkts</i>	(Optional) Input packets
<i>mgmt_in_bytes</i>	(Optional) Input bytes
<i>mgmt_in_mcast</i>	(Optional) Input multicast frames
<i>mgmt_in_compressed</i>	(Optional) Input compressed
<i>mgmt_in_errors</i>	(Optional) Input errors
<i>mgmt_in_frame</i>	(Optional) Input frame errors
<i>mgmt_in_overrun</i>	(Optional) Input overrun
<i>mgmt_in_fifo</i>	(Optional) Input fifo
<i>mgmt_out_pkts</i>	(Optional) Output packets

<i>mgmt_out_bytes</i>	(Optional) Output bytes
<i>mgmt_out_underruns</i>	(Optional) Output overruns
<i>mgmt_out_errors</i>	(Optional) Output errors
<i>mgmt_out_collisions</i>	(Optional) Output collisions
<i>mgmt_out_fifo</i>	(Optional) Output fifo
<i>mgmt_out_carrier</i>	(Optional) Output carrier errors
<i>mgmt_align_err</i>	(Optional) Align error
<i>mgmt_fcs_err</i>	(Optional) FCS error
<i>mgmt_xmit_err</i>	(Optional) Transmit error
<i>mgmt_rcv_err</i>	(Optional) Receive error
<i>mgmt_undersize</i>	(Optional) Undersize
<i>mgmt_outdisc</i>	(Optional) Out discard
<i>mgmt_single_col</i>	(Optional) Single collision
<i>mgmt_multi_col</i>	(Optional) Multiple collision
<i>mgmt_late_col</i>	(Optional) Late collision
<i>mgmt_excess_col</i>	(Optional) Excess collision
<i>mgmt_carri_sen</i>	(Optional) Carrier sense
<i>mgmt_runts</i>	(Optional) Runts
<i>mgmt_giants</i>	(Optional) Giants
<i>mgmt_sqetest_err</i>	(Optional) SQETest error
<i>mgmt_deferred_tx</i>	(Optional) Deferred tx
<i>mgmt_inmactx_err</i>	(Optional) In MAC tx
<i>mgmt_inmacrx_err</i>	(Optional) In MAC rx
<i>mgmt_symbol_err</i>	(Optional) Symbol error
<i>loop_in_pkts</i>	(Optional) Input packets
<i>loop_in_bytes</i>	(Optional) Input bytes
<i>loop_in_mcast</i>	(Optional) Input multicast
<i>loop_in_compressed</i>	(Optional) Input compressed
<i>loop_in_errors</i>	(Optional) Input errors

<i>loop_in_frame</i>	(Optional) Input frame errors
<i>loop_in_overn</i>	(Optional) Input overrun
<i>loop_in_fifo</i>	(Optional) Input fifo
<i>loop_out_pkts</i>	(Optional) Output packets
<i>loop_out_bytes</i>	(Optional) Output bytes
<i>loop_out_underruns</i>	(Optional) Output underruns
<i>loop_out_errors</i>	(Optional) Output errors
<i>loop_out_collisions</i>	(Optional) Output collisions
<i>loop_out_fifo</i>	(Optional) Output fifo
<i>loop_out_carriers</i>	(Optional) Output carrier errors
<i>admin-state</i>	(Optional)
<i>tunnel-ipv4</i>	(Optional) interface IPv4 address
<i>mtu</i>	(Optional) interface Maximum Transmission Unit
<i>bandwidth</i>	(Optional) interface Bandwidth in kilobits
<i>encap-type</i>	(Optional)
<i>keepalive-period</i>	(Optional) keealive period
<i>keepalive-retries</i>	(Optional) number of retries
<i>src-ipv4</i>	(Optional) tunnel source IPv4 address
<i>src-intf</i>	(Optional) tunnel source interface
<i>dest-ipv4</i>	(Optional) tunnel destination IPv4 address
<i>dest-hostname</i>	(Optional) tunnel destination hostname
<i>vrf_name</i>	(Optional) transport VRF name
<i>tunnel_vrf_name</i>	(Optional) tunnel VRF name
<i>wccp_header</i>	(Optional) wccp header
<i>ttl_val</i>	(Optional) tunnel time to live value
<i>tunnel_pmtud_age_time</i>	(Optional) tunnel path MTU discovery age time
<i>tunnel_pmtud_min_mtu</i>	(Optional) tunnel path MTU discovery min mtu
<i>tunnel_pmtud</i>	(Optional) tunnel path MTU discovered
<i>tunnel_pgm_mtu</i>	(Optional) tunnel actual programmed MTU

<i>tunnel_rx_pkt_count</i>	(Optional) total number of packets received
<i>tunnel_rx_byte_count</i>	(Optional) total number of bytes received
<i>tunnel_rx_rate</i>	(Optional) packets input rate per 5 minutes
<i>tunnel_tx_pkt_count</i>	(Optional) total number of packets transmitted
<i>tunnel_tx_byte_count</i>	(Optional) total number of bytes transmitted
<i>tunnel_tx_rate</i>	(Optional) packets transmitted per 5 minutes
<i>tunnel_clear_counter</i>	(Optional) Last clearing of show interface counters
<i>svi_if_index</i>	(Optional) Interface
<i>svi_admin_state</i>	(Optional)
<i>oper_state</i>	(Optional)
<i>svi_rsn_desc</i>	(Optional) Interface state reason detailed
<i>svi_line_proto</i>	(Optional)
<i>svi_hw</i>	(Optional) Hardware
<i>svi_mac</i>	(Optional) Address
<i>svi_desc</i>	(Optional) Interface Description
<i>svi_ip_addr</i>	(Optional) IP Address
<i>svi_ip_mask</i>	(Optional) IP address mask
<i>svi_mtu</i>	(Optional) MTU size in bytes
<i>svi_bw</i>	(Optional) Bandwidth in kilobits
<i>svi_delay</i>	(Optional) Throughput delay (tens of microseconds)
<i>vlan_id</i>	(Optional) Vlan
<i>type</i>	(Optional) type
<i>svi_tx_load</i>	(Optional) Tx Load
<i>svi_rx_load</i>	(Optional) Rx Load
<i>svi_carrier_delay_sec</i>	(Optional) carrier delay value in seconds
<i>svi_carrier_delay_msec</i>	(Optional) carrier delay value in milli-seconds
<i>svi_arp_type</i>	(Optional) ARP type
<i>svi_arp_timeout</i>	(Optional) ARP timeout value
<i>svi_time_last_cleared</i>	(Optional) Time last cleared

<i>TABLE_sec_vlan</i>	(Optional) secondary vlans
<i>sec_vlan</i>	(Optional) vlan id
<i>sec_vlan_type</i>	(Optional) secondary vlan type
<i>svi_reliability</i>	(Optional) Reliability
<i>overlay_addr</i>	(Optional) Overlay address
<i>overlay_addr_mask</i>	(Optional) Overlay address mask
<i>overlay_mtu</i>	(Optional) MTU
<i>overlay_bandwidth</i>	(Optional) Bandwidth
<i>overlay_encap_str</i>	(Optional) Encap type
<i>overlay_vrf</i>	(Optional) VRF
<i>overlay_src_addr</i>	(Optional) Source address
<i>overlay_dst_addr</i>	(Optional) Destination address
<i>overlay_last_link_flap</i>	(Optional) Last link flap
<i>overlay_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>overlay_load_interval</i>	(Optional) Load interval
<i>overlay_rx_ucastpkts</i>	(Optional) Received ucast pkts
<i>overlay_rx_ucastbytes</i>	(Optional) Received ucast bytes
<i>overlay_rx_mcastpkts</i>	(Optional) Received mcast pkts
<i>overlay_rx_mcastbytes</i>	(Optional) Received mcast bytes
<i>overlay_rx_bcastpkts</i>	(Optional) Received bcast pkts
<i>overlay_rx_bcastbytes</i>	(Optional) Received bcast bytes
<i>overlay_rx_pkts</i>	(Optional) Total received pkts
<i>overlay_rx_bytes</i>	(Optional) Total received bytes
<i>overlay_rx_bitrate</i>	(Optional) Receive bit rate
<i>overlay_rx_pktrate</i>	(Optional) Receive pkt rate
<i>overlay_tx_ucastpkts</i>	(Optional) Trasnmitted ucast pkts
<i>overlay_tx_ucastbytes</i>	(Optional) Trasnmitted ucast bytes
<i>overlay_tx_mcastpkts</i>	(Optional) Trasnmitted mcast pkts
<i>overlay_tx_mcastbytes</i>	(Optional) Trasnmitted mcast bytes

<i>overlay_tx_bcastpkts</i>	(Optional) Trasnmitted beast pkts
<i>overlay_tx_bcastbytes</i>	(Optional) Trasnmitted beast bytes
<i>overlay_tx_pkts</i>	(Optional) Total transmitted pkts
<i>overlay_tx_bytes</i>	(Optional) Total transmitted bytes
<i>overlay_tx_bitrate</i>	(Optional) Transmit bit rate
<i>overlay_tx_pktrate</i>	(Optional) Transmit pkt rate
<i>switchport</i>	(Optional) Switchport enabled

Command Mode

- /exec

show interface

```
show interface <ifid_brief1> [ brief ] [ __readonly__ ] [ { TABLE_interface_vfc [ <interface_vfc> ] [
<vsan_brief> ] [ <oper_port_state> ] [ <port_state> ] [ <bound_interface> ] [ <port_desc> ] [ <port_des> ] [
<mgmt_hw_desc1> ] [ <mgmt_hw_addr1> ] [ <port_name> ] [ <hardware> ] [ <sfp> ] [ <port_wwn> ] [
<peer_port_wwn> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <snmp_trap> ] [ <status> ] [ <state_rsn1>
] [ <fcot_info> ] [ <bind_info> ] [ <bind_mac> ] [ <bind_type> ] [ <port_mode> ] [ <fcid> ] [ <cfg_port_vsan>
] [ <vsan> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <admin_speed> ] [ <port_channel> ] [ <ip_addr1> ] [
<oper_txbbcredit> ] [ <oper_rxbcredit> ] [ <port_bb_scn> ] [ <admin_rxbufsize> ] [ <admin_port_encap>
] [ <admin_beacon_mode> ] [ <admin_fec_state> ] [ <oper_fec_state> ] [ <bundle_if_index> ] [
<trkd_if_index> ] [ <trk_cfg_vsans> ] [ <trkd_port_state> ] [ <num_ports> ] [ TABLE_trk_intf [ <trk_intf>
] ] [ <info_type_num> ] [ <info_model_num> ] [ <info_manufacturer> ] [ <info_port_id> ] [ <active_vsan>
] [ <trunk_vsan_up> ] [ <trunk_vsan_isolated> ] [ <trunk_vsan_initializing> ] [ <in_bps> ] [ <in_byps> ] [
<in_fps> ] [ <out_bps> ] [ <out_byps> ] [ <out_fps> ] [ <total_in_frames> ] [ <total_in_bytes> ] [
<total_in_discards> ] [ <total_in_errors> ] [ <invalid_crc> ] [ <unknown_class_frames> ] [ <frames_too_long>
] [ <frames_too_short> ] [ <total_out_frames> ] [ <total_out_bytes> ] [ <total_out_discards> ] [
<total_out_errors> ] [ <in_ols> ] [ <in_lrr> ] [ <in_nos> ] [ <in_loop_inits> ] [ <out_ols> ] [ <out_lrr> ] [
<out_nos> ] [ <out_loop_inits> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [
<tx_b2b_low_pri_cre> ] [ <fcoe_in_pkts> ] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ]
] [ TABLE_members [ <port_channel_member> ] ] [ <interface_last_changed> ] [ <time_last_cleared> ] } ] [
{ TABLE_interface_brief_vfc [ <interface_vfc> ] [ <vsan_brief> ] [ <admin_mode> ] [ <admin_trunk_mode>
] [ <status> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <port_rate_mode> ] [
<oper_speed> ] [ <port_channel> ] [ <ip_addr> ] } ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_brief1</i>	Enter interface type and number in module/slot format
brief	(Optional) Show brief info of interface
__readonly__	(Optional) Read Only
<i>interface_vfc</i>	(Optional) Interface index
TABLE_interface_vfc	(Optional) show interface
<i>vsan_brief</i>	(Optional) vsan for brief
<i>oper_port_state</i>	(Optional) oper port state
<i>port_state</i>	(Optional) port state
<i>bound_interface</i>	(Optional) bound interface
<i>port_desc</i>	(Optional) port description
<i>port_des</i>	(Optional) port description
<i>mgmt_hw_desc1</i>	(Optional) HW description

<i>mgmt_hw_addr1</i>	(Optional) HW address
<i>port_name</i>	(Optional) port description
<i>hardware</i>	(Optional) Hardware is
<i>sfp</i>	(Optional) sfp
<i>port_wwn</i>	(Optional) port wwn
<i>peer_port_wwn</i>	(Optional) peer port wwn
<i>admin_mode</i>	(Optional) admin mode
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>snmp_trap</i>	(Optional) snmp trap
<i>status</i>	(Optional) Status
<i>state_rsn1</i>	(Optional) state reason
<i>fcot_info</i>	(Optional) fcot info
<i>bind_info</i>	(Optional) bind interface
<i>bind_mac</i>	(Optional) bind mac
<i>bind_type</i>	(Optional) bind type
<i>port_mode</i>	(Optional) port mode
<i>fcid</i>	(Optional) fcid
<i>cfg_port_vsan</i>	(Optional) config port vsan
<i>vsan</i>	(Optional) vsan for brief
<i>port_rate_mode</i>	(Optional) operation port rate mode
<i>oper_speed</i>	(Optional) speed
<i>admin_speed</i>	(Optional) admin speed
<i>port_channel</i>	(Optional) port channel
<i>ip_addr1</i>	(Optional) Ip address
<i>oper_txbcredit</i>	(Optional) oper tx bbcredit
<i>oper_rxbcredit</i>	(Optional) oper rx bbcredit
<i>port_bb_scn</i>	(Optional) port bb scn
<i>admin_rxbufsize</i>	(Optional) admin rx bufsize
<i>admin_port_encap</i>	(Optional) admin port encap

<i>admin_beacon_mode</i>	(Optional) admin beacon mode
<i>admin_fec_state</i>	(Optional) admin fec state
<i>oper_fec_state</i>	(Optional) oper fec state
<i>bundle_if_index</i>	(Optional) bundle if index
<i>trkd_if_index</i>	(Optional) Trunk interfaces
<i>trk_cfg_vsans</i>	(Optional) Trunk vsans
<i>trkd_port_state</i>	(Optional) trunk port state
<i>num_ports</i>	(Optional) number of ports
TABLE_trk_intf	(Optional) trunk interfaces
<i>trk_intf</i>	(Optional) track interface
<i>info_type_num</i>	(Optional) info type num
<i>info_model_num</i>	(Optional) info model num
<i>info_manufacturer</i>	(Optional) info manufacturer
<i>info_port_id</i>	(Optional) info port id
<i>active_vsan</i>	(Optional) allowed and active vsan
<i>trunk_vsan_up</i>	(Optional) trunk vsan up
<i>trunk_vsan_isolated</i>	(Optional) trunk vsan isolated
<i>trunk_vsan_initializing</i>	(Optional) trunk vsan initializing
<i>in_bps</i>	(Optional) input bits/sec
<i>in_byps</i>	(Optional) input bytes/sec
<i>in_fps</i>	(Optional) input frames/sec
<i>out_bps</i>	(Optional) output bits/sec
<i>out_byps</i>	(Optional) output bytes/sec
<i>out_fps</i>	(Optional) output frames/sec
<i>total_in_frames</i>	(Optional) total in frames
<i>total_in_bytes</i>	(Optional) total in bytes
<i>total_in_discards</i>	(Optional) total in discards
<i>total_in_errors</i>	(Optional) total in errors
<i>invalid_crc</i>	(Optional) invalid crc

<i>unknown_class_frames</i>	(Optional) unknown class frames
<i>frames_too_long</i>	(Optional) frames too long
<i>frames_too_short</i>	(Optional) frames too short
<i>total_out_frames</i>	(Optional) total out frames
<i>total_out_bytes</i>	(Optional) total out bytes
<i>total_out_discards</i>	(Optional) total out discards
<i>total_out_errors</i>	(Optional) total out errors
<i>in_ols</i>	(Optional) input OLS
<i>in_lrr</i>	(Optional) input LRR
<i>in_nos</i>	(Optional) input NOS
<i>in_loop_inits</i>	(Optional) input loop inits
<i>out_ols</i>	(Optional) output OLS
<i>out_lrr</i>	(Optional) output LRR
<i>out_nos</i>	(Optional) output NOS
<i>out_loop_inits</i>	(Optional) output loop inits
<i>rx_b2b_perf_buff</i>	(Optional) rx b2b performance buff
<i>rx_b2b_credit</i>	(Optional) rx b2b credit
<i>tx_b2b_credit</i>	(Optional) tx b2b credit
<i>tx_b2b_low_pri_cre</i>	(Optional) tx b2b low pri credit
<i>fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>fcoe_in_octets</i>	(Optional) fcoe in octets
<i>fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>fcoe_out_octets</i>	(Optional) fcoe out octets
TABLE_members	(Optional) table for port-channel member interface
<i>port_channel_member</i>	(Optional) port-channel member interface
<i>interface_last_changed</i>	(Optional) interface last changed
<i>time_last_cleared</i>	(Optional) counters last cleared
TABLE_interface_brief_vfc	(Optional) show interface brief table
<i>interface_vfc</i>	(Optional) Interface index

<i>vsan_brief</i>	(Optional) vsan brief
<i>admin_mode</i>	(Optional) admin mode
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>status</i>	(Optional) status
<i>fcot_info</i>	(Optional) fcot info
<i>bind_info</i>	(Optional) bind interface
<i>bind_type</i>	(Optional) bind type
<i>bind_mac</i>	(Optional) bind mac address
<i>port_rate_mode</i>	(Optional) rate mode
<i>oper_speed</i>	(Optional) speed
<i>port_channel</i>	(Optional) port channel number
<i>ip_addr</i>	(Optional) IP address

Command Mode

- /exec

show interface

```
show interface <ifid_brief2> [ brief ] [ __readonly__ [ { TABLE_interface_fc [ <interface_vfc> ] [ <vsan_brief> ] [ <oper_port_state> ] [ <port_state> ] [ <bound_interface> ] [ <port_desc> ] [ <port_des> ] [ <mgmt_hw_desc1> ] [ <mgmt_hw_addr1> ] [ <port_name> ] [ <hardware> ] [ <sfp> ] [ <port_wwn> ] [ <peer_port_wwn> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <snmp_trap> ] [ <status> ] [ <state_rsn1> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_mac> ] [ <bind_type> ] [ <port_mode> ] [ <fcid> ] [ <cfg_port_vsan> ] [ <vsan> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <admin_speed> ] [ <port_channel> ] [ <ip_addr1> ] [ <oper_txbbcredit> ] [ <oper_rxbbcredit> ] [ <port_bb_scn> ] [ <admin_rxbufsize> ] [ <admin_port_encap> ] [ <admin_beacon_mode> ] [ <admin_fec_state> ] [ <oper_fec_state> ] [ <bundle_if_index> ] [ <trkd_if_index> ] [ <trk_cfg_vsans> ] [ <trkd_port_state> ] [ <num_ports> ] [ TABLE_trk_intf [ <trk_intf> ] ] [ <info_type_num> ] [ <info_model_num> ] [ <info_manufacturer> ] [ <info_port_id> ] [ <active_vsan> ] [ <trunk_vsan_up> ] [ <trunk_vsan_isolated> ] [ <trunk_vsan_initializing> ] [ <in_bps> ] [ <in_byps> ] [ <in_fps> ] [ <out_bps> ] [ <out_byps> ] [ <out_fps> ] [ <total_in_frames> ] [ <total_in_bytes> ] [ <total_in_discards> ] [ <total_in_errors> ] [ <invalid_crc> ] [ <unknown_class_frames> ] [ <frames_too_long> ] [ <frames_too_short> ] [ <total_out_frames> ] [ <total_out_bytes> ] [ <total_out_discards> ] [ <total_out_errors> ] [ <in_ols> ] [ <in_lrr> ] [ <in_nos> ] [ <in_loop_inits> ] [ <out_ols> ] [ <out_lrr> ] [ <out_nos> ] [ <out_loop_inits> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] [ <fcoe_in_pkts> ] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ] [ TABLE_members [ <port_channel_member> ] ] [ <interface_last_changed> ] [ <time_last_cleared> } ] ] [ { TABLE_interface_brief_fc [ <interface_fc> ] [ <vsan_brief> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <status> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <port_channel> ] [ <ip_addr> } ] ] [ { TABLE_interface_brief_san_pc [ <interface_san> ] [ <vsan_brief> ] [ <admin_trunk_mode> ] [ <status> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <ip_addr> } ] ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_brief2</i>	Enter interface type and number in module/slot format
brief	(Optional) Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface_vfc</i>	(Optional) Interface index
TABLE_interface_fc	(Optional) show interface
<i>vsan_brief</i>	(Optional) vsan for brief
<i>oper_port_state</i>	(Optional) oper port state
<i>port_state</i>	(Optional) port state
<i>bound_interface</i>	(Optional) bound interface
<i>port_desc</i>	(Optional) port description
<i>port_des</i>	(Optional) port description

<i>mgmt_hw_desc1</i>	(Optional) HW description
<i>mgmt_hw_addr1</i>	(Optional) HW address
<i>port_name</i>	(Optional) port description
<i>hardware</i>	(Optional) Hardware is
<i>sfp</i>	(Optional) sfp
<i>port_wwn</i>	(Optional) port wwn
<i>peer_port_wwn</i>	(Optional) peer port wwn
<i>admin_mode</i>	(Optional) admin mode
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>snmp_trap</i>	(Optional) snmp trap
<i>status</i>	(Optional) Status
<i>state_rsn1</i>	(Optional) state reason
<i>fcot_info</i>	(Optional) fcot info
<i>bind_info</i>	(Optional) bind interface
<i>bind_mac</i>	(Optional) bind mac
<i>bind_type</i>	(Optional) bind type
<i>port_mode</i>	(Optional) port mode
<i>fcid</i>	(Optional) fcid
<i>cfg_port_vsan</i>	(Optional) config port vsan
<i>vsan</i>	(Optional) vsan for brief
<i>port_rate_mode</i>	(Optional) operation port rate mode
<i>oper_speed</i>	(Optional) speed
<i>admin_speed</i>	(Optional) admin speed
<i>port_channel</i>	(Optional) port channel
<i>ip_addr1</i>	(Optional) Ip address
<i>oper_txbbcredit</i>	(Optional) oper tx bbcredit
<i>oper_rxbbcredit</i>	(Optional) oper rx bbcredit
<i>port_bb_scn</i>	(Optional) port bb scn
<i>admin_rxbufsize</i>	(Optional) admin rx bufsize

<i>admin_port_encap</i>	(Optional) admin port encap
<i>admin_beacon_mode</i>	(Optional) admin beacon mode
<i>admin_fec_state</i>	(Optional) admin fec state
<i>oper_fec_state</i>	(Optional) oper fec state
<i>bundle_if_index</i>	(Optional) bundle if index
<i>trkd_if_index</i>	(Optional) Trunk interfaces
<i>trk_cfg_vsans</i>	(Optional) Trunk vsans
<i>trkd_port_state</i>	(Optional) trunk port state
<i>num_ports</i>	(Optional) number of ports
TABLE_trk_intf	(Optional) trunk interfaces
<i>trk_intf</i>	(Optional) track interface
<i>info_type_num</i>	(Optional) info type num
<i>info_model_num</i>	(Optional) info model num
<i>info_manufacturer</i>	(Optional) info manufacturer
<i>info_port_id</i>	(Optional) info port id
<i>active_vsan</i>	(Optional) allowed and active vsan
<i>trunk_vsan_up</i>	(Optional) trunk vsan up
<i>trunk_vsan_isolated</i>	(Optional) trunk vsan isolated
<i>trunk_vsan_initializing</i>	(Optional) trunk vsan initializing
<i>in_bps</i>	(Optional) input bits/sec
<i>in_byps</i>	(Optional) input bytes/sec
<i>in_fps</i>	(Optional) input frames/sec
<i>out_bps</i>	(Optional) output bits/sec
<i>out_byps</i>	(Optional) output bytes/sec
<i>out_fps</i>	(Optional) output frames/sec
<i>total_in_frames</i>	(Optional) total in frames
<i>total_in_bytes</i>	(Optional) total in bytes
<i>total_in_discards</i>	(Optional) total in discards
<i>total_in_errors</i>	(Optional) total in errors

<i>invalid_crc</i>	(Optional) invalid crc
<i>unknown_class_frames</i>	(Optional) unknown class frames
<i>frames_too_long</i>	(Optional) frames too long
<i>frames_too_short</i>	(Optional) frames too short
<i>total_out_frames</i>	(Optional) total out frames
<i>total_out_bytes</i>	(Optional) total out bytes
<i>total_out_discards</i>	(Optional) total out discards
<i>total_out_errors</i>	(Optional) total out errors
<i>in_ols</i>	(Optional) input OLS
<i>in_lrr</i>	(Optional) input LRR
<i>in_nos</i>	(Optional) input NOS
<i>in_loop_inits</i>	(Optional) input loop inits
<i>out_ols</i>	(Optional) output OLS
<i>out_lrr</i>	(Optional) output LRR
<i>out_nos</i>	(Optional) output NOS
<i>out_loop_inits</i>	(Optional) output loop inits
<i>rx_b2b_perf_buff</i>	(Optional) rx b2b performance buff
<i>rx_b2b_credit</i>	(Optional) rx b2b credit
<i>tx_b2b_credit</i>	(Optional) tx b2b credit
<i>tx_b2b_low_pri_cre</i>	(Optional) tx b2b low pri credit
<i>fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>fcoe_in_octets</i>	(Optional) fcoe in octets
<i>fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>fcoe_out_octets</i>	(Optional) fcoe out octets
TABLE_members	(Optional) table for port-channel member interface
<i>port_channel_member</i>	(Optional) port-channel member interface
<i>interface_last_changed</i>	(Optional) interface last changed
<i>time_last_cleared</i>	(Optional) counters last cleared
TABLE_interface_brief_fc	(Optional) show interface brief table

<i>interface_fc</i>	(Optional) Interface index
<i>ip_addr</i>	(Optional) IP address
<i>vsan_brief</i>	(Optional) vsan brief
<i>admin_mode</i>	(Optional) admin mode
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>status</i>	(Optional) status
<i>fcot_info</i>	(Optional) fcot info
<i>bind_info</i>	(Optional) bind interface
<i>bind_type</i>	(Optional) bind type
<i>bind_mac</i>	(Optional) bind mac address
<i>port_rate_mode</i>	(Optional) rate mode
<i>oper_speed</i>	(Optional) speed
<i>port_channel</i>	(Optional) port channel number
TABLE_interface_brief_san_pc	(Optional) show interface brief for san-po
<i>interface_san</i>	(Optional) san_po interface
<i>vsan_brief</i>	(Optional) vsan brief
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>status</i>	(Optional) status
<i>port_rate_mode</i>	(Optional) rate mode
<i>oper_speed</i>	(Optional) speed
<i>ip_addr</i>	(Optional) IP address

Command Mode

- /exec

show interface

```

show interface <ifid> [ quick ] [ __readonly__ ] TABLE interface <interface> [ <desc> ] [ [ <svi_if_index> ]
[ <svi_admin_state> ] [ <oper_state> ] [ <svi_rsn_desc> ] [ <svi_line_proto> ] [ <svi_hw> ] [ <svi_mac> ] [
<svi_desc> ] [ <svi_ip_addr> ] [ <svi_ip_mask> ] [ <svi_mtu> ] [ <svi_bw> ] [ <svi_delay> ] [ <vlan_id> ]
[ <type> ] ] [ [ <svi_tx_load> ] [ <svi_rx_load> ] ] [ [ <svi_carrier_delay_sec> ] [ <svi_carrier_delay_msec>
] [ <svi_arp_type> ] [ <svi_arp_timeout> ] ] [ [ <svi_time_last_cleared> ] ] [ { [ TABLE_sec_vlan ] [
<sec_vlan> ] [ <sec_vlan_type> ] } ] [ [ <eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts>
] [ <eth_load_interval1_tx> ] [ <eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits>
] [ <eth_inrate1_summary_pkts> ] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [
<eth_load_interval2_rx> ] [ <eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [
<eth_outrate2_bits> ] [ <eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts>
] [ <eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes>
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes>
] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_l3avg2_inbytes> ] [ <eth_l3avg2_inpkts> ] [ <eth_l3avg2_outbytes> ] [ <eth_l3avg2_outpkts> ] [
<eth_l3avg3_inbytes> ] [ <eth_l3avg3_inpkts> ] [ <eth_l3avg3_outbytes> ] [ <eth_l3avg3_outpkts> ] [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_nobuf> ] [ <eth_inbcast> ] [ <eth_inmcast> ] [ <eth_inucast> ] [
<eth_ingiants> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [ <eth_insw_switched> ] [ <eth_runts> ] [
<eth_storm_supp> ] [ <eth_throtles> ] [ <eth_inerr> ] [ <eth_crc> ] [ <eth_ecc> ] [ <eth_frame> ] [
<eth_overrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_outbcast> ] [ <eth_outmcast> ] [ <eth_outucast>
] [ <eth_outgiants> ] [ <eth_inpause> ] [ <eth_dribble> ] [ <eth_in_ifdown_drops> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_underrun> ] [ <eth_outhw_switched> ] [
<eth_outsw_switched> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_resets> ] [ <eth_babbles> ] [ <eth_latecoll> ]
[ <eth_deferred> ] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_outpause> ] [ <eth_buffail> ] [
<eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_single_coll> ] [ <eth_multi_coll>
] [ <eth_excess_coll> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [
<eth_outcrc> ] [ <eth_symbol> ] [ <eth_out_drops> ] [ <eth_sqetest> ] [ <eth_inb64> ] [ <eth_inb65_127>
] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [ <eth_inb1024_1518> ] [
<eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outb64> ] [ <eth_outb65_127> ] [ <eth_outb128_255> ] [
<eth_outb256_511> ] [ <eth_outb512_1023> ] [ <eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [
<eth_outtrunk> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_fcoe_in_pkts> ] [ <eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [
<eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [ <eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [
<eth_nfcoe_out_octets> ] [ <eth_eee_atx_lpi_msec> ] [ <eth_eee_arcv_lpi_msec> ] [
<eth_eee_atx_lpi_transitions> ] [ <eth_eee_arcv_lpi_transitions> ] [ <eth_phy_ber_count> ] [
<eth_phy_errblks_count> ] ] [ [ <svi_routed_pkts_in> ] [ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out>
] [ <svi_routed_bytes_out> ] [ <svi_ucast_pkts_in> ] [ <svi_ucast_bytes_in> ] [ <svi_mcast_pkts_in> ] [
<svi_mcast_bytes_in> ] [ <svi_ucast_pkts_out> ] [ <svi_ucast_bytes_out> ] [ <svi_mcast_pkts_out> ] [
<svi_mcast_bytes_out> ] [ <svi_ipv4_ucast_pkts_in> ] [ <svi_ipv4_ucast_bytes_in> ] [
<svi_ipv4_ucast_pkts_out> ] [ <svi_ipv4_ucast_bytes_out> ] [ <svi_ipv4_mcast_pkts_in> ] [
<svi_ipv4_mcast_bytes_in> ] [ <svi_ipv4_mcast_pkts_out> ] [ <svi_ipv4_mcast_bytes_out> ] ] ]

```

```
<svi_ipv6_ucast_pkts_in> ][ <svi_ipv6_ucast_bytes_in> ][ <svi_ipv6_ucast_pkts_out> ][
<svi_ipv6_ucast_bytes_out> ][ <svi_ipv6_mcast_pkts_in> ][ <svi_ipv6_mcast_bytes_in> ][
<svi_ipv6_mcast_pkts_out> ][ <svi_ipv6_mcast_bytes_out> ][ <svi_average_input_bits> ][
<svi_average_input_packets> ][ <svi_average_output_bits> ][ <svi_average_output_packets> ][
<svi_rate_in_mins> ]][ [ <svi_reliability> ] ][ <switchport> ]]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid</i>	Enter interface type and number in module/slot format
quick	(Optional) Show info of interface skipping stats
<u>__readonly__</u>	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>desc</i>	(Optional) Interface description
<i>svi_if_index</i>	(Optional) Interface
<i>svi_admin_state</i>	(Optional)
<i>oper_state</i>	(Optional)
<i>svi_rsn_desc</i>	(Optional) Interface state reason detailed
<i>svi_line_proto</i>	(Optional)
<i>svi_hw</i>	(Optional) Hardware
<i>svi_mac</i>	(Optional) Address
<i>svi_desc</i>	(Optional) Interface Description
<i>svi_ip_addr</i>	(Optional) IP Address
<i>svi_ip_mask</i>	(Optional) IP address mask
<i>svi_mtu</i>	(Optional) MTU size in bytes
<i>svi_bw</i>	(Optional) Bandwidth in kilobits
<i>svi_delay</i>	(Optional) Throughput delay (tens of microseconds)
<i>vlan_id</i>	(Optional) Vlan
<i>type</i>	(Optional) type
<i>svi_tx_load</i>	(Optional) Tx Load
<i>svi_rx_load</i>	(Optional) Rx Load

<i>svi_carrier_delay_sec</i>	(Optional) carrier delay value in seconds
<i>svi_carrier_delay_msec</i>	(Optional) carrier delay value in milli-seconds
<i>svi_arp_type</i>	(Optional) ARP type
<i>svi_arp_timeout</i>	(Optional) ARP timeout value
<i>svi_time_last_cleared</i>	(Optional) Time last cleared
TABLE_sec_vlan	(Optional) secondary vlans
<i>sec_vlan</i>	(Optional) vlan id
<i>sec_vlan_type</i>	(Optional) secondary vlan type
<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec

<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) IPv4 L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) IPv4 L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) IPv4 L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) IPv4 L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes
<i>eth_l3out_ucastpkts</i>	(Optional) IPv4 L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) IPv4 L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) IPv4 L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) IPv4 L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes

<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_l3avg2_inbytes</i>	(Optional) Load interval 2 L3 average in switched bytes
<i>eth_l3avg2_inpkts</i>	(Optional) Load interval 2 L3 average in switched pkts
<i>eth_l3avg2_outbytes</i>	(Optional) Load interval 2 L3 average out switched bytes
<i>eth_l3avg2_outpkts</i>	(Optional) Load interval 2 L3 average out switched pkts
<i>eth_l3avg3_inbytes</i>	(Optional) Load interval 3 L3 average in switched bytes
<i>eth_l3avg3_inpkts</i>	(Optional) Load interval 3 L3 average in switched pkts
<i>eth_l3avg3_outbytes</i>	(Optional) Load interval 3 L3 average out switched bytes
<i>eth_l3avg3_outpkts</i>	(Optional) Load interval 3 L3 average out switched pkts
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_ingiants</i>	(Optional) giants
<i>eth_ipmcast</i>	(Optional) IP multicast
<i>eth_inhw_switched</i>	(Optional) Input H/W Switched
<i>eth_insw_switched</i>	(Optional) Input S/W Switched
<i>eth_runts</i>	(Optional) runts
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_throtles</i>	(Optional) throttles
<i>eth_inerr</i>	(Optional) input errors
<i>eth_crc</i>	(Optional) CRC

<i>eth_ecc</i>	(Optional) ECC
<i>eth_frame</i>	(Optional) frame
<i>eth_overrun</i>	(Optional) overrun
<i>eth_ignored</i>	(Optional) ignored
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outgiants</i>	(Optional) giants
<i>eth_inpause</i>	(Optional) pause input
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_underrun</i>	(Optional) underruns
<i>eth_outhw_switched</i>	(Optional) Out H/W Switched
<i>eth_outsw_switched</i>	(Optional) Out S/W Switched
<i>eth_outerr</i>	(Optional) output errors
<i>eth_coll</i>	(Optional) collisions
<i>eth_resets</i>	(Optional) interface resets
<i>eth_babbles</i>	(Optional) babbles
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_deferred</i>	(Optional) deferred
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_outpause</i>	(Optional) PAUSE output
<i>eth_buffail</i>	(Optional) output buffer failures

<i>eth_bufswapped</i>	(Optional) output buffers swapped out
<i>eth_arpdrops</i>	(Optional) arp drops
<i>eth_out_ifdown_drops</i>	(Optional) Output if-down drops
<i>eth_single_coll</i>	(Optional) single collisions
<i>eth_multi_coll</i>	(Optional) multi collisions
<i>eth_excess_coll</i>	(Optional) excessive collisions
<i>eth_jabbers</i>	(Optional) jabbers
<i>eth_shortframe</i>	(Optional) short frames
<i>eth_indiscard</i>	(Optional) discards
<i>eth_bad_encap</i>	(Optional) bad encapsulation
<i>eth_outcrc</i>	(Optional) Output CRC
<i>eth_symbol</i>	(Optional) symbol errors
<i>eth_out_drops</i>	(Optional) output drops
<i>eth_sqetest</i>	(Optional) SQE test
<i>eth_inb64</i>	(Optional) input pkts between 0 and 64 bytes
<i>eth_inb65_127</i>	(Optional) input pkts between 65 and 127 bytes
<i>eth_inb128_255</i>	(Optional) input pkts between 128 and 255 bytes
<i>eth_inb256_511</i>	(Optional) input pkts between 256 and 511 bytes
<i>eth_inb512_1023</i>	(Optional) input pkts between 512 and 1023 bytes
<i>eth_inb1024_1518</i>	(Optional) input pkts between 1024 and 1518 bytes
<i>eth_inb1519_1548</i>	(Optional) input pkts between 1519 and 1548 bytes
<i>eth_intrunk</i>	(Optional) input trunk pkts
<i>eth_outb64</i>	(Optional) output pkts between 0 and 64 bytes
<i>eth_outb65_127</i>	(Optional) output pkts between 65 and 127 bytes
<i>eth_outb128_255</i>	(Optional) output pkts between 128 and 255 bytes
<i>eth_outb256_511</i>	(Optional) output pkts between 256 and 511 bytes
<i>eth_outb512_1023</i>	(Optional) output pkts between 512 and 1023 bytes
<i>eth_outb1024_1518</i>	(Optional) output pkts between 1024 and 1518 bytes
<i>eth_outb1519_1548</i>	(Optional) output pkts between 1519 and 1548 bytes

<i>eth_outtrunk</i>	(Optional) output trunk pkts
<i>eth_bpdu_outlost</i>	(Optional) BPDU output lost
<i>eth_cos0_outlost</i>	(Optional) output pkts
<i>eth_cos1_outlost</i>	(Optional) output pkts
<i>eth_cos2_outlost</i>	(Optional) output pkts
<i>eth_cos3_outlost</i>	(Optional) output pkts
<i>eth_cos4_outlost</i>	(Optional) output pkts
<i>eth_cos5_outlost</i>	(Optional) output pkts
<i>eth_cos6_outlost</i>	(Optional) output pkts
<i>eth_cos7_outlost</i>	(Optional) output pkts
<i>eth_fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>eth_fcoe_in_octets</i>	(Optional) fcoe in octets
<i>eth_fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>eth_fcoe_out_octets</i>	(Optional) fcoe out octets
<i>eth_nfcoe_in_pkts</i>	(Optional) nfcoe in pkts
<i>eth_nfcoe_in_octets</i>	(Optional) nfcoe in octets
<i>eth_nfcoe_out_pkts</i>	(Optional) nfcoe out pkts
<i>eth_nfcoe_out_octets</i>	(Optional) nfcoe out octets
<i>eth_eee_atx_lpi_msec</i>	(Optional) Tx Lpi usec
<i>eth_eee_arcv_lpi_msec</i>	(Optional) Rx Lpi usec
<i>eth_eee_atx_lpi_transitions</i>	(Optional) Tx Lpi requests
<i>eth_eee_arcv_lpi_transitions</i>	(Optional) Rx Lpi indications
<i>eth_phy_ber_count</i>	(Optional) Bit error rate counter
<i>eth_phy_errblks_count</i>	(Optional) Errored blocks counter
<i>svi_reliability</i>	(Optional) Reliability
<i>switchport</i>	(Optional) Switchport enabled

Command Mode

- /exec

show interface

```
show interface <ifmgmt> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ] [
<state_rsn> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [ <share_state> ] [ <eth_bundle> ] [ <eth_dce_mode> ] [
<vpc_status> ] [ <eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [ <eth_ip_addr> ] [
<eth_ip_mask> ] [ <eth_ip_prefix> ] [ <eth_mtu> ] [ <eth_bw> ] [ <eth_encap_vlan> ] [ <encapsulation> ]
[ <eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [ <eth_rxload> ] [ <eth_loopback> ] [ <eth_keepalive> ]
[ <eth_duplex> ] [ <eth_speed> ] [ <eth_mode> ] [ <eth_ratemode> ] [ <eth_autoneg> ] [ <eth_beacon> ] [
<eth_media> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [ <eth_sw_t_monitor> ] [
<eth_ethertype> ] [ <eth_members> ] [ <eth_clk_mode> ] [ <eth_arp_type> ] [ <eth_arp_timeout> ] [
<eth_last_in> ] [ <eth_last_out> ] [ <eth_out_hang> ] [ <eth_clear_counters> ] [ <eth_link_flapped> ] [
<eth_inq_size> ] [ <eth_inq_max> ] [ <eth_inq_drops> ] [ <eth_inq_flush> ] [ <eth_out_drop> ] [
<eth_q_strategy> ] [ <eth_outq_size> ] [ <eth_outq_max> ] [ <eth_reset_cntr> ] [ <mgmt_hw_desc> ] [
<mgmt_hw_addr> ] [ <mgmt_ip_addr> ] [ <mgmt_ip_mask> ] [ <mgmt_mtu> ] [ <mgmt_speed> ] [
<mgmt_duplex> ] [ <vdc_lvl_in_avg_bits> ] [ <vdc_lvl_in_avg_pkts> ] [ <vdc_lvl_out_avg_bits> ] [
<vdc_lvl_out_avg_pkts> ] [ <vdc_lvl_in_pkts> ] [ <vdc_lvl_in_ucast> ] [ <vdc_lvl_in_mcast> ] [
<vdc_lvl_in_bcast> ] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [ <vdc_lvl_out_pkts> ]
[ <vdc_lvl_out_ucast> ] [ <vdc_lvl_out_mcast> ] [ <vdc_lvl_out_bcast> ] [ <vdc_lvl_out_bytes> ] [
<vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifmgmt</i>	Enter interface type and number in module/slot format
<u>__readonly__</u>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>state_rsn</i>	(Optional) Interface state reason
<i>eth_rsn_fac</i>	(Optional) State reason facility
<i>eth_rsn_code</i>	(Optional) State reason code
<i>share_state</i>	(Optional) Interface ownership
<i>eth_bundle</i>	(Optional) Belongs to bundle
<i>eth_dce_mode</i>	(Optional) DCE mode description
<i>vpc_status</i>	(Optional) VPC status
<i>eth_hw_desc</i>	(Optional) HW description

<i>eth_hw_addr</i>	(Optional) HW address
<i>eth_bia_addr</i>	(Optional) bia address
<i>desc</i>	(Optional) Interface description
<i>eth_ip_addr</i>	(Optional) IP Address
<i>eth_ip_mask</i>	(Optional) IP address mask
<i>eth_ip_prefix</i>	(Optional) IP address prefix
<i>eth_mtu</i>	(Optional) MTU
<i>eth_bw</i>	(Optional) Bandwidth
<i>eth_encap_vlan</i>	(Optional) Encapsulation Vlan
<i>encapsulation</i>	(Optional) Encapsulation
<i>eth_dly</i>	(Optional) Delay
<i>eth_reliability</i>	(Optional) Reliability
<i>eth_txload</i>	(Optional) Tx load
<i>eth_rxload</i>	(Optional) Rx load
<i>eth_loopback</i>	(Optional) Loopback
<i>eth_keepalive</i>	(Optional) Keepalive
<i>eth_duplex</i>	(Optional) Duplex
<i>eth_speed</i>	(Optional) Speed
<i>eth_mode</i>	(Optional) Port mode
<i>eth_ratemode</i>	(Optional) Rate mode
<i>eth_autoneg</i>	(Optional) Autonegotiation
<i>eth_beacon</i>	(Optional) Beacon
<i>eth_media</i>	(Optional) Media type
<i>eth_in_flowctrl</i>	(Optional) Input flowcontrol
<i>eth_out_flowctrl</i>	(Optional) Output flowcontrol
<i>eth_mdix</i>	(Optional) Mdx
<i>eth_swt_monitor</i>	(Optional) Switchport Monitor
<i>eth_ethertype</i>	(Optional) EtherType
<i>eth_members</i>	(Optional) Members in this channel

<i>eth_clk_mode</i>	(Optional) Clock mode
<i>eth_arp_type</i>	(Optional) ARP type
<i>eth_arp_timeout</i>	(Optional) ARP timeout
<i>eth_last_in</i>	(Optional) Last input
<i>eth_last_out</i>	(Optional) Last output
<i>eth_out_hang</i>	(Optional) Last output hang
<i>eth_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>eth_link_flapped</i>	(Optional) Last link flapped
<i>eth_inq_size</i>	(Optional) Input queue size
<i>eth_inq_max</i>	(Optional) Input queue max
<i>eth_inq_drops</i>	(Optional) Input queue drops
<i>eth_inq_flush</i>	(Optional) Input queue flushes
<i>eth_out_drop</i>	(Optional) Output drops
<i>eth_q_strategy</i>	(Optional) Queueing strategy
<i>eth_outq_size</i>	(Optional) Output queue size
<i>eth_outq_max</i>	(Optional) Output queue max
<i>eth_reset_cntr</i>	(Optional) Interface resets
<i>mgmt_hw_desc</i>	(Optional) HW description
<i>mgmt_hw_addr</i>	(Optional) HW address
<i>mgmt_ip_addr</i>	(Optional) IP address
<i>mgmt_ip_mask</i>	(Optional) IP address mask
<i>mgmt_mtu</i>	(Optional) MTU
<i>mgmt_speed</i>	(Optional) Speed
<i>mgmt_duplex</i>	(Optional) Duplex
<i>vdc_lvl_in_avg_bits</i>	(Optional) VDC level average input bits
<i>vdc_lvl_in_avg_pkts</i>	(Optional) VDC level average input packets
<i>vdc_lvl_out_avg_bits</i>	(Optional) VDC level average output bits
<i>vdc_lvl_out_avg_pkts</i>	(Optional) VDC level average output packets
<i>vdc_lvl_in_pkts</i>	(Optional) VDC level input packets

<i>vdc_lvl_in_ucast</i>	(Optional) VDC level input unicast packets
<i>vdc_lvl_in_mcast</i>	(Optional) VDC level input multicast packets
<i>vdc_lvl_in_bcast</i>	(Optional) VDC level input broadcast packets
<i>vdc_lvl_in_bytes</i>	(Optional) VDC level input bytes
<i>vdc_lvl_in_bps</i>	(Optional) VDC level input bytes per second
<i>vdc_lvl_in_pps</i>	(Optional) VDC level input packets per second
<i>vdc_lvl_out_pkts</i>	(Optional) VDC level output packets
<i>vdc_lvl_out_ucast</i>	(Optional) VDC level output unicast packets
<i>vdc_lvl_out_mcast</i>	(Optional) VDC level output multicast packets
<i>vdc_lvl_out_bcast</i>	(Optional) VDC level output broadcast packets
<i>vdc_lvl_out_bytes</i>	(Optional) VDC level output bytes
<i>vdc_lvl_out_bps</i>	(Optional) VDC level output bytes per second
<i>vdc_lvl_out_pps</i>	(Optional) VDC level output packets per second

Command Mode

- /exec

show interface

```
show interface <ifloop> [ __readonly__ TABLE_interface <interface> [ <state> ] [ <admin_state> ] [
<share_state> ] [ <state_rsn> ] [ <state_rsn_desc> ] [ <desc> ] [ <eth_bundle> ] [ <mgmt_sfp> ] [ <mgmt_type> ]
] [ <eth_eee_state> ] [ <eth_dce_mode> ] [ <vpc_status> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [
<eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix> ]
] [ <eth_mtu> ] [ <eth_bw> ] [ <eth_encap_vlan> ] [ <encapsulation> ] [ <eth_dly> ] [ <eth_reliability> ] [
<eth_txload> ] [ <eth_rxload> ] [ <eth_loopback> ] [ <eth_keepalive> ] [ <eth_duplex> ] [ <eth_speed> ] [
<eth_mode> ] [ <eth_ratemode> ] [ <eth_autoneg> ] [ <eth_beacon> ] [ <eth_media> ] [ <eth_in_flowctrl> ]
] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [ <eth_swt_monitor> ] [ <eth_ethertype> ] [ <eth_members> ] [
<eth_clk_mode> ] [ <eth_arp_type> ] [ <eth_arp_timeout> ] [ <eth_last_in> ] [ <eth_last_out> ] [
<eth_out_hang> ] [ <eth_clear_counters> ] [ <eth_link_flapped> ] [ <eth_inq_size> ] [ <eth_inq_max> ] [
<eth_inq_drops> ] [ <eth_inq_flush> ] [ <eth_out_drop> ] [ <eth_q_strategy> ] [ <eth_outq_size> ] [
<eth_outq_max> ] [ <eth_reset_cnt> ] [ <loop_in_pkts> ] [ <loop_in_bytes> ] [ <loop_in_mcast> ] [
<loop_in_compressed> ] [ <loop_in_errors> ] [ <loop_in_frame> ] [ <loop_in_overrun> ] [ <loop_in_fifo> ]
] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [ <loop_out_underruns> ] [ <loop_out_errors> ] [
<loop_out_collisions> ] [ <loop_out_fifo> ] [ <loop_out_carriers> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifloop</i>	Enter interface type and number in module/slot format
<u>__readonly__</u>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
<u>TABLE_interface</u>	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>admin_state</i>	(Optional) Interface admin state
<i>share_state</i>	(Optional) Interface ownership
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>desc</i>	(Optional) Interface description
<i>mgmt_sfp</i>	(Optional) mgmt sfp
<i>mgmt_type</i>	(Optional) mgmt type
<i>eth_bundle</i>	(Optional) Belongs to bundle
<i>eth_eee_state</i>	(Optional) EEE state
<i>eth_dce_mode</i>	(Optional) DCE mode description

<i>vpc_status</i>	(Optional) VPC status
<i>eth_rsn_fac</i>	(Optional) State reason facility
<i>eth_rsn_code</i>	(Optional) State reason code
<i>eth_hw_desc</i>	(Optional) HW description
<i>eth_hw_addr</i>	(Optional) HW address
<i>eth_bia_addr</i>	(Optional) bia address
<i>eth_ip_addr</i>	(Optional) IP Address
<i>eth_ip_mask</i>	(Optional) IP address mask
<i>eth_ip_prefix</i>	(Optional) IP Prefix
<i>eth_mtu</i>	(Optional) MTU
<i>eth_bw</i>	(Optional) Bandwidth
<i>eth_encap_vlan</i>	(Optional) Encapsulation Vlan
<i>encapsulation</i>	(Optional) Encapsulation
<i>eth_dly</i>	(Optional) Delay
<i>eth_reliability</i>	(Optional) Reliability
<i>eth_txload</i>	(Optional) Tx load
<i>eth_rxload</i>	(Optional) Rx load
<i>eth_loopback</i>	(Optional) Loopback
<i>eth_keepalive</i>	(Optional) Keepalive
<i>eth_duplex</i>	(Optional) Duplex
<i>eth_speed</i>	(Optional) Speed
<i>eth_mode</i>	(Optional) Port mode
<i>eth_ratemode</i>	(Optional) Rate mode
<i>eth_autoneg</i>	(Optional) Autonegotiation
<i>eth_beacon</i>	(Optional) Beacon
<i>eth_media</i>	(Optional) Media type
<i>eth_in_flowctrl</i>	(Optional) Input flowcontrol
<i>eth_out_flowctrl</i>	(Optional) Output flowcontrol
<i>eth_mdix</i>	(Optional) Mdx

<i>eth_swt_monitor</i>	(Optional) Switchport Monitor
<i>eth_etherstype</i>	(Optional) EtherType
<i>eth_members</i>	(Optional) Members in this channel
<i>eth_clk_mode</i>	(Optional) Clock mode
<i>eth_arp_type</i>	(Optional) ARP type
<i>eth_arp_timeout</i>	(Optional) ARP timeout
<i>eth_last_in</i>	(Optional) Last input
<i>eth_last_out</i>	(Optional) Last output
<i>eth_out_hang</i>	(Optional) Last output hang
<i>eth_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>eth_link_flapped</i>	(Optional) Last link flapped
<i>eth_inq_size</i>	(Optional) Input queue size
<i>eth_inq_max</i>	(Optional) Input queue max
<i>eth_inq_drops</i>	(Optional) Input queue drops
<i>eth_inq_flush</i>	(Optional) Input queue flushes
<i>eth_out_drop</i>	(Optional) Output drops
<i>eth_q_strategy</i>	(Optional) Queueing strategy
<i>eth_outq_size</i>	(Optional) Output queue size
<i>eth_outq_max</i>	(Optional) Output queue max
<i>eth_reset_cntr</i>	(Optional) Interface resets
<i>loop_in_pkts</i>	(Optional) Input packets
<i>loop_in_bytes</i>	(Optional) Input bytes
<i>loop_in_mcast</i>	(Optional) Input multicast
<i>loop_in_compressed</i>	(Optional) Input compressed
<i>loop_in_errors</i>	(Optional) Input errors
<i>loop_in_frame</i>	(Optional) Input frame errors
<i>loop_in_overrun</i>	(Optional) Input overrun
<i>loop_in_fifo</i>	(Optional) Input fifo
<i>loop_out_pkts</i>	(Optional) Output packets

<i>loop_out_bytes</i>	(Optional) Output bytes
<i>loop_out_underruns</i>	(Optional) Output underruns
<i>loop_out_errors</i>	(Optional) Output errors
<i>loop_out_collisions</i>	(Optional) Output collisions
<i>loop_out_fifo</i>	(Optional) Output fifo
<i>loop_out_carriers</i>	(Optional) Output carrier errors

Command Mode

- /exec

show interface

```
show interface <iftun_desc> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ] [
<desc> ] <admin-state> { <tunnel-ipv4> | <tunnel-ipv6> } <mtu> <bandwidth> <encap-type>
<keepalive-period> <keepalive-retries> { <src-ipv4> | <src-ipv6> } <src-intf> { <dest-ipv4> | <dest-ipv6> }
<dest-hostname> <vrf_name> <tunnel_vrf_name> <wccp_header> <ttl_val> <tunnel_pmtud_age_time>
<tunnel_pmtud_min_mtu> <tunnel_pmtud> <tunnel_pgm_mtu> <tunnel_rx_pkt_count>
<tunnel_rx_byte_count> <tunnel_rx_rate> <tunnel_tx_pkt_count> <tunnel_tx_byte_count> <tunnel_tx_rate>
<tunnel_clear_counter> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>iftun_desc</i>	Enter tunnel interface number
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>desc</i>	(Optional) Interface description
<i>admin-state</i>	(Optional)
<i>tunnel-ipv4</i>	(Optional) interface IPv4 address
<i>mtu</i>	(Optional) interface Maximum Transmission Unit
<i>bandwidth</i>	(Optional) interface Bandwidth in kilobits
<i>encap-type</i>	(Optional)
<i>keepalive-period</i>	(Optional) keealive period
<i>keepalive-retries</i>	(Optional) number of retries
<i>src-ipv4</i>	(Optional) tunnel source IPv4 address
<i>src-intf</i>	(Optional) tunnel source interface
<i>dest-ipv4</i>	(Optional) tunnel destination IPv4 address
<i>dest-hostname</i>	(Optional) tunnel destination hostname
<i>vrf_name</i>	(Optional) transport VRF name
<i>tunnel_vrf_name</i>	(Optional) tunnel VRF name

<i>wccp_header</i>	(Optional) wccp header
<i>ttl_val</i>	(Optional) tunnel time to live value
<i>tunnel_pmtud_age_time</i>	(Optional) tunnel path MTU discovery age time
<i>tunnel_pmtud_min_mtu</i>	(Optional) tunnel path MTU discovery min mtu
<i>tunnel_pmtud</i>	(Optional) tunnel path MTU discovered
<i>tunnel_pgm_mtu</i>	(Optional) tunnel actual programmed MTU
<i>tunnel_rx_pkt_count</i>	(Optional) total number of packets received
<i>tunnel_rx_byte_count</i>	(Optional) total number of bytes received
<i>tunnel_rx_rate</i>	(Optional) packets input rate per 5 minutes
<i>tunnel_tx_pkt_count</i>	(Optional) total number of packets transmitted
<i>tunnel_tx_byte_count</i>	(Optional) total number of bytes transmitted
<i>tunnel_tx_rate</i>	(Optional) packets transmitted per 5 minutes
<i>tunnel_clear_counter</i>	(Optional) Last clearing of show interface counters

Command Mode

- /exec

show interface

```
show interface <ifeth> [ quick ] [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ]
[ <state_rsn> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [ <admin_state> ] [ <share_state> ] [ <parent_interface>
] [ <vpc_status> ] [ <eth_bundle> ] [ <eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [
<eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix> ] [ <eth_mtu> ] + [ <eth_bw> ] [ <eth_bw_str> ] [
<eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [ <eth_rxload> ] [ <eth_encap_vlan> ] [ <encapsulation> ]
[ <medium> ] [ <eth_mode> ] [ <eth_duplex> ] [ <eth_speed> ] [ <eth_media> ] [ <eth_beacon> ] [
<eth_autoneg> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [ <eth_ratemode> ] [
<eth_swt_monitor> ] [ <eth_ethertype> ] [ <eth_eee_state> ] [ <eth_admin_fec_state> ] [ <eth_oper_fec_state>
] [ <eth_members> ] [ <eth_link_flapped> ] [ <eth_clear_counters> ] [ <eth_reset_cntr> ] [
<eth_load_intervall_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [ <eth_load_interval1_tx> ] [
<eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ] [ <eth_inrate1_summary_pkts>
] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [ <eth_load_interval2_rx> ] [
<eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [ <eth_outrate2_bits> ] [
<eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ] [
<eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes>
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes>
] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_inpkts> ] [ <eth_inbytes> ] [ <eth_jumbo_inpkts>
] [ <eth_storm_supp> ] [ <eth_runts> ] [ <eth_giants> ] [ <eth_crc> ] [ <eth_nobuf> ] [ <eth_inerr> ] [
<eth_frame> ] [ <eth_overrun> ] [ <eth_underrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_bad_eth>
] [ <eth_bad_proto> ] [ <eth_in_ifdown_drops> ] [ <eth_dribble> ] [ <eth_indiscard> ] [ <eth_inpause> ] [
<eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [
<eth_jumbo_outpkts> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_deferred> ] [ <eth_latecoll> ] [ <eth_lostcarrier>
] [ <eth_nocarrier> ] [ <eth_babbles> ] [ <eth_outdiscard> ] [ <eth_outpause> ] [ <switchport> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth</i>	Enter interface type and number in module/slot format
quick	(Optional) Show info of interface skipping stats
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state

<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>state_rsn</i>	(Optional) Interface state reason
<i>eth_rsn_fac</i>	(Optional) State reason facility
<i>eth_rsn_code</i>	(Optional) State reason code
<i>admin_state</i>	(Optional) admin state
<i>share_state</i>	(Optional) Interface ownership
<i>parent_interface</i>	(Optional) parent interface
<i>vpc_status</i>	(Optional) VPC status
<i>eth_bundle</i>	(Optional) Belongs to bundle
<i>eth_hw_desc</i>	(Optional) HW description
<i>eth_hw_addr</i>	(Optional) HW address
<i>eth_bia_addr</i>	(Optional) bia address
<i>desc</i>	(Optional) Interface description
<i>eth_ip_addr</i>	(Optional) IP Address
<i>eth_ip_mask</i>	(Optional) IP address mask
<i>eth_ip_prefix</i>	(Optional) IP address prefix
<i>eth_mtu</i>	(Optional) MTU
<i>eth_bw</i>	(Optional) Bandwidth
<i>eth_bw_str</i>	(Optional) Bandwidth
<i>eth_dly</i>	(Optional) Delay
<i>eth_reliability</i>	(Optional) Reliability
<i>eth_txload</i>	(Optional) Tx load
<i>eth_rxload</i>	(Optional) Rx load
<i>eth_encap_vlan</i>	(Optional) Encapsulation Vlan
<i>encapsulation</i>	(Optional) Encapsulation
<i>medium</i>	(Optional) medium type
<i>eth_mode</i>	(Optional) Port mode
<i>eth_duplex</i>	(Optional) Duplex
<i>eth_speed</i>	(Optional) Speed

<i>eth_media</i>	(Optional) Media type
<i>eth_beacon</i>	(Optional) Beacon
<i>eth_autoneg</i>	(Optional) Autonegotiation
<i>eth_in_flowctrl</i>	(Optional) Input flowcontrol
<i>eth_out_flowctrl</i>	(Optional) Output flowcontrol
<i>eth_mdix</i>	(Optional) Mdx
<i>eth_ratemode</i>	(Optional) Rate mode
<i>eth_swt_monitor</i>	(Optional) Switchport Monitor
<i>eth_etherType</i>	(Optional) EtherType
<i>eth_eee_state</i>	(Optional) EEE state
<i>eth_admin_fec_state</i>	(Optional) Admin FEC state
<i>eth_oper_fec_state</i>	(Optional) Oper FEC state
<i>eth_members</i>	(Optional) Members in this channel
<i>eth_link_flapped</i>	(Optional) Last link flapped
<i>eth_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>eth_reset_cntr</i>	(Optional) Interface resets
<i>eth_load_intervall_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_intervall_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec

<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec
<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes

<i>eth_l3out_ucastpkts</i>	(Optional) L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes
<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_jumbo_inpkts</i>	(Optional) Incoming jumbo pkts
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_runts</i>	(Optional) runts
<i>eth_giants</i>	(Optional) giants
<i>eth_crc</i>	(Optional) CRC
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_inerr</i>	(Optional) input errors
<i>eth_frame</i>	(Optional) frame
<i>eth_overrun</i>	(Optional) overrun
<i>eth_underrun</i>	(Optional) underruns

<i>eth_ignored</i>	(Optional) ignored
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_indiscard</i>	(Optional) discards
<i>eth_inpause</i>	(Optional) pause input
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_jumbo_outpkts</i>	(Optional) Outgoing jumbo pkts
<i>eth_outerr</i>	(Optional) output errors
<i>eth_coll</i>	(Optional) collisions
<i>eth_deferred</i>	(Optional) deferred
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_babbles</i>	(Optional) babbles
<i>eth_outdiscard</i>	(Optional) output discard
<i>eth_outpause</i>	(Optional) PAUSE output
<i>switchport</i>	(Optional) Switchport enabled

Command Mode

- /exec

show interface

```
show interface <ifrange> [ __readonly__ TABLE_interface <interface> <state> <state_rsn> <state_rsn_desc>
<desc> [ <overlay_addr> ] [ <overlay_addr_mask> ] [ <overlay_mtu> ] [ <overlay_bandwidth> ] [
<overlay_encap_str> ] [ <overlay_vrf> ] [ <overlay_src_addr> ] [ <overlay_dst_addr> ] [
<overlay_last_link_flap> ] [ <overlay_clear_counters> ] [ <overlay_load_interval> ] [ <overlay_rx_ucastpkts>
] [ <overlay_rx_ucastbytes> ] [ <overlay_rx_mcastpkts> ] [ <overlay_rx_mcastbytes> ] [ <overlay_rx_pkts>
] [ <overlay_rx_bytes> ] [ <overlay_rx_bcastpkts> ] [ <overlay_rx_bcastbytes> ] [ <overlay_rx_bitrate> ] [
<overlay_rx_pktrate> ] [ <overlay_tx_ucastpkts> ] [ <overlay_tx_ucastbytes> ] [ <overlay_tx_mcastpkts> ]
[ <overlay_tx_mcastbytes> ] [ <overlay_tx_bcastpkts> ] [ <overlay_tx_bcastbytes> ] [ <overlay_tx_pkts> ]
[ <overlay_tx_bytes> ] [ <overlay_tx_bitrate> ] [ <overlay_tx_pktrate> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>desc</i>	(Optional) Interface description
<i>overlay_addr</i>	(Optional) Overlay address
<i>overlay_addr_mask</i>	(Optional) Overlay address mask
<i>overlay_mtu</i>	(Optional) MTU
<i>overlay_bandwidth</i>	(Optional) Bandwidth
<i>overlay_encap_str</i>	(Optional) Encap type
<i>overlay_vrf</i>	(Optional) VRF
<i>overlay_src_addr</i>	(Optional) Source address
<i>overlay_dst_addr</i>	(Optional) Destination address
<i>overlay_last_link_flap</i>	(Optional) Last link flap
<i>overlay_clear_counters</i>	(Optional) Last clearing of show interface counters

<i>overlay_load_interval</i>	(Optional) Load interval
<i>overlay_rx_ucastpkts</i>	(Optional) Received ucast pkts
<i>overlay_rx_ucastbytes</i>	(Optional) Received ucast bytes
<i>overlay_rx_mcastpkts</i>	(Optional) Received mcast pkts
<i>overlay_rx_mcastbytes</i>	(Optional) Received mcast bytes
<i>overlay_rx_bcastpkts</i>	(Optional) Received bcast pkts
<i>overlay_rx_bcastbytes</i>	(Optional) Received bcast bytes
<i>overlay_rx_pkts</i>	(Optional) Total received pkts
<i>overlay_rx_bytes</i>	(Optional) Total received bytes
<i>overlay_rx_bitrate</i>	(Optional) Receive bit rate
<i>overlay_rx_pktrate</i>	(Optional) Receive pkt rate
<i>overlay_tx_ucastpkts</i>	(Optional) Trasnmitted ucast pkts
<i>overlay_tx_ucastbytes</i>	(Optional) Trasnmitted ucast bytes
<i>overlay_tx_mcastpkts</i>	(Optional) Trasnmitted mcast pkts
<i>overlay_tx_mcastbytes</i>	(Optional) Trasnmitted mcast bytes
<i>overlay_tx_bcastpkts</i>	(Optional) Trasnmitted bcast pkts
<i>overlay_tx_bcastbytes</i>	(Optional) Trasnmitted bcast bytes
<i>overlay_tx_pkts</i>	(Optional) Total transmitted pkts
<i>overlay_tx_bytes</i>	(Optional) Total transmitted bytes
<i>overlay_tx_bitrate</i>	(Optional) Transmit bit rate
<i>overlay_tx_pktrate</i>	(Optional) Transmit pkt rate

Command Mode

- /exec

show interface

```
show interface <ifrange> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ] [
<state_rsn> ] [ <admin_state> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [ <share_state> ] [ <vpc_status> ] [
<eth_bundle> ] [ <eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [ <eth_ip_addr> ] [
<eth_ip_mask> ] [ <eth_mtu> ] [ <eth_bw> ] [ <eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [ <eth_rxload>
] [ <eth_encap_vlan> ] [ <encapsulation> ] [ <eth_mode> ] [ <eth_duplex> ] [ <eth_speed> ] [ <eth_media>
] [ <eth_beacon> ] [ <eth_autoneg> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [
<eth_ratemode> ] [ <eth_swt_monitor> ] [ <eth_etherstype> ] [ <eth_members> ] [ <eth_link_flapped> ] [
<eth_clear_counters> ] [ <eth_reset_cntr> ] [ <nve_addr> ] [ <nve_addr_mask> ] [ <nve_vcid> ] [ <nve_mtu>
] [ <nve_bandwidth> ] [ <nve_encap_str> ] [ <nve_vrf> ] [ <nve_src_addr> ] [ <nve_dst_addr> ] [
<nve_last_link_flap> ] [ <nve_clear_counters> ] [ <nve_load_interval> ] [ <nve_rx_ucastpkts> ] [
<nve_rx_ucastbytes> ] [ <nve_rx_mcastpkts> ] [ <nve_rx_mcastbytes> ] [ <nve_rx_pkts> ] [ <nve_rx_bytes>
] [ <nve_rx_bcastpkts> ] [ <nve_rx_bcastbytes> ] [ <nve_rx_bitrate> ] [ <nve_rx_pktrate> ] [
<nve_tx_ucastpkts> ] [ <nve_tx_ucastbytes> ] [ <nve_tx_mcastpkts> ] [ <nve_tx_mcastbytes> ] [
<nve_tx_bcastpkts> ] [ <nve_tx_bcastbytes> ] [ <nve_tx_pkts> ] [ <nve_tx_bytes> ] [ <nve_tx_bitrate> ] [
<nve_tx_pktrate> ] ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>state_rsn</i>	(Optional) Interface state reason
<i>admin_state</i>	(Optional) admin state
<i>eth_rsn_fac</i>	(Optional) State reason facility
<i>eth_rsn_code</i>	(Optional) State reason code
<i>share_state</i>	(Optional) Interface ownership
<i>vpc_status</i>	(Optional) VPC status
<i>eth_bundle</i>	(Optional) Belongs to bundle
<i>eth_hw_desc</i>	(Optional) HW description
<i>eth_hw_addr</i>	(Optional) HW address

<i>eth_bia_addr</i>	(Optional) bia address
<i>desc</i>	(Optional) Interface description
<i>eth_ip_addr</i>	(Optional) IP Address
<i>eth_ip_mask</i>	(Optional) IP address mask
<i>eth_mtu</i>	(Optional) MTU
<i>eth_bw</i>	(Optional) Bandwidth
<i>eth_dly</i>	(Optional) Delay
<i>eth_reliability</i>	(Optional) Reliability
<i>eth_txload</i>	(Optional) Tx load
<i>eth_rxload</i>	(Optional) Rx load
<i>eth_encap_vlan</i>	(Optional) Encapsulation Vlan
<i>encapsulation</i>	(Optional) Encapsulation
<i>eth_mode</i>	(Optional) Port mode
<i>eth_duplex</i>	(Optional) Duplex
<i>eth_speed</i>	(Optional) Speed
<i>eth_media</i>	(Optional) Media type
<i>eth_beacon</i>	(Optional) Beacon
<i>eth_autoneg</i>	(Optional) Autonegotiation
<i>eth_in_flowctrl</i>	(Optional) Input flowcontrol
<i>eth_out_flowctrl</i>	(Optional) Output flowcontrol
<i>eth_mdix</i>	(Optional) Mdx
<i>eth_ratemode</i>	(Optional) Rate mode
<i>eth_sw_t_monitor</i>	(Optional) Switchport Monitor
<i>eth_ethertype</i>	(Optional) EtherType
<i>eth_members</i>	(Optional) Members in this channel
<i>eth_link_flapped</i>	(Optional) Last link flapped
<i>eth_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>eth_reset_cntr</i>	(Optional) Interface resets
<i>nve_addr</i>	(Optional) Peer address

<i>nve_addr_mask</i>	(Optional) Peer address mask
<i>nve_vcid</i>	(Optional) VCID
<i>nve_mtu</i>	(Optional) MTU
<i>nve_bandwidth</i>	(Optional) Bandwidth
<i>nve_encap_str</i>	(Optional) Encap type
<i>nve_vrf</i>	(Optional) VRF
<i>nve_src_addr</i>	(Optional) Source address
<i>nve_dst_addr</i>	(Optional) Destination address
<i>nve_last_link_flap</i>	(Optional) Last link flap
<i>nve_clear_counters</i>	(Optional) Last clearing of show interface counters
<i>nve_load_interval</i>	(Optional) Load interval
<i>nve_rx_ucastpkts</i>	(Optional) Received ucast pkts
<i>nve_rx_ucastbytes</i>	(Optional) Received ucast bytes
<i>nve_rx_mcastpkts</i>	(Optional) Received mcast pkts
<i>nve_rx_mcastbytes</i>	(Optional) Received mcast bytes
<i>nve_rx_bcastpkts</i>	(Optional) Received bcast pkts
<i>nve_rx_bcastbytes</i>	(Optional) Received bcast bytes
<i>nve_rx_pkts</i>	(Optional) Total received pkts
<i>nve_rx_bytes</i>	(Optional) Total received bytes
<i>nve_rx_bitrate</i>	(Optional) Receive bit rate
<i>nve_rx_pktrate</i>	(Optional) Receive pkt rate
<i>nve_tx_ucastpkts</i>	(Optional) Trasnmitted ucast pkts
<i>nve_tx_ucastbytes</i>	(Optional) Trasnmitted ucast bytes
<i>nve_tx_mcastpkts</i>	(Optional) Trasnmitted mcast pkts
<i>nve_tx_mcastbytes</i>	(Optional) Trasnmitted mcast bytes
<i>nve_tx_bcastpkts</i>	(Optional) Trasnmitted bcast pkts
<i>nve_tx_bcastbytes</i>	(Optional) Trasnmitted bcast bytes
<i>nve_tx_pkts</i>	(Optional) Total transmitted pkts
<i>nve_tx_bytes</i>	(Optional) Total transmitted bytes

<i>nve_tx_bitrate</i>	(Optional) Transmit bit rate
<i>nve_tx_pktrate</i>	(Optional) Transmit pkt rate

Command Mode

- /exec

show interface aggregate-counters

```
show interface aggregate-counters [ brief ] [ __readonly__ TABLE interface <interface_aggr> [ <str_aggr>
] [ <if_index_aggr> ] [ <in_bps_aggr> ] [ <in_byps_aggr> ] [ <in_fps_aggr> ] [ <out_bps_aggr> ] [
<out_byps_aggr> ] [ <out_fps_aggr> ] [ <total_in_frames_aggr> ] [ <total_in_bytes_aggr> ] [
<C2InFrames_aggr> ] [ <C2InOctets_aggr> ] [ <C3InFrames_aggr> ] [ <C3InOctets_aggr> ] [
<CfInFrames_aggr> ] [ <CfInOctets_aggr> ] [ <total_in_discards_aggr> ] [ <total_in_errors_aggr> ] [
<InvalidCrcs_aggr> ] [ <UnknownClassFrames_aggr> ] [ <FramesTooLong_aggr> ] [ <FramesTooShort_aggr>
] [ <total_out_frames_aggr> ] [ <total_out_bytes_aggr> ] [ <C2OutFrames_aggr> ] [ <C2OutOctets_aggr> ]
[ <C3OutFrames_aggr> ] [ <C3OutOctets_aggr> ] [ <CfOutFrames_aggr> ] [ <CfOutOctets_aggr> ] [
<total_out_discards_aggr> ] [ <total_out_errors_aggr> ] [ <OlsIns_aggr> ] [ <LRRIn_aggr> ] [ <NOSIn_aggr>
] [ <in_lip_aggr> ] [ <OlsOuts_aggr> ] [ <LRROut_aggr> ] [ <NOSOut_aggr> ] [ <out_lip_aggr> ] [
<LinkFailures_aggr> ] [ <SyncLosses_aggr> ] [ <SigLosses_aggr> ] [ <TxBBCreditTransistionToZero_aggr>
] [ <RxBBCreditTransistionToZero_aggr> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit>
] [ <tx_b2b_low_pri_cre> ] [ <InputRate_aggr_brief> ] [ <TotalIpFrame_aggr_brief> ] [ <OutRate_aggr_brief>
] [ <TotalOpFrame_aggr_brief> ] [ <line_aggr_brief> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
aggregate-counters	Show interface aggregate counters
brief	(Optional) Show interface aggregate counters in brief
__readonly__	(Optional) Read Only
<i>interface_aggr</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>str_aggr</i>	(Optional) string
<i>if_index_aggr</i>	(Optional) index
<i>in_bps_aggr</i>	(Optional) input rate in bits/s
<i>in_byps_aggr</i>	(Optional) input rate in bytes/s
<i>in_fps_aggr</i>	(Optional) input rate in frames/s
<i>out_bps_aggr</i>	(Optional) output rate in bits/s
<i>out_byps_aggr</i>	(Optional) output rate in bytes/s
<i>out_fps_aggr</i>	(Optional) output rate in frames/s
<i>total_in_frames_aggr</i>	(Optional) total input frames
<i>total_in_bytes_aggr</i>	(Optional) total input frames
<i>C2InFrames_aggr</i>	(Optional) class-2 frames

<i>C2InOctets_aggr</i>	(Optional) class-2 frames in bytes
<i>C3InFrames_aggr</i>	(Optional) class-3 frames
<i>C3InOctets_aggr</i>	(Optional) class-3 frames in bytes
<i>CfInFrames_aggr</i>	(Optional) class-f frames
<i>CfInOctets_aggr</i>	(Optional) class-f frames in bytes
<i>total_in_discards_aggr</i>	(Optional) total in discards
<i>total_in_errors_aggr</i>	(Optional) total in errors
<i>InvalidCrcs_aggr</i>	(Optional) invalid CRC
<i>UnknownClassFrames_aggr</i>	(Optional) unknown class
<i>FramesTooLong_aggr</i>	(Optional) too long
<i>FramesTooShort_aggr</i>	(Optional) too short
<i>total_out_frames_aggr</i>	(Optional) total out frames
<i>total_out_bytes_aggr</i>	(Optional) total out frames in byte
<i>C2OutFrames_aggr</i>	(Optional) class-2 out frames
<i>C2OutOctets_aggr</i>	(Optional) class-2 out frames in bytes
<i>C3OutFrames_aggr</i>	(Optional) class-3 out frames
<i>C3OutOctets_aggr</i>	(Optional) class-3 out frames in bytes
<i>CfOutFrames_aggr</i>	(Optional) class-f out frames
<i>CfOutOctets_aggr</i>	(Optional) class-f out frames in bytes
<i>total_out_discards_aggr</i>	(Optional) total out discards
<i>total_out_errors_aggr</i>	(Optional) total out errors
<i>OlsIns_aggr</i>	(Optional) input OLS
<i>LRRIn_aggr</i>	(Optional) input LRR
<i>NOSIn_aggr</i>	(Optional) input NOS
<i>in_lip_aggr</i>	(Optional) loop inits
<i>OlsOuts_aggr</i>	(Optional) output OLS
<i>LRROut_aggr</i>	(Optional) output LRR
<i>NOSOut_aggr</i>	(Optional) output NOS
<i>out_lip_aggr</i>	(Optional) loop inits

<i>LinkFailures_aggr</i>	(Optional) link failure
<i>SyncLosses_aggr</i>	(Optional) sync losses
<i>SigLosses_aggr</i>	(Optional) signal losses
<i>TxBBCreditTransistionToZero_aggr</i>	(Optional) B2B credit transitions to zero
<i>RxBBCreditTransistionToZero_aggr</i>	(Optional) B2B credit transitions to zero
<i>rx_b2b_perf_buff</i>	(Optional) rx B2B performance buff
<i>rx_b2b_credit</i>	(Optional) rx B2B credit
<i>tx_b2b_credit</i>	(Optional) tx B2B credit
<i>tx_b2b_low_pri_cre</i>	(Optional) tx B2B low price credit
<i>InputRate_aggr_brief</i>	(Optional) Input rate in MBps
<i>TotalIpFrame_aggr_brief</i>	(Optional) Total input frames
<i>OutRate_aggr_brief</i>	(Optional) Output rate in MBps
<i>TotalOpFrame_aggr_brief</i>	(Optional) Total output frames
<i>line_aggr_brief</i>	(Optional) to print a line

Command Mode

- /exec

show interface aggregate-counters

```
show interface <ifid_aggr_ctrs2> aggregate-counters [ brief ] [ __readonly__ TABLE_interface
<interface_aggr> [ <str_aggr> ] [ <if_index_aggr> ] [ <in_bps_aggr> ] [ <in_byps_aggr> ] [ <in_fps_aggr>
] [ <out_bps_aggr> ] [ <out_byps_aggr> ] [ <out_fps_aggr> ] [ <total_in_frames_aggr> ] [
<total_in_bytes_aggr> ] [ <C2InFrames_aggr> ] [ <C2InOctets_aggr> ] [ <C3InFrames_aggr> ] [
<C3InOctets_aggr> ] [ <CfInFrames_aggr> ] [ <CfInOctets_aggr> ] [ <total_in_discards_aggr> ] [
<total_in_errors_aggr> ] [ <InvalidCrcs_aggr> ] [ <UnknownClassFrames_aggr> ] [ <FramesTooLong_aggr>
] [ <FramesTooShort_aggr> ] [ <total_out_frames_aggr> ] [ <total_out_bytes_aggr> ] [ <C2OutFrames_aggr>
] [ <C2OutOctets_aggr> ] [ <C3OutFrames_aggr> ] [ <C3OutOctets_aggr> ] [ <CfOutFrames_aggr> ] [
<CfOutOctets_aggr> ] [ <total_out_discards_aggr> ] [ <total_out_errors_aggr> ] [ <OlsIns_aggr> ] [
<LRRIn_aggr> ] [ <NOSIn_aggr> ] [ <in_lip_aggr> ] [ <OlsOuts_aggr> ] [ <LRROut_aggr> ] [
<NOSOut_aggr> ] [ <out_lip_aggr> ] [ <LinkFailures_aggr> ] [ <SyncLosses_aggr> ] [ <SigLosses_aggr>
] [ <TxBBCreditTransistionToZero_aggr> ] [ <RxBBCreditTransistionToZero_aggr> ] [ <rx_b2b_perf_buff>
] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] [ <InputRate_aggr_brief> ] [
<TotalIpFrame_aggr_brief> ] [ <OutRate_aggr_brief> ] [ <TotalOpFrame_aggr_brief> ] [ <line_aggr_brief>
] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_aggr_ctrs2</i>	Enter interface type and number in module/slot format
aggregate-counters	Show interface aggregate counters
brief	(Optional) Show interface aggregate counters in brief
<i>__readonly__</i>	(Optional) Read Only
<i>interface_aggr</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>str_aggr</i>	(Optional) string
<i>if_index_aggr</i>	(Optional) index
<i>in_bps_aggr</i>	(Optional) input rate in bits/s
<i>in_byps_aggr</i>	(Optional) input rate in bytes/s
<i>in_fps_aggr</i>	(Optional) input rate in frames/s
<i>out_bps_aggr</i>	(Optional) output rate in bits/s
<i>out_byps_aggr</i>	(Optional) output rate in bytes/s
<i>out_fps_aggr</i>	(Optional) output rate in frames/s
<i>total_in_frames_aggr</i>	(Optional) total input frames

<i>total_in_bytes_aggr</i>	(Optional) total input frames
<i>C2InFrames_aggr</i>	(Optional) class-2 frames
<i>C2InOctets_aggr</i>	(Optional) class-2 frames in bytes
<i>C3InFrames_aggr</i>	(Optional) class-3 frames
<i>C3InOctets_aggr</i>	(Optional) class-3 frames in bytes
<i>CfInFrames_aggr</i>	(Optional) class-f frames
<i>CfInOctets_aggr</i>	(Optional) class-f frames in bytes
<i>total_in_discards_aggr</i>	(Optional) total in discards
<i>total_in_errors_aggr</i>	(Optional) total in errors
<i>InvalidCrcs_aggr</i>	(Optional) invalid CRC
<i>UnknownClassFrames_aggr</i>	(Optional) unknown class
<i>FramesTooLong_aggr</i>	(Optional) too long
<i>FramesTooShort_aggr</i>	(Optional) too short
<i>total_out_frames_aggr</i>	(Optional) total out frames
<i>total_out_bytes_aggr</i>	(Optional) total out frames in byte
<i>C2OutFrames_aggr</i>	(Optional) class-2 out frames
<i>C2OutOctets_aggr</i>	(Optional) class-2 out frames in bytes
<i>C3OutFrames_aggr</i>	(Optional) class-3 out frames
<i>C3OutOctets_aggr</i>	(Optional) class-3 out frames in bytes
<i>CfOutFrames_aggr</i>	(Optional) class-f out frames
<i>CfOutOctets_aggr</i>	(Optional) class-f out frames in bytes
<i>total_out_discards_aggr</i>	(Optional) total out discards
<i>total_out_errors_aggr</i>	(Optional) total out errors
<i>OlsIns_aggr</i>	(Optional) input OLS
<i>LRRIn_aggr</i>	(Optional) input LRR
<i>NOSIn_aggr</i>	(Optional) input NOS
<i>in_lip_aggr</i>	(Optional) loop inits
<i>OlsOuts_aggr</i>	(Optional) output OLS
<i>LRROut_aggr</i>	(Optional) output LRR

<i>NOSOut_aggr</i>	(Optional) output NOS
<i>out_lip_aggr</i>	(Optional) loop inits
<i>LinkFailures_aggr</i>	(Optional) link failure
<i>SyncLosses_aggr</i>	(Optional) sync losses
<i>SigLosses_aggr</i>	(Optional) signal losses
<i>TxBBCreditTransitionToZero_aggr</i>	(Optional) B2B credit transitions to zero
<i>RxBBCreditTransitionToZero_aggr</i>	(Optional) B2B credit transitions to zero
<i>rx_b2b_perf_buff</i>	(Optional) rx B2B performance buff
<i>rx_b2b_credit</i>	(Optional) rx B2B credit
<i>tx_b2b_credit</i>	(Optional) tx B2B credit
<i>tx_b2b_low_pri_cre</i>	(Optional) tx B2B low price credit
<i>InputRate_aggr_brief</i>	(Optional) Input rate in MBps
<i>TotalIpFrame_aggr_brief</i>	(Optional) Total input frames
<i>OutRate_aggr_brief</i>	(Optional) Output rate in MBps
<i>TotalOpFrame_aggr_brief</i>	(Optional) Total output frames
<i>line_aggr_brief</i>	(Optional) to print a line

Command Mode

- /exec

show interface aggregate-counters

```
show interface <ifid_aggr_ctrs> aggregate-counters [ brief ] [ __readonly__ TABLE_interface <interface_aggr>
[ <str_aggr> ] [ <if_index_aggr> ] [ <in_bps_aggr> ] [ <in_byps_aggr> ] [ <in_fps_aggr> ] [ <out_bps_aggr> ]
[ <out_byps_aggr> ] [ <out_fps_aggr> ] [ <total_in_frames_aggr> ] [ <total_in_bytes_aggr> ] [
<C2InFrames_aggr> ] [ <C2InOctets_aggr> ] [ <C3InFrames_aggr> ] [ <C3InOctets_aggr> ] [
<CfInFrames_aggr> ] [ <CfInOctets_aggr> ] [ <total_in_discards_aggr> ] [ <total_in_errors_aggr> ] [
<InvalidCrcs_aggr> ] [ <UnknownClassFrames_aggr> ] [ <FramesTooLong_aggr> ] [ <FramesTooShort_aggr> ]
[ <total_out_frames_aggr> ] [ <total_out_bytes_aggr> ] [ <C2OutFrames_aggr> ] [ <C2OutOctets_aggr> ]
[ <C3OutFrames_aggr> ] [ <C3OutOctets_aggr> ] [ <CfOutFrames_aggr> ] [ <CfOutOctets_aggr> ] [
<total_out_discards_aggr> ] [ <total_out_errors_aggr> ] [ <OlsIns_aggr> ] [ <LRRIn_aggr> ] [ <NOSIn_aggr> ]
[ <in_lip_aggr> ] [ <OlsOuts_aggr> ] [ <LRROut_aggr> ] [ <NOSOut_aggr> ] [ <out_lip_aggr> ] [
<LinkFailures_aggr> ] [ <SyncLosses_aggr> ] [ <SigLosses_aggr> ] [ <TxBBCreditTransistionToZero_aggr> ]
[ <RxBBCreditTransistionToZero_aggr> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ]
[ <tx_b2b_low_pri_cre> ] [ <InputRate_aggr_brief> ] [ <TotalIpFrame_aggr_brief> ] [ <OutRate_aggr_brief> ]
[ <TotalOpFrame_aggr_brief> ] [ <line_aggr_brief> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_aggr_ctrs</i>	Enter interface type and number in module/slot format
aggregate-counters	Show interface aggregate counters
brief	(Optional) Show interface aggregate counters in brief
__readonly__	(Optional) Read Only
<i>interface_aggr</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>str_aggr</i>	(Optional) string
<i>if_index_aggr</i>	(Optional) index
<i>in_bps_aggr</i>	(Optional) input rate in bits/s
<i>in_byps_aggr</i>	(Optional) input rate in bytes/s
<i>in_fps_aggr</i>	(Optional) input rate in frames/s
<i>out_bps_aggr</i>	(Optional) output rate in bits/s
<i>out_byps_aggr</i>	(Optional) output rate in bytes/s
<i>out_fps_aggr</i>	(Optional) output rate in frames/s
<i>total_in_frames_aggr</i>	(Optional) total input frames
<i>total_in_bytes_aggr</i>	(Optional) total input frames

<i>C2InFrames_aggr</i>	(Optional) class-2 frames
<i>C2InOctets_aggr</i>	(Optional) class-2 frames in bytes
<i>C3InFrames_aggr</i>	(Optional) class-3 frames
<i>C3InOctets_aggr</i>	(Optional) class-3 frames in bytes
<i>CfInFrames_aggr</i>	(Optional) class-f frames
<i>CfInOctets_aggr</i>	(Optional) class-f frames in bytes
<i>total_in_discards_aggr</i>	(Optional) total in discards
<i>total_in_errors_aggr</i>	(Optional) total in errors
<i>InvalidCrcs_aggr</i>	(Optional) invalid CRC
<i>UnknownClassFrames_aggr</i>	(Optional) unknown class
<i>FramesTooLong_aggr</i>	(Optional) too long
<i>FramesTooShort_aggr</i>	(Optional) too short
<i>total_out_frames_aggr</i>	(Optional) total out frames
<i>total_out_bytes_aggr</i>	(Optional) total out frames in byte
<i>C2OutFrames_aggr</i>	(Optional) class-2 out frames
<i>C2OutOctets_aggr</i>	(Optional) class-2 out frames in bytes
<i>C3OutFrames_aggr</i>	(Optional) class-3 out frames
<i>C3OutOctets_aggr</i>	(Optional) class-3 out frames in bytes
<i>CfOutFrames_aggr</i>	(Optional) class-f out frames
<i>CfOutOctets_aggr</i>	(Optional) class-f out frames in bytes
<i>total_out_discards_aggr</i>	(Optional) total out discards
<i>total_out_errors_aggr</i>	(Optional) total out errors
<i>OlsIns_aggr</i>	(Optional) input OLS
<i>LRRIn_aggr</i>	(Optional) input LRR
<i>NOSIn_aggr</i>	(Optional) input NOS
<i>in_lip_aggr</i>	(Optional) loop inits
<i>OlsOuts_aggr</i>	(Optional) output OLS
<i>LRROut_aggr</i>	(Optional) output LRR
<i>NOSOut_aggr</i>	(Optional) output NOS

<i>out_lip_aggr</i>	(Optional) loop inits
<i>LinkFailures_aggr</i>	(Optional) link failure
<i>SyncLosses_aggr</i>	(Optional) sync losses
<i>SigLosses_aggr</i>	(Optional) signal losses
<i>TxBBCreditTransistionToZero_aggr</i>	(Optional) B2B credit transitions to zero
<i>RxBBCreditTransistionToZero_aggr</i>	(Optional) B2B credit transitions to zero
<i>rx_b2b_perf_buff</i>	(Optional) rx B2B performance buff
<i>rx_b2b_credit</i>	(Optional) rx B2B credit
<i>tx_b2b_credit</i>	(Optional) tx B2B credit
<i>tx_b2b_low_pri_cre</i>	(Optional) tx B2B low price credit
<i>InputRate_aggr_brief</i>	(Optional) Input rate in MBps
<i>TotalIpFrame_aggr_brief</i>	(Optional) Total input frames
<i>OutRate_aggr_brief</i>	(Optional) Output rate in MBps
<i>TotalOpFrame_aggr_brief</i>	(Optional) Total output frames
<i>line_aggr_brief</i>	(Optional) to print a line

Command Mode

- /exec

show interface bbcredit

```
show interface <ifid_bbcrd> bbcredit [ __readonly__ TABLE_interface [ <interface_sfp> <state> [
<down_reason> ] [ <transmit_b2b> ] [ <receive_b2b> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [
<tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_bbcrd</i>	Enter interface type and number in module/slot format
bbcredit	Show BB_credit information for interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface_sfp</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) State
<i>down_reason</i>	(Optional) Reason for interface being down
<i>transmit_b2b</i>	(Optional) Transmit B2B
<i>receive_b2b</i>	(Optional) Receive B2B
<i>rx_b2b_perf_buff</i>	(Optional) RX B2B performance buffer
<i>rx_b2b_credit</i>	(Optional) RX B2B credit remaining
<i>tx_b2b_credit</i>	(Optional) TX B2B credit remaining
<i>tx_b2b_low_pri_cre</i>	(Optional) TX B2B low priority Credit

Command Mode

- /exec

show interface brief

```

show interface <ifid_brf> brief [ __readonly__ { TABLE_interface <interface> [ <desc> ] [ <svi_if_index>
] [ <svi_admin_state> ] [ <oper_state> ] [ <svi_rsn_desc> ] [ <svi_line_proto> ] [ <svi_hw> ] [ <svi_mac> ]
[ <svi_desc> ] [ <svi_ip_addr> ] [ <svi_ip_mask> ] [ <svi_mtu> ] [ <svi_bw> ] [ <svi_delay> ] [ <vlan_id>
] [ <type> ] ] [ <svi_tx_load> ] [ <svi_rx_load> ] ] [ <svi_carrier_delay_sec> ] [ <svi_carrier_delay_msec>
] [ <svi_arp_type> ] [ <svi_arp_timeout> ] ] [ <svi_time_last_cleared> ] ] [ { TABLE_secondary_vlan
<sec_vlan> <sec_vlan_type> } ] [ <eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ]
[ <eth_load_interval1_tx> ] [ <eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits>
] [ <eth_inrate1_summary_pkts> ] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [
<eth_load_interval2_rx> ] [ <eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [
<eth_outrate2_bits> ] [ <eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts>
] [ <eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes>
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes>
] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_l3avg2_inbytes> ] [ <eth_l3avg2_inpkts> ] [ <eth_l3avg2_outbytes> ] [ <eth_l3avg2_outpkts> ] [
<eth_l3avg3_inbytes> ] [ <eth_l3avg3_inpkts> ] [ <eth_l3avg3_outbytes> ] [ <eth_l3avg3_outpkts> ] [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_nobuf> ] [ <eth_inbcast> ] [ <eth_inmcast> ] [ <eth_inucast> ] [
<eth_ingiants> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [ <eth_insw_switched> ] [ <eth_runts> ] [
<eth_storm_supp> ] [ <eth_throtles> ] [ <eth_inerr> ] [ <eth_crc> ] [ <eth_ecc> ] [ <eth_frame> ] [
<eth_overrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_outbcast> ] [ <eth_outmcast> ] [ <eth_outucast>
] [ <eth_outgiants> ] [ <eth_inpause> ] [ <eth_dribble> ] [ <eth_in_ifdown_drops> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_underrun> ] [ <eth_outhw_switched> ] [
<eth_outsw_switched> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_resets> ] [ <eth_babbles> ] [ <eth_latecoll> ]
[ <eth_deferred> ] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_outpause> ] [ <eth_buffail> ] [
<eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_single_coll> ] [ <eth_multi_coll>
] [ <eth_excess_coll> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [
<eth_outcrc> ] [ <eth_symbol> ] [ <eth_out_drops> ] [ <eth_sqetest> ] [ <eth_inb64> ] [ <eth_inb65_127>
] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [ <eth_inb1024_1518> ] [
<eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outb64> ] [ <eth_outb65_127> ] [ <eth_outb128_255> ] [
<eth_outb256_511> ] [ <eth_outb512_1023> ] [ <eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [
<eth_outtrunk> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_fcoe_in_pkts> ] [ <eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [
<eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [ <eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [
<eth_nfcoe_out_octets> ] [ <eth_eee_atx_lpi_msec> ] [ <eth_eee_arcv_lpi_msec> ] [
<eth_eee_atx_lpi_transitions> ] [ <eth_eee_arcv_lpi_transitions> ] [ <eth_phy_ber_count> ] [
<eth_phy_errblks_count> ] ] [ <svi_routed_pkts_in> ] [ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out>
] [ <svi_routed_bytes_out> ] [ <svi_ucast_pkts_in> ] [ <svi_ucast_bytes_in> ] [ <svi_mcast_pkts_in> ] [
<svi_mcast_bytes_in> ] [ <svi_ucast_pkts_out> ] [ <svi_ucast_bytes_out> ] [ <svi_mcast_pkts_out> ] [
<svi_mcast_bytes_out> ] [ <svi_ipv4_ucast_pkts_in> ] [ <svi_ipv4_ucast_bytes_in> ] [
<svi_ipv4_ucast_pkts_out> ] [ <svi_ipv4_ucast_bytes_out> ] [ <svi_ipv4_mcast_pkts_in> ] [
<svi_ipv4_mcast_bytes_in> ] [ <svi_ipv4_mcast_pkts_out> ] [ <svi_ipv4_mcast_bytes_out> ] ] ]

```

```
<svi_ipv6_ucast_pkts_in> ][ <svi_ipv6_ucast_bytes_in> ][ <svi_ipv6_ucast_pkts_out> ][
<svi_ipv6_ucast_bytes_out> ][ <svi_ipv6_mcast_pkts_in> ][ <svi_ipv6_mcast_bytes_in> ][
<svi_ipv6_mcast_pkts_out> ][ <svi_ipv6_mcast_bytes_out> ][ <svi_average_input_bits> ][
<svi_average_input_packets> ][ <svi_average_output_bits> ][ <svi_average_output_packets> ][
<svi_rate_in_mins> ]][ [ <svi_reliability> ] ][ <switchport> ] } }
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_brf</i>	Enter interface type and number in module/slot format
brief	Show brief info of interface
<u>__readonly__</u>	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>desc</i>	(Optional) Interface description
<i>svi_if_index</i>	(Optional) Interface
<i>svi_admin_state</i>	(Optional)
<i>oper_state</i>	(Optional)
<i>svi_rsn_desc</i>	(Optional) Interface state reason detailed
<i>svi_line_proto</i>	(Optional)
<i>svi_hw</i>	(Optional) Hardware
<i>svi_mac</i>	(Optional) Address
<i>svi_desc</i>	(Optional) Interface Description
<i>svi_ip_addr</i>	(Optional) IP Address
<i>svi_ip_mask</i>	(Optional) IP address mask
<i>svi_mtu</i>	(Optional) MTU size in bytes
<i>svi_bw</i>	(Optional) Bandwidth in kilobits
<i>svi_delay</i>	(Optional) Throughput delay (tens of microseconds)
<i>vlan_id</i>	(Optional) Vlan
<i>type</i>	(Optional) type
<i>svi_tx_load</i>	(Optional) Tx Load
<i>svi_rx_load</i>	(Optional) Rx Load

<i>svi_carrier_delay_sec</i>	(Optional) carrier delay value in seconds
<i>svi_carrier_delay_msec</i>	(Optional) carrier delay value in milli-seconds
<i>svi_arp_type</i>	(Optional) ARP type
<i>svi_arp_timeout</i>	(Optional) ARP timeout value
<i>svi_time_last_cleared</i>	(Optional) Time last cleared
TABLE_secondary_vlan	(Optional) Secondary vlan
<i>sec_vlan</i>	(Optional) Secondary vlan ID
<i>sec_vlan_type</i>	(Optional) Secondary vlan type
<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec

<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) IPv4 L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) IPv4 L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) IPv4 L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) IPv4 L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes
<i>eth_l3out_ucastpkts</i>	(Optional) IPv4 L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) IPv4 L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) IPv4 L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) IPv4 L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes

<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_l3avg2_inbytes</i>	(Optional) Load interval 2 L3 average in switched bytes
<i>eth_l3avg2_inpkts</i>	(Optional) Load interval 2 L3 average in switched pkts
<i>eth_l3avg2_outbytes</i>	(Optional) Load interval 2 L3 average out switched bytes
<i>eth_l3avg2_outpkts</i>	(Optional) Load interval 2 L3 average out switched pkts
<i>eth_l3avg3_inbytes</i>	(Optional) Load interval 3 L3 average in switched bytes
<i>eth_l3avg3_inpkts</i>	(Optional) Load interval 3 L3 average in switched pkts
<i>eth_l3avg3_outbytes</i>	(Optional) Load interval 3 L3 average out switched bytes
<i>eth_l3avg3_outpkts</i>	(Optional) Load interval 3 L3 average out switched pkts
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_ingiants</i>	(Optional) giants
<i>eth_ipmcast</i>	(Optional) IP multicast
<i>eth_inhw_switched</i>	(Optional) Input H/W Switched
<i>eth_insw_switched</i>	(Optional) Input S/W Switched
<i>eth_runts</i>	(Optional) runts
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_throtles</i>	(Optional) throttles
<i>eth_inerr</i>	(Optional) input errors
<i>eth_crc</i>	(Optional) CRC

<i>eth_ecc</i>	(Optional) ECC
<i>eth_frame</i>	(Optional) frame
<i>eth_overrun</i>	(Optional) overrun
<i>eth_ignored</i>	(Optional) ignored
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outgiants</i>	(Optional) giants
<i>eth_inpause</i>	(Optional) pause input
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_underrun</i>	(Optional) underruns
<i>eth_outhw_switched</i>	(Optional) Out H/W Switched
<i>eth_outsw_switched</i>	(Optional) Out S/W Switched
<i>eth_outerr</i>	(Optional) output errors
<i>eth_coll</i>	(Optional) collisions
<i>eth_resets</i>	(Optional) interface resets
<i>eth_babbles</i>	(Optional) babbles
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_deferred</i>	(Optional) deferred
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_outpause</i>	(Optional) PAUSE output
<i>eth_buffail</i>	(Optional) output buffer failures

<i>eth_bufswapped</i>	(Optional) output buffers swapped out
<i>eth_arpdrops</i>	(Optional) arp drops
<i>eth_out_ifdown_drops</i>	(Optional) Output if-down drops
<i>eth_single_coll</i>	(Optional) single collisions
<i>eth_multi_coll</i>	(Optional) multi collisions
<i>eth_excess_coll</i>	(Optional) excessive collisions
<i>eth_jabbers</i>	(Optional) jabbers
<i>eth_shortframe</i>	(Optional) short frames
<i>eth_indiscard</i>	(Optional) discards
<i>eth_bad_encap</i>	(Optional) bad encapsulation
<i>eth_outcrc</i>	(Optional) Output CRC
<i>eth_symbol</i>	(Optional) symbol errors
<i>eth_out_drops</i>	(Optional) output drops
<i>eth_sqetest</i>	(Optional) SQE test
<i>eth_inb64</i>	(Optional) input pkts between 0 and 64 bytes
<i>eth_inb65_127</i>	(Optional) input pkts between 65 and 127 bytes
<i>eth_inb128_255</i>	(Optional) input pkts between 128 and 255 bytes
<i>eth_inb256_511</i>	(Optional) input pkts between 256 and 511 bytes
<i>eth_inb512_1023</i>	(Optional) input pkts between 512 and 1023 bytes
<i>eth_inb1024_1518</i>	(Optional) input pkts between 1024 and 1518 bytes
<i>eth_inb1519_1548</i>	(Optional) input pkts between 1519 and 1548 bytes
<i>eth_intrunk</i>	(Optional) input trunk pkts
<i>eth_outb64</i>	(Optional) output pkts between 0 and 64 bytes
<i>eth_outb65_127</i>	(Optional) output pkts between 65 and 127 bytes
<i>eth_outb128_255</i>	(Optional) output pkts between 128 and 255 bytes
<i>eth_outb256_511</i>	(Optional) output pkts between 256 and 511 bytes
<i>eth_outb512_1023</i>	(Optional) output pkts between 512 and 1023 bytes
<i>eth_outb1024_1518</i>	(Optional) output pkts between 1024 and 1518 bytes
<i>eth_outb1519_1548</i>	(Optional) output pkts between 1519 and 1548 bytes

<i>eth_outtrunk</i>	(Optional) output trunk pkts
<i>eth_bpdu_outlost</i>	(Optional) BPDU output lost
<i>eth_cos0_outlost</i>	(Optional) output pkts
<i>eth_cos1_outlost</i>	(Optional) output pkts
<i>eth_cos2_outlost</i>	(Optional) output pkts
<i>eth_cos3_outlost</i>	(Optional) output pkts
<i>eth_cos4_outlost</i>	(Optional) output pkts
<i>eth_cos5_outlost</i>	(Optional) output pkts
<i>eth_cos6_outlost</i>	(Optional) output pkts
<i>eth_cos7_outlost</i>	(Optional) output pkts
<i>eth_fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>eth_fcoe_in_octets</i>	(Optional) fcoe in octets
<i>eth_fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>eth_fcoe_out_octets</i>	(Optional) fcoe out octets
<i>eth_nfcoe_in_pkts</i>	(Optional) nfcoe in pkts
<i>eth_nfcoe_in_octets</i>	(Optional) nfcoe in octets
<i>eth_nfcoe_out_pkts</i>	(Optional) nfcoe out pkts
<i>eth_nfcoe_out_octets</i>	(Optional) nfcoe out octets
<i>eth_eee_atx_lpi_msec</i>	(Optional) Tx Lpi usec
<i>eth_eee_arcv_lpi_msec</i>	(Optional) Rx Lpi usec
<i>eth_eee_atx_lpi_transitions</i>	(Optional) Tx Lpi requests
<i>eth_eee_arcv_lpi_transitions</i>	(Optional) Rx Lpi indications
<i>eth_phy_ber_count</i>	(Optional) Bit error rate counter
<i>eth_phy_errblks_count</i>	(Optional) Errored blocks counter
<i>svi_reliability</i>	(Optional) Reliability
<i>switchport</i>	(Optional) Switchport enabled

Command Mode

- /exec

show interface brief

```
show interface <ifpch_brf> brief [ __readonly__ TABLE_interface <interface> [ <vlan> ] <type> <portmode>
<state> <state_rsn_desc> <speed> <ratemode> [ <proto> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifpch_brf</i>	Enter interface type and number in module/slot format
brief	Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>vlan</i>	(Optional) Vlan
<i>type</i>	(Optional) Type
<i>portmode</i>	(Optional) Port mode
<i>state</i>	(Optional) Interface state
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>speed</i>	(Optional) Speed
<i>ratemode</i>	(Optional) Interface port speed
<i>proto</i>	(Optional) Port Channel Protocol

Command Mode

- /exec

show interface brief

```
show interface brief [ controller | cli ] [ __readonly__ { TABLE_interface [ <interface> ] [ <vlan> ] [ <type>
] [ <portmode> ] [ <state> ] [ <state_rsn> ] [ <state_rsn_desc> ] [ <desc> ] [ <vrf> ] [ <ipv6_addr> ] [ <ip_addr>
] [ <speed> ] [ <mtu> ] [ <ratemode> ] [ <portchan> ] [ <proto> ] [ <interface_vfc> ] [ <vsan_brief> ] [
<admin_mode> ] [ <admin_trunk_mode> ] [ <status> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_type> ] [
<bind_mac> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <port_channel> ] [ <ip_addr1> ] [ {
TABLE_secondary_vlan <sec_vlan> <sec_vlan_type> } ] [ <svi_admin_state> ] [ <svi_rsn_desc> } ] }
```

Syntax Description

show	Show running system information
interface	Show interface status and information
brief	Show brief info of interface
controller	(Optional) Show controller configured interfaces
cli	(Optional) Show CLI configured interfaces
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>desc</i>	(Optional) Interface description
<i>vrf</i>	(Optional) Vrf membership
<i>ip_addr</i>	(Optional) IP address
<i>mtu</i>	(Optional) MTU
<i>speed</i>	(Optional) Speed
<i>vlan</i>	(Optional) Vlan
<i>type</i>	(Optional) Type
<i>portmode</i>	(Optional) Port mode
<i>ratemode</i>	(Optional) Interface port speed
<i>portchan</i>	(Optional) Port Channel Membership
<i>proto</i>	(Optional) Port Channel Protocol

<i>interface_vfc</i>	(Optional) Interface index
<i>vsan_brief</i>	(Optional) vsan brief
<i>admin_mode</i>	(Optional) admin mode
<i>admin_trunk_mode</i>	(Optional) admin trunk mode
<i>status</i>	(Optional) status
<i>fcot_info</i>	(Optional) fcot info
<i>bind_info</i>	(Optional) bind interface
<i>bind_type</i>	(Optional) bind type
<i>bind_mac</i>	(Optional) bind mac address
<i>port_rate_mode</i>	(Optional) rate mode
<i>oper_speed</i>	(Optional) speed
<i>port_channel</i>	(Optional) port channel number
<i>ip_addr1</i>	(Optional) IP address
TABLE_secondary_vlan	(Optional) Secondary vlan
<i>sec_vlan</i>	(Optional) Secondary vlan ID
<i>sec_vlan_type</i>	(Optional) Secondary vlan type
<i>svi_admin_state</i>	(Optional) svi admin state
<i>svi_rsn_desc</i>	(Optional) Interface state reason detailed

Command Mode

- /exec

show interface brief

show interface <ifloop_brf> brief [__readonly__ TABLE_interface <interface> <state> [<desc>]]

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifloop_brf</i>	Enter interface type and number in module/slot format
brief	Show brief info of interface
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>desc</i>	(Optional) Interface description

Command Mode

- /exec

show interface brief

```
show interface <iftunnel_brf> brief [ __readonly__ TABLE_interface <interface> <state> <admin-state> {
<tunnel-ipv4> | <tunnel-ipv6> } <mtu> <bandwidth> <encap-type> <keepalive-period> <keepalive-retries>
{ <src-ipv4> | <src-ipv6> } <src-intf> { <dest-ipv4> | <dest-ipv6> } <dest-hostname> <vrf_name>
<tunnel_vrf_name> <wccp_header> <ttl_val> <tunnel_pmtud_age_time> <tunnel_pmtud_min_mtu>
<tunnel_pmtud> <tunnel_pgm_mtu> <tunnel_rx_pkt_count> <tunnel_rx_byte_count> <tunnel_rx_rate>
<tunnel_tx_pkt_count> <tunnel_tx_byte_count> <tunnel_tx_rate> <tunnel_clear_counter> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>iftunnel_brf</i>	Enter interface type and number in module/slot format
brief	Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>admin-state</i>	(Optional)
<i>tunnel-ipv4</i>	(Optional) interface IPv4 address
<i>mtu</i>	(Optional) interface Maximum Transmission Unit
<i>bandwidth</i>	(Optional) interface Bandwidth in kilobits
<i>encap-type</i>	(Optional)
<i>keepalive-period</i>	(Optional) keealive period
<i>keepalive-retries</i>	(Optional) number of retries
<i>src-ipv4</i>	(Optional) tunnel source IPv4 address
<i>src-intf</i>	(Optional) tunnel source interface
<i>dest-ipv4</i>	(Optional) tunnel destination IPv4 address
<i>dest-hostname</i>	(Optional) tunnel destination hostname
<i>vrf_name</i>	(Optional) transport VRF name
<i>tunnel_vrf_name</i>	(Optional) tunnel VRF name
<i>wccp_header</i>	(Optional) wccp header

<i>tll_val</i>	(Optional) tunnel time to live value
<i>tunnel_pmtud_age_time</i>	(Optional) tunnel path MTU discovery age time
<i>tunnel_pmtud_min_mtu</i>	(Optional) tunnel path MTU discovery min mtu
<i>tunnel_pmtud</i>	(Optional) tunnel path MTU discovered
<i>tunnel_pgm_mtu</i>	(Optional) tunnel actual programmed MTU
<i>tunnel_rx_pkt_count</i>	(Optional) total number of packets received
<i>tunnel_rx_byte_count</i>	(Optional) total number of bytes received
<i>tunnel_rx_rate</i>	(Optional) packets input rate per 5 minutes
<i>tunnel_tx_pkt_count</i>	(Optional) total number of packets transmitted
<i>tunnel_tx_byte_count</i>	(Optional) total number of bytes transmitted
<i>tunnel_tx_rate</i>	(Optional) packets transmitted per 5 minutes
<i>tunnel_clear_counter</i>	(Optional) Last clearing of show interface counters

Command Mode

- /exec

show interface brief

```
show interface <ifmgmt_brf> brief [ __readonly__ TABLE_interface <interface> [ <vrf> ] <state> [
<ipv6_addr> ] [ <ip_addr> ] <mtu> <speed> [ <duplex> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifmgmt_brf</i>	Enter interface type and number in module/slot format
brief	Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>vrf</i>	(Optional) Vrf membership
<i>state</i>	(Optional) Interface state
<i>ip_addr</i>	(Optional) IP address
<i>mtu</i>	(Optional) MTU
<i>speed</i>	(Optional) Speed
<i>duplex</i>	(Optional) Duplex

Command Mode

- /exec

show interface brief

```
show interface <ifeth_brf> brief [ __readonly__ TABLE_interface <interface> [ <vlan> ] <type> <portmode>
<state> <state_rsn_desc> <speed> <ratemode> [ <portchan> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_brf</i>	Enter interface type and number in module/slot format
brief	Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>vlan</i>	(Optional) Vlan
<i>type</i>	(Optional) Type
<i>portmode</i>	(Optional) Port mode
<i>state</i>	(Optional) Interface state
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>speed</i>	(Optional) Speed
<i>ratemode</i>	(Optional) Interface port speed
<i>portchan</i>	(Optional) Port Channel Membership

Command Mode

- /exec

show interface brief

```
show interface <ifrange> brief [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn> ] [
<state_rsn_desc> ] [ <overlay_mtu> ] [ <overlay_bandwidth> ] [ <overlay_vrf> ] [ <overlay_src_addr> ] [
<overlay_dst_addr> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number
brief	Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>overlay_mtu</i>	(Optional) MTU
<i>overlay_bandwidth</i>	(Optional) Bandwidth
<i>overlay_vrf</i>	(Optional) VRF
<i>overlay_src_addr</i>	(Optional) Source address
<i>overlay_dst_addr</i>	(Optional) Destination address

Command Mode

- /exec

show interface brief

```
show interface <ifrange> brief [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn> ] [
<state_rsn_desc> ] [ <admin_state> ] [ <nve_addr> ] [ <nve_vcid> ] [ <nve_mtu> ] [ <nve_bandwidth> ] [
<nve_vrf> ] [ <nve_src_addr> ] [ <nve_dst_addr> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number
brief	Show brief info of interface
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>admin_state</i>	(Optional) admin state
<i>nve_addr</i>	(Optional) Peer address
<i>nve_vcid</i>	(Optional) VCID
<i>nve_mtu</i>	(Optional) MTU
<i>nve_bandwidth</i>	(Optional) Bandwidth
<i>nve_vrf</i>	(Optional) VRF
<i>nve_src_addr</i>	(Optional) Source address
<i>nve_dst_addr</i>	(Optional) Destination address

Command Mode

- /exec

show interface cable-diagnostics-tdr

```
show interface <ifid_tdr> cable-diagnostics-tdr [ __readonly__ TABLE interface <interface> <speed>
<distance1> <pair1_status> <distance2> <pair2_status> <distance3> <pair3_status> <distance4> <pair4_status>
]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_tdr</i>	Enter interface type and number in module/slot format
cable-diagnostics-tdr	Show interface tdr test information
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>speed</i>	(Optional) Speed
<i>distance1</i>	(Optional) Distance to fault for pair 1
<i>distance2</i>	(Optional) Distance to fault for pair 2
<i>distance3</i>	(Optional) Distance to fault for pair 3
<i>distance4</i>	(Optional) Distance to fault for pair 4
<i>pair1_status</i>	(Optional) Pair1 status
<i>pair2_status</i>	(Optional) Pair2 status
<i>pair3_status</i>	(Optional) Pair3 status
<i>pair4_status</i>	(Optional) Pair4 status

Command Mode

- /exec

show interface capabilities

```
show interface capabilities [ __readonly__ TABLE_interface <interface> <model> <type> <speed> <duplex>
<trunk_encap> [ <dce_capable> ] <channel> <bcast_supp> <flo_ctrl> <rate_mode> <port_mode> [ <fast_start>
] <qos_scheduling> <cos_rewrite> <tos_rewrite> [ <inline_power> ] <span> <udld> [ <mdix> ] [ <tdr> ]
<lnk_debounce> <lnk_debounce_time> <fex_fabric> <dot1q_tunnel> [ <pvlan_trunk_mode> ] [ <port_group>
] [ <port_group_members> ] <eee_capable> <pfc_capable> [ <speed_group_capable> ] <buffer_boost_capable>
[ <bkout_capable> ] [ <macsec_capable> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
capabilities	Show interface capabilities information
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>model</i>	(Optional) Model
<i>type</i>	(Optional) Type
<i>speed</i>	(Optional) Speed
<i>duplex</i>	(Optional) Duplex
<i>trunk_encap</i>	(Optional) Trunk encap. type
<i>dce_capable</i>	(Optional) DCE mode capable
<i>channel</i>	(Optional) Channel
<i>bcast_supp</i>	(Optional) Broadcast suppression
<i>flo_ctrl</i>	(Optional) Flowcontrol
<i>rate_mode</i>	(Optional) Rate mode
<i>port_mode</i>	(Optional) Port mode
<i>fast_start</i>	(Optional) Fast start
<i>qos_scheduling</i>	(Optional) QOS scheduling
<i>cos_rewrite</i>	(Optional) CoS rewrite
<i>tos_rewrite</i>	(Optional) ToS rewrite
<i>inline_power</i>	(Optional) Inline power

<i>span</i>	(Optional) SPAN
<i>udld</i>	(Optional) UDLD
<i>mdix</i>	(Optional) MDIX
<i>tdr</i>	(Optional) TDR
<i>lnk_debounce</i>	(Optional) Link debounce
<i>lnk_debounce_time</i>	(Optional) Link debounce time
<i>fex_fabric</i>	(Optional) FEX Fabric
<i>dot1q_tunnel</i>	(Optional) dot1q-tunnel
<i>pvlan_trunk_mode</i>	(Optional) Private-vlan trunk mode
<i>port_group</i>	(Optional) Port Group
<i>port_group_members</i>	(Optional) Port Group Members
<i>eee_capable</i>	(Optional) EEE (efficient-eth)
<i>pfc_capable</i>	(Optional) PFC Capable:
<i>bkout_capable</i>	(Optional) Breakout Capable:
<i>buffer_boost_capable</i>	(Optional) Buffer Boost Capable:
<i>speed_group_capable</i>	(Optional) Speed group capable
<i>macsec_capable</i>	(Optional) MACSEC capable

Command Mode

- /exec

show interface capabilities

```
show interface <ifid_cap> capabilities [ __readonly__ { TABLE_interface_capabilities_if <interface> [
<min_speed> ][ <max_speed> ][ <FC-PH_version_high> ][ <FC-PH_version_low> ][ <recieve_data_max>
][ <recieve_data_min> ][ <transmit_data_max> ][ <transmit_data_min> ][ <class_service> ][ <class_2>
][ <class_3> ][ <hold_time_max> ][ <hold_time_min> ][ <BB_state_change> ][ <max_BB_state_change>
][ <rate_mode_change> ][ <rate_mode_cap> ][ <recieve_BB_credit> ][ <FX_recieve_BB_credit> ][
<ISL_recieve_BB_credit> ][ <shared_performance_buf_mod_supp> ][
<dedicated_performance_buf_mod_supp> ][ <fx_mode_perf_buf> ][ <isl_mode_perf_buf> ][ <out_of_order>
][ <beacon_mode_config> ][ <extended_B2B> ][ <on_demand_port> } ] }
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_cap</i>	Enter interface type and number in module/slot format
capabilities	Show interface capabilities information
<i>__readonly__</i>	(Optional)
TABLE_interface_capabilities_if	(Optional) interface capabilities if table
<i>interface</i>	(Optional) fc interface
<i>min_speed</i>	(Optional) Min Speed
<i>max_speed</i>	(Optional) Max Speed
<i>FC-PH_version_high</i>	(Optional) FC-PH version high
<i>FC-PH_version_low</i>	(Optional) FC-PH version low
<i>recieve_data_max</i>	(Optional) Receive data field size max
<i>recieve_data_min</i>	(Optional) Receive data field size min
<i>transmit_data_max</i>	(Optional) Transmit data field size max
<i>transmit_data_min</i>	(Optional) Transmit data field size min
<i>class_service</i>	(Optional) Classes of Service supported
<i>class_2</i>	(Optional) Class 2 sequential delivery
<i>class_3</i>	(Optional) Class 3 sequential delivery
<i>hold_time_max</i>	(Optional) Hold time max
<i>hold_time_min</i>	(Optional) Hold time min
<i>BB_state_change</i>	(Optional) BB state change notification

<i>max_BB_state_change</i>	(Optional) Maximum BB state change notifications
<i>rate_mode_change</i>	(Optional) Rate Mode change
<i>rate_mode_cap</i>	(Optional) Rate Mode Capabilities
<i>recieve_BB_credit</i>	(Optional) Receive BB Credit modification supported
<i>FX_recieve_BB_credit</i>	(Optional) FX mode Receive BB Credit (min/max/default)
<i>ISL_recieve_BB_credit</i>	(Optional) ISL mode Receive BB Credit (min/max/default)
<i>shared_performance_buf_mod_supp</i>	(Optional) Performance buffer modification supported shared
<i>dedicated_performance_buf_mod_supp</i>	(Optional) Performance buffer modification supported dedicated
<i>fx_mode_perf_buf</i>	(Optional) FX mode performance buffers
<i>isl_mode_perf_buf</i>	(Optional) ISL mode performance buffers
<i>out_of_order</i>	(Optional) Out of Service capable
<i>beacon_mode_config</i>	(Optional) Beacon mode configurable
<i>extended_B2B</i>	(Optional) Extended B2B credit capable
<i>on_demand_port</i>	(Optional) On demand port activation license supported

Command Mode

- /exec

show interface capabilities

```
show interface <ifid_eth_cap> capabilities [ __readonly__ TABLE_interface <interface> <model> <type>
<speed> <duplex> <trunk_encap> [ <dce_capable> ] <channel> <bcast_supp> <flo_ctrl> <rate_mode>
<port_mode> [ <fast_start> ] <qos_scheduling> <cos_rewrite> <tos_rewrite> [ <inline_power> ] <span>
<udld> [ <mdix> ] [ <tdr> ] <lnk_debounce> <lnk_debounce_time> <fex_fabric> <dot1q_tunnel> [
<pvlan_trunk_mode> ] [ <port_group> ] [ <port_group_members> ] <eee_capable> <pfc_capable> [
<speed_group_capable> ] <buffer_boost_capable> [ <bkout_capable> ] [ <macsec_capable> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_eth_cap</i>	Enter interface type and number in module/slot format
capabilities	Show interface capabilities information
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>model</i>	(Optional) Model
<i>type</i>	(Optional) Type
<i>speed</i>	(Optional) Speed
<i>duplex</i>	(Optional) Duplex
<i>trunk_encap</i>	(Optional) Trunk encap. type
<i>dce_capable</i>	(Optional) DCE mode capable
<i>channel</i>	(Optional) Channel
<i>bcast_supp</i>	(Optional) Broadcast suppression
<i>flo_ctrl</i>	(Optional) Flowcontrol
<i>rate_mode</i>	(Optional) Rate mode
<i>port_mode</i>	(Optional) Port mode
<i>fast_start</i>	(Optional) Fast start
<i>qos_scheduling</i>	(Optional) QOS scheduling
<i>cos_rewrite</i>	(Optional) CoS rewrite
<i>tos_rewrite</i>	(Optional) ToS rewrite

<i>inline_power</i>	(Optional) Inline power
<i>span</i>	(Optional) SPAN
<i>udld</i>	(Optional) UDLD
<i>mdix</i>	(Optional) MDIX
<i>tdr</i>	(Optional) TDR
<i>lnk_debounce</i>	(Optional) Link debounce
<i>lnk_debounce_time</i>	(Optional) Link debounce time
<i>fex_fabric</i>	(Optional) FEX Fabric
<i>dot1q_tunnel</i>	(Optional) dot1q-tunnel
<i>pvlan_trunk_mode</i>	(Optional) Private-vlan trunk mode
<i>port_group</i>	(Optional) Port Group
<i>port_group_members</i>	(Optional) Port Group Members
<i>eee_capable</i>	(Optional) EEE (efficient-eth)
<i>pfc_capable</i>	(Optional) PFC Capable:
<i>bkout_capable</i>	(Optional) Breakout Capable:
<i>buffer_boost_capable</i>	(Optional) Buffer Boost Capable:
<i>speed_group_capable</i>	(Optional) Speed group capable
<i>macsec_capable</i>	(Optional) MACSEC capable

Command Mode

- /exec

show_interface

show_interface <single>

Syntax Description

show_interface	Port_mgr hidden command
<i>single</i>	interface type and number in module/slot format

Command Mode

- /exec

show interface counters

```
show interface <ifid_ctr> counters [ brief ] [ __readonly__ ] [ { TABLE_counters <sfp> { TABLE_input_rate
<bit_per_sec> <bytes_per_sec> <frames_per_sec> } { TABLE_output_rate <bit_per_sec> <bytes_per_sec>
<frames_per_sec> } { TABLE_input <frames> <bytes> [ <class_2_frames> ] [ <class_2_bytes> ] [
<class_3_frames> ] [ <class_3_bytes> ] [ <class_f_frames> ] [ <class_f_bytes> ] [ <class_2_3_frames> ]
<discards> <errors> <crc_fcs> <unknown_class> <too_long> <too_short> } { TABLE_output <frames>
<bytes> [ <class_2_frames> ] [ <class_2_bytes> ] [ <class_3_frames> ] [ <class_3_bytes> ] [ <class_f_frames>
] [ <class_f_bytes> ] [ <class_2_3_frames> ] [ <discards> ] [ <errors> ] [ <crc_fcs> ] } [ <timeout_discards>
] [ <credit_loss> ] [ <input_ols> ] [ <input_lrr> ] [ <input_nos> ] [ <input_loop_inits> ] [ <output_ols> ] [
<output_lrr> ] [ <output_nos> ] [ <output_loop_inits> ] [ <link_faliures> ] [ <sync_loss> ] [ <signal_loss> ]
[ <b2b_transmit> ] [ <b2b_receive> ] [ <txwait> ] [ <tx_credit_unavbl> ] [ <b2b_receive_remain> ] [
<b2b_transmit_remain> ] [ <low_priority_b2b_remain> ] [ <off_seq_err_rcvd> ] [ <broadcast_frames> ] [
<errors> ] [ <queue_drops> ] [ <if_down_drops> ] [ <red_drops> ] [ <bad_ether_type_drops> ] [
<bad_protocol_drops> ] [ <arp_drops> ] [ <reass_frames> ] [ <timestamp_error> ] [ <rx_b2b_perf_buff> ]
[ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] [ <time_last_cleared> } } ] [ {
TABLE_counters_brief <sfp> <fc_input_rate> <fc_frames_in> <fc_output_rate> <fc_frames_out> } ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_ctr</i>	Enter interface type and number in module/slot format
counters	Show interface counters
brief	(Optional) Show interface counters in brief
<u>__readonly__</u>	(Optional) Readonly
TABLE_counters	(Optional) Table counters
<i>sfp</i>	(Optional) SFP
TABLE_input_rate	(Optional) Input rate
<i>bit_per_sec</i>	(Optional) Input rate bits per second
<i>bytes_per_sec</i>	(Optional) Input rate bytes per second
<i>frames_per_sec</i>	(Optional) Input rate frames per second
TABLE_output_rate	(Optional) Output rate
<i>bit_per_sec</i>	(Optional) Output rate bits per second
<i>bytes_per_sec</i>	(Optional) Output rate bytes per second
<i>frames_per_sec</i>	(Optional) Output rate frames per second
TABLE_input	(Optional) Input values

<i>frames</i>	(Optional) Frames
<i>bytes</i>	(Optional) Bytes
<i>class_2_frames</i>	(Optional) Class 2 frames
<i>class_2_bytes</i>	(Optional) Class 2 bytes
<i>class_3_frames</i>	(Optional) Class 3 frames
<i>class_3_bytes</i>	(Optional) Class 3 bytes
<i>class_f_frames</i>	(Optional) Class f frames
<i>class_f_bytes</i>	(Optional) Class f bytes
<i>class_2_3_frames</i>	(Optional) Class 2/3 Frames
<i>discards</i>	(Optional) Discards
<i>errors</i>	(Optional) Errors
<i>crc_fcs</i>	(Optional) CRC/FCS
<i>unknown_class</i>	(Optional) Unknown Class
<i>too_long</i>	(Optional) Frames too long
<i>too_short</i>	(Optional) Frames too short
TABLE_output	(Optional) Output Values
<i>frames</i>	(Optional) Frames
<i>bytes</i>	(Optional) Bytes
<i>class_2_frames</i>	(Optional) Class 2 frames
<i>class_2_bytes</i>	(Optional) Class 2 bytes
<i>class_3_frames</i>	(Optional) Class 3 frames
<i>class_3_bytes</i>	(Optional) Class 3 bytes
<i>class_f_frames</i>	(Optional) Class f frames
<i>class_f_bytes</i>	(Optional) Class f bytes
<i>class_2_3_frames</i>	(Optional) Class 2/3 frames
<i>discards</i>	(Optional) Discards
<i>errors</i>	(Optional) Errors
<i>crc_fcs</i>	(Optional) CRC/FCS
<i>timeout_discards</i>	(Optional) Timeout Discards

<i>credit_loss</i>	(Optional) Credit Loss
<i>input_ols</i>	(Optional) input ols
<i>input_lrr</i>	(Optional) input LRR
<i>input_nos</i>	(Optional) input NOS
<i>input_loop_inits</i>	(Optional) input loop inits
<i>output_ols</i>	(Optional) output OLS
<i>output_lrr</i>	(Optional) output LRR
<i>output_nos</i>	(Optional) output NOS
<i>output_loop_inits</i>	(Optional) output loop inits
<i>link_faliures</i>	(Optional) link faliures
<i>sync_loss</i>	(Optional) Sync loss
<i>signal_loss</i>	(Optional) Signal loss
<i>b2b_transmit</i>	(Optional) B2B transmit
<i>b2b_receive</i>	(Optional) B2B receive
<i>txwait</i>	(Optional) TxWait
<i>tx_credit_unavbl</i>	(Optional) Tx credit unavliable
<i>b2b_receive_remain</i>	(Optional) B2B receive remain
<i>b2b_transmit_remain</i>	(Optional) B2B transmit remain
<i>low_priority_b2b_remain</i>	(Optional) Low priority B2B credit remaining
<i>time_last_cleared</i>	(Optional) Last time cleared
<i>broadcast_frames</i>	(Optional) Broadcast frames
<i>errors</i>	(Optional) Errors
<i>queue_drops</i>	(Optional) Queue drops
<i>if_down_drops</i>	(Optional) If down drops
<i>red_drops</i>	(Optional) Red drops
<i>bad_ether_type_drops</i>	(Optional) Bad ether type drops
<i>bad_protocol_drops</i>	(Optional) Bad Protocol Drops
<i>arp_drops</i>	(Optional) Arp Drops
<i>timestamp_error</i>	(Optional) Timestamp Error

<i>reass_frames</i>	(Optional) Reass Frames
<i>rx_b2b_perf_buff</i>	(Optional) RX B2B performance buffer
<i>rx_b2b_credit</i>	(Optional) RX B2B credit remaining
<i>tx_b2b_credit</i>	(Optional) TX B2B credit remaining
<i>tx_b2b_low_pri_cre</i>	(Optional) TX B2B low priority Credit
<i>off_seq_err_rcvd</i>	(Optional) Offset Sequence Error Received
TABLE_counters_brief	(Optional) Table counters brief
<i>sfp</i>	(Optional) FC id
<i>fc_input_rate</i>	(Optional) Input rate
<i>fc_frames_in</i>	(Optional) Frames in
<i>fc_output_rate</i>	(Optional) Output rate
<i>fc_frames_out</i>	(Optional) Frames out

Command Mode

- /exec

show interface counters

```
show interface <ifid_ctr> counters [ snmp ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] } { TABLE_tx_counters
<interface_tx> [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast>
] } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_ctr</i>	Enter interface type and number in module/slot format
counters	Show interface counters
snmp	(Optional) Show SNMP MIB values
<u>__readonly__</u>	(Optional) Read Only
<i>interface_rx</i>	(Optional) Interface index rx
<i>interface_tx</i>	(Optional) Interface index tx
TABLE_rx_counters	(Optional) show Rx counters
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
TABLE_tx_counters	(Optional) show Tx counters
<i>eth_outpkts</i>	(Optional) Packets output
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts

Command Mode

- /exec

show interface counters

```
show interface counters [ module <module> ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inpkts> ] [ <fc_inframes> ] [ <eth_inbytes> ] [ <fc_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [
<eth_inbcast> ] [ <eth_l3in_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts>
] } { TABLE_tx_counters <interface_tx> [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [
<eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts>
] [ <eth_l3out_bcastpkts> ] } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
<i>__readonly__</i>	(Optional) Read Only
<i>interface_rx</i>	(Optional) Interface index rx
<i>interface_tx</i>	(Optional) Interface index tx
TABLE_rx_counters	(Optional) show Rx counters
TABLE_tx_counters	(Optional) show Tx counters
<i>eth_inpkts</i>	(Optional) Packets input
<i>fc_inframes</i>	(Optional) Frames input fc
<i>eth_inbytes</i>	(Optional) Bytes input
<i>fc_inbytes</i>	(Optional) Bytes input fc
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_outpkts</i>	(Optional) Packets output
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts

<i>eth_l3in_bytes</i>	(Optional) L3 Rx bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 Rx Unicast pkts
<i>eth_l3in_mcastpkts</i>	(Optional) L3 Rx Multicast pkts
<i>eth_l3in_bcastpkts</i>	(Optional) L3 Rx Broadcast pkts
<i>eth_l3out_bytes</i>	(Optional) L3 Tx bytes
<i>eth_l3out_ucastpkts</i>	(Optional) L3 Tx Unicast pkts
<i>eth_l3out_mcastpkts</i>	(Optional) L3 Tx Multicast pkts
<i>eth_l3out_bcastpkts</i>	(Optional) L3 Tx Broadcast pkts

Command Mode

- /exec

show interface counters

```
show interface counters [ non-zero ] [ __readonly__ { TABLE_rx_counters <interface_rx> [ <eth_inpkts> ]
[ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] } } { TABLE_tx_counters
<interface_tx> [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast>
] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] } }
```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
non-zero	(Optional) To display only the non-zero counter values
__readonly__	(Optional) Read Only
<i>interface_rx</i>	(Optional) Interface index rx
<i>interface_tx</i>	(Optional) Interface index tx
TABLE_rx_counters	(Optional) show Rx counters
TABLE_tx_counters	(Optional) show Tx counters
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_outpkts</i>	(Optional) Packets output
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_l3in_bytes</i>	(Optional) L3 Rx bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 Rx Unicast pkts
<i>eth_l3in_mcastpkts</i>	(Optional) L3 Rx Multicast pkts
<i>eth_l3in_bcastpkts</i>	(Optional) L3 Rx Broadcast pkts

<i>eth_l3out_bytes</i>	(Optional) L3 Tx bytes
<i>eth_l3out_ucastpkts</i>	(Optional) L3 Tx Unicast pkts
<i>eth_l3out_mcastpkts</i>	(Optional) L3 Tx Multicast pkts
<i>eth_l3out_bcastpkts</i>	(Optional) L3 Tx Broadcast pkts

Command Mode

- /exec

show interface counters

```
show interface <ifeth_ctr> counters [ snmp ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] } } { TABLE_tx_counters
<interface_tx> [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes>
] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] } }
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr</i>	Enter interface type and number in module/slot format
counters	Show interface counters
snmp	(Optional) Show SNMP MIB values
<u>__readonly__</u>	(Optional) Read Only
TABLE_rx_counters	(Optional) show Rx counters
<i>interface_rx</i>	(Optional) Interface index rx
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_inucast</i>	(Optional) Unicasts input
<i>eth_inmcast</i>	(Optional) Multicasts input
<i>eth_inbcast</i>	(Optional) Broadcasts input
<i>eth_l3in_bytes</i>	(Optional) L3 Rx bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 Rx Unicast pkts
<i>eth_l3in_mcastpkts</i>	(Optional) L3 Rx Multicast pkts
<i>eth_l3in_bcastpkts</i>	(Optional) L3 Rx Broadcast pkts
TABLE_tx_counters	(Optional) show Tx counters
<i>interface_tx</i>	(Optional) Interface index tx
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts output
<i>eth_outmcast</i>	(Optional) Multicasts output
<i>eth_outbcast</i>	(Optional) Broadcasts output
<i>eth_l3out_bytes</i>	(Optional) L3 Tx bytes

<i>eth_l3out_ucastpkts</i>	(Optional) L3 Tx Unicast pkts
<i>eth_l3out_mcastpkts</i>	(Optional) L3 Tx Multicast pkts
<i>eth_l3out_bcastpkts</i>	(Optional) L3 Tx Broadcast pkts

Command Mode

- /exec

show interface counters

```
show interface <ifeth_ctr> counters [ __readonly__ { TABLE_rx_counters <interface_rx> [ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] } { TABLE_tx_counters <interface_tx> [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr</i>	Enter interface type and number in module/slot format
counters	Show interface counters
<i>__readonly__</i>	(Optional) Read Only
TABLE_rx_counters	(Optional) show Rx counters
<i>interface_rx</i>	(Optional) Interface index rx
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_inucast</i>	(Optional) Unicasts input
<i>eth_inmcast</i>	(Optional) Multicasts input
<i>eth_inbcast</i>	(Optional) Broadcasts input
<i>eth_l3in_bytes</i>	(Optional) L3 Rx bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 Rx Unicast pkts
<i>eth_l3in_mcastpkts</i>	(Optional) L3 Rx Multicast pkts
<i>eth_l3in_bcastpkts</i>	(Optional) L3 Rx Broadcast pkts
TABLE_tx_counters	(Optional) show Tx counters
<i>interface_tx</i>	(Optional) Interface index tx
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts output
<i>eth_outmcast</i>	(Optional) Multicasts output
<i>eth_outbcast</i>	(Optional) Broadcasts output
<i>eth_l3out_bytes</i>	(Optional) L3 Tx bytes
<i>eth_l3out_ucastpkts</i>	(Optional) L3 Tx Unicast pkts

<i>eth_l3out_mcastpkts</i>	(Optional) L3 Tx Multicast pkts
<i>eth_l3out_bcastpkts</i>	(Optional) L3 Tx Broadcast pkts

Command Mode

- /exec

show interface counters

```
show interface <ifrange> counters [ __readonly__ TABLE_interface <interface> [ <overlay_load_interval>
] [ <overlay_rx_ucastpkts> ] [ <overlay_rx_ucastbytes> ] [ <overlay_rx_mcastpkts> ] [
<overlay_rx_mcastbytes> ] [ <overlay_rx_pkts> ] [ <overlay_rx_bytes> ] [ <overlay_rx_bcastpkts> ] [
<overlay_rx_bcastbytes> ] [ <overlay_rx_bitrate> ] [ <overlay_rx_pktrate> ] [ <overlay_tx_ucastpkts> ] [
<overlay_tx_ucastbytes> ] [ <overlay_tx_mcastpkts> ] [ <overlay_tx_mcastbytes> ] [ <overlay_tx_bcastpkts>
] [ <overlay_tx_bcastbytes> ] [ <overlay_tx_pkts> ] [ <overlay_tx_bytes> ] [ <overlay_tx_bitrate> ] [
<overlay_tx_pktrate> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number
counters	Show interface counters
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>overlay_load_interval</i>	(Optional) Load interval
<i>overlay_rx_ucastpkts</i>	(Optional) Received ucast pkts
<i>overlay_rx_ucastbytes</i>	(Optional) Received ucast bytes
<i>overlay_rx_mcastpkts</i>	(Optional) Received mcast pkts
<i>overlay_rx_mcastbytes</i>	(Optional) Received mcast bytes
<i>overlay_rx_bcastpkts</i>	(Optional) Received bcast pkts
<i>overlay_rx_bcastbytes</i>	(Optional) Received bcast bytes
<i>overlay_rx_pkts</i>	(Optional) Total received pkts
<i>overlay_rx_bytes</i>	(Optional) Total received bytes
<i>overlay_rx_bitrate</i>	(Optional) Receive bit rate
<i>overlay_rx_pktrate</i>	(Optional) Receive pkt rate
<i>overlay_tx_ucastpkts</i>	(Optional) Trasnmitted ucast pkts
<i>overlay_tx_ucastbytes</i>	(Optional) Trasnmitted ucast bytes
<i>overlay_tx_mcastpkts</i>	(Optional) Trasnmitted mcast pkts
<i>overlay_tx_mcastbytes</i>	(Optional) Trasnmitted mcast bytes

<i>overlay_tx_bcastpkts</i>	(Optional) Trasnmitted beast pkts
<i>overlay_tx_bcastbytes</i>	(Optional) Trasnmitted beast bytes
<i>overlay_tx_pkts</i>	(Optional) Total transmitted pkts
<i>overlay_tx_bytes</i>	(Optional) Total transmitted bytes
<i>overlay_tx_bitrate</i>	(Optional) Transmit bit rate
<i>overlay_tx_pktrate</i>	(Optional) Transmit pkt rate

Command Mode

- /exec

show interface counters

```
show interface <ifrange> counters [ __readonly__ { TABLE_nve_counters <interface> [ <ucast_inbytes> ]
[ <ucast_inpkts> ] [ <ucast_outbytes> ] [ <ucast_outpkts> ] [ <mcast_inbytes> ] [ <mcast_inpkts> ] [
<mcast_outbytes> ] [ <mcast_outpkts> ] } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number
counters	Show interface counters
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_nve_counters	(Optional) show interface
<i>ucast_inbytes</i>	(Optional) ucast bytes input
<i>ucast_inpkts</i>	(Optional) ucast packets input
<i>ucast_outbytes</i>	(Optional) ucast bytes output
<i>ucast_outpkts</i>	(Optional) ucast packets output
<i>mcast_inbytes</i>	(Optional) mcast bytes input
<i>mcast_inpkts</i>	(Optional) mcast packets input
<i>mcast_outbytes</i>	(Optional) mcast bytes output
<i>mcast_outpkts</i>	(Optional) mcast packets output

Command Mode

- /exec

show interface counters brief

```
show interface <ifeth_ctr_brf> counters brief [ <counter_val> ] [ __readonly__ TABLE_interface <interface>
<eth_inrate1> <eth_inframes1> <eth_outrate1> <eth_outframes1> <eth_load_intv1> <eth_inrate2>
<eth_inframes2> <eth_outrate2> <eth_outframes2> <eth_load_intv2> [ <eth_inrate3> <eth_inframes3>
<eth_outrate3> <eth_outframes3> <eth_load_intv3> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr_brf</i>	Enter interface type and number in module/slot format
counters	Show interface counters
brief	Show interface counters in brief
<i>counter_val</i>	(Optional) Specify a single load interval id to show the rates
<i>__readonly__</i>	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>eth_inrate1</i>	(Optional) interval 1 input rate in mbps
<i>eth_inframes1</i>	(Optional) interval 1 input rate in frames (pkts)
<i>eth_outrate1</i>	(Optional) interval 1 output rate in mbps
<i>eth_outframes1</i>	(Optional) interval 1 output rate in output frames (pkts)
<i>eth_load_intv1</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate2</i>	(Optional) interval 2 input rate in mbps
<i>eth_inframes2</i>	(Optional) interval 2 input rate in frames (pkts)
<i>eth_outrate2</i>	(Optional) interval 2 output rate in mbps
<i>eth_outframes2</i>	(Optional) interval 2 output rate in output frames (pkts)
<i>eth_load_intv2</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate3</i>	(Optional) interval 3 input rate in mbps
<i>eth_inframes3</i>	(Optional) interval 3 input rate in frames (pkts)
<i>eth_outrate3</i>	(Optional) interval 3 output rate in mbps
<i>eth_outframes3</i>	(Optional) interval 3 output rate in output frames (pkts)

<i>eth_load_intv3</i>	(Optional) interval 3 timer value in sec
-----------------------	------------------------------------------

Command Mode

- /exec

show interface counters brief

```
show interface counters brief [ <counter_val> ] [ __readonly__ TABLE_interface <interface> [ <eth_inrate1> ] [ <eth_inframes1> ] [ <eth_outrate1> ] [ <eth_outframes1> ] [ <eth_load_intv1> ] [ <eth_inrate2> ] [ <eth_inframes2> ] [ <eth_outrate2> ] [ <eth_outframes2> ] [ <eth_load_intv2> ] [ <eth_inrate3> ] [ <eth_inframes3> ] [ <eth_outrate3> ] [ <eth_outframes3> ] [ <eth_load_intv3> ] [ <fc_input_rate> ] [ <fc_frames_in> ] [ <fc_output_rate> ] [ <fc_frames_out> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
brief	Show interface counters in brief
<i>counter_val</i>	(Optional) Specify a single load interval id to show the rates
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>eth_inrate1</i>	(Optional) interval 1 input rate in mbps
<i>eth_inframes1</i>	(Optional) interval 1 input rate in frames (pkts)
<i>eth_outrate1</i>	(Optional) interval 1 output rate in mbps
<i>eth_outframes1</i>	(Optional) interval 1 output rate in output frames (pkts)
<i>eth_load_intv1</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate2</i>	(Optional) interval 2 input rate in mbps
<i>eth_inframes2</i>	(Optional) interval 2 input rate in frames (pkts)
<i>eth_outrate2</i>	(Optional) interval 2 output rate in mbps
<i>eth_outframes2</i>	(Optional) interval 2 output rate in output frames (pkts)
<i>eth_load_intv2</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate3</i>	(Optional) interval 3 input rate in mbps
<i>eth_inframes3</i>	(Optional) interval 3 input rate in frames (pkts)
<i>eth_outrate3</i>	(Optional) interval 3 output rate in mbps
<i>eth_outframes3</i>	(Optional) interval 3 output rate in output frames (pkts)
<i>eth_load_intv3</i>	(Optional) interval 3 timer value in sec

<i>fc_input_rate</i>	(Optional) Input rate
<i>fc_frames_in</i>	(Optional) Frames in
<i>fc_output_rate</i>	(Optional) Output rate
<i>fc_frames_out</i>	(Optional) Frames out

Command Mode

- /exec

show interface counters detailed

```
show interface <ifmgmt_ctr_dtl> counters detailed [ __readonly__ TABLE_interface <interface> [
<vdc_lvl_in_pkts> ] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_ucast> ] [ <vdc_lvl_in_mcast> ] [
<vdc_lvl_in_bcast> ] [ <vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [ <vdc_lvl_in_avg_pkts> ] [
<vdc_lvl_in_avg_bytes> ] [ <vdc_lvl_out_pkts> ] [ <vdc_lvl_out_bytes> ] [ <vdc_lvl_out_ucast> ] [
<vdc_lvl_out_mcast> ] [ <vdc_lvl_out_bcast> ] [ <vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] [
<vdc_lvl_out_avg_pkts> ] [ <vdc_lvl_out_avg_bytes> ] [ <mgmt_in_pkts> ] [ <mgmt_in_bytes> ] [
<mgmt_in_mcast> ] [ <mgmt_in_compressed> ] [ <mgmt_in_errors> ] [ <mgmt_in_frame> ] [
<mgmt_in_overrun> ] [ <mgmt_in_fifo> ] [ <mgmt_out_pkts> ] [ <mgmt_out_bytes> ] [
<mgmt_out_underruns> ] [ <mgmt_out_errors> ] [ <mgmt_out_collisions> ] [ <mgmt_out_fifo> ] [
<mgmt_out_carrier> ] [ <mgmt_align_err> ] [ <mgmt_fcs_err> ] [ <mgmt_xmit_err> ] [ <mgmt_rcv_err> ]
[ <mgmt_undersize> ] [ <mgmt_outdisc> ] [ <mgmt_single_col> ] [ <mgmt_multi_col> ] [ <mgmt_late_col>
] [ <mgmt_excess_col> ] [ <mgmt_carri_sen> ] [ <mgmt_runs> ] [ <mgmt_giants> ] [ <mgmt_sqetest_err>
] [ <mgmt_deferred_tx> ] [ <mgmt_inmactx_err> ] [ <mgmt_inmacrx_err> ] [ <mgmt_symbol_err> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifmgmt_ctr_dtl</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
<u>__readonly__</u>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>vdc_lvl_in_pkts</i>	(Optional) VDC level input packets
<i>vdc_lvl_in_bytes</i>	(Optional) VDC level input bytes
<i>vdc_lvl_in_ucast</i>	(Optional) VDC level input unicast packets
<i>vdc_lvl_in_mcast</i>	(Optional) VDC level input multicast packets
<i>vdc_lvl_in_bcast</i>	(Optional) VDC level input broadcast packets
<i>vdc_lvl_in_bps</i>	(Optional) VDC level input bytes per second
<i>vdc_lvl_in_pps</i>	(Optional) VDC level input packets per second
<i>vdc_lvl_in_avg_pkts</i>	(Optional) VDC level average input packets
<i>vdc_lvl_in_avg_bytes</i>	(Optional) VDC level average input bytes
<i>vdc_lvl_out_pkts</i>	(Optional) VDC level output packets

<i>vdc_lvl_out_bytes</i>	(Optional) VDC level output bytes
<i>vdc_lvl_out_ucast</i>	(Optional) VDC level output unicast packets
<i>vdc_lvl_out_mcast</i>	(Optional) VDC level output multicast packets
<i>vdc_lvl_out_bcast</i>	(Optional) VDC level output broadcast packets
<i>vdc_lvl_out_bps</i>	(Optional) VDC level output bytes per second
<i>vdc_lvl_out_pps</i>	(Optional) VDC level output packets per second
<i>vdc_lvl_out_avg_pkts</i>	(Optional) VDC level average output packets
<i>vdc_lvl_out_avg_bytes</i>	(Optional) VDC level average output bytes
<i>mgmt_in_pkts</i>	(Optional) Input packets
<i>mgmt_in_bytes</i>	(Optional) Input bytes
<i>mgmt_in_mcast</i>	(Optional) Input multicast frames
<i>mgmt_in_compressed</i>	(Optional) Input compressed
<i>mgmt_in_errors</i>	(Optional) Input errors
<i>mgmt_in_frame</i>	(Optional) Input frame errors
<i>mgmt_in_overrun</i>	(Optional) Input overrun
<i>mgmt_in_fifo</i>	(Optional) Input fifo
<i>mgmt_out_pkts</i>	(Optional) Output packets
<i>mgmt_out_bytes</i>	(Optional) Output bytes
<i>mgmt_out_underruns</i>	(Optional) Output overruns
<i>mgmt_out_errors</i>	(Optional) Output errors
<i>mgmt_out_collisions</i>	(Optional) Output collisions
<i>mgmt_out_fifo</i>	(Optional) Output fifo
<i>mgmt_out_carrier</i>	(Optional) Output carrier errors
<i>mgmt_align_err</i>	(Optional) Align error
<i>mgmt_fcs_err</i>	(Optional) FCS error
<i>mgmt_xmit_err</i>	(Optional) Transmit error
<i>mgmt_rcv_err</i>	(Optional) Receive error
<i>mgmt_undersize</i>	(Optional) Undersize
<i>mgmt_outdisc</i>	(Optional) Out discard

<i>mgmt_single_col</i>	(Optional) Single collision
<i>mgmt_multi_col</i>	(Optional) Multiple collision
<i>mgmt_late_col</i>	(Optional) Late collision
<i>mgmt_excess_col</i>	(Optional) Excess collision
<i>mgmt_carri_sen</i>	(Optional) Carrier sense
<i>mgmt_runts</i>	(Optional) Runts
<i>mgmt_giants</i>	(Optional) Giants
<i>mgmt_sqetest_err</i>	(Optional) SQETest error
<i>mgmt_deferred_tx</i>	(Optional) Deferred tx
<i>mgmt_inmactx_err</i>	(Optional) In MAC tx
<i>mgmt_inmacrx_err</i>	(Optional) In MAC rx
<i>mgmt_symbol_err</i>	(Optional) Symbol error

Command Mode

- /exec

show interface counters detailed

```

show interface counters detailed [ snmp ] [ __readonly__ TABLE_interface <interface> [ <vdc_lvl_in_pkts>
] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_ucast> ] [ <vdc_lvl_in_mcast> ] [ <vdc_lvl_in_bcast> ] [
<vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [ <vdc_lvl_in_avg_pkts> ] [ <vdc_lvl_in_avg_bytes> ] [
<vdc_lvl_out_pkts> ] [ <vdc_lvl_out_bytes> ] [ <vdc_lvl_out_ucast> ] [ <vdc_lvl_out_mcast> ] [
<vdc_lvl_out_bcast> ] [ <vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] [ <vdc_lvl_out_avg_pkts> ] [
<vdc_lvl_out_avg_bytes> ] [ <mgmt_in_pkts> ] [ <mgmt_in_bytes> ] [ <mgmt_in_mcast> ] [
<mgmt_in_compressed> ] [ <mgmt_in_errors> ] [ <mgmt_in_frame> ] [ <mgmt_in_overrun> ] [
<mgmt_in_fifo> ] [ <mgmt_out_pkts> ] [ <mgmt_out_bytes> ] [ <mgmt_out_underruns> ] [
<mgmt_out_errors> ] [ <mgmt_out_collisions> ] [ <mgmt_out_fifo> ] [ <mgmt_out_carrier> ] [
<mgmt_align_err> ] [ <mgmt_fcs_err> ] [ <mgmt_xmit_err> ] [ <mgmt_rcv_err> ] [ <mgmt_undersize> ] [
<mgmt_outdisc> ] [ <mgmt_single_col> ] [ <mgmt_multi_col> ] [ <mgmt_late_col> ] [ <mgmt_excess_col>
] [ <mgmt_carri_sen> ] [ <mgmt_runts> ] [ <mgmt_giants> ] [ <mgmt_sqetest_err> ] [ <mgmt_deferred_tx>
] [ <mgmt_inmactx_err> ] [ <mgmt_inmacrx_err> ] [ <mgmt_symbol_err> ] [ <loop_in_pkts> ] [
<loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors> ] [ <loop_in_frame>
] [ <loop_in_overrun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [ <loop_out_underruns>
] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [ <loop_out_carriers> ] [
<eth_load_intervall_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [ <eth_load_interval1_tx> ] [
<eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ] [ <eth_inrate1_summary_pkts>
] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [ <eth_load_interval2_rx> ] [
<eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [ <eth_outrate2_bits> ] [
<eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ] [
<eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_inpkts> ] [ <eth_inucast> ] [
<eth_inmcast> ] [ <eth_inbcast> ] [ <eth_ingiants> ] [ <eth_inbytes> ] [ <eth_storm_supp> ] [ <eth_inb64>
] [ <eth_inb65_127> ] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [
<eth_inb1024_1518> ] [ <eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outpkts> ] [ <eth_outucast> ] [
<eth_outmcast> ] [ <eth_outbcast> ] [ <eth_outgiants> ] [ <eth_outbytes> ] [ <eth_outb64> ] [
<eth_outb65_127> ] [ <eth_outb128_255> ] [ <eth_outb256_511> ] [ <eth_outb512_1023> ] [
<eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [ <eth_outtrunk> ] [ <eth_nobuf> ] [ <eth_runts> ] [
<eth_crc> ] [ <eth_ecc> ] [ <eth_overrun> ] [ <eth_underrun> ] [ <eth_ignored> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_in_ifdown_drops> ] [ <eth_coll> ] [ <eth_latecoll> ] [ <eth_lostcarrier> ] [
<eth_nocarrier> ] [ <eth_babbles> ] [ <eth_watchdog> ] [ <eth_dribble> ] [ <eth_inerr> ] [ <eth_outerr> ] [
<eth_deferred> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_single_coll> ] [ <eth_multi_coll> ] [
<eth_excess_coll> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [ <eth_outcrc> ] [ <eth_symbol> ] [
<eth_out_drops> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_inpause> ] [ <eth_outpause> ] [ <eth_resets> ] [ <eth_sqetest> ] [
<eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes> ] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [
<eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [ <eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [
<eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [
<eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [
<eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [
<eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [
<eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [
<eth_insw_switched> ] [ <eth_throtles> ] [ <eth_frame> ] [ <eth_outhw_switched> ] [ <eth_outsw_switched>
] [ <eth_buffail> ] [ <eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_fcoe_in_pkts>

```

```

][ <eth_fcoe_in_octets> ][ <eth_fcoe_out_pkts> ][ <eth_fcoe_out_octets> ][ <eth_nfcoe_in_pkts> ][
<eth_nfcoe_in_octets> ][ <eth_nfcoe_out_pkts> ][ <eth_nfcoe_out_octets> ][ <svi_routed_pkts_in> ][
<svi_routed_bytes_in> ][ <svi_routed_pkts_out> ][ <svi_routed_bytes_out> ][ <svi_ucast_pkts_in> ][
<svi_ucast_bytes_in> ][ <svi_mcast_pkts_in> ][ <svi_mcast_bytes_in> ][ <svi_ucast_pkts_out> ][
<svi_ucast_bytes_out> ][ <svi_mcast_pkts_out> ][ <svi_mcast_bytes_out> ][ <svi_ipv4_ucast_pkts_in> ][
<svi_ipv4_ucast_bytes_in> ][ <svi_ipv4_ucast_pkts_out> ][ <svi_ipv4_ucast_bytes_out> ][
<svi_ipv4_mcast_pkts_in> ][ <svi_ipv4_mcast_bytes_in> ][ <svi_ipv4_mcast_pkts_out> ][
<svi_ipv4_mcast_bytes_out> ][ <svi_ipv6_ucast_pkts_in> ][ <svi_ipv6_ucast_bytes_in> ][
<svi_ipv6_ucast_pkts_out> ][ <svi_ipv6_ucast_bytes_out> ][ <svi_ipv6_mcast_pkts_in> ][
<svi_ipv6_mcast_bytes_in> ][ <svi_ipv6_mcast_pkts_out> ][ <svi_ipv6_mcast_bytes_out> ][
<svi_average_input_bits> ][ <svi_average_input_packets> ][ <svi_average_output_bits> ][
<svi_average_output_packets> ][ <svi_rate_in_mins> ][ <svi_time_last_cleared> ][ <svi_tx_load> ][
<svi_rx_load> ][ <svi_reliability> ][ <input_rate_bit_per_sec> ][ <input_rate_bytes_per_sec> ][
<input_rate_frames_per_sec> ][ <output_rate_bit_per_sec> ][ <output_rate_bytes_per_sec> ][
<output_rate_frames_per_sec> ][ <in_frames> ][ <in_bytes> ][ <class_2_in_frames> ][ <class_2_in_bytes> ][
<class_3_in_frames> ][ <class_3_in_bytes> ][ <class_f_in_frames> ][ <class_f_in_bytes> ][
<class_2_3_in_frames> ][ <in_discards> ][ <in_errors> ][ <in_crc_fcs> ][ <in_unknown_class> ][
<in_too_long> ][ <in_too_short> ][ <out_frames> ][ <out_bytes> ][ <class_2_out_frames> ][
<class_2_out_bytes> ][ <class_3_out_frames> ][ <class_3_out_bytes> ][ <class_f_out_frames> ][
<class_f_out_bytes> ][ <class_2_3_out_frames> ][ <out_discards> ][ <out_errors> ][ <out_crc_fcs> ][
<timeout_discards> ][ <credit_loss> ][ <input_ols> ][ <input_lrr> ][ <input_nos> ][ <input_loop_inits> ][
<output_ols> ][ <output_lrr> ][ <output_nos> ][ <output_loop_inits> ][ <link_faliures> ][ <sync_loss> ][
<signal_loss> ][ <b2b_transmit> ][ <b2b_receive> ][ <txwait> ][ <tx_credit_unavbl> ][
<b2b_receive_remain> ][ <b2b_transmit_remain> ][ <low_priority_b2b_remain> ][ <off_seq_err_rcvd> ][
<broadcast_frames> ][ <errors> ][ <queue_drops> ][ <if_down_drops> ][ <red_drops> ][
<bad_ether_type_drops> ][ <bad_protocol_drops> ][ <arp_drops> ][ <reass_frames> ][ <timestamp_error> ][
<rx_b2b_perf_buff> ][ <rx_b2b_credit> ][ <tx_b2b_credit> ][ <tx_b2b_low_pri_cre> ][
<time_last_cleared> ] ]

```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
detailed	Show only non-zero counters
snmp	(Optional) Show SNMP MIB values
__readonly__	(Optional) Read Only
TABLE_interface	(Optional) show interface
interface	(Optional) Interface index
vdc_lvl_in_pkts	(Optional) VDC level input packets
vdc_lvl_in_bytes	(Optional) VDC level input bytes
vdc_lvl_in_ucast	(Optional) VDC level input unicast packets
vdc_lvl_in_mcast	(Optional) VDC level input multicast packets

<i>vdc_lvl_in_bcast</i>	(Optional) VDC level input broadcast packets
<i>vdc_lvl_in_bps</i>	(Optional) VDC level input bytes per second
<i>vdc_lvl_in_pps</i>	(Optional) VDC level input packets per second
<i>vdc_lvl_in_avg_pkts</i>	(Optional) VDC level average input packets
<i>vdc_lvl_in_avg_bytes</i>	(Optional) VDC level average input bytes
<i>vdc_lvl_out_pkts</i>	(Optional) VDC level output packets
<i>vdc_lvl_out_bytes</i>	(Optional) VDC level output bytes
<i>vdc_lvl_out_ucast</i>	(Optional) VDC level output unicast packets
<i>vdc_lvl_out_mcast</i>	(Optional) VDC level output multicast packets
<i>vdc_lvl_out_bcast</i>	(Optional) VDC level output broadcast packets
<i>vdc_lvl_out_bps</i>	(Optional) VDC level output bytes per second
<i>vdc_lvl_out_pps</i>	(Optional) VDC level output packets per second
<i>vdc_lvl_out_avg_pkts</i>	(Optional) VDC level average output packets
<i>vdc_lvl_out_avg_bytes</i>	(Optional) VDC level average output bytes
<i>mgmt_in_pkts</i>	(Optional) Input packets
<i>mgmt_in_bytes</i>	(Optional) Input bytes
<i>mgmt_in_mcast</i>	(Optional) Input multicast frames
<i>mgmt_in_compressed</i>	(Optional) Input compressed
<i>mgmt_in_errors</i>	(Optional) Input errors
<i>mgmt_in_frame</i>	(Optional) Input frame errors
<i>mgmt_in_overrun</i>	(Optional) Input overrun
<i>mgmt_in_fifo</i>	(Optional) Input fifo
<i>mgmt_out_pkts</i>	(Optional) Output packets
<i>mgmt_out_bytes</i>	(Optional) Output bytes
<i>mgmt_out_underruns</i>	(Optional) Output overruns
<i>mgmt_out_errors</i>	(Optional) Output errors
<i>mgmt_out_collisions</i>	(Optional) Output collisions
<i>mgmt_out_fifo</i>	(Optional) Output fifo
<i>mgmt_out_carrier</i>	(Optional) Output carrier errors

<i>mgmt_align_err</i>	(Optional) Align error
<i>mgmt_fcs_err</i>	(Optional) FCS error
<i>mgmt_xmit_err</i>	(Optional) Transmit error
<i>mgmt_rcv_err</i>	(Optional) Receive error
<i>mgmt_undersize</i>	(Optional) Undersize
<i>mgmt_outdisc</i>	(Optional) Out discard
<i>mgmt_single_col</i>	(Optional) Single collision
<i>mgmt_multi_col</i>	(Optional) Multiple collision
<i>mgmt_late_col</i>	(Optional) Late collision
<i>mgmt_excess_col</i>	(Optional) Excess collision
<i>mgmt_carri_sen</i>	(Optional) Carrier sense
<i>mgmt_runts</i>	(Optional) Runts
<i>mgmt_giants</i>	(Optional) Giants
<i>mgmt_sqetest_err</i>	(Optional) SQETest error
<i>mgmt_deferred_tx</i>	(Optional) Deferred tx
<i>mgmt_inmactx_err</i>	(Optional) In MAC tx
<i>mgmt_inmacrx_err</i>	(Optional) In MAC rx
<i>mgmt_symbol_err</i>	(Optional) Symbol error
<i>loop_in_pkts</i>	(Optional) Input packets
<i>loop_in_bytes</i>	(Optional) Input bytes
<i>loop_in_mcast</i>	(Optional) Input multicast
<i>loop_in_compressed</i>	(Optional) Input compressed
<i>loop_in_errors</i>	(Optional) Input errors
<i>loop_in_frame</i>	(Optional) Input frame errors
<i>loop_in_overrun</i>	(Optional) Input overrun
<i>loop_in_fifo</i>	(Optional) Input fifo
<i>loop_out_pkts</i>	(Optional) Output packets
<i>loop_out_bytes</i>	(Optional) Output bytes
<i>loop_out_underruns</i>	(Optional) Output underruns

<i>loop_out_errors</i>	(Optional) Output errors
<i>loop_out_collisions</i>	(Optional) Output collisions
<i>loop_out_fifo</i>	(Optional) Output fifo
<i>loop_out_carriers</i>	(Optional) Output carrier errors
<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec
<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec

<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_ingiants</i>	(Optional) giants
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_inb64</i>	(Optional) input pkts between 0 and 64 bytes
<i>eth_inb65_127</i>	(Optional) input pkts between 65 and 127 bytes
<i>eth_inb128_255</i>	(Optional) input pkts between 128 and 255 bytes
<i>eth_inb256_511</i>	(Optional) input pkts between 256 and 511 bytes
<i>eth_inb512_1023</i>	(Optional) input pkts between 512 and 1023 bytes
<i>eth_inb1024_1518</i>	(Optional) input pkts between 1024 and 1518 bytes
<i>eth_inb1519_1548</i>	(Optional) input pkts between 1519 and 1548 bytes
<i>eth_intrunk</i>	(Optional) input trunk pkts
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outgiants</i>	(Optional) giants
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_outb64</i>	(Optional) output pkts between 0 and 64 bytes
<i>eth_outb65_127</i>	(Optional) output pkts between 65 and 127 bytes
<i>eth_outb128_255</i>	(Optional) output pkts between 128 and 255 bytes

<i>eth_outb256_511</i>	(Optional) output pkts between 256 and 511 bytes
<i>eth_outb512_1023</i>	(Optional) output pkts between 512 and 1023 bytes
<i>eth_outb1024_1518</i>	(Optional) output pkts between 1024 and 1518 bytes
<i>eth_outb1519_1548</i>	(Optional) output pkts between 1519 and 1548 bytes
<i>eth_outtrunk</i>	(Optional) output trunk pkts
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_runts</i>	(Optional) runts
<i>eth_crc</i>	(Optional) CRC
<i>eth_ecc</i>	(Optional) ECC
<i>eth_overrun</i>	(Optional) overrun
<i>eth_underrun</i>	(Optional) underruns
<i>eth_ignored</i>	(Optional) ignored
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_coll</i>	(Optional) collisions
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_babbles</i>	(Optional) babbles
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_inerr</i>	(Optional) input errors
<i>eth_outerr</i>	(Optional) output errors
<i>eth_deferred</i>	(Optional) deferred
<i>eth_jabbers</i>	(Optional) jabbers
<i>eth_shortframe</i>	(Optional) short frames
<i>eth_single_coll</i>	(Optional) single collisions
<i>eth_multi_coll</i>	(Optional) multi collisions

<i>eth_excess_coll</i>	(Optional) excessive collisions
<i>eth_indiscard</i>	(Optional) discards
<i>eth_bad_encap</i>	(Optional) bad encapsulation
<i>eth_outcrc</i>	(Optional) Output CRC
<i>eth_symbol</i>	(Optional) symbol errors
<i>eth_out_drops</i>	(Optional) output drops
<i>eth_bpdu_outlost</i>	(Optional) BPDU output lost
<i>eth_cos0_outlost</i>	(Optional) output pkts
<i>eth_cos1_outlost</i>	(Optional) output pkts
<i>eth_cos2_outlost</i>	(Optional) output pkts
<i>eth_cos3_outlost</i>	(Optional) output pkts
<i>eth_cos4_outlost</i>	(Optional) output pkts
<i>eth_cos5_outlost</i>	(Optional) output pkts
<i>eth_cos6_outlost</i>	(Optional) output pkts
<i>eth_cos7_outlost</i>	(Optional) output pkts
<i>eth_inpause</i>	(Optional) pause input
<i>eth_outpause</i>	(Optional) PAUSE output
<i>eth_resets</i>	(Optional) interface resets
<i>eth_sqetest</i>	(Optional) SQE test
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) L3 in switched mcast bytes

<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes
<i>eth_l3out_ucastpkts</i>	(Optional) L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes
<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_ipmcast</i>	(Optional) IP multicast
<i>eth_inhw_switched</i>	(Optional) Input H/W Switched
<i>eth_insw_switched</i>	(Optional) Input S/W Switched
<i>eth_throtles</i>	(Optional) throttles
<i>eth_frame</i>	(Optional) frame
<i>eth_outhw_switched</i>	(Optional) Out H/W Switched
<i>eth_outsw_switched</i>	(Optional) Out S/W Switched
<i>eth_buffail</i>	(Optional) output buffer failures
<i>eth_bufswapped</i>	(Optional) output buffers swapped out
<i>eth_arpdrops</i>	(Optional) arp drops
<i>eth_out_ifdown_drops</i>	(Optional) Output if-down drops
<i>eth_fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>eth_fcoe_in_octets</i>	(Optional) fcoe in octets

<i>eth_fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>eth_fcoe_out_octets</i>	(Optional) fcoe out octets
<i>eth_nfcoe_in_pkts</i>	(Optional) nfcoe in pkts
<i>eth_nfcoe_in_octets</i>	(Optional) nfcoe in octets
<i>eth_nfcoe_out_pkts</i>	(Optional) nfcoe out pkts
<i>eth_nfcoe_out_octets</i>	(Optional) nfcoe out octets
<i>svi_time_last_cleared</i>	(Optional) Time last cleared
<i>svi_tx_load</i>	(Optional) Tx Load
<i>svi_rx_load</i>	(Optional) Rx Load
<i>svi_reliability</i>	(Optional) Reliability
<i>input_rate_bit_per_sec</i>	(Optional) Input rate bits per second
<i>input_rate_bytes_per_sec</i>	(Optional) Input rate bytes per second
<i>input_rate_frames_per_sec</i>	(Optional) Input rate frames per second
<i>output_rate_bit_per_sec</i>	(Optional) Output rate bits per second
<i>output_rate_bytes_per_sec</i>	(Optional) Output rate bytes per second
<i>output_rate_frames_per_sec</i>	(Optional) Output rate frames per second
<i>in_frames</i>	(Optional) Frames
<i>in_bytes</i>	(Optional) Bytes
<i>class_2_in_frames</i>	(Optional) Class 2 frames
<i>class_2_in_bytes</i>	(Optional) Class 2 bytes
<i>class_3_in_frames</i>	(Optional) Class 3 frames
<i>class_3_in_bytes</i>	(Optional) Class 3 bytes
<i>class_f_in_frames</i>	(Optional) Class f frames
<i>class_f_in_bytes</i>	(Optional) Class f bytes
<i>class_2_3_in_frames</i>	(Optional) Class 2/3 Frames
<i>in_discards</i>	(Optional) Discards
<i>in_errors</i>	(Optional) Errors
<i>in_crc_fcs</i>	(Optional) CRC/FCS
<i>in_unknown_class</i>	(Optional) Unknown Class

<i>in_too_long</i>	(Optional) Frames too long
<i>in_too_short</i>	(Optional) Frames too short
<i>out_frames</i>	(Optional) Frames
<i>out_bytes</i>	(Optional) Bytes
<i>class_2_out_frames</i>	(Optional) Class 2 frames
<i>class_2_out_bytes</i>	(Optional) Class 2 bytes
<i>class_3_out_frames</i>	(Optional) Class 3 frames
<i>class_3_out_bytes</i>	(Optional) Class 3 bytes
<i>class_f_out_frames</i>	(Optional) Class f frames
<i>class_f_out_bytes</i>	(Optional) Class f bytes
<i>class_2_3_out_frames</i>	(Optional) Class 2/3 frames
<i>out_discards</i>	(Optional) Discards
<i>out_errors</i>	(Optional) Errors
<i>out_crc_fcs</i>	(Optional) CRC/FCS
<i>timeout_discards</i>	(Optional) Timeout Discards
<i>credit_loss</i>	(Optional) Credit Loss
<i>input_ols</i>	(Optional) input ols
<i>input_lrr</i>	(Optional) input LRR
<i>input_nos</i>	(Optional) input NOS
<i>input_loop_inits</i>	(Optional) input loop inits
<i>output_ols</i>	(Optional) output OLS
<i>output_lrr</i>	(Optional) output LRR
<i>output_nos</i>	(Optional) output NOS
<i>output_loop_inits</i>	(Optional) output loop inits
<i>link_faliures</i>	(Optional) link faliures
<i>sync_loss</i>	(Optional) Sync loss
<i>signal_loss</i>	(Optional) Signal loss
<i>b2b_transmit</i>	(Optional) B2B transmit
<i>b2b_receive</i>	(Optional) B2B receive

<i>txwait</i>	(Optional) TxWait
<i>tx_credit_unavbl</i>	(Optional) Tx credit unavaliable
<i>b2b_receive_remain</i>	(Optional) B2B receive remain
<i>b2b_transmit_remain</i>	(Optional) B2B transmit remain
<i>low_priority_b2b_remain</i>	(Optional) Low priority B2B credit remaining
<i>off_seq_err_rcvd</i>	(Optional) Offset Sequence Error Received
<i>broadcast_frames</i>	(Optional) Broadcast frames
<i>errors</i>	(Optional) Errors
<i>queue_drops</i>	(Optional) Queue drops
<i>if_down_drops</i>	(Optional) If down drops
<i>red_drops</i>	(Optional) Red drops
<i>bad_ether_type_drops</i>	(Optional) Bad ether type drops
<i>bad_protocol_drops</i>	(Optional) Bad Protocol Drops
<i>arp_drops</i>	(Optional) Arp Drops
<i>timestamp_error</i>	(Optional) Timestamp Error
<i>reass_frames</i>	(Optional) Reass Frames
<i>rx_b2b_perf_buff</i>	(Optional) RX B2B performance buffer
<i>rx_b2b_credit</i>	(Optional) RX B2B credit remaining
<i>tx_b2b_credit</i>	(Optional) TX B2B credit remaining
<i>tx_b2b_low_pri_cre</i>	(Optional) TX B2B low priority Credit
<i>time_last_cleared</i>	(Optional) Last time cleared

Command Mode

- /exec

show interface counters detailed

```
show interface <ifloop_ctr_dtl> counters detailed [ __readonly__ TABLE_interface <interface> [
<loop_in_pkts> ] [ <loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors> ]
[ <loop_in_frame> ] [ <loop_in_overnun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [
<loop_out_underruns> ] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [
<loop_out_carriers> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifloop_ctr_dtl</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>loop_in_pkts</i>	(Optional) Input packets
<i>loop_in_bytes</i>	(Optional) Input bytes
<i>loop_in_mcast</i>	(Optional) Input multicast
<i>loop_in_compressed</i>	(Optional) Input compressed
<i>loop_in_errors</i>	(Optional) Input errors
<i>loop_in_frame</i>	(Optional) Input frame errors
<i>loop_in_overnun</i>	(Optional) Input overrun
<i>loop_in_fifo</i>	(Optional) Input fifo
<i>loop_out_pkts</i>	(Optional) Output packets
<i>loop_out_bytes</i>	(Optional) Output bytes
<i>loop_out_underruns</i>	(Optional) Output underruns
<i>loop_out_errors</i>	(Optional) Output errors
<i>loop_out_collisions</i>	(Optional) Output collisions
<i>loop_out_fifo</i>	(Optional) Output fifo
<i>loop_out_carriers</i>	(Optional) Output carrier errors

Command Mode

- /exec

show interface counters detailed

```
show interface <ifeth_ctr_dtl> counters detailed [ snmp ] [ __readonly__ TABLE_interface <interface> [
<eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [ <eth_load_interval1_tx> ] [
<eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ] [ <eth_inrate1_summary_pkts>
] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [ <eth_load_interval2_rx> ] [
<eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [ <eth_outrate2_bits> ] [
<eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ] [
<eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_inpkts> ] [ <eth_inucast> ] [
<eth_inmcast> ] [ <eth_inbcast> ] [ <eth_ingiants> ] [ <eth_inbytes> ] [ <eth_storm_supp> ] [ <eth_inb64>
] [ <eth_inb65_127> ] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [
<eth_inb1024_1518> ] [ <eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outpkts> ] [ <eth_outucast> ] [
<eth_outmcast> ] [ <eth_outbcast> ] [ <eth_outgiants> ] [ <eth_outbytes> ] [ <eth_outb64> ] [
<eth_outb65_127> ] [ <eth_outb128_255> ] [ <eth_outb256_511> ] [ <eth_outb512_1023> ] [
<eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [ <eth_outtrunk> ] [ <eth_nobuf> ] [ <eth_runts> ] [
<eth_crc> ] [ <eth_ecc> ] [ <eth_overnun> ] [ <eth_underrun> ] [ <eth_ignored> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_in_ifdown_drops> ] [ <eth_coll> ] [ <eth_latecoll> ] [ <eth_lostcarrier> ] [
<eth_nocarrier> ] [ <eth_babbles> ] [ <eth_watchdog> ] [ <eth_dribble> ] [ <eth_inerr> ] [ <eth_outerr> ] [
<eth_deferred> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_single_coll> ] [ <eth_multi_coll> ] [
<eth_excess_coll> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [ <eth_outcrc> ] [ <eth_symbol> ] [
<eth_out_drops> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_inpause> ] [ <eth_outpause> ] [ <eth_resets> ] [ <eth_sqetest> ] [
<eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes> ] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [
<eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [ <eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [
<eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [
<eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [
<eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [
<eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [
<eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [
<eth_insw_switched> ] [ <eth_throtles> ] [ <eth_frame> ] [ <eth_outhw_switched> ] [ <eth_outsw_switched>
] [ <eth_buffail> ] [ <eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr_dtl</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
snmp	(Optional) Show SNMP MIB values
__readonly__	(Optional) Read Only

<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec
<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary

<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_ingiants</i>	(Optional) giants
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_inb64</i>	(Optional) input pkts between 0 and 64 bytes
<i>eth_inb65_127</i>	(Optional) input pkts between 65 and 127 bytes
<i>eth_inb128_255</i>	(Optional) input pkts between 128 and 255 bytes
<i>eth_inb256_511</i>	(Optional) input pkts between 256 and 511 bytes
<i>eth_inb512_1023</i>	(Optional) input pkts between 512 and 1023 bytes
<i>eth_inb1024_1518</i>	(Optional) input pkts between 1024 and 1518 bytes
<i>eth_inb1519_1548</i>	(Optional) input pkts between 1519 and 1548 bytes
<i>eth_intrunk</i>	(Optional) input trunk pkts
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outgiants</i>	(Optional) giants
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_outb64</i>	(Optional) output pkts between 0 and 64 bytes
<i>eth_outb65_127</i>	(Optional) output pkts between 65 and 127 bytes
<i>eth_outb128_255</i>	(Optional) output pkts between 128 and 255 bytes
<i>eth_outb256_511</i>	(Optional) output pkts between 256 and 511 bytes
<i>eth_outb512_1023</i>	(Optional) output pkts between 512 and 1023 bytes

<i>eth_outb1024_1518</i>	(Optional) output pkts between 1024 and 1518 bytes
<i>eth_outb1519_1548</i>	(Optional) output pkts between 1519 and 1548 bytes
<i>eth_outtrunk</i>	(Optional) output trunk pkts
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_runts</i>	(Optional) runts
<i>eth_crc</i>	(Optional) CRC
<i>eth_ecc</i>	(Optional) ECC
<i>eth_overrun</i>	(Optional) overrun
<i>eth_underrun</i>	(Optional) underruns
<i>eth_ignored</i>	(Optional) ignored
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_coll</i>	(Optional) collisions
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_babbles</i>	(Optional) babbles
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_inerr</i>	(Optional) input errors
<i>eth_outerr</i>	(Optional) output errors
<i>eth_deferred</i>	(Optional) deferred
<i>eth_jabbers</i>	(Optional) jabbers
<i>eth_shortframe</i>	(Optional) short frames
<i>eth_single_coll</i>	(Optional) single collisions
<i>eth_multi_coll</i>	(Optional) multi collisions
<i>eth_excess_coll</i>	(Optional) excessive collisions
<i>eth_indiscard</i>	(Optional) discards

<i>eth_bad_encap</i>	(Optional) bad encapsulation
<i>eth_outcrc</i>	(Optional) Output CRC
<i>eth_symbol</i>	(Optional) symbol errors
<i>eth_out_drops</i>	(Optional) output drops
<i>eth_bpdu_outlost</i>	(Optional) BPDU output lost
<i>eth_cos0_outlost</i>	(Optional) output pkts
<i>eth_cos1_outlost</i>	(Optional) output pkts
<i>eth_cos2_outlost</i>	(Optional) output pkts
<i>eth_cos3_outlost</i>	(Optional) output pkts
<i>eth_cos4_outlost</i>	(Optional) output pkts
<i>eth_cos5_outlost</i>	(Optional) output pkts
<i>eth_cos6_outlost</i>	(Optional) output pkts
<i>eth_cos7_outlost</i>	(Optional) output pkts
<i>eth_inpause</i>	(Optional) pause input
<i>eth_outpause</i>	(Optional) PAUSE output
<i>eth_resets</i>	(Optional) interface resets
<i>eth_sqetest</i>	(Optional) SQE test
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes

<i>eth_l3out_ucastpkts</i>	(Optional) L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes
<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_ipmcast</i>	(Optional) IP multicast
<i>eth_inhw_switched</i>	(Optional) Input H/W Switched
<i>eth_insw_switched</i>	(Optional) Input S/W Switched
<i>eth_throtles</i>	(Optional) throttles
<i>eth_frame</i>	(Optional) frame
<i>eth_outhw_switched</i>	(Optional) Out H/W Switched
<i>eth_outsw_switched</i>	(Optional) Out S/W Switched
<i>eth_buffail</i>	(Optional) output buffer failures
<i>eth_bufswapped</i>	(Optional) output buffers swapped out
<i>eth_arpdrops</i>	(Optional) arp drops
<i>eth_out_ifdown_drops</i>	(Optional) Output if-down drops

Command Mode

- /exec

show interface counters detailed all

```
show interface <ifrange> counters detailed all [ snmp ] [ __readonly__ TABLE_interface <interface> [
<svi_routed_pkts_in> ] [ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out> ] [ <svi_routed_bytes_out> ] [
<svi_ucast_pkts_in> ] [ <svi_ucast_bytes_in> ] [ <svi_mcast_pkts_in> ] [ <svi_mcast_bytes_in> ] [
<svi_ucast_pkts_out> ] [ <svi_ucast_bytes_out> ] [ <svi_mcast_pkts_out> ] [ <svi_mcast_bytes_out> ] [
<svi_ipv4_ucast_pkts_in> ] [ <svi_ipv4_ucast_bytes_in> ] [ <svi_ipv4_ucast_pkts_out> ] [
<svi_ipv4_ucast_bytes_out> ] [ <svi_ipv4_mcast_pkts_in> ] [ <svi_ipv4_mcast_bytes_in> ] [
<svi_ipv4_mcast_pkts_out> ] [ <svi_ipv4_mcast_bytes_out> ] [ <svi_ipv6_ucast_pkts_in> ] [
<svi_ipv6_ucast_bytes_in> ] [ <svi_ipv6_ucast_pkts_out> ] [ <svi_ipv6_ucast_bytes_out> ] [
<svi_ipv6_mcast_pkts_in> ] [ <svi_ipv6_mcast_bytes_in> ] [ <svi_ipv6_mcast_pkts_out> ] [
<svi_ipv6_mcast_bytes_out> ] [ <svi_average_input_bits> ] [ <svi_average_input_packets> ] [
<svi_average_output_bits> ] [ <svi_average_output_packets> ] [ <svi_rate_in_mins> ] [
<svi_time_last_cleared> ] [ <svi_tx_load> ] [ <svi_rx_load> ] [ <svi_reliability> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
all	everything
snmp	(Optional) Show SNMP MIB values
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>svi_time_last_cleared</i>	(Optional) Time last cleared
<i>svi_tx_load</i>	(Optional) Tx Load
<i>svi_rx_load</i>	(Optional) Rx Load
<i>svi_reliability</i>	(Optional) Reliability

Command Mode

- /exec

show interface counters detailed all

```
show interface <ifid_ctr_dtl_all> counters detailed all [ snmp ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_ctr_dtl_all</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
all	Show every interface counter
snmp	(Optional) Show SNMP MIB values

Command Mode

- /exec

show interface counters detailed all

```
show interface <ifmgmt_ctr_dtl_all> counters detailed all [ __readonly__ TABLE_interface <interface> [
<vdc_lvl_in_pkts> ][ <vdc_lvl_in_bytes> ][ <vdc_lvl_in_ucast> ][ <vdc_lvl_in_mcast> ][
<vdc_lvl_in_bcast> ][ <vdc_lvl_in_bps> ][ <vdc_lvl_in_pps> ][ <vdc_lvl_in_avg_pkts> ][
<vdc_lvl_in_avg_bytes> ][ <vdc_lvl_out_pkts> ][ <vdc_lvl_out_bytes> ][ <vdc_lvl_out_ucast> ][
<vdc_lvl_out_mcast> ][ <vdc_lvl_out_bcast> ][ <vdc_lvl_out_bps> ][ <vdc_lvl_out_pps> ][
<vdc_lvl_out_avg_pkts> ][ <vdc_lvl_out_avg_bytes> ][ <mgmt_in_pkts> ][ <mgmt_in_bytes> ][
<mgmt_in_mcast> ][ <mgmt_out_pkts> ][ <mgmt_out_bytes> ][ <mgmt_in_errors> ][ <mgmt_out_errors>
][ <mgmt_in_fifo> ][ <mgmt_out_fifo> ][ <mgmt_in_compressed> ][ <mgmt_in_frame> ][
<mgmt_in_overrun> ][ <mgmt_out_underruns> ][ <mgmt_out_collisions> ][ <mgmt_out_carrier> ][
<mgmt_align_err> ][ <mgmt_fcs_err> ][ <mgmt_xmit_err> ][ <mgmt_rcv_err> ][ <mgmt_undersize> ][
<mgmt_outdisc> ][ <mgmt_single_col> ][ <mgmt_multi_col> ][ <mgmt_late_col> ][ <mgmt_excess_col>
][ <mgmt_carri_sen> ][ <mgmt_runts> ][ <mgmt_giants> ][ <mgmt_sqetest_err> ][ <mgmt_deferred_tx>
][ <mgmt_inmactx_err> ][ <mgmt_inmacrx_err> ][ <mgmt_symbol_err> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifmgmt_ctr_dtl_all</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
all	Show every interface counter
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>vdc_lvl_in_pkts</i>	(Optional) VDC level input packets
<i>vdc_lvl_in_bytes</i>	(Optional) VDC level input bytes
<i>vdc_lvl_in_ucast</i>	(Optional) VDC level input unicast packets
<i>vdc_lvl_in_mcast</i>	(Optional) VDC level input multicast packets
<i>vdc_lvl_in_bcast</i>	(Optional) VDC level input broadcast packets
<i>vdc_lvl_in_bps</i>	(Optional) VDC level input bytes per second
<i>vdc_lvl_in_pps</i>	(Optional) VDC level input packets per second
<i>vdc_lvl_in_avg_pkts</i>	(Optional) VDC level average input packets
<i>vdc_lvl_in_avg_bytes</i>	(Optional) VDC level average input bytes

<i>vdc_lvl_out_pkts</i>	(Optional) VDC level output packets
<i>vdc_lvl_out_bytes</i>	(Optional) VDC level output bytes
<i>vdc_lvl_out_ucast</i>	(Optional) VDC level output unicast packets
<i>vdc_lvl_out_mcast</i>	(Optional) VDC level output multicast packets
<i>vdc_lvl_out_bcast</i>	(Optional) VDC level output broadcast packets
<i>vdc_lvl_out_bps</i>	(Optional) VDC level output bytes per second
<i>vdc_lvl_out_pps</i>	(Optional) VDC level output packets per second
<i>vdc_lvl_out_avg_pkts</i>	(Optional) VDC level average output packets
<i>vdc_lvl_out_avg_bytes</i>	(Optional) VDC level average output bytes
<i>mgmt_in_pkts</i>	(Optional) Input packets
<i>mgmt_in_bytes</i>	(Optional) Input bytes
<i>mgmt_in_mcast</i>	(Optional) Input multicast frames
<i>mgmt_out_pkts</i>	(Optional) Output packets
<i>mgmt_out_bytes</i>	(Optional) Output bytes
<i>mgmt_in_errors</i>	(Optional) Input errors
<i>mgmt_out_errors</i>	(Optional) Output errors
<i>mgmt_in_fifo</i>	(Optional) Input fifo
<i>mgmt_out_fifo</i>	(Optional) Output fifo
<i>mgmt_in_compressed</i>	(Optional) Input compressed
<i>mgmt_in_frame</i>	(Optional) Input frame errors
<i>mgmt_in_overnun</i>	(Optional) Input overrun
<i>mgmt_out_underruns</i>	(Optional) Output overruns
<i>mgmt_out_collisions</i>	(Optional) Output collisions
<i>mgmt_out_carrier</i>	(Optional) Output carrier errors
<i>mgmt_align_err</i>	(Optional) Align error
<i>mgmt_fcs_err</i>	(Optional) FCS error
<i>mgmt_xmit_err</i>	(Optional) Transmit error
<i>mgmt_rcv_err</i>	(Optional) Receive error
<i>mgmt_undersize</i>	(Optional) Undersize

<i>mgmt_outdisc</i>	(Optional) Out discard
<i>mgmt_single_col</i>	(Optional) Single collision
<i>mgmt_multi_col</i>	(Optional) Multiple collision
<i>mgmt_late_col</i>	(Optional) Late collision
<i>mgmt_excess_col</i>	(Optional) Excess collision
<i>mgmt_carri_sen</i>	(Optional) Carrier sense
<i>mgmt_runts</i>	(Optional) Runts
<i>mgmt_giants</i>	(Optional) Giants
<i>mgmt_sqetest_err</i>	(Optional) SQETest error
<i>mgmt_deferred_tx</i>	(Optional) Deferred tx
<i>mgmt_inmactx_err</i>	(Optional) In MAC tx
<i>mgmt_inmacrx_err</i>	(Optional) In MAC rx
<i>mgmt_symbol_err</i>	(Optional) Symbol error

Command Mode

- /exec

show interface counters detailed all

```
show interface <ifloop_ctr_dtl_all> counters detailed all [ __readonly__ TABLE_interface <interface> [
<rx_total_pkts> ] [ <tx_total_pkts> ] [ <rx_mcast_pkts> ] [ <rx_octets> ] [ <tx_octets> ] [ <loop_in_pkts> ]
[ <loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors> ] [ <loop_in_frame>
] [ <loop_in_overrun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [ <loop_out_underruns>
] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [ <loop_out_carriers> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifloop_ctr_dtl_all</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
all	Show every interface counter
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>rx_total_pkts</i>	(Optional) total input packets
<i>tx_total_pkts</i>	(Optional) total output packets
<i>rx_mcast_pkts</i>	(Optional) input multicasts
<i>rx_octets</i>	(Optional) input bytes
<i>tx_octets</i>	(Optional) output bytes
<i>loop_in_pkts</i>	(Optional) Input packets
<i>loop_in_bytes</i>	(Optional) Input bytes
<i>loop_in_mcast</i>	(Optional) Input multicast
<i>loop_in_compressed</i>	(Optional) Input compressed
<i>loop_in_errors</i>	(Optional) Input errors
<i>loop_in_frame</i>	(Optional) Input frame errors
<i>loop_in_overrun</i>	(Optional) Input overrun
<i>loop_in_fifo</i>	(Optional) Input fifo
<i>loop_out_pkts</i>	(Optional) Output packets

<i>loop_out_bytes</i>	(Optional) Output bytes
<i>loop_out_underruns</i>	(Optional) Output underruns
<i>loop_out_errors</i>	(Optional) Output errors
<i>loop_out_collisions</i>	(Optional) Output collisions
<i>loop_out_fifo</i>	(Optional) Output fifo
<i>loop_out_carriers</i>	(Optional) Output carrier errors

Command Mode

- /exec

show interface counters detailed all

```

show interface <ifeth_ctr_dtl_all> counters detailed all [ snmp ] [ __readonly__ TABLE interface <interface>
[ <rx_total_pkts> ] [ <tx_total_pkts> ] [ <rx_ucast_pkts> ] [ <rx_mcast_pkts> ] [ <rx_bcast_pkts> ] [
<rx_octets> ] [ <tx_ucast_pkts> ] [ <tx_mcast_pkts> ] [ <tx_bcast_pkts> ] [ <tx_octets> ] [
<rxtx_pkts_64octets> ] [ <rxtx_pkts_65_127octets> ] [ <rxtx_pkts_128_255octets> ] [
<rxtx_pkts_256_511octets> ] [ <rxtx_pkts_512_1023octets> ] [ <rxtx_pkts_1024_1518octets> ] [
<rxtx_pkts_1519_1548octets> ] [ <rx_trunk_frames> ] [ <tx_trunk_frames> ] [ <rx_drop_events> ] [
<rxtx_giants> ] [ <eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [
<eth_load_interval1_tx> ] [ <eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ]
[ <eth_inrate1_summary_pkts> ] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [
<eth_load_interval2_rx> ] [ <eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [
<eth_outrate2_bits> ] [ <eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ]
[ <eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes> ]
[ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes> ]
[ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_l3avg2_inbytes> ] [ <eth_l3avg2_inpkts> ] [ <eth_l3avg2_outbytes> ] [ <eth_l3avg2_outpkts> ] [
<eth_l3avg3_inbytes> ] [ <eth_l3avg3_inpkts> ] [ <eth_l3avg3_outbytes> ] [ <eth_l3avg3_outpkts> ] [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_nobuf> ] [ <eth_inbcast> ] [ <eth_inmcast> ] [ <eth_inucast> ] [
<eth_ingiants> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [ <eth_insw_switched> ] [ <eth_runts> ] [
<eth_storm_supp> ] [ <eth_throtles> ] [ <eth_inerr> ] [ <eth_crc> ] [ <eth_ecc> ] [ <eth_frame> ] [
<eth_overrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_outbcast> ] [ <eth_outmcast> ] [ <eth_outucast> ]
[ <eth_outgiants> ] [ <eth_inpause> ] [ <eth_dribble> ] [ <eth_in_ifdown_drops> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_underrun> ] [ <eth_outhw_switched> ] [
<eth_outsw_switched> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_resets> ] [ <eth_babbles> ] [ <eth_latecoll> ]
[ <eth_deferred> ] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_outpause> ] [ <eth_buffail> ] [
<eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_single_coll> ] [ <eth_multi_coll> ]
[ <eth_excess_coll> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [
<eth_outcrc> ] [ <eth_symbol> ] [ <eth_out_drops> ] [ <eth_sqetest> ] [ <eth_inb64> ] [ <eth_inb65_127> ]
[ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [ <eth_inb1024_1518> ] [
<eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outb64> ] [ <eth_outb65_127> ] [ <eth_outb128_255> ] [
<eth_outb256_511> ] [ <eth_outb512_1023> ] [ <eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [
<eth_outtrunk> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost> ]
[ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_fcoe_in_pkts> ] [ <eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [
<eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [ <eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [
<eth_nfcoe_out_octets> ] [ <eth_eee_atx_lpi_msec> ] [ <eth_eee_arcv_lpi_msec> ] [
<eth_eee_atx_lpi_transitions> ] [ <eth_eee_arcv_lpi_transitions> ] [ <eth_phy_ber_count> ] [
<eth_phy_errblks_count> ] ]

```

Syntax Description

show	Show running system information
------	---------------------------------

interface	Show interface status and information
<i>ifeth_ctr_dtl_all</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
all	everything
snmp	(Optional) Show SNMP MIB values
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>rx_total_pkts</i>	(Optional) total input packets
<i>tx_total_pkts</i>	(Optional) total output packets
<i>rx_ucast_pkts</i>	(Optional) input unicasts
<i>rx_mcast_pkts</i>	(Optional) input multicasts
<i>rx_bcast_pkts</i>	(Optional) input broadcasts
<i>rx_octets</i>	(Optional) input bytes
<i>tx_ucast_pkts</i>	(Optional) output unicasts
<i>tx_mcast_pkts</i>	(Optional) output multicasts
<i>tx_bcast_pkts</i>	(Optional) output broadcasts
<i>tx_octets</i>	(Optional) output bytes
<i>rxtx_pkts_64octets</i>	(Optional) all pkts between 0 and 64 bytes
<i>rxtx_pkts_65_127octets</i>	(Optional) all pkts between 65 and 127 bytes
<i>rxtx_pkts_128_255octets</i>	(Optional) all pkts between 128 and 255 bytes
<i>rxtx_pkts_256_511octets</i>	(Optional) all pkts between 256 and 511 bytes
<i>rxtx_pkts_512_1023octets</i>	(Optional) all pkts between 512 and 1023 bytes
<i>rxtx_pkts_1024_1518octets</i>	(Optional) all pkts between 1024 and 1518 bytes
<i>rxtx_pkts_1519_1548octets</i>	(Optional) all pkts between 1519 and 1548 bytes
<i>rx_trunk_frames</i>	(Optional) input trunk pkts
<i>tx_trunk_frames</i>	(Optional) output trunk pkts
<i>rx_drop_events</i>	(Optional) dropped pkts

<i>rxtx_giants</i>	(Optional) giants
<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec
<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary

<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary
<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) IPv4 L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) IPv4 L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) IPv4 L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) IPv4 L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes
<i>eth_l3out_ucastpkts</i>	(Optional) IPv4 L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) IPv4 L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) IPv4 L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) IPv4 L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes
<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_l3avg2_inbytes</i>	(Optional) Load interval 2 L3 average in switched bytes

<i>eth_l3avg2_inpkts</i>	(Optional) Load interval 2 L3 average in switched pkts
<i>eth_l3avg2_outbytes</i>	(Optional) Load interval 2 L3 average out switched bytes
<i>eth_l3avg2_outpkts</i>	(Optional) Load interval 2 L3 average out switched pkts
<i>eth_l3avg3_inbytes</i>	(Optional) Load interval 3 L3 average in switched bytes
<i>eth_l3avg3_inpkts</i>	(Optional) Load interval 3 L3 average in switched pkts
<i>eth_l3avg3_outbytes</i>	(Optional) Load interval 3 L3 average out switched bytes
<i>eth_l3avg3_outpkts</i>	(Optional) Load interval 3 L3 average out switched pkts
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_ingiants</i>	(Optional) giants
<i>eth_ipmcast</i>	(Optional) IP multicast
<i>eth_inhw_switched</i>	(Optional) Input H/W Switched
<i>eth_insw_switched</i>	(Optional) Input S/W Switched
<i>eth_runts</i>	(Optional) runts
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_throtles</i>	(Optional) throttles
<i>eth_inerr</i>	(Optional) input errors
<i>eth_crc</i>	(Optional) CRC
<i>eth_ecc</i>	(Optional) ECC
<i>eth_frame</i>	(Optional) frame
<i>eth_overrun</i>	(Optional) overrun
<i>eth_ignored</i>	(Optional) ignored
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outmcast</i>	(Optional) Multicasts

<i>eth_outucast</i>	(Optional) Unicasts
<i>eth_outgiants</i>	(Optional) giants
<i>eth_inpause</i>	(Optional) pause input
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_underrun</i>	(Optional) underruns
<i>eth_outhw_switched</i>	(Optional) Out H/W Switched
<i>eth_outsw_switched</i>	(Optional) Out S/W Switched
<i>eth_outerr</i>	(Optional) output errors
<i>eth_coll</i>	(Optional) collisions
<i>eth_resets</i>	(Optional) interface resets
<i>eth_babbles</i>	(Optional) babbles
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_deferred</i>	(Optional) deferred
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_outpause</i>	(Optional) PAUSE output
<i>eth_buffail</i>	(Optional) output buffer failures
<i>eth_bufswapped</i>	(Optional) output buffers swapped out
<i>eth_arpdrops</i>	(Optional) arp drops
<i>eth_out_ifdown_drops</i>	(Optional) Output if-down drops
<i>eth_single_coll</i>	(Optional) single collisions
<i>eth_multi_coll</i>	(Optional) multi collisions
<i>eth_excess_coll</i>	(Optional) excessive collisions
<i>eth_jabbers</i>	(Optional) jabbers

<i>eth_shortframe</i>	(Optional) short frames
<i>eth_indiscard</i>	(Optional) discards
<i>eth_bad_encap</i>	(Optional) bad encapsulation
<i>eth_outcrc</i>	(Optional) Output CRC
<i>eth_symbol</i>	(Optional) symbol errors
<i>eth_out_drops</i>	(Optional) output drops
<i>eth_sqetest</i>	(Optional) SQE test
<i>eth_inb64</i>	(Optional) input pkts between 0 and 64 bytes
<i>eth_inb65_127</i>	(Optional) input pkts between 65 and 127 bytes
<i>eth_inb128_255</i>	(Optional) input pkts between 128 and 255 bytes
<i>eth_inb256_511</i>	(Optional) input pkts between 256 and 511 bytes
<i>eth_inb512_1023</i>	(Optional) input pkts between 512 and 1023 bytes
<i>eth_inb1024_1518</i>	(Optional) input pkts between 1024 and 1518 bytes
<i>eth_inb1519_1548</i>	(Optional) input pkts between 1519 and 1548 bytes
<i>eth_intrunk</i>	(Optional) input trunk pkts
<i>eth_outb64</i>	(Optional) output pkts between 0 and 64 bytes
<i>eth_outb65_127</i>	(Optional) output pkts between 65 and 127 bytes
<i>eth_outb128_255</i>	(Optional) output pkts between 128 and 255 bytes
<i>eth_outb256_511</i>	(Optional) output pkts between 256 and 511 bytes
<i>eth_outb512_1023</i>	(Optional) output pkts between 512 and 1023 bytes
<i>eth_outb1024_1518</i>	(Optional) output pkts between 1024 and 1518 bytes
<i>eth_outb1519_1548</i>	(Optional) output pkts between 1519 and 1548 bytes
<i>eth_outtrunk</i>	(Optional) output trunk pkts
<i>eth_bpdu_outlost</i>	(Optional) BPDU output lost
<i>eth_cos0_outlost</i>	(Optional) output pkts
<i>eth_cos1_outlost</i>	(Optional) output pkts
<i>eth_cos2_outlost</i>	(Optional) output pkts
<i>eth_cos3_outlost</i>	(Optional) output pkts
<i>eth_cos4_outlost</i>	(Optional) output pkts

<i>eth_cos5_outlost</i>	(Optional) output pkts
<i>eth_cos6_outlost</i>	(Optional) output pkts
<i>eth_cos7_outlost</i>	(Optional) output pkts
<i>eth_fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>eth_fcoe_in_octets</i>	(Optional) fcoe in octets
<i>eth_fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>eth_fcoe_out_octets</i>	(Optional) fcoe out octets
<i>eth_nfcoe_in_pkts</i>	(Optional) nfcoe in pkts
<i>eth_nfcoe_in_octets</i>	(Optional) nfcoe in octets
<i>eth_nfcoe_out_pkts</i>	(Optional) nfcoe out pkts
<i>eth_nfcoe_out_octets</i>	(Optional) nfcoe out octets
<i>eth_eee_atx_lpi_msec</i>	(Optional) Tx Lpi usec
<i>eth_eee_arcv_lpi_msec</i>	(Optional) Rx Lpi usec
<i>eth_eee_atx_lpi_transitions</i>	(Optional) Tx Lpi requests
<i>eth_eee_arcv_lpi_transitions</i>	(Optional) Rx Lpi indications
<i>eth_phy_ber_count</i>	(Optional) Bit error rate counter
<i>eth_phy_errblks_count</i>	(Optional) Errored blocks counter

Command Mode

- /exec

show interface counters detailed cached

```

show interface <ifeth_ctr_dtl_all> counters detailed cached [ __readonly__ TABLE interface <interface> [
<rx_total_pkts> ][ <tx_total_pkts> ][ <rx_ucast_pkts> ][ <rx_mcast_pkts> ][ <rx_bcast_pkts> ][ <rx_octets> ]
][ <tx_ucast_pkts> ][ <tx_mcast_pkts> ][ <tx_bcast_pkts> ][ <tx_octets> ][ <rxtx_pkts_64octets> ][
<rxtx_pkts_65_127octets> ][ <rxtx_pkts_128_255octets> ][ <rxtx_pkts_256_511octets> ][
<rxtx_pkts_512_1023octets> ][ <rxtx_pkts_1024_1518octets> ][ <rxtx_pkts_1519_1548octets> ][
<rx_trunk_frames> ][ <tx_trunk_frames> ][ <rx_drop_events> ][ <rxtx_giants> ][ <eth_load_interval1_rx> ]
][ <eth_inrate1_bits> ][ <eth_inrate1_pkts> ][ <eth_load_interval1_tx> ][ <eth_outrate1_bits> ][
<eth_outrate1_pkts> ][ <eth_inrate1_summary_bits> ][ <eth_inrate1_summary_pkts> ][
<eth_outrate1_summary_bits> ][ <eth_outrate1_summary_pkts> ][ <eth_load_interval2_rx> ][
<eth_inrate2_bits> ][ <eth_inrate2_pkts> ][ <eth_load_interval2_tx> ][ <eth_outrate2_bits> ][
<eth_outrate2_pkts> ][ <eth_inrate2_summary_bits> ][ <eth_inrate2_summary_pkts> ][
<eth_outrate2_summary_bits> ][ <eth_outrate2_summary_pkts> ][ <eth_load_interval3_rx> ][
<eth_inrate3_bits> ][ <eth_inrate3_pkts> ][ <eth_load_interval3_tx> ][ <eth_outrate3_bits> ][
<eth_outrate3_pkts> ][ <eth_inrate3_summary_bits> ][ <eth_inrate3_summary_pkts> ][
<eth_outrate3_summary_bits> ][ <eth_outrate3_summary_pkts> ][ <eth_l2_ucastpkts> ][ <eth_l2_ucastbytes> ]
][ <eth_l2_mcastpkts> ][ <eth_l2_mcastbytes> ][ <eth_l2_bcastpkts> ][ <eth_l2_bcastbytes> ][
<eth_l3in_ucastpkts> ][ <eth_l3in_ucastbytes> ][ <eth_l3in_mcastpkts> ][ <eth_l3in_mcastbytes> ][
<eth_l3in_bcastpkts> ][ <eth_l3in_bcastbytes> ][ <eth_l3out_ucastpkts> ][ <eth_l3out_ucastbytes> ][
<eth_l3out_mcastpkts> ][ <eth_l3out_mcastbytes> ][ <eth_l3out_bcastpkts> ][ <eth_l3out_bcastbytes> ][
<eth_l3in_routed_pkts> ][ <eth_l3in_routed_bytes> ][ <eth_l3out_routed_pkts> ][ <eth_l3out_routed_bytes> ]
][ <eth_l3avg1_inbytes> ][ <eth_l3avg1_inpkts> ][ <eth_l3avg1_outbytes> ][ <eth_l3avg1_outpkts> ][
<eth_l3avg2_inbytes> ][ <eth_l3avg2_inpkts> ][ <eth_l3avg2_outbytes> ][ <eth_l3avg2_outpkts> ][
<eth_l3avg3_inbytes> ][ <eth_l3avg3_inpkts> ][ <eth_l3avg3_outbytes> ][ <eth_l3avg3_outpkts> ][
<eth_inpkts> ][ <eth_inbytes> ][ <eth_nobuf> ][ <eth_inbcast> ][ <eth_inmcast> ][ <eth_inucast> ][
<eth_ingiants> ][ <eth_ipmcast> ][ <eth_inhw_switched> ][ <eth_insw_switched> ][ <eth_runts> ][
<eth_storm_supp> ][ <eth_throtles> ][ <eth_inerr> ][ <eth_crc> ][ <eth_ecc> ][ <eth_frame> ][
<eth_overrun> ][ <eth_ignored> ][ <eth_watchdog> ][ <eth_outbroadcast> ][ <eth_outmulticast> ][ <eth_outcast> ]
][ <eth_outgiants> ][ <eth_inpause> ][ <eth_dribble> ][ <eth_in_ifdown_drops> ][ <eth_bad_eth> ][
<eth_bad_proto> ][ <eth_outpkts> ][ <eth_outbytes> ][ <eth_underrun> ][ <eth_outhw_switched> ][
<eth_outsw_switched> ][ <eth_outerr> ][ <eth_coll> ][ <eth_resets> ][ <eth_babbles> ][ <eth_latecoll> ]
][ <eth_deferred> ][ <eth_lostcarrier> ][ <eth_nocarrier> ][ <eth_outpause> ][ <eth_buffail> ][
<eth_bufswapped> ][ <eth_arpdrops> ][ <eth_out_ifdown_drops> ][ <eth_single_coll> ][ <eth_multi_coll> ]
][ <eth_excess_coll> ][ <eth_jabbers> ][ <eth_shortframe> ][ <eth_indiscard> ][ <eth_bad_encap> ][
<eth_outcrc> ][ <eth_symbol> ][ <eth_out_drops> ][ <eth_sqetest> ][ <eth_inb64> ][ <eth_inb65_127> ]
][ <eth_inb128_255> ][ <eth_inb256_511> ][ <eth_inb512_1023> ][ <eth_inb1024_1518> ][
<eth_inb1519_1548> ][ <eth_intrunk> ][ <eth_outb64> ][ <eth_outb65_127> ][ <eth_outb128_255> ][
<eth_outb256_511> ][ <eth_outb512_1023> ][ <eth_outb1024_1518> ][ <eth_outb1519_1548> ][
<eth_outtrunk> ][ <eth_bpdu_outlost> ][ <eth_cos0_outlost> ][ <eth_cos1_outlost> ][ <eth_cos2_outlost> ]
][ <eth_cos3_outlost> ][ <eth_cos4_outlost> ][ <eth_cos5_outlost> ][ <eth_cos6_outlost> ][
<eth_cos7_outlost> ][ <eth_fcoe_in_pkts> ][ <eth_fcoe_in_octets> ][ <eth_fcoe_out_pkts> ][
<eth_fcoe_out_octets> ][ <eth_nfcoe_in_pkts> ][ <eth_nfcoe_in_octets> ][ <eth_nfcoe_out_pkts> ][
<eth_nfcoe_out_octets> ][ <eth_eee_atx_lpi_msec> ][ <eth_eee_arcv_lpi_msec> ][
<eth_eee_atx_lpi_transitions> ][ <eth_eee_arcv_lpi_transitions> ][ <eth_phy_ber_count> ][
<eth_phy_errblks_count> ] ]

```

Syntax Description

show	Show running system information
------	---------------------------------

interface	Show interface status and information
<i>ifeth_ctr_dtl_all</i>	Enter interface type and number in module/slot format
counters	Show interface counters
detailed	Show only non-zero counters
cached	everything cached
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>rx_total_pkts</i>	(Optional) total input packets
<i>tx_total_pkts</i>	(Optional) total output packets
<i>rx_ucast_pkts</i>	(Optional) input unicasts
<i>rx_mcast_pkts</i>	(Optional) input multicasts
<i>rx_bcast_pkts</i>	(Optional) input broadcasts
<i>rx_octets</i>	(Optional) input bytes
<i>tx_ucast_pkts</i>	(Optional) output unicasts
<i>tx_mcast_pkts</i>	(Optional) output multicasts
<i>tx_bcast_pkts</i>	(Optional) output broadcasts
<i>tx_octets</i>	(Optional) output bytes
<i>rxtx_pkts_64octets</i>	(Optional) all pkts between 0 and 64 bytes
<i>rxtx_pkts_65_127octets</i>	(Optional) all pkts between 65 and 127 bytes
<i>rxtx_pkts_128_255octets</i>	(Optional) all pkts between 128 and 255 bytes
<i>rxtx_pkts_256_511octets</i>	(Optional) all pkts between 256 and 511 bytes
<i>rxtx_pkts_512_1023octets</i>	(Optional) all pkts between 512 and 1023 bytes
<i>rxtx_pkts_1024_1518octets</i>	(Optional) all pkts between 1024 and 1518 bytes
<i>rxtx_pkts_1519_1548octets</i>	(Optional) all pkts between 1519 and 1548 bytes
<i>rx_trunk_frames</i>	(Optional) input trunk pkts
<i>tx_trunk_frames</i>	(Optional) output trunk pkts
<i>rx_drop_events</i>	(Optional) dropped pkts
<i>rxtx_giants</i>	(Optional) giants

<i>eth_load_interval1_rx</i>	(Optional) interval 1 timer value in sec
<i>eth_inrate1_bits</i>	(Optional) interval 1 input rate bits/sec
<i>eth_inrate1_pkts</i>	(Optional) interval 1 input rate pkts/sec
<i>eth_load_interval1_tx</i>	(Optional) interval 1 timer value in sec
<i>eth_outrate1_bits</i>	(Optional) interval 1 output rate bits/sec
<i>eth_outrate1_pkts</i>	(Optional) interval 1 output rate pkts/sec
<i>eth_inrate1_summary_bits</i>	(Optional) interval 1 input rate bit summary
<i>eth_inrate1_summary_pkts</i>	(Optional) interval 1 input rate pkt summary
<i>eth_outrate1_summary_bits</i>	(Optional) interval 1 output rate bit summary
<i>eth_outrate1_summary_pkts</i>	(Optional) interval 1 output rate pkt summary
<i>eth_load_interval2_rx</i>	(Optional) interval 2 timer value in sec
<i>eth_inrate2_bits</i>	(Optional) interval 2 input rate bits/sec
<i>eth_inrate2_pkts</i>	(Optional) interval 2 input rate pkts/sec
<i>eth_load_interval2_tx</i>	(Optional) interval 2 timer value in sec
<i>eth_outrate2_bits</i>	(Optional) interval 2 output rate bits/sec
<i>eth_outrate2_pkts</i>	(Optional) interval 2 output rate pkts/sec
<i>eth_inrate2_summary_bits</i>	(Optional) interval 2 input rate bit summary
<i>eth_inrate2_summary_pkts</i>	(Optional) interval 2 input rate pkt summary
<i>eth_outrate2_summary_bits</i>	(Optional) interval 2 output rate bit summary
<i>eth_outrate2_summary_pkts</i>	(Optional) interval 2 output rate pkt summary
<i>eth_load_interval3_rx</i>	(Optional) interval 3 timer value in sec
<i>eth_inrate3_bits</i>	(Optional) interval 3 input rate bits/sec
<i>eth_inrate3_pkts</i>	(Optional) interval 3 input rate pkts/sec
<i>eth_load_interval3_tx</i>	(Optional) interval 3 timer value in sec
<i>eth_outrate3_bits</i>	(Optional) interval 3 output rate bits/sec
<i>eth_outrate3_pkts</i>	(Optional) interval 3 output rate pkts/sec
<i>eth_inrate3_summary_bits</i>	(Optional) interval 3 input rate bit summary
<i>eth_inrate3_summary_pkts</i>	(Optional) interval 3 input rate pkt summary
<i>eth_outrate3_summary_bits</i>	(Optional) interval 3 output rate bit summary

<i>eth_outrate3_summary_pkts</i>	(Optional) interval 3 output rate pkt summary
<i>eth_l2_ucastpkts</i>	(Optional) L2 switched ucast pkts
<i>eth_l2_ucastbytes</i>	(Optional) L2 switched ucast bytes
<i>eth_l2_mcastpkts</i>	(Optional) L2 switched mcast pkts
<i>eth_l2_mcastbytes</i>	(Optional) L2 switched mcast bytes
<i>eth_l2_bcastpkts</i>	(Optional) L2 switched bcast pkts
<i>eth_l2_bcastbytes</i>	(Optional) L2 switched bcast bytes
<i>eth_l3in_ucastpkts</i>	(Optional) IPv4 L3 in switched ucast pkts
<i>eth_l3in_ucastbytes</i>	(Optional) IPv4 L3 in switched ucast bytes
<i>eth_l3in_mcastpkts</i>	(Optional) IPv4 L3 in switched mcast pkts
<i>eth_l3in_mcastbytes</i>	(Optional) IPv4 L3 in switched mcast bytes
<i>eth_l3in_bcastpkts</i>	(Optional) L3 in switched bcast pkts
<i>eth_l3in_bcastbytes</i>	(Optional) L3 in switched bcast bytes
<i>eth_l3out_ucastpkts</i>	(Optional) IPv4 L3 out switched ucast pkts
<i>eth_l3out_ucastbytes</i>	(Optional) IPv4 L3 out switched ucast bytes
<i>eth_l3out_mcastpkts</i>	(Optional) IPv4 L3 out switched mcast pkts
<i>eth_l3out_mcastbytes</i>	(Optional) IPv4 L3 out switched mcast bytes
<i>eth_l3out_bcastpkts</i>	(Optional) L3 out switched bcast pkts
<i>eth_l3out_bcastbytes</i>	(Optional) L3 out switched bcast bytes
<i>eth_l3in_routed_pkts</i>	(Optional) L3 in routed pkts
<i>eth_l3in_routed_bytes</i>	(Optional) L3 in routed bytes
<i>eth_l3out_routed_pkts</i>	(Optional) L3 out routed pkts
<i>eth_l3out_routed_bytes</i>	(Optional) L3 out routed bytes
<i>eth_l3avg1_inbytes</i>	(Optional) Load interval 1 L3 average in switched bytes
<i>eth_l3avg1_inpkts</i>	(Optional) Load interval 1 L3 average in switched pkts
<i>eth_l3avg1_outbytes</i>	(Optional) Load interval 1 L3 average out switched bytes
<i>eth_l3avg1_outpkts</i>	(Optional) Load interval 1 L3 average out switched pkts
<i>eth_l3avg2_inbytes</i>	(Optional) Load interval 2 L3 average in switched bytes
<i>eth_l3avg2_inpkts</i>	(Optional) Load interval 2 L3 average in switched pkts

<i>eth_l3avg2_outbytes</i>	(Optional) Load interval 2 L3 average out switched bytes
<i>eth_l3avg2_outpkts</i>	(Optional) Load interval 2 L3 average out switched pkts
<i>eth_l3avg3_inbytes</i>	(Optional) Load interval 3 L3 average in switched bytes
<i>eth_l3avg3_inpkts</i>	(Optional) Load interval 3 L3 average in switched pkts
<i>eth_l3avg3_outbytes</i>	(Optional) Load interval 3 L3 average out switched bytes
<i>eth_l3avg3_outpkts</i>	(Optional) Load interval 3 L3 average out switched pkts
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_nobuf</i>	(Optional) No buffer received
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_ingiants</i>	(Optional) giants
<i>eth_ipmcast</i>	(Optional) IP multicast
<i>eth_inhw_switched</i>	(Optional) Input H/W Switched
<i>eth_insw_switched</i>	(Optional) Input S/W Switched
<i>eth_runs</i>	(Optional) runs
<i>eth_storm_supp</i>	(Optional) storm suppression
<i>eth_throtles</i>	(Optional) throttles
<i>eth_inerr</i>	(Optional) input errors
<i>eth_crc</i>	(Optional) CRC
<i>eth_ecc</i>	(Optional) ECC
<i>eth_frame</i>	(Optional) frame
<i>eth_overrun</i>	(Optional) overrun
<i>eth_ignored</i>	(Optional) ignored
<i>eth_watchdog</i>	(Optional) watchdog
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outucast</i>	(Optional) Unicasts

<i>eth_outgiants</i>	(Optional) giants
<i>eth_inpause</i>	(Optional) pause input
<i>eth_dribble</i>	(Optional) input packets with dribble condition
<i>eth_in_ifdown_drops</i>	(Optional) Input if-down drops
<i>eth_bad_eth</i>	(Optional) bad ether type drop
<i>eth_bad_proto</i>	(Optional) bad protocol drops
<i>eth_outpkts</i>	(Optional) packets output
<i>eth_outbytes</i>	(Optional) bytes output
<i>eth_underrun</i>	(Optional) underruns
<i>eth_outhw_switched</i>	(Optional) Out H/W Switched
<i>eth_outsw_switched</i>	(Optional) Out S/W Switched
<i>eth_outerr</i>	(Optional) output errors
<i>eth_coll</i>	(Optional) collisions
<i>eth_resets</i>	(Optional) interface resets
<i>eth_babbles</i>	(Optional) babbles
<i>eth_latecoll</i>	(Optional) late collision
<i>eth_deferred</i>	(Optional) deferred
<i>eth_lostcarrier</i>	(Optional) lost carrier
<i>eth_nocarrier</i>	(Optional) no carrier
<i>eth_outpause</i>	(Optional) PAUSE output
<i>eth_buffail</i>	(Optional) output buffer failures
<i>eth_bufswapped</i>	(Optional) output buffers swapped out
<i>eth_arpdrops</i>	(Optional) arp drops
<i>eth_out_ifdown_drops</i>	(Optional) Output if-down drops
<i>eth_single_coll</i>	(Optional) single collisions
<i>eth_multi_coll</i>	(Optional) multi collisions
<i>eth_excess_coll</i>	(Optional) excessive collisions
<i>eth_jabbers</i>	(Optional) jabbers
<i>eth_shortframe</i>	(Optional) short frames

<i>eth_indiscard</i>	(Optional) discards
<i>eth_bad_encap</i>	(Optional) bad encapsulation
<i>eth_outcrc</i>	(Optional) Output CRC
<i>eth_symbol</i>	(Optional) symbol errors
<i>eth_out_drops</i>	(Optional) output drops
<i>eth_sqetest</i>	(Optional) SQE test
<i>eth_inb64</i>	(Optional) input pkts between 0 and 64 bytes
<i>eth_inb65_127</i>	(Optional) input pkts between 65 and 127 bytes
<i>eth_inb128_255</i>	(Optional) input pkts between 128 and 255 bytes
<i>eth_inb256_511</i>	(Optional) input pkts between 256 and 511 bytes
<i>eth_inb512_1023</i>	(Optional) input pkts between 512 and 1023 bytes
<i>eth_inb1024_1518</i>	(Optional) input pkts between 1024 and 1518 bytes
<i>eth_inb1519_1548</i>	(Optional) input pkts between 1519 and 1548 bytes
<i>eth_intrunk</i>	(Optional) input trunk pkts
<i>eth_outb64</i>	(Optional) output pkts between 0 and 64 bytes
<i>eth_outb65_127</i>	(Optional) output pkts between 65 and 127 bytes
<i>eth_outb128_255</i>	(Optional) output pkts between 128 and 255 bytes
<i>eth_outb256_511</i>	(Optional) output pkts between 256 and 511 bytes
<i>eth_outb512_1023</i>	(Optional) output pkts between 512 and 1023 bytes
<i>eth_outb1024_1518</i>	(Optional) output pkts between 1024 and 1518 bytes
<i>eth_outb1519_1548</i>	(Optional) output pkts between 1519 and 1548 bytes
<i>eth_outtrunk</i>	(Optional) output trunk pkts
<i>eth_bpdu_outlost</i>	(Optional) BPDU output lost
<i>eth_cos0_outlost</i>	(Optional) output pkts
<i>eth_cos1_outlost</i>	(Optional) output pkts
<i>eth_cos2_outlost</i>	(Optional) output pkts
<i>eth_cos3_outlost</i>	(Optional) output pkts
<i>eth_cos4_outlost</i>	(Optional) output pkts
<i>eth_cos5_outlost</i>	(Optional) output pkts

<i>eth_cos6_outlost</i>	(Optional) output pkts
<i>eth_cos7_outlost</i>	(Optional) output pkts
<i>eth_fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>eth_fcoe_in_octets</i>	(Optional) fcoe in octets
<i>eth_fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>eth_fcoe_out_octets</i>	(Optional) fcoe out octets
<i>eth_nfcoe_in_pkts</i>	(Optional) nfcoe in pkts
<i>eth_nfcoe_in_octets</i>	(Optional) nfcoe in octets
<i>eth_nfcoe_out_pkts</i>	(Optional) nfcoe out pkts
<i>eth_nfcoe_out_octets</i>	(Optional) nfcoe out octets
<i>eth_eee_atx_lpi_msec</i>	(Optional) Tx Lpi usec
<i>eth_eee_arcv_lpi_msec</i>	(Optional) Rx Lpi usec
<i>eth_eee_atx_lpi_transitions</i>	(Optional) Tx Lpi requests
<i>eth_eee_arcv_lpi_transitions</i>	(Optional) Rx Lpi indications
<i>eth_phy_ber_count</i>	(Optional) Bit error rate counter
<i>eth_phy_errblks_count</i>	(Optional) Errored blocks counter

Command Mode

- /exec

show interface counters details

```
show interface <ifid_ctr_det> counters details [ __readonly__ TABLE_interface <interface> [ <fcoe_in_pkts>
] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_ctr_det</i>	Enter interface type and number in module/slot format
counters	Show interface counters
details	Show interface counters in detail
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>fcoe_in_octets</i>	(Optional) fcoe in octets
<i>fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>fcoe_out_octets</i>	(Optional) fcoe out octets

Command Mode

- /exec

show interface counters details

```
show interface <ifid_ctrs_det2> counters details [ __readonly__ TABLE_ifid_counters [ <sfp> <in_frames>
<in_bytes> <class_2_frames> <class_2_in_bytes> <class_2_in_discards> <class_2_in_f_bsy_frames>
<class_2_in_f_rgt_frames> <class_2_in_port_reject_frames> <class_3_frames> <class_3_bytes_rcvd>
<class_f_frames> <class_f_bytes_rcvd> <class_f_in_discards> <class_f_errors_rcvd> <class_f_out_discards>
<class_f_errors_trans> <out_frames> <out_bytes> <class_2_out_frames> <class_2_bytes_trans>
<class_3_out_frames> <class_3_bytes_trans> <class_3_out_discards> <class_f_out_frames>
<class_f_bytes_trans> <class_f_discards> <muticast_rcvd> <multicast_trans> <broadcast_rcvd>
<broadcast_trans> <unicast_rcvd> <unicast_trans> <timeout_discards> <credit_loss> <link_faliures>
<sync_loss> <signal_loss> <prm_seq_pro_err> <inv_trans_err> <inv_crc> <delim_err> <addr_iden_err>
<link_reset_rcvd> <link_reset_trans> <off_seq_err_rcvd> <off_seq_err_trans> <frames_rcvd_short>
<frames_rcvd_long> <txwait> <frames_rcvd_greater> <frame_rcvd_short_header> <link_reset_resp_rcvd>
<link_reset_resp_trans> <non_oper_seq_rcvd> <non_oper_seq_trans> <frag_frames_rcvd> <frames_eof_abort>
<unknown_class_frames_rcvd> <8b10b_disparity_err> <frames_discard> <ex_link_param_sw_fab> [
<in_link_ser_req_faliures> ] <b2b_credits_transmit> <b2b_credits_receive> <eisl_frames> <framing_err>
<f8_lip_seq_err_rcvd> <f8_lip_seq_err_issued> <non_f8_lip_seq_err_rcvd> <non_f8_lip_seq_err_issued>
[ <fec_corrected> ] [ <fec_uncorrected> ] ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_ctrs_det2</i>	Enter interface type and number in module/slot format
counters	Show interface counters
details	Show interface counters in detail
<u>__readonly__</u>	(Optional)
TABLE_ifid_counters	(Optional) show interface counters
<i>sfp</i>	(Optional) SFP
<i>in_frames</i>	(Optional) in frames
<i>in_bytes</i>	(Optional) in bytes
<i>class_2_frames</i>	(Optional) Class 2 frames
<i>class_2_in_bytes</i>	(Optional) Class 2 bytes received
<i>class_2_in_discards</i>	(Optional) Class 2 discards received
<i>class_2_in_f_bsy_frames</i>	(Optional) Class 2 F_BSY frames received
<i>class_2_in_f_rgt_frames</i>	(Optional) Class 2 F_RGT frames
<i>class_2_in_port_reject_frames</i>	(Optional) Class 2 port reject frames
<i>class_3_frames</i>	(Optional) Class 3 frames

<i>class_3_bytes_rcv</i>	(Optional) Class 3 bytes received
<i>class_f_frames</i>	(Optional) Class f frames
<i>class_f_bytes_rcv</i>	(Optional) Class F bytes received
<i>class_f_in_discards</i>	(Optional) Class F in discards
<i>class_f_errors_rcvd</i>	(Optional) Class F errors received
<i>class_f_out_discards</i>	(Optional) Class F out discards
<i>class_f_errors_trans</i>	(Optional) Class F errors transmitted
<i>out_frames</i>	(Optional) Out frames
<i>out_bytes</i>	(Optional) Out bytes
<i>class_2_out_frames</i>	(Optional) Class 2 frames transmitted
<i>class_2_bytes_trans</i>	(Optional) Class 2 bytes transmitted
<i>class_3_out_frames</i>	(Optional) Class 3 frames transmitted
<i>class_3_bytes_trans</i>	(Optional) Class 3 bytes transmitted
<i>class_3_out_discards</i>	(Optional) Class 3 out discards
<i>class_f_out_frames</i>	(Optional) Class F out frames
<i>class_f_bytes_trans</i>	(Optional) Class F bytes transmitted
<i>class_f_discards</i>	(Optional) Class F discards
<i>multicast_rcvd</i>	(Optional) Multicast received
<i>multicast_trans</i>	(Optional) Muticast transmitted
<i>broadcast_rcvd</i>	(Optional) Broadcast received
<i>broadcast_trans</i>	(Optional) Broadcast transmitted
<i>unicast_rcvd</i>	(Optional) Unicast received
<i>unicast_trans</i>	(Optional) Unicast transmitted
<i>timeout_discards</i>	(Optional) timeout discards
<i>credit_loss</i>	(Optional) credit loss
<i>link_faliures</i>	(Optional) Link faliures
<i>sync_loss</i>	(Optional) Sync Loss
<i>signal_loss</i>	(Optional) Signal Loss
<i>prm_seq_pro_err</i>	(Optional) primitive sequence protocol errors

<i>inv_trans_err</i>	(Optional) invalid transmission errors
<i>inv_crc</i>	(Optional) Invalid crc
<i>delim_err</i>	(Optional) Delimiter Errors
<i>addr_iden_err</i>	(Optional) Address Identification errors
<i>link_reset_rcvd</i>	(Optional) link reset received
<i>link_reset_trans</i>	(Optional) link reset transmitted
<i>off_seq_err_rcvd</i>	(Optional) Offline sequence error received
<i>off_seq_err_trans</i>	(Optional) Offline sequence Error transmitted
<i>frames_rcvd_short</i>	(Optional) frames received that are shorter than the minimum allowable frame length regardless of the CRC/FCS error
<i>frames_rcvd_long</i>	(Optional) frames received that are longer than the minimum allowable frame length regardless of the CRC/FCS error
<i>txwait</i>	(Optional) TXwait
<i>frames_rcvd_greater</i>	(Optional) frames received with length greater than what was agreed to in FLOGI/PLOGI
<i>frame_rcvd_short_header</i>	(Optional) frames received with length less than the minimum indicated by the frame header
<i>link_reset_resp_rcvd</i>	(Optional) Link reset responses received
<i>link_reset_resp_trans</i>	(Optional) Link reset responses transmitted
<i>non_oper_seq_rcvd</i>	(Optional) Non operational sequence received
<i>non_oper_seq_trans</i>	(Optional) Non operational sequence transmitted
<i>frag_frames_rcvd</i>	(Optional) fragmented frames received
<i>frames_eof_abort</i>	(Optional) frames EOF abort
<i>unknown_class_frames_rcvd</i>	(Optional) unknown class frames received
<i>8b10b_disparity_err</i>	(Optional) 8b10b disparity errors
<i>frames_discard</i>	(Optional) frames discard
<i>ex_link_param_sw_fab</i>	(Optional) external link parameters switch fabric
<i>in_link_ser_req_faliures</i>	(Optional) internal link serial request faliures
<i>b2b_credits_transmit</i>	(Optional) B2B credits transmit
<i>b2b_credits_receive</i>	(Optional) B2B credits receive

<i>eisl_frames</i>	(Optional) EISL frames
<i>framing_err</i>	(Optional) Framing Error
<i>f8_lip_seq_err_rcvd</i>	(Optional) f8 LIP sequence error received
<i>f8_lip_seq_err_issued</i>	(Optional) f8 LIP sequence error issued
<i>non_f8_lip_seq_err_rcvd</i>	(Optional) non f8 LIP sequence error received
<i>non_f8_lip_seq_err_issued</i>	(Optional) non f8 LIP sequence error issued
<i>fec_corrected</i>	(Optional) fec corrected blocks
<i>fec_uncorrected</i>	(Optional) fec uncorrected blocks

Command Mode

- /exec

show interface counters errors

show interface <loop_ctr_errs> counters errors

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>loop_ctr_errs</i>	Enter interface type and number in module/slot format
counters	Show interface counters
errors	Show interface error counters

Command Mode

- /exec

show interface counters errors

```
show interface <ifeth_ctr_errs> counters errors [ snmp ] [ __readonly__ TABLE_interface <interface> [
<eth_align_err> ] [ <eth_fcs_err> ] [ <eth_xmit_err> ] [ <eth_rcv_err> ] [ <eth_undersize> ] [ <eth_outdisc>
] [ <eth_single_col> ] [ <eth_multi_col> ] [ <eth_late_col> ] [ <eth_excess_col> ] [ <eth_carri_sen> ] [
<eth_runts> ] [ <eth_giants> ] [ <eth_sqetest_err> ] [ <eth_deferred_tx> ] [ <eth_inmactx_err> ] [
<eth_inmacrx_err> ] [ <eth_symbol_err> ] [ <eth_indisc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr_errs</i>	Enter interface type and number in module/slot format
counters	Show interface counters
errors	Show interface error counters
snmp	(Optional) Show SNMP MIB values
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>eth_align_err</i>	(Optional) Align error
<i>eth_fcs_err</i>	(Optional) FCS error
<i>eth_xmit_err</i>	(Optional) Transmit error
<i>eth_rcv_err</i>	(Optional) Receive error
<i>eth_undersize</i>	(Optional) Undersize
<i>eth_outdisc</i>	(Optional) Out discard
<i>eth_single_col</i>	(Optional) Single collision
<i>eth_multi_col</i>	(Optional) Multiple collision
<i>eth_late_col</i>	(Optional) Late collision
<i>eth_excess_col</i>	(Optional) Excess collision
<i>eth_carri_sen</i>	(Optional) Carrier sense
<i>eth_runts</i>	(Optional) Runts
<i>eth_giants</i>	(Optional) Giants
<i>eth_sqetest_err</i>	(Optional) SQETest error

<i>eth_deferred_tx</i>	(Optional) Deferred tx
<i>eth_inmactx_err</i>	(Optional) In MAC tx
<i>eth_inmacrx_err</i>	(Optional) In MAC rx
<i>eth_symbol_err</i>	(Optional) Symbol error
<i>eth_indisc</i>	(Optional) In discards

Command Mode

- /exec

show interface counters errors

```
show interface counters errors [ module <module> ] [ non-zero ] [ __readonly__ TABLE_interface <interface>
[ <eth_align_err> ] [ <eth_fcs_err> ] [ <eth_xmit_err> ] [ <eth_rcv_err> ] [ <eth_undersize> ] [ <eth_outdisc>
] [ <eth_single_col> ] [ <eth_multi_col> ] [ <eth_late_col> ] [ <eth_excess_col> ] [ <eth_carri_sen> ] [
<eth_runs> ] [ <eth_giants> ] [ <eth_sqetest_err> ] [ <eth_deferred_tx> ] [ <eth_inmactx_err> ] [
<eth_inmacrx_err> ] [ <eth_symbol_err> ] [ <eth_indisc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
errors	Show interface error counters
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
non-zero	(Optional) Display only the non-zero error values
<u>__readonly__</u>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>eth_align_err</i>	(Optional) Align error
<i>eth_fcs_err</i>	(Optional) FCS error
<i>eth_xmit_err</i>	(Optional) Transmit error
<i>eth_rcv_err</i>	(Optional) Receive error
<i>eth_undersize</i>	(Optional) Undersize
<i>eth_outdisc</i>	(Optional) Out discard
<i>eth_single_col</i>	(Optional) Single collision
<i>eth_multi_col</i>	(Optional) Multiple collision
<i>eth_late_col</i>	(Optional) Late collision
<i>eth_excess_col</i>	(Optional) Excess collision
<i>eth_carri_sen</i>	(Optional) Carrier sense
<i>eth_runs</i>	(Optional) Runts
<i>eth_giants</i>	(Optional) Giants

<i>eth_sqetest_err</i>	(Optional) SQETest error
<i>eth_deferred_tx</i>	(Optional) Deferred tx
<i>eth_inmactx_err</i>	(Optional) In MAC tx
<i>eth_inmacrx_err</i>	(Optional) In MAC rx
<i>eth_symbol_err</i>	(Optional) Symbol error
<i>eth_indisc</i>	(Optional) In discards

Command Mode

- /exec

show interface counters snmp

```
show interface counters snmp [ module <module> ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ]
[ <eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] } } { TABLE_tx_counters
<interface_tx> [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast>
] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] } }
```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
snmp	Show SNMP MIB values
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
<i>__readonly__</i>	(Optional) Read Only
TABLE_rx_counters	(Optional) show Rx counters
<i>interface_rx</i>	(Optional) Interface index
<i>eth_inpkts</i>	(Optional) Packets input
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_inucast</i>	(Optional) Unicasts
<i>eth_inmcast</i>	(Optional) Multicasts
<i>eth_inbcast</i>	(Optional) Broadcasts
<i>eth_l3in_bytes</i>	(Optional) L3 Rx bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 Rx Unicast pkts
<i>eth_l3in_mcastpkts</i>	(Optional) L3 Rx Multicast pkts
<i>eth_l3in_bcastpkts</i>	(Optional) L3 Rx Broadcast pkts
TABLE_tx_counters	(Optional) show Tx counters
<i>interface_tx</i>	(Optional) Interface index
<i>eth_outpkts</i>	(Optional) Packets output
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts

<i>eth_outmcast</i>	(Optional) Multicasts
<i>eth_outbcast</i>	(Optional) Broadcasts
<i>eth_l3out_bytes</i>	(Optional) L3 Tx bytes
<i>eth_l3out_ucastpkts</i>	(Optional) L3 Tx Unicast pkts
<i>eth_l3out_mcastpkts</i>	(Optional) L3 Tx Multicast pkts
<i>eth_l3out_bcastpkts</i>	(Optional) L3 Tx Broadcast pkts

Command Mode

- /exec

show interface counters snmp

```
show interface <ifeth_ctr> counters snmp [ __readonly__ { TABLE_rx_counters <interface_rx> [ <eth_inbytes>
] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [ <eth_l3in_ucastpkts> ] [
<eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] } { TABLE_tx_counters <interface_tx> [ <eth_outbytes>
] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ]
[ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr</i>	Enter interface type and number in module/slot format
counters	Show interface counters
snmp	Show SNMP MIB values
<u>__readonly__</u>	(Optional) Read Only
TABLE_rx_counters	(Optional) show Rx counters
<i>interface_rx</i>	(Optional) Interface index rx
<i>eth_inbytes</i>	(Optional) Bytes input
<i>eth_inucast</i>	(Optional) Unicasts input
<i>eth_inmcast</i>	(Optional) Multicasts input
<i>eth_inbcast</i>	(Optional) Broadcasts input
<i>eth_l3in_bytes</i>	(Optional) L3 Rx bytes
<i>eth_l3in_ucastpkts</i>	(Optional) L3 Rx Unicast pkts
<i>eth_l3in_mcastpkts</i>	(Optional) L3 Rx Multicast pkts
<i>eth_l3in_bcastpkts</i>	(Optional) L3 Rx Broadcast pkts
TABLE_tx_counters	(Optional) show Tx counters
<i>interface_tx</i>	(Optional) Interface index tx
<i>eth_outbytes</i>	(Optional) Bytes output
<i>eth_outucast</i>	(Optional) Unicasts output
<i>eth_outmcast</i>	(Optional) Multicasts output
<i>eth_outbcast</i>	(Optional) Broadcasts output
<i>eth_l3out_bytes</i>	(Optional) L3 Tx bytes

<i>eth_l3out_ucastpkts</i>	(Optional) L3 Tx Unicast pkts
<i>eth_l3out_mcastpkts</i>	(Optional) L3 Tx Multicast pkts
<i>eth_l3out_bcastpkts</i>	(Optional) L3 Tx Broadcast pkts

Command Mode

- /exec

show interface counters storm-control

```
show interface <ifeth_ctr_stm_ctrl> counters storm-control [ __readonly__ TABLE_interface <interface>
<eth_ucast_supp> <eth_mcast_supp> <eth_bcast_supp> <eth_total_supp> <supp_action> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr_stm_ctrl</i>	Enter interface type and number in module/slot format
counters	Show interface counters
storm-control	Show interface storm-control counters
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>eth_ucast_supp</i>	(Optional) Unicast suppression percentage
<i>eth_mcast_supp</i>	(Optional) Multicast suppression percentage
<i>eth_bcast_supp</i>	(Optional) Broadcast suppression percentage
<i>eth_total_supp</i>	(Optional) Total discarded due to suppression
<i>supp_action</i>	(Optional) Action to be taken on suppression

Command Mode

- /exec

show interface counters storm-control

```
show interface counters storm-control [ module <module> ] [ __readonly__ TABLE_interface <interface>
<eth_ucast_supp> <eth_mcast_supp> <eth_bcast_supp> <eth_total_supp> <supp_action> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
storm-control	Show interface storm-control counters
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>eth_ucast_supp</i>	(Optional) Unicast suppression percentage
<i>eth_mcast_supp</i>	(Optional) Multicast suppression percentage
<i>eth_bcast_supp</i>	(Optional) Broadcast suppression percentage
<i>eth_total_supp</i>	(Optional) Total discarded due to suppression
<i>supp_action</i>	(Optional) Action to be taken on suppression

Command Mode

- /exec

show interface counters table

show interface counters table [verbose]

Syntax Description

show	Show running system information
interface	Show interface status and information
counters	Show interface counters
table	format counters in a table
verbose	(Optional) show errors counts after counters

Command Mode

- /exec

show interface counters trunk

```
show interface <ifeth_ctr_trnk> counters trunk [ __readonly__ TABLE_interface <interface> [
<eth_trunk_frames_tx> ] [ <eth_trunk_frames_rx> ] [ <eth_wrong_encap> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_ctr_trnk</i>	Enter interface type and number in module/slot format
counters	Show interface counters
trunk	Show interface trunk counters
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
<i>TABLE_interface</i>	(Optional) show interface
<i>eth_trunk_frames_tx</i>	(Optional) Trunk frame transmitted
<i>eth_trunk_frames_rx</i>	(Optional) Trunk frames received
<i>eth_wrong_encap</i>	(Optional) Wrong encapsulation

Command Mode

- /exec

show interface dampening

```
show interface dampening [ __readonly__ { [ TABLE_vrf_dampen <vrf> [ TABLE_interface_dampen
<interface> <Flaps> <Penalty> <Supp> <ReuseTm> <HalfL> <ReuseV> <SuppV> <MaxSTm> <MaxP>
<Restart> ] ] } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
dampening	Show interface dampening info
__readonly__	(Optional) Read Only
TABLE_vrf_dampen	(Optional) show interface vrf dampening
vrf	(Optional) Vrf membership
TABLE_interface_dampen	(Optional) show interface dampening
interface	(Optional) Interface index
Flaps	(Optional) Number of times that an interface has flapped
Penalty	(Optional) Accumulated penalty
Supp	(Optional) Indicates if the interface is dampened
ReuseTm	(Optional) Reuse timer
HalfL	(Optional) Half-life counter
ReuseV	(Optional) Reuse threshold timer
SuppV	(Optional) Suppress threshold
MaxSTm	(Optional) Maximum suppress
MaxP	(Optional) Maximum penalty
Restart	(Optional) Restart timer

Command Mode

- /exec

show interface debounce

show interface debounce [*__readonly__* *TABLE_interface* <interface> <debounce> <debounce_val>]

Syntax Description

show	Show running system information
interface	Show interface status and information
debounce	Show interface debounce time information
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
<i>TABLE_interface</i>	(Optional) show interface
<i>debounce</i>	(Optional) Debounce time
<i>debounce_val</i>	(Optional) Value(ms)

Command Mode

- /exec

show interface debounce

```
show interface <ifeth_dbnc> debounce [ __readonly__ TABLE_interface <interface> <debounce>
<debounce_val> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_dbnc</i>	Enter interface type and number in module/slot format
debounce	Show interface debounce time information
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>debounce</i>	(Optional) Debounce time
<i>debounce_val</i>	(Optional) Value(ms)

Command Mode

- /exec

show interface description

```
show interface <ifid_mgmt_loop> description [ __readonly__ TABLE_interface <interface> [ <state> ] [
<protocol> ] [ <desc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_mgmt_loop</i>	Enter interface type and number in module/slot format
description	Show interface description
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>protocol</i>	(Optional) Protocol
<i>desc</i>	(Optional) Description

Command Mode

- /exec

show interface description

show interface <ifid_desc1> description [__readonly__ TABLE_interface <interface_fc> [<desc_fc>]]

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_desc1</i>	Enter interface type and number in module/slot format
description	Show interface description
__readonly__	(Optional) Read Only
<i>interface_fc</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>desc_fc</i>	(Optional) Description

Command Mode

- /exec

show interface description

show interface <ifid> description [__readonly__ <start> <if_index> <LINE>]

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
description	Interface specific description
__readonly__	(Optional) Read Only
<i>start</i>	(Optional) Start
<i>if_index</i>	(Optional) Interface
<i>LINE</i>	(Optional) Description

Command Mode

- /exec

show interface description

```
show interface description [ __readonly__ TABLE_interface <interface> [ <state> ] [ <type> ] [ <speed> ] [ <protocol> ] [ <desc> ] ]
```

Syntax Description

<i>show</i>	Show running system information
<i>interface</i>	Show interface status and information
<i>description</i>	Show interface description
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
<i>TABLE_interface</i>	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>type</i>	(Optional) Type
<i>speed</i>	(Optional) Speed
<i>protocol</i>	(Optional) Protocol
<i>desc</i>	(Optional) Description

Command Mode

- /exec

show interface description

```
show interface <ifid_eth> description [ __readonly__ TABLE_interface <interface> [ <state> ] [ <type> ] [ <speed> ] [ <protocol> ] [ <desc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_eth</i>	Enter interface type and number in module/slot format
description	Show interface description
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>type</i>	(Optional) Type
<i>speed</i>	(Optional) Speed
<i>protocol</i>	(Optional) Protocol
<i>desc</i>	(Optional) Description

Command Mode

- /exec

show interface description

```
show interface <iftun_desc> description [ __readonly__ TABLE_interface <interface> <state> <protocol>
<desc> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>iftun_desc</i>	Enter tunnel interface number
description	Show interface description
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>protocol</i>	(Optional) Protocol
<i>desc</i>	(Optional) Description

Command Mode

- /exec

show interface description

```
show interface <ifrange> description [ __readonly__ TABLE_interface <interface> <state> <protocol> <desc> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter tunnel interface number
description	Show interface description
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>protocol</i>	(Optional) Protocol
<i>desc</i>	(Optional) Description

Command Mode

- /exec

show interface description

```
show interface <ifrange> description [ __readonly__ TABLE_interface <interface> <state> <protocol> <desc> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter tunnel interface number
description	Show interface description
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>state</i>	(Optional) Interface state
<i>protocol</i>	(Optional) Protocol
<i>desc</i>	(Optional) Description

Command Mode

- /exec

show interface detail-counters

```
show interface detail-counters [ __readonly__ [ { TABLE_counters <sfp> <in_frames> <in_bytes>
<class_2_frames> <class_2_in_bytes> <class_2_in_discards> <class_2_in_f_bsy_frames>
<class_2_in_f_rgt_frames> <class_2_in_port_reject_frames> <class_3_frames> <class_3_bytes_rcvd>
<class_f_frames> <class_f_bytes_rcvd> <class_f_in_discards> <class_f_errors_rcvd> <class_f_out_discards>
<class_f_errors_trans> <out_frames> <out_bytes> <class_2_out_frames> <class_2_bytes_trans>
<class_3_out_frames> <class_3_bytes_trans> <class_3_out_discards> <class_f_out_frames>
<class_f_bytes_trans> <class_f_discards> <muticast_rcvd> <multicast_trans> <broadcast_rcvd>
<broadcast_trans> <unicast_rcvd> <unicast_trans> <timeout_discards> <credit_loss> <link_faliures>
<sync_loss> <signal_loss> <prm_seq_pro_err> <inv_trans_err> <inv_crc> <delim_err> <addr_iden_err>
<link_reset_rcvd> <link_reset_trans> <off_seq_err_rcvd> <off_seq_err_trans> <frames_rcvd_short>
<frames_rcvd_long> <txwait> <frames_rcvd_greater> <frame_rcvd_short_header> <link_reset_resp_rcvd>
<link_reset_resp_trans> <non_oper_seq_rcvd> <non_oper_seq_trans> <frag_frames_rcvd> <frames_eof_abort>
<unknown_class_frames_rcvd> <8b10b_disparity_err> <frames_discard> <ex_link_param_sw_fab> [
<in_link_ser_req_faliures> ] <b2b_credits_transmit> <b2b_credits_receive> <eisl_frames> <framing_err>
<f8_lip_seq_err_rcvd> <f8_lip_seq_err_issued> <non_f8_lip_seq_err_rcvd> <non_f8_lip_seq_err_issued>
[ <fec_corrected> ] [ <fec_uncorrected> ] } ] [ { TABLE_interface <interface> [ <fcoe_in_pkts> ] [
<fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ] } ] ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
detail-counters	Show interface counters in detail
<i>__readonly__</i>	(Optional)
<i>TABLE_counters</i>	(Optional) show interface counters
<i>sfp</i>	(Optional) SFP
<i>in_frames</i>	(Optional) in frames
<i>in_bytes</i>	(Optional) in bytes
<i>class_2_frames</i>	(Optional) Class 2 frames
<i>class_2_in_bytes</i>	(Optional) Class 2 bytes received
<i>class_2_in_discards</i>	(Optional) Class 2 discards received
<i>class_2_in_f_bsy_frames</i>	(Optional) Class 2 F_BSY frames received
<i>class_2_in_f_rgt_frames</i>	(Optional) Class 2 F_RGT frames
<i>class_2_in_port_reject_frames</i>	(Optional) Class 2 port reject frames
<i>class_3_frames</i>	(Optional) Class 3 frames
<i>class_3_bytes_rcvd</i>	(Optional) Class 3 bytes received

<i>class_f_frames</i>	(Optional) Class f frames
<i>class_f_bytes_rcvd</i>	(Optional) Class F bytes received
<i>class_f_in_discards</i>	(Optional) Class F in discards
<i>class_f_errors_rcvd</i>	(Optional) Class F errors received
<i>class_f_out_discards</i>	(Optional) Class F out discards
<i>class_f_errors_trans</i>	(Optional) Class F errors transmitted
<i>out_frames</i>	(Optional) Out frames
<i>out_bytes</i>	(Optional) Out bytes
<i>class_2_out_frames</i>	(Optional) Class 2 frames transmitted
<i>class_2_bytes_trans</i>	(Optional) Class 2 bytes transmitted
<i>class_3_out_frames</i>	(Optional) Class 3 frames transmitted
<i>class_3_bytes_trans</i>	(Optional) Class 3 bytes transmitted
<i>class_3_out_discards</i>	(Optional) Class 3 out discards
<i>class_f_out_frames</i>	(Optional) Class F out frames
<i>class_f_bytes_trans</i>	(Optional) Class F bytes transmitted
<i>class_f_discards</i>	(Optional) Class F discards
<i>multicast_rcvd</i>	(Optional) Multicast received
<i>multicast_trans</i>	(Optional) Multicast transmitted
<i>broadcast_rcvd</i>	(Optional) Broadcast received
<i>broadcast_trans</i>	(Optional) Broadcast transmitted
<i>unicast_rcvd</i>	(Optional) Unicast received
<i>unicast_trans</i>	(Optional) Unicast transmitted
<i>timeout_discards</i>	(Optional) timeout discards
<i>credit_loss</i>	(Optional) credit loss
<i>link_faliures</i>	(Optional) Link faliures
<i>sync_loss</i>	(Optional) Sync Loss
<i>signal_loss</i>	(Optional) Signal Loss
<i>prm_seq_pro_err</i>	(Optional) primitive sequence protocol errors
<i>inv_trans_err</i>	(Optional) invaid transmission errors

<i>inv_crc</i>	(Optional) Invalid crc
<i>delim_err</i>	(Optional) Delimiter Errors
<i>addr_iden_err</i>	(Optional) Address Identification errors
<i>link_reset_rcvd</i>	(Optional) link reset received
<i>link_reset_trans</i>	(Optional) link reset transmitted
<i>off_seq_err_rcvd</i>	(Optional) Offline sequence error received
<i>off_seq_err_trans</i>	(Optional) Offline sequence Error transmitted
<i>frames_rcvd_short</i>	(Optional) frames received that are shorter than the minimum allowable frame length regardless of the CRC/FCS error
<i>frames_rcvd_long</i>	(Optional) frames received that are longer than the minimum allowable frame length regardless of the CRC/FCS error
<i>txwait</i>	(Optional) TXwait
<i>frames_rcvd_greater</i>	(Optional) frames received with length greater than what was agreed to in FLOGI/PLOGI
<i>frame_rcvd_short_header</i>	(Optional) frames received with length less than the minimum indicated by the frame header
<i>link_reset_resp_rcvd</i>	(Optional) Link reset responses received
<i>link_reset_resp_trans</i>	(Optional) Link reset responses transmitted
<i>non_oper_seq_rcvd</i>	(Optional) Non operational sequence received
<i>non_oper_seq_trans</i>	(Optional) Non operational sequence transmitted
<i>frag_frames_rcvd</i>	(Optional) fragmented frames received
<i>frames_eof_abort</i>	(Optional) frames EOF abort
<i>unknown_class_frames_rcvd</i>	(Optional) unknown class frames received
<i>8b10b_disparity_err</i>	(Optional) 8b10b disparity errors
<i>frames_discard</i>	(Optional) frames discard
<i>ex_link_param_sw_fab</i>	(Optional) external link parameters switch fabric
<i>in_link_ser_req_faliures</i>	(Optional) internal link serial request faliures
<i>b2b_credits_transmit</i>	(Optional) B2B credits transmit
<i>b2b_credits_receive</i>	(Optional) B2B credits receive
<i>eisl_frames</i>	(Optional) EISL frames

<i>framing_err</i>	(Optional) Framing Error
<i>f8_lip_seq_err_rcvd</i>	(Optional) f8 LIP sequence error received
<i>f8_lip_seq_err_issued</i>	(Optional) f8 LIP sequence error issued
<i>non_f8_lip_seq_err_rcvd</i>	(Optional) non f8 LIP sequence error received
<i>non_f8_lip_seq_err_issued</i>	(Optional) non f8 LIP sequence error issued
<i>fec_corrected</i>	(Optional) fec corrected blocks
<i>fec_uncorrected</i>	(Optional) fec uncorrected blocks
TABLE_interface	(Optional) interface
<i>interface</i>	(Optional) interface
<i>fcoe_in_pkts</i>	(Optional) fcoe in pkts
<i>fcoe_in_octets</i>	(Optional) fcoe in octets
<i>fcoe_out_pkts</i>	(Optional) fcoe out pkts
<i>fcoe_out_octets</i>	(Optional) fcoe out octets

Command Mode

- /exec

show interface fcoe

```
show interface <ifeth_fcoe> fcoe [ __readonly__ TABLE_interface <interface> [ <state> ] [ <vfc> ] [ <vfc_bound> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_fcoe</i>	Enter interface type and number in module/slot format
fcoe	Show interface fcoe information
<i>__readonly__</i>	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>state</i>	(Optional) State of interface
<i>vfc</i>	(Optional) VFC
<i>vfc_bound</i>	(Optional) Binding information

Command Mode

- /exec

show interface fec

show interface fec

Syntax Description

show	Show running system information
interface	Interface
fec	Show fec admin and operation state on physical interface

Command Mode

- /exec

show interface flowcontrol

```
show interface flowcontrol [ module <module> ] [ __readonly__ TABLE_interface <interface> <send_admin>
<send_oper> <recv_admin> <recv_oper> <rxpause> <txpause> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
flowcontrol	Show interface flowcontrol information
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>send_admin</i>	(Optional) Send flowcontrol admin
<i>send_oper</i>	(Optional) Send flowcontrol oper
<i>recv_admin</i>	(Optional) Receive flowcontrol admin
<i>recv_oper</i>	(Optional) Receive flowcontrol oper
<i>rxpause</i>	(Optional) RxPause
<i>txpause</i>	(Optional) TxPause

Command Mode

- /exec

show interface flowcontrol

```
show interface <ifeth_fl_ctrl> flowcontrol [ __readonly__ TABLE_interface <interface> <send_admin>
<send_oper> <recv_admin> <recv_oper> <rxpause> <txpause> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_fl_ctrl</i>	Enter interface type and number in module/slot format
flowcontrol	Show interface flowcontrol information
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>send_admin</i>	(Optional) Send flowcontrol admin
<i>send_oper</i>	(Optional) Send flowcontrol oper
<i>recv_admin</i>	(Optional) Receive flowcontrol admin
<i>recv_oper</i>	(Optional) Receive flowcontrol oper
<i>rxpause</i>	(Optional) RxPause
<i>txpause</i>	(Optional) TxPause

Command Mode

- /exec

show interface hardware-mappings

show interface hardware-mappings [json]

Syntax Description

show	Show running system information
interface	Interface
hardware-mappings	Show hardware port number and unit information for interfaces
json	(Optional) display the output in json format

Command Mode

- /exec

show interface mac-address

```
show interface <ifid_macaddr> mac-address [ __readonly__ TABLE_interface <interface> <address>
<bia_address> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_macaddr</i>	Enter interface type and number in module/slot format
mac-address	Show interface MAC address
__readonly__	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>address</i>	(Optional) MAC Address
<i>bia_address</i>	(Optional) Burn-In MAC Address

Command Mode

- /exec

show interface mac-address

show interface mac-address [*__readonly__* *TABLE_interface* <interface> <address> <bia_address>]

Syntax Description

show	Show running system information
interface	Show interface status and information
mac-address	Show interface MAC address
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_interface</i>	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>address</i>	(Optional) MAC Address
<i>bia_address</i>	(Optional) Burn-In MAC Address

Command Mode

- /exec

show interface priority-flow-control

```
show interface [ <if_list> ] priority-flow-control [ detail ] [ module <module> ] [ __readonly__ [
TABLE_pfc_interface <if_name_str> <admin> <oper> [ <cos-list> ] <rx-stats> <tx-stats> [ <rx_ppp_cos_0>
] [ <rx_ppp_cos_1> ] [ <rx_ppp_cos_2> ] [ <rx_ppp_cos_3> ] [ <rx_ppp_cos_4> ] [ <rx_ppp_cos_5> ] [
<rx_ppp_cos_6> ] [ <rx_ppp_cos_7> ] [ <tx_ppp_cos_0> ] [ <tx_ppp_cos_1> ] [ <tx_ppp_cos_2> ] [
<tx_ppp_cos_3> ] [ <tx_ppp_cos_4> ] [ <tx_ppp_cos_5> ] [ <tx_ppp_cos_6> ] [ <tx_ppp_cos_7> ] ] ]
```

Syntax Description

show	commands to display
interface	Interface for displaying pfc information
<i>if_list</i>	(Optional) List of interfaces
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
priority-flow-control	Show interface PFC information
detail	(Optional) Show detailed per priority Tx/Rx PFC statistics
__readonly__	(Optional)
<i>if_name_str</i>	(Optional) interface name
TABLE_pfc_interface	(Optional) PFC information of an interface
<i>admin</i>	(Optional) PFC admin
<i>oper</i>	(Optional) PFC oper
<i>cos-list</i>	(Optional) List of class-of-service values

Command Mode

- /exec

show interface private-vlan mapping

```
show interface [ <if> ] private-vlan mapping [ __readonly__ [ <output-filtered> ] [ { TABLE_interf_mapp
<interface-id> [ <secondary-vlan> + ] [ <pvlan-type> } } ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>if</i>	(Optional) Vlan Interface number
private-vlan	Show interface private vlan information
mapping	Show interface private vlan information
<code>__readonly__</code>	(Optional) Read Only
<i>output-filtered</i>	(Optional) the output is filtered for specified ifs
TABLE_interf_mapp	(Optional) Pvlan interface mapping table
<i>interface-id</i>	(Optional) Interface
<i>secondary-vlan</i>	(Optional) Secondary Vlan
<i>pvlan-type</i>	(Optional) PVLAN Type

Command Mode

- /exec

show interface pruning

```
show interface pruning [ __readonly__ <start> { TABLE_interface_pruning1 <if_index1> <rx_join> } {
TABLE_interface_pruning2 <if_index2> <cur_join> } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
pruning	Show interface trunk VTP pruning information
<i>__readonly__</i>	(Optional) Read Only
<i>start</i>	(Optional) Start
TABLE_interface_pruning1	(Optional) Interface pruning information in table format
<i>if_index1</i>	(Optional) Trunk
<i>rx_join</i>	(Optional) Vlans pruned for lack of request by neighbor
TABLE_interface_pruning2	(Optional) Interface pruning information in table format
<i>if_index2</i>	(Optional) Trunk
<i>cur_join</i>	(Optional) Vlan traffic requested of neighbor

Command Mode

- /exec

show interface snmp-ifindex

```
show interface snmp-ifindex [ __readonly__ TABLE_interface <interface> <snmp-ifindex> [ <ifindex-hex> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
snmp-ifindex	Show snmp ifindex list
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>ifindex-hex</i>	(Optional) If Index in Hex
<i>snmp-ifindex</i>	(Optional) If Index in Dec

Command Mode

- /exec

show interface status

```
show interface <ifeth_status> status [ __readonly__ TABLE_interface <interface> [ <name> ] [ <state> ] [
<vlan> ] <duplex> <speed> [ <type> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_status</i>	Enter interface type and number in module/slot format
status	Show interface line status
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>vlan</i>	(Optional) Vlan
<i>duplex</i>	(Optional) Duplex
<i>speed</i>	(Optional) Speed
<i>type</i>	(Optional) Type

Command Mode

- /exec

show interface status

show interface <ifid> status [__readonly__ <start> <if_index> <admin-state> <line-proto>]

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
status	Interface status
__readonly__	(Optional) Read Only
<i>start</i>	(Optional) Start
<i>if_index</i>	(Optional) Interface
<i>admin-state</i>	(Optional)
<i>line-proto</i>	(Optional)

Command Mode

- /exec

show interface status

```
show interface status [ down | inactive | module <module> | up | auto-column ] [ __readonly__ TABLE interface
<interface> [ <name> ] [ <state> ] [ <state_san> ] [ <state_rsn> ] [ <vlan> ] [ <duplex> ] [ <speed> ] [ <type>
] [ <admin_mode> ] [ <vsan> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <oper_speed> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
status	Show interface line status
down	(Optional) Show interface down state
inactive	(Optional) Show interface inactive state
auto-column	(Optional) Show interface status auto-column adjusted
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
up	(Optional) Show interface up state
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>state_san</i>	(Optional) SAN Port State
<i>vlan</i>	(Optional) Vlan
<i>vsan</i>	(Optional) Vsan
<i>duplex</i>	(Optional) Duplex
<i>speed</i>	(Optional) Speed
<i>type</i>	(Optional) Type
<i>state_rsn</i>	(Optional) Port State Reason
<i>bind_info</i>	(Optional) bind interface
<i>bind_type</i>	(Optional) bind type
<i>bind_mac</i>	(Optional) bind mac

<i>oper_speed</i>	(Optional) speed
<i>admin_mode</i>	(Optional) admin mode

Command Mode

- /exec

show interface status

```
show interface <ifid_status> status [ __readonly__ TABLE_interface <interface> [ <name> ] [ <state> ] [ <vlan> ] [ <duplex> ] [ <speed> ] [ <type> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_status</i>	Enter interface type and number in module/slot format
status	Show interface line status
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>vlan</i>	(Optional) Vlan
<i>duplex</i>	(Optional) Duplex
<i>speed</i>	(Optional) Speed
<i>type</i>	(Optional) Type

Command Mode

- /exec

show interface status

```
show interface <iftun_status> status [ err-disabled ] [ __readonly__ TABLE_interface <interface> <name>
<state> <state_rsn> <state_rsn_desc> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>iftun_status</i>	Enter tunnel interface number
status	Show interface line status
err-disabled	(Optional) Show interface error disabled state
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed

Command Mode

- /exec

show interface status

```
show interface <ifrange> status [ err-disabled ] [ __readonly__ TABLE_interface <interface> <name> <state>
<state_rsn> <state_rsn_desc> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter tunnel interface number
status	Show interface line status
err-disabled	(Optional) Show interface error disabled state
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed

Command Mode

- /exec

show interface status

```
show interface <ifrange> status [ err-disabled ] [ __readonly__ TABLE_interface <interface> <name> <state>
<state_rsn> <state_rsn_desc> <admin_state> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifrange</i>	Enter tunnel interface number
status	Show interface line status
err-disabled	(Optional) Show interface error disabled state
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed
<i>admin_state</i>	(Optional) admin state

Command Mode

- /exec

show interface status err-disabled

```
show interface <ifeth_errdis> status err-disabled [ __readonly__ TABLE_interface <interface> [ <name> ]
<state> [ <state_rsn> ] [ <state_rsn_desc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
status	Show interface line status
<i>ifeth_errdis</i>	Enter interface type and number in module/slot format
err-disabled	Show interface error disabled state
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed

Command Mode

- /exec

show interface status err-disabled

```
show interface status err-disabled [ __readonly__ TABLE_interface <interface> [ <name> ] <state> [
<state_rsn> ] [ <state_rsn_desc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
status	Show interface line status
err-disabled	Show interface error disabled state
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
<i>state</i>	(Optional) Interface state
<i>state_rsn</i>	(Optional) Interface state reason
<i>state_rsn_desc</i>	(Optional) Interface state reason detailed

Command Mode

- /exec

show interface status err-vlans

```
show interface status err-vlans [ __readonly__ TABLE_interface <interface> [ <name> ] { TABLE_vlan
<err_vlan> <err_vlan_status> <err_vlan_syserr> } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
status	Show interface line status
err-vlans	Show errored vlans
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>name</i>	(Optional) Name
TABLE_vlan	(Optional) show vlan
<i>err_vlan</i>	(Optional) Errored vlan
<i>err_vlan_status</i>	(Optional) Errored vlan status
<i>err_vlan_syserr</i>	(Optional) Errored vlan syserr name

Command Mode

- /exec

show interface status err-vlans

```
show interface <ifeth_errvlans> status err-vlans [ __readonly__ TABLE_interface <interface> [ <name> ] [
{ TABLE_vlan [ <err_vlan> ] [ <err_vlan_status> ] [ <err_vlan_syserr> } } ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_errvlans</i>	Enter interface type and number in module/slot format
status	Show interface line status
err-vlans	Show errored vlans
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
<i>TABLE_interface</i>	(Optional) show interface
<i>name</i>	(Optional) Name
<i>TABLE_vlan</i>	(Optional) show vlan
<i>err_vlan</i>	(Optional) Errored vlan
<i>err_vlan_status</i>	(Optional) Errored vlan status
<i>err_vlan_syserr</i>	(Optional) Errored vlan syserr name

Command Mode

- /exec

show interface switchport

```
show interface <ifeth_swth> switchport [ __readonly__ TABLE_interface <interface> <switchport> [
<switchport_monitor> ] [ <switchport_isolated> ] [ <switchport_block_multicast> ] [
<switchport_block_unicast> ] [ <oper_mode> ] [ <access_vlan> ] [ <access_vlan_name> ] [ <native_vlan>
] [ <native_vlan_name> ] [ <trunk_vlans> ] [ <fabricpath_topologies> ] [ <pruning_vlans> ] [ <voice_vlan>
] [ <voice_vlan_name> ] [ <extended_trust> ] [ <extended_trust_name> ] [ <admin_pvlan_pri_assoc> ] [
<admin_pvlan_sec_assoc> ] [ <admin_pvlan_pri_mapping> ] [ <admin_pvlan_sec_mapping> ] [
<admin_pvlan_trunk_native> ] [ <admin_pvlan_trunk_encap> ] [ <admin_pvlan_trunk_normal> ] [
<admin_pvlan_trunk_private> ] [ <oper_pvlan> ] [ <autostate_mode> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_swth</i>	Enter interface type and number in module/slot format
switchport	Show interface switchport information
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_interface</i>	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>switchport</i>	(Optional) Switchport enabled
<i>switchport_monitor</i>	(Optional) Switchport monitor enabled
<i>switchport_isolated</i>	(Optional) Switchport isolated enabled
<i>switchport_block_multicast</i>	(Optional) Switchport monitor enabled
<i>switchport_block_unicast</i>	(Optional) Switchport monitor enabled
<i>oper_mode</i>	(Optional) Operational mode
<i>access_vlan</i>	(Optional) Access mode VLAN
<i>access_vlan_name</i>	(Optional) Access mode VLAN name
<i>native_vlan</i>	(Optional) Trunking native mode VLAN
<i>native_vlan_name</i>	(Optional) Trunking native mode VLAN name
<i>trunk_vlans</i>	(Optional) Trunking VLANs Allowed
<i>fabricpath_topologies</i>	(Optional) FabricPath Topologies Allowed
<i>pruning_vlans</i>	(Optional) Pruning eligible VLANs
<i>voice_vlan</i>	(Optional) Voice VLAN

<i>voice_vlan_name</i>	(Optional) Voice VLAN name
<i>extended_trust</i>	(Optional) Extended Trust
<i>extended_trust_name</i>	(Optional) Extended Trust name
<i>admin_pvlan_pri_assoc</i>	(Optional) Administrative private-vlan primary host-association
<i>admin_pvlan_sec_assoc</i>	(Optional) Administrative private-vlan secondary host-association
<i>admin_pvlan_pri_mapping</i>	(Optional) Administrative private-vlan primary mapping
<i>admin_pvlan_sec_mapping</i>	(Optional) Administrative private-vlan secondary mapping
<i>admin_pvlan_trunk_native</i>	(Optional) Administrative private-vlan trunk native VLAN
<i>admin_pvlan_trunk_encap</i>	(Optional) Administrative private-vlan trunk encapsulation
<i>admin_pvlan_trunk_normal</i>	(Optional) Administrative private-vlan trunk normal VLANs
<i>admin_pvlan_trunk_private</i>	(Optional) Administrative private-vlan trunk private VLANs
<i>oper_pvlan</i>	(Optional) Operational private-vlan
<i>autostate_mode</i>	(Optional) SVI Autostate Exclude Info

Command Mode

- /exec

show interface switchport

```
show interface switchport [ __readonly__ ] [ TABLE_interface <interface> <switchport> ] [ <switchport_monitor> ] [ <switchport_isolated> ] [ <switchport_block_multicast> ] [ <switchport_block_unicast> ] [ <mac_learning> ] [ <oper_mode> ] [ <access_vlan> ] [ <access_vlan_name> ] [ <native_vlan> ] [ <native_vlan_name> ] [ <trunk_vlans> ] [ <fabricpath_topologies> ] [ <pruning_vlans> ] [ <voice_vlan> ] [ <voice_vlan_name> ] [ <extended_trust> ] [ <extended_trust_name> ] [ <admin_pvlan_pri_assoc> ] [ <admin_pvlan_sec_assoc> ] [ <admin_pvlan_pri_mapping> ] [ <admin_pvlan_sec_mapping> ] [ <admin_pvlan_trunk_native> ] [ <admin_pvlan_trunk_encap> ] [ <admin_pvlan_trunk_normal> ] [ <admin_pvlan_trunk_private> ] [ <oper_pvlan> ] [ <autostate_mode> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
switchport	Show interface switchport information
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_interface</i>	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>switchport</i>	(Optional) Switchport enabled
<i>switchport_monitor</i>	(Optional) Switchport monitor enabled
<i>switchport_isolated</i>	(Optional) Switchport isolated enabled
<i>mac_learning</i>	(Optional) Mac learning enabled/disabled
<i>switchport_block_multicast</i>	(Optional) Switchport monitor enabled
<i>switchport_block_unicast</i>	(Optional) Switchport monitor enabled
<i>oper_mode</i>	(Optional) Operational mode
<i>access_vlan</i>	(Optional) Access mode VLAN
<i>access_vlan_name</i>	(Optional) Access mode VLAN name
<i>native_vlan</i>	(Optional) Trunking native mode VLAN
<i>native_vlan_name</i>	(Optional) Trunking native mode VLAN name
<i>trunk_vlans</i>	(Optional) Trunking VLANs Allowed
<i>fabricpath_topologies</i>	(Optional) FabricPath Topologies Allowed
<i>pruning_vlans</i>	(Optional) Pruning eligible VLANs
<i>voice_vlan</i>	(Optional) Voice VLAN

<i>voice_vlan_name</i>	(Optional) Voice VLAN name
<i>extended_trust</i>	(Optional) Extended Trust
<i>extended_trust_name</i>	(Optional) Extended Trust name
<i>admin_pvlan_pri_assoc</i>	(Optional) Administrative private-vlan primary host-association
<i>admin_pvlan_sec_assoc</i>	(Optional) Administrative private-vlan secondary host-association
<i>admin_pvlan_pri_mapping</i>	(Optional) Administrative private-vlan primary mapping
<i>admin_pvlan_sec_mapping</i>	(Optional) Administrative private-vlan secondary mapping
<i>admin_pvlan_trunk_native</i>	(Optional) Administrative private-vlan trunk native VLAN
<i>admin_pvlan_trunk_encap</i>	(Optional) Administrative private-vlan trunk encapsulation
<i>admin_pvlan_trunk_normal</i>	(Optional) Administrative private-vlan trunk normal VLANs
<i>admin_pvlan_trunk_private</i>	(Optional) Administrative private-vlan trunk private VLANs
<i>oper_pvlan</i>	(Optional) Operational private-vlan
<i>autostate_mode</i>	(Optional) SVI Autostate Exclude Info

Command Mode

- /exec

show interface switchport backup

```
show interface switchport backup [ detail ] [ __readonly__ { TABLE_pair <ai_name> <bi_name> <ai_state>
<bi_state> <ai_prefer> <bi_prefer> <preempt_mode> <delay_value> <delay_default> <delay_scheduled>
<mcast_fast> <ai_bw> <ai_bw_name> <bi_bw> <bi_bw_name> <mmu_primary> } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
switchport	Show interface switchport information
backup	Show interface backup
detail	(Optional) Backup interface info in detail
<i>__readonly__</i>	(Optional) Read Only
TABLE_pair	(Optional) Show interface backup
<i>ai_name</i>	(Optional) Active Interface name
<i>bi_name</i>	(Optional) Backup Interface name
<i>ai_state</i>	(Optional) Active Interface state
<i>bi_state</i>	(Optional) Backup Interface state
<i>ai_prefer</i>	(Optional) Active Interface prefer VLANs
<i>bi_prefer</i>	(Optional) Backup Interface prefer VLANs
<i>preempt_mode</i>	(Optional) Preempt mode
<i>delay_value</i>	(Optional) Preempt delay
<i>delay_default</i>	(Optional) Preempt delay value is default
<i>delay_scheduled</i>	(Optional) Preemption has been scheduled
<i>mcast_fast</i>	(Optional) Multicast Fast-Convergence
<i>ai_bw</i>	(Optional) Active Interface bandwidth
<i>ai_bw_name</i>	(Optional) Active Interface name for bandwidth
<i>bi_bw</i>	(Optional) Backup Interface bandwidth
<i>bi_bw_name</i>	(Optional) Backup Interface name for bandwidth
<i>mmu_primary</i>	(Optional) MAC Move Update primary VLAN

Command Mode

show interface switchport backup

- /exec

show interface transceiver

```

show interface <ifid_transceiver> transceiver [ calibrations | details | sprom ] [ __readonly__ TABLE_interface
<interface> [ <sfp> ] [ <qsfp_or_cfp> ] [ <type> ] [ <name> ] [ <partnum> ] [ <rev> ] [ <serialnum> ] [
<nom_bitrate> ] [ <len_9> ] [ <len_9_2> ] [ <len_50> ] [ <len_625> ] [ <len_cu> ] [ <len_50_OM3> ] [
<txcvr_type> ] [ <connector_type> ] [ <bit_encoding> ] [ <protocol_type> ] [ <10gbe_code> ] [
<fiber_type_byte0> ] [ <fiber_type_byte1> ] [ <tx_range> ] [ <cable_type> ] [ <ciscoid> ] [ <ciscoid_1> ] [
<cisco_part_number> ] [ <cisco_product_id> ] [ <cisco_version_id> ] [ <cisco_vendor_id> ] [
<firmware_version> ] [ <identifier> ] [ <ext_identifier> ] [ <connector> ] [ <infiniband_compliance_code>
] [ <sonet_compliance_code> ] [ <gigabit_ethernet_compliance_code> ] [ <fibre_chan_link_length> ] [
<fibre_chan_trans_technology> ] [ <fibre_chan_trans_tech_reserved> ] [ <fibre_chan_transmission_media>
] [ <fibre_chan_speed> ] [ <encoding> ] [ <br_nominal> ] [ <reserved1> ] [ <length_smf> ] [ <length_om5>
] [ <length_om4> ] [ <length_om3> ] [ <length_om2> ] [ <length_om1> ] [ <length_9u_1> ] [ <length_9u_2>
] [ <length_50u> ] [ <length_60u> ] [ <length_copper> ] [ <reserved3> ] [ <wave_length> ] [
<wave_len_tolerance> ] [ <vendor_oui> ] [ <vendor_part_no> ] [ <vendor_revision> ] [ <reserved4> ] [
<check_code_id> ] [ <options> ] [ <br_max> ] [ <br_min> ] [ <vendor_serial_no> ] [ <data_code> ] [
<diagnostic_monitoring_type> ] [ <enhanced_options> ] [ <sff8472compliance> ] [ <check_code_ext> ] [
<vendor_specific_data_id_data> ] [ <vendor_oui> ] [ <date_code> ] [ <clei_code> ] [ <power_class> ] [
<max_power> ] [ <cable_attenuation> ] [ <near_end_lanes> ] [ <far_end_lanes> ] [ <media_interface> ] [
<adv_code> ] [ <host_elt_intf_code> ] [ <med_intf_adv_code> ] [ <host_lane_count> ] [ <med_lane_count>
] [ <max_mod_temp> ] [ <min_mod_temp> ] [ <min_op_volt> ] [ <info_not_available> ] [ <temp_slope> ]
[ <temp_offset> ] [ <volt_slope> ] [ <volt_offset> ] [ <curr_slope> ] [ <curr_offset> ] [ <tx_pwr_slope> ] [
<tx_pwr_offset> ] [ <rx_pwr_4> ] [ <rx_pwr_3> ] [ <rx_pwr_2> ] [ <rx_pwr_1> ] [ <rx_pwr_0> ] [
TABLE_lane [ <lane_number> ] [ <temperature> ] [ <temp_flag> ] [ <temp_alm_hi> ] [ <temp_alm_lo> ]
[ <temp_warn_hi> ] [ <temp_warn_lo> ] [ <voltage> ] [ <volt_flag> ] [ <volt_alm_hi> ] [ <volt_alm_lo>
] [ <volt_warn_hi> ] [ <volt_warn_lo> ] [ <current> ] [ <current_flag> ] [ <current_alm_hi> ] [
<current_alm_lo> ] [ <current_warn_hi> ] [ <current_warn_lo> ] [ <tx_pwr> ] [ <tx_pwr_flag> ] [
<tx_pwr_alm_hi> ] [ <tx_pwr_alm_lo> ] [ <tx_pwr_warn_hi> ] [ <tx_pwr_warn_lo> ] [ <rx_pwr> ] [
<rx_pwr_flag> ] [ <rx_pwr_alm_hi> ] [ <rx_pwr_alm_lo> ] [ <rx_pwr_warn_hi> ] [ <rx_pwr_warn_lo> ]
[ <xmit_faults> ] [ <snr> ] [ <snr_flag> ] [ <snr_alm_hi> ] [ <snr_alm_lo> ] [ <snr_warn_hi> ] [
<snr_warn_lo> ] [ <isi> ] [ <isi_flag> ] [ <isi_alm_hi> ] [ <isi_alm_lo> ] [ <isi_warn_hi> ] [ <isi_warn_lo>
] [ <pam> ] [ <pam_flag> ] [ <pam_alm_hi> ] [ <pam_alm_lo> ] [ <pam_warn_hi> ] [ <pam_warn_lo> ] [
<pre_fec_ber> ] [ <pre_fec_ber_flag> ] [ <pre_fec_ber_alm_hi> ] [ <pre_fec_ber_alm_lo> ] [
<pre_fec_ber_warn_hi> ] [ <pre_fec_ber_warn_lo> ] [ <uncorrect_ber> ] [ <uncorrect_ber_flag> ] [
<uncorrect_ber_alm_hi> ] [ <uncorrect_ber_alm_lo> ] [ <uncorrect_ber_warn_hi> ] [
<uncorrect_ber_warn_lo> ] [ <tec_current> ] [ <tec_current_flag> ] [ <tec_current_alm_hi> ] [
<tec_current_alm_lo> ] [ <tec_current_warn_hi> ] [ <tec_current_warn_lo> ] [ <laser_freq> ] [
<laser_freq_flag> ] [ <laser_freq_alm_hi> ] [ <laser_freq_alm_lo> ] [ <laser_freq_warn_hi> ] [
<laser_freq_warn_lo> ] [ <laser_temp> ] [ <laser_temp_flag> ] [ <laser_temp_alm_hi> ] [
<laser_temp_alm_lo> ] [ <laser_temp_warn_hi> ] [ <laser_temp_warn_lo> ] [ <pre_fec_ber_acc> ] [
<pre_fec_ber_acc_flag> ] [ <pre_fec_ber_acc_alm_hi> ] [ <pre_fec_ber_acc_alm_lo> ] [
<pre_fec_ber_acc_warn_hi> ] [ <pre_fec_ber_acc_warn_lo> ] [ <pre_fec_ber_min> ] [ <pre_fec_ber_min_flag>
] [ <pre_fec_ber_min_alm_hi> ] [ <pre_fec_ber_min_alm_lo> ] [ <pre_fec_ber_min_warn_hi> ] [
<pre_fec_ber_min_warn_lo> ] [ <pre_fec_ber_max> ] [ <pre_fec_ber_max_flag> ] [
<pre_fec_ber_max_alm_hi> ] [ <pre_fec_ber_max_alm_lo> ] [ <pre_fec_ber_max_warn_hi> ] [
<pre_fec_ber_max_warn_lo> ] [ <pre_fec_ber_cur> ] [ <pre_fec_ber_cur_flag> ] [ <pre_fec_ber_cur_alm_hi>
] [ <pre_fec_ber_cur_alm_lo> ] [ <pre_fec_ber_cur_warn_hi> ] [ <pre_fec_ber_cur_warn_lo> ] [
<uncorrect_ber_acc> ] [ <uncorrect_ber_acc_flag> ] [ <uncorrect_ber_acc_alm_hi> ] [
<uncorrect_ber_acc_alm_lo> ] [ <uncorrect_ber_acc_warn_hi> ] [ <uncorrect_ber_acc_warn_lo> ] [
<uncorrect_ber_min> ] [ <uncorrect_ber_min_flag> ] [ <uncorrect_ber_min_alm_hi> ] [

```

```
<uncorrect_ber_min_alm_lo> ][ <uncorrect_ber_min_warn_hi> ][ <uncorrect_ber_min_warn_lo> ][
<uncorrect_ber_max> ][ <uncorrect_ber_max_flag> ][ <uncorrect_ber_max_alm_hi> ][
<uncorrect_ber_max_alm_lo> ][ <uncorrect_ber_max_warn_hi> ][ <uncorrect_ber_max_warn_lo> ][
<uncorrect_ber_cur> ][ <uncorrect_ber_cur_flag> ][ <uncorrect_ber_cur_alm_hi> ][
<uncorrect_ber_cur_alm_lo> ][ <uncorrect_ber_cur_warn_hi> ][ <uncorrect_ber_cur_warn_lo> ] ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_transceiver</i>	Enter interface type and number in module/slot format
transceiver	Show interface transceiver information
calibrations	(Optional) Show interface transceiver calibration information
details	(Optional) Show interface transceiver detail information
sprom	(Optional) Show interface transceiver sprom information
__readonly__	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>sfp</i>	(Optional) sfp
<i>qsfp_or_cfp</i>	(Optional) qsfp_or_cfp
<i>type</i>	(Optional) type
<i>name</i>	(Optional) Name
<i>partnum</i>	(Optional) part number
<i>rev</i>	(Optional) revision
<i>serialnum</i>	(Optional) serial number
<i>nom_bitrate</i>	(Optional) Nominal bit rate in MBits/sec
<i>len_9</i>	(Optional) Link length supported for 9/125um fiber in Km
<i>len_9_2</i>	(Optional) Link length supported for 9/125um fiber in m
<i>len_50</i>	(Optional) Link length supported for 50/125um fiber in m
<i>len_625</i>	(Optional) Link length supported for 62.5/125um fiber in m
<i>len_cu</i>	(Optional) Link length supported for copper sfp in m
<i>len_50_OM3</i>	(Optional) Link length supported for 50/125um fiber in m
<i>txcvr_type</i>	(Optional)

<i>connector_type</i>	(Optional)
<i>bit_encoding</i>	(Optional)
<i>protocol_type</i>	(Optional)
<i>10gbe_code</i>	(Optional)
<i>fiber_type_byte0</i>	(Optional)
<i>fiber_type_byte1</i>	(Optional)
<i>tx_range</i>	(Optional)
<i>cable_type</i>	(Optional)
<i>ciscoid</i>	(Optional) Cisco extended id
<i>ciscoid_1</i>	(Optional) Cisco extended id number
<i>cisco_part_number</i>	(Optional) Cisco part number
<i>cisco_product_id</i>	(Optional) Cisco product identifier
<i>cisco_version_id</i>	(Optional) Cisco version identifier
<i>cisco_vendor_id</i>	(Optional) Cisco vendor identifier
<i>firmware_version</i>	(Optional) Firmware version
<i>identifier</i>	(Optional) SFP Identifier
<i>ext_identifier</i>	(Optional) SFP Ext Identifier
<i>connector</i>	(Optional) SFP connector
<i>infiniband_compliance_code</i>	(Optional) SFP Infiniband Compliance Code
<i>sonet_compliance_code</i>	(Optional) Sonet Compliance Code
<i>gigabit_ethernet_compliance_code</i>	(Optional) Gigabit Ethernet Compliance Code
<i>fibre_chan_link_length</i>	(Optional) Fibre Chan Link Length
<i>fibre_chan_trans_technology</i>	(Optional) Fibre Chan Trans Technology
<i>fibre_chan_trans_tech_reserved</i>	(Optional) Fibre Chan Trans Tech Reserved
<i>fibre_chan_transmission_media</i>	(Optional) Fibre Chan Transmission Media
<i>fibre_chan_speed</i>	(Optional) Fibre Chan Speed
<i>encoding</i>	(Optional) Encoding
<i>br_nominal</i>	(Optional) BR Nominal
<i>reserved1</i>	(Optional) Reserved1

<i>length_smf</i>	(Optional) Length_SMF
<i>length_om5</i>	(Optional) Length_OM5
<i>length_om4</i>	(Optional) Length_OM4
<i>length_om3</i>	(Optional) Length_OM3
<i>length_om2</i>	(Optional) Length_OM2
<i>length_om1</i>	(Optional) Length_OM1
<i>length_9u_1</i>	(Optional) Length 9u 1
<i>length_9u_2</i>	(Optional) Length 9u 2
<i>length_50u</i>	(Optional) Length 50u
<i>length_60u</i>	(Optional) Length 60u
<i>length_copper</i>	(Optional) Length Copper
<i>reserved3</i>	(Optional) Reserved3
<i>wave_length</i>	(Optional) Nominal transmitter output wavelength
<i>wave_len_tolerance</i>	(Optional) Wavelength tolerance
<i>vendor_oui</i>	(Optional) Vendor OUI
<i>vendor_part_no</i>	(Optional) Vendor Part No
<i>vendor_revision</i>	(Optional) Vendor Revision
<i>reserved4</i>	(Optional) Reserved4
<i>check_code_id</i>	(Optional) Check Code ID
<i>options</i>	(Optional) Options
<i>br_max</i>	(Optional) BR max
<i>br_min</i>	(Optional) BR min
<i>vendor_serial_no</i>	(Optional) Vendor Serial No
<i>data_code</i>	(Optional) Data code
<i>diagnostic_monitoring_type</i>	(Optional) Diagnostic Monitoring Type
<i>enhanced_options</i>	(Optional) Enhanced Options
<i>sff8472compliance</i>	(Optional) SFF8472Compliance
<i>check_code_ext</i>	(Optional) Check code ext
<i>vendor_specific_data_id_data</i>	(Optional) Vendor Specific Data Id Data

<i>vendor_oui</i>	(Optional) 3-octet canonical vendor IEEE company ID
<i>date_code</i>	(Optional) date code and lot code
<i>clei_code</i>	(Optional) 10-character CLEI code
<i>power_class</i>	(Optional) power class
<i>max_power</i>	(Optional) maximum power consumption
<i>cable_attenuation</i>	(Optional) copper cable attenuation
<i>near_end_lanes</i>	(Optional) near end lane information
<i>far_end_lanes</i>	(Optional) far end lane information
<i>media_interface</i>	(Optional) media interface technology
<i>adv_code</i>	(Optional) Module Advertising Code
<i>host_elt_intf_code</i>	(Optional) Module Host Electrical Interfaces Code
<i>med_intf_adv_code</i>	(Optional) Media Interface Advertising Code
<i>host_lane_count</i>	(Optional) Host Lane Count
<i>med_lane_count</i>	(Optional) Media Lane Count
<i>max_mod_temp</i>	(Optional) Maximum Module Temperature
<i>min_mod_temp</i>	(Optional) Minimum Module Temperature
<i>min_op_volt</i>	(Optional) Minimum Operating Voltage
<i>info_not_available</i>	(Optional) Info not available
<i>temp_slope</i>	(Optional) Temperature slope
<i>temp_offset</i>	(Optional) Temperature offset
<i>volt_slope</i>	(Optional) Voltage slope
<i>volt_offset</i>	(Optional) Voltage offset
<i>curr_slope</i>	(Optional) Current slope
<i>curr_offset</i>	(Optional) Current offset
<i>tx_pwr_slope</i>	(Optional) Tx power slope
<i>tx_pwr_offset</i>	(Optional) Tx power offset
<i>rx_pwr_4</i>	(Optional) Rx power 4
<i>rx_pwr_3</i>	(Optional) Rx power 3
<i>rx_pwr_2</i>	(Optional) Rx power 2

<i>rx_pwr_1</i>	(Optional) Rx power 1
<i>rx_pwr_0</i>	(Optional) Rx power 0
TABLE_lane	(Optional) show lane
<i>lane_number</i>	(Optional) Lane number
<i>temperature</i>	(Optional) Temperature
<i>temp_flag</i>	(Optional) Temperature Flag
<i>temp_alrm_hi</i>	(Optional) Temperature Alarm High
<i>temp_alrm_lo</i>	(Optional) Temperature Alarm Low
<i>temp_warn_hi</i>	(Optional) Temperature Warning High
<i>temp_warn_lo</i>	(Optional) Temperature Warning Low
<i>voltage</i>	(Optional) Voltage
<i>volt_flag</i>	(Optional) Voltage Flag
<i>volt_alrm_hi</i>	(Optional) Voltage Alarm High
<i>volt_alrm_lo</i>	(Optional) Voltage Alarm Low
<i>volt_warn_hi</i>	(Optional) Voltage Warning High
<i>volt_warn_lo</i>	(Optional) Voltage Warning Low
<i>current</i>	(Optional) Current
<i>current_flag</i>	(Optional) Current Flag
<i>current_alrm_hi</i>	(Optional) Current Alarm High
<i>current_alrm_lo</i>	(Optional) Current Alarm Low
<i>current_warn_hi</i>	(Optional) Current Warning High
<i>current_warn_lo</i>	(Optional) Current Warning Low
<i>tx_pwr</i>	(Optional) Tx Power
<i>tx_pwr_flag</i>	(Optional) Tx Power Flag
<i>tx_pwr_alrm_hi</i>	(Optional) Tx Power Alarm High
<i>tx_pwr_alrm_lo</i>	(Optional) Tx Power Alarm Low
<i>tx_pwr_warn_hi</i>	(Optional) Tx Power Warning High
<i>tx_pwr_warn_lo</i>	(Optional) Tx Power Warning Low
<i>rx_pwr</i>	(Optional) Rx Power

<i>rx_pwr_flag</i>	(Optional) Rx Power Flag
<i>rx_pwr_alrm_hi</i>	(Optional) Rx Power Alarm High
<i>rx_pwr_alrm_lo</i>	(Optional) Rx Power Alarm Low
<i>rx_pwr_warn_hi</i>	(Optional) Rx Power Warning High
<i>rx_pwr_warn_lo</i>	(Optional) Rx Power Warning Low
<i>xmit_faults</i>	(Optional) Transmit Fault Count
<i>snr</i>	(Optional) RX Signal-to-Noise Ratio (SNR)
<i>snr_flag</i>	(Optional) SNR Flag
<i>snr_alrm_hi</i>	(Optional) SNR Alarm High
<i>snr_alrm_lo</i>	(Optional) SNR Alarm Low
<i>snr_warn_hi</i>	(Optional) SNR Warning High
<i>snr_warn_lo</i>	(Optional) SNR Warning Low
<i>isi</i>	(Optional) Residual-Dispersion(ISI)
<i>isi_flag</i>	(Optional) ISI Flag
<i>isi_alrm_hi</i>	(Optional) ISI alarm high
<i>isi_alrm_lo</i>	(Optional) ISI alarm low
<i>isi_warn_hi</i>	(Optional) ISI warning high
<i>isi_warn_lo</i>	(Optional) ISI warning low
<i>pam</i>	(Optional) PAM Transition
<i>pam_flag</i>	(Optional) PAM Flag
<i>pam_alrm_hi</i>	(Optional) PAM alarm high
<i>pam_alrm_lo</i>	(Optional) PAM alarm low
<i>pam_warn_hi</i>	(Optional) PAM warning high
<i>pam_warn_lo</i>	(Optional) PAM warning low
<i>pre_fec_ber</i>	(Optional) Pre-FEC BER
<i>pre_fec_ber_flag</i>	(Optional) Pre-FEC BER flag
<i>pre_fec_ber_alrm_hi</i>	(Optional) Pre-FEC BER alarm high
<i>pre_fec_ber_alrm_lo</i>	(Optional) Pre-FEC BER alarm low
<i>pre_fec_ber_warn_hi</i>	(Optional) Pre-FEC BER warning high

<i>pre_fec_ber_warn_lo</i>	(Optional) Pre-FEC BER warning low
<i>uncorrect_ber</i>	(Optional) Uncorrected BER
<i>uncorrect_ber_flag</i>	(Optional) Uncorrected BER flag
<i>uncorrect_ber_alm_hi</i>	(Optional) Uncorrected BER alarm high
<i>uncorrect_ber_alm_lo</i>	(Optional) Uncorrected BER alarm low
<i>uncorrect_ber_warn_hi</i>	(Optional) Uncorrected BER warning high
<i>uncorrect_ber_warn_lo</i>	(Optional) Uncorrected BER warning low
<i>tec_current</i>	(Optional) TEC Current
<i>tec_current_flag</i>	(Optional) TEC Current flag
<i>tec_current_alm_hi</i>	(Optional) TEC Current Alarm High
<i>tec_current_alm_lo</i>	(Optional) TEC Current Alarm Low
<i>tec_current_warn_hi</i>	(Optional) TEC Current Warning High
<i>tec_current_warn_lo</i>	(Optional) TEC Current Warning Low
<i>laser_freq</i>	(Optional) Laser Frequency
<i>laser_freq_flag</i>	(Optional) Laser Frequency flag
<i>laser_freq_alm_hi</i>	(Optional) Laser Frequency Alarm High
<i>laser_freq_alm_lo</i>	(Optional) Laser Frequency Alarm Low
<i>laser_freq_warn_hi</i>	(Optional) Laser Frequency Warning High
<i>laser_freq_warn_lo</i>	(Optional) Laser Frequency Warning Low
<i>laser_temp</i>	(Optional) Laser Temperature
<i>laser_temp_flag</i>	(Optional) Laser Temperature flag
<i>laser_temp_alm_hi</i>	(Optional) Laser Temperature Alarm High
<i>laser_temp_alm_lo</i>	(Optional) Laser Temperature Alarm Low
<i>laser_temp_warn_hi</i>	(Optional) Laser Temperature Warning High
<i>laser_temp_warn_lo</i>	(Optional) Laser Temperature Warning Low
<i>pre_fec_ber_acc</i>	(Optional) Pre-FEC BER Acc
<i>pre_fec_ber_acc_flag</i>	(Optional) Pre-FEC BER Acc flag
<i>pre_fec_ber_acc_alm_hi</i>	(Optional) Pre-FEC BER Acc alarm high
<i>pre_fec_ber_acc_alm_lo</i>	(Optional) Pre-FEC BER Acc alarm low

<i>pre_fec_ber_acc_warn_hi</i>	(Optional) Pre-FEC BER Acc warning high
<i>pre_fec_ber_acc_warn_lo</i>	(Optional) Pre-FEC BER Acc warning low
<i>pre_fec_ber_min</i>	(Optional) Pre-FEC BER Min
<i>pre_fec_ber_min_flag</i>	(Optional) Pre-FEC BER Min flag
<i>pre_fec_ber_min_alm_hi</i>	(Optional) Pre-FEC BER Min alarm high
<i>pre_fec_ber_min_alm_lo</i>	(Optional) Pre-FEC BER Min alarm low
<i>pre_fec_ber_min_warn_hi</i>	(Optional) Pre-FEC BER Min warning high
<i>pre_fec_ber_min_warn_lo</i>	(Optional) Pre-FEC BER Min warning low
<i>pre_fec_ber_max</i>	(Optional) Pre-FEC BER Max
<i>pre_fec_ber_max_flag</i>	(Optional) Pre-FEC BER Max flag
<i>pre_fec_ber_max_alm_hi</i>	(Optional) Pre-FEC BER Max alarm high
<i>pre_fec_ber_max_alm_lo</i>	(Optional) Pre-FEC BER Max alarm low
<i>pre_fec_ber_max_warn_hi</i>	(Optional) Pre-FEC BER Max warning high
<i>pre_fec_ber_max_warn_lo</i>	(Optional) Pre-FEC BER Max warning low
<i>pre_fec_ber_cur</i>	(Optional) Pre-FEC BER Cur
<i>pre_fec_ber_cur_flag</i>	(Optional) Pre-FEC BER Cur flag
<i>pre_fec_ber_cur_alm_hi</i>	(Optional) Pre-FEC BER Cur alarm high
<i>pre_fec_ber_cur_alm_lo</i>	(Optional) Pre-FEC BER Cur alarm low
<i>pre_fec_ber_cur_warn_hi</i>	(Optional) Pre-FEC BER Cur warning high
<i>pre_fec_ber_cur_warn_lo</i>	(Optional) Pre-FEC BER Cur warning low
<i>uncorrect_ber_acc</i>	(Optional) Uncorrected BER Acc
<i>uncorrect_ber_acc_flag</i>	(Optional) Uncorrected BER Acc flag
<i>uncorrect_ber_acc_alm_hi</i>	(Optional) Uncorrected BER Acc alarm high
<i>uncorrect_ber_acc_alm_lo</i>	(Optional) Uncorrected BER Acc alarm low
<i>uncorrect_ber_acc_warn_hi</i>	(Optional) Uncorrected BER Acc warning high
<i>uncorrect_ber_acc_warn_lo</i>	(Optional) Uncorrected BER Acc warning low
<i>uncorrect_ber_min</i>	(Optional) Uncorrected BER Min
<i>uncorrect_ber_min_flag</i>	(Optional) Uncorrected BER Min flag
<i>uncorrect_ber_min_alm_hi</i>	(Optional) Uncorrected BER Min alarm high

<i>uncorrect_ber_min_alm_lo</i>	(Optional) Uncorrected BER Min alarm low
<i>uncorrect_ber_min_warn_hi</i>	(Optional) Uncorrected BER Min warning high
<i>uncorrect_ber_min_warn_lo</i>	(Optional) Uncorrected BER Min warning low
<i>uncorrect_ber_max</i>	(Optional) Uncorrected BER Max
<i>uncorrect_ber_max_flag</i>	(Optional) Uncorrected BER Max flag
<i>uncorrect_ber_max_alm_hi</i>	(Optional) Uncorrected BER Max alarm high
<i>uncorrect_ber_max_alm_lo</i>	(Optional) Uncorrected BER Max alarm low
<i>uncorrect_ber_max_warn_hi</i>	(Optional) Uncorrected BER Max warning high
<i>uncorrect_ber_max_warn_lo</i>	(Optional) Uncorrected BER Max warning low
<i>uncorrect_ber_cur</i>	(Optional) Uncorrected BER Cur
<i>uncorrect_ber_cur_flag</i>	(Optional) Uncorrected BER Cur flag
<i>uncorrect_ber_cur_alm_hi</i>	(Optional) Uncorrected BER Cur alarm high
<i>uncorrect_ber_cur_alm_lo</i>	(Optional) Uncorrected BER Cur alarm low
<i>uncorrect_ber_cur_warn_hi</i>	(Optional) Uncorrected BER Cur warning high
<i>uncorrect_ber_cur_warn_lo</i>	(Optional) Uncorrected BER Cur warning low

Command Mode

- /exec

show interface transceiver

```
show interface <ifid_trns_fc> transceiver [ calibrations | details ] [ __readonly__ TABLE_interface
<interface_fc> [ <sfp_fc> ] [ <type_fc> ] [ <name_fc> ] [ <partnum_fc> ] [ <rev_fc> ] [ <serialnum_fc> ] [
<cisco_partnum_fc> ] [ <cisco_pid_fc> ] [ <tx_type_fc> ] [ <tx_len_fc> ] [ <tx_medium_fc> ] [ <tx_speeds_fc> ] [
<nom_bitrate_fc> ] [ <len_9_fc> ] [ <len_50_fc> ] [ <len_625_fc> ] [ <len_50_OM3_fc> ] [
<cisco_ext_id_fc> ] [ <txcvr_type_fc> ] [ <connector_type_fc> ] [ <bit_encoding_fc> ] [ <protocol_type_fc> ] [
<10gbe_code_fc> ] [ <fiber_type_byte0_fc> ] [ <fiber_type_byte1_fc> ] [ <tx_range_fc> ] [
<temp_slope_fc> ] [ <temp_offset_fc> ] [ <volt_slope_fc> ] [ <volt_offset_fc> ] [ <curr_slope_fc> ] [
<curr_offset_fc> ] [ <tx_pwr_slope_fc> ] [ <tx_pwr_offset_fc> ] [ <rx_pwr_4_fc> ] [ <rx_pwr_3_fc> ] [
<rx_pwr_2_fc> ] [ <rx_pwr_1_fc> ] [ <rx_pwr_0_fc> ] [ <temperature_fc> ] [ <temp_flag_fc> ] [
<temp_alm_hi_fc> ] [ <temp_alm_lo_fc> ] [ <temp_warn_hi_fc> ] [ <temp_warn_lo_fc> ] [ <voltage_fc> ] [
<volt_flag_fc> ] [ <volt_alm_hi_fc> ] [ <volt_alm_lo_fc> ] [ <volt_warn_hi_fc> ] [ <volt_warn_lo_fc> ] [
<current_fc> ] [ <current_flag_fc> ] [ <current_alm_hi_fc> ] [ <current_alm_lo_fc> ] [
<current_warn_hi_fc> ] [ <current_warn_lo_fc> ] [ <tx_pwr_fc> ] [ <tx_pwr_flag_fc> ] [ <tx_pwr_alm_hi_fc> ] [
<tx_pwr_alm_lo_fc> ] [ <tx_pwr_warn_hi_fc> ] [ <tx_pwr_warn_lo_fc> ] [ <rx_pwr_fc> ] [
<rx_pwr_flag_fc> ] [ <rx_pwr_alm_hi_fc> ] [ <rx_pwr_alm_lo_fc> ] [ <rx_pwr_warn_hi_fc> ] [
<rx_pwr_warn_lo_fc> ] [ <xmit_faults_fc> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_trns_fc</i>	Enter interface type and number in module/slot format
transceiver	Show interface transceiver information
calibrations	(Optional) Show interface transceiver calibration information
details	(Optional) Show interface transceiver detail information
__readonly__	(Optional) Read Only
<i>interface_fc</i>	(Optional) Interface index
TABLE_interface	(Optional) show interface
<i>sfp_fc</i>	(Optional) sfp
<i>type_fc</i>	(Optional) type
<i>name_fc</i>	(Optional) Name
<i>partnum_fc</i>	(Optional) part number
<i>rev_fc</i>	(Optional) revision
<i>serialnum_fc</i>	(Optional) serial number
<i>cisco_partnum_fc</i>	(Optional) Cisco part number
<i>cisco_pid_fc</i>	(Optional) Cisco PID

<i>tx_type_fc</i>	(Optional) FC Transmitter type
<i>tx_len_fc</i>	(Optional) FC Transmitter length
<i>tx_medium_fc</i>	(Optional) FC Transmitter medium
<i>tx_speeds_fc</i>	(Optional) Transmission speeds
<i>nom_bitrate_fc</i>	(Optional) Nominal bit rate in MBits/sec
<i>len_9_fc</i>	(Optional) Link length supported for 9/125um fiber
<i>len_50_fc</i>	(Optional) Link length supported for 50/125um fiber
<i>len_625_fc</i>	(Optional) Link length supported for 62.5/125um fiber
<i>len_50_OM3_fc</i>	(Optional) Link length supported for 50/125um fiber in m
<i>cisco_ext_id_fc</i>	(Optional) Cisco extended ID
<i>txcvr_type_fc</i>	(Optional) Transceiver type
<i>connector_type_fc</i>	(Optional) Connector type
<i>bit_encoding_fc</i>	(Optional) Bit encoding
<i>protocol_type_fc</i>	(Optional) Protocol type
<i>10gbe_code_fc</i>	(Optional) 10GbE code byte
<i>fiber_type_byte0_fc</i>	(Optional) Fiber Type Byte 0
<i>fiber_type_byte1_fc</i>	(Optional) Fiber Type Byte 1
<i>tx_range_fc</i>	(Optional) Transmission Range
<i>temp_slope_fc</i>	(Optional) Temperature slope
<i>temp_offset_fc</i>	(Optional) Temperature offset
<i>volt_slope_fc</i>	(Optional) Voltage slope
<i>volt_offset_fc</i>	(Optional) Voltage offset
<i>curr_slope_fc</i>	(Optional) Current slope
<i>curr_offset_fc</i>	(Optional) Current offset
<i>tx_pwr_slope_fc</i>	(Optional) Tx power slope
<i>tx_pwr_offset_fc</i>	(Optional) Tx power offset
<i>rx_pwr_4_fc</i>	(Optional) Rx power 4
<i>rx_pwr_3_fc</i>	(Optional) Rx power 3
<i>rx_pwr_2_fc</i>	(Optional) Rx power 2

<i>rx_pwr_1_fc</i>	(Optional) Rx power 1
<i>rx_pwr_0_fc</i>	(Optional) Rx power 0
<i>temperature_fc</i>	(Optional) Temperature
<i>temp_flag_fc</i>	(Optional) Temperature Flag
<i>temp_alm_hi_fc</i>	(Optional) Temperature Alarm High
<i>temp_alm_lo_fc</i>	(Optional) Temperature Alarm Low
<i>temp_warn_hi_fc</i>	(Optional) Temperature Warning High
<i>temp_warn_lo_fc</i>	(Optional) Temperature Warning Low
<i>voltage_fc</i>	(Optional) Voltage
<i>volt_flag_fc</i>	(Optional) Voltage Flag
<i>volt_alm_hi_fc</i>	(Optional) Voltage Alarm High
<i>volt_alm_lo_fc</i>	(Optional) Voltage Alarm Low
<i>volt_warn_hi_fc</i>	(Optional) Voltage Warning High
<i>volt_warn_lo_fc</i>	(Optional) Voltage Warning Low
<i>current_fc</i>	(Optional) Current
<i>current_flag_fc</i>	(Optional) Current Flag
<i>current_alm_hi_fc</i>	(Optional) Current Alarm High
<i>current_alm_lo_fc</i>	(Optional) Current Alarm Low
<i>current_warn_hi_fc</i>	(Optional) Current Warning High
<i>current_warn_lo_fc</i>	(Optional) Current Warning Low
<i>tx_pwr_fc</i>	(Optional) Tx Power
<i>tx_pwr_flag_fc</i>	(Optional) Tx Power Flag
<i>tx_pwr_alm_hi_fc</i>	(Optional) Tx Power Alarm High
<i>tx_pwr_alm_lo_fc</i>	(Optional) Tx Power Alarm Low
<i>tx_pwr_warn_hi_fc</i>	(Optional) Tx Power Warning High
<i>tx_pwr_warn_lo_fc</i>	(Optional) Tx Power Warning Low
<i>rx_pwr_fc</i>	(Optional) Rx Power
<i>rx_pwr_flag_fc</i>	(Optional) Rx Power Flag
<i>rx_pwr_alm_hi_fc</i>	(Optional) Rx Power Alarm High

<i>rx_pwr_alrm_lo_fc</i>	(Optional) Rx Power Alarm Low
<i>rx_pwr_warn_hi_fc</i>	(Optional) Rx Power Warning High
<i>rx_pwr_warn_lo_fc</i>	(Optional) Rx Power Warning Low
<i>xmit_faults_fc</i>	(Optional) Transmit Fault Count

Command Mode

- /exec

show interface transceiver

```

show interface transceiver [ calibrations | details ] [ __readonly__ TABLE_interface <interface> [ <sfp> ] [
<type> ] [ <name> ] [ <partnum> ] [ <rev> ] [ <serialnum> ] [ <nom_bitrate> ] [ <len_9> ] [ <len_50> ] [
<len_625> ] [ <len_cu> ] [ <len_50_OM3> ] [ <txcvr_type> ] [ <connector_type> ] [ <bit_encoding> ] [
<protocol_type> ] [ <10gbe_code> ] [ <fiber_type_byte0> ] [ <fiber_type_byte1> ] [ <tx_type> ] [ <tx_len> ]
] [ <tx_medium> ] [ <tx_speeds> ] [ <tx_range> ] [ <cable_type> ] [ <ciscoid> ] [ <ciscoid_1> ] [
<cisco_part_number> ] [ <cisco_product_id> ] [ <cisco_vendor_id> ] [ <cisco_ext_id> ] [ <info_not_available> ]
] [ <temp_slope> ] [ <temp_offset> ] [ <volt_slope> ] [ <volt_offset> ] [ <curr_slope> ] [ <curr_offset> ] [
<tx_pwr_slope> ] [ <tx_pwr_offset> ] [ <rx_pwr_4> ] [ <rx_pwr_3> ] [ <rx_pwr_2> ] [ <rx_pwr_1> ] [
<rx_pwr_0> ] [ TABLE_lane [ <lane_number> ] [ <temperature> ] [ <temp_flag> ] [ <temp_alm_hi> ] [
<temp_alm_lo> ] [ <temp_warn_hi> ] [ <temp_warn_lo> ] [ <voltage> ] [ <volt_flag> ] [ <volt_alm_hi> ]
] [ <volt_alm_lo> ] [ <volt_warn_hi> ] [ <volt_warn_lo> ] [ <current> ] [ <current_flag> ] [ <current_alm_hi> ]
] [ <current_alm_lo> ] [ <current_warn_hi> ] [ <current_warn_lo> ] [ <tx_pwr> ] [ <tx_pwr_flag> ] [
<tx_pwr_alm_hi> ] [ <tx_pwr_alm_lo> ] [ <tx_pwr_warn_hi> ] [ <tx_pwr_warn_lo> ] [ <rx_pwr> ] [
<rx_pwr_flag> ] [ <rx_pwr_alm_hi> ] [ <rx_pwr_alm_lo> ] [ <rx_pwr_warn_hi> ] [ <rx_pwr_warn_lo> ]
] [ <xmit_faults> ] [ <snr> ] [ <snr_flag> ] [ <snr_alm_hi> ] [ <snr_alm_lo> ] [ <snr_warn_hi> ] [
<snr_warn_lo> ] [ <isi> ] [ <isi_flag> ] [ <isi_alm_hi> ] [ <isi_alm_lo> ] [ <isi_warn_hi> ] [ <isi_warn_lo> ]
] [ <pam> ] [ <pam_flag> ] [ <pam_alm_hi> ] [ <pam_alm_lo> ] [ <pam_warn_hi> ] [ <pam_warn_lo> ] [
<pre_fec_ber> ] [ <pre_fec_ber_flag> ] [ <pre_fec_ber_alm_hi> ] [ <pre_fec_ber_alm_lo> ] [
<pre_fec_ber_warn_hi> ] [ <pre_fec_ber_warn_lo> ] [ <uncorrect_ber> ] [ <uncorrect_ber_flag> ] [
<uncorrect_ber_alm_hi> ] [ <uncorrect_ber_alm_lo> ] [ <uncorrect_ber_warn_hi> ] [
<uncorrect_ber_warn_lo> ] [ <tec_current> ] [ <tec_current_flag> ] [ <tec_current_alm_hi> ] [
<tec_current_alm_lo> ] [ <tec_current_warn_hi> ] [ <tec_current_warn_lo> ] [ <laser_freq> ] [
<laser_freq_flag> ] [ <laser_freq_alm_hi> ] [ <laser_freq_alm_lo> ] [ <laser_freq_warn_hi> ] [
<laser_freq_warn_lo> ] [ <laser_temp> ] [ <laser_temp_flag> ] [ <laser_temp_alm_hi> ] [
<laser_temp_alm_lo> ] [ <laser_temp_warn_hi> ] [ <laser_temp_warn_lo> ] [ <pre_fec_ber_acc> ] [
<pre_fec_ber_acc_flag> ] [ <pre_fec_ber_acc_alm_hi> ] [ <pre_fec_ber_acc_alm_lo> ] [
<pre_fec_ber_acc_warn_hi> ] [ <pre_fec_ber_acc_warn_lo> ] [ <pre_fec_ber_min> ] [ <pre_fec_ber_min_flag> ]
] [ <pre_fec_ber_min_alm_hi> ] [ <pre_fec_ber_min_alm_lo> ] [ <pre_fec_ber_min_warn_hi> ] [
<pre_fec_ber_min_warn_lo> ] [ <pre_fec_ber_max> ] [ <pre_fec_ber_max_flag> ] [
<pre_fec_ber_max_alm_hi> ] [ <pre_fec_ber_max_alm_lo> ] [ <pre_fec_ber_max_warn_hi> ] [
<pre_fec_ber_max_warn_lo> ] [ <pre_fec_ber_cur> ] [ <pre_fec_ber_cur_flag> ] [ <pre_fec_ber_cur_alm_hi> ]
] [ <pre_fec_ber_cur_alm_lo> ] [ <pre_fec_ber_cur_warn_hi> ] [ <pre_fec_ber_cur_warn_lo> ] [
<uncorrect_ber_acc> ] [ <uncorrect_ber_acc_flag> ] [ <uncorrect_ber_acc_alm_hi> ] [
<uncorrect_ber_acc_alm_lo> ] [ <uncorrect_ber_acc_warn_hi> ] [ <uncorrect_ber_acc_warn_lo> ] [
<uncorrect_ber_min> ] [ <uncorrect_ber_min_flag> ] [ <uncorrect_ber_min_alm_hi> ] [
<uncorrect_ber_min_alm_lo> ] [ <uncorrect_ber_min_warn_hi> ] [ <uncorrect_ber_min_warn_lo> ] [
<uncorrect_ber_max> ] [ <uncorrect_ber_max_flag> ] [ <uncorrect_ber_max_alm_hi> ] [
<uncorrect_ber_max_alm_lo> ] [ <uncorrect_ber_max_warn_hi> ] [ <uncorrect_ber_max_warn_lo> ] [
<uncorrect_ber_cur> ] [ <uncorrect_ber_cur_flag> ] [ <uncorrect_ber_cur_alm_hi> ] [
<uncorrect_ber_cur_alm_lo> ] [ <uncorrect_ber_cur_warn_hi> ] [ <uncorrect_ber_cur_warn_lo> ] ] ]

```

Syntax Description

show	Show running system information
interface	Show interface status and information
transceiver	Show interface transceiver information

<i>calibrations</i>	(Optional) Show interface transceiver calibration information
<i>details</i>	(Optional) Show interface transceiver detail information
<i>__readonly__</i>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_ <i>interface</i>	(Optional) show interface
<i>sfp</i>	(Optional) sfp
<i>type</i>	(Optional) type
<i>name</i>	(Optional) Name
<i>partnum</i>	(Optional) part number
<i>rev</i>	(Optional) revision
<i>serialnum</i>	(Optional) serial number
<i>nom_bitrate</i>	(Optional) Nominal bit rate in MBits/sec
<i>len_9</i>	(Optional) Link length supported for 9/125um fiber
<i>len_50</i>	(Optional) Link length supported for 50/125um fiber
<i>len_625</i>	(Optional) Link length supported for 62.5/125um fiber
<i>len_cu</i>	(Optional) Link length supported for copper
<i>len_50_OM3</i>	(Optional) Link length supported for 50/125um fiber in m
<i>txcvr_type</i>	(Optional)
<i>connector_type</i>	(Optional)
<i>bit_encoding</i>	(Optional)
<i>protocol_type</i>	(Optional)
<i>10gbe_code</i>	(Optional)
<i>fiber_type_byte0</i>	(Optional)
<i>fiber_type_byte1</i>	(Optional)
<i>tx_type</i>	(Optional) FC Transmitter type
<i>tx_len</i>	(Optional) FC Transmitter length
<i>tx_medium</i>	(Optional) FC Transmitter medium
<i>tx_speeds</i>	(Optional) Transmission speeds
<i>tx_range</i>	(Optional) Transmission range

<i>cable_type</i>	(Optional)
<i>ciscoid</i>	(Optional) Cisco extended id
<i>ciscoid_1</i>	(Optional) Cisco extended id number
<i>cisco_part_number</i>	(Optional) Cisco part number
<i>cisco_product_id</i>	(Optional) Cisco product identifier
<i>cisco_vendor_id</i>	(Optional) Cisco vendor identifier
<i>cisco_ext_id</i>	(Optional) Cisco extended ID
<i>info_not_available</i>	(Optional) No info available for this transceiver
<i>temp_slope</i>	(Optional) Temperature slope
<i>temp_offset</i>	(Optional) Temperature offset
<i>volt_slope</i>	(Optional) Voltage slope
<i>volt_offset</i>	(Optional) Voltage offset
<i>curr_slope</i>	(Optional) Current slope
<i>curr_offset</i>	(Optional) Current offset
<i>tx_pwr_slope</i>	(Optional) Tx power slope
<i>tx_pwr_offset</i>	(Optional) Tx power offset
<i>rx_pwr_4</i>	(Optional) Rx power 4
<i>rx_pwr_3</i>	(Optional) Rx power 3
<i>rx_pwr_2</i>	(Optional) Rx power 2
<i>rx_pwr_1</i>	(Optional) Rx power 1
<i>rx_pwr_0</i>	(Optional) Rx power 0
TABLE_lane	(Optional) show lane
<i>lane_number</i>	(Optional) Lane number
<i>temperature</i>	(Optional) Temperature
<i>temp_flag</i>	(Optional) Temperature Flag
<i>temp_alarm_hi</i>	(Optional) Temperature Alarm High
<i>temp_alarm_lo</i>	(Optional) Temperature Alarm Low
<i>temp_warn_hi</i>	(Optional) Temperature Warning High
<i>temp_warn_lo</i>	(Optional) Temperature Warning Low

<i>voltage</i>	(Optional) Voltage
<i>volt_flag</i>	(Optional) Voltage Flag
<i>volt_alarm_hi</i>	(Optional) Voltage Alarm High
<i>volt_alarm_lo</i>	(Optional) Voltage Alarm Low
<i>volt_warn_hi</i>	(Optional) Voltage Warning High
<i>volt_warn_lo</i>	(Optional) Voltage Warning Low
<i>current</i>	(Optional) Current
<i>current_flag</i>	(Optional) Current Flag
<i>current_alarm_hi</i>	(Optional) Current Alarm High
<i>current_alarm_lo</i>	(Optional) Current Alarm Low
<i>current_warn_hi</i>	(Optional) Current Warning High
<i>current_warn_lo</i>	(Optional) Current Warning Low
<i>tx_pwr</i>	(Optional) Tx Power
<i>tx_pwr_flag</i>	(Optional) Tx Power Flag
<i>tx_pwr_alarm_hi</i>	(Optional) Tx Power Alarm High
<i>tx_pwr_alarm_lo</i>	(Optional) Tx Power Alarm Low
<i>tx_pwr_warn_hi</i>	(Optional) Tx Power Warning High
<i>tx_pwr_warn_lo</i>	(Optional) Tx Power Warning Low
<i>rx_pwr</i>	(Optional) Rx Power
<i>rx_pwr_flag</i>	(Optional) Rx Power Flag
<i>rx_pwr_alarm_hi</i>	(Optional) Rx Power Alarm High
<i>rx_pwr_alarm_lo</i>	(Optional) Rx Power Alarm Low
<i>rx_pwr_warn_hi</i>	(Optional) Rx Power Warning High
<i>rx_pwr_warn_lo</i>	(Optional) Rx Power Warning Low
<i>xmit_faults</i>	(Optional) Transmit Fault Count
<i>snr</i>	(Optional) RX Signal-to-Noise Ratio (SNR)
<i>snr_flag</i>	(Optional) SNR Flag
<i>snr_alarm_hi</i>	(Optional) SNR Alarm High
<i>snr_alarm_lo</i>	(Optional) SNR Alarm Low

<i>snr_warn_hi</i>	(Optional) SNR Warning High
<i>snr_warn_lo</i>	(Optional) SNR Warning Low
<i>isi</i>	(Optional) Residual-Dispersion(ISI)
<i>isi_flag</i>	(Optional) ISI Flag
<i>isi_alm_hi</i>	(Optional) ISI alarm high
<i>isi_alm_lo</i>	(Optional) ISI alarm low
<i>isi_warn_hi</i>	(Optional) ISI warning high
<i>isi_warn_lo</i>	(Optional) ISI warning low
<i>pam</i>	(Optional) PAM Transition
<i>pam_flag</i>	(Optional) PAM Flag
<i>pam_alm_hi</i>	(Optional) PAM alarm high
<i>pam_alm_lo</i>	(Optional) PAM alarm low
<i>pam_warn_hi</i>	(Optional) PAM warning high
<i>pam_warn_lo</i>	(Optional) PAM warning low
<i>pre_fec_ber</i>	(Optional) Pre-FEC BER
<i>pre_fec_ber_flag</i>	(Optional) Pre-FEC BER flag
<i>pre_fec_ber_alm_hi</i>	(Optional) Pre-FEC BER alarm high
<i>pre_fec_ber_alm_lo</i>	(Optional) Pre-FEC BER alarm low
<i>pre_fec_ber_warn_hi</i>	(Optional) Pre-FEC BER warning high
<i>pre_fec_ber_warn_lo</i>	(Optional) Pre-FEC BER warning low
<i>uncorrect_ber</i>	(Optional) Uncorrected BER
<i>uncorrect_ber_flag</i>	(Optional) Uncorrected BER flag
<i>uncorrect_ber_alm_hi</i>	(Optional) Uncorrected BER alarm high
<i>uncorrect_ber_alm_lo</i>	(Optional) Uncorrected BER alarm low
<i>uncorrect_ber_warn_hi</i>	(Optional) Uncorrected BER warning high
<i>uncorrect_ber_warn_lo</i>	(Optional) Uncorrected BER warning low
<i>tec_current</i>	(Optional) TEC Current
<i>tec_current_flag</i>	(Optional) TEC Current flag
<i>tec_current_alm_hi</i>	(Optional) TEC Current Alarm High

<i>tec_current_alm_lo</i>	(Optional) TEC Current Alarm Low
<i>tec_current_warn_hi</i>	(Optional) TEC Current Warning High
<i>tec_current_warn_lo</i>	(Optional) TEC Current Warning Low
<i>laser_freq</i>	(Optional) Laser Frequency
<i>laser_freq_flag</i>	(Optional) Laser Frequency flag
<i>laser_freq_alm_hi</i>	(Optional) Laser Frequency Alarm High
<i>laser_freq_alm_lo</i>	(Optional) Laser Frequency Alarm Low
<i>laser_freq_warn_hi</i>	(Optional) Laser Frequency Warning High
<i>laser_freq_warn_lo</i>	(Optional) Laser Frequency Warning Low
<i>laser_temp</i>	(Optional) Laser Temperature
<i>laser_temp_flag</i>	(Optional) Laser Temperature flag
<i>laser_temp_alm_hi</i>	(Optional) Laser Temperature Alarm High
<i>laser_temp_alm_lo</i>	(Optional) Laser Temperature Alarm Low
<i>laser_temp_warn_hi</i>	(Optional) Laser Temperature Warning High
<i>laser_temp_warn_lo</i>	(Optional) Laser Temperature Warning Low
<i>pre_fec_ber_acc</i>	(Optional) Pre-FEC BER Acc
<i>pre_fec_ber_acc_flag</i>	(Optional) Pre-FEC BER Acc flag
<i>pre_fec_ber_acc_alm_hi</i>	(Optional) Pre-FEC BER Acc alarm high
<i>pre_fec_ber_acc_alm_lo</i>	(Optional) Pre-FEC BER Acc alarm low
<i>pre_fec_ber_acc_warn_hi</i>	(Optional) Pre-FEC BER Acc warning high
<i>pre_fec_ber_acc_warn_lo</i>	(Optional) Pre-FEC BER Acc warning low
<i>pre_fec_ber_min</i>	(Optional) Pre-FEC BER Min
<i>pre_fec_ber_min_flag</i>	(Optional) Pre-FEC BER Min flag
<i>pre_fec_ber_min_alm_hi</i>	(Optional) Pre-FEC BER Min alarm high
<i>pre_fec_ber_min_alm_lo</i>	(Optional) Pre-FEC BER Min alarm low
<i>pre_fec_ber_min_warn_hi</i>	(Optional) Pre-FEC BER Min warning high
<i>pre_fec_ber_min_warn_lo</i>	(Optional) Pre-FEC BER Min warning low
<i>pre_fec_ber_max</i>	(Optional) Pre-FEC BER Max
<i>pre_fec_ber_max_flag</i>	(Optional) Pre-FEC BER Max flag

<i>pre_fec_ber_max_alm_hi</i>	(Optional) Pre-FEC BER Max alarm high
<i>pre_fec_ber_max_alm_lo</i>	(Optional) Pre-FEC BER Max alarm low
<i>pre_fec_ber_max_warn_hi</i>	(Optional) Pre-FEC BER Max warning high
<i>pre_fec_ber_max_warn_lo</i>	(Optional) Pre-FEC BER Max warning low
<i>pre_fec_ber_cur</i>	(Optional) Pre-FEC BER Cur
<i>pre_fec_ber_cur_flag</i>	(Optional) Pre-FEC BER Cur flag
<i>pre_fec_ber_cur_alm_hi</i>	(Optional) Pre-FEC BER Cur alarm high
<i>pre_fec_ber_cur_alm_lo</i>	(Optional) Pre-FEC BER Cur alarm low
<i>pre_fec_ber_cur_warn_hi</i>	(Optional) Pre-FEC BER Cur warning high
<i>pre_fec_ber_cur_warn_lo</i>	(Optional) Pre-FEC BER Cur warning low
<i>uncorrect_ber_acc</i>	(Optional) Uncorrected BER Acc
<i>uncorrect_ber_acc_flag</i>	(Optional) Uncorrected BER Acc flag
<i>uncorrect_ber_acc_alm_hi</i>	(Optional) Uncorrected BER Acc alarm high
<i>uncorrect_ber_acc_alm_lo</i>	(Optional) Uncorrected BER Acc alarm low
<i>uncorrect_ber_acc_warn_hi</i>	(Optional) Uncorrected BER Acc warning high
<i>uncorrect_ber_acc_warn_lo</i>	(Optional) Uncorrected BER Acc warning low
<i>uncorrect_ber_min</i>	(Optional) Uncorrected BER Min
<i>uncorrect_ber_min_flag</i>	(Optional) Uncorrected BER Min flag
<i>uncorrect_ber_min_alm_hi</i>	(Optional) Uncorrected BER Min alarm high
<i>uncorrect_ber_min_alm_lo</i>	(Optional) Uncorrected BER Min alarm low
<i>uncorrect_ber_min_warn_hi</i>	(Optional) Uncorrected BER Min warning high
<i>uncorrect_ber_min_warn_lo</i>	(Optional) Uncorrected BER Min warning low
<i>uncorrect_ber_max</i>	(Optional) Uncorrected BER Max
<i>uncorrect_ber_max_flag</i>	(Optional) Uncorrected BER Max flag
<i>uncorrect_ber_max_alm_hi</i>	(Optional) Uncorrected BER Max alarm high
<i>uncorrect_ber_max_alm_lo</i>	(Optional) Uncorrected BER Max alarm low
<i>uncorrect_ber_max_warn_hi</i>	(Optional) Uncorrected BER Max warning high
<i>uncorrect_ber_max_warn_lo</i>	(Optional) Uncorrected BER Max warning low
<i>uncorrect_ber_cur</i>	(Optional) Uncorrected BER Cur

<i>uncorrect_ber_cur_flag</i>	(Optional) Uncorrected BER Cur flag
<i>uncorrect_ber_cur_alm_hi</i>	(Optional) Uncorrected BER Cur alarm high
<i>uncorrect_ber_cur_alm_lo</i>	(Optional) Uncorrected BER Cur alarm low
<i>uncorrect_ber_cur_warn_hi</i>	(Optional) Uncorrected BER Cur warning high
<i>uncorrect_ber_cur_warn_lo</i>	(Optional) Uncorrected BER Cur warning low

Command Mode

- /exec

show interface trunk

```
show interface <ifeth_trnk> trunk [ __readonly__ { TABLE_interface <interface> <native> <status>
<portchannel> } { TABLE_allowed_vlans <interface> <allowedvlans> } { TABLE_errored_vlans <interface>
<erroredvlans> } { TABLE_stp_forward <interface> <stpfwd_vlans> } [ { TABLE_fabricpath_vlans
<interface> <fabricpath_vlans> } ] { TABLE_vtp_pruning <interface> <vtppruning_vlans> } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifeth_trnk</i>	Enter interface type and number in module/slot format
trunk	Show interface trunk information
__readonly__	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>native</i>	(Optional) Native VLAN
<i>status</i>	(Optional) Status
<i>portchannel</i>	(Optional) Port Channel
TABLE_allowed_vlans	(Optional) show allowed vlans
<i>interface</i>	(Optional) Interface index
<i>allowedvlans</i>	(Optional) VLANs allowed and active in management domain
TABLE_errored_vlans	(Optional) show errored vlans
<i>interface</i>	(Optional) Interface index
<i>erroredvlans</i>	(Optional) Errored VLANs
TABLE_stp_forward	(Optional) show STP forwarding VLANs
<i>interface</i>	(Optional) Interface index
<i>stpfwd_vlans</i>	(Optional) STP Forwarding VLANs
TABLE_fabricpath_vlans	(Optional) show fabricpath VLANs
<i>interface</i>	(Optional) Interface index
<i>fabricpath_vlans</i>	(Optional) FabricPath VLANs
TABLE_vtp_pruning	(Optional) show VTP pruning VLANs

<i>interface</i>	(Optional) Interface index
<i>vtppruning_vlans</i>	(Optional) VTP Pruning VLANs

Command Mode

- /exec

show interface trunk

```
show interface trunk [ module <module> | vlan <vlan_id> | fex <fex_num> ] [ __readonly__ [ {
TABLE_interface <interface> <native> <status> <portchannel> } ] [ { TABLE_allowed_vlans <interface>
<allowedvlans> } ] [ { TABLE_errored_vlans <interface> <erroredvlans> } ] [ { TABLE_stp_forward
<interface> <stpfwd_vlans> } ] [ { TABLE_fabricpath_vlans <interface> <fabricpath_vlans> } ] [ {
TABLE_vtp_pruning <interface> <vtppruning_vlans> } ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
trunk	Show interface trunk information
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
fex	(Optional) Limit display to interfaces on a FEX
<i>fex_num</i>	(Optional) Enter FEX number
vlan	(Optional) Show per vlan information for trunk
<i>vlan_id</i>	(Optional) Enter vlan range
<i>interface</i>	(Optional) Interface index
<i>__readonly__</i>	(Optional) Read Only
TABLE_interface	(Optional) show interface
<i>interface</i>	(Optional) Interface index
<i>native</i>	(Optional) Native VLAN
<i>status</i>	(Optional) Status
<i>portchannel</i>	(Optional) Port Channel
TABLE_allowed_vlans	(Optional) show allowed vlans
<i>interface</i>	(Optional) Interface index
<i>allowedvlans</i>	(Optional) VLANs allowed and active in management domain
TABLE_errored_vlans	(Optional) show errored vlans
<i>interface</i>	(Optional) Interface index
<i>erroredvlans</i>	(Optional) Errored VLANs
TABLE_stp_forward	(Optional) show STP forwarding VLANs

<i>interface</i>	(Optional) Interface index
<i>stp fwd_vlans</i>	(Optional) STP Forwarding VLANs
TABLE_fabricpath_vlans	(Optional) show fabricpath VLANs
<i>interface</i>	(Optional) Interface index
<i>fabricpath_vlans</i>	(Optional) FabricPath VLANs
TABLE_vtp_pruning	(Optional) show VTP pruning VLANs
<i>vtp pruning_vlans</i>	(Optional) VTP Pruning VLANs

Command Mode

- /exec

show interface trunk vsan

```
show interface <ifid_trnk> trunk vsan [ <vsan_id> ] [ __readonly__ { TABLE_interface_trunk [ <interface>
] [ <oper_state> ] [ <oper_state_reason> ] [ <bundle_str> ] [ TABLE_vsan_info { [ <vsan_num> ] [
<vsan_state> ] [ <vsan_state_reason> ] [ <fcid> ] } } ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_trnk</i>	Enter interface type and number in module/slot format
trunk	Show interface trunk information
vsan	Show per vsan information for trunk
<i>vsan_id</i>	(Optional) Enter vsan range
<i>__readonly__</i>	(Optional) Read Only
TABLE_interface_trunk	(Optional) interface trunk table
<i>interface</i>	(Optional) fc interface
<i>oper_state</i>	(Optional) the status of trunking
<i>oper_state_reason</i>	(Optional) reason for operation state
<i>bundle_str</i>	(Optional) bundle string
TABLE_vsan_info	(Optional) vsan information
<i>vsan_num</i>	(Optional) the vsan ID
<i>vsan_state</i>	(Optional) the ststus of vsan
<i>vsan_state_reason</i>	(Optional) reason for vsan state
<i>fcid</i>	(Optional) FCID

Command Mode

- /exec

show interface trunk vsan

```
show interface trunk vsan [ <vsan_id> ] [ __readonly__ { TABLE_interface_trunk [ <interface> ] [ <oper_state> ] [ <oper_state_reason> ] [ <bundle_str> ] [ TABLE_vsan_info { [ <vsan_num> ] [ <vsan_state> ] [ <vsan_state_reason> ] [ <fcid> ] } } ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
trunk	Show interface trunk information
vsan	Show per vsan information for trunk
<i>vsan_id</i>	(Optional) Enter vsan range
<i>__readonly__</i>	(Optional)
TABLE_interface_trunk	(Optional) interface trunk table
<i>interface</i>	(Optional) fc interface
<i>oper_state</i>	(Optional) the status of trunking
<i>oper_state_reason</i>	(Optional) reason for operation state
<i>bundle_str</i>	(Optional) bundle string
TABLE_vsan_info	(Optional) vsan information
<i>vsan_num</i>	(Optional) the vsan ID
<i>vsan_state</i>	(Optional) the status of vsan
<i>vsan_state_reason</i>	(Optional) reason for vsan state
<i>fcid</i>	(Optional) FCID

Command Mode

- /exec

show interface trunk vsan

```
show interface <ifid_trnk> trunk vsan [ <vsan_id> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifid_trnk</i>	Enter interface type and number in module/slot format
trunk	Show interface trunk information
vsan	Show per vsan information for trunk
<i>vsan_id</i>	(Optional) Enter vsan range

Command Mode

- /exec

show interface untagged-cos

```
show interface untagged-cos [ module <mod_num> ] [ __readonly__ <interface> <ucos-value> ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
untagged-cos	Show interface untagged CoS information
module	(Optional) Limit display to interfaces on module
<i>mod_num</i>	(Optional) Enter module number
<i>__readonly__</i>	(Optional)
<i>interface</i>	(Optional) Interface index
<i>ucos-value</i>	(Optional) COS value

Command Mode

- /exec

show interface vlan mapping

```
show interface <ifindex> vlan mapping [ __readonly__ <if-index-id> { TABLE_vlan_xlt <orig-vlan-id> [
<inner-vlan-id> ] <xlt-vlan-id> } <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
interface	Show interface status and information
<i>ifindex</i>	Enter interface type and number in module/slot format
vlan	Show VLAN information
mapping	VLAN translation mapping
<i>__readonly__</i>	(Optional) Read Only
TABLE_vlan_xlt	(Optional) Vlan translation table
<i>if-index-id</i>	(Optional) Interface index id
<i>orig-vlan-id</i>	(Optional) Original Vlan Id
<i>inner-vlan-id</i>	(Optional) Inner Vlan Id
<i>xlt-vlan-id</i>	(Optional) Translated Vlan Id
<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker

Command Mode

- /exec

show inventory

```
show inventory [ chassis | fans | power_supply | module [ <module> ] | <s0> [ <santa-cruz-range> ] | all ] [
__readonly__ TABLE_inv <name> <desc> <productid> <vendorid> <serialnum> ]
```

Syntax Description

show	Show running system information
inventory	system inventory information
chassis	(Optional) system inventory chassis information
fans	(Optional) system inventory fan information
power_supply	(Optional) system inventory power supply information
module	(Optional) system inventory module information
<i>module</i>	(Optional) please enter the module number
<i>s0</i>	(Optional) please enter the module number
<i>santa-cruz-range</i>	(Optional) please enter the xbar number
all	(Optional) system and transceiver inventory information
<u>__readonly__</u>	(Optional)
TABLE_inv	(Optional) Inventory table
<i>name</i>	(Optional) Name of inventory
<i>desc</i>	(Optional) Description of inventory
<i>productid</i>	(Optional) Product ID
<i>vendorid</i>	(Optional) Vendor ID
<i>serialnum</i>	(Optional) Serial Number

Command Mode

- /exec

<i>global_punt_pkt_cnt</i>	(Optional) Global packet punt count
<i>global_punt_byte_cnt</i>	(Optional) Global byte punt count
<i>global_glean_pkt_cnt</i>	(Optional) Global glean packet count
<i>global_glean_byte_cnt</i>	(Optional) Global glean byte count
<i>glean_pkt_cnt</i>	(Optional) Glean packet count
<i>glean_byte_cnt</i>	(Optional) Glean byte count
<i>normal_pkt_cnt</i>	(Optional) Packet count
<i>normal_byte_cnt</i>	(Optional) Byte count
<i>last_updated</i>	(Optional) Last updated
<i>count-static</i>	(Optional) Count static
<i>count-dynamic</i>	(Optional) Count dynamic
<i>count-others</i>	(Optional) Count others
<i>count-throttle</i>	(Optional) Count throttle
<i>count-total</i>	(Optional) Count total
TABLE_afi	(Optional) TABLR afi
<i>afi</i>	(Optional) afi
<i>count</i>	(Optional) count
TABLE_adj	(Optional) Adjacency table
<i>intf-out</i>	(Optional) Interface
<i>phy-intf</i>	(Optional) Physical interface
<i>ip-addr-out</i>	(Optional) IP address
<i>mac</i>	(Optional) MAC address
<i>pref</i>	(Optional) Preference
<i>owner</i>	(Optional) Owner
<i>pkt-count</i>	(Optional) Packet count
<i>byte-count</i>	(Optional) Byte count
<i>is-best</i>	(Optional) Best
<i>is-thrtld</i>	(Optional) Throttled

Command Mode

- /exec

show ip amt relay

```
show { ip | ipv6 } amt relay [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ TABLE_vrf <vrf>
<tut> <ra> <nds> <ldn> <nts> <lrn> <lra> <lq> <uc> <rc4> <rc6> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
vrf	(Optional) Display information for VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
amt	AMT show commands
relay	Display status information about the AMT Relay
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>tut</i>	(Optional)
<i>ra</i>	(Optional)
<i>vrf</i>	(Optional)
<i>nds</i>	(Optional)
<i>ldn</i>	(Optional)
<i>nts</i>	(Optional)
<i>lrn</i>	(Optional)
<i>lra</i>	(Optional)
<i>lq</i>	(Optional)
<i>uc</i>	(Optional)
<i>rc4</i>	(Optional)
<i>rc6</i>	(Optional)

Command Mode

- /exec

show ip amt route

```
show { ip | ipv6 } amt route [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ TABLE_vrf <vrf>
<rc4> <rc6> { TABLE_route <addrs> <if> <nbr> <gwa> <gw_exp> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
vrf	(Optional) Display information for VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
amt	AMT show commands
route	Display multicast routes learned via AMT
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>rc4</i>	(Optional)
<i>rc6</i>	(Optional)
TABLE_route	(Optional)
<i>addrs</i>	(Optional)
<i>if</i>	(Optional)
<i>nbr</i>	(Optional)
<i>gwa</i>	(Optional)
<i>gw_exp</i>	(Optional)

Command Mode

- /exec

show ip amt tunnel

```
show ip amt tunnel [ <address4> <port> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__
TABLE_vrf <vrf> <tc4> { TABLE_tunnel <gwa> <gwp> <ut> <ld> <lr> <rc> <exp> { TABLE_route
<source> <group> <rexp> } } ]
```

Syntax Description

show	Show running system information
amt	AMT show commands
ip	Display IP information
tunnel	Display tunnel information
vrf	(Optional) Display information for VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>address4</i>	(Optional) IP address of tunnel endpoint
<i>port</i>	(Optional) UDP port number of gateway
detail	(Optional) Display routes joined by tunnel endpoint
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>tc4</i>	(Optional)
TABLE_tunnel	(Optional)
<i>gwa</i>	(Optional)
<i>gwp</i>	(Optional)
<i>ut</i>	(Optional)
<i>ld</i>	(Optional)
<i>lr</i>	(Optional)
<i>rc</i>	(Optional)
<i>exp</i>	(Optional)
TABLE_route	(Optional)
<i>source</i>	(Optional)

<i>group</i>	(Optional)
<i>rexp</i>	(Optional)

Command Mode

- /exec

show ip arp

```
show ip arp [ [ [ <ip-address> | [ sync-entries | fhrp-non-active-learn ] [ detail ] | static | summary | [ summary
] <interface> ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ] [ __readonly__ TABLE_vrf <vrf-name-out>
] [ <cnt-resolved> ] [ <cnt-incomplete> ] [ <cnt-thrtld-incomplete> ] [ <cnt-unknown> ] [ <cnt-total> ] [
TABLE_adj <intf-out> <ip-addr-out> [ <time-stamp> ] { <mac> | <unknown> | <incomplete> } [ <phy-intf>
] [ <flags> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
summary	(Optional) Display ARP adjacency summary
detail	(Optional) Display detailed information
sync-entries	(Optional) Display ARP table learnt only due to arp table sync
fhrp-non-active-learn	(Optional) Display ARP table learnt only due to request for non-active FHRP address
<i>interface</i>	(Optional) ARP interface
<i>ip-address</i>	(Optional) IP address
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display ARP entries for all vrfs
static	(Optional) Display Static ARP entries
__readonly__	(Optional)
TABLE_vrf	(Optional) Show VRF table
<i>vrf-name-out</i>	(Optional) Show VRF name
<i>cnt-resolved</i>	(Optional) Show total resolved ARP entries
<i>cnt-incomplete</i>	(Optional) Show total incomplete ARP entreis
<i>cnt-thrtld-incomplete</i>	(Optional) Show total incomplete throttled entries
<i>cnt-unknown</i>	(Optional) Show total unknow entris
<i>cnt-total</i>	(Optional) Show total

<i>TABLE_adj</i>	(Optional) Show IP ARP
<i>intf-out</i>	(Optional) Show interface
<i>ip-addr-out</i>	(Optional) Show ip address
<i>time-stamp</i>	(Optional) Show age of adjacency
<i>mac</i>	(Optional) Show mac
<i>unknown</i>	(Optional) Show unknown entry
<i>incomplete</i>	(Optional) Show incomplete entry
<i>phy-intf</i>	(Optional) Show physical interface
<i>flags</i>	(Optional) Show flags

Command Mode

- /exec

show ip arp anycast topo-info

```
show ip arp anycast topo-info [ <topo-id> ] [ __readonly__ { TABLE_ip_arp_anycast_topo_info [
<ip_arp_anycat_topo_id> ] [ <ip_arp_anycast_feature> ] [ <ip_arp_anycast_mode> ] } ]
```

Syntax Description

show	Show running system information
ip	Configure IP features
arp	Configure ARP parameters
anycast	anycast feature info
topo-info	Per topology specific information
<i>topo-id</i>	(Optional) Topology ID (VLAN-ID or BD-ID)
<i>__readonly__</i>	(Optional)
TABLE_ip_arp_anycast_topo_info	(Optional) Show ip arp anycast topo-info
<i>ip_arp_anycat_topo_id</i>	(Optional) Show ARP anycast topo-id
<i>ip_arp_anycast_feature</i>	(Optional) Show ARP anycast feature
<i>ip_arp_anycast_mode</i>	(Optional) Show ARP anycast mode

Command Mode

- /exec

show ip arp client

```
show ip arp client [ __readonly__ { <arp-clients> } [ TABLE_arp_client_list { <arp-cli-uuid> <l2-client-type>
<client-flg> <mts-addr-sap> <cli-msg-cnt> [ <l2-cli-func-name> ] [ <l2-cli-dbg-func> ] [
<l2-cli-dbg-un-init-func> ] } ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
client	Display ARP Client table
<i>__readonly__</i>	(Optional)
<i>arp-clients</i>	(Optional) Number of ARP Clients
TABLE_arp_client_list	(Optional) Show ip arp client
<i>arp-cli-uuid</i>	(Optional) Protocol uuid
<i>l2-client-type</i>	(Optional) Client type
<i>client-flg</i>	(Optional) Flags
<i>mts-addr-sap</i>	(Optional) SAP
<i>cli-msg-cnt</i>	(Optional) Client message count
<i>l2-cli-func-name</i>	(Optional) Received function
<i>l2-cli-dbg-func</i>	(Optional) Debug init function
<i>l2-cli-dbg-un-init-func</i>	(Optional) Debug Un-init function

Command Mode

- /exec

show ip arp controller-statistics

```
show ip arp controller-statistics [ __readonly__ { TABLE_ip_arp_controller_statistics [
<arp_adj_controller_add_count> ] [ <arp_adj_controller_del_count> ] [ <arp_adj_controller_add_err_count>
] [ <arp_adj_controller_del_err> ] } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
controller-statistics	Controller statistics
__readonly__	(Optional)
TABLE_ip_arp_controller_statistics	(Optional) Show controller-statistics
<i>arp_adj_controller_add_count</i>	(Optional)
<i>arp_adj_controller_del_count</i>	(Optional)
<i>arp_adj_controller_add_err_count</i>	(Optional)
<i>arp_adj_controller_del_err</i>	(Optional)

Command Mode

- /exec

show ip arp esi

```
show ip arp esi [ __readonly__ { TABLE_ip_arp_esi [ <ip_arp_esi_interface> ] [ <ip_arp_esi_value> ] } ]
```

Syntax Description

show	Show running system information
ip	Configure IP features
arp	Configure ARP parameters
esi	ESI information
__readonly__	(Optional)
TABLE_ip_arp_esi	(Optional) Show ip arp esi
<i>ip_arp_esi_interface</i>	(Optional) Interface
<i>ip_arp_esi_value</i>	(Optional) Values

Command Mode

- /exec

show ip arp inspection

```
show ip arp inspection [ __readonly__ <src_mac_valid> <dest_mac_valid> <ip_addr_valid> TABLE_entry
<active_vlan_id> <is_insp_enabled> <oper_state> [ <acl_name> ] [ [ <acl_logging> ] <dhcp_logging> ] [
<req_fwded> <res_fwded> <req_dropped> <res_dropped> <dhcp_drops> <acl_drops> <dhcp_permits>
<acl_permits> <req_smac_fails> <res_smac_fails> <res_dmac_fails> <req_ip_fails> <res_ip_fails> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
arp	IP ARP table
inspection	Status of ARP Inspection
<i>__readonly__</i>	(Optional) read only
<i>src_mac_valid</i>	(Optional) source ethernet address in header must be same as sender mac address in arp payload
<i>dest_mac_valid</i>	(Optional) destination ethernet address in header must be same as target mac address in arp payload
<i>ip_addr_valid</i>	(Optional) validate the target ip address to filter broadcast/multicast address in arp payload
TABLE_entry	(Optional)
<i>active_vlan_id</i>	(Optional) active vlan id
<i>is_insp_enabled</i>	(Optional)
<i>oper_state</i>	(Optional)
<i>acl_name</i>	(Optional)
<i>acl_logging</i>	(Optional)
<i>dhcp_logging</i>	(Optional)

Command Mode

- /exec

show ip arp inspection interfaces

```
show ip arp inspection interfaces [ <intf1> ] [ __readonly__ <intf_header> [ TABLE_intf <intf2> <trust_state> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
arp	IP ARP table
inspection	Status of ARP Inspection
interfaces	Trust status of all interfaces
<i>intf1</i>	(Optional) interface
<i>__readonly__</i>	(Optional)
<i>TABLE_intf</i>	(Optional)
<i>intf_header</i>	(Optional)
<i>intf2</i>	(Optional)
<i>trust_state</i>	(Optional)

Command Mode

- /exec

show ip arp inspection log

```
show ip arp inspection log [ __readonly__ <log_buff_size> <log_rate_entries> <log_rate_interval> <log_frame> ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
arp	IP ARP table
inspection	Status of ARP Inspection
log	Log Buffer
<i>__readonly__</i>	(Optional)
<i>log_buff_size</i>	(Optional) number of entries per log buffer
<i>log_rate_entries</i>	(Optional) number of entries into log buffer per sec
<i>log_rate_interval</i>	(Optional) time after which log buffer is updated in sec
<i>log_frame</i>	(Optional) log frames in buffer

Command Mode

- /exec

show ip arp inspection statistics

```
show ip arp inspection statistics [ vlan <vlan-range> ] [ __readonly__ TABLE_stats <vlanid> <req_fwded>
<res_fwded> <req_dropped> <res_dropped> <dhcp_drops> [ <acl_drops> ] <dhcp_permits> [ <acl_permits>
] <req_smac_fails> <res_smac_fails> <res_dmac_fails> <req_ip_fails> <res_ip_fails> ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
arp	IP ARP table
inspection	Status of ARP Inspection
statistics	Status of ARP Inspection
vlan	(Optional) Selected vlan range
<i>vlan-range</i>	(Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
<i>__readonly__</i>	(Optional)
TABLE_stats	(Optional)
<i>vlanid</i>	(Optional) ip arp inspection vlan id

Command Mode

- /exec

show ip arp inspection vlan

```
show ip arp inspection { vlan <vlan-range> } [ __readonly__ <src_vlan_mac_valid> <dest_vlan_mac_valid>
<ip_vlan_addr_valid> TABLE_vlan <active_vlan_id> <is_insp_enabled> <oper_state> [ <dhcp_logging> ]
[ <acl_name> ] [ <acl_logging> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
arp	IP ARP table
inspection	Status of ARP Inspection
vlan	Selected vlan range
<i>vlan-range</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
<i>__readonly__</i>	(Optional)
<i>src_vlan_mac_valid</i>	(Optional) validates header source mac address with sender mac address in arp payload
<i>dest_vlan_mac_valid</i>	(Optional) validates header destination mac address with target mac address in arp payload
<i>ip_vlan_addr_valid</i>	(Optional) filters invalid ip addresses like multicast/broadcast in arp requests/responses
TABLE_vlan	(Optional)
<i>active_vlan_id</i>	(Optional) active vlan id
<i>is_insp_enabled</i>	(Optional) ip arp inspection on vlan
<i>oper_state</i>	(Optional) operational on vlan
<i>acl_name</i>	(Optional) arp inspection access list name
<i>acl_logging</i>	(Optional) acl logging options
<i>dhcp_logging</i>	(Optional) ip arp inspection dhcp-binding logging options

Command Mode

- /exec

show ip arp multihoming-statistics

```
show ip arp multihoming-statistics [ <interface> ] [ interface-all ] [ vrf { <vrf-name> | <vrf-known-name> |
all } ] [ __readonly__ TABLE_vrf <vrf-name-out2> TABLE_stat <ps-recv-add-l2rib> <ps-proc-add-l2rib>
<ps-recv-del-l2rib> <ps-proc-del-l2rib> <ps-recv-pc-shut-l2rib> <ps-proc-pc-shut-l2rib>
<ps-recv-remote-upd-l2rib> <ps-proc-remote-upd-l2rib> <ps-add-err-invalid-flags> <ps-del-err-invalid-flags>
<ps-add-err-invalid-curr-state> <ps-del-err-invalid-curr-state> <ps-del-err-mac-mismatch> <ps-del-err-sec-del>
<ps-del-err-tl-route> <tl-del-err-psro-route> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
multihoming-statistics	Display ARP Multihoming stats
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display ARP Multihoming statistics for all vrfs
interface-all	(Optional) Display ARP Multihoming statistics for all interface
<i>interface</i>	(Optional) ARP interface
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional) VRF table
<i>vrf-name-out2</i>	(Optional) VRF name
TABLE_stat	(Optional) Show ip arp multihoming statistics
<i>ps-recv-add-l2rib</i>	(Optional) Received ADD from L2RIB
<i>ps-recv-del-l2rib</i>	(Optional) Received DEL from L2RIB
<i>ps-recv-remote-upd-l2rib</i>	(Optional) Received remote UPD from L2RIB
<i>ps-recv-pc-shut-l2rib</i>	(Optional) Received PC shut from L2RIB
<i>ps-proc-add-l2rib</i>	(Optional) Processed ADD from L2RIB
<i>ps-proc-del-l2rib</i>	(Optional) Processed DEL from L2RIB
<i>ps-proc-remote-upd-l2rib</i>	(Optional) Processed remote UPD from L2RIB
<i>ps-proc-pc-shut-l2rib</i>	(Optional) Processed PC shut from L2RIB

<i>ps-add-err-invalid-flags</i>	(Optional) Multihoming ADD error invalid flag
<i>ps-del-err-invalid-flags</i>	(Optional) Multihoming DEL error invalid flag
<i>ps-add-err-invalid-curr-state</i>	(Optional) Multihoming ADD error invalid current state
<i>ps-del-err-invalid-curr-state</i>	(Optional) Multihoming DEL error invalid current state
<i>ps-del-err-mac-mismatch</i>	(Optional) Peer sync DEL error MAC mismatch
<i>ps-del-err-tl-route</i>	(Optional) Peer sync DEL error second delete
<i>tl-del-err-psro-route</i>	(Optional) True local DEL error deleteing PS RO route
<i>ps-del-err-sec-del</i>	(Optional) Peer sync DEL error second delete

Command Mode

- /exec

show ip arp off-list

```
show ip arp off-list [ { vlan | bdi } <vlan-id> ] [ __readonly__ [ <offlist-vlan-id> <vlan-adj-cnt> ] [
<arp-sync-adj-cnt> ] { TABLE_arp_vlan_list <adj-vlan-id> <off-adj-ip-addr> <time-stamp> <arp-mac-addr>
<off-adj-flags> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
off-list	Show adjacencies in off-list arp database
vlan	(Optional) Vlan id
bdi	(Optional) Bridge Domain Name/Id
<i>vlan-id</i>	(Optional) Show information for specified vlan
<i>__readonly__</i>	(Optional)
<i>offlist-vlan-id</i>	(Optional) Show ip arp offlist vlan-id
<i>vlan-adj-cnt</i>	(Optional) Show ip arp vlan adjacency count
<i>arp-sync-adj-cnt</i>	(Optional) Show arp sync adjacency count
TABLE_arp_vlan_list	(Optional) Show ip arp vlan list
<i>adj-vlan-id</i>	(Optional) Show ip arp adjacency vlan id
<i>off-adj-ip-addr</i>	(Optional) Show arp offlist adjacency ip address
<i>time-stamp</i>	(Optional) Show duration
<i>arp-mac-addr</i>	(Optional) Show mac address
<i>off-adj-flags</i>	(Optional) show offlist adjacency flgs

Command Mode

- /exec

show ip arp open-flow error-statistics

```
show ip arp open-flow error-statistics [ __readonly__ { TABLE_ip_arp_open_flow_error_statistics [
<arp_ofa_total_err_cnt> ] [ <arp_ofa_dp_adj_err_on_del> ] [ <arp_ofa_cp_mac_mismatch_err_on_del> ] [
<arp_ofa_cp_null_mac_err_on_del> ] [ <arp_ofa_cp_no_adj_err_on_del_flag> ] [
<arp_ofa_cp_cp_nh_mismatch_err_on_del> ] [ <arp_ofa_cp_adj_del_failure_err> ] [
<arp_ofa_cp_null_mac_err_on_add> ] [ <arp_ofa_cp_dp_mac_mismatch_err_on_add> ] [
<arp_ofa_cp_cp_mac_mismatch_err_on_add> ] [ <arp_ofa_cp_added_first_err> ] [
<arp_ofa_dp_overwrite_cp_err> ] [ <arp_ofa_dp_cp_nh_mismatch_err_on_add> ] [
<arp_ofa_cp_cp_nh_mismatch_err_on_add> ] [ <arp_ofa_cp_dp_nh_mismatch_err_on_add> ] [
<arp_ofa_cp_adj_add_failure_err> ] [ <arp_ofa_barrier_response_err> ] } ]
```

Syntax Description

show	Show running system information
ip	Configure IP features
arp	Configure ARP parameters
open-flow	open flow
error-statistics	IR mode specific adjacency statistics
<i>__readonly__</i>	(Optional)
<i>TABLE_ip_arp_open_flow_error_statistics</i>	(Optional) ARP Open Flow Error Statistics
<i>arp_ofa_total_err_cnt</i>	(Optional) OFA total error count
<i>arp_ofa_dp_adj_err_on_del</i>	(Optional) Controller Deleting DP adjacency error
<i>arp_ofa_cp_mac_mismatch_err_on_del</i>	(Optional) CP adjacency MAC mismatch error while delete
<i>arp_ofa_cp_null_mac_err_on_del</i>	(Optional) CP adjacency NULL mac error while delete
<i>arp_ofa_cp_no_adj_err_on_del_flag</i>	(Optional) No adjacency found while delete
<i>arp_ofa_cp_cp_nh_mismatch_err_on_del</i>	(Optional) CP adjacency NH mismatch error while delete
<i>arp_ofa_cp_adj_del_failure_err</i>	(Optional) Other errors while deleting
<i>arp_ofa_cp_null_mac_err_on_add</i>	(Optional) CP adjacency NULL mac error while Adding
<i>arp_ofa_cp_dp_mac_mismatch_err_on_add</i>	(Optional) DP adjacency present with different mac
<i>arp_ofa_cp_cp_mac_mismatch_err_on_add</i>	(Optional) CP adjacency present with different mac
<i>arp_ofa_cp_added_first_err</i>	(Optional) CP adjacency added first
<i>arp_ofa_dp_overwrite_cp_err</i>	(Optional) Overwriting CP adjacency with DP
<i>arp_ofa_dp_cp_nh_mismatch_err_on_add</i>	(Optional) DP adjacency already present with different NH
<i>arp_ofa_cp_cp_nh_mismatch_err_on_add</i>	(Optional) CP adjacency already present with different NH

<i>arp_ofa_cp_dp_nh_mismatch_err_on_add</i>	(Optional) Overwriting CP adj with DP with different NH
<i>arp_ofa_cp_adj_add_failure_err</i>	(Optional) Other errors while adding
<i>arp_ofa_barrier_response_err</i>	(Optional) Barrier responses

Command Mode

- /exec

show ip arp statistics

```
show ip arp statistics [ <interface> ] [ interface-all ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_vrf <vrf-name-out1> [ TABLE_stat <tx-total> <tx-req> <tx-reply> <tx-req-l2>
<tx-reply-l2> <tx-grat> <tx-tunnel> <tx-drop> [ <tx-srvrport> ] [ <tx-fbrport> ] [ <tx-fixup-core> ] [
<tx-fixup-server> ] [ <tx-fixup-rarp> ] [ <tx-anycast-glean> ] <tx-mbuf-fail> <tx-ctxt-not-crted> <tx-bad-ctxt-id>
<tx-invalid-ifindex> <tx-invalid-sip> <tx-invalid-dip> <tx-own-ip> <tx-unattached-ip> <tx-adj-create-fail>
<tx-null-sip> <tx-null-smac> <tx-client-enq-fail> <tx-dest-unreachable-proxy-arp>
<tx-dest-unreachable-enhanced-proxy> <tx-dest-l2port-track> <tx-invalid-local-proxy> <tx-invalid-proxy>
<tx-vip-not-active> <tx-skip-refresh-over-core-and-flood-to-server> <rx-total> <rx-req> <rx-reply> <rx-req-l2>
<rx-reply-l2> <rx-proxy> <rx-local-proxy> <rx-enhanced-proxy> <rx-enhanced-proxy-anycast>
<rx-enhanced-proxy-l2port-track> <rx-tunnel> <rx-fastpath> <rx-snoop> <rx-drop> <rx-srvrport> <bad-if>
<bad-len> <invalid-prot> <invalid-hrd-type> <invalid-ctxt> <ctxt-not-crted> <invalid-l2> <invalid-l3>
<invalid-sip> <our-sip> <arp-if-no-mem> <subnet-mismatch> <dir-bcast> <invalid-dip> <non-local-dst>
<non-active-fhrp> <invalid-smac> <our-smac> <not-init> <l2-prxy-en> <l2-port-untrusted> <stdby-fhrp-vip>
<grat-prxy-en> <arp-req-ignore> <l2-intf> <l2fm-query-fail> <tunnel_fail> [ <hsrp-active-vmac> ] [
<rx-intf-down> ] <recv-glean-count> <refresh-req-from-clients> <l2rib-signals> <adds> <dels> <timeouts>
] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
statistics	Display ARP statistics
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display ARP statistics for all vrfs
interface-all	(Optional) Display ARP statistics for all interface
<i>interface</i>	(Optional) ARP interface
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional) Table Vrf
<i>vrf-name-out1</i>	(Optional) Show VRF name
TABLE_stat	(Optional) Show IP ARP statistics
<i>tx-total</i>	(Optional) Sent: total
<i>tx-req</i>	(Optional) Sent: request
<i>tx-reply</i>	(Optional) Sent: reply

<i>tx-req-l2</i>	(Optional) Sent: request on L2
<i>tx-reply-l2</i>	(Optional) Sent: replay on L2
<i>tx-grat</i>	(Optional) Sent: gratuitous
<i>tx-tunnel</i>	(Optional) Sent: tunnel packet
<i>tx-drop</i>	(Optional) Sent:Dropped packet
<i>tx-svrport</i>	(Optional) Sent from Server Port
<i>tx-fbrport</i>	(Optional) Sent from Fabric Port
<i>tx-fixup-core</i>	(Optional) Sent: fixup core
<i>tx-fixup-server</i>	(Optional) Sent: fixup server
<i>tx-fixup-rarp</i>	(Optional) Sent: fixup rarp
<i>tx-anycast-glean</i>	(Optional) Sent: modified anycast glean
<i>tx-mbuf-fail</i>	(Optional) Sent:MBUF operation failed
<i>tx-ctxt-not-crtd</i>	(Optional) Sent:Context not yet created
<i>tx-bad-ctxt-id</i>	(Optional) Sent:Invalid context
<i>tx-invalid-ifindex</i>	(Optional) Sent:Invalid ifindex
<i>tx-invalid-sip</i>	(Optional) Sent:Invalid SRC IP
<i>tx-invalid-dip</i>	(Optional) Sent:Invalid DEST IP
<i>tx-own-ip</i>	(Optional) Sent:Destination is our own IP
<i>tx-unattached-ip</i>	(Optional) Sent:Unattached IP
<i>tx-adj-create-fail</i>	(Optional) Sent:Adjacency Couldn't be added
<i>tx-null-sip</i>	(Optional) Sent:Null Source IP
<i>tx-null-smac</i>	(Optional) Sent: Null Source MAC
<i>tx-client-enq-fail</i>	(Optional) Sent: Client Enqueue Failed
<i>tx-dest-unreachable-proxy-arp</i>	(Optional) Sent: Dest. not reachable for proxy arp
<i>tx-dest-unreachable-enhanced-proxy</i>	(Optional) Sent:Dest. unreachable for enhanced proxy
<i>tx-dest-l2port-track</i>	(Optional) Sent:Dest. on L2 port being tracked
<i>tx-invalid-local-proxy</i>	(Optional) Sent:Invalid Local proxy arp
<i>tx-invalid-proxy</i>	(Optional) Sent:Invalid proxy arp
<i>tx-vip-not-active</i>	(Optional) Sent:VIP is not active

<i>tx-skip-refresh-over-core-and-flood-to-server</i>	(Optional) ARP refresh skipped over core and sent on server side
<i>rx-total</i>	(Optional) Received: total
<i>rx-req</i>	(Optional) Received: Requests
<i>rx-reply</i>	(Optional) Received: Replies
<i>rx-req-l2</i>	(Optional) Received: Requests on L2
<i>rx-reply-l2</i>	(Optional) Received: Replies on L2
<i>rx-proxy</i>	(Optional) Received: Proxy arp
<i>rx-local-proxy</i>	(Optional) Received: Local-Proxy arp
<i>rx-enhanced-proxy</i>	(Optional) Received: Enhanced Proxy arp
<i>rx-enhanced-proxy-anycast</i>	(Optional) Received: Anycast proxy Proxy arp
<i>rx-enhanced-proxy-l2port-track</i>	(Optional) Received: L2 Port-track Proxy arp
<i>rx-tunnel</i>	(Optional) Received: Tunneled
<i>rx-fastpath</i>	(Optional) Received: Fastpath
<i>rx-snoop</i>	(Optional) Received: Snooped
<i>rx-drop</i>	(Optional) Received: Dropped
<i>rx-srvrport</i>	(Optional) Received: on Server Port
<i>bad-if</i>	(Optional) Appeared on a wrong interface
<i>bad-len</i>	(Optional) Incorrect length
<i>invalid-prot</i>	(Optional) Invalid protocol packet
<i>invalid-hrd-type</i>	(Optional) Invalid Hardware type
<i>invalid-ctxt</i>	(Optional) Invalid context
<i>ctxt-not-crtd</i>	(Optional) Context not yet created
<i>invalid-l2</i>	(Optional) Invalid layer 2 address length
<i>invalid-l3</i>	(Optional) Invalid layer 3 address length
<i>invalid-sip</i>	(Optional) Invalid source IP address
<i>our-sip</i>	(Optional) Source IP address is our own
<i>arp-if-no-mem</i>	(Optional) No mem to create per intf structure
<i>subnet-mismatch</i>	(Optional) Source address mismatch with subnet
<i>dir-bcast</i>	(Optional) Directed broadcast source

<i>invalid-dip</i>	(Optional) Invalid destination IP address
<i>non-local-dst</i>	(Optional) Non-local destination IP address
<i>non-active-fhrp</i>	(Optional) Non-active FHRP dest IP address. Learn and drop
<i>invalid-smac</i>	(Optional) Invalid source MAC address
<i>our-smac</i>	(Optional) Source MAC address is our own
<i>not-init</i>	(Optional) Received before arp initialization
<i>l2-prxy-en</i>	(Optional) L2 packet on proxy-arp-enabled interface
<i>l2-port-untrusted</i>	(Optional) L2 packet on untrusted L2 port
<i>stdby-fhrp-vip</i>	(Optional) Packet with VIP on standby FHRP
<i>grat-prxy-en</i>	(Optional) Grat arp received on proxy-arp-enabled interface
<i>arp-req-ignore</i>	(Optional) Requests came for existing entries
<i>l2-intf</i>	(Optional) Requests came on a L2 interface
<i>l2fm-query-fail</i>	(Optional) L2FM query failed for a L2 Address
<i>tunnel_fail</i>	(Optional) Dropping due to tunneling failures
<i>hsrp-active-vmac</i>	(Optional) Dropping due to HSRP standby receiving HSRP active vmac
<i>rx-intf-down</i>	(Optional) Received Interface Down
<i>recv-glean-count</i>	(Optional) Glean requests recv count
<i>refresh-req-from-clients</i>	(Optional) Refresh requests received from clients
<i>l2rib-signals</i>	(Optional) Signals received from L2rib
<i>adds</i>	(Optional) Adds
<i>dels</i>	(Optional) Deletes
<i>timeouts</i>	(Optional) Timeouts

Command Mode

- /exec

show ip arp suppression-cache

```
show ip arp suppression-cache { detail [ vlan <vlan_id> ] | summary | statistics | vlan <vlan_id> | local [ vlan
<vlan_id> ] | remote [ vlan <vlan_id> ] } [ __readonly__ TABLE_arp-suppression [ TABLE_entries <ip-addr>
<age> <mac> <vlan> <physical-iod> <flag> [ <remote-vtep-addr> ] ] [ TABLE_summary <remote-count>
<local-count> <total-count> ] [ TABLE_stats TABLE_suppressed <total> <requests> <requests-on-l2>
<gratuitous> <gratuitous-on-l2> TABLE_forwarded <total-sent> <requests-sent> <replies-sent>
<requests-on-core-sent> <replies-on-core-sent> <dropped-sent> <requests-on-l2-sent> <replies-on-l2-sent>
<requests-on-core-l2-sent> <replies-on-core-l2-sent> <dropped-l2-sent> TABLE_received <total-recv>
<requests-recv> <replies-recv> <local-requests-recv> <local-replies-recv> <gratuitous-recv> <dropped-recv>
<requests-on-l2-recv> <replies-on-l2-recv> <gratuitous-l2-recv> <dropped-l2-recv> TABLE_entrystats
<adds> <dels> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
suppression-cache	arp-suppression-cache
detail	show details
summary	show summary
statistics	show statistics
local	show local entries
remote	show remote entries
vlan	(Optional) L2vlan
<i>vlan_id</i>	(Optional) Vlan
<i>__readonly__</i>	(Optional)
TABLE_arp-suppression	(Optional) IP ARP suppression-cache
TABLE_entries	(Optional) IP ARP suppression entries
<i>ip-addr</i>	(Optional) IP address
<i>age</i>	(Optional) Age
<i>mac</i>	(Optional) MAC address
<i>vlan</i>	(Optional) vlan id
<i>physical-iod</i>	(Optional) Physical iod
<i>flag</i>	(Optional) Flags

<i>remote-vtep-addr</i>	(Optional) Remote Vtep Address
TABLE_summary	(Optional) IP ARP suppression-cache Summary
<i>remote-count</i>	(Optional) Remote count
<i>local-count</i>	(Optional) Local count
<i>total-count</i>	(Optional) Total count
TABLE_stats	(Optional) Show IP ARP suppression statistics
TABLE_suppressed	(Optional) Suppressed table
<i>total</i>	(Optional) total
<i>requests</i>	(Optional) request
<i>requests-on-l2</i>	(Optional) requests-on-l2
<i>gratuitous</i>	(Optional) gratuitous
<i>gratuitous-on-l2</i>	(Optional) gratuitous-on-l2
TABLE_forwarded	(Optional) Forwarded table
<i>total-sent</i>	(Optional) total
<i>requests-sent</i>	(Optional) Requests sent on L3
<i>replies-sent</i>	(Optional) Replies sent on L3
<i>requests-on-core-sent</i>	(Optional) Request on core port
<i>replies-on-core-sent</i>	(Optional) Reply on core port
<i>dropped-sent</i>	(Optional) Dropped
<i>requests-on-l2-sent</i>	(Optional) Requests on L2
<i>replies-on-l2-sent</i>	(Optional) Replies on L2
<i>requests-on-core-l2-sent</i>	(Optional) Request on core port L2
<i>replies-on-core-l2-sent</i>	(Optional) Reply on core port L2
<i>dropped-l2-sent</i>	(Optional) Dropped on L2
TABLE_received	(Optional) Received
<i>total-recv</i>	(Optional) Total
<i>requests-recv</i>	(Optional) Requests on L3 mode
<i>replies-recv</i>	(Optional) Replies on L3 mode
<i>local-requests-recv</i>	(Optional) Local Request

<i>local-replies-recv</i>	(Optional) Local Responses
<i>gratuitous-recv</i>	(Optional) Gratuitous on L3 mode
<i>dropped-recv</i>	(Optional) Dropped on L3 mode
<i>requests-on-l2-recv</i>	(Optional) Requests on L2 mode
<i>replies-on-l2-recv</i>	(Optional) Replies on L2 mode
<i>gratuitous-l2-recv</i>	(Optional) Gratuitous on L2 mode
<i>dropped-l2-recv</i>	(Optional) Dropped on L2 mode
TABLE_entrystats	(Optional) ARP suppression-cache Local entry statistics
<i>adds</i>	(Optional) Adds
<i>dels</i>	(Optional) Deletes

Command Mode

- /exec

show ip arp suppression topo-info

```
show ip arp suppression topo-info [ <topo-id> ] [ __readonly__ { TABLE_ip_arp_suppression_topo_info [
<ip_arp_suppression_topo_id> ] [ <ip_arp_suppression_mode> ] [ <ip_arp_suppression_hmm_mode> ] } ]
```

Syntax Description

show	Show running system information
ip	Configure IP features
arp	Configure ARP parameters
suppression	ARP-suppression based event
topo-info	E-VPN identifier
<i>topo-id</i>	(Optional) E-VPN identifier (VLAN-ID or BD-ID)
<i>__readonly__</i>	(Optional)
TABLE_ip_arp_suppression_topo_info	(Optional) Show suppression topo-info
<i>ip_arp_suppression_topo_id</i>	(Optional) Show ARP suppression topo_id
<i>ip_arp_suppression_mode</i>	(Optional) Show ARP suppression mode
<i>ip_arp_suppression_hmm_mode</i>	(Optional) Show ARP suppression hmm mode

Command Mode

- /exec

show ip arp tunnel-statistics

```
show ip arp tunnel-statistics [ __readonly__ { TABLE_ip_arp_tunnel_stat [ <arp-tun-pkt-rcv-cnt> ] [
<arp-tun-pkt-rcv-ing-vpc> ] [ <arp-tun-pkt-rcv-ing-gpc> ] [ <arp-tun-pkt-rcv-ing-orp-vpc> ] [
<arp-tun-pkt-rcv-ing-orp-vpc-pl> ] [ <arp-tun-pkt-snd-cnt> ] [ <arp-tun-pkt-snd-snoop-cnt> ] [
<arp-tun-pkt-snd-non-local-vip-cnt> ] [ <arp-tun-pkt-snd-peer-gate-cnt> ] [ <arp-tun-pkt-snd-ing-vpc> ] [
<arp-tun-pkt-snd-ing-gpc> ] [ <arp-tun-pkt-snd-ing-orp-vpc> ] [ <arp-tun-pkt-snd-ing-orp-vpc-pl> ] [
<arp-tun-pkt-rcv-drp-cnt> ] [ <arp-tun-pkt-snd-drp-cnt> ] [ <arp-tun-pkt-snd-drp-snd-fail-cnt> ] [
<arp-tun-pkt-rcv-drp-ver-cnt> ] [ <arp-tun-pkt-rcv-drp-pl-cnt> ] [ <arp-tun-pkt-rcv-drp-ing-non-mct> ] [
<arp-tun-pkt-rcv-drp-inv-ing-intf> ] [ <arp-tun-pkt-snd-drp-inv-ing-intf> ] [
<arp-tun-pkt-rcvdrp-inv-gpc-core-sw> ] [ <arp-tun-pkt-rcvdrp-inv-gpc-peer-sw> ] [ <arp-tun-pkt-drp-inv-mccc>
] [ <arp-tun-pkt-im-api-fail> ] [ <arp-tun-pkt-drp-ctxt-inv> ] [ <arp-tun-pkt-drp-mct-dwn> ] [
<arp-tun-pkt-rcv-drp-mbuf-op-fail> ] [ <arp-tun-pkt-snd-drp-mbuf-op-fail> ] [ <arp-tun-pkt-snd-drp-tunnel>
] [ <arp-tun-pkt-snd-drp-ce> ] [ <arp-tun-pkt-snd-drp-inv-gpc> ] [ <arp-tun-pkt-rcv-drp-inv-gpc> ] [
<arp-tun-pkt-sys-mcecm-key-not-found> ] } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
tunnel-statistics	Display ARP statistics for tunneled packets
__readonly__	(Optional)
TABLE_ip_arp_tunnel_stat	(Optional) ARP Tunnel statistics
<i>arp-tun-pkt-rcv-cnt</i>	(Optional) Total tunneled packets received
<i>arp-tun-pkt-rcv-ing-vpc</i>	(Optional) Tunneled packets rx for ingress vPC
<i>arp-tun-pkt-rcv-ing-gpc</i>	(Optional) Tunneled packets rx for ingress GPC
<i>arp-tun-pkt-rcv-ing-orp-vpc</i>	(Optional) Tunneled Packets rx for ingress orphan vPC
<i>arp-tun-pkt-rcv-ing-orp-vpc-pl</i>	(Optional) Tunneled Packets rx for ingress orphan vPC+
<i>arp-tun-pkt-snd-cnt</i>	(Optional) Total tunneled packets sent
<i>arp-tun-pkt-snd-snoop-cnt</i>	(Optional) Tunneled packets Sent for ARP Snoop
<i>arp-tun-pkt-snd-non-local-vip-cnt</i>	(Optional) Tunneled packets sent for Non-Local VIP
<i>arp-tun-pkt-snd-peer-gate-cnt</i>	(Optional) Tunneled Packets sent for Peer Gateway
<i>arp-tun-pkt-snd-ing-vpc</i>	(Optional) Tunneled packets tx for ingress vPC
<i>arp-tun-pkt-snd-ing-gpc</i>	(Optional) Tunneled packets tx for ingress GPC
<i>arp-tun-pkt-snd-ing-orp-vpc</i>	(Optional) Tunneled Packets tx for ingress orphan vPC

<i>arp-tun-pkt-snd-ing-orp-vpc-pl</i>	(Optional) Tunneled Packets tx for ingress orphan vPC+
<i>arp-tun-pkt-rcv-drp-cnt</i>	(Optional) Total tunnel packets rcv dropped
<i>arp-tun-pkt-snd-drp-cnt</i>	(Optional) Total tunnel packets send dropped
<i>arp-tun-pkt-snd-drp-snd-fail-cnt</i>	(Optional) Drops due to send failed
<i>arp-tun-pkt-rcv-drp-ver-cnt</i>	(Optional) Received packet with invalid version
<i>arp-tun-pkt-rcv-drp-pl-cnt</i>	(Optional) Received packet with invalid payload type
<i>arp-tun-pkt-rcv-drp-ing-non-mct</i>	(Optional) Received packet on non mct interface
<i>arp-tun-pkt-rcv-drp-inv-ing-intf</i>	(Optional) Received packet with invalid ingress port
<i>arp-tun-pkt-snd-drp-inv-ing-intf</i>	(Optional) Drop send packets for invalid ingress port
<i>arp-tun-pkt-rcvdrp-inv-gpc-core-sw</i>	(Optional) Drop rcv pkt, invalid GPC of core switch
<i>arp-tun-pkt-rcvdrp-inv-gpc-peer-sw</i>	(Optional) Drop rcv pkt, invalid GPC of peer switch
<i>arp-tun-pkt-drp-inv-mcec</i>	(Optional) Failed to retrieve vPC ID while processing
<i>arp-tun-pkt-im-api-fail</i>	(Optional) IM api failed while processing
<i>arp-tun-pkt-drp-ctxt-inv</i>	(Optional) Drop tunnel packet as context is invalid
<i>arp-tun-pkt-drp-mct-dwn</i>	(Optional) Drop tunnel packet as mct is down
<i>arp-tun-pkt-rcv-drp-mbuf-op-fail</i>	(Optional) Drop rcv packets as mbuf operation failed
<i>arp-tun-pkt-snd-drp-mbuf-op-fail</i>	(Optional) Drop send packets as mbuf operation failed
<i>arp-tun-pkt-snd-drp-tunnel</i>	(Optional) Cannot tunnel a incoming tunneled packet
<i>arp-tun-pkt-snd-drp-ce</i>	(Optional) Cannot tunnel in a CE network
<i>arp-tun-pkt-snd-drp-inv-gpc</i>	(Optional) Drop send pkt, failed in retrieving the GPC
<i>arp-tun-pkt-rcv-drp-inv-gpc</i>	(Optional) Drop rcv pkt, failed in retrieving the GPC
<i>arp-tun-pkt-sys-mcecm-key-not-found</i>	(Optional) MCEC_ID to PHY_IF_INDEX not found in DB

Command Mode

- /exec

show ip arp vpc-statistics

```
show ip arp vpc-statistics [ __readonly__ { TABLE_arp_vpc_stats [ <arp-pro-drp-pull-disable> ] [
<arp-pro-drp-push-msg-disable> ] [ <arp-pro-ign-snd-pull-disabe> ] [ <arp-ign-snd-push-disable> ] [
<arp-drp-im-fail> ] [ <arp-drp-mcecm-fail> ] [ <arp-drp-invalid-pc-iod> ] [ <arp-drp-pt-lookup-fail> ] [
<arp-drp-resp-fail-no-mct> ] [ <arp-drp-resp-fail> ] [ <arp-mcecm-ifidx-vpc-fail> ] [
<arp-mcecm-vpc-ifidx-fail> ] [ <arp-periodic-mcecm-ifidx-vpc-fail> ] [ <arp-resp-sent> ] [ <arp-resp-recvd>
] [ <arp-resp-recv-err> ] [ <arp-rcvd-msg> ] [ <arp-send-fail> ] [ <arp-cfs-rel-dlvry-fail> ] [
<arp-cfs-rel-dnvry-suc> ] [ <arp-drp-pt-add-fail> ] [ <arp-drp-no-mem> ] [ <arp-drp-tmr-cre-fail> ] [
<arp-drp-add-adj-fail> ] [ <arp-off-drp-pt-lookup-fail> ] [ <arp-dont-drp-vlan-mismat> ] [ <arp-drp-svi-invalid>
] [ <arp-dont-drop-sv-down> ] [ <arp-drp-mct-down> ] [ <arp-drp-ctxt-invalid> ] [ <arp-drp-vrf-invalid> ] [
<arp-drp-l3addr-invalid> ] [ <arp-drp-l3addr-sanity-fail> ] [ <arp-drp-mac-sanity-fail> ] [ <arp-own-rtr-mac>
] [ <arp-drp-own-ipaddr> ] [ <arp-drp-own-vipaddr> ] [ <arp-drp-adj-fail> ] [ <arp-drp-subnet-mismatch> ] [
<arp-drp-adj-exist> ] [ <arp-dont-drp-ip-not-enable> ] [ <arp-drp-total-cnt> ] [ <arp-dont-drop-total-cnt> ] [
<arp-drp-inval-phy-iod> ] [ <arp-add-adj> ] [ <arp-del-adj> ] [ <arp-adj-already-exist> ] [
<arp-sync-recv-op-add-adj> ] [ <arp-sync-recv-op-del-adj> ] [ <arp-sync-push-msg-adj-cnt> ] [
<arp-sync-send-op-add-adj> ] [ <arp-sync-send-op-del-adj> ] [ <arp-sync-adj-cnt> ] [ <arp-sync-addadj-fail>
] [ <arp-sync-drp-svi-inv> ] [ <arp-sync-drp-svi-dwn> ] [ <arp-sync-drp-ctxt-inv> ] [ <arp-sync-null-adj> ]
] [ <arp-sync-invalid-ip> ] [ <arp-periodic-sync-adj-l2-suppl-cnt> ] [
<arp-periodic-sync-stop-bcast-pkt-sync-count> ] } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
arp	Display ARP table and statistics
vpc-statistics	Show vPC global statistics
__readonly__	(Optional)
TABLE_arp_vpc_stats	(Optional) Arp Vpc statistics
<i>arp-mcecm-ifidx-vpc-fail</i>	(Optional) Unable to retrieve VPC id from ifidx
<i>arp-mcecm-vpc-ifidx-fail</i>	(Optional) Unable to retrieve ifidx from VPC id
<i>arp-periodic-mcecm-ifidx-vpc-fail</i>	(Optional) Unable to retrieve ifidx from VPC id during periodic sync
<i>arp-sync-recv-op-add-adj</i>	(Optional) Total adjacencies recieved from peer to add
<i>arp-sync-recv-op-del-adj</i>	(Optional) Total adjacencies received from peer to delete
<i>arp-sync-push-msg-adj-cnt</i>	(Optional) Total gross adjacencies sent periodically
<i>arp-sync-send-op-add-adj</i>	(Optional) Total adjacencies sent to peer to add
<i>arp-sync-send-op-del-adj</i>	(Optional) Total adjacencies sent to peer to delete
<i>arp-sync-adj-cnt</i>	(Optional) Total periodic sync adjacencies

<i>arp-sync-addadj-fail</i>	(Optional) Failure in adding adjacencies while periodic sync send
<i>arp-sync-drp-svi-inv</i>	(Optional) Total drops during periodic sync because of invalid svi
<i>arp-sync-drp-svi-dwn</i>	(Optional) Total drops during periodic sync because of svi down
<i>arp-sync-drp-ctxt-inv</i>	(Optional) Total drops during periodic sync because of invalid context
<i>arp-sync-null-adj</i>	(Optional) Total drops while processing syne of NULL Adjacencies
<i>arp-sync-invalid-ip</i>	(Optional) Total drops while processing sync because of NULL IP
<i>arp-periodic-sync-adj-l2-supp-cnt</i>	(Optional) Total periodic sync adjacenciesadded for L2 suppression case
<i>arp-periodic-sync-stop-bcast-pkt-sync-count</i>	(Optional) Total Bcast packets that was stopped sync to peer
<i>arp-pro-drp-pull-disable</i>	(Optional) Drop the received CFS pull request
<i>arp-pro-drp-push-msg-disable</i>	(Optional) Drop the received CFS push message
<i>arp-pro-ign-snd-pull-disabe</i>	(Optional) Ignore to send pull request using CFSoE
<i>arp-ign-snd-push-disable</i>	(Optional) Ignore to send push message using CFSoE
<i>arp-drp-im-fail</i>	(Optional) IM api failed while processing CFS payload
<i>arp-drp-mcecm-fail</i>	(Optional) MCECM api failed while processing CFS payload
<i>arp-drp-invalid-pc-iod</i>	(Optional) Invalid MCT port-channel iod
<i>arp-drp-pt-lookup-fail</i>	(Optional) PT lookup failed while processing CFS payload
<i>arp-drp-resp-fail-no-mct</i>	(Optional) Sending CFS response failed due to invalid MCT iod
<i>arp-drp-resp-fail</i>	(Optional) Sending CFS response failed
<i>arp-resp-sent</i>	(Optional) Response sent via CFSoE
<i>arp-resp-recvd</i>	(Optional) Response received via CFSoE
<i>arp-resp-recv-err</i>	(Optional) Response received via CFSoE with errors
<i>arp-rvcd-msg</i>	(Optional) Received message via CFSoE
<i>arp-send-fail</i>	(Optional) Send message failed via CFSoE
<i>arp-cfs-rel-dlvry-fail</i>	(Optional) MCECM send api failed via CFSoE
<i>arp-cfs-rel-dnvry-suc</i>	(Optional) Send message succeeded via CFSoE
<i>arp-drp-pt-add-fail</i>	(Optional) PT add failed while processing offlist
<i>arp-drp-no-mem</i>	(Optional) Memory alloc failed while processing offlist databse
<i>arp-drp-tmr-cre-fail</i>	(Optional) Timer create failed while processing offlist database

<i>arp-drp-add-adj-fail</i>	(Optional) Adjacency addition failed while processing offlist database
<i>arp-off-drp-pt-lookup-fail</i>	(Optional) PT lookup failed while processing offlist database
<i>arp-dont-drp-vlan-mismat</i>	(Optional) VLAN mismatch while processing offlist database
<i>arp-drp-svi-invalid</i>	(Optional) SVI is invalid while processing offlist database
<i>arp-dont-drop-sv-down</i>	(Optional) SVI is down while processing offlist database
<i>arp-drp-mct-down</i>	(Optional) MCT is down while processing offlist database
<i>arp-drp-ctxt-invalid</i>	(Optional) Ctxt_type is invalid while processing offlist database
<i>arp-drp-vrf-invalid</i>	(Optional) VRF is invalid while processing offlist database
<i>arp-drp-l3addr-invalid</i>	(Optional) VRF is invalid while processing offlist database
<i>arp-drp-l3addr-sanity-fail</i>	(Optional) IP address sanity failed
<i>arp-drp-mac-sanity-fail</i>	(Optional) MAC address sanity failed
<i>arp-own-rtr-mac</i>	(Optional) Our own router mac
<i>arp-drp-own-ipaddr</i>	(Optional) Our own ip address
<i>arp-drp-own-vipadd</i>	(Optional) Our own virtual ip address
<i>arp-drp-adj-fail</i>	(Optional) Create adjacency failed
<i>arp-drp-subnet-mismatch</i>	(Optional) Subnet mismatch
<i>arp-drp-adj-exist</i>	(Optional) Entry exists
<i>arp-dont-drp-ip-not-enable</i>	(Optional) IP not enabled on interface
<i>arp-drp-inval-phy-iod</i>	(Optional) Physical interface invalid
<i>arp-drp-total-cnt</i>	(Optional) Total drop count
<i>arp-dont-drop-total-cnt</i>	(Optional) Total don't drop count
<i>arp-add-adj</i>	(Optional) Total adjacency additions
<i>arp-del-adj</i>	(Optional) Total adjacency deletions
<i>arp-adj-already-exist</i>	(Optional) Total adjacencies ignored as already exist

Command Mode

- /exec

show ip as-path-access-list

```
show ip as-path-access-list [ <aspl-name> | <aspl-cfg-name> ] [ __readonly__ TABLE_aspl <name> <action>
<rule> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
as-path-access-list	List AS path access lists
<i>aspl-name</i>	(Optional) AS path access list name
<i>aspl-cfg-name</i>	(Optional) Known as-path access-list name
<i>__readonly__</i>	(Optional)
TABLE_aspl	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>rule</i>	(Optional)

Command Mode

- /exec

show ip client

```
show ip client [ <client-name> ] [ __readonly__ [ TABLE_ip_clnt [ TABLE_clnt { <clnt-name> <clnt-uuid>
<clnt-pid> <clnt-ext-pid> [ <clnt-proto> ] <clnt-ind> <clnt-cntxt-id> <clnt-mts-sap> <clnt-flg>
<clnt-msg-succ-cnt> <clnt-msg-fail-cnt> [ <clnt-recv-fn-name> <clnt-recv-fn> ] } ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
client	Display clients registered with the IP process
<i>client-name</i>	(Optional) Display information for a single IP client
<i>__readonly__</i>	(Optional)
<i>TABLE_ip_clnt</i>	(Optional)
<i>TABLE_clnt</i>	(Optional)
<i>clnt-name</i>	(Optional)
<i>clnt-uuid</i>	(Optional)
<i>clnt-pid</i>	(Optional)
<i>clnt-ext-pid</i>	(Optional)
<i>clnt-proto</i>	(Optional)
<i>clnt-ind</i>	(Optional)
<i>clnt-cntxt-id</i>	(Optional)
<i>clnt-mts-sap</i>	(Optional)
<i>clnt-flg</i>	(Optional)
<i>clnt-msg-succ-cnt</i>	(Optional)
<i>clnt-msg-fail-cnt</i>	(Optional)
<i>clnt-recv-fn-name</i>	(Optional)
<i>clnt-recv-fn</i>	(Optional)

Command Mode

- /exec

show ip community-list

```
show ip community-list [ <cl_name> ] [ __readonly__ TABLE_cl <name> <seq> <action> <rule> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
community-list	List community-list
<i>cl_name</i>	(Optional) Standard or expanded community-list name
<i>__readonly__</i>	(Optional)
<i>TABLE_cl</i>	(Optional)
<i>name</i>	(Optional)
<i>seq</i>	(Optional)
<i>action</i>	(Optional)
<i>rule</i>	(Optional)

Command Mode

- /exec

show ip debug

show ip debug

Syntax Description

show	Show running system information
ip	Display IP information
debug	Display IP debug-filter configuration

Command Mode

- /exec

show ip dhcp global statistics

```
show ip dhcp global statistics [ __readonly__ <pkts_processed> <pkts_recvd_through_cfsoe> <pkts_fwded>
<pkts_cfsoe_fwded> <pkts_dropped> <pkts_dropped_from_untrusted_ports>
<pkts_dropped_src_mac_chk_fail> <pkts_dropped_opt82_ins_fail> <pkts_dropped_unknown_op_intf>
<pkts_dropped_unknown_pkt> <pkts_dropped_no_trust_inf> <pkts_dropped_unknown_pkt>
<pkts_dropped_relay_disable> <pkts_dropped_no_binding_entry> <pkts_dropped_interface_error>
<pkts_dropped_max_hops_exceeded> <pkts_dropped_queue_full> ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show information about DHCP
global	DHCP global stats
statistics	Statistics related to DHCP
<i>__readonly__</i>	(Optional) Read only
<i>pkts_processed</i>	(Optional) Packets processed
<i>pkts_recvd_through_cfsoe</i>	(Optional) Packets received through cfsoe
<i>pkts_fwded</i>	(Optional) Packets forwarded
<i>pkts_cfsoe_fwded</i>	(Optional) Packets forwarded on cfsoe
<i>pkts_dropped</i>	(Optional) Total packets dropped
<i>pkts_dropped_from_untrusted_ports</i>	(Optional) Packets dropped from untrusted ports
<i>pkts_dropped_src_mac_chk_fail</i>	(Optional) Packets dropped due to MAC address check failure
<i>pkts_dropped_opt82_ins_fail</i>	(Optional) Packets dropped due to Option 82 insertion failure
<i>pkts_dropped_unknown_op_intf</i>	(Optional) Packets dropped due to o/p intf unknown
<i>pkts_dropped_unknown_pkt</i>	(Optional) Packets dropped which were unknown
<i>pkts_dropped_no_trust_inf</i>	(Optional) Packets dropped due to no trusted ports
<i>pkts_dropped_relay_disable</i>	(Optional) Packets dropped due to dhcp relay not enabled
<i>pkts_dropped_no_binding_entry</i>	(Optional) Packets dropped due to no binding entry
<i>pkts_dropped_interface_error</i>	(Optional) Packets dropped due to interface error/no interface
<i>pkts_dropped_max_hops_exceeded</i>	(Optional) Packets dropped due to max hops exceeded
<i>pkts_dropped_queue_full</i>	(Optional) Packets dropped due to queue full

Command Mode

- /exec

show ip dhcp option82 suboption info interface

```
show ip dhcp option82 suboption info interface [ <intf> ] [ __readonly__ <intf_header> { TABLE_intf_option82
<intf_name> <option82_status> <suboption_string> <tx_count> } ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show items in DHCP
option82	DHCP option82
suboption	DHCP option82 suboption
info	DHCP option82 suboption information
interface	DHCP option82 suboption information of all interfaces
<i>intf</i>	(Optional) interface
<i>__readonly__</i>	(Optional) Read only
<i>intf_header</i>	(Optional)
TABLE_intf_option82	(Optional)
<i>intf_name</i>	(Optional)
<i>option82_status</i>	(Optional)
<i>suboption_string</i>	(Optional)
<i>tx_count</i>	(Optional)

Command Mode

- /exec

show ip dhcp relay

```
show ip dhcp relay [ __readonly__ <relay_service_enable> <relay_opt82_enable> <relay_opt82_customize>
<relay_subopt_VPN_enable> <relay_subopt_type_cisco_enable> <global_smart-relay_enable>
<global_relay_trusted_enable> <relay_trusted_port_enable> <global_src_addr_hsrp_enable>
<smart_relay_intf_hdr> [ TABLE_intf <smart_relay_enabled_intf> ] <subnet_bcast_intf_hdr> [ TABLE_intf
<subnet_bcast_enabled_intf> ] <trusted_port_intf_hdr> [ TABLE_intf <trusted_port_enabled_intf> ]
<relay_src_addr_hsrp_hdr> [ TABLE_intf <src_addr_hsrp_enabled_intf> ] <relay_address_hdr> [ TABLE_intf
<intf> <relay_address> <vrf_name> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show items in DHCP
relay	DHCP relay
<i>__readonly__</i>	(Optional) Read only
<i>relay_service_enable</i>	(Optional)
<i>relay_opt82_enable</i>	(Optional)
<i>relay_opt82_customize</i>	(Optional)
<i>relay_subopt_VPN_enable</i>	(Optional)
<i>relay_subopt_type_cisco_enable</i>	(Optional)
<i>global_smart-relay_enable</i>	(Optional)
<i>global_relay_trusted_enable</i>	(Optional)
<i>relay_trusted_port_enable</i>	(Optional)
<i>global_src_addr_hsrp_enable</i>	(Optional) V4 Relay src-addr hsrp is globally enabled or not
<i>smart_relay_intf_hdr</i>	(Optional) Smart relay interfaces header
TABLE_intf	(Optional)
<i>smart_relay_enabled_intf</i>	(Optional) smart-relay enabled interfaces
<i>subnet_bcast_intf_hdr</i>	(Optional) Subnet broadcast interfaces header
TABLE_intf	(Optional)
<i>subnet_bcast_enabled_intf</i>	(Optional) subnet_bcast enabled interfaces
<i>trusted_port_intf_hdr</i>	(Optional) Trusted port interfaces header
TABLE_intf	(Optional)

<i>trusted_port_enabled_intf</i>	(Optional) trusted_port enabled interfaces
<i>relay_src_addr_hsrp_hdr</i>	(Optional) Header for V4 Relay src-addr enabled interfaces
TABLE_intf	(Optional)
<i>src_addr_hsrp_enabled_intf</i>	(Optional) source-address hsrp enabled interfaces
<i>relay_address_hdr</i>	(Optional) relay address header
TABLE_intf	(Optional) Table for list of interfaces
<i>intf</i>	(Optional) interface name
<i>relay_address</i>	(Optional) helper address
<i>vrf_name</i>	(Optional) vrf name

Command Mode

- /exec

show ip dhcp relay address

```
show ip dhcp relay address [ interface <intf-range> ] [ __readonly__ <intf_header> [ TABLE_intf <intf2>
<relay_address> <vrf_name> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show DHCP
relay	relay address of the interface
address	DHCP relay address
interface	(Optional) DHCP relay address of the interface
<i>intf-range</i>	(Optional) interface
<i>__readonly__</i>	(Optional) Read only
<i>intf_header</i>	(Optional) interface header
TABLE_intf	(Optional)
<i>intf2</i>	(Optional) interface name
<i>relay_address</i>	(Optional) helper address
<i>vrf_name</i>	(Optional) VRF name

Command Mode

- /exec

show ip dhcp relay information trusted-sources

show ip dhcp relay information trusted-sources [__readonly__ <header> [TABLE_intf <intf>]]

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show DHCP
relay	DHCP Relay
information	Relay information
trusted-sources	Relay Trusted Sources
__readonly__	(Optional) Read only
TABLE_intf	(Optional) trusted interface table
<i>header</i>	(Optional) interface header
<i>intf</i>	(Optional) interface name

Command Mode

- /exec

show ip dhcp relay statistics

```
show ip dhcp relay statistics [ interface <intf> | { interface <intf> serverip <ip-addr-val> [ use-vrf <vrf-name>
] } ] [ __readonly__ [ <msg_stats_hdr> <msg_type_str> <tx_pkts> <rx_pkts> <drops> <msg_type_str_offer>
<offer_rx_pkts> <offer_tx_pkts> <offer_drops> <msg_type_str_request> <request_rx_pkts> <request_tx_pkts>
<request_drops> <msg_type_str_ack> <ack_rx_pkts> <ack_tx_pkts> <ack_drops> <msg_type_str_release>
<release_rx_pkts> <release_tx_pkts> <release_drops> <msg_type_str_decline> <decline_rx_pkts>
<decline_tx_pkts> <decline_drops> <msg_type_str_inform> <inform_rx_pkts> <inform_tx_pkts>
<inform_drops> <msg_type_str_nack> <nack_rx_pkts> <nack_tx_pkts> <nack_drops> <line>
<msg_type_str_total> <total_rx_pkts> <total_tx_pkts> <total_drops> <line_x> ] [ <server_consolidated_hdr>
[ TABLE_server_info <server_helper_addr> <server_vrf> <server_total_request> <server_total_response>
] <line_y> ] [ <l3_fwd_hdr> <l3_fwd_rx_pkts> <l3_fwd_tx_pkts> <l3_fwd_drops> <non_dhcp_hdr>
<non_dhcp_rx_pkts> <non_dhcp_tx_pkts> <non_dhcp_drops> <drop_hdr> <drop_validation_fail>
<drop_relay_disable> <drop_invalid_msg_type> <drop_intf_err> <drop_tx_sock_err>
<drop_tx_fail_client_intf> <drop_unknown_op_intf> <drop_l3_unknown_op_intf> <drop_max_hops>
<drop_opt82_insert_fail> <drop_malformed> <drop_mct_drop> <drop_untrusted_relay_intf> ] [
<server_discover> <server_request> <server_decline> <server_release> <server_inform> <server_ack>
<server_nack> <server_offer> <server_resp_hdr> <drop_unknown> <server_req_hdr> ] <footer> ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show information about DHCP
relay	DHCP Relay
statistics	Statistics related to DHCP
interface	(Optional) input interface
<i>intf</i>	(Optional) interface
serverip	(Optional) Helper address
<i>ip-addr-val</i>	(Optional) IP address
use-vrf	(Optional) helper address VRF membership
<i>vrf-name</i>	(Optional) VRF name
__readonly__	(Optional) Read only
<i>msg_stats_hdr</i>	(Optional) dhcp message statistics header
<i>msg_type_str</i>	(Optional) dhcp message type
<i>rx_pkts</i>	(Optional) received dhcp packets
<i>tx_pkts</i>	(Optional) forwarded dhcp packets
<i>drops</i>	(Optional) dhcp packet drops

<i>msg_type_str_offer</i>	(Optional) dhcp message type
<i>offer_rx_pkts</i>	(Optional) received dhcp packets
<i>offer_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>offer_drops</i>	(Optional) dhcp packet drops
<i>msg_type_str_request</i>	(Optional) dhcp message type
<i>request_rx_pkts</i>	(Optional) received dhcp packets
<i>request_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>request_drops</i>	(Optional) dhcp packet drops
<i>msg_type_str_ack</i>	(Optional) dhcp message type
<i>ack_rx_pkts</i>	(Optional) received dhcp packets
<i>ack_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>ack_drops</i>	(Optional) dhcp packet drops
<i>msg_type_str_release</i>	(Optional) dhcp message type
<i>release_rx_pkts</i>	(Optional) received dhcp packets
<i>release_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>release_drops</i>	(Optional) dhcp packet drops
<i>msg_type_str_decline</i>	(Optional) dhcp message type
<i>decline_rx_pkts</i>	(Optional) received dhcp packets
<i>decline_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>decline_drops</i>	(Optional) dhcp packet drops
<i>msg_type_str_inform</i>	(Optional) dhcp message type
<i>inform_rx_pkts</i>	(Optional) received dhcp packets
<i>inform_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>inform_drops</i>	(Optional) dhcp packet drops
<i>msg_type_str_nack</i>	(Optional) dhcp message type
<i>nack_rx_pkts</i>	(Optional) received dhcp packets
<i>nack_tx_pkts</i>	(Optional) forwarded dhcp packets
<i>nack_drops</i>	(Optional) dhcp packet drops
<i>line</i>	(Optional)

<i>msg_type_str_total</i>	(Optional) total dhcp packets of all message types
<i>total_rx_pkts</i>	(Optional) total forwarded dhcp packets
<i>total_tx_pkts</i>	(Optional) total forwarded dhcp packets
<i>total_drops</i>	(Optional) total dhcp drops
<i>line_x</i>	(Optional)
<i>server_consolidated_hdr</i>	(Optional) DHCP server stats
TABLE_server_info	(Optional)
<i>server_helper_addr</i>	(Optional) dhcp server address
<i>server_vrf</i>	(Optional) dhcp server vrf
<i>server_total_request</i>	(Optional) total dhcp requests to server
<i>server_total_response</i>	(Optional) total dhcp responses from server
<i>line_y</i>	(Optional)
<i>l3_fwd_hdr</i>	(Optional) DHCP l3 forward header
<i>l3_fwd_rx_pkts</i>	(Optional) DHCP l3 received packets
<i>l3_fwd_tx_pkts</i>	(Optional) DHCP l3 forwarded packets
<i>l3_fwd_drops</i>	(Optional) DHCP l3 forward drops
<i>non_dhcp_hdr</i>	(Optional) non dhcp packets header
<i>non_dhcp_rx_pkts</i>	(Optional) total non dhcp packets received
<i>non_dhcp_tx_pkts</i>	(Optional) total non dhcp packets forwarded
<i>non_dhcp_drops</i>	(Optional) total non dhcp drops
<i>drop_hdr</i>	(Optional) total dhcp drops in various scenarios
<i>drop_validation_fail</i>	(Optional) drops due to option 82 validation failed
<i>drop_relay_disable</i>	(Optional) drops due to dhcp relay not enabled
<i>drop_invalid_msg_type</i>	(Optional) drops due to invalid message type
<i>drop_intf_err</i>	(Optional) drops due to interface error
<i>drop_tx_sock_err</i>	(Optional) tx failure towards server
<i>drop_tx_fail_client_intf</i>	(Optional) drops due to Tx failure towards client
<i>drop_unknown_op_intf</i>	(Optional) Unknown output interface
<i>drop_l3_unknown_op_intf</i>	(Optional) unknown vrf interface for server

<i>drop_max_hops</i>	(Optional) drops due to max hop exceeded
<i>drop_opt82_insert_fail</i>	(Optional) Insertion of option 82 failed
<i>drop_malformed</i>	(Optional) drops due to packet malformed
<i>drop_mct_drop</i>	(Optional) drops through mct
<i>drop_untrusted_relay_intf</i>	(Optional) drops due to untrusted relay interface
<i>server_discover</i>	(Optional) DHCP discover messages relayed to server
<i>server_request</i>	(Optional) DHCP request messages relayed to server
<i>server_decline</i>	(Optional) DHCP decline messages relayed to server
<i>server_release</i>	(Optional) DHCP release messages relayed to server
<i>server_inform</i>	(Optional) DHCP inform messages relayed to server
<i>server_ack</i>	(Optional) DHCP ack messages relayed from server
<i>server_nack</i>	(Optional) DHCP nack messages relayed from server
<i>server_offer</i>	(Optional) DHCP offer messages relayed from server
<i>server_resp_hdr</i>	(Optional) DHCP server response header
<i>drop_unknown</i>	(Optional) drops due to Unknown Failure
<i>server_req_hdr</i>	(Optional) DHCP server request header
<i>footer</i>	(Optional) footer line

Command Mode

- /exec

show ip dhcp snooping

```
show ip dhcp snooping [ __readonly__ <snoop_service_enable> <snoop_gbl_enable> <snoop_vlan_enable>
<snoop_oper_vlan_enable> <snoop_opt82_enable> <snoop_hwaddr_verify_enable> <snoop_hdr> [ {
TABLE_intf_entry <intf_entry_if_index> <intf_entry_trust_dhcp> <intf_entry_pkt_limit> } ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show items in DHCP
snooping	DHCP snooping
<i>__readonly__</i>	(Optional) Read only
<i>snoop_service_enable</i>	(Optional)
<i>snoop_gbl_enable</i>	(Optional)
<i>snoop_vlan_enable</i>	(Optional)
<i>snoop_oper_vlan_enable</i>	(Optional)
<i>snoop_opt82_enable</i>	(Optional)
<i>snoop_hwaddr_verify_enable</i>	(Optional)
<i>snoop_hdr</i>	(Optional)
TABLE_intf_entry	(Optional)
<i>intf_entry_if_index</i>	(Optional)
<i>intf_entry_trust_dhcp</i>	(Optional) is DHCP snooping trusted on the interface
<i>intf_entry_pkt_limit</i>	(Optional) limit for DHCP packets per second on the interface

Command Mode

- /exec

show ip dhcp snooping binding

show ip dhcp snooping binding [<ip> | <mac> | vlan <vlan-range> |

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show items in DHCP
snooping	DHCP snooping
binding	DHCP snooping bindings
<i>ip</i>	(Optional) Binding entry IP address
<i>mac</i>	(Optional) Binding entry MAC address
vlan	(Optional) Binding entry VLAN
<i>vlan-range</i>	(Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19

Command Mode

- /exec

show ip dhcp snooping statistics

show ip dhcp snooping statistics [{ vlan <vlan-id> interface <intf> } |

Syntax Description

<i>vlan-id</i>	(Optional)]
show	Show running system information
ip	Show the IP features of the system
dhcp	Show information about DHCP
snooping	DHCP snooping
statistics	Statistics related to DHCP
vlan	(Optional) VLAN
interface	(Optional) input interface
<i>intf</i>	(Optional) interface

Command Mode

- /exec

show ip dhcp status

show ip dhcp status [*__readonly__* [*<current_cli_op>*] [*<last_cli_op>* *<last_cli_stat>*]]

Syntax Description

show	Show running system information
ip	Show the IP features of the system
dhcp	Show information about DHCP
status	Current CLI command and execution status of the last command
<i>__readonly__</i>	(Optional) Read only
<i>current_cli_op</i>	(Optional) current cli operation
<i>last_cli_op</i>	(Optional) last cli operation
<i>last_cli_stat</i>	(Optional) last cli status

Command Mode

- /exec

show ip dns source-interface

```
show ip dns source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipdnsvrf
<vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
dns	Display domain-lookup information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ipdnsvrf	(Optional) source interface of dns given vrf
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip dns source-interface vrf all

```
show ip dns source-interface vrf all [ __readonly__ [ { TABLE_ipdns <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
dns	Display domain-lookup information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_ipdns	(Optional) source interface of dns
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip eigrp

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_asn <asn> <router_id> TABLE_vrf <vrf> <state> <authen_md5> <authen_keychain>
<metric_weight_k1> <metric_weight_k2> <metric_weight_k3> <metric_weight_k4> <metric_weight_k5>
[ <metric_weight_k6> <metric_rib scale> ] <metric_version> <eigrp_proto> { <multicast_group> |
<multicast_groupv6> } <int_distance> <ext_distance> <max_paths> <num_interfaces> <num_lo_interfaces>
<num_pass_interfaces> <num_peers> [ { TABLE_redist <redist_srcproto> <redist_routemap> } ]
<graceful_restart> <stub_configured> [ <stub_option_connected> <stub_option_summary>
<stub_option_redist> <stub_option_leak_map> <stub_option_receive_only> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
detail	(Optional) Show detailed EIGRP process stats
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>eigrp-ptag</i>	(Optional) Process tag
<i>__readonly__</i>	(Optional)
TABLE_asn	(Optional) AS Number table
<i>asn</i>	(Optional) AS number
<i>router_id</i>	(Optional) Router-ID
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
<i>state</i>	(Optional) EIGRP Process Status
<i>authen_md5</i>	(Optional) Authentication Mode
<i>authen_keychain</i>	(Optional) Authentication Key-Chain
<i>metric_weight_k1</i>	(Optional) DUAL metric k1
<i>metric_weight_k2</i>	(Optional) DUAL metric k2

<i>metric_weight_k3</i>	(Optional) DUAL metric k3
<i>metric_weight_k4</i>	(Optional) DUAL metric k4
<i>metric_weight_k5</i>	(Optional) DUAL metric k5
<i>metric_weight_k6</i>	(Optional) DUAL metric k6
<i>metric_rib_scale</i>	(Optional) RIB Scale
<i>metric_version</i>	(Optional) Metric version
<i>eigrp_proto</i>	(Optional) IP Protocol number
<i>multicast_group</i>	(Optional) Multicast Group Address
<i>int_distance</i>	(Optional) Internal Administrative Distance
<i>ext_distance</i>	(Optional) External Administrative Distance
<i>max_paths</i>	(Optional) Maximum paths allowed for a dndb
<i>num_interfaces</i>	(Optional) Number of EIGRP interfaces configured under this AS
<i>num_lo_interfaces</i>	(Optional) Number of EIGRP loopback interfaces configured under this AS
<i>num_pass_interfaces</i>	(Optional) Number of EIGRP Passive interfaces configured under this AS
<i>num_peers</i>	(Optional) Number of EIGRP peers
TABLE_redist	(Optional) Redistribution Table
<i>redist_srcproto</i>	(Optional) Source protocol of the redistributed route
<i>redist_routemap</i>	(Optional) Route-map used in this redistribution
<i>graceful_restart</i>	(Optional) Graceful restart configured?
<i>stub_configured</i>	(Optional) Stub-Routing configured?
<i>stub_option_connected</i>	(Optional) Advertise connected routes?
<i>stub_option_summary</i>	(Optional) Advertise summary routes?
<i>stub_option_redist</i>	(Optional) Advertise redistributed routes?
<i>stub_option_leak_map</i>	(Optional) Allow routes permitted by leak-map?
<i>stub_option_receive_only</i>	(Optional) Configured as receive only?

Command Mode

- /exec

show ip eigrp accounting

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] accounting [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_asn <asn> <router_id> TABLE_vrf <vrf> <total_prefix> <redist_state> <redist_count>
<restart_count> <acct_timer> [ TABLE_peer { <p_ipaddr> | <p_ipv6addr> } <p_state> <p_ifname>
<p_prefix_count> <p_restart_count> <p_acct_timer> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>eigrp-ptag</i>	(Optional) Process tag
accounting	IP-EIGRP Accounting
<u>__readonly__</u>	(Optional)
TABLE_asn	(Optional) AS number table
<i>asn</i>	(Optional) AS number
<i>router_id</i>	(Optional) Router-ID
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
<i>total_prefix</i>	(Optional) Total prefix count (Aggregate)
<i>redist_state</i>	(Optional) State of redistributed prefixes
<i>redist_count</i>	(Optional) Number of redistributed prefixes
<i>restart_count</i>	(Optional) Number of times the prefix was suspended
<i>acct_timer</i>	(Optional) Accounting timer
TABLE_peer	(Optional) Peer (Prefix) table
<i>p_ipaddr</i>	(Optional) Peer IP addr

<i>p_state</i>	(Optional) Peer state
<i>p_ifname</i>	(Optional) Peering interface
<i>p_prefix_count</i>	(Optional) Number of Prefixes learnt from the peer
<i>p_restart_count</i>	(Optional) Number of times the prefix was suspended
<i>p_acct_timer</i>	(Optional) Peer accounting timer

Command Mode

- /exec

show ip eigrp event-history

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] [ internal ] event-history { fsm | packet | rib }
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
<i>eigrp-ptag</i>	(Optional) Process tag
internal	(Optional) Commands for internal use
event-history	Event History of EIGRP
fsm	FSM log of EIGRP
packet	Packet log of EIGRP
rib	RIB log of EIGRP

Command Mode

- /exec

show ip eigrp event-history bfd

show { ip | ipv6 } eigrp [<eigrp-ptag>] [internal] event-history bfd

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
<i>eigrp-ptag</i>	(Optional) Process tag
internal	(Optional) Commands for internal use
event-history	Event History of EIGRP
bfd	Show bfd log of EIGRP

Command Mode

- /exec

show ip eigrp interfaces

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] interfaces [ detail ] [ <interface> ] [ brief ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_asn <asn> TABLE_vrf <vrf> [ TABLE_if <ifname>
<peer_count> <xmitq_unrel> <xmitq_rel> <mean_srtt> <send_intvl_unrel> <send_intvl_rel>
<mcast_flow_delay> <pending_routes> [ <hello_intvl> <holdtime_intvl> <next_xmit_erno>
<packetize_pending> <mcasts_sent_unrel> <mcasts_sent_rel> <ucasts_sent_unrel> <ucasts_sent_rel>
<mcast_exceptions> <cr_packets> <acks_suppressed> <retrans_sent> <out_of_seq_rcvd> <stub_interface>
<nexthop_self> <auth_mode_md5> <auth_key_chain> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>eigrp-ptag</i>	(Optional) Process tag
interfaces	IP-EIGRP interfaces
detail	(Optional) Show detailed interface information
<i>interface</i>	(Optional) Interface
brief	(Optional) Show summary information only
__readonly__	(Optional)
TABLE_asn	(Optional) AS number table
<i>asn</i>	(Optional) AS number
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
TABLE_if	(Optional) Interface table
<i>ifname</i>	(Optional) Interface name
<i>peer_count</i>	(Optional) Number of Peer on this interface
<i>xmitq_unrel</i>	(Optional) Xmit Q (unreliable) count

<i>xmitq_rel</i>	(Optional) Xmit Q (reliable) count
<i>mean_srtt</i>	(Optional) Mean of all peer SRTTs
<i>send_intvl_unrel</i>	(Optional) Base packet gap, per queue (unreliable)
<i>send_intvl_rel</i>	(Optional) Base packet gap, per queue (reliable)
<i>mcast_flow_delay</i>	(Optional) Last delay for Multicast flow control timer
<i>pending_routes</i>	(Optional) Pending routes on the interface
<i>hello_intvl</i>	(Optional) Configured hello interval for interface
<i>holdtime_intvl</i>	(Optional) Configured holdtime interval for interface
<i>next_xmit_serno</i>	(Optional) Next xmit serial number
<i>packetize_pending</i>	(Optional) Packetization pending?
<i>mcasts_sent_unrel</i>	(Optional) Number of Multicasts sent (unreliable)
<i>mcasts_sent_rel</i>	(Optional) Number of Multicasts sent (reliable)
<i>ucasts_sent_unrel</i>	(Optional) Number of Unicasts sent (unreliable)
<i>ucasts_sent_rel</i>	(Optional) Number of Unicasts sent (reliable)
<i>mcast_exceptions</i>	(Optional) Multicast exceptions (Count of multicasts sent as unicasts)
<i>cr_packets</i>	(Optional) Count of Multicasts sent with CR
<i>acks_suppressed</i>	(Optional) Count of suppressed ACK packets
<i>retrans_sent</i>	(Optional) Count of Retransmissions sent
<i>out_of_seq_rcvd</i>	(Optional) Count of packets received Out-of-Sequence
<i>stub_interface</i>	(Optional) All Peers are stubbed?
<i>nexthop_self</i>	(Optional) should retain next-hop?
<i>auth_mode_md5</i>	(Optional) MD5 Authentication enabled?
<i>auth_key_chain</i>	(Optional) Authentication key-chain

Command Mode

- /exec

show ip eigrp route-map statistics

```
show ip eigrp [ <eigrp-ptag> ] route-map statistics { { redistribute { bgp <as> | { eigrp | isis | ospf | rip } <tag>
| static | direct | amt | lisp } } | table-map } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_asn <asn> TABLE_vrf <vrf> { TABLE_rmap <name> <action> <seq_num> [ { TABLE_cmd
<command> <compare_count> <match_count> } ] } <total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
eigrp	Display EIGRP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>eigrp-ptag</i>	(Optional) Process tag
route-map	Route-map related information
statistics	Route-map statistics
redistribute	Redistribute information from another routing protocol
table-map	Tablemap information
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
isis	IS-IS Routing for IPv4
ospf	Open Shortest Path First (OSPF)
rip	Routing Information Protocol (RIP)
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
<i>tag</i>	Process tag
static	Static routes
direct	Directly connected
amt	AMT Anycast prefix
lisp	LISP EID-prefixes

<i>__readonly__</i>	(Optional)
<i>TABLE_asn</i>	(Optional) AS number table
<i>asn</i>	(Optional) AS number
<i>TABLE_vrf</i>	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
<i>TABLE_rmap</i>	(Optional) Routemap table
<i>name</i>	(Optional) Route-map Name
<i>action</i>	(Optional) Route-map action
<i>seq_num</i>	(Optional) Sequence number of the rule in route-map
<i>TABLE_cmd</i>	(Optional) Route-map command table
<i>command</i>	(Optional) Route-map command
<i>compare_count</i>	(Optional) Number of comparisons
<i>match_count</i>	(Optional) Number of matches
<i>total_accept_count</i>	(Optional) Total number of packets accepted by the policy
<i>total_reject_count</i>	(Optional) Total number of packets rejected by the policy

Command Mode

- /exec

show ip eigrp traffic

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] traffic [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_asn <asn> TABLE_vrf <vrf> <hellos_sent> <hellos_rcvd> <updates_sent> <updates_rcvd>
<queries_sent> <queries_rcvd> <replies_sent> <replies_rcvd> <acks_sent> <acks_rcvd> <max_inqueue_depth>
<inqueue_drops> <sia_queries_sent> <sia_queries_rcvd> <sia_replies_sent> <sia_replies_rcvd> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>eigrp-ptag</i>	(Optional) Process tag
traffic	IP-EIGRP Traffic Statistics
__readonly__	(Optional)
TABLE_asn	(Optional) AS number table
<i>asn</i>	(Optional) AS number
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
<i>hellos_sent</i>	(Optional) Number of Hellos sent
<i>hellos_rcvd</i>	(Optional) Number of Hellos received
<i>updates_sent</i>	(Optional) Number of Updates sent
<i>updates_rcvd</i>	(Optional) Number of Updates received
<i>queries_sent</i>	(Optional) Number of Queries sent
<i>queries_rcvd</i>	(Optional) Number of Queries received
<i>replies_sent</i>	(Optional) Number of Replies sent
<i>replies_rcvd</i>	(Optional) Number of Replies received

<i>acks_sent</i>	(Optional) Number of ACKs sent
<i>acks_rcvd</i>	(Optional) Number of ACKs received
<i>max_inqueue_depth</i>	(Optional) Input queue high water mark
<i>inqueue_drops</i>	(Optional) Input queue drops
<i>sia_queries_sent</i>	(Optional) Number of SIA queries sent
<i>sia_queries_rcvd</i>	(Optional) Number of SIA queries received
<i>sia_replies_sent</i>	(Optional) Number of SIA replies sent
<i>sia_replies_rcvd</i>	(Optional) Number of SIA replies received

Command Mode

- /exec

show ip extcommunity-list

show ip extcommunity-list [<extcl_name>] [__readonly__ TABLE_extcl <name> <action> <rule>]

Syntax Description

show	Show running system information
ip	Display IP information
extcommunity-list	List extcommunity-list
<i>extcl_name</i>	(Optional) Standard or expanded community-list name
<i>__readonly__</i>	(Optional)
TABLE_extcl	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>rule</i>	(Optional)

Command Mode

- /exec

show ip fib distribution

show ip fib distribution [pauz | rezum]

Syntax Description

show	
ip	ipv4
fib	forwarding information
distribution	fib distribution information
pauz	(Optional) start black-holing routes
rezum	(Optional) stop black-holing routes

Command Mode

- /exec

show ip fib distribution clients

show ip fib distribution clients [__readonly__ <id><pid><name><shms><shme><shmn>]

Syntax Description

show	
ip	ipv4
fib	forwarding information
distribution	fib distribution info
clients	unicast client information
__readonly__	(Optional)

Command Mode

- /exec

show ip fib distribution mroute

```
show ip fib distribution mroute [ { <group> | <gprefix> } [ <source> ] ] [ table <id> ] [ __readonly__
<table_name> <src_len> <grp_len> <df_ordinal> <rpfif> <rpf_ifname> <flag> <flag_value> <num_groups>
<num_sources> <refcount> <oiflist_id> <oif_count> <oif_name> <oif_ifindex> <bytecnt> <pkcnt> ]
```

Syntax Description

show	
ip	IP information
fib	Forwarding Information
distribution	FIB distribution information
mroute	MFDM IP multicast routing table
<i>group</i>	(Optional) IPv4 Multicast Group Address
<i>gprefix</i>	(Optional) IPv4 Multicast Group Prefix
<i>source</i>	(Optional) IPv4 Source Address
table	(Optional) Specify Multicast Routing Table
<i>id</i>	(Optional) Multicast Routing Table Identifier
<i>__readonly__</i>	(Optional)
<i>table_name</i>	(Optional) Table name
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifname</i>	(Optional) RPF Interface ifName
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>refcount</i>	(Optional) Reference Count
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>oif_count</i>	(Optional) Number of OIFs

<i>oif_name</i>	(Optional) OIF Name
<i>oif_ifindex</i>	(Optional) OIF ifIndex
<i>bytecnt</i>	(Optional) Current Byte counter
<i>pktcnt</i>	(Optional) Current Packet counter

Command Mode

- /exec

show ip fib distribution multicast

```
show ip fib distribution multicast [ messages ] [ __readonly__ <fibstate> <slot> <accepting_routes>
<num_accepting_routes> ]
```

Syntax Description

show	
ip	IP information
fib	Forwarding Information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
messages	(Optional) Outstanding Message Information
<i>__readonly__</i>	(Optional)
<i>fibstate</i>	(Optional) IP Multicast FIB process state
<i>slot</i>	(Optional) Slot
<i>accepting_routes</i>	(Optional) Indicates whether FIB is accepting routes
<i>num_accepting_routes</i>	(Optional) Number of fibs accepting routes

Command Mode

- /exec

show ip fib distribution multicast outgoing-interface-list

```
show ip fib distribution multicast outgoing-interface-list { L2 | L3 | OTV } [ <index> ] [ __readonly__
<platform_index> <ref_count> <num_oif> <oif> ]
```

Syntax Description

show	
ip	IP information
fib	Forwarding Information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
outgoing-interface-list	Outgoing interface list
L2	Layer 2 oiflist
L3	Layer 3 oiflist
OTV	OTV oiflist
<i>index</i>	(Optional) Outgoing Interface List index
<i>__readonly__</i>	(Optional)
<i>platform_index</i>	(Optional) Platform index
<i>ref_count</i>	(Optional) Reference count
<i>num_oif</i>	(Optional) Number of outgoing interfaces
<i>oif</i>	(Optional) OIF name

Command Mode

- /exec

show ip fib distribution state

show ip fib distribution state [__readonly__ <slot><known><ar><rcnt><state>]

Syntax Description

show	
ip	ipv4
fib	forwarding information
distribution	fib distribution info
state	unicast fib state info
__readonly__	(Optional)

Command Mode

- /exec

show ip fib mroute

```
show ip fib mroute [ { <group> | <gprefix> } [ <source> ] ] [ table <table-id> ] [ module <module> ] [
__readonly__ <table_type> <num_groups> <num_sources> <src_len> <grp_len> <df_ordinal> <rpfif>
<rpf_ifindex> <flag> <flag_value> <route_pkts> <route_bytes> <oiflist_id> <platform_id> <oif_count>
<refcount> <oifname> <oifindex> <oif_pkts> <oif_bytes> ]
```

Syntax Description

show	
ip	Display IP information
fib	Forwarding information
mroute	Multicast IPv4 routes
<i>group</i>	(Optional) Multicast IPv4 Group Address
<i>gprefix</i>	(Optional) Multicast IPv4 Group Prefix
<i>source</i>	(Optional) Multicast IPv4 Source Address
table	(Optional) display info per vpn-id
<i>table-id</i>	(Optional) table-id
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifindex</i>	(Optional) RPF Interface ifIndex
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>route_pkts</i>	(Optional) Route packet count

<i>route_bytes</i>	(Optional) Route bytes
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>platform_id</i>	(Optional) Platform-index
<i>oif_count</i>	(Optional) Number of OIFs
<i>refcount</i>	(Optional) OIF list Reference Count
<i>oifname</i>	(Optional) OIF Interface name
<i>oifindex</i>	(Optional) OIF Interface ifIndex
<i>oif_pkts</i>	(Optional) OIF packets
<i>oif_bytes</i>	(Optional) OIF bytes

Command Mode

- /exec

show ip fib mroute

```
show ip fib mroute [ { <group> | <gprefix> } [ <source> ] ] [ table <table-id> ] [ module <module> ] [
__readonly__ <table_type> <num_groups> <num_sources> <src_len> <grp_len> <df_ordinal> <rpfif>
<rpf_ifindex> <flag> <flag_value> <route_pkts> <route_bytes> <oiflist_id> <platform_id> <oif_count>
<refcount> <oifname> <oifindex> <oif_pkts> <oif_bytes> ]
```

Syntax Description

show	
ip	Display IP information
fib	Forwarding information
mroute	Multicast IPv4 routes
<i>group</i>	(Optional) Multicast IPv4 Group Address
<i>gprefix</i>	(Optional) Multicast IPv4 Group Prefix
<i>source</i>	(Optional) Multicast IPv4 Source Address
table	(Optional) display info per vpn-id
<i>table-id</i>	(Optional) table-id
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifindex</i>	(Optional) RPF Interface ifIndex
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>route_pkts</i>	(Optional) Route packet count

<i>route_bytes</i>	(Optional) Route bytes
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>platform_id</i>	(Optional) Platform-index
<i>oif_count</i>	(Optional) Number of OIFs
<i>refcount</i>	(Optional) OIF list Reference Count
<i>oifname</i>	(Optional) OIF Interface name
<i>oifindex</i>	(Optional) OIF Interface ifIndex
<i>oif_pkts</i>	(Optional) OIF packets
<i>oif_bytes</i>	(Optional) OIF bytes

Command Mode

- /exec

show ip fib route

```
show ip fib route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ table <table_id> ] [ summary | <prefix>
[ longer-prefixes ] | <address> | interface <interface> | next-hop <nh> | attached | unresolved | adjacency {
<aif> <anh> | drop | glean | punt } ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all>
} ] + [ __readonly__ [ <header> <vrfname> <tableid> <prefix-count> <pfx> { <nexthop> | <special> } <intf>
<route-count> <path-count> <mask-length> <routes-per-mask> ] [ TABLE_vrf { [ <vrf_name_out> ] [
<table_name> ] [ TABLE_prefix { [ <pfx> ] [ TABLE_path { [ <nexthop> | <special> ] [ <intf> ] } ] } ] ] ] ] ] ]
```

Syntax Description

show	
ip	Display IP information
fib	Forwarding information
route	display IP routing table
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
summary	(Optional) display route counts
<i>prefix</i>	(Optional) display single exact match route
longer-prefixes	(Optional) display longer prefixes
<i>address</i>	(Optional) display single longest match route
interface	(Optional) display routes with this output i/f only
<i>interface</i>	(Optional) output interface
next-hop	(Optional) display routes with this next-hop only
<i>nh</i>	(Optional) next hop address
attached	(Optional) display directly connected routes
unresolved	(Optional) display unresolved routes
adjacency	(Optional) display routes via specified adjacency
<i>aif</i>	(Optional) adjacency output interface

<i>anh</i>	(Optional) adjacency next-hop address
<i>drop</i>	(Optional) display routes via drop adjacency
<i>glean</i>	(Optional) display routes via glean adjacency
<i>punt</i>	(Optional) display routes via punt adjacency
<i>module</i>	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>header</i>	(Optional) header string
<i>vrfname</i>	(Optional) VRF name
<i>tableid</i>	(Optional) table identifier
<i>prefix-count</i>	(Optional) total number of prefix in VRF
<i>px</i>	(Optional) ipv4 prefix
<i>nexthop</i>	(Optional) next hop address
<i>special</i>	(Optional) special adjacencies
<i>intf</i>	(Optional) output interface
<i>route-count</i>	(Optional) total number of routes in VRF
<i>path-count</i>	(Optional) total number of paths in VRF
<i>mask-length</i>	(Optional) length of mask
<i>routes-per-mask</i>	(Optional)
TABLE_vrf	(Optional) vrf table
<i>vrf_name_out</i>	(Optional) VRF name
<i>table_name</i>	(Optional) table name
TABLE_prefix	(Optional) all xml prefix entries
<i>px</i>	(Optional) ipv4 prefix
TABLE_path	(Optional) path table
<i>nexthop</i>	(Optional) next hop address
<i>special</i>	(Optional) special adjacencies
<i>intf</i>	(Optional) output interface

Command Mode

- /exec

show ip fib route

```
show ip fib route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ summary | <prefix>
[ longer-prefixes ] | <address> | interface <interface> | next-hop <nh> | attached | unresolved | adjacency {
<aif> <anh> | drop | glean | punt } ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all>
} ] + [ __readonly__ <header> <vrfname> <tableid> <prefix-count> <px> { <nexthop> | <special> } <intf>
<route-count> <path-count> <mask-length> <routes-per-mask> ]
```

Syntax Description

show	
ip	Display IP information
fib	Forwarding information
route	display IP routing table
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
summary	(Optional) display route counts
<i>prefix</i>	(Optional) display single exact match route
longer-prefixes	(Optional) display longer prefixes
<i>address</i>	(Optional) display single longest match route
interface	(Optional) display routes with this output i/f only
<i>interface</i>	(Optional) output interface
next-hop	(Optional) display routes with this next-hop only
<i>nh</i>	(Optional) next hop address
attached	(Optional) display directly connected routes
unresolved	(Optional) display unresolved routes
adjacency	(Optional) display routes via specified adjacency
<i>aif</i>	(Optional) adjacency output interface
<i>anh</i>	(Optional) adjacency next-hop address

drop	(Optional) display routes via drop adjacency
glean	(Optional) display routes via glean adjacency
punt	(Optional) display routes via punt adjacency
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>header</i>	(Optional) header string
<i>vrfname</i>	(Optional) VRF name
<i>tableid</i>	(Optional) table identifier
<i>prefix-count</i>	(Optional) total number of prefix in VRF
<i>pfx</i>	(Optional) ipv4 prefix
<i>nexthop</i>	(Optional) next hop address
<i>special</i>	(Optional) special adjacencies
<i>intf</i>	(Optional) output interface
<i>route-count</i>	(Optional) total number of routes in VRF
<i>path-count</i>	(Optional) total number of paths in VRF
<i>mask-length</i>	(Optional) length of mask
<i>routes-per-mask</i>	(Optional)

Command Mode

- /exec

show ip fib route recovered

show ip fib route recovered

Syntax Description

show	
ip	ipv4
fib	display fib information
route	display IP routing table
recovered	log of routes recovered after TCAM free condition

Command Mode

- /exec

show ip ftp source-interface

```
show ip ftp source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipftpvrf
<vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ftp	Display FTP client information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ipftpvrf	(Optional) source interface of ftp given vrf
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip ftp source-interface vrf all

```
show ip ftp source-interface vrf all [ __readonly__ [ { TABLE_ipftp <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ftp	Display FTP client information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_ipftp	(Optional) source interface of ftp
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip http source-interface

```
show ip http source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_iphttpvrf
<vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
http	Display HTTP client information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_iphttpvrf	(Optional) source interface of http given vrf
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip http source-interface vrf all

```
show ip http source-interface vrf all [ __readonly__ [ { TABLE_iphttp <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
http	Display HTTP client information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_iphttp	(Optional) source interface of http
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip igmp event-history

```
show ip igmp [ internal ] event-history { errors | msgs | <igmp-event-hist-buf-name> | statistics }
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
internal	(Optional) Commands for internal use
event-history	Show various event logs of IGMP
errors	Show error logs of IGMP
msgs	Show various message logs of IGMP
<i>igmp-event-hist-buf-name</i>	Show various logs of IGMP
statistics	Show state and size of buffer

Command Mode

- /exec

show ip igmp groups

```
show ip igmp { groups | route } [ <source> [ <group> ] | <group> [ <source> ] ] [ <interface> ] [ summary ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ summary-old ] [ __readonly__ [ TABLE_vrf [ <if-name>
] [ <vrfname> ] [ <entry-count> ] [ <group-addr> ] [ <sourceaddress> ] [ TABLE_group [ <group-addr> ] [
<group-type> ] [ <if-name> ] [ <uptime> ] [ <expires> ] [ <reporter> ] ] [ TABLE_source [ <source-addr> ]
[ <group-type> ] [ <translate> ] [ <if-name> ] [ <uptime> ] [ <expires> ] [ <reporter> ] ] [ <vrf-cntxt> ] [
<g-count> ] [ <sg-count> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
groups	Display IGMP attached group membership information
route	Display IGMP attached group membership information
<i>group</i>	(Optional) Multicast IP address of single group to display
<i>source</i>	(Optional) Source IP address
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>interface</i>	(Optional) Display group membership on single interface name
summary	(Optional) Display group summary
summary-old	(Optional) Display group summary
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrfname</i>	(Optional)
<i>if-name</i>	(Optional)
<i>group-addr</i>	(Optional)
<i>entry-count</i>	(Optional)
<i>sourceaddress</i>	(Optional)
TABLE_group	(Optional)

<i>group-addr</i>	(Optional)
<i>group-type</i>	(Optional)
<i>if-name</i>	(Optional)
<i>uptime</i>	(Optional)
<i>expires</i>	(Optional)
<i>reporter</i>	(Optional)
TABLE_source	(Optional)
<i>source-addr</i>	(Optional)
<i>group-type</i>	(Optional)
<i>translate</i>	(Optional)
<i>if-name</i>	(Optional)
<i>uptime</i>	(Optional)
<i>expires</i>	(Optional)
<i>reporter</i>	(Optional)
<i>vrf-cntxt</i>	(Optional)
<i>g-count</i>	(Optional)
<i>sg-count</i>	(Optional)

Command Mode

- /exec

<i>ver</i>	(Optional)
TABLE_if	(Optional)
<i>if-name</i>	(Optional)
<i>if-status</i>	(Optional)
<i>ip-sum</i>	(Optional)
<i>addr</i>	(Optional)
<i>querier</i>	(Optional)
<i>q-ver</i>	(Optional)
<i>next-query</i>	(Optional)
<i>expires</i>	(Optional)
<i>mc</i>	(Optional)
<i>ver</i>	(Optional)
<i>host-ver</i>	(Optional)
<i>qi</i>	(Optional)
<i>cqi</i>	(Optional)
<i>mrt</i>	(Optional)
<i>cmrt</i>	(Optional)
<i>sqi</i>	(Optional)
<i>csqi</i>	(Optional)
<i>sqc</i>	(Optional)
<i>lmmrt</i>	(Optional)
<i>lmqc</i>	(Optional)
<i>gt</i>	(Optional)
<i>cgt</i>	(Optional)
<i>qt</i>	(Optional)
<i>cqt</i>	(Optional)
<i>uri</i>	(Optional)
<i>rv</i>	(Optional)
<i>crv</i>	(Optional)

<i>rll</i>	(Optional)
<i>rc</i>	(Optional)
<i>v1rr</i>	(Optional)
<i>v2qs</i>	(Optional)
<i>v2qr</i>	(Optional)
<i>v2rs</i>	(Optional)
<i>v2rr</i>	(Optional)
<i>v2ls</i>	(Optional)
<i>v2lr</i>	(Optional)
<i>v3qs</i>	(Optional)
<i>v3qr</i>	(Optional)
<i>v3rs</i>	(Optional)
<i>v3rr</i>	(Optional)
<i>v2ggdest</i>	(Optional)
<i>v3ggdest</i>	(Optional)
<i>cse</i>	(Optional)
<i>ple</i>	(Optional)
<i>lsip</i>	(Optional)
<i>scf</i>	(Optional)
<i>qnq</i>	(Optional)
<i>rvm</i>	(Optional)
<i>qvm</i>	(Optional)
<i>uit</i>	(Optional)
<i>v1gdam</i>	(Optional)
<i>v2gdam</i>	(Optional)
<i>v3dai</i>	(Optional)
<i>ra</i>	(Optional)
<i>static-group-map</i>	(Optional)
<i>join-group-map</i>	(Optional)

<i>host-proxy-group-map</i>	(Optional)
<i>il</i>	(Optional)
<i>host-proxy</i>	(Optional)
<i>un-solicited</i>	(Optional)
<i>unsoint</i>	(Optional)

Command Mode

- /exec

show ip igmp local-groups

```
show ip igmp local-groups [ <interface> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf [ <vrf-name> ] [ TABLE_if [ <if-name> ] [ TABLE_grp [ <group-addr> ] [ TABLE_src [
<source-addr> ] [ <last-reported> ] [ <local-group> ] [ <static-oif> ] [ <report-only> ] [ <host-proxy> ] ] ] ]
]]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
local-groups	Display IGMP local group membership information
<i>interface</i>	(Optional) Display group membership on single interface name
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_if	(Optional)
<i>if-name</i>	(Optional)
TABLE_grp	(Optional)
<i>group-addr</i>	(Optional)
TABLE_src	(Optional)
<i>source-addr</i>	(Optional)
<i>last-reported</i>	(Optional)
<i>local-group</i>	(Optional)
<i>static-oif</i>	(Optional)
<i>report-only</i>	(Optional)
<i>host-proxy</i>	(Optional)

Command Mode

- /exec

show ip igmp policy statistics reports

```
show ip igmp policy statistics reports [ <interface> ] [ __readonly__ [ TABLE_interface [ <if> ] [
TABLE_routemap [ <name> ] [ <action> ] [ <seq_num> ] [ TABLE_cmd [ <command> ] [ <match_count>
] [ <compare_count> ] ] ] [ <total_accept_count> ] [ <total_reject_count> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Show IGMP related information
policy	Policy related information
statistics	Policy statistics
reports	IGMP reports
<i>interface</i>	(Optional) Interface to display statistics for
<i>__readonly__</i>	(Optional)
TABLE_interface	(Optional)
<i>if</i>	(Optional)
TABLE_routemap	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seq_num</i>	(Optional)
TABLE_cmd	(Optional)
<i>command</i>	(Optional)
<i>compare_count</i>	(Optional)
<i>match_count</i>	(Optional)
<i>total_accept_count</i>	(Optional)
<i>total_reject_count</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping

```
show ip igmp snooping [ { vlan <vlan> | bridge-domain <bidid> } ] [ __readonly__ [ <vdc> ] [ <enabled> ] [
<omf> ] [ <grepsup> ] [ <gv3repsup> ] [ <glinklocalgrpsup> ] { TABLE_vlan <vlan-id> [ <description> ] [
<snoop-on> ] [ <qa> ] [ <qv> ] [ <qi> ] [ <qlmqi> ] [ <rv> ] [ <sq> ] [ <sqr> ] [ <eht> ] [ <fl> ] [ <repsup> ]
[ <v3repsup> ] [ <vlinklocalgrpsup> ] [ <rpc> ] [ <gc> ] [ TABLE_active_ports [ <actvports> ] ] [ <lkupmode>
] [ <omf_enabled> ] [ <reportfloodenable> ] [ <reportfloodall> ] [ TABLE_intf <if-name> ] [
<leavegroupaddress> ] } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
vlan	(Optional) Display VLAN IGMP snooping membership information
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD IGMP snooping membership information
<i>bidid</i>	(Optional) Specify BD
<i>__readonly__</i>	(Optional)
<i>vdc</i>	(Optional)
<i>enabled</i>	(Optional)
<i>omf</i>	(Optional)
<i>grepsup</i>	(Optional)
<i>gv3repsup</i>	(Optional)
<i>glinklocalgrpsup</i>	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
<i>description</i>	(Optional) description, if any
<i>snoop-on</i>	(Optional)
<i>qa</i>	(Optional)
<i>qv</i>	(Optional)
<i>qi</i>	(Optional)

<i>qlmqi</i>	(Optional)
<i>rv</i>	(Optional)
<i>sq</i>	(Optional)
<i>sqr</i>	(Optional)
<i>eht</i>	(Optional)
<i>fl</i>	(Optional)
<i>repsup</i>	(Optional)
<i>v3repsup</i>	(Optional)
<i>vlinklocalgrpsup</i>	(Optional)
<i>rpc</i>	(Optional)
<i>gc</i>	(Optional)
TABLE_active_ports	(Optional)
<i>actvports</i>	(Optional)
<i>lkupmode</i>	(Optional)
<i>omf_enabled</i>	(Optional)
<i>reportfloodenable</i>	(Optional)
<i>reportfloodall</i>	(Optional)
TABLE_intf	(Optional)
<i>if-name</i>	(Optional)
<i>leavegroupaddress</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping event-history

```
show ip igmp snooping [ internal ] event-history { statistics | <igmp-snoop-event-hist-buf-name> }
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
internal	(Optional) Display IGMP snooping internal information
event-history	Show various event logs of IGMP Snooping
statistics	Show state and size of the buffers
<i>igmp-snoop-event-hist-buf-name</i>	Show contents of event-history buffer

Command Mode

- /exec

<i>expires</i>	(Optional)
<i>cfs-flag</i>	(Optional)
<i>native-flag</i>	(Optional)
<i>delete-pending</i>	(Optional)
<i>cfs-update-pending</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping filter details

```
show ip igmp snooping filter [ vlan <vlan_id> ] details [ __readonly__ { TABLE_vlanid <vlan-id>
<access-group> <group-channels-limit> <igmp-min-ver> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
filter	Shows filter policy configuration
vlan	(Optional) Only for the specified VLAN
<i>vlan_id</i>	(Optional) VLAN ID
details	Shows different Filter configurations
<i>__readonly__</i>	(Optional)
TABLE_vlanid	(Optional)
<i>vlan-id</i>	(Optional)
<i>access-group</i>	(Optional)
<i>group-channels-limit</i>	(Optional)
<i>igmp-min-ver</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping groups

```
show ip igmp snooping [ otv | remote ] groups [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ vlan
<vlan> | bridge-domain <bdid> ] [ detail ] [ summary ] [ __readonly__ [ TABLE_vlan [ <vlan-id> ] [ <rports>
] [ <rtrPortFlag> ] [ TABLE_port <if-name> ] [ TABLE_rtrports <rport-if-name> ] [ <raddr> ] [ TABLE_source
<source> ] [ TABLE_group <addr> [ <g-mfdm> ] [ <ver> ] [ <old-host> ] [ <raddr> ] [ <static> ] [ <dynamic>
] [ TABLE_static_ports <static-if-name> ] [ TABLE_v2_ports <v2-if-name> [ <uptime> ] [ <expires> ] [
<gq-missed> ] ] [ TABLE_star_g_ports <star-g-if-name> [ <uptime> ] [ <expires> ] ] [ <g-vpc> ] [ <rsf> ] [
<js> ] [ TABLE_source <source> [ <srsf> ] [ <s-mfdm> ] [ <src-static> ] [ <src-dynamic> ] [
TABLE_src_static_ports <src-static-if-name> ] [ TABLE_src_dynamic [ <oifs> ] <dyn-if-name> [ <src-uptime>
] [ <src-expires> ] ] [ <s-vpc> ] ] ] [ <snoop-enabled> ] [ <omf-enabled> ] [ <group-count> ] [ <s-g-count>
] [ <total_star_g_count> ] [ <total_sg_count> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
otv	(Optional) IGMP Snooping OTV information
remote	(Optional) IGMP Snooping remote information
groups	Display snooping information for group address
summary	(Optional) Display snooping group summary
<i>group</i>	(Optional) Multicast IP address of single group to display
<i>source</i>	(Optional) Source IP address
vlan	(Optional) Display VLAN IGMP snooping membership information
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD IGMP snooping membership information
<i>bdid</i>	(Optional) Specify BD
detail	(Optional) Display detailed information for the group
__readonly__	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
<i>rports</i>	(Optional)
<i>rtrPortFlag</i>	(Optional)

<i>snoop-enabled</i>	(Optional)
<i>omf-enabled</i>	(Optional)
<i>group-count</i>	(Optional)
<i>s-g-count</i>	(Optional)
<i>total_star_g_count</i>	(Optional)
<i>total_sg_count</i>	(Optional)
TABLE_port	(Optional)
<i>if-name</i>	(Optional)
TABLE_rtrports	(Optional)
<i>rport-if-name</i>	(Optional)
<i>raddr</i>	(Optional)
TABLE_group	(Optional)
<i>addr</i>	(Optional)
<i>ver</i>	(Optional)
<i>raddr</i>	(Optional)
TABLE_source	(Optional)
<i>source</i>	(Optional)
<i>rsf</i>	(Optional)
<i>js</i>	(Optional)
<i>g-mfdm</i>	(Optional)
<i>old-host</i>	(Optional)
<i>g-vpc</i>	(Optional)
<i>static</i>	(Optional)
<i>dynamic</i>	(Optional)
TABLE_static_ports	(Optional)
<i>static-if-name</i>	(Optional)
TABLE_v2_ports	(Optional)
<i>v2-if-name</i>	(Optional)
<i>uptime</i>	(Optional)

<i>expires</i>	(Optional)
<i>gq-missed</i>	(Optional)
TABLE_star_g_ports	(Optional)
<i>star-g-if-name</i>	(Optional)
<i>uptime</i>	(Optional)
<i>expires</i>	(Optional)
TABLE_source	(Optional)
<i>source</i>	(Optional)
<i>srsf</i>	(Optional)
<i>s-mfdm</i>	(Optional)
<i>s-vpc</i>	(Optional)
<i>src-static</i>	(Optional)
<i>src-dynamic</i>	(Optional)
TABLE_src_static_ports	(Optional)
<i>src-static-if-name</i>	(Optional)
TABLE_src_dynamic	(Optional)
<i>oifs</i>	(Optional)
<i>dyn-if-name</i>	(Optional)
<i>src-uptime</i>	(Optional)
<i>src-expires</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping lookup-mode

```
show ip igmp snooping lookup-mode [ vlan <vlan> | bridge-domain <bidid> ] [ __readonly__ [ <configured> ] [ <operational> ] [ TABLE_vlan [ <vlan-id> ] [ <lookup> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
lookup-mode	IGMP Snooping lkup mode information
vlan	(Optional) Display VLAN information
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD information
<i>bidid</i>	(Optional) Specify BD
<i>__readonly__</i>	(Optional)
<i>configured</i>	(Optional)
<i>operational</i>	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
<i>lookup</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping mac-oif

```
show ip igmp snooping mac-oif [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ __readonly__ [ <totaloif> ] ] [ TABLE_vlan [ <vlan-id> ] [ <count> ] [ TABLE_mac [ <mac-addr> ] [ TABLE_oif [ <oifs> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
mac-oif	IGMP Snooping static mac oif information
vlan	(Optional) Display VLAN information
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD information
<i>bdid</i>	(Optional) Specify BD
detail	(Optional) static mac oif detail, M2RIB oif info
<i>__readonly__</i>	(Optional)
<i>totaloif</i>	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
<i>count</i>	(Optional)
TABLE_mac	(Optional)
<i>mac-addr</i>	(Optional)
TABLE_oif	(Optional)
<i>oifs</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping mrouter

```
show ip igmp snooping mrouter [ otv ] [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ __readonly__
TABLE_vlan <vlan-id> TABLE_intf <if-name> <static> <dynamic> <vpc> <fabricpath-core-port>
<co-learned> <user-configured> <learnt-by-peer> <uptime> <expires> <internal> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
mrouter	Display multicast routers detected
otv	(Optional) IGMP Snooping OTV information
vlan	(Optional) Display VLAN multicast router information
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD multicast router information
<i>bdid</i>	(Optional) Specify BD
detail	(Optional) Display detailed mrouter information
<i>__readonly__</i>	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
TABLE_intf	(Optional)
<i>if-name</i>	(Optional)
<i>uptime</i>	(Optional)
<i>expires</i>	(Optional)
<i>static</i>	(Optional)
<i>dynamic</i>	(Optional)
<i>internal</i>	(Optional)
<i>vpc</i>	(Optional)
<i>fabricpath-core-port</i>	(Optional)
<i>co-learned</i>	(Optional)

<i>user-configured</i>	(Optional)
<i>learnt-by-peer</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping pw vlan brief

show ip igmp snooping pw vlan brief [*__readonly__* <vlan-id>]

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
pw	IGMP Snooping PW information
vlan	Display VLAN/BD information
brief	Brief output
<i>__readonly__</i>	(Optional)
<i>vlan-id</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping querier

```
show ip igmp snooping querier [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ __readonly__ [ TABLE_vlan
<vlan-id> <qa> <qv> [ <expires> ] <qiod> <qname> <int> [ <last_member_query_count> ] [
<config_last_member_query_count> ] [ <snooping_version> ] [ <config_qv> ] [ <robust> ] [ <config_robust>
] [ <startup_query_count> ] [ <config_startup_query_count> ] [ <startup_query_interval> ] [
<config_startup_query_interval> ] [ <mbr_query_interval> ] [ <config_mbr_query_interval> ] [
<snooping_query_intvl> ] [ <config_snooping_query_intvl> ] [ <gquery_response_time> ] [
<config_gquery_response_time> ] [ <querier_timeout> ] [ <querier_timeout_flag> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
querier	Display snooping querier information
vlan	(Optional) Display VLAN IGMP snooping querier information
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD IGMP snooping querier information
<i>bdid</i>	(Optional) Specify BD
detail	(Optional) Display detailed information
<i>__readonly__</i>	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
<i>qa</i>	(Optional)
<i>expires</i>	(Optional)
<i>qv</i>	(Optional)
<i>qiod</i>	(Optional)
<i>qname</i>	(Optional)
<i>int</i>	(Optional)
<i>last_member_query_count</i>	(Optional)
<i>config_last_member_query_count</i>	(Optional)
<i>snooping_version</i>	(Optional)

<i>config_qv</i>	(Optional)
<i>robust</i>	(Optional)
<i>config_robust</i>	(Optional)
<i>startup_query_count</i>	(Optional)
<i>config_startup_query_count</i>	(Optional)
<i>startup_query_interval</i>	(Optional)
<i>config_startup_query_interval</i>	(Optional)
<i>mbr_query_interval</i>	(Optional)
<i>config_mbr_query_interval</i>	(Optional)
<i>snooping_query_intvl</i>	(Optional)
<i>config_snooping_query_intvl</i>	(Optional)
<i>gquery_response_time</i>	(Optional)
<i>config_gquery_response_time</i>	(Optional)
<i>querier_timeout</i>	(Optional)
<i>querier_timeout_flag</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping report statistics

```
show ip igmp snooping { report-policy | access-group } statistics [ vlan <vlan> ] [ __readonly__ [
TABLE_vlanid { <vlan-id> <rpm-type> <policy-name> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
report-policy	IGMP Report Policy
access-group	IGMP access-group
statistics	Policy statistics
vlan	(Optional) Display VLAN IGMP snooping policy statistics information
<i>vlan</i>	(Optional) Specify VLAN
__readonly__	(Optional)
TABLE_vlanid	(Optional)
<i>vlan-id</i>	(Optional)
<i>rpm-type</i>	(Optional)
<i>policy-name</i>	(Optional)

Command Mode

- /exec

show ip igmp snooping statistics

```
show ip igmp snooping statistics [ global | vlan <vlan> | bridge-domain <bidid> ] [ __readonly__ [ <pr> ] [
<inv_pkt> ] [ <pnv> ] [ <loopbkpkt> ] [ <mrdloopbk> ] [ <pf> ] [ <vpcdrqs> ] [ <vpcdrqr> ] [ <vpcdrqf> ] [
<vpcdrus> ] [ <vpcdrur> ] [ <vpcdruf> ] [ <vpccfss> ] [ <vpccfss> ] [ <vpccfssr> ] [ <vpccfssrf> ] [ <vpccfssrfp> ]
] [ <vpccfsurl> ] [ <vpccfsurlr> ] [ <vpccfsurlf> ] [ <vpccfsrl> ] [ <vpccfsrlr> ] [ <vpccfsrlf> ] [ <inv_iod> ]
] [ <stptcnr> ] [ <imapif> ] [ <mfreqr> ] [ <mfcmps> ] [ <mfdbgcmps> ] [ <bufsnt> ] [ <bufackr> ] [
<vpemismatch> ] [ { TABLE_vlan [ <vlan-id> ] [ <ut> ] [ <vpr> ] [ <v1rr> ] [ <v2rr> ] [ <v3rr> ] [ <v1qr> ]
] [ <v2qr> ] [ <v3qr> ] [ <v2lr> ] [ <phr> ] [ <irr> ] [ <iqr> ] [ <v1rs> ] [ <v2rs> ] [ <v2ls> ] [ <v3gs> ] [
<vmr> ] [ <upr> ] [ <qo> ] [ <v2ro> ] [ <v2lo> ] [ <v3ro> ] [ <vpsr> ] [ <str> ] [ <mps> ] [ <mpr> ] [ <mpe> ]
] [ <cps> ] [ <cpr> ] [ <cpe> ] [ <repflooded> ] [ <repfwded> ] } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
statistics	Display packet/error counter statistics
global	(Optional) Display global statistics
vlan	(Optional) Display VLAN statistics
<i>vlan</i>	(Optional) Specify VLAN
bridge-domain	(Optional) Display BD statistics
<i>bidid</i>	(Optional) Specify BD
<i>__readonly__</i>	(Optional)
<i>pr</i>	(Optional)
<i>inv_pkt</i>	(Optional)
<i>pnv</i>	(Optional)
<i>loopbkpkt</i>	(Optional)
<i>mrdloopbk</i>	(Optional)
<i>pf</i>	(Optional)
<i>vpcdrqs</i>	(Optional)
<i>vpcdrqr</i>	(Optional)
<i>vpcdrqf</i>	(Optional)
<i>vpcdrus</i>	(Optional)

<i>vpcdrur</i>	(Optional)
<i>vpcdruf</i>	(Optional)
<i>vpccfssf</i>	(Optional)
<i>vpccfsrs</i>	(Optional)
<i>vpccfsrr</i>	(Optional)
<i>vpccfsrf</i>	(Optional)
<i>vpccfsrjp</i>	(Optional)
<i>vpccfsurls</i>	(Optional)
<i>vpccfsurlr</i>	(Optional)
<i>vpccfsurlf</i>	(Optional)
<i>vpccfsrls</i>	(Optional)
<i>vpccfsrlr</i>	(Optional)
<i>vpccfsrlf</i>	(Optional)
<i>inv_iod</i>	(Optional)
<i>stptcnr</i>	(Optional)
<i>imapif</i>	(Optional)
<i>mfreqr</i>	(Optional)
<i>mfcmps</i>	(Optional)
<i>mfldgcmps</i>	(Optional)
<i>bufsnt</i>	(Optional)
<i>bufackr</i>	(Optional)
<i>vpcmismatch</i>	(Optional)
TABLE_vlan	(Optional)
<i>vlan-id</i>	(Optional)
<i>ut</i>	(Optional)
<i>vpr</i>	(Optional)
<i>v1rr</i>	(Optional)
<i>v2rr</i>	(Optional)
<i>v3rr</i>	(Optional)

<i>v1qr</i>	(Optional)
<i>v2qr</i>	(Optional)
<i>v3qr</i>	(Optional)
<i>v2lr</i>	(Optional)
<i>phr</i>	(Optional)
<i>irr</i>	(Optional)
<i>iqr</i>	(Optional)
<i>v1rs</i>	(Optional)
<i>v2rs</i>	(Optional)
<i>v2ls</i>	(Optional)
<i>v3gs</i>	(Optional)
<i>vmr</i>	(Optional)
<i>upr</i>	(Optional)
<i>qo</i>	(Optional)
<i>v2ro</i>	(Optional)
<i>v2lo</i>	(Optional)
<i>v3ro</i>	(Optional)
<i>vpsr</i>	(Optional)
<i>str</i>	(Optional)
<i>cps</i>	(Optional)
<i>cpr</i>	(Optional)
<i>cpe</i>	(Optional)
<i>mps</i>	(Optional)
<i>mpr</i>	(Optional)
<i>mpe</i>	(Optional)
<i>repflooded</i>	(Optional)
<i>repfwded</i>	(Optional)

Command Mode

- /exec

show ip igmp vrf all

```
show ip igmp vrf all [ __readonly__ { TABLE_vrfname <vrf-name> <vrf-id> <instance> <work-in-txlist> }
{ TABLE_vrfid <vrf-name-i> <vrf-id-i> <instance-i> <work-in-txlist-i> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
igmp	Display IGMP status and configuration
vrf	Display per-VRF information
all	Display information for all VRFs
__readonly__	(Optional)
TABLE_vrfname	(Optional)
<i>vrf-name</i>	(Optional)
<i>vrf-id</i>	(Optional)
<i>instance</i>	(Optional)
<i>work-in-txlist</i>	(Optional)
TABLE_vrfid	(Optional)
<i>vrf-name-i</i>	(Optional)
<i>vrf-id-i</i>	(Optional)
<i>instance-i</i>	(Optional)
<i>work-in-txlist-i</i>	(Optional)

Command Mode

- /exec

show ip interface

```
show ip interface { { { brief [ include-secondary ] } | [ <interface> ] | [ <ip-addr> ] } [ operational ] [ vaddr ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_intf [ <vrf-name-out> ] [
<intf-name> ] [ <proto-state> ] [ <link-state> ] [ <admin-state> ] [ <iod> ] [ <first_unnum_iod> ] [
TABLE_unnuminf <unnum-child-inf> ] [ <prefix> ] [ <subnet> ] [ <masklen> ] [ TABLE_secondary_address
<prefix1> <subnet1> <masklen1> ] [ <num-addr> ] [ <vaddr-client> ] [ <vaddr-prefix> ] [ <vaddr-subnet>
] [ <vaddr-masklen> ] [ <num-vaddr> ] [ <unnum-intf> ] [ <ip-disabled> ] [ <bcast-addr> ] [ <maddr> ] + [
<num-maddr> ] [ <mtu> ] [ <pref> ] [ <tag> ] [ <proxy-arp> ] [ <lcl-proxy-arp> ] [ <mrouting> ] [
<icmp-redirect> ] [ <dir-bcast> ] [ <ip-forwarding> ] [ <ip-unreach> ] [ <port-unreach> ] [ <urpf-mode> ] [
<ip-ls-type> ] [ <urpf-acl> ] [ <pbr-in> ] [ <pbr-out> ] [ <acl-in> ] [ <acl-out> ] [ <stats-last-reset> ] [
<upkt-sent> ] [ <upkt-recv> ] [ <upkt-fwd> ] [ <upkt-orig> ] [ <upkt-consumed> ] [ <ubyte-sent> ] [
<ubyte-recv> ] [ <ubyte-fwd> ] [ <ubyte-orig> ] [ <ubyte-consumed> ] [ <mpkt-sent> ] [ <mpkt-recv> ] [
<mpkt-fwd> ] [ <mpkt-orig> ] [ <mpkt-consumed> ] [ <mbyte-sent> ] [ <mbyte-recv> ] [ <mbyte-fwd> ] [
<mbyte-orig> ] [ <mbyte-consumed> ] [ <bpkt-sent> ] [ <bpkt-recv> ] [ <bpkt-fwd> ] [ <bpkt-orig> ] [
<bpkt-consumed> ] [ <bbyte-sent> ] [ <bbyte-recv> ] [ <bbyte-fwd> ] [ <bbyte-orig> ] [ <bbyte-consumed>
] [ <lpkt-sent> ] [ <lpkt-recv> ] [ <lpkt-fwd> ] [ <lpkt-orig> ] [ <lpkt-consumed> ] [ <lbyte-sent> ] [
<lbyte-recv> ] [ <lbyte-fwd> ] [ <lbyte-orig> ] [ <lbyte-consumed> ] [ <wccp-outbound> ] [ <wccp-inbound>
] [ <wccp-exclude> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
interface	Display IP related interface information
brief	Display summary of IP interface status and configuration
include-secondary	(Optional) Display summary of all IP addresses
operational	(Optional) Display only interfaces that are administratively enabled
<i>interface</i>	(Optional) Interface name to display
<i>ip-addr</i>	(Optional) Display interface for local IP address
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs
vaddr	(Optional) Display virtual IP addresses as well
__readonly__	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_intf	(Optional)

<i>intf-name</i>	(Optional)
<i>iod</i>	(Optional)
<i>first_unnum_iod</i>	(Optional)
<i>prefix</i>	(Optional)
<i>proto-state</i>	(Optional)
<i>link-state</i>	(Optional)
<i>admin-state</i>	(Optional)
<i>subnet</i>	(Optional)
<i>masklen</i>	(Optional)
TABLE_unnuminf	(Optional)
<i>unnum-child-inf</i>	(Optional)
TABLE_secondary_address	(Optional)
<i>prefix1</i>	(Optional)
<i>subnet1</i>	(Optional)
<i>masklen1</i>	(Optional)
<i>num-addr</i>	(Optional)
<i>vaddr-client</i>	(Optional)
<i>vaddr-prefix</i>	(Optional)
<i>vaddr-subnet</i>	(Optional)
<i>vaddr-masklen</i>	(Optional)
<i>num-vaddr</i>	(Optional)
<i>unnum-intf</i>	(Optional)
<i>ip-disabled</i>	(Optional)
<i>bcast-addr</i>	(Optional)
<i>maddr</i>	(Optional)
<i>num-maddr</i>	(Optional)
<i>mtu</i>	(Optional)
<i>pref</i>	(Optional)
<i>tag</i>	(Optional)

<i>proxy-arp</i>	(Optional)
<i>lcl-proxy-arp</i>	(Optional)
<i>mrouting</i>	(Optional)
<i>icmp-redirect</i>	(Optional)
<i>dir-bcast</i>	(Optional)
<i>ip-forwarding</i>	(Optional)
<i>ip-unreach</i>	(Optional)
<i>port-unreach</i>	(Optional)
<i>urpf-mode</i>	(Optional)
<i>ip-ls-type</i>	(Optional)
<i>urpf-acl</i>	(Optional)
<i>pbr-in</i>	(Optional)
<i>pbr-out</i>	(Optional)
<i>acl-in</i>	(Optional)
<i>acl-out</i>	(Optional)
<i>stats-last-reset</i>	(Optional)
<i>upkt-sent</i>	(Optional)
<i>upkt-recv</i>	(Optional)
<i>upkt-fwd</i>	(Optional)
<i>upkt-orig</i>	(Optional)
<i>upkt-consumed</i>	(Optional)
<i>ubyte-sent</i>	(Optional)
<i>ubyte-recv</i>	(Optional)
<i>ubyte-fwd</i>	(Optional)
<i>ubyte-orig</i>	(Optional)
<i>ubyte-consumed</i>	(Optional)
<i>mpkt-sent</i>	(Optional)
<i>mpkt-recv</i>	(Optional)
<i>mpkt-fwd</i>	(Optional)

<i>mpkt-orig</i>	(Optional)
<i>mpkt-consumed</i>	(Optional)
<i>mbyte-sent</i>	(Optional)
<i>mbyte-recv</i>	(Optional)
<i>mbyte-fwd</i>	(Optional)
<i>mbyte-orig</i>	(Optional)
<i>mbyte-consumed</i>	(Optional)
<i>bpkt-sent</i>	(Optional)
<i>bpkt-recv</i>	(Optional)
<i>bpkt-fwd</i>	(Optional)
<i>bpkt-orig</i>	(Optional)
<i>bpkt-consumed</i>	(Optional)
<i>bbyte-sent</i>	(Optional)
<i>bbyte-recv</i>	(Optional)
<i>bbyte-fwd</i>	(Optional)
<i>bbyte-orig</i>	(Optional)
<i>bbyte-consumed</i>	(Optional)
<i>lpkt-sent</i>	(Optional)
<i>lpkt-recv</i>	(Optional)
<i>lpkt-fwd</i>	(Optional)
<i>lpkt-orig</i>	(Optional)
<i>lpkt-consumed</i>	(Optional)
<i>lbyte-sent</i>	(Optional)
<i>lbyte-recv</i>	(Optional)
<i>lbyte-fwd</i>	(Optional)
<i>lbyte-orig</i>	(Optional)
<i>lbyte-consumed</i>	(Optional)
<i>wccp-outbound</i>	(Optional)
<i>wccp-inbound</i>	(Optional)

<i>wccp-exclude</i>	(Optional)
---------------------	------------

Command Mode

- /exec

show ip lisp

```
show { ip | ipv6 } lisp [ database ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
lisp	LISP show commands
database	(Optional) Show EID-prefixes configured for site
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show ip lisp data-cache

```
show ip lisp data-cache [ <eid> ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
lisp	LISP show commands
data-cache	Display EID-to-RLOC data cache mapping in this ITR
<i>eid</i>	(Optional) Display mapping for IP destination EID
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show ip lisp locator-hash

```
{ { show ip lisp locator-hash { <eid-prefix> | { <source-eid> <dest-eid> } } [ vrf { <vrf-name> | <vrf-known-name> } ] } | { show ipv6 lisp locator-hash { <eid-prefix6> | { <source-eid6> <dest-eid6> } } [ vrf { <vrf-name> | <vrf-known-name> } ] } }
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
lisp	LISP show commands
locator-hash	Display source and dest locators for EID pair
<i>source-eid</i>	Source IPv4 endpoint identifier (EID)
<i>dest-eid</i>	Destination IPv4 endpoint identifier (EID)
<i>eid-prefix</i>	Display exact match for IP EID-prefix entry
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show ip lisp map-cache

```
{ { show ip lisp map-cache [ <eid> | <eid-prefix> | detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] } | {
show ipv6 lisp map-cache [ <eid6> | <eid-prefix6> | detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] } }
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
lisp	LISP show commands
map-cache	Display EID-to-RLOC cache mapping in this ITR
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>eid</i>	(Optional) Display mapping for IP destination EID
<i>eid-prefix</i>	(Optional) Display exact match for IP EID-prefix entry
detail	(Optional) Display entire map-cache in long format

Command Mode

- /exec

show ip lisp statistics

```
show { ip | ipv6 } lisp statistics [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
lisp	LISP show commands
statistics	Display global LISP statistics
vrf	(Optional) Display statistics information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show ip lisp translate-cache

```
{ show ip lisp translate-cache [ <nrEID> ] } | { show ipv6 lisp translate-cache [ <nrEID6> ] }
```

Syntax Description

show	Show running system information
ip	Display IP information
ipv6	Display IPv6 information
lisp	LISP show commands
translate-cache	Display configured translation cache
<i>nrEID</i>	(Optional) IPv4 address of inside non-routable EID
<i>nrEID6</i>	(Optional) IPv6 address of inside non-routable EID

Command Mode

- /exec

show ip load-sharing

```
show ip load-sharing [ __readonly__ { <univer-id-ran-seed> [ <l3-msg-load> ] [ <l34-msg-load> ] [
<dest-addr-load> ] [ <src-dst-ip-gre> ] [ <bad-load> ] [ <gre-outer-hash> ] [ <concatenation> ] [ <rotate> ] [
<src-dst-ip-gtpu> ] } ]
```

Syntax Description

show	Show running system information
ip	Configure IP features
load-sharing	Display global loadbalance info
<i>__readonly__</i>	(Optional)
<i>univer-id-ran-seed</i>	(Optional)
<i>l3-msg-load</i>	(Optional)
<i>l34-msg-load</i>	(Optional)
<i>dest-addr-load</i>	(Optional)
<i>src-dst-ip-gre</i>	(Optional)
<i>bad-load</i>	(Optional)
<i>gre-outer-hash</i>	(Optional)
<i>concatenation</i>	(Optional)
<i>rotate</i>	(Optional)
<i>src-dst-ip-gtpu</i>	(Optional)

Command Mode

- /exec

show ip local policy

```
show ip local policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_pbr [ <interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
local	IP local options
policy	Policy routing
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_pbr	(Optional)
<i>interface</i>	(Optional)
<i>rmap</i>	(Optional)
<i>status</i>	(Optional)
<i>vrf_name</i>	(Optional)

Command Mode

- /exec

show ip logging

```
show ip logging [ hash ] [ __readonly__ ]
```

Syntax Description

show	Show running system information
ip	Display IP information
logging	Display IP policy logging table
hash	(Optional) logging hash data
__readonly__	(Optional)

Command Mode

- /exec

show ip mbgp

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast | mdt } |
all } ] } } [ <ip-addr> [ <ip-mask> [ longer-prefixes ] ] | <ip-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name>
| <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>ip-addr</i>	(Optional) Display one particular network from the BRIB in detail
<i>ip-mask</i>	(Optional) Mask for one particular prefix in the BRIB
<i>ip-prefix</i>	(Optional) Display one particular prefix from the BRIB in detail
longer-prefixes	(Optional) Display route and more specific routes
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
mdt	(Optional) Display BGP information for multicast distribution tree
all	(Optional) Display BGP information for all address families

Command Mode

- /exec

show ip mbgp

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } { route-map { <rmap-name> | <rmap-name> } | filter-list { <fltrlist-name> | <test_pol_name> } | {
community-list { <commlist-name> | <test_pol_name> } | extcommunity-list { <extcommlist-name> |
<test_pol_name> } } [ exact-match ] } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
route-map	Display routes matching the route-map
<i>rmap-name</i>	Route-map name
<i>rmap-name</i>	Known route-map name
filter-list	Display routes matching the filter-list
<i>fltrlist-name</i>	Name of filter-list
community-list	Display routes matching the community-list
extcommunity-list	Display routes matching the extcommunity-list
<i>commlist-name</i>	Name of community-list
<i>extcommlist-name</i>	Name of extcommunity-list
<i>test_pol_name</i>	An existing test-list policy
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	(Optional) Display BGP information for all address families
exact-match	(Optional) Exact match of the communities

Command Mode

- /exec

show ip mbgp community

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } community { <regexp-str> | { { <comm-id> | <wellknown-id> } + [ exact-match ] } } [ vrf { <vrf-name>
| <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display BGP information for all address families
community	Display routes matching the BGP communities
<i>regexp-str</i>	Regular expression to match the communities
<i>comm-id</i>	BGP community value
<i>wellknown-id</i>	BGP wellknown community
exact-match	(Optional) Exact match of the communities

Command Mode

- /exec

show ip mbgp dampening

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } dampening { dampened-paths [ regexp <regexp-str> ] | flap-statistics | parameters | history-paths [ regexp
<regexp-str> ] } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
dampening	Display dampening info
dampened-paths	Display all dampened paths
flap-statistics	Display flap statistics for routes
parameters	Display dampening parameters
history-paths	Display all history paths
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	(Optional) Display BGP information for all address families
regexp	(Optional) Display routes matching the AS path regular expression
<i>regexp-str</i>	(Optional) Regular expression to match the AS paths

Command Mode

- /exec

show ip mbgp extcommunity

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { ipv4 { unicast | multicast } | all }
] } } extcommunity { <regexp-str> | { { 4byteas-generic { transitive <ext-comm-gen-trans> | non-transitive
<ext-comm-gen-nontrans> } } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] }
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display BGP information for all address families
extcommunity	Display routes matching the BGP extcommunities
4byteas-generic	Generic extended community
transitive	Transitive extcommunity
non-transitive	Non-Transitive extcommunity
<i>regexp-str</i>	Regular expression to match the extcommunities
<i>ext-comm-gen-trans</i>	Extcommunity number aa4:nn format
<i>ext-comm-gen-nontrans</i>	Extcommunity number aa4:nn format
exact-match	(Optional) Exact match of the extcommunities

Command Mode

- /exec

show ip mbgp flap-statistics

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } flap-statistics [ <ip-prefix> | <ip-addr> [ <ip-mask> ] ] [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
flap-statistics	Display route flap statistics
<i>ip-prefix</i>	(Optional) Display flap statistics for one prefix
<i>ip-addr</i>	(Optional) Display flap statistics for one network
<i>ip-mask</i>	(Optional) Network mask
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	(Optional) Display BGP information for all address families

Command Mode

- /exec

show ip mbgp neighbors

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } neighbors [ [ { <neighbor-id> | <ipv6-neighbor-id> } [ routes [ advertised | received | dampened ] |
advertised-routes | received-routes | paths | flap-statistics ] ] | <neighbor-prefix-id> | <ipv6-neighbor-prefix-id>
} [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
neighbors	Display all configured BGP neighbors
<i>neighbor-id</i>	(Optional) Display one particular BGP neighbor
<i>neighbor-prefix-id</i>	Display details for a prefix peering
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	(Optional) Display BGP information for all address families
routes	(Optional) Display all routes advertised/received to/from peer
advertised	(Optional) Display all routes advertised to this peer
received	(Optional) Display all routes received from this peer
dampened	(Optional) Display all dampened routes received from this peer
advertised-routes	(Optional) Display all the routes advertised to this peer
received-routes	(Optional) Display all the routes received from this peer
flap-statistics	(Optional) Display flap statistics for routes received from this peer
paths	(Optional) Display AS paths learned from this peer

Command Mode

- /exec

show ip mbgp nexthop-database

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } nexthop-database [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
nexthop-database	Display nexthop database
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	(Optional) Display BGP information for all address families

Command Mode

- /exec

show ip mbgp nexthop

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 { unicast | multicast } ] } nexthop
<ipnexthop> [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
nexthop	Display routes matching the nexthop
<i>ipnexthop</i>	Nexthop address
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family

Command Mode

- /exec

show ip mbgp prefix-list

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 { unicast | multicast } ] } }
prefix-list { <prfxlist-name> | <test_pol_name> } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
prefix-list	Display routes matching the prefix-list
<i>prfxlist-name</i>	Name of prefix-list
<i>test_pol_name</i>	An existing test-list policy
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family

Command Mode

- /exec

show ip mbgp received-paths

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } received-paths [ private ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
received-paths	Display paths stored for soft-reconfig
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	(Optional) Display BGP information for all address families
private	(Optional) private

Command Mode

- /exec

show ip mroute

```
show ip mroute [ [ [ bitfield ] [ detail ] ] | sr | rp | [ summary [ count | software-forwarded | rpf-failed ] ] | { [
[ <source> <group> ] | [ <group> [ <source> ] ] ] [ shared-tree | source-tree | mofrr ] [ [ flags ] | [ detail ] ] [
bitfield ] | [ summary [ software-forwarded | rpf-failed ] ] } ] [ vrf { <vrf-name> | <vrf-known-name> | all
} ] [ __readonly__ TABLE_vrf <vrf-name> [ <expiry_timer> ] [ <route_count> ] [ <star_g_cnt> ] [ <sg_cnt>
] [ <star_g_prfx_cnt> ] [ TABLE_route_summary [ <total-num-routes> ] [ <star-g-route> ] [ <sg-route> ] [
<star-g-prfx> ] [ <group-count> ] [ <avg> ] [ <rem> ] [ <stats-pndg> ] ] [ TABLE_summary_source [
<group_addr> ] [ <group_mask_len> ] [ <source_count> ] [ TABLE_one_sg [ <source_addr> ] [ <packets>
] [ <bytes> ] [ <aps> ] [ <pps> ] [ <rate_buf> ] [ <oifs> ] [ <software_fwd> ] [ <rpf-failed-pkts> ] [
<rpf-failed-bytes> ] ] ] [ TABLE_one_route <mcast-addr> [ <source_addr> <group_addr> ] [ <pending>
] [ <bidir> ] [ <uptime> ] [ <mofrr> ] [ TABLE_mpib [ <mpib-name> ] [ <oif-count> ] [ <stale-route> ] ] [
<mdt-encap-index> ] [ <stats-pkts> ] [ <stats-bytes> ] [ <stats-rate-buf> ] [ <lisp-src-rloc> ] [
<translated-route-src> ] [ <translated-route-grp> ] [ <route-iif> ] [ <rpf-nbr> ] [ <mofrr-iif> ] [ <mofrr-nbr>
] [ <internal> ] [ <oif-count> ] [ <fabric-oif> ] [ <fabric-loser> ] [ <num-vpc-svi-oifs> ] [ TABLE_oif [
<oif-name> ] [ <oif-uptime> ] [ TABLE_oif_mpib [ <oif-mpib-name> ] [ <stale-oif> ] [ <omd-vpc-svi> ] ]
[ <rpf> ] ] [ <route-mdt-iod> ] [ <oif-list-bitfield> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
mroute	Display IP multicast routing table
summary	(Optional) Display route counts and packet rates
shared-tree	(Optional) Display route for *,G entries
source-tree	(Optional) Display route for S,G entries
software-forwarded	(Optional) Display software switched route counts only
rpf-failed	(Optional) Display RPF failure statistics
rp	(Optional) Display RP routes (RP, 0.0.0.0/32)
sr	(Optional) Display Service Reflect Routes only
mofrr	(Optional) Display mofrr routes
<i>group</i>	(Optional) Display multicast group/source address for route
<i>source</i>	(Optional) Display multicast group/source address for route

count	(Optional) Display route counts only
bitfield	(Optional) Display bitfield details
detail	(Optional) Display detailed route attributes
flags	(Optional) Display detailed route attributes
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
<i>expy_timer</i>	(Optional)
<i>route_count</i>	(Optional)
<i>star_g_cnt</i>	(Optional)
<i>sg_cnt</i>	(Optional)
<i>star_g_prfx_cnt</i>	(Optional)
TABLE_summary_source	(Optional)
<i>group_addr</i>	(Optional)
<i>group_mask_len</i>	(Optional)
<i>source_count</i>	(Optional)
TABLE_one_sg	(Optional)
<i>source_addr</i>	(Optional)
<i>packets</i>	(Optional)
<i>bytes</i>	(Optional)
<i>aps</i>	(Optional)
<i>pps</i>	(Optional)
<i>rate_buf</i>	(Optional)
<i>oifs</i>	(Optional)
<i>software_fwd</i>	(Optional)
<i>rpf-failed-pkts</i>	(Optional)
<i>rpf-failed-bytes</i>	(Optional)
TABLE_one_route	(Optional)
<i>mcast-addrs</i>	(Optional)

<i>source_addrs</i>	(Optional)
<i>group_addrs</i>	(Optional)
<i>bidir</i>	(Optional)
<i>pending</i>	(Optional)
<i>mofrr</i>	(Optional)
<i>uptime</i>	(Optional)
TABLE_mpib	(Optional)
<i>mpib-name</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>stale-route</i>	(Optional)
<i>mdt-encap-index</i>	(Optional)
<i>stats-pkts</i>	(Optional)
<i>stats-bytes</i>	(Optional)
<i>stats-rate-buf</i>	(Optional)
<i>lisp-src-rloc</i>	(Optional)
<i>translated-route-src</i>	(Optional)
<i>translated-route-grp</i>	(Optional)
<i>route-iif</i>	(Optional)
<i>rpf-nbr</i>	(Optional)
<i>mofrr-iif</i>	(Optional)
<i>mofrr-nbr</i>	(Optional)
<i>internal</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>fabric-oif</i>	(Optional)
<i>fabric-loser</i>	(Optional)
<i>num-vpc-svi-oifs</i>	(Optional)
TABLE_oif	(Optional)
<i>oif-name</i>	(Optional)
<i>oif-uptime</i>	(Optional)

TABLE_oif_mpib	(Optional)
<i>oif-mpib-name</i>	(Optional)
<i>stale-oif</i>	(Optional)
<i>omd-vpc-svi</i>	(Optional)
<i>rpf</i>	(Optional)
<i>route-mdt-iod</i>	(Optional)
<i>oif-list-bitfield</i>	(Optional)
TABLE_route_summary	(Optional)
<i>total-num-routes</i>	(Optional)
<i>star-g-route</i>	(Optional)
<i>sg-route</i>	(Optional)
<i>star-g-prfx</i>	(Optional)
<i>group-count</i>	(Optional)
<i>avg</i>	(Optional)
<i>rem</i>	(Optional)
<i>stats-pndg</i>	(Optional)

Command Mode

- /exec

show ip msdp count

```
show ip msdp count [ <asn> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ <out-vrf>
<total-cnt> [ TABLE_asn <out-asn> <src-cnt> <grp-cnt> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
count	Display SA cache counters
<i>asn</i>	(Optional) AS number
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-vrf</i>	(Optional)
<i>total-cnt</i>	(Optional)
TABLE_asn	(Optional)
<i>out-asn</i>	(Optional)
<i>src-cnt</i>	(Optional)
<i>grp-cnt</i>	(Optional)

Command Mode

- /exec

show ip msdp event-history

```
show ip msdp [ <asn> ] [ internal ] event-history { errors | msgs | <msdp-event-hist-buf-name> | statistics }
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
<i>asn</i>	(Optional) AS number
internal	(Optional) Commands for internal use
event-history	Show various event logs of MSDP
errors	Error logs of MSDP
msgs	Message logs of MSDP
<i>msdp-event-hist-buf-name</i>	Buffer
statistics	Buffer state

Command Mode

- /exec

show ip msdp mesh-group

```
show ip msdp mesh-group [ <mesh-group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
<out-vrf> [ TABLE_meshgroup [ <meshgroup-name> ] [ TABLE_peer [ <peer-ipaddr> ] [ <peer-asn> ] [
<peer-description> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
mesh-group	Display members of mesh-group
<i>mesh-group</i>	(Optional) Display single mesh-group
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
<i>out-vrf</i>	(Optional)
TABLE_meshgroup	(Optional)
<i>meshgroup-name</i>	(Optional)
TABLE_peer	(Optional)
<i>peer-ipaddr</i>	(Optional)
<i>peer-asn</i>	(Optional)
<i>peer-description</i>	(Optional)

Command Mode

- /exec

show ip msdp peer

```
show ip msdp peer [ <peer-address> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_peer [ <peer-ipaddr> ] [ <out-vrf> ] [ <peer-asn> ] [ <local-ipaddr> ] [ <local-iface> ] [
<fully-configured> ] [ <peer-description> ] [ <connection-status> ] [ <peer-listening> ] [ <state-duration> ]
[ <peer-uptime> ] [ <peer-rr> ] [ <peer-password> ] [ <peer-ki> ] [ <peer-kt> ] [ <peer-ri> ] [ <sa-in-policy>
] [ <sa-out-policy> ] [ <sa-limit> ] [ <mesh-name> ] [ <last-rcvd> ] [ <sa-rcvd> ] [ <sa-sent> ] [ <sa-req-rcvd>
] [ <sa-req-sent> ] [ <sa-resp-rcvd> ] [ <sa-resp-sent> ] [ <in-ctrl-msgs> ] [ <out-ctrl-msgs> ] [ <in-data-msgs>
] [ <out-data-msgs> ] [ <sa-ka-rcvd> ] [ <sa-ka-sent> ] [ <sa-notif-rcvd> ] [ <sa-notif-sent> ] [ <rem-port> ]
[ <local-port> ] [ <rpf-failures> ] [ <cache-lifetime> ] [ <estb-transitions> ] [ <conn-attempts> ] [ <discont-time>
] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
peer	Display MSDP peer information
<i>peer-address</i>	(Optional) IP address of MSDP peer
__readonly__	(Optional)
TABLE_peer	(Optional)
<i>peer-ipaddr</i>	(Optional)
<i>out-vrf</i>	(Optional)
<i>peer-asn</i>	(Optional)
<i>local-ipaddr</i>	(Optional)
<i>local-iface</i>	(Optional)
<i>fully-configured</i>	(Optional)
<i>peer-description</i>	(Optional)
<i>connection-status</i>	(Optional)
<i>state-duration</i>	(Optional)
<i>peer-listening</i>	(Optional)

<i>peer-uptime</i>	(Optional)
<i>peer-password</i>	(Optional)
<i>peer-ki</i>	(Optional)
<i>peer-kt</i>	(Optional)
<i>peer-ri</i>	(Optional)
<i>peer-rr</i>	(Optional)
<i>sa-in-policy</i>	(Optional)
<i>sa-out-policy</i>	(Optional)
<i>sa-limit</i>	(Optional)
<i>mesh-name</i>	(Optional)
<i>last-rcvd</i>	(Optional)
<i>sa-rcvd</i>	(Optional)
<i>sa-sent</i>	(Optional)
<i>sa-req-rcvd</i>	(Optional)
<i>sa-req-sent</i>	(Optional)
<i>sa-resp-rcvd</i>	(Optional)
<i>sa-resp-sent</i>	(Optional)
<i>out-ctrl-msgs</i>	(Optional)
<i>in-ctrl-msgs</i>	(Optional)
<i>out-data-msgs</i>	(Optional)
<i>in-data-msgs</i>	(Optional)
<i>sa-ka-rcvd</i>	(Optional)
<i>sa-ka-sent</i>	(Optional)
<i>sa-notif-rcvd</i>	(Optional)
<i>sa-notif-sent</i>	(Optional)
<i>rem-port</i>	(Optional)
<i>local-port</i>	(Optional)
<i>rpf-failures</i>	(Optional)
<i>cache-lifetime</i>	(Optional)

<i>estb-transitions</i>	(Optional)
<i>conn-attempts</i>	(Optional)
<i>discont-time</i>	(Optional)

Command Mode

- /exec

show ip msdp policy statistics sa-policy in

```
show ip msdp policy statistics sa-policy <peer-address> { in | out } [ vrf { <vrf-name> | <vrf-known-name>
} ] [ __readonly__ [ TABLE_routemap [ <name> ] [ <action> ] [ <seq_num> ] [ [ TABLE_cmd [ <command>
] [ <match_count> ] [ <compare_count> ] ] ] ] [ <total_accept_count> ] [ <total_reject_count> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	MSDP global configuration commands
policy	Policy information
statistics	Policy statistics
sa-policy	Configured SA policy for MSDP peer
<i>peer-address</i>	IP address of MSDP peer for SA policy
in	Input policy
out	Output policy
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_routemap	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seq_num</i>	(Optional)
TABLE_cmd	(Optional)
<i>command</i>	(Optional)
<i>compare_count</i>	(Optional)
<i>match_count</i>	(Optional)
<i>total_accept_count</i>	(Optional)
<i>total_reject_count</i>	(Optional)

Command Mode

- /exec

show ip msdp rpf

```
show ip msdp rpf <rp-address> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ <out-rp-address>
<out-vrf> [ TABLE_mesh [ <peer-addr> ] [ <mesh-name> ] ] [ <is-peer-cnt-one> ] [ <is-rp-peer> ] [
<is-bgp-alive> ] [ <bgp-peer-addr> ] [ <peer-asn> ] [ <origin-asn> ] [ <is-mbgp> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
rpf	Display RPF-peer for RP address
<i>rp-address</i>	IP address of RP
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
<i>out-rp-address</i>	(Optional)
<i>out-vrf</i>	(Optional)
TABLE_mesh	(Optional)
<i>peer-addr</i>	(Optional)
<i>mesh-name</i>	(Optional)
<i>is-peer-cnt-one</i>	(Optional)
<i>is-rp-peer</i>	(Optional)
<i>is-bgp-alive</i>	(Optional)
<i>bgp-peer-addr</i>	(Optional)
<i>peer-asn</i>	(Optional)
<i>origin-asn</i>	(Optional)
<i>is-mbgp</i>	(Optional)

Command Mode

- /exec

show ip msdp sa

```
show ip msdp { sa-cache | route } [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ <asn> ] [ peer
<peer> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <out-vrf> ] [
<total-sa-count> ] [ TABLE_sa [ <src-addr> ] [ <grp-addr> ] [ <rp-addr> ] [ <out-asn> ] [ <peer-addr> ] [
<uptime> ] [ <expire> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
route	Display MSDP SA route cache
sa-cache	Display MSDP SA route cache
<i>source</i>	(Optional) Display group/source address for SA
<i>group</i>	(Optional) Display group/source address for SA
<i>asn</i>	(Optional) AS number
detail	(Optional) Display detailed information
peer	(Optional) Display MSDP SA received from single peer
<i>peer</i>	(Optional) IP address of peer for SA
__readonly__	(Optional)
<i>out-vrf</i>	(Optional)
<i>total-sa-count</i>	(Optional)
TABLE_sa	(Optional)
<i>src-addr</i>	(Optional)
<i>grp-addr</i>	(Optional)
<i>rp-addr</i>	(Optional)
<i>peer-addr</i>	(Optional)

<i>out-asn</i>	(Optional)
<i>uptime</i>	(Optional)
<i>expire</i>	(Optional)

Command Mode

- /exec

show ip msdp sources

```
show ip msdp sources [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <out-vrf> ] [
TABLE_source [ <source-addr> ] [ <is-count-ge-limit> ] [ <count> ] [ <is-limit-valid> ] [ <limit> ] [
<source-prefix> ] [ <violates> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
sources	Display learned sources with their group counts and limits
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-vrf</i>	(Optional)
<i>TABLE_source</i>	(Optional)
<i>source-addr</i>	(Optional)
<i>is-count-ge-limit</i>	(Optional)
<i>count</i>	(Optional)
<i>is-limit-valid</i>	(Optional)
<i>limit</i>	(Optional)
<i>source-prefix</i>	(Optional)
<i>violates</i>	(Optional)

Command Mode

- /exec

show ip msdp statistics

```
show ip msdp statistics [ <peer-address> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
<out-vrf> <select-err> <recv-sel-err> { TABLE_peer <peer-address> <buffer-full> <recv-buf-full> <fatal-err>
<recv-fat-err> <would-block> <recv-would-block> <sock-exp> <invalid-type> <invalid-len> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
statistics	Display internal statistics
<i>peer-address</i>	(Optional) IP address of MSDP peer
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
<i>out-vrf</i>	(Optional)
<i>select-err</i>	(Optional)
<i>recv-sel-err</i>	(Optional)
TABLE_peer	(Optional)
<i>peer-address</i>	(Optional)
<i>buffer-full</i>	(Optional)
<i>recv-buf-full</i>	(Optional)
<i>fatal-err</i>	(Optional)
<i>recv-fat-err</i>	(Optional)
<i>would-block</i>	(Optional)
<i>recv-would-block</i>	(Optional)
<i>sock-exp</i>	(Optional)
<i>invalid-type</i>	(Optional)
<i>invalid-len</i>	(Optional)

Command Mode

- /exec

show ip msdp summary

```
show ip msdp summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <out-vrf> ] [
<local-asn> ] [ <originator-id> ] [ <config-peer-count> ] [ <estb-peer-count> ] [ <shut-peer-count> ] [
TABLE_peer [ <peer-address> ] [ <peer-asn> ] [ <peer-state> ] [ <peer-uptime> ] [ <peer-last-msg> ] [
<peer-sa-rcvd> ] [ <peer-sa-limit> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
msdp	Display MSDP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
summary	Display MSDP peer summary
<i>__readonly__</i>	(Optional)
<i>out-vrf</i>	(Optional)
<i>local-asn</i>	(Optional)
<i>originator-id</i>	(Optional)
<i>config-peer-count</i>	(Optional)
<i>estb-peer-count</i>	(Optional)
<i>shut-peer-count</i>	(Optional)
TABLE_peer	(Optional)
<i>peer-address</i>	(Optional)
<i>peer-asn</i>	(Optional)
<i>peer-state</i>	(Optional)
<i>peer-uptime</i>	(Optional)
<i>peer-last-msg</i>	(Optional)
<i>peer-sa-rcvd</i>	(Optional)
<i>peer-sa-limit</i>	(Optional)

Command Mode

- /exec

show ip nat max

```
show ip nat max [ __readonly__ <max_dyn_translations> <max_all_host> <static_translations>
<dynamic_translations> <icmp_translations> ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
nat	IP NAT information
max	IP NAT max values
<i>__readonly__</i>	(Optional)
<i>max_dyn_translations</i>	(Optional) Max Dynamic Translations
<i>max_all_host</i>	(Optional) Max All Hosts
<i>static_translations</i>	(Optional) No. Static Translations
<i>dynamic_translations</i>	(Optional) No. Dynamic Translations
<i>icmp_translations</i>	(Optional) No. ICMP Translations

Command Mode

- /exec

show ip nat statistics

```
show ip nat statistics [ _readonly_ <last_clear_time> <total_active_translations> <static_translations>
<dynamic_translations> <icmp_translations> <total_exp_translations> <syn_exp_translations>
<finrst_exp_translations> <inactive_exp_translations> <total_hits> <total_misses> <io_hits> <io_misses>
<oi_hits> <oi_misses> <total_sw_translated> <io_sw_translated> <oi_sw_translated> <total_sw_dropped>
<io_sw_dropped> <oi_sw_dropped> <addr_alloc_fail_drop> <port_alloc_fail_drop>
<dyn_trans_maxlimit_drop> <icmp_maxlimit_drop> <allhost_maxlimit_drop> <total_tcp_session_created>
<total_tcp_session_closed> [ <Total_NAT_inside_interfaces> ] [ { TABLE_NAT_inside_interfaces [
<nat_inside_interfaces> ] } ] [ <Total_NAT_outside_interfaces> ] [ { TABLE_NAT_outside_interfaces [
<nat_outside_interfaces> ] } ] [ { TABLE_NAT_inside_source_list [ <nat_in_acl_name> ] [
<nat_in_acl_refcount> ] [ <nat_in_pool_name> ] [ <nat_pool_overload> ] [ <in_pool_total_address> ] [
<in_pool_allocated> ] [ <in_pool_missed> ] [ <interface_name> ] [ <interface_status> ] [ <interface_ip_addr>
] } ] [ { TABLE_NAT_outside_source_list [ <nat_out_acl_name> ] [ <nat_out_acl_refcount> ] [
<nat_out_pool_name> ] [ <out_pool_total_address> ] [ <out_pool_allocated> ] [ <out_pool_missed> ] } ] ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
nat	IP NAT information
statistics	Translation statistics
<i>_readonly_</i>	(Optional)
<i>last_clear_time</i>	(Optional) Clearable stats collected from
<i>total_active_translations</i>	(Optional) Total active translations
<i>static_translations</i>	(Optional) No. Static Translations
<i>dynamic_translations</i>	(Optional) No. Dynamic Translations
<i>icmp_translations</i>	(Optional) No. ICMP Translations
<i>total_exp_translations</i>	(Optional) Total expired Translations
<i>syn_exp_translations</i>	(Optional) SYN timer expired Translations
<i>finrst_exp_translations</i>	(Optional) FIN-RST timer expired Translations
<i>inactive_exp_translations</i>	(Optional) Inactive timer expired Translations
<i>total_hits</i>	(Optional) Total Hits
<i>total_misses</i>	(Optional) Total Misses
<i>io_hits</i>	(Optional) In-Out Hits
<i>io_misses</i>	(Optional) In-Out Misses

<i>oi_hits</i>	(Optional) Out-In Hits
<i>oi_misses</i>	(Optional) Out-In Misses
<i>total_sw_translated</i>	(Optional) Total SW Translated Packets
<i>io_sw_translated</i>	(Optional) In-Out SW Translated Packets
<i>oi_sw_translated</i>	(Optional) Out-In SW Translated Packets
<i>total_sw_dropped</i>	(Optional) Total SW Dropped Packets
<i>io_sw_dropped</i>	(Optional) In-Out SW Dropped Packets
<i>oi_sw_dropped</i>	(Optional) Out-In SW Dropped Packets
<i>addr_alloc_fail_drop</i>	(Optional) Address alloc. failure dropped Packets
<i>port_alloc_fail_drop</i>	(Optional) Port alloc. failure dropped Packets
<i>dyn_trans_maxlimit_drop</i>	(Optional) Dyn. Translation max limit dropped Packets
<i>icmp_maxlimit_drop</i>	(Optional) ICMP max limit dropped Packets
<i>allhost_maxlimit_drop</i>	(Optional) Allhost max limit dropped Packets
<i>total_tcp_session_created</i>	(Optional) Total tcp session created
<i>total_tcp_session_closed</i>	(Optional) Total tcp session closed
<i>Total_NAT_inside_interfaces</i>	(Optional) Number of NAT inside interfaces
TABLE_NAT_inside_interfaces	(Optional) NAT inside interfaces
<i>nat_inside_interfaces</i>	(Optional) NAT Inside Interfaces
<i>Total_NAT_outside_interfaces</i>	(Optional) Number of NAT outside interfaces
TABLE_NAT_outside_interfaces	(Optional) NAT outside interfaces
<i>nat_outside_interfaces</i>	(Optional) NAT Outside Interfaces
TABLE_NAT_inside_source_list	(Optional) NAT Inside source list
TABLE_NAT_outside_source_list	(Optional) NAT Outside source list
<i>nat_in_acl_name</i>	(Optional) NAT inside access list name
<i>nat_out_acl_name</i>	(Optional) NAT outside access list name
<i>nat_in_acl_refcount</i>	(Optional) NAT inside access list ref. count
<i>nat_out_acl_refcount</i>	(Optional) NAT outside access list ref. count
<i>nat_in_pool_name</i>	(Optional) NAT inside Pool name
<i>nat_out_pool_name</i>	(Optional) NAT outside Pool name

<i>nat_pool_overload</i>	(Optional) NAT Pool overload
<i>in_pool_total_address</i>	(Optional) Total address in the inside pool
<i>out_pool_total_address</i>	(Optional) Total address in the outside pool
<i>in_pool_allocated</i>	(Optional) Total address allocated in the inside pool
<i>out_pool_allocated</i>	(Optional) Total address allocated in the outside pool
<i>in_pool_missed</i>	(Optional) Total failed address allocation in the inside pool
<i>out_pool_missed</i>	(Optional) Total failed address allocation in the outside pool
<i>interface_name</i>	(Optional) NAT source list interface name
<i>interface_status</i>	(Optional) NAT source list interface status
<i>interface_ip_addr</i>	(Optional) NAT source list interface addr

Command Mode

- /exec

show ip nat timeout

```
show ip nat timeout [ __readonly__ <tcp_timeout> <udp_timeout> [ <icmp_timeout> ] <dynamic_timeout>
[ <sampling_timeout> ] [ <syn_timeout> ] [ <finrst_timeout> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
nat	IP NAT information
timeout	IP NAT timeout values
<i>__readonly__</i>	(Optional)
<i>tcp_timeout</i>	(Optional) TCP Timeout
<i>udp_timeout</i>	(Optional) UDP Timeout
<i>icmp_timeout</i>	(Optional) ICMP Timeout
<i>dynamic_timeout</i>	(Optional) Dynamic Timeout
<i>sampling_timeout</i>	(Optional) Sampling Timeout
<i>syn_timeout</i>	(Optional) SYN Timeout
<i>finrst_timeout</i>	(Optional) FINRST Timeout

Command Mode

- /exec

show ip nat translations

```
show ip nat translations [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ verbose ] [ internal-detail ] [
__readonly__ { TABLE_nat_translation [ <Protocol> ] [ <Inside_global_IP_V4_Address> ] [
<Inside_global_port> ] [ <Inside_local_IP_V4_Address> ] [ <Inside_local_port> ] [
<Outside_local_IP_V4_Address> ] [ <Outside_local_port> ] [ <Outside_global_IP_V4_Address> ] [
<Outside_global_port> ] [ <VRF> ] [ <In_stats_count> ] [ <Out_stats_count> ] [ <Group_id> ] [ <Time_left>
] [ <Syn> ] [ <Fin_rst> ] [ <Flags> ] [ <Entry_id> ] [ <State> } } ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
nat	IP NAT information
translations	Translation entries
verbose	(Optional) Show extra information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all vrfs
internal-detail	(Optional) Display internal debugs
<i>__readonly__</i>	(Optional) Readonly
TABLE_nat_translation	(Optional) NAT Translation Table
<i>Protocol</i>	(Optional) Protocol
<i>Inside_global_IP_V4_Address</i>	(Optional) Inside global address
<i>Inside_global_port</i>	(Optional) Inside global port
<i>Inside_local_IP_V4_Address</i>	(Optional) Inside local address
<i>Inside_local_port</i>	(Optional) Inside local port
<i>Outside_local_IP_V4_Address</i>	(Optional) Outside local address
<i>Outside_local_port</i>	(Optional) Outside local port
<i>Outside_global_IP_V4_Address</i>	(Optional) Outside global address
<i>Outside_global_port</i>	(Optional) Outside global port
<i>Flags</i>	(Optional) Flags

<i>In_stats_count</i>	(Optional) In stats count
<i>Out_stats_count</i>	(Optional) Out stats count
<i>Entry_id</i>	(Optional) Entry ID
<i>State</i>	(Optional) State
<i>Group_id</i>	(Optional) Group ID
<i>VRF</i>	(Optional) VRF
<i>Time_left</i>	(Optional) Time Left (HH:MM:SS)
<i>Syn</i>	(Optional) Syn
<i>Fin_rst</i>	(Optional) FIN RESET

Command Mode

- /exec

show ip ospf

```
show ip ospf [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag>
<instance_number> <cname> <rid> [ <domain_tag> ] [ <dn_bit_ignore> ] [ <stateful_ha> <gr_ha> [
<gr_planned_only> ] [ <gr_notify_period> ] [ <gr_grace_period> ] [ <gr_state> ] [ <gr_last_status> ] [
<gr_helper_mode> ] <support_tos0_only> <support_opaque_lsa> [ <low_mem_cond> ] [ <is_asbr> <is_asbr>
[ <max_lsa_non_self_number> ] [ <max_lsa_state> ] [ <max_lsa_warning_only> ] [
<max_lsa_current_non_self_lsa_number> ] [ <max_lsa_threshold_pct> ] [ <max_lsa_ignore_time> ] [
<max_lsa_reset_time> ] [ <max_lsa_ignore_count> ] [ <max_lsa_current_ignore_count> ] [
<max_lsa_ignore_time_left> ] [ <max_lsa_reset_time_left> ] [ <max_lsa_permanent_ignore> ] [ {
TABLE_redist <proto> [ <max_lsas> ] [ <warning> ] [ <threshold> ] [ <current_count> } ] ] <admin_dist>
<ref_bw> <spf_start_time> <spf_hold_time> <spf_max_time> <lsa_start_time> <lsa_hold_time>
<lsa_max_time> <min_lsa_arr_time> <lsa_aging_pace> <spf_max_paths> <max_metric_adver> [ [
<max_metric_time_left> ] [ <max_metric_wait_bgp> ] [ <max_metric_timeout> ] [ <max_metric_always>
] [ <max_metric_sum_lsa> ] [ <max_metric_ext_lsa> ] ] <asext_lsa_cnt> <asext_lsa_crc> <asopaque_lsa_cnt>
<asopaque_lsa_crc> <area_total> <area_normal> <area_stub> <area_nssa> <act_area_total> <act_area_normal>
<act_area_stub> <act_area_nssa> <no_discard_rt_ext> <no_discard_rt_int> [ <bfd_enabled> ] [ <passive_dflt>
] [ <name_lookup> ] [ <segrt_configured> ] [ <segrt_enabled> ] [ { <srgb_min_label> <srgb_max_label> }
] [ { TABLE_area <aname> [ <backbone_active> ] [ <active> ] <age> <total_intf> <act_intf> <passive_intf>
<loopback_intf> [ <gr_nbr_cnt> ] <stub> [ <stub_def_cost> ] <nssa> [ <no_redist> ] [ <nssa_trans> ]
<no_summary> <auth_type> [ { <area_segrt_configured> | <area_segrt_disabled_by_config> } ] [
<area_segrt_enabled> ] <spf_runs> <last_spf_run_time> [ <rtr_lsa_throt> ] [ TABLE_range <addr> <masklen>
<state> <nets> <advertise> [ <cost> ] ] [ <filter_in> ] [ <filter_out> ] <lsa_cnt> <lsa_crc> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>instance_number</i>	(Optional)
<i>cname</i>	(Optional)
<i>rid</i>	(Optional)

<i>domain_tag</i>	(Optional)
<i>dn_bit_ignore</i>	(Optional)
<i>stateful_ha</i>	(Optional)
<i>gr_ha</i>	(Optional)
<i>gr_planned_only</i>	(Optional)
<i>gr_notify_period</i>	(Optional)
<i>gr_grace_period</i>	(Optional)
<i>gr_state</i>	(Optional)
<i>gr_last_status</i>	(Optional)
<i>gr_helper_mode</i>	(Optional)
<i>support_tos0_only</i>	(Optional)
<i>support_opaque_lsa</i>	(Optional)
<i>low_mem_cond</i>	(Optional)
<i>is_abr</i>	(Optional)
<i>is_asbr</i>	(Optional)
<i>max_lsa_non_self_number</i>	(Optional)
<i>max_lsa_state</i>	(Optional)
<i>max_lsa_warning_only</i>	(Optional)
<i>max_lsa_current_non_self_lsa_number</i>	(Optional)
<i>max_lsa_threshold_pct</i>	(Optional)
<i>max_lsa_ignore_time</i>	(Optional)
<i>max_lsa_reset_time</i>	(Optional)
<i>max_lsa_ignore_count</i>	(Optional)
<i>max_lsa_current_ignore_count</i>	(Optional)
<i>max_lsa_ignore_time_left</i>	(Optional)
<i>max_lsa_reset_time_left</i>	(Optional)
<i>max_lsa_permanent_ignore</i>	(Optional)
TABLE_redist	(Optional)
<i>proto</i>	(Optional)

<i>max_lsas</i>	(Optional)
<i>warning</i>	(Optional)
<i>threshold</i>	(Optional)
<i>current_count</i>	(Optional)
<i>admin_dist</i>	(Optional)
<i>ref_bw</i>	(Optional)
<i>spf_start_time</i>	(Optional)
<i>spf_hold_time</i>	(Optional)
<i>spf_max_time</i>	(Optional)
<i>lsa_start_time</i>	(Optional)
<i>lsa_hold_time</i>	(Optional)
<i>lsa_max_time</i>	(Optional)
<i>min_lsa_arr_time</i>	(Optional)
<i>lsa_aging_pace</i>	(Optional)
<i>spf_max_paths</i>	(Optional)
<i>max_metric_adver</i>	(Optional)
<i>max_metric_time_left</i>	(Optional)
<i>max_metric_wait_bgp</i>	(Optional)
<i>max_metric_timeout</i>	(Optional)
<i>max_metric_always</i>	(Optional)
<i>max_metric_sum_lsa</i>	(Optional)
<i>max_metric_ext_lsa</i>	(Optional)
<i>asext_lsa_cnt</i>	(Optional)
<i>asext_lsa_crc</i>	(Optional)
<i>asopaque_lsa_cnt</i>	(Optional)
<i>asopaque_lsa_crc</i>	(Optional)
<i>area_total</i>	(Optional)
<i>area_normal</i>	(Optional)
<i>area_stub</i>	(Optional)

<i>area_nssa</i>	(Optional)
<i>act_area_total</i>	(Optional)
<i>act_area_normal</i>	(Optional)
<i>act_area_stub</i>	(Optional)
<i>act_area_nssa</i>	(Optional)
<i>bfd_enabled</i>	(Optional)
<i>name_lookup</i>	(Optional)
<i>passive_dflt</i>	(Optional)
<i>no_discard_rt_ext</i>	(Optional)
<i>no_discard_rt_int</i>	(Optional)
<i>segrt_configured</i>	(Optional)
<i>segrt_enabled</i>	(Optional)
<i>srgb_min_label</i>	(Optional)
<i>srgb_max_label</i>	(Optional)
TABLE_area	(Optional)
<i>aname</i>	(Optional)
<i>backbone_active</i>	(Optional)
<i>active</i>	(Optional)
<i>age</i>	(Optional)
<i>total_intf</i>	(Optional)
<i>act_intf</i>	(Optional)
<i>passive_intf</i>	(Optional)
<i>loopback_intf</i>	(Optional)
<i>gr_nbr_cnt</i>	(Optional)
<i>stub</i>	(Optional)
<i>stub_def_cost</i>	(Optional)
<i>nssa</i>	(Optional)
<i>no_redist</i>	(Optional)
<i>nssa_trans</i>	(Optional)

<i>no_summary</i>	(Optional)
<i>auth_type</i>	(Optional)
<i>area_segrt_configured</i>	(Optional)
<i>area_segrt_disabled_by_config</i>	(Optional)
<i>area_segrt_enabled</i>	(Optional)
<i>spf_runs</i>	(Optional)
<i>last_spf_run_time</i>	(Optional)
<i>rtr_lsa_throt</i>	(Optional)
TABLE_range	(Optional)
<i>addr</i>	(Optional)
<i>masklen</i>	(Optional)
<i>state</i>	(Optional)
<i>nets</i>	(Optional)
<i>advertise</i>	(Optional)
<i>cost</i>	(Optional)
<i>filter_in</i>	(Optional)
<i>filter_out</i>	(Optional)
<i>lsa_cnt</i>	(Optional)
<i>lsa_crc</i>	(Optional)

Command Mode

- /exec

show ip ospf border-routers

```
show ip ospf [ <tag> ] border-routers [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> [ TABLE_br <type> <addr> <cost> <asbr> <abr> <area> <spf_inst> [
<mlink_unresolved> ] [ TABLE_br_ubest_nh [ <ubest_nh_addr> ] [ <ubest_nh_intf> ] ] [ TABLE_br_mbtest_nh
[ <mbest_nh_addr> ] [ <mbest_nh_intf> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
border-routers	Border routers
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_br	(Optional)
<i>type</i>	(Optional)
<i>addr</i>	(Optional)
<i>cost</i>	(Optional)
<i>asbr</i>	(Optional)
<i>abr</i>	(Optional)
<i>area</i>	(Optional)
<i>spf_inst</i>	(Optional)
<i>mlink_unresolved</i>	(Optional)
TABLE_br_ubest_nh	(Optional)

<i>ubest_nh_addr</i>	(Optional)
<i>ubest_nh_intf</i>	(Optional)
TABLE_br_mbest_nh	(Optional)
<i>mbest_nh_addr</i>	(Optional)
<i>mbest_nh_intf</i>	(Optional)

Command Mode

- /exec

show ip ospf database

```
show ip ospf [ <tag> ] database [ [ [ network | asbr-summary | summary | router | opaque-link | opaque-area
[ type { router-information | ext-prefix | ext-link } ] | nssa-external ] [ area <area-id-ip> ] ] | external [ ext_tag
<tag_val> ] | opaque-as ] [ <lsid> ] [ self-originated | adv-router <advid> | adv-router-name <adv-name> ] ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [
TABLE_db2_lsa <name> [ <area> ] <id> <advtr> <age> <seqno> <cksum> [ <opaque_id> ] [ <prefix> ] [
<prefix_mask> ] [ <srgb_base> ] [ <srgb_range> ] [ <corrupt> ] [ <rtr_num_links> ] [ <tag> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
database	Link-state Database Summary
network	(Optional) Display network LSAs
asbr-summary	(Optional) Display type 4 (asbr-summary) LSAs
external	(Optional) Display type 5 (external) LSAs
router	(Optional) Display router LSAs
nssa-external	(Optional) Display type 7 (NSSA external) LSAs
opaque-link	(Optional) Display Opaque Link-Local LSAs
opaque-area	(Optional) Display Opaque Area LSAs
opaque-as	(Optional) Display Opaque AS LSAs
summary	(Optional) Display type 3 (network-summary) LSAs
self-originated	(Optional) Display only self-originated LSAs
<i>lsid</i>	(Optional) Restrict display by link state ID
adv-router	(Optional) Restrict display by Advertising router
<i>advid</i>	(Optional) Advertising router ID

<i>adv-router-name</i>	(Optional) Restrict display by Advertising router name
<i>adv-name</i>	(Optional) DNS Name of the Advertising router
<i>area</i>	(Optional) Display only LSA's in this area
<i>area-id-ip</i>	(Optional) Area Id as an integer or ip address
<i>ext_tag</i>	(Optional) Restrict display by tag
<i>tag_val</i>	(Optional) 32-bit tag value
<i>type</i>	(Optional) Opaque type
<i>router-information</i>	(Optional) Router Information (RI) Opaque LSA
<i>ext-prefix</i>	(Optional) Extended Prefix Opaque LSA
<i>ext-link</i>	(Optional) Extended Link Opaque LSA
<i>tag</i>	(Optional)
<i>__readonly__</i>	(Optional)
<i>TABLE_ctx</i>	(Optional)
<i>rid</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>TABLE_db2_lsa</i>	(Optional)
<i>name</i>	(Optional)
<i>area</i>	(Optional)
<i>id</i>	(Optional)
<i>advrtr</i>	(Optional)
<i>age</i>	(Optional)
<i>seqno</i>	(Optional)
<i>cksum</i>	(Optional)
<i>opaque_id</i>	(Optional)
<i>prefix</i>	(Optional)
<i>prefix_mask</i>	(Optional)
<i>srgb_base</i>	(Optional)
<i>srgb_range</i>	(Optional)

<i>corrupt</i>	(Optional)
<i>rtr_num_links</i>	(Optional)

Command Mode

- /exec

show ip ospf database database-summary

```
show ip ospf [ <tag> ] database database-summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_ctx <rid> <ptag> <cname> [ TABLE_dbsum [ TABLE_dbsum_area <area> [
TABLE_dbsum_area_lsa <area_lsa_name> <area_lsa_count> ] <area_lsa_total> ] [ TABLE_dbsum_all [
TABLE_dbsum_lsa_all <lsa_name> <lsa_count> ] <non_self_lsa_total> <lsa_total> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
database	Link-state Database Summary
database-summary	Summary of database
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>rid</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_dbsum	(Optional)
TABLE_dbsum_area	(Optional)
<i>area</i>	(Optional)
TABLE_dbsum_area_lsa	(Optional)
<i>area_lsa_name</i>	(Optional)
<i>area_lsa_count</i>	(Optional)
<i>area_lsa_total</i>	(Optional)
TABLE_dbsum_all	(Optional)

TABLE_dbsum_lsa_all	(Optional)
<i>lsa_name</i>	(Optional)
<i>lsa_count</i>	(Optional)
<i>non_self_lsa_total</i>	(Optional)
<i>lsa_total</i>	(Optional)

Command Mode

- /exec

opaque-link	(Optional) Display Opaque Link-Local LSAs
opaque-area	(Optional) Display Opaque Area LSAs
opaque-as	(Optional) Display Opaque AS LSAs
summary	(Optional) Display type 3 (network-summary) LSAs
self-originated	(Optional) Display only self-originated LSAs
<i>lsid</i>	(Optional) Restrict display by link state ID
adv-router	(Optional) Restrict display by Advertising router
<i>advid</i>	(Optional) Advertising router ID
adv-router-name	(Optional) Restrict display by Advertising router name
<i>adv-name</i>	(Optional) DNS Name of the Advertising router
area	(Optional) Display only LSA's in this area
<i>area-id-ip</i>	(Optional) Area Id as an integer or ip address
ext_tag	(Optional) Restrict display by tag
<i>tag_val</i>	(Optional) 32-bit tag value
type	(Optional) Opaque type
router-information	(Optional) Router Information (RI) Opaque LSA
ext-prefix	(Optional) Extended Prefix Opaque LSA
ext-link	(Optional) Extended Link Opaque LSA
detail	Display LSA in detail
private	(Optional) Developer-only statistics
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>rid</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_db2_lsa	(Optional)
<i>name</i>	(Optional)
<i>area</i>	(Optional)
<i>rtr_max_metric</i>	(Optional)

TABLE_lsdb	(Optional)
<i>age</i>	(Optional)
<i>maxage</i>	(Optional)
<i>options</i>	(Optional)
<i>options_str</i>	(Optional)
<i>wrapping</i>	(Optional)
<i>dummy</i>	(Optional)
<i>flush_pending</i>	(Optional)
<i>type</i>	(Optional)
<i>id</i>	(Optional)
<i>id_str</i>	(Optional)
<i>opaque_type</i>	(Optional)
<i>opaque_type_str</i>	(Optional)
<i>opaque_id</i>	(Optional)
<i>prefix</i>	(Optional)
<i>prefix_mask</i>	(Optional)
<i>srgb_base</i>	(Optional)
<i>srgb_range</i>	(Optional)
<i>advrtr</i>	(Optional)
<i>seqno</i>	(Optional)
<i>cksum</i>	(Optional)
<i>len</i>	(Optional)
<i>corrupt</i>	(Optional)
<i>rtr_abr</i>	(Optional)
<i>rtr_asbr</i>	(Optional)
<i>rtr_translate</i>	(Optional)
<i>rtr_vlink_end</i>	(Optional)
<i>rtr_num_links</i>	(Optional)
<i>rtr_links_mismatch</i>	(Optional)

TABLE_rlsa	(Optional)
<i>rtr_link_type</i>	(Optional)
<i>rtr_link_id_str</i>	(Optional)
<i>rtr_link_id</i>	(Optional)
<i>rtr_link_data_str</i>	(Optional)
<i>rtr_link_data</i>	(Optional)
<i>rtr_link_num_tos</i>	(Optional)
<i>rtr_link_metric</i>	(Optional)
TABLE_rlinktos	(Optional)
<i>rtr_link_tos_id</i>	(Optional)
<i>rtr_link_tos_metric</i>	(Optional)
<i>net_mask</i>	(Optional)
TABLE_netlsa	(Optional)
<i>net_rtr</i>	(Optional)
<i>sum_mask</i>	(Optional)
<i>sum_metric</i>	(Optional)
TABLE_sumlsa	(Optional)
<i>sum_tos_id</i>	(Optional)
<i>sum_tos_metric</i>	(Optional)
<i>nssa_mask</i>	(Optional)
<i>nssa_metric_type2</i>	(Optional)
<i>nssa_metric</i>	(Optional)
<i>nssa_fwd_addr</i>	(Optional)
<i>nssa_tag</i>	(Optional)
TABLE_nssa	(Optional)
<i>nssa_tos_metric_type2</i>	(Optional)
<i>nssa_tos_id</i>	(Optional)
<i>nssa_tos_metric</i>	(Optional)
<i>nssa_tos_fwd_addr</i>	(Optional)

<i>nssa_tos_tag</i>	(Optional)
<i>asext_mask</i>	(Optional)
<i>asext_metric_type2</i>	(Optional)
<i>asext_metric</i>	(Optional)
<i>asext_fwd_addr</i>	(Optional)
<i>asext_tag</i>	(Optional)
TABLE_asext	(Optional)
<i>asext_tos_metric_type2</i>	(Optional)
<i>asext_tos_id</i>	(Optional)
<i>asext_tos_metric</i>	(Optional)
<i>asext_tos_fwd_addr</i>	(Optional)
<i>asext_tos_tag</i>	(Optional)
<i>opaque_link_intf</i>	(Optional)
<i>opaque_unknown</i>	(Optional)
<i>opaque_data_len</i>	(Optional)
<i>opaque_data</i>	(Optional)
<i>opaque_corrupt</i>	(Optional)
<i>tlv_type</i>	(Optional)
<i>tlv_len</i>	(Optional)
<i>tlv_data</i>	(Optional)
<i>tlv_unknown</i>	(Optional)
<i>gr_interval</i>	(Optional)
<i>gr_reason</i>	(Optional)
<i>gr_addr</i>	(Optional)
<i>te_frag_id</i>	(Optional)
<i>te_rtr_id</i>	(Optional)
<i>te_link_type</i>	(Optional)
<i>te_link_id</i>	(Optional)
<i>te_link_metric</i>	(Optional)

<i>te_link_max_bw</i>	(Optional)
<i>te_link_rsv_bw</i>	(Optional)
<i>te_link_unrsv_bw</i>	(Optional)
<i>te_link_admin</i>	(Optional)
<i>te_num_links</i>	(Optional)

Command Mode

- /exec

show ip ospf event-history

show ip ospf [<tag>] [internal] event-history { errors | msgs | statistics | adjacency | event | ha | flooding | lsa | spf | redistribution | ldp | te | rib | hello | spf-trigger | cli | objstore | segrt }

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
internal	(Optional) Commands for internal use
event-history	Show various event logs of OSPF
errors	Error logs
msgs	IPC logs
statistics	Show the state and size of the buffers
adjacency	Adjacency formation logs
event	Internal event logs
ha	HA and GR logs
flooding	LSA flooding logs
lsa	LSA generation and database logs
spf	SPF calculation logs
redistribution	Redistribution logs
ldp	LDP related logs
te	MPLS TE related logs
rib	RIB related logs
hello	Hello related logs
cli	Cli logs
spf-trigger	SPF TRIGGER related logs
objstore	DME OBJSTORE related logs
segrt	Segment Routing logs

Command Mode

- /exec

show ip ospf event-history detail

show ip ospf [<tag>] [internal] event-history detail [statistics]

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
internal	(Optional) Commands for internal use
event-history	Show event history of OSPF
detail	Show detailed event history information
statistics	(Optional) Show the state and size of the verbose history buffer

Command Mode

- /exec

show ip ospf interface

```
show ip ospf [ <tag> ] interface [ <interface> | vrf { <vrf-name> | <vrf-known-name> | all } ] [ private ] [
__readonly__ TABLE_ctx <ptag> <cname> [ TABLE_intf <ifname> <admin_status> <proto_status> [
<unnumbered> ] <addr> [ <masklen> ] [ <parent_intf> ] <area> [ <if_cfg> ] <state_str> <type_str> <cost>
[ <bfd_enabled> ] [ <ldp_sync> ] [ <sid_index> ] [ <sid_n_flag_clear> ] [ <sid_exp_null> ] <index> [ <passive> ]
] [ <mpls> ] [ <transmit_delay> ] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid> ] [ <bdr_addr> ] [
<nbr_total> ] [ <nbr_flood> ] [ <nbr_adj> ] [ <gr_nbr> ] [ <hello_interval> ] [ <dead_interval> ] [
<wait_interval> ] [ <rxmt_interval> ] [ <hello_timer> ] [ <wait_timer> ] [ <pacing_timer> ] [ <lsu_timer> ]
[ <lsack_timer> ] [ <netlsa_throt_timer> ] [ <auth_type> ] [ <keychain_name> ] [ <keychain_ready> ] [
<auth_md5_keyid> ] [ <auth_keyid> ] [ <auth_algo> ] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
interface	OSPF enabled interface
<i>interface</i>	(Optional) OSPF enabled interface
private	(Optional) Developer-only statistics
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_intf	(Optional)
<i>ifname</i>	(Optional)
<i>admin_status</i>	(Optional)
<i>proto_status</i>	(Optional)
<i>unnumbered</i>	(Optional)
<i>addr</i>	(Optional)

<i>masklen</i>	(Optional)
<i>parent_intf</i>	(Optional)
<i>area</i>	(Optional)
<i>if_cfg</i>	(Optional)
<i>state_str</i>	(Optional)
<i>type_str</i>	(Optional)
<i>cost</i>	(Optional)
<i>bfd_enabled</i>	(Optional)
<i>ldp_sync</i>	(Optional)
<i>sid_index</i>	(Optional)
<i>sid_n_flag_clear</i>	(Optional)
<i>sid_exp_null</i>	(Optional)
<i>index</i>	(Optional)
<i>passive</i>	(Optional)
<i>mpls</i>	(Optional)
<i>transmit_delay</i>	(Optional)
<i>if_priority</i>	(Optional)
<i>dr_rid</i>	(Optional)
<i>dr_addr</i>	(Optional)
<i>bdr_rid</i>	(Optional)
<i>bdr_addr</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>nbr_flood</i>	(Optional)
<i>nbr_adj</i>	(Optional)
<i>gr_nbr</i>	(Optional)
<i>hello_interval</i>	(Optional)
<i>dead_interval</i>	(Optional)
<i>wait_interval</i>	(Optional)
<i>rxmt_interval</i>	(Optional)

<i>hello_timer</i>	(Optional)
<i>wait_timer</i>	(Optional)
<i>pacing_timer</i>	(Optional)
<i>lsu_timer</i>	(Optional)
<i>lsack_timer</i>	(Optional)
<i>netlsa_throt_timer</i>	(Optional)
<i>auth_type</i>	(Optional)
<i>keychain_name</i>	(Optional)
<i>keychain_ready</i>	(Optional)
<i>auth_md5_keyid</i>	(Optional)
<i>auth_keyid</i>	(Optional)
<i>auth_algo</i>	(Optional)
<i>link_lsa_cnt</i>	(Optional)
<i>link_lsa_crc</i>	(Optional)

Command Mode

- /exec

show ip ospf interface brief

```
show ip ospf [ <tag> ] interface brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> <intf_count> TABLE_intf <ifname> <index> <area> <cost> <state_str>
<nbr_total> <admin_status> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
interface	OSPF enabled interface
brief	Display summary of OSPF interfaces
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>intf_count</i>	(Optional)
TABLE_intf	(Optional)
<i>ifname</i>	(Optional)
<i>index</i>	(Optional)
<i>area</i>	(Optional)
<i>cost</i>	(Optional)
<i>state_str</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>admin_status</i>	(Optional)

Command Mode

- /exec

- /exec

show ip ospf neighbors

```
show ip ospf [ <tag> ] neighbors [ { { <interface> [ <neighbor> | <neighbor-name> ] } | { [ <neighbor> |
<neighbor-name> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] } } ] [ __readonly__ TABLE_ctx <ptag>
<cname> <nbrcount> [ TABLE_nbr <rid> <priority> <state> <drstate> <uptime> <addr> <intf> [ <multiarea>
] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
neighbors	Neighbor list
<i>interface</i>	(Optional) OSPF enabled interface
<i>neighbor</i>	(Optional) Router ID of neighbor
<i>neighbor-name</i>	(Optional) DNS Name of the neighbor
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>nbrcount</i>	(Optional)
TABLE_nbr	(Optional)
<i>rid</i>	(Optional)
<i>priority</i>	(Optional)
<i>state</i>	(Optional)
<i>drstate</i>	(Optional)
<i>uptime</i>	(Optional)

<i>addr</i>	(Optional)
<i>intf</i>	(Optional)
<i>multiarea</i>	(Optional)

Command Mode

- /exec

show ip ospf neighbors detail

```
show ip ospf [ <tag> ] neighbors [ <interface> ] [ <neighbor> | <neighbor-name> ] detail [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ private ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_nbr <rid>
<addr> <area> <intf> <state> <transition> <lastchange> [ <bfd_state> ] [ <priority> ] [ <ifid> ] [ <dr> ] [
<dc> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [ <dbdallsent> ] [ <dbdallacked> ] [
<lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] <helloptions> <dbdoptions> <lastnonhello> [ <deadtimer>
] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [ <lsutimer> ] [ <rerxmtimer> ] [ <fastrerxmtimer>
] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [ <helpercand> ] [ <helperterm> ] [ <senddbd> ] [ <sendlsreq>
] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack> ] [ <sendlsreqreply> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
neighbors	Neighbor list
<i>interface</i>	(Optional) OSPF enabled interface
<i>neighbor</i>	(Optional) Router ID of neighbor
<i>neighbor-name</i>	(Optional) DNS Name of the neighbor
detail	Show detailed neighbor display
private	(Optional) Developer-only statistics
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_nbr	(Optional)
<i>rid</i>	(Optional)
<i>addr</i>	(Optional)

<i>area</i>	(Optional)
<i>intf</i>	(Optional)
<i>state</i>	(Optional)
<i>transition</i>	(Optional)
<i>lastchange</i>	(Optional)
<i>bfd_state</i>	(Optional)
<i>priority</i>	(Optional)
<i>ifid</i>	(Optional)
<i>dr</i>	(Optional)
<i>bdr</i>	(Optional)
<i>master</i>	(Optional)
<i>seqno</i>	(Optional)
<i>dbdallsentacked</i>	(Optional)
<i>dbdallsent</i>	(Optional)
<i>dbdallacked</i>	(Optional)
<i>lsaonreqlist</i>	(Optional)
<i>lsafromlastreq</i>	(Optional)
<i>lsregrxmts</i>	(Optional)
<i>helloptions</i>	(Optional)
<i>dbdoptions</i>	(Optional)
<i>lastmonhello</i>	(Optional)
<i>deadtimer</i>	(Optional)
<i>paddingtimer</i>	(Optional)
<i>dbdrxmtimer</i>	(Optional)
<i>regrxmtimer</i>	(Optional)
<i>lsutimer</i>	(Optional)
<i>rerxmtimer</i>	(Optional)
<i>fastrerxmtimer</i>	(Optional)
<i>lsacktimer</i>	(Optional)

<i>grtimer</i>	(Optional)
<i>helpermode</i>	(Optional)
<i>helpercand</i>	(Optional)
<i>helperterm</i>	(Optional)
<i>senddbd</i>	(Optional)
<i>sendsreq</i>	(Optional)
<i>sendsu</i>	(Optional)
<i>sendsurxmt</i>	(Optional)
<i>sendsack</i>	(Optional)
<i>sendsreqreply</i>	(Optional)
<i>dc</i>	(Optional)

Command Mode

- /exec

show ip ospf neighbors summary

```
show ip ospf [ <tag> ] neighbors [ <interface> ] summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_ctx <ptag> <cname> TABLE_intf { <ifname> | <total> } <down> <attempt> <init>
<twoway> <exstart> <exchange> <loading> <full> <if_total> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
neighbors	Neighbor list
<i>interface</i>	(Optional) OSPF enabled interface
summary	Summary of neighbors
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_intf	(Optional)
<i>ifname</i>	(Optional)
<i>total</i>	(Optional)
<i>down</i>	(Optional)
<i>attempt</i>	(Optional)
<i>init</i>	(Optional)
<i>twoway</i>	(Optional)
<i>exstart</i>	(Optional)
<i>exchange</i>	(Optional)

<i>loading</i>	(Optional)
<i>full</i>	(Optional)
<i>if_total</i>	(Optional)

Command Mode

- /exec

show ip ospf policy statistics

```
show ip ospf [ <inst> ] policy statistics { { redistribute { { bgp | eigrp } <as> | { isis | ospf | rip } <tag> | static
| direct | amt } } | { area <area-id-ip> filter-list { in | out } } } [ vrf { <vrf-name> | <vrf-known-name> | all }
] [ __readonly__ <ptag> TABLE_ctx <cname> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>inst</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
policy	Display Policy related information
statistics	Display Route Filter statistics
redistribute	Statistics for redistribution
isis	ISO Intermediate-to-Intermediate (IS-IS)
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
ospf	Open Shortest Path First (OSPFv2)
eigrp	Enhanced Interior Gateway Protocol (EIGRP)
rip	Routing Information Protocol (RIP)
static	Static
direct	Directly connected
amt	AMT anycast prefix
<i>tag</i>	Source protocol tag
area	Configure area properties
<i>area-id-ip</i>	Area Id as an integer or ip address
filter-list	Filter prefixes between OSPF areas

in	Filter networks sent to this area
out	Filter networks sent from this area
__readonly__	(Optional)
<i>ptag</i>	(Optional)
TABLE_ctx	(Optional)
<i>cname</i>	(Optional)

Command Mode

- /exec

Command Mode

- /exec

<i>age</i>	(Optional)
------------	------------

Command Mode

- /exec

<i>addr</i>	(Optional)
<i>masklen</i>	(Optional)
<i>type</i>	(Optional)
<i>in_rib</i>	(Optional)
<i>direct</i>	(Optional)
<i>area</i>	(Optional)
<i>vlink_unresolved</i>	(Optional)
TABLE_route_ubest_nh	(Optional)
<i>ubest_nh_addr</i>	(Optional)
<i>ubest_nh_intf</i>	(Optional)
<i>ubest_cost</i>	(Optional)
<i>distance</i>	(Optional)
<i>ubest_nh_direct</i>	(Optional)
<i>ubest_nh_in_rib</i>	(Optional)
TABLE_route_mbest_nh	(Optional)
<i>mbest_nh_addr</i>	(Optional)
<i>mbest_nh_intf</i>	(Optional)
<i>mbest_cost</i>	(Optional)
<i>mbest_nh_direct</i>	(Optional)
<i>mbest_nh_in_rib</i>	(Optional)

Command Mode

- /exec

show ip ospf route summary

```
show ip ospf [ <tag> ] route [ <ip-prefix> [ longer-prefixes ] ] summary [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_route <total_routes> <total_paths> [
TABLE_route_type <path_type> <path_routes> <path_paths> ] [ TABLE_route_masklen <masklen>
<masklen_routes> <masklen_paths> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
route	Internal OSPF routes
<i>ip-prefix</i>	(Optional) Show single exact match OSPF route
longer-prefixes	(Optional) Show exact match and more specific routes
summary	Show route counts
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_route	(Optional)
<i>total_routes</i>	(Optional)
<i>total_paths</i>	(Optional)
TABLE_route_type	(Optional)
<i>path_type</i>	(Optional)
<i>path_routes</i>	(Optional)
<i>path_paths</i>	(Optional)

TABLE_route_masklen	(Optional)
<i>masklen</i>	(Optional)
<i>masklen_routes</i>	(Optional)
<i>masklen_paths</i>	(Optional)

Command Mode

- /exec

show ip ospf sham-links

```
show ip ospf [ <tag> ] sham-links [ brief ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> [ TABLE_slink <name> [ <nbr_rid> ] <if_state> <transit_area> <nh_intf>
<nbr_addr> [ <transit_area_stub> ] [ <transit_area_nssa> ] <addr> [ <masklen> ] <area> [ <if_cfg> ] <state_str>
<type_str> <cost> [ <bfd_enabled> ] <index> [ <passive> ] [ <mpls> ] [ <transmit_delay> ] [ <if_priority>
] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid> ] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [ <nbr_adj> ] [
<gr_nbr> ] [ <hello_interval> ] [ <dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [ <sum_total> ] [
<hello_timer> ] [ <wait_timer> ] [ < pacing_timer> ] [ <lsu_timer> ] [ <lsack_timer> ] [ <netlsa_throt_timer>
] [ <auth_type> ] [ <keychain_name> ] [ <keychain_ready> ] [ <auth_md5_keyid> ] [ <link_lsa_cnt> ] [
<link_lsa_crc> ] [ <dc_enabled> ] [ <dest_ip> ] [ <src_ip> ] [ <ifnum> ] [ <state> ] [ <transition> ] [
<lastchange> ] [ <priority> ] [ <ifid> ] [ <dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [
<dbdallsent> ] [ <dbdallacked> ] [ <lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] [ <helloptions> ] [
<dbdoptions> ] [ <lastnonhello> ] [ <deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [
<lsutimer> ] [ <rerxmtimer> ] [ <fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [
<helpercand> ] [ <helperterm> ] [ <sendlssack> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack>
] [ <sendlsreqreply> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
sham-links	Sham link information
brief	(Optional) Display summary of OSPF sham links
__readonly__	(Optional)
ptag	(Optional)
TABLE_ctx	(Optional)
cname	(Optional)
TABLE_slink	(Optional)
name	(Optional)
nbr_rid	(Optional)

<i>if_state</i>	(Optional)
<i>transit_area</i>	(Optional)
<i>nh_intf</i>	(Optional)
<i>dc_enabled</i>	(Optional)
<i>nbr_addr</i>	(Optional)
<i>sum_total</i>	(Optional)
<i>transit_area_stub</i>	(Optional)
<i>transit_area_nssa</i>	(Optional)
<i>addr</i>	(Optional)
<i>masklen</i>	(Optional)
<i>area</i>	(Optional)
<i>if_cfg</i>	(Optional)
<i>state_str</i>	(Optional)
<i>type_str</i>	(Optional)
<i>cost</i>	(Optional)
<i>bfd_enabled</i>	(Optional)
<i>index</i>	(Optional)
<i>passive</i>	(Optional)
<i>mpls</i>	(Optional)
<i>transmit_delay</i>	(Optional)
<i>if_priority</i>	(Optional)
<i>dr_rid</i>	(Optional)
<i>dr_addr</i>	(Optional)
<i>bdr_rid</i>	(Optional)
<i>bdr_addr</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>nbr_flood</i>	(Optional)
<i>nbr_adj</i>	(Optional)
<i>gr_nbr</i>	(Optional)

<i>hello_interval</i>	(Optional)
<i>dead_interval</i>	(Optional)
<i>wait_interval</i>	(Optional)
<i>rxmt_interval</i>	(Optional)
<i>hello_timer</i>	(Optional)
<i>wait_timer</i>	(Optional)
<i>pacing_timer</i>	(Optional)
<i>lsu_timer</i>	(Optional)
<i>lsack_timer</i>	(Optional)
<i>netlsa_throt_timer</i>	(Optional)
<i>auth_type</i>	(Optional)
<i>keychain_name</i>	(Optional)
<i>keychain_ready</i>	(Optional)
<i>auth_md5_keyid</i>	(Optional)
<i>link_lsa_cnt</i>	(Optional)
<i>link_lsa_crc</i>	(Optional)
<i>state</i>	(Optional)
<i>transition</i>	(Optional)
<i>lastchange</i>	(Optional)
<i>priority</i>	(Optional)
<i>ifid</i>	(Optional)
<i>dr</i>	(Optional)
<i>bdr</i>	(Optional)
<i>master</i>	(Optional)
<i>seqno</i>	(Optional)
<i>dbdallsentacked</i>	(Optional)
<i>dbdallsent</i>	(Optional)
<i>dbdallacked</i>	(Optional)
<i>lsaonreqlist</i>	(Optional)

<i>lsafromlastreq</i>	(Optional)
<i>lsreqrxmts</i>	(Optional)
<i>helloptions</i>	(Optional)
<i>dbdoptions</i>	(Optional)
<i>lastnonhello</i>	(Optional)
<i>deadtimer</i>	(Optional)
<i>pacingtmer</i>	(Optional)
<i>dbdrxmtimer</i>	(Optional)
<i>reqrxmtimer</i>	(Optional)
<i>lsutimer</i>	(Optional)
<i>rerxmtimer</i>	(Optional)
<i>fastrerxmtimer</i>	(Optional)
<i>lsacktimer</i>	(Optional)
<i>grtimer</i>	(Optional)
<i>helpermode</i>	(Optional)
<i>helpercand</i>	(Optional)
<i>helperterm</i>	(Optional)
<i>senddbd</i>	(Optional)
<i>sendlsreq</i>	(Optional)
<i>sendlsu</i>	(Optional)
<i>sendlsurxmt</i>	(Optional)
<i>sendlsack</i>	(Optional)
<i>sendlsreqreply</i>	(Optional)
<i>dest_ip</i>	(Optional)
<i>src_ip</i>	(Optional)
<i>ifnum</i>	(Optional)

Command Mode

- /exec

show ip ospf statistics

```
show ip ospf [ <tag> ] statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_stats
<ptag> <cname> <last_clear> <rid_change> <dr_elections> <older_lsa_recv> <nbr_state_change>
<nbr_dead_postpone> <nbr_dead_expire> <nbr_bad_lsreq> <nbr_seqno_mismatch> <spf_full>
<spf_summary> <spf_external> <spf_extsummary> <rtr_generate> <rtr_refresh> <rtr_flush> <rtr_other_flush>
<net_generate> <net_refresh> <net_flush> <net_other_flush> <sum_generate> <sum_refresh> <sum_flush>
<sum_other_flush> <asbr_generate> <asbr_refresh> <asbr_flush> <asbr_other_flush> <asext_generate>
<asext_refresh> <asext_flush> <asext_other_flush> <opaque_link_generate> <opaque_link_refresh>
<opaque_link_flush> <opaque_link_other_flush> <opaque_area_generate> <opaque_area_refresh>
<opaque_area_flush> <opaque_area_other_flush> <opaque_as_generate> <opaque_as_refresh>
<opaque_as_flush> <opaque_as_other_flush> <limbo_lsa_count> <limbo_lsa_hwm> <limbo_lsa_deleted>
<limbo_lsa_revived> <limbo_runs> <limbo_lsa_last_time_hwm> [ <limbo_timer> ] <helloq_size>
<helloq_max_size> <helloq_hwm> <helloq_drops> <helloq_last_hwm_time> <floodq_size>
<floodq_max_size> <floodq_hwm> <floodq_drops> <floodq_last_hwm_time> <lsdb_add_fail> [
TABLE_buffer_detail [ <buf_size> ] [ <buf_size_huge> ] <buf_in_use> <buf_hwm> <buf_perm> <buf_alloc>
<buf_free> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
statistics	Event counters
<i>__readonly__</i>	(Optional)
TABLE_stats	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>last_clear</i>	(Optional)
<i>rid_change</i>	(Optional)
<i>dr_elections</i>	(Optional)
<i>older_lsa_recv</i>	(Optional)

<i>nbr_state_change</i>	(Optional)
<i>nbr_dead_postpone</i>	(Optional)
<i>nbr_dead_expire</i>	(Optional)
<i>nbr_bad_lsreq</i>	(Optional)
<i>nbr_seqno_mismatch</i>	(Optional)
<i>spf_full</i>	(Optional)
<i>spf_summary</i>	(Optional)
<i>spf_external</i>	(Optional)
<i>spf_extsummary</i>	(Optional)
<i>rtr_generate</i>	(Optional)
<i>rtr_refresh</i>	(Optional)
<i>rtr_flush</i>	(Optional)
<i>rtr_other_flush</i>	(Optional)
<i>net_generate</i>	(Optional)
<i>net_refresh</i>	(Optional)
<i>net_flush</i>	(Optional)
<i>net_other_flush</i>	(Optional)
<i>sum_generate</i>	(Optional)
<i>sum_refresh</i>	(Optional)
<i>sum_flush</i>	(Optional)
<i>sum_other_flush</i>	(Optional)
<i>asbr_generate</i>	(Optional)
<i>asbr_refresh</i>	(Optional)
<i>asbr_flush</i>	(Optional)
<i>asbr_other_flush</i>	(Optional)
<i>asext_generate</i>	(Optional)
<i>asext_refresh</i>	(Optional)
<i>asext_flush</i>	(Optional)
<i>asext_other_flush</i>	(Optional)

<i>opaque_link_generate</i>	(Optional)
<i>opaque_link_refresh</i>	(Optional)
<i>opaque_link_flush</i>	(Optional)
<i>opaque_link_other_flush</i>	(Optional)
<i>opaque_area_generate</i>	(Optional)
<i>opaque_area_refresh</i>	(Optional)
<i>opaque_area_flush</i>	(Optional)
<i>opaque_area_other_flush</i>	(Optional)
<i>opaque_as_generate</i>	(Optional)
<i>opaque_as_refresh</i>	(Optional)
<i>opaque_as_flush</i>	(Optional)
<i>opaque_as_other_flush</i>	(Optional)
<i>limbo_lsa_count</i>	(Optional)
<i>limbo_lsa_hwm</i>	(Optional)
<i>limbo_lsa_deleted</i>	(Optional)
<i>limbo_lsa_revived</i>	(Optional)
<i>limbo_runs</i>	(Optional)
<i>limbo_lsa_last_time_hwm</i>	(Optional)
<i>limbo_timer</i>	(Optional)
<i>helloq_size</i>	(Optional)
<i>helloq_max_size</i>	(Optional)
<i>helloq_hwm</i>	(Optional)
<i>helloq_drops</i>	(Optional)
<i>helloq_last_hwm_time</i>	(Optional)
<i>floodq_size</i>	(Optional)
<i>floodq_max_size</i>	(Optional)
<i>floodq_hwm</i>	(Optional)
<i>floodq_drops</i>	(Optional)
<i>floodq_last_hwm_time</i>	(Optional)

<i>lsdb_add_fail</i>	(Optional)
TABLE_buffer_detail	(Optional)
<i>buf_size</i>	(Optional)
<i>buf_size_huge</i>	(Optional)
<i>buf_in_use</i>	(Optional)
<i>buf_hwm</i>	(Optional)
<i>buf_perm</i>	(Optional)
<i>buf_alloc</i>	(Optional)
<i>buf_free</i>	(Optional)

Command Mode

- /exec

show ip ospf summary-address

```
show ip ospf [ <tag> ] summary-address [ private ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ [ TABLE_ctx <ptag> <cname> <rid> [ TABLE_sum <addr> <masklen> [ <metric> ] [ <tag>
] [ <pending> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
summary-address	Summary-address redistribution information
private	(Optional) Developer-only statistics
<i>tag</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>rid</i>	(Optional)
TABLE_sum	(Optional)
<i>addr</i>	(Optional)
<i>masklen</i>	(Optional)
<i>metric</i>	(Optional)
<i>pending</i>	(Optional)

Command Mode

- /exec

show ip ospf traffic

```
show ip ospf [ <tag> ] traffic [ <interface> [ detail ] | [ detail ] | [ detail ] vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_traf <ptag> <cname> <last_clear> [ <ifname> ] <pkt_in> <pkt_out>
<lsu_first_trans> <lsu_retrans> <lsu_for_lsreq> <lsu_nbr_trans> <throttle_out> <throttle_out_token>
<throttle_out_ip> <lsa_ignored> <lsa_dropped_spf> <lsa_dropped_gr> <pkt_drops_in> <pkt_drops_out>
<pkt_errors_in> <pkt_errors_out> <hello_errors_in> <dbds_errors_in> <lsreqs_errors_in> <lsus_errors_in>
<lsacks_errors_in> <pkt_unknown_in> <pkt_unknown_out> <pkt_no_ospf_intf> <bad_version> <bad_crc>
<dup_rtr_id> <dup_src_addr> <invalid_src_addr> <invalid_dst_addr> <non_existing_nbr> <pkt_passive_intf>
<wrong_area> <invalid_pkt_len> <nbr_changed_routerid_ipaddr> <nbr_changed_interfaceid> <bad_auth>
<pkt_no_vrf> [ <bad_reserved> ] <hellos_in> <dbds_in> <lsreqs_in> <lsus_in> <lsacks_in> <hellos_out>
<dbds_out> <lsreqs_out> <lsus_out> <lsacks_out> [ <hellos_in_hq> <dbds_in_hq> <lsreqs_in_flq>
<lsus_in_flq> <lsacks_in_flq> <lsas_in_dbds_in> <lsas_in_lsreqs_in> <lsas_in_lsus_in> <lsas_in_lsacks_in>
<lsas_in_dbds_out> <lsas_in_lsreqs_out> <lsas_in_lsus_out> <lsas_in_lsacks_out> <lsas_in_rxmt_lsus_out>
] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
<i>interface</i>	(Optional) OSPF enabled interface
detail	(Optional) Display detailed information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
traffic	Packet counters
<i>__readonly__</i>	(Optional)
<i>TABLE_traf</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>last_clear</i>	(Optional)
<i>ifname</i>	(Optional)
<i>pkt_in</i>	(Optional)

<i>pkt_out</i>	(Optional)
<i>lsu_first_trans</i>	(Optional)
<i>lsu_retrans</i>	(Optional)
<i>lsu_for_lsreq</i>	(Optional)
<i>lsu_nbr_trans</i>	(Optional)
<i>throttle_out</i>	(Optional)
<i>throttle_out_token</i>	(Optional)
<i>throttle_out_ip</i>	(Optional)
<i>lsa_ignored</i>	(Optional)
<i>lsa_dropped_spf</i>	(Optional)
<i>lsa_dropped_gr</i>	(Optional)
<i>pkt_drops_in</i>	(Optional)
<i>pkt_drops_out</i>	(Optional)
<i>pkt_errors_in</i>	(Optional)
<i>pkt_errors_out</i>	(Optional)
<i>hello_errors_in</i>	(Optional)
<i>dbds_errors_in</i>	(Optional)
<i>lsreqs_errors_in</i>	(Optional)
<i>lsus_errors_in</i>	(Optional)
<i>lsacks_errors_in</i>	(Optional)
<i>pkt_unknown_in</i>	(Optional)
<i>pkt_unknown_out</i>	(Optional)
<i>pkt_no_ospf_intf</i>	(Optional)
<i>bad_version</i>	(Optional)
<i>bad_crc</i>	(Optional)
<i>dup_rtr_id</i>	(Optional)
<i>dup_src_addr</i>	(Optional)
<i>invalid_src_addr</i>	(Optional)
<i>invalid_dst_addr</i>	(Optional)

<i>non_existing_nbr</i>	(Optional)
<i>pkt_passive_intf</i>	(Optional)
<i>wrong_area</i>	(Optional)
<i>invalid_pkt_len</i>	(Optional)
<i>nbr_changed_routerid_ipaddr</i>	(Optional)
<i>nbr_changed_interfaceid</i>	(Optional)
<i>bad_auth</i>	(Optional)
<i>bad_reserved</i>	(Optional)
<i>pkt_no_vrf</i>	(Optional)
<i>hellos_in</i>	(Optional)
<i>dbds_in</i>	(Optional)
<i>lsreqs_in</i>	(Optional)
<i>lsus_in</i>	(Optional)
<i>lsacks_in</i>	(Optional)
<i>hellos_out</i>	(Optional)
<i>dbds_out</i>	(Optional)
<i>lsreqs_out</i>	(Optional)
<i>lsus_out</i>	(Optional)
<i>lsacks_out</i>	(Optional)
<i>hellos_in_hq</i>	(Optional)
<i>dbds_in_hq</i>	(Optional)
<i>lsreqs_in_flq</i>	(Optional)
<i>lsus_in_flq</i>	(Optional)
<i>lsacks_in_flq</i>	(Optional)
<i>lsas_in_dbds_in</i>	(Optional)
<i>lsas_in_lsreqs_in</i>	(Optional)
<i>lsas_in_lsus_in</i>	(Optional)
<i>lsas_in_lsacks_in</i>	(Optional)
<i>lsas_in_dbds_out</i>	(Optional)

<i>lsas_in_lsreqs_out</i>	(Optional)
<i>lsas_in_lsus_out</i>	(Optional)
<i>lsas_in_lsacks_out</i>	(Optional)
<i>lsas_in_rxmt_lsus_out</i>	(Optional)

Command Mode

- /exec

show ip ospf virtual-links

```
show ip ospf [ <tag> ] virtual-links [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ TABLE_vlink <name> <nbr_rid> <if_state> <transit_area> <nh_intf> <nbr_addr> [
<transit_area_stub> ] [ <transit_area_nssa> ] <addr> [ <masklen> ] <area> [ <if_cfg> ] <state_str> <type_str>
<cost> <index> [ <passive> ] [ <mpls> ] [ <transmit_delay> ] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [
<bdr_rid> ] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [ <nbr_adjs> ] [ <gr_nbr> ] [ <hello_interval> ] [
<dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [ <hello_timer> ] [ <wait_timer> ] [ <pacing_timer>
] [ <lsu_timer> ] [ <lsack_timer> ] [ <netlsa_throt_timer> ] [ <auth_type> ] [ <keychain_name> ] [
<keychain_ready> ] [ <auth_md5_keyid> ] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] [ <dc_enabled> ] [ <state>
] [ <transition> ] [ <lastchange> ] [ <priority> ] [ <ifid> ] [ <dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [
<dbdallsentacked> ] [ <dbdallsent> ] [ <dbdallacked> ] [ <lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts>
] [ <helloptions> ] [ <dbdoptions> ] [ <lastnonhello> ] [ <deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ]
[ <reqrxtimer> ] [ <lsutimer> ] [ <rerxmtimer> ] [ <fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [
<helpermode> ] [ <helpercand> ] [ <helperterm> ] [ <senddbd> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt>
] [ <sendlsack> ] [ <sendlsrepreply> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
virtual-links	Virtual link information
__readonly__	(Optional)
TABLE_ctx	(Optional)
ptag	(Optional)
cname	(Optional)
TABLE_vlink	(Optional)
name	(Optional)
nbr_rid	(Optional)
if_state	(Optional)
transit_area	(Optional)

<i>nh_intf</i>	(Optional)
<i>dc_enabled</i>	(Optional)
<i>nbr_addr</i>	(Optional)
<i>transit_area_stub</i>	(Optional)
<i>transit_area_nssa</i>	(Optional)
<i>addr</i>	(Optional)
<i>masklen</i>	(Optional)
<i>area</i>	(Optional)
<i>if_cfg</i>	(Optional)
<i>state_str</i>	(Optional)
<i>type_str</i>	(Optional)
<i>cost</i>	(Optional)
<i>index</i>	(Optional)
<i>passive</i>	(Optional)
<i>mpls</i>	(Optional)
<i>transmit_delay</i>	(Optional)
<i>if_priority</i>	(Optional)
<i>dr_rid</i>	(Optional)
<i>dr_addr</i>	(Optional)
<i>bdr_rid</i>	(Optional)
<i>bdr_addr</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>nbr_flood</i>	(Optional)
<i>nbr_adj</i>	(Optional)
<i>gr_nbr</i>	(Optional)
<i>hello_interval</i>	(Optional)
<i>dead_interval</i>	(Optional)
<i>wait_interval</i>	(Optional)
<i>rxmt_interval</i>	(Optional)

<i>hello_timer</i>	(Optional)
<i>wait_timer</i>	(Optional)
<i>pacing_timer</i>	(Optional)
<i>lsu_timer</i>	(Optional)
<i>lsack_timer</i>	(Optional)
<i>netlsa_throt_timer</i>	(Optional)
<i>auth_type</i>	(Optional)
<i>keychain_name</i>	(Optional)
<i>keychain_ready</i>	(Optional)
<i>auth_md5_keyid</i>	(Optional)
<i>link_lsa_cnt</i>	(Optional)
<i>link_lsa_crc</i>	(Optional)
<i>state</i>	(Optional)
<i>transition</i>	(Optional)
<i>lastchange</i>	(Optional)
<i>priority</i>	(Optional)
<i>ifid</i>	(Optional)
<i>dr</i>	(Optional)
<i>bdr</i>	(Optional)
<i>master</i>	(Optional)
<i>seqno</i>	(Optional)
<i>dbdallsentacked</i>	(Optional)
<i>dbdallsent</i>	(Optional)
<i>dbdallacked</i>	(Optional)
<i>lsaonreqlist</i>	(Optional)
<i>lsafromlastreq</i>	(Optional)
<i>lsreqrxmts</i>	(Optional)
<i>helloptions</i>	(Optional)
<i>dbdoptions</i>	(Optional)

<i>lastnonhello</i>	(Optional)
<i>deadtimer</i>	(Optional)
<i>paddingtimer</i>	(Optional)
<i>dbdrxtimer</i>	(Optional)
<i>reqrxmtimer</i>	(Optional)
<i>lsutimer</i>	(Optional)
<i>rerxmtimer</i>	(Optional)
<i>fastrerxmtimer</i>	(Optional)
<i>lsacktimer</i>	(Optional)
<i>grtimer</i>	(Optional)
<i>helpermode</i>	(Optional)
<i>helpercand</i>	(Optional)
<i>helperterm</i>	(Optional)
<i>senddbd</i>	(Optional)
<i>sendsreq</i>	(Optional)
<i>sendsu</i>	(Optional)
<i>sendsurxmt</i>	(Optional)
<i>sendsack</i>	(Optional)
<i>sendsreqreply</i>	(Optional)

Command Mode

- /exec

show ip ospf virtual-links brief

```
show ip ospf [ <tag> ] virtual-links brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> <vlink_count> [ TABLE_vlink <nbr_rid> <vlink_num> <transit_area> <cost>
<if_state> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ospf	Display OSPF status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
virtual-links	Virtual link information
brief	Display summary of OSPF virtual links
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>vlink_count</i>	(Optional)
TABLE_vlink	(Optional)
<i>nbr_rid</i>	(Optional)
<i>vlink_num</i>	(Optional)
<i>transit_area</i>	(Optional)
<i>cost</i>	(Optional)
<i>if_state</i>	(Optional)

Command Mode

- /exec

show ip pim config-sanity

```
show ip pim config-sanity [ __readonly__ [ TABLE_vrf <out-context> [ TABLE_RP <rp-addr> [ {
<rperr-count><rp-interface><rp-error> } ] ] [ TABLE_ANYCAST [ { <arperr-count> <anycastrp-addr> [
<arp-interface> ] <arp-error> [ <configure-as-RP> } ] ] [ TABLE_MEMBER [ { <memerr-count> [
<mem-interface> ] <mem-error> } ] ] <found> ] [ TABLE_BSR [ { <rp-cand-count> [ <rp-cand-interface>
] <rp-cand-error> } ] [ { <bsr-cand-count> [ <bsr-cand-interface> ] <bsr-cand-error> } ] ] [ TABLE_AUTORP
[ { <rp-cand-count> [ <rp-cand-interface> ] <rp-cand-error> } ] [ { <auto-cand-count> [ <auto-cand-interface>
] <auto-cand-error> } ] ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
config-sanity	Configuration Sanity check
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>out-context</i>	(Optional)
TABLE_RP	(Optional)
<i>rp-addr</i>	(Optional)
TABLE_ANYCAST	(Optional)
<i>arperr-count</i>	(Optional)
<i>anycastrp-addr</i>	(Optional)
<i>arp-interface</i>	(Optional)
<i>arp-error</i>	(Optional)
<i>configure-as-RP</i>	(Optional)
TABLE_MEMBER	(Optional)
<i>memerr-count</i>	(Optional)
<i>mem-interface</i>	(Optional)
<i>mem-error</i>	(Optional)
<i>found</i>	(Optional)
TABLE_BSR	(Optional)
<i>rp-cand-count</i>	(Optional)

<i>rp-cand-interface</i>	(Optional)
<i>rp-cand-error</i>	(Optional)
<i>bsr-cand-count</i>	(Optional)
<i>bsr-cand-interface</i>	(Optional)
<i>bsr-cand-error</i>	(Optional)
TABLE_AUTHORP	(Optional)
<i>rp-cand-count</i>	(Optional)
<i>rp-cand-interface</i>	(Optional)
<i>rp-cand-error</i>	(Optional)
<i>auto-cand-count</i>	(Optional)
<i>auto-cand-interface</i>	(Optional)
<i>auto-cand-error</i>	(Optional)

Command Mode

- /exec

show ip pim df

```
show ip pim df [ <rp-or-group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [ __readonly__ ]
[ TABLE_ctx [ <out-context> ] [ TABLE_rp [ <rp-addr> ] [ <df-ordinal> ] [ <df-bits> ] [ <df-bits-count> ]
[ <metric-pref> ] [ <metric> ] [ TABLE_grange [ <grange-grp> ] [ <grange-masklen> ] ] [ TABLE_iod [
<if-name> ] [ <df-winner> ] [ <df-state> ] [ <winner-metric-pref> ] [ <winner-metric> ] [ <uptime> ] [ <is-rpf>
]]]]]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
df	Display Bidir Designated Forwarders
<i>rp-or-group</i>	(Optional) Display for a single RP or group address
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
internal	(Optional) Commands for internal use
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>out-context</i>	(Optional)
TABLE_rp	(Optional)
<i>rp-addr</i>	(Optional)
<i>df-ordinal</i>	(Optional)
<i>df-bits</i>	(Optional)
<i>df-bits-count</i>	(Optional)
<i>metric-pref</i>	(Optional)
<i>metric</i>	(Optional)
TABLE_grange	(Optional)
<i>grange-grp</i>	(Optional)
<i>grange-masklen</i>	(Optional)

TABLE_iod	(Optional)
<i>if-name</i>	(Optional)
<i>df-winner</i>	(Optional)
<i>df-state</i>	(Optional)
<i>winner-metric-pref</i>	(Optional)
<i>winner-metric</i>	(Optional)
<i>uptime</i>	(Optional)
<i>is-rpf</i>	(Optional)

Command Mode

- /exec

show ip pim event-history

```
show ip pim [ internal ] event-history { errors | msgs | <pim-event-hist-buf-name> | statistics }
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	PIM global configuration commands
internal	(Optional) Commands for internal use
event-history	Show various event logs of PIM
errors	Show error logs of PIM
msgs	Show various message logs of PIM
<i>pim-event-hist-buf-name</i>	Show event hist buffer name
statistics	Show the state and size of the buffer

Command Mode

- /exec

show ip pim fabric info

```
show ip pim fabric info [ __readonly__ <switch_role> <fabric_ctrl_addr> <peer_fabric_ctrl_infra>
<vpc_domain_id> <peer_fabric_ctrl_addr> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
fabric	Fabric functionality
info	show the fabric info
<i>__readonly__</i>	(Optional)
<i>switch_role</i>	(Optional)
<i>fabric_ctrl_addr</i>	(Optional)
<i>peer_fabric_ctrl_infra</i>	(Optional)
<i>vpc_domain_id</i>	(Optional)
<i>peer_fabric_ctrl_addr</i>	(Optional)

Command Mode

- /exec

show ip pim fabric legacy-vlans

```
show ip pim fabric legacy-vlans [ __readonly__ TABLE_legacy_vlan <vlan_id> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
fabric	Fabric functionality
legacy-vlans	Show legacy VLANs on this switch
<i>__readonly__</i>	(Optional)
<i>TABLE_legacy_vlan</i>	(Optional)
<i>vlan_id</i>	(Optional)

Command Mode

- /exec

show ip pim host-proxy

show ip pim host-proxy [__readonly__ TABLE_intf <intf-name>]

Syntax Description

show	Show running system information
ip	Display IP information
pim	PIM global configuration commands
host-proxy	host-proxy
__readonly__	(Optional)
TABLE_intf	(Optional)
<i>intf-name</i>	(Optional)

Command Mode

- /exec

show ip pim interface

```
show ip pim interface [ <interface> ] [ brief ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [
__readonly__ ] [ <is-pim-enabled> ] [ TABLE_vrf [ <out-context> ] [ TABLE_brief [ <if-name> ] [ <if-addr>
] [ <if-dr> ] [ <if-nbr-count> ] [ <if-is-border> ] ] [ TABLE_iod [ <if-name> ] [ <if-status> ] [
<cached_if_status> ] [ <if-addr-summary> ] [ <pim-dr-address> ] [ <dr-priority> ] [ <no-dr-priority> ] [
<nbr-cnt> ] [ <hello-interval-sec> ] [ <hello-interval-msec> ] [ <hello-timer> ] [ <holdtime-msec> ] [
<holdtime-sec> ] [ <if-conf-dr-priority> ] [ <if-conf-delay> ] [ <is-border> ] [ <genid> ] [ <isauth-config> ]
[ <nbr-policy-name> ] [ <jp-in-policy-name> ] [ <jp-out-policy-name> ] [ <jp-interval> ] [ <jp-next-send> ]
[ <pim-bfd-enabled> ] [ <is-passive> ] [ <is-pim-vpc-svi> ] [ <is-auto-enabled> ] [ <vpc-peer-nbr> ] [
<last-cleared> ] [ <hello-sent> ] [ <hello-rcvd> ] [ <hello-early-sent> ] [ <jp-sent> ] [ <jp-rcvd> ] [ <assert-sent>
] [ <assert-rcvd> ] [ <graft-sent> ] [ <graft-rcvd> ] [ <graft-ack-sent> ] [ <graft-ack-rcvd> ] [ <df-offer-sent>
] [ <df-offer-rcvd> ] [ <df-winner-sent> ] [ <df-winner-rcvd> ] [ <df-backoff-sent> ] [ <df-backoff-rcvd> ] [
<pass-sent> ] [ <pass-rcvd> ] [ <cksum-errors> ] [ <invalid-errors> ] [ <invalid-df-errors> ] [ <auth-failed>
] [ <pak-len-errors> ] [ <ver-errors> ] [ <pkts-self> ] [ <pkts-non-nbr> ] [ <pkts-on-passive> ] [ <jp-rcvd-on-rpf>
] [ <jp-rcvd-no-rp> ] [ <jp-rcvd-wrong-rp> ] [ <jp-rcvd-for-ssm> ] [ <jp-rcvd-for-bidir> ] [ <jp-in-policy-filter>
] [ <jp-out-policy-filter> ] [ <ecmp-redirect-sent> ] [ <ecmp-redirect-rcv> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
interface	Display PIM interface related information
<i>interface</i>	(Optional) Interface name of single interface to display
brief	(Optional) Display one line status per interface
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
internal	(Optional) Commands for internal use
<i>__readonly__</i>	(Optional)
<i>is-pim-enabled</i>	(Optional)
TABLE_vrf	(Optional)
<i>out-context</i>	(Optional)
TABLE_brief	(Optional)
<i>if-name</i>	(Optional)

<i>if-addr</i>	(Optional)
<i>if-dr</i>	(Optional)
<i>if-nbr-count</i>	(Optional)
<i>if-is-border</i>	(Optional)
TABLE_iod	(Optional)
<i>if-name</i>	(Optional)
<i>if-status</i>	(Optional)
<i>cached_if_status</i>	(Optional)
<i>if-addr-summary</i>	(Optional)
<i>pim-dr-address</i>	(Optional)
<i>dr-priority</i>	(Optional)
<i>no-dr-priority</i>	(Optional)
<i>nbr-cnt</i>	(Optional)
<i>hello-interval-sec</i>	(Optional)
<i>hello-interval-msec</i>	(Optional)
<i>hello-timer</i>	(Optional)
<i>holdtime-msec</i>	(Optional)
<i>holdtime-sec</i>	(Optional)
<i>if-conf-dr-priority</i>	(Optional)
<i>if-conf-delay</i>	(Optional)
<i>is-border</i>	(Optional)
<i>genid</i>	(Optional)
<i>isauth-config</i>	(Optional)
<i>nbr-policy-name</i>	(Optional)
<i>jp-in-policy-name</i>	(Optional)
<i>jp-out-policy-name</i>	(Optional)
<i>jp-interval</i>	(Optional)
<i>jp-next-send</i>	(Optional)
<i>pim-bfd-enabled</i>	(Optional)

<i>is-passive</i>	(Optional)
<i>is-pim-vpc-svi</i>	(Optional)
<i>is-auto-enabled</i>	(Optional)
<i>vpc-peer-nbr</i>	(Optional)
<i>last-cleared</i>	(Optional)
<i>hello-sent</i>	(Optional)
<i>hello-rcvd</i>	(Optional)
<i>hello-early-sent</i>	(Optional)
<i>jp-sent</i>	(Optional)
<i>jp-rcvd</i>	(Optional)
<i>assert-sent</i>	(Optional)
<i>assert-rcvd</i>	(Optional)
<i>graft-sent</i>	(Optional)
<i>graft-rcvd</i>	(Optional)
<i>graft-ack-sent</i>	(Optional)
<i>graft-ack-rcvd</i>	(Optional)
<i>df-offer-sent</i>	(Optional)
<i>df-offer-rcvd</i>	(Optional)
<i>df-winner-sent</i>	(Optional)
<i>df-winner-rcvd</i>	(Optional)
<i>df-backoff-sent</i>	(Optional)
<i>df-backoff-rcvd</i>	(Optional)
<i>pass-sent</i>	(Optional)
<i>pass-rcvd</i>	(Optional)
<i>cksum-errors</i>	(Optional)
<i>invalid-errors</i>	(Optional)
<i>invalid-df-errors</i>	(Optional)
<i>auth-failed</i>	(Optional)
<i>pak-len-errors</i>	(Optional)

<i>ver-errors</i>	(Optional)
<i>pkts-self</i>	(Optional)
<i>pkts-non-nbr</i>	(Optional)
<i>pkts-on-passive</i>	(Optional)
<i>jp-rcvd-on-rpf</i>	(Optional)
<i>jp-rcvd-no-rp</i>	(Optional)
<i>jp-rcvd-wrong-rp</i>	(Optional)
<i>jp-rcvd-for-ssm</i>	(Optional)
<i>jp-rcvd-for-bidir</i>	(Optional)
<i>jp-in-policy-filter</i>	(Optional)
<i>jp-out-policy-filter</i>	(Optional)
<i>ecmp-redirect-sent</i>	(Optional)
<i>ecmp-redirect-recv</i>	(Optional)

Command Mode

- /exec

show ip pim mdt

```
show ip pim mdt [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <out_context>
<mti> <mti_status> <default_mdt_grp> <grp_mode> <asm_shared_tree> <mti_config_mtu> <mti_active_mtu>
<cfg_tunnel_src_if> <bgp_update_src_if> <hello_interval> <jp_interval> <data_mdt_join_interval>
<data_switchover_interval> <data_holddown_interval> <data_timeout_interval> <mdt_src> <mdt_src_if>
<bgp_rd> <bgp_rd_set> <send_join_count> <rcvd_join_count> { TABLE_data_mdt <grange_prefix>
<grange_mask_len> <threshold> [ <policy_name> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
mdt	Display MDT information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>out_context</i>	(Optional)
<i>mti</i>	(Optional)
<i>mti_status</i>	(Optional)
<i>default_mdt_grp</i>	(Optional)
<i>grp_mode</i>	(Optional)
<i>asm_shared_tree</i>	(Optional)
<i>mti_config_mtu</i>	(Optional)
<i>mti_active_mtu</i>	(Optional)
<i>cfg_tunnel_src_if</i>	(Optional)
<i>bgp_update_src_if</i>	(Optional)
<i>hello_interval</i>	(Optional)
<i>jp_interval</i>	(Optional)

<i>data_mdt_join_interval</i>	(Optional)
<i>data_switchover_interval</i>	(Optional)
<i>data_holddown_interval</i>	(Optional)
<i>data_timeout_interval</i>	(Optional)
<i>mdt_src</i>	(Optional)
<i>mdt_src_if</i>	(Optional)
<i>bgp_rd</i>	(Optional)
<i>bgp_rd_set</i>	(Optional)
<i>send_join_count</i>	(Optional)
<i>rcvd_join_count</i>	(Optional)
TABLE_data_mdt	(Optional)
<i>grange_prefix</i>	(Optional)
<i>grange_mask_len</i>	(Optional)
<i>threshold</i>	(Optional)
<i>policy_name</i>	(Optional)

Command Mode

- /exec

show ip pim mdt bgp

```
show ip pim mdt bgp [ mdt-source <src-addr> ] [ __readonly__ { TABLE_entry <bgp_rd> <mdt_src>
<mdt_grp> <local> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
mdt	Display MDT information
bgp	Display BGP related information
mdt-source	(Optional) Source address of MVPN neighbor
<i>src-addr</i>	(Optional) Source Address
<i>__readonly__</i>	(Optional)
TABLE_entry	(Optional)
<i>bgp_rd</i>	(Optional)
<i>mdt_src</i>	(Optional)
<i>mdt_grp</i>	(Optional)
<i>local</i>	(Optional)

Command Mode

- /exec

show ip pim mdt history interval

```
show ip pim mdt history interval <min> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_vrf <out_context> [ { TABLE_entry <csrc> <cgrp> <psrc> <pgrp> <uptime> <send_count> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
mdt	Display MDT information
history	Display MDT Data Join Send Histoy
interval	Display in specified interval
<i>min</i>	Minutes
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>out_context</i>	(Optional)
TABLE_entry	(Optional)
<i>csrc</i>	(Optional)
<i>cgrp</i>	(Optional)
<i>psrc</i>	(Optional)
<i>pgrp</i>	(Optional)
<i>uptime</i>	(Optional)
<i>send_count</i>	(Optional)

Command Mode

- /exec

show ip pim mdt receive

```
show ip pim mdt receive [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
[ <out_context> ] [ TABLE_entry [ <csrc> ] [ <cgrp> ] [ <psrc> ] [ <pgrp> ] [ <uptime> ] [ <expires> ] [
<rcv_count> ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
mdt	Display MDT information
receive	Display Received Data Joins Information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
detail	(Optional) Display detailed information
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>out_context</i>	(Optional)
TABLE_entry	(Optional)
<i>csrc</i>	(Optional)
<i>cgrp</i>	(Optional)
<i>psrc</i>	(Optional)
<i>pgrp</i>	(Optional)
<i>uptime</i>	(Optional)
<i>expires</i>	(Optional)
<i>rcv_count</i>	(Optional)

Command Mode

- /exec

show ip pim mdt send

```
show ip pim mdt send [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<out_context> [ { TABLE_entry <csrc> <cgrp> <psrc> <pgrp> <uptime> <send_count> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
mdt	Display MDT information
send	Display MDT Data Join Send Information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
detail	(Optional) Display detailed information
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>out_context</i>	(Optional)
TABLE_entry	(Optional)
<i>csrc</i>	(Optional)
<i>cgrp</i>	(Optional)
<i>psrc</i>	(Optional)
<i>pgrp</i>	(Optional)
<i>uptime</i>	(Optional)
<i>send_count</i>	(Optional)

Command Mode

- /exec

show ip pim neighbor

```
show ip pim neighbor { [ <interface> ] [ <ipaddr> ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ detail
| internal ] [ __readonly__ [ TABLE_vrf <out-context> [ TABLE_neighbor
<nbr-addr><if-name><uptime><expires> [ <dr-priority> ] <bidir-capable><bfd-state> [
<longest-hello-intvl><non-hello-pkts> ] [ <ecmp-redirect-capable> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
neighbor	Display PIM neighbor related information
<i>interface</i>	(Optional) Display neighbors on single interface name
<i>ipaddr</i>	(Optional) IP address of single neighbor to display
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
detail	(Optional) Display detailed information
internal	(Optional) Commands for internal use
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>out-context</i>	(Optional)
TABLE_neighbor	(Optional)
<i>dr-priority</i>	(Optional)
<i>ecmp-redirect-capable</i>	(Optional)

Command Mode

- /exec

TABLE_timeoutlist	(Optional)
<i>timeoutoif-name</i>	(Optional)
<i>immediate-list-count</i>	(Optional)
TABLE_immediatelist	(Optional)
<i>immediateoif-name</i>	(Optional)
<i>immediate-timeout-list-count</i>	(Optional)
TABLE_immediatetimeoutlist	(Optional)
<i>immediatetimeoutoif-name</i>	(Optional)
<i>sgr-prune-list-count</i>	(Optional)
TABLE_sgrprunelist	(Optional)
<i>sgrprunelistoif-name</i>	(Optional)

Command Mode

- /exec

show ip pim policy statistics

```
show ip pim policy statistics { register-policy | bsr { bsr-policy | rp-candidate-policy } | auto-rp {
rp-candidate-policy | mapping-agent-policy } } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
{ TABLE_routemap <name> <action> <seq_num> [ { TABLE_cmd <command> <match_count>
<compare_count> } ] } <total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	PIM global configuration commands
policy	Policy related information
statistics	Policy statistics
register-policy	Show statistics for register-policy
bsr	Bootstrap protocol RP-distribution policy
bsr-policy	Statistics for filtered BSR messages
rp-candidate-policy	Statistics for filtered RP candidate messages
auto-rp	Statistics for auto-rp messages
rp-candidate-policy	Statistics for filtered RP candidate messages
mapping-agent-policy	Statistics for filtered mapping agent messages
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_routemap	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seq_num</i>	(Optional)
TABLE_cmd	(Optional)
<i>command</i>	(Optional)

<i>compare_count</i>	(Optional)
<i>match_count</i>	(Optional)
<i>total_accept_count</i>	(Optional)
<i>total_reject_count</i>	(Optional)

Command Mode

- /exec

show ip pim policy statistics jp

```
show ip pim policy statistics { jp-policy | neighbor-policy } <interface> [ __readonly__ { TABLE_routemap
<name> <action> <seq_num> [ { TABLE_cmd <command> <match_count> <compare_count> } ] }
<total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	PIM global configuration commands
policy	Policy related information
statistics	Policy statistics
jp-policy	Statistics for jp-policy
neighbor-policy	Statistics for neighbor-policy
<i>interface</i>	Interface to display policy statistics for
<i>__readonly__</i>	(Optional)
TABLE_routemap	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seq_num</i>	(Optional)
TABLE_cmd	(Optional)
<i>command</i>	(Optional)
<i>compare_count</i>	(Optional)
<i>match_count</i>	(Optional)
<i>total_accept_count</i>	(Optional)
<i>total_reject_count</i>	(Optional)

Command Mode

- /exec

show ip pim route

```
show ip pim route [ [ <source> [ <group> ] ] ] [ <group> [ <source> ] ] [ bitfield ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf [ <context-name> ] [ <route-count> ] [
TABLE_one_route [ <mcast-addr> ] [ <rp-addr> ] [ <rp-local> ] [ <bidir> ] [ <sgexpire> ] [ <sgexpire> ]
[ <timeleft> ] [ <rp-bit> ] [ <register> ] [ <intf-name> ] [ <rpf-nbr-1> ] [ <rpf-nbr-addr> ] [ <intf-name-2> ]
[ <rpf-nbr-2> ] [ <uptime> ] [ <is-attached> ] [ <is-static> ] [ <zero-nonpim-oifs> ] [ <is-external> ] [
<otv-decap> ] [ <otv-router-mode> ] [ <non-dr-oifs-only> ] [ <data-created> ] [ <mdt-encap> ] [ <mdt-decap>
] [ <vxlan-decap> ] [ <vxlan-encap> ] [ <sw-pkts> ] [ <sw-bytes> ] [ <hw-pkts> ] [ <hw-bytes> ] [ <rpf-src>
] [ <mrrib-rpf-notify> ] [ <add-pending> ] [ <aged-route> ] [ <sg-expiry-cfg> ] [ <jp-holdtime> ] [
<route-metric-internal> ] [ <metric-pref-internal> ] [ <delay-register-stop> ] [ <register-stop-rcvd> ] [
<lisp-src-rloc> ] [ TABLE_lisp_encap [ <encap-src-rloc> ] [ <encap-dst-rloc> ] [ <timeout-count> ] [
<add-pending> ] [ <del-pending> ] ] [ <oif-count> ] [ <oif-bf-str> ] [ <timeout-count> ] [ <timeout-bf-str> ]
[ <immediate-count> ] [ <immediate-bf-str> ] [ <immediate-timeout-count> ] [ <immediate-timeout-bf-str>
] [ <sgr-prune-list-count> ] [ <sgr-prune-list-bf-str> ] [ <timeout-interval> ] [ <jp-holdtime-rndup> ] [
<mdt-encap-index> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
route	Display PIM specific route information
<i>group</i>	(Optional) Group address to display
<i>source</i>	(Optional) Source address to display
bitfield	(Optional) Display details of each bitfield for PIM route
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>context-name</i>	(Optional)
<i>route-count</i>	(Optional)
TABLE_one_route	(Optional)
<i>mcast-addr</i>	(Optional)
<i>rp-addr</i>	(Optional)

<i>rp-local</i>	(Optional)
<i>bidir</i>	(Optional)
<i>sgexpire</i>	(Optional)
<i>sgrexpire</i>	(Optional)
<i>timeleft</i>	(Optional)
<i>rp-bit</i>	(Optional)
<i>register</i>	(Optional)
<i>intf-name</i>	(Optional)
<i>rpf-nbr-1</i>	(Optional)
<i>rpf-nbr-addr</i>	(Optional)
<i>intf-name-2</i>	(Optional)
<i>rpf-nbr-2</i>	(Optional)
<i>uptime</i>	(Optional)
<i>is-attached</i>	(Optional)
<i>is-static</i>	(Optional)
<i>zero-nonpim-oifs</i>	(Optional)
<i>is-external</i>	(Optional)
<i>otv-decap</i>	(Optional)
<i>otv-router-mode</i>	(Optional)
<i>non-dr-oifs-only</i>	(Optional)
<i>data-created</i>	(Optional)
<i>mdt-encap</i>	(Optional)
<i>mdt-decap</i>	(Optional)
<i>vxlan-decap</i>	(Optional)
<i>vxlan-encap</i>	(Optional)
<i>sw-pkts</i>	(Optional)
<i>sw-bytes</i>	(Optional)
<i>hw-pkts</i>	(Optional)
<i>hw-bytes</i>	(Optional)

<i>rpf-src</i>	(Optional)
<i>mrib-rpf-notify</i>	(Optional)
<i>add-pending</i>	(Optional)
<i>aged-route</i>	(Optional)
<i>sg-expiry-cfg</i>	(Optional)
<i>jp-holdtime</i>	(Optional)
<i>route-metric-internal</i>	(Optional)
<i>metric-pref-internal</i>	(Optional)
<i>delay-register-stop</i>	(Optional)
<i>register-stop-rcvd</i>	(Optional)
<i>lisp-src-rloc</i>	(Optional)
TABLE_lisp_encap	(Optional)
<i>encap-src-rloc</i>	(Optional)
<i>encap-dst-rloc</i>	(Optional)
<i>timeout-count</i>	(Optional)
<i>add-pending</i>	(Optional)
<i>del-pending</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>oif-bf-str</i>	(Optional)
<i>timeout-count</i>	(Optional)
<i>timeout-bf-str</i>	(Optional)
<i>immediate-count</i>	(Optional)
<i>immediate-bf-str</i>	(Optional)
<i>immediate-timeout-count</i>	(Optional)
<i>immediate-timeout-bf-str</i>	(Optional)
<i>sgr-prune-list-count</i>	(Optional)
<i>sgr-prune-list-bf-str</i>	(Optional)
<i>timeout-interval</i>	(Optional)
<i>jp-holdtime-rndup</i>	(Optional)

<i>mdt-encap-index</i>	(Optional)
------------------------	------------

Command Mode

- /exec

show ip pim rp-hash

```
show ip pim rp-hash <group> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ <out-context>
[ <rp-found> ] [ <is-rp-bsr-learnt> ] [ <out-group1> <rp-addr1> ] [ <out-group> <hash-length> <out-bsr> ]
[ { TABLE_rp <rp-addr> <hash> <isbest_hash> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
rp-hash	Display RP hash value for group
<i>group</i>	Group address for RP lookup
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
<i>out-context</i>	(Optional)
<i>rp-found</i>	(Optional)
<i>is-rp-bsr-learnt</i>	(Optional)
<i>out-group1</i>	(Optional)
<i>rp-addr1</i>	(Optional)
<i>out-group</i>	(Optional)
<i>hash-length</i>	(Optional)
<i>out-bsr</i>	(Optional)
TABLE_rp	(Optional)
<i>rp-addr</i>	(Optional)
<i>hash</i>	(Optional)
<i>isbest_hash</i>	(Optional)

Command Mode

- /exec

show ip pim rp

```
show ip pim rp [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [ __readonly__ [
TABLE_vrf <out-context> ] [ <is-bsr-enabled> ] [ <is-bsr-listen-only> ] [ <is-bsr-forward-only> ] [ <bsr-address>
] [ <is-bsr-local> ] [ <bs-timer> ] [ <bsr-uptime> ] [ <bsr-expires> ] [ <bsr-priority> ] [ <bsr-hash-masklen>
] [ <is-autorp-enabled> ] [ <is-autorp-listen-only> ] [ <is-autorp-forward-only> ] [ <auto-rp-addr> ] [
<is-autorp-local> ] [ <autorp-dis-timer> ] [ <autorp-cand-address> ] [ <autorp-up-time> ] [ <autorp-expire-time>
] [ <rp-cand-policy-name> ] [ <bsr-policy-name> ] [ <rp-announce-policy-name> ] [
<rp-discovery-policy-name> ] [ TABLE_anycast_rp <anycast-rp-addr> [ TABLE_arp_rp <arp-rp-addr>
<is-rpaddr-local> ] ] [ TABLE_rp [ <rp-addr> ] [ <is-rp-local> ] [ <df-ordinal> ] [ <rp-uptime> ] [ <rp-priority>
] [ <is_autorp_source> ] [ <is_bsr_source> ] [ <is_static_source> ] [ <rp-source> ] [ <static-rp-group-map>
] [ TABLE_grange [ <grange-grp> ] [ <grange-masklen> ] [ <grange-is-deny> ] [ <is-bidir-grp> ] [
<autorp-expires> ] [ <bsr-rp-expires> ] [ <rp-owner-flags> ] ] [ [ <bidir-ordinal> ] [ <df-bits-recovered> ] [
<rp-nbr-address> ] [ <metric> ] [ <metric-preference> ] ] ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
rp	Display PIM RP, Auto-RP, and BSR related information
<i>group</i>	(Optional) Display RP for group address
internal	(Optional) Commands for internal use
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional)
<i>out-context</i>	(Optional)
<i>is-bsr-enabled</i>	(Optional)
<i>is-bsr-listen-only</i>	(Optional)
<i>is-bsr-forward-only</i>	(Optional)
<i>bsr-address</i>	(Optional)
<i>is-bsr-local</i>	(Optional)
<i>bsr-priority</i>	(Optional)

<i>bsr-hash-masklen</i>	(Optional)
<i>bs-timer</i>	(Optional)
<i>bsr-uptime</i>	(Optional)
<i>bsr-expires</i>	(Optional)
<i>is-autorp-enabled</i>	(Optional)
<i>is-autorp-listen-only</i>	(Optional)
<i>is-autorp-forward-only</i>	(Optional)
<i>auto-rp-addr</i>	(Optional)
<i>autorp-cand-address</i>	(Optional)
<i>is-autorp-local</i>	(Optional)
<i>autorp-dis-timer</i>	(Optional)
<i>autorp-up-time</i>	(Optional)
<i>autorp-expire-time</i>	(Optional)
<i>rp-cand-policy-name</i>	(Optional)
<i>bsr-policy-name</i>	(Optional)
<i>rp-announce-policy-name</i>	(Optional)
<i>rp-discovery-policy-name</i>	(Optional)
TABLE_anycast_rp	(Optional)
<i>anycast-rp-addr</i>	(Optional)
TABLE_arp_rp	(Optional)
<i>arp-rp-addr</i>	(Optional)
<i>is-rpaddr-local</i>	(Optional)
TABLE_rp	(Optional)
<i>rp-addr</i>	(Optional)
<i>is-rp-local</i>	(Optional)
<i>df-ordinal</i>	(Optional)
<i>rp-uptime</i>	(Optional)
<i>rp-priority</i>	(Optional)
<i>is_autorp_source</i>	(Optional)

<i>is_bsr_source</i>	(Optional)
<i>is_static_source</i>	(Optional)
<i>rp-source</i>	(Optional)
<i>static-rp-group-map</i>	(Optional)
TABLE_ <i>grange</i>	(Optional)
<i>grange-grp</i>	(Optional)
<i>grange-masklen</i>	(Optional)
<i>grange-is-deny</i>	(Optional)
<i>is-bidir-grp</i>	(Optional)
<i>autorp-expires</i>	(Optional)
<i>bsr-rp-expires</i>	(Optional)
<i>rp-owner-flags</i>	(Optional)
<i>bidir-ordinal</i>	(Optional)
<i>df-bits-recovered</i>	(Optional)
<i>rpf-nbr-address</i>	(Optional)
<i>metric</i>	(Optional)
<i>metric-preference</i>	(Optional)

Command Mode

- /exec

show ip pim statistics

```
show ip pim statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <vrf-name>
[ <uptime> <reg-sent> <reg-rcvd> <null-reg-sent> <null-reg-rcvd> <reg-stop-sent> <reg-stop-rcvd>
<reg-rcvd-not-rp> <reg-rcvd-for-ssm> <reg-rcvd-for-bidir> <bootstrap-sent> <bootstrap-rcvd> <cand-rp-sent>
<cand-rp-rcvd> <bs-no-nbr> <bs-border-deny> <bs-len-errors> <bs-rpf-failed> <bs-no-listen>
<candrp-border-deny> <candrp-no-listen> <autorp-announce-sent> <autorp-announce-rcvd>
<autorp-discovery-sent> <autorp-discovery-rcvd> <autorp-rpf-failed> <autorp-border-deny>
<autorp-invalid-type> <autorp-ttl-expired> <autorp-no-listen> <ctrl-no-route> <data-no-route> <no-state>
<create-state> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
statistics	Packet counter statistics
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
<i>uptime</i>	(Optional)
<i>reg-sent</i>	(Optional)
<i>reg-rcvd</i>	(Optional)
<i>null-reg-sent</i>	(Optional)
<i>null-reg-rcvd</i>	(Optional)
<i>reg-stop-sent</i>	(Optional)
<i>reg-stop-rcvd</i>	(Optional)
<i>reg-rcvd-not-rp</i>	(Optional)
<i>reg-rcvd-for-ssm</i>	(Optional)
<i>reg-rcvd-for-bidir</i>	(Optional)

<i>bootstrap-sent</i>	(Optional)
<i>bootstrap-rcvd</i>	(Optional)
<i>cand-rp-sent</i>	(Optional)
<i>cand-rp-rcvd</i>	(Optional)
<i>bs-no-nbr</i>	(Optional)
<i>bs-border-deny</i>	(Optional)
<i>bs-len-errors</i>	(Optional)
<i>bs-rpf-failed</i>	(Optional)
<i>bs-no-listen</i>	(Optional)
<i>candrp-border-deny</i>	(Optional)
<i>candrp-no-listen</i>	(Optional)
<i>autorp-announce-sent</i>	(Optional)
<i>autorp-announce-rcvd</i>	(Optional)
<i>autorp-discovery-sent</i>	(Optional)
<i>autorp-discovery-rcvd</i>	(Optional)
<i>autorp-rpf-failed</i>	(Optional)
<i>autorp-border-deny</i>	(Optional)
<i>autorp-invalid-type</i>	(Optional)
<i>autorp-ttl-expired</i>	(Optional)
<i>autorp-no-listen</i>	(Optional)
<i>ctrl-no-route</i>	(Optional)
<i>data-no-route</i>	(Optional)
<i>no-state</i>	(Optional)
<i>create-state</i>	(Optional)

Command Mode

- /exec

show ip pim vrf

```
show ip pim vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ detail | internal ] [ __readonly__ {
TABLE_context <out-context> <context-id> <count> <table-id> <bfd> <mvpn> } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
pim	Display PIM status and configuration
vrf	Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs PIM is configured for
detail	(Optional) Display detailed information
internal	(Optional) VRF related internal information
__readonly__	(Optional)
TABLE_context	(Optional)
<i>out-context</i>	(Optional)
<i>context-id</i>	(Optional)
<i>table-id</i>	(Optional)
<i>count</i>	(Optional)
<i>bfd</i>	(Optional)
<i>mvpn</i>	(Optional)

Command Mode

- /exec

show ip ping source-interface

```
show ip ping source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ippingvrf
<vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ping	Display ping client information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ippingvrf	(Optional) source interface of ping
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip ping source-interface vrf all

```
show ip ping source-interface vrf all [ __readonly__ [ { TABLE_ipping <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ping	Display ping client information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_ipping	(Optional) source interface of ping
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip policy

```
show ip policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ detail ] [ __readonly__ { TABLE_pbr [ <interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
policy	Policy routing
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_pbr	(Optional)
<i>interface</i>	(Optional)
<i>rmap</i>	(Optional)
<i>status</i>	(Optional)
<i>vrf_name</i>	(Optional)

Command Mode

- /exec

show ip prefix-list

```
show ip prefix-list { { [ detail | summary ] [ <ipv4-pfl-name> | <ipv4-pfl-cfg-name> ] } | { { <ipv4-pfl-name>
| <ipv4-pfl-cfg-name> } seq <seq-no> } | { { <ipv4-pfl-name> | <ipv4-pfl-cfg-name> } <prefix> [ first-match
| longer ] } } [ __readonly__ TABLE_ip_pfl <name> <seq> <action> <rule> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
detail	(Optional) Show detailed information
summary	(Optional) Show summarized information
prefix-list	List IP prefix lists
<i>ipv4-pfl-name</i>	(Optional) Name of prefix-list
<i>ipv4-pfl-cfg-name</i>	(Optional) Known prefix-list name
seq	Sequence number
<i>seq-no</i>	Sequence number
<i>prefix</i>	IP prefix network/length, e.g., 35.0.0.0/8
first-match	(Optional) Find the first match
longer	(Optional) Find the more specific entries
<i>__readonly__</i>	(Optional)
TABLE_ip_pfl	(Optional)
<i>name</i>	(Optional)
<i>seq</i>	(Optional)
<i>action</i>	(Optional)
<i>rule</i>	(Optional)

Command Mode

- /exec

show ip process

```
show ip process [ api ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_ip_pro_vrf
[ { <pro-cntxt-name> <pro-cntxt-id> <pro-base-tid> <pro-auto-disc> <pro-atuo-add> <pro-null-bcast>
<auto-punt-bcast> <static-disc> <static-def-route> <ip-unreach> } ] [ TABLE_pro_api [ <api-vrf>
<api-cntxt-id> <api-base-tid> <api-ip-addr> <api-rtr-id-iod> ] ] [ TABLE_iod [ { <entry-iod> } ] ] [
TABLE_local_addr [ { <local-addr> } ] ] ] [ TABLE_ip_pro_all { <all-pro-cntxt-name> <all-pro-cntxt-id>
} ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
process	Display IP global information
api	(Optional) Show api values
vrf	(Optional) Display per-VRF information
all	(Optional) Display all VRFs
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ip_pro_vrf	(Optional)
<i>pro-cntxt-name</i>	(Optional)
<i>pro-cntxt-id</i>	(Optional)
<i>pro-base-tid</i>	(Optional)
<i>pro-auto-disc</i>	(Optional)
<i>pro-atuo-add</i>	(Optional)
<i>pro-null-bcast</i>	(Optional)
<i>auto-punt-bcast</i>	(Optional)
<i>static-disc</i>	(Optional)
<i>static-def-route</i>	(Optional)
<i>ip-unreach</i>	(Optional)
TABLE_pro_api	(Optional)
<i>api-vrf</i>	(Optional)

<i>api-cntxt-id</i>	(Optional)
<i>api-base-tid</i>	(Optional)
<i>api-ip-addr</i>	(Optional)
<i>api-rtr-id-iod</i>	(Optional)
TABLE_iod	(Optional)
<i>entry-iod</i>	(Optional)
TABLE_local_addr	(Optional)
<i>local-addr</i>	(Optional)
TABLE_ip_pro_all	(Optional)
<i>all-pro-cntxt-name</i>	(Optional)
<i>all-pro-cntxt-id</i>	(Optional)

Command Mode

- /exec

show ip rip

```
show { ipv6 | ip } rip [ instance <inst> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_inst <inst-name> TABLE_vrf <vrf> <port> <mcast-grp> <admin-dist> <update-tmr> <expire-tmr>
<garbage-tmr> <def-metric> <max-paths> <def-rt-distrib> <def-distrib-always> <process-disabled>
<out-of-mem> [ TABLE_afi <afi> { TABLE_interface <if-name> } TABLE_redistrib <redistributing> {
TABLE_clients <pibname> <policy> } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
ip	Display IP information
rip	Display RIP routing protocol status
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<u>__readonly__</u>	(Optional)
TABLE_inst	(Optional)
<i>inst-name</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>port</i>	(Optional)
<i>mcast-grp</i>	(Optional)
<i>admin-dist</i>	(Optional)
<i>update-tmr</i>	(Optional)
<i>expire-tmr</i>	(Optional)
<i>garbage-tmr</i>	(Optional)
<i>def-metric</i>	(Optional)
<i>max-paths</i>	(Optional)

<i>def-rt-distrib</i>	(Optional)
<i>def-distrib-always</i>	(Optional)
<i>process-disabled</i>	(Optional)
<i>out-of-mem</i>	(Optional)
TABLE_afi	(Optional)
<i>af</i>	(Optional)
TABLE_interface	(Optional)
<i>if-name</i>	(Optional)
TABLE_redistrib	(Optional)
<i>redistributing</i>	(Optional)
TABLE_clients	(Optional)
<i>pibname</i>	(Optional)
<i>policy</i>	(Optional)

Command Mode

- /exec

show ip rip interface

```
show { ipv6 | ip } rip [ instance <inst> ] interface [ <interface> ] [ detail ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_inst <inst-name> TABLE_vrf <vrf> [ TABLE_inter
<if-name> <if-status> <protocol-up> <local-only> <no-addr-conf> <if-addr> <if-mask> <if-metric>
<poison-reverse> <if-passive> <route-dist-filter> <in-policy> <out-policy> [ { TABLE_auth <auth-ena>
<auth-type> <auth-keychain> } ] [ TABLE_detail <import-routes> <periodic-updates> <trigger-updates>
<out-mcast-request> <out-ucast-update> <out-ucast-request> <in-mcast-update> <in-mcast-request>
<in-ucast-update> <in-ucast-request> <bad-pkt> <bad-route> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
ip	Display IP information
rip	Display RIP routing protocol status
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
interface	RIP interface
<i>interface</i>	(Optional) RIP interface
detail	(Optional) Detailed information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_inst	(Optional)
<i>inst-name</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
TABLE_inter	(Optional)
<i>if-name</i>	(Optional)
<i>if-status</i>	(Optional)
<i>protocol-up</i>	(Optional)

<i>local-only</i>	(Optional)
<i>no-addr-conf</i>	(Optional)
<i>if-addr</i>	(Optional)
<i>if-mask</i>	(Optional)
<i>if-metric</i>	(Optional)
<i>poison-reverse</i>	(Optional)
<i>if-passive</i>	(Optional)
<i>route-dist-filter</i>	(Optional)
<i>in-policy</i>	(Optional)
<i>out-policy</i>	(Optional)
TABLE_auth	(Optional)
<i>auth-ena</i>	(Optional)
<i>auth-type</i>	(Optional)
<i>auth-keychain</i>	(Optional)
TABLE_detail	(Optional)
<i>import-routes</i>	(Optional)
<i>periodic-updates</i>	(Optional)
<i>trigger-updates</i>	(Optional)
<i>out-mcast-request</i>	(Optional)
<i>out-ucast-update</i>	(Optional)
<i>out-ucast-request</i>	(Optional)
<i>in-mcast-update</i>	(Optional)
<i>in-mcast-request</i>	(Optional)
<i>in-ucast-update</i>	(Optional)
<i>in-ucast-request</i>	(Optional)
<i>bad-pkt</i>	(Optional)
<i>bad-route</i>	(Optional)

Command Mode

- /exec

show ip rip neighbor

```
show { ipv6 | ip } rip [ instance <inst> ] neighbor [ <interface> ] [ vrf { <vrf-name> | <vrf-known-name> |
all } ] [ __readonly__ TABLE_inst <inst-name> TABLE_vrf <vrf> <numberof-adj> <dead-timer-seconds>
{ TABLE_adj <adj-addr> <if-name> <last-response-sent> <last-response-rcvd> <last-request-sent>
<last-request-rcvd> <last-response-sent-state> <last-response-rcvd-state> <last-request-sent-state>
<last-request-rcvd-state> <in-bad-packets> <in-bad-routes> } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
ip	Display IP information
rip	Display RIP status and configuration
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
neighbor	RIP neighbor
<i>interface</i>	(Optional) RIP interface
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_inst	(Optional)
<i>inst-name</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>numberof-adj</i>	(Optional)
<i>dead-timer-seconds</i>	(Optional)
TABLE_adj	(Optional)
<i>adj-addr</i>	(Optional)
<i>if-name</i>	(Optional)
<i>last-response-sent-state</i>	(Optional)

<i>last-response-sent</i>	(Optional)
<i>last-response-rcvd-state</i>	(Optional)
<i>last-response-rcvd</i>	(Optional)
<i>last-request-sent-state</i>	(Optional)
<i>last-request-sent</i>	(Optional)
<i>last-request-rcvd-state</i>	(Optional)
<i>last-request-rcvd</i>	(Optional)
<i>in-bad-packets</i>	(Optional)
<i>in-bad-routes</i>	(Optional)

Command Mode

- /exec

show ip rip policy statistics redistribute

```
show ip rip [ instance <inst> ] policy statistics redistribute { bgp <as> | { eigrp | isis | <src-rip> | ospf } <tag>
| direct | static } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_asn <asn> TABLE_vrf
<vrf> { TABLE_rmap <name> <action> <seq_num> [ { TABLE_cmd <command> <compare_count>
<match_count> } ] } <total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ip	Display IP information
rip	Display RIP routing protocol status
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
policy	Policy related information
statistics	Policy statistics
redistribute	RIP redistribute routes from other routing protocol
bgp	Border Gateway Protocol (BGP)
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
<i>as</i>	Autonomous system number
isis	Intermediate-to-intermediate (ISIS)
src-rip	Routing Information Protocol (RIP)
ospf	Open Shortest Path First (OSPFv2)
<i>tag</i>	Process tag
direct	Directly connected routes
static	Static routes
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_asn	(Optional) AS number table

<i>asn</i>	(Optional) AS number
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
TABLE_rmap	(Optional) Routemap table
<i>name</i>	(Optional) Route-map Name
<i>action</i>	(Optional) Route-map action
<i>seq_num</i>	(Optional) Sequence number of the rule in route-map
TABLE_cmd	(Optional) Route-map command table
<i>command</i>	(Optional) Route-map command
<i>compare_count</i>	(Optional) Number of comparisons
<i>match_count</i>	(Optional) Number of matches
<i>total_accept_count</i>	(Optional) Total number of packets accepted by the policy
<i>total_reject_count</i>	(Optional) Total number of packets rejected by the policy

Command Mode

- /exec

show ip rip route

```
show { ipv6 | ip } rip [ instance <inst> ] route [ { <ipv6-prefix> | <ip-prefix> } [ { longer-prefixes |
shorter-prefixes } ] ] [ summary ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_inst
<inst-name> TABLE_vrf <vrf> [ { TABLE_route <best-route> <rt-prefix> <rt-mask> <rt-numnh> {
TABLE_nexthop <nh-direct> <nh-redistrib> <nh-addr> <nh-interface> <nh-metric> <nh-tag> <nh-state>
<nh-state-timer> } } ] [ { TABLE_summary <is-summary> <total-num-rts> <total-best-rts> <total-paths> {
TABLE_rtspermask <mask-length> <rts-per-mask> } } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
ip	Display IP information
rip	Display RIP routing protocol status
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
route	RIP routes
summary	(Optional) route counts
<i>ip-prefix</i>	(Optional) Exact prefix
longer-prefixes	(Optional) exact match and more specific routes
shorter-prefixes	(Optional) exact match and less specific routes
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_inst	(Optional)
<i>inst-name</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
TABLE_route	(Optional)
<i>best-route</i>	(Optional)

<i>rt-prefix</i>	(Optional)
<i>rt-mask</i>	(Optional)
<i>rt-numnh</i>	(Optional)
TABLE_nexthop	(Optional)
<i>nh-direct</i>	(Optional)
<i>nh-redistrib</i>	(Optional)
<i>nh-addr</i>	(Optional)
<i>nh-interface</i>	(Optional)
<i>nh-metric</i>	(Optional)
<i>nh-tag</i>	(Optional)
<i>nh-state</i>	(Optional)
<i>nh-state-timer</i>	(Optional)
TABLE_summary	(Optional)
<i>is-summary</i>	(Optional)
<i>total-num-rts</i>	(Optional)
<i>total-best-rts</i>	(Optional)
<i>total-paths</i>	(Optional)
TABLE_rtspermask	(Optional)
<i>mask-length</i>	(Optional)
<i>rts-per-mask</i>	(Optional)

Command Mode

- /exec

show ip rip statistics

```
show { ipv6 | ip } rip [ instance <inst> ] statistics [ * | <interface> ] [ __readonly__ TABLE_inst <inst-name>
TABLE_interface <if-name> <periodic-updates> <trigger-updates> <out-mcast-request> <out-ucast-update>
<out-ucast-request> <in-mcast-update> <in-mcast-request> <in-ucast-update> <in-ucast-request> <bad-pkt>
<bad-route> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
ip	Display IP information
rip	Display RIP status and configuration
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
statistics	RIP statistics
<i>interface</i>	(Optional) RIP interface
*	(Optional) RIP statistics for all interfaces
__readonly__	(Optional)
TABLE_inst	(Optional)
<i>inst-name</i>	(Optional)
TABLE_interface	(Optional)
<i>if-name</i>	(Optional)
<i>periodic-updates</i>	(Optional)
<i>trigger-updates</i>	(Optional)
<i>out-mcast-request</i>	(Optional)
<i>out-ucast-update</i>	(Optional)
<i>out-ucast-request</i>	(Optional)
<i>in-mcast-update</i>	(Optional)
<i>in-mcast-request</i>	(Optional)
<i>in-ucast-update</i>	(Optional)
<i>in-ucast-request</i>	(Optional)

<i>bad-pkt</i>	(Optional)
<i>bad-route</i>	(Optional)

Command Mode

- /exec

show ip route

```
show ip route [ ip | ipv4 ] [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ip-addr> | {
<ip-prefix> [ { longer-prefixes | shorter-prefixes } ] ] [ { <protocol> [ all ] } | { bind-label <bind-lbl> |
next-hop <next-hop> | next-hop-v6 <next-hop-v6> } | { interface <interface> } | { updated { [ since <stime>
] [ until <utime> ] } } ] + [ summary | detail ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [
__readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [ TABLE_prefix <ipprefix> <ucast-nhops>
<mcast-nhops> <attached> TABLE_path [ <ipnexthop> ] [ <ifname> ] [ <bindlbl> ] <uptime> <pref> <metric>
<clientname> [ <type> ] [ <tag> ] [ <stale> ] [ <unres> ] [ <hidden> ] [ <stale-label> ] [ <bgpbackuppath> ]
[ <ubest> ] [ <mbest> ] ] [ TABLE_summary <routes> <paths> [ <multicast_paths> ] [ TABLE_unicast [
<clientnameuni> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_multicast [ <clientnamemulti> ] [
<best-paths> ] [ <backup-paths> ] ] [ TABLE_route_count [ <mask_len> ] [ <count> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
route	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
l3vm-info	(Optional) Display corresponding L3VM information
rpf	(Optional) Display RPF information for multicast source
<i>ip-addr</i>	(Optional) Display single route longest match lookup
<i>ip-prefix</i>	(Optional) Display single exact match route
longer-prefixes	(Optional) Display matching routes with mask-lengths \geq prefix
shorter-prefixes	(Optional) Display matching routes with mask-lengths \leq prefix
<i>protocol</i>	(Optional) Display routes for protocol (or route type)
all	(Optional) Display routes for protocol for backup next-hops too
bind-label	(Optional) Display routes with this bind-label only

<i>bind-lbl</i>	(Optional) Binding label
<i>next-hop</i>	(Optional) Display routes with this next-hop only
<i>next-hop</i>	(Optional) Next hop address
<i>next-hop-v6</i>	(Optional) Display routes with this V6 next-hop only
<i>interface</i>	(Optional) Display routes with this output interface only
<i>interface</i>	(Optional) Interface Name
<i>updated</i>	(Optional) Display routes filtered by last updated time
<i>since</i>	(Optional) Display those routes updated since this time
<i>stime</i>	(Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>until</i>	(Optional) Display those routes updated until this time
<i>utime</i>	(Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>summary</i>	(Optional) Display route counts
<i>detail</i>	(Optional) Display routes in full detail
<i>__readonly__</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>TABLE_addrf</i>	(Optional)
<i>addrf</i>	(Optional)
<i>TABLE_prefix</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>ucast-nhops</i>	(Optional)
<i>mcast-nhops</i>	(Optional)
<i>attached</i>	(Optional)
<i>TABLE_path</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>ifname</i>	(Optional)
<i>bindlbl</i>	(Optional)
<i>uptime</i>	(Optional)
<i>pref</i>	(Optional)

<i>metric</i>	(Optional)
<i>clientname</i>	(Optional)
<i>type</i>	(Optional)
<i>tag</i>	(Optional)
<i>stale</i>	(Optional)
<i>unres</i>	(Optional)
<i>hidden</i>	(Optional)
<i>stale-label</i>	(Optional)
<i>bgpbackuppath</i>	(Optional)
<i>ubest</i>	(Optional)
<i>mbest</i>	(Optional)
TABLE_summary	(Optional)
<i>routes</i>	(Optional)
<i>paths</i>	(Optional)
<i>multicast_paths</i>	(Optional)
TABLE_unicast	(Optional)
<i>clientnameuni</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_multicast	(Optional)
<i>clientnamemulti</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_route_count	(Optional)
<i>mask_len</i>	(Optional)
<i>count</i>	(Optional)

Command Mode

- /exec

show ip sla application

```
show ip sla application [ __readonly__ <version> [ <line-length> ] <type-name> <feature-name>
<lowmemorymark> <max-entries> <probe-cap> <entries-config> <entries-active> <entries-pending>
<entries-inactive> <last-change-time> <rttMonApplReset> [ <rttMonApplTimeOfLastSet> ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
application	IP SLAs Application
<i>__readonly__</i>	(Optional)
<i>version</i>	(Optional)
<i>line-length</i>	(Optional)
<i>type-name</i>	(Optional)
<i>feature-name</i>	(Optional)
<i>lowmemorymark</i>	(Optional)
<i>max-entries</i>	(Optional)
<i>probe-cap</i>	(Optional)
<i>entries-config</i>	(Optional)
<i>entries-active</i>	(Optional)
<i>entries-pending</i>	(Optional)
<i>entries-inactive</i>	(Optional)
<i>last-change-time</i>	(Optional)
<i>rttMonApplReset</i>	(Optional) Appl Reset
<i>rttMonApplTimeOfLastSet</i>	(Optional)

Command Mode

- /exec

show ip sla configuration

```
show ip sla configuration [ <entry-num> ] [ __readonly__ { TABLE_configuration [ <index> ] [ <owner> ]
[ <tag> ] [ <timeout> ] [ <oper-type> ] [ <dest-ip> ] [ <source-int> ] [ <source-ip> ] [ <dest-port> ] [
<source-port> ] [ <dns-source-port> ] [ <traffic-class> ] [ <tos> ] [ <dns-name-server> ] [ <flow-label> ] [
<data-pattern> ] [ <switch-id> ] [ <profile-id> ] [ <interface> ] [ <packet-size> ] [ <packet-interval> ] [
<num-packets> ] [ <codec-type> ] [ <codec-num-packets> ] [ <codec-packet-size> ] [ <codec-packet-interval>
] [ <codec-adv-factor> ] [ <verify-data> ] [ <precision> ] [ <packet-priority> ] [ <ntp-sync-tolerance> ] [
<ntp-sync-to-type> ] [ <vrf-name> ] [ <control-enabled> ] [ <http-oper> ] [ <http-version> ] [ <url> ] [ <proxy>
] [ <raw-strings> ] [ <cache-control> ] [ <http-vrf-name> ] [ <http-owner> ] [ <http-tag> ] [ <http-timeout>
] [ <frequency> ] [ <secondary-freq-timeout> ] [ <secondary-freq-loss> ] [ <next-start-time> ] [
<group-scheduled> ] [ <randomly-scheduled> ] [ <low-frequency> ] [ <high-frequency> ] [ <life> ] [ <ageout>
] [ <recurring> ] [ <status-of-entry> ] [ <threshold> ] [ <hours> ] [ <buckets> ] [ <interval> ] [ <einterval> ]
[ <ebuckets> ] [ <lives> ] [ <hsbuckets> ] [ <filter> ] } ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
configuration	IP SLA configuration
<i>entry-num</i>	(Optional) Entry Number
<i>__readonly__</i>	(Optional)
TABLE_configuration	(Optional) show ip sla configuration information
<i>index</i>	(Optional)
<i>owner</i>	(Optional)
<i>tag</i>	(Optional)
<i>timeout</i>	(Optional)
<i>oper-type</i>	(Optional)
<i>dest-ip</i>	(Optional)
<i>source-int</i>	(Optional)
<i>source-ip</i>	(Optional)
<i>dest-port</i>	(Optional)
<i>source-port</i>	(Optional)
<i>dns-source-port</i>	(Optional)
<i>traffic-class</i>	(Optional)

<i>tos</i>	(Optional)
<i>dns-name-server</i>	(Optional)
<i>flow-label</i>	(Optional)
<i>data-pattern</i>	(Optional)
<i>profile-id</i>	(Optional)
<i>switch-id</i>	(Optional)
<i>interface</i>	(Optional)
<i>packet-size</i>	(Optional)
<i>packet-interval</i>	(Optional)
<i>num-packets</i>	(Optional)
<i>codec-type</i>	(Optional)
<i>codec-num-packets</i>	(Optional)
<i>codec-packet-size</i>	(Optional)
<i>codec-packet-interval</i>	(Optional)
<i>codec-adv-factor</i>	(Optional)
<i>verify-data</i>	(Optional)
<i>precision</i>	(Optional)
<i>packet-priority</i>	(Optional)
<i>ntp-sync-tolerance</i>	(Optional)
<i>ntp-sync-toctype</i>	(Optional)
<i>vrf-name</i>	(Optional)
<i>control-enabled</i>	(Optional)
<i>http-oper</i>	(Optional)
<i>http-version</i>	(Optional)
<i>url</i>	(Optional)
<i>proxy</i>	(Optional)
<i>raw-strings</i>	(Optional)
<i>cache-control</i>	(Optional)
<i>http-vrf-name</i>	(Optional)

<i>http-owner</i>	(Optional)
<i>http-tag</i>	(Optional)
<i>http-timeout</i>	(Optional)
<i>frequency</i>	(Optional)
<i>secondary-freq-timeout</i>	(Optional)
<i>secondary-freq-loss</i>	(Optional)
<i>next-start-time</i>	(Optional)
<i>group-scheduled</i>	(Optional)
<i>randomly-scheduled</i>	(Optional)
<i>low-frequency</i>	(Optional)
<i>high-frequency</i>	(Optional)
<i>life</i>	(Optional)
<i>ageout</i>	(Optional)
<i>recurring</i>	(Optional)
<i>status-of-entry</i>	(Optional)
<i>threshold</i>	(Optional)
<i>hours</i>	(Optional)
<i>buckets</i>	(Optional)
<i>interval</i>	(Optional)
<i>einterval</i>	(Optional)
<i>ebuckets</i>	(Optional)
<i>lives</i>	(Optional)
<i>hsbuckets</i>	(Optional)
<i>filter</i>	(Optional)

Command Mode

- /exec

show ip sla enhanced-history collection-statistics

```
show ip sla enhanced-history collection-statistics [ <operation-number> [ interval <interval-in-secs> ] ] [
__readonly__ [ { TABLE_generic [ <entry-num> ] [ <aggregate-interval> ] [ { TABLE_bkt [ <bkt-index> ]
[ <agg-sti> ] [ <tgt-addr> ] [ <oper-type> ] [ <nofod> ] [ <nofot> ] [ <nofob> ] [ <nofonc> ] [ <nofoie> ] [
<nofose> ] [ <nofove> ] [ <ntp-state> ] [ <icpif> ] [ <mos-score> ] [ <rtt-values> ] [ <num-rtt> ] [ <rtt-avg>
] [ <rtt-min> ] [ <rtt-max> ] [ <rtt-sum> ] [ <rtt-sum2> ] [ <num-out-sync-rtt> ] [ <plsd> ] [ <plds> ] [ <pos>
] [ <pl-mia> ] [ <pla> ] [ <int-err> ] [ <busies> ] [ <pkt-skipped> ] [ <jitter-value-precision> ] [ <min-pos-sd>
] [ <max-pos-sd> ] [ <num-pos-sd> ] [ <sum-pos-sd> ] [ <sum2-pos-sd> ] [ <min-neg-sd> ] [ <max-neg-sd>
] [ <num-neg-sd> ] [ <sum-neg-sd> ] [ <sum2-neg-sd> ] [ <min-pos-ds> ] [ <max-pos-ds> ] [ <num-pos-ds>
] [ <sum-pos-ds> ] [ <sum2-pos-ds> ] [ <min-neg-ds> ] [ <max-neg-ds> ] [ <num-neg-ds> ] [ <sum-neg-ds>
] [ <sum2-neg-ds> ] [ <jitter-avg> ] [ <jitter-sd-avg> ] [ <jitter-ds-avg> ] [ <inter-jit-out> ] [ <inter-jit-in> ]
[ <ow-precision> ] [ <num-ow> ] [ <ow-min-sd> ] [ <ow-max-sd> ] [ <ow-sum-sd> ] [ <ow-sum2-sd> ] [
<ow-min-ds> ] [ <ow-max-ds> ] [ <ow-sum-ds> ] [ <ow-sum2-ds> ] [ <avg-ow-sd> ] [ <avg-ow-ds> ] } ] [
<outstring> ] } ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
enhanced-history	IP SLAs Enhanced History
collection-statistics	IP SLAs Collection Statistics
<i>operation-number</i>	(Optional) Entry Number
interval	(Optional) Aggregation Interval
<i>interval-in-secs</i>	(Optional) Interval in seconds
<i>__readonly__</i>	(Optional)
TABLE_generic	(Optional) Show History Information
<i>entry-num</i>	(Optional)
<i>aggregate-interval</i>	(Optional)
TABLE_bkt	(Optional) Show bucket History Information
<i>bkt-index</i>	(Optional)
<i>agg-sti</i>	(Optional)
<i>tgt-addr</i>	(Optional)
<i>oper-type</i>	(Optional)
<i>nofod</i>	(Optional)

<i>nofot</i>	(Optional)
<i>nofob</i>	(Optional)
<i>nofonc</i>	(Optional)
<i>nofoie</i>	(Optional)
<i>nofose</i>	(Optional)
<i>nofove</i>	(Optional)
<i>ntp-state</i>	(Optional)
<i>icpif</i>	(Optional)
<i>mos-score</i>	(Optional)
<i>rtt-values</i>	(Optional)
<i>num-rtt</i>	(Optional)
<i>rtt-avg</i>	(Optional)
<i>rtt-min</i>	(Optional)
<i>rtt-max</i>	(Optional)
<i>rtt-sum</i>	(Optional)
<i>rtt-sum2</i>	(Optional)
<i>num-out-sync-rtt</i>	(Optional)
<i>plsd</i>	(Optional)
<i>plds</i>	(Optional)
<i>pos</i>	(Optional)
<i>pl-mia</i>	(Optional)
<i>pla</i>	(Optional)
<i>int-err</i>	(Optional)
<i>busies</i>	(Optional)
<i>pkt-skipped</i>	(Optional)
<i>jitter-value-precision</i>	(Optional)
<i>min-pos-sd</i>	(Optional)
<i>max-pos-sd</i>	(Optional)
<i>num-pos-sd</i>	(Optional)

<i>sum-pos-sd</i>	(Optional)
<i>sum2-pos-sd</i>	(Optional)
<i>min-neg-sd</i>	(Optional)
<i>max-neg-sd</i>	(Optional)
<i>num-neg-sd</i>	(Optional)
<i>sum-neg-sd</i>	(Optional)
<i>sum2-neg-sd</i>	(Optional)
<i>min-pos-ds</i>	(Optional)
<i>max-pos-ds</i>	(Optional)
<i>num-pos-ds</i>	(Optional)
<i>sum-pos-ds</i>	(Optional)
<i>sum2-pos-ds</i>	(Optional)
<i>min-neg-ds</i>	(Optional)
<i>max-neg-ds</i>	(Optional)
<i>num-neg-ds</i>	(Optional)
<i>sum-neg-ds</i>	(Optional)
<i>sum2-neg-ds</i>	(Optional)
<i>jitter-avg</i>	(Optional)
<i>jitter-sd-avg</i>	(Optional)
<i>jitter-ds-avg</i>	(Optional)
<i>inter-jit-out</i>	(Optional)
<i>inter-jit-in</i>	(Optional)
<i>ow-precision</i>	(Optional)
<i>num-ow</i>	(Optional)
<i>ow-min-sd</i>	(Optional)
<i>ow-max-sd</i>	(Optional)
<i>ow-sum-sd</i>	(Optional)
<i>ow-sum2-sd</i>	(Optional)
<i>ow-min-ds</i>	(Optional)

<i>ow-max-ds</i>	(Optional)
<i>ow-sum-ds</i>	(Optional)
<i>ow-sum2-ds</i>	(Optional)
<i>avg-ow-sd</i>	(Optional)
<i>avg-ow-ds</i>	(Optional)
<i>oustring</i>	(Optional)

Command Mode

- /exec

show ip sla enhanced-history distribution-statistics

```
show ip sla enhanced-history distribution-statistics [ <operation-number> [ interval <interval-in-secs> ] ] [
__readonly__ [ <hdr> ] [ { TABLE_generic [ <col1> ] [ <col2> ] [ <col3> ] } ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
enhanced-history	IP SLAs Enhanced History
distribution-statistics	IP SLAs Distribution Statistics
<i>operation-number</i>	(Optional) Entry Number
interval	(Optional) Aggregation Interval
<i>interval-in-secs</i>	(Optional) Interval in seconds
<i>__readonly__</i>	(Optional)
<i>hdr</i>	(Optional)
TABLE_generic	(Optional) Show History Information
<i>col1</i>	(Optional)
<i>col2</i>	(Optional)
<i>col3</i>	(Optional)

Command Mode

- /exec

show ip sla group schedule

```
show ip sla group schedule [ <group-operation-number> ] [ __readonly__ [ <entry-number> ] [ <probe-list>
] [ <num-probes> ] [ <sched-period> ] [ <mode> ] [ <low-freq> ] [ <high-freq> ] [ <freq> ] [ <snmp-status>
] [ <next-start-time> ] [ <life> ] [ <ageout> ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
group	IP SLAs Group Scheduling/Configuration
schedule	Group Scheduling
<i>group-operation-number</i>	(Optional) Group Schedule Entry Number
<i>__readonly__</i>	(Optional)
<i>entry-number</i>	(Optional)
<i>probe-list</i>	(Optional)
<i>num-probes</i>	(Optional)
<i>sched-period</i>	(Optional)
<i>mode</i>	(Optional)
<i>low-freq</i>	(Optional)
<i>high-freq</i>	(Optional)
<i>freq</i>	(Optional)
<i>snmp-status</i>	(Optional)
<i>next-start-time</i>	(Optional)
<i>life</i>	(Optional)
<i>ageout</i>	(Optional)

Command Mode

- /exec

show ip sla history

```
show ip sla history [ <operation-number> ] [ tabular | full | interval-statistics ] [ __readonly__ [ <outstring> ] ] [ { TABLE_generic [ <index> ] [ <life-index> ] [ <bucket-index> ] [ <col1> ] [ <addr> ] [ <dest-id> ] [ <nsr> ] [ <st> ] [ <latest-rtt> ] [ <latest-ret-code> ] [ <col2> ] } ] [ <error> ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
history	IP SLAs History
<i>operation-number</i>	(Optional) Entry Number
tabular	(Optional) Compact Output
full	(Optional) Listed Output
interval-statistics	(Optional) Interval statistics output
<i>__readonly__</i>	(Optional)
<i>outstring</i>	(Optional)
TABLE_generic	(Optional) Show History Information
<i>index</i>	(Optional)
<i>life-index</i>	(Optional)
<i>bucket-index</i>	(Optional)
<i>col1</i>	(Optional)
<i>addr</i>	(Optional)
<i>dest-id</i>	(Optional)
<i>nsr</i>	(Optional)
<i>st</i>	(Optional)
<i>latest-rtt</i>	(Optional)
<i>latest-ret-code</i>	(Optional)
<i>col2</i>	(Optional)
<i>error</i>	(Optional)

Command Mode

- /exec

show ip sla reaction-configuration

```
show ip sla reaction-configuration [ <entry-num> ] [ __readonly__ { TABLE_reaction [ <entry-number> ] [ <index> ] [ <reaction> ] [ <threshold-type> ] [ <rising-value> ] [ <falling-value> ] [ <threshold-countX> ] [ <threshold-countY> ] [ <action-type> ] [ <unconfigured> ] } ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
reaction-configuration	IP SLAs Reaction Configuration
<i>entry-num</i>	(Optional) Entry Number
<i>__readonly__</i>	(Optional)
<i>TABLE_reaction</i>	(Optional)
<i>entry-number</i>	(Optional)
<i>index</i>	(Optional)
<i>reaction</i>	(Optional)
<i>threshold-type</i>	(Optional)
<i>rising-value</i>	(Optional)
<i>falling-value</i>	(Optional)
<i>threshold-countX</i>	(Optional)
<i>threshold-countY</i>	(Optional)
<i>action-type</i>	(Optional)
<i>unconfigured</i>	(Optional)

Command Mode

- /exec

show ip sla reaction-trigger

```
show ip sla reaction-trigger [ <entry-num> ] [ __readonly__ { TABLE_trigger [ <entry-number> ] [ <index> ] [ <target-entry> ] [ <snmp-status> ] [ <operational-state> ] [ <unconfigured> ] } ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
reaction-trigger	IP SLAs Reaction Trigger
<i>entry-num</i>	(Optional) Entry Number
<i>__readonly__</i>	(Optional)
<i>TABLE_trigger</i>	(Optional)
<i>entry-number</i>	(Optional)
<i>index</i>	(Optional)
<i>target-entry</i>	(Optional)
<i>snmp-status</i>	(Optional)
<i>operational-state</i>	(Optional)
<i>unconfigured</i>	(Optional)

Command Mode

- /exec

show ip sla responder

```
show ip sla responder [ __readonly__ <rttMonApplResponder> <gen-enabled> [ <ctrl-msg-count> ] [ <errors>
] [ { TABLE_recent [ <print-recent-hdr> ] [ <print-recent-err-hdr> ] [ <recent-addr> ] [ <recent-time> ] [
<recent-error> ] } ] <perm-enabled> [ { TABLE_permanent_udp [ <print-udp-hdr> ] [ <address> ] [ <port>
] } ] [ { TABLE_permanent_tcp [ <print-tcp-hdr> ] [ <address> ] [ <port> ] } ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
responder	IP SLAs Responder Information
<i>__readonly__</i>	(Optional)
<i>rttMonApplResponder</i>	(Optional) rttMonApplResponder
<i>gen-enabled</i>	(Optional)
<i>ctrl-msg-count</i>	(Optional)
<i>errors</i>	(Optional)
TABLE_recent	(Optional) Show recent control message information
<i>print-recent-hdr</i>	(Optional)
<i>print-recent-err-hdr</i>	(Optional)
<i>recent-addr</i>	(Optional)
<i>recent-time</i>	(Optional)
<i>recent-error</i>	(Optional)
<i>perm-enabled</i>	(Optional)
TABLE_permanent_udp	(Optional) Show UDP permanent port/address information
<i>print-udp-hdr</i>	(Optional)
<i>address</i>	(Optional)
<i>port</i>	(Optional)
TABLE_permanent_tcp	(Optional) Show TCP permanent port/address information
<i>print-tcp-hdr</i>	(Optional)
<i>address</i>	(Optional)

<i>port</i>	(Optional)
-------------	------------

Command Mode

- /exec

<i>top</i>	(Optional)
TABLE_detail	(Optional) Show ip sla statistics detail information
<i>sti</i>	(Optional)
<i>operation-type</i>	(Optional)
<i>MINICPIF</i>	(Optional)
<i>MAXICPIF</i>	(Optional)
<i>MINMOS</i>	(Optional)
<i>MAXMOS</i>	(Optional)
<i>update-count</i>	(Optional)
<i>micro-accuracy</i>	(Optional)
<i>nano-accuracy</i>	(Optional)
<i>latest-RTT</i>	(Optional)
<i>latest-return-code</i>	(Optional)
<i>latest-start-time</i>	(Optional)
<i>http-dns-rtt</i>	(Optional)
<i>http-tcp-rtt</i>	(Optional)
<i>http-ttfb</i>	(Optional)
<i>http-rtt</i>	(Optional)
<i>http-status</i>	(Optional)
<i>http-recvlen</i>	(Optional)
<i>http-bodysize</i>	(Optional)
<i>http-dns-timeout</i>	(Optional)
<i>http-tcp-timeout</i>	(Optional)
<i>http-t-timeout</i>	(Optional)
<i>http-dns-error</i>	(Optional)
<i>http-tcp-error</i>	(Optional)
<i>http-t-error</i>	(Optional)
<i>ntp-sync-state</i>	(Optional)
<i>rtt-count</i>	(Optional)

<i>rtt-min</i>	(Optional)
<i>rtt-avg</i>	(Optional)
<i>rtt-max</i>	(Optional)
<i>lat-ow-samples</i>	(Optional)
<i>sd-lat-ow-min</i>	(Optional)
<i>sd-lat-ow-avg</i>	(Optional)
<i>sd-lat-ow-max</i>	(Optional)
<i>ds-lat-ow-min</i>	(Optional)
<i>ds-lat-ow-avg</i>	(Optional)
<i>ds-lat-ow-max</i>	(Optional)
<i>sd-lat-sum</i>	(Optional)
<i>sd-lat-sum2</i>	(Optional)
<i>ds-lat-sum</i>	(Optional)
<i>ds-lat-sum2</i>	(Optional)
<i>sd-jitter-count</i>	(Optional)
<i>ds-jitter-count</i>	(Optional)
<i>sd-jitter-min</i>	(Optional)
<i>sd-jitter-avg</i>	(Optional)
<i>sd-jitter-max</i>	(Optional)
<i>ds-jitter-min</i>	(Optional)
<i>ds-jitter-avg</i>	(Optional)
<i>ds-jitter-max</i>	(Optional)
<i>sd-pos-jitter-min</i>	(Optional)
<i>sd-pos-jitter-avg</i>	(Optional)
<i>sd-pos-jitter-max</i>	(Optional)
<i>sd-pos-jitter-num</i>	(Optional)
<i>sd-pos-jitter-sum</i>	(Optional)
<i>sd-pos-jitter-sum2</i>	(Optional)
<i>sd-neg-jitter-min</i>	(Optional)

<i>sd-neg-jitter-avg</i>	(Optional)
<i>sd-neg-jitter-max</i>	(Optional)
<i>sd-neg-jitter-num</i>	(Optional)
<i>sd-neg-jitter-sum</i>	(Optional)
<i>sd-neg-jitter-sum2</i>	(Optional)
<i>ds-pos-jitter-min</i>	(Optional)
<i>ds-pos-jitter-avg</i>	(Optional)
<i>ds-pos-jitter-max</i>	(Optional)
<i>ds-pos-jitter-num</i>	(Optional)
<i>ds-pos-jitter-sum</i>	(Optional)
<i>ds-pos-jitter-sum2</i>	(Optional)
<i>ds-neg-jitter-min</i>	(Optional)
<i>ds-neg-jitter-avg</i>	(Optional)
<i>ds-neg-jitter-max</i>	(Optional)
<i>ds-neg-jitter-num</i>	(Optional)
<i>ds-neg-jitter-sum</i>	(Optional)
<i>ds-neg-jitter-sum2</i>	(Optional)
<i>pkt-unprocessed</i>	(Optional)
<i>pkt-loss</i>	(Optional)
<i>pkt-loss-per</i>	(Optional)
<i>pkt-loss-min</i>	(Optional)
<i>pkt-loss-max</i>	(Optional)
<i>pkt-loss-inter-min</i>	(Optional)
<i>pkt-loss-inter-max</i>	(Optional)
<i>inter-jitter-out</i>	(Optional)
<i>inter-jitter-in</i>	(Optional)
<i>jitter-avg</i>	(Optional)
<i>pkt-loss-sd</i>	(Optional)
<i>pkt-loss-sd-per</i>	(Optional)

<i>pkt-loss-sd-min</i>	(Optional)
<i>pkt-loss-sd-max</i>	(Optional)
<i>pkt-loss-sd-inter-min</i>	(Optional)
<i>pkt-loss-sd-inter-max</i>	(Optional)
<i>pkt-loss-ds</i>	(Optional)
<i>pkt-loss-ds-per</i>	(Optional)
<i>pkt-loss-ds-min</i>	(Optional)
<i>pkt-loss-ds-max</i>	(Optional)
<i>pkt-loss-ds-inter-min</i>	(Optional)
<i>pkt-loss-ds-inter-max</i>	(Optional)
<i>pkt-oos</i>	(Optional)
<i>pkt-oos-sd</i>	(Optional)
<i>pkt-oos-ds</i>	(Optional)
<i>pkt-oos-both</i>	(Optional)
<i>pkt-mia</i>	(Optional)
<i>pkt-late</i>	(Optional)
<i>pkt-skipped</i>	(Optional)
<i>voice-icpif</i>	(Optional)
<i>voice-mos</i>	(Optional)
<i>dnobs</i>	(Optional)
<i>dmam</i>	(Optional)
<i>dtoo</i>	(Optional)
<i>dmin</i>	(Optional)
<i>dmax</i>	(Optional)
<i>pnobs</i>	(Optional)
<i>pmam</i>	(Optional)
<i>ptoo</i>	(Optional)
<i>pmin</i>	(Optional)
<i>pmax</i>	(Optional)

<i>nnobs</i>	(Optional)
<i>nmam</i>	(Optional)
<i>ntoo</i>	(Optional)
<i>nmin</i>	(Optional)
<i>nmax</i>	(Optional)
<i>outstring1</i>	(Optional)
<i>outstring2</i>	(Optional)
<i>nos</i>	(Optional)
<i>nof</i>	(Optional)
<i>noot</i>	(Optional)
<i>nofo1</i>	(Optional)
<i>nofo2</i>	(Optional)
TABLE_br	(Optional) Bin range related info
<i>br</i>	(Optional)
<i>avg-lat</i>	(Optional)
<i>potc</i>	(Optional)
<i>noc-by-lat</i>	(Optional)
<i>sorthigh-by-low</i>	(Optional)
<i>operot</i>	(Optional)
<i>life-left</i>	(Optional)
<i>oper-state</i>	(Optional)
<i>reset-time</i>	(Optional)
<i>nob</i>	(Optional)
<i>bbh</i>	(Optional)
<i>bbv</i>	(Optional)

Command Mode

- /exec

show ip sla twamp connection detail

```
show ip sla twamp connection detail [ __readonly__ [ { TABLE_twamp-connection-detail <Connection-Id>
<Client-Addr> <Client-Port> <Client-VRF> <Mode> <Connection-state> <Control-state>
<Number-Of-Test-requests> } ] ]
```

Syntax Description

show	
ip	
sla	
twamp	
connection	
detail	
<i>__readonly__</i>	(Optional)
<i>TABLE_twamp-connection-detail</i>	(Optional) connection related info
<i>Connection-Id</i>	(Optional)
<i>Client-Addr</i>	(Optional)
<i>Client-Port</i>	(Optional)
<i>Client-VRF</i>	(Optional)
<i>Mode</i>	(Optional)
<i>Connection-state</i>	(Optional)
<i>Control-state</i>	(Optional)
<i>Number-Of-Test-requests</i>	(Optional)

Command Mode

- /exec

show ip sla twamp connection requests

```
show ip sla twamp connection requests [ __readonly__ [ { TABLE_twamp-connection-request <Connection-Id>
<Client-Addr> <Client-Port> <Client-VRF> } ] [ <Total-Connections> ] ]
```

Syntax Description

show	
ip	
sla	
twamp	
connection	
requests	
<i>__readonly__</i>	(Optional)
<i>TABLE_twamp-connection-request</i>	(Optional) connection requests related info
<i>Connection-Id</i>	(Optional)
<i>Client-Addr</i>	(Optional)
<i>Client-Port</i>	(Optional)
<i>Client-VRF</i>	(Optional)
<i>Total-Connections</i>	(Optional)

Command Mode

- /exec

show ip sla twamp session

```
show ip sla twamp session [ __readonly__ <twamp-resp-status> [ { TABLE_twamp-session [ <recv-addr> ]
[ <recv-port> ] [ <send-addr> ] [ <send-port> ] [ <send-vrf> ] [ <sess-id> ] [ <conn-id> ] } ] ]
```

Syntax Description

show	
ip	
sla	Service Level Agreement (SLA)
twamp	IP SLAs Twamp Information
session	Display TWAMP Sessions
<i>__readonly__</i>	(Optional)
<i>twamp-resp-status</i>	(Optional)
TABLE_twamp-session	(Optional) session related information
<i>recv-addr</i>	(Optional)
<i>recv-port</i>	(Optional)
<i>send-addr</i>	(Optional)
<i>send-port</i>	(Optional)
<i>send-vrf</i>	(Optional)
<i>sess-id</i>	(Optional)
<i>conn-id</i>	(Optional)

Command Mode

- /exec

show ip sla twamp standards

```
show ip sla twamp standards [ __readonly__ [ { TABLE_twamp-standards <twamp-standard-feature>
<twamp-standard-org> <twamp-standard> } ] ]
```

Syntax Description

show	
ip	
sla	
twamp	
standards	
<i>__readonly__</i>	(Optional)
<i>TABLE_twamp-standards</i>	(Optional) twamp standards for each supported feature
<i>twamp-standard-feature</i>	(Optional)
<i>twamp-standard-org</i>	(Optional)
<i>twamp-standard</i>	(Optional)

Command Mode

- /exec

show ip ssh source-interface

```
show ip ssh source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipsshvrf
<vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ssh	Display SSH client information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ipsshvrf	(Optional) source interface of ssh given vrf
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip ssh source-interface vrf all

```
show ip ssh source-interface vrf all [ __readonly__ [ { TABLE_ipssh <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
ssh	Display SSH client information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_ipssh	(Optional) source interface of ssh
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip static-route

```
show ip static-route [ multicast ] [ internal ] [ track-table ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ [ <count> <unres-count> ] [ TABLE_vrf_all { <cntxt_name> <cntxt_id> [ TABLE_each_vrf
{ <prefix_addr_msk> <nhop_addr_msk> <nhop_vrf_info> <nhop_intr_info> <urib_stat> [ <seg_id> ] [
<tunnel_id> <urib_encap_type> ] [ <nhop_urib_stat> ] [ <track_obj_num> <track_obj_state> ] } ] ] [
TABLE_multicast <multicast> ] [ TABLE_track-table ] [ TABLE_route <prefix> <masklen> <nhop>
<nhop-masklen> <intf> <real-nhop> <iod> <pref> <tag> <unres> ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
static-route	Display configured static routes
multicast	(Optional) Display only multicast routes
internal	(Optional) Display internal data structure info
track-table	(Optional) Display track object details associated with static routes
vrf	(Optional) Display per-VRF information
all	(Optional) Display all VRFs
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_vrf_all	(Optional)
<i>cntxt_name</i>	(Optional)
<i>cntxt_id</i>	(Optional)
TABLE_each_vrf	(Optional)
<i>prefix_addr_msk</i>	(Optional)
<i>nhop_addr_msk</i>	(Optional)
<i>nhop_vrf_info</i>	(Optional)
<i>nhop_intr_info</i>	(Optional)
<i>urib_stat</i>	(Optional)
<i>seg_id</i>	(Optional)
<i>tunnel_id</i>	(Optional)

<i>urib_encap_type</i>	(Optional)
<i>nhop_urib_stat</i>	(Optional)
<i>track_obj_num</i>	(Optional)
<i>track_obj_state</i>	(Optional)
TABLE_multicast	(Optional)
<i>multicast</i>	(Optional)
TABLE_track-table	(Optional)
TABLE_route	(Optional)
<i>prefix</i>	(Optional)
<i>masklen</i>	(Optional)
<i>nhop</i>	(Optional)
<i>nhop-masklen</i>	(Optional)
<i>intf</i>	(Optional)
<i>real-nhop</i>	(Optional)
<i>iod</i>	(Optional)
<i>pref</i>	(Optional)
<i>tag</i>	(Optional)
<i>unres</i>	(Optional)
<i>count</i>	(Optional)
<i>unres-count</i>	(Optional)

Command Mode

- /exec

show ip tcp mss

show ip tcp mss

Syntax Description

show	Show running system information
ip	Configure IP features
tcp	Global TCP parameters
mss	Maximum segment size for TCP connections in bytes

Command Mode

- /exec

show ip telnet source-interface

```
show ip telnet source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ {
TABLE_ iptelnetvrf <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
telnet	Display telnet information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ iptelnetvrf	(Optional) source interface of telnet given vrf
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip telnet source-interface vrf all

```
show ip telnet source-interface vrf all [ __readonly__ [ { TABLE_ip telnet <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
telnet	Display telnet information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_ip telnet	(Optional) source interface of telnet
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip tftp source-interface

```
show ip tftp source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipftpvrf
<vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
tftp	Display TFTP client information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_ipftpvrf	(Optional) source interface of tftp given vrf
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip tftp source-interface vrf all

```
show ip tftp source-interface vrf all [ __readonly__ [ { TABLE_ip tftp <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
tftp	Display TFTP client information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_ip tftp	(Optional) source interface of tftp
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip traceroute source-interface

```
show ip traceroute source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ {
TABLE_iptraceroutevrf <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
traceroute	Display traceroute client information
source-interface	Display source interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_iptraceroutevrf	(Optional) source interface of traceroute
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip traceroute source-interface vrf all

```
show ip traceroute source-interface vrf all [ __readonly__ [ { TABLE_iptraceroute <vrfname> <ifname> } ] ]
```

Syntax Description

show	Show running system information
ip	Display IP information
traceroute	Display traceroute client information
source-interface	Display source interface information
vrf	Display per-VRF information
all	Display entries for all vrfs
__readonly__	(Optional)
TABLE_iptraceroute	(Optional) source interface of traceroute
<i>vrfname</i>	(Optional) vrfname
<i>ifname</i>	(Optional) ifname

Command Mode

- /exec

show ip traffic

```
show ip traffic [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_vrf [ <vrf-name-out>
] } ] [ { TABLE_ip_soft_processed_traffic [ { TABLE_trans_and_reception [ <rcvd> ] [ <sent> ] [ <consumed>
] [ <fwd-ucast> ] [ <fwd-mcast> ] [ <fwd-label> ] [ <ingress-mcecfwd> } ] } ] [ { TABLE_opts [ <opts-end>
] [ <opts-nop> ] [ <opts-bsec> ] [ <opts-loosesrc-route> ] [ <opts-timestamp> ] [ <opts-esec> ] [
<opts-record-route> ] [ <opts-stid> ] [ <opts-strsrc-route> ] [ <opts-alert> ] [ <opts-cipso> ] [ <opts-ump> ]
[ <opts-other> } ] } ] [ { TABLE_errors [ <bad-csum> ] [ <too-small> ] [ <bad-ver> ] [ <bad-hlen> ] [ <bad-len>
] [ <bad-dest> ] [ <bad-ttl> ] [ <cant-fwd> ] [ <out-drop> ] [ <bad-encap> ] [ <no-route> ] [ <no-proto> ] [
<bad-options> ] [ <vinci> ] [ <snoop> ] [ <svi> ] [ <restart-recovery> ] [ <mbuf-fail> ] [ <bad-context> ] [
<rpf-drops> ] [ <bad-gw-mac> ] [ <ing-ips-option-fail> ] [ <nat-in-drop> ] [ <nat-out-drop> ] [
<ing-option-proc-fail> ] [ <ing-mfwd-fail> ] [ <ing-lisp-drop> ] [ <ing-lisp-decap-drop> ] [
<ing-lisp-encap-drop> ] [ <ing-lisp-encap> ] [ <ing-mfwd-copy-drop> ] [ <ing-ra-reass-drop> ] [
<ing-icmp-redirect> ] [ <ing-drop-ifmgr-init> ] [ <ing-drop-invlld-filter> ] [ <ing-drop-invlld-l2-msg> ] [
<ingress> ] [ <egrees> ] [ <directed_bdcast> } ] } ] [ { TABLE_fragment [ <frag> ] [ <fragmented> ] [ <out-frag>
] [ <frag-drop> ] [ <cant-frag> ] [ <reams> ] [ <frag-to> } ] } ] [ { TABLE_icmp_software_proc_traffic [ {
TABLE_transmission [ <tx-redir> ] [ <tx-unreach> ] [ <tx-echo-req> ] [ <tx-echo-reply> ] [ <tx-mask-req>
] [ <tx-mask-rep> ] [ <tx-info-req> ] [ <tx-info-reply> ] [ <tx-param-prob> ] [ <tx-source-quench> ] [
<tx-tstamp-req> ] [ <tx-tstamp-reply> ] [ <tx-time-exceeded> ] [ <tx-router-solicit> ] [ <tx-router-advert> ]
[ <out-drop-badlen> ] [ <encap-fail> ] [ <xmit-fail> ] [ <icmp-originate> ] [ <redirect-originate-req> ] [
<originate-deny> ] [ <short-ip> ] [ <old-icmp> ] [ <error-drop> } ] } ] [ { TABLE_reception [ <rx-redir> ] [
<rx-unreach> ] [ <rx-echo-req> ] [ <rx-echo-reply> ] [ <rx-mask-req> ] [ <rx-mask-rep> ] [ <rx-info-req> ]
[ <rx-info-reply> ] [ <rx-param-prob> ] [ <rx-source-quench> ] [ <rx-tstamp-req> ] [ <rx-tstamp-reply> ] [
<rx-time-exceeded> ] [ <rx-router-solicit> ] [ <rx-router-advert> ] [ <rx-format-errors> ] [ <rx-csum-errors>
] [ <lisp-processed> ] [ <lisp-noclient> ] [ <lisp-consumed> ] [ <icmp-replies> ] [ <icmp-reply-drop> ] [
<icmp-inactive-addr> } ] } ] [ { TABLE_stat_last_never [ <stat-last-never> } ] } ] [ {
TABLE_rfc4293_ip_soft_proc_traffic [ { TABLE_rfc_reception [ <inrcv> ] [ <inocet> ] [ <inhdrerr> ] [
<innoroutes> ] [ <inaddrerr> ] [ <innoproto> ] [ <intruncated> ] [ <inforw> ] [ <reamsreqds> ] [ <reamsoks>
] [ <reamsfails> ] [ <indiscards> ] [ <indelivers> ] [ <inmcastpkts> ] [ <inmcastbytes> ] [ <inbastpkts> } ] } ]
[ { TABLE_rfc_transmission [ <out-req> ] [ <out-no-route> ] [ <out-forwdgrams> ] [ <out-discards> ] [
<out-frag-req> ] [ <out-frag-oks> ] [ <out-frag-fails> ] [ <out-frag-create> ] [ <out-transmits> ] [ <byte-sent>
] [ <out-mcast-pkts> ] [ <out-mcast-bytes> ] [ <out-bcast-pkts> ] [ <out-bcast-bytes> } ] } ] } ] }
```

Syntax Description

show	Show running system information
ip	Display IP information
traffic	Display IP software processed traffic statistics
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<code>__readonly__</code>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)

TABLE_ip_soft_processed_traffic	(Optional)
TABLE_trans_and_reception	(Optional)
<i>rcvd</i>	(Optional)
<i>sent</i>	(Optional)
<i>consumed</i>	(Optional)
<i>fwd-ucast</i>	(Optional)
<i>fwd-mcast</i>	(Optional)
<i>fwd-label</i>	(Optional)
<i>ingress-mcecfwd</i>	(Optional)
TABLE_opts	(Optional)
<i>opts-end</i>	(Optional)
<i>opts-nop</i>	(Optional)
<i>opts-bsec</i>	(Optional)
<i>opts-loosesrc-route</i>	(Optional)
<i>opts-timestamp</i>	(Optional)
<i>opts-esec</i>	(Optional)
<i>opts-record-route</i>	(Optional)
<i>opts-ump</i>	(Optional)
<i>opts-stid</i>	(Optional)
<i>opts-strsrc-route</i>	(Optional)
<i>opts-alert</i>	(Optional)
<i>opts-cipso</i>	(Optional)
<i>opts-other</i>	(Optional)
TABLE_errors	(Optional)
<i>bad-csum</i>	(Optional)
<i>too-small</i>	(Optional)
<i>bad-ver</i>	(Optional)
<i>bad-hlen</i>	(Optional)
<i>bad-len</i>	(Optional)

<i>bad-dest</i>	(Optional)
<i>bad-ttl</i>	(Optional)
<i>cant-fwd</i>	(Optional)
<i>out-drop</i>	(Optional)
<i>bad-encap</i>	(Optional)
<i>no-route</i>	(Optional)
<i>no-proto</i>	(Optional)
<i>bad-options</i>	(Optional)
<i>vinci</i>	(Optional)
<i>snoop</i>	(Optional)
<i>svi</i>	(Optional)
<i>restart-recovery</i>	(Optional)
<i>mbuf-fail</i>	(Optional)
<i>bad-context</i>	(Optional)
<i>rpf-drops</i>	(Optional)
<i>bad-gw-mac</i>	(Optional)
<i>ing-ips-option-fail</i>	(Optional)
<i>nat-in-drop</i>	(Optional)
<i>nat-out-drop</i>	(Optional)
<i>ing-option-proc-fail</i>	(Optional)
<i>ing-mfrwd-fail</i>	(Optional)
<i>ing-lisp-drop</i>	(Optional)
<i>ing-lisp-decap-drop</i>	(Optional)
<i>ing-lisp-encap-drop</i>	(Optional)
<i>ing-lisp-encap</i>	(Optional)
<i>ing-mfwd-copy-drop</i>	(Optional)
<i>ing-ra-reass-drop</i>	(Optional)
<i>ing-icmp-redirect</i>	(Optional)
<i>ing-drop-ifmgr-init</i>	(Optional)

<i>ing-drop-invld-filter</i>	(Optional)
<i>ing-drop-invld-l2-msg</i>	(Optional)
<i>ingress</i>	(Optional)
<i>egrees</i>	(Optional)
<i>directed_bdcast</i>	(Optional)
TABLE_fragment	(Optional)
<i>frag</i>	(Optional)
<i>fragmented</i>	(Optional)
<i>out-frag</i>	(Optional)
<i>frag-drop</i>	(Optional)
<i>cant-frag</i>	(Optional)
<i>reasm</i>	(Optional)
<i>frag-to</i>	(Optional)
TABLE_icmp_software_proc_traffic	(Optional)
TABLE_transmission	(Optional)
<i>tx-redirect</i>	(Optional)
<i>tx-unreach</i>	(Optional)
<i>tx-echo-req</i>	(Optional)
<i>tx-echo-reply</i>	(Optional)
<i>tx-mask-req</i>	(Optional)
<i>tx-mask-rep</i>	(Optional)
<i>tx-info-req</i>	(Optional)
<i>tx-info-reply</i>	(Optional)
<i>tx-param-prob</i>	(Optional)
<i>tx-source-quench</i>	(Optional)
<i>tx-tstamp-req</i>	(Optional)
<i>tx-tstamp-reply</i>	(Optional)
<i>tx-time-exceeded</i>	(Optional)
<i>tx-router-solicit</i>	(Optional)

<i>tx-router-advert</i>	(Optional)
<i>out-drop-badlen</i>	(Optional)
<i>encap-fail</i>	(Optional)
<i>xmit-fail</i>	(Optional)
<i>icmp-originate</i>	(Optional)
<i>redirect-originate-req</i>	(Optional)
<i>originate-deny</i>	(Optional)
<i>short-ip</i>	(Optional)
<i>old-icmp</i>	(Optional)
<i>error-drop</i>	(Optional)
TABLE_reception	(Optional)
<i>rx-redir</i>	(Optional)
<i>rx-unreach</i>	(Optional)
<i>rx-echo-req</i>	(Optional)
<i>rx-echo-reply</i>	(Optional)
<i>rx-mask-req</i>	(Optional)
<i>rx-mask-rep</i>	(Optional)
<i>rx-info-req</i>	(Optional)
<i>rx-info-reply</i>	(Optional)
<i>rx-param-prob</i>	(Optional)
<i>rx-source-quench</i>	(Optional)
<i>rx-tstamp-req</i>	(Optional)
<i>rx-tstamp-reply</i>	(Optional)
<i>rx-time-exceeded</i>	(Optional)
<i>rx-router-solicit</i>	(Optional)
<i>rx-router-advert</i>	(Optional)
<i>rx-format-errors</i>	(Optional)
<i>rx-csum-errors</i>	(Optional)
<i>lisp-processed</i>	(Optional)

<i>lisp-noclient</i>	(Optional)
<i>lisp-consumed</i>	(Optional)
<i>icmp-replies</i>	(Optional)
<i>icmp-reply-drop</i>	(Optional)
<i>icmp-inactive-addr</i>	(Optional)
TABLE_stat_last_never	(Optional)
<i>stat-last-never</i>	(Optional)
TABLE_rfc4293_ip_soft_proc_traffic	(Optional)
TABLE_rfc_reception	(Optional)
<i>inrcv</i>	(Optional)
<i>inoctet</i>	(Optional)
<i>inhdrrr</i>	(Optional)
<i>innoroutes</i>	(Optional)
<i>inaddrerr</i>	(Optional)
<i>innoproto</i>	(Optional)
<i>intruncated</i>	(Optional)
<i>inforw</i>	(Optional)
<i>reasmreqds</i>	(Optional)
<i>reasmoks</i>	(Optional)
<i>reasmfails</i>	(Optional)
<i>indiscards</i>	(Optional)
<i>indelivers</i>	(Optional)
<i>inmcastpkts</i>	(Optional)
<i>inmcastbytes</i>	(Optional)
<i>inbastpkts</i>	(Optional)
TABLE_rfc_transmission	(Optional)
<i>out-req</i>	(Optional)
<i>out-no-route</i>	(Optional)
<i>out-forwdgrams</i>	(Optional)

<i>out-discards</i>	(Optional)
<i>out-frag-req</i>	(Optional)
<i>out-frag-oks</i>	(Optional)
<i>out-frag-fails</i>	(Optional)
<i>out-frag-create</i>	(Optional)
<i>out-transmits</i>	(Optional)
<i>byte-sent</i>	(Optional)
<i>out-mcast-pkts</i>	(Optional)
<i>out-mcast-bytes</i>	(Optional)
<i>out-bcast-pkts</i>	(Optional)
<i>out-bcast-bytes</i>	(Optional)

Command Mode

- /exec

show ip udp relay

```
show ip udp relay [ __readonly__ [ <udp_relay_service_enable> <udp_relay_hdr> TABLE_default_ports
<port_name> <udp_relay_port_enable> ] [ <udp_ports_hdr> TABLE_ports <udp_port_num> ] [ <udp_intf_hdr>
TABLE_intf <udp_intf_idx> <udp_sub_bcast> <udp_objgrp> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
udp	Show items in UDP relay
relay	UDP relay
<i>__readonly__</i>	(Optional) Read only
<i>udp_relay_service_enable</i>	(Optional)
<i>udp_relay_hdr</i>	(Optional)
TABLE_default_ports	(Optional)
<i>port_name</i>	(Optional) UDP Port Name
<i>udp_relay_port_enable</i>	(Optional)
<i>udp_ports_hdr</i>	(Optional)
TABLE_ports	(Optional)
<i>udp_port_num</i>	(Optional)
<i>udp_intf_hdr</i>	(Optional)
TABLE_intf	(Optional)
<i>udp_intf_idx</i>	(Optional) UDP relay interfaces
<i>udp_sub_bcast</i>	(Optional)
<i>udp_objgrp</i>	(Optional) Object-group

Command Mode

- /exec

show ip udp relay interface

```
show ip udp relay interface [ <intf_range> ] [ __readonly__ <udp_intf_hdr> [ TABLE_intf <udp_intf_idx>
<udp_sub_bcast> <udp_objgrp> ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
udp	Show items in UDP relay
relay	UDP relay
interface	Interface ID
<i>intf_range</i>	(Optional) interface
<i>__readonly__</i>	(Optional) Read only
<i>udp_intf_hdr</i>	(Optional)
TABLE_intf	(Optional)
<i>udp_intf_idx</i>	(Optional) UDP relay interfaces
<i>udp_sub_bcast</i>	(Optional)
<i>udp_objgrp</i>	(Optional) Object-group

Command Mode

- /exec

show ip udp relay object-group

```
show ip udp relay object-group [ <obj-grp-name> ] [ __readonly__ [ TABLE_objgrp_list [ <udp_objgrp> ]
[ TABLE_objgrp [ <host_addr> ] [ <net_addr> <net_mask> ] [ <prefix_addr> <prefix_len> ] ] <udp_intf_hdr>
[ TABLE_intf <udp_intf_idx> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
udp	Show items in UDP relay
relay	UDP relay
object-group	Object-group
<i>obj-grp-name</i>	(Optional) object-group name
<i>__readonly__</i>	(Optional) Read only
TABLE_objgrp_list	(Optional)
<i>udp_objgrp</i>	(Optional) Object-group
TABLE_objgrp	(Optional)
<i>host_addr</i>	(Optional) Host Address
<i>net_addr</i>	(Optional) Network Address
<i>net_mask</i>	(Optional) Network Mask
<i>prefix_addr</i>	(Optional) Network Address
<i>prefix_len</i>	(Optional) IP Prefix Length
<i>udp_intf_hdr</i>	(Optional)
TABLE_intf	(Optional)
<i>udp_intf_idx</i>	(Optional) UDP relay interfaces

Command Mode

- /exec

show ip verify source

```
show ip verify source [ interface <intf6> ] [ __readonly__ <verify_ipsg_exclude_vlans> [ <verify_hdr> ] [
<verify_intf_ipsg_val> | <verify_ipsg_enable_intfs> ] [ { TABLE_verify_entry <verify_intf>
<verify_intf_ipsg_val> [ { TABLE_verify_entry_intfs <verify_ipsg_enable_intfs> } ] <verify_filter_mode>
<verify_ip_addr> <verify_mac_addr> <verify_vlan> } ] ]
```

Syntax Description

show	Show running system information
ip	Show the IP features of the system
verify	Verify IPSG information
source	IPSG source
interface	(Optional) Interface
<i>intf6</i>	(Optional) interface
<i>__readonly__</i>	(Optional) Read only
<i>verify_ipsg_exclude_vlans</i>	(Optional)
<i>verify_hdr</i>	(Optional) IP source guard operational entries
<i>verify_intf_ipsg_val</i>	(Optional) IP source guard value (enabled or disable)
<i>verify_ipsg_enable_intfs</i>	(Optional) IP source guard enabled interfaces names
TABLE_verify_entry	(Optional)
<i>verify_filter_mode</i>	(Optional)
<i>verify_intf</i>	(Optional)
TABLE_verify_entry_intfs	(Optional)
<i>verify_ip_addr</i>	(Optional) verify ip address
<i>verify_mac_addr</i>	(Optional) verify mac address
<i>verify_vlan</i>	(Optional) vlan for interface

Command Mode

- /exec

show ipv6 adjacency

```
show ipv6 { adjacency | neighbor } [ <interface> [ summary ] | <ipv6-addr> [ detail ] | detail | summary |
non-best | [ throttle ] statistics ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
<invalid_pkt_cnt> ] [ <invalid_byte_cnt> ] [ <global_drop_pkt_cnt> ] [ <global_drop_byte_cnt> ] [
<global_punt_pkt_cnt> ] [ <global_punt_byte_cnt> ] [ <global_glean_pkt_cnt> ] [ <global_glean_byte_cnt>
] [ <glean_pkt_cnt> ] [ <glean_byte_cnt> ] [ <normal_pkt_cnt> ] [ <normal_byte_cnt> ] [ <last_updated> ]
[ <count-static> ] [ <count-dynamic> ] [ <count-others> ] [ <count-throttle> ] [ <count-total> ] [ TABLE_vrf
<vrf-name-out> ] [ TABLE_afi <afi> <count> ] [ TABLE_adj <intf-out> <ipv6-addr> [ <phy-intf> ] <time-stamp>
<mac> <pref> <owner> [ <pkt-count> ] [ <byte-count> ] [ <is-best> ] [ <is-thrld> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
adjacency	Display adjacency table
neighbor	Show IPv6 neighbor entry
<i>interface</i>	(Optional) Display specific interface adjacencies only
detail	(Optional) Show detail information of adjacency entries
summary	(Optional) Show adjacency summary
non-best	(Optional) Show both best/non-best entries
throttle	(Optional) Throttle
statistics	(Optional) Show adjacency statistics
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Show adjacency entries for all vrfs
__readonly__	(Optional)
TABLE_vrf	(Optional) VRF table
<i>vrf-name-out</i>	(Optional) VRF name
<i>invalid_pkt_cnt</i>	(Optional) Invalid packet count
<i>invalid_byte_cnt</i>	(Optional) Invalid byte count
<i>global_drop_pkt_cnt</i>	(Optional) Global drop packet count
<i>global_drop_byte_cnt</i>	(Optional) Global drop byte count

<i>global_punt_pkt_cnt</i>	(Optional) Global punt packet count
<i>global_punt_byte_cnt</i>	(Optional) Global punt byte count
<i>global_glean_pkt_cnt</i>	(Optional) Global glean packet count
<i>global_glean_byte_cnt</i>	(Optional) Global glean byte count
<i>glean_pkt_cnt</i>	(Optional) Glean packet count
<i>glean_byte_cnt</i>	(Optional) Glean byte count
<i>normal_pkt_cnt</i>	(Optional) Packet count
<i>normal_byte_cnt</i>	(Optional) Byte count
<i>last_updated</i>	(Optional) Lat updated
<i>count-static</i>	(Optional) Static count
<i>count-dynamic</i>	(Optional) Dynamic count
<i>count-others</i>	(Optional) Others count
<i>count-throttle</i>	(Optional) Throttled count
<i>count-total</i>	(Optional) Total count
TABLE_afi	(Optional) AFI table
<i>afi</i>	(Optional) AFI
<i>count</i>	(Optional) Count
TABLE_adj	(Optional) Adjacency table for IPV6
<i>intf-out</i>	(Optional) Interface
<i>phy-intf</i>	(Optional) Physical interface
<i>time-stamp</i>	(Optional) Age
<i>mac</i>	(Optional) MAC address
<i>pref</i>	(Optional) Preference
<i>owner</i>	(Optional) Owner
<i>pkt-count</i>	(Optional) Packet count
<i>byte-count</i>	(Optional) Byte count
<i>is-best</i>	(Optional) Best
<i>is-thrtld</i>	(Optional) Throttled

Command Mode

- /exec

show ipv6 amt tunnel

```
show ipv6 amt tunnel [ <address6> <port> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__
TABLE_vrf <vrf> <tc6> { TABLE_tunnel <gwa> <gwp> <ut> <ld> <lr> <rc> <exp> { TABLE_route
<source> <group> <rexp> } } ]
```

Syntax Description

show	Show running system information
amt	AMT show commands
ipv6	Display IPv6 information
tunnel	Display tunnel information
vrf	(Optional) Display information for VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>port</i>	(Optional) UDP port number of gateway
detail	(Optional) Display routes joined by tunnel endpoint
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf</i>	(Optional)
<i>tc6</i>	(Optional)
TABLE_tunnel	(Optional)
<i>gwa</i>	(Optional)
<i>gwp</i>	(Optional)
<i>ut</i>	(Optional)
<i>ld</i>	(Optional)
<i>lr</i>	(Optional)
<i>rc</i>	(Optional)
<i>exp</i>	(Optional)
TABLE_route	(Optional)
<i>source</i>	(Optional)
<i>group</i>	(Optional)

<i>exp</i>	(Optional)
------------	------------

Command Mode

- /exec

show ipv6 bgp

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [
<ipv6-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234
} ]
```

Syntax Description

show	Show running system information
ipv6	Display BGP information for IPv6 address family
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
longer-prefixes	(Optional) Display route and more specific routes

Command Mode

- /exec

show ipv6 bgp

```
show ipv6 { bgp | mbgp } { route-map { <rmap-name> | <rmap-name> } | prefix-list { <prfxlist-name> |
<test_pol_name> } | filter-list { <fltrlist-name> | <test_pol_name> } | community-list { <commlist-name> |
<test_pol_name> } | extcommunity-list { <extcommlist-name> | <test_pol_name> } [ exact-match ] }
```

Syntax Description

show	Show running system information
ipv6	Display BGP information for IPv6 address family
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
route-map	Display routes matching the route-map
<i>rmap-name</i>	Route-map name
<i>rmap-name</i>	Known route-map name
prefix-list	Display routes matching the prefix-list
<i>prfxlist-name</i>	Name of prefix-list
filter-list	Display routes matching the filter-list
<i>fltrlist-name</i>	Name of filter-list
community-list	Display routes matching the community-list
<i>commlist-name</i>	Name of community-list
extcommunity-list	Display routes matching the extcommunity-list
<i>extcommlist-name</i>	Name of extcommunity-list
<i>test_pol_name</i>	An existing test-list policy
exact-match	(Optional) Exact match of the communities

Command Mode

- /exec

show ipv6 bgp

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] {
rib-install | rib-uninstall | rib-pending } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv6	Display BGP information for IPv6 address family
rib-install	Routes installed in RIB
rib-uninstall	Routes not installed in RIB
rib-pending	Routes not acknowledged by RIB

Command Mode

- /exec

show ipv6 bgp community

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
community { <regex-str> | { { <comm-id> | <wellknown-id> } + [ exact-match ] } } [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
ipv6	Display BGP information for IPv6 address family
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
community	Display routes matching the BGP communities
<i>regex-str</i>	Regular expression to match the communities
<i>comm-id</i>	BGP community value
<i>wellknown-id</i>	BGP wellknown community
exact-match	(Optional) Exact match of the communities

Command Mode

- /exec

show ipv6 bgp dampening

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
dampening { dampened-paths [ regexp <regexp-str> ] | history-paths [ regexp <regexp-str> ] | parameters |
flap-statistics } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
dampening	Display dampening info
parameters	Display dampening parameters
dampened-paths	Display all dampened paths
history-paths	Display all history paths
flap-statistics	Display flap statistics for routes
ipv6	Display BGP information for IPv6 address family
regexp	(Optional) Display routes matching the AS path regular expression
<i>regexp-str</i>	(Optional) Regular expression to match the AS paths

Command Mode

- /exec

show ipv6 bgp extcommunity

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
extcommunity { <regexp-str> | { { 4byteas-generic { transitive <ext-comm-gen-trans> | non-transitive
<ext-comm-gen-nontrans> } } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ipv6	Display BGP information for IPv6 address family
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
extcommunity	Display routes matching the BGP extcommunities
4byteas-generic	Generic extended community
transitive	Transitive extcommunity
non-transitive	Non-Transitive extcommunity
<i>regexp-str</i>	Regular expression to match the extcommunities
<i>ext-comm-gen-trans</i>	Extcommunity number aa4:nn format
<i>ext-comm-gen-nontrans</i>	Extcommunity number aa4:nn format
exact-match	(Optional) Exact match of the extcommunities

Command Mode

- /exec

show ipv6 bgp flap-statistics

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
flap-statistics [ <ipv6-prefix> ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
flap-statistics	Display route flap statistics
ipv6	Display BGP information for IPv6 address family

Command Mode

- /exec

show ipv6 bgp neighbors

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
neighbors { [ { <neighbor-id> | <ipv6-neighbor-id> } [ routes [ advertised | received | dampened ] |
advertised-routes | paths | received-routes | flap-statistics ] ] | <neighbor-prefix-id> | <ipv6-neighbor-prefix-id>
} [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
neighbors	Display all configured BGP neighbors
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>neighbor-id</i>	(Optional) Display one particular BGP neighbor
<i>neighbor-prefix-id</i>	Display details for a prefix peering
ipv6	Display BGP information for IPv6 address family
routes	(Optional) Display all routes advertised/received to/from peer
advertised	(Optional) Display all routes advertised to this peer
received	(Optional) Display all routes received from this peer
dampened	(Optional) Display all dampened routes received from this peer
advertised-routes	(Optional) Display all the routes advertised to this peer
received-routes	(Optional) Display all the routes received from this peer
flap-statistics	(Optional) Display flap statistics for routes received from this peer
paths	(Optional) Display AS paths learned from this peer

Command Mode

- /exec

show ipv6 bgp nexthop-database

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]  
nexthop-database [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
nexthop-database	Display nexthop database
ipv6	Display BGP information for IPv6 address family

Command Mode

- /exec

show ipv6 bgp nexthop

show ipv6 { bgp | mbgp } nexthop <ipv6nexthop>

Syntax Description

show	Show running system information
ipv6	Display BGP information for IPv6 address family
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
nexthop	Display routes matching the nexthop

Command Mode

- /exec

show ipv6 bgp received-paths

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
received-paths [ private ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ipv6	Display BGP information for IPv6 address family
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
received-paths	Display paths stored for soft-reconfig
private	(Optional) private

Command Mode

- /exec

show ipv6 bgp regexp

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] regexp
<regexp-str> [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv6	Display BGP information for IPv6 address family
regexp	Display routes matching the AS path regular expression
<i>regexp-str</i>	Regular expression to match the AS paths

Command Mode

- /exec

show ipv6 bgp summary

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]  
summary [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
summary	Display summarized information of BGP state
ipv6	Display BGP information for IPv6 address family

Command Mode

- /exec

show ipv6 client

```
show ipv6 client [ <client-name> ] [ __readonly__ { TABLE_ipv6_client { <cli-name> <cli-stat> <cli-pid>
<cli-ext-pid> [ <protocol> ] <pib-index> <cli-uuid> <rou-vrf> <rou-flg> <ctrl-sap> <data-sap> <ipc-ctrl-mq>
<ipc-ctrl-fail> <ipc-data-mq> <ipc-data-fail> [ <if-ext-ind> ] [ <recv-fn> <recv-hex> ] } } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
client	Display clients registered with the IPv6 process
<i>client-name</i>	(Optional) Display information for a single IPv6 client
<i>__readonly__</i>	(Optional)
TABLE_ipv6_client	(Optional) IPV6 client table
<i>cli-name</i>	(Optional) client name
<i>cli-stat</i>	(Optional) client state
<i>cli-pid</i>	(Optional) client pid
<i>cli-ext-pid</i>	(Optional) client ext-pid
<i>protocol</i>	(Optional) ipv6 client protocol
<i>pib-index</i>	(Optional) client pib-index
<i>cli-uuid</i>	(Optional) client uuid
<i>rou-vrf</i>	(Optional) client route vrf
<i>rou-flg</i>	(Optional) client route flag
<i>ctrl-sap</i>	(Optional) client control sap
<i>data-sap</i>	(Optional) client data sap
<i>ipc-ctrl-mq</i>	(Optional) client ipc control message queue
<i>ipc-ctrl-fail</i>	(Optional) client ipc control fail
<i>ipc-data-mq</i>	(Optional) client ipc data message queue
<i>ipc-data-fail</i>	(Optional) client ipc data fail
<i>if-ext-ind</i>	(Optional) client if ext indes
<i>recv-fn</i>	(Optional) client receive fn name
<i>recv-hex</i>	(Optional) receive-hexadecimal address

Command Mode

- /exec

show ipv6 dhcp guard policy

```
show ipv6 dhcp guard policy [ <pname> ] [ __readonly__ { TABLE_dhcp_guard_policy <name> <role> [
<target> ] [ <max_pref> ] [ <min_pref> ] [ <match_src_list> ] [ <match_prefix_list> ] } ]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
<i>pname</i>	(Optional) Policy name for dhcp guard feature
<i>__readonly__</i>	(Optional)
TABLE_dhcp_guard_policy	(Optional) IPv6 DHCP guard policy
<i>name</i>	(Optional) Policy Name
<i>role</i>	(Optional) Role
<i>target</i>	(Optional) Target
<i>max_pref</i>	(Optional) Max preference
<i>min_pref</i>	(Optional) Min preference
<i>match_src_list</i>	(Optional) Source Address Match Access List
<i>match_prefix_list</i>	(Optional) Prefix List Match Prefix List

Command Mode

- /exec

show ipv6 dhcp relay

```
show ipv6 dhcp relay [ interface <intf-range> ] [ __readonly__ [ <relay_service_enable> [ <gbl_src_intf> ]
<relay_vpn_enable> <relay_cisco_option_enable> ] [ TABLE_intf <interface-name> [ <intf_src_intf> ]
<intf_header> [ TABLE_addr <relay_address> <dst_intf> <vrf_name> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
dhcp	Show DHCPv6
relay	DHCPv6 relay address of the interface
interface	(Optional) DHCPv6 relay address of the interface
<i>intf-range</i>	(Optional) interface
<i>__readonly__</i>	(Optional) Read only
<i>relay_service_enable</i>	(Optional) is dhcpv6 relay service enabled
<i>gbl_src_intf</i>	(Optional) interface name
<i>relay_vpn_enable</i>	(Optional) is dhcpv6 relay insertion of vpn sub options enabled
<i>relay_cisco_option_enable</i>	(Optional) is dhcpv6 relay cisco option enabled
TABLE_intf	(Optional)
<i>interface-name</i>	(Optional) interface name
<i>intf_src_intf</i>	(Optional) interface name
<i>intf_header</i>	(Optional) interface header
TABLE_addr	(Optional)
<i>dst_intf</i>	(Optional) interface name
<i>vrf_name</i>	(Optional) VRF name

Command Mode

- /exec

show ipv6 dhcp relay statistics

```
show ipv6 dhcp relay statistics [ interface <intf> [ [ server-ip <ip-addr-val> [ use-vrf <vrf-name> ] [ interface
<dest-interface> ] ] ] [ server-ip <ip-addr-val> [ interface <dest-interface> ] [ use-vrf <vrf-name> ] ] ] [
__readonly__ [ <msg_stats_hdr> <msg_type_str> <rx_pkts> <tx_pkts> <drops> <msg_type_str_advertise>
<rx_pkts_advertise> <tx_pkts_advertise> <drops_advertise> <msg_type_str_request> <rx_pkts_request>
<tx_pkts_request> <drops_request> <msg_type_str_confirm> <rx_pkts_confirm> <tx_pkts_confirm>
<drops_confirm> <msg_type_str_renew> <rx_pkts_renew> <tx_pkts_renew> <drops_renew>
<msg_type_str_rebind> <rx_pkts_rebind> <tx_pkts_rebind> <drops_rebind> <msg_type_str_reply>
<rx_pkts_reply> <tx_pkts_reply> <drops_reply> <msg_type_str_release> <rx_pkts_release> <tx_pkts_release>
<drops_release> <msg_type_str_decline> <rx_pkts_decline> <tx_pkts_decline> <drops_decline>
<msg_type_str_reconfigure> <rx_pkts_reconfigure> <tx_pkts_reconfigure> <drops_reconfigure>
<msg_type_str_inforeq> <rx_pkts_inforeq> <tx_pkts_inforeq> <drops_inforeq> <msg_type_str_relay_fwd>
<rx_pkts_relay_fwd> <tx_pkts_relay_fwd> <drops_relay_fwd> <msg_type_str_relay_reply>
<rx_pkts_relay_reply> <tx_pkts_relay_reply> <drops_relay_reply> <msg_type_str_unknown>
<rx_pkts_unknown> <tx_pkts_unknown> <drops_unknown> <msg_type_str_total> <rx_pkts_total>
<tx_pkts_total> <drops_total> ] [ <server_stats_hdr> [ TABLE_server <server_helper_addr> <server_vrf>
<server_intf> <server_requests> <server_responses> ] ] [ <drop_hdr> <drop_relay_disable> <drop_max_hops>
<drop_validation_fails> <drop_unknown_op_intf> <drop_bad_context> <drop_opt_insert_fail>
<drop_server_direct_reply> <drop_no_ipv6_addr> <drop_intf_error> <drop_vpn_disabled>
<drop_ipv6_extn_hdrs_presence> <drop_mct_drop> ] ]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
dhcp	Show information about DHCPv6
relay	DHCPv6 Relay
statistics	Statistics related to DHCPv6
interface	(Optional) input interface
<i>intf</i>	(Optional) interface
server-ip	(Optional) Server address
use-vrf	(Optional) server address VRF membership
<i>vrf-name</i>	(Optional) VRF name
interface	(Optional) Destination interface for the server address
<i>dest-interface</i>	(Optional) Destination interface
<i>__readonly__</i>	(Optional) Read only
<i>msg_stats_hdr</i>	(Optional) dhcpv6 message statistics header
<i>msg_type_str</i>	(Optional) dhcpv6 message type

<i>rx_pkts</i>	(Optional) dhcpv6 received packets
<i>tx_pkts</i>	(Optional) dhcpv6 forwarded packets
<i>drops</i>	(Optional) dhcpv6 packet drops
<i>msg_type_str_advertise</i>	(Optional)
<i>rx_pkts_advertise</i>	(Optional)
<i>tx_pkts_advertise</i>	(Optional)
<i>drops_advertise</i>	(Optional)
<i>msg_type_str_request</i>	(Optional)
<i>rx_pkts_request</i>	(Optional)
<i>tx_pkts_request</i>	(Optional)
<i>drops_request</i>	(Optional)
<i>msg_type_str_confirm</i>	(Optional)
<i>rx_pkts_confirm</i>	(Optional)
<i>tx_pkts_confirm</i>	(Optional)
<i>drops_confirm</i>	(Optional)
<i>msg_type_str_renew</i>	(Optional)
<i>rx_pkts_renew</i>	(Optional)
<i>tx_pkts_renew</i>	(Optional)
<i>drops_renew</i>	(Optional)
<i>msg_type_str_rebind</i>	(Optional)
<i>rx_pkts_rebind</i>	(Optional)
<i>tx_pkts_rebind</i>	(Optional)
<i>drops_rebind</i>	(Optional)
<i>msg_type_str_reply</i>	(Optional)
<i>rx_pkts_reply</i>	(Optional)
<i>tx_pkts_reply</i>	(Optional)
<i>drops_reply</i>	(Optional)
<i>msg_type_str_release</i>	(Optional)
<i>rx_pkts_release</i>	(Optional)

<i>tx_pkts_release</i>	(Optional)
<i>drops_release</i>	(Optional)
<i>msg_type_str_decline</i>	(Optional)
<i>rx_pkts_decline</i>	(Optional)
<i>tx_pkts_decline</i>	(Optional)
<i>drops_decline</i>	(Optional)
<i>msg_type_str_reconfigure</i>	(Optional)
<i>rx_pkts_reconfigure</i>	(Optional)
<i>tx_pkts_reconfigure</i>	(Optional)
<i>drops_reconfigure</i>	(Optional)
<i>msg_type_str_inforeq</i>	(Optional)
<i>rx_pkts_inforeq</i>	(Optional)
<i>tx_pkts_inforeq</i>	(Optional)
<i>drops_inforeq</i>	(Optional)
<i>msg_type_str_relay_fwd</i>	(Optional)
<i>rx_pkts_relay_fwd</i>	(Optional)
<i>tx_pkts_relay_fwd</i>	(Optional)
<i>drops_relay_fwd</i>	(Optional)
<i>msg_type_str_relay_reply</i>	(Optional)
<i>rx_pkts_relay_reply</i>	(Optional)
<i>tx_pkts_relay_reply</i>	(Optional)
<i>drops_relay_reply</i>	(Optional)
<i>msg_type_str_unknown</i>	(Optional)
<i>rx_pkts_unknown</i>	(Optional)
<i>tx_pkts_unknown</i>	(Optional)
<i>drops_unknown</i>	(Optional)
<i>msg_type_str_total</i>	(Optional) total of all dhcpv6 message types
<i>rx_pkts_total</i>	(Optional)
<i>tx_pkts_total</i>	(Optional)

<i>drops_total</i>	(Optional)
<i>server_stats_hdr</i>	(Optional) per-server statistics header
TABLE_server	(Optional)
<i>server_vrf</i>	(Optional) dhcpv6 server vrf
<i>server_intf</i>	(Optional) interface name
<i>server_requests</i>	(Optional)
<i>server_responses</i>	(Optional)
<i>drop_hdr</i>	(Optional)
<i>drop_relay_disable</i>	(Optional)
<i>drop_max_hops</i>	(Optional)
<i>drop_validation_fails</i>	(Optional)
<i>drop_unknown_op_intf</i>	(Optional)
<i>drop_bad_context</i>	(Optional)
<i>drop_opt_insert_fail</i>	(Optional)
<i>drop_server_direct_reply</i>	(Optional)
<i>drop_no_ipv6_addr</i>	(Optional)
<i>drop_intf_error</i>	(Optional)
<i>drop_vpn_disabled</i>	(Optional)
<i>drop_ipv6_extn_hdrs_presence</i>	(Optional)
<i>drop_mct_drop</i>	(Optional) drops through mct

Command Mode

- /exec

show ipv6 eigrp route-map statistics

```
show ipv6 eigrp [ <eigrp-ptag> ] route-map statistics { { redistribute { bgp <as> | { eigrp | isis | ospfv3 | rip
} <tag> | static | direct | amt } } | table-map } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_asn <asn> TABLE_vrf <vrf> { TABLE_rmap <name> <action> <seq_num> [ { TABLE_cmd
<command> <compare_count> <match_count> } ] } <total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
eigrp	Display EIGRP status and configuration
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>eigrp-ptag</i>	(Optional) Process tag
route-map	Route-map related information
statistics	Route-map statistics
redistribute	Redistribute information from another routing protocol
table-map	Tablemap information
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
isis	IS-IS Routing for IPv4
ospfv3	Open Shortest Path First (OSPF) V3
rip	Routing Information Protocol (RIP)
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
<i>tag</i>	Process tag
static	Static routes
direct	Directly connected
amt	AMT Anycast prefix
__readonly__	(Optional)

TABLE_asn	(Optional) AS number table
<i>asn</i>	(Optional) AS number
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
TABLE_rmap	(Optional) Route-map table
<i>name</i>	(Optional) Route-map name
<i>action</i>	(Optional) Route-map action
<i>seq_num</i>	(Optional) Sequence number of the clause
TABLE_cmd	(Optional) Route-map command table
<i>command</i>	(Optional) Route-map command
<i>compare_count</i>	(Optional) Number of comparisons
<i>match_count</i>	(Optional) Number of matches
<i>total_accept_count</i>	(Optional) Total number of packets accepted by this policy
<i>total_reject_count</i>	(Optional) Total number of packets rejected by this policy

Command Mode

- /exec

show ipv6 fragments

```
show ipv6 fragments [ <source-addr> ] [ __readonly__ [ TABLE_ipv6_frag [ TABLE_ipv6_each_q {
<ipv6-src> <ipv6-dest> <frag-id> <frag-off> <m-flag> <nxt-header> <pay-load> <expires> } ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
fragments	Display queued fragments
__readonly__	(Optional)
TABLE_ipv6_frag	(Optional) IPV6 fragment table
TABLE_ipv6_each_q	(Optional) IPV6 each fragment queue table
<i>frag-id</i>	(Optional) fragment id
<i>frag-off</i>	(Optional) fragment offset
<i>m-flag</i>	(Optional) m flag
<i>nxt-header</i>	(Optional) next header
<i>pay-load</i>	(Optional) fargment payload
<i>expires</i>	(Optional) expiry time

Command Mode

- /exec

show ipv6 icmp

```
show ipv6 icmp { adjacency | neighbor | sync-entries } [ <interface> ] [ detail ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ { <icmpv6-vrftype> <icmpv6-cxt-name> } [ TABLE_icmpv6_all_int
{ TABLE_icmpv6_one_int { <icmpv6-ipv6-addr> <time-stamp-icmpv6> <icmpv6-mac> <icmpv6-state>
<icmpv6-short-name> [ <phy-int-short-name> ] } } ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	Display ICMPv6 information
adjacency	Show IPv6 dynamic learnt adjacency entry
neighbor	Show IPv6 dynamic learnt neighbor entry
sync-entries	Show IPv6 table learnt only due to table sync
<i>interface</i>	(Optional) Interface name to display
detail	(Optional) Display detailed information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>icmpv6-vrftype</i>	(Optional)
<i>icmpv6-cxt-name</i>	(Optional)
TABLE_icmpv6_all_int	(Optional)
TABLE_icmpv6_one_int	(Optional)
<i>time-stamp-icmpv6</i>	(Optional)
<i>icmpv6-mac</i>	(Optional)
<i>icmpv6-state</i>	(Optional)
<i>icmpv6-short-name</i>	(Optional)
<i>phy-int-short-name</i>	(Optional)

Command Mode

- /exec

show ipv6 icmp global traffic

```
show ipv6 { icmp | nd } global traffic [ __readonly__ [ { TABLE_icmpv6_global_stat [ <st-total> ] [ <rv-total> ] [ <st-err> ] [ <rv-err> ] [ <st-int-drp-cnt> ] [ <rv-int-drp-cnt> ] [ <st-adj-nt-recov-am-ha> ] [ <rv-adj-nt-recov-am-ha> ] [ <st-pkt-allow-inv-ttl-vpc> ] [ <rv-pkt-allow-inv-ttl-vpc> ] [ <st-drp-src-mac-own> ] [ <rv-drp-src-mac-own> ] [ <st-drp-tgt-ip-not-own> ] [ <rv-drp-tgt-ip-not-own> ] [ <st-drp-src-ip-not-own> ] [ <rv-drp-src-ip-not-own> ] [ <st-dest-unreach> ] [ <rv-dest-unreach> ] [ <st-admin-prohibit> ] [ <rv-admin-prohibit> ] [ <st-time-exceed> ] [ <rv-time-exceed> ] [ <st-para-pbms> ] [ <rv-para-pbms> ] [ <st-echo-req> ] [ <rv-echo-req> ] [ <st-echo-reply> ] [ <rv-echo-reply> ] [ <st-redirect> ] [ <rv-redirect> ] [ <st-pkt-too-big> ] [ <rv-pkt-too-big> ] [ <st-rtr-adver> ] [ <rv-rtr-adver> ] [ <st-rtr-solicit> ] [ <rv-rtr-solicit> ] [ <st-nei-adver> ] [ <rv-nei-adver> ] [ <st-nei-solicit> ] [ <rv-nei-solicit> ] [ <fast-path-pkts> ] [ <fastpath-disable> ] [ <ign-fastpath-pkts> ] [ <dup-rtr-ra-recvd> ] [ <rv-dup-rtr-ra-recvd> ] } ] [ { TABLE_icmpv6_mld_stat <st-v1-queries> <rv-v1-queries> <st-v2-queries> <rv-v2-queries> <st-v1-reports> <rv-v1-reports> <st-v2-reports> <rv-v2-reports> <st-v1-leaves> <rv-v1-leaves> } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	Display ICMPv6 information
nd	ICMPv6 Neighbor Discovery commands
global	Show ICMPv6/ND global variables
traffic	Display ICMPv6 software processed traffic statistics
__readonly__	(Optional)
TABLE_icmpv6_global_stat	(Optional) ICMPV6 global statistics
<i>st-total</i>	(Optional) total sent messages
<i>rv-total</i>	(Optional) total receive messages
<i>st-err</i>	(Optional) total sent error message
<i>rv-err</i>	(Optional) total receive error message
<i>st-int-drp-cnt</i>	(Optional) sent interface down drop count
<i>rv-int-drp-cnt</i>	(Optional) receive interface down drop count
<i>st-adj-nt-recov-am-ha</i>	(Optional) sent Adjacency not recovered from AM aft HA
<i>rv-adj-nt-recov-am-ha</i>	(Optional) receive Adjacency not recovered from AM aft HA
<i>st-pkt-allow-inv-ttl-vpc</i>	(Optional) sent Pkts allowed due to inv ttl on vPC-MCT
<i>rv-pkt-allow-inv-ttl-vpc</i>	(Optional) receive Pkts allowed due to inv ttl on vPC-MCT
<i>st-drp-src-mac-own</i>	(Optional) sent packet drop source mac address own

<i>rv-drp-src-mac-own</i>	(Optional) receive packet drop source mac address own
<i>st-drp-tgt-ip-not-own</i>	(Optional) sent drop tgt ip address not own
<i>rv-drp-tgt-ip-not-own</i>	(Optional) receive drop tgt ip address not own
<i>st-drp-src-ip-not-own</i>	(Optional) sent dropped source ip address
<i>rv-drp-src-ip-not-own</i>	(Optional) receive dropped source ip address
<i>st-dest-unreach</i>	(Optional) sent destination unreachable
<i>rv-dest-unreach</i>	(Optional) receive destination unreachable
<i>st-admin-prohibit</i>	(Optional) sent Administratively Prohibited
<i>rv-admin-prohibit</i>	(Optional) receive Administratively Prohibited
<i>st-time-exceed</i>	(Optional) sent time exceeded
<i>rv-time-exceed</i>	(Optional) receive time exceeded
<i>st-para-pbms</i>	(Optional) sent parameter problems
<i>rv-para-pbms</i>	(Optional) receive parameter problems
<i>st-echo-req</i>	(Optional) sent echo request
<i>rv-echo-req</i>	(Optional) receive echo request
<i>st-echo-reply</i>	(Optional) sent echo replies
<i>rv-echo-reply</i>	(Optional) receive echo replies
<i>st-redirect</i>	(Optional) sent redirects
<i>rv-redirect</i>	(Optional) receive redirects
<i>st-pkt-too-big</i>	(Optional) sent packet too big
<i>rv-pkt-too-big</i>	(Optional) receive packet too big
<i>st-rtr-adver</i>	(Optional) sent router advertisements
<i>rv-rtr-adver</i>	(Optional) receive router advertisements
<i>st-rtr-solicit</i>	(Optional) sent router solicitations
<i>rv-rtr-solicit</i>	(Optional) receive router solicitations
<i>st-nei-adver</i>	(Optional) sent neighbor advertisements
<i>rv-nei-adver</i>	(Optional) receive neighbor advertisements
<i>st-nei-solicit</i>	(Optional) sent neighbor solicitations
<i>rv-nei-solicit</i>	(Optional) receive neighbor solicitations

<i>fast-path-pkts</i>	(Optional) fastpath packets
<i>fastpath-disable</i>	(Optional) [fastpath disabled / others]
<i>ign-fastpath-pkts</i>	(Optional) Packets drop request ignore count
<i>dup-rtr-ra-recvd</i>	(Optional) Duplicate router RA sent
<i>rv-dup-rtr-ra-recvd</i>	(Optional) Duplicate router RA received
TABLE_icmpv6_mld_stat	(Optional) ICMPv6 MLD Statistics
<i>st-v1-queries</i>	(Optional) V1 Queries sent
<i>rv-v1-queries</i>	(Optional) V1 Queries recieved
<i>st-v2-queries</i>	(Optional) V2 Queries sent
<i>rv-v2-queries</i>	(Optional) V2 Queries received
<i>st-v1-reports</i>	(Optional) V1 Reports sent
<i>rv-v1-reports</i>	(Optional) V1 Reports received
<i>st-v2-reports</i>	(Optional) V2 Reports sent
<i>rv-v2-reports</i>	(Optional) V2 Reports received
<i>st-v1-leaves</i>	(Optional) V1 Leaves sent
<i>rv-v1-leaves</i>	(Optional) V1 Leaves received

Command Mode

- /exec

show ipv6 icmp interface

```
{ show ipv6 { icmp | nd } interface [ <interface> ] { [ prefix [ full ] ] [ route ] [ detail ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] } | { show ipv6 [ icmp ] mld interface [ brief ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] } | { show ipv6 [ icmp ] mld interface <interface> } [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_intf <intf-name> <proto-state> <link-state> <admin-state> [ TABLE_addr <addr> ] <subnet> <link-local-addr> <icmpv6-disabled> <last-ns-sent> <last-na-sent> <last-ra-sent> <next-na-sent> <ra-min-interval> <ra-interval> <set-m-flag> <set-o-flag> <current-hop-limit> <mtu> <router-lifetime> <reachable-time> <retrans-timer> <ns-interval> <send-redirect> <send-unreachables> <mld-disabled> <mld-querier> <mld-entry-count> <mld-config-version> <mld-querier-version> <mld-host-version> <mld-query-timer> <mld-querier-expiry> <mld-qi> <mld-config-qi> <mld-query-mrt> <mld-config-query-mrt> <mld-startup-qi> <mld-config-startup-qi> <mld-startup-qc> <mld-config-last-member-mrt> <mld-last-member-qc> <mld-group-timeout> <mld-config-group-timeout> <mld-querier-timeout> <mld-config-querier-timeout> <mld-config-unsol-rpt-interval> <mld-qrv> <mld-config-robustness-variable> <mld-config-rpt-link-local> <mld-refcount> <static-group-map> <join-group-map> <ra-sent> <ra-rec> <rs-sent> <rs-rec> <na-sent> <na-rec> <ns-sent> <ns-rec> <redirect-sent> <redirect-rec> <msg-sent> <msg-rec> <errors-sent> <erros-rec> <ifdown-sent> <ifdown-rec> <am-ha-not-ready> <allow-mct-ttl> <our-own-mac> <tgt-not-us> <dest-unreachs-sent> <dest-unreachs-rec> <admin-prohibs-sent> <admin-prohibs-rec> <time-excds-sent> <time-excds-rec> <parm-problems-sent> <parm-problems-rec> <echos-sent> <echos-rec> <echo-replies-sent> <echo-replies-rec> <pkt-toobigs-sent> <pkt-toobigs-rec> <fastpath-pkt-recv> <fastpath-disable-pkt-recv> <fastpath-ignore-pkt-recv> <v1-queries-sent> <v1-queries-rec> <v2-queries-sent> <v2-queries-rec> <v1-reports-sent> <v1-reports-rec> <v2-reports-sent> <v2-reports-rec> <v1-leaves-sent> <v1-leaves-rec> <v2-leaves-sent> <v2-leaves-rec> <uptime> <mld-config-il> [ TABLE_one_int <grp-id> <protocol-one-int> <client-uuid> <client-state-act> <client-in-use> TABLE_vip_list <virt-ipv6> <virt-mac> <context_name> <context_id> <last-solocit-st> <last-nei-ad-st> <last-rtr-adv-st> <nxt-rtr-ad-st> ] <max-dad-attempts> <current-dad-attempts> [ TABLE_route <route> <preference> <lifetime> <info-option> <reachability-verify-enabled> <adv-route-info> <route-zero-lifetime> ] [ TABLE_prefix <prefix> <enabled> <vlaidlife-time> <preferredlife-time> <on-link> <off-link> <autonomous> ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	Display ICMPv6 information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
nd	ICMPv6 Neighbor Discovery commands
mld	Display Multicast Listener Discovery information
interface	Display ICMPv6 related interface information
prefix	(Optional) Display List of ICMPv6 RA prefix

<code>route</code>	(Optional) Display List of ICMPv6 RA routes
<code>full</code>	(Optional) Display Complete prefix information
<code>detail</code>	(Optional) Display ICMPv6 related interface information in detail
<code>brief</code>	(Optional) Display ICMPv6 related interface information in brief
<code>interface</code>	(Optional) Interface name to show
<code>__readonly__</code>	(Optional)
<code>TABLE_vrf</code>	(Optional)
<code>vrf-name-out</code>	(Optional)
<code>TABLE_intf</code>	(Optional)
<code>intf-name</code>	(Optional)
<code>proto-state</code>	(Optional)
<code>link-state</code>	(Optional)
<code>admin-state</code>	(Optional)
<code>TABLE_addr</code>	(Optional)
<code>icmpv6-disabled</code>	(Optional)
<code>last-ns-sent</code>	(Optional)
<code>last-na-sent</code>	(Optional)
<code>last-ra-sent</code>	(Optional)
<code>next-na-sent</code>	(Optional)
<code>ra-min-interval</code>	(Optional)
<code>ra-interval</code>	(Optional)
<code>set-m-flag</code>	(Optional)
<code>set-o-flag</code>	(Optional)
<code>current-hop-limit</code>	(Optional)
<code>mtu</code>	(Optional)
<code>router-lifetime</code>	(Optional)
<code>reachable-time</code>	(Optional)
<code>retrans-timer</code>	(Optional)
<code>ns-interval</code>	(Optional)

<i>send-redirect</i>	(Optional)
<i>send-unreachables</i>	(Optional)
<i>mld-disabled</i>	(Optional)
<i>mld-entry-count</i>	(Optional)
<i>mld-config-version</i>	(Optional)
<i>mld-querier-version</i>	(Optional)
<i>mld-host-version</i>	(Optional)
<i>mld-query-timer</i>	(Optional)
<i>mld-querier-expiry</i>	(Optional)
<i>mld-qi</i>	(Optional)
<i>mld-config-qi</i>	(Optional)
<i>mld-query-mrt</i>	(Optional)
<i>mld-config-query-mrt</i>	(Optional)
<i>mld-startup-qi</i>	(Optional)
<i>mld-config-startup-qi</i>	(Optional)
<i>mld-startup-qc</i>	(Optional)
<i>mld-config-last-member-mrt</i>	(Optional)
<i>mld-last-member-qc</i>	(Optional)
<i>mld-group-timeout</i>	(Optional)
<i>mld-config-group-timeout</i>	(Optional)
<i>mld-querier-timeout</i>	(Optional)
<i>mld-config-querier-timeout</i>	(Optional)
<i>mld-config-unsol-rpt-interval</i>	(Optional)
<i>mld-grv</i>	(Optional)
<i>mld-config-robustness-variable</i>	(Optional)
<i>mld-config-rpt-link-local</i>	(Optional)
<i>mld-refcount</i>	(Optional)
<i>static-group-map</i>	(Optional)
<i>join-group-map</i>	(Optional)

<i>ra-sent</i>	(Optional)
<i>ra-rec</i>	(Optional)
<i>rs-sent</i>	(Optional)
<i>rs-rec</i>	(Optional)
<i>na-sent</i>	(Optional)
<i>na-rec</i>	(Optional)
<i>ns-sent</i>	(Optional)
<i>ns-rec</i>	(Optional)
<i>redirect-sent</i>	(Optional)
<i>redirect-rec</i>	(Optional)
<i>msg-sent</i>	(Optional)
<i>msg-rec</i>	(Optional)
<i>errors-sent</i>	(Optional)
<i>erros-rec</i>	(Optional)
<i>ifdown-sent</i>	(Optional)
<i>ifdown-rec</i>	(Optional)
<i>am-ha-not-ready</i>	(Optional)
<i>allow-mct-ttl</i>	(Optional)
<i>our-own-mac</i>	(Optional)
<i>tgt-not-us</i>	(Optional)
<i>dest-unreachs-sent</i>	(Optional)
<i>dest-unreachs-rec</i>	(Optional)
<i>admin-prohibs-sent</i>	(Optional)
<i>admin-prohibs-rec</i>	(Optional)
<i>time-excds-sent</i>	(Optional)
<i>time-excds-rec</i>	(Optional)
<i>parm-problems-sent</i>	(Optional)
<i>parm-problems-rec</i>	(Optional)
<i>echos-sent</i>	(Optional)

<i>echos-rec</i>	(Optional)
<i>echo-replies-sent</i>	(Optional)
<i>echo-replies-rec</i>	(Optional)
<i>pkt-toobigs-sent</i>	(Optional)
<i>pkt-toobigs-rec</i>	(Optional)
<i>fastpath-pkt-recv</i>	(Optional)
<i>fastpath-disable-pkt-recv</i>	(Optional)
<i>fastpath-ignore-pkt-recv</i>	(Optional)
<i>v1-queries-sent</i>	(Optional)
<i>v1-queries-rec</i>	(Optional)
<i>v2-queries-sent</i>	(Optional)
<i>v2-queries-rec</i>	(Optional)
<i>v1-reports-sent</i>	(Optional)
<i>v1-reports-rec</i>	(Optional)
<i>v2-reports-sent</i>	(Optional)
<i>v2-reports-rec</i>	(Optional)
<i>v1-leaves-sent</i>	(Optional)
<i>v1-leaves-rec</i>	(Optional)
<i>v2-leaves-sent</i>	(Optional)
<i>v2-leaves-rec</i>	(Optional)
<i>uptime</i>	(Optional)
<i>mld-config-il</i>	(Optional)
TABLE_one_int	(Optional)
<i>grp-id</i>	(Optional)
<i>protocol-one-int</i>	(Optional)
<i>client-uuid</i>	(Optional)
<i>client-state-act</i>	(Optional)
<i>client-in-use</i>	(Optional)
TABLE_vip_list	(Optional)

<i>virt-mac</i>	(Optional)
<i>context_name</i>	(Optional)
<i>context_id</i>	(Optional)
<i>last-solocit-st</i>	(Optional)
<i>last-nei-ad-st</i>	(Optional)
<i>last-rtr-adv-st</i>	(Optional)
<i>nxt-rtr-ad-st</i>	(Optional)
<i>max-dad-attempts</i>	(Optional)
<i>current-dad-attempts</i>	(Optional)
TABLE_route	(Optional)
<i>preference</i>	(Optional)
<i>lifetime</i>	(Optional)
<i>info-option</i>	(Optional)
<i>reachability-verify-enabled</i>	(Optional)
<i>adv-route-info</i>	(Optional)
<i>route-zero-lifetime</i>	(Optional)
TABLE_prefix	(Optional)
<i>enabled</i>	(Optional)
<i>vlaidlif-time</i>	(Optional)
<i>preferredlif-time</i>	(Optional)
<i>on-link</i>	(Optional)
<i>off-link</i>	(Optional)
<i>autonomous</i>	(Optional)

Command Mode

- /exec

show ipv6 icmp off-list

```
show ipv6 icmp off-list [ vlan <vlan-id> ] [ __readonly__ [ <vlan-adj-cnt> ] [ <icmpv6-sync-adj-cnt> ] {
TABLE_icmpv6_vlan_list <adj-vlan-id> <off-adj-ip-addr> <icmpv6-time-stamp> <icmpv6-mac-addr>
<off-adj-flags> } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	Display ICMPv6 information
off-list	Show adjacencies in off-list icmpv6 database
vlan	(Optional) Vlan id
<i>vlan-id</i>	(Optional) Show information for specified vlan
<i>__readonly__</i>	(Optional)
<i>vlan-adj-cnt</i>	(Optional) vlan adjacency count
<i>icmpv6-sync-adj-cnt</i>	(Optional) icmpv6 sync adjacency count
TABLE_icmpv6_vlan_list	(Optional) icmpv6 vlan list table
<i>adj-vlan-id</i>	(Optional) adjacency vlan id
<i>icmpv6-time-stamp</i>	(Optional) icmpv6 time stamp
<i>icmpv6-mac-addr</i>	(Optional) icmpv6 mac address
<i>off-adj-flags</i>	(Optional) offlist adjacency flags

Command Mode

- /exec

TABLE_glo_vrf	(Optional)
<i>group-id</i>	(Optional)
<i>protocol-vrf</i>	(Optional)
<i>cli-uuid</i>	(Optional)
<i>vaddr-action</i>	(Optional)
<i>vrf-interface</i>	(Optional)
<i>vaddr-mac</i>	(Optional)
<i>cxt-name</i>	(Optional)
<i>cxt-id</i>	(Optional)
TABLE_one_int	(Optional)
<i>lcache-inter</i>	(Optional)
<i>cxt-name-int</i>	(Optional)
<i>cxt_id-int</i>	(Optional)
<i>grp-id</i>	(Optional)
<i>protocol-one-int</i>	(Optional)
<i>client-uuid</i>	(Optional)
<i>client-state-act</i>	(Optional)
<i>client-in-use</i>	(Optional)
<i>client-state</i>	(Optional)
TABLE_one_group	(Optional)
TABLE_vip_list	(Optional)
<i>virt-mac</i>	(Optional)
<i>cxt_name</i>	(Optional)
<i>cxt_id</i>	(Optional)
<i>last-solocit-st</i>	(Optional)
<i>last-nei-ad-st</i>	(Optional)
<i>last-rtr-adv-st</i>	(Optional)
<i>nxt-rtr-ad-st</i>	(Optional)
<i>vmac-addr</i>	(Optional)

<i>st-total</i>	(Optional)
<i>rv-total</i>	(Optional)
<i>st-err</i>	(Optional)
<i>rv-err</i>	(Optional)
<i>st-int-dwn-drp</i>	(Optional)
<i>rv-int-dwn-drp</i>	(Optional)
<i>st-adj-nt-recov-am</i>	(Optional)
<i>rv-adj-nt-recov-am</i>	(Optional)
<i>st-pkt-allow-inv-ttl</i>	(Optional)
<i>rv-pkt-allow-inv-ttl</i>	(Optional)
<i>st-pkt-drp-src-mac-own</i>	(Optional)
<i>rv-pkt-drp-src-mac-own</i>	(Optional)
<i>st-pkt-drp-tgt-not-own</i>	(Optional)
<i>rv-pkt-drp-tgt-not-own</i>	(Optional)
<i>st-pkt-drp-src-not-own</i>	(Optional)
<i>rv-pkt-drp-src-not-own</i>	(Optional)
<i>st-dest-unreach</i>	(Optional)
<i>rv-dest-unreach</i>	(Optional)
<i>st-admin-prohi</i>	(Optional)
<i>rv-admin-prohi</i>	(Optional)
<i>st-time-exceed</i>	(Optional)
<i>rv-time-exceed</i>	(Optional)
<i>st-patr-pbm</i>	(Optional)
<i>rv-patr-pbm</i>	(Optional)
<i>st-echo-req</i>	(Optional)
<i>rv-echo-req</i>	(Optional)
<i>st-echo-reply</i>	(Optional)
<i>rv-echo-reply</i>	(Optional)
<i>st-dup-ra</i>	(Optional)

<i>rv-dup-ra</i>	(Optional)
<i>st-redirect</i>	(Optional)
<i>rv-redirect</i>	(Optional)
<i>st-pkt-too-big</i>	(Optional)
<i>rv-pkt-too-big</i>	(Optional)
<i>st-rtr-adver</i>	(Optional)
<i>rv-rtr-adver</i>	(Optional)
<i>st-rtr-solicit</i>	(Optional)
<i>rv-rtr-solicit</i>	(Optional)
<i>st-nei-adver</i>	(Optional)
<i>rv-nei-adver</i>	(Optional)
<i>st-nei-solicit</i>	(Optional)
<i>rv-nei-solicit</i>	(Optional)

Command Mode

- /exec

show ipv6 icmp vpc-statistics

```
show ipv6 icmp vpc-statistics [ __readonly__ [ { TABLE_ icmpv6_vpc_stats [ <icmpv6-pro-drp-pull-disable>
] [ <icmpv6-pro-drp-push-msg-disable> ] [ <icmpv6-pro-ign-snd-pull-disabe> ] [
<icmpv6-ign-snd-push-disable> ] [ <icmpv6-drp-im-fail> ] [ <icmpv6-drp-mcecm-fail> ] [
<icmpv6-drp-invalid-pc-iod> ] [ <icmpv6-drp-pt-lookup-fail> ] [ <icmpv6-drp-resp-fail-no-mct> ] [
<icmpv6-drp-resp-fail> ] [ <icmpv6-vpc-id-ifindx-sending-pushmsg> ] [ <icmpv6-vpc-id-proc-cfs-payload>
] [ <icmpv6-resp-sent> ] [ <icmpv6-resp-recvd> ] [ <icmpv6-resp-recv-err> ] [ <icmpv6-rcvd-msg> ] [
<icmpv6-send-fail> ] [ <icmpv6-cfs-rel-dlvry-fail> ] [ <icmpv6-cfs-rel-dnvry-suc> ] [ <icmpv6-drp-pt-add-fail>
] [ <icmpv6-drp-no-mem> ] [ <icmpv6-drp-tmr-cre-fail> ] [ <icmpv6-drp-add-adj-fail> ] [
<icmpv6-off-drp-pt-lookup-fail> ] [ <icmpv6-dont-drp-vlan-mismat> ] [ <icmpv6-drp-svi-invalid> ] [
<icmpv6-dont-drop-sv-down> ] [ <icmpv6-drp-mct-down> ] [ <icmpv6-drp-ctxt-invalid> ] [
<icmpv6-drp-vrf-invalid> ] [ <icmpv6-drp-l3addr-invalid> ] [ <icmpv6-drp-l3addr-sanity-fail> ] [
<icmpv6-drp-mac-sanity-fail> ] [ <icmpv6-own-rtr-mac> ] [ <icmpv6-drp-own-ipv6addr> ] [
<icmpv6-drp-own-vipv6add> ] [ <icmpv6-drp-adj-fail> ] [ <icmpv6-drp-subnet-mismatch> ] [
<icmpv6-drp-adj-exist> ] [ <icmpv6-dont-drp-ip-not-enable> ] [ <icmpv6-drp-total-cnt> ] [
<icmpv6-dont-drop-total-cnt> ] [ <icmpv6-add-adj> ] [ <icmpv6-del-adj> ] [ <icmpv6-adj-already-exist> ] [
<icmpv6-vpc-id-periodic-sync> ] [ <icmpv6-vpc-id-cfs-payload-periodic-sync> ] } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	Display ICMPv6 information
vpc-statistics	Show vPC global statistics
__readonly__	(Optional)
TABLE_ icmpv6_vpc_stats	(Optional) icmpv6 Vpc statistics
<i>icmpv6-pro-drp-pull-disable</i>	(Optional) icmpv6 protocol drop pull disable
<i>icmpv6-pro-drp-push-msg-disable</i>	(Optional) icmpv6 protocol drop push message disable
<i>icmpv6-pro-ign-snd-pull-disabe</i>	(Optional) icmpv6 protocol ignore send pull disable
<i>icmpv6-ign-snd-push-disable</i>	(Optional) icmpv6 ignore send push disable
<i>icmpv6-drp-im-fail</i>	(Optional) icmpv6 drop im fail
<i>icmpv6-drp-mcecm-fail</i>	(Optional) MCECM api failed while processing CFS payload
<i>icmpv6-drp-invalid-pc-iod</i>	(Optional) Invalid MCT port-channel iod while processing CFS payload
<i>icmpv6-drp-pt-lookup-fail</i>	(Optional) PT lookup failed while processing CFS payload
<i>icmpv6-drp-resp-fail-no-mct</i>	(Optional) invalid MCT iod while processing CFS payload
<i>icmpv6-drp-resp-fail</i>	(Optional) response failed while processing CFS payload
<i>icmpv6-vpc-id-ifindx-sending-pushmsg</i>	(Optional) Unable to retrieve VPC id ifindex while sending push message

<i>icmpv6-vpc-id-proc-cfs-payload</i>	(Optional) Unable to retrieve ifindex from vpc id
<i>icmpv6-vpc-id-periodic-sync</i>	(Optional) unable to retrieve vpc id ifindex for periodic sync
<i>icmpv6-vpc-id-cfs-payload-periodic-sync</i>	(Optional) unable to retrieve ifindex from vpc id while processing cfs payload for periodic sync
<i>icmpv6-resp-sent</i>	(Optional) Response sent via CFSOE
<i>icmpv6-resp-recvd</i>	(Optional) Response received via CFSOE
<i>icmpv6-resp-recv-err</i>	(Optional) Response received via CFSOE with errors
<i>icmpv6-rcvd-msg</i>	(Optional) Received message via CFSOE
<i>icmpv6-send-fail</i>	(Optional) Send message failed via CFSOE
<i>icmpv6-cfs-rel-dlvry-fail</i>	(Optional) MCECM send api failed via CFSOE
<i>icmpv6-cfs-rel-dnvry-suc</i>	(Optional) Send message succeeded via CFSOE
<i>icmpv6-drp-pt-add-fail</i>	(Optional) PT add failed while processing offlist database
<i>icmpv6-drp-no-mem</i>	(Optional) Memory alloc failed while processing offlist database
<i>icmpv6-drp-tmr-cre-fail</i>	(Optional) Timer create failed while processing offlist database
<i>icmpv6-drp-add-adj-fail</i>	(Optional) Adjacency addition failed while processing offlist database
<i>icmpv6-off-drp-pt-lookup-fail</i>	(Optional) PT lookup failed while processing offlist database
<i>icmpv6-dont-drp-vlan-mismat</i>	(Optional) VLAN mismatch while processing offlist database
<i>icmpv6-drp-svi-invalid</i>	(Optional) SVI is invalid while processing offlist database
<i>icmpv6-dont-drop-sv-down</i>	(Optional) SVI is down while processing offlist database
<i>icmpv6-drp-mct-down</i>	(Optional) MCT is down while processing offlist database
<i>icmpv6-drp-ctxt-invalid</i>	(Optional) Ctxt_type is invalid while processing offlist database
<i>icmpv6-drp-vrf-invalid</i>	(Optional) VRF is invalid while processing offlist database
<i>icmpv6-drp-l3addr-invalid</i>	(Optional) IP address is invalid while processing offlist database
<i>icmpv6-drp-l3addr-sanity-fail</i>	(Optional) IP address sanity failed while processing offlist database
<i>icmpv6-drp-mac-sanity-fail</i>	(Optional) MAC address sanity failed while processing offlist database
<i>icmpv6-own-rtr-mac</i>	(Optional) Our own router mac while processing offlist database
<i>icmpv6-drp-own-ipv6addr</i>	(Optional) Our own ip address while processing offlist database
<i>icmpv6-drp-own-vipv6add</i>	(Optional) Our own virtual ip address while processing offlist database
<i>icmpv6-drp-adj-fail</i>	(Optional) Create adjacency failed while processing offlist database

<i>icmpv6-drp-subnet-mismatch</i>	(Optional) Subnet mismatch while processing offlist database
<i>icmpv6-drp-adj-exist</i>	(Optional) Entry exists while processing offlist database
<i>icmpv6-dont-drp-ip-not-enable</i>	(Optional) IPv6 not enabled on interface while processing offlist database
<i>icmpv6-drp-total-cnt</i>	(Optional) Total drop count while processing offlist database
<i>icmpv6-dont-drop-total-cnt</i>	(Optional) Total don't drop count while processing offlist database
<i>icmpv6-add-adj</i>	(Optional) Total adjacency additions in offlist database
<i>icmpv6-del-adj</i>	(Optional) Total adjacency deletions in offlist database
<i>icmpv6-adj-already-exist</i>	(Optional) Total adjacencies ignored as they already exists in offlist database

Command Mode

- /exec

show ipv6 interface

```
show ipv6 interface { [ brief [ include-secondary ] ] [ <interface> | <ipv6-addr> ] [ detail ] } [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ [ TABLE_intf <vrf-name-out> <intf-name> [ <proto-state> ] [
<link-state> ] [ <admin-state> ] [ <iod> ] [ TABLE_addr <addr> ] [ <prefix> ] [ { TABLE_sec_addr [
<sec-prefix> ] } ] [ <linklocal-addr> ] [ <linklocal-configured> ] [ { TABLE_vaddr [ <v-addr> ] } ] [
<ipv6-disabled> ] [ <mrouting-enabled> ] [ <mgroup-locally-joined> ] [ { TABLE_maddr <m-addr> [
<m-addr-refcnt> ] } ] [ { TABLE_sg [ <sg-saddr> ] [ <sg-maddr> ] [ <sg-refcnt> ] } ] [ <mtu> ] [
<global-in-pcl-configured> ] [ <global-in-pcl-name> ] [ <global-in-pcl-pending> ] [ <global-out-pcl-configured>
] [ <global-out-pcl-name> ] [ <global-out-pcl-pending> ] [ <in-pcl-configured> ] [ <in-pcl-name> ] [
<in-pcl-pending> ] [ <out-pcl-configured> ] [ <out-pcl-name> ] [ <out-pcl-pending> ] [ <urpf-mode> ] [
<ipv6-lstype> ] [ <stats-last-reset> ] [ <acl-in> ] [ <acl-out> ] [ <upkt-fwd> ] [ <upkt-orig> ] [ <upkt-consumed>
] [ <ubyte-fwd> ] [ <ubyte-orig> ] [ <ubyte-consumed> ] [ <mpkt-fwd> ] [ <mpkt-orig> ] [ <mpkt-consumed>
] [ <mbyte-fwd> ] [ <mbyte-orig> ] [ <mbyte-consumed> ] [ <upkt-in-acc> ] [ <upkt-in-rej> ] [ <ubyte-in-acc>
] [ <ubyte-in-rej> ] [ <mpkt-in-acc> ] [ <mpkt-in-rej> ] [ <mbyte-in-acc> ] [ <mbyte-in-rej> ] [ <upkt-out-acc>
] [ <upkt-out-rej> ] [ <ubyte-out-acc> ] [ <ubyte-out-rej> ] [ <mpkt-out-acc> ] [ <mpkt-out-rej> ] [
<mbyte-out-acc> ] [ <mbyte-out-rej> ] [ <hw-upkt-sent> ] [ <hw-upkt-recv> ] [ <hw-ubyte-sent> ] [
<hw-ubyte-recv> ] [ <hw-mpkt-sent> ] [ <hw-mpkt-recv> ] [ <hw-mbyte-sent> ] [ <hw-mbyte-recv> ] [
<hw-upkt-drop> ] [ <hw-ubyte-drop> ] [ <hw-mpkt-drop> ] [ <hw-mbyte-drop> ] [ <hw-mpkt-rpdrop> ] [
<hw-mbyte-rpdrop> ] [ <hw-mpkt-dfdrop> ] [ <hw-mbyte-dfdrop> ] [ <unspecified-src> ] [
<total-pkt-recv-tent-addr> ] [ <total-pkts-recv-invalid-addr-state> ] [ <total-pkt-recv-dup-state> ] [
<anycast-pkt-arrived-tcp> ] [ <deliver-intf-down> ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
interface	Display IPv6 related interface information
brief	(Optional) Display summary of IPv6 status and configuration
include-secondary	(Optional) Display summary of all IPv6 addresses
<i>interface</i>	(Optional) Interface name to display
detail	(Optional) Display detailed IPv6 interface information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs
__readonly__	(Optional)
TABLE_addr	(Optional)
<i>vrf-name-out</i>	(Optional)

TABLE_intf	(Optional)
<i>intf-name</i>	(Optional)
<i>proto-state</i>	(Optional)
<i>link-state</i>	(Optional)
<i>admin-state</i>	(Optional)
<i>iod</i>	(Optional)
<i>addr</i>	(Optional)
<i>prefix</i>	(Optional)
TABLE_sec_addr	(Optional)
<i>sec-prefix</i>	(Optional)
<i>linklocal-configured</i>	(Optional)
TABLE_vaddr	(Optional)
<i>ipv6-disabled</i>	(Optional)
<i>mrouting-enabled</i>	(Optional)
<i>mgroup-locally-joined</i>	(Optional)
TABLE_maddr	(Optional)
<i>m-addr-refcnt</i>	(Optional)
TABLE_sg	(Optional)
<i>sg-refcnt</i>	(Optional)
<i>mtu</i>	(Optional)
<i>global-in-pcl-configured</i>	(Optional)
<i>global-in-pcl-name</i>	(Optional)
<i>global-in-pcl-pending</i>	(Optional)
<i>global-out-pcl-configured</i>	(Optional)
<i>global-out-pcl-name</i>	(Optional)
<i>global-out-pcl-pending</i>	(Optional)
<i>in-pcl-configured</i>	(Optional)
<i>in-pcl-name</i>	(Optional)
<i>in-pcl-pending</i>	(Optional)

<i>out-pcl-configured</i>	(Optional)
<i>out-pcl-name</i>	(Optional)
<i>out-pcl-pending</i>	(Optional)
<i>urpf-mode</i>	(Optional)
<i>ipv6-lstype</i>	(Optional)
<i>stats-last-reset</i>	(Optional)
<i>acl-in</i>	(Optional)
<i>acl-out</i>	(Optional)
<i>upkt-fwd</i>	(Optional)
<i>upkt-orig</i>	(Optional)
<i>upkt-consumed</i>	(Optional)
<i>ubyte-fwd</i>	(Optional)
<i>ubyte-orig</i>	(Optional)
<i>ubyte-consumed</i>	(Optional)
<i>mpkt-fwd</i>	(Optional)
<i>mpkt-orig</i>	(Optional)
<i>mpkt-consumed</i>	(Optional)
<i>mbyte-fwd</i>	(Optional)
<i>mbyte-orig</i>	(Optional)
<i>mbyte-consumed</i>	(Optional)
<i>upkt-in-acc</i>	(Optional)
<i>upkt-in-rej</i>	(Optional)
<i>ubyte-in-acc</i>	(Optional)
<i>ubyte-in-rej</i>	(Optional)
<i>mpkt-in-acc</i>	(Optional)
<i>mpkt-in-rej</i>	(Optional)
<i>mbyte-in-acc</i>	(Optional)
<i>mbyte-in-rej</i>	(Optional)
<i>upkt-out-acc</i>	(Optional)

<i>upkt-out-rej</i>	(Optional)
<i>ubyte-out-acc</i>	(Optional)
<i>ubyte-out-rej</i>	(Optional)
<i>mpkt-out-acc</i>	(Optional)
<i>mpkt-out-rej</i>	(Optional)
<i>mbyte-out-acc</i>	(Optional)
<i>mbyte-out-rej</i>	(Optional)
<i>hw-upkt-sent</i>	(Optional)
<i>hw-upkt-recv</i>	(Optional)
<i>hw-ubyte-sent</i>	(Optional)
<i>hw-ubyte-recv</i>	(Optional)
<i>hw-mpkt-sent</i>	(Optional)
<i>hw-mpkt-recv</i>	(Optional)
<i>hw-mbyte-sent</i>	(Optional)
<i>hw-mbyte-recv</i>	(Optional)
<i>hw-upkt-drop</i>	(Optional)
<i>hw-ubyte-drop</i>	(Optional)
<i>hw-mpkt-drop</i>	(Optional)
<i>hw-mbyte-drop</i>	(Optional)
<i>hw-mpkt-rpdrop</i>	(Optional)
<i>hw-mbyte-rpdrop</i>	(Optional)
<i>hw-mpkt-dfdrop</i>	(Optional)
<i>hw-mbyte-dfdrop</i>	(Optional)
<i>unspecified-src</i>	(Optional)
<i>total-pkt-recv-tent-addr</i>	(Optional)
<i>total-pkts-recv-invalid-addr-state</i>	(Optional)
<i>total-pkt-recv-dup-state</i>	(Optional)
<i>anycast-pkt-arrived-tcp</i>	(Optional)
<i>deliver-intf-down</i>	(Optional)

Command Mode

- /exec

show ipv6 lisp data-cache

```
show ipv6 lisp data-cache [ <eid> ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
lisp	LISP show commands
data-cache	Display EID-to-RLOC data cache mapping in this ITR
<i>eid</i>	(Optional) Display mapping for IPv6 destination EID
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show ipv6 local policy

```
show ipv6 local policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_pbr [
<interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
local	IPv6 local options
policy	Policy routing
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_pbr	(Optional)
<i>interface</i>	(Optional)
<i>rmap</i>	(Optional)
<i>status</i>	(Optional)
<i>vrf_name</i>	(Optional)

Command Mode

- /exec

show ipv6 mld groups

```
show ipv6 [ icmp ] mld groups [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ <interface> ] [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <vrf-name-out> <entry-count>
TABLE_group <group-out> TABLE_intf <intf-name> <icmpv6-disabled> <mld-source> <mld-group>
<mld-source-unspec> <mld-static> <mld-local-group> <mld-translated> <mld-uptime> <mld-expire> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	(Optional) Display ICMPv6 information
mld	Display Multicast Listener Discovery information
groups	Display MLD attached group membership information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>interface</i>	(Optional) Display group membership on interface name
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional) vrf table
<i>vrf-name-out</i>	(Optional) vrf name
<i>entry-count</i>	(Optional) entry count
TABLE_group	(Optional) group table
TABLE_intf	(Optional) interface table
<i>intf-name</i>	(Optional) interface name
<i>icmpv6-disabled</i>	(Optional) icmpv6 disabled
<i>mld-source-unspec</i>	(Optional) mld source unspecified
<i>mld-static</i>	(Optional) mld static
<i>mld-local-group</i>	(Optional) mld local group
<i>mld-translated</i>	(Optional) mld translated
<i>mld-uptime</i>	(Optional) mld uptime

<i>mld-expire</i>	(Optional) mld expire
-------------------	-----------------------

Command Mode

- /exec

show ipv6 mld local-groups

```
show ipv6 [ icmp ] mld local-groups [ <interface> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_vrf <vrf> { TABLE_entry <group-addr> <source-addr> <static-oif> <local-group>
<if-name> <last-reported> } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
icmp	(Optional) Display ICMPv6 information
mld	Display Multicast Listener Discovery information
local-groups	Display MLD local group membership information
<i>interface</i>	(Optional) Display group membership on interface name
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional) vrf table
<i>vrf</i>	(Optional) vrf
TABLE_entry	(Optional) entry table
<i>static-oif</i>	(Optional) static oif
<i>local-group</i>	(Optional) local group
<i>if-name</i>	(Optional) interface name
<i>last-reported</i>	(Optional) last reported

Command Mode

- /exec

show ipv6 mroute

```
show ipv6 mroute [ [ bitfield ] | rp | { [ <group> ] summary [ software-forwarded ] } | { summary [ count |
software-forwarded ] } | { { <source> <group> } | { <group> [ <source> ] } } [ summary [ software-forwarded
] | bitfield ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_vrf <vrf-name> [
TABLE_addr <mcast-addr> <pending> <bidir> <uptime> [ TABLE_mpib <mpib-name> <stale-route> ]
<if-name><rpf-nbr> <internal> <oif-count><fabric-oif><fabric-loser> [ TABLE_oif <oif-name> <oif-uptime>
[ TABLE_oif_mpib <oif-mpib-name> <stale-oif> ] <rpf> ] [ <oif-list-bitfield> ] ] [ <total-route-count>
<star-g-count> <source-count> <star-g-prefix-count> <group-count> <avg-sources-per-group><rem> [
<reason-for-route-stats-pending> ] ] [ TABLE_group <group-addr> <group-mask-len> <source-count-per-grp>
[ TABLE_source <route-or-source> [ <name> ] <packets> <bytes> <aps> <pps> <bit-rate-in-bps> <oifs> [
<software-pkts> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) Multicast VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
mroute	Display IPv6 multicast routing table
summary	(Optional) Display route counts and packet rates
software-forwarded	(Optional) Display software switched route counts only
rp	(Optional) Display RP routes (RP, 0.0.0.0/32)
count	(Optional) Display route counts only
bitfield	(Optional) Display bitfield details
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_addr	(Optional)
<i>mcast-addr</i>	(Optional)
<i>bidir</i>	(Optional)
<i>pending</i>	(Optional)
<i>uptime</i>	(Optional)

<i>internal</i>	(Optional)
TABLE_mpib	(Optional)
<i>mpib-name</i>	(Optional)
<i>stale-route</i>	(Optional)
TABLE_oif	(Optional)
<i>oif-name</i>	(Optional)
<i>oif-uptime</i>	(Optional)
<i>rpf</i>	(Optional)
<i>oif-list-bitfield</i>	(Optional)
TABLE_oif_mpib	(Optional)
<i>oif-mpib-name</i>	(Optional)
<i>stale-oif</i>	(Optional)
<i>total-route-count</i>	(Optional)
<i>star-g-count</i>	(Optional)
<i>source-count</i>	(Optional)
<i>star-g-prefix-count</i>	(Optional)
<i>group-count</i>	(Optional)
<i>reason-for-route-stats-pending</i>	(Optional)
TABLE_group	(Optional)
<i>group-addr</i>	(Optional)
<i>group-mask-len</i>	(Optional)
<i>source-count-per-grp</i>	(Optional)
TABLE_source	(Optional)
<i>route-or-source</i>	(Optional)
<i>name</i>	(Optional)
<i>packets</i>	(Optional)
<i>bytes</i>	(Optional)
<i>aps</i>	(Optional)
<i>pps</i>	(Optional)

<i>bit-rate-in-bps</i>	(Optional)
<i>oifs</i>	(Optional)
<i>software-pkts</i>	(Optional)

Command Mode

- /exec

show ipv6 mtu

```
show ipv6 mtu [ statistics | vrf { <vrf-name> | <vrf-known-name> | all [ detail ] } ] [ __readonly__ [
TABLE_mtu_stat <out-ent> <exp-ent> <purge-ent> <int-err> <pkt-too-big> <cache-miss> <cache-upd>
<mtu-small> <cache-no-upd> ] [ TABLE_mtu_vrf [ <tot-ipv6-mtu> ] [ TABLE_one_mtu [ <pmtu-cntxt> ]
[ { <mtu-ipv6> <mtu-cache> <up-time> <iod-lcache> } ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPV6 information
mtu	Display IPV6 Path MTU Cache
statistics	(Optional) Display non-TCP Path MTU Statistics
vrf	(Optional) Clear information for particular VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
detail	(Optional) Display IPV6 Path MTU Cache with detail
__readonly__	(Optional)
TABLE_mtu_stat	(Optional) mtu statistic table
<i>out-ent</i>	(Optional) outstanding entries
<i>exp-ent</i>	(Optional) expired entries
<i>purge-ent</i>	(Optional) purge entries
<i>int-err</i>	(Optional) internal entries
<i>pkt-too-big</i>	(Optional) packets too big messages received
<i>cache-miss</i>	(Optional) cache misses
<i>cache-upd</i>	(Optional) cache updates
<i>mtu-small</i>	(Optional) too small mtu advertised
<i>cache-no-upd</i>	(Optional) cache no update
TABLE_mtu_vrf	(Optional) MTU vrf table
<i>tot-ipv6-mtu</i>	(Optional) total ipv6 mtu messages
TABLE_one_mtu	(Optional) MTU table

<i>pmtu-cntxt</i>	(Optional) pmtu context
<i>mtu-cache</i>	(Optional) mtu cache
<i>up-time</i>	(Optional) up time
<i>iod-lcache</i>	(Optional) iod lcache

Command Mode

- /exec

show ipv6 nd ra dns search-list

```
show ipv6 nd ra dns search-list [ interface <interface> ] [ __readonly__ { TABLE_intf <intf_name>
<dns_supress_server_list> [ { TABLE_list <list_no> <list_name> [ { <finite> | <infinite> } ] <seq_no> } ]
} ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
nd	ICMPv6 Neighbor Discovery commands
ra	Router Advertisement
dns	Domain Name System
search-list	DNS Search List
interface	(Optional) Display DNS Search List information on interface
<i>interface</i>	(Optional) Interface name to display
<i>__readonly__</i>	(Optional)
TABLE_intf	(Optional) IPV6 Interface name
<i>intf_name</i>	(Optional) Interface name
<i>dns_supress_server_list</i>	(Optional) DNS Supress server list
TABLE_list	(Optional) Search list
<i>list_no</i>	(Optional) Search list number
<i>list_name</i>	(Optional) Search list name
<i>finite</i>	(Optional) Search list life time
<i>infinite</i>	(Optional) Search list infinte time
<i>seq_no</i>	(Optional) Search list sequence number

Command Mode

- /exec

Command Mode

- /exec

show ipv6 nd raguard policy

```
show ipv6 nd raguard policy [ <name> ] [ __readonly__ { TABLE_raguard_policy <policy> [ <port_type>
] <device_role> [ <min_hop_limit> ] [ <max_hop_limit> ] [ <mgd_conf_flag> ] [ <other_conf_flag> ] [
<rtr_pref_max> ] [ <ra_prefix_list> ] [ <ipv6_acl> ] [ { TABLE_raguard_targets <target> <target_type>
<target_policy> <feature> <target_range> } } ]
```

Syntax Description

<i>name</i>	(Optional) Policy name for feature RA guard
<i>__readonly__</i>	(Optional)
TABLE_raguard_policy	(Optional) IPv6 RA guard policy
<i>policy</i>	(Optional) Policy Name
<i>port_type</i>	(Optional) Port type
<i>device_role</i>	(Optional) Device role
<i>min_hop_limit</i>	(Optional) Minimum hop limit
<i>max_hop_limit</i>	(Optional) Minimum hop limit
<i>mgd_conf_flag</i>	(Optional) Check managed config flag
<i>other_conf_flag</i>	(Optional) Check other config flag
<i>rtr_pref_max</i>	(Optional) Router-preference maximum
<i>ra_prefix_list</i>	(Optional) Match RA prefix list
<i>ipv6_acl</i>	(Optional) Match IPv6 access list
TABLE_raguard_targets	(Optional) RA Guard Targets table
<i>target</i>	(Optional) Target Name
<i>target_type</i>	(Optional) Target Type
<i>target_policy</i>	(Optional) Policy Name
<i>feature</i>	(Optional) Feature
<i>target_range</i>	(Optional) Target Range

Command Mode

- /exec

show ipv6 neighbor binding

```
show ipv6 neighbor binding [ { { vlan <vlanid> [ details ] } } | { { address { <ipv6-addr> | all } } { interface <intfid> vlan <vlanid> [ details ] } }
```

Syntax Description

<i>intfid</i>	(Optional) [details]
show	Show running system information
ipv6	Show the IPv6 features of the system
<i>vlanid</i>	(Optional) Vlan number

Command Mode

- /exec

show ipv6 neighbor binding mac

show ipv6 neighbor binding mac <macaddr> { interface <intfid> vlan <vlanid> [details] |

Syntax Description

<i>intfid</i>	[details]
show	Show running system information
ipv6	Show the IPv6 features of the system
<i>macaddr</i>	48-bit hardware address
<i>vlanid</i>	Vlan number

Command Mode

- /exec

show ipv6 neighbor static

```
show ipv6 neighbor static [ interface <interface> ] [ __readonly__ [ TABLE_i6_nei { <nei-ipv6> <nei-mac>
<nei-iod> <nei-if-iod> } ] [ <tot-nei-ent> ] [ TABLE_nei_cnt { <nei-ipv6-tot> <nei-mac-tot> <nei-iod-tot>
<nei-if-iod-tot> } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
neighbor	Show IPv6 neighbor entry
static	Displays only static neighbors
interface	(Optional) Display IPv6 related interface information
<i>interface</i>	(Optional) Interface name to display
<i>__readonly__</i>	(Optional)
TABLE_i6_nei	(Optional) ipv6 neighbor table
<i>nei-mac</i>	(Optional) neighbor mac address
<i>nei-iod</i>	(Optional) neighbor iod
<i>nei-if-iod</i>	(Optional) neighbor interface iod
<i>tot-nei-ent</i>	(Optional) total neighbor entries
TABLE_nei_cnt	(Optional) neighbor count table
<i>nei-mac-tot</i>	(Optional) neighbor mac address
<i>nei-iod-tot</i>	(Optional) neighbor iod
<i>nei-if-iod-tot</i>	(Optional) neighbor physical interface iod

Command Mode

- /exec

show ipv6 pim df

```
show ipv6 pim df [ <rp-or-group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
<out-context> ] [ { TABLE_rp [ <rp-addr> ] [ <df-ordinal> ] [ <df-bits> ] [ <df-bits-count> ] [ <metric-pref>
] [ <metric> ] [ { TABLE_grange [ <grange-grp> ] [ <grange-masklen> ] } ] [ { TABLE_iod [ <if-name> ]
[ <df-winner> ] [ <df-state> ] [ <winner-metric-pref> ] [ <winner-metric> ] [ <uptime> ] [ <is-rpf> } } ] ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
df	Display Bidir Designated Forwarders
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-context</i>	(Optional)
TABLE_rp	(Optional)
<i>df-ordinal</i>	(Optional)
<i>df-bits</i>	(Optional)
<i>df-bits-count</i>	(Optional)
<i>metric-pref</i>	(Optional)
<i>metric</i>	(Optional)
TABLE_grange	(Optional)
<i>grange-masklen</i>	(Optional)
TABLE_iod	(Optional)
<i>if-name</i>	(Optional)
<i>df-state</i>	(Optional)
<i>winner-metric-pref</i>	(Optional)
<i>winner-metric</i>	(Optional)

<i>uptime</i>	(Optional)
<i>is-rpf</i>	(Optional)

Command Mode

- /exec

show ipv6 pim event-history

show ipv6 pim [internal] event-history { errors | msgs | <pim6-event-hist-buf-name> | statistics }

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	PIM6 global configuration commands
internal	(Optional) Commands for internal use
event-history	Show various event logs of PIM6
errors	Show error logs of PIM6
msgs	Show various message logs of PIM6
<i>pim6-event-hist-buf-name</i>	Show logs of event-hist buffer
statistics	Show state and size of buffers

Command Mode

- /exec

show ipv6 pim fabric info

show ipv6 pim fabric info [*__readonly__* <*switch_role*>]

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
fabric	Fabric functionality
info	show the fabric info
<i>__readonly__</i>	(Optional)
<i>switch_role</i>	(Optional)

Command Mode

- /exec

show ipv6 pim fabric legacy-vlans

show ipv6 pim fabric legacy-vlans [*__readonly__* *TABLE_legacy_vlan* *<vlan_id>*]

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
fabric	Fabric functionality
legacy-vlans	Show legacy VLANs on this switch
<i>__readonly__</i>	(Optional)
<i>TABLE_legacy_vlan</i>	(Optional)
<i>vlan_id</i>	(Optional)

Command Mode

- /exec

show ipv6 pim group-range

```
show ipv6 pim group-range [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
<out-context> ] [ { TABLE_group [ <invalid-grp> ] [ <grp-addr> ] [ <mode> ] [ <rp-addr> ] [
<sh-tree-only-range> ] } ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
group-range	Display the various group ranges
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-context</i>	(Optional)
TABLE_group	(Optional)
<i>invalid-grp</i>	(Optional)
<i>grp-addr</i>	(Optional)
<i>mode</i>	(Optional)
<i>rp-addr</i>	(Optional)
<i>sh-tree-only-range</i>	(Optional)

Command Mode

- /exec

show ipv6 pim interface show ipv6 pim interface

```
show ipv6 pim interface <interface> | show ipv6 pim interface [ brief ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ [ <out-context> ] [ { TABLE_iod [ <if-name> ] [ <if-addr> ] [ <if-status> ] [ <dr> ] [
<is-iface-in-cib> ] [ <is-pim-enabled> ] [ <if-addr-summary> ] [ <dr-priority> ] [ <no-dr-priority> ] [ <nbr-cnt>
] [ <hello-interval-sec> ] [ <hello-interval-msec> ] [ <hello-timer> ] [ <holdtime-sec> ] [ <holdtime-msec> ]
] [ <is-border> ] [ <genid> ] [ <isauth-config> ] [ <nbr-policy-name> ] [ <jp-in-policy-name> ] [
<jp-out-policy-name> ] [ <is-passive> ] [ <last-cleared> ] [ <hello-sent> ] [ <hello-rcvd> ] [ <jp-sent> ] [
<jp-rcvd> ] [ <assert-sent> ] [ <assert-rcvd> ] [ <graft-sent> ] [ <graft-rcvd> ] [ <graft-ack-sent> ] [
<graft-ack-rcvd> ] [ <df-offer-sent> ] [ <df-offer-rcvd> ] [ <df-winner-sent> ] [ <df-winner-rcvd> ] [
<df-backoff-sent> ] [ <df-backoff-rcvd> ] [ <pass-sent> ] [ <pass-rcvd> ] [ <cksum-errors> ] [ <invalid-errors>
] [ <invalid-df-errors> ] [ <auth-failed> ] [ <pak-len-errors> ] [ <ver-errors> ] [ <pkts-self> ] [ <pkts-non-nbr>
] [ <pkts-on-passive> ] [ <jp-rcvd-on-rpf> ] [ <jp-rcvd-no-rp> ] [ <jp-rcvd-wrong-rp> ] [ <jp-rcvd-for-ssm>
] [ <jp-rcvd-for-bidir> ] [ <jp-in-policy-filter> ] [ <jp-out-policy-filter> ] } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
interface	Display PIM6 interface related information
<i>interface</i>	Interface name of single interface to display
brief	(Optional) Display one line status per interface
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-context</i>	(Optional)
TABLE_iod	(Optional)
<i>if-name</i>	(Optional)
<i>if-addr</i>	(Optional)
<i>dr</i>	(Optional)
<i>nbr-cnt</i>	(Optional)
<i>is-iface-in-cib</i>	(Optional)
<i>is-pim-enabled</i>	(Optional)

<i>is-border</i>	(Optional)
<i>if-addr-summary</i>	(Optional)
<i>if-status</i>	(Optional)
<i>dr-priority</i>	(Optional)
<i>no-dr-priority</i>	(Optional)
<i>hello-interval-sec</i>	(Optional)
<i>hello-interval-msec</i>	(Optional)
<i>hello-timer</i>	(Optional)
<i>holdtime-sec</i>	(Optional)
<i>holdtime-msec</i>	(Optional)
<i>genid</i>	(Optional)
<i>isauth-config</i>	(Optional)
<i>is-passive</i>	(Optional)
<i>nbr-policy-name</i>	(Optional)
<i>jp-in-policy-name</i>	(Optional)
<i>jp-out-policy-name</i>	(Optional)
<i>last-cleared</i>	(Optional)
<i>hello-sent</i>	(Optional)
<i>hello-rcvd</i>	(Optional)
<i>jp-sent</i>	(Optional)
<i>jp-rcvd</i>	(Optional)
<i>assert-sent</i>	(Optional)
<i>assert-rcvd</i>	(Optional)
<i>graft-sent</i>	(Optional)
<i>graft-rcvd</i>	(Optional)
<i>graft-ack-sent</i>	(Optional)
<i>graft-ack-rcvd</i>	(Optional)
<i>df-offer-sent</i>	(Optional)
<i>df-offer-rcvd</i>	(Optional)

<i>df-winner-sent</i>	(Optional)
<i>df-winner-rcvd</i>	(Optional)
<i>df-backoff-sent</i>	(Optional)
<i>df-backoff-rcvd</i>	(Optional)
<i>pass-sent</i>	(Optional)
<i>pass-rcvd</i>	(Optional)
<i>cksum-errors</i>	(Optional)
<i>invalid-errors</i>	(Optional)
<i>invalid-df-errors</i>	(Optional)
<i>auth-failed</i>	(Optional)
<i>pak-len-errors</i>	(Optional)
<i>ver-errors</i>	(Optional)
<i>pkts-self</i>	(Optional)
<i>pkts-non-nbr</i>	(Optional)
<i>pkts-on-passive</i>	(Optional)
<i>jp-rcvd-on-rpf</i>	(Optional)
<i>jp-rcvd-no-rp</i>	(Optional)
<i>jp-rcvd-wrong-rp</i>	(Optional)
<i>jp-rcvd-for-ssm</i>	(Optional)
<i>jp-rcvd-for-bidir</i>	(Optional)
<i>jp-in-policy-filter</i>	(Optional)
<i>jp-out-policy-filter</i>	(Optional)

Command Mode

- /exec

show ipv6 pim neighbor

```
show ipv6 pim neighbor { [ <interface> ] | [ <ipv6addr> ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ]
[ __readonly__ [ TABLE_vrf <out-context> [ TABLE_neighbor <nbr-addr><if-name><uptime><expires>
[ <dr-priority> ] <bidir-capable> <bfd-state><name> [ TABLE_secondary <sec-addr> ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
neighbor	Display PIM6 neighbor related information
<i>interface</i>	(Optional) Display neighbors on single interface name
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>out-context</i>	(Optional)
TABLE_neighbor	(Optional)
<i>dr-priority</i>	(Optional)
<i>bidir-capable</i>	(Optional)
TABLE_secondary	(Optional)

Command Mode

- /exec

show ipv6 pim oif-list

```
show ipv6 pim oif-list <group> [ <source> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_vrf <vrf-name> { TABLE_grp <mcast-addr> <incoming-intf> <rpf-nbr> <timeout-interval>
<oif-list-count> [ { TABLE_oiflist <oif-name> } ] <timeout-list-count> [ { TABLE_timeoutlist
<timeoutoif-name> } ] <immediate-list-count> [ { TABLE_immediatelist <immediateoif-name> } ]
<immediate-timeout-list-count> [ { TABLE_immediatettimeoutlist <immediatettimeoutoif-name> } ]
<sg-r-prune-list-count> [ { TABLE_sgrprunelist <sgrprunelisoif-name> } ] }
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
oif-list	Display interfaces for oif-list of PIM6 route
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_grp	(Optional)
<i>mcast-addr</i>	(Optional)
<i>incoming-intf</i>	(Optional)
<i>timeout-interval</i>	(Optional)
<i>oif-list-count</i>	(Optional)
TABLE_oiflist	(Optional)
<i>oif-name</i>	(Optional)
<i>timeout-list-count</i>	(Optional)
TABLE_timeoutlist	(Optional)
<i>timeoutoif-name</i>	(Optional)
<i>immediate-list-count</i>	(Optional)

TABLE_immediatelist	(Optional)
<i>immediateoif-name</i>	(Optional)
<i>immediate-timeout-list-count</i>	(Optional)
TABLE_immediatettimeoutlist	(Optional)
<i>immediatettimeoutoif-name</i>	(Optional)
<i>sgr-prune-list-count</i>	(Optional)
TABLE_sgrprunelist	(Optional)
<i>sgrprunelisoif-name</i>	(Optional)

Command Mode

- /exec

show ipv6 pim policy statistics jp

```
show ipv6 pim policy statistics { jp-policy | neighbor-policy } <interface> [ __readonly__ { TABLE_routemap
<name> <action> <seq_num> [ { TABLE_cmd <command> <match_count> <compare_count> } ] }
<total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	PIM6 global configuration commands
policy	Policy related information
statistics	Policy statistics
jp-policy	Statistics for jp-policy
neighbor-policy	Statistics for neighbor-policy
<i>interface</i>	Interface to display policy statistics for
<i>__readonly__</i>	(Optional)
TABLE_routemap	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seq_num</i>	(Optional)
TABLE_cmd	(Optional)
<i>command</i>	(Optional)
<i>compare_count</i>	(Optional)
<i>match_count</i>	(Optional)
<i>total_accept_count</i>	(Optional)
<i>total_reject_count</i>	(Optional)

Command Mode

- /exec

show ipv6 pim route

```
show ipv6 pim route { [ bitfield ] | <source> <group> | <group> [ <source> ] [ bitfield ] } [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <context-name> <route-count> [ TABLE_one_route
<mcast-addr> [ <rp-addr> <rp-local> ] <bidir> <sgexpire> <is-fabricowned> [ <sgexpire> ] [ <timeleft> ]
<rp-bit> [ <register> ] [ <assert-timeout> ] <intf-name> <rpf-nbr-1> <rpf-nbr-addr> <rpf-nbr-2> [ <metric-pref>
<route-metric> ] [ <oif-count> ] [ <oif-bf-str> ] [ <timeout-count> ] [ <timeout-bf-str> ] [ <immediate-count>
] [ <immediate-bf-str> ] [ <immediate-timeout-count> ] [ <immediate-timeout-bf-str> ] [ <sgr-prune-list-count>
] [ <sgr-prune-list-bf-str> ] [ <timeout-interval> <jp-holdtime-rndup> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
route	Display PIM6 specific route information
bitfield	(Optional) Display details of each bitfield for PIM6 route
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>context-name</i>	(Optional)
<i>route-count</i>	(Optional)
TABLE_one_route	(Optional)
<i>mcast-addr</i>	(Optional)
<i>rp-addr</i>	(Optional)
<i>rp-local</i>	(Optional)
<i>bidir</i>	(Optional)
<i>sgexpire</i>	(Optional)
<i>is-fabricowned</i>	(Optional)
<i>sgexpire</i>	(Optional)
<i>timeleft</i>	(Optional)

<i>rp-bit</i>	(Optional)
<i>register</i>	(Optional)
<i>assert-timeout</i>	(Optional)
<i>intf-name</i>	(Optional)
<i>rpf-nbr-1</i>	(Optional)
<i>rpf-nbr-addr</i>	(Optional)
<i>rpf-nbr-2</i>	(Optional)
<i>metric-pref</i>	(Optional)
<i>route-metric</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>oif-bf-str</i>	(Optional)
<i>timeout-count</i>	(Optional)
<i>timeout-bf-str</i>	(Optional)
<i>immediate-count</i>	(Optional)
<i>immediate-bf-str</i>	(Optional)
<i>immediate-timeout-count</i>	(Optional)
<i>immediate-timeout-bf-str</i>	(Optional)
<i>sgr-prune-list-count</i>	(Optional)
<i>sgr-prune-list-bf-str</i>	(Optional)
<i>timeout-interval</i>	(Optional)
<i>jp-holdtime-rndup</i>	(Optional)

Command Mode

- /exec

show ipv6 pim rp-hash

```
show ipv6 pim rp-hash <group> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <out-context> ] [ <rp-found> ] [ <is-rp-bsr-learnt> ] [ <out-group> ] [ <hash-length> ] [ <out-bsr> ] [ { TABLE_rp [ <rp-addr> ] [ <hash> ] [ <isbest_hash> ] } ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
rp-hash	Display RP hash value for group
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-context</i>	(Optional)
<i>rp-found</i>	(Optional)
<i>is-rp-bsr-learnt</i>	(Optional)
<i>hash-length</i>	(Optional)
TABLE_rp	(Optional)
<i>hash</i>	(Optional)
<i>isbest_hash</i>	(Optional)

Command Mode

- /exec

show ipv6 pim rp

```
show ipv6 pim rp [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <out-context> ] [ <is-bsr-enabled> ] [ <is-bsr-listen-only> ] [ <is-bsr-forward-only> ] [ <are-we-bsr> ] [ <bsr-address> ] [ <is-bsr-address> ] [ <bsr-priority> ] [ <bsr-hash-masklen> ] [ <bs-timer> ] [ <bsr-uptime> ] [ <bsr-expires> ] [ <rp-cand-policy-name> ] [ <bsr-policy-name> ] [ <rp-announce-policy-name> ] [ <rp-discovery-policy-name> ] [ { TABLE_ anycast_rp [ <anycast-rp-addr> ] [ { TABLE_ arp_rp [ <arp-rp-addr> ] [ <is-rpaddr-local> ] } ] } ] [ { TABLE_ rp [ <rp-addr> ] [ <is-rp-in-cib> ] [ <df-ordinal> ] [ <rp-uptime> ] [ <rp-priority> ] [ <bsr-rp-expires> ] [ <bsr-info-src> ] [ <is-rp-static> ] [ <static-rp-group-map> ] [ { TABLE_ grange [ <grange-grp> ] [ <grange-masklen> ] [ <is-bidir-grp> ] [ <is-bsr-rp-owner> ] [ <is-static-rp-owner> ] } ] } ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
rp	Display PIM6 RP and BSR related information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>out-context</i>	(Optional)
<i>is-bsr-enabled</i>	(Optional)
<i>is-bsr-listen-only</i>	(Optional)
<i>is-bsr-forward-only</i>	(Optional)
<i>are-we-bsr</i>	(Optional)
<i>is-bsr-address</i>	(Optional)
<i>bsr-priority</i>	(Optional)
<i>bsr-hash-masklen</i>	(Optional)
<i>bs-timer</i>	(Optional)
<i>bsr-uptime</i>	(Optional)
<i>bsr-expires</i>	(Optional)
<i>rp-cand-policy-name</i>	(Optional)

<i>bsr-policy-name</i>	(Optional)
<i>rp-announce-policy-name</i>	(Optional)
<i>rp-discovery-policy-name</i>	(Optional)
TABLE_anycast_rp	(Optional)
TABLE_arp_rp	(Optional)
<i>is-rpaddr-local</i>	(Optional)
TABLE_rp	(Optional)
<i>is-rp-in-cib</i>	(Optional)
<i>df-ordinal</i>	(Optional)
<i>rp-uptime</i>	(Optional)
<i>rp-priority</i>	(Optional)
<i>bsr-rp-expires</i>	(Optional)
<i>is-rp-static</i>	(Optional)
<i>static-rp-group-map</i>	(Optional)
TABLE_grange	(Optional)
<i>grange-masklen</i>	(Optional)
<i>is-bidir-grp</i>	(Optional)
<i>is-bsr-rp-owner</i>	(Optional)
<i>is-static-rp-owner</i>	(Optional)

Command Mode

- /exec

show ipv6 pim statistics

```
show ipv6 pim statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <uptime> ] [
<reg-sent> ] [ <reg-rcvd> ] [ <null-reg-sent> ] [ <null-reg-rcvd> ] [ <reg-stop-sent> ] [ <reg-stop-rcvd> ] [
<reg-rcvd-not-rp> ] [ <reg-rcvd-for-ssm> ] [ <reg-rcvd-for-bidir> ] [ <bootstrap-sent> ] [ <bootstrap-rcvd>
] [ <cand-rp-sent> ] [ <cand-rp-rcvd> ] [ <bs-no-nbr> ] [ <bs-border-deny> ] [ <bs-len-errors> ] [ <bs-rpf-failed>
] [ <bs-no-listen> ] [ <candrp-border-deny> ] [ <candrp-no-listen> ] [ <ctrl-no-route> ] [ <data-no-route> ] [
<no-state> ] [ <create-state> ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
statistics	Packet counter statistics
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>uptime</i>	(Optional)
<i>reg-sent</i>	(Optional)
<i>reg-rcvd</i>	(Optional)
<i>null-reg-sent</i>	(Optional)
<i>null-reg-rcvd</i>	(Optional)
<i>reg-stop-sent</i>	(Optional)
<i>reg-stop-rcvd</i>	(Optional)
<i>reg-rcvd-not-rp</i>	(Optional)
<i>reg-rcvd-for-ssm</i>	(Optional)
<i>reg-rcvd-for-bidir</i>	(Optional)
<i>bootstrap-sent</i>	(Optional)
<i>bootstrap-rcvd</i>	(Optional)
<i>cand-rp-sent</i>	(Optional)

<i>cand-rp-rcvd</i>	(Optional)
<i>bs-no-nbr</i>	(Optional)
<i>bs-border-deny</i>	(Optional)
<i>bs-len-errors</i>	(Optional)
<i>bs-rpf-failed</i>	(Optional)
<i>bs-no-listen</i>	(Optional)
<i>candrp-border-deny</i>	(Optional)
<i>candrp-no-listen</i>	(Optional)
<i>ctrl-no-route</i>	(Optional)
<i>data-no-route</i>	(Optional)
<i>no-state</i>	(Optional)
<i>create-state</i>	(Optional)

Command Mode

- /exec

show ipv6 pim vrf

```
show ipv6 pim vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ detail ] [ __readonly__ TABLE_context [
<out-context> ] [ <context-id> ] [ <count> ] [ <table-id> ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
pim	Display PIM6 status and configuration
vrf	Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs PIM6 is configured for
detail	(Optional) Display detailed information
<i>__readonly__</i>	(Optional)
TABLE_context	(Optional)
<i>out-context</i>	(Optional)
<i>context-id</i>	(Optional)
<i>table-id</i>	(Optional)
<i>count</i>	(Optional)

Command Mode

- /exec

show ipv6 policy

```
show ipv6 policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_pbr [ <interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
policy	Policy routing
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_pbr	(Optional)
<i>interface</i>	(Optional)
<i>rmap</i>	(Optional)
<i>status</i>	(Optional)
<i>vrf_name</i>	(Optional)

Command Mode

- /exec

show ipv6 prefix-list

```
show ipv6 prefix-list { [ detail | summary ] [ <ipv6-pfl-name> | <ipv6-pfl-cfg-name> ] } | { { <ipv6-pfl-name>
| <ipv6-pfl-cfg-name> } seq <seq-no> } | { { <ipv6-pfl-name> | <ipv6-pfl-cfg-name> } <prefix> [ first-match
| longer ] } } [ __readonly__ TABLE_ipv6_pfl <name> <seq> <action> <rule> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
detail	(Optional) Show detailed information
summary	(Optional) Show summarized information
prefix-list	List IPv6 prefix lists
<i>ipv6-pfl-name</i>	(Optional) Name of prefix-list
<i>ipv6-pfl-cfg-name</i>	(Optional) Known prefix-list name
seq	Sequence number
<i>seq-no</i>	Sequence number
first-match	(Optional) Find the first match
longer	(Optional) Find the more specific entries
<i>__readonly__</i>	(Optional)
TABLE_ipv6_pfl	(Optional)
<i>name</i>	(Optional)
<i>seq</i>	(Optional)
<i>action</i>	(Optional)
<i>rule</i>	(Optional)

Command Mode

- /exec

show ipv6 process

```
show ipv6 process [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_ipv6_all {
<cnxt-name> <cnxt-id> } ] [ TABLE_ipv6 { <ipv6-vrf> <ipv6-vrf-id> <auto-disc> <auto-add> <sta-disc>
<sta-def> [ <ipv6-unreach> } ] [ TABLE_iod { <iod-val> <iod-ifind> } ] [ TABLE_ipv6_nxt { <ipv6-nxt>
} ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
process	Display IPv6 global information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs
<i>__readonly__</i>	(Optional)
TABLE_ipv6_all	(Optional) IPV6 process table
<i>cnxt-name</i>	(Optional) context name
<i>cnxt-id</i>	(Optional) context name
TABLE_ipv6	(Optional) ipv6 table
<i>ipv6-vrf</i>	(Optional) vrf name
<i>ipv6-vrf-id</i>	(Optional) vrf id
<i>auto-disc</i>	(Optional) auto discard
<i>auto-add</i>	(Optional) auto add
<i>sta-disc</i>	(Optional) static discard
<i>sta-def</i>	(Optional) static def
<i>ipv6-unreach</i>	(Optional) ipv6 unreachable
TABLE_iod	(Optional) IOD table
<i>iod-val</i>	(Optional) iod value
<i>iod-ifind</i>	(Optional) iod if index
TABLE_ipv6_nxt	(Optional) ipv6 next hop table

Command Mode

- /exec

show ipv6 rguard statistics

```
show ipv6 rguard statistics [ interface <intf-range> ] [ __readonly__ <msg_stats_hdr> <intf2> <rx_pkts>
<drop_count> ]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
rguard	IPV6 rguard
statistics	RA packet drop count
interface	(Optional) Rguard enabled interfaces
<i>intf-range</i>	(Optional) interface
<i>__readonly__</i>	(Optional) Read only
<i>msg_stats_hdr</i>	(Optional)
<i>intf2</i>	(Optional) interface name
<i>rx_pkts</i>	(Optional)
<i>drop_count</i>	(Optional)

Command Mode

- /exec

show ipv6 rip policy statistics redistribute

```
show ipv6 rip [ instance <inst> ] policy statistics redistribute { bgp <as> | { eigrp | isis | <src-rip> | ospfv3 |
lisp } <tag> | direct | static } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_asn
<asn> TABLE_vrf <vrf> { TABLE_rmap <name> <action> <seq_num> [ { TABLE_cmd <command>
<compare_count> <match_count> } ] } <total_accept_count> <total_reject_count> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
rip	Display RIP routing protocol status
instance	(Optional) Process ID
<i>inst</i>	(Optional) Process ID
policy	Policy related information
statistics	Policy statistics
redistribute	RIP redistribute routes from other routing protocol
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
isis	Intermediate-to-intermediate (ISIS)
src-rip	Routing Information Protocol (RIP)
ospfv3	Open Shortest Path First (OSPFv3)
lisp	LISP EID-prefixes
<i>tag</i>	Process tag
direct	Directly connected routes
static	Static routes
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)

TABLE_asn	(Optional) AS number table
<i>asn</i>	(Optional) AS number
TABLE_vrf	(Optional) VRF table
<i>vrf</i>	(Optional) VRF name
TABLE_rmap	(Optional) Routemap table
<i>name</i>	(Optional) Route-map Name
<i>action</i>	(Optional) Route-map action
<i>seq_num</i>	(Optional) Sequence number of the rule in route-map
TABLE_cmd	(Optional) Route-map command table
<i>command</i>	(Optional) Route-map command
<i>compare_count</i>	(Optional) Number of comparisons
<i>match_count</i>	(Optional) Number of matches
<i>total_accept_count</i>	(Optional) Total number of packets accepted by the policy
<i>total_reject_count</i>	(Optional) Total number of packets rejected by the policy

Command Mode

- /exec

show ipv6 route

```
show ipv6 route [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ipv6-addr> | { <ipv6-prefix>
[ { longer-prefixes | shorter-prefixes } ] ] [ { <ipv6-protocol> [ all ] } | { next-hop <next-hop> } | { interface
<interface> } | { updated { [ since <stime> ] [ until <utime> ] } } ] + [ summary | { [ detail ] [ deleted ] } ] [
vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ _readonly_ TABLE_vrf <vrf-name-out> TABLE_addrf
<addrf> [ TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> [ <attached> ] TABLE_path [ <ubest>
] [ <mbest> ] [ <ipnexthop> ] [ <ifname> ] <uptime> <pref> <metric> <clientname> [ <type> ] [ <tag> ] [
<stale> ] [ <stalebl> ] [ <hidden> ] ] [ TABLE_summary <routes> <paths> [ <multicast_paths> ] [
TABLE_unicast [ <clientnameuni> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_multicast [
<clientnamemulti> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_route_count [ <mask_len> ] [ <count>
] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
route	Display IPv6 routing table
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
l3vm-info	(Optional) Display corresponding L3VM information
rpf	(Optional) Display RPF information for multicast source
longer-prefixes	(Optional) Display matching routes with mask-lengths >= prefix
shorter-prefixes	(Optional) Display matching routes with mask-lengths <= prefix
<i>ipv6-protocol</i>	(Optional) Display routes for protocol (or route type)
all	(Optional) Display routes for protocol for backup next-hops too
next-hop	(Optional) Display routes with this next-hop only
interface	(Optional) Display routes with this output interface only
<i>interface</i>	(Optional) Interface Name
updated	(Optional) Display routes filtered by last updated time

<i>since</i>	(Optional) Display those routes updated since this time
<i>stime</i>	(Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>until</i>	(Optional) Display those routes updated until this time
<i>utime</i>	(Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>summary</i>	(Optional) Display route counts
<i>deleted</i>	(Optional) Display delete-pending routes also
<i>detail</i>	(Optional) Display routes in full detail
<i>__readonly__</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>TABLE_addrf</i>	(Optional)
<i>addrf</i>	(Optional)
<i>TABLE_prefix</i>	(Optional)
<i>ucast-nhops</i>	(Optional)
<i>mcast-nhops</i>	(Optional)
<i>attached</i>	(Optional)
<i>TABLE_path</i>	(Optional)
<i>ubest</i>	(Optional)
<i>mbest</i>	(Optional)
<i>ifname</i>	(Optional)
<i>pref</i>	(Optional)
<i>tag</i>	(Optional)
<i>metric</i>	(Optional)
<i>uptime</i>	(Optional)
<i>clientname</i>	(Optional)
<i>type</i>	(Optional)
<i>stale</i>	(Optional)
<i>stalelbl</i>	(Optional)
<i>hidden</i>	(Optional)

TABLE_summary	(Optional)
<i>routes</i>	(Optional)
<i>paths</i>	(Optional)
<i>multicast_paths</i>	(Optional)
TABLE_unicast	(Optional)
<i>clientnameuni</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_multicast	(Optional)
<i>clientnamemulti</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_route_count	(Optional)
<i>mask_len</i>	(Optional)
<i>count</i>	(Optional)

Command Mode

- /exec

<i>retrans-time</i>	(Optional) retransmission time
TABLE_prefix_ipv6	(Optional) ipv6 prefix table
<i>ipv6-prefix</i>	(Optional) ipv6 prefix
<i>buf-ipv6</i>	(Optional) ipv6 buffer
<i>buf-autono</i>	(Optional) ipv6 buffer autonomous flag
<i>valid-life-time</i>	(Optional) ipv6 valid life time
<i>prefer-life</i>	(Optional) ipv6 preferred life time

Command Mode

- /exec

show ipv6 snooping capture-policy

```
show ipv6 snooping capture-policy [ vlan <vlanid> ] [ interface <intf> ] [ __readonly__ <cmdout> ]
```

Syntax Description

<code>show</code>	Show running system information
<code>ipv6</code>	Show the IPv6 features of the system
<i>vlanid</i>	(Optional) VLAN ID
<i>intf</i>	(Optional) interface
<code>__readonly__</code>	(Optional)
<i>cmdout</i>	(Optional)

Command Mode

- /exec

show ipv6 snooping counters vlan

```
show ipv6 snooping counters { { vlan <vlanid> } | { interface <intf> } } [ __readonly__ [ {
TABLE_target_counters <target> [ { TABLE_protocol_msgs <protocol_name> [ { TABLE_sub_protocol_msgs
[ <subfield_name> ] [ <msg_count> ] } ] } ] [ { TABLE_bridged_msgs <protocol_name> [ {
TABLE_sub_protocol_msgs [ <subfield_name> ] [ <msg_count> ] } ] } ] [ { TABLE_dropped_msgs
<feature_name> <protocol_name> [ { TABLE_sub_protocol_msgs [ <subfield_name> ] [ <msg_count> ] [
<drop_reason> ] } ] } ] } ] }
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
<i>vlanid</i>	VLAN ID
<i>intf</i>	interface
<i>__readonly__</i>	(Optional)
TABLE_target_counters	(Optional) Policy counters per target
<i>target</i>	(Optional) Target Name
TABLE_protocol_msgs	(Optional) Protocol messages table
<i>protocol_name</i>	(Optional) Protocol name
TABLE_sub_protocol_msgs	(Optional) Protocol sub-messages table
<i>subfield_name</i>	(Optional) Sub-field name
<i>msg_count</i>	(Optional) Message count
TABLE_bridged_msgs	(Optional) Bridged messages table
<i>protocol_name</i>	(Optional) Protocol name
TABLE_sub_protocol_msgs	(Optional) Protocol sub-messages table
<i>subfield_name</i>	(Optional) Sub-field name
<i>msg_count</i>	(Optional) Message count
TABLE_dropped_msgs	(Optional) Bridged messages table
<i>feature_name</i>	(Optional) Feature name
<i>protocol_name</i>	(Optional) Protocol name
TABLE_sub_protocol_msgs	(Optional) Protocol sub-messages table
<i>subfield_name</i>	(Optional) Sub-field name

<i>msg_count</i>	(Optional) Message count
<i>drop_reason</i>	(Optional) Drop reason

Command Mode

- /exec

show ipv6 snooping events

show ipv6 snooping events [__readonly__ <cmdout>]

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
__readonly__	(Optional)
<i>cmdout</i>	(Optional)

Command Mode

- /exec

show ipv6 snooping features

```
show ipv6 snooping features [ __readonly__ { TABLE_features <name> <priority> <state> } ]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
__readonly__	(Optional)
TABLE_features	(Optional) IPv6 Snooping Features
<i>name</i>	(Optional) Name
<i>priority</i>	(Optional) Priority
<i>state</i>	(Optional) State

Command Mode

- /exec

show ipv6 snooping messages

show ipv6 snooping messages [detailed <count>] [__readonly__ <cmdout>]

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
<i>count</i>	(Optional) Number of messages to display
<i>__readonly__</i>	(Optional)
<i>cmdout</i>	(Optional)

Command Mode

- /exec

show ipv6 snooping policies

```
show ipv6 snooping policies { [ vlan <vlanid> ] | [ interface <intf> ] } [ __readonly__ { TABLE_policies
<target> <target_type> <policy> <feature> <target_range> } ]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
<i>vlanid</i>	(Optional) VLAN ID
<i>intf</i>	(Optional) interface
__readonly__	(Optional)
TABLE_policies	(Optional) IPv6 Snooping Policies
<i>target</i>	(Optional) Target Name
<i>target_type</i>	(Optional) Target Type
<i>policy</i>	(Optional) Policy Name
<i>feature</i>	(Optional) Feature
<i>target_range</i>	(Optional) Target Range

Command Mode

- /exec

show ipv6 snooping policy

```
show ipv6 snooping policy [ <policy_name> ] [ __readonly__ { [ TABLE_glean_policy <policy> [ <port_type>
] <sec_lvl> <device_role> [ <data_glean> ] [ <dest_glean> ] [ <glean_type> ] [ <reachable_lifetime> ] [
<stale_lifetime> ] { [ TABLE_non_glean_protocols | TABLE_glean_protocols # 395
../feature/sisf/core/nxos/src/sisf_glean_dme.cmd <protocol> [ <prefix_list> ] } } [ <limit_address_cnt> ] [
<limit_address_cnt_v4_per_mac> ] [ <limit_address_cnt_v6_per_mac> ] [ <limit_address_cnt_v4_per_target>
] [ <tracking> ] { { [ TABLE_targets <target> <target_type> <target_policy> <feature> <target_range> ] } }
]
```

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
<i>policy_name</i>	(Optional) Policy name for feature snooping
<i>__readonly__</i>	(Optional)
TABLE_glean_policy	(Optional) IPv6 DHCP guard policy
<i>policy</i>	(Optional) Policy Name
<i>port_type</i>	(Optional) Port type
<i>sec_lvl</i>	(Optional) Security level
<i>device_role</i>	(Optional) Device role
<i>data_glean</i>	(Optional) Data glean
<i>dest_glean</i>	(Optional) Destination glean
<i>glean_type</i>	(Optional) Glean type
<i>reachable_lifetime</i>	(Optional) Reachable lifetime
<i>stale_lifetime</i>	(Optional) Stale lifetime
TABLE_non_glean_protocols	(Optional) Non Glean protocols
<i>protocol</i>	(Optional) Protocol
TABLE_glean_protocols	(Optional) Glean protocols
<i>prefix_list</i>	(Optional) Prefix list
<i>limit_address_cnt</i>	(Optional) Limit address count
<i>limit_address_cnt_v4_per_mac</i>	(Optional) Limit address count v4 per mac
<i>limit_address_cnt_v6_per_mac</i>	(Optional) Limit address count v6 per mac
<i>limit_address_cnt_v4_per_target</i>	(Optional) Limit address count v4 per target

<i>tracking</i>	(Optional) Tracking
TABLE_targets	(Optional) Targets table
<i>target</i>	(Optional) Target Name
<i>target_type</i>	(Optional) Target Type
<i>target_policy</i>	(Optional) Policy Name
<i>feature</i>	(Optional) Feature
<i>target_range</i>	(Optional) Target Range

Command Mode

- /exec

show ipv6 snooping pss database

show ipv6 snooping pss database [__readonly__ <cmdout>]

Syntax Description

show	Show running system information
ipv6	Show the IPv6 features of the system
__readonly__	(Optional)
<i>cmdout</i>	(Optional)

Command Mode

- /exec

show ipv6 static-route

```
show ipv6 static-route [ <prefix> ] [ multicast ] [ track-table ] [ vrf { <vrf-name> | <vrf-known-name> | all }
] [ __readonly__ [ TABLE_vrf <vrf-name-out> ] [ TABLE_route [ <prefix-out> ] [ <next-hop> ] [ <intf-name>
] [ <pref> ] [ <next-hop-vrf> ] [ <reslv-tid> ] [ <real-nh> ] [ <has-real-intf> ] [ <real-intf-name> ] [ <track-id>
] [ <track-status> ] [ <rnh-status> ] [ <bfd-status> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
static-route	Display configured static routes
multicast	(Optional) Display configured static mroutes
track-table	(Optional) Display track object details associated with static routes
all	(Optional) Display all VRFs
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional) VRF table
<i>vrf-name-out</i>	(Optional) vrf name
TABLE_route	(Optional) Route table
<i>intf-name</i>	(Optional) interface name
<i>pref</i>	(Optional) interface prefix
<i>next-hop-vrf</i>	(Optional) next hop vrf
<i>reslv-tid</i>	(Optional) reslv tid
<i>has-real-intf</i>	(Optional) has real interface
<i>real-intf-name</i>	(Optional) real interface name
<i>track-id</i>	(Optional) interface track id
<i>track-status</i>	(Optional) interface track status
<i>rnh-status</i>	(Optional) interface rn timer status
<i>bfd-status</i>	(Optional) interface bfd status

Command Mode

- /exec

show ipv6 traffic

```
show ipv6 traffic [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ TABLE_vrf
<vrf-name-out> ] TABLE_ipv6_traffic <uptime> <upkt-fwd> <mpkt-fwd> <ubyte-fwd> <mbyte-fwd>
<upkt-orig> <mpkt-orig> <ubyte-orig> <mbyte-orig> <upkt-consumed> <mpkt-consumed> <ubyte-consumed>
<mbyte-consumed> <ufrag-orig> <mfra-orig> <ufrag-consumed> <mfrag-consumed> <bad-version>
<rt-lookup-fail> <hoplimit-excd> <opt-header-error> <pld-length-too-small> <pm-failed> <mbuf-error>
<could-not-enc> <dest-if-down> <rx-pkts-recv> <rx-bytes-recv> <rx-inhderrors> <rx-innoroutes>
<rx-inaddrrerrors> <rx-inunknownprotos> <rx-intruncatedpkts> <rx-inforwdgrams> <rx-reasmreqds>
<rx-reasmoks> <rx-reasmfails> <rx-indiscards> <rx-indelivers> <rx-inmcastpkts> <rx-inmcastbytes>
<tx-pkts-sent> <tx-bytes-sent> <tx-outrequests> <tx-outnoroutes> <tx-outforwdgrams> <tx-outdiscards>
<tx-outfragreqds> <tx-outfragoks> <tx-outfragfails> <tx-outfragcreates> <tx-outtransmits> <tx-outmcastpkts>
<tx-outmcastbytes> ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
traffic	Display IPv6 traffic statistics
detail	(Optional) Display per protocol IPv6 statistics
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional) VRF table
<i>vrf-name-out</i>	(Optional) vrf name
TABLE_ipv6_traffic	(Optional) ipv6 traffic table
<i>uptime</i>	(Optional) up time
<i>upkt-fwd</i>	(Optional) unicast packets forward
<i>mpkt-fwd</i>	(Optional) multicast packets forward
<i>ubyte-fwd</i>	(Optional) unicast byte forward
<i>mbyte-fwd</i>	(Optional) multicast byte forward
<i>upkt-orig</i>	(Optional) unicast packet origin
<i>mpkt-orig</i>	(Optional) multicast packet origin
<i>ubyte-orig</i>	(Optional) unicast byte origin

<i>mbyte-orig</i>	(Optional) multicast byte origin
<i>upkt-consumed</i>	(Optional) unicast packet consumed
<i>mpkt-consumed</i>	(Optional) multicast packet consumed
<i>ubyte-consumed</i>	(Optional) unicast byte consumed
<i>mbyte-consumed</i>	(Optional) multicast byte consumed
<i>ufrag-orig</i>	(Optional) unicast fragment origin
<i>mfra-orig</i>	(Optional) multicast fragment origin
<i>ufrag-consumed</i>	(Optional) unicast fragment consumed
<i>mfrag-consumed</i>	(Optional) multicast fragment consumed
<i>bad-version</i>	(Optional) bad version
<i>rt-lookup-fail</i>	(Optional) route lookup fail
<i>hoplimit-excd</i>	(Optional) hoplimit exceeded
<i>opt-header-error</i>	(Optional) opt header error
<i>pld-length-too-small</i>	(Optional) pld length too small
<i>pm-failed</i>	(Optional) packet manager failed
<i>mbuf-error</i>	(Optional) m-buffer error
<i>could-not-enc</i>	(Optional) could not encode
<i>dest-if-down</i>	(Optional) destination if down
<i>rx-pkts-recv</i>	(Optional) packets received
<i>rx-bytes-recv</i>	(Optional) bytes received
<i>rx-inhdrrrors</i>	(Optional) inhdr error
<i>rx-innoroutes</i>	(Optional) in-no routes
<i>rx-inaddrerrors</i>	(Optional) in-address error
<i>rx-inunknownprotos</i>	(Optional) in-unknown protocol
<i>rx-intruncatedpkts</i>	(Optional) in-truncated packets
<i>rx-inforwgrams</i>	(Optional) in-forward
<i>rx-reasmreqds</i>	(Optional) reasm request
<i>rx-reasmoks</i>	(Optional) reasm ok
<i>rx-reasmfails</i>	(Optional) reasm fail

<i>rx-indiscards</i>	(Optional) in-discards
<i>rx-indelivers</i>	(Optional) in-delivers
<i>rx-inmcastpkts</i>	(Optional) in multicast packets
<i>rx-inmcastbytes</i>	(Optional) in multicast bytes
<i>tx-pkts-sent</i>	(Optional) packets sent
<i>tx-bytes-sent</i>	(Optional) bytes sent
<i>tx-outrequests</i>	(Optional) out request
<i>tx-outnoroutes</i>	(Optional) out no routes
<i>tx-outforwdgrams</i>	(Optional) out forwardgrams
<i>tx-outdiscards</i>	(Optional) out discards
<i>tx-outfragreqds</i>	(Optional) out fragment request
<i>tx-outfragoks</i>	(Optional) out fragment oks
<i>tx-outfragfails</i>	(Optional) out fragment fails
<i>tx-outfragcreates</i>	(Optional) out fragment creates
<i>tx-outtransmits</i>	(Optional) out transmits
<i>tx-outmcastpkts</i>	(Optional) out multicast packets
<i>tx-outmcastbytes</i>	(Optional) out multicast bytes

Command Mode

- /exec

show isis

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ process | protocol ] [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <instance_num> <uuid>
<process-id> <vrf-name-out> <system-id-out> <is-type-out> <sap-out> <qh-out> <mtu-out> [ <gr-status-out>
] [ <gr-state-active-out> ] [ <gr-state-inactive-out> ] [ <last-gr-status-fail-out> ] [ <last-gr-status-success-out>
] [ <last-gr-status-none-out> ] [ <gr-status-disable-out> ] [ TABLE_afi_safi <af-ix> <af-bfd-config>
<af-pib-tag> ] <metric-style> <accept-metric> [ <net-set-none> ] [ TABLE_area_addr <area-addr-nsap> ] [
<proc-state-not-config> ] [ <proc-state-admin-down> ] [ <proc-state-l3vm-down> ] [
<proc-state-unknown-down> ] [ <proc-state-not-specified> ] [ <proc-state-no-net> ] [ <proc-state-no-vrf-id>
] [ <proc-state-out-memory> ] [ <proc-state-restart> ] [ <proc-state-running> ] <vrf-id-out> [ TABLE_te
<te-lvl-out> <te-lvl-active> ] [ <te-ted-out> ] [ <mpls-te-out> ] [ TABLE_mpls_te [ <mpls-te-lvl-out> ] [
<mpls-te-rtrid-intf-out> ] [ <mpls-te-fa-lvl-out> ] [ TABLE_te_fa <te-fa-sysid-out> <te-fa-intf-out> ] [
<te-stat-sys-id-out> ] [ <te-stat-rtr-id-out> ] [ TABLE_te_stat_lvl <te-stat-lvl-out> <te-stat-up-out>
<te-stat-down-out> ] [ TABLE_segment_routing <af-out> <ptag-out> <cfg-out> <enable-out> [ <exp-null-cfg>
] ] [ TABLE_iib_list_yeild <intf-name-out> ] [ TABLE_auth <auth-lvl-out> [ <auth-type-no-type> ] [
<auth-type-cleartext> ] [ <auth-type-md5> ] [ <auth-type-key-chain> ] [ <auth-type-none> ] [ <auth-check>
] [ <auth-no-check> ] ] [ TABLE_spf <spf-lvl-out> [ <spf-timer> ] ] [ TABLE_distribute_ls
<distribute-linkst-lvl> ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
process	(Optional) Display IS-IS process information
protocol	(Optional) Display IS-IS process information
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>instance_num</i>	(Optional)
<i>uuid</i>	(Optional)
<i>process-id</i>	(Optional)
<i>vrf-name-out</i>	(Optional)

<i>system-id-out</i>	(Optional)
<i>is-type-out</i>	(Optional)
<i>sap-out</i>	(Optional)
<i>qh-out</i>	(Optional)
<i>mtu-out</i>	(Optional)
<i>gr-status-out</i>	(Optional)
<i>gr-state-active-out</i>	(Optional)
<i>gr-state-inactive-out</i>	(Optional)
<i>last-gr-status-fail-out</i>	(Optional)
<i>last-gr-status-success-out</i>	(Optional)
<i>last-gr-status-none-out</i>	(Optional)
<i>gr-status-disable-out</i>	(Optional)
TABLE_afi_safi	(Optional)
<i>af-ix</i>	(Optional)
<i>af-bfd-config</i>	(Optional)
<i>af-pib-tag</i>	(Optional)
<i>metric-style</i>	(Optional)
<i>accept-metric</i>	(Optional)
<i>net-set-none</i>	(Optional)
TABLE_area_addr	(Optional)
<i>area-addr-nsap</i>	(Optional)
<i>proc-state-not-config</i>	(Optional)
<i>proc-state-admin-down</i>	(Optional)
<i>proc-state-l3vm-down</i>	(Optional)
<i>proc-state-unknown-down</i>	(Optional)
<i>proc-state-not-specified</i>	(Optional)
<i>proc-state-no-net</i>	(Optional)
<i>proc-state-no-vrf-id</i>	(Optional)
<i>proc-state-out-memory</i>	(Optional)

<i>proc-state-restart</i>	(Optional)
<i>proc-state-running</i>	(Optional)
<i>vrf-id-out</i>	(Optional)
TABLE_te	(Optional)
<i>te-lvl-out</i>	(Optional)
<i>te-lvl-active</i>	(Optional)
<i>te-ted-out</i>	(Optional)
<i>mpls-te-out</i>	(Optional)
TABLE_mpls_te	(Optional)
<i>mpls-te-lvl-out</i>	(Optional)
<i>mpls-te-rtrid-intf-out</i>	(Optional)
<i>mpls-te-fa-lvl-out</i>	(Optional)
TABLE_te_fa	(Optional)
<i>te-fa-sysid-out</i>	(Optional)
<i>te-fa-intf-out</i>	(Optional)
<i>te-stat-sys-id-out</i>	(Optional)
<i>te-stat-rtr-id-out</i>	(Optional)
TABLE_te_stat_lvl	(Optional)
<i>te-stat-lvl-out</i>	(Optional)
<i>te-stat-up-out</i>	(Optional)
<i>te-stat-down-out</i>	(Optional)
TABLE_segment_routing	(Optional)
<i>af-out</i>	(Optional)
<i>ptag-out</i>	(Optional)
<i>cfg-out</i>	(Optional)
<i>enable-out</i>	(Optional)
<i>exp-null-cfg</i>	(Optional)
TABLE_iib_list_yeild	(Optional)
<i>intf-name-out</i>	(Optional)

TABLE_auth	(Optional)
<i>auth-lvl-out</i>	(Optional)
<i>auth-type-no-type</i>	(Optional)
<i>auth-type-cleartext</i>	(Optional)
<i>auth-type-md5</i>	(Optional)
<i>auth-type-key-chain</i>	(Optional)
<i>auth-type-none</i>	(Optional)
<i>auth-check</i>	(Optional)
<i>auth-no-check</i>	(Optional)
TABLE_spf	(Optional)
<i>spf-lvl-out</i>	(Optional)
<i>spf-timer</i>	(Optional)
TABLE_distribute_ls	(Optional)
<i>distribute-linkst-lvl</i>	(Optional)

Command Mode

- /exec

show isis adjacency

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] adjacency [ <interface> [ p2p-level-1-2 ] ] [ { system-id <sid> } | [ detail ] | [ summary ] } ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <adj-summary-out> <adj-interface-out> [ <adj-interface-name-out> ] [ { TABLE_process_adj <adj-sys-name-out> <adj-sys-id-out> [ <adj-usage-out> ] [ <adj-level-out> ] <adj-state-out> <adj-hold-time-out> <adj-intf-name-out> <adj-detail-set-out> [ { <adj-transitions-out> <adj-flap-out> [ <adj-flap-time-out> ] <adj-ckt-type-out> <adj-ipv4-addr-out> <adj-ipv6-addr-out> <adj-bcast-out> [ { <adj-ckt-id-out> <adj-lan-prio-out> } ] <adj-bfd-ipv4-establish-out> <adj-bfd-ipv6-establish-out> <adj-resurrect-out> [ { <adj-resurrect-count-out> <adj-resurrect-hwm-out> } ] <adj-restart-capable-out> <adj-restart-ack-out> [ { <adj-restart-mode-out> <adj-restart-adj-seen-ra-out> <adj-restart-adj-seen-csnp-out> <adj-restart-adj-seen-l1-csnp-out> <adj-restart-adj-seen-l2-csnp-out> <adj-restart-suppress-adj-out> } ] [ { TABLE_adj_sid <adj-sid-value> <adj-sid-f-flag> <adj-sid-b-flag> <adj-sid-v-flag> <adj-sid-l-flag> <adj-sid-s-flag> <adj-sid-p-flag> <adj-sid-weight> } ] } ] ] [ { TABLE_p2p_adj_sum <adj-summ-p2p-level-out> <adj-summ-p2p-state-out> <adj-summ-p2p-count-out> } ] [ { TABLE_lan_adj_sum <adj-summ-lan-level-out> <adj-summ-lan-state-out> <adj-summ-lan-count-out> } ] } ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
adjacency	Display IS-IS adjacency information
<i>interface</i>	(Optional) IS-IS interface
system-id	(Optional) Hostname or System ID
<i>sid</i>	(Optional) Hostname or System ID (in the form of XXXX.XXXX.XXXX)
detail	(Optional) Display IS-IS adjacency detail information
p2p-level-1-2	(Optional) Display IS-IS point-to-point information at level-1-2
summary	(Optional) Display IS-IS adjacency summary information
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)

TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>adj-summary-out</i>	(Optional)
<i>adj-interface-out</i>	(Optional)
<i>adj-interface-name-out</i>	(Optional)
TABLE_process_adj	(Optional)
<i>adj-sys-name-out</i>	(Optional)
<i>adj-sys-id-out</i>	(Optional)
<i>adj-usage-out</i>	(Optional)
<i>adj-level-out</i>	(Optional)
<i>adj-state-out</i>	(Optional)
<i>adj-hold-time-out</i>	(Optional)
<i>adj-intf-name-out</i>	(Optional)
<i>adj-detail-set-out</i>	(Optional)
<i>adj-transitions-out</i>	(Optional)
<i>adj-flap-out</i>	(Optional)
<i>adj-flap-time-out</i>	(Optional)
<i>adj-ckt-type-out</i>	(Optional)
<i>adj-ipv4-addr-out</i>	(Optional)
<i>adj-ipv6-addr-out</i>	(Optional)
<i>adj-bcast-out</i>	(Optional)
<i>adj-ckt-id-out</i>	(Optional)
<i>adj-lan-prio-out</i>	(Optional)
<i>adj-bfd-ipv4-establish-out</i>	(Optional)
<i>adj-bfd-ipv6-establish-out</i>	(Optional)
<i>adj-resurrect-out</i>	(Optional)
<i>adj-resurrect-count-out</i>	(Optional)
<i>adj-resurrect-hwm-out</i>	(Optional)
<i>adj-restart-capable-out</i>	(Optional)

<i>adj-restart-ack-out</i>	(Optional)
<i>adj-restart-mode-out</i>	(Optional)
<i>adj-restart-adj-seen-ra-out</i>	(Optional)
<i>adj-restart-adj-seen-csnp-out</i>	(Optional)
<i>adj-restart-adj-seen-l1-csnp-out</i>	(Optional)
<i>adj-restart-adj-seen-l2-csnp-out</i>	(Optional)
<i>adj-restart-suppress-adj-out</i>	(Optional)
TABLE_adj_sid	(Optional)
<i>adj-sid-value</i>	(Optional)
<i>adj-sid-f-flag</i>	(Optional)
<i>adj-sid-b-flag</i>	(Optional)
<i>adj-sid-v-flag</i>	(Optional)
<i>adj-sid-l-flag</i>	(Optional)
<i>adj-sid-s-flag</i>	(Optional)
<i>adj-sid-p-flag</i>	(Optional)
<i>adj-sid-weight</i>	(Optional)
TABLE_p2p_adj_sum	(Optional)
<i>adj-summ-p2p-level-out</i>	(Optional)
<i>adj-summ-p2p-state-out</i>	(Optional)
<i>adj-summ-p2p-count-out</i>	(Optional)
TABLE_lan_adj_sum	(Optional)
<i>adj-summ-lan-level-out</i>	(Optional)
<i>adj-summ-lan-state-out</i>	(Optional)
<i>adj-summ-lan-count-out</i>	(Optional)

Command Mode

- /exec

show isis csnp

```
show isis [ <isis-tag> ] csnp [ detail ] [ __readonly__ TABLE_process_tag <process-tag-out> [ {
TABLE_CSNPLEVEL <csnp-level> <csnp-cache-valid> <csnp-cache-hit> <cscnp-cache-miss> <csnp-hit-rate>
[ { TABLE_CSNPLSPS <csnp-start-lsp-id> <csnp-end-lsp-id> <csnp-entry-valid> <csnp-pdu-lengh> [ {
TABLE_CSNPONELSP <csnp-lsp-id> <csnp-lsp-seq-num> <csnp-lsp-chk-sum> <csnp-lsp-life-time> } ] }
] } ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
csnp	Display IS-IS CSNP cache contents
detail	(Optional) Display detailed IS-IS information
<i>__readonly__</i>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
TABLE_CSNPLEVEL	(Optional)
<i>csnp-level</i>	(Optional)
<i>csnp-cache-valid</i>	(Optional)
<i>csnp-cache-hit</i>	(Optional)
<i>cscnp-cache-miss</i>	(Optional)
<i>csnp-hit-rate</i>	(Optional)
TABLE_CSNPLSPS	(Optional)
<i>csnp-start-lsp-id</i>	(Optional)
<i>csnp-end-lsp-id</i>	(Optional)
<i>csnp-entry-valid</i>	(Optional)
<i>csnp-pdu-lengh</i>	(Optional)
TABLE_CSNPONELSP	(Optional)
<i>csnp-lsp-id</i>	(Optional)
<i>csnp-lsp-seq-num</i>	(Optional)
<i>csnp-lsp-chk-sum</i>	(Optional)

<i>csnp-lsp-life-time</i>	(Optional)
---------------------------	------------

Command Mode

- /exec

show isis database

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database [ <level> ] [ detail | advertise
| summary ] [ <lid> ] { [ zero-sequence ] | [ ip prefix <ip-prefix> ] | [ ipv6 prefix <ipv6-prefix> ] | [ router-id
<rid> ] | [ adjacency <adj-id> ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ {
TABLE_process_tag <process-tag-out> } { TABLE_vrf <vrf-name-out> [ <dbase-hname-absent-out> ] [ {
TABLE_process_lvl <dbase-level-out> [ { TABLE_process_lsp <dbase-lsp-name-out> <dbase-lsp-status-out>
<dbase-lsp-absent-out> [ { <dbase-lsp-seqnum-out> <dbase-lsp-cksum-out> [ <dbase-lsp-lifetime-str-out> ]
[ <dbase-lsp-lifetime-out> ] <dbase-att-out> <dbase-partition-out> <dbase-overload-out> <dbase-istype-out>
} ] [ { <dbase-lsp-instance-out> [ { TABLE_process_tlv <dbase-lsp-tlv-name-out> [ <dbase-lsp-area-addr-out>
] [ <dbase-lsp-is-nbr-name-out> ] [ <dbase-lsp-is-nbr-metric-out> ] [ <dbase-lsp-is-nbr-ext-metric-out> ] [
<dbase-lsp-es-nbr-name-out> ] [ <dbase-lsp-es-nbr-metric-out> ] [ <dbase-lsp-es-nbr-ext-metric-out> ] [
<dbase-lsp-auth-type-out> ] [ <dbase-lsp-auth-len-out> ] [ <dbase-lsp-ext-is-name-out> ] [
<dbase-lsp-ext-is-metric-out> ] [ <dbase-lsp-ip-ri-addr-out> ] [ <dbase-lsp-ip-ri-mask-out> ] [
<dbase-lsp-ip-ri-metric-out> ] [ <dbase-lsp-ip-ri-ext-metric-out> ] [ <dbase-lsp-ip-ri-up-down-out> ] [
<dbase-lsp-cap-rtrid> ] [ <dbase-lsp-cap-flags> ] [ { TABLE_process_nlpid <dbase-lsp-prot-support-out> }
] [ <dbase-lsp-ip-addr-out> ] [ <dbase-lsp-ipv6-addr-out> ] [ { TABLE_process_extip
<dbase-lsp-extip-addr-out> <dbase-lsp-extip-prefix-len-out> <dbase-lsp-extip-metric-out>
<dbase-lsp-extip-up-down-out> [ <dbase-lsp-extip-pfxsid> ] [ <dbase-lsp-extip-pfxsid-flags> ] [
<dbase-lsp-extip-unknown-out> } ] [ <dbase-lsp-hname-out> ] [ <dbase-lsp-hname-len-out> ] [ {
TABLE_process_extipv6 <dbase-lsp-extipv6-addr-out> <dbase-lsp-extipv6-prefix-len-out>
<dbase-lsp-extipv6-metric-out> <dbase-lsp-extipv6-up-down-out> <dbase-lsp-extipv6-ext-origin-out> [
<dbase-lsp-extipv6-pfxsid> ] [ <dbase-lsp-extipv6-pfxsid-flags> ] [ <dbase-lsp-extipv6-unknown-out> } ] ]
[ { TABLE_process_subtlv <dbase-lsp-subtlv-name-out> [ <dbase-lsp-extis-admin-group-out> ] [
<dbase-lsp-subtlv-ip-addr-out> ] [ <dbase-lsp-extis-bw-out> ] [ <dbase-lsp-extis-pri1-out> ] [
<dbase-lsp-extis-pri1-val-out> ] [ <dbase-lsp-extis-pri2-out> ] [ <dbase-lsp-extis-pri2-val-out> ] [
<dbase-lsp-extis-te-metric-out> ] [ <dbase-lsp-extis-p2p-adjsid-out> ] [ <dbase-lsp-extis-p2p-adjsid-flags> ]
[ <dbase-lsp-extis-p2p-adjsid-weight> ] [ <dbase-lsp-extis-lan-adjsid-out> ] [ <dbase-lsp-extis-lan-adjsid-sysid>
] [ <dbase-lsp-extis-lan-adjsid-flags> ] [ <dbase-lsp-extis-lan-adjsid-weight> ] [
<dbase-lsp-cap-subtlv-sr-start-sid> ] [ <dbase-lsp-cap-subtlv-sr-end-sid> ] [ <dbase-lsp-cap-subtlv-sr-range>
] [ <dbase-lsp-cap-subtlv-sr-flags> ] [ <dbase-lsp-subtlv-len-out> ] [ <dbase-lsp-subtlv-unknown-out> } ] ]
[ <dbase-lsp-tlv-len-out> ] [ <dbase-lsp-tlv-unknown-out> ] } ] <dbase-lsp-digest-out> } ] } [ {
<dbase-lsp-total-out> [ { <dbase-lsp-empty-out> <dbase-lsp-zeroseq-out> } ] } ] } ] }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
database	Display IS-IS database information

<i>level</i>	(Optional) IS-IS level
<i>lid</i>	(Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX
<i>detail</i>	(Optional) Display detailed IS-IS information
<i>advertise</i>	(Optional) Display advertise tlv lsp-memory information
<i>summary</i>	(Optional) Display summary IS-IS information
<i>zero-sequence</i>	(Optional) LSP with zero sequence number
<i>ip</i>	(Optional) IP attribute filter
<i>ipv6</i>	(Optional) IPv6 attribute filter
<i>prefix</i>	(Optional) Prefix filter
<i>ip-prefix</i>	(Optional) Single exact match IP prefix filter
<i>adjacency</i>	(Optional) Adjacency filter
<i>adj-id</i>	(Optional) Single exact match adjacency filter
<i>router-id</i>	(Optional) Router-id filter
<i>rid</i>	(Optional) single exact match router-id filter
<i>__readonly__</i>	(Optional)
<i>TABLE_process_tag</i>	(Optional)
<i>process-tag-out</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>dbase-hname-absent-out</i>	(Optional)
<i>TABLE_process_lvl</i>	(Optional)
<i>dbase-level-out</i>	(Optional)
<i>TABLE_process_lsp</i>	(Optional)
<i>dbase-lsp-name-out</i>	(Optional)
<i>dbase-lsp-status-out</i>	(Optional)
<i>dbase-lsp-absent-out</i>	(Optional)
<i>dbase-lsp-seqnum-out</i>	(Optional)
<i>dbase-lsp-cksum-out</i>	(Optional)
<i>dbase-lsp-lifetime-str-out</i>	(Optional)

<i>dbase-lsp-lifetime-out</i>	(Optional)
<i>dbase-att-out</i>	(Optional)
<i>dbase-partition-out</i>	(Optional)
<i>dbase-overload-out</i>	(Optional)
<i>dbase-istype-out</i>	(Optional)
<i>dbase-lsp-instance-out</i>	(Optional)
TABLE_process_tlv	(Optional)
<i>dbase-lsp-tlv-name-out</i>	(Optional)
<i>dbase-lsp-area-addr-out</i>	(Optional)
<i>dbase-lsp-is-nbr-name-out</i>	(Optional)
<i>dbase-lsp-is-nbr-metric-out</i>	(Optional)
<i>dbase-lsp-is-nbr-ext-metric-out</i>	(Optional)
<i>dbase-lsp-es-nbr-name-out</i>	(Optional)
<i>dbase-lsp-es-nbr-metric-out</i>	(Optional)
<i>dbase-lsp-es-nbr-ext-metric-out</i>	(Optional)
<i>dbase-lsp-auth-type-out</i>	(Optional)
<i>dbase-lsp-auth-len-out</i>	(Optional)
<i>dbase-lsp-ext-is-name-out</i>	(Optional)
<i>dbase-lsp-ext-is-metric-out</i>	(Optional)
<i>dbase-lsp-ip-ri-addr-out</i>	(Optional)
<i>dbase-lsp-ip-ri-mask-out</i>	(Optional)
<i>dbase-lsp-ip-ri-metric-out</i>	(Optional)
<i>dbase-lsp-ip-ri-ext-metric-out</i>	(Optional)
<i>dbase-lsp-ip-ri-up-down-out</i>	(Optional)
TABLE_process_nlpid	(Optional)
<i>dbase-lsp-prot-support-out</i>	(Optional)
<i>dbase-lsp-ip-addr-out</i>	(Optional)
<i>dbase-lsp-ipv6-addr-out</i>	(Optional)
TABLE_process_extip	(Optional)

<i>dbase-lsp-extip-addr-out</i>	(Optional)
<i>dbase-lsp-extip-prefix-len-out</i>	(Optional)
<i>dbase-lsp-extip-metric-out</i>	(Optional)
<i>dbase-lsp-extip-up-down-out</i>	(Optional)
<i>dbase-lsp-extip-pfxsid</i>	(Optional)
<i>dbase-lsp-extip-pfxsid-flags</i>	(Optional)
<i>dbase-lsp-extip-unknown-out</i>	(Optional)
<i>dbase-lsp-hname-out</i>	(Optional)
<i>dbase-lsp-hname-len-out</i>	(Optional)
TABLE_process_extipv6	(Optional)
<i>dbase-lsp-extipv6-addr-out</i>	(Optional)
<i>dbase-lsp-extipv6-prefix-len-out</i>	(Optional)
<i>dbase-lsp-extipv6-metric-out</i>	(Optional)
<i>dbase-lsp-extipv6-up-down-out</i>	(Optional)
<i>dbase-lsp-extipv6-ext-origin-out</i>	(Optional)
<i>dbase-lsp-extipv6-pfxsid</i>	(Optional)
<i>dbase-lsp-extipv6-pfxsid-flags</i>	(Optional)
<i>dbase-lsp-extipv6-unknown-out</i>	(Optional)
<i>dbase-lsp-tlv-len-out</i>	(Optional)
<i>dbase-lsp-tlv-unknown-out</i>	(Optional)
TABLE_process_subtlv	(Optional)
<i>dbase-lsp-subtlv-name-out</i>	(Optional)
<i>dbase-lsp-extis-admin-group-out</i>	(Optional)
<i>dbase-lsp-subtlv-ip-addr-out</i>	(Optional)
<i>dbase-lsp-extis-bw-out</i>	(Optional)
<i>dbase-lsp-extis-pri1-out</i>	(Optional)
<i>dbase-lsp-extis-pri1-val-out</i>	(Optional)
<i>dbase-lsp-extis-pri2-out</i>	(Optional)
<i>dbase-lsp-extis-pri2-val-out</i>	(Optional)

<i>dbase-lsp-extis-te-metric-out</i>	(Optional)
<i>dbase-lsp-extis-p2p-adjsid-out</i>	(Optional)
<i>dbase-lsp-extis-p2p-adjsid-flags</i>	(Optional)
<i>dbase-lsp-extis-p2p-adjsid-weight</i>	(Optional)
<i>dbase-lsp-extis-lan-adjsid-out</i>	(Optional)
<i>dbase-lsp-extis-lan-adjsid-sysid</i>	(Optional)
<i>dbase-lsp-extis-lan-adjsid-flags</i>	(Optional)
<i>dbase-lsp-extis-lan-adjsid-weight</i>	(Optional)
<i>dbase-lsp-subtlv-len-out</i>	(Optional)
<i>dbase-lsp-subtlv-unknown-out</i>	(Optional)
<i>dbase-lsp-digest-out</i>	(Optional)
<i>dbase-lsp-total-out</i>	(Optional)
<i>dbase-lsp-empty-out</i>	(Optional)
<i>dbase-lsp-zeroseq-out</i>	(Optional)
<i>dbase-lsp-cap-rtrid</i>	(Optional)
<i>dbase-lsp-cap-flags</i>	(Optional)
<i>dbase-lsp-cap-subtlv-sr-start-sid</i>	(Optional)
<i>dbase-lsp-cap-subtlv-sr-end-sid</i>	(Optional)
<i>dbase-lsp-cap-subtlv-sr-range</i>	(Optional)
<i>dbase-lsp-cap-subtlv-sr-flags</i>	(Optional)

Command Mode

- /exec

show isis distribute-ls

```
show isis [ <isis-tag> ] distribute-ls { [ system-id <sid> ] [ lsp-id <lid> ] } [ brief ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <vrf-name-out>
<vrf-id-out> <lslib-connection-out> <client-type-out> <protocol-instance-out> <nxos-instance-out>
<ha-recovery-out> [ <queue-all-out> ] <update-timer-sec-out> <update-timer-msec-out>
<update-timer-running-out> [ <update-timer-due-in> ] [ { TABLE_process_lvl <level-out>
<level-distributing-out> [ { TABLE_ls_node [ <node-id-out> ] [ <node-name-out> ] [ { TABLE_ls_lsp
<lsp-id-out> <lsp-name-out> <lsp-purged-out> [ <node-grpid-out> ] [ <prefix-grpid-out> ] [ <link-grpid-out>
] [ <node-attr-bitfield-out> ] [ <node-flags-out> ] [ <attached-bit-out> ] [ <overloaded-bit-out> ] [ <area-id-out>
] [ <area-length-out> ] [ <name-out> ] [ <ipv4-id-out> ] [ { TABLE_srgb <number-out> <start-out> <size-out>
} ] [ <sr-algo-count-out> ] [ { TABLE_sr_algo <algo-out> } ] [ { TABLE_ls_link <nbr-node-out>
<local-ip-out> <remote-ip-out> [ <link-attr-bitfield-out> ] [ <metric-out> ] [ <local-ip-attr-out> ] [
<remote-ip-attr-out> ] [ <max-link-bw-out> ] [ <max-resv-bw-out> ] [ { TABLE_unresv_bw <number-out>
<bw-out> } ] [ <metric-te-out> ] [ { TABLE_adj_sid <asid-out> <flag-out> <weight-out> } ] } ] [ {
TABLE_ls_prefix <prefix-out> <prefix-len-out> [ <prefix-attr-bitfield-out> ] [ <metric-out> ] [ { TABLE_sid
<sid-out> <algo-out> <flags-out> } ] } ] } ] } ] }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
distribute-ls	Link-state distribution database
system-id	(Optional) Hostname or System ID
<i>sid</i>	(Optional) Hostname or System ID (in the form of XXXX.XXXX.XXXX)
lsp-id	(Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX
<i>lid</i>	(Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX
brief	(Optional) Short output
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>vrf-name-out</i>	(Optional)

<i>vrf-id-out</i>	(Optional)
<i>lslib-connection-out</i>	(Optional)
<i>client-type-out</i>	(Optional)
<i>protocol-instance-out</i>	(Optional)
<i>nxos-instance-out</i>	(Optional)
<i>ha-recovery-out</i>	(Optional)
<i>queue-all-out</i>	(Optional)
<i>update-timer-sec-out</i>	(Optional)
<i>update-timer-msec-out</i>	(Optional)
<i>update-timer-running-out</i>	(Optional)
<i>update-timer-due-in</i>	(Optional)
TABLE_process_lvl	(Optional)
<i>level-out</i>	(Optional)
<i>level-distributing-out</i>	(Optional)
TABLE_ls_node	(Optional)
<i>node-id-out</i>	(Optional)
<i>node-name-out</i>	(Optional)
TABLE_ls_lsp	(Optional)
<i>lsp-id-out</i>	(Optional)
<i>lsp-name-out</i>	(Optional)
<i>lsp-purged-out</i>	(Optional)
<i>node-grpid-out</i>	(Optional)
<i>prefix-grpid-out</i>	(Optional)
<i>link-grpid-out</i>	(Optional)
<i>node-attr-bitfield-out</i>	(Optional)
<i>node-flags-out</i>	(Optional)
<i>attached-bit-out</i>	(Optional)
<i>overloaded-bit-out</i>	(Optional)
<i>area-id-out</i>	(Optional)

<i>area-length-out</i>	(Optional)
<i>name-out</i>	(Optional)
<i>ipv4-id-out</i>	(Optional)
TABLE_srgb	(Optional)
<i>number-out</i>	(Optional)
<i>start-out</i>	(Optional)
<i>size-out</i>	(Optional)
<i>sr-algo-count-out</i>	(Optional)
TABLE_sr_algo	(Optional)
<i>algo-out</i>	(Optional)
TABLE_ls_link	(Optional)
<i>nbr-node-out</i>	(Optional)
<i>local-ip-out</i>	(Optional)
<i>remote-ip-out</i>	(Optional)
<i>link-attr-bitfield-out</i>	(Optional)
<i>metric-out</i>	(Optional)
<i>local-ip-attr-out</i>	(Optional)
<i>remote-ip-attr-out</i>	(Optional)
<i>max-link-bw-out</i>	(Optional)
<i>max-resv-bw-out</i>	(Optional)
TABLE_unresv_bw	(Optional)
<i>number-out</i>	(Optional)
<i>bw-out</i>	(Optional)
<i>metric-te-out</i>	(Optional)
TABLE_adj_sid	(Optional)
<i>asid-out</i>	(Optional)
<i>flag-out</i>	(Optional)
<i>weight-out</i>	(Optional)
TABLE_ls_prefix	(Optional)

<i>prefix-out</i>	(Optional)
<i>prefix-len-out</i>	(Optional)
<i>prefix-attr-bitfield-out</i>	(Optional)
<i>metric-out</i>	(Optional)
TABLE_sid	(Optional)
<i>sid-out</i>	(Optional)
<i>algo-out</i>	(Optional)
<i>flags-out</i>	(Optional)

Command Mode

- /exec

show isis event-history

```
show isis [ <isis-tag> ] [ internal ] event-history { errors | msgs | <isis-event-hist-buf-name> | statistics }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
internal	(Optional) Commands for internal use
event-history	Display IS-IS event history
errors	Error history
msgs	Message history
<i>isis-event-hist-buf-name</i>	Event history buffer
statistics	Show the state and size of the buffer

Command Mode

- /exec

show isis hostname

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] { hostname | hostname-table } [ detail
] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <vrf-name-out> <tag-out>
<hname-enabled-out> <hname-detail-out> [ TABLE_hostname <hname-id-out> <hname-level-out>
<hname-id-mine-out> <hname-name-out> ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
hostname	Display IS-IS hostname table information
hostname-table	Display IS-IS hostname table information
detail	(Optional) Display detailed IS-IS information
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>tag-out</i>	(Optional)
<i>hname-enabled-out</i>	(Optional)
<i>hname-detail-out</i>	(Optional)
TABLE_hostname	(Optional)
<i>hname-id-out</i>	(Optional)
<i>hname-level-out</i>	(Optional)
<i>hname-id-mine-out</i>	(Optional)
<i>hname-name-out</i>	(Optional)

Command Mode

- /exec

show isis interface

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] interface [ brief | <interface> ] [ level-1
| level-2 ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag
<process-tag-out> { TABLE_vrf <vrf-name-out> [ { TABLE_interface [ { <intfb-name-out> <intfb-type-out>
<intfb-ix-out> <intfb-state-out> <intfb-ready-state-out> <intfb-cid-out> <intfb-ckt-type-out> <intfb-mtu-out>
[ { <intf-p2p-metric-lvl-1-out> <intf-p2p-metric-lvl-2-out> <intf-p2p-prio-lvl-1-out> <intf-p2p-prio-lvl-2-out>
<intf-p2p-adj-count-lvl-1-out> <intf-p2p-adj-up-count-lvl-1-out> <intf-p2p-adj-count-lvl-2-out>
<intf-p2p-adj-up-count-lvl-2-out> } ] [ { <intf-loopback-metric-lvl-1-out> <intf-loopback-metric-lvl-2-out>
<intf-loopback-prio-lvl-1-out> <intf-loopback-prio-lvl-2-out> <intf-loopback-adj-count-lvl-1-out>
<intf-loopback-adj-up-count-lvl-1-out> <intf-loopback-adj-count-lvl-2-out>
<intf-loopback-adj-up-count-lvl-2-out> } ] [ { <intf-bcast-metric-lvl-1-out> <intf-bcast-metric-lvl-2-out>
<intf-bcast-prio-lvl-1-out> <intf-bcast-prio-lvl-2-out> <intf-bcast-adj-count-lvl-1-out>
<intf-bcast-adj-up-count-lvl-1-out> <intf-bcast-adj-count-lvl-2-out> <intf-bcast-adj-up-count-lvl-2-out> } ]
} ] [ { <intf-name-out> <intf-status-out> } ] [ { <intf-state-out> <intf-internal-state-out> [
<intf-cib-disabled-out> ] [ <intf-cid-invalid-out> ] } ] [ { TABLE_auth [ { <intf-auth-info-out> [
<intf-auth-kchain-out> ] <intf-auth-chk-info-out> } ] } ] [ { <intf-ix-out> <intf-cid-out> <intf-ckt-type-out>
} ] [ { TABLE_bfd [ <intf-bfd-ipv4-state-out> ] [ <intf-bfd-ipv6-state-out> ] } ] [ <intf-passive-mask-out> ]
[ <intf-passive-mask-lvl-out> ] [ <intf-mgrp-set-out> ] [ <intf-mgrp-state-out> ] [ <intf-mgrp-id-out> ] [
<intf-p2p-type-out> ] [ { <intf-p2p-ext-local-cid-out> <intf-p2p-cid-out> <intf-retx-intv-out>
<intf-retx-throttle-out> } ] [ <intf-loopback-type-out> ] [ { <intf-lsp-intv-out> <intf-mtu-out> [
<intf-hpad-state-out> ] } ] [ { <intf-p2p-pad-ts-out> } ] [ <intf-p2p-adj-count-out> <intf-p2p-adj-up-count-out>
<intf-p2p-prio-out> <intf-p2p-hello-intv-out> <intf-p2p-hello-multi-out> <intf-p2p-hello-next-out> [ {
TABLE_p2p <intf-p2p-lvl-out> <intf-p2p-adj-lvl-out> <intf-p2p-adj-up-lvl-out> <intf-p2p-metric-lvl-out>
<intf-p2p-csnp-lvl-out> <intf-p2p-csnp-nxt-lvl-out> <intf-p2p-lspid-last-lvl-out> } ] } ] [ { <intf-bcast-type-out>
[ { TABLE_bcast_pad [ { <intf-bcast-lvl-out> <intf-bcast-pad-ts-out> } ] } ] [ { TABLE_bcast_dis [ {
<intf-bcast-lvl-dis-out> <intf-bcast-dis-ts-out> } ] } ] [ { TABLE_bcast_pkt <intf-bcast-lvl-info-out>
<intf-bcast-lvl-metric-0-out> <intf-bcast-lvl-metric-2-out> <intf-bcast-lvl-csnp-intv-out>
<intf-bcast-lvl-csnp-next-out> <intf-bcast-lvl-iih-intv-out> <intf-bcast-lvl-iih-multi-out>
<intf-bcast-lvl-iih-next-out> } ] [ { TABLE_bcast_adj <intf-bcast-lvl-value-out> <intf-bcast-lvl-adj-out>
<intf-bcast-lvl-adj-up-out> <intf-bcast-lvl-prio-out> <intf-bcast-lvl-ctid-out> <intf-bcast-lvl-ctid-ts-out>
} ] } ] [ { TABLE_loopback <intf-loopback-lvl-out> <intf-loopback-lvl-metric-out> } ] [ <intf-unknown-out>
} ] } ] }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
brief	(Optional) Brief display of IS-IS interfaces

interface	Display IS-IS interface information
level-1	(Optional) Display Level-1 interfaces
level-2	(Optional) Display level-2 interfaces
<i>interface</i>	(Optional) IS-IS interface
<i>__readonly__</i>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_interface	(Optional)
<i>intf-status-out</i>	(Optional)
<i>intf-name-out</i>	(Optional)
<i>intf-ix-out</i>	(Optional)
<i>intf-state-out</i>	(Optional)
<i>intf-cid-out</i>	(Optional)
<i>intf-ckt-type-out</i>	(Optional)
<i>intfb-name-out</i>	(Optional)
<i>intfb-type-out</i>	(Optional)
<i>intfb-ix-out</i>	(Optional)
<i>intfb-state-out</i>	(Optional)
<i>intfb-ready-state-out</i>	(Optional)
<i>intfb-cid-out</i>	(Optional)
<i>intfb-ckt-type-out</i>	(Optional)
<i>intf-p2p-metric-lvl-1-out</i>	(Optional)
<i>intf-p2p-metric-lvl-2-out</i>	(Optional)
<i>intf-p2p-prio-lvl-1-out</i>	(Optional)
<i>intf-p2p-prio-lvl-2-out</i>	(Optional)
<i>intf-p2p-adj-count-lvl-1-out</i>	(Optional)
<i>intf-p2p-adj-count-lvl-2-out</i>	(Optional)

<i>intf-p2p-adj-up-count-lvl-1-out</i>	(Optional)
<i>intf-p2p-adj-up-count-lvl-2-out</i>	(Optional)
<i>intf-loopback-metric-lvl-1-out</i>	(Optional)
<i>intf-loopback-metric-lvl-2-out</i>	(Optional)
<i>intf-loopback-prio-lvl-1-out</i>	(Optional)
<i>intf-loopback-prio-lvl-2-out</i>	(Optional)
<i>intf-loopback-adj-count-lvl-1-out</i>	(Optional)
<i>intf-loopback-adj-count-lvl-2-out</i>	(Optional)
<i>intf-loopback-adj-up-count-lvl-1-out</i>	(Optional)
<i>intf-loopback-adj-up-count-lvl-2-out</i>	(Optional)
<i>intf-bcast-metric-lvl-1-out</i>	(Optional)
<i>intf-bcast-metric-lvl-2-out</i>	(Optional)
<i>intf-bcast-prio-lvl-1-out</i>	(Optional)
<i>intf-bcast-prio-lvl-2-out</i>	(Optional)
<i>intf-bcast-adj-count-lvl-1-out</i>	(Optional)
<i>intf-bcast-adj-count-lvl-2-out</i>	(Optional)
<i>intf-bcast-adj-up-count-lvl-1-out</i>	(Optional)
<i>intf-bcast-adj-up-count-lvl-2-out</i>	(Optional)
<i>intf-internal-state-out</i>	(Optional)
<i>intf-cib-disabled-out</i>	(Optional)
<i>intf-cid-invalid-out</i>	(Optional)
TABLE_auth	(Optional)
<i>intf-auth-info-out</i>	(Optional)
<i>intf-auth-kchain-out</i>	(Optional)
<i>intf-auth-chk-info-out</i>	(Optional)
TABLE_bfd	(Optional)
<i>intf-bfd-ipv4-state-out</i>	(Optional)
<i>intf-bfd-ipv6-state-out</i>	(Optional)
<i>intf-passive-mask-out</i>	(Optional)

<i>intf-passive-mask-lvl-out</i>	(Optional)
<i>intf-mgrp-set-out</i>	(Optional)
<i>intf-mgrp-state-out</i>	(Optional)
<i>intf-mgrp-id-out</i>	(Optional)
<i>intf-p2p-type-out</i>	(Optional)
<i>intf-p2p-ext-local-cid-out</i>	(Optional)
<i>intf-p2p-cid-out</i>	(Optional)
<i>intf-retx-intv-out</i>	(Optional)
<i>intf-retx-throttle-out</i>	(Optional)
<i>intf-loopback-type-out</i>	(Optional)
<i>intf-lsp-intv-out</i>	(Optional)
<i>intf-mtu-out</i>	(Optional)
<i>intfb-mtu-out</i>	(Optional)
<i>intf-hpad-state-out</i>	(Optional)
<i>intf-p2p-pad-ts-out</i>	(Optional)
<i>intf-p2p-adj-count-out</i>	(Optional)
<i>intf-p2p-adj-up-count-out</i>	(Optional)
<i>intf-p2p-prio-out</i>	(Optional)
<i>intf-p2p-hello-intv-out</i>	(Optional)
<i>intf-p2p-hello-multi-out</i>	(Optional)
<i>intf-p2p-hello-next-out</i>	(Optional)
TABLE_p2p	(Optional)
<i>intf-p2p-lvl-out</i>	(Optional)
<i>intf-p2p-adj-lvl-out</i>	(Optional)
<i>intf-p2p-adj-up-lvl-out</i>	(Optional)
<i>intf-p2p-metric-lvl-out</i>	(Optional)
<i>intf-p2p-csnp-lvl-out</i>	(Optional)
<i>intf-p2p-csnp-nxt-lvl-out</i>	(Optional)
<i>intf-p2p-lspid-last-lvl-out</i>	(Optional)

<i>intf-bcast-type-out</i>	(Optional)
TABLE_bcast_pad	(Optional)
<i>intf-bcast-lvl-out</i>	(Optional)
<i>intf-bcast-pad-ts-out</i>	(Optional)
TABLE_bcast_dis	(Optional)
<i>intf-bcast-lvl-dis-out</i>	(Optional)
<i>intf-bcast-dis-ts-out</i>	(Optional)
TABLE_bcast_pkt	(Optional)
<i>intf-bcast-lvl-info-out</i>	(Optional)
<i>intf-bcast-lvl-metric-0-out</i>	(Optional)
<i>intf-bcast-lvl-metric-2-out</i>	(Optional)
<i>intf-bcast-lvl-csnp-intv-out</i>	(Optional)
<i>intf-bcast-lvl-csnp-next-out</i>	(Optional)
<i>intf-bcast-lvl-iih-intv-out</i>	(Optional)
<i>intf-bcast-lvl-iih-multi-out</i>	(Optional)
<i>intf-bcast-lvl-iih-next-out</i>	(Optional)
TABLE_bcast_adj	(Optional)
<i>intf-bcast-lvl-value-out</i>	(Optional)
<i>intf-bcast-lvl-adj-out</i>	(Optional)
<i>intf-bcast-lvl-adj-up-out</i>	(Optional)
<i>intf-bcast-lvl-prio-out</i>	(Optional)
<i>intf-bcast-lvl-ctid-out</i>	(Optional)
<i>intf-bcast-lvl-ctid-ts-out</i>	(Optional)
TABLE_loopback	(Optional)
<i>intf-loopback-lvl-out</i>	(Optional)
<i>intf-loopback-lvl-metric-out</i>	(Optional)
<i>intf-unknown-out</i>	(Optional)

Command Mode

- /exec

show isis ipv6 redistribute route

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ipv6 redistribute route [ summary |
<ipv6-addr> | <ipv6-prefix> [ longer-prefixes [ summary ] ] ] [ direct-mask ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <redist-route-ipv6-vrf>
[ <redist-route-ipv6-af-ix> ] [ { TABLE_one_route <redist-route-ipv6-prefix> [ <redist-route-ipv6-mask-len>
] [ <redist-route-ipv6-pib-name> ] [ <redist-route-ipv6-direct-mask> ] [ <redist-route-ipv6-route-type> ] [ {
TABLE_redist <redist-route-ipv6-status> <redist-route-ipv6-level> [ <redist-route-ipv6-metric> ] [
<redist-route-ipv6-sum-addr-prefix> ] [ <redist-route-ipv6-sum-addr-mask-len> } ] } ] [
<redist-route-ipv6-summary-addr-prefix> ] [ <redist-route-ipv6-summary-addr-mask-len> ] [
<redist-route-ipv6-summary-route-total> ] [ { TABLE_protocol <redist-route-ipv6-summary-pib-name> [
<redist-route-ipv6-summary-prot-route-total> ] } ] [ <redist-route-ipv6-summary-pending-total> ] [ {
TABLE_mask_len <redist-route-ipv6-summary-mask-len-ix> [ <redist-route-ipv6-summary-mask-len> ] }
] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
redistribute	Display IS-IS redistribute information
route	Display ISIS redistribute route
ipv6	Display IS-IS IPv6 information
longer-prefixes	(Optional) Display exact match and more specific routes
summary	(Optional) Display route counts
direct-mask	(Optional) Display routes with direct-mask set
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>redist-route-ipv6-vrf</i>	(Optional)
<i>redist-route-ipv6-af-ix</i>	(Optional)
TABLE_one_route	(Optional)

<i>redist-route-ipv6-prefix</i>	(Optional)
<i>redist-route-ipv6-mask-len</i>	(Optional)
<i>redist-route-ipv6-pib-name</i>	(Optional)
<i>redist-route-ipv6-direct-mask</i>	(Optional)
<i>redist-route-ipv6-route-type</i>	(Optional)
TABLE_redist	(Optional)
<i>redist-route-ipv6-status</i>	(Optional)
<i>redist-route-ipv6-level</i>	(Optional)
<i>redist-route-ipv6-metric</i>	(Optional)
<i>redist-route-ipv6-sum-addr-prefix</i>	(Optional)
<i>redist-route-ipv6-sum-addr-mask-len</i>	(Optional)
<i>redist-route-ipv6-summary-addr-prefix</i>	(Optional)
<i>redist-route-ipv6-summary-addr-mask-len</i>	(Optional)
<i>redist-route-ipv6-summary-route-total</i>	(Optional)
TABLE_protocol	(Optional)
<i>redist-route-ipv6-summary-pib-name</i>	(Optional)
<i>redist-route-ipv6-summary-prot-route-total</i>	(Optional)
<i>redist-route-ipv6-summary-pending-total</i>	(Optional)
TABLE_mask_len	(Optional)
<i>redist-route-ipv6-summary-mask-len-ix</i>	(Optional)
<i>redist-route-ipv6-summary-mask-len</i>	(Optional)

Command Mode

- /exec

show isis ipv6 route-map statistics

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ipv6 route-map statistics { { redistribute
{ static | direct | amt | bgp <as> | { <src-isis> | eigrp | ospfv3 | rip } <tag> } } | { distribute <src-level> into
<dst-level> } } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_process_tag [
<process-tag-out> ] [ <route-map-stat-vrf> ] [ { TABLE_process_route_map [ <name> ] [ <action> ] [ <seq>
] [ { TABLE_cmd [ <str> ] [ <compare-count> ] [ <match-count> ] } ] <accept-count> <reject-count> } ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
ipv6	Display IS-IS IPv6 information
route-map	Display IS-IS route-map information
statistics	Display IS-IS route-map statistics
redistribute	Redistribute information from another routing protocol
static	Static routes
direct	Directly connected
amt	AMT anycast prefix
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
eigrp	Enhanced Interior Gateway Protocol
src-isis	IS-IS Routing for IPv6
ospfv3	Open Shortest Path First (OSPF) V3
rip	RIP for IPv6 (RIPNG)
<i>tag</i>	Process tag
distribute	Distribute routes between ISIS levels
into	from level-n into level-m

<i>src-level</i>	Route-distribution between levels
<i>dst-level</i>	Route-distribution between levels
<i>__readonly__</i>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>route-map-stat-vrf</i>	(Optional)
TABLE_process_route_map	(Optional) Routemap table
<i>name</i>	(Optional) Route-map Name
<i>action</i>	(Optional) Route-map action
<i>seq</i>	(Optional) Sequence number of the rule in route-map
TABLE_cmd	(Optional) Route-map command table
<i>str</i>	(Optional) Route-map command
<i>compare-count</i>	(Optional) Number of comparisons
<i>match-count</i>	(Optional) Number of matches
<i>accept-count</i>	(Optional) Total number of packets accepted by the policy
<i>reject-count</i>	(Optional) Total number of pakcets rejected by the policy

Command Mode

- /exec

detail	(Optional) Display detail route information
private	(Optional) Show detail and internal information
<u>__readonly__</u>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>afi-safi-out</i>	(Optional)
TABLE_prefix	(Optional)
<i>route-prefix-out</i>	(Optional)
<i>route-mask-len-out</i>	(Optional)
<i>route-level-out</i>	(Optional)
<i>route-summ-discard-addr-out</i>	(Optional)
<i>route-summ-discard-mask-len-out</i>	(Optional)
<i>route-discard-addr-out</i>	(Optional)
<i>route-discard-mask-len-out</i>	(Optional)
<i>route-addr-print-out</i>	(Optional)
<i>route-mask-len-print-out</i>	(Optional)
<i>route-direct-print-out</i>	(Optional)
TABLE_direct_path	(Optional)
<i>route-direct-out</i>	(Optional)
<i>route-direct-via-out</i>	(Optional)
<i>route-direct-if-name-out</i>	(Optional)
<i>route-direct-metric-out</i>	(Optional)
<i>route-direct-level-out</i>	(Optional)
<i>route-direct-instance-out</i>	(Optional)
TABLE_best_path	(Optional)
<i>route-no-def-prefix-out</i>	(Optional)
<i>route-def-prefix-out</i>	(Optional)

<i>route-addr-valid-out</i>	(Optional)
<i>route-marker-out</i>	(Optional)
<i>route-ifname-out</i>	(Optional)
<i>route-metric-out</i>	(Optional)
<i>route-pref-out</i>	(Optional)
<i>route-instance-out</i>	(Optional)
<i>route-discard-mask-out</i>	(Optional)
<i>route-sum-prefix-out</i>	(Optional)
<i>route-sum-prefix-len-out</i>	(Optional)
<i>route-total-out</i>	(Optional)
<i>route-paths-total-out</i>	(Optional)
<i>route-paths-best-out</i>	(Optional)
<i>route-paths-backup-out</i>	(Optional)
TABLE_sum_best_route	(Optional)
<i>route-sum-lvl-out</i>	(Optional)
<i>route-sum-total-out</i>	(Optional)
<i>route-sum-direct-out</i>	(Optional)
<i>route-sum-normal-out</i>	(Optional)
<i>route-sum-missing-out</i>	(Optional)
<i>route-best-pend-num-out</i>	(Optional)
<i>route-bestpaths-out</i>	(Optional)
TABLE_sum_best_path	(Optional)
<i>route-path-sum-lvl-out</i>	(Optional)
<i>route-path-sum-total-out</i>	(Optional)
<i>route-path-sum-direct-out</i>	(Optional)
<i>route-path-sum-normal-out</i>	(Optional)
<i>route-backuppaths-out</i>	(Optional)
TABLE_sum_backup_path	(Optional)
<i>backup-path-sum-lvl-out</i>	(Optional)

<i>backup-path-sum-total-out</i>	(Optional)
<i>backup-path-sum-direct-out</i>	(Optional)
<i>backup-path-sum-normal-out</i>	(Optional)
<i>route-bestroutes-per-mask-out</i>	(Optional)
TABLE_best_mask	(Optional)
<i>route-best-mask-val-out</i>	(Optional)
<i>route-best-mask-count-out</i>	(Optional)
<i>route-pend-q-count-out</i>	(Optional)

Command Mode

- /exec

<i>addr-metric-absent-out</i>	(Optional)
<i>addr-metric-out</i>	(Optional)
<i>addr-route-count-out</i>	(Optional)

Command Mode

- /exec

show isis lslib

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] lslib [ cache [ nodes | links | prefixes
| node <s0> | link <s1> | prefix <s2> | links-of-node <s3> | prefixes-of-node <s4> ] [ detail ] ] [ vrf { <vrf-name>
| <vrf-known-name> | all } ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
lslib	LSLIB client information
cache	(Optional) Link-state cache in LSLIB
nodes	(Optional) All Node objects
links	(Optional) All Link objects
prefixes	(Optional) All Prefix objects
node	(Optional) One node object information
<i>s0</i>	(Optional) Node information
link	(Optional) One link object information
<i>s1</i>	(Optional) Link information
prefix	(Optional) One prefix object information
<i>s2</i>	(Optional) Prefix information
links-of-node	(Optional) All links information of a node
<i>s3</i>	(Optional) Node information
prefixes-of-node	(Optional) All prefixes information of a node
<i>s4</i>	(Optional) Node information
detail	(Optional) Detailed info
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs

Command Mode

- /exec

show isis lsp free-list

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] { non-pseudonode | pseudonode {
<interface> | orphan } } lsp free-list [ summary ] [ vrf { <vrf-name> | <vrf-known-name> | all } ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
non-pseudonode	Display IS-IS non-pseudo-node information
pseudonode	Display IS-IS pseudo-node information
<i>interface</i>	IS-IS interface
orphan	Display orphan LSP information
lsp	Display IS-IS LSP information
free-list	Display free-list information
summary	(Optional) Display LSP count per free-list

Command Mode

- /exec

show isis mesh-group

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] mesh-group [ <mesh-id> ] [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <vrf-name-out> <tag-out> [
<mesh-id-set-out> ] [ <mesh-id-invalid-out> ] [ <mesh-id-none-out> ] [ { TABLE_meshid <mesh-set-id-out>
[ { TABLE_if <mesh-id-intf-name-out> } } ] ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
mesh-group	Display IS-IS mesh-groups
<i>mesh-id</i>	(Optional) Display a single mesh-group
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>tag-out</i>	(Optional)
<i>mesh-id-set-out</i>	(Optional)
<i>mesh-id-invalid-out</i>	(Optional)
<i>mesh-id-none-out</i>	(Optional)
TABLE_meshid	(Optional)
<i>mesh-set-id-out</i>	(Optional)
TABLE_if	(Optional)
<i>mesh-id-intf-name-out</i>	(Optional)

Command Mode

- /exec

show isis non tlv overflow-list

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] { non-pseudonode | pseudonode
<interface> } tlv overflow-list [ vrf { <vrf-name> | <vrf-known-name> | all } ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
non-pseudonode	Display IS-IS non-pseudo-node information
pseudonode	Display IS-IS pseudo-node information
<i>interface</i>	IS-IS interface
tlv	Display IS-IS TLV information
overflow-list	Display ISIS TLV overflow-list information

Command Mode

- /exec

show isis redistribute route

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ ip ] redistribute route [ summary |
<ip-addr> | <ip-prefix> [ longer-prefixes [ summary ] ] ] [ direct-mask ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <redist-route-vrf> [ <redist-route-af-ix> ] [
{ TABLE_one_route <redist-route-prefix> [ <redist-route-mask-len> ] [ <redist-route-pib-name> ] [
<redist-route-direct-mask> ] [ <redist-route-route-type> ] [ { TABLE_redist <redist-route-status>
<redist-route-level> [ <redist-route-metric> ] [ <redist-route-sum-addr-prefix> ] [
<redist-route-sum-addr-mask-len> } } ] [ <redist-route-summary-addr-prefix> ] [
<redist-route-summary-addr-mask-len> ] [ <redist-route-summary-route-total> ] [ { TABLE_protocol
<redist-route-summary-pib-name> [ <redist-route-summary-prot-route-total> } ] [
<redist-route-summary-pending-total> ] [ { TABLE_mask_len <redist-route-summary-mask-len-ix> [
<redist-route-summary-mask-len> } ] ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
redistribute	Display IS-IS redistribute information
route	Display ISIS redistribute route
ip	(Optional) Display IS-IS IPv4 information
<i>ip-addr</i>	(Optional) Display single IP redistribute route
<i>ip-prefix</i>	(Optional) Display single exact match IP redistribute route
longer-prefixes	(Optional) Display exact match and more specific routes
summary	(Optional) Display route counts
direct-mask	(Optional) Display routes with direct-mask set
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>redist-route-vrf</i>	(Optional)

<i>redist-route-af-ix</i>	(Optional)
TABLE_one_route	(Optional)
<i>redist-route-prefix</i>	(Optional)
<i>redist-route-mask-len</i>	(Optional)
<i>redist-route-pib-name</i>	(Optional)
<i>redist-route-direct-mask</i>	(Optional)
<i>redist-route-route-type</i>	(Optional)
TABLE_redist	(Optional)
<i>redist-route-status</i>	(Optional)
<i>redist-route-level</i>	(Optional)
<i>redist-route-metric</i>	(Optional)
<i>redist-route-sum-addr-prefix</i>	(Optional)
<i>redist-route-sum-addr-mask-len</i>	(Optional)
<i>redist-route-summary-addr-prefix</i>	(Optional)
<i>redist-route-summary-addr-mask-len</i>	(Optional)
<i>redist-route-summary-route-total</i>	(Optional)
TABLE_protocol	(Optional)
<i>redist-route-summary-pib-name</i>	(Optional)
<i>redist-route-summary-prot-route-total</i>	(Optional)
<i>redist-route-summary-pending-total</i>	(Optional)
TABLE_mask_len	(Optional)
<i>redist-route-summary-mask-len-ix</i>	(Optional)
<i>redist-route-summary-mask-len</i>	(Optional)

Command Mode

- /exec

show isis route-map statistics

```
show isis [<isis-tag>] [vrf {<vrf-name> | <vrf-known-name> | all}] [ip] route-map statistics { { redistribute
{ static | direct | amt | bgp <as> | { <src-isis> | eigrp | ospf | rip } <tag> } } | { distribute <src-level> into
<dst-level> } } [vrf {<vrf-name> | <vrf-known-name> | all}] [ __readonly__ { TABLE_process_tag
<process-tag-out> { TABLE_vrf <route-map-stat-vrf> [ { TABLE_process_route_map [ <name> ] [ <action>
] [ <seq> ] [ { TABLE_cmd [ <str> ] [ <compare-count> ] [ <match-count> ] } ] <accept-count> <reject-count>
} } } }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
ip	(Optional) Display IS-IS IPv4 information
route-map	Display IS-IS route-map information
statistics	Display IS-IS route-map statistics
redistribute	Redistribute information from another routing protocol
static	Static routes
direct	Directly connected
amt	AMT anycast prefix
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
eigrp	Enhanced Interior Gateway Protocol
src-isis	IS-IS Routing for IPv4
ospf	Open Shortest Path First (OSPF)
rip	RIP for IPv4
<i>tag</i>	Process tag
distribute	Distribute routes between ISIS levels

<i>into</i>	from level-n into level-m
<i>src-level</i>	Route-distribution between levels
<i>dst-level</i>	Route-distribution between levels
<i>__readonly__</i>	(Optional)
<i>TABLE_process_tag</i>	(Optional)
<i>process-tag-out</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>route-map-stat-vrf</i>	(Optional)
<i>TABLE_process_route_map</i>	(Optional) Routemap table
<i>name</i>	(Optional) Route-map Name
<i>action</i>	(Optional) Route-map action
<i>seq</i>	(Optional) Sequence number of the rule in route-map
<i>TABLE_cmd</i>	(Optional) Route-map command table
<i>str</i>	(Optional) Route-map command
<i>compare-count</i>	(Optional) Number of comparisons
<i>match-count</i>	(Optional) Number of matches
<i>accept-count</i>	(Optional) Total number of packets accepted by the policy
<i>reject-count</i>	(Optional) Total number of packets rejected by the policy

Command Mode

- /exec

show isis route

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ ip ] route [ summary | detail | private
| <ip-addr> [ detail | private ] | <ip-prefix> [ detail | private | longer-prefixes [ summary | detail | private ] ] ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> {
TABLE_vrf <vrf-name-out> <afi-safi-out> [ TABLE_prefix [ <route-prefix-out> <route-mask-len-out>
<route-level-out> ] [ <route-summ-discard-addr-out> <route-summ-discard-mask-len-out> ] [
<route-discard-addr-out> <route-discard-mask-len-out> ] [ <route-addr-print-out> <route-mask-len-print-out>
<route-direct-print-out> ] [ TABLE_direct_path [ <route-direct-out> <route-direct-via-out>
<route-direct-if-name-out> <route-direct-metric-out> <route-direct-level-out> ] [ <route-direct-instance-out>
] ] [ TABLE_best_path [ <route-no-def-prefix-out> ] [ <route-def-prefix-out> ] <route-addr-valid-out>
<route-marker-out> <route-iframe-out> <route-metric-out> <route-pref-out> [ <route-instance-out> ] ] [
<route-discard-mask-out> ] [ [ <route-sum-prefix-out> <route-sum-prefix-len-out> ] <route-total-out>
<route-paths-total-out> <route-paths-best-out> <route-paths-backup-out> [ TABLE_sum_best_route
<route-sum-lvl-out> <route-sum-total-out> [ <route-sum-direct-out> ] [ <route-sum-normal-out> ] [
<route-sum-missing-out> ] ] [ <route-best-pend-num-out> ] <route-bestpaths-out> [ TABLE_sum_best_path
<route-path-sum-lvl-out> <route-path-sum-total-out> [ <route-path-sum-direct-out> ] [
<route-path-sum-normal-out> ] ] <route-backuppaths-out> [ TABLE_sum_backup_path
<backup-path-sum-lvl-out> <backup-path-sum-total-out> [ <backup-path-sum-direct-out> ] [
<backup-path-sum-normal-out> ] ] <route-bestroutes-per-mask-out> [ TABLE_best_mask
<route-best-mask-val-out> <route-best-mask-count-out> ] [ <route-pend-q-count-out> ] ] ] } }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
ip	(Optional) Display IS-IS IPv4 information
route	Display IS-IS route information
<i>ip-addr</i>	(Optional) Display single IP route
<i>ip-prefix</i>	(Optional) Display single exact match IP route
longer-prefixes	(Optional) Display exact match and more specific routes
summary	(Optional) Display route counts
detail	(Optional) Display detail route information
private	(Optional) Show detail and internal information

<code>__readonly__</code>	(Optional)
<code>TABLE_process_tag</code>	(Optional)
<code>process-tag-out</code>	(Optional)
<code>TABLE_vrf</code>	(Optional)
<code>vrf-name-out</code>	(Optional)
<code>afi-safi-out</code>	(Optional)
<code>TABLE_prefix</code>	(Optional)
<code>route-prefix-out</code>	(Optional)
<code>route-mask-len-out</code>	(Optional)
<code>route-level-out</code>	(Optional)
<code>route-summ-discard-addr-out</code>	(Optional)
<code>route-summ-discard-mask-len-out</code>	(Optional)
<code>route-discard-addr-out</code>	(Optional)
<code>route-discard-mask-len-out</code>	(Optional)
<code>route-addr-print-out</code>	(Optional)
<code>route-mask-len-print-out</code>	(Optional)
<code>route-direct-print-out</code>	(Optional)
<code>TABLE_direct_path</code>	(Optional)
<code>route-direct-out</code>	(Optional)
<code>route-direct-via-out</code>	(Optional)
<code>route-direct-if-name-out</code>	(Optional)
<code>route-direct-metric-out</code>	(Optional)
<code>route-direct-level-out</code>	(Optional)
<code>route-direct-instance-out</code>	(Optional)
<code>TABLE_best_path</code>	(Optional)
<code>route-no-def-prefix-out</code>	(Optional)
<code>route-def-prefix-out</code>	(Optional)
<code>route-addr-valid-out</code>	(Optional)
<code>route-marker-out</code>	(Optional)

<i>route-ifname-out</i>	(Optional)
<i>route-metric-out</i>	(Optional)
<i>route-pref-out</i>	(Optional)
<i>route-instance-out</i>	(Optional)
<i>route-discard-mask-out</i>	(Optional)
<i>route-sum-prefix-out</i>	(Optional)
<i>route-sum-prefix-len-out</i>	(Optional)
<i>route-total-out</i>	(Optional)
<i>route-paths-total-out</i>	(Optional)
<i>route-paths-best-out</i>	(Optional)
<i>route-paths-backup-out</i>	(Optional)
TABLE_sum_best_route	(Optional)
<i>route-sum-lvl-out</i>	(Optional)
<i>route-sum-total-out</i>	(Optional)
<i>route-sum-direct-out</i>	(Optional)
<i>route-sum-normal-out</i>	(Optional)
<i>route-sum-missing-out</i>	(Optional)
<i>route-best-pend-num-out</i>	(Optional)
<i>route-bestpaths-out</i>	(Optional)
TABLE_sum_best_path	(Optional)
<i>route-path-sum-lvl-out</i>	(Optional)
<i>route-path-sum-total-out</i>	(Optional)
<i>route-path-sum-direct-out</i>	(Optional)
<i>route-path-sum-normal-out</i>	(Optional)
<i>route-backuppaths-out</i>	(Optional)
TABLE_sum_backup_path	(Optional)
<i>backup-path-sum-lvl-out</i>	(Optional)
<i>backup-path-sum-total-out</i>	(Optional)
<i>backup-path-sum-direct-out</i>	(Optional)

<i>backup-path-sum-normal-out</i>	(Optional)
<i>route-bestroutes-per-mask-out</i>	(Optional)
TABLE_best_mask	(Optional)
<i>route-best-mask-val-out</i>	(Optional)
<i>route-best-mask-count-out</i>	(Optional)
<i>route-pend-q-count-out</i>	(Optional)

Command Mode

- /exec

show isis rrm

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] rrm <interface> [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <rrm-if-name> [ {
TABLE_rrm <rrm-level> <rrm-retx-interval> <rrm-retx-throttle-interval> <rrm-retx-queue-length>
<rrm-next-retx> <rrm-retx-queue-hwm> <rrm-retx-queue-exceed> <rrm-dbase-hdr> [ <rrm-timestamp> ] [
<rrm-lsp-retx-instance> ] [ <rrm-lsp-db-instance> ] [ <rrm-rrm-set> ] [ <rrm-srm-set> ] } } ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
rrm	Display IS-IS Retransmit-Routing-Message information
<i>interface</i>	IS-IS interface
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>rrm-if-name</i>	(Optional)
TABLE_rrm	(Optional)
<i>rrm-level</i>	(Optional)
<i>rrm-retx-interval</i>	(Optional)
<i>rrm-retx-throttle-interval</i>	(Optional)
<i>rrm-retx-queue-length</i>	(Optional)
<i>rrm-next-retx</i>	(Optional)
<i>rrm-retx-queue-hwm</i>	(Optional)
<i>rrm-retx-queue-exceed</i>	(Optional)
<i>rrm-dbase-hdr</i>	(Optional)
<i>rrm-timestamp</i>	(Optional)

<i>rrm-lsp-retx-instance</i>	(Optional)
<i>rrm-lsp-db-instance</i>	(Optional)
<i>rrm-rrm-set</i>	(Optional)
<i>rrm-srm-set</i>	(Optional)

Command Mode

- /exec

TABLE_lvl_detail	(Optional)
<i>lvl-out</i>	(Optional)
<i>instance-out</i>	(Optional)
<i>init-ts-out</i>	(Optional)
<i>ts-lvl-out</i>	(Optional)
<i>ts-is-out</i>	(Optional)
<i>ts-urib-out</i>	(Optional)
<i>ts-elapsed-out</i>	(Optional)
TABLE_lvl_second	(Optional)
<i>lvls-out</i>	(Optional)
<i>spf-node-out</i>	(Optional)
<i>spf-cnt-out</i>	(Optional)
<i>changed-cnt-out</i>	(Optional)
<i>spf-reason-out</i>	(Optional)
TABLE_log_brief	(Optional)
<i>ago-time-out</i>	(Optional)
TABLE_lvl	(Optional)
<i>lvl-out</i>	(Optional)
<i>reason-out</i>	(Optional)
<i>count-out</i>	(Optional)
<i>elapsed-ts-out</i>	(Optional)

Command Mode

- /exec

show isis srm

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] srm <interface> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <srm-if-name> [ { TABLE_srm <srm-level> <srm-if-eligible> <srm-if-not-on-srm-list> <srm-lsp-interval> <srm-next-lsp> <srm-dbase-hdr> } } ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
srm	Display IS-IS Send-Routing-Message information
<i>interface</i>	IS-IS interface
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>srm-if-name</i>	(Optional)
TABLE_srm	(Optional)
<i>srm-level</i>	(Optional)
<i>srm-if-eligible</i>	(Optional)
<i>srm-if-not-on-srm-list</i>	(Optional)
<i>srm-lsp-interval</i>	(Optional)
<i>srm-next-lsp</i>	(Optional)
<i>srm-dbase-hdr</i>	(Optional)

Command Mode

- /exec

show isis ssn

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ssn <interface> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <snn-if-name> [ { TABLE_ssn <snn-level> <snn-psnp-eligible> <snn-next-psnp> <snn-dbase_hdr> } ] } ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
ssn	Display IS-IS Send-Sequence-Number information
<i>interface</i>	IS-IS interface
<i>__readonly__</i>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>snn-if-name</i>	(Optional)
TABLE_ssn	(Optional)
<i>snn-level</i>	(Optional)
<i>snn-psnp-eligible</i>	(Optional)
<i>snn-next-psnp</i>	(Optional)
<i>snn-dbase_hdr</i>	(Optional)

Command Mode

- /exec

show isis statistics

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] statistics [ <interface> ] [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ <stat-if-out> <tag-out> TABLE_vrf [ <vrf-name-out>
] [ <stat-if-name-out> ] [ <stat-spf-calc-out> ] [ <stat-lsp-sourced-out> ] [ <stat-lsp-refresh-out> ] [
<stat-lsp-purge-out> ] <stat-dis-elections-out> ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
statistics	Display IS-IS protocol statistics
<i>interface</i>	(Optional) IS-IS interface
<i>__readonly__</i>	(Optional)
<i>stat-if-out</i>	(Optional)
<i>tag-out</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>stat-if-name-out</i>	(Optional)
<i>stat-spf-calc-out</i>	(Optional)
<i>stat-lsp-sourced-out</i>	(Optional)
<i>stat-lsp-refresh-out</i>	(Optional)
<i>stat-lsp-purge-out</i>	(Optional)
<i>stat-dis-elections-out</i>	(Optional)

Command Mode

- /exec

show isis summary-address

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ ip ] summary-address [ <ip-addr> |
<ip-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<vrf-name-out> <tag-out> <afi-safi-out> [ <addr-absent-out> ] [ { TABLE_addr <sum-prefix-out>
<mask-len-out> <level-out> [ { TABLE_lvl <addr-lvl-out> <addr-num-out> [ <addr-metric-absent-out> ] [
<addr-metric-out> ] [ <addr-route-count-out> } ] } ] ] ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
ip	(Optional) Display IS-IS IPv4 information
summary-address	Display IS-IS summary address
<i>ip-addr</i>	(Optional) Display single IP summary address
<i>ip-prefix</i>	(Optional) Display single exact match IP summary address
longer-prefixes	(Optional) Display exact match and more specific summary address
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>tag-out</i>	(Optional)
<i>afi-safi-out</i>	(Optional)
<i>addr-absent-out</i>	(Optional)
TABLE_addr	(Optional)
<i>sum-prefix-out</i>	(Optional)
<i>mask-len-out</i>	(Optional)
<i>level-out</i>	(Optional)
TABLE_lvl	(Optional)

<i>addr-lvl-out</i>	(Optional)
<i>addr-num-out</i>	(Optional)
<i>addr-metric-absent-out</i>	(Optional)
<i>addr-metric-out</i>	(Optional)
<i>addr-route-count-out</i>	(Optional)

Command Mode

- /exec

show isis topology

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] topology [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <topology-vrf> [ {
TABLE_LEVEL <topology-level> [ { TABLE_ONE_ROUTE <topology-one-route-node-name> [
<topology-one-route-spf-instance> ] [ <topology-one-route-on-path> ] [ <topology-one-route-mt-id> ] [ {
TABLE_ONE_ROUTE_NH <topology-one-route-nh-system-name> [ <topology-one-route-nh-if-name> ] [
<topology-one-route-nh-metric> ] } ] [ { TABLE_ONE_ROUTE_MBEST
<topology-one-route-mbest-system-name> [ <topology-one-route-mbest-if-name> ] [
<topology-one-route-mbest-metric> ] } ] } ] [ <topology-default-spf-instance> ] [ { TABLE_NH
<topology-nh-system-name> [ <topology-nh-if-name> ] [ <topology-nh-metric> ] } ] [ { TABLE_MBEST
<topology-mbest-system-name> [ <topology-mbest-if-name> ] [ <topology-mbest-metric> ] } ] } ] }
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
topology	Display IS-IS Topology information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>topology-vrf</i>	(Optional)
TABLE_LEVEL	(Optional)
<i>topology-level</i>	(Optional)
TABLE_ONE_ROUTE	(Optional)
<i>topology-one-route-node-name</i>	(Optional)
<i>topology-one-route-spf-instance</i>	(Optional)
<i>topology-one-route-on-path</i>	(Optional)
<i>topology-one-route-mt-id</i>	(Optional)
TABLE_ONE_ROUTE_NH	(Optional)

<i>topology-one-route-nh-system-name</i>	(Optional)
<i>topology-one-route-nh-if-name</i>	(Optional)
<i>topology-one-route-nh-metric</i>	(Optional)
TABLE_ONE_ROUTE_MBEST	(Optional)
<i>topology-one-route-mbest-system-name</i>	(Optional)
<i>topology-one-route-mbest-if-name</i>	(Optional)
<i>topology-one-route-mbest-metric</i>	(Optional)
<i>topology-default-spf-instance</i>	(Optional)
TABLE_NH	(Optional)
<i>topology-nh-system-name</i>	(Optional)
<i>topology-nh-if-name</i>	(Optional)
<i>topology-nh-metric</i>	(Optional)
TABLE_MBEST	(Optional)
<i>topology-mbest-system-name</i>	(Optional)
<i>topology-mbest-if-name</i>	(Optional)
<i>topology-mbest-metric</i>	(Optional)

Command Mode

- /exec

show isis traffic

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] traffic [ <interface> ] [ mbuf-priority
] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out>
{ TABLE_vrf <vrf-name-out> <traffic-if-out> [ <traffic-if-name-out> ] <traffic-lan-iih-out>
<traffic-lan-iih-rcv-out> <traffic-lan-iih-xmit-out> <traffic-lan-iih-rcv-auth-err-out> <traffic-lan-iih-rcv-err-out>
<traffic-p2p-iih-out> <traffic-p2p-iih-rcv-out> <traffic-p2p-iih-xmit-out> <traffic-p2p-iih-rcv-auth-err-out>
<traffic-p2p-iih-rcv-err-out> <traffic-csnp-out> <traffic-csnp-rcv-out> <traffic-csnp-xmit-out>
<traffic-csnp-rcv-auth-err-out> <traffic-csnp-rcv-err-out> <traffic-psnp-out> <traffic-psnp-rcv-out>
<traffic-psnp-xmit-out> <traffic-psnp-rcv-auth-err-out> <traffic-psnp-rcv-err-out> <traffic-lsp-out>
<traffic-lsp-rcv-out> <traffic-lsp-flood-out> <traffic-lsp-rcv-auth-err-out> <traffic-lsp-rcv-err-out>
<traffic-lsp-rexmit-out> [ <traffic-xmit-err-out> ] [ <traffic-unknown-pdu-rcv-out> } } ]
```

Syntax Description

show	Show running system information
isis	Display IS-IS status and configuration
<i>isis-tag</i>	(Optional) Routing process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
traffic	Display IS-IS traffic information
<i>interface</i>	(Optional) IS-IS interface
mbuf-priority	(Optional) Display mbuf priorities for received PDUs
<u>__readonly__</u>	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>traffic-if-out</i>	(Optional)
<i>traffic-if-name-out</i>	(Optional)
<i>traffic-lan-iih-out</i>	(Optional)
<i>traffic-lan-iih-rcv-out</i>	(Optional)
<i>traffic-lan-iih-xmit-out</i>	(Optional)

<i>traffic-lan-iih-rcv-auth-err-out</i>	(Optional)
<i>traffic-lan-iih-rcv-err-out</i>	(Optional)
<i>traffic-p2p-iih-out</i>	(Optional)
<i>traffic-p2p-iih-rcv-out</i>	(Optional)
<i>traffic-p2p-iih-xmit-out</i>	(Optional)
<i>traffic-p2p-iih-rcv-auth-err-out</i>	(Optional)
<i>traffic-p2p-iih-rcv-err-out</i>	(Optional)
<i>traffic-csnp-out</i>	(Optional)
<i>traffic-csnp-rcv-out</i>	(Optional)
<i>traffic-csnp-xmit-out</i>	(Optional)
<i>traffic-csnp-rcv-auth-err-out</i>	(Optional)
<i>traffic-csnp-rcv-err-out</i>	(Optional)
<i>traffic-psnp-out</i>	(Optional)
<i>traffic-psnp-rcv-out</i>	(Optional)
<i>traffic-psnp-xmit-out</i>	(Optional)
<i>traffic-psnp-rcv-auth-err-out</i>	(Optional)
<i>traffic-psnp-rcv-err-out</i>	(Optional)
<i>traffic-lsp-out</i>	(Optional)
<i>traffic-lsp-rcv-out</i>	(Optional)
<i>traffic-lsp-flood-out</i>	(Optional)
<i>traffic-lsp-rcv-auth-err-out</i>	(Optional)
<i>traffic-lsp-rcv-err-out</i>	(Optional)
<i>traffic-lsp-rexmit-out</i>	(Optional)
<i>traffic-xmit-err-out</i>	(Optional)
<i>traffic-unknown-pdu-rcv-out</i>	(Optional)

Command Mode

- /exec

show itd

```
show itd <svc-name> [ brief ] [ __readonly__ <is_firstentry> <is_detail> <is_active> <is_firstentry_routemap>
<is_firstentry_standby> <is_firstentry_acl> <is_lastentry> [ TABLE_summary <service_name> [ <probe> ]
<lb_scheme> [ <interface> ] <state> <buckets> [ <reason> ] [ <vrf_name> ] [ <excludeACL> ] [ <userACL>
] [ <peer_status> ] [ TABLE_device <device_grp> <dg_probe> <dg_probe_port> ] [ TABLE_route_map [
<route_map> ] [ <interface> ] [ <r_status> ] [ <int_track_id> ] ] [ TABLE_vip [ <vip_ip> ] [ <vip_probe> ]
[ <vip_port> ] [ <vip_dgname> ] [ <ace_name> ] [ <ace_seq> ] [ <ace_ip> ] [ <ace_protocol> ] [ <ace_port>
] [ TABLE_vip_node [ <vip_node> ] [ <vip_nodev6> ] <vip_config> <vip_weight> <vip_node_probe>
<vip_node_probe_port> <vip_node_probe_ip> <vip_status> <vip_track_id> <vip_ip_sla_id> [
TABLE_vip_standby [ <vip_standby_ip> ] [ <vip_standby_ipv6> ] <vip_standby_config>
<vip_standby_weight> <vip_standby_probe> <vip_standby_probe_port> <vip_standby_probe_ip>
<vip_standby_status> <vip_standby_track_id> <vip_standby_sla_id> ] [ TABLE_vip_acl [ <vip_access_list>
] ] ] [ TABLE_node [ <node> ] [ <nodev6> ] <config> <weight> <node_probe> <node_probe_port>
<node_probe_ip> <status> <track_id> <ip_sla_id> [ TABLE_standby [ <standby_ip> ] [ <standby_ipv6> ]
<standby_config> <standby_weight> <standby_probe> <standby_probe_port> <standby_probe_ip>
<standby_status> <standby_track_id> <standby_sla_id> ] [ TABLE_acl [ <access_list> ] ] ] ]
```

Syntax Description

show	Show running system information
itd	ITD service
<i>svc-name</i>	ITD service name
brief	(Optional) brief
<i>__readonly__</i>	(Optional) Read Only
<i>is_firstentry</i>	(Optional)
<i>is_detail</i>	(Optional)
<i>is_active</i>	(Optional)
<i>is_firstentry_routemap</i>	(Optional)
<i>is_firstentry_acl</i>	(Optional)
<i>is_lastentry</i>	(Optional)
<i>is_firstentry_standby</i>	(Optional)
TABLE_summary	(Optional)
<i>service_name</i>	(Optional) service_name
<i>probe</i>	(Optional) probe
<i>lb_scheme</i>	(Optional) lb scheme
<i>interface</i>	(Optional) interface

<i>state</i>	(Optional) state
<i>buckets</i>	(Optional) buckets
<i>reason</i>	(Optional) inactive reason
<i>vrf_name</i>	(Optional) VRF-Name
<i>excludeACL</i>	(Optional) exclude access-list
<i>userACL</i>	(Optional) user access-list
<i>peer_status</i>	(Optional) peer status
TABLE_device	(Optional)
<i>device_grp</i>	(Optional) service device group
<i>dg_probe</i>	(Optional) probe type
<i>dg_probe_port</i>	(Optional) probe port
TABLE_route_map	(Optional)
<i>route_map</i>	(Optional) service route map
<i>interface</i>	(Optional) interface
<i>r_status</i>	(Optional) route map status
<i>int_track_id</i>	(Optional) interface track id
TABLE_vip	(Optional)
<i>vip_ip</i>	(Optional) vip ip
<i>vip_probe</i>	(Optional) vip protocol
<i>vip_port</i>	(Optional) vip port
<i>vip_dgname</i>	(Optional) vip device group
<i>ace_name</i>	(Optional) ace information
<i>ace_seq</i>	(Optional) ace information
<i>ace_ip</i>	(Optional) ace information
<i>ace_protocol</i>	(Optional) ace information
<i>ace_port</i>	(Optional) ace information
TABLE_vip_node	(Optional)
<i>vip_node</i>	(Optional) service node ip
<i>vip_nodev6</i>	(Optional) service node IPv6

<i>vip_config</i>	(Optional) node config
<i>vip_weight</i>	(Optional) node weight
<i>vip_status</i>	(Optional) node status
<i>vip_node_probe</i>	(Optional) node probe type
<i>vip_node_probe_port</i>	(Optional) node probe port
<i>vip_node_probe_ip</i>	(Optional) node probe ip
<i>vip_track_id</i>	(Optional) node track id
<i>vip_ip_sla_id</i>	(Optional) node ip sla id
TABLE_vip_standby	(Optional)
<i>vip_standby_ip</i>	(Optional) standby node ip
<i>vip_standby_ipv6</i>	(Optional) standby node ipv6
<i>vip_standby_config</i>	(Optional) standby node config
<i>vip_standby_weight</i>	(Optional) standby node weight
<i>vip_standby_status</i>	(Optional) standby node status
<i>vip_standby_probe</i>	(Optional) standby node probe type
<i>vip_standby_probe_port</i>	(Optional) standby node probe port
<i>vip_standby_probe_ip</i>	(Optional) standby node probe ip
<i>vip_standby_track_id</i>	(Optional) standby node track id
<i>vip_standby_sla_id</i>	(Optional) standby node sla id
TABLE_vip_acl	(Optional)
<i>vip_access_list</i>	(Optional) access list
TABLE_node	(Optional)
<i>node</i>	(Optional) service node ip
<i>nodev6</i>	(Optional) service node IPv6
<i>config</i>	(Optional) node config
<i>weight</i>	(Optional) node weight
<i>status</i>	(Optional) node status
<i>node_probe</i>	(Optional) node probe type
<i>node_probe_port</i>	(Optional) node probe port

<i>node_probe_ip</i>	(Optional) node probe ip
<i>track_id</i>	(Optional) node track id
<i>ip_sla_id</i>	(Optional) node ip sla id
TABLE_standby	(Optional)
<i>standby_ip</i>	(Optional) standby node ip
<i>standby_ipv6</i>	(Optional) standby node ipv6
<i>standby_config</i>	(Optional) standby node config
<i>standby_weight</i>	(Optional) standby node weight
<i>standby_status</i>	(Optional) standby node status
<i>standby_probe</i>	(Optional) standby node probe type
<i>standby_probe_port</i>	(Optional) standby node probe port
<i>standby_probe_ip</i>	(Optional) standby node probe ip
<i>standby_track_id</i>	(Optional) standby node track id
<i>standby_sla_id</i>	(Optional) standby node sla id
TABLE_acl	(Optional)
<i>access_list</i>	(Optional) access list

Command Mode

- /exec

show itd

```
show itd [ brief ] [ __readonly__ <i>is_firstentry</i> <i>is_detail</i> <i>is_active</i> <i>is_firstentry_routemap</i>
<i>is_firstentry_standby</i> <i>is_firstentry_acl</i> <i>is_lastentry</i> [ TABLE_summary <service_name> [ <probe> ]
<lb_scheme> [ <interface> ] <state> <buckets> [ <reason> ] [ <vrf_name> ] [ <excludeACL> ] [ <userACL>
] [ <peer_status> ] [ TABLE_device <device_grp> <dg_probe> <dg_probe_port> ] [ TABLE_route_map [
<route_map> ] [ <interface> ] [ <r_status> ] [ <int_track_id> ] ] [ TABLE_vip [ <vip_ip> ] [ <vip_probe> ]
[ <vip_port> ] [ <vip_dgname> ] [ TABLE_vip_node [ <vip_node> ] [ <vip_nodev6> ] <vip_config>
<vip_weight> <vip_node_probe> <vip_node_probe_port> <vip_node_probe_ip> <vip_status> <vip_track_id>
<vip_ip_sla_id> [ TABLE_vip_standby [ <vip_standby_ip> ] [ <vip_standby_ipv6> ] <vip_standby_config>
<vip_standby_weight> <vip_standby_probe> <vip_standby_probe_port> <vip_standby_probe_ip>
<vip_standby_status> <vip_standby_track_id> <vip_standby_sla_id> ] [ TABLE_vip_acl [ <vip_access_list>
] ] ] [ TABLE_node [ <node> ] [ <nodev6> ] <config> <weight> <node_probe> <node_probe_port>
<node_probe_ip> <status> <track_id> <ip_sla_id> [ TABLE_standby [ <standby_ip> ] [ <standby_ipv6> ]
<standby_config> <standby_weight> <standby_probe> <standby_probe_port> <standby_probe_ip>
<standby_status> <standby_track_id> <standby_sla_id> ] [ TABLE_acl [ <access_list> ] ] ] ]
```

Syntax Description

show	Show running system information
itd	ITD service
brief	(Optional) brief
<i>__readonly__</i>	(Optional) Read Only
<i>is_firstentry</i>	(Optional)
<i>is_detail</i>	(Optional)
<i>is_active</i>	(Optional)
<i>is_firstentry_routemap</i>	(Optional)
<i>is_firstentry_acl</i>	(Optional)
<i>is_lastentry</i>	(Optional)
<i>is_firstentry_standby</i>	(Optional)
<i>TABLE_summary</i>	(Optional)
<i>service_name</i>	(Optional) service_name
<i>probe</i>	(Optional) probe
<i>lb_scheme</i>	(Optional) lb scheme
<i>interface</i>	(Optional) interface
<i>state</i>	(Optional) state
<i>buckets</i>	(Optional) buckets

<i>reason</i>	(Optional) inactive reason
<i>vrf_name</i>	(Optional) VRF-Name
<i>userACL</i>	(Optional) user access-list
<i>excludeACL</i>	(Optional) exclude access-list
<i>peer_status</i>	(Optional) peer status
TABLE_device	(Optional)
<i>device_grp</i>	(Optional) service device group
<i>dg_probe</i>	(Optional) device-group probe type
<i>dg_probe_port</i>	(Optional) device-group probe port
TABLE_route_map	(Optional)
<i>route_map</i>	(Optional) service route map
<i>interface</i>	(Optional) interface
<i>r_status</i>	(Optional) route map status
<i>int_track_id</i>	(Optional) interface track id
TABLE_vip	(Optional)
<i>vip_ip</i>	(Optional) vip ip
<i>vip_probe</i>	(Optional) vip protocol
<i>vip_port</i>	(Optional) vip port
<i>vip_dgname</i>	(Optional) vip device group
TABLE_vip_node	(Optional)
<i>vip_node</i>	(Optional) service node ip
<i>vip_nodev6</i>	(Optional) service node IPv6
<i>vip_config</i>	(Optional) node config
<i>vip_weight</i>	(Optional) node weight
<i>vip_status</i>	(Optional) node status
<i>vip_node_probe</i>	(Optional) node probe type
<i>vip_node_probe_port</i>	(Optional) node probe port
<i>vip_node_probe_ip</i>	(Optional) node probe ip
<i>vip_track_id</i>	(Optional) node track id

<i>vip_ip_sla_id</i>	(Optional) node ip sla id
TABLE_vip_standby	(Optional)
<i>vip_standby_ip</i>	(Optional) standby node ip
<i>vip_standby_ipv6</i>	(Optional) standby node ipv6
<i>vip_standby_config</i>	(Optional) standby node config
<i>vip_standby_weight</i>	(Optional) standby node weight
<i>vip_standby_status</i>	(Optional) standby node status
<i>vip_standby_probe</i>	(Optional) standby node probe type
<i>vip_standby_probe_port</i>	(Optional) standby node probe port
<i>vip_standby_probe_ip</i>	(Optional) standby node probe ip
<i>vip_standby_track_id</i>	(Optional) standby node track id
<i>vip_standby_sla_id</i>	(Optional) standby node sla id
TABLE_vip_acl	(Optional)
<i>vip_access_list</i>	(Optional) access list
TABLE_node	(Optional)
<i>node</i>	(Optional) service node ip
<i>nodev6</i>	(Optional) service node IPv6
<i>config</i>	(Optional) node config
<i>weight</i>	(Optional) node weight
<i>status</i>	(Optional) node status
<i>node_probe</i>	(Optional) node probe type
<i>node_probe_port</i>	(Optional) node probe port
<i>node_probe_ip</i>	(Optional) node probe ip
<i>track_id</i>	(Optional) node track id
<i>ip_sla_id</i>	(Optional) node ip sla id
TABLE_standby	(Optional)
<i>standby_ip</i>	(Optional) standby node ip
<i>standby_ipv6</i>	(Optional) standby node ipv6
<i>standby_config</i>	(Optional) standby node config

<i>standby_weight</i>	(Optional) standby node weight
<i>standby_status</i>	(Optional) standby node status
<i>standby_probe</i>	(Optional) standby node probe type
<i>standby_probe_port</i>	(Optional) standby node probe port
<i>standby_probe_ip</i>	(Optional) standby node probe ip
<i>standby_track_id</i>	(Optional) standby node track id
<i>standby_sla_id</i>	(Optional) standby node sla id
TABLE_acl	(Optional)
<i>access_list</i>	(Optional) access list

Command Mode

- /exec

show itd session device-group

```
show itd session device-group [ <name> ] [ __readonly__ <first_entry> [ TABLE_svc <node> ] ]
```

Syntax Description

show	Show running system information
itd	ITD service
session	ITD service session
device-group	ITD service session device-group
<i>name</i>	(Optional) ITD Service session name
<i>__readonly__</i>	(Optional) Read Only
<i>first_entry</i>	(Optional)
TABLE_svc	(Optional)
<i>node</i>	(Optional) node

Command Mode

- /exec

show itd statistics

```
show itd { <service_name> | all } [ src { <src-ip> | <src-IPv6> } | dst { <dst-ip> | <dst-IPv6> } ] statistics [
brief ] [ __readonly__ <is_firstentry_node> <is_firstentry_acl> <is_for_ace> [ TABLE_nice <service_name>
[ <vip> ] [ <ace_seq> ] [ <ace_ip> ] [ <vip_pkt> ] <dev_grp> <node> <node_pkt> [ <acl> ] [ <acl_pkt> ]
<mode> <percentage> ] ]
```

Syntax Description

show	Show running system information
itd	ITD service
statistics	ITD statistics
brief	(Optional) brief
__readonly__	(Optional) Read Only
<i>is_firstentry_node</i>	(Optional)
<i>is_firstentry_acl</i>	(Optional)
<i>is_for_ace</i>	(Optional)
TABLE_nice	(Optional)
<i>service_name</i>	ITD service name
all	All ITD services
src	(Optional) Statistics for src ip
<i>src-ip</i>	(Optional) Provide statistics for src ip
dst	(Optional) Statistics for dst ip
<i>dst-ip</i>	(Optional) Provide statistics for dst ip
<i>vip</i>	(Optional) service virtual ip
<i>ace_seq</i>	(Optional) service ACE name and sequence number
<i>ace_ip</i>	(Optional) service ACE ip/mask/prefix
<i>vip_pkt</i>	(Optional) virtual ip pkt_count
<i>dev_grp</i>	(Optional) device group
<i>node</i>	(Optional) service node ip
<i>node_pkt</i>	(Optional) node pkt count
<i>acl</i>	(Optional) access list

<i>acl_pkt</i>	(Optional) acl pkt count
<i>mode</i>	(Optional) Redirect mode
<i>percentage</i>	(Optional) Packet percentage

Command Mode

- /exec

show itd vrf

```
show itd vrf [ <name> ] [ __readonly__ <first_entry> [ TABLE_svc <service_name> <vrf_name> <vrf_id> ] ]
```

Syntax Description

show	Show running system information
itd	ITD service
vrf	ITD service vrf
<i>name</i>	(Optional) ITD Service VRF name
<i>__readonly__</i>	(Optional) Read Only
<i>first_entry</i>	(Optional)
TABLE_svc	(Optional)
<i>service_name</i>	(Optional) itd service name
<i>vrf_name</i>	(Optional) vrf name
<i>vrf_id</i>	(Optional) vrf id

Command Mode

- /exec



K Show Commands

- [show key chain, on page 1458](#)
- [show key chain mode decrypt, on page 1459](#)
- [show keystore, on page 1460](#)
- [show kim inconsistency, on page 1461](#)
- [show kubernetes containers, on page 1462](#)

show key chain

```
{ show key chain [ <keychain> ] } [ __readonly__ TABLE_keychain <chain_name> { TABLE_key [ <key_id> ] [ <key_string> ] [ <crypto_algo> ] [ <accept_utc_zone> ] [ <accept_start> ] [ <accept_end> ] [ <accept_valid> ] [ <send_utc_zone> ] [ <send_start> ] [ <send_end> ] [ <send_valid> ] } }
```

Syntax Description

show	Show running system information
key	Display Key Information
chain	Display Keychain Information
<i>keychain</i>	(Optional) Keychain name
<i>__readonly__</i>	(Optional)
TABLE_keychain	(Optional)
TABLE_key	(Optional)
<i>chain_name</i>	(Optional)
<i>key_id</i>	(Optional)
<i>key_string</i>	(Optional)
<i>crypto_algo</i>	(Optional)
<i>accept_utc_zone</i>	(Optional)
<i>accept_start</i>	(Optional)
<i>accept_end</i>	(Optional)
<i>accept_valid</i>	(Optional)
<i>send_utc_zone</i>	(Optional)
<i>send_start</i>	(Optional)
<i>send_end</i>	(Optional)
<i>send_valid</i>	(Optional)

Command Mode

- /exec

show key chain mode decrypt

```
{ show key chain [ <keychain> ] mode decrypt } [ __readonly__ TABLE_keychain_decrypt <chain_name>
{ TABLE_key [ <key_id> ] [ <key_string> ] [ <crypto_algo> ] [ <accept_utc_zone> ] [ <accept_start> ] [
<accept_end> ] [ <accept_valid> ] [ <send_utc_zone> ] [ <send_start> ] [ <send_end> ] [ <send_valid> ] } }
```

Syntax Description

show	Show running system information
key	Display Key Information
chain	Display Keychain Information
<i>keychain</i>	(Optional) Keychain name
mode	Mode of display
decrypt	Display Decrypted Keystings
<i>__readonly__</i>	(Optional)
<i>TABLE_keychain_decrypt</i>	(Optional)
<i>TABLE_key</i>	(Optional)
<i>chain_name</i>	(Optional)
<i>key_id</i>	(Optional)
<i>key_string</i>	(Optional)
<i>crypto_algo</i>	(Optional)
<i>accept_utc_zone</i>	(Optional)
<i>accept_start</i>	(Optional)
<i>accept_end</i>	(Optional)
<i>accept_valid</i>	(Optional)
<i>send_utc_zone</i>	(Optional)
<i>send_start</i>	(Optional)
<i>send_end</i>	(Optional)
<i>send_valid</i>	(Optional)

Command Mode

- /exec

show keystore

```
show keystore [ __readonly__ { TABLE_sksd_state_entries <index> <handle> } <keystore_type>
<keystore_ver> <fw_panic> <fw_resets> <rx_fifo_underruns> <rx_timeouts> <rx_bad_checksums>
<rx_bad_fragment_lengths> <keystore_corruption> ]
```

Syntax Description

keystore	keystore stats
<i>__readonly__</i>	(Optional)
TABLE_sksd_state_entries	(Optional) Displays handles of the keys stored
<i>index</i>	(Optional) Index value
<i>handle</i>	(Optional) Handle Name
<i>keystore_type</i>	(Optional) Type of storage h/w or s/w
<i>keystore_ver</i>	(Optional) Version
<i>fw_panic</i>	(Optional) Number of panics
<i>fw_resets</i>	(Optional) Number of Resets
<i>rx_fifo_underruns</i>	(Optional) Rx FIFO Underruns
<i>rx_timeouts</i>	(Optional) Number of Rx timeouts
<i>rx_bad_checksums</i>	(Optional) Number of Bad Checsums
<i>rx_bad_fragment_lengths</i>	(Optional) Bad fragment lenghts received
<i>keystore_corruption</i>	(Optional) Number of corruptions detected

Command Mode

- /exec

show kim inconsistency

show kim inconsistency

Syntax Description

show	Show running system information
kim	Display KIM information
inconsistency	KIM inconsistency

Command Mode

- /exec

show kubernetes containers

show kubernetes containers [brief | interface <if_name>]

Syntax Description

show	Show running system information
kubernetes	Show kubernetes
containers	containers
brief	(Optional) Show brief information
interface	(Optional) Interface name
<i>if_name</i>	(Optional) Physical interface

Command Mode

- /exec



L Show Commands

- [show l2 mroute](#), on page 1469
- [show l2 multicast ftag](#), on page 1471
- [show l2 multicast trees](#), on page 1472
- [show l2 route](#), on page 1474
- [show l2fwder l2rib info](#), on page 1476
- [show l2fwder statistics](#), on page 1477
- [show l2rib clients](#), on page 1478
- [show l2rib producers](#), on page 1479
- [show l2rib registrations](#), on page 1481
- [show l2route evpn ead all](#), on page 1482
- [show l2route evpn ethernet-segment esi](#), on page 1483
- [show l2route evpn fl all](#), on page 1484
- [show l2route evpn fl evi](#), on page 1485
- [show l2route evpn imet all](#), on page 1486
- [show l2route evpn imet evi](#), on page 1487
- [show l2route evpn mac-ip all](#), on page 1488
- [show l2route evpn mac-ip evi](#), on page 1490
- [show l2route evpn mac all](#), on page 1492
- [show l2route evpn mac evi](#), on page 1494
- [show l2route evpn path-list all](#), on page 1496
- [show l2route evpn startup-route all](#), on page 1497
- [show l2route evpn startup-route evi](#), on page 1498
- [show l2route fl topology](#), on page 1499
- [show l2route peerid](#), on page 1500
- [show l2route summary](#), on page 1501
- [show l2route topology](#), on page 1502
- [show l2route topology](#), on page 1504
- [show l2route topology](#), on page 1506
- [show lacp counters](#), on page 1508
- [show lacp interface](#), on page 1509
- [show lacp issu-impact](#), on page 1512
- [show lacp neighbor](#), on page 1513
- [show lacp port-channel](#), on page 1514

- [show lacp system-identifier](#), on page 1515
- [show ldap-search-map](#), on page 1516
- [show ldap-server](#), on page 1517
- [show ldap-server groups](#), on page 1518
- [show ldap-server statistics](#), on page 1520
- [show license](#), on page 1522
- [show license brief](#), on page 1523
- [show license default](#), on page 1524
- [show license feature package mapping](#), on page 1525
- [show license file](#), on page 1526
- [show license host-id](#), on page 1527
- [show license tech support](#), on page 1528
- [show license usage](#), on page 1529
- [show line](#), on page 1530
- [show line console](#), on page 1531
- [show line console connected](#), on page 1532
- [show line console user-input-string](#), on page 1533
- [show lisp ddt](#), on page 1534
- [show lisp ddt queue](#), on page 1535
- [show lisp ddt referral-cache](#), on page 1536
- [show lisp dynamic-eid](#), on page 1537
- [show lisp elp](#), on page 1538
- [show lisp negative-prefix](#), on page 1539
- [show lisp proxy-itr](#), on page 1540
- [show lisp site](#), on page 1541
- [show lisp site instance-id](#), on page 1542
- [show lldp all](#), on page 1543
- [show lldp dcba interface](#), on page 1544
- [show lldp entry](#), on page 1546
- [show lldp interface](#), on page 1548
- [show lldp neighbors](#), on page 1550
- [show lldp neighbors detail](#), on page 1552
- [show lldp neighbors system-detail](#), on page 1554
- [show lldp portid-subtype](#), on page 1555
- [show lldp timers](#), on page 1556
- [show lldp tlv-select](#), on page 1557
- [show lldp traffic](#), on page 1558
- [show lldp traffic interface](#), on page 1559
- [show locator-led status](#), on page 1560
- [show logging](#), on page 1561
- [show logging console](#), on page 1562
- [show logging info](#), on page 1563
- [show logging ip access-list cache](#), on page 1565
- [show logging ip access-list status](#), on page 1567
- [show logging last](#), on page 1568
- [show logging level](#), on page 1569

- [show logging level](#), on page 1571
- [show logging level aaa](#), on page 1572
- [show logging level acllog](#), on page 1573
- [show logging level aclmgr](#), on page 1574
- [show logging level adbm](#), on page 1575
- [show logging level adjmgr](#), on page 1576
- [show logging level amt](#), on page 1577
- [show logging level arp](#), on page 1578
- [show logging level ascii-cfg](#), on page 1579
- [show logging level assoc_mgr](#), on page 1580
- [show logging level backup](#), on page 1581
- [show logging level bfd](#), on page 1582
- [show logging level bgp](#), on page 1583
- [show logging level bloggerd](#), on page 1584
- [show logging level bootvar](#), on page 1585
- [show logging level callhome](#), on page 1586
- [show logging level capability](#), on page 1587
- [show logging level catena](#), on page 1588
- [show logging level cdp](#), on page 1589
- [show logging level cert_enroll](#), on page 1590
- [show logging level cfs](#), on page 1591
- [show logging level clis](#), on page 1592
- [show logging level clk_mgr](#), on page 1593
- [show logging level confcheck](#), on page 1594
- [show logging level copp](#), on page 1595
- [show logging level core](#), on page 1596
- [show logging level cts](#), on page 1597
- [show logging level dhcp_snoop](#), on page 1598
- [show logging level diagnostic diagclient](#), on page 1599
- [show logging level diagnostic diagmgr](#), on page 1600
- [show logging level dot1x](#), on page 1601
- [show logging level ecp](#), on page 1602
- [show logging level eigrp](#), on page 1603
- [show logging level eltm](#), on page 1604
- [show logging level epp](#), on page 1605
- [show logging level ethdstats](#), on page 1606
- [show logging level ethpm](#), on page 1607
- [show logging level evb](#), on page 1608
- [show logging level evmc](#), on page 1609
- [show logging level evmed](#), on page 1610
- [show logging level evms](#), on page 1611
- [show logging level fabric forwarding](#), on page 1612
- [show logging level fcoe_mgr](#), on page 1613
- [show logging level feature-mgr](#), on page 1614
- [show logging level fs-daemon](#), on page 1615
- [show logging level gpixm](#), on page 1616

- [show logging level hardware-telemetry](#), on page 1617
- [show logging level hsrp](#), on page 1618
- [show logging level icam](#), on page 1619
- [show logging level im](#), on page 1620
- [show logging level imp](#), on page 1621
- [show logging level interface-vlan](#), on page 1622
- [show logging level ip igmp](#), on page 1623
- [show logging level ip msdp](#), on page 1624
- [show logging level ip sla responder](#), on page 1625
- [show logging level ip sla sender](#), on page 1626
- [show logging level ip sla twamp-server](#), on page 1627
- [show logging level ipconf](#), on page 1628
- [show logging level ipfib](#), on page 1629
- [show logging level ipqos](#), on page 1630
- [show logging level ipv6 icmp](#), on page 1631
- [show logging level iscm](#), on page 1632
- [show logging level iscm](#), on page 1633
- [show logging level isis](#), on page 1634
- [show logging level keystore](#), on page 1635
- [show logging level l2fm](#), on page 1636
- [show logging level l3vm](#), on page 1637
- [show logging level lacp](#), on page 1638
- [show logging level ldap](#), on page 1639
- [show logging level license](#), on page 1640
- [show logging level lim](#), on page 1641
- [show logging level lisp](#), on page 1642
- [show logging level lldp](#), on page 1643
- [show logging level m2rib](#), on page 1644
- [show logging level mfdm](#), on page 1645
- [show logging level mfwd](#), on page 1646
- [show logging level mmode](#), on page 1647
- [show logging level module](#), on page 1648
- [show logging level monitor](#), on page 1649
- [show logging level mvsh](#), on page 1650
- [show logging level nat](#), on page 1651
- [show logging level nbm](#), on page 1652
- [show logging level netstack](#), on page 1653
- [show logging level nfm](#), on page 1654
- [show logging level ngoam](#), on page 1655
- [show logging level npv](#), on page 1656
- [show logging level ntp](#), on page 1657
- [show logging level nxsdk](#), on page 1658
- [show logging level openflow](#), on page 1659
- [show logging level ospf](#), on page 1660
- [show logging level ospfv3](#), on page 1661
- [show logging level pfstat](#), on page 1662

- [show logging level pim, on page 1663](#)
- [show logging level pim, on page 1664](#)
- [show logging level pixm, on page 1665](#)
- [show logging level pktmgr, on page 1666](#)
- [show logging level platform, on page 1667](#)
- [show logging level plbm, on page 1668](#)
- [show logging level plcmgr, on page 1669](#)
- [show logging level pltfm_config, on page 1670](#)
- [show logging level plugin, on page 1671](#)
- [show logging level poap, on page 1672](#)
- [show logging level poed, on page 1673](#)
- [show logging level port-channel, on page 1674](#)
- [show logging level port-profile, on page 1675](#)
- [show logging level port-resources, on page 1676](#)
- [show logging level port-security, on page 1677](#)
- [show logging level port, on page 1678](#)
- [show logging level private-vlan, on page 1679](#)
- [show logging level ptp, on page 1680](#)
- [show logging level radius, on page 1681](#)
- [show logging level res_mgr, on page 1682](#)
- [show logging level rip, on page 1683](#)
- [show logging level routing ipv6 multicast, on page 1684](#)
- [show logging level routing multicast, on page 1685](#)
- [show logging level rpm, on page 1686](#)
- [show logging level rsvp, on page 1687](#)
- [show logging level sal, on page 1688](#)
- [show logging level san-port-channel, on page 1689](#)
- [show logging level san-port-channel, on page 1690](#)
- [show logging level scheduler, on page 1691](#)
- [show logging level security, on page 1692](#)
- [show logging level session-mgr, on page 1693](#)
- [show logging level sflow, on page 1694](#)
- [show logging level smartc, on page 1695](#)
- [show logging level smm, on page 1696](#)
- [show logging level snmpd, on page 1697](#)
- [show logging level snmpmib_proc, on page 1698](#)
- [show logging level spanning-tree, on page 1699](#)
- [show logging level spm, on page 1700](#)
- [show logging level stripcl, on page 1701](#)
- [show logging level sysmgr, on page 1702](#)
- [show logging level tacacs, on page 1703](#)
- [show logging level track, on page 1704](#)
- [show logging level tunnel, on page 1705](#)
- [show logging level u2rib, on page 1706](#)
- [show logging level u6rib, on page 1707](#)
- [show logging level udld, on page 1708](#)

- [show logging level ufdm, on page 1709](#)
- [show logging level urib, on page 1710](#)
- [show logging level vdc_mgr, on page 1711](#)
- [show logging level virtual-service, on page 1712](#)
- [show logging level vlan_mgr, on page 1713](#)
- [show logging level vmm, on page 1714](#)
- [show logging level vmtracker, on page 1715](#)
- [show logging level vpc, on page 1716](#)
- [show logging level vrrp-cfg, on page 1717](#)
- [show logging level vrrp-eng, on page 1718](#)
- [show logging level vrrpv3, on page 1719](#)
- [show logging level vsan, on page 1720](#)
- [show logging level vshd, on page 1721](#)
- [show logging level vtp, on page 1722](#)
- [show logging level wwn, on page 1723](#)
- [show logging level xbar, on page 1724](#)
- [show logging logfile, on page 1725](#)
- [show logging logfile duration, on page 1726](#)
- [show logging logfile last-index, on page 1727](#)
- [show logging logfile start-seqn, on page 1728](#)
- [show logging logfile start-time, on page 1729](#)
- [show logging loopback, on page 1730](#)
- [show logging module, on page 1731](#)
- [show logging monitor, on page 1732](#)
- [show logging nvram, on page 1733](#)
- [show logging onboard, on page 1734](#)
- [show logging onboard, on page 1735](#)
- [show logging onboard kernel-trace, on page 1738](#)
- [show logging origin-id, on page 1739](#)
- [show logging pending-diff, on page 1740](#)
- [show logging pending, on page 1741](#)
- [show logging rate-limit, on page 1742](#)
- [show logging server, on page 1743](#)
- [show logging session status, on page 1744](#)
- [show logging source-interface, on page 1745](#)
- [show logging status, on page 1746](#)
- [show logging timestamp, on page 1747](#)
- [show login on-failure log, on page 1748](#)
- [show login on-successful log, on page 1749](#)

show l2 mroute

```
show { l2 | fabricpath } mroute { [ vdc-omf ] { [ resolved ] } | [ vlan <vlanid> ] { { [ omf ] | [ flood ] | [ source
{ <srcaddr> | <v6srcaddr> | <macsrcaddr> } ] [ group { <groupaddr> | <v6groupaddr> | <macgroupaddr> }
] } [ resolved ] [ ftag <ftag-id> ] [ hex ] } } [ __readonly__ [ <hex2> ] { TABLE_gr [ <ftag> ] <vlan_id> [ {
<v4src> <v4grp> <macgrp> | <v6src> <v6grp> <macsrc> } ] [ <omf> | <flood> ] <rt-uptime> <owners>
<num_nh> TABLE_nh { <nh_if> | <nh_sw> } [ <stale> ] [ <exclude> ] [ <svi> ] <flags> <nh-uptime>
<owner> <rt_type> | <done> | <start> } ]
```

Syntax Description

show	Show running system information
l2	Layer2 information
fabricpath	fabricpath information
mroute	Show multicast route database
vdc-omf	(Optional) Display vdc omf route
vlan	(Optional) Show information for a vlan
omf	(Optional) Show catch-all entry consisting of mroute ports
flood	(Optional) Display vlan flood route
ftag	(Optional) Show ftag number
source	(Optional) Show (s, g) source IP address
group	(Optional) Show group address
hex	(Optional) Display switch-ids in hex
<i>vlanid</i>	(Optional) Vlan value
<i>ftag-id</i>	(Optional) ftag id
<i>groupaddr</i>	(Optional) Group address
<i>macgroupaddr</i>	(Optional) MAC Group address
<i>srcaddr</i>	(Optional) Source address
<i>macsrcaddr</i>	(Optional) MAC source address
resolved	(Optional) Resolve switchid nexthops into the underlying interfaces
__readonly__	(Optional) Read Only
<i>hex2</i>	(Optional)
TABLE_gr	(Optional)

<i>vlan_id</i>	(Optional) VLAN
<i>rt-uptime</i>	(Optional) Time route was created
<i>num_nh</i>	(Optional) Number of next-hops
<i>owners</i>	(Optional) Owners
<i>v4src</i>	(Optional) IPv4 Multicast traffic source
<i>v4grp</i>	(Optional) IPv4 Multicast Group address
<i>macsrc</i>	(Optional) MAC Multicast traffic source
<i>macgrp</i>	(Optional) MAC Multicast Group address
<i>ftag</i>	(Optional) ftag id
<i>omf</i>	(Optional) Is OMF route
<i>flood</i>	(Optional) Is flood to vlan route
TABLE_nh	(Optional)
<i>nh_if</i>	(Optional) The next hop interface
<i>nh_sw</i>	(Optional) The next hop switch id
<i>owner</i>	(Optional) Owner
<i>flags</i>	(Optional) flags
<i>nh-uptime</i>	(Optional) Time nexthop was created
<i>rt_type</i>	(Optional) Route type
<i>stale</i>	(Optional) Is stale
<i>exclude</i>	(Optional) exclude from post routing replication
<i>svi</i>	(Optional) SVI interface
<i>done</i>	(Optional) Done displaying route data
<i>start</i>	(Optional) Print header

Command Mode

- /exec

show l2 multicast ftag

```
show { l2 | fabricpath } multicast ftag [ <ftag-id> ] [ __readonly__ TABLE_topo <id> <topo_config>
TABLE_ftag <ftag> <topo_id> <config> ]
```

Syntax Description

show	Show running system information
l2	Layer2 information
fabricpath	fabricpath information
multicast	Multicast information
ftag	ftag number
<i>ftag-id</i>	(Optional) ftag id
<i>__readonly__</i>	(Optional) Read Only
TABLE_topo	(Optional)
<i>id</i>	(Optional) topo id
<i>topo_config</i>	(Optional) program ftag star route
TABLE_ftag	(Optional)
<i>ftag</i>	(Optional) ftag
<i>topo_id</i>	(Optional) topo id
<i>config</i>	(Optional) ftag config

Command Mode

- /exec

show l2 multicast trees

```
show { l2 | fabricpath } multicast trees [ topo <topo-id> ] [ ftag <ftag-id> ] [ hex ] [ __readonly__ [ <hex2> ] ] { TABLE_swid <ftag> <topo_id> <sw_id> <rt-uptime> <owners> <num_nh> TABLE_nh [ <preferred> ] { <nh_if> | <nh_sw> } [ <stale> ] <distance> <nh-uptime> <owner> <flags> <rt_type> | <start> | <done> } ]
```

Syntax Description

show	Show running system information
l2	Layer2 information
fabricpath	fabricpath information
multicast	Multicast information
trees	Show the broadcast/multicast tree database
topo	(Optional) Show topo instance
ftag	(Optional) Show ftag number
hex	(Optional) Display switch-ids in hex
<i>topo-id</i>	(Optional) topo id
<i>ftag-id</i>	(Optional) ftag id
<i>__readonly__</i>	(Optional) Read Only
<i>hex2</i>	(Optional)
TABLE_swid	(Optional)
<i>sw_id</i>	(Optional) switch id
<i>topo_id</i>	(Optional) topo id
<i>ftag</i>	(Optional) ftag id
<i>rt-uptime</i>	(Optional) Time route was created
<i>num_nh</i>	(Optional) Number of next-hops
<i>owners</i>	(Optional) Owners
TABLE_nh	(Optional)
<i>preferred</i>	(Optional) Is preferred interface
<i>nh_if</i>	(Optional) The next hop interface
<i>nh_sw</i>	(Optional) The next hop switch id

<i>owner</i>	(Optional) Owner
<i>flags</i>	(Optional) flags
<i>rt_type</i>	(Optional) Route type
<i>nh-uptime</i>	(Optional) Time nexthop was created
<i>distance</i>	(Optional) admin distance
<i>stale</i>	(Optional) Is stale
<i>start</i>	(Optional)
<i>done</i>	(Optional)

Command Mode

- /exec

show l2 route

```
show { l2 | fabricpath } route [ topology { <topo_val> [ switchid <switchid> ] | all } | switchid <switchid> ]
[ detail | hex ] + [ __readonly__ <line_marker> <is_hex> { TABLE_route <topo_id> <ftag_value> <swid>
<sswid> <num_paths> { TABLE_path <path_str> <admin_distance> <metric> <time> <time_detail> <uuid>
} } ]
```

Syntax Description

show	Show running system information
l2	Layer2 information
fabricpath	fabricpath information
route	Show FabricPath route information
topology	(Optional) topology
<i>topo_val</i>	(Optional) topology value
switchid	(Optional) switchid
<i>switchid</i>	(Optional) switchid value
all	(Optional) all topologies
detail	(Optional) detail
hex	(Optional) display in hex
__readonly__	(Optional) Read Only
<i>line_marker</i>	(Optional) line marker
<i>is_hex</i>	(Optional) print in hex
TABLE_route	(Optional) Route delimiter
<i>topo_id</i>	(Optional) topo-id value
<i>ftag_value</i>	(Optional) ftag value
<i>swid</i>	(Optional) switch-id
<i>sswid</i>	(Optional) sub-switch id
<i>num_paths</i>	(Optional) num of paths
TABLE_path	(Optional) Path delimiter
<i>path_str</i>	(Optional) paths
<i>admin_distance</i>	(Optional) admin distance

<i>metric</i>	(Optional) metric
<i>time</i>	(Optional) time
<i>time_detail</i>	(Optional) time_detail
<i>uuid</i>	(Optional) uuid

Command Mode

- /exec

show l2fwder l2rib info

show l2fwder l2rib info

Syntax Description

show	Show running system information
l2fwder	L2 software forwarding
l2rib	L2RIB
info	stats and info

Command Mode

- /exec

show l2fwder statistics

show l2fwder statistics

Syntax Description

show	Show running system information
l2fwder	Display L2FWDER forwarding information
statistics	Show L2FWDER packet counters

Command Mode

- /exec

show l2rib clients

```
show l2rib clients [ <client_id> ] [ __readonly__ TABLE_l2rib_clients <client-id> <uuid> <process-suffix> ]
```

Syntax Description

show	Show running system information
l2rib	Layer 2 routing information base
clients	L2RIB Clients
<i>client_id</i>	(Optional) Enter Client ID
<i>__readonly__</i>	(Optional)
TABLE_l2rib_clients	(Optional) L2RIB Clients Table
<i>client-id</i>	(Optional) Client ID
<i>uuid</i>	(Optional) Process ID
<i>process-suffix</i>	(Optional) Process Name Suffix

Command Mode

- /exec

show l2rib producers

```
show l2rib producers [ { topology | mac | mac-ip | ead | pl | imet | flood-list | startup-route | peerid | es } [ static
| local | bgp | vxlan | hmm | arp | ofa | lisp ] ] [ detail ] [ __readonly__ TABLE_l2rib_producers <prod-name>
<prod-id> <client-id> <obj-type> <admin-dist> <purge-time> <state> [ <prod-flags> ] ]
```

Syntax Description

show	Show running system information
l2rib	Layer 2 routing information base
producers	L2RIB Producers
detail	(Optional) Detailed information
topology	(Optional) Filter on Topology
mac	(Optional) Filter on MAC
mac-ip	(Optional) Filter on MAC-IP
ead	(Optional) Filter on Ethernet-AD
pl	(Optional) Filter on Path List
imet	(Optional) Filter on IMET Route
flood-list	(Optional) Filter on Flood List
startup-route	(Optional) Filter on Startup Route
peerid	(Optional) Filter on Peerid
es	(Optional) Filter on ES
static	(Optional) Static
local	(Optional) Local
bgp	(Optional) BGP
vxlan	(Optional) VXLAN
hmm	(Optional) HMM
arp	(Optional) ARP
ofa	(Optional) OFA
lisp	(Optional) lisp
__readonly__	(Optional)
TABLE_l2rib_producers	(Optional) L2RIB Producers Table

<i>prod-name</i>	(Optional) Producer Name
<i>prod-id</i>	(Optional) Producer ID
<i>client-id</i>	(Optional) Client ID
<i>obj-type</i>	(Optional) Object Type
<i>admin-dist</i>	(Optional) Admin Distance
<i>purge-time</i>	(Optional) Purge Time
<i>state</i>	(Optional) State
<i>prod-flags</i>	(Optional) Global Producer Flags

Command Mode

- /exec

show l2rib registrations

```
show l2rib registrations [ client <client_id> [ <topo_id> { mac | mac-ip | ead | pl | imet | flood-list | arp-signal
| startup-route | topo | es } ] ] [ __readonly__ TABLE_l2rib_registrations <client-id> <topo-id> <obj-type>
<prod> ]
```

Syntax Description

show	Show running system information
l2rib	Layer 2 routing information base
registrations	L2RIB Registrations
client	(Optional) Global Registraion Entries
<i>client_id</i>	(Optional) Enter Client ID
<i>topo_id</i>	(Optional) Enter Topology ID
mac	(Optional) Filter on MAC
mac-ip	(Optional) Filter on MAC-IP
ead	(Optional) Filter on Ethernet-AD
pl	(Optional) Filter on Path List
imet	(Optional) Filter on IMET Route
es	(Optional) Filter on Ethernet Segment ID
flood-list	(Optional) Filter on Flood List
startup-route	(Optional) Filter on Startup Route
arp-signal	(Optional) Filter on ARP Signal
topo	(Optional) Filter on Topo Subtype
__readonly__	(Optional)
TABLE_l2rib_registrations	(Optional) L2RIB Registrations Table
<i>client-id</i>	(Optional) Client ID
<i>topo-id</i>	(Optional) Topology ID
<i>obj-type</i>	(Optional) Object Type
<i>prod</i>	(Optional) Producer

Command Mode

- /exec

show l2route evpn ead all

```
show l2route evpn ead all [ detail ] [ __readonly__ TABLE_l2route_evpn_ead_all <topo-id> <prod> <esi>
<client-nfn> <num_pls> [ { <next-hop> } ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
ead	EAD
all	Display all routes without filtering
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_evpn_ead_all	(Optional) L2RIB EVPN EAD All Table
<i>topo-id</i>	(Optional) Topology ID
<i>prod</i>	(Optional) Producer
<i>esi</i>	(Optional) ESI
<i>client-nfn</i>	(Optional) Client Notification Bitmap
<i>num_pls</i>	(Optional) Number of Path lists
<i>next-hop</i>	(Optional) Next Hop

Command Mode

- /exec

show l2route evpn ethernet-segment esi

```
show l2route evpn ethernet-segment { esi <esi-id> | all } [ bgp | vxlan ] [ detail ] [ __readonly__
TABLE_l2route_es <ethernet-segment> <originating-rtr> <prod-name> <int-ifhdl> <client-nfn> ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
ethernet-segment	Ethernet Segment ID
esi	ESI Value
<i>esi-id</i>	ESI ID
all	Display all entries without filtering
bgp	(Optional) Filter on BGP producer
vxlan	(Optional) Filter on VXLAN producer
detail	(Optional) Detailed information
<i>__readonly__</i>	(Optional)
TABLE_l2route_es	(Optional) L2RIB ES Table
<i>ethernet-segment</i>	(Optional) ESI
<i>originating-rtr</i>	(Optional) Originating Router
<i>prod-name</i>	(Optional) Producer Name
<i>int-ifhdl</i>	(Optional) Interface Handle
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route evpn fl all

```
show l2route evpn fl all [ detail ] [ __readonly__ TABLE_l2route_fl_all <topo-id> <peer-id> <flood-list>
<is-service-node> [ <client-nfn> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
fl	Flood List
all	Display all routes without filtering
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_fl_all	(Optional) L2RIB Flood List All Table
<i>topo-id</i>	(Optional) Topology ID
<i>peer-id</i>	(Optional) Peer-ID
<i>flood-list</i>	(Optional) Flood List
<i>is-service-node</i>	(Optional) Is Service Node
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route evpn fl evi

```
show l2route evpn fl evi <vpn-id> [ detail ] [ __readonly__ TABLE_l2route_fl <peer-id> <flood-list>
<is-service-node> [ <client-nfn> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
fl	Flood List
evi	Filter on E-VPN identifier (VLAN-ID or BD-ID)
<i>vpn-id</i>	E-VPN identifier (VLAN-ID or BD-ID)
detail	(Optional) Detailed information
<i>__readonly__</i>	(Optional)
TABLE_l2route_fl	(Optional) L2RIB Flood List Table
<i>peer-id</i>	(Optional) Peer-ID
<i>flood-list</i>	(Optional) Flood List
<i>is-service-node</i>	(Optional) Is Service Node
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route evpn imet all

```
show l2route evpn imet all [ detail ] [ __readonly__ TABLE_l2route_imet_all <topo-id> <vni> <prod-type>
<ip-addr> [ <eth-tag-id> ] [ <pmsi-flags> ] [ <flags> ] [ <type> ] [ <vni-label> ] [ <tunnel-id> ] [ <client-nfn>
]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
imet	IMET Route
all	Display all routes without filtering
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_imet_all	(Optional) L2RIB IMET All Table
<i>topo-id</i>	(Optional) Topology ID
<i>vni</i>	(Optional) VNI
<i>prod-type</i>	(Optional) Producer Type
<i>ip-addr</i>	(Optional) IP Address
<i>eth-tag-id</i>	(Optional) Ethernet Tag ID
<i>pmsi-flags</i>	(Optional) PMSI Flags
<i>flags</i>	(Optional) Flags
<i>type</i>	(Optional) Type
<i>vni-label</i>	(Optional) VNI Label
<i>tunnel-id</i>	(Optional) Tunnel ID
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route evpn imet evi

```
show l2route evpn imet evi <vpn-id> [ bgp | vxlan ] [ detail ] [ __readonly__ TABLE_l2route_imet <vni>
<prod-type> <ip-addr> [ <eth-tag-id> ] [ <pmsi-flags> ] [ <flags> ] [ <type> ] [ <vni-label> ] [ <tunnel-id>
] [ <client-nfn> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
imet	IMET Route
evi	Filter on E-VPN identifier (VLAN-ID or BD-ID)
<i>vpn-id</i>	E-VPN identifier (VLAN-ID or BD-ID)
bgp	(Optional) Filter on BGP producer (remote imet routes)
vxlan	(Optional) Filter on VXLAN producer (local imet routes)
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_imet	(Optional) L2RIB IMET Table
<i>vni</i>	(Optional) VNI
<i>prod-type</i>	(Optional) Producer Type
<i>ip-addr</i>	(Optional) IP Address
<i>eth-tag-id</i>	(Optional) Ethernet Tag ID
<i>pmsi-flags</i>	(Optional) PMSI Flags
<i>flags</i>	(Optional) Flags
<i>type</i>	(Optional) Type
<i>vni-label</i>	(Optional) VNI Label
<i>tunnel-id</i>	(Optional) Tunnel ID
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route evpn mac-ip all

```
show l2route evpn mac-ip all [ detail ] [ __readonly__ TABLE_l2route_mac_ip_all <topo-id> <mac-addr>
<host-ip> <prod-type> <flags> <seq-num> <next-hop1> [ <next-hop2> ] [ <l3-info> ] [ <fwd-state> ] [
<rte-res> ] [ <sent-to> ] [ <peerid> ] [ <peer-ifindex> ] [ <esi-id> ] [ <soo> ] [ <pcinfo> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
mac-ip	MAC-IP Route
all	Display all routes without filtering
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_mac_ip_all	(Optional) L2RIB Mac-IP All Table
<i>topo-id</i>	(Optional) Topology ID
<i>mac-addr</i>	(Optional) Mac Address
<i>host-ip</i>	(Optional) Host IP
<i>prod-type</i>	(Optional) Producer Type
<i>flags</i>	(Optional) Flags
<i>seq-num</i>	(Optional) Sequence Number
<i>next-hop1</i>	(Optional) Next Hop 1
<i>next-hop2</i>	(Optional) Next Hop 2
<i>l3-info</i>	(Optional) L3 Information
<i>fwd-state</i>	(Optional) Forwarding State
<i>rte-res</i>	(Optional) Route Resolution
<i>sent-to</i>	(Optional) Active Clients
<i>peerid</i>	(Optional) Peer ID
<i>peer-ifindex</i>	(Optional) Peer Interface Index
<i>esi-id</i>	(Optional) ESI ID
<i>soo</i>	(Optional) SOO

<i>pcinfo</i>	(Optional) Port-Channel Info
---------------	------------------------------

Command Mode

- /exec

show l2route evpn mac-ip evi

```
show l2route evpn mac-ip evi <vpn-id> [ arp | bgp | hmm ] [ mac <mac_addr> ] [ host-ip { <ipv4_host> | <ipv6_host> } ] [ next-hop { <ipv4_addr> | <ipv6_addr> | <if-hdl> } ] [ detail ] [ __readonly__
TABLE_l2route_mac_ip_evi <topo-id> <mac-addr> <prod-type> <seq-num> <host-ip> <next-hop1> [
<next-hop2> ] [ <l3-info> ] [ <fwd-state> ] [ <rte-res> ] [ <sent-to> ] [ <peerid> ] [ <peer-ifindex> ] [ <esi-id>
] [ <soo> ] [ <pcinfo> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
mac-ip	MAC-IP Route
evi	Filter on E-VPN identifier (VLAN-ID or BD-ID)
<i>vpn-id</i>	E-VPN identifier (VLAN-ID or BD-ID)
arp	(Optional) Filter on ARP producer
bgp	(Optional) Filter on BGP producer
hmm	(Optional) Filter on HMM producer
mac	(Optional) Filter on MAC address
<i>mac_addr</i>	(Optional) 48-bit MAC address value
host-ip	(Optional) Filter on Host IP address
<i>ipv4_host</i>	(Optional) IPv4 address
next-hop	(Optional) Filter on Next-Hop IP or Interface Name
<i>ipv4_addr</i>	(Optional) IPv4 address of Next Hop
<i>if-hdl</i>	(Optional) Interface index of Next Hop
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_mac_ip_evi	(Optional) L2RIB Mac-IP Table
<i>topo-id</i>	(Optional) Topology ID
<i>mac-addr</i>	(Optional) Mac Address
<i>prod-type</i>	(Optional) Producer Type
<i>host-ip</i>	(Optional) Host IP

<i>seq-num</i>	(Optional) Sequence Number
<i>next-hop1</i>	(Optional) Next Hop 1
<i>next-hop2</i>	(Optional) Next Hop 2
<i>fwd-state</i>	(Optional) Forwarding State
<i>rte-res</i>	(Optional) Route Resolution
<i>sent-to</i>	(Optional) Active Clients
<i>esi-id</i>	(Optional) ESI ID
<i>soo</i>	(Optional) SOO
<i>pcinfo</i>	(Optional) Port-Channel Info
<i>l3-info</i>	(Optional) L3 Information
<i>peerid</i>	(Optional) Peer ID
<i>peer-ifindex</i>	(Optional) Peer Interface Index

Command Mode

- /exec

show l2route evpn mac all

```
show l2route evpn mac all [ detail ] [ __readonly__ TABLE_l2route_mac_all <topo-id> <mac-addr>
<prod-type> <flags> <seq-num> <next-hop1> [ <next-hop2> ] [ <rte-res> ] [ <fwd-state> ] [ <res-pl-next-hop1>
] [ <res-pl-next-hop2> ] [ <sent-to> ] [ <esi-id> ] [ <soo> ] [ <pcinfo> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
mac	MAC Route
all	Display all routes without filtering
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_mac_all	(Optional) L2RIB Mac All Table
<i>topo-id</i>	(Optional) Topology ID
<i>mac-addr</i>	(Optional) Mac Address
<i>prod-type</i>	(Optional) Producer Type
<i>flags</i>	(Optional) Flags
<i>seq-num</i>	(Optional) Sequence Number
<i>fwd-state</i>	(Optional) Forwarding State
<i>res-pl-next-hop1</i>	(Optional) Resultant PL Next hop 1
<i>res-pl-next-hop2</i>	(Optional) Resultant PL Next hop 2
<i>rte-res</i>	(Optional) Route Resolution
<i>sent-to</i>	(Optional) Active Clients
<i>esi-id</i>	(Optional) ESI ID
<i>soo</i>	(Optional) SOO
<i>pcinfo</i>	(Optional) Port-Channel Info
<i>next-hop1</i>	(Optional) Next Hop 1
<i>next-hop2</i>	(Optional) Next Hop 2

Command Mode

- /exec

show l2route evpn mac evi

```
show l2route evpn mac evi <vpn-id> [ static | local | bgp | vxlan | lisp ] [ mac <mac_addr> ] [ next-hop {
<ipv4_addr> | <ipv6_addr> | <if-hdl> } ] [ esi <esi-id> ] [ detail ] [ __readonly__ TABLE_l2route_mac_evi
<topo-id> <mac-addr> <prod-type> <flags> <seq-num> <next-hop1> [ <next-hop2> ] [ <rte-res> ] [ <fwd-state>
] [ <res-pl-next-hop1> ] [ <res-pl-next-hop2> ] [ <sent-to> ] [ <esi-id> ] [ <soo> ] [ <pcinfo> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
mac	MAC Route
evi	Filter on E-VPN identifier (VLAN-ID or BD-ID)
<i>vpn-id</i>	E-VPN identifier (VLAN-ID or BD-ID)
static	(Optional) Filter on Static producer
local	(Optional) Filter on Local producer
bgp	(Optional) Filter on BGP producer
vxlan	(Optional) Filter on VXLAN producer
lisp	(Optional) Filter on LISP producer
mac	(Optional) Filter on MAC address
esi	(Optional) Filter on ESI value
<i>mac_addr</i>	(Optional) Enter 48-bit MAC address value
next-hop	(Optional) Filter on Next-Hop IP or Interface Name
<i>ipv4_addr</i>	(Optional) IPv4 address of Next Hop
<i>if-hdl</i>	(Optional) Interface index of Next Hop
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_mac_evi	(Optional) L2RIB Mac EVI Table
<i>topo-id</i>	(Optional) Topology ID
<i>mac-addr</i>	(Optional) Mac Address
<i>prod-type</i>	(Optional) Producer Type

<i>flags</i>	(Optional) Flags
<i>seq-num</i>	(Optional) Sequence Number
<i>next-hop1</i>	(Optional) Next Hop 1
<i>next-hop2</i>	(Optional) Next Hop 2
<i>fwd-state</i>	(Optional) Forwarding State
<i>res-pl-next-hop1</i>	(Optional) Resultant PL Next hop 1
<i>res-pl-next-hop2</i>	(Optional) Resultant PL Next hop 2
<i>rte-res</i>	(Optional) Route Resolution
<i>sent-to</i>	(Optional) Active Clients
<i>esi-id</i>	(Optional) ESI ID
<i>soo</i>	(Optional) SOO
<i>pcinfo</i>	(Optional) Port-Channel Info

Command Mode

- /exec

show l2route evpn path-list all

```
show l2route evpn path-list { all | esi <esi-id> } [ detail ] [ __readonly__ TABLE_l2route_evpn_pathlist_all
<topo-id> <prod> <esi> [ <ecmp_label> ] [ <flags> ] [ <client_ctx> ] <mac-cnt> <client-nfn> [ { <cp-next-hop>
} ] [ { <res-next-hop> } ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
path-list	Path-List
all	Display all routes without filtering
esi	ESI Value
<i>esi-id</i>	ESI ID
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_evpn_pathlist_all	(Optional) L2RIB EVPN Pathlist all Table
<i>topo-id</i>	(Optional) Topology ID
<i>prod</i>	(Optional) Producer
<i>esi</i>	(Optional) ESI
<i>ecmp_label</i>	(Optional) ECMP label
<i>flags</i>	(Optional) Flags
<i>client_ctx</i>	(Optional) Client context
<i>mac-cnt</i>	(Optional) Mac count
<i>client-nfn</i>	(Optional) Client Notification Bitmap
<i>cp-next-hop</i>	(Optional) Control plane Next hops
<i>res-next-hop</i>	(Optional) Resultant Next hops

Command Mode

- /exec

show l2route evpn startup-route all

```
show l2route evpn startup-route all [ detail ] [ __readonly__ TABLE_l2route_startup_route_all <topo-id>
<src-group> <del-src-group> [ <src-lpbk-ifhdl> ] [ <nve-ifhdl> ] [ <flags> ] [ <client-nfn> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
startup-route	Startup Route
all	Display all routes without filtering
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_startup_route_all	(Optional) L2RIB Startup-Route All Table
<i>topo-id</i>	(Optional) Topology ID
<i>src-group</i>	(Optional) Source Group
<i>del-src-group</i>	(Optional) Delivery Source Group
<i>src-lpbk-ifhdl</i>	(Optional) Source Loopback Interface Handle
<i>nve-ifhdl</i>	(Optional) NVE Interface Handle
<i>flags</i>	(Optional) Flags
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route evpn startup-route evi

```
show l2route evpn startup-route evi <vpn-id> [ detail ] [ __readonly__ TABLE_l2route_startup_route
<src-group> <del-src-group> [ <src-lpbk-ifhdl> ] [ <nve-ifhdl> ] [ <flags> ] [ <client-nfn> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
evpn	EVPN
startup-route	Startup Route
evi	Filter on E-VPN identifier (VLAN-ID or BD-ID)
<i>vpn-id</i>	E-VPN identifier (VLAN-ID or BD-ID)
detail	(Optional) Detailed information
<i>__readonly__</i>	(Optional)
TABLE_l2route_startup_route	(Optional) L2RIB Startup-Route Table
<i>src-group</i>	(Optional) Source Group
<i>del-src-group</i>	(Optional) Delivery Source Group
<i>src-lpbk-ifhdl</i>	(Optional) Source Loopback Interface Handle
<i>nve-ifhdl</i>	(Optional) NVE Interface Handle
<i>flags</i>	(Optional) Flags
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route fl topology

```
show l2route fl { topology <topo-id> | all } [ detail ] [ __readonly__ TABLE_l2route_fl [ <topo-id> ] <peer-id>
<flood-list> <is-service-node> [ <client-nfn> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
fl	Flood List
all	Display all routes without filtering
topology	Filter on topology ID
<i>topo-id</i>	topology ID
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_fl	(Optional) L2RIB Flood List Table
<i>topo-id</i>	(Optional) Topology ID
<i>peer-id</i>	(Optional) Peer-ID
<i>flood-list</i>	(Optional) Flood List
<i>is-service-node</i>	(Optional) Is Service Node
<i>client-nfn</i>	(Optional) Client Notification Bitmap

Command Mode

- /exec

show l2route peerid

```
show l2route peerid [ __readonly__ TABLE_l2route_peerid <if-hdl> <ip-addr> <peer-id> <if-idx> <num-macs>
<num-nhs> ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
peerid	Display Peer ID DB
__readonly__	(Optional)
TABLE_l2route_peerid	(Optional) L2RIB Peer-ID Table
<i>if-hdl</i>	(Optional) Interface Handle
<i>ip-addr</i>	(Optional) IP Address
<i>if-idx</i>	(Optional) Peer Interface Index
<i>peer-id</i>	(Optional) Peer-ID
<i>num-macs</i>	(Optional) Number of Macs
<i>num-nhs</i>	(Optional) Number of NHs

Command Mode

- /exec

show l2route summary

```
show l2route summary [ __readonly__ { <total_memory> <numof_converged_tables> [ {
TABLE_l2route_summary <table_name> { TABLE_producer <producer_name> <id> <objects> <memory>
} <total><total_obj><total_mem> } ] } ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
summary	Summary
<i>__readonly__</i>	(Optional) Read only
<i>total_memory</i>	(Optional) Total memory
<i>numof_converged_tables</i>	(Optional) Number of converged tables
TABLE_l2route_summary	(Optional) L2route summary table
<i>table_name</i>	(Optional) Table name
TABLE_producer	(Optional) Producer table
<i>producer_name</i>	(Optional) Producer name
<i>id</i>	(Optional) id
<i>objects</i>	(Optional) objects
<i>memory</i>	(Optional) Memory

Command Mode

- /exec

show l2route topology

```
show l2route topology [ <topo_id> ] [ detail ] [ __readonly__ TABLE_l2route_topology <topo-id> <topo-name>
<topo-type> [ <vni> ] [ <encap-type> ] [ <iod> ] [ <if-hdl> ] [ <vtep-ip> ] [ <emulated-ip> ] [ <emulated-ro-ip>
] [ <tx-id> ] [ <rcvd-flag> ] [ <rmac> ] [ <vrf-id> ] [ <vmac> ] [ <vmac-ro> ] [ <flags> ] [ <sub-flags> ] [
<prev-flags> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
topology	Display topology IDs
<i>topo_id</i>	(Optional) Enter Topology ID
detail	(Optional) Detailed information
<i>__readonly__</i>	(Optional)
TABLE_l2route_topology	(Optional) L2RIB Topology Table
<i>topo-id</i>	(Optional) Topology ID
<i>topo-name</i>	(Optional) Topology Name
<i>topo-type</i>	(Optional) Topology Type
<i>vni</i>	(Optional) VNI
<i>encap-type</i>	(Optional) Encap Type
<i>iod</i>	(Optional) IOD
<i>if-hdl</i>	(Optional) Interface Handle
<i>vtep-ip</i>	(Optional) VTEP IP Address
<i>emulated-ip</i>	(Optional) Emulated VTEP IP Address
<i>emulated-ro-ip</i>	(Optional) Emulated RO VTEP IP Address
<i>tx-id</i>	(Optional) Transaction ID for Topology Ack
<i>rcvd-flag</i>	(Optional) Flag to Indicate Topology Ack
<i>rmac</i>	(Optional) Local Router MAC (For L3 VNIs)
<i>vrf-id</i>	(Optional) VRF ID (For L3 VNIs)
<i>vmac</i>	(Optional) Local Virtual MAC (For L3 VNIs)
<i>vmac-ro</i>	(Optional) Local Virtual MAC Re-Orig(For Multi-site)

<i>flags</i>	(Optional) Flags
<i>sub-flags</i>	(Optional) Sub Flags
<i>prev-flags</i>	(Optional) Previous Flags

Command Mode

- /exec

show l2route topology

```
show l2route { mac | openflow mac | dataplane mac [ local | remote ] } { topology <topo-id> | all } [ detail ]
[ __readonly__ TABLE_l2route_mac <topo-id> <mac-addr> <prod-type> <flags> <seq-num> <next-hop1>
[ <next-hop2> ] [ <rte-res> ] [ <fwd-state> ] [ <res-pl-next-hop1> ] [ <res-pl-next-hop2> ] [ <sent-to> ] [
<esi-id> ] [ <soo> ] [ <pcinfo> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
dataplane	dataplane
openflow	openflow
mac	MAC Route
all	Display all routes without filtering
local	(Optional) dataplane learnt local routes
remote	(Optional) dataplane learnt remote routes
topology	Filter on topology ID
<i>topo-id</i>	topology ID
detail	(Optional) Detailed information
<i>__readonly__</i>	(Optional)
<i>TABLE_l2route_mac</i>	(Optional) L2RIB Mac All Table
<i>topo-id</i>	(Optional) Topology ID
<i>mac-addr</i>	(Optional) Mac Address
<i>prod-type</i>	(Optional) Producer Type
<i>flags</i>	(Optional) Flags
<i>seq-num</i>	(Optional) Sequence Number
<i>next-hop1</i>	(Optional) Next Hop 1
<i>next-hop2</i>	(Optional) Next Hop 2
<i>fwd-state</i>	(Optional) Forwarding State
<i>res-pl-next-hop1</i>	(Optional) Resultant PL Next hop1
<i>res-pl-next-hop2</i>	(Optional) Resultant PL Next hop2

<i>rte-res</i>	(Optional) Route Resolution
<i>sent-to</i>	(Optional) Active Clients
<i>esi-id</i>	(Optional) ESI ID
<i>soo</i>	(Optional) SOO
<i>pcinfo</i>	(Optional) Port-Channel Info

Command Mode

- /exec

show l2route topology

```
show l2route { mac-ip | openflow mac-ip } { topology <topo-id> | all } [ detail ] [ __readonly__
TABLE_l2route_mac_ip_openflow <topo-id> <mac-addr> <prod-type> <seq-num> <host-ip> <next-hop1>
[ <next-hop2> ] [ <l3-info> ] [ <fwd-state> ] [ <rte-res> ] [ <sent-to> ] [ <peerid> ] [ <peer-ifindex> ] [ <esi-id>
] [ <soo> ] [ <pcinfo> ] ]
```

Syntax Description

show	Show running system information
l2route	Layer 2 routing information base
mac-ip	MAC-IP Route
all	Display all routes without filtering
openflow	openflow
topology	Filter on topology ID
<i>topo-id</i>	topology ID
detail	(Optional) Detailed information
__readonly__	(Optional)
TABLE_l2route_mac_ip_openflow	(Optional) L2RIB Mac-IP Table
<i>topo-id</i>	(Optional) Topology ID
<i>mac-addr</i>	(Optional) Mac Address
<i>prod-type</i>	(Optional) Producer Type
<i>host-ip</i>	(Optional) Host IP
<i>next-hop1</i>	(Optional) Next Hop 1
<i>next-hop2</i>	(Optional) Next Hop 2
<i>seq-num</i>	(Optional) Sequence Number
<i>fwd-state</i>	(Optional) Forwarding State
<i>rte-res</i>	(Optional) Route Resolution
<i>sent-to</i>	(Optional) Active Clients
<i>esi-id</i>	(Optional) ESI ID
<i>soo</i>	(Optional) SOO
<i>pcinfo</i>	(Optional) Port-Channel Info

<i>l3-info</i>	(Optional) L3 Information
<i>peerid</i>	(Optional) Peer ID
<i>peer-ifindex</i>	(Optional) Peer Interface Index

Command Mode

- /exec

show lacp counters

```
show lacp counters [ interface <if0> ] [ __readonly__ TABLE_interface <interface> TABLE_member <port>
<pdus-sent> <pdus-rcvd> <marker-rcvd> <marker-resp-sent> <pkt-errors> [ <illegal-rcvd> ] [ <unknown-rcvd>
]
```

Syntax Description

show	Show running system information
lacp	LACP protocol
counters	LACP counters
interface	(Optional) Specify a port-channel
<i>if0</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_interface	(Optional) Port channel table
<i>interface</i>	(Optional) Port channel
TABLE_member	(Optional) Member port info
<i>port</i>	(Optional) Member port
<i>pdus-sent</i>	(Optional) Number of PDUs sent
<i>pdus-rcvd</i>	(Optional) Number of PDUs received
<i>marker-rcvd</i>	(Optional) Number of Marker PDUs received
<i>marker-resp-sent</i>	(Optional) Number of Marker response PDUs sent
<i>pkt-errors</i>	(Optional) Number of packet errors
<i>illegal-rcvd</i>	(Optional) Number of illegal packets received
<i>unknown-rcvd</i>	(Optional) Number of unknown packets received

Command Mode

- /exec

show lacp interface

```
show lacp interface [ <if0> ] [ __readonly__ { TABLE_lacp_intf <interface> <operational-state>
<channel-group> <port-channel> <p dus-sent> <p dus-rcvd> <marker-sent> <marker-rcvd> <marker-resp-sent>
<marker-resp-rcvd> <unknown-rcvd> <illegal-rcvd> <lag-id> <active-time> { localport <local-interface>
<local-mac-address> <local-system-priority> <local-port-priority> <local-port-num> <local-op-key>
<local-activity> <local-timeout> <local-sync> <local-collecting> <local-distributing> <partner-info-timeout>
<local-admin-state> <local-oper-state> } { partnerport <partner-interface> <partner-mac-address>
<partner-system-priority> <partner-port-priority> <partner-port-num> <partner-op-key> <partner-activity>
<partner-timeout> <partner-sync> <partner-collecting> <partner-distributing> <partner-admin-state>
<partner-oper-state> } <agg-or-indiv> } ]
```

Syntax Description

show	Show running system information
lacp	LACP protocol
interface	Specify a interface
<i>if0</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_lacp_intf	(Optional) Table of LACP interfaces
<i>interface</i>	(Optional) Interface ID
<i>channel-group</i>	(Optional) Channel Group
<i>port-channel</i>	(Optional) Port Channel
<i>lag-id</i>	(Optional) LAG Id
<i>active-time</i>	(Optional) active-time
<i>operational-state</i>	(Optional) Operational State
<i>agg-or-indiv</i>	(Optional) Aggregate or individual port
<i>p dus-rcvd</i>	(Optional) PDUs received
<i>p dus-sent</i>	(Optional) PDUs sent
<i>marker-rcvd</i>	(Optional) Markers received
<i>marker-sent</i>	(Optional) Markers sent
<i>marker-resp-rcvd</i>	(Optional) Marker response received
<i>marker-resp-sent</i>	(Optional) Marker response sent
<i>unknown-rcvd</i>	(Optional) Unknown pdus received

<i>illegal-rcvd</i>	(Optional) Illegal pdus received
localport	(Optional) Local port information
<i>local-interface</i>	(Optional) Interface
<i>local-mac-address</i>	(Optional) MAC Address
<i>local-system-priority</i>	(Optional) System Priority
<i>local-port-priority</i>	(Optional) Port Priority
<i>local-port-num</i>	(Optional) Port Number
<i>local-op-key</i>	(Optional) Operational Key
<i>local-admin-state</i>	(Optional) Local Admin State
<i>local-oper-state</i>	(Optional) Local Oper State
<i>local-activity</i>	(Optional) Mode
<i>local-timeout</i>	(Optional) Timeout
<i>local-sync</i>	(Optional) Synchronization
<i>local-distributing</i>	(Optional) Distributing
<i>local-collecting</i>	(Optional) Collecting
<i>partner-info-timeout</i>	(Optional) Partner information refresh timeout
partnerport	(Optional) Partner port information
<i>partner-interface</i>	(Optional) Partner Interface
<i>partner-mac-address</i>	(Optional) Partner MAC Address
<i>partner-system-priority</i>	(Optional) Partner System Priority
<i>partner-port-priority</i>	(Optional) Partner Port Priority
<i>partner-port-num</i>	(Optional) Partner Port Number
<i>partner-op-key</i>	(Optional) Operational Key
<i>partner-admin-state</i>	(Optional) Partner Admin State
<i>partner-oper-state</i>	(Optional) Partner Oper State
<i>partner-activity</i>	(Optional) Mode
<i>partner-timeout</i>	(Optional) Timeout
<i>partner-sync</i>	(Optional) Synchronization
<i>partner-distributing</i>	(Optional) Distributing

<i>partner-collecting</i>	(Optional) Collecting
---------------------------	-----------------------

Command Mode

- /exec

show lacp issu-impact

```
show lacp issu-impact [ __readonly__ TABLE_interface <interface> [ <failed_interface> ] [ <intf_issu_ready> ] ]
```

Syntax Description

show	Show running system information
lacp	Show LACP information
issu-impact	Check for ISSU readiness
__readonly__	(Optional)
TABLE_interface	(Optional) Port-channel issu-impact member list
<i>interface</i>	(Optional) Port-channel Member
<i>failed_interface</i>	(Optional) ISSU failed interface
<i>intf_issu_ready</i>	(Optional) interfaces ready for issu

Command Mode

- /exec

show lacp neighbor

```
show lacp neighbor [ interface <if0> ][ __readonly__ TABLE_interface <interface> TABLE_member <port>
<partner-system-id> <partner-port-num> <partner-age> <partner-flags> <partner-port-priority>
<partner-oper-key> <partner-port-state> ]
```

Syntax Description

show	Show running system information
lacp	LACP protocol
neighbor	LACP interface neighbor
interface	(Optional) Specify a port-channel
<i>if0</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_interface	(Optional) Port channel table
<i>interface</i>	(Optional) Port channel
TABLE_member	(Optional) Member port info
<i>port</i>	(Optional) Member port
<i>partner-system-id</i>	(Optional) Partner System ID
<i>partner-port-num</i>	(Optional) Partner Port Number
<i>partner-age</i>	(Optional) Partner age
<i>partner-flags</i>	(Optional) Partner flags
<i>partner-port-priority</i>	(Optional) Partner Port Priority
<i>partner-oper-key</i>	(Optional) Partner oper key
<i>partner-port-state</i>	(Optional) Partner port state

Command Mode

- /exec

show lacp port-channel

```
show lacp port-channel [ interface <if0> ] [ __readonly__ TABLE_interface <interface> <aggr-mac-address>
<local-system-priority> <local-system-id> <local-admin-key> <local-oper-key> <partner-system-priority>
<partner-system-id> <partner-oper-key> <max-delay> <agg-or-indiv> { <port-list> } + ]
```

Syntax Description

show	Show running system information
lacp	LACP protocol
port-channel	LACP port-channels
interface	(Optional) Specify a port-channel
<i>if0</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_interface	(Optional) Port channel table
<i>interface</i>	(Optional) Port channel
<i>aggr-mac-address</i>	(Optional) Mac Address of aggregator
<i>local-system-priority</i>	(Optional) Local System Priority
<i>local-system-id</i>	(Optional) Local System-Id
<i>local-admin-key</i>	(Optional) Local admin key
<i>local-oper-key</i>	(Optional) Local oper key
<i>partner-system-priority</i>	(Optional) Partner System Priority
<i>partner-system-id</i>	(Optional) Partner System-Id
<i>partner-oper-key</i>	(Optional) Partner oper key
<i>max-delay</i>	(Optional) Maximum delay between aggregator and mac-client
<i>agg-or-indiv</i>	(Optional) Aggregate or individual port
<i>port-list</i>	(Optional) List of port names for member ports

Command Mode

- /exec

show lacp system-identifier

show lacp system-identifier [__readonly__ <system-priority> <system-mac>]

Syntax Description

show	Show running system information
lacp	LACP protocol
system-identifier	Show system-identifier information
__readonly__	(Optional)
<i>system-priority</i>	(Optional) System priority
<i>system-mac</i>	(Optional) System mac address

Command Mode

- /exec

show ldap-search-map

```
show ldap-search-map [ __readonly__ { number_of_search_maps <search_map_count> } [
TABLE_ldap_searchmaps [ <map_name> <map_baseDN> <map_attr> <map_filter> ] ] ]
```

Syntax Description

<i>__readonly__</i>	(Optional)
<i>number_of_search_maps</i>	(Optional) Total number of search maps configured
<i>search_map_count</i>	(Optional) Ldap Search map count
<i>TABLE_ldap_searchmaps</i>	(Optional) Ldap search map configuration
<i>map_name</i>	(Optional) Search map name
<i>map_baseDN</i>	(Optional) Ldap base DN
<i>map_attr</i>	(Optional) Search map attribute
<i>map_filter</i>	(Optional) Ldap Search filter
show	Show running system information
ldap-search-map	Show LDAP configuration information

Command Mode

- /exec

show ldap-server

```
show ldap-server [ __readonly__ { global_timeout <g_timeout> } { global_port <g_port> } { global_deadtime
<g_deadtime> } { total_number_of_server <g_servers_count> } { TABLE_ldap_hosts <ldap_host>
<h_idletime> <h_test_user> <h_test_passwd> [ <h_test_dn> ] <h_timeout> <h_port> <h_rootDN>
<h_ssl_enable> } ]
```

Syntax Description

<code>__readonly__</code>	(Optional)
<code>TABLE_ldap_hosts</code>	(Optional) Ldap host configuration
<code>global_timeout</code>	(Optional) Ldap host global timeout
<code>global_port</code>	(Optional) Ldap host global port
<code>global_deadtime</code>	(Optional) Ldap host global deadtime
<code>total_number_of_server</code>	(Optional) Total number of ldap hosts configured
<code>g_servers_count</code>	(Optional) Total number of ldap hosts configured
<code>g_timeout</code>	(Optional) global timeout value
<code>g_port</code>	(Optional) Global ldap port
<code>g_deadtime</code>	(Optional) Global deadtime value
<code>ldap_host</code>	(Optional) Ldap host
<code>h_idletime</code>	(Optional) Ldap host idletime
<code>h_test_user</code>	(Optional) Ldap host testuser
<code>h_test_passwd</code>	(Optional) Ldap host password
<code>h_test_dn</code>	(Optional) Ldap testuser dn
<code>h_timeout</code>	(Optional) Ldap host timeout
<code>h_port</code>	(Optional) Ldap host port
<code>h_rootDN</code>	(Optional) Ldap host RootDN
<code>h_ssl_enable</code>	(Optional) Ldap host ssl configuration
<code>show</code>	Show running system information
<code>ldap-server</code>	Show LDAP configuration information

Command Mode

- /exec

show ldap-server groups

```
show ldap-server groups [ __readonly__ { total_number_of_groups <total_groups_count> } { TABLE_groups
<g_name> <g_vrf> <g_mode> <is_bind_and_search> <g_append_with_baseDN> <g_compare_or_bind>
<g_cmp_passwd_attr> [ <user-server-group> ] [ <Cert-DN-match> ] <auth_mechanism> [ TABLE_g_servers
<g_server> <g_port> <g_timeout> ] [ <g_search_map> ] } ]
```

Syntax Description

show	Show running system information
ldap-server	Show LDAP configuration information
groups	Show LDAP server group configuration information
<i>__readonly__</i>	(Optional)
<i>total_number_of_groups</i>	(Optional) Total number of Ldap groups configured
<i>total_groups_count</i>	(Optional) Ldap group count
TABLE_groups	(Optional) LDAP Group information
<i>g_name</i>	(Optional) Ldap group name
<i>g_vrf</i>	(Optional) LDAP group vrf
<i>g_mode</i>	(Optional) LDAP group mode
<i>is_bind_and_search</i>	(Optional) Ldap Authentication bind or search
<i>g_append_with_baseDN</i>	(Optional) LDAP baseDN append information
<i>g_compare_or_bind</i>	(Optional) LDAP bind or compare
<i>g_cmp_passwd_attr</i>	(Optional) LDAP compare password attribute
<i>user-server-group</i>	(Optional) Ldap server group validation
<i>Cert-DN-match</i>	(Optional) Ldap group CERT-DN match
<i>auth_mechanism</i>	(Optional) Ldap server group authentication mechanism
TABLE_g_servers	(Optional) LDAP group server information
<i>g_server</i>	(Optional) LDAP group host
<i>g_port</i>	(Optional) LDAP group host port
<i>g_timeout</i>	(Optional) LDAP group host timeout
<i>g_search_map</i>	(Optional) LDAP group search map

Command Mode

- /exec

show ldap-server statistics

```
show ldap-server statistics <host0> [ __readonly__ { <server_state> [ <clock_time> { monitoring_statistics
<time_in_pstate> <ndead> <tt_in_dstate> } ] } { auth_statistics <auth_failed_transactions>
<auth_succ_transactions> <auth_req_sent> <auth_req_timedout> <auth_resp_no_match>
<auth_resp_not_processed> <auth_resp_error> } [ acct_statistics <acct_failed_transactions>
<acct_succ_transactions> <acct_req_sent> <acct_req_timedout> <acct_resp_no_match>
<acct_resp_not_processed> <acct_resp_error> } ] ]
```

Syntax Description

show	Show running system information
ldap-server	Show LDAP configuration information
statistics	Show LDAP statistics
<i>host0</i>	DNS name or IP address
<i>__readonly__</i>	(Optional)
<i>server_state</i>	(Optional) Show state of server
<i>clock_time</i>	(Optional) Show clock time in terms of hours, minutes and seconds
monitoring_statistics	(Optional) Monitoring Statistics
<i>time_in_pstate</i>	(Optional) Time in previous state
<i>ndead</i>	(Optional) Number of times dead
<i>tt_in_dstate</i>	(Optional) Total time in dead state
auth_statistics	(Optional) Authentication Statistics
acct_statistics	(Optional) Accounting Statistics
<i>auth_failed_transactions</i>	(Optional) Authentication: Failed transactions
<i>auth_succ_transactions</i>	(Optional) Authentication: Successful transactions
<i>auth_req_sent</i>	(Optional) Authentication: Requests sent
<i>auth_req_timedout</i>	(Optional) Authentication: Requests timedout
<i>auth_resp_no_match</i>	(Optional) Authentication: Responses with no matching requests
<i>auth_resp_not_processed</i>	(Optional) Authentication: Responses not processed
<i>auth_resp_error</i>	(Optional) Authentication: Responses containing errors
<i>acct_failed_transactions</i>	(Optional) Accounting: Failed transactions
<i>acct_succ_transactions</i>	(Optional) Accounting: Successful transactions

<i>acct_req_sent</i>	(Optional) Accounting: Requests sent
<i>acct_req_timeout</i>	(Optional) Accounting: Requests timeout
<i>acct_resp_no_match</i>	(Optional) Accounting: Responses with no matching requests
<i>acct_resp_not_processed</i>	(Optional) Accounting: Responses not processed
<i>acct_resp_error</i>	(Optional) Accounting: Responses containing errors

Command Mode

- /exec

show license

```
show license [ __readonly__ { [ <lic_file_name> <lic_file_contents> ] + } ]
```

Syntax Description

show	Show running system information
license	show the contents of all the license files
__readonly__	(Optional) Read only
<i>lic_file_name</i>	(Optional) Name of the license file
<i>lic_file_contents</i>	(Optional) License file contents

Command Mode

- /exec

show license brief

```
show license brief [ __readonly__ { [ <lic_file_name> ] + } ]
```

Syntax Description

show	Show running system information
license	show the contents of all the license files
brief	Show a list of license files
__readonly__	(Optional) Read only
<i>lic_file_name</i>	(Optional) Name of the license file

Command Mode

- /exec

show license default

show license default [__readonly__ { TABLE_lic_default <feature_name> <def_lic_count> }]

Syntax Description

show	Show running system information
license	show the contents of all the license files
default	Show services using default license
__readonly__	(Optional) Read Only
<i>feature_name</i>	(Optional) Licensed Feature Name
TABLE_lic_default	(Optional)
<i>def_lic_count</i>	(Optional) Default License Count

Command Mode

- /exec

show license feature package mapping

```
show license feature package mapping [ __readonly__ { [ <app_name> [ <lc_type> <flags> <pkg_name>
<version> ]+ ]+ ] [ <null_map> ] } ]
```

Syntax Description

show	Show running system information
license	show the contents of all the license files
feature	Show application name
package	Show license package name
mapping	Show mapping between application and package name
<i>__readonly__</i>	(Optional) Read only
<i>app_name</i>	(Optional) Name of the application
<i>lc_type</i>	(Optional) Lincard type
<i>flags</i>	(Optional) Are all licenses required
<i>pkg_name</i>	(Optional) License Package Name
<i>version</i>	(Optional) License version
<i>null_map</i>	(Optional) No mappings defined

Command Mode

- /exec

show license file

```
show license file <license-file> [ __readonly__ { [ <lic_file_contents> ] + } ]
```

Syntax Description

show	Show running system information
license	Show the contents of all the license files
file	Show contents of a license file
<i>license-file</i>	Show the contents of license file __nil__ Please install a license before using this command.
__readonly__	(Optional) Read only
<i>lic_file_contents</i>	(Optional) License file contents

Command Mode

- /exec

show license host-id

```
show license host-id [ __readonly__ { <host_id> } ]
```

Syntax Description

show	Show running system information
license	show the contents of all the license files
host-id	Show unique id for this host for licensing
__readonly__	(Optional) Read only
<i>host_id</i>	(Optional) unique id for this host for licensing

Command Mode

- /exec

show license tech support

show license tech support

Syntax Description

show	show commands
license	Display licensing information
tech	Gather information for troubleshooting
support	Gather information for troubleshooting

Command Mode

- /exec

show license usage

```
show license usage [ { detail | <license-feature> } ] [ __readonly__ { [ [ TABLE_show_lic_usage {
<feature_name> <lic_installed> <count> <status> <expiry_date> <comments> } ] { [ <application_name> ]
+ } ] ] [ <auth_status> [ TABLE_show_smart_lic_usage { <smart_feature_name> <smart_description>
<smart_count> <smart_version> <smart_status> } ] ] } ]
```

Syntax Description

show	Show running system information
license	show the contents of all the license files
usage	Show license usage table
detail	(Optional) Show license usage table
<i>license-feature</i>	(Optional) Show usage of this license package
<i>__readonly__</i>	(Optional) Read only
TABLE_show_lic_usage	(Optional) License usage
<i>feature_name</i>	(Optional) Name of the feature
<i>lic_installed</i>	(Optional) Is the license installed?
<i>count</i>	(Optional) License count
<i>status</i>	(Optional) License status
<i>expiry_date</i>	(Optional) Expiry date of the license
<i>comments</i>	(Optional) License comments
<i>application_name</i>	(Optional) Name of the application using the license
<i>auth_status</i>	(Optional) Brief about smart license usage
TABLE_show_smart_lic_usage	(Optional) Smart License usage
<i>smart_feature_name</i>	(Optional) Name of the feature
<i>smart_description</i>	(Optional) Description of the entitlement
<i>smart_count</i>	(Optional) License count
<i>smart_version</i>	(Optional) License version
<i>smart_status</i>	(Optional) License status

Command Mode

- /exec

show line

```
show line [ __readonly__ <speed> <databits> <stopbits> <parity> <modem_in> <modem_init_str> <stat> [
TABLE_ps_output <ps> ] [ <speed_aux> <databits_aux> <stopbits_aux> <parity_aux> <modem_in_aux>
<modem_init_str_aux> <hw_fc_aux> <stat_aux> [ TABLE_ps_output_aux <ps_aux> ] ] ]
```

Syntax Description

show	Show running system information
line	Show the line configuration
__readonly__	(Optional)
TABLE_ps_output	(Optional) Process info for console login
TABLE_ps_output_aux	(Optional) Process info for com1 login
<i>speed</i>	(Optional) Port speed(baud)
<i>databits</i>	(Optional) Bits per byte
<i>stopbits</i>	(Optional) Bits
<i>parity</i>	(Optional) Parity
<i>modem_in</i>	(Optional) Modem In
<i>modem_init_str</i>	(Optional) Modem Init-String
<i>stat</i>	(Optional) Statistics
<i>ps</i>	(Optional) Login process
<i>speed_aux</i>	(Optional) Port speed(baud)
<i>databits_aux</i>	(Optional) Bits per byte
<i>stopbits_aux</i>	(Optional) Bits
<i>parity_aux</i>	(Optional) Parity
<i>modem_in_aux</i>	(Optional) Modem In
<i>modem_init_str_aux</i>	(Optional) Modem Init-String
<i>hw_fc_aux</i>	(Optional) Hardware Flowcontrol
<i>stat_aux</i>	(Optional) Statistics
<i>ps_aux</i>	(Optional) Login process

Command Mode

- /exec

show line console

```
show line console [ __readonly__ <speed> <databits> <stopbits> <parity> <modem_in> <modem_init_str>
<stat> [ TABLE_ps_output <ps> ] ]
```

Syntax Description

show	Show running system information
line	Show the line configuration
console	Show console line configurations
<i>__readonly__</i>	(Optional)
TABLE_ps_output	(Optional) Process info for console login
<i>speed</i>	(Optional) Port speed(baud)
<i>databits</i>	(Optional) Bits per byte
<i>stopbits</i>	(Optional) Bits
<i>parity</i>	(Optional) Parity
<i>modem_in</i>	(Optional) Modem In
<i>modem_init_str</i>	(Optional) Modem Init-String
<i>stat</i>	(Optional) Statistics
<i>ps</i>	(Optional) Login process

Command Mode

- /exec

show line console connected

show line console connected [__readonly__ <output>]

Syntax Description

show	Show running system information
line	Show the line configuration
console	Show console line configurations
connected	Show whether the line is currently connected physically
__readonly__	(Optional)
<i>output</i>	(Optional) output string

Command Mode

- /exec

show line console user-input-string

```
show line console user-input-string [ __readonly__ <input> ]
```

Syntax Description

show	Show running system information
line	Show the line configuration
console	Show console line configurations
user-input-string	Show user-input init string
__readonly__	(Optional)
<i>input</i>	(Optional) user input string

Command Mode

- /exec

show lisp ddt

```
show lisp ddt [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
lisp	LISP show commands
ddt	LISP Delegated Database Tree (LISP-DDT)
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lisp ddt queue

```
show lisp ddt queue [ [ instance-id <iid> ] { <eid> | <eid6> } ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
lisp	LISP show commands
ddt	LISP Delegated Database Tree (LISP-DDT)
queue	Display LISP-DDT Map-Request queue in Map-Resolver
instance-id	(Optional) Show instance-ID summary display
<i>iid</i>	(Optional) Instance-ID for EID-prefix
<i>eid</i>	(Optional) IPv4 EID address
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lisp ddt referral-cache

```
{ show lisp ddt referral-cache [ [ instance-id <iid> ] { <eid> | <eid6> } ] [ vrf { <vrf-name> | <vrf-known-name> } ] } | { show lisp ddt referral-cache { ms-ack | ms-referral | node-referral | ms-not-registered | delegation-hole | not-authoritative } [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

Syntax Description

show	Show running system information
lisp	LISP show commands
ddt	LISP Delegated Database Tree (LISP-DDT)
referral-cache	Display LISP-DDT referral cache
instance-id	(Optional) Show instance-ID summary display
<i>iid</i>	(Optional) Instance-ID for EID-prefix
<i>eid</i>	(Optional) IPv4 EID address
ms-ack	Referral cache entries to map-servers
ms-referral	Referral cache entries from parent of map-servers
node-referral	Referral cache entries from parent of DDT-nodes
ms-not-registered	Referral cache entries from map-servers
delegation-hole	Referral cache entries from any DDT-node
not-authoritative	Referral cache entries from any DDT-node
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lisp dynamic-eid

```
{ show lisp dynamic-eid { summary | { [ <dyn-eid-name> ] [ detail ] } } [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

Syntax Description

show	Show running system information
lisp	LISP show commands
dynamic-eid	Display dynamic-EIDs configured and discovered
summary	One-line summary display of discovered dynamic-EIDs
<i>dyn-eid-name</i>	(Optional) Display a single dynamic-EID
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
detail	(Optional) Display discovered dynamic-EIDs

Command Mode

- /exec

show lisp elp

```
show lisp elp [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
lisp	LISP show commands
elp	Display LISP Explicit Locator Paths configured
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lisp negative-prefix

```
show lisp negative-prefix { <eid> | <eid6> } [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
lisp	LISP show commands
negative-prefix	Compute negative-prefix for hole in EID space
<i>eid</i>	IPv4 EID address
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lisp proxy-itr

```
show lisp proxy-itr [ vrf { <vrf-name> | <vrf-known-name> } ]
```

Syntax Description

show	Show running system information
lisp	LISP show commands
proxy-itr	Display discovered proxy-ITRs (PITRs)
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lisp site

```
{ show lisp site [ { { <eid> | <eid6> } [ instance-id <iid> ] } | { { <eid-prefix> | <eid-prefix6> } [ instance-id <iid> ] } | <site-name> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

Syntax Description

show	Show running system information
lisp	LISP show commands
site	Display Map-Server site EID-prefixes configured
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>eid</i>	(Optional) Display mapping for IP destination EID
<i>eid-prefix</i>	(Optional) Display exact match for IP EID-prefix entry
instance-id	(Optional) Instance EID-prefix registered in
<i>iid</i>	(Optional) Instance-ID value
<i>site-name</i>	(Optional) Display a single site
detail	(Optional) Display allowed registered locator sources

Command Mode

- /exec

show lisp site instance-id

```
{ show lisp site instance-id [ <iid> ] [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

Syntax Description

show	Show running system information
lisp	LISP show commands
site	Display Map-Server site EID-prefixes configured
instance-id	Show instance-ID summary display
<i>iid</i>	(Optional) Show detail for entries of a single Instance-ID
vrf	(Optional) Display information for vrf
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec

show lldp all

```
show lldp all [ __readonly__ TABLE_lldp_all <intf_desc> <lldp_tx> <lldp_rx> <lldp_dcbx> ]
```

Syntax Description

show	Show running system information
lldp	Show lldp Protocol information
all	Show all interfaces in lldp database
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_lldp_all</i>	(Optional) output of show lldp all
<i>intf_desc</i>	(Optional) Interface desc
<i>lldp_tx</i>	(Optional) lldp tx status
<i>lldp_rx</i>	(Optional) lldp rx status
<i>lldp_dcbx</i>	(Optional) lldp dcbx status

Command Mode

- /exec

show lldp dcbx interface

```
show lldp dcbx interface <if_in> [ __readonly__ <if_out> <cfg_proto> <det_proto> [ <l_op_ver> <l_max_ver>
<l_seq_no> <l_ack_no> ] [ <l_feature> <l_feat_len> <l_cfg> ] + [ <p_op_ver> <p_max_ver> <p_seq_no>
<p_ack_no> ] [ <p_tlv_type> <p_tlv_ctrl> <p_tlv_len> <p_tlv_value> ] + ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
dcbx	Show dcbx information
interface	Show lldp interface information
<i>if_in</i>	Enter interface
<i>__readonly__</i>	(Optional)
<i>if_out</i>	(Optional) Interface ID
<i>cfg_proto</i>	(Optional) Configured DCBX Protocol
<i>det_proto</i>	(Optional) DCBX Protocol detected
<i>l_op_ver</i>	(Optional) local dcbx control operation version
<i>l_max_ver</i>	(Optional) local dcbx control maximum version
<i>l_seq_no</i>	(Optional) local dcbx control seq no
<i>l_ack_no</i>	(Optional) local dcbx control ack no
<i>l_feature</i>	(Optional) local feature
<i>l_feat_len</i>	(Optional) Local Feature Length
<i>l_cfg</i>	(Optional) local feature config
<i>p_op_ver</i>	(Optional) peer dcbx control operation version
<i>p_max_ver</i>	(Optional) peer dcbx control maximum version
<i>p_seq_no</i>	(Optional) peer dcbx control seq no
<i>p_ack_no</i>	(Optional) peer dcbx control ack no
<i>p_tlv_type</i>	(Optional) peer TLV type field
<i>p_tlv_ctrl</i>	(Optional) peer TLV control info
<i>p_tlv_len</i>	(Optional) Peer TLV Length
<i>p_tlv_value</i>	(Optional) peer TLV value field

Command Mode

- /exec

show lldp entry

```
show lldp entry [ <sys-name> ] [ __readonly__ { <neigh_hdr> } { TABLE_entry <chassis_type> <chassis_id>
<port_type> <port_id> <l_port_id> <port_desc> <sys_name> <sys_desc> <ttl> <capability>
<mgmt_addr_type> <mgmt_addr> <mgmt_addr_ipv6_type> <mgmt_addr_ipv6> <vlan_id> } { <neigh_count>
} ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
entry	Show lldp entry information
<i>sys-name</i>	(Optional) WORD Peer's System name
<i>__readonly__</i>	(Optional)
<i>neigh_hdr</i>	(Optional)
TABLE_entry	(Optional) Table Entry
<i>chassis_type</i>	(Optional) Chassis ID type
<i>chassis_id</i>	(Optional) Chassis ID
<i>port_type</i>	(Optional) Port ID type
<i>port_id</i>	(Optional) Port ID
<i>l_port_id</i>	(Optional) Port ID
<i>port_desc</i>	(Optional) Port description
<i>sys_name</i>	(Optional) System name
<i>sys_desc</i>	(Optional) System description
<i>ttl</i>	(Optional) Time to live
<i>capability</i>	(Optional) Capability
<i>mgmt_addr_type</i>	(Optional) Management Address type
<i>mgmt_addr</i>	(Optional) Management Address
<i>mgmt_addr_ipv6_type</i>	(Optional) IPV6 Management Address type
<i>mgmt_addr_ipv6</i>	(Optional) IPV6 Management Address
<i>vlan_id</i>	(Optional) Vlan ID
<i>neigh_count</i>	(Optional)

Command Mode

- /exec

show lldp interface

```
show lldp interface <if0> [ __readonly__ <interface> <tx_en> <rx_en> <dcbx_en> <port_mac> [ <tlv_type>
<tlv_len> [ <tlv_value> ] ] + [ <l_op_ver> <l_max_ver> <l_seq_no> <l_ack_no> [ <l_feature> <l_cfg_len>
<l_cfg> ] + ] [ <p_op_ver> <p_max_ver> <p_seq_no> <p_ack_no> [ <p_tlv_type> <p_tlv_len> <p_tlv_value>
] + ] ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
interface	Show lldp interface information
<i>if0</i>	Enter interface
<i>__readonly__</i>	(Optional)
<i>interface</i>	(Optional) Interface ID
<i>tx_en</i>	(Optional) tx enable
<i>rx_en</i>	(Optional) rx enable
<i>dcbx_en</i>	(Optional) dcbox enable
<i>port_mac</i>	(Optional) Port mac address
<i>tlv_type</i>	(Optional) TLV type field
<i>tlv_len</i>	(Optional) TLV len field
<i>tlv_value</i>	(Optional) TLV value field
<i>l_op_ver</i>	(Optional) local dcbox control operation version
<i>l_max_ver</i>	(Optional) local dcbox control maximum version
<i>l_seq_no</i>	(Optional) local dcbox control seq no
<i>l_ack_no</i>	(Optional) local dcbox control ack no
<i>l_feature</i>	(Optional) local feature
<i>l_cfg_len</i>	(Optional) local feature config length
<i>l_cfg</i>	(Optional) local feature config
<i>p_op_ver</i>	(Optional) peer dcbox control operation version
<i>p_max_ver</i>	(Optional) peer dcbox control maximum version
<i>p_seq_no</i>	(Optional) peer dcbox control seq no

<i>p_ack_no</i>	(Optional) peer dcbx control ack no
<i>p_tlv_type</i>	(Optional) peer TLV type field
<i>p_tlv_len</i>	(Optional) peer TLV len field
<i>p_tlv_value</i>	(Optional) peer TLV value field

Command Mode

- /exec

show lldp neighbors

```
show lldp neighbors [ interface <if> ] [ __readonly__ { <neigh_hdr> } { TABLE_nbor <chassis_type>
<chassis_id> <l_port_id> <hold_time> [ <capability> ] <system_capability> <enabled_capability> <port_type>
<port_id> <mgmt_addr_type> <mgmt_addr> <mgmt_addr_ipv6_type> <mgmt_addr_ipv6> } { <neigh_count>
} ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
neighbors	Show lldp neighbor information
interface	(Optional) Show lldp neighbor information on an interface
<i>if</i>	(Optional) Enter interface
<i>__readonly__</i>	(Optional)
<i>neigh_hdr</i>	(Optional)
TABLE_nbor	(Optional) Neighbor Table
<i>chassis_type</i>	(Optional) Chassis ID type
<i>chassis_id</i>	(Optional) Chassis ID
<i>l_port_id</i>	(Optional) Local port ID
<i>hold_time</i>	(Optional) Hold time
<i>capability</i>	(Optional) Capability
<i>system_capability</i>	(Optional) System Capability
<i>enabled_capability</i>	(Optional) Enabled Capability
<i>port_type</i>	(Optional) Port ID type
<i>port_id</i>	(Optional) Port ID
<i>mgmt_addr_type</i>	(Optional) Management Address type
<i>mgmt_addr</i>	(Optional) Management Address
<i>mgmt_addr_ipv6_type</i>	(Optional) IPV6 Management Address type
<i>mgmt_addr_ipv6</i>	(Optional) IPV6 Management Address
<i>neigh_count</i>	(Optional)

Command Mode

- /exec

show lldp neighbors detail

```
show lldp neighbors [ interface <if> ] detail [ __readonly__ { <neigh_hdr> } { TABLE_nbor_detail
<chassis_type> <chassis_id> <port_type> <port_id> <l_port_id> <port_desc> <sys_name> <sys_desc> <ttl>
[ <capability> ] <system_capability> <enabled_capability> <mgmt_addr_type> <mgmt_addr>
<mgmt_addr_ipv6_type> <mgmt_addr_ipv6> <vlan_id> } { <neigh_count> } ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
neighbors	Show lldp neighbor information
interface	(Optional) Show lldp neighbor information on an interface
<i>if</i>	(Optional) Enter interface
detail	Show lldp neighbor detail information
<i>__readonly__</i>	(Optional)
<i>neigh_hdr</i>	(Optional)
TABLE_nbor_detail	(Optional) Neighbor detail Table
<i>chassis_type</i>	(Optional) Chassis ID type
<i>chassis_id</i>	(Optional) Chassis ID
<i>port_type</i>	(Optional) Port ID type
<i>port_id</i>	(Optional) Port ID
<i>l_port_id</i>	(Optional) Port ID
<i>port_desc</i>	(Optional) Port description
<i>sys_name</i>	(Optional) System name
<i>sys_desc</i>	(Optional) System description
<i>ttl</i>	(Optional) Time to live
<i>capability</i>	(Optional) Capability
<i>system_capability</i>	(Optional) System Capability
<i>enabled_capability</i>	(Optional) Enabled Capability
<i>mgmt_addr_type</i>	(Optional) Management Address type
<i>mgmt_addr</i>	(Optional) Management Address

<i>mgmt_addr_ipv6_type</i>	(Optional) IPV6 Management Address type
<i>mgmt_addr_ipv6</i>	(Optional) IPV6 Management Address
<i>vlan_id</i>	(Optional) Vlan ID
<i>neigh_count</i>	(Optional)

Command Mode

- /exec

show lldp neighbors system-detail

```
show lldp neighbors [ interface <if> ] system-detail [ __readonly__ { <neigh_hdr> } { TABLE_nbor_sys_detail
<sys_type> <sys_name> <l_port_id> <chassis_type> <chassis_id> <port_type> <port_id> <ttl> <capability>
<mgmt_addr_type> <mgmt_addr> } { <neigh_count> } ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
neighbors	Show lldp neighbor information
interface	(Optional) Show lldp neighbor information on an interface
<i>if</i>	(Optional) Enter interface
system-detail	Show lldp neighbor system detail information
<i>__readonly__</i>	(Optional)
<i>neigh_hdr</i>	(Optional)
TABLE_nbor_sys_detail	(Optional) Neighbor sys-detail Table
<i>sys_type</i>	(Optional) System Type
<i>sys_name</i>	(Optional) System Name
<i>l_port_id</i>	(Optional) Local port ID
<i>chassis_type</i>	(Optional) Chassis ID type
<i>chassis_id</i>	(Optional) Chassis ID
<i>port_type</i>	(Optional) Port ID type
<i>port_id</i>	(Optional) Port ID
<i>ttl</i>	(Optional) Time to live
<i>capability</i>	(Optional) Capability
<i>mgmt_addr_type</i>	(Optional) Management Address type
<i>mgmt_addr</i>	(Optional) Management Address
<i>neigh_count</i>	(Optional)

Command Mode

- /exec

show lldp portid-subtype

```
show lldp portid-subtype [ __readonly__ <portid_subtype> ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
portid-subtype	Show lldp portid-subtype
__readonly__	(Optional)
<i>portid_subtype</i>	(Optional) portid-subtype for LLDP TLV and MIBs

Command Mode

- /exec

show lldp timers

```
show lldp timers [ __readonly__ <ttl> <reinit> <tx_interval> <tx_delay> <hold_mplier> <notification_interval> ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
timers	Show lldp timers
<i>__readonly__</i>	(Optional)
<i>ttl</i>	(Optional) Time to Live for lldp info
<i>reinit</i>	(Optional) Interface reinit timer
<i>tx_interval</i>	(Optional) Wait interval between successive transmit
<i>tx_delay</i>	(Optional) Delay between successive frame transmissions
<i>hold_mplier</i>	(Optional) Hold multiplier for ttl
<i>notification_interval</i>	(Optional) Notification interval for SNMP trap

Command Mode

- /exec

show lldp tlv-select

```
show lldp tlv-select [ __readonly__ <management-address-v4> <management-address-v6> <port-description>
<port-vlan> <power-management> <system-capabilities> <system-description> <system-name>
<dcbxp-cin-cee> [ <dcbxp-cn> ] [ <dcbxp-ets-cfg> ] [ <dcbxp-ets-reco> ] [ <dcbxp-pfc-cfg> ] [
<dcbxp-app-pri> ] [ <dcbxp-app-vlan> ] ]
```

Syntax Description

show	Show running system information
lldp	Show information about lldp
tlv-select	Show lldp tlv-select
__readonly__	(Optional)
<i>management-address-v4</i>	(Optional) Management address v4
<i>management-address-v6</i>	(Optional) Management address v6
<i>port-description</i>	(Optional) Port description
<i>port-vlan</i>	(Optional) Port vlan
<i>power-management</i>	(Optional) IEEE 802.3 DTE Power via MDI TLV
<i>system-capabilities</i>	(Optional) System capabilities
<i>system-description</i>	(Optional) System description
<i>system-name</i>	(Optional) System name
<i>dcbxp-cin-cee</i>	(Optional) DCBXP CIN or CEE
<i>dcbxp-cn</i>	(Optional) DCBXP Congestion Notification
<i>dcbxp-ets-cfg</i>	(Optional) DCBXP ETS Configuration
<i>dcbxp-ets-reco</i>	(Optional) DCBXP ETS Recommendation
<i>dcbxp-pfc-cfg</i>	(Optional) DCBXP PFC Configuration
<i>dcbxp-app-pri</i>	(Optional) DCBXP Application Priorities
<i>dcbxp-app-vlan</i>	(Optional) DCBXP Application VLAN's

Command Mode

- /exec

show lldp traffic

show lldp traffic [*__readonly__* <tx_cnt> <aged_cnt> <rx_cnt> <rx_err> <disc_cnt> <unrecognized_tlv>]

Syntax Description

show	Show running system information
lldp	Show information about lldp
traffic	Show lldp counters
<i>__readonly__</i>	(Optional)
<i>tx_cnt</i>	(Optional) Transmit count
<i>aged_cnt</i>	(Optional) Aged out count
<i>rx_cnt</i>	(Optional) Received count
<i>rx_err</i>	(Optional) Received error count
<i>disc_cnt</i>	(Optional) Disconnect count
<i>unrecognized_tlv</i>	(Optional) Unrecognized TLV count

Command Mode

- /exec

show lldp traffic interface

show lldp traffic interface <if> [__readonly__ <interface> <tx_cnt> <aged_cnt> <rx_cnt> <rx_err> <disc_cnt> <unrecognized_tlv>]

Syntax Description

show	Show running system information
lldp	Show information about lldp
traffic	Show lldp counters
interface	Show lldp traffic counters on an interface
<i>if</i>	Enter interface
<i>__readonly__</i>	(Optional)
<i>interface</i>	(Optional) Interface ID
<i>tx_cnt</i>	(Optional) Transmit count
<i>aged_cnt</i>	(Optional) Aged out count
<i>rx_cnt</i>	(Optional) Received count
<i>rx_err</i>	(Optional) Received error count
<i>disc_cnt</i>	(Optional) Disconnect count
<i>unrecognized_tlv</i>	(Optional) Unrecognized TLV count

Command Mode

- /exec

show locator-led status

show locator-led status [__readonly__ { TABLE_loc_led_stat <component> <status> }]

Syntax Description

show	Show running system information
locator-led	blink locator led on device
status	status
__readonly__	(Optional)
TABLE_loc_led_stat	(Optional)
<i>component</i>	(Optional)
<i>status</i>	(Optional)

Command Mode

- /exec

show logging

show logging

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile

Command Mode

- /exec

show logging console

show logging console

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
console	Show console logging configuration

Command Mode

- /exec

show logging info

```
show logging info [ __readonly__ { <console_status> [ <console_severity> ] } { <monitor_status> [
<monitor_severity> ] } { <linecard_status> [ <linecard_severity> ] } { <log_timestamp> } [ {
<source_interface_status> } [ <source_interface_intf> | <source_interface_intf_index> <source_interface_error>
] ] { <server_status> [ { TABLE_logserver <server> <forwarding> <severity> <facility> <vrf> <port> [
<transport> ] } ] } { <origin_id_status> } [ <origin_id> ] ] [ [ <logflash_status> ] [ <logflash_severity> ] ]
{ <logfile_status> [ <logfile_name> <logfile_severity> <logfile_size> ] } { { TABLE_facility
<fac_name> <def_level> <cur_level> } { <fac_info> } } ]
```

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
info	Show logging configuration
<i>__readonly__</i>	(Optional)
<i>console_status</i>	(Optional) console logging status
<i>console_severity</i>	(Optional) console logging level
<i>monitor_status</i>	(Optional) monitor logging status
<i>monitor_severity</i>	(Optional) monitor logging level
<i>linecard_status</i>	(Optional) linecard logging status
<i>linecard_severity</i>	(Optional) linecard logging level
<i>log_timestamp</i>	(Optional) timestamp unit
<i>source_interface_status</i>	(Optional) source-interface logging status
<i>source_interface_intf</i>	(Optional) source-interface interface
<i>server_status</i>	(Optional) logging server status
TABLE_logserver	(Optional) output of show logging server
<i>transport</i>	(Optional) remote server transport
<i>origin_id_status</i>	(Optional) origin-id status
<i>origin_id</i>	(Optional) origin-id
<i>logflash_status</i>	(Optional) logflash status
<i>logflash_severity</i>	(Optional) logflash level
<i>logfile_status</i>	(Optional) logfile status
TABLE_facility	(Optional) output of show logging level(facility)

<i>fac_info</i>	(Optional) level info
-----------------	-----------------------

Command Mode

- /exec

show logging ip access-list cache

```
show logging ip access-list cache [ detail ] [ __readonly__ <disp_flags> <sgt> <src_ip> <dst_ip> <src_port>
<dst_port> <if_index> <proto> <hit_cnt> <acl_name> <acl_num> <acl_permit> <acl_ingress> <acl_type>
<acl_appl_if_index> <acl_fltr_hit_cnt> ]
```

Syntax Description

show	Show running system information
logging	logging information
ip	IP configuration
access-list	Access-list
cache	logging
detail	(Optional) Show additional details about entries in cache
<i>__readonly__</i>	(Optional)
<i>disp_flags</i>	(Optional) Display flags
<i>sgt</i>	(Optional) SGT
<i>src_ip</i>	(Optional) Source IP
<i>dst_ip</i>	(Optional) Dest IP
<i>src_port</i>	(Optional) Source port
<i>dst_port</i>	(Optional) Dest port
<i>if_index</i>	(Optional) Interface
<i>proto</i>	(Optional) Protocol
<i>hit_cnt</i>	(Optional) Hits
<i>acl_name</i>	(Optional) ACL Name
<i>acl_num</i>	(Optional) ACL Number
<i>acl_permit</i>	(Optional) ACL Permit
<i>acl_ingress</i>	(Optional) ACL Ingress
<i>acl_type</i>	(Optional) ACL Filter Type
<i>acl_appl_if_index</i>	(Optional) ACL Applied Interface
<i>acl_fltr_hit_cnt</i>	(Optional) ACL Filter Count

Command Mode

- /exec

show logging ip access-list status

show logging ip access-list status [*__readonly__* <num_entries> <seconds> <num_packets>]

Syntax Description

show	Show running system information
logging	logging information
ip	IP configuration
access-list	Access-list
status	ACLLOG status
<i>__readonly__</i>	(Optional)
<i>num_entries</i>	(Optional) Max flows
<i>seconds</i>	(Optional) Log-update interval in seconds
<i>num_packets</i>	(Optional) threshold

Command Mode

- /exec

show logging last

show logging last <i0>

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
last	Show last few lines of logfile
<i>i0</i>	Enter number of lines to display

Command Mode

- /exec

show logging level

```
show logging level [ { auth | authpriv | cron | daemon | ftp | kernel | local0 | local1 | local2 | local3 | local4 |
local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp } ] [ __readonly__ { TABLE_facility <fac_name>
<def_level> <cur_level> } ]
```

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
auth	(Optional) Show Authorization System logging configuration
authpriv	(Optional) Show Authorization (Private) logging configuration
cron	(Optional) Show Cron/at facility logging configuration
daemon	(Optional) Show System daemons logging configuration
ftp	(Optional) Show File Transfer System logging configuration
kernel	(Optional) Show kernel logging configuration
local0	(Optional) Show Local use daemons logging configuration
local1	(Optional) Show Local use daemons logging configuration
local2	(Optional) Show Local use daemons logging configuration
local3	(Optional) Show Local use daemons logging configuration
local4	(Optional) Show Local use daemons logging configuration
local5	(Optional) Show Local use daemons logging configuration
local6	(Optional) Show Local use daemons logging configuration
local7	(Optional) Show Local use daemons logging configuration
lpr	(Optional) Show Line Printer System logging configuration
mail	(Optional) Show Mail System logging configuration
news	(Optional) Show USENET news logging configuration
syslog	(Optional) Show Internal Syslog Messages logging configuration
user	(Optional) Show user process logging configuration
uucp	(Optional) Show Unix-to-Unix copy system logging configuration
__readonly__	(Optional)

<i>fac_name</i>	(Optional) facility names
TABLE_facility	(Optional)
<i>def_level</i>	(Optional) default severity
<i>cur_level</i>	(Optional) current severity

Command Mode

- /exec

show logging level

show logging level

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration

Command Mode

- /exec

show logging level aaa

show logging level aaa

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
aaa	Show aaa logging configuration

Command Mode

- /exec

show logging level aclog

show logging level aclog

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
aclog	Show aclog logging configuration

Command Mode

- /exec

show logging level aclmgr

show logging level aclmgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
aclmgr	Show aclmgr logging configuration

Command Mode

- /exec

show logging level adbm

show logging level adbm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
adbm	Show adbm logging configuration

Command Mode

- /exec

show logging level adjmgr

show logging level adjmgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
adjmgr	Show adjmgr logging configuration

Command Mode

- /exec

show logging level amt

show logging level amt

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
amt	Show amt logging configuration

Command Mode

- /exec

show logging level arp

show logging level arp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
arp	Show arp logging configuration

Command Mode

- /exec

show logging level ascii-cfg

show logging level ascii-cfg

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ascii-cfg	Show ascii-cfg logging configuration

Command Mode

- /exec

show logging level assoc_mgr

show logging level assoc_mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
assoc_mgr	Show Association Manager Logging Configuration

Command Mode

- /exec

show logging level backup

show logging level { backup | flexlink }

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
backup	Show Switchport Backup logging level
flexlink	Show Switchport Backup logging level

Command Mode

- /exec

show logging level bfd

show logging level bfd

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
bfd	Show bfd logging configuration

Command Mode

- /exec

show logging level bgp

show logging level bgp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
bgp	Show BGP logging configuration

Command Mode

- /exec

show logging level bloggerd

show logging level bloggerd

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
bloggerd	Show BloggerD logging configuration

Command Mode

- /exec

show logging level bootvar

show logging level bootvar

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
bootvar	Show bootvar logging configuration

Command Mode

- /exec

show logging level callhome

show logging level callhome

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
callhome	Show callhome logging configuration

Command Mode

- /exec

show logging level capability

show logging level capability

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
capability	Show capability logging configuration

Command Mode

- /exec

show logging level catena

show logging level catena

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
catena	Show catena logging configuration

Command Mode

- /exec

show logging level cdp

show logging level cdp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
cdp	Show CDP logging configuration

Command Mode

- /exec

show logging level cert_enroll

show logging level cert_enroll

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
cert_enroll	Show Cert-enroll logging configuration

Command Mode

- /exec

show logging level cfs

show logging level cfs

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration

Command Mode

- /exec

show logging level clis

show logging level clis

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
clis	Show CLIS logging configuration

Command Mode

- /exec

show logging level clk_mgr

show logging level clk_mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
clk_mgr	Show clock manager logging configuration

Command Mode

- /exec

show logging level confcheck

show logging level confcheck

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
confcheck	Show confcheck logging configuration

Command Mode

- /exec

show logging level copp

show logging level copp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
copp	Show copp logging configuration

Command Mode

- /exec

show logging level core

show logging level core

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
core	Show core daemon logging configuration

Command Mode

- /exec

show logging level cts

show logging level cts

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
cts	Show cts logging configuration

Command Mode

- /exec

show logging level dhcp_snoop

show logging level dhcp_snoop

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
dhcp_snoop	Show DHCP snoop logging configuration

Command Mode

- /exec

show logging level diagnostic diagclient

show logging level diagnostic diagclient

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
diagnostic	Diagnostic commands
diagclient	Show diagclient logging configuration

Command Mode

- /exec

show logging level diagnostic diagmgr

show logging level diagnostic diagmgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
diagnostic	Diagnostic commands
diagmgr	Show diagmgr logging configuration

Command Mode

- /exec

show logging level dot1x

show logging level dot1x

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
dot1x	Show dot1x logging configuration

Command Mode

- /exec

show logging level ecp

show logging level ecp

Syntax Description

show	Show running system information
logging	Modify message logging facilities
level	Facility parameter for syslog messages
ecp	Set syslog filter level for ECP

Command Mode

- /exec

show logging level eigrp

show logging level eigrp [<eigrp-ptag>]

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
eigrp	Show EIGRP logging configuration
<i>eigrp-ptag</i>	(Optional) Process tag

Command Mode

- /exec

show logging level eltm

show logging level eltm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
eltm	Show eltm logging configuration

Command Mode

- /exec

show logging level epp

show logging level epp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
epp	Show epp logging configuration

Command Mode

- /exec

show logging level ethdstats

show logging level ethdstats

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ethdstats	Show delta statistics logging configuration

Command Mode

- /exec

show logging level ethpm

show logging level ethpm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ethpm	Show ethpm logging configuration

Command Mode

- /exec

show logging level evb

show logging level evb

Syntax Description

show	Show running system information
logging	Modify message logging facilities
level	Facility parameter for syslog messages
evb	Set syslog filter level for EVB

Command Mode

- /exec

show logging level evmc

show logging level evmc

Syntax Description

show	Show running system information
logging	Show message logging facilities
level	Show facility logging configuration
evmc	Show level for evmc syslog messages

Command Mode

- /exec

show logging level evmed

show logging level evmed

Syntax Description

show	Show running system information
logging	Show message logging facilities
level	Show facility logging configuration
evmed	Show level for evmed syslog messages

Command Mode

- /exec

show logging level evms

show logging level evms

Syntax Description

show	Show running system information
logging	Show message logging facilities
level	Show facility logging configuration
evms	Show level for evms syslog messages

Command Mode

- /exec

show logging level fabric forwarding

show logging level fabric forwarding

Syntax Description

show	Show running system information
logging	Modify message logging facilities
level	Facility parameter for syslog messages
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)

Command Mode

- /exec

show logging level fcoe_mgr

show logging level fcoe_mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
fcoe_mgr	Show fcoe_mgr logging configuration

Command Mode

- /exec

show logging level feature-mgr

show logging level feature-mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
feature-mgr	Show feature manager logging configuration

Command Mode

- /exec

show logging level fs-daemon

show logging level fs-daemon

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
fs-daemon	Show fs-daemon logging configuration

Command Mode

- /exec

show logging level gpixm

show logging level gpixm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
gpixm	Show global-pixm logging configuration

Command Mode

- /exec

show logging level hardware-telemetry

show logging level hardware-telemetry

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
hardware-telemetry	Show hardware-telemetry logging configuration

Command Mode

- /exec

show logging level hsrp

show logging level hsrp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
hsrp	Show HSRP logging configuration

Command Mode

- /exec

show logging level icam

show logging level icam

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
icam	Show icam logging configuration

Command Mode

- /exec

show logging level im

show logging level im

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
im	Show im logging configuration

Command Mode

- /exec

show logging level imp

show logging level imp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
imp	Show imp logging configuration

Command Mode

- /exec

show logging level interface-vlan

show logging level interface-vlan

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
interface-vlan	Show interface-vlan logging configuration

Command Mode

- /exec

show logging level ip igmp

show logging level ip igmp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ip	Display IP information
igmp	Show igmp logging configuration

Command Mode

- /exec

show logging level ip msdp

show logging level ip msdp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ip	Display IP information
msdp	Show msdp logging configuration

Command Mode

- /exec

show logging level ip sla responder

show logging level ip sla responder

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ip	
sla	Service Level Agreement (SLA)
responder	Show sla-responder logging configuration

Command Mode

- /exec

show logging level ip sla sender

show logging level ip sla sender

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ip	
sla	Service Level Agreement (SLA)
sender	Show sla-sender logging configuration

Command Mode

- /exec

show logging level ip sla twamp-server

show logging level ip sla twamp-server

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ip	
sla	Service Level Agreement (SLA)
twamp-server	Show sla-twamp-server logging configuration

Command Mode

- /exec

show logging level ipconf

show logging level ipconf [ipv6]

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ipconf	Show ipconf logging configuration
ipv6	(Optional) Show ipv6 Conf logging configuration

Command Mode

- /exec

show logging level ipfib

show logging level ipfib

Syntax Description

show	show
logging	logging
level	level
ipfib	ipfib

Command Mode

- /exec

show logging level ipqos

show logging level ipqos

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration

Command Mode

- /exec

show logging level ipv6 icmp

show logging level ipv6 icmp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ipv6	Configure IPv6 features
icmp	Show icmpv6 logging configuration

Command Mode

- /exec

show logging level iscm

show logging level iscm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
iscm	Show iscm logging configuration

Command Mode

- /exec

show logging level iscm

show logging level iscm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
iscm	Show iscm logging configuration

Command Mode

- /exec

show logging level isis

show logging level isis

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
isis	Show ISIS logging configuration

Command Mode

- /exec

show logging level keystore

show logging level { keystore | sksd }

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
keystore	Show Keystore logging configuration
sksd	show Keystore/sksd logging configuration

Command Mode

- /exec

show logging level l2fm

show logging level l2fm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
l2fm	Show l2fm logging configuration

Command Mode

- /exec

show logging level l3vm

show logging level l3vm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
l3vm	Show L3VM logging configuration

Command Mode

- /exec

show logging level lacp

show logging level lacp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
lacp	Show lacp logging configuration

Command Mode

- /exec

show logging level ldap

show logging level ldap

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ldap	Show ldap logging configuration

Command Mode

- /exec

show logging level license

show logging level { license | licmgr }

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
license	Show Licensing logging configuration
licmgr	Show Licensing logging configuration

Command Mode

- /exec

show logging level lim

show logging level lim

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
lim	Show lim logging configuration

Command Mode

- /exec

show logging level lisp

show logging level lisp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
lisp	Show lisp logging configuration

Command Mode

- /exec

show logging level lldp

show logging level lldp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
lldp	Show LLDP logging configuration

Command Mode

- /exec

show logging level m2rib

show logging level m2rib

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
m2rib	Show M2RIB logging configuration

Command Mode

- /exec

show logging level mfdm

show logging level mfdm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
mfdm	Show mfdm logging configuration

Command Mode

- /exec

show logging level mfwd

show logging level mfwd

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
mfwd	Show MCASTFWD logging configuration

Command Mode

- /exec

show logging level mmode

show logging level mmode

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
mmode	Show maintenance mode logging configuration

Command Mode

- /exec

show logging level module

show logging level module

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
module	Show module(linecard) manager logging configuration

Command Mode

- /exec

show logging level monitor

show logging level monitor

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
monitor	Show monitor logging configuration

Command Mode

- /exec

show logging level mvsh

show logging level mvsh

Syntax Description

show	Show commands
logging	Show message logging facilities
level	Show message logging facilities
mvsh	Show level for mvsh syslog messages

Command Mode

- /exec

show logging level nat

show logging level nat

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
nat	Show NAT logging configurarion

Command Mode

- /exec

show logging level nbm

show logging level nbm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
nbm	Show Non Blocking Multicast logging configuration

Command Mode

- /exec

show logging level netstack

show logging level netstack

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
netstack	Show netstack logging configuration

Command Mode

- /exec

show logging level nfm

show logging level nfm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
nfm	Show NFM logging configuration

Command Mode

- /exec

show logging level ngoam

show logging level ngoam

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ngoam	Show ngoam logging level

Command Mode

- /exec

show logging level npv

show logging level npv

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
npv	Show npv logging configuration

Command Mode

- /exec

show logging level ntp

show logging level ntp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ntp	Show NTP logging settings.

Command Mode

- /exec

show logging level nxsdk

show logging level nxsdk

Syntax Description

show	Show running system information
logging	Modify message logging facilities
level	Facility parameter for syslog messages
nxsdk	NXOS SDK

Command Mode

- /exec

show logging level openflow

show logging level openflow

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
openflow	Show OpenFlow agent logging configuration

Command Mode

- /exec

show logging level ospf

show logging level ospf

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ospf	Show OSPF logging configuration

Command Mode

- /exec

show logging level ospfv3

show logging level ospfv3

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ospfv3	Display OSPFv3 status and configuration

Command Mode

- /exec

show logging level pfstat

show logging level pfstat

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
pfstat	Show pfstat logging configuration

Command Mode

- /exec

show logging level pim

show logging level [ip] pim

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ip	(Optional) Display IP information
pim	Show pim logging configuration

Command Mode

- /exec

show logging level pim

show logging level [ipv6] pim

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ipv6	(Optional) Display IPv6 information
pim	Show pim6 logging configuration

Command Mode

- /exec

show logging level pixm

show logging level pixm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
pixm	Show vdc-local-pixm logging configuration

Command Mode

- /exec

show logging level pktmgr

show logging level pktmgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
pktmgr	Show pktmgr logging configuration

Command Mode

- /exec

show logging level platform

show logging level platform

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
platform	Show platform logging configuration

Command Mode

- /exec

show logging level plbm

show logging level plbm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
plbm	Show plbm logging configuration

Command Mode

- /exec

show logging level plcmgr

show logging level plcmgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration

Command Mode

- /exec

show logging level pltfm_config

show logging level pltfm_config

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
pltfm_config	Show pltfm_config logging configuration

Command Mode

- /exec

show logging level plugin

show logging level plugin

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
plugin	Show plugin logging configuration

Command Mode

- /exec

show logging level poap

show logging level poap

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
poap	Show poap logging configuration

Command Mode

- /exec

show logging level poed

show logging level poed

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
poed	Show PoE Daemon Logging Configuration

Command Mode

- /exec

show logging level port-channel

show logging level port-channel

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
port-channel	Show port-channel logging configuration

Command Mode

- /exec

show logging level port-profile

show logging level port-profile

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
port-profile	Show syslog level for port-profile

Command Mode

- /exec

show logging level port-resources

show logging level port-resources

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
port-resources	Show port-resources logging configuration

Command Mode

- /exec

show logging level port-security

show logging level port-security

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
port-security	Show port-security logging configuration

Command Mode

- /exec

show logging level port

show logging level port

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
port	Show port logging configuration

Command Mode

- /exec

show logging level private-vlan

show logging level private-vlan

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
private-vlan	Show interface-vlan logging configuration

Command Mode

- /exec

show logging level ptp

show logging level ptp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ptp	Show ptp logging configuration

Command Mode

- /exec

show logging level radius

show logging level radius

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
radius	Show radius logging configuration

Command Mode

- /exec

show logging level res_mgr

show logging level res_mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
res_mgr	Show res_mgr logging configuration

Command Mode

- /exec

show logging level rip

show logging level rip

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
rip	Show RIP logging configuration

Command Mode

- /exec

show logging level routing ipv6 multicast

show logging level routing ipv6 multicast

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display multicast information

Command Mode

- /exec

show logging level routing multicast

show logging level routing [ip | ipv4] multicast

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information

Command Mode

- /exec

show logging level rpm

show logging level rpm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
rpm	Show RPM logging configuration

Command Mode

- /exec

show logging level rsvp

show logging level rsvp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
rsvp	Show RSVP logging configuration

Command Mode

- /exec

show logging level sal

show logging level sal

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
sal	Show SAL logging configuration

Command Mode

- /exec

show logging level san-port-channel

show logging level san-port-channel

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
san-port-channel	Show san-port-channel logging configuration

Command Mode

- /exec

show logging level san-port-channel

show logging level san-port-channel

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
san-port-channel	Show san-port-channel logging configuration

Command Mode

- /exec

show logging level scheduler

show logging level scheduler

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
scheduler	Show scheduler logging configuration

Command Mode

- /exec

show logging level security

show logging level security

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
security	Show security logging configuration

Command Mode

- /exec

show logging level session-mgr

show logging level session-mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
session-mgr	Show session-mgr logging configurarion

Command Mode

- /exec

show logging level sflow

show logging level sflow

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
sflow	Show sFlow logging configuration

Command Mode

- /exec

show logging level smartc

show logging level smartc

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
smartc	Show smartc logging configuration

Command Mode

- /exec

show logging level smm

show logging level smm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
smm	Show Shared Memory Manager logging configuration

Command Mode

- /exec

show logging level snmpd

show logging level snmpd

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
snmpd	Show SNMP logging configuration

Command Mode

- /exec

show logging level snmpmib_proc

show logging level snmpmib_proc

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
snmpmib_proc	Show snmpmib_proc logging configuration

Command Mode

- /exec

show logging level spanning-tree

show logging level spanning-tree

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
spanning-tree	Show spanning-tree logging configuration

Command Mode

- /exec

show logging level spm

show logging level spm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
spm	Show spm logging configuration

Command Mode

- /exec

show logging level stripcl

show logging level stripcl

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
stripcl	Show stripcl logging configuration

Command Mode

- /exec

show logging level sysmgr

show logging level sysmgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
sysmgr	Show sysmgr logging configuration

Command Mode

- /exec

show logging level tacacs

show logging level tacacs

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
tacacs	Show tacacs+ logging configuration

Command Mode

- /exec

show logging level track

show logging level track

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
track	Show track logging configuration

Command Mode

- /exec

show logging level tunnel

show logging level tunnel

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
tunnel	Show tunnel logging settings

Command Mode

- /exec

show logging level u2rib

show logging level u2rib

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
u2rib	Show U2RIB logging configuration

Command Mode

- /exec

show logging level u6rib

show logging level u6rib

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
u6rib	Show U6RIB logging configuration

Command Mode

- /exec

show logging level udd

show logging level udd

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
udd	Show udd logging configuration

Command Mode

- /exec

show logging level ufdm

show logging level ufdm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
ufdm	Show ufdm logging configuration

Command Mode

- /exec

show logging level urib

show logging level urib

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
urib	Show URIB logging configuration

Command Mode

- /exec

show logging level vdc_mgr

show logging level vdc_mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vdc_mgr	Show vdc manager logging configuration

Command Mode

- /exec

show logging level virtual-service

show logging level virtual-service

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
virtual-service	Show virtualization manager logging configuration

Command Mode

- /exec

show logging level vlan_mgr

show logging level vlan_mgr

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vlan_mgr	Show vlan manager logging configuration

Command Mode

- /exec

show logging level vmm

show logging level vmm

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vmm	Show vmm logging configuration

Command Mode

- /exec

show logging level vmtracker

show logging level vmtracker

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vmtracker	Show vmtracker logging configuration

Command Mode

- /exec

show logging level vpc

show logging level vpc

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vpc	Show vPC logging configuration

Command Mode

- /exec

show logging level vrrp-cfg

show logging level vrrp-cfg

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vrrp-cfg	Show vrrp-cfg logging configuration

Command Mode

- /exec

show logging level vrrp-eng

show logging level vrrp-eng

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vrrp-eng	Show vrrp-eng logging configuration

Command Mode

- /exec

show logging level vrrpv3

show logging level vrrpv3

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vrrpv3	level for vrrpv3 configuration

Command Mode

- /exec

show logging level vsan

show logging level vsan

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vsan	Show vsan logging configuration

Command Mode

- /exec

show logging level vshd

show logging level vshd

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration

Command Mode

- /exec

show logging level vtp

show logging level vtp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
vtp	Show vtp logging configuration

Command Mode

- /exec

show logging level wwn

show logging level wwn

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration
wwn	Show wwn logging configuration

Command Mode

- /exec

show logging level xbar

show logging level xbar

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
level	Show facility logging configuration

Command Mode

- /exec

show logging logfile

show logging logfile

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
logfile	Show contents of logfile

Command Mode

- /exec

show logging logfile duration

show logging logfile duration <s1>

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
logfile	Show contents of logfile
duration	show messages from logfile of last given duration
<i>s1</i>	Enter hour, minutes, seconds of duration as HH:MM:SS

Command Mode

- /exec

show logging logfile last-index

show logging logfile last-index

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
logfile	Show contents of logfile
last-index	Show the sequence-number of the last message in logfile

Command Mode

- /exec

show logging logfile start-seqn

show logging logfile start-seqn <i0> [end-seqn <i1>]

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
logfile	Show contents of logfile
start-seqn	Show messages from logfile from a given start-sequence-number
<i>i0</i>	Enter starting sequence number
end-seqn	(Optional) Show messages from logfile from a given end-sequence-number
<i>i1</i>	(Optional) Enter ending sequence number

Command Mode

- /exec

show logging logfile start-time

show logging logfile start-time <i0> <s0> <i1> <s1> [end-time <i2> <s2> <i3> <s3>]

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
logfile	Show contents of logfile
start-time	Show messages from logfile from a given start-time
<i>i0</i>	Enter year in YYYY format
<i>s0</i>	Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>i1</i>	Enter day of month in dd format
<i>s1</i>	Enter hour, minutes, seconds as HH:MM:SS
end-time	(Optional) Show messages from logfile up to a given end-time
<i>i2</i>	(Optional) Enter year in YYYY format
<i>s2</i>	(Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec
<i>i3</i>	(Optional) Enter day of month in dd format
<i>s3</i>	(Optional) Enter hour, minutes, seconds as HH:MM:SS

Command Mode

- /exec

show logging loopback

show logging loopback

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
loopback	Show logging loopback configuration

Command Mode

- /exec

show logging module

show logging module

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
module	Show module(linecard) logging configuration

Command Mode

- /exec

show logging monitor

show logging monitor

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
monitor	Show monitor logging configuration

Command Mode

- /exec

show logging nvram

```
show logging nvram [ [ { last <i0> } ] [ __readonly__ [ <error> ] [ { TABLE_nvram <log> } ] ] ]
```

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
nvram	Show NVRAM log
last	(Optional) Show last few lines of nvram log
<i>i0</i>	(Optional) Enter number of lines to display
__readonly__	(Optional)
<i>error</i>	(Optional) error message
TABLE_nvram	(Optional) nvram log prints
<i>log</i>	(Optional) single log line

Command Mode

- /exec

show logging onboard

```
show logging onboard { counter-stats | endtime <s0> [ { counter-stats | internal { <dc3_options> } } ] | internal
{ <dc3_options> } | module <module> { counter-stats | endtime1 <s1> [ { counter-stats | internal {
<dc3_options> } } ] | internal { <dc3_options> } | starttime <s2> [ { counter-stats | endtime2 <s3> [ {
counter-stats | internal { <dc3_options> } } ] | internal { <dc3_options> } } ] | starttime1 <s4> [ { counter-stats
| endtime3 <s5> [ { counter-stats | internal { <dc3_options> } } ] | internal { <dc3_options> } } ] }
```

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
onboard	Show OBFL information
counter-stats	Show OBFL counter statistics
endtime	Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s0</i>	End time format - mm/dd/yy-HH:MM:SS
internal	(Optional) Show Logging Onboard Internal
module	Show OBFL information for Module
<i>module</i>	Enter module number
endtime1	Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s1</i>	End time format - mm/dd/yy-HH:MM:SS
starttime	Show OBFL logs from start time mm/dd/yy-HH:MM:SS
<i>s2</i>	Start time format - mm/dd/yy-HH:MM:SS
endtime2	(Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s3</i>	(Optional) End time format - mm/dd/yy-HH:MM:SS
starttime1	Show OBFL logs from start time mm/dd/yy-HH:MM:SS
<i>s4</i>	Start time format - mm/dd/yy-HH:MM:SS
endtime3	(Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s5</i>	(Optional) End time format - mm/dd/yy-HH:MM:SS
<i>dc3_options</i>	(Optional) dc3 options

Command Mode

- /exec

show logging onboard

```
show logging onboard [ card-first-power-on | card-boot-history | <common_options> | endtime <s0> [ {
<common_options> | error-stats [ port <i0> ] } ] | error-stats [ port1 <i1> ] | module <module> [
<common_options> | endtime1 <s1> [ { <common_options> | error-stats [ port3 <i3> ] } ] | error-stats [ port4
<i4> ] | starttime <s2> [ { <common_options> | endtime2 <s3> [ { <common_options> | error-stats [ port6
<i6> ] } ] | error-stats [ port7 <i7> ] } ] | card-first-power-on | card-boot-history ] | obfl-logs | starttime1 <s4>
[ { <common_options> | endtime3 <s5> [ { <common_options> | error-stats [ port8 <i8> ] } ] | error-stats [
port9 <i9> ] } ] | credit-loss [ module <module> [ last <last_no> { minutes | hours | days } ] | last <last_no>
{ minutes | hours | days } ] | flow-control { pause-count [ module <module> [ last <last_no> { minutes | hours
| days } ] | last <last_no> { minutes | hours | days } ] | pause-events [ module <module> [ last <last_no> {
minutes | hours | days } ] | last <last_no> { minutes | hours | days } ] | request-timeout [ module <module> ]
| timeout-drops [ module <module> [ port10 <i10> [ last <last_no> { minutes | hours | days } ] | last <last_no>
{ minutes | hours | days } ] | last <last_no> { minutes | hours | days } } ] }
```

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
onboard	Show OBFL information
card-first-power-on	(Optional) show card first power on information
card-boot-history	(Optional) show card boot history
endtime	(Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s0</i>	(Optional) End time format - mm/dd/yy-HH:MM:SS
error-stats	(Optional) Show OBFL error statistics
port	(Optional) Show OBFL error statistics for a port
<i>i0</i>	(Optional)
<i>common_options</i>	(Optional) give the options
port1	(Optional) Show OBFL error statistics for a port
<i>i1</i>	(Optional)
module	(Optional) Show OBFL information for Module
<i>module</i>	(Optional) Enter module number
endtime1	(Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s1</i>	(Optional) End time format - mm/dd/yy-HH:MM:SS
port3	(Optional) Show OBFL error statistics for a port
<i>i3</i>	(Optional)

port4	(Optional) Show OBFL error statistics for a port
<i>i4</i>	(Optional)
starttime	(Optional) Show OBFL logs from start time mm/dd/yy-HH:MM:SS
<i>s2</i>	(Optional) Start time format - mm/dd/yy-HH:MM:SS
endtime2	(Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s3</i>	(Optional) End time format - mm/dd/yy-HH:MM:SS
port6	(Optional) Show OBFL error statistics for a port
<i>i6</i>	(Optional)
port7	(Optional) Show OBFL error statistics for a port
<i>i7</i>	(Optional)
starttime1	(Optional) Show OBFL logs from start time mm/dd/yy-HH:MM:SS
<i>s4</i>	(Optional) Start time format - mm/dd/yy-HH:MM:SS
endtime3	(Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS
<i>s5</i>	(Optional) End time format - mm/dd/yy-HH:MM:SS
port8	(Optional) Show OBFL error statistics for a port
<i>i8</i>	(Optional)
port9	(Optional) Show OBFL error statistics for a port
<i>i9</i>	(Optional)
obfl-logs	(Optional) Show OBFL Tech Support Log.
timeout-drops	(Optional) Show OBFL Timeout Drops logs
port10	(Optional) Show OBFL statistics per port basis
<i>i10</i>	(Optional)
credit-loss	(Optional) Show OBFL Credit Loss logs
last	(Optional) Show last min/hour/day logs
<i>last_no</i>	(Optional) Duration in min/hrs/day
minutes	(Optional) entry in minutes
hours	(Optional) entry in hours
days	(Optional) entry in days
request-timeout	(Optional) Show OBFL request timeout log

flow-control	(Optional) Show OBFL Flow Control log
pause-count	(Optional) Show Flow Control Pause Count Logs
pause-events	(Optional) Show Flow Control Pause Event Logs

Command Mode

- /exec

show logging onboard kernel-trace

show logging onboard kernel-trace

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
onboard	Show OBFL information
kernel-trace	Show OBFL Kernel Trace

Command Mode

- /exec

show logging origin-id

show logging origin-id

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
origin-id	Show logging origin id configuration

Command Mode

- /exec

show logging pending-diff

show logging pending-diff

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
pending-diff	server address pending configuration diff

Command Mode

- /exec

show logging pending

show logging pending

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
pending	server address pending configuration

Command Mode

- /exec

show logging rate-limit

show logging rate-limit

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
rate-limit	Show rate limit configuration

Command Mode

- /exec

show logging server

```
show logging server [ __readonly__ [ <noentry> ] [ { TABLE_logserv <server> <forwarding> <severity>
<facility> <vrf> <port> [ <transport> ] } ] ]
```

Syntax Description

<code>show</code>	Show running system information
<code>logging</code>	Show logging configuration and contents of logfile
<code>server</code>	Show server logging configuration
<code>__readonly__</code>	(Optional)
<code>noentry</code>	(Optional) logging server not configured
<code>TABLE_logserv</code>	(Optional) output of show logging server
<code>server</code>	(Optional) remote server address
<code>forwarding</code>	(Optional) remote server forwarding
<code>severity</code>	(Optional) remote server severity
<code>facility</code>	(Optional) remote server facility
<code>vrf</code>	(Optional) remote server vrf
<code>port</code>	(Optional) remote server port
<code>transport</code>	(Optional) remote server transport

Command Mode

- /exec

show logging session status

show logging session status

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
session	Show logging session status
status	Show logging session status

Command Mode

- /exec

show logging source-interface

show logging source-interface

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
source-interface	Show logging source-interface configuration

Command Mode

- /exec

show logging status

show logging status

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
status	Show logging status

Command Mode

- /exec

show logging timestamp

show logging timestamp

Syntax Description

show	Show running system information
logging	Show logging configuration and contents of logfile
timestamp	Show logging timestamp configuration

Command Mode

- /exec

show login on-failure log

show login on-failure log [__readonly__ [<status>]]

Syntax Description

show	show
login	login
on-failure	authentication failure
log	Log
__readonly__	(Optional)
<i>status</i>	(Optional) login on failure log enabled or disabled

Command Mode

- /exec

show login on-successful log

show login on-successful log [__readonly__ [<status>]]

Syntax Description

show	show
login	login
on-successful	authentication successful
log	Log
__readonly__	(Optional)
<i>status</i>	(Optional) login on successful log enabled or disabled

Command Mode

- /exec

show login on-successful log



M Show Commands

- [show mac-list](#), on page 1752
- [show mac address-table](#), on page 1753
- [show mac address-table](#), on page 1755
- [show mac address-table aging-time](#), on page 1757
- [show mac address-table count](#), on page 1758
- [show mac address-table count es](#), on page 1760
- [show mac address-table learning-mode](#), on page 1761
- [show mac address-table limit](#), on page 1762
- [show mac address-table loop-detect](#), on page 1763
- [show mac address-table multicast](#), on page 1764
- [show mac address-table notification mac-move](#), on page 1765
- [show maintenance maint-delay](#), on page 1766
- [show maintenance on-reload reset-reasons](#), on page 1767
- [show maintenance profile](#), on page 1768
- [show maintenance snapshot-delay](#), on page 1769
- [show maintenance timeout](#), on page 1770
- [show module](#), on page 1771
- [show module bandwidth-fairness](#), on page 1774
- [show module uptime](#), on page 1775
- [show monitor](#), on page 1776
- [show monitor session](#), on page 1777
- [show mvpn bgp mdt](#), on page 1780
- [show mvpn mdt encap](#), on page 1781
- [show mvpn mdt route](#), on page 1782
- [show mvr](#), on page 1783
- [show mvr groups](#), on page 1784
- [show mvr interface](#), on page 1785
- [show mvr members](#), on page 1786
- [show mvr members count](#), on page 1787
- [show mvr members vlan](#), on page 1788
- [show mvr receiver-ports](#), on page 1789
- [show mvr source-ports](#), on page 1790

show mac-list

```
show mac-list { [ <mac_list_name> [ { seq <seq_no> | { <mac_addr> [ <mac_mask> } ] } ] ] [ __readonly__
TABLE_mac_list <name> <seq> <action> <rule> ]
```

Syntax Description

show	Show running system information
mac-list	Show mac-lists
<i>mac_list_name</i>	(Optional) Name of mac list
seq	(Optional) Sequence number
<i>seq_no</i>	(Optional) Sequence number
<i>mac_addr</i>	(Optional) MAC address
<i>mac_mask</i>	(Optional) MAC mask
<i>__readonly__</i>	(Optional)
TABLE_mac_list	(Optional)
<i>name</i>	(Optional)
<i>seq</i>	(Optional)
<i>action</i>	(Optional)
<i>rule</i>	(Optional)

Command Mode

- /exec

show mac address-table

```
show mac address-table <module> [ count ] [ static | dynamic | secure ] [ { [ address1 <mac-addr> | switch-id
<swid> [ sub-switch-id <sswid> ] } | vlan1 <id> | [ vdc1 <vdc> | <e-vdc> ] | fe1 <feid> ] + } | { [ address
<mac-addr> | interface <interface-name> | vlan <id> | [ vdc <vdc> | <e-vdc> ] | fe <feid> ] + } ] [ hex ] [
__readonly__ <entrycount> <l2entry> <header> <pi_e> <age> <rm> <ifname> <sec> <ntfy> <type> ]
```

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
<i>module</i>	Module Number
count	(Optional) Number of entries
static	(Optional) Display Static Entries
dynamic	(Optional) Display Dynamic Entries
secure	(Optional) Display Secure Entries
address	(Optional) address
address1	(Optional) address
<i>mac-addr</i>	(Optional) MAC Address
switch-id	(Optional) Remote Switch ID
<i>swid</i>	(Optional) Switch ID
sub-switch-id	(Optional) Remote Sub Switch ID
<i>sswid</i>	(Optional) Sub Switch ID
interface	(Optional) Interface
<i>interface-name</i>	(Optional) Interface name
vlan	(Optional) VLAN
vlan1	(Optional) VLAN
<i>id</i>	(Optional) VLAN ID
vdc	(Optional) VDC ID or Name
vdc1	(Optional) VDC ID or Name
<i>vdc</i>	(Optional) VDC ID

<i>e-vdc</i>	(Optional) Select VDC ID that match VDC Name
<i>fe</i>	(Optional) Forwarding Engine Instance ID(Zero based)
<i>fel</i>	(Optional) Forwarding Engine Instance ID(Zero based)
<i>feid</i>	(Optional) FE ID value
<i>hex</i>	(Optional) display swid/sswid/lid in hex
<i>__readonly__</i>	(Optional)
<i>header</i>	(Optional) Header
<i>pi_e</i>	(Optional) Primary Interface of EARL
<i>age</i>	(Optional) Last seen age in seconds
<i>rm</i>	(Optional) RM
<i>ifname</i>	(Optional) interface name as string
<i>sec</i>	(Optional) secure
<i>ntfy</i>	(Optional) notify
<i>entrycount</i>	(Optional) Number of L2 entries
<i>l2entry</i>	(Optional) L2 Entry String
<i>type</i>	(Optional) MAC type - Static or Dynamic

Command Mode

- /exec

show mac address-table

```
show mac address-table [ static | dynamic | secure ] [ local ] [ { [ address1 <mac-addr> | { switch-id <swid>
[ sub-switch-id <sswid> ] } | vlan1 <id> ] + } | { [ address <mac-addr> | interface <interface-name> | vlan
<id> ] + } | { [ address2 <mac-addr> | interface1 <interface-name> | vni <vni-id> | peer-ip <peer-ipv4> ] + }
| { [ address3 <mac-addr> | interface2 <interface-name> | vni1 <vni-id> | es { <esid-opt1> | <esid-opt2> | all
} ] + } ] [ _readonly_ [ { TABLE_mac_address <disp_mac_addr><disp_type><disp_vlan> [ <disp_is_static>
] <disp_age><disp_is_secure><disp_is_ntfy><disp_port> } ] ]
```

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
static	(Optional) Display Static Entries
dynamic	(Optional) Display Dynamic Entries
secure	(Optional) Display Secure Entries
local	(Optional) Display MAC Entries Learned Locally and Not on the Overlay/VXLAN
address	(Optional) address
address1	(Optional) address
address2	(Optional) address
address3	(Optional) address
<i>mac-addr</i>	(Optional) MAC Address
switch-id	(Optional) Remote Switch ID
<i>swid</i>	(Optional) Switch ID
sub-switch-id	(Optional) Remote Sub Switch ID
<i>sswid</i>	(Optional) Sub Switch ID
interface	(Optional) Interface
interface1	(Optional) Interface
<i>interface-name</i>	(Optional) Interface name
interface2	(Optional) Interface
<i>interface-name</i>	(Optional) Interface name
vlan	(Optional) VLAN

vlan1	(Optional) VLAN
<i>id</i>	(Optional) VLAN ID
vni	(Optional) VXLAN Network Identifier
vni1	(Optional) VXLAN Network Identifier
<i>vni-id</i>	(Optional) VXLAN Network Identifier
peer-ip	(Optional) VXLAN Peer IP Address
<i>peer-ipv4</i>	(Optional) VXLAN Peer IP Address
es	(Optional) EVPN Remote ESID
<i>esid-opt1</i>	(Optional) EE:EE:EE:EE:EE:EE:EE:EE:EE:EE ESID Option 1
<i>esid-opt2</i>	(Optional) EEEE.EEEE.EEEE.EEEE.EEEE ESID Option 2
all	(Optional) all ESIs
__readonly__	(Optional)
TABLE_mac_address	(Optional) Mac address table
<i>disp_is_static</i>	(Optional) Static/Dynamic

Command Mode

- /exec

show mac address-table aging-time

show mac address-table aging-time [*__readonly__* <age_str> <age>]

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
aging-time	Configured/default age
<i>__readonly__</i>	(Optional)
<i>age_str</i>	(Optional) Age info
<i>age</i>	(Optional) Age time

Command Mode

- /exec

show mac address-table count

```
show mac address-table count [ static | dynamic | secure ] [ local ] [ { [ interface <interface-name> | { switch-id
<swid> [ sub-switch-id <sswid> ] } | vlan <id> ] + } ] | { [ interface1 <interface-name> | vni <vni-id> | peer-ip
<peer-ipv4> ] + } ] [ __readonly__ TABLE-macaddtblcount [ <id-out> ] [ <count_str> ] [ <total_cnt> ] [
<dyn_cnt> ] [ <otv_cnt> ] [ <static_cnt> ] [ <secure_cnt> ] ]
```

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
count	Number of MAC entries
static	(Optional) Display Static Entries
dynamic	(Optional) Display Dynamic Entries
secure	(Optional) Display Secure Entries
local	(Optional) Display MAC Entries Learned Locally and Not on the Overlay/VXLAN
vlan	(Optional) VLAN
<i>id</i>	(Optional) VLAN ID
interface	(Optional) Interface
interface1	(Optional) Interface
<i>interface-name</i>	(Optional) Interface name
switch-id	(Optional) Remote Switch ID
<i>swid</i>	(Optional) Switch ID
sub-switch-id	(Optional) Remote Sub Switch ID
<i>sswid</i>	(Optional) Sub Switch ID
vni	(Optional) VXLAN Network Identifier
<i>vni-id</i>	(Optional) VXLAN Network Identifier
peer-ip	(Optional) VXLAN Peer IP Address
<i>peer-ipv4</i>	(Optional) VXLAN Peer IP Address
__readonly__	(Optional)
TABLE-macaddtblcount	(Optional) MAC Address Dynamic Count Table

<i>id-out</i>	(Optional) MAC Address Table VLAN ID
<i>count_str</i>	(Optional) Count info
<i>total_cnt</i>	(Optional) Total count
<i>dyn_cnt</i>	(Optional) Dynamic count
<i>otv_cnt</i>	(Optional) OTV count
<i>static_cnt</i>	(Optional) Static count
<i>secure_cnt</i>	(Optional) Secure count

Command Mode

- /exec

show mac address-table count es

show mac address-table count es { <es-id> | <es-id2> | all }

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
count	Number of MAC entries
es	EVPN Remote ESID
<i>es-id</i>	EE:EE:EE:EE:EE:EE:EE:EE:EE ESID
<i>es-id2</i>	EEEE.EEEE.EEEE.EEEE.EEEE ESID
all	all ESIs

Command Mode

- /exec

show mac address-table learning-mode

```
show mac address-table learning-mode [ vlan <id> ] [ __readonly__ <learning_mode_str> <vlan_id>
<mode_str> ]
```

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
learning-mode	Learning Mode
vlan	(Optional) VLAN
<i>id</i>	(Optional) VLAN ID
<i>__readonly__</i>	(Optional)
<i>learning_mode_str</i>	(Optional) Learning Mode
<i>vlan_id</i>	(Optional) VLAN ID
<i>mode_str</i>	(Optional) Mode

Command Mode

- /exec

show mac address-table limit

show mac address-table limit [__readonly__ <limit_str> <limit>]

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
limit	Configured/default mac limit
__readonly__	(Optional)
<i>limit_str</i>	(Optional) Limit info
<i>limit</i>	(Optional) Mac limit

Command Mode

- /exec

show mac address-table loop-detect

show mac address-table loop-detect

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
loop-detect	Display Action for Mac Loop Detection

Command Mode

- /exec

show mac address-table multicast

```
show mac address-table multicast [ vlan <vlan> | bridge-domain <bdid> ] [ __readonly__ [ TABLE_mac [
<vlan-id> ] [ <mac-addr> ] [ <type> ] [ <age> ] [ TABLE_oif [ <oifs> ] ] ] ] ]
```

Syntax Description

show	Show running system information
mac	MAC configuration commands
address-table	MAC Address Table
multicast	mcast mac OIF Static Entry
vlan	(Optional) VLAN
<i>vlan</i>	(Optional) VLAN
bridge-domain	(Optional) BD
<i>bdid</i>	(Optional) BD
<i>__readonly__</i>	(Optional)
TABLE_mac	(Optional)
<i>vlan-id</i>	(Optional)
<i>mac-addr</i>	(Optional)
<i>type</i>	(Optional)
<i>age</i>	(Optional)
TABLE_oif	(Optional)
<i>oifs</i>	(Optional)

Command Mode

- /exec

show mac address-table notification mac-move

```
show mac address-table notification mac-move [ __readonly__ TABLE_mac_notif <disp_mm_status>
<disp_mm_triggers> <disp_macs_added> <disp_macs_moved> <disp_macs_removed> ]
```

Syntax Description

show	show
mac	MAC configuration commands
address-table	MAC Address Table
notification	Display Notification Information
mac-move	Mac Move Notification
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_mac_notif</i>	(Optional) Mac address notification table
<i>disp_mm_status</i>	(Optional) Mac Move Status
<i>disp_mm_triggers</i>	(Optional) # of triggers
<i>disp_macs_added</i>	(Optional) Number of MACs added since system bring up
<i>disp_macs_removed</i>	(Optional) Number of MACs removed since system bring up
<i>disp_macs_moved</i>	(Optional) Number of MACs moved since system bring up

Command Mode

- /exec

show maintenance maint-delay

show maintenance maint-delay [__readonly__ <delay>]

Syntax Description

show	Show running system information
maintenance	maintenance
maint-delay	maintenance mode CLI release delay value
__readonly__	(Optional)
<i>delay</i>	(Optional) delay value in seconds

Command Mode

- /exec

show maintenance on-reload reset-reasons

```
show maintenance on-reload reset-reasons [ __readonly__ [ TABLE_reset_reason <reset_reason> ] <rr_bitmap> ]
```

Syntax Description

show	Show running system information
maintenance	maintenance
on-reload	on reload maintenance mode configuration
reset-reasons	system reset reasons
<i>__readonly__</i>	(Optional)
<i>TABLE_reset_reason</i>	(Optional)
<i>rr_bitmap</i>	(Optional) reset reason bitmap
<i>reset_reason</i>	(Optional) system reset reason

Command Mode

- /exec

show maintenance profile

show maintenance profile [<mode>] [__readonly__ TABLE_profile <name> [TABLE_cfg <cfg>]]

Syntax Description

show	Show running system information
maintenance	maintenance
profile	maintenance profile
<i>mode</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_profile	(Optional)
<i>name</i>	(Optional) profile name
TABLE_cfg	(Optional)
<i>cfg</i>	(Optional) profile config

Command Mode

- /exec

show maintenance snapshot-delay

show maintenance snapshot-delay [__readonly__ <delay>]

Syntax Description

show	Show running system information
maintenance	maintenance
snapshot-delay	after_maintenance snapshot delay value
__readonly__	(Optional)
<i>delay</i>	(Optional) delay value in seconds

Command Mode

- /exec

show maintenance timeout

show maintenance timeout [__readonly__ <timeout>]

Syntax Description

show	Show running system information
maintenance	maintenance
timeout	timeout value
__readonly__	(Optional)
<i>timeout</i>	(Optional) timeout value

Command Mode

- /exec

show module

```
show module [ { <module> } | { <s0> [ <santa-cruz-range> ] } | { fabric [ <module> ] } ] [ __readonly__ {
TABLE_modinfo <modinf> <ports> <modtype> <model> <status> } [ { TABLE_modpwrinfo <modpwr>
<pwrstat> <reason> } ] { TABLE_modwwninfo <modwwn> <sw> <hw> <slottype> } [ { TABLE_modapplinfo
<modappl> <desc> <applver> } ] { TABLE_modmacinfo <modmac> <mac> <serialnum> } {
TABLE_moddiaginfo <mod> <diagstatus> } [ { TABLE_modinfo <modinf> <ports> <modtype> <model>
<status> } [ { TABLE_modpwrinfo <modpwr> <pwrstat> <reason> } ] { TABLE_modwwninfo <modwwn>
<sw> <hw> <slottype> } [ { TABLE_modapplinfo <modappl> <desc> <applver> } ] { TABLE_modmacinfo
<modmac> <mac> <serialnum> } { TABLE_moddiaginfo <mod> <diagstatus> } ] [ { TABLE_xbarinfo
<xbarinf> <xbarports> <xbartype> <xbarmodel> <xbarstatus> } ] [ { TABLE_xbarpwrinfo <xbarpwr>
<xbarpwrstat> <xbarreason> } ] [ { TABLE_xbarwwninfo <xbarwwn> <xbarsw> <xbarhw> <xbarwwnstr>
} ] [ { TABLE_xbarmacinfo <xbarmac> <xbarmacaddr> <xbarserialnum> } ] ] ]
```

Syntax Description

show	Show running system information
module	Show module information
<i>module</i>	(Optional) Enter module number
<i>s0</i>	(Optional) Show xbar information
<i>santa-cruz-range</i>	(Optional) please enter the xbar number
fabric	(Optional) Show fabric information
__readonly__	(Optional)
TABLE_modinfo	(Optional) Show Module info
<i>modinf</i>	(Optional) Module
<i>ports</i>	(Optional) Num Ports
<i>modtype</i>	(Optional) Module Type
<i>model</i>	(Optional) Model
<i>status</i>	(Optional) Status
TABLE_modpwrinfo	(Optional) Mod Pwr Info
<i>modpwr</i>	(Optional) Module
<i>pwrstat</i>	(Optional) Power Status
<i>reason</i>	(Optional) Reason
TABLE_modwwninfo	(Optional) Mod WWN Info
<i>modwwn</i>	(Optional) Module

<i>sw</i>	(Optional) SW Ver
<i>hw</i>	(Optional) HW Ver
<i>slottype</i>	(Optional) Slot
TABLE_modapplinfo	(Optional) Mod Appl image info
<i>modappl</i>	(Optional) Module
<i>desc</i>	(Optional) Image desc
<i>applver</i>	(Optional) Version
TABLE_modmacinfo	(Optional) Mod MAC Info
<i>modmac</i>	(Optional) Module
<i>mac</i>	(Optional) MAC
<i>serialnum</i>	(Optional) Serial Num
TABLE_moddiaginfo	(Optional) Mod diag info
<i>mod</i>	(Optional) Module
<i>diagstatus</i>	(Optional) Diag status
TABLE_xbarinfo	(Optional) Show xbar info
<i>xbarinf</i>	(Optional) Module
<i>xbarports</i>	(Optional) Num Ports
<i>xbartype</i>	(Optional) Module Type
<i>xbarmodel</i>	(Optional) Model
<i>xbarstatus</i>	(Optional) Status
TABLE_xbarpwrinfo	(Optional) Xbar Pwr Info
<i>xbarpwr</i>	(Optional) Module
<i>xbarpwrstat</i>	(Optional) Power Status
<i>xbarreason</i>	(Optional) Reason
TABLE_xbarwwninfo	(Optional) Xbar WWN Info
<i>xbarwwn</i>	(Optional) Module
<i>xbarsw</i>	(Optional) SW Ver
<i>xbarhw</i>	(Optional) HW Ver
<i>xbarwwnstr</i>	(Optional) WWN

TABLE_xbarmacinfo	(Optional) Xbar MAC Info
<i>xbarmac</i>	(Optional) Module
<i>xbarmacaddr</i>	(Optional) MAC
<i>xbarserialnum</i>	(Optional) Serial Num

Command Mode

- /exec

show module bandwidth-fairness

show module <module> bandwidth-fairness [__readonly__ { TABLE_fairness <statement> }]

Syntax Description

show	Show running system information
module	Show module information
<i>module</i>	Enter module number
bandwidth-fairness	Show bandwidth fairness status
__readonly__	(Optional)
TABLE_fairness	(Optional)
<i>statement</i>	(Optional)

Command Mode

- /exec

show module uptime

```
show module uptime [ __readonly__ { TABLE_uptimeinf <slot> <starttime> <daysup> <hoursup> <minutesup> <secondsup> } ]
```

Syntax Description

show	Show running system information
module	Show module information
uptime	Show how long the module has been up and running
__readonly__	(Optional)
TABLE_uptimeinf	(Optional) Show uptime info
<i>slot</i>	(Optional) Slot
<i>starttime</i>	(Optional) Start Time
<i>daysup</i>	(Optional) Days Up
<i>hoursup</i>	(Optional) Hours Up
<i>minutesup</i>	(Optional) Minutes Up
<i>secondsup</i>	(Optional) Seconds Up

Command Mode

- /exec

show monitor

show monitor [*__readonly__* *TABLE_session* <session_number> <state> <state_reason> <description>]

Syntax Description

show	Show running system information
monitor	Show Ethernet SPAN information
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_session</i>	(Optional) show monitor
<i>session_number</i>	(Optional) session id
<i>state</i>	(Optional) State
<i>state_reason</i>	(Optional) State reason
<i>description</i>	(Optional) Session Description

Command Mode

- /exec

show monitor session

```
show monitor session { all | <session_number> | warp | range <session_range> } [ brief ] [ __readonly__ [
TABLE_session <session_number> [ <description> ] [ <type> ] [ <version> ] [ <state> ] [ <state_reason> ]
[ <err_desc> ] [ <flow_id> ] [ <switch_id> ] [ <erspan_granularity> ] [ <vrf_name> ] [ <acl_name> ] [
<erspan_ttl> ] [ <erspan_dscp> ] [ <header_type> ] [ <span_mtu> ] [ <span_sampling> ] [ <ip_filter> ] + [
<dst_ip> ] [ <origin_ip> ] [ <src_ip> ] [ <control_pkt_filter> ] [ TABLE_sources_rx [ <sources_rx> ] ] [
TABLE_sources_tx [ <sources_tx> ] ] [ TABLE_sources_both [ <sources_both> ] ] [ <source_vlans_rx> ] [
<source_vlans_tx> ] [ <source_vlans_both> ] [ <source_vsans_rx> ] [ <tree-id> <switchid> ] + [ <filter_vlans>
] [ <destinations> ] + [ <acl_destinations> ] + [ <rate_limit_cap> ] + [ <mtu_capability> ] + [
<sampling_capability> ] + [ <mcbe> ] + [ <l3_egress_span> ] + [ <erspan_acl> ] + [ <erspan_v3_cap> ] + [
<erspan_v2_cap> ] + [ <erspan_gran_cap> ] + [ <fex_ingress_intf> ] + [ <sources_rx_2> ] + [
<marker_time_intv> ] [ <marker_pkt_count> ] [ <marker_pkt_fail> ] [ <erspan_egress_if> ] ] ]
```

Syntax Description

show	Show running system information
monitor	Show Ethernet SPAN information
session	Show session info
all	All sessions
<i>session_number</i>	
warp	warp session
range	Specify a range
<i>session_range</i>	
brief	(Optional) Brief information
__readonly__	(Optional) Read only
TABLE_session	(Optional) show monitor
<i>session_number</i>	(Optional) session number
<i>description</i>	(Optional) Session Description
<i>type</i>	(Optional) Session type
<i>version</i>	(Optional) Erspan source version: v2/v3
<i>state</i>	(Optional) State
<i>state_reason</i>	(Optional) State reason
<i>err_desc</i>	(Optional) Error Description
<i>flow_id</i>	(Optional) erspan-id

<i>switch_id</i>	(Optional) erspan_switch-id
<i>erspan_granularity</i>	(Optional) ERSPAN Type III Granularity
<i>vrf_name</i>	(Optional) ERSPAN session VRF
<i>acl_name</i>	(Optional) ERSPAN session ACL
<i>erspan_ttl</i>	(Optional) ERSPAN TTL Value
<i>erspan_dscp</i>	(Optional) ERSPAN DSCP Value
<i>header_type</i>	(Optional) ERSPAN Header Type
<i>span_mtu</i>	(Optional) SPAN MTU value
<i>span_sampling</i>	(Optional) SPAN sampling range
<i>ip_filter</i>	(Optional) IP filter value
<i>dst_ip</i>	(Optional) ERSPAN destination IP
<i>origin_ip</i>	(Optional) ERSPAN origin IP at source router
<i>src_ip</i>	(Optional) ERSPAN source IP
<i>control_pkt_filter</i>	(Optional) Control packet filter value
TABLE_sources_rx	(Optional) ingress intf table
<i>sources_rx</i>	(Optional) List of ingress sources
TABLE_sources_tx	(Optional) egress intf table
<i>sources_tx</i>	(Optional) List of egress sources
TABLE_sources_both	(Optional) bi-direction intf table
<i>sources_both</i>	(Optional) List of sources in both directions
<i>source_vlans_rx</i>	(Optional) Source ingress vlan
<i>source_vsans_rx</i>	(Optional) Source ingress vsan
<i>source_vlans_tx</i>	(Optional) Source egress vlan
<i>source_vlans_both</i>	(Optional) Source vlans in both directions
<i>tree-id</i>	(Optional) proxy layer2 gateway source tree-id
<i>switchid</i>	(Optional) proxy layer2 gateway source switchid
<i>filter_vlans</i>	(Optional) Filter vlans
<i>destinations</i>	(Optional) List of destinations
<i>acl_destinations</i>	(Optional) List of interfaces that wont work for acl capture

<i>rate_limit_cap</i>	(Optional) List of modules that support Rate Limit
<i>mtu_capability</i>	(Optional) List of modules that support MTU
<i>sampling_capability</i>	(Optional) List of modules that support Sampling
<i>mcbe</i>	(Optional) List all modules that support multicast best effort
<i>l3_egress_span</i>	(Optional) List of modules that support L3 Multicast Egress SPAN
<i>erspan_acl</i>	(Optional) List of modules that support ERSPAN ACL filtering
<i>erspan_v3_cap</i>	(Optional) List of modules that support erspan version3
<i>erspan_v2_cap</i>	(Optional) List of modules that support erspan version2
<i>erspan_gran_cap</i>	(Optional) List of modules that support the granularity set
<i>fex_ingress_intf</i>	(Optional) List of fex interfaces that wont work for ingress span
<i>erspan_egress_if</i>	(Optional) Egress interface for ERSPAN SRC session
<i>sources_rx_2</i>	(Optional) List of ingress sources
<i>marker_time_intv</i>	(Optional) Marker packet interval
<i>marker_pkt_count</i>	(Optional) Marker packet count
<i>marker_pkt_fail</i>	(Optional) Marker packet fail count

Command Mode

- /exec

show mvpn bgp mdt

```
show mvpn bgp { mdt-safi | auto-discovery } [ mdt-source <src-addr> ] [ __readonly__ { TABLE_entry
<bgp_rd> <mdt_src> <mdt_grp> <local> } ]
```

Syntax Description

show	Show running system information
mvpn	Display Multicast VPN information
bgp	Display BGP related information
mdt-safi	Display Auto-discovered BGP MDT-SAFI database
auto-discovery	Display Auto-discovered BGP MDT-SAFI database
mdt-source	(Optional) Source address of MVPN neighbor
<i>src-addr</i>	(Optional) Source Address
<i>__readonly__</i>	(Optional)
TABLE_entry	(Optional)
<i>bgp_rd</i>	(Optional)
<i>mdt_src</i>	(Optional)
<i>mdt_grp</i>	(Optional)
<i>local</i>	(Optional)

Command Mode

- /exec

show mvpn mdt encap

```
show mvpn mdt encap [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<out_context> { TABLE_encap <encap_index> <mdt_grp> <mdt_src> <mdt_src_if> } ]
```

Syntax Description

show	Show running system information
mvpn	Display Multicast VPN information
mdt	Display MDT information
encap	Display MDT Encap table
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>out_context</i>	(Optional)
<i>TABLE_encap</i>	(Optional)
<i>encap_index</i>	(Optional)
<i>mdt_grp</i>	(Optional)
<i>mdt_src</i>	(Optional)
<i>mdt_src_if</i>	(Optional)

Command Mode

- /exec

show mvpn mdt route

```
show mvpn mdt route [ detail ] [ __readonly__ TABLE_vrf <out_context> [ TABLE_mroute <src_addr>
<grp_addr> <uptime> <ref_count> ] ]
```

Syntax Description

show	Show running system information
mvpn	Display Multicast VPN information
mdt	Display MDT information
route	Display MDT route information
detail	(Optional) Display detailed information
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>out_context</i>	(Optional)
TABLE_mroute	(Optional)
<i>src_addr</i>	(Optional)
<i>grp_addr</i>	(Optional)
<i>uptime</i>	(Optional)
<i>ref_count</i>	(Optional)

Command Mode

- /exec

show mvr

```
show mvr [ verbose ] [ __readonly__ <mvr-status> <mvr-default-vlan> <number-of-mvr-vlans> [
<mvr-group-list> <cfg-nodes> <interface-cfg-nodes> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
verbose	(Optional) Show in detail
__readonly__	(Optional)
<i>mvr-status</i>	(Optional)
<i>mvr-default-vlan</i>	(Optional)
<i>number-of-mvr-vlans</i>	(Optional)
<i>mvr-group-list</i>	(Optional)
<i>cfg-nodes</i>	(Optional)
<i>interface-cfg-nodes</i>	(Optional)

Command Mode

- /exec

show mvr groups

```
show mvr groups [ __readonly__ [ TABLE_group_list <ip-address> <ip-max-addr> <rn-count-char> <rn-count>
<mvr-vlan-string> <if-name> ] [ [ <interface-name> ] [ <mvr-vlan> ] [ TABLE_mvr_vlan <global-mvr-vlan>
] <mvr-groups> <mvr-receiver-type> <mvr-source-type> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
groups	show mvr groups config
<i>__readonly__</i>	(Optional)
<i>TABLE_group_list</i>	(Optional)
<i>ip-address</i>	(Optional)
<i>ip-max-addr</i>	(Optional)
<i>rn-count-char</i>	(Optional)
<i>rn-count</i>	(Optional)
<i>mvr-vlan-string</i>	(Optional)
<i>if-name</i>	(Optional)
<i>interface-name</i>	(Optional)
<i>mvr-vlan</i>	(Optional)
<i>TABLE_mvr_vlan</i>	(Optional)
<i>global-mvr-vlan</i>	(Optional)
<i>mvr-groups</i>	(Optional)
<i>mvr-receiver-type</i>	(Optional)
<i>mvr-source-type</i>	(Optional)

Command Mode

- /exec

show mvr interface

```
show mvr interface [ <if0> ] [ __readonly__ [ TABLE_if_name <interface-name> <access-vlan> <src-rcvr>
<igmp-mvr-port-status> <mvr-vlan-str> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
interface	show mvr interfaces
<i>if0</i>	(Optional) Interface name
<i>__readonly__</i>	(Optional)
<i>TABLE_if_name</i>	(Optional)
<i>interface-name</i>	(Optional)
<i>access-vlan</i>	(Optional)
<i>src-rcvr</i>	(Optional)
<i>igmp-mvr-port-status</i>	(Optional)
<i>mvr-vlan-str</i>	(Optional)

Command Mode

- /exec

show mvr members

```
show mvr members [ interface <if0> ] [ __readonly__ [ TABLE_mvr_vlan <mvr-vlan> <group> <status> [
TABLE_members_if <if-name> ] ] [ <vlan> <mvr-group> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
members	show active mvr groups
interface	(Optional) show active mvr groups config on interface
<i>if0</i>	(Optional) Interface name
<i>__readonly__</i>	(Optional)
<i>TABLE_mvr_vlan</i>	(Optional)
<i>mvr-vlan</i>	(Optional)
<i>group</i>	(Optional)
<i>status</i>	(Optional)
<i>TABLE_members_if</i>	(Optional)
<i>if-name</i>	(Optional)
<i>vlan</i>	(Optional)
<i>mvr-group</i>	(Optional)

Command Mode

- /exec

show mvr members count

```
show mvr members count [ __readonly__ [ TABLE_mvr_vlan <mvr-vlan> <mvr-members-count> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
members	show active mvr groups
count	Active mvr groups on each mvr-vlan
__readonly__	(Optional)
TABLE_mvr_vlan	(Optional)
<i>mvr-vlan</i>	(Optional)
<i>mvr-members-count</i>	(Optional)

Command Mode

- /exec

show mvr members vlan

```
show mvr members { vlan <vlan-id> } [ __readonly__ [ TABLE_mvr_vlan <mvr-vlan> <grp> <stat> [
TABLE_interface_vlan <interface-name> ] ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
members	show active mvr groups
vlan	vlan
<i>vlan-id</i>	Enter MVR Vlan
<i>__readonly__</i>	(Optional)
TABLE_mvr_vlan	(Optional)
<i>mvr-vlan</i>	(Optional)
<i>grp</i>	(Optional)
<i>stat</i>	(Optional)
TABLE_interface_vlan	(Optional)
<i>interface-name</i>	(Optional)

Command Mode

- /exec

show mvr receiver-ports

```
show mvr receiver-ports [ <if0> ] [ __readonly__ [ TABLE_mvr_if_name <mvr-if-name> <mvr-vlan-str>
<igmp-port-status> <rx_reports> <rx_leaves> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
receiver-ports	List MVR receiver ports
<i>if0</i>	(Optional) Interface name
<i>__readonly__</i>	(Optional)
<i>TABLE_mvr_if_name</i>	(Optional)
<i>mvr-if-name</i>	(Optional)
<i>mvr-vlan-str</i>	(Optional)
<i>igmp-port-status</i>	(Optional)
<i>rx_reports</i>	(Optional)
<i>rx_leaves</i>	(Optional)

Command Mode

- /exec

show mvr source-ports

```
show mvr source-ports [ <if0> ] [ __readonly__ [ TABLE_mvr_if_name <mvr-if-name> <interface-name>
<igmp-port-status> ] ]
```

Syntax Description

show	Show running system information
mvr	show mvr info
source-ports	List MVR source ports
<i>if0</i>	(Optional) Interface name
<i>__readonly__</i>	(Optional)
<i>TABLE_mvr_if_name</i>	(Optional)
<i>mvr-if-name</i>	(Optional)
<i>interface-name</i>	(Optional)
<i>igmp-port-status</i>	(Optional)

Command Mode

- /exec



N Show Commands

- [show nbm defaults](#), on page 1793
- [show nbm flow-policy](#), on page 1794
- [show nbm flows](#), on page 1795
- [show nbm flows bandwidth](#), on page 1798
- [show nbm flows statistics](#), on page 1799
- [show nbm flows summary](#), on page 1800
- [show nbm host-policy all](#), on page 1801
- [show nbm host-policy applied](#), on page 1802
- [show nbm host-policy applied receiver](#), on page 1803
- [show nbm interface bandwidth](#), on page 1804
- [show ngoam interface statistics](#), on page 1805
- [show ngoam loopback](#), on page 1806
- [show ngoam pathtrace](#), on page 1808
- [show ngoam probe](#), on page 1812
- [show ngoam traceroute statistics](#), on page 1814
- [show ngoam xconnect session](#), on page 1816
- [show npv external-interface-usage](#), on page 1818
- [show npv flogi-table](#), on page 1819
- [show npv status](#), on page 1820
- [show npv traffic-map](#), on page 1822
- [show ntp access-groups](#), on page 1823
- [show ntp authentication-keys](#), on page 1824
- [show ntp authentication-status](#), on page 1825
- [show ntp information](#), on page 1826
- [show ntp logging-status](#), on page 1827
- [show ntp peer-status](#), on page 1828
- [show ntp peers](#), on page 1829
- [show ntp rts-update](#), on page 1830
- [show ntp session status](#), on page 1831
- [show ntp source-interface](#), on page 1832
- [show ntp source](#), on page 1833
- [show ntp statistics](#), on page 1834
- [show ntp status](#), on page 1837

- [show ntp trusted-keys](#), on page 1838
- [show nxapi-server logs](#), on page 1839
- [show nxapi](#), on page 1840
- [show nxapi syntax](#), on page 1841

show nbm defaults

show nbm defaults

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
defaults	Default config

Command Mode

- /exec

show nbm flow-policy

show nbm flow-policy [name { <policy-name> }]

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flow-policy	Flow policy show command
name	(Optional) Policy name
<i>policy-name</i>	(Optional) Policy name value

Command Mode

- /exec

show nbm flows

```
show nbm flows [ group-based | m-group <group-ip-id> | { flow-policy { <cfg-pol-name> |
<unknown-pol-name> } } | source <source-ip> [ group <group-ip> ] | group <group-ip> [ source <source-ip>
] | interface <if-name> ] [ all | active | inactive | no-receiver ] [ detail ] [ __readonly__ TABLE flows {
<mcast_grp> <src_ip> <start_time> <src_intf> <src_nbr_device> <lid> <status> <num_rx> <bw_mbps>
<cfg_mbps> <src_slot> <unit> <slice> } [ { <act_slot> <act_unit> <stdby_slot> <stdby_unit> } ] [ { <dscp>
<qos> <owner_type> <pol_name> } [ <flag> ] [ { <n_link> <num_links> } ] [ { <slot_2> <unit_2>
<num_rx_2> } ] [ { <iiod> <ilink> <i_ifidx> <fab_iiod> <fab_oiod> <fab_ifidx> <oiod> <olink> <i_ieth_port>
<fab_ieth_port> } ] [ { <rcv_if_idx> <ioid> <name> <rcv_nbr_device> } ] [ { <end_timestr> <flow_rate_bps>
<packets> <bytes> } ] ]
```

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM flows (default will be active flows)
active	(Optional) Active flows (default)
inactive	(Optional) Inactive flows
no-receiver	(Optional) Flows without any receiver
all	(Optional) Both active and inactive flows
group-based	(Optional) Multicast group based (*,G) flows to IGMP receivers
m-group	(Optional) Multicast group
<i>group-ip-id</i>	(Optional) Multicast group address
flow-policy	(Optional) Flow policy
<i>cfg-pol-name</i>	(Optional) Policy name
<i>unknown-pol-name</i>	(Optional) Policy name
source	(Optional) Source IP address
<i>source-ip</i>	(Optional) Source IP address
group	(Optional) Multicast group
<i>group-ip</i>	(Optional) Multicast group address
interface	(Optional) Ingress interface
detail	(Optional) Detailed output
<i>if-name</i>	(Optional) Interface name
__readonly__	(Optional)

<i>TABLE_flows</i>	(Optional) Flow stats table
<i>mcast_grp</i>	(Optional) Multicast group IP
<i>src_ip</i>	(Optional) Source IP
<i>start_time</i>	(Optional) Start time
<i>src_intf</i>	(Optional) Ingress source interface
<i>src_nbr_device</i>	(Optional) Ingress neighbor device name
<i>lid</i>	(Optional) Logical internal flow ID
<i>status</i>	(Optional) Flow status
<i>num_rx</i>	(Optional) Number of receivers
<i>bw_mbps</i>	(Optional) Set bandwidth
<i>cfg_mbps</i>	(Optional) Configured bandwidth
<i>src_slot</i>	(Optional) Source slot
<i>unit</i>	(Optional) Source unit
<i>slice</i>	(Optional) Source slice
<i>dscp</i>	(Optional) Flow DSCP
<i>qos</i>	(Optional) Flow QOS group
<i>owner_type</i>	(Optional) Flow Owner type
<i>pol_name</i>	(Optional) Flow Policy name
<i>flag</i>	(Optional) Flow not guarantee flag
<i>n_link</i>	(Optional) N Link
<i>num_links</i>	(Optional) Number of Links
<i>act_slot</i>	(Optional) Active FM Slot
<i>act_unit</i>	(Optional) Active FM Unit
<i>stdby_slot</i>	(Optional) Standby FM Slot
<i>stdby_unit</i>	(Optional) Standby FM Unit
<i>slot_2</i>	(Optional) Slot
<i>unit_2</i>	(Optional) Unit
<i>num_rx_2</i>	(Optional) Number of Receivers
<i>iiod</i>	(Optional) IIOD

<i>ilink</i>	(Optional) Ilink
<i>i_ifidx</i>	(Optional) Internal IF IDX
<i>fab_iiod</i>	(Optional) Fabric IIOD
<i>fab_oiod</i>	(Optional) Fabric OIOD
<i>fab_ifidx</i>	(Optional) Fabric IFIDX
<i>oiod</i>	(Optional) OIOD
<i>olink</i>	(Optional) OLink
<i>i_ieth_port</i>	(Optional) Internal IEth Link
<i>fab_ieth_port</i>	(Optional) Fabric IEth Port
<i>rcv_if_idx</i>	(Optional) Receiver interface index
<i>iod</i>	(Optional) Outgoing IOD
<i>name</i>	(Optional) Outgoing interface name
<i>rcv_nbr_device</i>	(Optional) Outgoing neighbor device name
<i>end_timestr</i>	(Optional) Deleted flow end time
<i>flow_rate_bps</i>	(Optional) Deleted flow flow rate in bps
<i>packets</i>	(Optional) Deleted flow packets
<i>bytes</i>	(Optional) Deleted flow bytes

Command Mode

- /exec

show nbm flows bandwidth

show nbm flows bandwidth

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM flows
bandwidth	Per Flow Bandwidth in Mbps

Command Mode

- /exec

show nbm flows statistics

```
show nbm flows statistics [ group-based | m-group <group-ip-id> | { flow-policy { <cfg-pol-name> |
<unknown-pol-name> } } ] [ interface <if-name> ] [ __readonly__ { TABLE_stats <mcast_grp> <src_ip>
<start_time> <src_intf> <packets> <bytes> <allow_bytes> <drop_bytes> } ]
```

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM flows
statistics	Flow statistics
group-based	(Optional) Multicast group based (*,G) flows to IGMP receivers
m-group	(Optional) Multicast group
<i>group-ip-id</i>	(Optional) Multicast group address
flow-policy	(Optional) Flow policy
<i>cfg-pol-name</i>	(Optional) Policy name
<i>unknown-pol-name</i>	(Optional) Policy name
interface	(Optional) Ingress port
<i>if-name</i>	(Optional) Interface name
__readonly__	(Optional)
TABLE_stats	(Optional) Flow stats table
<i>mcast_grp</i>	(Optional) Multicast group IP
<i>src_ip</i>	(Optional) Source IP
<i>start_time</i>	(Optional) Start time
<i>src_intf</i>	(Optional) Ingress source interface
<i>packets</i>	(Optional) Packets
<i>bytes</i>	(Optional) Bytes
<i>allow_bytes</i>	(Optional) Allowed bytes
<i>drop_bytes</i>	(Optional) Dropped bytes

Command Mode

- /exec

show nbm flows summary

```
show nbm flows summary [ __readonly__ TABLE_flows_summary { <flow_type> <sg> <starg> <total> } ]
```

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
flows	NBM Flows
summary	NBM Flow Summary
__readonly__	(Optional)
TABLE_flows_summary	(Optional) Flows summary
<i>flow_type</i>	(Optional) Type of Flow Summary
<i>sg</i>	(Optional) (S,G) number of flows
<i>starg</i>	(Optional) (*,G) number of flows
<i>total</i>	(Optional) Total Flows

Command Mode

- /exec

show nbm host-policy all

```
show nbm host-policy all { sender | { receiver { local | external } } }
```

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
host-policy	Host policy
all	All policies on switch
sender	Sender Policy
receiver	Receiver Policy
local	Local receiver policy
external	External receiver policy

Command Mode

- /exec

show nbm host-policy applied

show nbm host-policy applied { sender { all | interface { <if-name> } } }

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
host-policy	Host policy
applied	Applied policies only
sender	Sender Policy
all	All policies on switch
interface	Interface
<i>if-name</i>	Interface name

Command Mode

- /exec

show nbm host-policy applied receiver

```
show nbm host-policy applied receiver { local { all | interface { <if-name> } } | external }
```

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
host-policy	Host policy
applied	Applied policies only
receiver	Receiver Policy
local	Local receiver policy
all	All policies on switch
external	External receiver policy
interface	Interface
<i>if-name</i>	Interface name

Command Mode

- /exec

show nbm interface bandwidth

```
show nbm interface bandwidth [ __readonly__ [ TABLE_bw { <index> <ifname> <iod> <slot> <unit> <slice>
<ingr_fl_bw_available> <ingr_fl_bw_usable> <ingr_fl_bw_capacity> <egr_fl_bw_available>
<egr_fl_bw_capacity> <nbr_dev_id> <nbr_dev_name> <external> } ] ]
```

Syntax Description

show	Show running system information
nbm	Non Blocking Multicast
interface	interface
bandwidth	Bandwidth interface table
__readonly__	(Optional)
TABLE_bw	(Optional) TABLE BW
<i>index</i>	(Optional) Index
<i>ifname</i>	(Optional) Interface
<i>iod</i>	(Optional) IOD
<i>slot</i>	(Optional) SLOT
<i>unit</i>	(Optional) UNIT
<i>slice</i>	(Optional) SLICE
<i>ingr_fl_bw_available</i>	(Optional) Ingress Flow BW available
<i>ingr_fl_bw_usable</i>	(Optional) Ingress Flow BW usable
<i>ingr_fl_bw_capacity</i>	(Optional) Ingress Flow BW capacity
<i>egr_fl_bw_available</i>	(Optional) Egress Flow BW available
<i>egr_fl_bw_capacity</i>	(Optional) Egress Flow BW capacity
<i>nbr_dev_id</i>	(Optional) Neighbor device ID
<i>nbr_dev_name</i>	(Optional) Neighbor device name
<i>external</i>	(Optional) External

Command Mode

- /exec

show ngoam interface statistics

```
show ngoam interface statistics [ __readonly__ [ TABLE_stats { <interface-name> <tx> <rx> } <statistics-end> ] ]
```

Syntax Description

TABLE_stats	(Optional) interface statistics table
<i>interface-name</i>	(Optional) interface namestring
<i>tx</i>	(Optional) ngoam probe transmit on the interface
<i>rx</i>	(Optional) ngoam probe receive on the interface
show	Show running system information
ngoam	ngoam
interface	probe packet interface
statistics	ngoam probe interface statistics
__readonly__	(Optional) Read Only
<i>statistics-end</i>	(Optional) statistics table end marker

Command Mode

- /exec

show ngoam loopback

```
show ngoam loopback { { statistics { session { <handle> | all } | summary } } | { status { session { <handle> | all } } } } [ __readonly__ [ TABLE_statistics { <sender-handle> <connect-check-id> <last-clear-stats>
TABLE_stats_attr { <stat-attr> <stat-value> } } ] [ TABLE_status { <st-sender-handle> <type> <state> } ]
[ TABLE_statistics_summary { <last-clear-summary-stats> <tx> <rx> <timeout> <unsent> <req-sw-fwd>
<req-drop> <resp-tx> <resp-rx> <resp-unsent> <resp-dup> <resp-sw-fwd> <resp-drop> } ] ]
```

Syntax Description

show	Show running system information
ngoam	ngoam
loopback	ngoam loopback
statistics	ngoam loopback statistics
summary	ngoam loopback statistics summary
status	ngoam loopback status
session	ngoam loopback session
session	ngoam loopback session
<i>handle</i>	ngoam loopback session handle
<i>handle</i>	ngoam loopback session handle
all	Display results for all ping/loopback sessions
all	Display results for all ping/loopback sessions
TABLE_statistics	(Optional) statistics table
<i>sender-handle</i>	(Optional) sender handle
<i>connect-check-id</i>	(Optional) connect check id
<i>last-clear-stats</i>	(Optional) last clear time for statistics
TABLE_stats_attr	(Optional) Stats attributes table
<i>stat-attr</i>	(Optional) stats type
<i>stat-value</i>	(Optional) stats value
TABLE_statistics_summary	(Optional) statistics summary table
<i>last-clear-summary-stats</i>	(Optional) last clear time for summary statistics
<i>tx</i>	(Optional) summary request sent
<i>rx</i>	(Optional) summary reply received

<i>timeout</i>	(Optional) summary timeout
<i>unsent</i>	(Optional) summary unsent
<i>resp-tx</i>	(Optional) summary resp tx
<i>resp-rx</i>	(Optional) summary resp rx
<i>resp-unsent</i>	(Optional) summary resp unsent
<i>resp-dup</i>	(Optional) Duplicate responses received
<i>req-sw-fwd</i>	(Optional) Request pkts sw fwded
<i>resp-sw-fwd</i>	(Optional) Response pkts sw fwded
<i>req-drop</i>	(Optional) Requests dropped
<i>resp-drop</i>	(Optional) Responses dropped
TABLE_status	(Optional) database status table
<i>st-sender-handle</i>	(Optional) sender handle
<i>type</i>	(Optional) ngoam ping type
<i>state</i>	(Optional) ngoam ping state
<u>__readonly__</u>	(Optional) Read Only

Command Mode

- /exec

show ngoam pathtrace

```
show ngoam pathtrace { { statistics { summary | { session { <handle> | all } } } } | { database session {
<handle> | all } [ detail ] } } [ __readonly__ [ { TABLE_stats <sender-handle> <last-clear-stats> [
TABLE_stats_fields { <stat-attr> <stat-value> } ] ] ] [ { TABLE_summary <last-clear-summary-stats> <tx>
<rx> <timeout> <unsent> <req-sw-fwd> <req-drop> <resp-tx> <resp-rx> <resp-unsent> <resp-dup>
<resp-sw-fwd> <resp-drop> } ] ] [ { TABLE_database <db-sender-handle> <db-start-time> <db-end-time>
<db-last-clear-stats> <db-tx> <db-rx> <db-timeout> <db-unsent> <db-req-sw-fwd> <db-req-drop> <db-resp-tx>
<db-resp-rx> <db-resp-unsent> <db-resp-dup> <db-resp-sw-fwd> <db-resp-drop> { TABLE_db_reply
<seq-number> <cli-status> [ <reply-ip> ] [ <reply-ipv6> ] [ <ingress-if> ] [ <ingress-if-state> ] [ <egress-if>
] [ <egress-if-state> ] [ { TABLE_ifstats <if-name> <rx-len> <rx-bytes> <rx-pkt-rate> <rx-byte-rate> <rx-load>
<rx-ucast> <rx-mcast> <rx-bcast> <rx-discards> <rx-errors> <rx-unknown> <rx-bandwidth> <tx-len>
<tx-bytes> <tx-pkt-rate> <tx-byte-rate> <tx-load> <tx-ucast> <tx-mcast> <tx-bcast> <tx-discards> <tx-errors>
<tx-bandwidth> } ] [ <end-row> ] + } } ] ]
```

Syntax Description

show	Show running system information
ngoam	ngoam
pathtrace	ngoam pathtrace
statistics	ngoam pathtrace statistics
summary	ngoam pathtrace statistics summary
session	ngoam pathtrace session
<i>handle</i>	ngoam pathtrace session handle
all	Display results for all pathtrace sessions
database	ngoam pathtrace results from the database
session	ngoam pathtrace session
all	Display results for all pathtrace sessions
<i>handle</i>	ngoam pathtrace session handle
detail	(Optional) Show detailed stats if present
__readonly__	(Optional) Read Only
TABLE_stats	(Optional) statistics table
<i>sender-handle</i>	(Optional) sender handle
<i>last-clear-stats</i>	(Optional) last clear time for statistics
TABLE_stats_fields	(Optional) statistics entries
<i>stat-attr</i>	(Optional) stats type

<i>stat-value</i>	(Optional) stats value
TABLE_summary	(Optional) statistics summary table
<i>last-clear-summary-stats</i>	(Optional) last clear time for summary statistics
<i>tx</i>	(Optional) summary request sent
<i>rx</i>	(Optional) summary reply received
<i>timeout</i>	(Optional) summary timeout
<i>unsent</i>	(Optional) summary unsent
<i>req-sw-fwd</i>	(Optional) Request pkts sw fwded
<i>req-drop</i>	(Optional) Requests dropped
<i>resp-tx</i>	(Optional) summary resp tx
<i>resp-rx</i>	(Optional) summary resp rx
<i>resp-unsent</i>	(Optional) summary resp unsent
<i>resp-dup</i>	(Optional) Duplicate responses received
<i>resp-sw-fwd</i>	(Optional) Response pkts sw fwded
<i>resp-drop</i>	(Optional) Responses dropped
TABLE_database	(Optional) pathtrace database
<i>db-sender-handle</i>	(Optional) Sender handle
<i>db-start-time</i>	(Optional) Start time
<i>db-end-time</i>	(Optional) End time
<i>db-last-clear-stats</i>	(Optional) Last clear stats
<i>db-tx</i>	(Optional) Tx packets
<i>db-rx</i>	(Optional) Rx packets
<i>db-timeout</i>	(Optional) Timeout
<i>db-unsent</i>	(Optional) Unsent
<i>db-req-sw-fwd</i>	(Optional) Request pkts sw fwded
<i>db-req-drop</i>	(Optional) Requests dropped
<i>db-resp-tx</i>	(Optional) Response tx
<i>db-resp-rx</i>	(Optional) Response Rx
<i>db-resp-unsent</i>	(Optional) Response unsent

<i>db-resp-dup</i>	(Optional) Duplicate response recvd
<i>db-resp-sw-fwd</i>	(Optional) Response pkts sw fwded
<i>db-resp-drop</i>	(Optional) Responses dropped
TABLE_db_reply	(Optional) Replies
<i>seq-number</i>	(Optional) Sequence number
<i>cli-status</i>	(Optional) ngoam pathtrace status
<i>reply-ip</i>	(Optional) ngoam pathtrace reply ip
<i>ingress-if</i>	(Optional) Ingress interface
<i>ingress-if-state</i>	(Optional) Ingress interface state
<i>egress-if</i>	(Optional) Egress interface
<i>egress-if-state</i>	(Optional) Egress interface state
<i>end-row</i>	(Optional) Row end
TABLE_ifstats	(Optional) Interface statistics
<i>if-name</i>	(Optional) Interface name
<i>rx-len</i>	(Optional) Rx Length
<i>rx-bytes</i>	(Optional) Rx Bytes
<i>rx-pkt-rate</i>	(Optional) Rx packet rate
<i>rx-byte-rate</i>	(Optional) Rx byte rate
<i>rx-load</i>	(Optional) Rx load
<i>rx-ucast</i>	(Optional) Rx unicast pkts
<i>rx-mcast</i>	(Optional) Rx mcast pkts
<i>rx-bcast</i>	(Optional) Rx bcast pkts
<i>rx-discards</i>	(Optional) Rx discards
<i>rx-errors</i>	(Optional) Rx errors
<i>rx-unknown</i>	(Optional) Rx unknown
<i>rx-bandwidth</i>	(Optional) Rx bandwidth
<i>tx-len</i>	(Optional) Tx Length
<i>tx-bytes</i>	(Optional) Tx Bytes
<i>tx-pkt-rate</i>	(Optional) Tx packet rate

<i>tx-byte-rate</i>	(Optional) Tx byte rate
<i>tx-load</i>	(Optional) Tx load
<i>tx-ucast</i>	(Optional) Tx unicast pkts
<i>tx-mcast</i>	(Optional) Tx mcast pkts
<i>tx-bcast</i>	(Optional) Tx bcast pkts
<i>tx-discards</i>	(Optional) Tx discards
<i>tx-errors</i>	(Optional) Tx unknown
<i>tx-bandwidth</i>	(Optional) Tx bandwidth

Command Mode

- /exec

show ngoam probe

```
show ngoam probe { { statistics { summary | { session { <handle> | all } } } } [ __readonly__ [ TABLE_stats
{ <sender-handle> <transaction-id> <dst-vip> <vni> <oam-type> <flow-str> <last-clear-stats> <req-sent>
<req-not-sent> } <statistics-end> ] [ TABLE_summary { <last-clear-summary-stats> <tx> <rx> <timeout>
<unsent> <resp-tx> <resp-rx> <resp-unsent> } ] ]
```

Syntax Description

show	Show running system information
ngoam	ngoam
probe	ngoam probe
statistics	ngoam probe statistics
summary	ngoam probe statistics summary
session	ngoam probe session
<i>handle</i>	ngoam probe session handle
all	Display results for all probe sessions
TABLE_stats	(Optional) statistics table
<i>sender-handle</i>	(Optional) sender handle
<i>transaction-id</i>	(Optional) Transaction Identifier
<i>dst-vip</i>	(Optional) Destination Vtep ip address
<i>vni</i>	(Optional) vxlan header vni
<i>oam-type</i>	(Optional) draft pang oam type
<i>flow-str</i>	(Optional) 128 byte flow string.
<i>last-clear-stats</i>	(Optional) last clear time for statistics
<i>req-sent</i>	(Optional) request sent
<i>req-not-sent</i>	(Optional) request not sent or failed
<i>statistics-end</i>	(Optional) statistics table end marker
TABLE_summary	(Optional) statistics summary table
<i>last-clear-summary-stats</i>	(Optional) last clear time for summary statistics
<i>tx</i>	(Optional) summary request sent
<i>rx</i>	(Optional) summary reply received

<i>timeout</i>	(Optional) summary timeout
<i>unsent</i>	(Optional) summary unsent
<i>resp-tx</i>	(Optional) summary resp tx
<i>resp-rx</i>	(Optional) summary resp rx
<i>resp-unsent</i>	(Optional) summary resp unsent
<i>__readonly__</i>	(Optional) Read Only

Command Mode

- /exec

show ngoam traceroute statistics

```
show ngoam traceroute statistics { summary | { session { <handle> | all } } } [ __readonly__ [ TABLE_stats
{ <sender-handle> <last-clear-stats> TABLE_stats_attr { <stat-attr> <stat-value> } } ] [ TABLE_summary
{ <last-clear-summary-stats> <tx> <rx> <timeout> <unsent> <resp-tx> <resp-rx> <resp-unsent> <resp-dup>
} ] ]
```

Syntax Description

show	Show running system information
ngoam	ngoam
traceroute	ngoam traceroute
statistics	ngoam traceroute statistics
summary	ngoam traceroute statistics summary
session	ngoam traceroute session
<i>handle</i>	ngoam traceroute session handle
all	Display results for all traceroute sessions
TABLE_stats	(Optional) statistics table
<i>sender-handle</i>	(Optional) sender handle
<i>last-clear-stats</i>	(Optional) last clear time for statistics
TABLE_stats_attr	(Optional) Stats attributes table
<i>stat-attr</i>	(Optional) stats type
<i>stat-value</i>	(Optional) stats value
TABLE_summary	(Optional) statistics summary table
<i>last-clear-summary-stats</i>	(Optional) last clear time for summary statistics
<i>tx</i>	(Optional) summary request sent
<i>rx</i>	(Optional) summary reply received
<i>timeout</i>	(Optional) summary timeout
<i>unsent</i>	(Optional) summary unsent
<i>resp-tx</i>	(Optional) summary resp tx
<i>resp-rx</i>	(Optional) summary resp rx
<i>resp-unsent</i>	(Optional) summary resp unsent

<i>resp-dup</i>	(Optional) Duplicate responses received
<i>__readonly__</i>	(Optional) Read Only

Command Mode

- /exec

show ngoam xconnect session

```
show ngoam xconnect session { <id> [ iodb ] | all [ dbdump ] } [ __readonly__ [ TABLE_xc_db_summary
{ [ <legend> ] <vlan-id> <peer-ip> <vni> <db-state> <local-if> <local-if-state> <remote-if> <remote-if-state>
[ <end-row> ] + } + ] [ ENTRY_xc_db_detail { <detail> <d-vlan-id> <d-peer-ip> [ <peer-name> ] <d-vni>
<d-db-state> <last-state-change-ts> <d-local-if> <d-local-if-state> <vpc-if> <vpc-if-state> <remote-if-detail>
<remote-if-detail-state> <remote-vpc-if> <remote-vpc-if-state> [ <d-end-row> ] + } ] ]
```

Syntax Description

show	Show running system information
ngoam	ngoam information
xconnect	crossconnect info
session	xc session id
<i>id</i>	Vlan-id of the xc
iodb	(Optional) Iodb
all	show summary info for all sessions
__readonly__	(Optional) Read Only
TABLE_xc_db_summary	(Optional) XC Db table
ENTRY_xc_db_detail	(Optional) XC Db detail
<i>detail</i>	(Optional) Detail or not
<i>vlan-id</i>	(Optional) Vlan id
<i>d-vlan-id</i>	(Optional) Vlan id
<i>vni</i>	(Optional) vni
<i>d-vni</i>	(Optional) vni
<i>local-if</i>	(Optional) Interface
<i>d-local-if</i>	(Optional) Interface
<i>local-if-state</i>	(Optional) Interface state
<i>d-local-if-state</i>	(Optional) Interface state
<i>remote-if</i>	(Optional) Remote interface
<i>remote-if-state</i>	(Optional) Remote interface state
<i>remote-if-detail</i>	(Optional) Remote interface
<i>remote-if-detail-state</i>	(Optional) Remote interface state

<i>vpc-if</i>	(Optional) Interface
<i>vpc-if-state</i>	(Optional) Interface state
<i>remote-vpc-if</i>	(Optional) Remote vpc interface
<i>remote-vpc-if-state</i>	(Optional) Remote vpc interface state
<i>db-state</i>	(Optional) XC state
<i>d-db-state</i>	(Optional) XC state
<i>last-state-change-ts</i>	(Optional) Last state change timestamp
<i>peer-ip</i>	(Optional) Peer ip
<i>d-peer-ip</i>	(Optional) Peer ip
<i>peer-name</i>	(Optional) Peer name
<i>end-row</i>	(Optional) end row
<i>d-end-row</i>	(Optional) end row
<i>legend</i>	(Optional) legend
<i>dbdump</i>	(Optional) Dump the whole database

Command Mode

- /exec

show npv external-interface-usage

```
show npv external-interface-usage [ server-interface <if0> ] [ __readonly__ { TABLE_intf_usage <svr_intf>
<ext_intf> } ]
```

Syntax Description

show	Show running system information
npv	Show information about NPV
external-interface-usage	Show external interface usage by server interfaces
server-interface	(Optional) Show external interface usage by a server interface
<i>if0</i>	(Optional)
__readonly__	(Optional) Read Only
TABLE_intf_usage	(Optional) External Interfaces Usage Table
<i>svr_intf</i>	(Optional) Server Interface
<i>ext_intf</i>	(Optional) External Interface

Command Mode

- /exec

show npv flogi-table

```
show npv flogi-table [ { interface <iif0> | vsan <i0> } ] [ __readonly__ [ [ TABLE_flogi <svr_intf> <vsan_id>
<fcid> <pwwn> <ext_intf> <nwwn> ] [ <flogi_count> ] ] ]
```

Syntax Description

show	Show running system information
npv	Show information about NPV
flogi-table	Show information about FLOGI sessions
interface	(Optional) Show information about FLOGI sessions for a server interface
<i>if0</i>	(Optional)
vsan	(Optional) Show information about FLOGI sessions for a VSAN
<i>i0</i>	(Optional)
__readonly__	(Optional) Read Only
TABLE_flogi	(Optional) FLOGI Table
<i>svr_intf</i>	(Optional) Server Interface
<i>vsan_id</i>	(Optional) VSAN ID
<i>fcid</i>	(Optional) FLOGI FCID
<i>pwwn</i>	(Optional) The PWWN
<i>ext_intf</i>	(Optional) External Interface
<i>nwwn</i>	(Optional) The NWWN
<i>flogi_count</i>	(Optional) Total FLOGI Count

Command Mode

- /exec

show npv status

```
show npv status [ vsan <i0> ] [ __readonly__ [ [ <npiv_status> ] [ <load_balance> ] [ { TABLE_extintf
<ext_intf> [ <ext_vsan> ] [ <ext_fcid> ] <ext_state> [ { TABLE_vsan <vsan_vsan> <vsan_state> [ <vsan_fcid>
] } ] ] ] <ext_intf_count> [ { TABLE_svrntf <svr_intf> <svr_vsan> <svr_state> } ] <svr_intf_count> ] ]
```

Syntax Description

show	Show running system information
npv	Show information about NPV
status	Show NPV status
vsan	(Optional) Show NPV status for a specific VSAN
i0	(Optional)
__readonly__	(Optional) Read Only
npiv_status	(Optional) NPIV enable/disable status
load_balance	(Optional) disruptive load balance status
TABLE_extintf	(Optional) External Interfaces Table
ext_intf	(Optional) External Interface
ext_vsan	(Optional) External Interface VSAN
ext_fcid	(Optional) External Interface FCID
ext_state	(Optional) External Interface State
TABLE_vsan	(Optional) External Interfaces VSAN Table
vsan_vsan	(Optional) External Interface VSAN
vsan_state	(Optional) VSAN State
vsan_fcid	(Optional) VSAN FCID
ext_intf_count	(Optional) External Interface count
TABLE_svrntf	(Optional) Server Interfaces Table
svr_intf	(Optional) Server Interface
svr_vsan	(Optional) Server Interface VSAN
svr_state	(Optional) Server Interface State
svr_intf_count	(Optional) Server Interface count

Command Mode

- /exec

show npv traffic-map

```
show npv traffic-map [ server-interface <if0> ] [ __readonly__ [ { TABLE_traffic_map <svr_intf> <ext_intf> } ] ]
```

Syntax Description

show	Show running system information
npv	Show information about NPV
traffic-map	Show information about Traffic Map
server-interface	(Optional) Show information about Traffic map for a server interface
<i>if0</i>	(Optional)
__readonly__	(Optional) Read Only
TABLE_traffic_map	(Optional) Traffic Map Table
<i>svr_intf</i>	(Optional) Server Interface
<i>ext_intf</i>	(Optional) External Interface

Command Mode

- /exec

show ntp access-groups

```
show ntp access-groups [ __readonly__ [ <matchall> ] [ { TABLE_accessgroups <accesslist> [ <type> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
access-groups	Display NTP access groups
__readonly__	(Optional)
<i>matchall</i>	(Optional) matchall
TABLE_accessgroups	(Optional) accessgroups
<i>accesslist</i>	(Optional) accesslist
<i>type</i>	(Optional) type

Command Mode

- /exec

show ntp authentication-keys

```
show ntp authentication-keys [ __readonly__ [ { TABLE_authkeys <Authkey> [ <MD5String> ] } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
authentication-keys	Display authentication keys
__readonly__	(Optional)
TABLE_authkeys	(Optional) authentication keys
<i>Authkey</i>	(Optional) authentication key
<i>MD5String</i>	(Optional) password

Command Mode

- /exec

show ntp authentication-status

```
show ntp authentication-status [ __readonly__ [ <authentication> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
authentication-status	NTP Authentication Status
<i>__readonly__</i>	(Optional)
<i>authentication</i>	(Optional) authentication enabled/disabled

Command Mode

- /exec

show ntp information

show ntp information [*__readonly__* [*<system_type>*] [*<software_version>*]]

Syntax Description

show	Show running system information
ntp	Show NTP information
information	Show ntp information
<i>__readonly__</i>	(Optional)
<i>system_type</i>	(Optional) Ntp System Type
<i>software_version</i>	(Optional) Ntp Software Version

Command Mode

- /exec

show ntp logging-status

show ntp logging-status [__readonly__ [<loggingstatus>]]

Syntax Description

show	Show running system information
ntp	Show NTP information
logging-status	Display NTP logging status
__readonly__	(Optional)
<i>loggingstatus</i>	(Optional) logging enabled/disabled

Command Mode

- /exec

show ntp peer-status

```
show ntp peer-status [ __readonly__ [ <totalpeers> ] [ { TABLE_peersstatus <syncmode> <remote> <local>
<st> <poll> <reach> <delay> [ <vrf> ] } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
peer-status	Show the status for all the server/peers
__readonly__	(Optional)
<i>totalpeers</i>	(Optional) totalpeers
TABLE_peersstatus	(Optional) peersstatus
<i>syncmode</i>	(Optional) peermode
<i>remote</i>	(Optional) remote addr
<i>local</i>	(Optional) local addr
<i>st</i>	(Optional) stratum
<i>poll</i>	(Optional) ntp poll
<i>reach</i>	(Optional) reach
<i>delay</i>	(Optional) delay
<i>vrf</i>	(Optional) vrf name

Command Mode

- /exec

show ntp peers

```
show ntp peers [ __readonly__ [ { TABLE_peers <PeerIPAddress> <serv_peer> <conf_flag> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
peers	Show all the peers.
__readonly__	(Optional)
TABLE_peers	(Optional) peers
<i>PeerIPAddress</i>	(Optional) peer Ip addr
<i>serv_peer</i>	(Optional) server or peer
<i>conf_flag</i>	(Optional) configured or dynamic

Command Mode

- /exec

show ntp rts-update

show ntp rts-update [__readonly__ [<rtsupdate>]]

Syntax Description

show	Show running system information
ntp	Show NTP information
rts-update	Show if the RTS update is enabled
__readonly__	(Optional)
<i>rtsupdate</i>	(Optional) rts update enabled/disabled

Command Mode

- /exec

show ntp session status

```
show ntp session status [ __readonly__ [ <session_status> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
session	Show the session information
status	Show the session status
__readonly__	(Optional)
<i>session_status</i>	(Optional) last session status

Command Mode

- /exec

show ntp source-interface

show ntp source-interface [__readonly__ [<sourceinterface>]]

Syntax Description

show	Show running system information
ntp	Show NTP information
source-interface	Source interface configured
__readonly__	(Optional)
<i>sourceinterface</i>	(Optional) source interface

Command Mode

- /exec

show ntp source

```
show ntp source [ __readonly__ [ { TABLE_sourceip <sourceip> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
source	Source IP address configured
__readonly__	(Optional)
TABLE_sourceip	(Optional) source ip table
<i>sourceip</i>	(Optional) source ip addr

Command Mode

- /exec

show ntp statistics

```
show ntp statistics [ [ io ] | [ local ] | [ memory ] | peer { ipaddr { <ipv4_0> | <ipv6_1> } | name <s0> } ] [
__readonly__ [ { <iotimesincereset> <ioreceivebuffers> <iofreereceivebuffers> <iousedreceivebuffers>
<iolowwaterrefills> <iodroppedpackets> <ioignoredpackets> <ioreceivedpackets> <iopacketsent>
<iopacketsnotsent> <iointerruptshandled> <ioreceivedbyint> } ] [ { <localsystemuptime> <localtimesincereset>
<localoldversionpackets> <localnewversionpackets> <localunknownversionnumber> <localbadpacketformat>
<localpacketsprocessed> <localbadauthentication> [ <localpacketsrejected> } ] [ { <memtimesincereset>
<memtotalpeermemory> <memfreepeermemory> <memcallstofindpeer> <memnewpeerallocations>
<mempeerdemobilizations> <memhashtablecounts> } ] [ { <peeripremotehost> <peeriplocalinterface>
<peeriptimelastreceived> <peeriptimeuntilnextsend> <peeripreachabilitychange> <peerippacketsent>
<peerippacketsreceived> <peeripbadauthentication> <peeripbogusorigin> <peeripduplicate>
<peeripbaddispersion> <peeripbadreferencetime> <peeripcandidateorder> } ] [ { <peernameremotehost>
<peernamelocalinterface> <peernametimelastreceived> <peernametimeuntilnextsend>
<peernamereachabilitychange> <peernamepacketsent> <peernamepacketsreceived>
<peernamebadauthentication> <peernamebogusorigin> <peernameduplicate> <peernameduplicate>
<peernamebaddispersion> <peernamebadreferencetime> <peernamecandidateorder> } ] ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
statistics	Show the NTP statistics
io	(Optional) Show the input-output statistics.
local	(Optional) Show the counters maintained by the local NTP.
memory	(Optional) Show the statistics counters related to memory code.
peer	Show the per-peer statistics counter of a peer.
ipaddr	Peer's IP address
<i>ipv4_0</i>	
name	Peer's Name
<i>s0</i>	
<i>__readonly__</i>	(Optional)
<i>iotimesincereset</i>	(Optional) time since reset
<i>ioreceivebuffers</i>	(Optional) receive buffers
<i>iofreereceivebuffers</i>	(Optional) free receive buffers
<i>iousedreceivebuffers</i>	(Optional) used receive buffers
<i>iolowwaterrefills</i>	(Optional) low water refills

<i>iodroppedpackets</i>	(Optional) dropped packets
<i>ioignoredpackets</i>	(Optional) ignored packets
<i>ioreceivedpackets</i>	(Optional) received packets
<i>iopacketsent</i>	(Optional) packets sent
<i>iopacketsnotsent</i>	(Optional) packets not sent
<i>iointerruptshandled</i>	(Optional) interrupts handled
<i>ioreceivedbyint</i>	(Optional) received by int
<i>localsystemuptime</i>	(Optional) system up time
<i>localtimesincereset</i>	(Optional) time since reset
<i>localoldversionpackets</i>	(Optional) old version packets
<i>localnewversionpackets</i>	(Optional) new version packets
<i>localunknownversionnumber</i>	(Optional) unknown version number
<i>localbadpacketformat</i>	(Optional) bad packet format
<i>localpacketsprocessed</i>	(Optional) packets processed
<i>localbadauthentication</i>	(Optional) bad authentication
<i>localpacketsrejected</i>	(Optional) packets rejected
<i>memtimesincereset</i>	(Optional) time since reset
<i>memtotalpeermemory</i>	(Optional) total peer memory
<i>memfreepeermemory</i>	(Optional) free peer memory
<i>memcallstofindpeer</i>	(Optional) calls to find peer
<i>memnewpeerallocations</i>	(Optional) new peer allocations
<i>mempeerdemobilizations</i>	(Optional) peer demobilizations
<i>memhashtablecounts</i>	(Optional) hash table counts
<i>peeripremotehost</i>	(Optional) peeripremotehost
<i>peeriplocalinterface</i>	(Optional) peeriplocalinterface
<i>peeriptimelastreceived</i>	(Optional) peeriptimelastreceived
<i>peeriptimeuntilnextsend</i>	(Optional) peeriptimeuntilnextsend
<i>peeripreachabilitychange</i>	(Optional) peeripreachabilitychange
<i>peerippacketsent</i>	(Optional) peerippacketsent

<i>peerippacketsreceived</i>	(Optional) peerippacketsreceived
<i>peeripbadauthentication</i>	(Optional) peeripbadauthentication
<i>peeripbogusorigin</i>	(Optional) peeripbogusorigin
<i>peeripduplicate</i>	(Optional) peeripduplicate
<i>peeripbaddispersion</i>	(Optional) peeripbaddispersion
<i>peeripbadreferencetime</i>	(Optional) peeripbadreferencetime
<i>peeripcandidateorder</i>	(Optional) peeripcandidateorder
<i>peername remotehost</i>	(Optional) peername remotehost
<i>peername localinterface</i>	(Optional) peername localinterface
<i>peername timelastreceived</i>	(Optional) peername timelastreceived
<i>peername timeuntilnextsend</i>	(Optional) peername timeuntilnextsend
<i>peername reachabilitychange</i>	(Optional) peername reachabilitychange
<i>peername packetsent</i>	(Optional) peername packetsent
<i>peername packetsreceived</i>	(Optional) peername packetsreceived
<i>peername badauthentication</i>	(Optional) peername badauthentication
<i>peername bogusorigin</i>	(Optional) peername bogusorigin
<i>peername duplicate</i>	(Optional) peername duplicate
<i>peername baddispersion</i>	(Optional) peername baddispersion
<i>peername badreferencetime</i>	(Optional) peername badreferencetime
<i>peername candidateorder</i>	(Optional) peername candidateorder

Command Mode

- /exec

show ntp status

```
show ntp status [ __readonly__ [ <distribution> ] [ <operational_state> ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
status	Show the NTP distribution status
<i>__readonly__</i>	(Optional)
<i>distribution</i>	(Optional) distribution enabled/disabled
<i>operational_state</i>	(Optional) last operation status

Command Mode

- /exec

show ntp trusted-keys

```
show ntp trusted-keys [ __readonly__ [ { TABLE_trustkeys <key> } ] ]
```

Syntax Description

show	Show running system information
ntp	Show NTP information
trusted-keys	Display trusted keys
__readonly__	(Optional)
TABLE_trustkeys	(Optional) trusted keys
<i>key</i>	(Optional) trusted key

Command Mode

- /exec

show nxapi-server logs

show nxapi-server logs

Syntax Description

show	Show running system information
nxapi-server	Show NX-API Server
logs	Show NX-API Server logs

Command Mode

- /exec

show nxapi

```
show nxapi [ __readonly__ <nxapi_status> [ configuration_error <c_error> ] [ <http_port> ] [ <https_port>
<ssl_issuer> <ssl_enddate> ] ]
```

Syntax Description

show	Show running system information
nxapi	Show nxapi status
__readonly__	(Optional)
<i>nxapi_status</i>	(Optional) NX-API enabled status
configuration_error	(Optional) config syntax error
<i>c_error</i>	(Optional) config syntax error
<i>http_port</i>	(Optional) Configured HTTP port
<i>https_port</i>	(Optional) Configured HTTPS port
<i>ssl_issuer</i>	(Optional) Issuer information for current certificate
<i>ssl_enddate</i>	(Optional) Expiration date of current certificate

Command Mode

- /exec

show nxapi syntax

show nxapi syntax <cli>

Syntax Description

show	Show running system information
nxapi	Show nxapi status
syntax	Display syntax for given command
<i>cli</i>	the exact cli to look-up

Command Mode

- /exec

show nxapi syntax



O Show Commands

- [show object-group](#), on page 1844
- [show openflow hardware capabilities](#), on page 1845
- [show openflow switch](#), on page 1846
- [show openflow switch flows](#), on page 1847
- [show ospfv3](#), on page 1848
- [show ospfv3 border-routers](#), on page 1853
- [show ospfv3 database](#), on page 1855
- [show ospfv3 database database-summary](#), on page 1858
- [show ospfv3 database detail](#), on page 1860
- [show ospfv3 event-history](#), on page 1865
- [show ospfv3 event-history detail](#), on page 1866
- [show ospfv3 interface](#), on page 1867
- [show ospfv3 interface brief](#), on page 1870
- [show ospfv3 memory](#), on page 1872
- [show ospfv3 neighbors](#), on page 1874
- [show ospfv3 neighbors detail](#), on page 1876
- [show ospfv3 neighbors summary](#), on page 1879
- [show ospfv3 policy statistics](#), on page 1881
- [show ospfv3 request-list](#), on page 1883
- [show ospfv3 retransmission-list](#), on page 1885
- [show ospfv3 route](#), on page 1887
- [show ospfv3 route summary](#), on page 1889
- [show ospfv3 statistics](#), on page 1891
- [show ospfv3 summary-address](#), on page 1895
- [show ospfv3 traffic](#), on page 1896
- [show ospfv3 virtual-links](#), on page 1900
- [show ospfv3 virtual-links brief](#), on page 1904

show object-group

```
show object-group [ <name> ] [ __readonly__ TABLE_ogroup <group_type> <group_name> [ TABLE_seqno
<seqno> { <_port_op> <port0_num> | <_port_range> <port1_num> <port2_num> | <hostaddr> | <net_ip> |
<mask_ip_addr> <mask_ip_mask> | <hostipv6> | <net_ipv6> | <mask_ipv6_addr> <mask_ipv6_mask> } ]
]
```

Syntax Description

show	Show running system information
object-group	Show configured ACL object groups
<i>name</i>	(Optional) object-group name
<i>__readonly__</i>	(Optional)
<i>group_type</i>	(Optional) Object group type
<i>group_name</i>	(Optional) Object group name
<i>seqno</i>	(Optional) Sequence number
TABLE_ogroup	(Optional)
TABLE_seqno	(Optional)
<i>_port_op</i>	(Optional) Port operator
<i>_port_range</i>	(Optional) Port range
<i>port0_num</i>	(Optional) Port number
<i>port1_num</i>	(Optional) Port number
<i>port2_num</i>	(Optional) Port number
<i>net_ip</i>	(Optional) A.B.C.D Network address of object-group member
<i>hostaddr</i>	(Optional) A.B.C.D Host address
<i>mask_ip_addr</i>	(Optional) A.B.C.D IP address
<i>mask_ip_mask</i>	(Optional) A.B.C.D IP address mask

Command Mode

- /exec

show openflow hardware capabilities

show openflow hardware capabilities [pipeline <pipeline-id>]

Syntax Description

show	Show running system information
openflow	Show OpenFlow information
hardware	Hardware
capabilities	Capabilities
pipeline	(Optional) Pipeline id
<i>pipeline-id</i>	(Optional) Pipeline id

Command Mode

- /exec

show openflow switch

```
show openflow switch <switch-id> [ { controllers [ stats | { role { master | slave | equal } } ] | ports } ] [
__readonly__ <cli_output> <ctrlv4> <ctrlport> ]
```

Syntax Description

show	Show running system information
openflow	Show OpenFlow information
switch	Logical switch id
<i>switch-id</i>	Logical switch-id to enter
controllers	(Optional) Controllers
stats	(Optional) Stats
ports	(Optional) Ports
role	(Optional) Controller role
master	(Optional) Master
slave	(Optional) Slave
equal	(Optional) Equal
<i>__readonly__</i>	(Optional)
<i>cli_output</i>	(Optional)
<i>ctrlv4</i>	(Optional)
<i>ctrlport</i>	(Optional)

Command Mode

- /exec

show openflow switch flows

```
show openflow switch <switch-id> flows [ [ table-id <table-id> ] [ [ pending | pending-del | controller |
configured | default | fixed ] [ brief | list | summary ] ] | stats ]
```

Syntax Description

show	Show running system information
openflow	Show OpenFlow information
switch	Logical switch id
<i>switch-id</i>	Logical switch-id to enter
flows	Flows
brief	(Optional) Brief
summary	(Optional) Summary
pending	(Optional) Pending
pending-del	(Optional) Pending delete
controller	(Optional) Controller
configured	(Optional) Configured
default	(Optional) Default
fixed	(Optional) Fixed
stats	(Optional) Stats
table-id	(Optional) Table-id for the pipeline
list	(Optional) List
<i>table-id</i>	(Optional) Table ID

Command Mode

- /exec

show ospfv3

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <instance_number> <cname> <rid> <stateful_ha> <gr_ha> [ [ <gr_planned_only> ] [
<gr_notify_period> ] [ <gr_grace_period> ] [ <gr_state> ] [ <gr_last_status> ] ] [ <gr_helper_mode> ]
<support_tos0_only> <support_opaque_lsa> [ <low_mem_cond> ] <is_abr> <is_asbr> [
<max_lsa_non_self_number> ] [ <max_lsa_state> ] [ <max_lsa_warning_only> ] [
<max_lsa_current_non_self_lsa_number> ] [ <max_lsa_threshold_pct> ] [ <max_lsa_ignore_time> ] [
<max_lsa_reset_time> ] [ <max_lsa_ignore_count> ] [ <max_lsa_current_ignore_count> ] [
<max_lsa_ignore_time_left> ] [ <max_lsa_reset_time_left> ] [ <max_lsa_permanent_ignore> ] [
<ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] [ { TABLE_redist <proto> [ <max_lsas> ] [
<warning> ] [ <threshold> ] [ <current_count> ] } ] <admin_dist> <ref_bw> <spf_start_time> <spf_hold_time>
<spf_max_time> <lsa_start_time> <lsa_hold_time> <lsa_max_time> <min_lsa_arr_time> <lsa_aging_pace>
<spf_max_paths> <max_metric_adver> [ [ <max_metric_time_left> ] [ <max_metric_wait_bgp> ] [
<max_metric_timeout> ] [ <max_metric_always> ] [ <max_metric_sum_lsa> ] [ <max_metric_ext_lsa> ] ]
<asext_lsa_cnt> <asext_lsa_crc> <area_total> <area_normal> <area_stub> <area_nssa> <act_area_total>
<act_area_normal> <act_area_stub> <act_area_nssa> <no_discard_rt_ext> <no_discard_rt_int> [
<bfd_enabled> ] [ <passive_dflt> ] [ <name_lookup> ] [ { TABLE_area <aname> [ <backbone_active> ] [
<active> ] <age> <total_intf> <act_intf> <passive_intf> <loopback_intf> [ <gr_nbr_cnt> ] <stub> [
<stub_def_cost> ] <nssa> [ <no_redist> ] [ <nssa_trans> ] <no_summary> <spf_runs> <last_spf_run_time>
[ <rtr_lsa_throt> ] [ <ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] [ TABLE_range <addr>
<masklen> <state> <nets> <advertise> [ <cost> ] ] [ <filter_in> ] [ <filter_out> ] <lsa_cnt> <lsa_crc> } ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
__readonly__	(Optional)
TABLE_ctx	(Optional)
ptag	(Optional)
instance_number	(Optional)
cname	(Optional)
rid	(Optional)

<i>stateful_ha</i>	(Optional)
<i>gr_ha</i>	(Optional)
<i>gr_planned_only</i>	(Optional)
<i>gr_notify_period</i>	(Optional)
<i>gr_grace_period</i>	(Optional)
<i>gr_state</i>	(Optional)
<i>gr_last_status</i>	(Optional)
<i>gr_helper_mode</i>	(Optional)
<i>support_tos0_only</i>	(Optional)
<i>support_opaque_lsa</i>	(Optional)
<i>low_mem_cond</i>	(Optional)
<i>is_abr</i>	(Optional)
<i>is_asbr</i>	(Optional)
<i>max_lsa_non_self_number</i>	(Optional)
<i>max_lsa_state</i>	(Optional)
<i>max_lsa_warning_only</i>	(Optional)
<i>max_lsa_current_non_self_lsa_number</i>	(Optional)
<i>max_lsa_threshold_pct</i>	(Optional)
<i>max_lsa_ignore_time</i>	(Optional)
<i>max_lsa_reset_time</i>	(Optional)
<i>max_lsa_ignore_count</i>	(Optional)
<i>max_lsa_current_ignore_count</i>	(Optional)
<i>max_lsa_ignore_time_left</i>	(Optional)
<i>max_lsa_reset_time_left</i>	(Optional)
<i>max_lsa_permanent_ignore</i>	(Optional)
<i>ipsec_sa_type</i>	(Optional) IPsec SA Type
<i>ipsec_sa_algorithm</i>	(Optional) IPsec SA Algorithm name
<i>ipsec_sa_spi</i>	(Optional) IPsec SA SPI Value
TABLE_redist	(Optional)

<i>proto</i>	(Optional)
<i>max_lsas</i>	(Optional)
<i>warning</i>	(Optional)
<i>threshold</i>	(Optional)
<i>current_count</i>	(Optional)
<i>admin_dist</i>	(Optional)
<i>ref_bw</i>	(Optional)
<i>spf_start_time</i>	(Optional)
<i>spf_hold_time</i>	(Optional)
<i>spf_max_time</i>	(Optional)
<i>lsa_start_time</i>	(Optional)
<i>lsa_hold_time</i>	(Optional)
<i>lsa_max_time</i>	(Optional)
<i>min_lsa_arr_time</i>	(Optional)
<i>lsa_aging_pace</i>	(Optional)
<i>spf_max_paths</i>	(Optional)
<i>max_metric_adver</i>	(Optional)
<i>max_metric_time_left</i>	(Optional)
<i>max_metric_wait_bgp</i>	(Optional)
<i>max_metric_timeout</i>	(Optional)
<i>max_metric_always</i>	(Optional)
<i>max_metric_sum_lsa</i>	(Optional)
<i>max_metric_ext_lsa</i>	(Optional)
<i>asext_lsa_cnt</i>	(Optional)
<i>asext_lsa_crc</i>	(Optional)
<i>area_total</i>	(Optional)
<i>area_normal</i>	(Optional)
<i>area_stub</i>	(Optional)
<i>area_nssa</i>	(Optional)

<i>act_area_total</i>	(Optional)
<i>act_area_normal</i>	(Optional)
<i>act_area_stub</i>	(Optional)
<i>act_area_nssa</i>	(Optional)
<i>bfd_enabled</i>	(Optional)
<i>passive_dflt</i>	(Optional)
<i>name_lookup</i>	(Optional)
<i>no_discard_rt_ext</i>	(Optional)
<i>no_discard_rt_int</i>	(Optional)
TABLE_area	(Optional)
<i>aname</i>	(Optional)
<i>backbone_active</i>	(Optional)
<i>active</i>	(Optional)
<i>age</i>	(Optional)
<i>total_intf</i>	(Optional)
<i>act_intf</i>	(Optional)
<i>passive_intf</i>	(Optional)
<i>loopback_intf</i>	(Optional)
<i>gr_nbr_cnt</i>	(Optional)
<i>stub</i>	(Optional)
<i>stub_def_cost</i>	(Optional)
<i>nssa</i>	(Optional)
<i>no_redist</i>	(Optional)
<i>nssa_trans</i>	(Optional)
<i>no_summary</i>	(Optional)
<i>spf_runs</i>	(Optional)
<i>last_spf_run_time</i>	(Optional)
<i>rtr_lsa_throt</i>	(Optional)
<i>ipsec_sa_type</i>	(Optional) IPsec SA Type

<i>ipsec_sa_algorithm</i>	(Optional) IPsec SA Algorithm name
<i>ipsec_sa_spi</i>	(Optional) IPsec SA SPI Value
TABLE_range	(Optional)
<i>masklen</i>	(Optional)
<i>state</i>	(Optional)
<i>nets</i>	(Optional)
<i>advertise</i>	(Optional)
<i>cost</i>	(Optional)
<i>filter_in</i>	(Optional)
<i>filter_out</i>	(Optional)
<i>lsa_cnt</i>	(Optional)
<i>lsa_crc</i>	(Optional)

Command Mode

- /exec

show ospfv3 border-routers

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] border-routers [ all_routes ] [
vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_br
<type> <addr> <cost> <asbr> <abr> <area> <spf_inst> [ <vlink_unresolved> ] [ TABLE_br_ubest_nh [
<ubest_nh_addr> ] [ <ubest_nh_intf> ] ] [ TABLE_br_mbest_nh [ <mbest_nh_addr> ] [ <mbest_nh_intf> ]
] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
border-routers	Border routers
all_routes	(Optional) Display all OSPFv3 routes
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_br	(Optional)
<i>type</i>	(Optional)
<i>addr</i>	(Optional)
<i>cost</i>	(Optional)
<i>asbr</i>	(Optional)
<i>abr</i>	(Optional)
<i>area</i>	(Optional)
<i>spf_inst</i>	(Optional)
<i>vlink_unresolved</i>	(Optional)

TABLE_br_ubest_nh	(Optional)
<i>ubest_nh_intf</i>	(Optional)
TABLE_br_mbest_nh	(Optional)
<i>mbest_nh_intf</i>	(Optional)

Command Mode

- /exec

show ospfv3 database

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database [ [ [ router | network
| intra-area-prefix | inter-area { irouter | iprefix } | nssa-external | area-unknown | [ [ { link | link-unknown |
grace } [ <interface> ] ] ] ] [ area <area-id-ip> ] ] | external [ tag <tag_val> ] | as-unknown [ <lsid> ] [
self-originated | adv-router <adv-id> | adv-router-name <adv-name> ] ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [ TABLE_db3_lsa [ <name> ] [ <area> ] [ <id>
] [ <advrtr> ] [ <age> ] [ <seqno> ] [ <corrupt> ] [ <rtr_num_links> ] [ <net_num_rtr> ] [ <prefix> ] [
<inter_rid> ] [ <link_if> ] [ <intra_ref_type> ] [ <intra_ref_lsid> ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
database	Link-state Database Summary
router	(Optional) Display router LSAs
network	(Optional) Display network LSAs
inter-area	(Optional) Display inter-area LSAs
iprefix	(Optional) Display Inter-Area-Prefix LSAs
irouter	(Optional) Display Inter-Area-Router LSAs
nssa-external	(Optional) Display NSSA-external LSAs
area-unknown	(Optional) Display area-scope unknown LSAs
external	(Optional) Display AS-external LSAs
as-unknown	(Optional) Display as-scope unknown LSAs
grace	(Optional) Display Grace LSAs
link	(Optional) Display Link LSAs
link-unknown	(Optional) Display link-scope unknown LSAs
<i>interface</i>	(Optional) OSPF enabled interface

intra-area-prefix	(Optional) Display Intra-Area-Prefix LSAs
self-originated	(Optional) Display only self-originated LSAs
<i>lsid</i>	(Optional) Restrict display by link state ID
adv-router	(Optional) Restrict display by Advertising router
<i>advid</i>	(Optional) Advertising router ID
adv-router-name	(Optional) Restrict display by Advertising router name
<i>adv-name</i>	(Optional) DNS Name of the Advertising router
area	(Optional) Display only LSA's in this area
<i>area-id-ip</i>	(Optional) Area Id as an integer or ip address
tag	(Optional) Restrict display by tag
<i>tag_val</i>	(Optional) 32-bit tag value
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>rid</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_db3_lsa	(Optional)
<i>name</i>	(Optional)
<i>area</i>	(Optional)
<i>id</i>	(Optional)
<i>advrtr</i>	(Optional)
<i>age</i>	(Optional)
<i>seqno</i>	(Optional)
<i>corrupt</i>	(Optional)
<i>rtr_num_links</i>	(Optional)
<i>net_num_rtr</i>	(Optional)
<i>inter_rid</i>	(Optional)
<i>link_if</i>	(Optional)
<i>intra_ref_type</i>	(Optional)

<i>intra_ref_lsid</i>	(Optional)
-----------------------	------------

Command Mode

- /exec

show ospfv3 database database-summary

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database database-summary
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [
TABLE_dbsum [ TABLE_dbsum_area <area> [ TABLE_dbsum_area_lsa <area_lsa_name> <area_lsa_count>
] <area_lsa_total> ] [ TABLE_dbsum_all [ TABLE_dbsum_lsa_all <lsa_name> <lsa_count> ]
<non_self_lsa_total> <lsa_total> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
database	Link-state Database Summary
database-summary	Summary of database
__readonly__	(Optional)
TABLE_ctx	(Optional)
rid	(Optional)
ptag	(Optional)
cname	(Optional)
TABLE_dbsum	(Optional)
TABLE_dbsum_area	(Optional)
area	(Optional)
TABLE_dbsum_area_lsa	(Optional)
area_lsa_name	(Optional)
area_lsa_count	(Optional)
area_lsa_total	(Optional)
TABLE_dbsum_all	(Optional)

TABLE_dbsum_lsa_all	(Optional)
<i>lsa_name</i>	(Optional)
<i>lsa_count</i>	(Optional)
<i>non_self_lsa_total</i>	(Optional)
<i>lsa_total</i>	(Optional)

Command Mode

- /exec

external	(Optional) Display AS-external LSAs
as-unknown	(Optional) Display as-scope unknown LSAs
grace	(Optional) Display Grace LSAs
link	(Optional) Display Link LSAs
link-unknown	(Optional) Display link-scope unknown LSAs
<i>interface</i>	(Optional) OSPF enabled interface
intra-area-prefix	(Optional) Display Intra-Area-Prefix LSAs
self-originated	(Optional) Display only self-originated LSAs
<i>lsid</i>	(Optional) Restrict display by link state ID
adv-router	(Optional) Restrict display by Advertising router
<i>advid</i>	(Optional) Advertising router ID
adv-router-name	(Optional) Restrict display by Advertising router name
<i>adv-name</i>	(Optional) DNS Name of the Advertising router
area	(Optional) Display only LSA's in this area
<i>area-id-ip</i>	(Optional) Area Id as an integer or ip address
tag	(Optional) Restrict display by tag
<i>tag_val</i>	(Optional) 32-bit tag value
detail	Display LSA in detail
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>rid</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_db3_lsa	(Optional)
<i>name</i>	(Optional)
<i>area</i>	(Optional)
TABLE_lsdb	(Optional)
<i>age</i>	(Optional)
<i>maxage</i>	(Optional)

<i>wrapping</i>	(Optional)
<i>dummy</i>	(Optional)
<i>flush_pending</i>	(Optional)
<i>type</i>	(Optional)
<i>intf</i>	(Optional)
<i>id</i>	(Optional)
<i>advrtr</i>	(Optional)
<i>seqno</i>	(Optional)
<i>cksum</i>	(Optional)
<i>len</i>	(Optional)
<i>corrupt</i>	(Optional)
<i>rtr_abr</i>	(Optional)
<i>rtr_asbr</i>	(Optional)
<i>rtr_translate</i>	(Optional)
<i>rtr_vlink_end</i>	(Optional)
<i>rtr_options</i>	(Optional)
<i>rtr_num_links</i>	(Optional)
TABLE_rlsa	(Optional)
<i>rtr_link_type</i>	(Optional)
<i>rtr_link_metric</i>	(Optional)
<i>rtr_link_ifid</i>	(Optional)
<i>rtr_link_nbr_ifid</i>	(Optional)
<i>rtr_link_nbr_rid</i>	(Optional)
<i>net_options</i>	(Optional)
TABLE_nlsa	(Optional)
<i>net_rtr</i>	(Optional)
<i>ia_prefix_options</i>	(Optional)
<i>ia_prefix_metric</i>	(Optional)
<i>ia_rtr_options</i>	(Optional)

<i>ia_rtr_metric</i>	(Optional)
<i>ia_rtr_rid</i>	(Optional)
<i>asext_options</i>	(Optional)
<i>asext_metric_type2</i>	(Optional)
<i>asext_metric</i>	(Optional)
<i>asext_tag</i>	(Optional)
<i>asext_ref_lstype</i>	(Optional)
<i>asext_ref_lsid</i>	(Optional)
<i>link_priority</i>	(Optional)
<i>link_options</i>	(Optional)
<i>link_num_prefix</i>	(Optional)
TABLE_linklsa	(Optional)
<i>link_prefix_options</i>	(Optional)
<i>intra_num_prefix</i>	(Optional)
<i>intra_ref_lstype</i>	(Optional)
<i>intra_ref_lsid</i>	(Optional)
<i>intra_ref_advrtr</i>	(Optional)
TABLE_iaplsa	(Optional)
<i>intra_prefix_options</i>	(Optional)
<i>intra_prefix_metric</i>	(Optional)
<i>corrupted_length</i>	(Optional)
<i>tlv_type</i>	(Optional)
<i>tlv_len</i>	(Optional)
<i>tlv_data</i>	(Optional)
<i>tlv_unknown</i>	(Optional)
<i>gr_interval</i>	(Optional)
<i>gr_reason</i>	(Optional)
<i>unknown</i>	(Optional)
<i>data_len</i>	(Optional)

<i>data</i>	(Optional)
-------------	------------

Command Mode

- /exec

show ospfv3 event-history

```
show ospfv3 [ <tag> ] [ internal ] event-history { errors | msgs | statistics | adjacency | event | ha | flooding |
lsa | spf | redistribution | hello | spf-trigger | cli | rib }
```

Syntax Description

show	Show running system information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
internal	(Optional) Commands for internal use
event-history	Show various event logs of OSPF
errors	Error logs
msgs	IPC logs
statistics	Show the state and size of the buffers
adjacency	Adjacency formation logs
event	Internal event logs
ha	HA and GR logs
flooding	LSA flooding logs
lsa	LSA generation and database logs
spf	SPF calculation logs
redistribution	Redistribution logs
hello	Hello related logs
spf-trigger	SPF TRIGGER related logs
cli	Cli logs
rib	RIB related logs

Command Mode

- /exec

show ospfv3 event-history detail

show ospfv3 [<tag>] [internal] event-history detail [statistics]

Syntax Description

show	Show running system information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
internal	(Optional) Commands for internal use
event-history	Show event history of OSPF
detail	Show detailed event history information
statistics	(Optional) Show the state and size of the verbose history buffer

Command Mode

- /exec

show ospfv3 interface

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] interface [ <interface> | vrf {
<vrf-name> | <vrf-known-name> | all } ] [ private ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_intf
<ifname> <admin_status> <proto_status> <addr> [ <masklen> ] [ <inst_id> ] <area> [ <if_cfg> ] <state_str>
<type_str> <cost> [ <bfd_enabled> ] <index> [ <passive> ] [ <mpls> ] [ <transmit_delay> ] [ <if_priority>
] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid> ] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [ <nbr_adj> ] [
<gr_nbr> ] [ <hello_interval> ] [ <dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [ <hello_timer>
] [ <wait_timer> ] [ <pacing_timer> ] [ <lsu_timer> ] [ <lsack_timer> ] [ <netlsa_throt_timer> ] [ <link_lsa_cnt>
] [ <link_lsa_crc> ] [ <ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
interface	OSPF enabled interface
interface	(Optional) OSPF enabled interface
private	(Optional) Developer-only statistics
__readonly__	(Optional)
TABLE_ctx	(Optional)
ptag	(Optional)
cname	(Optional)
TABLE_intf	(Optional)
ifname	(Optional)
admin_status	(Optional)
proto_status	(Optional)
masklen	(Optional)
inst_id	(Optional)

<i>area</i>	(Optional)
<i>if_cfg</i>	(Optional)
<i>state_str</i>	(Optional)
<i>type_str</i>	(Optional)
<i>cost</i>	(Optional)
<i>bfd_enabled</i>	(Optional)
<i>index</i>	(Optional)
<i>passive</i>	(Optional)
<i>mpls</i>	(Optional)
<i>transmit_delay</i>	(Optional)
<i>if_priority</i>	(Optional)
<i>dr_rid</i>	(Optional)
<i>bdr_rid</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>nbr_flood</i>	(Optional)
<i>nbr_adj</i>	(Optional)
<i>gr_nbr</i>	(Optional)
<i>hello_interval</i>	(Optional)
<i>dead_interval</i>	(Optional)
<i>wait_interval</i>	(Optional)
<i>rxmt_interval</i>	(Optional)
<i>hello_timer</i>	(Optional)
<i>wait_timer</i>	(Optional)
<i>pacing_timer</i>	(Optional)
<i>lsu_timer</i>	(Optional)
<i>lsack_timer</i>	(Optional)
<i>netlsa_throt_timer</i>	(Optional)
<i>link_lsa_cnt</i>	(Optional)
<i>link_lsa_crc</i>	(Optional)

<i>ipsec_sa_type</i>	(Optional) IPsec SA Type
<i>ipsec_sa_algorithm</i>	(Optional) IPsec SA Algorithm name
<i>ipsec_sa_spi</i>	(Optional) IPsec SA SPI Value

Command Mode

- /exec

show ospfv3 interface brief

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] interface brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> <intf_count> TABLE_intf <ifname> <index> <area> <cost> <state_str> <nbr_total> <admin_status> ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
interface	OSPF enabled interface
brief	Display summary of OSPFv3 interfaces
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>intf_count</i>	(Optional)
TABLE_intf	(Optional)
<i>ifname</i>	(Optional)
<i>index</i>	(Optional)
<i>area</i>	(Optional)
<i>cost</i>	(Optional)
<i>state_str</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>admin_status</i>	(Optional)

Command Mode

- /exec

show ospfv3 memory

```
show [ ipv6 ] ospfv3 [ <tag> ] memory [ __readonly__ TABLE_mem <ptag> <byte_total> <byte_consumed>
<byte_overhead> <byte_allocated> <alloc_current> <alloc_created> <alloc_failed> <alloc_free> <bf_current>
<bf_created> <bf_failed> <bf_free> <bf_byte_consumed> <bf_32_current> <bf_32_created> <bf_32_failed>
<bf_32_free> <bf_32_byte_consumed> <slab_current> <slab_created> <slab_failed> <slab_free>
<slab_byte_consumed> <if_index_alloc_failed> <nbr_index_alloc_failed> ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
memory	Memory usage statistics
<i>__readonly__</i>	(Optional)
TABLE_mem	(Optional)
<i>ptag</i>	(Optional)
<i>byte_total</i>	(Optional)
<i>byte_consumed</i>	(Optional)
<i>byte_overhead</i>	(Optional)
<i>byte_allocated</i>	(Optional)
<i>alloc_current</i>	(Optional)
<i>alloc_created</i>	(Optional)
<i>alloc_failed</i>	(Optional)
<i>alloc_free</i>	(Optional)
<i>bf_current</i>	(Optional)
<i>bf_created</i>	(Optional)
<i>bf_failed</i>	(Optional)
<i>bf_free</i>	(Optional)
<i>bf_byte_consumed</i>	(Optional)
<i>bf_32_current</i>	(Optional)
<i>bf_32_created</i>	(Optional)

<i>bf_32_failed</i>	(Optional)
<i>bf_32_free</i>	(Optional)
<i>bf_32_byte_consumed</i>	(Optional)
<i>slab_current</i>	(Optional)
<i>slab_created</i>	(Optional)
<i>slab_failed</i>	(Optional)
<i>slab_free</i>	(Optional)
<i>slab_byte_consumed</i>	(Optional)
<i>if_index_alloc_failed</i>	(Optional)
<i>nbr_index_alloc_failed</i>	(Optional)

Command Mode

- /exec

show ospfv3 neighbors

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] neighbors [ { { <interface> [
<neighbor> | <neighbor-name> ] } | { [ <neighbor> | <neighbor-name> ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] } } ] [ __readonly__ TABLE_ctx <ptag> <cname> <nbrcount> [ TABLE_nbr <rid> <priority> <state>
<drstate> <uptime> <ifid> <intf> [ <multiarea> ] <addr> ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
neighbors	Neighbor list
interface	(Optional) OSPF enabled interface
neighbor	(Optional) Router ID of neighbor
neighbor-name	(Optional) DNS Name of the neighbor
__readonly__	(Optional)
TABLE_ctx	(Optional)
ptag	(Optional)
cname	(Optional)
nbrcount	(Optional)
TABLE_nbr	(Optional)
rid	(Optional)
priority	(Optional)
state	(Optional)
drstate	(Optional)
uptime	(Optional)

<i>ifid</i>	(Optional)
<i>intf</i>	(Optional)
<i>multiarea</i>	(Optional)

Command Mode

- /exec

show ospfv3 neighbors detail

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] neighbors [ <interface> ] [
<neighbor> ] detail [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ private ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ TABLE_nbr <rid> <addr> <area> <intf> <state> <transition> <lastchange> [ <bfd_state>
] [ <priority> ] [ <ifid> ] [ <dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [ <dbdallsent> ] [
<dbdallacked> ] [ <lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] <helloptions> <dbdoptions>
<lastnonhello> [ <deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [ <lsutimer> ] [
<rerxmtimer> ] [ <fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [ <helpercand> ] [
<helperterm> ] [ <senddbd> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack> ] [
<sendlsreqreply> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
neighbors	Neighbor list
<i>interface</i>	(Optional) OSPF enabled interface
<i>neighbor</i>	(Optional) Router ID of neighbor
detail	Show detailed neighbor display
private	(Optional) Developer-only statistics
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_nbr	(Optional)
<i>rid</i>	(Optional)
<i>area</i>	(Optional)
<i>intf</i>	(Optional)

<i>state</i>	(Optional)
<i>transition</i>	(Optional)
<i>lastchange</i>	(Optional)
<i>bfd_state</i>	(Optional)
<i>priority</i>	(Optional)
<i>ifid</i>	(Optional)
<i>dr</i>	(Optional)
<i>bdr</i>	(Optional)
<i>master</i>	(Optional)
<i>seqno</i>	(Optional)
<i>dbdallsentacked</i>	(Optional)
<i>dbdallsent</i>	(Optional)
<i>dbdallacked</i>	(Optional)
<i>lsaonreqlist</i>	(Optional)
<i>lsafromlastreq</i>	(Optional)
<i>lsreqrxmts</i>	(Optional)
<i>helloptions</i>	(Optional)
<i>dbdoptions</i>	(Optional)
<i>lastnonhello</i>	(Optional)
<i>deadtimer</i>	(Optional)
<i>pacingt看mer</i>	(Optional)
<i>dbdrxmtimer</i>	(Optional)
<i>reqrxmtimer</i>	(Optional)
<i>lsutimer</i>	(Optional)
<i>rerxmtimer</i>	(Optional)
<i>fastrerxmtimer</i>	(Optional)
<i>lsacktimer</i>	(Optional)
<i>grtimer</i>	(Optional)
<i>helpermode</i>	(Optional)

<i>helpercand</i>	(Optional)
<i>helperterm</i>	(Optional)
<i>senddbd</i>	(Optional)
<i>sendsreq</i>	(Optional)
<i>sendsu</i>	(Optional)
<i>sendsurxmt</i>	(Optional)
<i>sendsack</i>	(Optional)
<i>sendsreqreply</i>	(Optional)

Command Mode

- /exec

show ospfv3 neighbors summary

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] neighbors [ <interface> ]
summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname>
TABLE_intf { <ifname> | <total> } <down> <attempt> <init> <twoway> <exstart> <exchange> <loading>
<full> <if_total> ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
neighbors	Neighbor list
<i>interface</i>	(Optional) OSPF enabled interface
summary	Summary of neighbors
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_intf	(Optional)
<i>ifname</i>	(Optional)
<i>total</i>	(Optional)
<i>down</i>	(Optional)
<i>attempt</i>	(Optional)
<i>init</i>	(Optional)
<i>twoway</i>	(Optional)
<i>exstart</i>	(Optional)

<i>exchange</i>	(Optional)
<i>loading</i>	(Optional)
<i>full</i>	(Optional)
<i>if_total</i>	(Optional)

Command Mode

- /exec

show ospfv3 policy statistics

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] policy statistics { { redistribute
{ bgp <as> | { isis | rip } <tag> | static | direct | amt } } | { area <area-id-ip> filter-list { in | out } } } [ vrf {
<vrf-name> | <vrf-known-name> | all } ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
policy	Display Policy related information
statistics	Display Route Filter statistics
redistribute	Statistics for redistribution
rip	Routing Information Protocol (RIP)
isis	ISO Intermediate-to-Intermediate (IS-IS)
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous system number
static	Static
direct	Directly connected
amt	AMT anycast prefix
area	Configure area properties
<i>area-id-ip</i>	Area Id as an integer or ip address
filter-list	Filter prefixes between OSPF areas
in	Filter networks sent to this area
out	Filter networks sent from this area
<i>tag</i>	

Command Mode

- /exec

show ospfv3 request-list

```
show [ ipv6 ] ospfv3 [ <tag> ] request-list { <ip-addr> | <neighbor-name> } <interface> [ __readonly__ [
TABLE_ctx <ptag> <cname> [ TABLE_lsreq <nbr_rid> <intf> <nbr_addr> <total> [ TABLE_lsa [ <type>
] [ <lsid> ] [ <advrtr> ] [ <seqno> ] [ <cksum> ] [ <age> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
request-list	Link state request list
<i>interface</i>	OSPF enabled interface
<i>ip-addr</i>	Neighbor router ID
<i>neighbor-name</i>	DNS Name of the neighbor
<i>__readonly__</i>	(Optional)
<i>TABLE_ctx</i>	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>TABLE_lsreq</i>	(Optional)
<i>nbr_rid</i>	(Optional)
<i>intf</i>	(Optional)
<i>total</i>	(Optional)
<i>TABLE_lsa</i>	(Optional)
<i>type</i>	(Optional)
<i>lsid</i>	(Optional)
<i>advrtr</i>	(Optional)
<i>seqno</i>	(Optional)
<i>cksum</i>	(Optional)
<i>age</i>	(Optional)

Command Mode

- /exec

show ospfv3 retransmission-list

```
show [ ipv6 ] ospfv3 [ <tag> ] retransmission-list { <routerid> | <router-name> } <interface> [ __readonly__
[ TABLE_ctx <ptag> <cname> [ TABLE_rxmit <nbr_rid> <intf> <nbr_addr> [ <timer_running> ] [
<timer_due> ] [ TABLE_lsa [ <type> ] [ <lsid> ] [ <advtr> ] [ <seqno> ] [ <cksum> ] [ <age> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
retransmission-list	Link state retransmission list
routerid	Neighbor router ID
router-name	DNS Name of the router
interface	OSPF enabled interface
__readonly__	(Optional)
TABLE_ctx	(Optional)
ptag	(Optional)
cname	(Optional)
TABLE_rxmit	(Optional)
nbr_rid	(Optional)
intf	(Optional)
timer_running	(Optional)
timer_due	(Optional)
TABLE_lsa	(Optional)
type	(Optional)
lsid	(Optional)
advtr	(Optional)
seqno	(Optional)
cksum	(Optional)
age	(Optional)

Command Mode

- /exec

show ospfv3 route

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] route [ <ipv6-prefix> [
longer-prefixes ] ] [ all_routes ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ <hdr_addr> ] [ <hdr_masklen> ] [ TABLE_route <addr> <masklen> <type> <in_rib>
<direct> [ <area> ] [ <tag> ] [ <vlink_unresolved> ] [ TABLE_route_ubest_nh [ <ubest_nh_addr> ] [
<ubest_nh_intf> ] [ <ubest_cost> ] [ <distance> ] [ <ubest_nh_direct> ] [ <ubest_nh_in_rib> ] ] [
TABLE_route_mbest_nh [ <mbest_nh_addr> ] [ <mbest_nh_intf> ] [ <mbest_cost> ] [ <mbest_nh_direct>
] [ <mbest_nh_in_rib> ] ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
route	Internal OSPF routes
longer-prefixes	(Optional) Show exact match and more specific routes
all_routes	(Optional) Display all OSPFv3 routes
<i>tag</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>hdr_masklen</i>	(Optional)
TABLE_route	(Optional)
<i>masklen</i>	(Optional)
<i>type</i>	(Optional)
<i>in_rib</i>	(Optional)
<i>direct</i>	(Optional)

<i>area</i>	(Optional)
<i>vlink_unresolved</i>	(Optional)
TABLE_route_ubest_nh	(Optional)
<i>ubest_nh_intf</i>	(Optional)
<i>ubest_cost</i>	(Optional)
<i>distance</i>	(Optional)
<i>ubest_nh_direct</i>	(Optional)
<i>ubest_nh_in_rib</i>	(Optional)
TABLE_route_mbest_nh	(Optional)
<i>mbest_nh_intf</i>	(Optional)
<i>mbest_cost</i>	(Optional)
<i>mbest_nh_direct</i>	(Optional)
<i>mbest_nh_in_rib</i>	(Optional)

Command Mode

- /exec

show ospfv3 route summary

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] route [ <ipv6-prefix> [
longer-prefixes ] ] summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ TABLE_route <total_routes> <total_paths> [ TABLE_route_type <path_type>
<path_routes> <path_paths> ] [ TABLE_route_masklen <masklen> <masklen_routes> <masklen_paths> ] ]
]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
route	Internal OSPF routes
longer-prefixes	(Optional) Show exact match and more specific routes
summary	Show route counts
__readonly__	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
TABLE_route	(Optional)
<i>total_routes</i>	(Optional)
<i>total_paths</i>	(Optional)
TABLE_route_type	(Optional)
<i>path_type</i>	(Optional)
<i>path_routes</i>	(Optional)
<i>path_paths</i>	(Optional)
TABLE_route_masklen	(Optional)

<i>masklen</i>	(Optional)
<i>masklen_routes</i>	(Optional)
<i>masklen_paths</i>	(Optional)

Command Mode

- /exec

show ospfv3 statistics

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_stats <ptag> <cname> <last_clear> <rid_change> <dr_elections> <older_lsa_recv> <nbr_state_change> <nbr_dead_postpone> <nbr_dead_expire> <nbr_bad_lsreq> <nbr_seqno_mismatch> <spf_full> <spf_summary> <spf_external> <spf_extsummary> <rtr_generate> <rtr_refresh> <rtr_flush> <rtr_other_flush> <net_generate> <net_refresh> <net_flush> <net_other_flush> <inter_prefix_generate> <inter_prefix_refresh> <inter_prefix_flush> <inter_prefix_other_flush> <inter_router_generate> <inter_router_refresh> <inter_router_flush> <inter_router_other_flush> <asext_generate> <asext_refresh> <asext_flush> <asext_other_flush> <link_generate> <link_refresh> <link_flush> <link_other_flush> <intra_prefix_generate> <intra_prefix_refresh> <intra_prefix_flush> <intra_prefix_other_flush> <unknown_generate> <unknown_refresh> <unknown_flush> <unknown_other_flush> <limbo_lsa_count> <limbo_lsa_hwm> <limbo_lsa_deleted> <limbo_lsa_revived> <limbo_runs> <limbo_lsa_last_time_hwm> [ <limbo_timer> ] <helloq_size> <helloq_max_size> <helloq_hwm> <helloq_drops> <helloq_last_hwm_time> <floodq_size> <floodq_max_size> <floodq_hwm> <floodq_drops> <floodq_last_hwm_time> <lsdb_add_fail> [ TABLE_buffer_detail [ <buf_size> ] [ <buf_size_huge> ] <buf_in_use> <buf_hwm> <buf_perm> <buf_alloc> <buf_free> ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
statistics	Event counters
__readonly__	(Optional)
TABLE_stats	(Optional)
ptag	(Optional)
cname	(Optional)
last_clear	(Optional)
rid_change	(Optional)
dr_elections	(Optional)
older_lsa_recv	(Optional)

<i>nbr_state_change</i>	(Optional)
<i>nbr_dead_postpone</i>	(Optional)
<i>nbr_dead_expire</i>	(Optional)
<i>nbr_bad_lsreq</i>	(Optional)
<i>nbr_seqno_mismatch</i>	(Optional)
<i>spf_full</i>	(Optional)
<i>spf_summary</i>	(Optional)
<i>spf_external</i>	(Optional)
<i>spf_extsummary</i>	(Optional)
<i>rtr_generate</i>	(Optional)
<i>rtr_refresh</i>	(Optional)
<i>rtr_flush</i>	(Optional)
<i>rtr_other_flush</i>	(Optional)
<i>net_generate</i>	(Optional)
<i>net_refresh</i>	(Optional)
<i>net_flush</i>	(Optional)
<i>net_other_flush</i>	(Optional)
<i>inter_prefix_generate</i>	(Optional)
<i>inter_prefix_refresh</i>	(Optional)
<i>inter_prefix_flush</i>	(Optional)
<i>inter_prefix_other_flush</i>	(Optional)
<i>inter_router_generate</i>	(Optional)
<i>inter_router_refresh</i>	(Optional)
<i>inter_router_flush</i>	(Optional)
<i>inter_router_other_flush</i>	(Optional)
<i>asext_generate</i>	(Optional)
<i>asext_refresh</i>	(Optional)
<i>asext_flush</i>	(Optional)
<i>asext_other_flush</i>	(Optional)

<i>link_generate</i>	(Optional)
<i>link_refresh</i>	(Optional)
<i>link_flush</i>	(Optional)
<i>link_other_flush</i>	(Optional)
<i>intra_prefix_generate</i>	(Optional)
<i>intra_prefix_refresh</i>	(Optional)
<i>intra_prefix_flush</i>	(Optional)
<i>intra_prefix_other_flush</i>	(Optional)
<i>unknown_generate</i>	(Optional)
<i>unknown_refresh</i>	(Optional)
<i>unknown_flush</i>	(Optional)
<i>unknown_other_flush</i>	(Optional)
<i>limbo_lsa_count</i>	(Optional)
<i>limbo_lsa_hwm</i>	(Optional)
<i>limbo_lsa_deleted</i>	(Optional)
<i>limbo_lsa_revived</i>	(Optional)
<i>limbo_runs</i>	(Optional)
<i>limbo_lsa_last_time_hwm</i>	(Optional)
<i>limbo_timer</i>	(Optional)
<i>helloq_size</i>	(Optional)
<i>helloq_max_size</i>	(Optional)
<i>helloq_hwm</i>	(Optional)
<i>helloq_drops</i>	(Optional)
<i>helloq_last_hwm_time</i>	(Optional)
<i>floodq_size</i>	(Optional)
<i>floodq_max_size</i>	(Optional)
<i>floodq_hwm</i>	(Optional)
<i>floodq_drops</i>	(Optional)
<i>floodq_last_hwm_time</i>	(Optional)

<i>lsdb_add_fail</i>	(Optional)
TABLE_buffer_detail	(Optional)
<i>buf_size</i>	(Optional)
<i>buf_size_huge</i>	(Optional)
<i>buf_in_use</i>	(Optional)
<i>buf_hwm</i>	(Optional)
<i>buf_perm</i>	(Optional)
<i>buf_alloc</i>	(Optional)
<i>buf_free</i>	(Optional)

Command Mode

- /exec

show ospfv3 summary-address

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] summary-address [ private ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_ctx <ptag> <cname> <rid> [
TABLE_sum <addr> <masklen> [ <metric> ] [ <tag> ] [ <pending> ] ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
summary-address	Summary-address redistribution information
private	(Optional) Developer-only statistics
<i>tag</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>rid</i>	(Optional)
TABLE_sum	(Optional)
<i>masklen</i>	(Optional)
<i>metric</i>	(Optional)
<i>pending</i>	(Optional)

Command Mode

- /exec

show ospfv3 traffic

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] traffic [ <interface> [ detail ]
| [ detail ] | [ detail ] vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_traf <ptag>
<cname> <last_clear> [ <ifname> ] <pkt_in> <pkt_out> <lsu_first_trans> <lsu_retrans> <lsu_for_lsreq>
<lsu_nbr_trans> <throttle_out> <throttle_out_token> <throttle_out_ip> <lsa_ignored> <lsa_dropped_spf>
<lsa_dropped_gr> <pkt_drops_in> <pkt_drops_out> <pkt_errors_in> <pkt_errors_out> <hello_errors_in>
<dbds_errors_in> <lsreqs_errors_in> <lsus_errors_in> <lsacks_errors_in> <pkt_unknown_in>
<pkt_unknown_out> <pkt_no_ospf_intf> <bad_version> <bad_crc> <dup_rtr_id> <dup_src_addr>
<invalid_src_addr> <invalid_dst_addr> <non_existing_nbr> <pkt_passive_intf> <wrong_area>
<invalid_pkt_len> <nbr_changed_routerid_ipaddr> <nbr_changed_interfaceid> [ <bad_auth> ] [
<bad_reserved> ] [ <pkt_no_vrf> ] <hello_in> <dbds_in> <lsreqs_in> <lsus_in> <lsacks_in> <hello_out>
<dbds_out> <lsreqs_out> <lsus_out> <lsacks_out> [ <hello_in_hq> <dbds_in_hq> <lsreqs_in_flq>
<lsus_in_flq> <lsacks_in_flq> <lsas_in_dbds_in> <lsas_in_lsreqs_in> <lsas_in_lsus_in> <lsas_in_lsacks_in>
<lsas_in_dbds_out> <lsas_in_lsreqs_out> <lsas_in_lsus_out> <lsas_in_lsacks_out> <lsas_in_rxmt_lsus_out>
] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
interface	(Optional) OSPF enabled interface
detail	(Optional) Display detailed information
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
traffic	Packet counters
__readonly__	(Optional)
TABLE_traf	(Optional)
ptag	(Optional)
cname	(Optional)
last_clear	(Optional)
ifname	(Optional)
pkt_in	(Optional)

<i>pkt_out</i>	(Optional)
<i>lsu_first_trans</i>	(Optional)
<i>lsu_retrans</i>	(Optional)
<i>lsu_for_lsreq</i>	(Optional)
<i>lsu_nbr_trans</i>	(Optional)
<i>throttle_out</i>	(Optional)
<i>throttle_out_token</i>	(Optional)
<i>throttle_out_ip</i>	(Optional)
<i>lsa_ignored</i>	(Optional)
<i>lsa_dropped_spf</i>	(Optional)
<i>lsa_dropped_gr</i>	(Optional)
<i>pkt_drops_in</i>	(Optional)
<i>pkt_drops_out</i>	(Optional)
<i>pkt_errors_in</i>	(Optional)
<i>pkt_errors_out</i>	(Optional)
<i>hello_errors_in</i>	(Optional)
<i>dbds_errors_in</i>	(Optional)
<i>lsreqs_errors_in</i>	(Optional)
<i>lsus_errors_in</i>	(Optional)
<i>lsacks_errors_in</i>	(Optional)
<i>pkt_unknown_in</i>	(Optional)
<i>pkt_unknown_out</i>	(Optional)
<i>pkt_no_ospf_intf</i>	(Optional)
<i>bad_version</i>	(Optional)
<i>bad_crc</i>	(Optional)
<i>dup_rtr_id</i>	(Optional)
<i>dup_src_addr</i>	(Optional)
<i>invalid_src_addr</i>	(Optional)
<i>invalid_dst_addr</i>	(Optional)

<i>non_existing_nbr</i>	(Optional)
<i>pkt_passive_intf</i>	(Optional)
<i>wrong_area</i>	(Optional)
<i>invalid_pkt_len</i>	(Optional)
<i>nbr_changed_routerid_ipaddr</i>	(Optional)
<i>nbr_changed_interfaceid</i>	(Optional)
<i>bad_auth</i>	(Optional)
<i>bad_reserved</i>	(Optional)
<i>pkt_no_vrf</i>	(Optional)
<i>hellos_in</i>	(Optional)
<i>dbds_in</i>	(Optional)
<i>lsreqs_in</i>	(Optional)
<i>lsus_in</i>	(Optional)
<i>lsacks_in</i>	(Optional)
<i>hellos_out</i>	(Optional)
<i>dbds_out</i>	(Optional)
<i>lsreqs_out</i>	(Optional)
<i>lsus_out</i>	(Optional)
<i>lsacks_out</i>	(Optional)
<i>hellos_in_hq</i>	(Optional)
<i>dbds_in_hq</i>	(Optional)
<i>lsreqs_in_flq</i>	(Optional)
<i>lsus_in_flq</i>	(Optional)
<i>lsacks_in_flq</i>	(Optional)
<i>lsas_in_dbds_in</i>	(Optional)
<i>lsas_in_lsreqs_in</i>	(Optional)
<i>lsas_in_lsus_in</i>	(Optional)
<i>lsas_in_lsacks_in</i>	(Optional)
<i>lsas_in_dbds_out</i>	(Optional)

<i>lsas_in_lsreqs_out</i>	(Optional)
<i>lsas_in_lsus_out</i>	(Optional)
<i>lsas_in_lsacks_out</i>	(Optional)
<i>lsas_in_rxmt_lsus_out</i>	(Optional)

Command Mode

- /exec

show ospfv3 virtual-links

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] virtual-links [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_vlink <name> <nbr_rid>
<if_state> <transit_area> <nh_intf> <nbr_addr> [ <transit_area_stub> ] [ <transit_area_nssa> ] <addr> [
<masklen> ] <inst_id> <area> [ <if_cfg> ] <state_str> <type_str> <cost> <index> [ <passive> ] [ <mpls> ]
[ <transmit_delay> ] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid> ] [ <bdr_addr> ] [ <nbr_total> ]
[ <nbr_flood> ] [ <nbr_adjst> ] [ <gr_nbr> ] [ <hello_interval> ] [ <dead_interval> ] [ <wait_interval> ] [
<rxmt_interval> ] [ <hello_timer> ] [ <wait_timer> ] [ <pacing_timer> ] [ <lsu_timer> ] [ <lsack_timer> ] [
<netlsa_throt_timer> ] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] [ <state> ] [ <transition> ] [ <lastchange> ] [
<priority> ] [ <ifid> ] [ <dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [ <dbdallsent> ] [
<dbdallacked> ] [ <lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] [ <hellooptions> ] [ <dbdoptions> ] [
<lastnonhello> ] [ <deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [ <lsutimer> ] [
<rerxmtimer> ] [ <fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [ <helpercand> ] [
<helperterm> ] [ <senddbd> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack> ] [
<sendlsreqreply> ] [ <ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
tag	(Optional) Process tag
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
virtual-links	Virtual link information
__readonly__	(Optional)
TABLE_ctx	(Optional)
ptag	(Optional)
cname	(Optional)
TABLE_vlink	(Optional)
name	(Optional)
nbr_rid	(Optional)
if_state	(Optional)
transit_area	(Optional)

<i>nh_intf</i>	(Optional)
<i>transit_area_stub</i>	(Optional)
<i>transit_area_nssa</i>	(Optional)
<i>masklen</i>	(Optional)
<i>inst_id</i>	(Optional)
<i>area</i>	(Optional)
<i>if_cfg</i>	(Optional)
<i>state_str</i>	(Optional)
<i>type_str</i>	(Optional)
<i>cost</i>	(Optional)
<i>index</i>	(Optional)
<i>passive</i>	(Optional)
<i>mpls</i>	(Optional)
<i>transmit_delay</i>	(Optional)
<i>if_priority</i>	(Optional)
<i>dr_rid</i>	(Optional)
<i>bdr_rid</i>	(Optional)
<i>nbr_total</i>	(Optional)
<i>nbr_flood</i>	(Optional)
<i>nbr_adj</i>	(Optional)
<i>gr_nbr</i>	(Optional)
<i>hello_interval</i>	(Optional)
<i>dead_interval</i>	(Optional)
<i>wait_interval</i>	(Optional)
<i>rxmt_interval</i>	(Optional)
<i>hello_timer</i>	(Optional)
<i>wait_timer</i>	(Optional)
<i>pacing_timer</i>	(Optional)
<i>lsu_timer</i>	(Optional)

<i>lsack_timer</i>	(Optional)
<i>netlsa_throt_timer</i>	(Optional)
<i>link_lsa_cnt</i>	(Optional)
<i>link_lsa_crc</i>	(Optional)
<i>state</i>	(Optional)
<i>transition</i>	(Optional)
<i>lastchange</i>	(Optional)
<i>priority</i>	(Optional)
<i>ifid</i>	(Optional)
<i>dr</i>	(Optional)
<i>bdr</i>	(Optional)
<i>master</i>	(Optional)
<i>seqno</i>	(Optional)
<i>dbdallsentacked</i>	(Optional)
<i>dbdallsent</i>	(Optional)
<i>dbdallacked</i>	(Optional)
<i>lsaonreqlist</i>	(Optional)
<i>lsafromlastreq</i>	(Optional)
<i>lsreqrxmts</i>	(Optional)
<i>helloptions</i>	(Optional)
<i>dbdoptions</i>	(Optional)
<i>lastnonhello</i>	(Optional)
<i>deadtimer</i>	(Optional)
<i>pacingtmer</i>	(Optional)
<i>dbdrxmtimer</i>	(Optional)
<i>reqrxmtimer</i>	(Optional)
<i>lsutimer</i>	(Optional)
<i>rerxmtimer</i>	(Optional)
<i>fastrerxmtimer</i>	(Optional)

<i>lsacktimer</i>	(Optional)
<i>grtimer</i>	(Optional)
<i>helpermode</i>	(Optional)
<i>helpercand</i>	(Optional)
<i>helperterm</i>	(Optional)
<i>senddbd</i>	(Optional)
<i>sendslreq</i>	(Optional)
<i>sendslu</i>	(Optional)
<i>sendsurxmt</i>	(Optional)
<i>sendsack</i>	(Optional)
<i>sendsreqreply</i>	(Optional)
<i>ipsec_sa_type</i>	(Optional) IPsec SA Type
<i>ipsec_sa_algorithm</i>	(Optional) IPsec SA Algorithm name
<i>ipsec_sa_spi</i>	(Optional) IPsec SA SPI Value

Command Mode

- /exec

show ospfv3 virtual-links brief

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] virtual-links brief [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> <vlink_count> [
TABLE_vlink <nbr_rid> <vlink_num> <transit_area> <cost> <if_state> ] ]
```

Syntax Description

show	Show running system information
ipv6	(Optional) Display IPv6 information
ospfv3	Display OSPFv3 status and configuration
<i>tag</i>	(Optional) Process tag
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
virtual-links	Virtual link information
brief	Display summary of OSPFv3 virtual links
<i>__readonly__</i>	(Optional)
TABLE_ctx	(Optional)
<i>ptag</i>	(Optional)
<i>cname</i>	(Optional)
<i>vlink_count</i>	(Optional)
TABLE_vlink	(Optional)
<i>nbr_rid</i>	(Optional)
<i>vlink_num</i>	(Optional)
<i>transit_area</i>	(Optional)
<i>cost</i>	(Optional)
<i>if_state</i>	(Optional)

Command Mode

- /exec



P Show Commands

- [show param-list](#), on page 1908
- [show password secure-mode](#), on page 1909
- [show password strength-check](#), on page 1910
- [show pending](#), on page 1911
- [show plb](#), on page 1912
- [show plb analytics](#), on page 1916
- [show plb vrf](#), on page 1918
- [show pmap-int-br interface br](#), on page 1919
- [show pmap-int](#), on page 1920
- [show policy-map](#), on page 1921
- [show policy-map interface control-plane](#), on page 1925
- [show policy-map system](#), on page 1928
- [show policy-map type control-plane](#), on page 1932
- [show policy-map type network-qos](#), on page 1935
- [show port-channel capacity](#), on page 1937
- [show port-channel compatibility-parameters](#), on page 1938
- [show port-channel database](#), on page 1939
- [show port-channel fast-convergence](#), on page 1941
- [show port-channel load-balance](#), on page 1942
- [show port-channel load-balance forwarding-path1 interface src-interface](#), on page 1943
- [show port-channel load-balance forwarding-path interface](#), on page 1945
- [show port-channel load-balance hardware forwarding-path interface source](#), on page 1947
- [show port-channel rbh-distribution](#), on page 1949
- [show port-channel scale-fanout](#), on page 1950
- [show port-channel summary](#), on page 1951
- [show port-channel traffic](#), on page 1952
- [show port-channel usage](#), on page 1953
- [show port-license](#), on page 1954
- [show port-profile](#), on page 1955
- [show port-profile brief](#), on page 1957
- [show port-profile expand-interface](#), on page 1958
- [show port-profile sync-status](#), on page 1959
- [show port-profile usage](#), on page 1960

- [show port-security](#), on page 1961
- [show port-security address](#), on page 1962
- [show port-security address interface](#), on page 1963
- [show port-security interface](#), on page 1964
- [show port-security state](#), on page 1965
- [show port naming](#), on page 1966
- [show postcard-telemetry exporter](#), on page 1967
- [show postcard-telemetry flow-profile](#), on page 1968
- [show postcard-telemetry monitor](#), on page 1969
- [show postcard-telemetry queue-profile](#), on page 1970
- [show postcard-telemetry sessions](#), on page 1971
- [show postcard-telemetry watchlist](#), on page 1972
- [show power inline](#), on page 1973
- [show power inline](#), on page 1974
- [show power inline police](#), on page 1975
- [show power inline priority](#), on page 1976
- [show privilege](#), on page 1977
- [show processes](#), on page 1978
- [show processes cpu](#), on page 1979
- [show processes cpu history](#), on page 1980
- [show processes cpu history data](#), on page 1981
- [show processes cpu module](#), on page 1982
- [show processes log](#), on page 1983
- [show processes log details](#), on page 1984
- [show processes log pid](#), on page 1985
- [show processes log vdc-all](#), on page 1986
- [show processes memory](#), on page 1987
- [show processes memory physical](#), on page 1988
- [show processes memory shared](#), on page 1989
- [show processes vdc](#), on page 1992
- [show processes vdc cpu](#), on page 1993
- [show processes vdc log](#), on page 1994
- [show processes vdc log details](#), on page 1995
- [show processes vdc log pid](#), on page 1996
- [show processes vdc memory](#), on page 1997
- [show processes version](#), on page 1998
- [show pss debug](#), on page 1999
- [show ptp brief](#), on page 2000
- [show ptp clock](#), on page 2001
- [show ptp clock foreign-masters record](#), on page 2003
- [show ptp corrections](#), on page 2004
- [show ptp cost](#), on page 2005
- [show ptp counters interface](#), on page 2006
- [show ptp delay summary](#), on page 2007
- [show ptp domain data](#), on page 2008
- [show ptp interface domain](#), on page 2009

- [show ptp packet-trace](#), on page 2010
- [show ptp parent](#), on page 2011
- [show ptp port interface](#), on page 2012
- [show ptp time-property](#), on page 2014

show param-list

```
show param-list [ param-list-name <plistname> ] [ show-instance ] [ __readonly__ <param_list_header_flag>
<param_list_name> <param_list_var> <param_list_type> <param_instance_header_flag>
<param_instance_name> <param_instance_var> <param_instance_val> ]
```

Syntax Description

show	Show running system information
param-list	Show param-list
param-list-name	(Optional) param list name
<i>plistname</i>	(Optional) Enter the name of the param-list
show-instance	(Optional) show instances for the param list
<i>__readonly__</i>	(Optional)
<i>param_list_header_flag</i>	(Optional)
<i>param_list_name</i>	(Optional)
<i>param_list_var</i>	(Optional)
<i>param_list_type</i>	(Optional)
<i>param_instance_header_flag</i>	(Optional)
<i>param_instance_name</i>	(Optional)
<i>param_instance_var</i>	(Optional)
<i>param_instance_val</i>	(Optional)

Command Mode

- /exec

show password secure-mode

```
show password secure-mode [ __readonly__ { secure_mode <secure_mode_status> } ]
```

Syntax Description

show	Show running system information
password	Password for the user
secure-mode	secure mode for changing passwords
__readonly__	(Optional)
secure_mode	(Optional) run time status about xml
<i>secure_mode_status</i>	(Optional) Run time status about secure mode

Command Mode

- /exec

show password strength-check

show password strength-check [__readonly__ { operation_status <o_status> }]

Syntax Description

show	Show running system information
password	Password for the user
strength-check	Strength check of password
__readonly__	(Optional)
operation_status	(Optional) run-time information about password strength-check
<i>o_status</i>	(Optional) operational status of password strength check

Command Mode

- /exec

show pending

show [pending]

Syntax Description

show	Display region configurations
pending	(Optional) Display the new mst configuration to be applied

Command Mode

- /exec/configure/spanning-tree/mst/configuration

<i>src_interface</i>	(Optional) source interface for probe
<i>state</i>	(Optional) state
<i>buckets</i>	(Optional) buckets
<i>reason</i>	(Optional) inactive reason
<i>vrf_name</i>	(Optional) VRF-Name
<i>excl_acl</i>	(Optional) exclude access-list
TABLE_device	(Optional)
<i>device_grp</i>	(Optional) service device group
<i>dg_probe</i>	(Optional) probe type
<i>dg_probe_port</i>	(Optional) probe port
TABLE_route_map	(Optional)
<i>route_map</i>	(Optional) service route map
<i>interface</i>	(Optional) interface
<i>r_status</i>	(Optional) route map status
TABLE_vip	(Optional)
<i>vip_ip</i>	(Optional) vip ip
<i>vip_probe</i>	(Optional) vip protocol
<i>vip_port</i>	(Optional) vip port
<i>vip_dgname</i>	(Optional) vip device group
<i>ace_name</i>	(Optional) ace information
<i>ace_seq</i>	(Optional) ace information
<i>ace_ip</i>	(Optional) ace information
<i>ace_protocol</i>	(Optional) ace information
<i>ace_port</i>	(Optional) ace information
TABLE_vip_node	(Optional)
<i>vip_node</i>	(Optional) service node ip
<i>vip_nodev6</i>	(Optional) service node IPv6
<i>vip_config</i>	(Optional) node config
<i>vip_weight</i>	(Optional) node weight

<i>vip_status</i>	(Optional) node status
<i>vip_node_probe</i>	(Optional) node probe type
<i>vip_node_probe_port</i>	(Optional) node probe port
<i>vip_node_probe_ip</i>	(Optional) node probe ip
<i>vip_track_id</i>	(Optional) node track id
<i>vip_ip_sla_id</i>	(Optional) node ip sla id
TABLE_vip_standby	(Optional)
<i>vip_standby_ip</i>	(Optional) standby node ip
<i>vip_standby_ipv6</i>	(Optional) standby node ipv6
<i>vip_standby_config</i>	(Optional) standby node config
<i>vip_standby_weight</i>	(Optional) standby node weight
<i>vip_standby_status</i>	(Optional) standby node status
<i>vip_standby_probe</i>	(Optional) standby node probe type
<i>vip_standby_probe_port</i>	(Optional) standby node probe port
<i>vip_standby_probe_ip</i>	(Optional) standby node probe ip
<i>vip_standby_track_id</i>	(Optional) standby node track id
<i>vip_standby_sla_id</i>	(Optional) standby node sla id
TABLE_vip_acl	(Optional)
<i>vip_access_list</i>	(Optional) access list
TABLE_node	(Optional)
<i>node</i>	(Optional) service node ip
<i>nodev6</i>	(Optional) service node IPv6
<i>config</i>	(Optional) node config
<i>weight</i>	(Optional) node weight
<i>status</i>	(Optional) node status
<i>node_probe</i>	(Optional) node probe type
<i>node_probe_port</i>	(Optional) node probe port
<i>node_probe_ip</i>	(Optional) node probe ip
<i>track_id</i>	(Optional) node track id

<i>ip_sla_id</i>	(Optional) node ip sla id
TABLE_standby	(Optional)
<i>standby_ip</i>	(Optional) standby node ip
<i>standby_ipv6</i>	(Optional) standby node ipv6
<i>standby_config</i>	(Optional) standby node config
<i>standby_weight</i>	(Optional) standby node weight
<i>standby_status</i>	(Optional) standby node status
<i>standby_probe</i>	(Optional) standby node probe type
<i>standby_probe_port</i>	(Optional) standby node probe port
<i>standby_probe_ip</i>	(Optional) standby node probe ip
<i>standby_track_id</i>	(Optional) standby node track id
<i>standby_sla_id</i>	(Optional) standby node sla id
TABLE_acl	(Optional)
<i>access_list</i>	(Optional) access list

Command Mode

- /exec

show plb analytics

```
show plb analytics [ service <service-name> ] [ src { <sip> | <sipv6> } | node { <nip> | <nipv6> } | vip {
<vip> | <vipv6> } | device-group <group-name> ] [ brief ] [ __readonly__ <plbshowinfo-stats-svc-hdr> [
TABLE_stats_svc <plbshowinfo-stats-service_name> <plbshowinfo-stats-dev-grp> <plbshowinfo-stats-vip>
<plbshowinfo-stats-vip-pkts> <plbshowinfo-stats-vip-pkts-percentage> [ <plbshowinfo-stats-ace-seq> ] [
<plbshowinfo-stats-ace-ip> ] <plbshowinfo-stats-bkt-hdr> [ TABLE_stats_bkt <plbshowinfo-stats-acl> [
<plbshowinfo-stats-oper-node> ] <plbshowinfo-stats-node-mode> <plbshowinfo-stats-orig-node>
<plbshowinfo-stats-node-pkts> <plbshowinfo-stats-node-pkts-percentage> [ <plbshowinfo-stats-acl-pkts> ]
[ <plbshowinfo-for-ace> ] ] ] <plb-show-end> [ <plb-true-end> ] ]
```

Syntax Description

show	Show running system information
plb	PLB service
analytics	PLB analytics information
service	(Optional) PLB analytics for specific service
<i>service-name</i>	(Optional) Specify plb service name
src	(Optional) Analytics information for source (bucket) ip
node	(Optional) Analytics information for destination device group node/server ip
vip	(Optional) Analytics information for virtual ip
device-group	(Optional) Analytics information of specified device group
<i>group-name</i>	(Optional) Specify device group name
<i>sip</i>	(Optional) Specify source ipv4 address
<i>nip</i>	(Optional) Specify destination ipv4 address
<i>vip</i>	(Optional) Specify virtual ipv4 address
brief	(Optional) Brief analytics information
<i>__readonly__</i>	(Optional) Read Only
<i>plbshowinfo-stats-svc-hdr</i>	(Optional) PLB analytics service header
TABLE_stats_svc	(Optional) plb stats service
<i>plbshowinfo-stats-service_name</i>	(Optional) PLB analytics service name
<i>plbshowinfo-stats-dev-grp</i>	(Optional) PLB analytics device group
<i>plbshowinfo-stats-vip</i>	(Optional) PLB analytics VIP IP
<i>plbshowinfo-stats-vip-pkts</i>	(Optional) PLB analytics virtual ip pkt_count

<i>plbshowinfo-stats-vip-pkts-percentage</i>	(Optional) PLB analytics virtual ip pkts percentage
<i>plbshowinfo-stats-ace-seq</i>	(Optional) PLB analytics ACE name and sequence number
<i>plbshowinfo-stats-ace-ip</i>	(Optional) PLB analytics ACE ip/mask/prefix
<i>plbshowinfo-stats-bkt-hdr</i>	(Optional) PLB analytics bucket header
TABLE_stats_bkt	(Optional) plb stats bucket
<i>plbshowinfo-stats-acl</i>	(Optional) PLB analytics bucket/acl name
<i>plbshowinfo-stats-oper-node</i>	(Optional) PLB analytics Operational node ip
<i>plbshowinfo-stats-node-mode</i>	(Optional) PLB analytics node mode
<i>plbshowinfo-stats-orig-node</i>	(Optional) PLB analytics Original node ip
<i>plbshowinfo-stats-node-pkts</i>	(Optional) PLB analytics node pkts count
<i>plbshowinfo-stats-node-pkts-percentage</i>	(Optional) PLB analytics node pkts percentage
<i>plbshowinfo-stats-acl-pkts</i>	(Optional) PLB analytics acl pkts
<i>plbshowinfo-for-ace</i>	(Optional) PLB analytics for ACE
<i>plb-show-end</i>	(Optional) Show plb end marker
<i>plb-true-end</i>	(Optional) show plb true end marker

Command Mode

- /exec

show plb vrf

```
show plb vrf [ <vrf-name> ] [ __readonly__ <plbshowinfo-vrf-hdr> { TABLE_svc
<plbshowinfo-vrf-service_name> <plbshowinfo-vrf-name> <plbshowinfo-vrf-id> } <plb-show-end> [
<plb-true-end> ] ]
```

Syntax Description

show	Show running system information
plb	PLB service
vrf	PLB service vrf
<i>vrf-name</i>	(Optional) VRF name
<i>__readonly__</i>	(Optional) Read Only
<i>plbshowinfo-vrf-hdr</i>	(Optional) PLB info vrf header
TABLE_svc	(Optional) PLB Service VRF details
<i>plbshowinfo-vrf-service_name</i>	(Optional) PLB service name
<i>plbshowinfo-vrf-name</i>	(Optional) PLB vrf name
<i>plbshowinfo-vrf-id</i>	(Optional) PLB vrf id
<i>plb-show-end</i>	(Optional) Show plb end marker
<i>plb-true-end</i>	(Optional) show plb true end marker

Command Mode

- /exec

show pmap-int-br interface br

```
show pmap-int-br interface br [ __readonly__ { [ TABLE_ifvlanstr <if-vlan-str> <if-status> [ <in-pmap-qos>
] [ <out-pmap-qos> ] [ <in-pmap-que> ] [ <out-pmap-que> ] ] } ]
```

Syntax Description

show	Show running system information
pmap-int-br	Show policy maps
interface	Show service policy on interface
br	Brief report of all policies attached to interfaces
TABLE_ifvlanstr	(Optional) all interfaces xml sessions
<i>if-vlan-str</i>	(Optional) ifindex or vlan id: xml key
<i>__readonly__</i>	(Optional)
<i>if-status</i>	(Optional) Interface/vlan status [active/inactive]: xml key
<i>in-pmap-qos</i>	(Optional) Input QoS Policy-map name: xml key
<i>out-pmap-qos</i>	(Optional) output QoS Policy-map name: xml key
<i>in-pmap-que</i>	(Optional) Input Que Policy-map name: xml key
<i>out-pmap-que</i>	(Optional) Output Que Policy-map name: xml key

Command Mode

- /exec

show pmap-int

show pmap-int { interface [<iface-list>] [input | output] [type <qos-or-q>] [detail] |

Syntax Description

show	Show running system information
pmap-int	Show policy maps
interface	Show service policy on interface
<i>iface-list</i>	(Optional) List of Interface
input	(Optional) Input Service policy
output	(Optional) Output Service policy
type	(Optional) Type of policy
<i>qos-or-q</i>	(Optional)
detail	(Optional) Detailed QoS or Queuing statistics

Command Mode

- /exec

show policy-map

```
show policy-map [ { [ type qos ] [ <pmap-name-qos> ] } | { type queuing [ <pmap-name-que> ] } ] [
__readonly__ { [ <display-all> ] [ TABLE_pmap <pmap-key> [ <type-spec> ] [ <yqos-or-q> ] [ <options>
] <pmap-name-out> [ <desc> ] [ TABLE_cmap <cmap-key> [ <type-cmap-spec> ] [ <xqos-or-q> ] [
<cmap-name> ] [ TABLE_action <action-key> [ <serv-pol-type> ] [ <serv-pol-name> ] [ <inner> ] [
<dlb-disable> ] [ <cos> ] [ <exp-val-imposition> ] [ <exp-val-topmost> ] [ <dscp-enum> ] [ <dscp> ] [
<prec-enum> ] [ <prec> ] [ <disc-class> ] [ <qos-group> ] [ <tmap-from> ] [ <tmap-to> ] [ <tmap-name> ] [
<avg-rate-type> ] [ <rate-units> ] [ <shape-rate> ] [ <min-rate-type> ] [ <min-rate-units> ] [ <shape-min-rate>
] [ <max-rate-type> ] [ <max-rate-units> ] [ <shape-max-rate> ] [ <rise-threshold-units> ] [
<fall-threshold-units> ] [ <prio-level> ] [ <qlim-param-type> ] [ <qlim-param-val> ] [ <ooo> ] [ <size-units>
] [ <qlim-size> ] [ <qlim-enum-spec> ] [ <rdet-agg> ] [ <rdet-mode> ] [ <rdet-burst-opt> ] [ <rdet-mesh-opt>
] [ <rdet-ecn> ] [ TABLE_rdet <rdet-key> [ <rdet-values> ] [ <rdet-min-thresh> ] [ <rdet-size-units> ] [
<rdet-max-thresh> ] [ <rdet-drop-prob> ] [ <rdet-weight> ] [ <rdet-cap-average> ] [ <rdet-nonecn-mode> ]
[ TABLE_rdet_nonecn <rdet-nonecn-key> [ <rdet-nonecn-min-thresh> ] [ <rdet-nonecn-size-units> ] [
<rdet-nonecn-max-thresh> ] [ <rdet-nonecn-drop-prob> ] ] [ <afd-mode> ] [ TABLE_afd <afd-key> [
<afd-values> ] [ <afd-queue-desired> ] [ <afd-size-units> ] [ <afd-ecn> ] ] [ <pause> <size-in-bytes>
<xoff-bytes> <xon-bytes> ] [ <priority-group-number> ] [ <bw-units> ] [ <bw-rate> ] [ <rem-bw-units> ] [
<rem-bw-rate> ] [ <agg-policer-name> ] [ <cir-spec> ] [ <bc-spec> ] [ <be-spec> ] [ <cir-rate-units> ] [ <cir>
] [ <bc-size-units> ] [ <bc> ] [ <pir-rate-units> ] [ <pir> ] [ <be-size-units> ] [ <be> ] [ <cnf-col-cmap> ] [
<exc-col-cmap> ] [ TABLE_police <police-key> [ <cnf-act> ] [ <exc-act> ] [ <vio-act> ] [ <set-type> ] [
<enum-spec> ] [ <set-val> ] [ <ptmap-from> ] [ <ptmap-to> ] [ <ptmap-name> ] ] [ <burst-detect-enable> ]
] ] ] }
```

Syntax Description

show	Show running system information
policy-map	Show policy maps
type	(Optional) Type of the policy-map
qos	(Optional) type qos
queuing	(Optional) type queuing
<i>pmap-name-qos</i>	(Optional) policy map name (type qos)
<i>pmap-name-que</i>	(Optional) policy map name (type queuing)
<i>__readonly__</i>	(Optional)
<i>display-all</i>	(Optional) Display all kinds of class-maps
TABLE_pmap	(Optional) all pmap xml sessions
<i>pmap-key</i>	(Optional) Policy-map name: xml key
TABLE_rdet	(Optional) all WRED sessions
TABLE_rdet_nonecn	(Optional) all WRED non ECN sessions
TABLE_afd	(Optional) all AFD sessions

TABLE_police	(Optional) all police actions
<i>police-key</i>	(Optional) police actions count: xml key
TABLE_cmap	(Optional) all cmap xml sessions
<i>cmap-key</i>	(Optional) Class-map name: xml key
TABLE_action	(Optional) all actions
<i>action-key</i>	(Optional) Actions count: xml key
<i>yqos-or-q</i>	(Optional)
<i>options</i>	(Optional) match-first option
<i>pmap-name-out</i>	(Optional) Policy-map name
<i>desc</i>	(Optional) Description string
<i>cmap-name</i>	(Optional) Class-map name
<i>xqos-or-q</i>	(Optional)
<i>serv-pol-type</i>	(Optional) Type of service policy referred to
<i>serv-pol-name</i>	(Optional) Name of policy-map referred to within this policy-map
<i>type-spec</i>	(Optional) Type of policy-map specified or not
<i>type-cmap-spec</i>	(Optional) Type of class-map specified or not
<i>inner</i>	(Optional) Specifies if tunnel or inner keywords are mentioned
<i>dlb-disable</i>	(Optional) Disable Dynamic Load Balancing
<i>cos</i>	(Optional) IEEE 802.1Q Class of Service value
<i>exp-val-imposition</i>	(Optional) MPLS EXP value of type imposition
<i>exp-val-topmost</i>	(Optional) MPLS EXP value of type topmost
<i>dscp</i>	(Optional) DSCP in IP(v4) and IPv6 packets
<i>dscp-enum</i>	(Optional)
<i>prec</i>	(Optional) Precedence in IP(v4) and IPv6 packets
<i>prec-enum</i>	(Optional)
<i>disc-class</i>	(Optional) Discard class
<i>qos-group</i>	(Optional) Qos-group
<i>tmap-from</i>	(Optional)
<i>tmap-to</i>	(Optional)

<i>tmap-name</i>	(Optional) Table map name
<i>ptmap-from</i>	(Optional)
<i>ptmap-to</i>	(Optional)
<i>ptmap-name</i>	(Optional) Table map name
<i>avg-rate-type</i>	(Optional) Specifies if average shape rate is specified
<i>rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us
<i>min-rate-type</i>	(Optional) Specifies if minimum shape rate is specified
<i>min-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us
<i>max-rate-type</i>	(Optional) Specifies if maximum shape rate is specified
<i>max-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us
<i>cir-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps
<i>pir-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps
<i>prio-level</i>	(Optional) Priority if specified
<i>qlim-param-type</i>	(Optional) Type of parameter for qlim - cos/prec/dscp/disc class/qosgrp
<i>qlim-param-val</i>	(Optional) Parameter value for qlimit
<i>qlim-size</i>	(Optional) Queue size for qlimit
<i>size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>rdet-size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>rdet-nonecn-size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>afd-size-units</i>	(Optional) Units of queue size - bytes/kbytes/mbytes
<i>bc-size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>be-size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>qlim-enum-spec</i>	(Optional) Whether qlimit parameter is specified in enum or not
<i>rdet-mode</i>	(Optional) Random-detect mode
<i>rdet-nonecn-mode</i>	(Optional) Random-detect non-ecn mode
<i>rdet-agg</i>	(Optional) Are the params for aggregate flow
<i>rdet-values</i>	(Optional) List of class-of-service values for random-detect
<i>rdet-drop-prob</i>	(Optional) Random-detect drop probability
<i>rdet-weight</i>	(Optional) Random-detect queue length weight

<i>rdet-cap-average</i>	(Optional) Random-detect cap-average
<i>rdet-ecn</i>	(Optional) Random-detect ECN
<i>rdet-burst-opt</i>	(Optional) Random-detect burst optimized
<i>rdet-mesh-opt</i>	(Optional) Random-detect mesh optimized
<i>rdet-nonecn-drop-prob</i>	(Optional) Random-detect non-ecn drop probability
<i>afd-mode</i>	(Optional) AFD mode
<i>afd-values</i>	(Optional) List of class-of-service values for AFD
<i>afd-ecn</i>	(Optional) AFD ECN
<i>pause</i>	(Optional) Pause value
<i>priority-group-number</i>	(Optional) Priority group value
<i>bw-units</i>	(Optional) Bandwidth units
<i>rem-bw-units</i>	(Optional) Remaining bandwidth units
<i>rem-bw-rate</i>	(Optional) Remaining bandwidth rate
<i>agg-policer-name</i>	(Optional) Aggregate policer name
<i>cir-spec</i>	(Optional) Is CIR keyword specified
<i>bc-spec</i>	(Optional) Is Committed Burst keyword specified
<i>be-spec</i>	(Optional) Is Extended Burst keyword specified
<i>cnf-col-cmap</i>	(Optional) Conforming color class-map name
<i>exc-col-cmap</i>	(Optional) Exceeding color class-map name
<i>enum-spec</i>	(Optional) Is DSCP or PREC enum value specified
<i>cnf-act</i>	(Optional) Conform action (Police)
<i>exc-act</i>	(Optional) Exceed action (Police)
<i>vio-act</i>	(Optional) Violate action (Police)
<i>set-type</i>	(Optional) Type of set in police action
<i>set-val</i>	(Optional) Value of set type in police action
<i>ooo</i>	(Optional) Out-of-Order
<i>burst-detect-enable</i>	(Optional) Burst detect feature is enabled

Command Mode

- /exec

show policy-map interface control-plane

```
show policy-map interface control-plane { [ module <slot-no-in> [ class < cmap-name> ] ] [ class < cmap-name>
[ module <slot-no-in> ] ] } [ __readonly__ [ <scale-factor-cmd> ] <pmap-name> [ TABLE_cmap <cmap-key>
<cmap-name-out> <opt_any_or_all> [ TABLE_match <match-key> { [ access_grp <acc_grp_name> ] [
redirect <opt_match_redirect> ] [ exception <opt_match_except> ] [ protocol <opt_match_protocol> ] } + ] [
<class-off-rate> <class-drop-rate> <class-pkts> <class-bytes> ] [ [ <set_vld_flg> ] { { cos [ inner ] <cos-val>
} | { dscp [ tunnel ] <dscp-val> } | { precedence [ tunnel1 ] <prec-val> } } ] [ <threshold> <level> ] [ [
<policer_show_flags> ] [ <cir> <opt_kbps_mbps_gbps_pps_cir> ] [ { percent <cir-perc> } ] [ <bc>
<opt_kbytes_mbytes_gbytes_bc> ] [ <pir> <opt_kbps_mbps_gbps_pps_pir> ] [ { percent1 <pir-perc> } ] [
<be> <opt_kbytes_mbytes_gbytes_be> ] ] [ TABLE_slot { <slot-no-out> { [ [ <conform-pkts> |
<conform-bytes> ] ] [ { <opt_drop_transmit_conform> } | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit
<set-dscp-val> } | { set-prec-transmit <set-prec-val> } ] [ { [ [ <exceed-pkts> ] <exceed-bytes> ] { {
<opt_drop_transmit_exceed> } | { set dscp1 dscp2 table cir-markdown-map } } } ] [ [ <violate-pkts> |
<violate-bytes> ] ] { { <opt_drop_transmit_violate> } | { set1 dscp3 dscp4 table1 pir-markdown-map } } }
} } ] ] ] }
```

Syntax Description

show	Show running system information
policy-map	Show policy maps
interface	Show service policy on interface
control-plane	command is for copp policy
module	(Optional) module number for statistics
class	(Optional) class-name name
<i>cmap-name</i>	(Optional) Name of the class-map
<i>pmap-name</i>	(Optional) Name of the Policy-map
<i>__readonly__</i>	(Optional)
<i>scale-factor-cmd</i>	(Optional) Scale factor command
TABLE_cmap	(Optional) all cmap xml sessions
<i>cmap-key</i>	(Optional) Class-map key : XML output
<i>cmap-name-out</i>	(Optional) Name of the output class-map
<i>opt_any_or_all</i>	(Optional) Enter match-any or match-all
TABLE_match	(Optional) all match xml sessions
<i>match-key</i>	(Optional) Match key : XML output
access_grp	(Optional)
<i>acc_grp_name</i>	(Optional)

redirect	(Optional)
<i>opt_match_redirect</i>	(Optional) Match criteria for redirected packets
exception	(Optional)
<i>opt_match_except</i>	(Optional) Match criteria for exception packets
protocol	(Optional)
<i>opt_match_protocol</i>	(Optional) Match criteria for protocol packets
<i>set_vld_flg</i>	(Optional) Set valid flag
cos	(Optional)
inner	(Optional)
<i>cos-val</i>	(Optional) Set cos val
dscp	(Optional)
tunnel	(Optional)
<i>dscp-val</i>	(Optional) Set dscp val
precedence	(Optional)
tunnel1	(Optional)
<i>prec-val</i>	(Optional) Set prec val
<i>policer_show_flags</i>	(Optional) Policer show flags
<i>level</i>	(Optional) syslog severity level
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	(Optional)
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional)
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
TABLE_slot	(Optional) all slot-num : XML output
<i>slot-no-in</i>	(Optional) input slot no
<i>slot-no-out</i>	(Optional) output slot no
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional)

<i>set-cos-val</i>	(Optional) Conform action cos val
set-dscp-transmit	(Optional)
<i>set-dscp-val</i>	(Optional) Conform action dscp val
set-prec-transmit	(Optional)
<i>set-prec-val</i>	(Optional) Conform action prec val
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional)
dscp1	(Optional)
dscp2	(Optional)
table	(Optional)
cir-markdown-map	(Optional)
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional)
dscp3	(Optional)
dscp4	(Optional)
table1	(Optional)
pir-markdown-map	(Optional)

Command Mode

- /exec

show policy-map system

```
show policy-map system [ type { network-qos | qos [ input2 ] | queuing [ input | output ] } ] [ __readonly__
{ [ <display-all> ] [ TABLE_xpmap <xpmap-name> [ <desc> ] [ TABLE_xcmap <xcmap-name> [
TABLE_xaction <xaction-key> [ <cos-list> ] [ <qos-group-list> ] [ <protocol> ] [ <pause> <timeout>
<size-in-bytes> <xoff-bytes> <xon-bytes> ] [ <pfc-cos-list> ] [ <pfc_rx_only> ] [ <cc> ] [ <thresh-units> ] [
<min-thresh> ] [ <max-thresh> ] [ <drop-prob> ] [ <iod> ] [ <mtu> ] [ <set-cos> ] [ <dpp> ] [ <dctcp-threshold>
] [ <queue-limit> ] [ <stat-en-dis-enum> ] ] ] ] [ TABLE_pmap <pmap-key> <pmap-inner-outer> <in-or-out>
<yqos-or-q> [ <options> ] <pmap-name> [ <stat-status-enum> ] [ TABLE_cmap <cmap-key> [ <xqos-or-q>
] <match-opts> <cmap-name> [ TABLE_match <match-key> [ <not> ] [ <inner> ] [ <cos-list> ] [
<match-cmap-xqos-or-q> ] [ <match-cmap-opts> ] [ <match-cmap-name> ] ] [ TABLE_action <action-key>
[ <set-inner> ] [ <cos> ] [ <serv-pol-type> ] [ <serv-pol-name> ] [ <serv-pol-return-inout> ] [ <rate-units> ]
[ <shape-rate> ] [ <min-rate-type> ] [ <min-rate-units> ] [ <shape-min-rate> ] [ <max-rate-type> ] [
<max-rate-units> ] [ <shape-max-rate> ] [ <prio-level> ] [ <qlim-param-type> ] [ <qlim-param-val> ] [
<size-units> ] [ <qlim-size> ] [ <qlim-enum-spec> ] [ <bw-units> ] [ <bw-rate> ] [ <rem-bw-units> ] [
<rem-bw-rate> ] [ <rise-threshold-units> ] [ <fall-threshold-units> ] [ <rdet-agg> ] [ <rdet-mode> ] [
<rdet-burst-opt> ] [ <rdet-mesh-opt> ] [ TABLE_rdet <rdet-key> [ <rdet-values> ] [ <rdet-min-thresh> ] [
<rdet-size-units> ] [ <rdet-max-thresh> ] [ <rdet-drop-prob> ] [ <rdet-weight> ] [ <rdet-cap-average> ] ] [
<rdet-ecn> ] [ TABLE_afd <afd-key> [ <afd-values> ] [ <afd-queue-desired> ] [ <afd-size-units> ] [ <afd-ecn>
] ] [ <pause> <size-in-bytes> <xoff-bytes> <xon-bytes> ] ] ] ] }
```

Syntax Description

show	Show running system information
policy-map	Show policy maps
type	(Optional) Type of the policy-map
system	Active policy in the system
network-qos	(Optional) type network-qos
qos	(Optional) type qos
input2	(Optional) input policy
queuing	(Optional) type queuing
input	(Optional) input policy
output	(Optional) output policy
__readonly__	(Optional)
<i>display-all</i>	(Optional) Display all network-qos policy-maps
TABLE_xpmap	(Optional) all xpmap xml sessions
<i>xpmap-name</i>	(Optional) Policy-map name
TABLE_xcmap	(Optional) all xcmap xml sessions

<i>xcmmap-name</i>	(Optional) Class-map name
TABLE_xaction	(Optional) all network-qos actions
<i>xaction-key</i>	(Optional) network-qos ctions count: xml key
TABLE_pmap	(Optional) all pmap xml sessions
<i>pmap-key</i>	(Optional) Policy-map name: xml key
TABLE_cmap	(Optional) all cmap xml sessions
<i>cmap-key</i>	(Optional) Class-map name: xml key
TABLE_action	(Optional) all actions
<i>action-key</i>	(Optional) Actions count: xml key
TABLE_match	(Optional) all match xml sessions
<i>match-key</i>	(Optional) match count: xml key
TABLE_rdet	(Optional) all WRED sessions
TABLE_afd	(Optional) all AFD sessions
<i>stat-en-dis-enum</i>	(Optional)
<i>in-or-out</i>	(Optional)
<i>yqos-or-q</i>	(Optional)
<i>stat-status-enum</i>	(Optional)
<i>desc</i>	(Optional) Description string
<i>thresh-units</i>	(Optional) Units of threshold - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>drop-prob</i>	(Optional) Drop Probability at Maximum Threshold value
<i>pause</i>	(Optional) Pause value
<i>pfc-cos-list</i>	(Optional) List of class-of-service values
<i>pfc_rx_only</i>	(Optional) Pause receive only mode enabled
<i>timeout</i>	(Optional) timeout value
<i>cc</i>	(Optional) congestion control protocol
<i>iod</i>	(Optional) IOD value
<i>mtu</i>	(Optional) MTU value
<i>set-cos</i>	(Optional) Set CoS value
<i>dpp</i>	(Optional) Dynamic Packet Prioritization Class

<i>queue-limit</i>	(Optional) Queue size for the class
<i>protocol</i>	(Optional) protocol
<i>dctcp-threshold</i>	(Optional) DCTCP threshold in bytes
<i>cos-list</i>	(Optional) List of class-of-service values
<i>qos-group-list</i>	(Optional) List of qos-group values
<i>options</i>	(Optional) match-first option
<i>pmap-name</i>	(Optional) Policy-map name
<i>pmap-inner-outer</i>	(Optional) Inner or Outer policy-map
<i>serv-pol-return-inout</i>	(Optional) Inner or Outer policy-map
<i>cmap-name</i>	(Optional) Class-map name
<i>xqos-or-q</i>	(Optional)
<i>match-opts</i>	(Optional) Type of match in class-map
<i>match-cmap-xqos-or-q</i>	(Optional)
<i>match-cmap-opts</i>	(Optional) Type of match in class-map
<i>not</i>	(Optional) Negate this match result
<i>inner</i>	(Optional) Specifies if tunnel or inner keywords are mentioned
<i>cos-list</i>	(Optional) List of class-of-service values
<i>match-cmap-name</i>	(Optional) class-map name
<i>serv-pol-type</i>	(Optional) Type of service policy referred to
<i>serv-pol-name</i>	(Optional) Name of policy-map referred to within this policy-map
<i>set-inner</i>	(Optional) Specifies if tunnel or inner keywords are mentioned
<i>cos</i>	(Optional) IEEE 802.1Q Class of Service value
<i>rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us
<i>min-rate-type</i>	(Optional) Specifies if minimum shape rate is specified
<i>min-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us
<i>max-rate-type</i>	(Optional) Specifies if maximum shape rate is specified
<i>max-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us
<i>prio-level</i>	(Optional) Priority if specified
<i>qlim-param-type</i>	(Optional) Type of parameter for qlim - cos/prec/dscp/disc class/qosgrp

<i>qlim-param-val</i>	(Optional) Parameter value for qlimit
<i>qlim-size</i>	(Optional) Queue size for qlimit
<i>size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>qlim-enum-spec</i>	(Optional) Whether qlimit parameter is specified in enum or not
<i>rdet-size-units</i>	(Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>afd-size-units</i>	(Optional) Units of queue size - bytes/kbytes/mbytes
<i>bw-units</i>	(Optional) Bandwidth units
<i>rem-bw-units</i>	(Optional) Remaining bandwidth units
<i>rem-bw-rate</i>	(Optional) Remaining bandwidth rate
<i>rdet-values</i>	(Optional) List of class-of-service values for random-detect
<i>rdet-agg</i>	(Optional) Are the params for aggregate flow
<i>rdet-mode</i>	(Optional) Random-detect mode
<i>rdet-drop-prob</i>	(Optional) Random-detect drop probability
<i>rdet-weight</i>	(Optional) Random-detect queue length weight
<i>rdet-cap-average</i>	(Optional) Random-detect cap-average
<i>rdet-ecn</i>	(Optional) Random-detect ECN
<i>rdet-burst-opt</i>	(Optional) Random-detect burst optimized
<i>rdet-mesh-opt</i>	(Optional) Random-detect mesh optimized
<i>afd-values</i>	(Optional) List of class-of-service values for afd
<i>afd-ecn</i>	(Optional) AFD ECN
<i>pause</i>	(Optional) Pause value

Command Mode

- /exec

show policy-map type control-plane

```
show policy-map type control-plane [ expand ] [ { name <pmap-name> } ] [ __readonly__ [ { TABLE_pmap
<pmap-name1> [ { TABLE_cmap <cmap-name> [ <opt_any_or_all> ] [ TABLE_match <match_key> { [
access_grp <acc_grp_name> ] [ redirect <opt_match_redirect> ] [ exception <opt_match_except> ] [ protocol
<opt_match_protocol> } ] ] [ { TABLE_set_action <set_vld_flg> { { cos [ inner ] <cos-val> } | { dscp [ tunnel
] <dscp-val> } | { precedence [ tunnel1 ] <prec-val> } } } ] [ <threshold> <level> ] [ [ <policer_show_flags>
] [ <cir> <opt_kbps_mbps_gbps_pps_cir> ] [ percent <cir-perc> ] [ <pir> <opt_kbps_mbps_gbps_pps_pir>
] [ percent1 <pir-perc> ] [ <bc> <opt_kbytes_mbytes_gbytes_bc> ] [ <be> <opt_kbytes_mbytes_gbytes_be>
] [ { <opt_drop_transmit_conform> } | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit <set-dscp-val>
} | { set-prec-transmit <set-prec-val> } ] [ { <opt_drop_transmit_exceed> } | { set dscp1 dscp2 table
cir-markdown-map } ] [ { <opt_drop_transmit_violate> } | { set1 dscp3 dscp4 table1 pir-markdown-map } ]
] ] ] ] ]
```

Syntax Description

show	Show running system information
policy-map	Show policy maps
type	Type of the policy-map
control-plane	command is for copp policy
expand	(Optional) Display the match-criterias along with class-map
name	(Optional) policy-map name
<i>pmap-name</i>	(Optional) Name of the Policy-map
<i>__readonly__</i>	(Optional)
TABLE_pmap	(Optional) Table of policy-map
<i>pmap-name1</i>	(Optional) Name of the Policy-map
TABLE_cmap	(Optional) Table of class-map
<i>cmap-name</i>	(Optional) Name of the class-map
<i>opt_any_or_all</i>	(Optional) Enter match-any or match-all
TABLE_match	(Optional) Table of match statement
<i>match_key</i>	(Optional) Match key : XML output
access_grp	(Optional)
<i>acc_grp_name</i>	(Optional)
redirect	(Optional)
<i>opt_match_redirect</i>	(Optional) Match criteria for redirected packets

exception	(Optional)
<i>opt_match_except</i>	(Optional) Match criteria for exception packets
protocol	(Optional)
<i>opt_match_protocol</i>	(Optional) Match criteria for protocol packets
TABLE_set_action	(Optional) Table of set action
<i>set_vld_flg</i>	(Optional) Set valid flag
<i>level</i>	(Optional) syslog severity level
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	(Optional)
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional)
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional)
<i>set-cos-val</i>	(Optional) Conform action cos val
set-dscp-transmit	(Optional)
<i>set-dscp-val</i>	(Optional) Conform action dscp val
set-prec-transmit	(Optional)
<i>set-prec-val</i>	(Optional) Conform action prec val
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional)
dscp1	(Optional)
dscp2	(Optional)
table	(Optional)
cir-markdown-map	(Optional)
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional)
dscp3	(Optional)

dscp4	(Optional)
table1	(Optional)
pir-markdown-map	(Optional)
cos	(Optional)
inner	(Optional)
<i>cos-val</i>	(Optional) Set cos val
dscp	(Optional)
tunnel	(Optional)
<i>dscp-val</i>	(Optional) Set dscp val
precedence	(Optional)
tunnel1	(Optional)
<i>prec-val</i>	(Optional) Set prec val
<i>policer_show_flags</i>	(Optional) Policer show flags

Command Mode

- /exec

show policy-map type network-qos

```
show policy-map type network-qos [ <pmap-name-nq> ] [ __readonly__ { [ <display-all> ] [ TABLE_xpmap
<xpmap-name> [ <desc> ] [ TABLE_xcmap <xcmap-name> [ TABLE_action <action-key> [ <cos-list> ] [
<qos-group-list> ] [ <protocol> ] [ <pause> <timeout> <size-in-bytes> <xoff-bytes> <xon-bytes> ] [
<pfc-cos-list> ] [ <pfc_rx_only> ] [ <cc> ] [ <thresh-units> ] [ <min-thresh> ] [ <max-thresh> ] [ <drop-prob>
] [ <iod> ] [ <mtu> ] [ <set-cos> ] [ <dpp> ] [ <dctcp-threshold> ] [ <queue-limit> ] ] ] ] ] }
```

Syntax Description

show	Show running system information
policy-map	Show policy maps
type	Type of the policy-map
<i>pmap-name-nq</i>	(Optional) Policy-map name
network-qos	type network-qos
<i>__readonly__</i>	(Optional)
<i>display-all</i>	(Optional) Display all network-qos policy-maps
TABLE_xpmap	(Optional) all xpmap xml sessions
<i>xpmap-name</i>	(Optional) Policy-map name
TABLE_xcmap	(Optional) all xcmap xml sessions
<i>xcmap-name</i>	(Optional) Class-map name
TABLE_action	(Optional) all actions
<i>action-key</i>	(Optional) Actions count: xml key
<i>desc</i>	(Optional) Description string
<i>cos-list</i>	(Optional) List of class-of-service values
<i>qos-group-list</i>	(Optional) List of qos-group values
<i>protocol</i>	(Optional) protocol
<i>pause</i>	(Optional) Pause value
<i>timeout</i>	(Optional) timeout value
<i>pfc-cos-list</i>	(Optional) List of class-of-service values
<i>cc</i>	(Optional) congestion control protocol
<i>thresh-units</i>	(Optional) Units of threshold - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>drop-prob</i>	(Optional) Drop Probability at Maximum Threshold value

<i>iod</i>	(Optional) IOD value
<i>mtu</i>	(Optional) MTU value
<i>set-cos</i>	(Optional) Set CoS value
<i>dpp</i>	(Optional) Dynamic Packet Prioritization Class
<i>dctcp-threshold</i>	(Optional) DCTCP threshold in bytes
<i>queue-limit</i>	(Optional) Queue size for the class
<i>pfc_rx_only</i>	(Optional) Pause receive only mode is enabled

Command Mode

- /exec

show port-channel capacity

show port-channel capacity [*__readonly__* <total> <used> <free> <percentage_used>]

Syntax Description

show	Show running system information
port-channel	Show port-channel information
capacity	Capacity information
<i>__readonly__</i>	(Optional)
<i>total</i>	(Optional) Total resource
<i>used</i>	(Optional) Used resource
<i>free</i>	(Optional) Free resource
<i>percentage_used</i>	(Optional) Used resource in percentage

Command Mode

- /exec

show port-channel compatibility-parameters

show port-channel compatibility-parameters [*__readonly__* { *TABLE_compatibility* <parameter> <description> } +]

Syntax Description

show	Show running system information
port-channel	Show port-channel information
compatibility-parameters	Show compatibility parameters
<i>__readonly__</i>	(Optional)
<i>TABLE_compatibility</i>	(Optional) Port-channel compatibility table
<i>parameter</i>	(Optional) Compatibility parameter
<i>description</i>	(Optional) Parameter description

Command Mode

- /exec

show port-channel database

```
show port-channel database [ interface <if0> ] [ __readonly__ TABLE_interface <interface>
<last-membership-update> <total-ports> <total-up-ports> [ <first_operational-port> ] <age-of-channel> [
<time-since-last-bundle> ] [ <last-bundled-member> ] [ <time-since-last-unbundle> ] [
<last-unbundled-member> ] [ { TABLE_member <port> <mode> <port-status> } ] [ <protocol> ] ]
```

Syntax Description

show	Show running system information
port-channel	Show port-channel information
database	Show port-channel database
interface	(Optional) Specify a port-channel
<i>if0</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_interface	(Optional) Port-channel table
<i>interface</i>	(Optional) Port channel
<i>mode</i>	(Optional) channel-group mode
<i>last-membership-update</i>	(Optional) Last membership update
<i>total-ports</i>	(Optional) Total number of member ports
<i>total-up-ports</i>	(Optional) Total number of UP member ports
<i>first_operational-port</i>	(Optional) First operational port
TABLE_member	(Optional) Member ports info
<i>port</i>	(Optional) Member port
<i>port-status</i>	(Optional) Member port status
<i>age-of-channel</i>	(Optional) Age of port channel
<i>time-since-last-bundle</i>	(Optional) Time since last port bundled
<i>last-bundled-member</i>	(Optional) Last bundled member port
<i>time-since-last-unbundle</i>	(Optional) Time since last port un-bundled
<i>last-unbundled-member</i>	(Optional) Last unbundled member port
<i>protocol</i>	(Optional) Port channel protocol

Command Mode

show port-channel database

- /exec

show port-channel fast-convergence

show port-channel fast-convergence

Syntax Description

show	Show running system information
port-channel	Configure port channel parameters
fast-convergence	Show port-channel fast-convergence status

Command Mode

- /exec

show port-channel load-balance

```
show port-channel load-balance { [ module <module> ] | { fex { all } } } [ __readonly__ [ <sys-cfg> ] [ {
<module-cfg> } ] + <non-ip-val> <non-ip-sel> <ipv4-val> <ipv4-sel> [ <ipv6-val> ] { TABLE_mod_configs
[ <mod-number> ] <mod-non-ip-val> <mod-non-ip-sel> <mod-ipv4-val> <mod-ipv4-sel> } ]
```

Syntax Description

show	Show running system information
port-channel	Show port-channel information
load-balance	Show port-channel load balance
module	(Optional) slot
<i>module</i>	(Optional) Specify a module number
fex	FEX devices
all	Display all configured FEX port-channel LB
<i>__readonly__</i>	(Optional)
<i>sys-cfg</i>	(Optional) system wide load balance configuraton
<i>module-cfg</i>	(Optional) per module load balance configuraton
<i>non-ip-val</i>	(Optional) load balance setting for non-ip traffic
<i>non-ip-sel</i>	(Optional) non ip select
<i>ipv4-val</i>	(Optional) load balance setting for ipv4 traffic
<i>ipv4-sel</i>	(Optional) ip select
<i>ipv6-val</i>	(Optional) load balance setting for ipv6 traffic
TABLE_mod_configs	(Optional) module configurations
<i>mod-number</i>	(Optional) module number
<i>mod-non-ip-val</i>	(Optional) load balance setting for non-ip traffic
<i>mod-non-ip-sel</i>	(Optional) non ip select
<i>mod-ipv4-val</i>	(Optional) load balance setting for ipv4 traffic
<i>mod-ipv4-sel</i>	(Optional) ip select

Command Mode

- /exec

show port-channel load-balance forwarding-path1 interface src-interface

```
show port-channel load-balance forwarding-path1 interface <ch-id> src-interface <src-if> { vlan <vlan-id> |
src-mac <src-mac> | dst-mac <dst-mac> | src-ip <src-ip> | dst-ip <dst-ip> | src-ipv6 <src-ipv6> | dst-ipv6
<dst-ipv6> | l4-src-port <l4-src-port> | l4-dst-port <l4-dst-port> | ether-type <ethertype> | ip-prot <prot> }
+ [ __readonly__ { loadbalance-algorithm <algorithm> } { outgoing-port-id <port> } ]
```

Syntax Description

show	Show running system information
port-channel	Configure port channel parameters
load-balance	Show port-channel load balance
forwarding-path1	Packet forwarding information
interface	Specify a port-channel number
<i>ch-id</i>	Port-Channel name
vlan	VLAN - for dot1Q tagged packets at ingress
<i>vlan-id</i>	VLAN ID
src-mac	Source MAC Address
<i>src-mac</i>	Source MAC address
dst-mac	Destination MAC Address
<i>dst-mac</i>	Destination MAC address
src-ip	Source IP address
<i>src-ip</i>	Source IP address in format i.i.i.i
dst-ip	Destination IPv4 address
<i>dst-ip</i>	Destination IP address in format i.i.i.i
src-ipv6	Source IPv6 address
dst-ipv6	Destination IPv6 address
l4-src-port	Source Port
<i>l4-src-port</i>	Source L4 port
l4-dst-port	Destination Port
<i>l4-dst-port</i>	Destination L4 port

ether-type	Ethernet Type
<i>ethertype</i>	Ethernet Type
src-interface	Optional source interface (physical switch port only)
<i>src-if</i>	Interface name
ip-proto	IP v4/v6 Protocol
<i>prot</i>	IP Protocol
__readonly__	(Optional)
loadbalance-algorithm	(Optional) load balance algorithm
<i>algorithm</i>	(Optional) algorithm
outgoing-port-id	(Optional) outgoing port-id
<i>port</i>	(Optional) port

Command Mode

- /exec

show port-channel load-balance forwarding-path interface

```
show port-channel load-balance forwarding-path { interface <ch-id> | hgig } { src-interface <src-if> | vlan
<vlan-id> | src-mac <src-mac> | dst-mac <dst-mac> | src-ip <src-ip> | dst-ip <dst-ip> | src-ipv6 <src-ipv6> |
dst-ipv6 <dst-ipv6> | l4-src-port <l4-src-port> | l4-dst-port <l4-dst-port> | ethertype <ethertype> | protocol
<prot> } + [ module <module> | fex <fex-range> | hgig-tgid <tgid> ] + [ source-interface <if-id> ] [
__readonly__ { loadbalance-algorithm <algorithm> } { outgoing-port-id <port> } ]
```

Syntax Description

show	Show running system information
port-channel	Configure port channel parameters
load-balance	Show port-channel load balance
forwarding-path	Packet forwarding information
interface	Specify a port-channel number
<i>ch-id</i>	Port-Channel name
hgig	Hgig hashing result (only with RTAG7)
vlan	VLAN of the ingress packet i.e. when available
<i>vlan-id</i>	
src-mac	Source MAC Address
<i>src-mac</i>	Source MAC address
dst-mac	Destination MAC Address
<i>dst-mac</i>	Destination MAC address
src-ip	Source IPv4 address
<i>src-ip</i>	Source IP address in format i.i.i.i
dst-ip	Destination IPv4 address
<i>dst-ip</i>	Destination IP address in format i.i.i.i
src-ipv6	Source IPv6 address
dst-ipv6	Destination IPv6 address
l4-src-port	Source L4 port
<i>l4-src-port</i>	Source L4 port
l4-dst-port	Destination l4 port
<i>l4-dst-port</i>	Destination L4 port

ethertype	Ethertype of the packet stream
<i>ethertype</i>	
src-interface	Optional source interface (physical switch port only)
<i>src-if</i>	Interface name
source-interface	(Optional) Source interface - Required paramter
<i>if-id</i>	(Optional) Interface name
protocol	Protocol
<i>prot</i>	
module	(Optional) Module #
<i>module</i>	(Optional)
fex	(Optional) FEX devices
<i>fex-range</i>	(Optional) FEX device range
hgig-tgid	(Optional) Hgig #
<i>tgid</i>	(Optional)
__readonly__	(Optional)
loadbalance-algorithm	(Optional) load balance algorithm
<i>algorithm</i>	(Optional) load balance algorithm
outgoing-port-id	(Optional) outgoing port-id
<i>port</i>	(Optional) outgoing port-id

Command Mode

- /exec

show port-channel load-balance hardware forwarding-path interface source

```
show port-channel load-balance hardware forwarding-path { interface <ch-id> | hgig } { source-interface
<if-id> } { vlan <vlan-id> | src-mac <src-mac> | dst-mac <dst-mac> | src-ip <src-ip> | dst-ip <dst-ip> | src-ipv6
<src-ipv6> | dst-ipv6 <dst-ipv6> | l4-src-port <l4-src-port> | l4-dst-port <l4-dst-port> | ethertype <ethertype>
| protocol <prot> } + [ module <module> | fex <fex-range> | hgig-tgid <tgid> ] [ __readonly__ {
loadbalance-algorithm <algorithm> } { outgoing-port-id <port> } ]
```

Syntax Description

show	Show running system information
port-channel	Configure port channel parameters
load-balance	Show port-channel load balance
hardware	ASIC hardware based information
forwarding-path	Packet forwarding information
interface	Specify a port-channel number
<i>ch-id</i>	Port-Channel name
hgig	Higig hashing result (only with RTAG7)
source-interface	Source interface - Required paramter
<i>if-id</i>	Interface name
vlan	VLAN of the ingress packet i.e. when available
<i>vlan-id</i>	
src-mac	Source MAC Address
<i>src-mac</i>	Source MAC address
dst-mac	Destination MAC Address
<i>dst-mac</i>	Destination MAC address
src-ip	Source IPv4 address
<i>src-ip</i>	Source IP address in format i.i.i.i
dst-ip	Destination IPv4 address
<i>dst-ip</i>	Destination IP address in format i.i.i.i
src-ipv6	Source IPv6 address
dst-ipv6	Destination IPv6 address

l4-src-port	Source L4 port
<i>l4-src-port</i>	Source L4 port
l4-dst-port	Destination l4 port
<i>l4-dst-port</i>	Destination L4 port
ethertype	Ethertype of the packet stream
<i>ethertype</i>	
protocol	Protocol
<i>prot</i>	
module	(Optional) Module #
<i>module</i>	(Optional)
fex	(Optional) FEX devices
<i>fex-range</i>	(Optional) FEX device range
hgig-tgid	(Optional) Hgig #
<i>tgid</i>	(Optional)
__readonly__	(Optional)
loadbalance-algorithm	(Optional) load balance algorithm
<i>algorithm</i>	(Optional) load balance algorithm
outgoing-port-id	(Optional) outgoing port-id
<i>port</i>	(Optional) outgoing port-id

Command Mode

- /exec

show port-channel rbh-distribution

```
show port-channel rbh-distribution [ interface <if0> ] [ __readonly__ TABLE_channel <chan-id> <port> {
<rbh> } + <num_of_buckets> ]
```

Syntax Description

show	Show running system information
port-channel	Show port-channel information
rbh-distribution	Show RBH distribution for member ports
interface	(Optional) Specify a port-channel interface
<i>if0</i>	(Optional)
<i>__readonly__</i>	(Optional)
TABLE_channel	(Optional) Port-channel table
<i>chan-id</i>	(Optional) Channel ID
<i>port</i>	(Optional) Member port
<i>num_of_buckets</i>	(Optional) Channel ID
<i>rbh</i>	(Optional) Channel ID

Command Mode

- /exec

show port-channel scale-fanout

show port-channel scale-fanout

Syntax Description

show	Show running system information
port-channel	Configure port channel parameters
scale-fanout	Enable/disable port-channel scale-fanout when ports span more than 16 ASIC units

Command Mode

- /exec

show port-channel summary

```
show port-channel summary [ interface <if0> | controller ] [ __readonly__ TABLE_channel <group>
<port-channel> <layer> <status> <type> <prtcl> [ { TABLE_member <port> <port-status> } ] ]
```

Syntax Description

show	Show running system information
port-channel	Show port-channel information
summary	Show port-channel summary
interface	(Optional) Specify a port-channel
<i>if0</i>	(Optional)
controller	(Optional) Show controller configured port-channels
<i>__readonly__</i>	(Optional)
TABLE_channel	(Optional) Port-channel table
<i>group</i>	(Optional) Channel group number
<i>port-channel</i>	(Optional) Port channel
<i>type</i>	(Optional) Channel type
<i>prtcl</i>	(Optional) Channel protocol
<i>status</i>	(Optional) Channel status
<i>layer</i>	(Optional) Channel layer info
TABLE_member	(Optional) Member table
<i>port</i>	(Optional) Member port
<i>port-status</i>	(Optional) Member port status

Command Mode

- /exec

show port-channel traffic

```
show port-channel traffic [ interface <if0> ] [ __readonly__ TABLE_channel <chanId> <port> <rx-ucst>
<tx-ucst> <rx-mcst> <tx-mcst> <rx-bcst> <tx-bcst> ]
```

Syntax Description

show	Show running system information
port-channel	Show port-channel information
traffic	Show port-channel traffic statistics
__readonly__	(Optional)
interface	(Optional) Specify a port-channel
<i>if0</i>	(Optional)
TABLE_channel	(Optional) Port-channel table
<i>chanId</i>	(Optional) Channel ID
<i>port</i>	(Optional) Member port
<i>rx-ucst</i>	(Optional) Received unicast
<i>tx-ucst</i>	(Optional) Transmitted unicast
<i>rx-mcst</i>	(Optional) Received multicast
<i>tx-mcst</i>	(Optional) Transmitted multicast
<i>rx-bcst</i>	(Optional) Received broadcast
<i>tx-bcst</i>	(Optional) Transmitted broadcast

Command Mode

- /exec

show port-channel usage

```
show port-channel usage [ __readonly__ <total-channel-number-used> { <used-range-low> [ <used-range-hi> ] } + { <unused-range-low> [ <unused-range-hi> ] } + ]
```

Syntax Description

show	Show running system information
port-channel	Show port-channel information
usage	Show port-channel number usage
<i>__readonly__</i>	(Optional)
<i>total-channel-number-used</i>	(Optional) Total used number of port-channels
<i>used-range-low</i>	(Optional) Used range low end value
<i>used-range-hi</i>	(Optional) Used range high end value
<i>unused-range-low</i>	(Optional) Un-used range low end value
<i>unused-range-hi</i>	(Optional) Un-used range high end value

Command Mode

- /exec

show port-license

```
show port-license [ __readonly__ <consumed_port_licenses> [ TABLE_portlicense <interface> <cookie>
<port_activation_license> ] ]
```

Syntax Description

show	Show running system information
port-license	Show port license information
<i>__readonly__</i>	(Optional)
<i>consumed_port_licenses</i>	(Optional) Consumed port licenses
TABLE_portlicense	(Optional) port and licenses
<i>interface</i>	(Optional) interface name
<i>cookie</i>	(Optional) cookie
<i>port_activation_license</i>	(Optional) license state

Command Mode

- /exec

show port-profile

```
show port-profile [ name <all_profile_name> ] [ __readonly__ TABLE_port_profile_all <profile_name> [
<profile_id> ] <type> [ <desc> ] [ <status> ] [ <max_ports> ] [ <min_ports> ] [ <inherit> ] [ <profile_cfg> ]
+ [ <cmd_depth> ] [ <cmd_key> ] [ <parent_seqno> ] [ <cmd_seqno> ] [ <cmd_attr> ] [ <form_type> ] [
<cmd_mask> ] [ <shadow_cmd> ] [ <cmd_flags> ] [ <eval_cfg> ] + [ <intf> ] + [ <cap_l3> ] [ <cap_iscsi>
] [ <ctrl_sgid> ] [ <pkt_sgid> ] [ <sys_vlans> ] [ <portgrp> ] [ <pprole> ] [ <port_binding> ] ]
```

Syntax Description

show	Show running system information
port-profile	Show port-profile
name	(Optional) port-profile name
<i>all_profile_name</i>	(Optional) Enter the name of the profile
<i>__readonly__</i>	(Optional)
<i>TABLE_port_profile_all</i>	(Optional)
<i>profile_name</i>	(Optional)
<i>profile_id</i>	(Optional)
<i>type</i>	(Optional)
<i>desc</i>	(Optional)
<i>status</i>	(Optional)
<i>max_ports</i>	(Optional)
<i>min_ports</i>	(Optional)
<i>inherit</i>	(Optional)
<i>profile_cfg</i>	(Optional)
<i>cmd_depth</i>	(Optional)
<i>cmd_key</i>	(Optional)
<i>parent_seqno</i>	(Optional)
<i>cmd_seqno</i>	(Optional)
<i>cmd_attr</i>	(Optional)
<i>form_type</i>	(Optional)
<i>cmd_mask</i>	(Optional)
<i>shadow_cmd</i>	(Optional)

<i>cmd_flags</i>	(Optional)
<i>eval_cfg</i>	(Optional)
<i>intf</i>	(Optional)
<i>cap_l3</i>	(Optional) L3 Profile
<i>cap_iscsi</i>	(Optional) iSCSI cap
<i>ctrl_sgid</i>	(Optional) Control Vlan Pinned Sgid
<i>pkt_sgid</i>	(Optional) Packet Vlan Pinned Sgid
<i>sys_vlans</i>	(Optional) System Vlans
<i>portgrp</i>	(Optional) VMware Portgroup
<i>pprole</i>	(Optional) Port-profile Role
<i>port_binding</i>	(Optional) Port-binding

Command Mode

- /exec

show port-profile brief

```
show port-profile brief [ __readonly__ { TABLE_port_profile [ <profile_name> ] [ <type> ] [ <status> ] [
<profile_cfg_cnt> ] [ <eval_cfg_cnt> ] [ <intf_cnt> ] [ <inherit_cnt> ] [ <header_flag> ] } { TABLE_intf_count
[ <intf_type> ] [ <intf_count> ] [ <tot_header_flag> ] } ]
```

Syntax Description

show	Show running system information
port-profile	Show port-profile
brief	Brief info about profiles
<i>__readonly__</i>	(Optional)
<i>profile_name</i>	(Optional)
TABLE_port_profile	(Optional)
<i>type</i>	(Optional)
<i>status</i>	(Optional)
<i>profile_cfg_cnt</i>	(Optional)
<i>eval_cfg_cnt</i>	(Optional)
<i>intf_cnt</i>	(Optional)
<i>inherit_cnt</i>	(Optional)
<i>header_flag</i>	(Optional)
TABLE_intf_count	(Optional)
<i>intf_type</i>	(Optional)
<i>intf_count</i>	(Optional)
<i>tot_header_flag</i>	(Optional)

Command Mode

- /exec

show port-profile expand-interface

```
show port-profile expand-interface [ name <all_profile_name> ] [ __readonly__ TABLE_port_profile
<profile_name> [ TABLE_interface <intf> [ <intf_cfg> ] + ] ]
```

Syntax Description

show	Show running system information
port-profile	Show port-profile
expand-interface	Active profile config applied in a interface
name	(Optional) port-profile name
<i>all_profile_name</i>	(Optional) Enter the name of the profile
<i>__readonly__</i>	(Optional)
TABLE_port_profile	(Optional)
<i>profile_name</i>	(Optional)
TABLE_interface	(Optional)
<i>intf</i>	(Optional)
<i>intf_cfg</i>	(Optional)

Command Mode

- /exec

show port-profile sync-status

```
show port-profile sync-status [ interface <intfname> ] [ __readonly__ <intf> + [ <inherit> ] <status> + [
<sync_status> ] [ <cached_cmds> ] [ <errors> ] [ <recovery> ] ]
```

Syntax Description

show	Show running system information
port-profile	Show port-profile
sync-status	Interfaces out-of-sync with port-profiles
interface	(Optional) Interface name
<i>intfname</i>	(Optional) Name of interface
<i>__readonly__</i>	(Optional)
<i>intf</i>	(Optional)
<i>status</i>	(Optional)
<i>inherit</i>	(Optional)
<i>sync_status</i>	(Optional)
<i>cached_cmds</i>	(Optional)
<i>errors</i>	(Optional)
<i>recovery</i>	(Optional)

Command Mode

- /exec

show port-profile usage

```
show port-profile usage [ name <all_profile_name> ] [ __readonly__ TABLE_port_profile <profile_name>
[ TABLE_interface <interface> ] ]
```

Syntax Description

show	Show running system information
port-profile	Show port-profile
usage	List of interfaces inherited a profile
name	(Optional) port-profile name
<i>all_profile_name</i>	(Optional) Enter the name of the profile
<i>__readonly__</i>	(Optional)
TABLE_port_profile	(Optional)
TABLE_interface	(Optional)
<i>profile_name</i>	(Optional)
<i>interface</i>	(Optional)

Command Mode

- /exec

show port-security

```
show port-security [ __readonly__ { TABLE_eth_port_sec_interfaces <secure_port> <max_secure_addr>
<current_addr> <security_violation> <security_action> <num_val> <num_elems> <cmdid_show_index>
<port_state> } <total_addr> <max_sys_limit> ]
```

Syntax Description

port-security	Show secure port information
<i>__readonly__</i>	(Optional)
TABLE_eth_port_sec_interfaces	(Optional) Displays the secured interfaces
<i>secure_port</i>	(Optional) Interface Index
<i>max_secure_addr</i>	(Optional) Maximum number of secured MAC addresses
<i>current_addr</i>	(Optional) Number of secured MAC addresses
<i>security_violation</i>	(Optional) Number of security violations
<i>security_action</i>	(Optional) Security Action Shutdown/Restrict/Protect
<i>num_val</i>	(Optional) Number of Values
<i>num_elems</i>	(Optional) Number of Elements
<i>cmdid_show_index</i>	(Optional) Index for the Interfaces
<i>port_state</i>	(Optional) Port security enabled or disabled
<i>total_addr</i>	(Optional) Total number of secured MAC addresses
<i>max_sys_limit</i>	(Optional) Maximum allowed MACs excluding one per port

Command Mode

- /exec

show port-security address

```
show port-security address [ __readonly__ { TABLE_eth_port_sec_mac_addrs <vlan_id> <mac_addr> <type>
<if_index> <remain_age> <remote_learnt> <remote_aged> <num_elems> <cmd_addr_index> } <total_addr>
<max_sys_limit> ]
```

Syntax Description

port-security	Show secure port information
address	Show secure address
__readonly__	(Optional)
TABLE_eth_port_sec_mac_addrs	(Optional) Displays the secured MAC addresses
if_index	(Optional) Interface index
vlan_id	(Optional) vlan id
mac_addr	(Optional) mac address
type	(Optional) static/sticky/dyanmic MAC address
remain_age	(Optional) Remaining age
remote_learnt	(Optional) Remotely learnt
remote_aged	(Optional) Remotely Aged Out
num_elems	(Optional) Number of Elements
cmd_addr_index	(Optional) Index for the interface address
total_addr	(Optional) Total number of secured MAC addresses
max_sys_limit	(Optional) Maximum allowed MACs excluding one per port

Command Mode

- /exec

show port-security address interface

```
show port-security address interface <interface-id> [ __readonly__ { TABLE_eth_port_sec_mac_addrs
<vlan_id> <mac_addr> <type> <if_index> <remain_age> <remote_learnt> <remote_aged> <num_elems>
<cmd_addr_index> } <total_addr> <max_sys_limit> <first> ]
```

Syntax Description

port-security	Show secure port information
address	Show secure address
interface	Show secure interface
<i>interface-id</i>	ethernet
<i>__readonly__</i>	(Optional)
TABLE_eth_port_sec_mac_addrs	(Optional) Displays the secured MAC addresses
<i>if_index</i>	(Optional) Interface index
<i>vlan_id</i>	(Optional) vlan id
<i>mac_addr</i>	(Optional) mac address
<i>type</i>	(Optional) static/sticky/dyanmic MAC address
<i>remain_age</i>	(Optional) Remaining age
<i>remote_learnt</i>	(Optional) Remotely learnt
<i>remote_aged</i>	(Optional) Remotely Aged Out
<i>num_elems</i>	(Optional) Number of Elements
<i>cmd_addr_index</i>	(Optional) Index for the interface address
<i>total_addr</i>	(Optional) Total number of secured MAC addresses
<i>max_sys_limit</i>	(Optional) Maximum allowed MACs excluding one per port
<i>first</i>	(Optional) To identify the first entry

Command Mode

- /exec

show port-security interface

```
show port-security interface <interface-id> [ __readonly__ <config_port_security> <oper_port_security>
<port_status> <violation_mode> <aging_time> <aging_type> <max_mac_addr> <total_sec_addrs>
<conf_num_addrs> <num_sticky_addrs> <trap_count> ]
```

Syntax Description

port-security	Show secure port information
interface	Show secure interface
<i>interface-id</i>	ethernet
<i>__readonly__</i>	(Optional)
<i>config_port_security</i>	(Optional) Port Security configuration is Enabled/Disabled
<i>oper_port_security</i>	(Optional) Port Security is Operationally Enabled/Disabled
<i>port_status</i>	(Optional) Secure Up/Down
<i>violation_mode</i>	(Optional) Shutdown/Restrict/Protect
<i>aging_time</i>	(Optional) Aging time in minutes
<i>aging_type</i>	(Optional) Absolute/Inactivity
<i>max_mac_addr</i>	(Optional) Configured Maximum
<i>total_sec_addrs</i>	(Optional) Total number of secured MAC addresses
<i>conf_num_addrs</i>	(Optional) Number of configured MAC addresses
<i>num_sticky_addrs</i>	(Optional) Number of sticky MAC addresses
<i>trap_count</i>	(Optional) Trap Count

Command Mode

- /exec

show port-security state

show port-security state [__readonly__ <status>]

Syntax Description

port-security	Port security related command
state	port security state
__readonly__	(Optional)
<i>status</i>	(Optional) show port-security

Command Mode

- /exec

show port naming

show port naming

Syntax Description

show	Show running system information
port	Show port information
naming	Show port naming information

Command Mode

- /exec

show postcard-telemetry exporter

```
show postcard-telemetry exporter [ name ] [ <exportername> ] [ __readonly__ <exporter> <description>
<dest> <vrf> <vrf_id> <vrf_resolved> <dest_udp> <source_intf> <source_ip> <dscp> ]
```

Syntax Description

show	Show running system information
postcard-telemetry	Show POSTCARD information
exporter	Show POSTCARD Exporter Configuration
name	(Optional) Show a specific POSTCARD Exporter
<i>exportername</i>	(Optional) Specify an exporter
<i>__readonly__</i>	(Optional)
<i>exporter</i>	(Optional)
<i>description</i>	(Optional)
<i>dest</i>	(Optional)
<i>vrf</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_resolved</i>	(Optional)
<i>dest_udp</i>	(Optional)
<i>source_intf</i>	(Optional)
<i>source_ip</i>	(Optional)
<i>dscp</i>	(Optional)

Command Mode

- /exec

show postcard-telemetry flow-profile

```
show postcard-telemetry flow-profile [ name ] [ <flow-profilename> ] [ __readonly__ <flow-profile>
<description> <dscp> <age> <latency> ]
```

Syntax Description

show	Show running system information
postcard-telemetry	Show POSTCARD information
flow-profile	Show POSTCARD flow Profile Configuration
name	(Optional) Show a specific POSTCARD flow Profile
<i>flow-profilename</i>	(Optional) Specify an flow Profile
<i>__readonly__</i>	(Optional)
<i>flow-profile</i>	(Optional)
<i>description</i>	(Optional)
<i>dscp</i>	(Optional)
<i>age</i>	(Optional)
<i>latency</i>	(Optional)

Command Mode

- /exec

show postcard-telemetry monitor

```
show postcard-telemetry monitor [ name ] [ <monitorname> [ cache [ detailed ] ] ] [ __readonly__ <monitor>
<use_count> <description> <record> <event> <exporter> <bucket_id> <src_addr> <dest_addr> <watchlist>
]
```

Syntax Description

show	Show running system information
postcard-telemetry	Show POSTCARD information
monitor	Show Monitor Configuration
name	(Optional) Show a specific POSTCARD Monitor
<i>monitorname</i>	(Optional) Specify a monitor
cache	(Optional) Flow monitor cache contents
detailed	(Optional) Show the entire cache contents
<i>__readonly__</i>	(Optional)
<i>monitor</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>record</i>	(Optional)
<i>event</i>	(Optional)
<i>exporter</i>	(Optional)
<i>bucket_id</i>	(Optional)
<i>src_addr</i>	(Optional)
<i>dest_addr</i>	(Optional)
<i>watchlist</i>	(Optional)

Command Mode

- /exec

show postcard-telemetry queue-profile

```
show postcard-telemetry queue-profile [ name ] [ <queue-profilename> ] [ __readonly__ <queue-profile>
<description> <depth> <latency> ]
```

Syntax Description

show	Show running system information
postcard-telemetry	Show POSTCARD information
queue-profile	Show POSTCARD Queue Profile Configuration
name	(Optional) Show a specific POSTCARD Queue Profile
<i>queue-profilename</i>	(Optional) Specify an Queue Profile
<i>__readonly__</i>	(Optional)
<i>queue-profile</i>	(Optional)
<i>description</i>	(Optional)
<i>depth</i>	(Optional)
<i>latency</i>	(Optional)

Command Mode

- /exec

show postcard-telemetry sessions

show postcard-telemetry sessions [<monitorname>] [__readonly__ <monitor>]

Syntax Description

show	Show running system information
postcard-telemetry	Show POSTCARD information
sessions	Show Session Configuration
<i>monitorname</i>	(Optional) Specify a monitor
__readonly__	(Optional)
<i>monitor</i>	(Optional)

Command Mode

- /exec

show postcard-telemetry watchlist

```
show postcard-telemetry watchlist [ name ] [ { <watchlistname> } ] [ __readonly__ <watchlist> <use_count>
<description> <num_aces> <ace_seq_num> <ace_action> <ace_type> <ace_sip> <ace_sip_len> <ace_dip>
<ace_dip_len> ]
```

Syntax Description

show	Show running system information
postcard-telemetry	Show POSTCARD information
watchlist	Show watchlist Configuration
name	(Optional) Show the configuration for a specific POSTCARD Record
<i>watchlistname</i>	(Optional) Specify a watchlist
<i>__readonly__</i>	(Optional)
<i>watchlist</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>num_aces</i>	(Optional)
<i>ace_seq_num</i>	(Optional)
<i>ace_action</i>	(Optional)
<i>ace_type</i>	(Optional)
<i>ace_sip</i>	(Optional)
<i>ace_sip_len</i>	(Optional)
<i>ace_dip</i>	(Optional)
<i>ace_dip_len</i>	(Optional)

Command Mode

- /exec

show power inline

```
show power inline <if0> [ __readonly__ { TABLE_intf_info <intf_name> <admin> <oper> <supp_pwr>
<del_pwr> <device> <class> <max> } ]
```

Syntax Description

show	Show running system information
power	Power over Ethernet
<i>if0</i>	
<i>__readonly__</i>	(Optional)
TABLE_intf_info	(Optional) Interface information
<i>intf_name</i>	(Optional) Interface name
<i>admin</i>	(Optional) Port mode
<i>oper</i>	(Optional) Oper mode
<i>supp_pwr</i>	(Optional) Supplied power
<i>del_pwr</i>	(Optional) delivered power
<i>device</i>	(Optional) Device information
<i>class</i>	(Optional) POE Class
<i>max</i>	(Optional) Max power

Command Mode

- /exec

show power inline

```
show power inline [ __readonly__ { TABLE_fex_info <module_id> <avail_pwr> <used_pwr> <rem_pwr>
} { TABLE_intf_info <intf_name> <admin> <oper> <supp_pwr> <del_pwr> <device> <class> <max> } ]
```

Syntax Description

show	Show running system information
power	Power over Ethernet
__readonly__	(Optional)
TABLE_fex_info	(Optional) FEX information
<i>module_id</i>	(Optional) FEX id
<i>avail_pwr</i>	(Optional) Available power
<i>used_pwr</i>	(Optional) Used power
<i>rem_pwr</i>	(Optional) Free power
TABLE_intf_info	(Optional) Interface information
<i>intf_name</i>	(Optional) Interface name
<i>admin</i>	(Optional) Port mode
<i>oper</i>	(Optional) Oper mode
<i>supp_pwr</i>	(Optional) Supplied power
<i>del_pwr</i>	(Optional) delivered power
<i>device</i>	(Optional) Device information
<i>class</i>	(Optional) POE Class
<i>max</i>	(Optional) Max power

Command Mode

- /exec

show power inline police

```
show power inline police [ __readonly__ { TABLE_police <intf_name> <admin> <oper> <admin_police>
<oper_police> <cutoff_pwr> <oper_pwr> } ]
```

Syntax Description

show	Show running system information
power	Power over Ethernet
police	Show per-port policing
__readonly__	(Optional)
TABLE_police	(Optional) Police information
<i>intf_name</i>	(Optional) Interface name
<i>admin</i>	(Optional) Port mode
<i>oper</i>	(Optional) Oper mode
<i>admin_police</i>	(Optional) Configured admin police
<i>oper_police</i>	(Optional) Current police
<i>cutoff_pwr</i>	(Optional) Cutoff power
<i>oper_pwr</i>	(Optional) Oper power

Command Mode

- /exec

show power inline priority

show power inline priority [*__readonly__* { *TABLE_priority* <intf_name> <admin> <oper> <priority> }]

Syntax Description

show	Show running system information
power	Power over Ethernet
priority	Show per-port priority
<i>__readonly__</i>	(Optional)
<i>TABLE_priority</i>	(Optional) Port priority information
<i>intf_name</i>	(Optional) Interface name
<i>admin</i>	(Optional) Port mode
<i>oper</i>	(Optional) Oper mode
<i>priority</i>	(Optional) port priority

Command Mode

- /exec

show privilege

show privilege

Syntax Description

show	Show running system information
privilege	Display privilege information

Command Mode

- /exec

show processes

```
show processes [ __readonly__ { [ TABLE_processes <pid> <state> <pc> <start_cnt> <tty> <p_type>
<process> ] } ]
```

Syntax Description

show	Show running system information
processes	Show processes
__readonly__	(Optional)
TABLE_processes	(Optional) all process information
<i>pid</i>	(Optional) process id
<i>state</i>	(Optional) process state
<i>pc</i>	(Optional) pc register
<i>start_cnt</i>	(Optional) TBD
<i>tty</i>	(Optional) TBD
<i>p_type</i>	(Optional) process type
<i>process</i>	(Optional) process name

Command Mode

- /exec

show processes cpu

```
show processes cpu [ sort ] [ __readonly__ { [ TABLE_process_cpu <pid> <runtime> <invoked> <usecs>
<onsec> <process> ] [ <user_percent> ] [ <kernel_percent> ] [ <idle_percent> ] } ]
```

Syntax Description

show	Show running system information
processes	Show processes
cpu	Show processes CPU Info
sort	(Optional) Show processes CPU Info (Sorted by Cpu Util with time base)
__readonly__	(Optional)
TABLE_process_cpu	(Optional) all process memory
<i>pid</i>	(Optional) process id
<i>runtime</i>	(Optional) Runtime
<i>invoked</i>	(Optional) Invoked
<i>usecs</i>	(Optional) usecs
<i>onsec</i>	(Optional) fivesec
<i>process</i>	(Optional) name of the process
<i>user_percent</i>	(Optional) user
<i>kernel_percent</i>	(Optional) kernel
<i>idle_percent</i>	(Optional) idle

Command Mode

- /exec

show processes cpu history

show processes cpu history

Syntax Description

show	Show running system information
processes	Show processes
cpu	Show processes CPU Info
history	Show processes CPU Util History

Command Mode

- /exec

show processes cpu history data

```
show processes cpu history data [ __readonly__ { [ TABLE_processes_cpu_history <cpu_avg_sec> ] } ]
```

Syntax Description

show	Show running system information
processes	Show processes
cpu	Show processes CPU Info
history	Show processes CPU Util History
data	Display the CPU util as data, instead of graph
<i>__readonly__</i>	(Optional)
<i>TABLE_processes_cpu_history</i>	(Optional) 60 sec cpu history
<i>cpu_avg_sec</i>	(Optional) cpu avg for a sec

Command Mode

- /exec

show processes cpu module

```
show processes cpu module <i0> [ __readonly__ { [ TABLE_process_cpu <pid> <runtime> <invoked>
<usecs> <oneseq> <process> ] [ <user_percent> ] [ <kernel_percent> ] [ <idle_percent> ] } ]
```

Syntax Description

show	Show running system information
processes	Show processes
cpu	Show processes CPU Info
module	processes CPU Info
<i>i0</i>	module number
<i>__readonly__</i>	(Optional)
TABLE_process_cpu	(Optional) all process memory
<i>pid</i>	(Optional) process id
<i>runtime</i>	(Optional) Runtime
<i>invoked</i>	(Optional) Invoked
<i>usecs</i>	(Optional) usecs
<i>oneseq</i>	(Optional) oneseq
<i>process</i>	(Optional) name of the process
<i>user_percent</i>	(Optional) user
<i>kernel_percent</i>	(Optional) kernel
<i>idle_percent</i>	(Optional) idle

Command Mode

- /exec

show processes log

```
show processes log [ __readonly__ { [ TABLE_processes_log <vdc> <process> <pid> <normal_exit> <stack>
<core> <create_time> ] } ]
```

Syntax Description

<code>show</code>	Show running system information
<code>processes</code>	Show processes
<code>log</code>	Show information about process logs
<code>__readonly__</code>	(Optional)
<code>TABLE_processes_log</code>	(Optional) all processes log
<code>vdc</code>	(Optional) vdc
<code>process</code>	(Optional) vdc process name
<code>pid</code>	(Optional) pid
<code>normal_exit</code>	(Optional) process exit
<code>stack</code>	(Optional) stack
<code>core</code>	(Optional) core
<code>create_time</code>	(Optional) log create time

Command Mode

- /exec

show processes log details

show processes log details [__readonly__ { line_in_log_detail <line_in_file> }]

Syntax Description

show	Show running system information
processes	Show processes
log	Show information about process logs
details	Show detail of all logs with stack
__readonly__	(Optional)
line_in_log_detail	(Optional)
<i>line_in_file</i>	(Optional) each line

Command Mode

- /exec

show processes log pid

```
show processes log pid <i0> [ __readonly__ { TABLE_line_in_log_pid <line_in_file> } ]
```

Syntax Description

show	Show running system information
processes	Show processes
log	Show information about process logs
pid	Show detail log info about a specific process
<i>i0</i>	pid of the process
<i>__readonly__</i>	(Optional)
<i>TABLE_line_in_log_pid</i>	(Optional)
<i>line_in_file</i>	(Optional) each line

Command Mode

- /exec

show processes log vdc-all

```
show processes log vdc-all [ __readonly__ { [ TABLE_processes_log_vdc_all <vdc> <process> <pid>
<normal_exit> <stack> <core> <create_time> ] } ]
```

Syntax Description

TABLE_processes_log_vdc_all	(Optional) all processes log vdc all
show	Show running system information
processes	Show processes
log	Show information about process logs
vdc-all	Show information about process logs in all vdc's
__readonly__	(Optional)
vdc	(Optional) vdc process name
process	(Optional) vdc process name
pid	(Optional) process id
normal_exit	(Optional) process exit
stack	(Optional) stack
core	(Optional) core
create_time	(Optional) log create time

Command Mode

- /exec

show processes memory

```
show processes memory [ __readonly__ { TABLE_process_memory <mem_pid> <mem_alloc> <mem_limit>
<mem_used> <stack_base_ptr> <process> } ]
```

Syntax Description

show	Show running system information
processes	Show processes
memory	Show processes Memory Info
<i>__readonly__</i>	(Optional)
TABLE_process_memory	(Optional) all process memory
<i>mem_pid</i>	(Optional) process id
<i>mem_alloc</i>	(Optional) allocated memory
<i>mem_limit</i>	(Optional) memory limit
<i>mem_used</i>	(Optional) memory used
<i>stack_base_ptr</i>	(Optional) stack and base pointer
<i>process</i>	(Optional) name of the process

Command Mode

- /exec

show processes memory physical

```
show processes memory physical [ __readonly__ { TABLE_process_physical_memory <processid> <virtual>
<physical> <rss> <processname> } ]
```

Syntax Description

show	Show running system information
processes	Show processes
memory	Show processes Memory Info
physical	Show processes physical Memory
<i>__readonly__</i>	(Optional)
<i>TABLE_process_physical_memory</i>	(Optional) all process physical memory
<i>processid</i>	(Optional) process id
<i>virtual</i>	(Optional) virtual allocated memory
<i>physical</i>	(Optional) physical memory used
<i>rss</i>	(Optional) rss memory
<i>processname</i>	(Optional) name of the process

Command Mode

- /exec

show processes memory shared

```
show processes memory shared [ detail | dynamic ] [ __readonly__ TABLE_process_tag [ <process-tag-out> ] [ <process-memory-share-dynamic-component-str> ] [ <process-memory-share-dynamic-shared-memory-str> ] [ <process-memory-share-dynamic-current-size-str> ] [ <process-memory-share-dynamic-max-size-str> ] [ <process-memory-share-dynamic-used-str> ] [ <process-memory-share-component-str> ] [ <process-memory-share-shared-memory-str> ] [ <process-memory-share-size-str> ] [ <process-memory-share-used-str> ] [ <process-memory-share-available-str> ] [ <process-memory-share-ref-str> ] [ <process-memory-share-byte-set-address-str> ] [ <process-memory-share-byte-set-count-str> ] [ <process-memory-share-address-str> ] [ <process-memory-share-kbytes-1-str> ] [ <process-memory-share-kbytes-2-str> ] [ <process-memory-share-kbytes-3-str> ] [ <process-memory-share-count-str> ] [ { TABLE_SMMITEM <process-memory-share-smr-name> } ] [ { TABLE_SHOWPROC <process-memory-share-table-showproc-key> [ { TABLE_SHOWONEDYNAMIC [ <process-memory-share-component> ] [ <process-memory-share-shared-memory> ] [ <process-memory-share-current-size> ] [ <process-memory-share-max-size> ] [ <process-memory-share-used> ] } ] [ { TABLE_ONEITEM [ <process-memory-share-proc-smr-name> ] [ <process-memory-share-smr-addr> ] [ <process-memory-share-smr-size> ] [ <process-memory-share-smr-star-char> ] [ <process-memory-share-smr-empty-char> ] [ <process-memory-share-smr-used> ] [ <process-memory-share-smr-avail> ] [ <process-memory-share-smr-ref-count> ] [ <process-memory-share-dynamic-smr-name> ] } ] [ { TABLE_ONEITEMDYNAMIC [ <process-memory-share-dynamic-smr-addr> ] [ <process-memory-share-dynamic-smr-size> ] [ <process-memory-share-dynamic-plus-char> ] [ <process-memory-share-max-mem-size-str> ] [ <process-memory-share-dynamic-smr-used> ] [ <process-memory-share-dynamic-smr-avail> ] [ <process-memory-share-dynamic-smr-ref-count> ] [ <process-memory-share-region-smr-name> ] } ] } ] [ <process-memory-share-total-shm-size> ] [ <process-memory-share-total-shm-used> ] [ <process-memory-share-total-shm-avail> ] ] ]
```

Syntax Description

show	Show running system information
processes	Display process information
memory	Display memory information
shared	Display shared memory info
detail	(Optional) Display shared memory in bytes instead of default kbytes
dynamic	(Optional) Display details of dynamic shared memory segments
__readonly__	(Optional)
TABLE_process_tag	(Optional)
<i>process-tag-out</i>	(Optional)
<i>process-memory-share-dynamic-component-str</i>	(Optional)
<i>process-memory-share-dynamic-shared-memory-str</i>	(Optional)
<i>process-memory-share-dynamic-current-size-str</i>	(Optional)

show processes memory shared

<i>process-memory-share-dynamic-max-size-str</i>	(Optional)
<i>process-memory-share-dynamic-used-str</i>	(Optional)
<i>process-memory-share-component-str</i>	(Optional)
<i>process-memory-share-shared-memory-str</i>	(Optional)
<i>process-memory-share-size-str</i>	(Optional)
<i>process-memory-share-used-str</i>	(Optional)
<i>process-memory-share-available-str</i>	(Optional)
<i>process-memory-share-ref-str</i>	(Optional)
<i>process-memory-share-byte-set-address-str</i>	(Optional)
<i>process-memory-share-byte-set-count-str</i>	(Optional)
<i>process-memory-share-address-str</i>	(Optional)
<i>process-memory-share-kbytes-1-str</i>	(Optional)
<i>process-memory-share-kbytes-2-str</i>	(Optional)
<i>process-memory-share-kbytes-3-str</i>	(Optional)
<i>process-memory-share-count-str</i>	(Optional)
TABLE_SMMITEM	(Optional)
<i>process-memory-share-smr-name</i>	(Optional)
TABLE_SHOWPROC	(Optional)
<i>process-memory-share-table-showproc-key</i>	(Optional)
TABLE_SHOWONEDYNAMIC	(Optional)
<i>process-memory-share-component</i>	(Optional)
<i>process-memory-share-shared-memory</i>	(Optional)
<i>process-memory-share-current-size</i>	(Optional)
<i>process-memory-share-max-size</i>	(Optional)
<i>process-memory-share-used</i>	(Optional)
TABLE_ONEITEM	(Optional)
<i>process-memory-share-proc-smr-name</i>	(Optional)
<i>process-memory-share-smr-addr</i>	(Optional)
<i>process-memory-share-smr-size</i>	(Optional)

<i>process-memory-share-smr-star-char</i>	(Optional)
<i>process-memory-share-smr-empty-char</i>	(Optional)
<i>process-memory-share-smr-used</i>	(Optional)
<i>process-memory-share-smr-avail</i>	(Optional)
<i>process-memory-share-smr-ref-count</i>	(Optional)
TABLE_ONEITEMDYNAMIC	(Optional)
<i>process-memory-share-dynamic-smr-name</i>	(Optional)
<i>process-memory-share-dynamic-smr-addr</i>	(Optional)
<i>process-memory-share-dynamic-smr-size</i>	(Optional)
<i>process-memory-share-dynamic-plus-char</i>	(Optional)
<i>process-memory-share-max-mem-size-str</i>	(Optional)
<i>process-memory-share-dynamic-smr-used</i>	(Optional)
<i>process-memory-share-dynamic-smr-avail</i>	(Optional)
<i>process-memory-share-dynamic-smr-ref-count</i>	(Optional)
<i>process-memory-share-region-smr-name</i>	(Optional)
<i>process-memory-share-total-shm-size</i>	(Optional)
<i>process-memory-share-total-shm-used</i>	(Optional)
<i>process-memory-share-total-shm-avail</i>	(Optional)

Command Mode

- /exec

show processes vdc

```
show processes vdc <e-vdc2> [ __readonly__ { TABLE_processes_vdc <pid> <state> <pc> <start_cnt> <tty>
<p_type> <process> } ]
```

Syntax Description

show	Show running system information
processes	Show processes
vdc	Show processes in vdc
<i>e-vdc2</i>	Enter Virtual Device Context <vdc-id>
<i>__readonly__</i>	(Optional) Read only
<i>TABLE_processes_vdc</i>	(Optional) All process information
<i>pid</i>	(Optional) PID of process
<i>state</i>	(Optional) State of process
<i>pc</i>	(Optional) PC in which process exists
<i>start_cnt</i>	(Optional) TBD
<i>tty</i>	(Optional) TBD
<i>p_type</i>	(Optional) Type of Process
<i>process</i>	(Optional) Process Name

Command Mode

- /exec

show processes vdc cpu

```
show processes vdc <e-vdc2> cpu [ __readonly__ [ TABLE_process_vdc_cpu <pid> <runtime> <invoked>
<usecs> <onesecc> <process> ] [ <user_percent> ] [ <kernel_percent> ] [ <idle_percent> ] ]
```

Syntax Description

show	Show running system information
processes	Show processes
vdc	Show processes in vdc
<i>e-vdc2</i>	Enter Virtual Device Context <vdc-id>
cpu	Show processes CPU Info
<i>__readonly__</i>	(Optional) Readonly table for cpu log
<i>TABLE_process_vdc_cpu</i>	(Optional) All cpu process logs of vdc
<i>pid</i>	(Optional) PID of process
<i>runtime</i>	(Optional) Runtime
<i>invoked</i>	(Optional) Invoked
<i>usecs</i>	(Optional) uSecs
<i>onesecc</i>	(Optional) fivesec
<i>process</i>	(Optional) Name of process
<i>user_percent</i>	(Optional) user
<i>kernel_percent</i>	(Optional) kernel
<i>idle_percent</i>	(Optional) idle

Command Mode

- /exec

show processes vdc log

```
show processes vdc <e-vdc2> log [ __readonly__ { [ TABLE_processes_vdc_log <vdc> <process> <pid>
<normal_exit> <stack> <core> <create_time> ] } ]
```

Syntax Description

show	Show running system information
processes	Show processes
vdc	Show processes in vdc
<i>e-vdc2</i>	Enter Virtual Device Context <vdc-id>
log	Show information about process logs
<i>__readonly__</i>	(Optional) Read only table
TABLE_processes_vdc_log	(Optional) Table for log of all VDC Processes
<i>pid</i>	(Optional) PID of process
<i>vdc</i>	(Optional) VDC Number
<i>process</i>	(Optional) Process name
<i>normal_exit</i>	(Optional) Normal Exit status
<i>stack</i>	(Optional) Stack
<i>core</i>	(Optional) Core
<i>create_time</i>	(Optional) Time stamp of log

Command Mode

- /exec

show processes vdc log details

show processes vdc <e-vdc2> log details

Syntax Description

show	Show running system information
processes	Show processes
vdc	Show processes in vdc
<i>e-vdc2</i>	Enter Virtual Device Context <vdc-id>
log	Show information about process logs
details	Show detail of all logs with stack

Command Mode

- /exec

show processes vdc log pid

show processes vdc <e-vdc2> log pid <i1>

Syntax Description

show	Show running system information
processes	Show processes
vdc	Show processes in vdc
<i>e-vdc2</i>	Enter Virtual Device Context <vdc-id>
log	Show information about process logs
pid	Show detail log info about a specific process
<i>i1</i>	pid of the process

Command Mode

- /exec

show processes vdc memory

```
show processes vdc <e-vdc2> memory [ __readonly__ { [ TABLE_process_memory <mem_pid> <mem_alloc>
<mem_limit> <mem_used> <stack_base_ptr> <process> ] [ <sum_mem_mallocated> ] } ]
```

Syntax Description

show	Show running system information
processes	Show processes
vdc	Show processes in vdc
<i>e-vdc2</i>	Enter Virtual Device Context <vdc-id>
memory	Show processes Memory Info
<i>__readonly__</i>	(Optional)
TABLE_process_memory	(Optional) all process memory
<i>mem_pid</i>	(Optional) process id
<i>mem_alloc</i>	(Optional) allocated memory
<i>mem_limit</i>	(Optional) memory limit
<i>mem_used</i>	(Optional) memory used
<i>stack_base_ptr</i>	(Optional) stack and base pointer
<i>process</i>	(Optional) name of the process

Command Mode

- /exec

show processes version

show processes { version | threads } [<comp-string>] [__readonly__ TABLE_component <component-name> <version> <buildinfo> <sourceversion>]

Syntax Description

show	Show running system information
processes	Display process information
version	Display system release information
threads	Threads Info
<i>comp-string</i>	(Optional) Component name for detailed information
<i>__readonly__</i>	(Optional)
TABLE_component	(Optional)
<i>component-name</i>	(Optional)
<i>version</i>	(Optional)
<i>buildinfo</i>	(Optional)
<i>sourceversion</i>	(Optional)

Command Mode

- /exec

show pss debug

show pss debug

Syntax Description

show	Show running system information
pss	display pss information
debug	display pss debug configuration

Command Mode

- /exec

show ptp brief

```
show ptp brief [ __readonly__ <gtp-flag> [ TABLE_ptp <ptp-ifindex> <state> [ <dot1as-capable> ] ]
<ptp-end> ]
```

Syntax Description

<code>ptp</code>	Precision Time Protocol (IEEE 1588) Subsystem
<code>brief</code>	port states in brief
<code>__readonly__</code>	(Optional) Read Only
<code>gtp-flag</code>	(Optional) GTP mode
<code>TABLE_ptp</code>	(Optional) ptp table
<code>ptp-ifindex</code>	(Optional) ptp ifindex
<code>state</code>	(Optional) BMC state
<code>dot1as-capable</code>	(Optional) Dot1AS capable
<code>ptp-end</code>	(Optional) End of table

Command Mode

- /exec

show ptp clock

```
show ptp clock [ __readonly__ <clock-id> <domain-id> <num-ports> <priority1> <priority2> <class>
<accuracy> <scaled-log-variance> <offset-from-master> <mean-path-delay-to-master> <steps-removed>
<device-type> <encap> <slave-clock-oper> <master-clock-oper> <src-ip> <slave-only> [
<correction-threshold> ] [ <mean-path-delay-threshold> ] [ <gmTimeBaseIndicator> ] [
<last_gm_phase_change> ] [ <master_cum_scaled_rate_offset> ] [ <scaled_last_gm_freq_change> ] [
<cum_scaled_rate_offset> ] <local-clock-time> <bs-status> ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
clock	Set local clock attributes
<i>__readonly__</i>	(Optional) Read only
<i>domain-id</i>	(Optional) Domain Id
<i>clock-id</i>	(Optional) Clock Id
<i>priority1</i>	(Optional) Priority 1
<i>priority2</i>	(Optional) Priority 2
<i>num-ports</i>	(Optional) Number of PTP ports
<i>class</i>	(Optional) Class
<i>accuracy</i>	(Optional) Clock accuracy
<i>scaled-log-variance</i>	(Optional) scaled log variance
<i>offset-from-master</i>	(Optional) Offset from master
<i>mean-path-delay-to-master</i>	(Optional) mean path delay to master
<i>steps-removed</i>	(Optional) Steps removed
<i>device-type</i>	(Optional) Device Type
<i>encap</i>	(Optional) Encapsulation
<i>src-ip</i>	(Optional) IPv4 address (A.B.C.D) of source (in layer-3 encapsulation)
<i>slave-clock-oper</i>	(Optional) Slave clock operation
<i>master-clock-oper</i>	(Optional) Master clock operation
<i>slave-only</i>	(Optional) Slave-only mode
<i>correction-threshold</i>	(Optional) correction-threshold
<i>mean-path-delay-threshold</i>	(Optional) mean-path-delay threshold

<i>gmTimeBaseIndicator</i>	(Optional) time base indicator for current GM
<i>last_gm_phase_change</i>	(Optional) time difference of current and previous GM
<i>master_cum_scaled_rate_offset</i>	(Optional) cumulative scaled rate offset received from master
<i>scaled_last_gm_freq_change</i>	(Optional) scaled last GM frequency change
<i>cum_scaled_rate_offset</i>	(Optional) cumulative scaled rate offset
<i>local-clock-time</i>	(Optional) Local clock time
<i>bs-status</i>	(Optional) Broadsync status enable/disable

Command Mode

- /exec

show ptp clock foreign-masters record

```
show ptp clock foreign-masters record [ interface <if0> ] [ __readonly__ [ TABLE_ptp <interface-name>
<clock-id> <priority1> <priority2> <class> <accuracy> <scaled-log-variance> <steps-removed> <is-gm> ]
<ptp-end> ]
```

Syntax Description

<code>ptp</code>	Precision Time Protocol (IEEE 1588) Subsystem
<code>clock</code>	Set local clock attributes
<code>foreign-masters</code>	foreign-masters
<code>record</code>	record
<code>if0</code>	(Optional)
<code>__readonly__</code>	(Optional) Read only
<code>TABLE_ptp</code>	(Optional) ptp table
<code>interface-name</code>	(Optional) interface name
<code>clock-id</code>	(Optional) Clock Id
<code>priority1</code>	(Optional) Priority 1
<code>priority2</code>	(Optional) Priority 2
<code>class</code>	(Optional) Class
<code>accuracy</code>	(Optional) Clock accuracy
<code>scaled-log-variance</code>	(Optional) scaled log variance
<code>steps-removed</code>	(Optional) Steps removed
<code>is-gm</code>	(Optional) Is Grandmaster
<code>ptp-end</code>	(Optional) End of table

Command Mode

- /exec

show ptp corrections

```
show ptp corrections [ __readonly__ [ TABLE_ptp <intf-name> <sup-time> <correction-val>
<mean-path-delay> ] <ptp-end> ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
__readonly__	(Optional) Read Only
corrections	Display last few corrections
TABLE_ptp	(Optional) ptp table
<i>intf-name</i>	(Optional) interface name
<i>sup-time</i>	(Optional) sup time
<i>correction-val</i>	(Optional) correction value
<i>ptp-end</i>	(Optional) End of table

Command Mode

- /exec

show ptp cost

```
show ptp cost [ interface <if0> ] [ __readonly__ [ TABLE_ptp <ptp-ifindex> <cost> ] <ptp-end> ]
```

Syntax Description

<code>ptp</code>	Precision Time Protocol (IEEE 1588) Subsystem
<code>cost</code>	port costs
<code>if0</code>	(Optional)
<code>__readonly__</code>	(Optional) Read Only
<code>TABLE_ptp</code>	(Optional) ptp table
<code>ptp-ifindex</code>	(Optional) ptp ifindex
<code>cost</code>	(Optional) cost
<code>ptp-end</code>	(Optional) End of table

Command Mode

- /exec

show ptp counters interface

```
show ptp counters { interface <if0> | all } [ { detail | ipv4 <ip> } ] [ __readonly__ [ TABLE_ptp
<interface_name> [ <accepted-ip> ] <tx-announce-pkts> <rx-announce-pkts> <tx-sync-pkts> <rx-sync-pkts>
<tx-follow-up-pkts> <rx-follow-up-pkts> <tx-delay-req-pkts> <rx-delay-req-pkts> <tx-delay-resp-pkts>
<rx-delay-resp-pkts> <tx-pdelay-req-pkts> <rx-pdelay-req-pkts> <tx-pdelay-resp-pkts> <rx-pdelay-resp-pkts>
<tx-pdelay-follow-up-pkts> <rx-pdelay-follow-up-pkts> [ <tx-mgmt-pkts> ] [ <rx-mgmt-pkts> ] ] <ptp-end>
]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
__readonly__	(Optional) Read Only
counters	Display PTP packet counters
interface	Enter the port interface
all	Displays all information
<i>if0</i>	
detail	(Optional) Show detail
ipv4	(Optional) IP address for the stat info
<i>ip</i>	(Optional) IPv4 address (A.B.C.D)
TABLE_ptp	(Optional) ptp table
<i>interface_name</i>	(Optional) interface name
<i>accepted-ip</i>	(Optional) Accepted IP in unicast mode
<i>ptp-end</i>	(Optional) End of table

Command Mode

- /exec

show ptp delay summary

```
show ptp delay summary [ __readonly__ [ TABLE_ptp <intf-name-port> <device-type> <state> <link-delay>
] [ <ptp-end> ] [ <gtp-not-supported> ] ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
delay	delay
summary	summary
__readonly__	(Optional) Read only
TABLE_ptp	(Optional) ptp table
<i>intf-name-port</i>	(Optional) interface name and port
<i>device-type</i>	(Optional) Device Type
<i>state</i>	(Optional) BMC state
<i>link-delay</i>	(Optional) link delay
<i>ptp-end</i>	(Optional) End of table
<i>gtp-not-supported</i>	(Optional) GTP not supported

Command Mode

- /exec

show ptp domain data

```
show ptp domain data [ __readonly__ [ TABLE_ptp <multidom_cap> <gm_cap> <gm_convergence_time>
<def_dom> <transition_priority1> <transition_priority2> [ TABLE_ptp_domain <domain_number>
<domain_priority> <ptp_clock_class_threshold> <ptp_clock_accuracy_threshold> <ptp-ifindex> ] ] <ptp-end>
]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
domain	ptp domain number
data	ptp domain data
__readonly__	(Optional) Read Only
TABLE_ptp	(Optional) ptp table
<i>multidom_cap</i>	(Optional) Multidomain state ENABLED/DISABLED
<i>gm_cap</i>	(Optional) GM state ENABLE/DISABLED
<i>gm_convergence_time</i>	(Optional) ptp grandmaster convergence time
<i>def_dom</i>	(Optional) ptp default domain
<i>transition_priority1</i>	(Optional) ptp multi-domain transition priority1
<i>transition_priority2</i>	(Optional) ptp multi-domain transition priority2
TABLE_ptp_domain	(Optional)
<i>domain_number</i>	(Optional) ptp domain number
<i>domain_priority</i>	(Optional) ptp domain priority
<i>ptp_clock_class_threshold</i>	(Optional) ptp domain class
<i>ptp_clock_accuracy_threshold</i>	(Optional) ptp domain accuracy
<i>ptp-ifindex</i>	(Optional) ptp ifindex
<i>ptp-end</i>	(Optional) End of table

Command Mode

- /exec

show ptp interface domain

show ptp interface domain [__readonly__ [TABLE_ptp <ptp-ifindex> <interface-domain>] <ptp-end>]

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
interface	port
domain	ptp port domain
__readonly__	(Optional) Read Only
TABLE_ptp	(Optional) ptp table
<i>ptp-ifindex</i>	(Optional) ptp ifindex
<i>interface-domain</i>	(Optional) ptp port domain
<i>ptp-end</i>	(Optional) End of table

Command Mode

- /exec

show ptp packet-trace

```
show ptp packet-trace [ __readonly__ [ TABLE_ptp <intf-name> <sup-time> <pkt_dir> <pkt_type> <pkt_info>
] <ptp-header> <ptp-end> ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
__readonly__	(Optional) Read Only
packet-trace	Display last few pkt traces
TABLE_ptp	(Optional) ptp table
<i>intf-name</i>	(Optional) interface name
<i>sup-time</i>	(Optional) sup time
<i>pkt_dir</i>	(Optional) pkt_dir
<i>pkt_type</i>	(Optional) pkt_type
<i>pkt_info</i>	(Optional) pkt_info
<i>ptp-header</i>	(Optional) Start of table
<i>ptp-end</i>	(Optional) End of table

Command Mode

- /exec

show ptp parent

```
show ptp parent [ __readonly__ <clock-id> <port-num> <obs-parent-offset> <obs-parent-clk-phase-chg> [
<parent-ip> ] <gm-id> <gm-class> <gm-accuracy> <gm-scaled-log-variance> <gm-priority1> <gm-priority2>
[ TABLE-path-trace <path-trace-index> <path-trace-clock-id> ] ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
parent	parent clock
__readonly__	(Optional) Read only
<i>clock-id</i>	(Optional) Clock Id
<i>port-num</i>	(Optional) Port ID: port number
<i>obs-parent-offset</i>	(Optional) observed parent offset
<i>obs-parent-clk-phase-chg</i>	(Optional) observed parent clock phase change
<i>parent-ip</i>	(Optional) Parent clock IP
<i>gm-id</i>	(Optional) Grandmaster Id
<i>gm-class</i>	(Optional) Class
<i>gm-accuracy</i>	(Optional) Clock accuracy
<i>gm-scaled-log-variance</i>	(Optional) scaled log variance
<i>gm-priority1</i>	(Optional) GM Priority 1
<i>gm-priority2</i>	(Optional) GM Priority 2
TABLE-path-trace	(Optional) ptp path trace table
<i>path-trace-index</i>	(Optional) Clock Identity index
<i>path-trace-clock-id</i>	(Optional) Clock Identity in path trace

Command Mode

- /exec

show ptp port interface

```
show ptp port interface <if0> [ __readonly__ <intf-name> <clock-id> <port-num> <version> [
<transport-mode> ] [ <accepted-ip> ] <state> <vlan> <delay-req-intv> <ann-rx-tout> <peer-mean-path-delay>
<ann-intv> <sync-intv> <delay-mechanism> [ <peer-delay-req-intv> ] [ <device-type> ] [ <encap> ] [
<prop-delay-thresh> ] [ <neighbor-rate-ratio> ] <cost> <int-domain-id> ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
port	port
interface	Enter the port interface
<i>if0</i>	
<i>__readonly__</i>	(Optional) Read only
<i>intf-name</i>	(Optional) interface name
<i>clock-id</i>	(Optional) Port ID: Clock Id
<i>port-num</i>	(Optional) Port ID: port number
<i>version</i>	(Optional) version
<i>transport-mode</i>	(Optional) Transport mode
<i>accepted-ip</i>	(Optional) Accepted IPs
<i>state</i>	(Optional) BMC state
<i>vlan</i>	(Optional) Vlan
<i>delay-req-intv</i>	(Optional) log mean delay req interval
<i>ann-rx-tout</i>	(Optional) announce receipt timeout
<i>peer-mean-path-delay</i>	(Optional) peer mean path delay
<i>ann-intv</i>	(Optional) announce interval
<i>sync-intv</i>	(Optional) sync interval
<i>delay-mechanism</i>	(Optional) delay mechanism
<i>peer-delay-req-intv</i>	(Optional) peer delay req interval
<i>device-type</i>	(Optional) Device Type
<i>encap</i>	(Optional) Encapsulation
<i>prop-delay-thresh</i>	(Optional) propagation delay threshold

<i>neighbor-rate-ratio</i>	(Optional) Neighbor rate-ratio
<i>cost</i>	(Optional) Cost
<i>int-domain-id</i>	(Optional) domain id

Command Mode

- /exec

show ptp time-property

show ptp time-property [*__readonly__* <current-utc-offset-valid> <current-utc-offset> <leap-59> <leap-61> <time-traceable> <freq-traceable> <ptp-timescale> <time-source>]

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
time-property	time property
<i>__readonly__</i>	(Optional) Read only
<i>current-utc-offset-valid</i>	(Optional) current_utc_offset_valid
<i>current-utc-offset</i>	(Optional) current_utc_offset
<i>leap-59</i>	(Optional) leap-59
<i>leap-61</i>	(Optional) leap-61
<i>time-traceable</i>	(Optional) time-traceable
<i>freq-traceable</i>	(Optional) freq-traceable
<i>ptp-timescale</i>	(Optional) ptp-timescale
<i>time-source</i>	(Optional) time-source

Command Mode

- /exec



Q Show Commands

- [show qos dcbxp incompatibility interface](#), on page 2016
- [show qos dcbxp info](#), on page 2017
- [show qos dcbxp interface](#), on page 2018
- [show qos shared-policer](#), on page 2020
- [show queuing](#), on page 2022
- [show queuing burst-detect](#), on page 2024
- [show queuing pfc-queue](#), on page 2025
- [show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex](#), on page 2027
- [show queuing pfc-queue snmp ifIndex](#), on page 2029
- [show queuing tabular](#), on page 2030
- [show queuing tah-pfc-queue](#), on page 2032

show qos dcbxp incompatibility interface

```
show qos dcbxp incompatibility interface <iface-num> [ __readonly__ { <pfc> <mtu> <lpg> <rpg> <bw>
<lfcqe> <rfcqe> <liscsi> <riscsi> } ]
```

Syntax Description

show	Show running system information
dcbxp	DCBXP
incompatibility	incompatibility information
interface	incompatibility info for interface
<i>iface-num</i>	Interface
<i>__readonly__</i>	(Optional)
<i>pfc</i>	(Optional) pfc
<i>mtu</i>	(Optional) MTU Value
<i>lpg</i>	(Optional) Local Priority Grouping
<i>rpg</i>	(Optional) Remote Priority Grouping
<i>bw</i>	(Optional) CIN: bandwidth/priority
<i>lfcqe</i>	(Optional) local fcoe
<i>rfcqe</i>	(Optional) remote fcoe
<i>liscsi</i>	(Optional) local iscsi
<i>riscsi</i>	(Optional) remote iscsi

Command Mode

- /exec

show qos dcbxp info

```
show qos dcbxp info [ __readonly__ { TABLE_dcbxp <intf> <pfc> <pfcc> <pgr> <pgc> <mtur> <mtuc>
<fcoer> <fcoec> <iscsir> <iscsic> } ]
```

Syntax Description

show	Show running system information
dcbxp	DCBXP
info	information
__readonly__	(Optional)
TABLE_dcbxp	(Optional) dxcbpx info
<i>intf</i>	(Optional) Interface
<i>pfc</i>	(Optional) pfc recvd
<i>pfcc</i>	(Optional) pfc compatible
<i>pgr</i>	(Optional) pg received
<i>pgc</i>	(Optional) pg compatible
<i>mtur</i>	(Optional) mtu received
<i>mtuc</i>	(Optional) mtu compatible
<i>fcoer</i>	(Optional) fcoe received
<i>fcoec</i>	(Optional) fcoe compatible
<i>iscsir</i>	(Optional) iscsi received
<i>iscsic</i>	(Optional) iscsi compatible

Command Mode

- /exec

show qos dcbxp interface

```
show qos dcbxp interface [ <iface> ] [ __readonly__ [ <intf> { <info_absent> | { [ <local_pfc_cap>
<local_pfc_enable_list> ] [ <peers_pfc_cap> <peers_pfc_enable_list> ] [ <local_ets_maxtc>
<local_ets_priority_list> <local_ets_bandwidth_list> <local_ets_tsa_list> ] [ <peers_ets_maxtc>
<peers_ets_priority_list> <peers_ets_bandwidth_list> <peers_ets_tsa_list> ] [ <local_app_pri>
<local_app_type> <local_app_num> ] + [ <peers_app_pri> <peers_app_type> <peers_app_num> ] + [
<local_map_pri> <local_map_dscp> ] + [ <peers_map_pri> <peers_map_dscp> ] + } } ] + ]
```

Syntax Description

show	Show running system information
qos	QoS
dcbxp	DCBXP
interface	Per-interface information
<i>iface</i>	(Optional) Interface
<i>__readonly__</i>	(Optional)
<i>intf</i>	(Optional) Interface
<i>info_absent</i>	(Optional) No information is present for this Interface.
<i>local_pfc_cap</i>	(Optional) Number of Local Flows
<i>local_pfc_enable_list</i>	(Optional) List of Local Flows Enabled
<i>peers_pfc_cap</i>	(Optional) Number of Peer Flows
<i>peers_pfc_enable_list</i>	(Optional) List of Peer Flows Enabled
<i>local_ets_maxtc</i>	(Optional) Local ETS Maximum Traffic Classes
<i>local_ets_priority_list</i>	(Optional) Local ETS Priority List
<i>local_ets_bandwidth_list</i>	(Optional) Local ETS Bandwidth List
<i>local_ets_tsa_list</i>	(Optional) Local ETS TSA List
<i>peers_ets_maxtc</i>	(Optional) Peer ETS Maximum Traffic Classes
<i>peers_ets_priority_list</i>	(Optional) Peer ETS Priority List
<i>peers_ets_bandwidth_list</i>	(Optional) Peer ETS Bandwidth List
<i>peers_ets_tsa_list</i>	(Optional) Peer ETS TSA List
<i>local_app_pri</i>	(Optional) Local Application Priority
<i>local_app_type</i>	(Optional) Local Application Number Type

<i>local_app_num</i>	(Optional) Local Application Number
<i>peers_app_pri</i>	(Optional) Peer Application Priority
<i>peers_app_type</i>	(Optional) Peer Application Number Type
<i>peers_app_num</i>	(Optional) Peer Application Number
<i>local_map_pri</i>	(Optional) Local Map Priority
<i>local_map_dscp</i>	(Optional) Local Map DSCP Value
<i>peers_map_pri</i>	(Optional) Peer Map Priority
<i>peers_map_dscp</i>	(Optional) Peer Map DSCP Value

Command Mode

- /exec

show qos shared-policer

```
show qos shared-policer [ type qos1 ] [ <policer-name> ] [ __readonly__ { [ TABLE_policer <policer-name2>
[ <cir-spec> ] [ <bc-spec> ] [ <be-spec> ] [ <cir-rate-units> ] [ <cir> ] [ <bc-size-units> ] [ <bc> ] [
<pir-rate-units> ] [ <pir> ] [ <be-size-units> ] [ <be> ] [ <cnf-col-cmap> ] [ <exc-col-cmap> ] [ TABLE_action
<action-key> [ <cnf-act> ] [ <exc-act> ] [ <vio-act> ] [ <set-type> ] [ <enum-spec> ] [ <set-val> ] [
<tmap-from> ] [ <tmap-to> ] [ <tmap-name> ] ] ] } ]
```

Syntax Description

show	Show running system information
shared-policer	Shared policer
type	(Optional) Type of shared policer
qos1	(Optional) type qos
<i>policer-name</i>	(Optional) Shared policer name
<i>__readonly__</i>	(Optional)
TABLE_policer	(Optional) all police xml sessions
<i>policer-name2</i>	(Optional) Policer Name
TABLE_action	(Optional) all police actions xml sessions
<i>action-key</i>	(Optional) Count
<i>cir-spec</i>	(Optional) Is CIR keyword specified
<i>bc-spec</i>	(Optional) Is Committed Burst keyword specified
<i>be-spec</i>	(Optional) Is Extended Burst keyword specified
<i>cir-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps
<i>pir-rate-units</i>	(Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps
<i>bc-size-units</i>	(Optional) Units of size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>be-size-units</i>	(Optional) Units of size - pkts/bytes/kbytes/mbytes/ms/us/perc
<i>tmap-from</i>	(Optional)
<i>tmap-to</i>	(Optional)
<i>tmap-name</i>	(Optional) Table map name
<i>cnf-col-cmap</i>	(Optional) Conforming color class-map name
<i>exc-col-cmap</i>	(Optional) Exceeding color class-map name
<i>enum-spec</i>	(Optional) Is DSCP or PREC enum value specified

<i>cnf-act</i>	(Optional) Conform action (Police)
<i>exc-act</i>	(Optional) Exceed action (Police)
<i>vio-act</i>	(Optional) Violate action (Police)
<i>set-type</i>	(Optional) Type of set in police action
<i>set-val</i>	(Optional) Value of set type in police action

Command Mode

- /exec

show queuing

```
show queuing [ interface [ <if_list> ] ] [ summary ] [ module <module> ] [ __readonly__ [
TABLE_interface_mtu <intf_name> <mtu_val> ] [ TABLE_queuing_interface <dir> <if_name_str> [
TABLE_qosgrp_cfg <qosgrp> [ <bandwidth> ] [ <priority> ] [ <shape-min> ] [ <shape-max> ] [ <shape-units>
] [ <buffer-size> ] [ <pause-threshold> ] [ <resume-threshold> ] [ <threshold-mode> ] [ <q-limit> ] [
<q-limit-type> ] ] [ <mc-drop-pkt> ] [ TABLE_qosgrp_egress_stats <eq-qosgrp> [
TABLE_qosgrp_egress_stats_entry <eq-stat-type> <eq-stat-units> <eq-uc-stat-value> [
<eq-oobfc-uc-stat-value> ] [ <eq-mc-stat-value> ] ] ] [ TABLE_egress_stats_entry <ep-stat-type>
<ep-stat-units> <ep-stat-value> ] [ TABLE_ingress_stats_entry <ip-stat-type> <ip-stat-units> <ip-stat-value>
] [ <tx-ppp> <rx-ppp> [ TABLE_pfc_stats <cos> [ <pfc-qosgrp> ] [ <pfc-pg> ] <tx-pause-state>
<tx-pause-count> <rx-pause-state> <rx-pause-count> ] ] ] ]
```

Syntax Description

show	commands to display
queuing	Queuing related information
interface	(Optional) Interface for displaying queuing config
<i>if_list</i>	(Optional) List of interfaces
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
summary	(Optional) summary
<i>__readonly__</i>	(Optional)
TABLE_interface_mtu	(Optional) mtu values of each interface
<i>intf_name</i>	(Optional) interface name
<i>mtu_val</i>	(Optional) mtu val of interface
TABLE_queuing_interface	(Optional) Queuing information of an interface
<i>dir</i>	(Optional) Direction
<i>if_name_str</i>	(Optional) interface name
TABLE_qosgrp_cfg	(Optional) Qos-group configuration
<i>qosgrp</i>	(Optional) Qos-group value
<i>bandwidth</i>	(Optional) WRR bandwidth
<i>priority</i>	(Optional) Priority level
<i>shape-units</i>	(Optional) Shape units
<i>threshold-mode</i>	(Optional) queue threshold mode - dynamic/static

<i>q-limit</i>	(Optional) Queue limit
<i>q-limit-type</i>	(Optional) Queue limit type (S-Static, D-Dynamic, U-Unlimited)
TABLE_qosgrp_egress_stats	(Optional) Qos-group egress statistics
<i>eq-qosgrp</i>	(Optional) Qos-group value
TABLE_qosgrp_egress_stats_entry	(Optional) Qos-group egress statistics entry
<i>eq-stat-type</i>	(Optional) Qos-group egress statistics type
<i>eq-stat-units</i>	(Optional) Qos-group egress statistics units
TABLE_egress_stats_entry	(Optional) Egress port statistics
<i>ep-stat-type</i>	(Optional) Egress port statistics type
<i>ep-stat-units</i>	(Optional) Egress port statistics units
TABLE_ingress_stats_entry	(Optional) Ingress port statistics
<i>ip-stat-type</i>	(Optional) Ingress port statistics type
<i>ip-stat-units</i>	(Optional) Ingress port statistics units
TABLE_pfc_stats	(Optional) Per COS PFC statistics
<i>cos</i>	(Optional) PFC COS
<i>pfc-qosgrp</i>	(Optional) Qos-group of the given COS
<i>pfc-pg</i>	(Optional) PG of the given COS/Qos-group
<i>tx-pause-state</i>	(Optional) Tx PFC state of the given COS
<i>rx-pause-state</i>	(Optional) Rx PFC state of the given COS

Command Mode

- /exec

show queuing burst-detect

```
show queuing burst-detect [ interface <if_name> [ queue <queue_num> ] ] [ module <module> ] [ detail ] [
__readonly__ [ TABLE_instance [ <if-str> ] [ <queue> ] [ <pipe> ] [ <threshold> ] [ <start-time> ] [ <peak>
] [ <peak-time> ] [ <end-depth> ] [ <end-time> ] [ <duration> ] ] ]
```

Syntax Description

show	commands to display
queuing	Queuing related information
burst-detect	Out of Band micro-burst queue statistics
interface	(Optional) Interface
<i>if_name</i>	(Optional) interface name
queue	(Optional) Queue number for displaying statistics
<i>queue_num</i>	(Optional) Queue number
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
detail	(Optional) detailed statistics
<i>if-str</i>	(Optional) Interface name
<i>__readonly__</i>	(Optional) Read Only
TABLE_instance	(Optional) Instance
<i>queue</i>	(Optional) Queue Number
<i>pipe</i>	(Optional) XPE-A or XPE-B
<i>threshold</i>	(Optional) Threshold value in bytes
<i>start-time</i>	(Optional) Start time of burst
<i>peak</i>	(Optional) Peak depth in bytes
<i>peak-time</i>	(Optional) Peak time of burst
<i>end-depth</i>	(Optional) End depth in bytes
<i>end-time</i>	(Optional) End time of burst
<i>duration</i>	(Optional) Duration of burst

Command Mode

- /exec

show queuing pfc-queue

```
show queuing pfc-queue [ interface <if_list> ] [ module <module> ] [ detail ] [ __readonly__ <glb-wd-status>
<glb-wd-force-status> <glb-wd-timer> <glb-wd-timer-thresh> <glb-auto-restore> <glb-fixed-restore>
<glb-int-intf-multi> <disable-action> <intf-multi> [ TABLE_queuing_interface <if_name_str> [
TABLE_qosgrp_stats <eq-qosgrp> [ TABLE_qosgrp_stats_entry <q-stat-type> <q-shutdown> <q-restored>
<q-pkt-drained> <q-pkt-dropped> <q-pkt-drained-n-dropped> <q-aggr-pkt-dropped> <q-ing-pkt-dropped>
<q-ing-aggr-pkt-dropped> ] ] [ TABLE_qosgrp_stats_summary <qosgrp-summary> ] ] ]
```

Syntax Description

show	commands to display
queuing	Queuing related information
pfc-queue	PFC Queuing related information
interface	(Optional) Interface for displaying queuing config
<i>if_list</i>	(Optional) List of interfaces
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
detail	(Optional) Show detailed PFC Queuing WD information
<i>__readonly__</i>	(Optional)
<i>glb-wd-status</i>	(Optional) Global watch-dog timer status
<i>glb-wd-force-status</i>	(Optional) Global watch-dog forcestatus
<i>glb-wd-timer</i>	(Optional) Global watch-dog timer value in msec
<i>glb-wd-timer-thresh</i>	(Optional) Global watch-dog timer thresh value in ms
<i>glb-auto-restore</i>	(Optional) Global auto restore multiplier value
<i>glb-fixed-restore</i>	(Optional) Global fixed restore multiplier value
<i>glb-int-intf-multi</i>	(Optional) Global internal interface multiplier value
<i>disable-action</i>	(Optional) Only generate syslog for queue stuck, no action
<i>intf-multi</i>	(Optional) Interface multilplier value
<i>if_name_str</i>	(Optional) interface name
TABLE_queuing_interface	(Optional) Queuing information of an interface
TABLE_qosgrp_stats	(Optional) Qos-group egress statistics
<i>eq-qosgrp</i>	(Optional) Qos-group value

TABLE_qosgrp_stats_entry	(Optional) Qos-group egress statistics entry
<i>q-stat-type</i>	(Optional) Queue stat
TABLE_qosgrp_stats_summary	(Optional) Qos-group egress statistics summary
<i>qosgrp-summary</i>	(Optional) Qos-group summary value

Command Mode

- /exec

show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex

```
show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex <ifindex> [ __readonly__ [
TABLE_watchdogIfQueueTable <ifindex> [ TABLE_qosgrp_stats <eq-qosgrp> <state> <shutdowns>
<restores> <dropPkts> <totaldropPkts> <ingDropPkts> <totalIngDropPkts> ] ] ]
```

Syntax Description

show	commands to display
queuing	Queuing related information
pfc-queue	PFC Queuing related information
interface	Interface for displaying queuing config
snmp	commands for snmp
watchdogIfQueueTable	Table
ifIndex	port ifIndex
<i>ifindex</i>	interfaces ifIndex
<i>__readonly__</i>	(Optional)
TABLE_watchdogIfQueueTable	(Optional) PFC Queuing information of an interface
<i>ifindex</i>	(Optional) interface ifindex
TABLE_qosgrp_stats	(Optional) Qos-group egress statistics
<i>eq-qosgrp</i>	(Optional) Qos-group value
<i>state</i>	(Optional) Queue state
<i>shutdowns</i>	(Optional) Number of times queue is shutdown
<i>restores</i>	(Optional) Number of times queue is restored
<i>dropPkts</i>	(Optional) Total Number of packets drained + dropped since last shutdown
<i>totaldropPkts</i>	(Optional) Number of aggregate packets dropped during shutdowns
<i>ingDropPkts</i>	(Optional) Total Number of packets dropped in the ingress direction since last shutdown
<i>totalIngDropPkts</i>	(Optional) Number of aggregate packets dropped in the ingress direction during shutdowns

Command Mode

show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex

- /exec

show queuing pfc-queue snmp ifIndex

```
show queuing pfc-queue snmp ifIndex <ifidx> [ __readonly__ TABLE-cpfcWatchdogIfQueueInfoTable
<ifidx_out> <queueno_out> <q-state> <q-shutdown> <q-restored> <q-pkt-dropped> <q-aggr-pkt-dropped>
<q-ing-pkt-dropped> <q-ing-aggr-pkt-dropped> ]
```

Syntax Description

show	Show running system information
queuing	Queuing related information
pfc-queue	PFC Queuing related information
snmp	Snmp information
ifIndex	Interface index
<i>ifidx</i>	Index
<i>__readonly__</i>	(Optional) Read Only
TABLE-cpfcWatchdogIfQueueInfoTable	(Optional) SNMP table
<i>ifidx_out</i>	(Optional) Interface index out
<i>queueno_out</i>	(Optional) Queue number out
<i>q-state</i>	(Optional) Queue state
<i>q-shutdown</i>	(Optional) Number of times queue is shutdown
<i>q-restored</i>	(Optional) Number of times queue is restored
<i>q-pkt-dropped</i>	(Optional) Number of packets dropped since last shutdown
<i>q-aggr-pkt-dropped</i>	(Optional) Number of aggregate packets dropped
<i>q-ing-pkt-dropped</i>	(Optional) Number of Ingress packets dropped
<i>q-ing-aggr-pkt-dropped</i>	(Optional) Number of aggregate Ingress packets dropped

Command Mode

- /exec

show queuing tabular

```
show queuing tabular [ non-zero [ drop-only ] ] [ interface <if_list> ] [ module <module> ] [ __readonly__ [
TABLE_queuing_interface<if_name_str><qos_group_name_0><qos_group_name_1><qos_group_name_2>
<qos_group_name_3><qos_group_name_4><qos_group_name_5><qos_group_name_6>
<qos_group_name_7><qos_group_name_cpu><qos_group_name_span><tx_uc_pkt_qos_0>
<tx_uc_byte_qos_0><tx_uc_drop_pkt_qos_0><tx_uc_drop_byte_qos_0><tx_uc_ecn_pkt_qos_0>
<tx_uc_ecn_byte_qos_0><tx_oobfc_uc_pkt_qos_0><tx_oobfc_uc_byte_qos_0>
<tx_oobfc_uc_drop_pkt_qos_0><tx_oobfc_uc_drop_byte_qos_0><tx_fld_pkt_qos_0><tx_fld_byte_qos_0>
<tx_fld_drop_pkt_qos_0><tx_fld_drop_byte_qos_0><tx_mc_pkt_qos_0><tx_mc_byte_qos_0>
<tx_mc_drop_pkt_qos_0><tx_mc_drop_byte_qos_0><pfc_rx_qos_0><pfc_tx_qos_0><qos_grp_1>
<qos_grp_2><qos_grp_3><qos_grp_4><qos_grp_5><qos_grp_6><qos_grp_7><qos_grp_cpu>
<qos_grp_span><ing_drop_pkt> ] ]
```

Syntax Description

show	commands to display
queuing	Queuing related information
tabular	QoS stats in tabular form
non-zero	(Optional) Interface for non-zero stats
drop-only	(Optional) Interface for non-zero drop-only stats
interface	(Optional) Interface for displaying queuing config
<i>if_list</i>	(Optional) List of interfaces
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
__readonly__	(Optional)
<i>if_name_str</i>	(Optional) interface name
TABLE_queuing_interface	(Optional) Queuing information of an interface
<i>qos_group_name_0</i>	(Optional) QoS Group name
<i>qos_group_name_1</i>	(Optional) QoS Group name
<i>qos_group_name_2</i>	(Optional) QoS Group name
<i>qos_group_name_3</i>	(Optional) QoS Group name
<i>qos_group_name_4</i>	(Optional) QoS Group name
<i>qos_group_name_5</i>	(Optional) QoS Group name
<i>qos_group_name_6</i>	(Optional) QoS Group name

<i>qos_group_name_7</i>	(Optional) QoS Group name
<i>qos_group_name_cpu</i>	(Optional) QoS Group name
<i>qos_group_name_span</i>	(Optional) QoS Group name

Command Mode

- /exec

show queuing tah-pfc-queue

```
show queuing tah-pfc-queue [ interface <if_list> ] [ module <module> ] [ detail ] [ __readonly__ [
TABLE_queuing_interface <if_name_str> [ TABLE_qosgrp_stats <eq-qosgrp> [ TABLE_qosgrp_stats_entry
<q-stat-type> <q-shutdown> <q-restored> <q-pkt-drained> <q-pkt-dropped> <q-total-pkt-dropped>
<q-aggr-pkt-dropped> <q-ingr-pkt-dropped> <q-aggr-ingr-pkt-dropped> ] ] [ TABLE_qosgrp_stats_summary
<qosgrp-summary> ] ] ]
```

Syntax Description

show	commands to display
queuing	Queuing related information
tah-pfc-queue	PFC Queuing related information
interface	(Optional) Interface for displaying queuing config
<i>if_list</i>	(Optional) List of interfaces
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
detail	(Optional) Show detailed PFC Queuing WD information
<i>__readonly__</i>	(Optional)
<i>if_name_str</i>	(Optional) interface name
TABLE_queuing_interface	(Optional) Queuing information of an interface
TABLE_qosgrp_stats	(Optional) Qos-group egress statistics
<i>eq-qosgrp</i>	(Optional) Qos-group value
TABLE_qosgrp_stats_entry	(Optional) Qos-group egress statistics entry
<i>q-stat-type</i>	(Optional) Queue stat
TABLE_qosgrp_stats_summary	(Optional) Qos-group egress statistics summary
<i>qosgrp-summary</i>	(Optional) Qos-group summary value

Command Mode

- /exec



R Show Commands

- [show radius-cfs](#), on page 2037
- [show radius-server](#), on page 2038
- [show radius-server](#), on page 2039
- [show radius-server directed-request](#), on page 2041
- [show radius-server groups](#), on page 2042
- [show radius-server sorted](#), on page 2043
- [show radius-server statistics](#), on page 2044
- [show radius status](#), on page 2046
- [show redundancy status](#), on page 2047
- [show regexp](#), on page 2049
- [show reload](#), on page 2050
- [show resource](#), on page 2051
- [show rmon](#), on page 2052
- [show role](#), on page 2054
- [show role feature-group](#), on page 2056
- [show role feature](#), on page 2057
- [show rollback log exec](#), on page 2058
- [show rollback status](#), on page 2059
- [show route-map](#), on page 2060
- [show route-map pbr-statistics](#), on page 2061
- [show router-guard](#), on page 2062
- [show routing-context](#), on page 2063
- [show routing](#), on page 2064
- [show routing clients](#), on page 2067
- [show routing event-history](#), on page 2069
- [show routing hash](#), on page 2071
- [show routing hidden-nh](#), on page 2074
- [show routing ipv6](#), on page 2075
- [show routing ipv6 clients](#), on page 2078
- [show routing ipv6 event-history](#), on page 2082
- [show routing ipv6 hash](#), on page 2083
- [show routing ipv6 hidden-nh](#), on page 2085
- [show routing ipv6 memory estimate](#), on page 2086

- [show routing ipv6 memory statistics](#), on page 2088
- [show routing ipv6 multicast](#), on page 2090
- [show routing ipv6 multicast clients](#), on page 2093
- [show routing ipv6 multicast event-history](#), on page 2096
- [show routing ipv6 multicast memory estimate](#), on page 2097
- [show routing ipv6 nexthop info](#), on page 2099
- [show routing ipv6 nhlfe](#), on page 2100
- [show routing ipv6 recursive-next-hop](#), on page 2102
- [show routing memory estimate](#), on page 2103
- [show routing memory statistics](#), on page 2105
- [show routing multicast](#), on page 2107
- [show routing multicast clients](#), on page 2111
- [show routing multicast event-history](#), on page 2115
- [show routing multicast lisp encap](#), on page 2116
- [show routing multicast mdt encapsulation](#), on page 2117
- [show routing multicast memory estimate](#), on page 2118
- [show routing multicast sr](#), on page 2120
- [show routing nhlfe](#), on page 2122
- [show routing recursive-next-hop](#), on page 2124
- [show routing unresolved-next-hop](#), on page 2126
- [show running-config](#), on page 2127
- [show running-config aaa](#), on page 2128
- [show running-config acllog](#), on page 2129
- [show running-config aclmgr](#), on page 2130
- [show running-config aclmgr active](#), on page 2131
- [show running-config adjmgr](#), on page 2132
- [show running-config all](#), on page 2133
- [show running-config arp](#), on page 2134
- [show running-config assoc](#), on page 2135
- [show running-config backup](#), on page 2136
- [show running-config bfd](#), on page 2137
- [show running-config bgp](#), on page 2138
- [show running-config bloggerd](#), on page 2139
- [show running-config callhome](#), on page 2140
- [show running-config catena](#), on page 2141
- [show running-config cdp](#), on page 2142
- [show running-config cert-enroll](#), on page 2143
- [show running-config cfs](#), on page 2144
- [show running-config clock_manager](#), on page 2145
- [show running-config config-profile](#), on page 2146
- [show running-config config-template](#), on page 2147
- [show running-config controller](#), on page 2148
- [show running-config copp](#), on page 2149
- [show running-config dhcp](#), on page 2150
- [show running-config diagnostic](#), on page 2151
- [show running-config diff](#), on page 2152

- [show running-config dot1x](#), on page 2153
- [show running-config ecp](#), on page 2154
- [show running-config eem](#), on page 2155
- [show running-config eigrp](#), on page 2156
- [show running-config eltm](#), on page 2157
- [show running-config evb](#), on page 2158
- [show running-config exclude](#), on page 2159
- [show running-config expand-port-profile](#), on page 2160
- [show running-config fabric forwarding](#), on page 2161
- [show running-config fabric multicast](#), on page 2162
- [show running-config fcoe_mgr](#), on page 2163
- [show running-config hardware-telemetry](#), on page 2164
- [show running-config hsrp](#), on page 2165
- [show running-config icam](#), on page 2166
- [show running-config icmpv6](#), on page 2167
- [show running-config igmp](#), on page 2168
- [show running-config imp](#), on page 2169
- [show running-config interface](#), on page 2170
- [show running-config interface](#), on page 2171
- [show running-config ip](#), on page 2172
- [show running-config ipqos](#), on page 2173
- [show running-config ipqos active](#), on page 2174
- [show running-config ipv6](#), on page 2175
- [show running-config isis](#), on page 2176
- [show running-config l3vm](#), on page 2177
- [show running-config ldap](#), on page 2178
- [show running-config license](#), on page 2179
- [show running-config lisp](#), on page 2180
- [show running-config lldp](#), on page 2181
- [show running-config mmode](#), on page 2182
- [show running-config monitor](#), on page 2183
- [show running-config msdp](#), on page 2184
- [show running-config nat](#), on page 2185
- [show running-config nbm](#), on page 2186
- [show running-config ngoam](#), on page 2187
- [show running-config ntp](#), on page 2188
- [show running-config nv overlay](#), on page 2189
- [show running-config nxsdk](#), on page 2190
- [show running-config openflow](#), on page 2191
- [show running-config ospf](#), on page 2192
- [show running-config ospfv3](#), on page 2193
- [show running-config param-list](#), on page 2194
- [show running-config pim](#), on page 2195
- [show running-config pim6](#), on page 2196
- [show running-config plb-services](#), on page 2197
- [show running-config poe](#), on page 2198

- [show running-config port-profile](#), on page 2199
- [show running-config port-security](#), on page 2200
- [show running-config ptp](#), on page 2201
- [show running-config radius](#), on page 2202
- [show running-config rip](#), on page 2203
- [show running-config routing ip multicast](#), on page 2204
- [show running-config routing ipv6 multicast](#), on page 2205
- [show running-config rpm](#), on page 2206
- [show running-config rsvp](#), on page 2207
- [show running-config section](#), on page 2208
- [show running-config security](#), on page 2209
- [show running-config services](#), on page 2210
- [show running-config services](#), on page 2211
- [show running-config sflow](#), on page 2212
- [show running-config sla responder](#), on page 2213
- [show running-config sla sender](#), on page 2214
- [show running-config sla twamp-server](#), on page 2215
- [show running-config smart-channel](#), on page 2216
- [show running-config snmp](#), on page 2217
- [show running-config spanning-tree](#), on page 2218
- [show running-config srte](#), on page 2219
- [show running-config switch](#), on page 2220
- [show running-config tacacs](#), on page 2221
- [show running-config track](#), on page 2222
- [show running-config udd](#), on page 2223
- [show running-config vdc-all](#), on page 2224
- [show running-config vdc](#), on page 2225
- [show running-config virtual-service](#), on page 2226
- [show running-config vlan](#), on page 2227
- [show running-config vlan](#), on page 2228
- [show running-config vlan](#), on page 2229
- [show running-config vmtracker](#), on page 2230
- [show running-config vpc](#), on page 2231
- [show running-config vrf](#), on page 2232
- [show running-config vrf default](#), on page 2233
- [show running-config vrrp](#), on page 2234
- [show running-config vrrpv3](#), on page 2235
- [show running-config vshd](#), on page 2236
- [show running-config vtp](#), on page 2237
- [show running-config wwnm](#), on page 2238

show radius-cfs

```
show radius-cfs [ __readonly__ [ <distr_status> ] [ <session_status> ] [ <session_db> ] [ <merge_status> ] ]
```

Syntax Description

show	Show running system information
radius-cfs	Show radius cfs state
<i>__readonly__</i>	(Optional)
<i>distr_status</i>	(Optional) radius distribution status
<i>session_status</i>	(Optional) current session status
<i>session_db</i>	(Optional) status of session db
<i>merge_status</i>	(Optional) radius merge status

Command Mode

- /exec

show radius-server

```
show radius-server { <host> } [ __readonly__ { <host1> } [ <authen_port> ] [ <account_port> ] [ <share_key> ] [ <timeout> ] [ <retries> ] [ <secure_radius> ] [ <aid> ] <idle_tim> <test_user_name> <test_pwd> ]
```

Syntax Description

show	Show running system information
radius-server	Show RADIUS configuration information
<i>host</i>	DNS name or IP address
<i>__readonly__</i>	(Optional)
<i>host1</i>	(Optional) DNS name or IP address
<i>authen_port</i>	(Optional) RADIUS server's port for authentication
<i>account_port</i>	(Optional) RADIUS server's port for accounting
<i>timeout</i>	(Optional) radius server timeout
<i>retries</i>	(Optional) radius server retry count
<i>secure_radius</i>	(Optional) secure radius enabled or not
<i>aid</i>	(Optional) Authority identity
<i>share_key</i>	(Optional) RADIUS shared secret
<i>test_user_name</i>	(Optional) User name in test packets
<i>test_pwd</i>	(Optional) User password in test packets
<i>idle_tim</i>	(Optional) Time interval for monitoring the server

Command Mode

- /exec

show radius-server

```
show radius-server [ __readonly__ [ <global_secretKey> ] { <global_timeout> <retransmissionCount>
<global_deadtime> } [ <global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [
<global_testPassword> ] } { <server_count> } [ TABLE_server <server_ip> [ <auth_port> ] [ <acct_port> ]
[ <secretKey> ] [ <timeout> ] [ <retries> ] ] [ { <host0> <auth_port> <acct_port> <shared_key>
<idle_time><test_username> <test_password> } + ] ]
```

Syntax Description

show	Show running system information
radius-server	Show RADIUS configuration information
<i>__readonly__</i>	(Optional)
<i>global_secretKey</i>	(Optional) Global shared secret
<i>global_timeout</i>	(Optional) Global timeout for tacacs
<i>retransmissionCount</i>	(Optional) Retransmission count when there is no server response
<i>global_deadtime</i>	(Optional) Global deadtime
<i>global_source_intf</i>	(Optional) Radius global source interface
<i>global_idle_time</i>	(Optional) Radius global idle-time for server monitoring
<i>global_testUsername</i>	(Optional) Username of global test parameters
<i>global_testPassword</i>	(Optional) Password of global test parameters
<i>server_count</i>	(Optional) Total number of radius servers configured
TABLE_server	(Optional)
<i>server_ip</i>	(Optional) Ip address of the server
<i>auth_port</i>	(Optional) Authentication port used for this server
<i>acct_port</i>	(Optional) Accounting Port used for this server
<i>secretKey</i>	(Optional) Shared secret between the server and the tacacs client
<i>timeout</i>	(Optional) Timeout for this tacacs server
<i>retries</i>	(Optional) Retry count for individual servers
<i>host0</i>	(Optional) DNS name or IP address
<i>auth_port</i>	(Optional) RADIUS server's port for authentication
<i>acct_port</i>	(Optional) RADIUS server's port for accounting
<i>shared_key</i>	(Optional) RADIUS shared secret

<i>test_password</i>	(Optional) User password in test packets
----------------------	------------------------------------------

Command Mode

- /exec

show radius-server directed-request

```
show radius-server directed-request [ __readonly__ { <radius_directedRequest_status> } ]
```

Syntax Description

show	Show running system information
radius-server	Show RADIUS configuration information
directed-request	Show directed server enable configuration
__readonly__	(Optional)
<i>radius_directedRequest_status</i>	(Optional) status of radius-server directed request

Command Mode

- /exec

show radius-server groups

```
show radius-server groups [ <s0> ] [ __readonly__ [ <num_of_groups> ] TABLE_group <group_name> [
TABLE_server <server_ip> [ <auth_port> ] [ <acct_port> ] ] [ <dead_time> ] [ <vrf_name> ] [
<source_interface> ] ]
```

Syntax Description

show	Show running system information
radius-server	Show RADIUS configuration information
groups	Show RADIUS server group configuration information
<i>s0</i>	(Optional) RADIUS server group name
<i>__readonly__</i>	(Optional)
<i>num_of_groups</i>	(Optional) number of groups
TABLE_group	(Optional)
<i>group_name</i>	(Optional) name of the group
TABLE_server	(Optional)
<i>server_ip</i>	(Optional) DNS name or IP address
<i>auth_port</i>	(Optional) radius server authentication port
<i>acct_port</i>	(Optional) radius server accounting port
<i>dead_time</i>	(Optional) Time interval for which the server is marked as dead before sending a test command
<i>vrf_name</i>	(Optional) name of the vrf
<i>source_interface</i>	(Optional) Interface Description

Command Mode

- /exec

show radius-server sorted

```
show radius-server sorted [ __readonly__ [ <global_secretKey> ] { <global_timeout> <retransmissionCount>
<global_deadtime> } [ <global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [
<global_testPassword> ] } { <server_count> } [ TABLE_server <server_ip> [ <auth_port> ] [ <acct_port> ]
[ <secretKey> ] [ <timeout> ] [ <retries> ] ] ]
```

Syntax Description

show	Show running system information
radius-server	Show RADIUS configuration information
sorted	Show RADIUS servers sorted by name
<i>__readonly__</i>	(Optional)
<i>global_secretKey</i>	(Optional) Global shared secret
<i>global_timeout</i>	(Optional) Global timeout for tacacs
<i>retransmissionCount</i>	(Optional) Retransmission count when there is no server response
<i>global_deadtime</i>	(Optional) Global deadtime
<i>global_source_intf</i>	(Optional) Radius global source interface
<i>global_idle_time</i>	(Optional) Radius global idle-time for server monitoring
<i>global_testUsername</i>	(Optional) Username of global test parameters
<i>global_testPassword</i>	(Optional) Password of global test parameters
<i>server_count</i>	(Optional) Total number of radius servers configured
TABLE_server	(Optional)
<i>server_ip</i>	(Optional) Ip address of the server
<i>auth_port</i>	(Optional) Authentication port used for this server
<i>acct_port</i>	(Optional) Accounting Port used for this server
<i>secretKey</i>	(Optional) Shared secret between the server and the tacacs client
<i>timeout</i>	(Optional) Timeout for this tacacs server
<i>retries</i>	(Optional) Retry count for individual servers

Command Mode

- /exec

show radius-server statistics

```
show radius-server statistics <host0> [ __readonly__ { <server_state> [ <clock_time> { monitoring_statistics
<time_in_pstate> <ndead> <tt_in_dstate> } ] } { auth_statistics <auth_failed_transactions>
<auth_succ_transactions> <auth_req_sent> <auth_req_timedout> <auth_resp_no_match>
<auth_resp_not_processed> <auth_resp_error> } { acct_statistics <acct_failed_transactions>
<acct_succ_transactions> <acct_req_sent> <acct_req_timedout> <acct_resp_no_match>
<acct_resp_not_processed> <acct_resp_error> } } ]
```

Syntax Description

show	Show running system information
radius-server	Show RADIUS configuration information
statistics	Show RADIUS statistics
<i>host0</i>	DNS name or IP address
<i>__readonly__</i>	(Optional)
<i>server_state</i>	(Optional) Show state of server
<i>clock_time</i>	(Optional) Show clock time in terms of hours, minutes and seconds
<i>monitoring_statistics</i>	(Optional) Monitoring Statistics
<i>time_in_pstate</i>	(Optional) Time in previous state
<i>ndead</i>	(Optional) Number of times dead
<i>tt_in_dstate</i>	(Optional) Total time in dead state
<i>auth_statistics</i>	(Optional) Authentication Statistics
<i>acct_statistics</i>	(Optional) Accounting Statistics
<i>auth_failed_transactions</i>	(Optional) Authentication: Failed transactions
<i>auth_succ_transactions</i>	(Optional) Authentication: Successful transactions
<i>auth_req_sent</i>	(Optional) Authentication: Requests sent
<i>auth_req_timedout</i>	(Optional) Authentication: Requests timedout
<i>auth_resp_no_match</i>	(Optional) Authentication: Responses with no matching requests
<i>auth_resp_not_processed</i>	(Optional) Authentication: Responses not processed
<i>auth_resp_error</i>	(Optional) Authentication: Responses containing errors
<i>acct_failed_transactions</i>	(Optional) Accounting: Failed transactions
<i>acct_succ_transactions</i>	(Optional) Accounting: Successful transactions

<i>acct_req_sent</i>	(Optional) Accounting: Requests sent
<i>acct_req_timeout</i>	(Optional) Accounting: Requests timeout
<i>acct_resp_no_match</i>	(Optional) Accounting: Responses with no matching requests
<i>acct_resp_not_processed</i>	(Optional) Accounting: Responses not processed
<i>acct_resp_error</i>	(Optional) Accounting: Responses containing errors

Command Mode

- /exec

show radius status

```
show radius status [ __readonly__ [ <distr_status> ] [ <session_status> ] [ <session_owner> ] [ <session_db> ] [ <last_operation> ] [ <last_operation_status> ] [ <fail_code> ] ]
```

Syntax Description

show	Show running system information
radius	Show RADIUS Information
status	Show RADIUS cfs distribution status
<i>__readonly__</i>	(Optional)
<i>distr_status</i>	(Optional) radius distribution status
<i>session_status</i>	(Optional) current session status
<i>session_owner</i>	(Optional) owner of the current distribution session
<i>session_db</i>	(Optional) status of session db
<i>last_operation</i>	(Optional) last_operation
<i>last_operation_status</i>	(Optional) status of the last operation
<i>fail_code</i>	(Optional) reason for the failure of last operation

Command Mode

- /exec

show redundancy status

```
show redundancy status [ __readonly__ <rmode_admin> <rmode_opr> <this_sup> <this_sup_rd_st>
<this_sup_sup_st> <this_sup_int_st> <oth_sup> <oth_sup_rd_st> <oth_sup_sup_st> <oth_sup_int_st>
<sys_strt_time> <sys_uptm_days> <sys_uptm_hrs> <sys_uptm_mins> <sys_uptm_secs> <kern_uptm_days>
<kern_uptm_hrs> <kern_uptm_mins> <kern_uptm_secs> <asup_uptm_days> <asup_uptm_hrs>
<asup_uptm_mins> <asup_uptm_secs> ]
```

Syntax Description

show	
redundancy	Show system redundancy status
status	Current redundancy status
<i>__readonly__</i>	(Optional)
<i>rmode_admin</i>	(Optional)
<i>rmode_opr</i>	(Optional)
<i>this_sup</i>	(Optional)
<i>this_sup_rd_st</i>	(Optional)
<i>this_sup_sup_st</i>	(Optional)
<i>this_sup_int_st</i>	(Optional)
<i>oth_sup</i>	(Optional)
<i>oth_sup_rd_st</i>	(Optional)
<i>oth_sup_sup_st</i>	(Optional)
<i>oth_sup_int_st</i>	(Optional)
<i>sys_strt_time</i>	(Optional)
<i>sys_uptm_days</i>	(Optional)
<i>sys_uptm_hrs</i>	(Optional)
<i>sys_uptm_mins</i>	(Optional)
<i>sys_uptm_secs</i>	(Optional)
<i>kern_uptm_days</i>	(Optional)
<i>kern_uptm_hrs</i>	(Optional)
<i>kern_uptm_mins</i>	(Optional)
<i>kern_uptm_secs</i>	(Optional)

<i>asup_uptm_days</i>	(Optional)
<i>asup_uptm_hrs</i>	(Optional)
<i>asup_uptm_mins</i>	(Optional)
<i>asup_uptm_secs</i>	(Optional)

Command Mode

- /exec

show regexp

```
show { ip mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] all | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 { unicast | multicast } ] } regexp <regexp-str> [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	Display BGP information for all address families
regexp	Display routes matching the AS path regular expression
<i>regexp-str</i>	Regular expression to match the AS paths

Command Mode

- /exec

show reload

show reload [*__readonly__* <reload-schedule>]

Syntax Description

show	Show running system information
reload	Display information about scheduled reload
<i>__readonly__</i>	(Optional)
<i>reload-schedule</i>	(Optional) Reload scheduling info

Command Mode

- /exec

show resource

```
show resource [ <res-mgr-res-known-name> ] [ hidden-too | with-flags ] [ __readonly__ {
TABLE_vdc_resource_local <res_name> <min> <max> <used> <unused> <free> } ]
```

Syntax Description

show	Show running system information
resource	Show resource configuration for VDC
<i>res-mgr-res-known-name</i>	(Optional) Resource name
hidden-too	(Optional) Also show hidden resources
with-flags	(Optional) Also show resource flags
__readonly__	(Optional) Read Only
TABLE_vdc_resource_local	(Optional)
<i>res_name</i>	(Optional) Resource Name
<i>min</i>	(Optional) Resource min configuration
<i>max</i>	(Optional) Resource max configuration
<i>used</i>	(Optional) Resource current usage for this VDC
<i>unused</i>	(Optional) Resource reserved for this VDC but currently not used
<i>free</i>	(Optional) Resource current free for this VDC

Command Mode

- /exec

show rmon

```
show rmon { alarms | events | hcalarms | info | logs } [ __readonly__ [ TABLE_rmon_alarm { <alarm-str>
<ascii-buf-str> <samp-type-str> <ris-trshod-str> <fall-trshod-str> <start-enable-str> } ] [ TABLE_rmon_event
{ <ev-alaran-str> <ev-desc-str> <ev-fir-cause> <last-fired> } ] [ TABLE_rmon_hcala { <hc-alaran-str>
<hc-ascii-buf-str> <hc-sam-ty-str> <hc-ris-thresh-str> <hc-fal-thresh-str> <start-alm-str> <fail-attem-str> }
] [ TABLE_rmon_info { <max-32-64-ala-str> <max-conf-32-ala-str> <max-conf-64-ala-str> } ] [
TABLE_rmon_log { <event-id-str> <rmon-pch> [ <log-buff-str> ] <log-oid> } ] ]
```

Syntax Description

show	Show running system information
rmon	Display RMON statistics
alarms	Display the RMON alarm table
events	Display the RMON event table
hcalarms	Display the RMON HC(High Capacity) Alarm table
info	Display the RMON info
logs	Display the RMON event log table
__readonly__	(Optional)
TABLE_rmon_alarm	(Optional)
<i>alarm-str</i>	(Optional)
<i>ascii-buf-str</i>	(Optional)
<i>samp-type-str</i>	(Optional)
<i>ris-trshod-str</i>	(Optional)
<i>fall-trshod-str</i>	(Optional)
<i>start-enable-str</i>	(Optional)
TABLE_rmon_event	(Optional)
<i>ev-alaran-str</i>	(Optional)
<i>ev-desc-str</i>	(Optional)
<i>ev-fir-cause</i>	(Optional)
<i>last-fired</i>	(Optional)
TABLE_rmon_hcala	(Optional)
<i>hc-alaran-str</i>	(Optional)

<i>hc-ascii-buf-str</i>	(Optional)
<i>hc-sam-ty-str</i>	(Optional)
<i>hc-ris-thresh-str</i>	(Optional)
<i>hc-fal-thresh-str</i>	(Optional)
<i>start-alm-str</i>	(Optional)
<i>fail-attem-str</i>	(Optional)
TABLE_rmon_info	(Optional)
<i>max-32-64-ala-str</i>	(Optional)
<i>max-conf-32-ala-str</i>	(Optional)
<i>max-conf-64-ala-str</i>	(Optional)
TABLE_rmon_log	(Optional)
<i>event-id-str</i>	(Optional)
<i>rmon-pch</i>	(Optional)
<i>log-buff-str</i>	(Optional)
<i>log-oid</i>	(Optional)

Command Mode

- /exec

show role

```
show role [ name <arg3> ] [ __readonly__ { TABLE_role <role_name> <role_description> [ <attribute_scope> ] [ <permit_vsan> ] [ <permit_vlan> ] [ <permit_vlan_id> ] [ <permit_interface> ] [ <permit_interface_slot> ] [ <permit_vrf> ] [ TABLE_vrf<permit_vrf_name> ] [ { TABLE_rule <rule_num> <rule_action> { <rule_permission> | <rule_permission_mds> } [ <rule_featuretype> ] [ <rule_entity> ] } } ]
```

Syntax Description

show	Show running system information
role	Show role configuration
name	(Optional) Enter the role name
arg3	(Optional) Enter the role name
__readonly__	(Optional)
TABLE_role	(Optional)
role_name	(Optional)
role_description	(Optional)
attribute_scope	(Optional)
permit_vsan	(Optional)
permit_vlan	(Optional)
permit_vlan_id	(Optional)
permit_interface	(Optional)
permit_interface_slot	(Optional)
permit_vrf	(Optional)
TABLE_rule	(Optional)
rule_num	(Optional)
rule_action	(Optional)
rule_permission	(Optional)
rule_permission_mds	(Optional)
rule_featuretype	(Optional)
rule_entity	(Optional)

Command Mode

- /exec

show role feature-group

```
show role feature-group [ name <arg4> ] [ detail ] [ __readonly__ TABLE_role_feature_group
<feature_group_name> TABLE_role_feature <feature_name> [ TABLE_role_feature_rule <feature_rule> ]
]
```

Syntax Description

show	Show running system information
role	Show role configuration
feature-group	Role feature group
name	(Optional) Enter the feature-group name
<i>arg4</i>	(Optional) Feature-group name
detail	(Optional) Detailed information including feature rules
<i>__readonly__</i>	(Optional)
TABLE_role_feature_group	(Optional)
<i>feature_group_name</i>	(Optional)
TABLE_role_feature	(Optional)
<i>feature_name</i>	(Optional)
TABLE_role_feature_rule	(Optional)
<i>feature_rule</i>	(Optional)

Command Mode

- /exec

show role feature

```
show role feature [ name <arg5> | detail ] [ __readonly__ TABLE_role_feature <feature_name> [
TABLE_role_feature_rule <feature_rule> ] ]
```

Syntax Description

show	Show running system information
role	Show role configuration
feature	Role feature
name	(Optional) Enter the feature name
<i>arg5</i>	(Optional) Feature name
detail	(Optional) Detailed information including feature rules
<i>__readonly__</i>	(Optional)
TABLE_role_feature	(Optional)
<i>feature_name</i>	(Optional)
TABLE_role_feature_rule	(Optional)
<i>feature_rule</i>	(Optional)

Command Mode

- /exec

show rollback log exec

```
show rollback log { exec | verify } [ __readonly__ [ <log_entry> + ] ]
```

Syntax Description

show	Show running system information
rollback	Show rollback
log	show rollback log
exec	show rollback execution log
verify	show rollback verify log
<i>__readonly__</i>	(Optional) Read only
<i>log_entry</i>	(Optional) log entry from rollback log

Command Mode

- /exec

show rollback status

```
show rollback status [ __readonly__ <last_operation> [ <rollback_type> ] [ <name> ] [ <start_time> ] [ <end_time> ] [ <operation_status> ] ]
```

Syntax Description

show	Show running system information
rollback	show rollback
status	show status of last rollback operation
<i>__readonly__</i>	(Optional) Read only
<i>last_operation</i>	(Optional) last operation
<i>rollback_type</i>	(Optional) rollback type
<i>name</i>	(Optional) name
<i>start_time</i>	(Optional) start time
<i>end_time</i>	(Optional) end time
<i>operation_status</i>	(Optional) operation status

Command Mode

- /exec

show route-map

```
show route-map [ <route-map-name> | <route-map-cfg-name> ] [ __readonly__ TABLE_rmap <name>
<action> <seq> [ <descript> ] [ <continue> ] [ { TABLE_rmap_match <match_type> <match_stmt> } ] [ {
TABLE_rmap_set <set_type> <set_stmt> } ] ]
```

Syntax Description

show	Show running system information
route-map	Route-map information
<i>route-map-name</i>	(Optional) Route-map name
<i>route-map-cfg-name</i>	(Optional) Known route-map name
<i>__readonly__</i>	(Optional)
TABLE_rmap	(Optional)
TABLE_rmap_match	(Optional)
TABLE_rmap_set	(Optional)
<i>name</i>	(Optional)
<i>action</i>	(Optional)
<i>seq</i>	(Optional)
<i>descript</i>	(Optional)
<i>continue</i>	(Optional)
<i>match_type</i>	(Optional)
<i>match_stmt</i>	(Optional)
<i>set_type</i>	(Optional)
<i>set_stmt</i>	(Optional)

Command Mode

- /exec

show route-map pbr-statistics

```
show route-map { <pbr_rmap_name> | <pbr_rmap_cfg_name> } pbr-statistics [ __readonly__ <tag> <action>
<seq> <pbr_pkt_count> <dflt_rtg_pkt_count> ]
```

Syntax Description

show	Show running system information
route-map	Route-map information
<i>pbr_rmap_name</i>	Route-map name
<i>pbr_rmap_cfg_name</i>	Known route-map name
pbr-statistics	PBR statistics
<i>__readonly__</i>	(Optional)
<i>tag</i>	(Optional)
<i>action</i>	(Optional)
<i>seq</i>	(Optional)
<i>pbr_pkt_count</i>	(Optional)
<i>dflt_rtg_pkt_count</i>	(Optional)

Command Mode

- /exec

show router-guard

```
show router-guard [ vlan <vlan_id> ] [ __readonly__ [ TABLE_vlanid { <vlanid>
<globally-enabled-switch-port> } [ TABLE_if [ <disabled-if> ] ] ] ] ]
```

Syntax Description

show	Show running system information
router-guard	Shows router guard config details for all interfaces
vlan	(Optional) Only for the specified VLAN
<i>vlan_id</i>	(Optional) VLAN ID
<i>__readonly__</i>	(Optional)
TABLE_vlanid	(Optional)
<i>vlanid</i>	(Optional)
<i>globally-enabled-switch-port</i>	(Optional)
TABLE_if	(Optional)
<i>disabled-if</i>	(Optional)

Command Mode

- /exec

show routing-context

```
show routing-context [ __readonly__ <routing-con> ]
```

Syntax Description

show	Show running system information
routing-context	Display the current routing context
<i>__readonly__</i>	(Optional)
<i>routing-con</i>	(Optional)

Command Mode

- /exec

show routing

```
show routing [ ip | ipv4 ] [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ip-addr> | {
<ip-prefix> [ { longer-prefixes | shorter-prefixes } ] } ] [ { <protocol> [ all ] } | { bind-label <bind-lbl> |
next-hop <next-hop> | next-hop-v6 <next-hop-v6> } | { interface <interface> } | { updated { [ since <stime>
] [ until <utime> ] } } ] + [ summary | detail ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [
__readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [ TABLE_prefix <ipprefix> <ucast-nhops>
<mcast-nhops> <attached> TABLE_path [ <ipnexthop> ] [ <ifname> ] [ <bindlbl> ] <uptime> <pref> <metric>
<clientname> [ <type> ] [ <tag> ] [ <stale> ] [ <unres> ] [ <hidden> ] [ <stale-label> ] [ <bgpbackuppath> ]
[ <ubest> ] [ <mbest> ] ] [ TABLE_summary <routes> <paths> [ <multicast_paths> ] [ TABLE_unicast [
<clientnameuni> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_multicast [ <clientnamemulti> ] [
<best-paths> ] [ <backup-paths> ] ] [ TABLE_route_count [ <mask_len> ] [ <count> ] ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
l3vm-info	(Optional) Display corresponding L3VM information
rpf	(Optional) Display RPF information for multicast source
<i>ip-addr</i>	(Optional) Display single route longest match lookup
<i>ip-prefix</i>	(Optional) Display single exact match route
longer-prefixes	(Optional) Display matching routes with mask-lengths \geq prefix
shorter-prefixes	(Optional) Display matching routes with mask-lengths \leq prefix
<i>protocol</i>	(Optional) Display routes for protocol (or route type)
all	(Optional) Display routes for protocol for backup next-hops too
bind-label	(Optional) Display routes with this bind-label only

<i>bind-lbl</i>	(Optional) Binding label
<i>next-hop</i>	(Optional) Display routes with this next-hop only
<i>next-hop</i>	(Optional) Next hop address
<i>next-hop-v6</i>	(Optional) Display routes with this V6 next-hop only
<i>interface</i>	(Optional) Display routes with this output interface only
<i>interface</i>	(Optional) Interface Name
<i>updated</i>	(Optional) Display routes filtered by last updated time
<i>since</i>	(Optional) Display those routes updated since this time
<i>stime</i>	(Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>until</i>	(Optional) Display those routes updated until this time
<i>utime</i>	(Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>summary</i>	(Optional) Display route counts
<i>detail</i>	(Optional) Display routes in full detail
<i>__readonly__</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>TABLE_addrf</i>	(Optional)
<i>addrf</i>	(Optional)
<i>TABLE_prefix</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>ucast-nhops</i>	(Optional)
<i>mcast-nhops</i>	(Optional)
<i>attached</i>	(Optional)
<i>TABLE_path</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>ifname</i>	(Optional)
<i>bindlbl</i>	(Optional)
<i>uptime</i>	(Optional)
<i>pref</i>	(Optional)

<i>metric</i>	(Optional)
<i>clientname</i>	(Optional)
<i>type</i>	(Optional)
<i>tag</i>	(Optional)
<i>stale</i>	(Optional)
<i>unres</i>	(Optional)
<i>hidden</i>	(Optional)
<i>stale-label</i>	(Optional)
<i>bgpbackuppath</i>	(Optional)
<i>ubest</i>	(Optional)
<i>mbest</i>	(Optional)
TABLE_summary	(Optional)
<i>routes</i>	(Optional)
<i>paths</i>	(Optional)
<i>multicast_paths</i>	(Optional)
TABLE_unicast	(Optional)
<i>clientnameuni</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_multicast	(Optional)
<i>clientnamemulti</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_route_count	(Optional)
<i>mask_len</i>	(Optional)
<i>count</i>	(Optional)

Command Mode

- /exec

show routing clients

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] clients [ <client> | <protocol> ] [ __readonly__ { TABLE_client <client_name>
<pib_index> <epid> [ <mts_sap> ] [ <mts_sap_str> ] <mru_cache_hits> <mru_cache_misses> <pib_stale_time>
<pss_created> [ <bad_l3vm_table_refcount> ] [ <pib_stale_timer> ] [ { TABLE_nib_node
<uribtibtype_contextname> [ <all_igp> ] [ <self> ] [ <all> ] [ <unib_notify_mask> ] <routes> <rnhs> <labels>
[ <convg_req_mask> ] [ <convg_send_mask> ] [ <utib_state> ] [ <pending_timer> ] [ <urib_state_invalid>
} ] [ { TABLE_msgs_rcvd <urib_mtype_str> <upib_rcvd> } ] [ { TABLE_msgs_sent <urib_mtype_str>
<upib_sent> } ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
clients	Display urib client information
<i>client</i>	(Optional) Display single urib client information
<i>protocol</i>	(Optional) Display single urib client information
__readonly__	(Optional)
TABLE_client	(Optional)
<i>client_name</i>	(Optional)
<i>pib_index</i>	(Optional)
<i>epid</i>	(Optional)
<i>mts_sap</i>	(Optional)
<i>mts_sap_str</i>	(Optional)

<i>mru_cache_hits</i>	(Optional)
<i>mru_cache_misses</i>	(Optional)
<i>pib_stale_time</i>	(Optional)
<i>pss_created</i>	(Optional)
<i>bad_l3vm_table_refcount</i>	(Optional)
<i>pib_stale_timer</i>	(Optional)
TABLE_nib_node	(Optional)
<i>uribtibtype_contextname</i>	(Optional)
<i>all_igp</i>	(Optional)
<i>self</i>	(Optional)
<i>all</i>	(Optional)
<i>unib_notify_mask</i>	(Optional)
<i>routes</i>	(Optional)
<i>rnhs</i>	(Optional)
<i>labels</i>	(Optional)
<i>convg_req_mask</i>	(Optional)
<i>convg_send_mask</i>	(Optional)
<i>utib_state</i>	(Optional)
<i>pending_timer</i>	(Optional)
<i>urib_state_invalid</i>	(Optional)
TABLE_msgs_rcvd	(Optional)
<i>urib_mtype_str</i>	(Optional)
<i>upib_rcvd</i>	(Optional)
TABLE_msgs_sent	(Optional)
<i>urib_mtype_str</i>	(Optional)
<i>upib_sent</i>	(Optional)

Command Mode

- /exec

show routing event-history

```
show routing [ ip | ipv4 ] [ unicast ] [ internal ] event-history { statistics | msgs | { { add-route | cli | delete-route
| detail | dme | errors | general | ha | loop-detection | modify-route | notifications | recursive-next-hop | summary
| ufdm | ufdm-detail | ufdm-summary } [ filter [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ client
{ <client> | <protocol> } ] [ prefix-list <pfxlist-name> ] ] } }
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
internal	(Optional) Commands for internal use
event-history	Show routing event log
statistics	Show routing event log Statistics
msgs	Show routing message event log
add-route	Add route
cli	CLI
delete-route	Delete route
detail	Detail
dme	DME
errors	Errors
general	General
ha	HA
loop-detection	Loop detection
modify-route	Modify route
notifications	Notification
recursive-next-hop	Recursive next hop
summary	Summary
ufdm	UFDM

ufdm-detail	UFDM Detail
ufdm-summary	UFDM Summary
filter	(Optional) Filter event log
vrf	(Optional) Filter VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Filter for all VRFs
client	(Optional) Filter by client
<i>client</i>	(Optional) Filter by single urib client
<i>protocol</i>	(Optional) Filter by single urib client
prefix-list	(Optional) Filter by IPv4 prefix-list
<i>pxlist-name</i>	(Optional) IPv4 prefix list name

Command Mode

- /exec

show routing hash

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] hash <source> <dest> [ ip-proto <ip-proto> ] { { [ gtpu-teid <gtpu-teid> ] } } { [ <src-port>
<dest-port> ] } [ in-interface <in-interface> ] [ module <module-id> ] [ vrf { <vrf-name> | <vrf-known-name>
| <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> TABLE_hashpath <mcast>
<hashpath> <hash-val> TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> <attached> TABLE_path
<ubest> <mbest> <ipnexthop> <ifname> <pref> <metric> <uptime> <clientname> [ <type> ] [ <tag> ] [
<stale> ] [ <unres> ] [ <hidden> ] [ <stale-label> ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
hash	Display load-balancing hash information
<i>source</i>	Source IPv4 address of unicast flow or group address for multicast flow
<i>dest</i>	Destination IPv4 address of unicast flow or source address for multicast flow
<i>src-port</i>	(Optional) Source-port
<i>dest-port</i>	(Optional) Destination-port
in-interface	(Optional) Incoming Interface for Packet.Option valid on Tomahawk platform only
<i>in-interface</i>	(Optional) Interface Name
ip-proto	(Optional) IP Protocol information for the packet
<i>ip-proto</i>	(Optional) IP Protocol information for the packet
gtpu-teid	(Optional) GTPu TEID for the packet

<i>gtpu-teid</i>	(Optional) GTPu TEID for the packet
<i>module</i>	(Optional) Module
<i>module-id</i>	(Optional) Module
<i>__readonly__</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>TABLE_addrf</i>	(Optional)
<i>addrf</i>	(Optional)
<i>TABLE_hashpath</i>	(Optional)
<i>mcast</i>	(Optional)
<i>hashpath</i>	(Optional)
<i>hash-val</i>	(Optional)
<i>TABLE_prefix</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>ucast-nhops</i>	(Optional)
<i>mcast-nhops</i>	(Optional)
<i>attached</i>	(Optional)
<i>TABLE_path</i>	(Optional)
<i>ubest</i>	(Optional)
<i>mbest</i>	(Optional)
<i>ipnexthop</i>	(Optional)
<i>ifname</i>	(Optional)
<i>pref</i>	(Optional)
<i>metric</i>	(Optional)
<i>uptime</i>	(Optional)
<i>clientname</i>	(Optional)
<i>type</i>	(Optional)
<i>tag</i>	(Optional)
<i>stale</i>	(Optional)

<i>unres</i>	(Optional)
<i>hidden</i>	(Optional)
<i>stale-label</i>	(Optional)

Command Mode

- /exec

show routing hidden-nh

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] hidden-nh [ __readonly__ <uribtibtype_contextname> [ <utibtibtype_topologyname> ]
{ TABLE_hidden_nh <hidden_nh_uhn_prefix> <hidden_nh_uhn_mask_len> <pib> <rnh> <rnh_mask_len>
} ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
hidden-nh	Display hidden next-hop information
<i>__readonly__</i>	(Optional)
<i>uribtibtype_contextname</i>	(Optional)
<i>utibtibtype_topologyname</i>	(Optional)
TABLE_hidden_nh	(Optional)
<i>hidden_nh_uhn_prefix</i>	(Optional)
<i>hidden_nh_uhn_mask_len</i>	(Optional)
<i>pib</i>	(Optional)
<i>rnh</i>	(Optional)
<i>rnh_mask_len</i>	(Optional)

Command Mode

- /exec

show routing ipv6

```
show routing ipv6 [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ipv6-addr> | { <ipv6-prefix>
[ { longer-prefixes | shorter-prefixes } ] ] [ { <ipv6-protocol> [ all ] } | { next-hop <next-hop> } | { interface
<interface> } | { updated { [ since <stime> ] [ until <utime> ] } } ] + [ summary | { [ detail ] [ deleted ] } ] [
vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf
<addrf> [ TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> [ <attached> ] TABLE_path [ <ubest>
] [ <mbest> ] [ <ipnexthop> ] [ <ifname> ] <uptime> <pref> <metric> <clientname> [ <type> ] [ <tag> ] [
<stale> ] [ <stalelbl> ] [ <hidden> ] ] [ TABLE_summary <routes> <paths> [ <multicast_paths> ] [
TABLE_unicast [ <clientnameuni> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_multicast [
<clientnamemulti> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_route_count [ <mask_len> ] [ <count>
] ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
l3vm-info	(Optional) Display corresponding L3VM information
rpf	(Optional) Display RPF information for multicast source
longer-prefixes	(Optional) Display matching routes with mask-lengths >= prefix
shorter-prefixes	(Optional) Display matching routes with mask-lengths <= prefix
<i>ipv6-protocol</i>	(Optional) Display routes for protocol (or route type)
all	(Optional) Display routes for protocol for backup next-hops too
next-hop	(Optional) Display routes with this next-hop only
interface	(Optional) Display routes with this output interface only
<i>interface</i>	(Optional) Interface Name
updated	(Optional) Display routes filtered by last updated time

<i>since</i>	(Optional) Display those routes updated since this time
<i>stime</i>	(Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>until</i>	(Optional) Display those routes updated until this time
<i>utime</i>	(Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS]
<i>summary</i>	(Optional) Display route counts
<i>deleted</i>	(Optional) Display delete-pending routes also
<i>detail</i>	(Optional) Display routes in full detail
<i>__readonly__</i>	(Optional)
<i>TABLE_vrf</i>	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>TABLE_addrf</i>	(Optional)
<i>addrf</i>	(Optional)
<i>TABLE_prefix</i>	(Optional)
<i>ucast-nhops</i>	(Optional)
<i>mcast-nhops</i>	(Optional)
<i>attached</i>	(Optional)
<i>TABLE_path</i>	(Optional)
<i>ubest</i>	(Optional)
<i>mbest</i>	(Optional)
<i>ifname</i>	(Optional)
<i>pref</i>	(Optional)
<i>tag</i>	(Optional)
<i>metric</i>	(Optional)
<i>uptime</i>	(Optional)
<i>clientname</i>	(Optional)
<i>type</i>	(Optional)
<i>stale</i>	(Optional)
<i>stalelbl</i>	(Optional)
<i>hidden</i>	(Optional)

TABLE_summary	(Optional)
<i>routes</i>	(Optional)
<i>paths</i>	(Optional)
<i>multicast_paths</i>	(Optional)
TABLE_unicast	(Optional)
<i>clientnameuni</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_multicast	(Optional)
<i>clientnamemulti</i>	(Optional)
<i>best-paths</i>	(Optional)
<i>backup-paths</i>	(Optional)
TABLE_route_count	(Optional)
<i>mask_len</i>	(Optional)
<i>count</i>	(Optional)

Command Mode

- /exec

show routing ipv6 clients

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ]
clients [ <client> | <ipv6-protocol> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__
{ TABLE_client <client_name> <pib_index> <pib_state> <pib_id> <multicast_or_unicast_pib>
<mru_cache_hits> <mru_cache_misses> [ <mts_sap> ] [ <mts_sap_str> ] [ <bad_l3vm_table_refcount> ]
<pib_stale_time> [ { TABLE_nib_node <u6ribtibtype_contextname> <routes> <rnhs> [ {
TABLE_notiffee_mask [ <u6pib_name> ] [ <index> } ] ] [ <u6tib_state> ] [ <pending_timer> ] [
<u6rib_state_invalid> ] [ <u6nib_notifier_all> ] [ { TABLE_notify_rcd <notify_rcd_name>
<notify_rcd_handle> [ <notifier_pib_u6pib_index> } ] ] [ { TABLE_notiffee_nib <notiffee_pib_u6pib_name>
<u6nib_notify_handle> } ] ] ] [ { TABLE_ready_client_event_queue <queue_name><queue_count> [ {
TABLE_client_event <event> <use_buf> <sched> <resend> <buf> [ <state> } ] } ] ] [ {
TABLE_buffer_rqst_client_event_queue <queue_name><queue_count> [ { TABLE_client_event <event>
<use_buf> <sched> <resend> <buf> [ <state> } ] } ] ] [ <update_ack_queue_count> [ { TABLE_update_ack
<update_ack> <update_ack_data> <update_ack_type> <update_ack_xid> } ] ] [ {
TABLE_route_buffer_used_queue <queue_name> <queue_count> [ { TABLE_clt_buf
<clt_buf><clt_buf_count><clt_buf_xid> } ] } ] ] [ { TABLE_rnh_buffer_used_queue <queue_name>
<queue_count> [ { TABLE_clt_buf <clt_buf><clt_buf_count><clt_buf_xid> } ] } ] ] [ { TABLE_msgs_rcvd
<u6rib_mtype_str><u6pib_rcvd> } ] ] [ { TABLE_msgs_sent <u6rib_mtype_str><u6pib_sent> } ] } ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
clients	Display u6rib client information
<i>client</i>	(Optional) Display single u6rib client information
<i>ipv6-protocol</i>	(Optional) Display single u6rib client information
__readonly__	(Optional)
TABLE_client	(Optional)
<i>client_name</i>	(Optional)

<i>plib_index</i>	(Optional)
<i>plib_state</i>	(Optional)
<i>plib_id</i>	(Optional)
<i>multicast_or_unicast_plib</i>	(Optional)
<i>mru_cache_hits</i>	(Optional)
<i>mru_cache_misses</i>	(Optional)
<i>mts_sap</i>	(Optional)
<i>mts_sap_str</i>	(Optional)
<i>bad_l3vm_table_refcount</i>	(Optional)
<i>plib_stale_time</i>	(Optional)
TABLE_nib_node	(Optional)
<i>u6ribtibtype_contextname</i>	(Optional)
<i>routes</i>	(Optional)
<i>rnhs</i>	(Optional)
TABLE_notiffee_mask	(Optional)
<i>u6plib_name</i>	(Optional)
<i>index</i>	(Optional)
<i>u6tib_state</i>	(Optional)
<i>pending_timer</i>	(Optional)
<i>u6rib_state_invalid</i>	(Optional)
<i>u6nib_notifier_all</i>	(Optional)
TABLE_notify_rcd	(Optional)
<i>notify_rcd_name</i>	(Optional)
<i>notify_rcd_handle</i>	(Optional)
<i>notifier_plib_u6plib_index</i>	(Optional)
TABLE_notiffee_nib	(Optional)
<i>notiffee_plib_u6plib_name</i>	(Optional)
<i>u6nib_notify_handle</i>	(Optional)
TABLE_ready_client_event_queue	(Optional)

<i>queue_name</i>	(Optional)
<i>queue_count</i>	(Optional)
TABLE_client_event	(Optional)
<i>event</i>	(Optional)
<i>use_buf</i>	(Optional)
<i>sched</i>	(Optional)
<i>resend</i>	(Optional)
<i>buf</i>	(Optional)
<i>state</i>	(Optional)
TABLE_buffer_rqst_client_event_queue	(Optional)
<i>queue_name</i>	(Optional)
<i>queue_count</i>	(Optional)
TABLE_client_event	(Optional)
<i>event</i>	(Optional)
<i>use_buf</i>	(Optional)
<i>sched</i>	(Optional)
<i>resend</i>	(Optional)
<i>buf</i>	(Optional)
<i>state</i>	(Optional)
<i>update_ack_queue_count</i>	(Optional)
TABLE_update_ack	(Optional)
<i>update_ack</i>	(Optional)
<i>update_ack_data</i>	(Optional)
<i>update_ack_type</i>	(Optional)
<i>update_ack_xid</i>	(Optional)
TABLE_route_buffer_used_queue	(Optional)
TABLE_clt_buf	(Optional)
TABLE_rnh_buffer_used_queue	(Optional)
TABLE_clt_buf	(Optional)

TABLE_msgs_rcvd	(Optional)
TABLE_msgs_sent	(Optional)

Command Mode

- /exec

show routing ipv6 event-history

show routing ipv6 [unicast] [internal] event-history { statistics | msgs | am | cli | detail | errors | general | ha | lfe | recursive-next-hop | summary | ufdm | ufdm-detail | ufdm-summary }

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
internal	(Optional) Commands for internal use
event-history	Show routing event log
statistics	Show routing event log Statistics
msgs	Show routing message event log
am	AM
cli	CLI
detail	Detail
errors	Errors
general	General
ha	HA
lfe	LFE
recursive-next-hop	Recursive next hop
summary	Summary
ufdm	UFDM
ufdm-detail	UFDM Detail
ufdm-summary	UFDM Summary

Command Mode

- /exec

show routing ipv6 hash

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] hash [ mpls <ipv6-prefix> [ eos ] ] <source> <dest> [ ip-proto <ip-proto> ] [ <src-port> <dest-port> ] [ in-interface <in-interface> ] [ module <module-id> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> [ <hash-type> ] [ <mcast> ] [ <hashpath> ] TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> <attached> TABLE_path [ <ubest> ] [ <mbest> ] [ <ipnexthop> ] [ <ifname> ] <uptime> <pref> <metric> <clientname> [ <type> ] [ <tag> ] [ <stale> ] [ <hidden> ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
hash	Display load-balancing hash information
mpls	(Optional) MPLS path load-balancing hash information
eos	(Optional) Set End-of-Stack to 1
ip-proto	(Optional) IP Protocol information for the packet
<i>ip-proto</i>	(Optional) IP Protocol information for the packet
<i>src-port</i>	(Optional) Source-port
<i>dest-port</i>	(Optional) Destination-port
in-interface	(Optional) Incoming Interface for Packet.Option valid on Tomahawk platform only.
<i>in-interface</i>	(Optional) Interface Name
module	(Optional) Module
<i>module-id</i>	(Optional) Module
__readonly__	(Optional)

TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>hash-type</i>	(Optional)
<i>mcast</i>	(Optional)
<i>hashpath</i>	(Optional)
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>ucast-nhops</i>	(Optional)
<i>mcast-nhops</i>	(Optional)
<i>attached</i>	(Optional)
TABLE_path	(Optional)
<i>ubest</i>	(Optional)
<i>mbest</i>	(Optional)
<i>ifname</i>	(Optional)
<i>pref</i>	(Optional)
<i>tag</i>	(Optional)
<i>metric</i>	(Optional)
<i>uptime</i>	(Optional)
<i>clientname</i>	(Optional)
<i>type</i>	(Optional)
<i>stale</i>	(Optional)
<i>hidden</i>	(Optional)

Command Mode

- /exec

show routing ipv6 hidden-nh

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] hidden-nh [ __readonly__ <uribtibtype_contextname> { TABLE_hidden_nh <nh> <nh-iod> <hidden_nh_uhn_prefix> <hidden_nh_uhn_mask_len> <pib> <rnh> <rnh_mask_len> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
hidden-nh	Display hidden next-hop information
<i>__readonly__</i>	(Optional)
<i>uribtibtype_contextname</i>	(Optional)
TABLE_hidden_nh	(Optional)
<i>nh</i>	(Optional)
<i>nh-iod</i>	(Optional)
<i>hidden_nh_uhn_prefix</i>	(Optional)
<i>hidden_nh_uhn_mask_len</i>	(Optional)
<i>pib</i>	(Optional)
<i>rnh</i>	(Optional)
<i>rnh_mask_len</i>	(Optional)

Command Mode

- /exec

show routing ipv6 memory estimate

```
show routing ipv6 [ unicast ] memory estimate [ routes <route-count> next-hops <nh-count> ] [ labels ] [
__readonly__ <curr-max-MB> <curr-max-routes> <curr-max-nh> <inuse-MB> <inuse-routes> <inuse-nh>
<conf-max-MB> <conf-max-routes> <conf-max-nh> [ <est-MB> <est-routes> <est-nh> ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
memory	Display u6rib memory information
estimate	Display u6rib memory estimate
routes	(Optional) Display u6rib memory estimate for # routes
<i>route-count</i>	(Optional) Number of routes
next-hops	(Optional) Display u6rib memory estimate for # next-hops per route
<i>nh-count</i>	(Optional) Number of next-hops per route
labels	(Optional) When the routes are associated with next hop labels
<i>__readonly__</i>	(Optional)
<i>curr-max-MB</i>	(Optional)
<i>curr-max-routes</i>	(Optional)
<i>curr-max-nh</i>	(Optional)
<i>inuse-MB</i>	(Optional)
<i>inuse-routes</i>	(Optional)
<i>inuse-nh</i>	(Optional)
<i>conf-max-MB</i>	(Optional)
<i>conf-max-routes</i>	(Optional)
<i>conf-max-nh</i>	(Optional)
<i>est-MB</i>	(Optional)
<i>est-routes</i>	(Optional)
<i>est-nh</i>	(Optional)

Command Mode

- /exec

show routing ipv6 memory statistics

```
show routing ipv6 [ unicast ] memory statistics [ __readonly__ { TABLE_shrd_mem <rbuf-alloc>
<rbuf-high-water> <rbuf-max> <rbuf-numalloc> <slbs-alloc> <slbs-high-water> <slbs-max> <slbs-numalloc>
} { TABLE_u6rib_slabs <slab-name> <alloc-count> <max-allocs> <slab-size> } { TABLE_u6rib_blks
<slab-blk-name> <block-count> <max-blocks> <slab-count> } { TABLE_u6rib_routes_rnhs <ctx-name>
<user-nodes> <total-nodes> <elem-size> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
unicast	(Optional) Display unicast routing information
memory	Display u6rib memory information
statistics	Display u6rib memory statistics
<i>__readonly__</i>	(Optional)
<i>TABLE_shrd_mem</i>	(Optional)
<i>TABLE_u6rib_slabs</i>	(Optional)
<i>TABLE_u6rib_blks</i>	(Optional)
<i>TABLE_u6rib_routes_rnhs</i>	(Optional)
<i>ctx-name</i>	(Optional)
<i>slab-name</i>	(Optional)
<i>slab-blk-name</i>	(Optional)
<i>rbuf-alloc</i>	(Optional)
<i>rbuf-high-water</i>	(Optional)
<i>rbuf-max</i>	(Optional)
<i>rbuf-numalloc</i>	(Optional)
<i>slbs-alloc</i>	(Optional)
<i>slbs-high-water</i>	(Optional)
<i>slbs-max</i>	(Optional)
<i>slbs-numalloc</i>	(Optional)
<i>user-nodes</i>	(Optional)

<i>total-nodes</i>	(Optional)
<i>elem-size</i>	(Optional)
<i>alloc-count</i>	(Optional)
<i>max-allocs</i>	(Optional)
<i>slab-size</i>	(Optional)
<i>block-count</i>	(Optional)
<i>max-blocks</i>	(Optional)
<i>slab-count</i>	(Optional)

Command Mode

- /exec

show routing ipv6 multicast

```
show routing ipv6 multicast [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ topology <topology-name> ]
[ [ bitfield ] | rp | { [ <group> ] summary [ software-forwarded ] } | { summary [ count | software-forwarded
] } | { <source> <group> } | { <group> [ <source> ] } } [ summary [ software-forwarded ] | bitfield ] ] [
__readonly__ { TABLE_vrf <vrf-name> [ TABLE_addr <mcast-addr> <pending> <bidir> <uptime> [
TABLE_mpib <mpib-name> <stale-route> ] <if-name><rpf-nbr> <internal>
<oif-count><fabric-oif><fabric-loser> [ TABLE_oif <oif-name> <oif-uptime> [ TABLE_oif_mpib
<oif-mpib-name> <stale-oif> ] <rpf> ] [ <oif-list-bitfield> ] ] [ <total-route-count> <star-g-count>
<source-count> <star-g-prefix-count> <group-count> <avg-sources-per-group><rem> [
<reason-for-route-stats-pending> ] ] [ TABLE_group <group-addr> <group-mask-len> <source-count-per-grp>
[ TABLE_source <route-or-source> [ <name> ] <packets> <bytes> <aps> <pps> <bit-rate-in-bps> <oifs> [
<software-pkts> ] ] ] } ]
```

Syntax Description

show	Show running system information
ipv6	Display IPv6 information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
routing	Display routing information
multicast	Display multicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
summary	(Optional) Display route counts
software-forwarded	(Optional) Display software switched route counts only
rp	(Optional) Display RP routes (RP, 0::/128)
count	(Optional) Display route counts only
bitfield	(Optional) Display bitfield details
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_addr	(Optional)

<i>mcast-addrs</i>	(Optional)
<i>bidir</i>	(Optional)
<i>pending</i>	(Optional)
<i>uptime</i>	(Optional)
<i>internal</i>	(Optional)
TABLE_mpib	(Optional)
<i>mpib-name</i>	(Optional)
<i>stale-route</i>	(Optional)
TABLE_oif	(Optional)
<i>oif-name</i>	(Optional)
<i>oif-uptime</i>	(Optional)
<i>rpf</i>	(Optional)
<i>oif-list-bitfield</i>	(Optional)
TABLE_oif_mpib	(Optional)
<i>oif-mpib-name</i>	(Optional)
<i>stale-oif</i>	(Optional)
<i>total-route-count</i>	(Optional)
<i>star-g-count</i>	(Optional)
<i>source-count</i>	(Optional)
<i>star-g-prefix-count</i>	(Optional)
<i>group-count</i>	(Optional)
<i>reason-for-route-stats-pending</i>	(Optional)
TABLE_group	(Optional)
<i>group-addr</i>	(Optional)
<i>group-mask-len</i>	(Optional)
<i>source-count-per-grp</i>	(Optional)
TABLE_source	(Optional)
<i>route-or-source</i>	(Optional)
<i>name</i>	(Optional)

<i>packets</i>	(Optional)
<i>bytes</i>	(Optional)
<i>aps</i>	(Optional)
<i>pps</i>	(Optional)
<i>bit-rate-in-bps</i>	(Optional)
<i>oifs</i>	(Optional)
<i>software-pkts</i>	(Optional)

Command Mode

- /exec

show routing ipv6 multicast clients

```
show routing ipv6 multicast clients [ <client-name> ] [ __readonly__ { TABLE_client <client-name> <cid>
<pid> <mts-sap> <shared-mem> <is-stale-timer-running> <wants-notification> [ TABLE_protocol
<SSM-owner> <Bidir-owner> <static-owner> <shared-only-owner> <locally-joined-owner> <external-owner>
<Fabric-owner> ] { TABLE_join_notifications <sent> <fail> <ack-rcvd> } { TABLE_prune_notifications
<sent> <fail> <ack-rcvd> } { TABLE_rpf_notifications <sent> <fail> <ack-rcvd> } {
TABLE_delete_notifications <sent> <fail> <ack-rcvd> } { TABLE_clear_mrroute_notifications <sent> <fail>
} { TABLE_add_route_req <rcvd> <ack-sent> <ack-fail> } { TABLE_del_route_req <rcvd> <ack-sent>
<ack-fail> } { TABLE_upd_route_req <rcvd> <ack-sent> <ack-fail> } { TABLE_mts_route_req <rcvd>
<ack-sent> <ack-fail> } } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display multicast information
clients	Display multicast routing client information
<i>client-name</i>	(Optional) Multicast routing client name
<i>__readonly__</i>	(Optional)
TABLE_client	(Optional)
<i>client-name</i>	(Optional)
<i>cid</i>	(Optional)
<i>pid</i>	(Optional)
<i>mts-sap</i>	(Optional)
<i>shared-mem</i>	(Optional)
<i>is-stale-timer-running</i>	(Optional)
<i>wants-notification</i>	(Optional)
TABLE_protocol	(Optional)
<i>SSM-owner</i>	(Optional)
<i>Bidir-owner</i>	(Optional)
<i>static-owner</i>	(Optional)
<i>shared-only-owner</i>	(Optional)
<i>locally-joined-owner</i>	(Optional)

<i>external-owner</i>	(Optional)
<i>Fabric-owner</i>	(Optional)
TABLE_join_notifications	(Optional)
<i>sent</i>	(Optional)
<i>fail</i>	(Optional)
<i>ack-rcvd</i>	(Optional)
TABLE_prune_notifications	(Optional)
<i>sent</i>	(Optional)
<i>fail</i>	(Optional)
<i>ack-rcvd</i>	(Optional)
TABLE_rpf_notifications	(Optional)
<i>sent</i>	(Optional)
<i>fail</i>	(Optional)
<i>ack-rcvd</i>	(Optional)
TABLE_delete_notifications	(Optional)
<i>sent</i>	(Optional)
<i>fail</i>	(Optional)
<i>ack-rcvd</i>	(Optional)
TABLE_clear_mroute_notifications	(Optional)
<i>sent</i>	(Optional)
<i>fail</i>	(Optional)
TABLE_add_route_req	(Optional)
<i>rcvd</i>	(Optional)
<i>ack-sent</i>	(Optional)
<i>ack-fail</i>	(Optional)
TABLE_del_route_req	(Optional)
<i>rcvd</i>	(Optional)
<i>ack-sent</i>	(Optional)
<i>ack-fail</i>	(Optional)

TABLE_upd_route_req	(Optional)
<i>rcvd</i>	(Optional)
<i>ack-sent</i>	(Optional)
<i>ack-fail</i>	(Optional)
TABLE_mts_route_req	(Optional)
<i>rcvd</i>	(Optional)
<i>ack-sent</i>	(Optional)
<i>ack-fail</i>	(Optional)

Command Mode

- /exec

show routing ipv6 multicast event-history

```
show routing ipv6 multicast [ internal ] event-history { errors | msgs | <m6rib-event-hist-buf-name> | statistics
}
```

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display multicast information
internal	(Optional) Commands for internal use
event-history	Show various event logs of M6RIB
errors	Show error logs of M6RIB
msgs	Show various message logs of M6RIB
<i>m6rib-event-hist-buf-name</i>	M6RIB event history buffer name
statistics	Show the state and size of the buffers

Command Mode

- /exec

show routing ipv6 multicast memory estimate

```
show routing ipv6 multicast memory estimate [ groups <group-count> sources-per-group <source-count>
oifs-per-entry <oif-count> ] [ __readonly__ { { TABLE_cur_max <current-max-mb> <groups>
<sources-per-group> <oifs-per-entry> } { TABLE_in_use <in-use_kb> <groups> <sources-per-group>
<oifs-per-entry> } { TABLE_conf_max <conf-max-mb> <groups> <sources-per-group> <oifs-per-entry> }
[ TABLE_est_max <estimate-mb> <groups> <sources-per-group> <oifs-per-entry> ] } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display multicast information
memory	Display m6rib memory information
estimate	Display m6rib memory estimate
groups	(Optional) Display m6rib memory estimate for # groups
<i>group-count</i>	(Optional) Number of groups
sources-per-group	(Optional) Display mrib memory estimate for # sources per group
<i>source-count</i>	(Optional) Number of sources per route
oifs-per-entry	(Optional) Display mrib memory estimate for # oifs per (S,G) or (*,G) entry
<i>oif-count</i>	(Optional) Number of oifs per entry
<i>__readonly__</i>	(Optional)
TABLE_cur_max	(Optional)
<i>current-max-mb</i>	(Optional)
<i>groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)
TABLE_in_use	(Optional)
<i>in-use_kb</i>	(Optional)
<i>groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)

<i>oifs-per-entry</i>	(Optional)
TABLE_conf_max	(Optional)
<i>conf-max-mb</i>	(Optional)
<i>groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)
TABLE_est_max	(Optional)
<i>estimate-mb</i>	(Optional)
<i>groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)

Command Mode

- /exec

show routing ipv6 nexthop info

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] nexthop info [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
nexthop	Show the nh_info tree
info	Show the nh_info tree

Command Mode

- /exec

show routing ipv6 nhlfe

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ]
nhlfe [ stats ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ { TABLE_vrf
<vrf-name-out> [ <nhlfe-owner> <nhlfe-refcount> { TABLE_nhlabel <nlabel-index> <nh-label> }
<nhlfe-is-vpn> <nhlfe-owner-index> ] <total-entries> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
nhlfe	Display NHLFE db
stats	(Optional) Display statistics
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>nhlfe-owner</i>	(Optional)
<i>nhlfe-refcount</i>	(Optional)
TABLE_nhlabel	(Optional)
<i>nlabel-index</i>	(Optional)
<i>nh-label</i>	(Optional)
<i>nhlfe-is-vpn</i>	(Optional)
<i>nhlfe-owner-index</i>	(Optional)
<i>total-entries</i>	(Optional)

Command Mode

- /exec

show routing ipv6 recursive-next-hop

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] recursive-next-hop [ <ipv6-addr> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [ TABLE_prefix <ipprefix> <uptime> TABLE_clients <client-req> [ <client-pend> ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ipv6	Display IPv6 information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
recursive-next-hop	Display recursive next-hop table
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_addrf	(Optional)
<i>addrf</i>	(Optional)
TABLE_prefix	(Optional)
<i>uptime</i>	(Optional)
TABLE_clients	(Optional)
<i>client-req</i>	(Optional)
<i>client-pend</i>	(Optional)

Command Mode

- /exec

show routing memory estimate

```
show routing [ ip | ipv4 ] [ unicast ] memory estimate [ routes <route-count> [ next-hops <nh-count>
<nh-unique> ] [ next-hops-v6 <nh6-count> <nh6-unique> ] [ next-hops-srte <srte-count> <srte-unique> ] ] [
labels ] [ __readonly__ <current_max_mb> <current_max_routes> <urib_max_nh> <used_mb>
<route_stats_alloc_count> <nhs> <configured_max_mb> <configured_max_routes> <urib_routes_max_nh>
[ <estimate_mb> <estimate_routes> <estimate_nhs> <estimate_with_mvpn_mb> <estimate_with_ospf_mb>
<estimate_with_eigrp_mb> ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
memory	Display urib memory information
estimate	Display urib memory estimate
routes	(Optional) Display urib memory estimate for # routes
<i>route-count</i>	(Optional) Number of routes
next-hops	(Optional) Display urib memory estimate for # next-hops per route
<i>nh-count</i>	(Optional) Number of next-hops per route
<i>nh-unique</i>	(Optional) Number of unique next-hops (between 1 and route-count*nh-count)
next-hops-v6	(Optional) Display urib memory estimate for # V6 next-hops per route
<i>nh6-count</i>	(Optional) Number of V6 next-hops per route
<i>nh6-unique</i>	(Optional) Number of unique V6 next-hops (between 1 and route-count*nh6-count)
next-hops-srte	(Optional) Display urib memory estimate for # srte next-hops per route
<i>srte-count</i>	(Optional) Number of srte next-hops per route
<i>srte-unique</i>	(Optional) Number of unique srte next-hops (between 1 and route-count*srte-count)
labels	(Optional) When the routes are associated with next hop labels
<i>__readonly__</i>	(Optional)
<i>current_max_mb</i>	(Optional)

<i>current_max_routes</i>	(Optional)
<i>urib_max_nh</i>	(Optional)
<i>used_mb</i>	(Optional)
<i>route_stats_alloc_count</i>	(Optional)
<i>nhs</i>	(Optional)
<i>configured_max_mb</i>	(Optional)
<i>configured_max_routes</i>	(Optional)
<i>urib_routes_max_nh</i>	(Optional)
<i>estimate_mb</i>	(Optional)
<i>estimate_routes</i>	(Optional)
<i>estimate_nhs</i>	(Optional)
<i>estimate_with_mvpn_mb</i>	(Optional)
<i>estimate_with_ospf_mb</i>	(Optional)
<i>estimate_with_eigrp_mb</i>	(Optional)

Command Mode

- /exec

show routing memory statistics

```
show routing [ ip | ipv4 ] [ unicast ] memory statistics [ debug ] [ __readonly__ { TABLE_shrd_mem
<ubuf-alloc> <ubuf-high-water> <ubuf-max> <ubuf-numalloc> <rbuf-alloc> <rbuf-high-water> <rbuf-max>
<rbuf-numalloc> <slbs-alloc> <slbs-high-water> <slbs-max> <slbs-numalloc> } { TABLE_urib_slabs
<slab-name> <slab-alloc-count> <slab-max-allocs> <slab-size> } { TABLE_urib_blks <block-name>
<block-count> <max-blocks> <blks-count> } { TABLE_urib_routes_rnhs <ctx-name> <user-node>
<total-node> <elem-size> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
memory	Display urib memory information
statistics	Display urib memory statistics
debug	(Optional) Display debugging data
__readonly__	(Optional)
TABLE_shrd_mem	(Optional)
<i>ubuf-alloc</i>	(Optional)
<i>ubuf-high-water</i>	(Optional)
<i>ubuf-max</i>	(Optional)
<i>ubuf-numalloc</i>	(Optional)
<i>rbuf-alloc</i>	(Optional)
<i>rbuf-high-water</i>	(Optional)
<i>rbuf-max</i>	(Optional)
<i>rbuf-numalloc</i>	(Optional)
<i>slbs-alloc</i>	(Optional)
<i>slbs-high-water</i>	(Optional)
<i>slbs-max</i>	(Optional)
<i>slbs-numalloc</i>	(Optional)

TABLE_urib_slabs	(Optional)
<i>slab-name</i>	(Optional)
<i>slab-alloc-count</i>	(Optional)
<i>slab-max-allocs</i>	(Optional)
<i>slab-size</i>	(Optional)
TABLE_urib_blks	(Optional)
<i>block-name</i>	(Optional)
<i>block-count</i>	(Optional)
<i>max-blocks</i>	(Optional)
<i>blks-count</i>	(Optional)
TABLE_urib_routes_rnhs	(Optional)
<i>ctx-name</i>	(Optional)
<i>user-node</i>	(Optional)
<i>total-node</i>	(Optional)
<i>elem-size</i>	(Optional)

Command Mode

- /exec

show routing multicast

```
show routing [ ip | ipv4 ] multicast { { [ bitfield ] [ detail ] } | rp | { [ <group> ] summary [ software-forwarded
| rpf-failed ] } | { summary [ count | software-forwarded | rpf-failed ] } | { { <source> <group> } | { <group>
[ <source> ] | <group> shared-tree | <group> source-tree } | shared-tree | source-tree } { [ flags ] | [ detail ] |
[ summary [ software-forwarded | rpf-failed ] | bitfield ] } } [ vrf { <vrf-name> | <vrf-known-name> | all } ]
[ __readonly__ TABLE_vrf <vrf-name> [ <expyr_timer> ] [ <route_count> ] [ <star_g_cnt> ] [ <sg_cnt> ]
[ <star_g_prfx_cnt> ] [ TABLE_route_summary [ <total-num-routes> ] [ <star-g-route> ] [ <sg-route> ] [
<star-g-prfx> ] [ <group-count> ] [ <avg> ] [ <rem> ] [ <stats-pndg> ] ] [ TABLE_summary_source [
<group_addr> ] [ <group_mask_len> ] [ <source_count> ] [ TABLE_one_sg [ <source_addr> ] [ <packets>
] [ <bytes> ] [ <aps> ] [ <pps> ] [ <rate_buf> ] [ <oifs> ] [ <software_fwd> ] [ <rpf-failed-pkts> ] [
<rpf-failed-bytes> ] ] ] [ TABLE_one_route <mcast-addr> [ <source_addr> <group_addr> ] <pending>
<bidir> <uptime> <mofrr> [ TABLE_mpib [ <mpib-name> ] [ <oif-count> ] [ <stale-route> ] ] [
<mdt-encap-index> ] [ <stats-pkts> ] [ <stats-bytes> ] [ <stats-rate-buf> ] [ <lisp-src-rloc> ] [
<translated-route-src> ] [ <translated-route-grp> ] [ <route-iif> ] [ <rpf-nbr> ] [ <mofrr-iif> ] [ <mofrr-nbr>
] <internal> [ <oif-count> ] <fabric-oif> <fabric-loser> [ <num-vpc-svi-oifs> ] [ TABLE_oif [ <oif-name> ]
[ <oif-uptime> ] [ TABLE_oif_mpib [ <oif-mpib-name> ] [ <stale-oif> ] [ <omd-vpc-svi> ] ] <rpf> ] [
<route-mdt-iod> ] [ <oif-list-bitfield> ] ] ] ]
```

Syntax Description

show	Show running system information
ip	(Optional) Display IP information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
routing	Display routing information
ipv4	(Optional) Display IP information
multicast	Display multicast information
summary	Display route counts
shared-tree	Display route for *,G entries
source-tree	Display route for S,G entries
software-forwarded	(Optional) Display software switched route counts only
rpf-failed	(Optional) Display RPF failure statistics
rp	Display RP routes (RP, 0.0.0.0/32)
<i>group</i>	(Optional) Display multicast group/source address for route
<i>source</i>	Display multicast group/source address for route

count	(Optional) Display route counts only
bitfield	(Optional) Display bitfield details
detail	(Optional) Display detailed route attributes
flags	(Optional) Display detailed route attributes
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
<i>expry_timer</i>	(Optional)
<i>route_count</i>	(Optional)
<i>star_g_cnt</i>	(Optional)
<i>sg_cnt</i>	(Optional)
<i>star_g_prfx_cnt</i>	(Optional)
TABLE_summary_source	(Optional)
<i>group_addr</i>	(Optional)
<i>group_mask_len</i>	(Optional)
<i>source_count</i>	(Optional)
TABLE_one_sg	(Optional)
<i>source_addr</i>	(Optional)
<i>packets</i>	(Optional)
<i>bytes</i>	(Optional)
<i>aps</i>	(Optional)
<i>pps</i>	(Optional)
<i>rate_buf</i>	(Optional)
<i>oifs</i>	(Optional)
<i>software_fwd</i>	(Optional)
<i>rpf-failed-pkts</i>	(Optional)
<i>rpf-failed-bytes</i>	(Optional)
TABLE_one_route	(Optional)
<i>mcast-addrs</i>	(Optional)

<i>source_addrs</i>	(Optional)
<i>group_addrs</i>	(Optional)
<i>bidir</i>	(Optional)
<i>pending</i>	(Optional)
<i>mofrr</i>	(Optional)
<i>uptime</i>	(Optional)
TABLE_mpib	(Optional)
<i>mpib-name</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>stale-route</i>	(Optional)
<i>mdt-encap-index</i>	(Optional)
<i>stats-pkts</i>	(Optional)
<i>stats-bytes</i>	(Optional)
<i>stats-rate-buf</i>	(Optional)
<i>lisp-src-rloc</i>	(Optional)
<i>translated-route-src</i>	(Optional)
<i>translated-route-grp</i>	(Optional)
<i>route-iif</i>	(Optional)
<i>rpf-nbr</i>	(Optional)
<i>mofrr-iif</i>	(Optional)
<i>mofrr-nbr</i>	(Optional)
<i>internal</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>fabric-oif</i>	(Optional)
<i>fabric-loser</i>	(Optional)
<i>num-vpc-svi-oifs</i>	(Optional)
TABLE_oif	(Optional)
<i>oif-name</i>	(Optional)
<i>oif-uptime</i>	(Optional)

TABLE_oif_mpib	(Optional)
<i>oif-mpib-name</i>	(Optional)
<i>stale-oif</i>	(Optional)
<i>omd-vpc-svi</i>	(Optional)
<i>rpf</i>	(Optional)
<i>route-mdt-iod</i>	(Optional)
<i>oif-list-bitfield</i>	(Optional)
TABLE_route_summary	(Optional)
<i>total-num-routes</i>	(Optional)
<i>star-g-route</i>	(Optional)
<i>sg-route</i>	(Optional)
<i>star-g-prfx</i>	(Optional)
<i>group-count</i>	(Optional)
<i>avg</i>	(Optional)
<i>rem</i>	(Optional)
<i>stats-pndg</i>	(Optional)

Command Mode

- /exec

show routing multicast clients

```
show routing [ ip | ipv4 ] multicast clients [ <client-name> ] [ detail ] [ __readonly__ { TABLE_mpib
<mpib_name> <mpib_index> <mpib_pid> <mpib_mts_sap> <mpib_shm> <stale_timer> <join_notify>
<prune_notify> <rpf_notify> <delete_notify> <repopulate_notify> <zero-oif-notify> <non-zero-oif-notify>
<attach_notify> <non-attach_notify> <static_notify> <non-static_notify> <internal_notify>
<non-internal_notify><external_notify><non-external_notify> <otv-decap_notify>
<no-otv-decap_notify><vxlan-decap_notify> <no-vxlan-decap_notify>
<mdt-encap_notify><no-mdt-encap_notify> <mdt-decap_notify> <no-mdt-decap_notify><vpc-svi_notify>
<notification_pending> [ <ssm_owner> <bidir_owner> <static_owner> <shared_only_owner>
<locally_joined_owner> <external_owner> <mdt_owner> <fabric_owner> <sticky_iif_owner>
<data_created_owner> <internal_owner> <prune_owner> <attached_owner> <otv_decap_owner>
<vxlan_decap_owner> <secondary_owner> <encap_index_owner> <force_punt_owner> <multi_route_owner>
<register_stop_owner> ] <notify_sent> <notify_fail> <notify_ack_rcvd> <add_route_req_rcvd>
<add_route_ack_sent> <add_route_ack_fail> <delete_route_req_rcvd> <delete_route_ack_sent>
<delete_route_ack_fail> <update_route_req_rcvd> <update_route_ack_sent> <update_route_ack_fail>
<update_mdt_info_req_rcvd> <update_mdt_info_ack_sent> <update_mdt_info_ack_fail>
<mts_update_route_req_rcvd> <mts_update_route_ack_sent> <mts_update_route_ack_fail>
<force_update_rcvd> <notify_member_count> <pending_mpib> <uptime> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information
clients	Display multicast routing client information
<i>client-name</i>	(Optional) Multicast routing client name
detail	(Optional) Display detailed route attributes
__readonly__	(Optional)
TABLE_mpib	(Optional)
<i>mpib_name</i>	(Optional)
<i>mpib_index</i>	(Optional)
<i>mpib_pid</i>	(Optional)
<i>mpib_mts_sap</i>	(Optional)
<i>mpib_shm</i>	(Optional)
<i>stale_timer</i>	(Optional)

<i>join_notify</i>	(Optional)
<i>prune_notify</i>	(Optional)
<i>rpf_notify</i>	(Optional)
<i>delete_notify</i>	(Optional)
<i>repopulate_notify</i>	(Optional)
<i>zero-oif-notify</i>	(Optional)
<i>non-zero-oif-notify</i>	(Optional)
<i>attach-notify</i>	(Optional)
<i>non-attach-notify</i>	(Optional)
<i>static-notify</i>	(Optional)
<i>non-static-notify</i>	(Optional)
<i>internal-notify</i>	(Optional)
<i>otv-decap-notify</i>	(Optional)
<i>no-vxlan-decap-notify</i>	(Optional)
<i>mdt-decap-notify</i>	(Optional)
<i>notification_pending</i>	(Optional)
<i>ssm_owner</i>	(Optional)
<i>bidir_owner</i>	(Optional)
<i>static_owner</i>	(Optional)
<i>shared_only_owner</i>	(Optional)
<i>locally_joined_owner</i>	(Optional)
<i>external_owner</i>	(Optional)
<i>mdt_owner</i>	(Optional)
<i>fabric_owner</i>	(Optional)
<i>sticky_iif_owner</i>	(Optional)
<i>data_created_owner</i>	(Optional)
<i>internal_owner</i>	(Optional)
<i>prune_owner</i>	(Optional)
<i>attached_owner</i>	(Optional)

<i>otv_decap_owner</i>	(Optional)
<i>vxlan_decap_owner</i>	(Optional)
<i>secondary_owner</i>	(Optional)
<i>encap_index_owner</i>	(Optional)
<i>force_punt_owner</i>	(Optional)
<i>multi_route_owner</i>	(Optional)
<i>register_stop_owner</i>	(Optional)
<i>notify_sent</i>	(Optional)
<i>notify_fail</i>	(Optional)
<i>notify_ack_rcvd</i>	(Optional)
<i>add_route_req_rcvd</i>	(Optional)
<i>add_route_ack_sent</i>	(Optional)
<i>add_route_ack_fail</i>	(Optional)
<i>delete_route_req_rcvd</i>	(Optional)
<i>delete_route_ack_sent</i>	(Optional)
<i>delete_route_ack_fail</i>	(Optional)
<i>update_route_req_rcvd</i>	(Optional)
<i>update_route_ack_sent</i>	(Optional)
<i>update_route_ack_fail</i>	(Optional)
<i>update_mdt_info_req_rcvd</i>	(Optional)
<i>update_mdt_info_ack_sent</i>	(Optional)
<i>update_mdt_info_ack_fail</i>	(Optional)
<i>mts_update_route_req_rcvd</i>	(Optional)
<i>mts_update_route_ack_sent</i>	(Optional)
<i>mts_update_route_ack_fail</i>	(Optional)
<i>force_update_rcvd</i>	(Optional)
<i>notify_member_count</i>	(Optional)
<i>pending_mpib</i>	(Optional)
<i>uptime</i>	(Optional)

Command Mode

- /exec

show routing multicast event-history

```
show routing [ ip | ipv4 ] multicast [ internal ] event-history { errors | msgs | <mrib-event-hist-buf-name> |
statistics }
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information
internal	(Optional) Commands for internal use
event-history	Show various event logs of MRIB
errors	Show error logs of MRIB
msgs	Show various message logs of MRIB
<i>mrib-event-hist-buf-name</i>	Event history buffer name
statistics	State and size of buffer

Command Mode

- /exec

show routing multicast lisp encap

```
{ show routing [ ip | ipv4 ] multicast lisp encap } [ __readonly__ { TABLE_mrib_list_encap <encap-index>
<source-rloc> <dest-rloc> <ref-count> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information
lisp	LISP related information
encap	All the encap indices
__readonly__	(Optional)
TABLE_mrib_list_encap	(Optional)
<i>encap-index</i>	(Optional)
<i>source-rloc</i>	(Optional)
<i>dest-rloc</i>	(Optional)
<i>ref-count</i>	(Optional)

Command Mode

- /exec

show routing multicast mdt encapsulation

```
show routing [ ip | ipv4 ] multicast mdt encapsulation [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all
} ] [ __readonly__ [ TABLE_vrf <vrf-name> [ TABLE_mdt <index> <group> <source> <count>
<delete-pending> ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information
mdt	Multicast Distribution Tree
encapsulation	Encapsulation Information
detail	(Optional) Display detailed information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
TABLE_mdt	(Optional)
<i>index</i>	(Optional)
<i>group</i>	(Optional)
<i>source</i>	(Optional)
<i>count</i>	(Optional)
<i>delete-pending</i>	(Optional)

Command Mode

- /exec

show routing multicast memory estimate

```
show routing [ ip | ipv4 ] multicast memory estimate [ groups <group-count> sources-per-group <source-count>
oifs-per-entry <oif-count> [ mdt-encap-entries <encap-entry-count> ] [ __readonly__ [ TABLE_currentmax
[ <max-mb> ] [ <max-groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] ] [ TABLE_inuse [ <used-kb>
] [ <alloc-count> ] [ <sources-per-group> ] [ <oifs-per-entry> ] [ <mdt-encap-entry> ] ] [
TABLE_configuredmax [ <max-mb> ] [ <max-groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] ] [
TABLE_estimate [ <estimate-mb> ] [ <groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] [
<mdt-encap-entry> ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information
memory	Display mrib memory information
estimate	Display mrib memory estimate
groups	(Optional) Display mrib memory estimate for # groups
<i>group-count</i>	(Optional) Number of groups
sources-per-group	(Optional) Display mrib memory estimate for # sources per group
<i>source-count</i>	(Optional) Number of sources per route
oifs-per-entry	(Optional) Display mrib memory estimate for # oifs per (S,G) or (*,G) entry
<i>oif-count</i>	(Optional) Number of oifs per entry
mdt-encap-entries	(Optional) Display mrib memory estimate for # mdt encap entries
<i>encap-entry-count</i>	(Optional) Number of mdt encap entries
__readonly__	(Optional)
TABLE_currentmax	(Optional)
<i>max-mb</i>	(Optional)
<i>max-groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)

TABLE_inuse	(Optional)
<i>used-kb</i>	(Optional)
<i>alloc-count</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)
<i>mdt-encap-entry</i>	(Optional)
TABLE_configuredmax	(Optional)
<i>max-mb</i>	(Optional)
<i>max-groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)
TABLE_estimate	(Optional)
<i>estimate-mb</i>	(Optional)
<i>groups</i>	(Optional)
<i>sources-per-group</i>	(Optional)
<i>oifs-per-entry</i>	(Optional)
<i>mdt-encap-entry</i>	(Optional)

Command Mode

- /exec

show routing multicast sr

```
show routing [ ip | ipv4 ] multicast sr [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf <vrf-name> <mode> <mac-rewrite> [ TABLE_route <interface> <in-group-range>
<to-group-range> <group-mask> <in-source-range> <to-source-range> <source-mask> ] ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display multicast information
sr	Service Reflect Rules
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
<i>mode</i>	(Optional)
<i>mac-rewrite</i>	(Optional)
TABLE_route	(Optional)
<i>interface</i>	(Optional)
<i>in-group-range</i>	(Optional)
<i>to-group-range</i>	(Optional)
<i>group-mask</i>	(Optional)
<i>in-source-range</i>	(Optional)
<i>to-source-range</i>	(Optional)
<i>source-mask</i>	(Optional)

Command Mode

- /exec

show routing nhlfe

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] nhlfe [ stats ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__
TABLE_vrf <vrf-name-out> [ <nhlfe-owner> <nhlfe-refcount> { TABLE_nhlabel <nlabel-index> <nh-label>
} <nhlfe-is-vpn> <nhlfe-owner-index> ] <total-entries> ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
nhlfe	Display URIB NHLFE db
stats	(Optional) Display statistics
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
<i>nhlfe-owner</i>	(Optional)
<i>nhlfe-refcount</i>	(Optional)
TABLE_nhlabel	(Optional)
<i>nlabel-index</i>	(Optional)
<i>nh-label</i>	(Optional)
<i>nhlfe-is-vpn</i>	(Optional)
<i>nhlfe-owner-index</i>	(Optional)

<i>total-entries</i>	(Optional)
----------------------	------------

Command Mode

- /exec

show routing recursive-next-hop

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] recursive-next-hop [ <ip-addr> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ]
[ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [ TABLE_prefix <ipprefix> <uptime>
TABLE_clients <clientname> ] ]
```

Syntax Description

show	Show running system information
routing	Display routing information
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
recursive-next-hop	Display recursive next-hop table
<i>topology-name</i>	(Optional) topology name
<i>ip-addr</i>	(Optional) Display single recursive virtual next-hop
<i>__readonly__</i>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name-out</i>	(Optional)
TABLE_addrf	(Optional)
<i>addrf</i>	(Optional) Address type
TABLE_prefix	(Optional)
<i>ipprefix</i>	(Optional)
<i>uptime</i>	(Optional)
TABLE_clients	(Optional)
<i>clientname</i>	(Optional)

Command Mode

- /exec

show routing unresolved-next-hop

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] unresolved-next-hop { [ <ip-addr> [ detail ] ] | [ summary ] } [ vrf { <vrf-name> |
<vrf-known-name> | <vrf-all> } ]
```

Syntax Description

show	Show running system information
routing	Display routing information
unresolved-next-hop	Display unresolved next-hop list
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast information
topology	(Optional) Display per-topology information
<i>topology-name</i>	(Optional) topology name
<i>ip-addr</i>	(Optional) Display single unresolved next-hop
detail	(Optional) Display prefixes for unresolved next-hop
summary	(Optional) Show summary of resolve buffers

Command Mode

- /exec

show running-config

show running-config

Syntax Description

show	Show running system information
running-config	Current operating configuration

Command Mode

- /exec

show running-config aaa

show running-config aaa [all]

Syntax Description

show	show running-cfg
running-config	show running system information
aaa	Display aaa configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config acllog

show running-config acllog [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
acllog	show running config for acllog
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config aclmgr

show running-config aclmgr [all | inactive-if-config]

Syntax Description

show	Show running system information
running-config	Current operating configuration
aclmgr	show running config for aclmgr
all	(Optional) show running config with defaults
inactive-if-config	(Optional) show running config for inactive-policies

Command Mode

- /exec

show running-config aclmgr active

show running-config aclmgr { active-if-config | all-if-config }

Syntax Description

show	Show running system information
running-config	Current operating configuration
aclmgr	show running config for aclmgr
active-if-config	show running config for active-policies
all-if-config	show running config for all-policies

Command Mode

- /exec

show running-config adjmgr

show running-config adjmgr [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
adjmgr	Display adjmgr information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config all

show running-config all

Syntax Description

show	Show running system information
running-config	Current operating configuration
all	Current operating configuration with defaults

Command Mode

- /exec

show running-config arp

show running-config arp [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
arp	Display arp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config assoc

show running-config assoc [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
assoc	Original ID to Translated ID Association
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config backup

show running-config { backup | flexlink } [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
backup	Show running config for Switchport Backup
flexlink	Show running config for Switchport Backup
all	(Optional) Show config with defaults

Command Mode

- /exec

show running-config bfd

show running-config bfd [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
bfd	show running config for bfd
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config bgp

show running-config bgp [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
bgp	Display bgp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config bloggerd

show running-config bloggerd [all]

Syntax Description

show	show running-cfg
running-config	show running system information
bloggerd	Display bloggerd configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config callhome

show running-config callhome [all]

Syntax Description

show	show running-cfg
running-config	show running system information
callhome	Display callhome configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config catena

show running-config catena

Syntax Description

show	show running-cfg
running-config	show running system information
catena	catena instances

Command Mode

- /exec

show running-config cdp

show running-config cdp [all]

Syntax Description

show	show running-cfg
running-config	show running system information
cdp	Display cdp configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config cert-enroll

show running-config cert-enroll [all]

Syntax Description

show	show running-cfg
running-config	show running system information
cert-enroll	Display certificates configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config cfs

show running-config cfs [all]

Syntax Description

show	Show running system information
running-config	Current operation configuration
cfs	Display cfs configurations
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config clock_manager

show running-config clock_manager [all]

Syntax Description

running-config	Current operating configuration
clock_manager	show running config for clock manager
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config config-profile

show running-config config-profile [<all_conf_profile_name>]

Syntax Description

show	Show running-cfg
running-config	show running configuration
config-profile	Display port-profile configuration
<i>all_conf_profile_name</i>	(Optional) Enter the name of the profile

Command Mode

- /exec

show running-config config-template

show running-config config-template

Syntax Description

show	Show running system information
running-config	Current operationg configuration
config-template	Display config-template configuration

Command Mode

- /exec

show running-config controller

show running-config controller

Syntax Description

show	Show running system information
running-config	Current operating configuration
controller	controller

Command Mode

- /exec

show running-config copp

show running-config copp [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
copp	Control-Plane Policing
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config dhcp

show running-config dhcp [all]

Syntax Description

show	Show running system information
running-config	Current operation configuration
dhcp	Display dhcp snoop configurations
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config diagnostic

show running-config diagnostic [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
diagnostic	Display diagnostic information
all	(Optional) Display running config with defaults

Command Mode

- /exec

show running-config diff

show running-config diff

Syntax Description

show	Show running system information
running-config	Current operating configuration
diff	Show the difference between running and startup configuration

Command Mode

- /exec

show running-config dot1x

show running-config dot1x [all]

Syntax Description

show	show running-cfg
running-config	show running system information
dot1x	Display dot1x configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config ecp

show running-config ecp [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
ecp	ECP (Edge Control Protocol)
all	(Optional) Display running config with defaults

Command Mode

- /exec

show running-config eem

show running-config eem

Syntax Description

show	Show running system information
running-config	Show the system running configuration
eem	Show the event manager running configuration

Command Mode

- /exec

show running-config eigrp

show running-config eigrp [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
eigrp	Display eigrp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config eltm

show running-config eltm

Syntax Description

show	Show running system information
running-config	Current operation configuration
eltm	Display eltm configurations

Command Mode

- /exec

show running-config evb

show running-config evb [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
evb	EVB (Edge Virtual Bridge)
all	(Optional) Display running config with defaults

Command Mode

- /exec

show running-config exclude

show running-config exclude <feature-list> +

Syntax Description

show	Show running system information
running-config	Current operating configuration
exclude	Exclude running configuration of specified features
<i>feature-list</i>	Exclude features

Command Mode

- /exec

show running-config expand-port-profile

show running-config expand-port-profile

Syntax Description

show	Show running system information
running-config	Current operating configuration
expand-port-profile	Expand port profile

Command Mode

- /exec

show running-config fabric forwarding

show running-config fabric forwarding [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config fabric multicast

show running-config fabric multicast [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
fabric	Fabric
multicast	Multicast information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config fcoe_mgr

```
show running-config fcoe_mgr [ all ]
```

Syntax Description

show	show running-cfg
running-config	show running system information
fcoe_mgr	Display fcoe_mgr configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config hardware-telemetry

show running-config hardware-telemetry [all]

Syntax Description

running-config	Current operating configuration
hardware-telemetry	show running config for hardware-telemetry
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config hsrp

show running-config hsrp [all]

Syntax Description

show	Show system information
running-config	System running configuration
hsrp	HSRP running configuration
all	(Optional) Show HSRP running configuration defaults

Command Mode

- /exec

show running-config icam

show running-config icam

Syntax Description

show	show running-cfg
running-config	show running system information
icam	icam services

Command Mode

- /exec

show running-config icmpv6

show running-config icmpv6 [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
icmpv6	Display icmpv6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config igmp

show running-config igmp [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
igmp	Display igmp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config imp

show running-config imp [all]

Syntax Description

show	Show system information
running-config	System running configuration
imp	IMP running configuration
all	(Optional) Show IMP running configuration defaults

Command Mode

- /exec

show running-config interface

show running-config interface [<if0>] [all] [expand-port-profile]

Syntax Description

show	Show running system information
running-config	Current operating configuration
interface	Interface configuration
<i>if0</i>	(Optional) interface type and number in module/slot format
all	(Optional) show running config with defaults
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show running-config interface

show running-config interface <if0> [membership] [expand-port-profile]

Syntax Description

show	Show running system information
running-config	Current operating configuration
interface	Interface configuration
<i>if0</i>	interface type and number in module/slot format
membership	(Optional) Show membership information
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show running-config ip

show running-config ip [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
ip	Display ip information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config ipqos

show running-config ipqos [all | inactive-if-config]

Syntax Description

show	Show running system information
running-config	Current operating configuration
all	(Optional) show running config with defaults
inactive-if-config	(Optional) show running config for inactive-policies

Command Mode

- /exec

show running-config ipqos active

show running-config ipqos { active-if-config | all-if-config }

Syntax Description

show	Show running system information
running-config	Current operating configuration
active-if-config	show running config for active-policies
all-if-config	show running config for all-policies

Command Mode

- /exec

show running-config ipv6

show running-config ipv6 [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
ipv6	Display ipv6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config isis

show running-config isis [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
isis	Display isis information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config l3vm

show running-config l3vm [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
l3vm	Display l3vm information
all	(Optional) Display running config with defaults

Command Mode

- /exec

show running-config ldap

show running-config ldap [all]

Syntax Description

show	show running-cfg
running-config	show running system information
ldap	Display ldap configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config license

show running-config license [all]

Syntax Description

show	show
running-config	show running system information
license	Display licensing configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config lisp

show running-config lisp [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
lisp	Display lisp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config lldp

show running-config lldp [all]

Syntax Description

show	show running-cfg
running-config	show running system information
lldp	Display lldp configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config mmode

show running-config mmode [all]

Syntax Description

show	Show running system information
running-config	Show running configuration
mmode	Display maintenance mode running configuration
all	(Optional) Show running config with defaults

Command Mode

- /exec

show running-config monitor

show running-config monitor [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
monitor	Configure Ethernet SPAN sessions
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config msdp

show running-config msdp [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
msdp	Display msdp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config nat

show running-config nat [all]

Syntax Description

show	show running-cfg
running-config	show running system information
nat	Display NAT configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config nbm

show running-config nbm

Syntax Description

show	Show running system information
running-config	Current operating configuration
nbm	Non Blocking Multicast

Command Mode

- /exec

show running-config ngoam

show running-config ngoam [all]

Syntax Description

show	Show running system information
running-config	Show running system information
ngoam	ngoam configuration
all	(Optional) Show running config with defaults

Command Mode

- /exec

show running-config ntp

show running-config ntp [all]

Syntax Description

show	Show information
running-config	Show running system configuration
ntp	Show NTP information
all	(Optional) Show all NTP running configuration

Command Mode

- /exec

show running-config nv overlay

show running-config nv overlay [all]

Syntax Description

show	Show system information
running-config	System running configuration
nv	NVE running configuration
overlay	NVE running configuration
all	(Optional) Show NVE running configuration defaults

Command Mode

- /exec

show running-config nxsdk

show running-config nxsdk [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
nxsdk	NXOS SDK
all	(Optional) Display running config with defaults

Command Mode

- /exec

show running-config openflow

show running-config openflow [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
openflow	Show running config for OpenFlow agent
all	(Optional) Show running config with defaults

Command Mode

- /exec

show running-config ospf

show running-config ospf [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
ospf	Display ospf information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config ospfv3

show running-config ospfv3 [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
ospfv3	Display ospfv3 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config param-list

show running-config param-list [<plistname>]

Syntax Description

show	Show running-cfg
running-config	show running configuration
param-list	Display param-list configuration
<i>plistname</i>	(Optional) Enter the name of the param list

Command Mode

- /exec

show running-config pim

show running-config pim [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
pim	Display pim information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config pim6

show running-config pim6 [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
pim6	Display pim6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config plb-services

show running-config plb-services

Syntax Description

show	show running-cfg
running-config	show running system information
plb-services	PLB services

Command Mode

- /exec

show running-config poe

show running-config poe [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
poe	Power over Ethernet
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config port-profile

show running-config port-profile [<all_profile_name>]

Syntax Description

show	Show running-cfg
running-config	show running configuration
port-profile	Display port-profile configuration
<i>all_profile_name</i>	(Optional) Enter the name of the profile

Command Mode

- /exec

show running-config port-security

show running-config port-security [all]

Syntax Description

show	show running-cfg
running-config	show running system information
port-security	Display port-security configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config ptp

show running-config ptp [all]

Syntax Description

running-config	Current operating configuration
ptp	show running config for ptp
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config radius

show running-config radius [all]

Syntax Description

show	show running-cfg
running-config	show running system information
radius	Display radius configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config rip

show running-config rip [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
rip	Display rip information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config routing ip multicast

```
show running-config routing { ip | ipv4 } multicast [ all ]
```

Syntax Description

show	Show running system information
running-config	Current operationg configuration
routing	Display routing information
ip	Display IP information
ipv4	Display IP information
multicast	Display multicast information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config routing ipv6 multicast

show running-config routing ipv6 multicast [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display m6rib information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config rpm

show running-config rpm [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
rpm	Display Route Policy Manager (RPM) information
all	(Optional) Display running config with defaults

Command Mode

- /exec

show running-config rsvp

show running-config rsvp

Syntax Description

show	Show running system information
running-config	Current operating configuration
rsvp	Display RSVP status

Command Mode

- /exec

show running-config section

show running-config section <section>

Syntax Description

show	Show running system information
running-config	Current operating configuration
section	show only a particular section of running-config (in format needed for 'merge config' command)
<i>section</i>	the section to show, a regular expression, (use a dot for a space)

Command Mode

- /exec

show running-config security

show running-config security [all]

Syntax Description

show	show running-cfg
running-config	show running system information
security	Display security configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config services

show running-config services

Syntax Description

show	show running-cfg
running-config	show running system information
services	services

Command Mode

- /exec

show running-config services

show running-config services

Syntax Description

show	show running-cfg
running-config	show running system information
services	services

Command Mode

- /exec

show running-config sflow

show running-config sflow [all]

Syntax Description

running-config	Current operating configuration
sflow	show running config for sflow
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config sla responder

show running-config sla responder

Syntax Description

show	show running-cfg
running-config	show running system information
sla	Service Level Agreement (SLA)
responder	Show information about sla-responder

Command Mode

- /exec

show running-config sla sender

show running-config sla sender

Syntax Description

show	show running-cfg
running-config	show running system information
sla	Service Level Agreement (SLA)
sender	Show information about sla-sender

Command Mode

- /exec

show running-config sla twamp-server

show running-config sla twamp-server

Syntax Description

show	show running-cfg
running-config	show running system information
sla	Service Level Agreement (SLA)
twamp-server	Show IPSLA IPPM TWAMP server configuration

Command Mode

- /exec

show running-config smart-channel

show running-config smart-channel

Syntax Description

show	show running-cfg
running-config	show running system information
smart-channel	smart channel services

Command Mode

- /exec

show running-config snmp

show running-config snmp [all]

Syntax Description

show	show running-cfg
running-config	show running system information
snmp	Display snmp configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config spanning-tree

show running-config spanning-tree [<all> | interface <interface_range>]

Syntax Description

show	Show running system information
running-config	Current operating configuration
spanning-tree	Show spanning tree information
<i>all</i>	(Optional)
interface	(Optional) Specify an interface as a target for the command
<i>interface_range</i>	(Optional)

Command Mode

- /exec

show running-config srte

show running-config srte

Syntax Description

show	Show running system information
running-config	Current operating configuration
srte	SRTE

Command Mode

- /exec

show running-config switch

show running-config { switch-profile | include-switch-profile }

Syntax Description

show	Show running system information
running-config	Current operating configuration
switch-profile	Show switch-profile information
include-switch-profile	Show running and switch-profile configuration

Command Mode

- /exec

show running-config tacacs

show running-config tacacs + [all]

Syntax Description

show	show running-cfg
running-config	show running system information
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config track

show running-config track [all]

Syntax Description

show	Show running system information
running-config	Show the system running information
track	Show track running configuration
all	(Optional) Show track running configuration defaults

Command Mode

- /exec

show running-config uddl

show running-config uddl [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
uddl	Show uddl configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config vdc-all

show running-config vdc-all [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vdc-all	Display config from all VDC
all	(Optional) Display config from all VDC including defaults

Command Mode

- /exec

show running-config vdc

show running-config vdc [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vdc	Show Virtual Device Contexts
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config virtual-service

show running-config virtual-service

Syntax Description

show	Show running system information
running-config	Current operating configuration
virtual-service	Show running config for virtualization services

Command Mode

- /exec

show running-config vlan

show running-config vlan <vlan-id> [expand-port-profile]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vlan	Vlan commands
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show running-config vlan

show running-config vlan

Syntax Description

show	Show running system information
running-config	Current operating configuration
vlan	Vlan commands

Command Mode

- /exec

show running-config vlan

show running-config vlan <vlan-id> [expand-port-profile]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vlan	Vlan commands
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show running-config vmtracker

show running-config vmtracker [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vmtracker	show running config for vmtracker
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config vpc

show running-config vpc [all]

Syntax Description

running-config	Current operating configuration
vpc	show running config for vPC
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config vrf

show running-config vrf <vrf-cfg-name> [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
vrf	Display VRF information
<i>vrf-cfg-name</i>	Configurable VRF name
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config vrf default

show running-config vrf default [all]

Syntax Description

show	Show running system information
running-config	Current operationg configuration
vrf	Display VRF information
default	Known VRF name
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show running-config vrrp

show running-config vrrp [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vrrp	Display VRRP running configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config vrrpv3

show running-config vrrpv3 [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vrrpv3	Show running config for VRRPv3
all	(Optional) show running config with defaults

Command Mode

- /exec

show running-config vshd

show running-config vshd

Syntax Description

show	Show running system information
running-config	Current operating configuration
vshd	Show running config for vshd

Command Mode

- /exec

show running-config vtp

show running-config vtp [all]

Syntax Description

show	Show running system information
running-config	Current operating configuration
vtp	Show running configuration for VTP
all	(Optional) Show running configuration for VTP with defaults

Command Mode

- /exec

show running-config wwnm

show running-config wwnm

Syntax Description

show	Show running system information
running-config	Current running configuration
wwnm	Display WWN Manager running configuration

Command Mode

- /exec



S Show Commands

- [show san-port-channel compatibility-parameters](#), on page 2244
- [show san-port-channel consistency](#), on page 2245
- [show san-port-channel consistency detail](#), on page 2246
- [show san-port-channel database](#), on page 2248
- [show san-port-channel summary](#), on page 2250
- [show san-port-channel usage](#), on page 2251
- [show scheduler config](#), on page 2252
- [show scheduler job](#), on page 2254
- [show scheduler logfile](#), on page 2255
- [show scheduler schedule](#), on page 2256
- [show sflow](#), on page 2257
- [show sflow statistics](#), on page 2258
- [show smart-channel](#), on page 2259
- [show snapshots](#), on page 2263
- [show snapshots compare](#), on page 2264
- [show snapshots compare ipv4routes](#), on page 2266
- [show snapshots compare ipv6routes](#), on page 2267
- [show snapshots compare summary](#), on page 2268
- [show snapshots dump](#), on page 2269
- [show snapshots dump](#), on page 2270
- [show snapshots sections](#), on page 2271
- [show snmp](#), on page 2272
- [show snmp community](#), on page 2275
- [show snmp context](#), on page 2276
- [show snmp engineID](#), on page 2277
- [show snmp group](#), on page 2278
- [show snmp host](#), on page 2279
- [show snmp mib igmpCacheTable](#), on page 2280
- [show snmp mib igmpInterfaceTable](#), on page 2281
- [show snmp nms-statistics](#), on page 2283
- [show snmp oid-statistics](#), on page 2284
- [show snmp roleddebug](#), on page 2285
- [show snmp sessions](#), on page 2286

- [show snmp source-interface](#), on page 2287
- [show snmp trap](#), on page 2288
- [show snmp user](#), on page 2289
- [show sockets client](#), on page 2290
- [show sockets connection](#), on page 2298
- [show sockets local-port-range](#), on page 2301
- [show sockets ns-port-kiosk](#), on page 2302
- [show sockets statistics](#), on page 2303
- [show sockets tcp keychain binding](#), on page 2313
- [show spanning-tree](#), on page 2314
- [show spanning-tree blockedports](#), on page 2318
- [show spanning-tree bridge](#), on page 2319
- [show spanning-tree inconsistentports](#), on page 2321
- [show spanning-tree interface](#), on page 2322
- [show spanning-tree interface](#), on page 2323
- [show spanning-tree issu-impact](#), on page 2326
- [show spanning-tree mst](#), on page 2327
- [show spanning-tree mst configuration](#), on page 2332
- [show spanning-tree mst configuration digest](#), on page 2333
- [show spanning-tree mst interface](#), on page 2334
- [show spanning-tree pathcost method](#), on page 2337
- [show spanning-tree root](#), on page 2338
- [show spanning-tree summary](#), on page 2340
- [show spanning-tree summary totals](#), on page 2343
- [show sprom](#), on page 2345
- [show srte pce ipv4 peer](#), on page 2354
- [show srte policy](#), on page 2355
- [show srte policy fh](#), on page 2357
- [show ssh key](#), on page 2358
- [show ssh server](#), on page 2359
- [show ssx details](#), on page 2360
- [show ssx exporter](#), on page 2361
- [show ssx monitor](#), on page 2362
- [show ssx record](#), on page 2363
- [show startup-config](#), on page 2364
- [show startup-config aaa](#), on page 2365
- [show startup-config acllog](#), on page 2366
- [show startup-config aclmgr](#), on page 2367
- [show startup-config adjmgr](#), on page 2368
- [show startup-config arp](#), on page 2369
- [show startup-config assoc](#), on page 2370
- [show startup-config backup](#), on page 2371
- [show startup-config bfd](#), on page 2372
- [show startup-config bgp](#), on page 2373
- [show startup-config bloggerd](#), on page 2374
- [show startup-config callhome](#), on page 2375

- [show startup-config catena](#), on page 2376
- [show startup-config cdp](#), on page 2377
- [show startup-config cert-enroll](#), on page 2378
- [show startup-config cfs](#), on page 2379
- [show startup-config config-profile](#), on page 2380
- [show startup-config copp](#), on page 2381
- [show startup-config dhcp](#), on page 2382
- [show startup-config diagnostic](#), on page 2383
- [show startup-config dot1x](#), on page 2384
- [show startup-config ecp](#), on page 2385
- [show startup-config eem](#), on page 2386
- [show startup-config eigrp](#), on page 2387
- [show startup-config eltm](#), on page 2388
- [show startup-config evb](#), on page 2389
- [show startup-config exclude](#), on page 2390
- [show startup-config expand-port-profile](#), on page 2391
- [show startup-config fabric forwarding](#), on page 2392
- [show startup-config fabric multicast](#), on page 2393
- [show startup-config fcoe_mgr](#), on page 2394
- [show startup-config hardware-telemetry](#), on page 2395
- [show startup-config hsrp](#), on page 2396
- [show startup-config icam](#), on page 2397
- [show startup-config icmpv6](#), on page 2398
- [show startup-config igmp](#), on page 2399
- [show startup-config imp](#), on page 2400
- [show startup-config interface](#), on page 2401
- [show startup-config interface](#), on page 2402
- [show startup-config ip](#), on page 2403
- [show startup-config ipqos](#), on page 2404
- [show startup-config ipv6](#), on page 2405
- [show startup-config isis](#), on page 2406
- [show startup-config l3vm](#), on page 2407
- [show startup-config ldap](#), on page 2408
- [show startup-config license](#), on page 2409
- [show startup-config lisp](#), on page 2410
- [show startup-config lldp](#), on page 2411
- [show startup-config log](#), on page 2412
- [show startup-config mmode](#), on page 2413
- [show startup-config monitor](#), on page 2414
- [show startup-config msdp](#), on page 2415
- [show startup-config nat](#), on page 2416
- [show startup-config nbm](#), on page 2417
- [show startup-config ngoam](#), on page 2418
- [show startup-config ntp](#), on page 2419
- [show startup-config nv overlay](#), on page 2420
- [show startup-config nxsdk](#), on page 2421

- [show startup-config openflow](#), on page 2422
- [show startup-config ospf](#), on page 2423
- [show startup-config ospfv3](#), on page 2424
- [show startup-config param-list](#), on page 2425
- [show startup-config pim](#), on page 2426
- [show startup-config pim6](#), on page 2427
- [show startup-config plb-services](#), on page 2428
- [show startup-config poe](#), on page 2429
- [show startup-config port-profile](#), on page 2430
- [show startup-config port-security](#), on page 2431
- [show startup-config ptp](#), on page 2432
- [show startup-config radius](#), on page 2433
- [show startup-config rip](#), on page 2434
- [show startup-config routing ip multicast](#), on page 2435
- [show startup-config routing ipv6 multicast](#), on page 2436
- [show startup-config rpm](#), on page 2437
- [show startup-config rsvp](#), on page 2438
- [show startup-config security](#), on page 2439
- [show startup-config services](#), on page 2440
- [show startup-config sflow](#), on page 2441
- [show startup-config sla responder](#), on page 2442
- [show startup-config sla sender](#), on page 2443
- [show startup-config sla twamp-server](#), on page 2444
- [show startup-config smart-channel](#), on page 2445
- [show startup-config snmp](#), on page 2446
- [show startup-config srte](#), on page 2447
- [show startup-config switch](#), on page 2448
- [show startup-config tacacs](#), on page 2449
- [show startup-config track](#), on page 2450
- [show startup-config udd](#), on page 2451
- [show startup-config vdc-all](#), on page 2452
- [show startup-config vdc](#), on page 2453
- [show startup-config virtual-service](#), on page 2454
- [show startup-config vlan](#), on page 2455
- [show startup-config vlan](#), on page 2456
- [show startup-config vmtracker](#), on page 2457
- [show startup-config vpc](#), on page 2458
- [show startup-config vrf](#), on page 2459
- [show startup-config vrf default](#), on page 2460
- [show startup-config vrrpv3](#), on page 2461
- [show startup-config vshd](#), on page 2462
- [show startup-config vtp](#), on page 2463
- [show startup-config wwnm](#), on page 2464
- [show summary](#), on page 2465
- [show sup-monitor drops session](#), on page 2466
- [show switch-profile](#), on page 2467

- [show switch-profile](#), on page 2469
- [show switch-profile buffer](#), on page 2470
- [show switch-profile peer](#), on page 2471
- [show switch-profile status](#), on page 2472
- [show switch-scope controller](#), on page 2474
- [show switching-mode](#), on page 2475
- [show switching-mode fabric-speed](#), on page 2476
- [show system acl](#), on page 2477
- [show system auto-collect tech-support](#), on page 2478
- [show system boottime](#), on page 2479
- [show system clis event-history](#), on page 2480
- [show system config reload-pending](#), on page 2481
- [show system cores](#), on page 2482
- [show system default switchport](#), on page 2483
- [show system error-id](#), on page 2484
- [show system exception-info](#), on page 2485
- [show system fabric-mode](#), on page 2486
- [show system fast-reload stabilization-timer](#), on page 2487
- [show system image-verification](#), on page 2488
- [show system inband queuing statistics](#), on page 2489
- [show system inband queuing status](#), on page 2491
- [show system login](#), on page 2492
- [show system login failures](#), on page 2493
- [show system memory-thresholds](#), on page 2494
- [show system mode](#), on page 2495
- [show system poap](#), on page 2496
- [show system pss shrink status](#), on page 2497
- [show system redundancy ha status](#), on page 2498
- [show system redundancy status](#), on page 2499
- [show system reset-reason](#), on page 2500
- [show system reset-reason](#), on page 2501
- [show system reset-reason module](#), on page 2502
- [show system resources](#), on page 2503
- [show system resources](#), on page 2504
- [show system resources module](#), on page 2505
- [show system resources module all](#), on page 2506
- [show system routing mode](#), on page 2507
- [show system security](#), on page 2508
- [show system simulate fan-presence](#), on page 2509
- [show system standby manual-boot](#), on page 2510
- [show system switch-mode](#), on page 2511
- [show system uptime](#), on page 2512
- [show system verify bios flash](#), on page 2513
- [show system vlan reserved](#), on page 2514

show san-port-channel compatibility-parameters

```
show san-port-channel compatibility-parameters [ __readonly__ [ { TABLE_compatibility_params <parameter>
<description> } ] ]
```

Syntax Description

show	Show running system information
san-port-channel	Show san-port-channel information
compatibility-parameters	Show san-port-channel compatibility-parameters
__readonly__	(Optional) Read Only
TABLE_compatibility_params	(Optional) Table with compatibility params
<i>parameter</i>	(Optional) Compatibility parameter
<i>description</i>	(Optional) Parameter description

Command Mode

- /exec

show san-port-channel consistency

```
show san-port-channel consistency [ __readonly__ [ <msg> ] [ { [ <error_msg> ] [ <consistency_state> ] [ <module> ] [ { TABLE_inconsistent_database [ <database> ] [ { [ <total_port_channels> ] [ { TABLE_san_port_channel_database [ <interface> ] [ <total_ports> ] [ <first_operational_port> ] [ { TABLE_san_port_channel_member <port> <state> } ] [ <db_error_str> ] } ] } ] } ] } ] }
```

Syntax Description

show	Show running system information
san-port-channel	Show san-port-channel information
consistency	Show san-port-channel distributed database consistency
<i>__readonly__</i>	(Optional) Read Only
<i>msg</i>	(Optional) Message string
<i>error_msg</i>	(Optional) Prints consistency errors, if any
<i>consistency_state</i>	(Optional) Consistency state
<i>module</i>	(Optional) Module no
TABLE_inconsistent_database	(Optional) Table with details of inconsistent dbs
<i>database</i>	(Optional) Inconsistent database
TABLE_san_port_channel_database	(Optional) san-po Table
<i>total_port_channels</i>	(Optional) Total port channels
<i>interface</i>	(Optional) san-port-channel interface
<i>first_operational_port</i>	(Optional) First oper port in san-po
<i>total_ports</i>	(Optional) Total number of ports in the san-po
TABLE_san_port_channel_member	(Optional) san-po member Table
<i>port</i>	(Optional) san-po member port
<i>state</i>	(Optional) san-po member port state
<i>db_error_str</i>	(Optional) prints cmd errors, if any

Command Mode

- /exec

show san-port-channel consistency detail

```
show san-port-channel consistency detail [ __readonly__ [ <sup_total_port_channels> ] [ { [ <sup_db_error_str> ] [ { TABLE_sup_san_port_channel_database <sup_interface> [ <sup_total_ports> ] [ <sup_first_operational_port> ] [ { TABLE_sup_san_port_channel_member <sup_port> <sup_state> } ] } ] } ] [ <msg> ] [ { [ <error_msg> ] [ <db_index> ] [ <module> ] [ { [ <total_port_channels> ] [ { TABLE_san_port_channel_database [ <interface> ] [ <total_ports> ] [ <first_operational_port> ] [ { TABLE_san_port_channel_member <port> <state> } ] [ <db_error_str> ] } ] } ] } ] [ <consistency_state> ] ]
```

Syntax Description

show	Show running system information
san-port-channel	Show san-port-channel information
consistency	Show san-port-channel distributed database consistency
detail	Show san-port-channel distributed databases of all modules
<i>__readonly__</i>	(Optional) Read Only
<i>sup_total_port_channels</i>	(Optional) Authoritative po db - Total POs
TABLE_sup_san_port_channel_database	(Optional) Table with details of auth po db
<i>sup_interface</i>	(Optional) san-port-channel interface
<i>sup_first_operational_port</i>	(Optional) First oper port in san-po
<i>sup_total_ports</i>	(Optional) Total number of ports in the san-po
TABLE_sup_san_port_channel_member	(Optional) san-po member Table
<i>sup_port</i>	(Optional) san-po member port
<i>sup_state</i>	(Optional) san-po member port state
<i>sup_db_error_str</i>	(Optional) prints cmd errors, if any
<i>msg</i>	(Optional) Msg string
<i>error_msg</i>	(Optional) Prints errors, if any
<i>db_index</i>	(Optional) Database index
<i>module</i>	(Optional) Module no
<i>total_port_channels</i>	(Optional) Authoritative po db - Total POs
TABLE_san_port_channel_database	(Optional) Table with details of auth po db
<i>interface</i>	(Optional) san-port-channel interface
<i>first_operational_port</i>	(Optional) First oper port in san-po

<i>total_ports</i>	(Optional) Total number of ports in the san-po
TABLE_san_port_channel_member	(Optional) san-po member Table
<i>port</i>	(Optional) san-po member port
<i>state</i>	(Optional) san-po member port state
<i>db_error_str</i>	(Optional) prints cmd errors, if any
<i>consistency_state</i>	(Optional) Consistency state

Command Mode

- /exec

show san-port-channel database

```
show san-port-channel database [ interface <ifid> | all ] [ __readonly__ [ <error_str> ] ] [ {
TABLE_san_port_channel_database <interface> <admin_chan_mode> <oper_chan_mode>
<last_membership_update> [ <last_membership_update_fail_reason> ] [ <pcm_interface_flag> ] [
<vlan_interfaces> ] [ <first_operational_port> ] [ <total_ports> ] [ <total_oper_ports> ] [ {
TABLE_san_port_channel_member <port> <state> } ] } ] [ <cmd_error_str> ] ]
```

Syntax Description

show	Show running system information
san-port-channel	Show san-port-channel information
database	Show san-port-channel database
interface	(Optional) Specify a port-channel
<i>ifid</i>	(Optional)
all	(Optional) Display all port-channel
<i>__readonly__</i>	(Optional) Read Only
<i>error_str</i>	(Optional) Prints errors,if any
TABLE_san_port_channel_database	(Optional) san-port-channel database Table
<i>interface</i>	(Optional) san-po Interface
<i>admin_chan_mode</i>	(Optional) san-po administrative channel mode
<i>oper_chan_mode</i>	(Optional) san-po operational channel mode
<i>last_membership_update</i>	(Optional) Last membership update status
<i>last_membership_update_fail_reason</i>	(Optional) Membership update status casue
<i>pcm_interface_flag</i>	(Optional) san-po interface flag
<i>vlan_interfaces</i>	(Optional) san-po vlan interfaces
<i>first_operational_port</i>	(Optional) First oper port in san-po
<i>total_ports</i>	(Optional) Total number of ports in the san-po
<i>total_oper_ports</i>	(Optional) Total oper ports in the san-po
TABLE_san_port_channel_member	(Optional) san-po member Table
<i>port</i>	(Optional) san-po member port
<i>state</i>	(Optional) san-po member port state
<i>cmd_error_str</i>	(Optional) prints cmd errors,if any

Command Mode

- /exec

show san-port-channel summary

```
show san-port-channel summary [ __readonly__ [ { TABLE_san_port_channel_summary <interface>
<total_ports> <total_oper_ports> <first_operational_port> } ] [ <cmd_error_str> ] ]
```

Syntax Description

show	Show running system information
san-port-channel	Show san-port-channel information
summary	Show san-port-channel summary
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_san_port_channel_summary</i>	(Optional) san-port-channel Summary Table
<i>interface</i>	(Optional) san-po Interface
<i>total_ports</i>	(Optional) Total number of ports in the san-po
<i>total_oper_ports</i>	(Optional) Total oper ports in the san-po
<i>first_operational_port</i>	(Optional) First oper port in san-po
<i>cmd_error_str</i>	(Optional) Prints cmd error,if any

Command Mode

- /exec

show san-port-channel usage

```
show san-port-channel usage [ __readonly__ [ <total_channel_numbers_used> { <used_range> } + {
<unused_range> } + ] [ <error_str> ] ]
```

Syntax Description

show	Show running system information
san-port-channel	Show san-port-channel information
usage	Show san-port-channel usages
<i>__readonly__</i>	(Optional) Read Only
<i>total_channel_numbers_used</i>	(Optional) Total used number of port-channels
<i>used_range</i>	(Optional) Used range
<i>unused_range</i>	(Optional) Un-used range
<i>error_str</i>	(Optional) Prints error if any

Command Mode

- /exec

Command Mode

- /exec

show scheduler job

```
show scheduler job [ name <s0> ] [ __readonly__ [ { TABLE_schedulerjobs <jobname> [ <jobdata> ] } ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
job	Display job information
name	(Optional) Specify the name of job
<i>s0</i>	(Optional) Specify the job name
__readonly__	(Optional)
TABLE_schedulerjobs	(Optional) schedulerjobs
<i>jobname</i>	(Optional) job name
<i>jobdata</i>	(Optional) job data

Command Mode

- /exec

show scheduler logfile

```
show scheduler logfile [ __readonly__ [ { TABLE_joblog <jobname> [ <jobstatus> ] [ <schedulename> ] [ <scheduleusername> ] [ <completiontime> ] [ <joboutput> } } ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
logfile	Display scheduler job output log
<i>__readonly__</i>	(Optional)
<i>TABLE_joblog</i>	(Optional) jobs log
<i>jobname</i>	(Optional) job name
<i>jobstatus</i>	(Optional) job status
<i>schedulename</i>	(Optional) schedulename
<i>scheduleusername</i>	(Optional) scheduleusername
<i>completiontime</i>	(Optional) completiontime
<i>joboutput</i>	(Optional) joboutput

Command Mode

- /exec

show scheduler schedule

```
show scheduler schedule [ name <s0> ] [ __readonly__ [ { TABLE_schedules <schedulename> [
<scheduleusername> ] [ <scheduletype> ] [ <starttime> ] [ <lastexecetime> ] [ <lastcompletiontime> ] [
<execcount> ] [ <jobcount> ] [ { TABLE_jobs <jobname> [ <execstatus> ] } } ] ] ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
schedule	Display schedule information
name	(Optional) Specify the name of schedule
<i>s0</i>	(Optional) Specify the schedule name
<i>__readonly__</i>	(Optional)
TABLE_schedules	(Optional) schedules
<i>schedulename</i>	(Optional) Schedule name
<i>scheduleusername</i>	(Optional) schedule username
<i>scheduletype</i>	(Optional) scheduletype
<i>starttime</i>	(Optional) starttime
<i>lastexecetime</i>	(Optional) last exec time
<i>lastcompletiontime</i>	(Optional) lastcompletiontime
<i>execcount</i>	(Optional) execcount
<i>jobcount</i>	(Optional) jobcount
TABLE_jobs	(Optional) jobs
<i>jobname</i>	(Optional) jobname
<i>execstatus</i>	(Optional) execstatus

Command Mode

- /exec

show sflow

```
show sflow [ __readonly__ <sampling-rate> <max-sampled-size> <counter-poll-interval> <max-datagram-size>
<collector-ip> <collector-vrf> <source-ip> <collector-port> <agent-ip> <data-source-interface> ]
```

Syntax Description

show	Show running system information
sflow	Display sFlow global configuration
<i>__readonly__</i>	(Optional) Read only
<i>sampling-rate</i>	(Optional) Sampling Rate
<i>max-sampled-size</i>	(Optional) Max Sampled Size
<i>counter-poll-interval</i>	(Optional) Counter Poll Interval
<i>max-datagram-size</i>	(Optional) Max Datagram Size
<i>collector-ip</i>	(Optional) Collector IP
<i>collector-vrf</i>	(Optional) Collector VRF
<i>source-ip</i>	(Optional) Source IP
<i>collector-port</i>	(Optional) Collector Port
<i>agent-ip</i>	(Optional) Agent IP
<i>data-source-interface</i>	(Optional) Data Source Interface

Command Mode

- /exec

show sflow statistics

show sflow statistics [*__readonly__* <total-packets> <total-samples> <processed-samples> <dropped-samples> <rate-limiter-drops> <dropped-sflow-samples> <sent-datagrams> <dropped-datagrams>]

Syntax Description

show	Show running system information
sflow	Display sFlow global configuration
statistics	Display sFlow statistics
<i>__readonly__</i>	(Optional) Read only
<i>total-packets</i>	(Optional) Total Packets
<i>total-samples</i>	(Optional) Total Samples
<i>processed-samples</i>	(Optional) Processed Samples
<i>dropped-samples</i>	(Optional) Dropped Samples
<i>rate-limiter-drops</i>	(Optional) Rate-Limiter Drops
<i>dropped-sflow-samples</i>	(Optional) Dropped sflow Samples
<i>sent-datagrams</i>	(Optional) Sent Datagrams
<i>dropped-datagrams</i>	(Optional) Dropped Datagrams

Command Mode

- /exec

<i>reason</i>	(Optional) inactive reason
<i>vrf_name</i>	(Optional) VRF-Name
<i>userACL</i>	(Optional) user access-list
TABLE_device	(Optional)
<i>device_grp</i>	(Optional) service device group
<i>dg_probe</i>	(Optional) probe type
<i>dg_probe_port</i>	(Optional) probe port
TABLE_route_map	(Optional)
<i>route_map</i>	(Optional) service route map
<i>interface</i>	(Optional) interface
<i>r_status</i>	(Optional) route map status
<i>int_track_id</i>	(Optional) interface track id
TABLE_vip	(Optional)
<i>vip_ip</i>	(Optional) vip ip
<i>vip_probe</i>	(Optional) vip protocol
<i>vip_port</i>	(Optional) vip port
TABLE_vip_node	(Optional)
<i>vip_node</i>	(Optional) service node ip
<i>vip_nodev6</i>	(Optional) service node IPv6
<i>vip_config</i>	(Optional) node config
<i>vip_weight</i>	(Optional) node weight
<i>vip_status</i>	(Optional) node status
<i>vip_node_probe</i>	(Optional) node probe type
<i>vip_node_probe_port</i>	(Optional) node probe port
<i>vip_node_probe_ip</i>	(Optional) node probe ip
<i>vip_track_id</i>	(Optional) node track id
<i>vip_ip_sla_id</i>	(Optional) node ip sla id
TABLE_vip_standby	(Optional)
<i>vip_standby_ip</i>	(Optional) standby node ip

<i>vip_standby_ipv6</i>	(Optional) standby node ipv6
<i>vip_standby_config</i>	(Optional) standby node config
<i>vip_standby_weight</i>	(Optional) standby node weight
<i>vip_standby_status</i>	(Optional) standby node status
<i>vip_standby_probe</i>	(Optional) standby node probe type
<i>vip_standby_probe_port</i>	(Optional) standby node probe port
<i>vip_standby_probe_ip</i>	(Optional) standby node probe ip
<i>vip_standby_track_id</i>	(Optional) standby node track id
<i>vip_standby_sla_id</i>	(Optional) standby node sla id
TABLE_vip_acl	(Optional)
<i>vip_access_list</i>	(Optional) access list
TABLE_node	(Optional)
<i>node</i>	(Optional) service node ip
<i>nodev6</i>	(Optional) service node IPv6
<i>config</i>	(Optional) node config
<i>weight</i>	(Optional) node weight
<i>status</i>	(Optional) node status
<i>node_probe</i>	(Optional) node probe type
<i>node_probe_port</i>	(Optional) node probe port
<i>node_probe_ip</i>	(Optional) node probe ip
<i>track_id</i>	(Optional) node track id
<i>ip_sla_id</i>	(Optional) node ip sla id
TABLE_standby	(Optional)
<i>standby_ip</i>	(Optional) standby node ip
<i>standby_ipv6</i>	(Optional) standby node ipv6
<i>standby_config</i>	(Optional) standby node config
<i>standby_weight</i>	(Optional) standby node weight
<i>standby_status</i>	(Optional) standby node status
<i>standby_probe</i>	(Optional) standby node probe type

<i>standby_probe_port</i>	(Optional) standby node probe port
<i>standby_probe_ip</i>	(Optional) standby node probe ip
<i>standby_track_id</i>	(Optional) standby node track id
<i>standby_sla_id</i>	(Optional) standby node sla id
TABLE_acl	(Optional)
<i>access_list</i>	(Optional) access list

Command Mode

- /exec

show snapshots

show snapshots [*__readonly__* *TABLE_snapshot* <snap_name> <snap_ctime> <description>]

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
<i>__readonly__</i>	(Optional)
<i>TABLE_snapshot</i>	(Optional)
<i>snap_name</i>	(Optional) snapshot name
<i>snap_ctime</i>	(Optional) snapshot create time
<i>description</i>	(Optional) snapshot description

Command Mode

- /exec

show snapshots compare

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> [ __readonly__ TABLE_feature
<feat_name> [ <feat_state1> <feat_state2> ] [ TABLE_element <elemkey1> <elemval1> [ <elemkey2>
<elemval2> ] [ <elemkey3> <elemval3> ] [ <elemkey4> <elemval4> ] [ <elemstate1> <elemstate2> ] [
TABLE_value <tag> <val1> <val2> ] [ TABLE_subrow <subrowkey> <subrowval> [ <substate1> <substate2>
] [ TABLE_subvalue <tag> <val1> <val2> ] ] ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
<u>__readonly__</u>	(Optional)
TABLE_feature	(Optional)
<i>feat_name</i>	(Optional) feature name
<i>feat_state1</i>	(Optional) feature state in snapshot 1
<i>feat_state2</i>	(Optional) feature state in snapshot 2
TABLE_element	(Optional)
<i>elemkey1</i>	(Optional) element key 1
<i>elemval1</i>	(Optional) element value 1
<i>elemkey2</i>	(Optional) element key 2
<i>elemval2</i>	(Optional) element value 2
<i>elemkey3</i>	(Optional) element key 3
<i>elemval3</i>	(Optional) element value 3
<i>elemkey4</i>	(Optional) element key 4
<i>elemval4</i>	(Optional) element value 4
<i>elemstate1</i>	(Optional) element state in snapshot 1
<i>elemstate2</i>	(Optional) element state in snapshot 2
TABLE_value	(Optional)
<i>tag</i>	(Optional) element tag

<i>val1</i>	(Optional) element value for tag in snapshot1
<i>val2</i>	(Optional) element value for tag in snapshot2
TABLE_subrow	(Optional)
<i>subrowkey</i>	(Optional) subrow key
<i>subrowval</i>	(Optional) subrow value
<i>substate1</i>	(Optional) subrow state in snapshot 1
<i>substate2</i>	(Optional) subrow state in snapshot 2
TABLE_subvalue	(Optional)
<i>tag</i>	(Optional) subrow tag
<i>val1</i>	(Optional) subrow value for tag in snapshot1
<i>val2</i>	(Optional) subrow value for tag in snapshot2

Command Mode

- /exec

show snapshots compare ipv4routes

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> ipv4routes [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] [ TABLE_prefix <prefix>
<missing_snapshot> ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
ipv4routes	Compare ipv4 route information
<i>__readonly__</i>	(Optional)
TABLE_summary	(Optional)
<i>item_desc</i>	(Optional) item description
<i>summary_val1</i>	(Optional) summary value in snapshot1
<i>summary_val2</i>	(Optional) summary value in snapshot2
<i>changed</i>	(Optional) changed flag
TABLE_prefix	(Optional)
<i>prefix</i>	(Optional) route prefix
<i>missing_snapshot</i>	(Optional) missing in snapshot name

Command Mode

- /exec

show snapshots compare ipv6routes

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> ipv6routes [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] [ TABLE_prefix <prefix>
<missing_snapshot> ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
ipv6routes	Compare ipv6 route information
<i>__readonly__</i>	(Optional)
TABLE_summary	(Optional)
<i>item_desc</i>	(Optional) item description
<i>summary_val1</i>	(Optional) summary value in snapshot1
<i>summary_val2</i>	(Optional) summary value in snapshot2
<i>changed</i>	(Optional) changed flag
TABLE_prefix	(Optional)
<i>prefix</i>	(Optional) route prefix
<i>missing_snapshot</i>	(Optional) missing in snapshot name

Command Mode

- /exec

show snapshots compare summary

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> summary [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
summary	Compare summary information
<i>__readonly__</i>	(Optional)
<i>TABLE_summary</i>	(Optional)
<i>item_desc</i>	(Optional) item description
<i>summary_val1</i>	(Optional) summary value in snapshot1
<i>summary_val2</i>	(Optional) summary value in snapshot2
<i>changed</i>	(Optional) changed flag

Command Mode

- /exec

show snapshots dump

show snapshots dump <snapshot-name> [__readonly__ TABLE_snapshot <file_name> <snap_name>]

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
dump	Dump contents of snapshot
<i>snapshot-name</i>	Name of a snapshot
__readonly__	(Optional)
TABLE_snapshot	(Optional)
<i>file_name</i>	(Optional) snapshot XML file name
<i>snap_name</i>	(Optional) snapshot name

Command Mode

- /exec

show snapshots dump

```
show snapshots dump <snapshot-name> <section-name> [ __readonly__ TABLE_snapshot <file_name>
<snap_name> ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
dump	Dump contents of snapshot
<i>snapshot-name</i>	Name of a snapshot
<i>section-name</i>	Name of snapshot section
<code>__readonly__</code>	(Optional)
TABLE_snapshot	(Optional)
<i>file_name</i>	(Optional) snapshot XML file name
<i>snap_name</i>	(Optional) snapshot name

Command Mode

- /exec

show snapshots sections

show snapshots sections [*__readonly__* *TABLE_snapsection* <sectname> <sectcmd> <sectrow> <sectkey1> <sectkey2>]

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
sections	User-specified snapshot sections
<i>__readonly__</i>	(Optional)
<i>TABLE_snapsection</i>	(Optional)
<i>sectname</i>	(Optional) snapshot section name
<i>sectcmd</i>	(Optional) snapshot section show command
<i>sectrow</i>	(Optional) snapshot section row id
<i>sectkey1</i>	(Optional) snapshot section key 1
<i>sectkey2</i>	(Optional) snapshot section key 2

Command Mode

- /exec

show snmp

```
show snmp [ __readonly__ <sys_contact> <sys_location> <snmp_input_packets> <bad_snmp_version>
<unknown_community_name> <illegal_community_name> <encoding_Err> <req_var_nums> <alt_var_nums>
<get_req_in> <getnext_req_in> <set_req_in> <noname_pdu_in> <badval_pdu_in> <ro_pdu_in>
<genral_err_in> <get_resp_in> <unknown_ctx> <snmp_output_packets> <trap_pdu> <toobig_err>
<noname_pdu_out> <badval_pdu_out> <genral_err_out> <get_req_out> <getnext_req_out> <set_req_out>
<get_resp_out> <silent_drops> [ <max_pkt_size> ] [ { TABLE_snmp_community <community_name>
<grouporaccess> <context> <aclfilter> } ] [ { TABLE_snmp_users <user> <auth> <priv> [ { TABLE_groups
<group> } ] [ <acl_filter> ] [ <engineID> ] } ] <tcp_auth_status> [ <port_mon_status> [ <policy_name>
<pol_admin_status> <plo_oper_status> <pol_port_type> [ TABLE_policies <counter> <threshold> <interval>
<rising_threshold> <rising_event> <falling_threshold> <falling_event> <pmon_config> ] ] ] [ <protocol_status>
] [ { TABLE_snmp_contexts <context_name> <proto_instanceid> <vrf> <topology> [ <vlan> | <MST> ] }
] ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
__readonly__	(Optional) Read Only
TABLE_snmp_community	(Optional) Table that displays the community information
TABLE_snmp_users	(Optional) Table that displays the user information
TABLE_groups	(Optional) Table that displays the group information
TABLE_policies	(Optional) Table that displays the policy information
TABLE_snmp_contexts	(Optional) Table that displays the context information
<i>sys_contact</i>	(Optional) System Contact
<i>sys_location</i>	(Optional) System Location
<i>snmp_input_packets</i>	(Optional) SNMP input packets
<i>bad_snmp_version</i>	(Optional) bad snmp version in Input SNMP packets
<i>unknown_community_name</i>	(Optional) unknown community name in Input SNMP packets
<i>illegal_community_name</i>	(Optional) Illegal community name in Input SNMP packets
<i>encoding_Err</i>	(Optional) Encoding Errors in Input SNMP packets
<i>req_var_nums</i>	(Optional) number of requested variables
<i>alt_var_nums</i>	(Optional) number of altered variable
<i>get_req_in</i>	(Optional) GET request in Input SNMP packets
<i>getnext_req_in</i>	(Optional) GET-NEXT request in Input SNMP packets

<i>set_req_in</i>	(Optional) SET request in Input SNMP packets
<i>noname_pdu_in</i>	(Optional) NONAME PDU in Input SNMP packets
<i>badval_pdu_in</i>	(Optional) Bad value PDU in Input SNMP packets
<i>ro_pdu_in</i>	(Optional) Read only PDU in Input SNMP packets
<i>genral_err_in</i>	(Optional) Genral Error in Input SNMP packets
<i>get_resp_in</i>	(Optional) Get Response PDU in Input SNMP packets
<i>unknown_ctx</i>	(Optional) Unknown context Name in Input SNMP packets
<i>snmp_output_packets</i>	(Optional) SNMP Output Packets
<i>trap_pdu</i>	(Optional) Trap PDU in Output SNMP Packets
<i>toobig_err</i>	(Optional) Too Big errors in Output SNMP Packets
<i>noname_pdu_out</i>	(Optional)
<i>badval_pdu_out</i>	(Optional) NoName PDU in Output SNMP Packets
<i>genral_err_out</i>	(Optional) Genral Error in Output SNMP Packets
<i>get_req_out</i>	(Optional) GET request in Output SNMP Packets
<i>getnext_req_out</i>	(Optional) GET-NEXTrequest in Output SNMP Packets
<i>set_req_out</i>	(Optional) SET request in Output SNMP packets
<i>get_resp_out</i>	(Optional) Get Response PDU in Output SNMP Packets
<i>silent_drops</i>	(Optional) Silent Drop packets
<i>max_pkt_size</i>	(Optional) Maximum packet size
<i>community_name</i>	(Optional) community name
<i>grouporaccess</i>	(Optional) Group name
<i>context</i>	(Optional) context Name
<i>aclfilter</i>	(Optional) Acl filter name
<i>user</i>	(Optional) User name
<i>auth</i>	(Optional) Auth type
<i>priv</i>	(Optional) Priv Type
<i>group</i>	(Optional) Group name
<i>acl_filter</i>	(Optional) acl filter
<i>engineID</i>	(Optional) engine id for the user

<i>tcp_auth_status</i>	(Optional) TCP authentication status
<i>port_mon_status</i>	(Optional) Port monitor status
<i>policy_name</i>	(Optional) policy name
<i>pol_admin_status</i>	(Optional) Policy Admin status
<i>pol_oper_status</i>	(Optional) Police oper status
<i>pol_port_type</i>	(Optional) policy port type
<i>counter</i>	(Optional) counters
<i>threshold</i>	(Optional) Threshold
<i>interval</i>	(Optional) Interval
<i>rising_threshold</i>	(Optional) Rising threshold
<i>rising_event</i>	(Optional) Rising Event
<i>falling_threshold</i>	(Optional) Falling threshold
<i>falling_event</i>	(Optional) Falling Event
<i>pmon_config</i>	(Optional) PMON configured
<i>protocol_status</i>	(Optional) Protocol Enable status
<i>context_name</i>	(Optional) context name
<i>proto_instanceid</i>	(Optional) Protocol instance ID
<i>vrf</i>	(Optional) VRF Name
<i>topology</i>	(Optional) Topology
<i>vlan</i>	(Optional) VLAN name
<i>MST</i>	(Optional) MST name

Command Mode

- /exec

show snmp community

```
show snmp community [ __readonly__ { TABLE_snmp_community <community_name> <grouporaccess>
<context> <aclfilter> } ]
```

Syntax Description

<code>show</code>	Show running system information
<code>snmp</code>	show snmp information
<code>community</code>	show snmp community strings
<code>__readonly__</code>	(Optional) Read Only
<code>TABLE_snmp_community</code>	(Optional) contains all snmp community names
<code>community_name</code>	(Optional) community name
<code>grouporaccess</code>	(Optional) group or access name
<code>context</code>	(Optional) context name
<code>aclfilter</code>	(Optional) acl filter name

Command Mode

- /exec

show snmp context

```
show snmp context [ __readonly__ { TABLE_snmp_contexts <context_name> <proto_instanceid> <vrf>
<topology> [ <vlan> | <MST> ] } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
context	show snmp context mapping entries
__readonly__	(Optional)
TABLE_snmp_contexts	(Optional) All SNMP Contexts Entries
<i>context_name</i>	(Optional) SNMP context Name
<i>proto_instanceid</i>	(Optional) Name of the protocol instance
<i>vrf</i>	(Optional) VRF name
<i>topology</i>	(Optional) Name of the Topology
<i>vlan</i>	(Optional) VLAN Name
<i>MST</i>	(Optional)

Command Mode

- /exec

show snmp engineID

show snmp engineID [__readonly__ <engineIDHex> <engineIDDec>]

Syntax Description

show	Show running system information
snmp	show snmp information
engineID	show snmp engineID
__readonly__	(Optional)
<i>engineIDHex</i>	(Optional) SNMP engineID in HEX
<i>engineIDDec</i>	(Optional) SNMP engineID in Decimal

Command Mode

- /exec

show snmp group

```
show snmp group [ __readonly__ { TABLE_role <role_name> <role_description> [ <attribute_scope> ] [
<permit_vsan> ] [ <permit_vlan> ] [ <permit_vlan_id> ] [ <permit_interface> ] [ <permit_interface_slot> ]
[ <permit_vrf> ] [ TABLE_vrf<permit_vrf_name> ] [ { TABLE_rule [ <rule_num> ] [ <rule_action> ] {
<rule_permission> | <rule_permission_mds> } [ <rule_featuretype> ] [ <rule_entity> ] } } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
group	show snmp group
<i>__readonly__</i>	(Optional) Read Only
TABLE_role	(Optional) Table displays role
<i>role_name</i>	(Optional) Role Name
<i>role_description</i>	(Optional) Role Description
<i>attribute_scope</i>	(Optional) Role scope
<i>permit_vsan</i>	(Optional) permitted vsan
<i>permit_vlan</i>	(Optional)
<i>permit_vlan_id</i>	(Optional)
<i>permit_interface</i>	(Optional)
<i>permit_interface_slot</i>	(Optional)
<i>permit_vrf</i>	(Optional)
TABLE_rule	(Optional)
<i>rule_num</i>	(Optional)
<i>rule_action</i>	(Optional)
<i>rule_permission</i>	(Optional)
<i>rule_permission_mds</i>	(Optional)
<i>rule_featuretype</i>	(Optional)
<i>rule_entity</i>	(Optional)

Command Mode

- /exec

show snmp host

```
show snmp host [ __readonly__ { TABLE_host <host><port><version><level><type><secname> [ [ <vrf>
] [ TABLE_vrf_filters <vrf_filter> ] [ <src_intf> ] ] } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
host	show snmp hosts
__readonly__	(Optional) Read Only
TABLE_host	(Optional) displays the list of hosts configured for snmp requests
TABLE_vrf_filters	(Optional) displays the host vrf filters
vrf	(Optional) VRF Name
vrf_filter	(Optional) vrf filters
src_intf	(Optional) source interface

Command Mode

- /exec

show snmp mib igmpCacheTable

```
show snmp mib igmpCacheTable [ <igmpCacheAddress-in> ] [ <igmpCacheIfIndex-in> ] [ __readonly__
TABLE_igmpCacheTable <igmpCacheAddress-out> <igmpCacheIfIndex-out> <igmpCacheSelf>
<igmpCacheLastReporter> <igmpCacheUpTime> <igmpCacheExpiryTime> <igmpCacheStatus>
<igmpCacheVersion|HostTimer> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
igmpCacheTable	show mib table igmpCacheTable
<i>igmpCacheAddress-in</i>	(Optional) igmpCacheAddress
<i>igmpCacheIfIndex-in</i>	(Optional) igmpCacheIfIndex
<i>__readonly__</i>	(Optional)
TABLE_igmpCacheTable	(Optional)
<i>igmpCacheAddress-out</i>	(Optional) mib table index igmpCacheAddress
<i>igmpCacheIfIndex-out</i>	(Optional) mib table index igmpCacheIfIndex
<i>igmpCacheSelf</i>	(Optional) mib object igmpCacheSelf
<i>igmpCacheLastReporter</i>	(Optional) mib object igmpCacheLastReporter
<i>igmpCacheUpTime</i>	(Optional) mib object igmpCacheUpTime
<i>igmpCacheExpiryTime</i>	(Optional) mib object igmpCacheExpiryTime
<i>igmpCacheStatus</i>	(Optional) mib object igmpCacheStatus
<i>igmpCacheVersion HostTimer</i>	(Optional) mib object igmpCacheVersion HostTimer

Command Mode

- /exec

show snmp mib igmpInterfaceTable

```
show snmp mib igmpInterfaceTable [ <igmpInterfaceIfIndex-in> ] [ __readonly__ TABLE_igmpInterfaceTable
<igmpInterfaceIfIndex-out> <igmpInterfaceQueryInterval> <igmpInterfaceStatus> <igmpInterfaceVersion>
<igmpInterfaceQuerier> <igmpInterfaceQueryMaxResponseTime> <igmpInterfaceQuerierUpTime>
<igmpInterfaceQuerierExpiryTime> <igmpInterfaceVersion1QuerierTimer>
<igmpInterfaceWrongVersionQueries> <igmpInterfaceJoins> <igmpInterfaceProxyIfIndex>
<igmpInterfaceGroups> <igmpInterfaceRobustness> <igmpInterfaceLastMembQueryIntvl> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
igmpInterfaceTable	show mib table igmpInterfaceTable
<i>igmpInterfaceIfIndex-in</i>	(Optional) igmpInterfaceIndex
<i>__readonly__</i>	(Optional)
<i>TABLE_igmpInterfaceTable</i>	(Optional)
<i>igmpInterfaceIfIndex-out</i>	(Optional) mib table index igmpInterfaceIfIndex
<i>igmpInterfaceQueryInterval</i>	(Optional) mib object igmpInterfaceQueryInterval
<i>igmpInterfaceStatus</i>	(Optional) mib object igmpInterfaceStatus
<i>igmpInterfaceVersion</i>	(Optional) mib object igmpInterfaceVersion
<i>igmpInterfaceQuerier</i>	(Optional) mib object igmpInterfaceQuerier
<i>igmpInterfaceQueryMaxResponseTime</i>	(Optional) mib object igmpInterfaceQueryMaxResponseTime
<i>igmpInterfaceQuerierUpTime</i>	(Optional) mib object igmpInterfaceQuerierUpTime
<i>igmpInterfaceQuerierExpiryTime</i>	(Optional) mib object igmpInterfaceQuerierExpiryTime
<i>igmpInterfaceVersion1QuerierTimer</i>	(Optional) mib object igmpInterfaceVersion1QuerierTimer
<i>igmpInterfaceWrongVersionQueries</i>	(Optional) mib object igmpInterfaceWrongVersionQueries
<i>igmpInterfaceJoins</i>	(Optional) mib object igmpInterfaceJoins
<i>igmpInterfaceProxyIfIndex</i>	(Optional) mib object igmpInterfaceProxyIfIndex
<i>igmpInterfaceGroups</i>	(Optional) mib object igmpInterfaceGroups
<i>igmpInterfaceRobustness</i>	(Optional) mib object igmpInterfaceRobustness
<i>igmpInterfaceLastMembQueryIntvl</i>	(Optional) mib object igmpInterfaceLastMembQueryIntvl

Command Mode

- /exec

show snmp nms-statistics

```
show snmp nms-statistics [ __readonly__ <header> [ <nms_stats> ] ]
```

Syntax Description

show	Show running system information
snmp	Show snmp information
nms-statistics	Show SNMP NMS statistics
__readonly__	(Optional) Read Only
<i>header</i>	(Optional) NMS Statistics header
<i>nms_stats</i>	(Optional) NMS Statistics

Command Mode

- /exec

show snmp oid-statistics

```
show snmp oid-statistics [ last-access ] [ __readonly__ <header> { TABLE_snmp_gen <oid_stats> |
TABLE_snmp_la <oid_last_access_stats> } ]
```

Syntax Description

show	Show running system information
snmp	Show snmp information
oid-statistics	Show SNMP oid statistics
last-access	(Optional) Show SNMP oid statistics of last-access
__readonly__	(Optional) Read Only
<i>header</i>	(Optional) OID Statistics header
TABLE_snmp_gen	(Optional) contains all snmp oid statistics
<i>oid_stats</i>	(Optional) OID Statistics
TABLE_snmp_la	(Optional) contains all snmp oid last access statistics
<i>oid_last_access_stats</i>	(Optional) OID Last Access Statistics

Command Mode

- /exec

show snmp roledebug

show snmp roledebug

Syntax Description

show	Show running system information
snmp	show snmp information
roledebug	show SNMP roledebug

Command Mode

- /exec

show snmp sessions

show snmp sessions [__readonly__ { TABLE_session <dest> }]

Syntax Description

show	Show running system information
snmp	show snmp information
sessions	show snmp sessions
__readonly__	(Optional) Read Only
TABLE_session	(Optional) table displays destination
<i>dest</i>	(Optional) destination

Command Mode

- /exec

show snmp source-interface

```
show snmp source-interface [ __readonly__ { <trap_srcintf> <informs_srcintf> } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
source-interface	show source-interface through which notifications are sent
__readonly__	(Optional) Read Only
<i>trap_srcintf</i>	(Optional) Displays the source interface for traps
<i>informs_srcintf</i>	(Optional) Displays the source interface for informs

Command Mode

- /exec

show snmp trap

```
show snmp trap [ __readonly__ { TABLE_snmp_trap <trap_type><description><isEnabled> } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
trap	show snmp traps
__readonly__	(Optional) Read Only
TABLE_snmp_trap	(Optional) All snmp traps configured

Command Mode

- /exec

show snmp user

```
show snmp user [ <s0> [ engineID <s1> ] ][ __readonly__ [ { TABLE_snmp_users <user> <auth> <priv> [
{ TABLE_groups <group> } ] [ <acl_filter> ] [ <engineID> } } ] ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
user	show SNMPv3 users
<i>s0</i>	(Optional) Name of the user
engineID	(Optional) engineID
<i>s1</i>	(Optional) Target's SNMP engineID(colon separated) for SNMPv3 inform
__readonly__	(Optional) Read Only
TABLE_snmp_users	(Optional) table displays the snmp users
TABLE_groups	(Optional) table displays the groups for specific user
<i>user</i>	(Optional) user name
<i>auth</i>	(Optional) auth type
<i>priv</i>	(Optional) priv type
<i>group</i>	(Optional) group belongs to
<i>acl_filter</i>	(Optional) acl filter
<i>engineID</i>	(Optional) engineID for specific user

Command Mode

- /exec

show sockets client

```
show sockets client { [ pid <pid> ] [ tcp | udp | raw ] [ detail ] [ kstack-ns-all ] } [ __readonly__ [
TABLE_total_clients [ <socket-type> <total-clients> ] [ <no-total-clients> ] ] [ TABLE_cl_sk { <prefix>
<client-name> <pid> <No-of-clients> } [ <fast-tcp-mts-ctrl-q> ] [ { <cancel-requests> <cancel-unblocks>
<cancel-misses> <select-drops> <select-wakes> } ] [ TABLE_det [ { <fd> <client-id> [ <mts-sap> } ] ] ] [
TABLE_st [ <soc-calls> ] [ <bind-calls> ] [ <listen-calls> ] [ <accept-calls> ] [ <acc-dispat-err> ] [
<connect-calls> ] [ <connec-dispatch> ] [ <recvmmsg-dispatch> ] [ <recv-dis-nblock> ] [ <recvmmsg-call> ] [
<brecv-dispatch> ] [ <fsendmsg-calls> ] [ <sendmsg-dispatch> ] [ <sendmsg-calls> ] [ <msendmsg-calls> ]
[ <select-calls> ] [ <select-dispatch> ] [ <select-need-work> ] [ <sh-calls> ] [ <close-calls> ] [ <fcntl-calls>
] [ <iocctl-calls> ] [ <setsock-calls> ] [ <getsock-calls> ] [ <getsockname-calls> ] [ <getpeer-calls> ] [
<fork-calls> ] [ <execve-calls> ] [ <dup-calls> ] [ <can-calls> ] [ <can-miss> ] [ <can-unblk-sele> ] [
<soc-ha-calls> ] [ <pfork-client> ] [ <read-fd> ] [ <write-fd> ] [ <read-fd-set> ] [ <write-fd-set> ] [
<fast-tcp-send-req> ] [ <fast-tcp-send-suc> ] [ <fast-tcp-ack> ] ] [ TABLE_sterr [ <sock-err> ] [
<sock-nodev-err> ] [ <bind-err> ] [ <lis-err> ] [ <accept-err> ] [ <connect-err> ] [ <recvmmsg-err> ] [
<brcvmmsg-err> ] [ <fsendmsg-err> ] [ <sendmsg-err> ] [ <msndmsg-err> ] [ <select-err> ] [ <sel-nomem-err>
] [ <shut-err> ] [ <close-err> ] [ <fcntl-err> ] [ <iocctl-err> ] [ <setsock-err> ] [ <getsock-err> ] [ <getsockname-err>
] [ <getpeername-err> ] [ <fork-err> ] [ <execve-err> ] [ <dup-err> ] [ <psoc-vrf-err> ] [ <psoc-nosoc-err> ]
] [ <psoc-sock-null-err> ] [ <psoc-socre-err> ] [ <pbind-nsoc-err> ] [ <pbd-getsocaddr> ] [ <pbind-sobind-err>
] [ <plisten-nsoc-err> ] [ <plis-solis-err> ] [ <pacc-nsoc-err> ] [ <pacc-no-nsoc-err> ] [ <pacc-soc-null-err>
] [ <pacc-copy-err> ] [ <pacc-no-acc-err> ] [ <pacc-woublo-err> ] [ <pacc-connabo-err> ] [
<pacc-cond-wait-err> ] [ <pacc-so-err-err> ] [ <pacc-err-err> ] [ <pcon-no-soc-err> ] [ <pcon-ealready-err>
] [ <pconn-getsock> ] [ <pconn-socon-err> ] [ <pconn-einpro-err> ] [ <pconn-con-wait-err> ] [
<psend-no-soc-err> ] [ <psend-inval-iov> ] [ <psend-getsoc-err> ] [ <psend-msg-ctrl-err> ] [
<psend-sockarg-err> ] [ <psend-pru-sosend> ] [ <precv-nosock-err> ] [ <precv-inval-iovlen> ] [
<precv-pru-sorecv> ] [ <precv-cp-msg-err> ] [ <precv-cp-msg-nlen> ] [ <precv-cp-data-err> ] [
<pbrecv-rcvmmsg-err> ] [ <pshut-no-soc-err> ] [ <psetsock-val-err> ] [ <psetsock-inv-val> ] [ <psetsoc-no-soc-err>
] [ <psetsoc-sosetopt> ] [ <pgetsock-no-socerr> ] [ <pgetsock-cp-err> ] [ <pgetsock-val-err> ] [ <pgetsock-sogt-err>
] [ <pgtsoc-no-soc-err> ] [ <pgtsoc-cp-err> ] [ <pgtsoc-pru-soc-err> ] [ <pgtsoc-cpout-err> ] [
<pgtprne-no-soc-err> ] [ <pgtprne-enot-err> ] [ <pgtprne-cp-err> ] [ <pgtprne-pru-pradd> ] [
<pgtprne-cpout-err> ] [ <pclose-no-soc-err> ] [ <pclose-socnull-err> ] [ <pclose-p-cls2-err> ] [
<pfcntl-no-soc-err> ] [ <pfcntl-soc-null> ] [ <pfcntl-enotsup> ] [ <pfcntl-einval-err> ] [ <pioctl-no-soc-err>
] [ <pioctl-enotsup> ] [ <pioctl-pru-cntl> ] [ <pfork-enomem-err> ] [ <pdup-no-soc-err> ] [ <pudp-soc-null-err>
] [ <ha-nomem-err> ] [ <ha-tlv-err> ] [ <ha-soc-arg-err> ] [ <ha-cli-tlv-err> ] [ <ha-pss-upd-err> ] [
<ha-no-soc-err> ] [ <ha-soc-tlv-err> ] [ <ha-soc-pss-upd> ] [ <ha-inpcb-tlv> ] [ <ha-inpcb-pssky> ] [
<ha-ip-mopt-tlv> ] [ <ha-ip-mopt-pss> ] [ <ha-ip6-mopt-tlv> ] [ <ha-ip6-mopt-pss> ] [ <ha-tcpcb-tlv> ] [
<ha-tcpcb-pss> ] [ <ft-tcp-wblock> ] [ <ft-send-p-sndmsg> ] [ <ft-ack-rcv-no-soc> ] [ <!xc-tgid-err> ] ] [
TABLE_sp_cl [ <can-requests> <can-unblocks> <can-misses> <sel-drops> <sel-wakes> ] ] ] ] ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
client	Display sockets client information
pid	(Optional) Display specific client process information
<i>pid</i>	(Optional) Display client process <pid>

tcp	(Optional) Display TCP clients
udp	(Optional) Display UDP clients
raw	(Optional) Display RAW clients
detail	(Optional) Display socket details
kstack-ns-all	(Optional) Show kernel clients for all namespaces
__readonly__	(Optional)
TABLE_total_clients	(Optional) Total no of client sockets
socket-type	(Optional) Sockets type
total-clients	(Optional) total clients
no-total-clients	(Optional) number of total clients
TABLE_cl_sk	(Optional) Display Client sockets
prefix	(Optional) Prefix to the sockets
client-name	(Optional) Display socket client info
pid	(Optional) Display client process <pid>
No-of-clients	(Optional) Number of socket clients
fast-tcp-mts-ctrl-q	(Optional) Fast tcp mts control queue
cancel-requests	(Optional) cancel requests
cancel-unblocks	(Optional) cancel unblocks
cancel-misses	(Optional) cancel misses
select-drops	(Optional) select drops
select-wakes	(Optional) select wakes
TABLE_det	(Optional) Display Socket client Details
fd	(Optional) Client socket fd
client-id	(Optional) Client socket id
mts-sap	(Optional) socket mts addr sap
TABLE_st	(Optional) Sock detail Ctrl statistics
soc-calls	(Optional) sockets calls
bind-calls	(Optional) socket bind calls
listen-calls	(Optional) socket listen calls

<i>accept-calls</i>	(Optional) socket accept calls
<i>acc-dispat-err</i>	(Optional) socket accept dispatch error
<i>connect-calls</i>	(Optional) socket connect calls
<i>connec-dispatch</i>	(Optional) socket dispatch calls
<i>recvmsg-dispatch</i>	(Optional) receive msg dispatch
<i>recv-dis-nblock</i>	(Optional) receive dispatch nonblock
<i>recvmsg-call</i>	(Optional) receive message call
<i>brecv-dispatch</i>	(Optional) broadcast receive dispatch
<i>fsendmsg-calls</i>	(Optional) forward send message dispatch
<i>sendmsg-dispatch</i>	(Optional) send message dispatch
<i>sendmsg-calls</i>	(Optional) send message calls
<i>msendmsg-calls</i>	(Optional) multicast send message calls
<i>select-calls</i>	(Optional) select calls
<i>select-dispatch</i>	(Optional) select dispatch
<i>select-need-work</i>	(Optional) select need work
<i>sh-calls</i>	(Optional) show calls
<i>close-calls</i>	(Optional) close calls
<i>fcntl-calls</i>	(Optional) fcntl calls
<i>ioctl-calls</i>	(Optional) ioctl calls
<i>setsock-calls</i>	(Optional) setsock calls
<i>getsock-calls</i>	(Optional) getsock calls
<i>getsockname-calls</i>	(Optional) get socket name calls
<i>getpeer-calls</i>	(Optional) get peer calls
<i>fork-calls</i>	(Optional) fork calls
<i>execve-calls</i>	(Optional) execve calls
<i>dup-calls</i>	(Optional) duplicate calls
<i>can-calls</i>	(Optional) cancel calls
<i>can-miss</i>	(Optional) cancel miss
<i>can-unblk-sele</i>	(Optional) cancel unblock select

<i>soc-ha-calls</i>	(Optional) socket ha calls
<i>pfork-client</i>	(Optional) pfork client
<i>read-fd</i>	(Optional) socket read fd
<i>write-fd</i>	(Optional) socket write fd
<i>read-fd-set</i>	(Optional) socket read fd set
<i>write-fd-set</i>	(Optional) socket write fd set
<i>fast-tcp-send-req</i>	(Optional) socket fast tcp send request
<i>fast-tcp-send-suc</i>	(Optional) socket fast tcp send success
<i>fast-tcp-ack</i>	(Optional) socket fast tcp ack
TABLE_sterr	(Optional) Client Socket Error Statistics
<i>sock-err</i>	(Optional) socket error
<i>sock-nODEV-err</i>	(Optional) socket nodev error
<i>bind-err</i>	(Optional) socket bind error
<i>lis-err</i>	(Optional) socket listen error
<i>accept-err</i>	(Optional) socket accept error
<i>connect-err</i>	(Optional) socket connect error
<i>recvmsg-err</i>	(Optional) socket receive message error
<i>brcvmsg-err</i>	(Optional) socket broadcast receive message error
<i>fsendmsg-err</i>	(Optional) socket forward send message error
<i>sendmsg-err</i>	(Optional) socket send message error
<i>msndmsg-err</i>	(Optional) socket multicast send message error
<i>select-err</i>	(Optional) socket select error
<i>sel-nomem-err</i>	(Optional) socket select no member error
<i>shut-err</i>	(Optional) socket shutdown error
<i>close-err</i>	(Optional) socket close error
<i>fcntl-err</i>	(Optional) socket fcntl error
<i>ioctl-err</i>	(Optional) socket ioctl error
<i>setsoc-err</i>	(Optional) set socket error
<i>getsoc-err</i>	(Optional) get socket error

<i>getsocname-err</i>	(Optional) get socket name error
<i>getpeername-err</i>	(Optional) get peer name error
<i>fork-err</i>	(Optional) socket fork error
<i>execve-err</i>	(Optional) socket execve error
<i>dup-err</i>	(Optional) socket duplicate error
<i>psoc-vrf-err</i>	(Optional) psocket vrf error
<i>psoc-nosoc-err</i>	(Optional) psocket nosoc error
<i>psoc-sock-null-err</i>	(Optional) psocket socket null error
<i>psoc-socre-err</i>	(Optional) psocket socre error
<i>pbind-nsock-err</i>	(Optional) pbind nsock error
<i>pbid-getsocaddr</i>	(Optional) pbd getsocaddr
<i>pbind-sobind-err</i>	(Optional) pbind sobind error
<i>plisten-nsoc-err</i>	(Optional) plisten nsoc error
<i>plis-solis-err</i>	(Optional) plisten socket listen error
<i>pacc-nsoc-err</i>	(Optional) paccept new socket error
<i>pacc-no-nsoc-err</i>	(Optional) paccept no new socket error
<i>pacc-soc-null-err</i>	(Optional) paccept socket null error
<i>pacc-copy-err</i>	(Optional) paccept copy error
<i>pacc-no-acc-err</i>	(Optional) paccept no accept error
<i>pacc-woublo-err</i>	(Optional) paccept would block error
<i>pacc-connabo-err</i>	(Optional) paccept connect abort error
<i>pacc-cond-wait-err</i>	(Optional) paccept condition wait error
<i>pacc-so-err-err</i>	(Optional) paccept socket error
<i>pacc-err-err</i>	(Optional) paccept error
<i>pcon-no-soc-err</i>	(Optional) pconnect no socket error
<i>pcon-ealready-err</i>	(Optional) pconnect ready error
<i>pconn-getsock</i>	(Optional) pconnect get socket
<i>pconn-socon-err</i>	(Optional) pconnect socket on error
<i>pconn-einpro-err</i>	(Optional) pconnect einprogress error

<i>pconn-con-wait-err</i>	(Optional) pconnect condition wait error
<i>psend-no-soc-err</i>	(Optional) psend no socket error
<i>psend-inval-iov</i>	(Optional) psend invalidate iov
<i>psend-getsoc-err</i>	(Optional) psend getsocket error
<i>psend-msg-ctrl-err</i>	(Optional) psend message control error
<i>psend-sockarg-err</i>	(Optional) psend socket argument error
<i>psend-pru-sosend</i>	(Optional) psend pru socket send
<i>precv-nosock-err</i>	(Optional) preceive no socket error
<i>precv-inval-iovlen</i>	(Optional) preceive invalidate iovlen
<i>precv-pru-sorecv</i>	(Optional) preceive pru so receive
<i>precv-cp-msg-err</i>	(Optional) preceive copy message error
<i>precv-cp-msg-nlen</i>	(Optional) preceive copy message new length
<i>precv-cp-data-err</i>	(Optional) preceive copy data error
<i>pbrecv-rcvmsg-err</i>	(Optional) preceive receive message error
<i>pshut-no-soc-err</i>	(Optional) pshutdown no socket error
<i>psetsoc-val-err</i>	(Optional) pset socket value error
<i>psetsoc-inv-val</i>	(Optional) pset socket invalidate error
<i>psetsoc-no-soc-err</i>	(Optional) pset socket no socket error
<i>psetsoc-sosetopt</i>	(Optional) pset socket set opt
<i>pgetsoc-no-socerr</i>	(Optional) pget socket no socket error
<i>pgetsoc-cp-err</i>	(Optional) pget socket copy error
<i>pgetsoc-val-err</i>	(Optional) pget socket validate error
<i>pgetsoc-sogt-err</i>	(Optional) pget socket sogt error
<i>pgtsoc-no-soc-err</i>	(Optional) pget socket no socket error
<i>pgtsoc-cp-err</i>	(Optional) pget socket copy error
<i>pgtsoc-pru-soc-err</i>	(Optional) pget socket pru socket error
<i>pgtsoc-cpout-err</i>	(Optional) pget socket copy out error
<i>pgtprne-no-soc-err</i>	(Optional) pget peer name no socket error
<i>pgtprne-enot-err</i>	(Optional) pget peer name enot connect error

<i>pgtprne-cp-err</i>	(Optional) pget peer name copy error
<i>pgtprne-pru-pradd</i>	(Optional) pget peer name pru peer address
<i>pgtprne-cpout-err</i>	(Optional) pget peer name copy out error
<i>pclose-no-soc-err</i>	(Optional) pclose no socket error
<i>pclose-socnull-err</i>	(Optional) pclose socket null error
<i>pclose-p-cls2-err</i>	(Optional) pclose p close2 error
<i>pfcntl-no-soc-err</i>	(Optional) pfcntl no socket error
<i>pfcntl-soc-null</i>	(Optional) pfcntl socket null
<i>pfcntl-enotsup</i>	(Optional) pfcntl enotsupport errors
<i>pfcntl-einval-err</i>	(Optional) pfcntl invalidate error
<i>pioctl-no-soc-err</i>	(Optional) pioctl no socket error
<i>pioctl-enotsup</i>	(Optional) pioctl enotsup
<i>pioctl-pru-cntl</i>	(Optional) pioctl pru cntl
<i>pfork-enomem-err</i>	(Optional) pfork eno-memory error
<i>pdup-no-soc-err</i>	(Optional) pudp no socket error
<i>pdup-soc-null-err</i>	(Optional) pudp socket null error
<i>ha-nomem-err</i>	(Optional) ha no memory error
<i>ha-tlv-err</i>	(Optional) ha tlv error
<i>ha-soc-arg-err</i>	(Optional) ha socket argument error
<i>ha-cli-tlv-err</i>	(Optional) ha cli tlv error
<i>ha-pss-upd-err</i>	(Optional) ha pss udp error
<i>ha-no-soc-err</i>	(Optional) ha no socket error
<i>ha-soc-tlv-err</i>	(Optional) ha socket tlv error
<i>ha-soc-pss-upd</i>	(Optional) ha socket pss udp
<i>ha-inpcb-tlv</i>	(Optional) ha inpcb tlv value
<i>ha-inpcb-pssky</i>	(Optional) ha inpcb pssky value
<i>ha-ip-mopt-tlv</i>	(Optional) ha ip mopt tlv value
<i>ha-ip-mopt-pss</i>	(Optional) ha ip mopt pss value
<i>ha-ip6-mopt-tlv</i>	(Optional) ha ip6 mopt tlv value

<i>ha-ip6-mopt-pss</i>	(Optional) ha ip6 mopt pss value
<i>ha-tcpcb-tlv</i>	(Optional) ha socket update tcpcb to tlv error
<i>ha-tcpcb-pss</i>	(Optional) ha socket update tcpcb psskey update error
<i>fi-tcp-wblock</i>	(Optional) fast tcp send would block error
<i>fi-send-p-sndmsg</i>	(Optional) fast tcp send p_sendmsg errors
<i>fi-ack-rcv-no-soc</i>	(Optional) fast ack receive no socket
<i>lxc-tgid-err</i>	(Optional) Containers tgid err
TABLE_sp_cl	(Optional) Sock specific Ctrl statistics
<i>can-requests</i>	(Optional) socket control cancel request
<i>can-unblocks</i>	(Optional) socket cancel unblocks
<i>can-misses</i>	(Optional) socket cancel misses
<i>sel-drops</i>	(Optional) select drops
<i>sel-wakes</i>	(Optional) select wakes

Command Mode

- /exec

show sockets connection

```
show sockets connection [ pid <pid> | tcp | udp | raw ] [ local { <srcIP> | <srcIP6> } ] [ foreign { <dstIP> | <dstIP6> } ] [ detail ] [ keydetails ] [ __readonly__ [ { TABLE_sockets <protocol> [ <total-conn-count> ] [ { TABLE_conn <afi> [ <laddr> ] [ <lport> ] [ <faddr> ] [ <fport> ] [ <prot> ] [ <type> ] [ <ttl> ] [ <tos> ] [ <options> ] [ <state> ] [ <rcv-count> ] [ <rcv-hiwater> ] [ <rcv-lowat> ] [ <rcv-flags> ] [ <snd-count> ] [ <snd-hiwater> ] [ <snd-lowat> ] [ <snd-flags> ] [ <iss> ] [ <snd-una> ] [ <snd-nxt> ] [ <snd_wnd> ] [ <irs> ] [ <rcv-nxt> ] [ <rcv-wnd> ] [ <snd-cwnd> ] [ <srtt> ] [ <rtt> ] [ <rttvar> ] [ <krtt> ] [ <rttmin> ] [ <mss> ] [ <dur> ] [ <tcp-state> ] [ <flags> ] [ <md5-cnt> ] [ <md5-host> ] [ <md5-err> ] [ <tcp-count> ] [ <udp-count> ] [ <raw-count> ] [ <vrf-name> ] [ <intf> } } ] ] ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
connection	Display connection information
pid	(Optional) Display specific client process connection status
<i>pid</i>	(Optional) Display client process connection status <pid>
tcp	(Optional) Display all TCP connections
udp	(Optional) Display all UDP connections
raw	(Optional) Display all raw connections
local	(Optional) Display all TCP connections with specified local address
<i>srcIP</i>	(Optional) Display all TCP connections with specified local address
foreign	(Optional) Display all TCP connections with specified foreign address
<i>dstIP</i>	(Optional) Display all TCP connections with specified foreign address
detail	(Optional) Display detailed connection information
keydetails	(Optional) Display md5 key specific details
__readonly__	(Optional)
TABLE_sockets	(Optional) sockets table
<i>protocol</i>	(Optional) socket protocol
<i>total-conn-count</i>	(Optional) socket connection table
TABLE_conn	(Optional)
<i>afi</i>	(Optional) socket family
<i>prot</i>	(Optional) socket protocol

<i>tcp-state</i>	(Optional) socket tcp state
<i>rcv-count</i>	(Optional) socket connection receive count
<i>laddr</i>	(Optional) socket conection laddr
<i>lport</i>	(Optional) socket connection lport
<i>faddr</i>	(Optional) socket connection faddr
<i>fport</i>	(Optional) socket connection fport
<i>intf</i>	(Optional) socket connection interface
<i>vrf-name</i>	(Optional) socket vrf name
<i>snd-count</i>	(Optional) socket connection send count
<i>type</i>	(Optional) socket connection type
<i>ttl</i>	(Optional) socket connection ttl
<i>tos</i>	(Optional) socket connection tos
<i>options</i>	(Optional) socket connection option
<i>state</i>	(Optional) socket connection state
<i>iss</i>	(Optional) socket connection iss
<i>snd-una</i>	(Optional) socket connection send unavailable
<i>snd-nxt</i>	(Optional) socket connection send next
<i>snd_wnd</i>	(Optional) socket connection send window
<i>irs</i>	(Optional) socket connection irs
<i>rcv-nxt</i>	(Optional) socket connection receive next
<i>rcv-wnd</i>	(Optional) socket connection receive window
<i>snd-cwnd</i>	(Optional) socket connection close sent window
<i>srtt</i>	(Optional) socket connection srtt
<i>rtt</i>	(Optional) socket connection rtt
<i>rttvar</i>	(Optional) socket connection rttvar
<i>krtt</i>	(Optional) socket connection krtt
<i>rttmin</i>	(Optional) socket connection rtt mintues
<i>mss</i>	(Optional) socket connection mss
<i>dur</i>	(Optional) socket connection duration

<i>flags</i>	(Optional) socket connection flags
<i>md5-cnt</i>	(Optional) socket connection md5 count
<i>md5-host</i>	(Optional) socket connection md5 host
<i>md5-err</i>	(Optional) socket connection md5 error
<i>rcv-hiwat</i>	(Optional) socket connection receive hiwat
<i>rcv-lowat</i>	(Optional) socket connection receive lowat
<i>rcv-flags</i>	(Optional) socket connection receive flags
<i>snd-hiwat</i>	(Optional) socket connection send hiwat
<i>snd-lowat</i>	(Optional) socket connection send lowat
<i>snd-flags</i>	(Optional) socket connection send flags
<i>tcp-count</i>	(Optional) socket connection tcp count
<i>udp-count</i>	(Optional) socket connection udp count
<i>raw-count</i>	(Optional) socket connection raw count

Command Mode

- /exec

show sockets local-port-range

```
show sockets local-port-range [ __readonly__ <kstack_local_port_range_start> <kstack_local_port_range_end>
<netstack_local_port_range_start> <netstack_local_port_range_end> <nat_local_port_range_start>
<nat_local_port_range_end> ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
local-port-range	Display local port range
<i>__readonly__</i>	(Optional)
<i>kstack_local_port_range_start</i>	(Optional) Kstack local port range start
<i>kstack_local_port_range_end</i>	(Optional) Kstack local port range end
<i>netstack_local_port_range_start</i>	(Optional) Netstack local port range start
<i>netstack_local_port_range_end</i>	(Optional) Netstack local port range end
<i>nat_local_port_range_start</i>	(Optional) Nat local port range start
<i>nat_local_port_range_end</i>	(Optional) Nat local port range end

Command Mode

- /exec

show sockets ns-port-kiosk

show sockets ns-port-kiosk

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
ns-port-kiosk	Display port kiosk for netstack socket clients

Command Mode

- /exec

show sockets statistics

```

show sockets statistics [ all | tcp | tcp6 | tcpsum | udp | udp6 | udpsum | raw | raw6 | rawsum ] [ __readonly__
[ { TABLE_stat [ <rx-total> ] [ <rx-bad-csum> ] [ <rx-bad-offset> ] [ <rx-too-short> ] [ <rx-bad-md5> ] [
<rx-inseq-pack> ] [ <rx-inseq-bytes> ] [ <rx-dup-pack> ] [ <rx-dup-bytes> ] [ <rx-partdup-pack> ] [
<rx-partdup-bytes> ] [ <rx-oo-pack> ] [ <rx-oo-bytes> ] [ <rx-oo-drop-cnt> ] [ <rx-afterwin-pack> ] [
<rx-afterwin-bytes> ] [ <rx-afterclose-pack> ] [ <rx-winprobe-pack> ] [ <rx-winupdate-pack> ] [
<rx-dupack-pack> ] [ <rx-dupack-unsent-pack> ] [ <rx-ack-pack> ] [ <rx-ack-bytes> ] [ <rx-rcv-memdrop>
] [ <rx-dig-mssing> ] [ <rx-dig-unexpected> ] [ <rx-dig-notused> ] [ <rx-dig-valid> ] [ <rx-dig-invalid> ] [
<rx-get-passwd-fail> ] [ <rx-md5-mbuf-exded> ] [ <rx-uspec-src-recv> ] [ <rx-pkt-too-short> ] [ <rx-sin-finest>
] [ <rx-black-hole-syn> ] [ <rx-black-hole> ] [ <rx-drop-no-inpcb> ] [ <rx-drop-notcpcb> ] [
<rx-drp-sock-closed> ] [ <rx-syn-with-rst> ] [ <rx-syn-drop> ] [ <rx-bandlim> ] [ <rx-forged-pkt> ] [
<rx-drp-mbcast> ] [ <rx-drp-syn-add> ] [ <rx-drp-syn-recvd> ] [ <rx-drp-cc-sent> ] [ <rx-drp-rst-csent> ] [
<rx-frecv-enqueue> ] [ <rx-frecv-enqueue-fail> ] [ <rx-ftp-cant-rcv-more> ] [ <rx-ftp-data-ack-toapp-fail>
] [ <rx-ftp-data-ack-toapp> ] [ <tx-total> ] [ <tx-urg> ] [ <tx-ctrl> ] [ <tx-data-pack> ] [ <tx-data-bytes> ] [
<tx-reasm-pack> ] [ <tx-reasm-bytes> ] [ <tx-ackonly-pack> ] [ <tx-winprobe-pack> ] [ <tx-winupdate-bytes>
] [ <tx-encrypt> ] [ <tx-unencrypt> ] [ <tx-md5rst> ] [ <tx-conn-init> ] [ <tx-conn-accepted> ] [ <tx-conn-estd>
] [ <closed> ] [ <dropped> ] [ <emb-dropped> ] [ <tx-rxmt-timeout> ] [ <tx-rxmt-timeout-dropped> ] [
<tx-ka-timeout> ] [ <tx-ka-probe> ] [ <tx-ka-drop> ] [ <gen-seg-timed> ] [ <gen-rtt-updated> ] [ <gen-delack>
] [ <gen-persist-timeout> ] [ <gen-paws-drop> ] [ <gen-predack> ] [ <gen-predat> ] [ <gen-pcb-cachemiss>
] [ <gen-cache-drtt> ] [ <gen-cache-drttvar> ] [ <gen-cached-ssthresh> ] [ <gen-usedrtt> ] [ <gen-usedrttvar>
] [ <gen-usedssthresh> ] [ <gen-persistdrop> ] [ <gen-badsyn> ] [ <gen-mturesent> ] [ <gen-list-endrop> ] [
<gen-rpm-bind-synsock> ] [ <gen-rpm-bindsynadd> ] [ <gen-rpm-bindlookup> ] [ <gen-rpm-bindsetsock>
] [ <gen-rpm-unbind-getpass> ] [ <gen-rpm-unbinduser1> ] [ <gen-rpm-unbinduser2> ] [
<gen-rpm-unbindrollover> ] [ <gen-rpm-unbind-synfree> ] [ <gen-rpm-unbind-tpfree> ] [ <syn-sc-added> ]
[ <syn-retransmitted> ] [ <syn-dupsyn> ] [ <syn-dropped> ] [ <syn-completed> ] [ <syn-bucket-overflow> ]
[ <syn-cache-overflow> ] [ <syn-sc-reset> ] [ <syn-sc-stale> ] [ <syn-sc-aborted> ] [ <syn-sc-badack> ] [
<syn-sc-unreach> ] [ <syn-sc-zonefail> ] [ <syn-sc-sendcookie> ] [ <syn-sc-recvcookie> ] [ <syn-sc-crosshits>
] [ <syn-sc-supsyncrosshits> ] [ <syn-sc-removecrosshits> ] [ <udp-rx-total> ] [ <udp-rx-bad-csum> ] [
<udp-rx-no-csum> ] [ <udp-rx-too-short> ] [ <udp-rx-bad-len> ] [ <udp-rx-no-port> ] [ <udp-rx-no-port-bcast>
] [ <udp-rx-no-port-mcast> ] [ <udp-rx-full-socket-drop> ] [ <udp-tx-total> ] [ <raw-rx-version> ] [
<raw-rx-rcvd> ] [ <raw-rx-no-port> ] [ <raw-rx-full-socket-drop> ] [ <raw-tx-sent> ] [ <inpcb-tot-alloc> ] [
<inpcb-tot-bind> ] [ <inpcb-tot-laddr> ] [ <inpcb-tot-connect> ] [ <inpcb-tot-disconnect> ] [ <inpcb-tot-detach>
] [ <inpcb-tot-detach-noinc> ] [ <inpcb-tot-detach-rort> ] [ <inpcb-tot-rtfree> ] [ <inpcb-tot-setsock-addr> ]
[ <inpcb-tot-setpeeraddr> ] [ <inpcb-tot-notify> ] [ <inpcb-tot-lookup-npacli-deny> ] [
<inpcb-tot-lookup-npacli-allow> ] [ <inpcb-tot-inshash-ipv4> ] [ <inpcb-tot-inshash-ipv6> ] [
<inpcb-tot-brehash-ipv4> ] [ <inpcb-tot-brehash-ipv6> ] [ <inpcb-tot-bremhash> ] [ <inpcb-err-allocnomem>
] [ <inpcb-err-bindeinavl> ] [ <inpcb-err-eaddrinuse> ] [ <inpcb-err-eagain> ] [ <inpcb-err-eagain2> ] [
<inpcb-err-eaddrnotavail> ] [ <inpcb-err-eafnosupport> ] [ <inpcb-err-enomem> ] [ <inpcb-err-ehostunreach>
] [ <inpcb-err-laddr-enixio> ] [ <inpcb-err-laddr-ehostunreach2> ] [ <inpcb-err-connectladdr> ] [
<inpcb-err-connect-eaddrinuse> ] [ <inpcb-err-connbind> ] [ <inpcb-err-sockaddrnomem> ] [
<inpcb-err-sockaddrreconnreset> ] [ <inpcb-err-peeraddr-enomem> ] [ <inpcb-err-econnrest> ] [
<inpcb-err-respond-enobufs> ] [ <inpcb-err-binshash-enobufs> ] [ <in6pcb-tot-setport> ] [ <in6pcb-tot-bind>
] [ <in6pcb-tot-laddr> ] [ <in6pcb-tot-connect> ] [ <in6pcb-tot-disconnect> ] [ <in6pcb-tot-detach> ] [
<in6pcb-tot-sockaddr> ] [ <in6pcb-tot-peeraddr> ] [ <in6pcb-tot-notify> ] [ <in6pcb-tot-lookuplocal> ] [
<in6pcb-tot-hashnpacli-deny> ] [ <in6pcb-err-setporteagain> ] [ <in6pcb-err-setporteagain2> ] [
<in6pcb-err-seteagain3> ] [ <in6pcb-bind-eafnosupport> ] [ <in6pcb-err-bindeaddrinuse> ] [
<in6pcb-err-bindeaddrinuse2> ] [ <in6pcb-err-bindeaddrinuse3> ] [ <in6pcb-err-bindeaddrinuse4> ] [
<in6pcb-err-bindsetport> ] [ <in6pcb-err-bindeagain> ] [ <in6pcb-err-laddr-eafnosupport> ] [
<in6pcb-err-eaddrnotavail> ] [ <in6pcb-err-laddr-enomem> ] [ <in6pcb-err-laddr-ehostreach> ] [

```

```
<in6pcb-err-laddr-ehostunreach2> ] [ <in6pcb-err-laddr-ehostunreach3> ] [ <in6pcb-err-laddr-ehostunreach4>
] [ <in6pcb-err-laddr-enxio> ] [ <in6pcb-err-connladdr> ] [ <in6pcb-err-conneaddrinuse> ] [
<in6pcb-err-connbind> ] [ <in6pcb-err-sockaddr-enomem> ] [ <in6pcb-err-v4maps-enomem> ] [
<in6pcb-err-setsock-noinp> ] [ <in6pcb-err-setpeer-noinp> ] [ <in6pcb-err-sockaddr-noinp> ] [
<in6pcb-err-peeraddr-noinp> ] [ <in6pcb-err-notify-einavl> ] [ <in6pcb-err-ctloutput-nosoopt> ] } ] ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
statistics	Display sockets statistics
all	(Optional) Display TCP/UDP/RAW v4/v6 protocols statistics
tcp	(Optional) Display TCP v4 protocol statistics
tcp6	(Optional) Display TCP v6 protocol statistics
tcpsum	(Optional) Display sum of TCP v4 and TCP v6 protocols statistics
udp	(Optional) Display UDP v4 protocol statistics
udp6	(Optional) Display UDP v6 protocol statistics
udpsum	(Optional) Display sum of UDP v4 and UDP v6 protocols statistics
raw	(Optional) Display RAW v4 protocol statistics
raw6	(Optional) Display RAW v6 protocol statistics
rawsum	(Optional) Display sum of RAW v4 and RAW v6 protocols statistics
__readonly__	(Optional)
TABLE_stat	(Optional) sockets statistics table
<i>rx-total</i>	(Optional) total packets received
<i>rx-bad-csum</i>	(Optional) packets received with ccksum errs
<i>rx-bad-offset</i>	(Optional) packets received with bad offset
<i>rx-too-short</i>	(Optional) packets received too short
<i>rx-bad-md5</i>	(Optional) Recieved bad digest
<i>rx-inseq-pack</i>	(Optional) packets received in sequence
<i>rx-inseq-bytes</i>	(Optional) bytes received in sequence
<i>rx-dup-pack</i>	(Optional) duplicate-only packets received
<i>rx-dup-bytes</i>	(Optional) duplicate-only bytes received
<i>rx-partdup-pack</i>	(Optional) packets with some duplicate data

<i>rx-partdup-bytes</i>	(Optional) dup. bytes in part-dup. packets
<i>rx-oo-pack</i>	(Optional) out-of-order packets received
<i>rx-oo-bytes</i>	(Optional) out-of-order bytes received
<i>rx-oo-drop-cnt</i>	(Optional) out-of-order drop count
<i>rx-afterwin-pack</i>	(Optional) packets with data after window
<i>rx-afterwin-bytes</i>	(Optional) bytes rcvd after window
<i>rx-afterclose-pack</i>	(Optional) packets rcvd after close
<i>rx-winprobe-pack</i>	(Optional) rcvd window probe packets
<i>rx-winupdate-pack</i>	(Optional) rcvd window update packets
<i>rx-dupack-pack</i>	(Optional) rcvd duplicate acks
<i>rx-dupack-unsent-pack</i>	(Optional) rcvd acks for unsent data
<i>rx-ack-pack</i>	(Optional) rcvd ack packets
<i>rx-ack-bytes</i>	(Optional) bytes acked by rcvd acks
<i>rx-rcv-memdrop</i>	(Optional) packets dropped for lack of memory
<i>rx-dig-missing</i>	(Optional) digest missing
<i>rx-dig-unexpected</i>	(Optional) digest unexpected
<i>rx-dig-notused</i>	(Optional) digest not used
<i>rx-dig-valid</i>	(Optional) digest valid
<i>rx-dig-invalid</i>	(Optional) digest invalid
<i>rx-get-passwd-fail</i>	(Optional) get pass failed for RST
<i>rx-md5-mbuf-exded</i>	(Optional) md5 passwd exceeds mbuf
<i>rx-uspec-src-recv</i>	(Optional) Dropped Unspecified src pkt recieved
<i>rx-pkt-too-short</i>	(Optional) Dropped Packet too short
<i>rx-sin-finest</i>	(Optional) Dropped packet set with SYN/FIN
<i>rx-black-hole-syn</i>	(Optional) Dropped black hole SYN
<i>rx-black-hole</i>	(Optional) Dropped black hole
<i>rx-drop-no-inpcb</i>	(Optional) Dropped no inpcb
<i>rx-drop-notpcb</i>	(Optional) Dropped no tcpb
<i>rx-drp-sock-closed</i>	(Optional) Dropped socket closed

<i>rx-syn-with-rst</i>	(Optional) Dropped SYN with reset
<i>rx-syn-drop</i>	(Optional) Dropped SYN
<i>rx-bandlim</i>	(Optional) Dropped Bandlim rst open port
<i>rx-forged-pkt</i>	(Optional) Dropped Same src/dst
<i>rx-drp-mbcast</i>	(Optional) Dropped Broadcast/Multicast
<i>rx-drp-syn-add</i>	(Optional) Dropped Adding SYN failed
<i>rx-drp-syn-recvd</i>	(Optional) ACK recvd not for our SYN
<i>rx-drp-cc-sent</i>	(Optional) Dropped cc sent
<i>rx-drp-rst-ccsent</i>	(Optional) Dropped cc sent with reset
<i>rx-frecv-enqueue</i>	(Optional) Fast recv packets enqueued
<i>rx-frecv-enqueue-fail</i>	(Optional) Fast recv enqueue failed
<i>rx-ftcp-cant-rcv-more</i>	(Optional) Fast TCP can not recv more
<i>rx-ftcp-data-ack-toapp-fail</i>	(Optional) Fast TCP data ACK to app failed
<i>rx-ftcp-data-ack-toapp</i>	(Optional) Fast TCP data ACK to app
<i>tx-total</i>	(Optional) total packets sent
<i>tx-urg</i>	(Optional) packets sent with URG only
<i>tx-ctrl</i>	(Optional) control (SYN FIN RST) packets sent
<i>tx-data-pack</i>	(Optional) data packets sent
<i>tx-data-bytes</i>	(Optional) data bytes sent
<i>tx-reasm-pack</i>	(Optional) data packets retransmitted
<i>tx-reasm-bytes</i>	(Optional) data bytes retransmitted
<i>tx-ackonly-pack</i>	(Optional) ack-only packets sent
<i>tx-winprobe-pack</i>	(Optional) window probes sent
<i>tx-winupdate-bytes</i>	(Optional) window update-only packets sent
<i>tx-encrypt</i>	(Optional) Encrypted packets sent
<i>tx-unencrypt</i>	(Optional) Unencrypted packets sent
<i>tx-md5rst</i>	(Optional) No of encrypted RST packets
<i>tx-conn-init</i>	(Optional) connections initiated
<i>tx-conn-accepted</i>	(Optional) connections accepted

<i>tx-conn-estd</i>	(Optional) connections established
<i>closed</i>	(Optional) conn. closed (includes drops)
<i>dropped</i>	(Optional) connections dropped
<i>emb-dropped</i>	(Optional) embryonic connections dropped
<i>tx-rxmt-timeout</i>	(Optional) total rxmt timeout
<i>tx-rxmt-timeout-dropped</i>	(Optional) connections dropped in rxmt timeout
<i>tx-ka-timeout</i>	(Optional) keepalive timeouts
<i>tx-ka-probe</i>	(Optional) keepalive probes sent
<i>tx-ka-drop</i>	(Optional) connections dropped in keepalive
<i>gen-seg-timed</i>	(Optional) segs where we tried to get rtt
<i>gen-rtt-updated</i>	(Optional) times we succeeded to get rtt
<i>gen-delack</i>	(Optional) delayed acks sent
<i>gen-persist-timeout</i>	(Optional) persist timeouts
<i>gen-paws-drop</i>	(Optional) segments dropped due to PAWS
<i>gen-predack</i>	(Optional) hdr predict ok for acks
<i>gen-preddat</i>	(Optional) hdr predict ok for data pkts
<i>gen-pcb-cachemiss</i>	(Optional) PCB cache miss
<i>gen-cache-drtt</i>	(Optional) times cached RTT in route updated
<i>gen-cache-drttvar</i>	(Optional) times cached rttvar updated
<i>gen-cached-ssthresh</i>	(Optional) times cached ssthresh updated
<i>gen-usedrtt</i>	(Optional) times RTT initialized from route
<i>gen-usedrttvar</i>	(Optional) times RTTVAR initialized from rt
<i>gen-usedssthresh</i>	(Optional) times ssthresh initialized from rt
<i>gen-persistdrop</i>	(Optional) timeout in persist state
<i>gen-badsyn</i>	(Optional) bogus SYN, e.g. premature ACK
<i>gen-mturesent</i>	(Optional) resends due to MTU discovery
<i>gen-list-endrop</i>	(Optional) listen queue overflows
<i>gen-rpm-bind-synsock</i>	(Optional) rpm bind in synsock
<i>gen-rpm-bindsynadd</i>	(Optional) rpm bind in synadd

<i>gen-rpm-bindlookup</i>	(Optional) rpm bind in lookup
<i>gen-rpm-bindsetsock</i>	(Optional) rpm bind in setsock
<i>gen-rpm-unbind-getpass</i>	(Optional) rpm unbind get pass
<i>gen-rpm-unbinduser1</i>	(Optional) rpm unbind by user
<i>gen-rpm-unbinduser2</i>	(Optional) rpm unbind by user1
<i>gen-rpm-unbindrollover</i>	(Optional) rpm unbind during rollover
<i>gen-rpm-unbind-synfree</i>	(Optional) rpm unbind in syn free
<i>gen-rpm-unbind-tpfree</i>	(Optional) rpm unbind in tp free
<i>syn-sc-added</i>	(Optional) entry added to syncache
<i>syn-retransmitted</i>	(Optional) syncache entry was retransmitted
<i>syn-dupsyn</i>	(Optional) duplicate SYN packet
<i>syn-dropped</i>	(Optional) could not reply to packet
<i>syn-completed</i>	(Optional) successful extraction of entry
<i>syn-bucket-overflow</i>	(Optional) syncache per-bucket limit hit
<i>syn-cache-overflow</i>	(Optional) syncache cache limit hit
<i>syn-sc-reset</i>	(Optional) RST removed entry from syncache
<i>syn-sc-stale</i>	(Optional) timed out or listen socket gone
<i>syn-sc-aborted</i>	(Optional) syncache entry aborted
<i>syn-sc-badack</i>	(Optional) removed due to bad ACK
<i>syn-sc-unreach</i>	(Optional) ICMP unreachable received
<i>syn-sc-zonefail</i>	(Optional) zalloc() failed
<i>syn-sc-sendcookie</i>	(Optional) SYN cookie sent
<i>syn-sc-recvcookie</i>	(Optional) SYN cookie received
<i>syn-sc-crosshits</i>	(Optional) crosshits on the SC blocks
<i>syn-sc-supsyncrosshits</i>	(Optional) crosshits dup SYN on SC block
<i>syn-sc-removecrosshits</i>	(Optional) crosshits on SC blocks to remove
<i>udp-rx-total</i>	(Optional) total udp packets
<i>udp-rx-bad-csum</i>	(Optional) udp checksum error
<i>udp-rx-no-csum</i>	(Optional) udp no checksum

<i>udp-rx-too-short</i>	(Optional) udp packets drops
<i>udp-rx-bad-len</i>	(Optional) udp bad length
<i>udp-rx-no-port</i>	(Optional) udp no port
<i>udp-rx-no-port-bcast</i>	(Optional) udp no port broadcast
<i>udp-rx-no-port-mcast</i>	(Optional) udp no port multicast
<i>udp-rx-full-socket-drop</i>	(Optional) udp dropped full socket
<i>udp-tx-total</i>	(Optional) udp total packets
<i>raw-rx-version</i>	(Optional) raw sockets version
<i>raw-rx-rcvd</i>	(Optional) raw sockets connection received
<i>raw-rx-no-port</i>	(Optional) raw socket no port
<i>raw-rx-full-socket-drop</i>	(Optional) raw socket full sockets drop
<i>raw-tx-sent</i>	(Optional) raw socket connection sent
<i>inpcb-tot-alloc</i>	(Optional) inpcb allocation
<i>inpcb-tot-bind</i>	(Optional) inpcb bind
<i>inpcb-tot-laddr</i>	(Optional) inpcb laddr
<i>inpcb-tot-connect</i>	(Optional) inpcb connect
<i>inpcb-tot-disconnect</i>	(Optional) inpcb disconnect
<i>inpcb-tot-detach</i>	(Optional) inpcb detach
<i>inpcb-tot-detach-noinc</i>	(Optional) inpcb detaach no increment
<i>inpcb-tot-detach-rort</i>	(Optional) inpcb detach no return
<i>inpcb-tot-rtfree</i>	(Optional) inpcb rt free
<i>inpcb-tot-setsock-addr</i>	(Optional) inpcb set socket address
<i>inpcb-tot-setpeeraddr</i>	(Optional) inpcb set peer address
<i>inpcb-tot-notify</i>	(Optional) inpcb notify
<i>inpcb-tot-lookup-npacl-deny</i>	(Optional) inpcb lookup hash npacl deny
<i>inpcb-tot-lookup-npacl-allow</i>	(Optional) inpcb lookup npacl allow
<i>inpcb-tot-inshash-ipv4</i>	(Optional) inpcb inshash ipv4
<i>inpcb-tot-inshash-ipv6</i>	(Optional) inpcb inshash ipv6
<i>inpcb-tot-brehash-ipv4</i>	(Optional) inpcb brehash ipv4

<i>inpcb-tot-brehash-ipv6</i>	(Optional) inpcb brehash ipv6
<i>inpcb-tot-brehash</i>	(Optional) inpcb brehash
<i>inpcb-err-allocnomem</i>	(Optional) inpcb allocation no memory error
<i>inpcb-err-bindeinavl</i>	(Optional) inpcb bind inval error
<i>inpcb-err-eaddrinuse</i>	(Optional) inpcb eaddr in use error
<i>inpcb-err-eagain</i>	(Optional) inpcb eagain error
<i>inpcb-err-eagain2</i>	(Optional) inpcb eagain2 error
<i>inpcb-err-eaddrnotavail</i>	(Optional) inpcb eaddr not availableerror
<i>inpcb-err-eafnosupport</i>	(Optional) inpcb eaf no support error
<i>inpcb-err-enomem</i>	(Optional) inpcb no-memory error
<i>inpcb-err-ehostunreach</i>	(Optional) inpcb ehost unreachable error
<i>inpcb-err-laddr-enoio</i>	(Optional) inpcb laddr enxio error
<i>inpcb-err-laddr-ehostunreach2</i>	(Optional) inpcb laddr ehost unreachable2 error
<i>inpcb-err-connectladdr</i>	(Optional) inpcb connect laddr error
<i>inpcb-err-connect-eaddrinuse</i>	(Optional) inpcb connect eaddress in use error
<i>inpcb-err-connbind</i>	(Optional) inpcb connect bind error
<i>inpcb-err-sockaddrenomem</i>	(Optional) inpcb socket address no memory error
<i>inpcb-err-sockadreconnreset</i>	(Optional) inpcb socket address econnect reset error
<i>inpcb-err-peeraddr-enomem</i>	(Optional) inpcb peer address no memory error
<i>inpcb-err-econnrest</i>	(Optional) inpcb connection rest error
<i>inpcb-err-respond-enobufs</i>	(Optional) inpcb respond no buffer error
<i>inpcb-err-binshash-enobufs</i>	(Optional) inpcb binshash no buffer error
<i>in6pcb-tot-setport</i>	(Optional) in6pcb set port error
<i>in6pcb-tot-bind</i>	(Optional) in6pcb bind
<i>in6pcb-tot-laddr</i>	(Optional) in6pcb laddr
<i>in6pcb-tot-connect</i>	(Optional) in6pcb connect
<i>in6pcb-tot-disconnect</i>	(Optional) in6pcb disconnect
<i>in6pcb-tot-detach</i>	(Optional) in6pcb detach
<i>in6pcb-tot-sockaddr</i>	(Optional) in6pcb socket address

<i>in6pcb-tot-peeraddr</i>	(Optional) in6pcb peer address
<i>in6pcb-tot-notify</i>	(Optional) in6pcb notify
<i>in6pcb-tot-lookuplocal</i>	(Optional) in6pcb lookup local
<i>in6pcb-tot-hashnpacl-deny</i>	(Optional) in6pcb hash npacl deny
<i>in6pcb-err-setporteagain</i>	(Optional) in6pcb set port again error
<i>in6pcb-err-setporteagain2</i>	(Optional) in6pcb set port again2 error
<i>in6pcb-err-seteagain3</i>	(Optional) in6pcb set port again3 error
<i>in6pcb-bind-eafnosupport</i>	(Optional) in6pcb bind eaf no support error
<i>in6pcb-err-bindeaddrinuse</i>	(Optional) in6pcb bind address in use error
<i>in6pcb-err-bindeaddrinuse2</i>	(Optional) in6pcb bind address in use2 error
<i>in6pcb-err-bindeaddrinuse3</i>	(Optional) in6pcb bind address in use3 error
<i>in6pcb-err-bindeaddrinuse4</i>	(Optional) in6pcb bind address in use4 error
<i>in6pcb-err-bindsetport</i>	(Optional) in6pcb bind setport error
<i>in6pcb-err-bindeagain</i>	(Optional) in6pcb bind again error
<i>in6pcb-err-laddr-eafnosupport</i>	(Optional) in6pcb laddr eaf no support error
<i>in6pcb-err-eaddrnotavail</i>	(Optional) in6pcb address not available error
<i>in6pcb-err-laddr-enomem</i>	(Optional) in6pcb laddr no memory error
<i>in6pcb-err-laddr-ehostreach</i>	(Optional) in6pcb laddr host reach error
<i>in6pcb-err-laddr-ehostunreach2</i>	(Optional) in6pcb laddr host reach2 error
<i>in6pcb-err-laddr-ehostunreach3</i>	(Optional) in6pcb laddr host reach3 error
<i>in6pcb-err-laddr-ehostunreach4</i>	(Optional) in6pcb laddr host reach4 error
<i>in6pcb-err-laddr-enxio</i>	(Optional) in6pcb laddr enxio error
<i>in6pcb-err-connladdr</i>	(Optional) in6pcb connect laddr error
<i>in6pcb-err-conneaddrinuse</i>	(Optional) in6pcb connect eaddress in use error
<i>in6pcb-err-connbind</i>	(Optional) in6pcb connect bind error
<i>in6pcb-err-sockaddr-enomem</i>	(Optional) in6pcb socket address no memory error
<i>in6pcb-err-v4maps-enomem</i>	(Optional) in6pcb v4maps no memory error
<i>in6pcb-err-setsock-noinp</i>	(Optional) in6pcb set socket noinp error
<i>in6pcb-err-setpeer-noinp</i>	(Optional) in6pcb set peer noinp error

<i>in6pcb-err-sockaddr-noinp</i>	(Optional) in6pcb socket address noinp error
<i>in6pcb-err-peeraddr-noinp</i>	(Optional) in6pcb peer address noinp error
<i>in6pcb-err-notify-einavl</i>	(Optional) in6pcb notify egress available error
<i>in6pcb-err-ctloutput-nosoopt</i>	(Optional) in6pcb control output no socket opt error

Command Mode

- /exec

show sockets tcp keychain binding

```
show sockets tcp keychain binding [ __readonly__ { TABLE_keychain <keychain> <handle> <ref_count>
} ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
tcp	TCP information
keychain	Keychain information
binding	Binding information regarding RPM
<i>__readonly__</i>	(Optional)
<i>TABLE_keychain</i>	(Optional) all sockets tcp keychains
<i>keychain</i>	(Optional) xml keychain information
<i>handle</i>	(Optional) xml handle information
<i>ref_count</i>	(Optional) xml refcount information

Command Mode

- /exec

show spanning-tree

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] [ __readonly__ TABLE_tree <tree_id>
<tree_tree_type> <tree_protocol> <port_count> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> <stp_active> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdu_in>
<bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prestd> ] ] } | { show spanning-tree [ vlan <vlan-id> |
bridge-domain <bd-id> ] { <verbosity> | active } + [ __readonly__ TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <port_count> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> <stp_active> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> TABLE_port <if_index> <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdu_in>
<bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prestd> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
<i>verbosity</i>	verbosity
active	Report on active interfaces only
__readonly__	(Optional) Read Only

<i>TABLE_tree</i>	(Optional)
<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type
<i>tree_protocol</i>	(Optional) Tree Protocol
<i>port_count</i>	(Optional) Number of Ports in Tree
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_active</i>	(Optional) Spanning Tree State
<i>root_path_cost</i>	(Optional) Root Path Cost
<i>root_port_if_index</i>	(Optional) Root Port
<i>root_port_priority</i>	(Optional) Root Port Priority
<i>root_port_number</i>	(Optional) Root Port Number
<i>topology_change</i>	(Optional) Topology Change flag is set ?
<i>topology_change_detected</i>	(Optional) Topology Change detected flag is set ?
<i>topology_change_count</i>	(Optional) Topology Change Count
<i>topology_change_time_since_last</i>	(Optional) Time since last TC
<i>tc_initiator_if_index</i>	(Optional) Topology Change initiator port
<i>max_age</i>	(Optional) Max Age
<i>hello_time</i>	(Optional) Hello Time
<i>forward_delay</i>	(Optional) Forward delay
<i>bridge_max_age</i>	(Optional) Configured Bridge Max Age
<i>bridge_hello_time</i>	(Optional) Configured Hello Time
<i>bridge_forward_delay</i>	(Optional) Configured Forward Delay
<i>hold_time</i>	(Optional) Configured Hold Time
<i>hello_timer</i>	(Optional) Hello Timer Value
<i>topology_change_timer</i>	(Optional) Topology Change Timer Value
<i>tcn_timer</i>	(Optional) TCN Timer Value

<i>aging_timer</i>	(Optional) Ageing Timer Value
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>vpc</i>	(Optional) STP Port memembr of MCT/VPC PO
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>state</i>	(Optional) STP Port State
<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number
<i>port_protocol</i>	(Optional) Tree Protocol
<i>port_tree_type</i>	(Optional) Tree Type
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id
<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdus_in</i>	(Optional) BPDUs received on this stp port

<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?
<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer
<i>peer</i>	(Optional) STP protocol of the peer
<i>dispute</i>	(Optional) Is port Disputed ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>boundary</i>	(Optional) Is port boundary ?
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree blockedports

```
{ show spanning-tree [ vlan <vlan-id> ] blockedports [ __readonly__ [ TABLE_tree [ <port_info_tree_id> ]
[ TABLE_port [ <if_index> ] ] ] [ <tree_type> ] [ <num_ports> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
__readonly__	(Optional)
TABLE_tree	(Optional)
<i>port_info_tree_id</i>	(Optional) Tree name
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Port name
<i>tree_type</i>	(Optional) Tree Type
<i>num_ports</i>	(Optional) Number of Ports
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
blockedports	Show blocked ports

Command Mode

- /exec

show spanning-tree bridge

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] bridge [ priority [ system-id ] ][ __readonly__
{ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <bridge_mac> <bridge_priority>
<bridge_forward_delay> <bridge_max_age> <bridge_hello_time> } ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] bridge [ { detail | brief } ][ __readonly__ { TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <bridge_mac> <bridge_priority> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> } ] } | { show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] bridge [ { address
| forward-time | hello-time | id | max-age | protocol } ][ __readonly__ { TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <bridge_mac> <bridge_priority> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> } ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
bridge	Status and configuration of this bridge
address	(Optional) Mac address of this bridge
forward-time	(Optional) Forward delay interval
hello-time	(Optional) Hello time
id	(Optional) Spanning tree bridge identifier
max-age	(Optional) Max age
protocol	(Optional) Spanning tree protocol
brief	(Optional) Brief summary of the status and configuration output
detail	(Optional) Detailed of the status and configuration
priority	(Optional) Bridge priority of this bridge
system-id	(Optional) Spanning tree priority with system id extension
__readonly__	(Optional) Read Only
TABLE_tree	(Optional)
<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type

<i>tree_protocol</i>	(Optional) Tree Protocol
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>bridge_forward_delay</i>	(Optional) Configured Forward Delay
<i>bridge_max_age</i>	(Optional) Configured Bridge Max Age
<i>bridge_hello_time</i>	(Optional) Configured Hello Time

Command Mode

- /exec

show spanning-tree inconsistentports

```
{ show spanning-tree [ vlan <vlan-id> ] inconsistentports [ __readonly__ [ TABLE_tree <port_info_tree_id>
<if_index> <inconsistency> ] [ <tree_type> ] [ <num_ports> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
inconsistentports	Show inconsistent ports
<i>__readonly__</i>	(Optional)
TABLE_tree	(Optional)
<i>port_info_tree_id</i>	(Optional) Tree name
<i>if_index</i>	(Optional) Port name
<i>inconsistency</i>	(Optional) Inconsistency type
<i>tree_type</i>	(Optional) Tree Type
<i>num_ports</i>	(Optional) Number of Ports

Command Mode

- /exec

show spanning-tree interface

```
{ show spanning-tree [ vlan <vlan-id> ] interface <interface-id> { cost | inconsistency | edge | priority | rootcost
| state } [ __readonly__ [ TABLE_vlan_interface_info <tree_name> [ <cost> ] [ <edge> ] [ <inconsistency>
] [ <priority> ] [ <rootcost> ] [ <state> ] ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
interface	Spanning Tree interface status and configuration
<i>interface-id</i>	
cost	Port path cost
inconsistency	Port inconsistency state
edge	Edge Port configuration
priority	Port priority
rootcost	Path cost to root
state	Port spanning tree state
__readonly__	(Optional)
TABLE_vlan_interface_info	(Optional)
<i>tree_name</i>	(Optional) Spanning tree name
<i>cost</i>	(Optional) Path cost
<i>edge</i>	(Optional) Portfast enabled or not
<i>inconsistency</i>	(Optional) Port inconsistency
<i>priority</i>	(Optional) Port Priority
<i>rootcost</i>	(Optional) Designated Cost
<i>state</i>	(Optional) Port state

Command Mode

- /exec

show spanning-tree interface

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] interface <interface-id> [ __readonly__ {
TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role> <port_priority> <port_number>
<port_protocol> <port_tree_type> <path_cost> <port_designated_root> <port_designated_root_priority>
<designated_cost> <designated_bridge> <designated_bridge_priority> <designated_port> <tc_acknowledge>
<forward_transition_count> <self_looped> <inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type>
<port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard>
<oper_bpdufilter> <int_bpdufilter> <oper_networkport> <forward_delay_timer> <hold_timer> <message_age>
<peer> <dispute> <pvstsim_inc_timer> [ <boundary> ] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prest>
] ] ] } | { show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] interface <interface-id> { <verbosity>
| active } + [ __readonly__ { TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role>
<port_priority> <port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdus_in>
<bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> <oper_networkport>
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prest> ] ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
interface	Spanning Tree interface status and configuration
<i>interface-id</i>	
<i>verbosity</i>	verbosity
active	Report on active instances only
<u>__readonly__</u>	(Optional) Read Only
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>vpc</i>	(Optional) STP Port memembr of MCT/VPC PO
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>state</i>	(Optional) STP Port State

<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number
<i>port_protocol</i>	(Optional) Tree Protocol
<i>port_tree_type</i>	(Optional) Tree Type
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id
<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port
<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?

<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer
<i>peer</i>	(Optional) STP protocol of the peer
<i>dispute</i>	(Optional) Is port Disputed ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>boundary</i>	(Optional) Is port boundary ?
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree issu-impact

```
show spanning-tree issu-impact [ __readonly__ [ TABLE_topology <tc_detected> <tc_name> <no_of_tc>
<time> <tc_string> ] [ TABLE_BA_ports <port_name> ] [ <criteria1> ] [ <criteria2> ] [
TABLE_non_edge_ports <port> <vlan> <role> <sts> <tree> <instance> ] [ <criteria3> ] ]
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
issu-impact	Show whether STP meets ISSU criteria
<i>__readonly__</i>	(Optional)
<i>TABLE_topology</i>	(Optional)
<i>tc_detected</i>	(Optional)
<i>tc_name</i>	(Optional)
<i>no_of_tc</i>	(Optional)
<i>time</i>	(Optional)
<i>tc_string</i>	(Optional)
<i>TABLE_BA_ports</i>	(Optional)
<i>port_name</i>	(Optional)
<i>TABLE_non_edge_ports</i>	(Optional)
<i>port</i>	(Optional)
<i>vlan</i>	(Optional)
<i>role</i>	(Optional)
<i>sts</i>	(Optional)
<i>tree</i>	(Optional)
<i>instance</i>	(Optional)
<i>criteria1</i>	(Optional)
<i>criteria2</i>	(Optional)
<i>criteria3</i>	(Optional)

Command Mode

- /exec

show spanning-tree mst

```
{ show spanning-tree mst [ <mst-id> ] [ __readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol>
<port_count> <bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority>
<stp_active> <root_path_cost> <root_port_if_index> <root_port_priority> <root_port_number>
<topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> <ist-master-id-mac> <ist-master-prio> <ist-path-cost> <remaining-hops> <max-hops>
<txholdcount> <tree-vlan-map> TABLE_port <if_index> <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdu_in>
<bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> <boundary>
[ <simulate_pvst_cfg> ] <simulate_pvst> <prest> [ <designated_ist_master> ] [
<designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ] } { show spanning-tree mst
[ <mst-id> ] detail [ __readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <port_count>
<bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority> <stp_active>
<root_path_cost> <root_port_if_index> <root_port_priority> <root_port_number> <topology_change>
<topology_change_detected> <topology_change_count> <topology_change_time_since_last>
<tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age> <bridge_hello_time> <max_age>
<hello_time> <forward_delay> <hold_time> <hello_timer> <topology_change_timer> <tcn_timer>
<aging_timer> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <ist-master-id-mac>
<ist-master-prio> <ist-path-cost> <remaining-hops> <max-hops> <txholdcount> <tree-vlan-map> TABLE_port
<if_index> <port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol>
<port_tree_type> <path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost>
<designated_bridge> <designated_bridge_priority> <designated_port> <tc_acknowledge>
<forward_transition_count> <self_looped> <inconsistency> <bpdu_in> <bpdu_out> <port_fast> <link_type>
<port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard>
<oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ] <forward_delay_timer> <hold_timer>
<message_age> <peer> <dispute> <pvstsim_inc_timer> <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst>
<prest> [ <designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [
<vlan-map> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
<i>mst-id</i>	(Optional) MST instance range, example: 0-3,5,7-9
detail	Detailed information
<u>__readonly__</u>	(Optional) Read Only
TABLE_tree	(Optional)

<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type
<i>tree_protocol</i>	(Optional) Tree Protocol
<i>port_count</i>	(Optional) Number of Ports in Tree
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_active</i>	(Optional) Spanning Tree State
<i>root_path_cost</i>	(Optional) Root Path Cost
<i>root_port_if_index</i>	(Optional) Root Port
<i>root_port_priority</i>	(Optional) Root Port Priority
<i>root_port_number</i>	(Optional) Root Port Number
<i>topology_change</i>	(Optional) Topology Change flag is set ?
<i>topology_change_detected</i>	(Optional) Topology Change detected flag is set ?
<i>topology_change_count</i>	(Optional) Topology Change Count
<i>topology_change_time_since_last</i>	(Optional) Time since last TC
<i>tc_initiator_if_index</i>	(Optional) Topology Change initiator port
<i>max_age</i>	(Optional) Max Age
<i>hello_time</i>	(Optional) Hello Time
<i>forward_delay</i>	(Optional) Forward delay
<i>bridge_max_age</i>	(Optional) Configured Bridge Max Age
<i>bridge_hello_time</i>	(Optional) Configured Hello Time
<i>bridge_forward_delay</i>	(Optional) Configured Forward Delay
<i>hold_time</i>	(Optional) Configured Hold Time
<i>hello_timer</i>	(Optional) Hello Timer Value
<i>topology_change_timer</i>	(Optional) Topology Change Timer Value
<i>tcn_timer</i>	(Optional) TCN Timer Value
<i>aging_timer</i>	(Optional) Ageing Timer Value

<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>ist-master-id-mac</i>	(Optional) IST Master ID MAC address
<i>ist-master-prio</i>	(Optional) IST Master ID priority
<i>ist-path-cost</i>	(Optional) IST path cost
<i>remaining-hops</i>	(Optional) Remaining hops
<i>max-hops</i>	(Optional) Max Hops
<i>txholdcount</i>	(Optional) TX Hold count
<i>tree-vlan-map</i>	(Optional) Bitmap of vlans mapped to tree
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>state</i>	(Optional) STP Port State
<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>port_tree_type</i>	(Optional) Tree Type
<i>port_protocol</i>	(Optional) Tree Protocol
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id

<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port
<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?
<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer
<i>peer</i>	(Optional) STP protocol of the peer
<i>boundary</i>	(Optional) Is port boundary ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>dispute</i>	(Optional) Is port Disputed ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>designated_ist_master</i>	(Optional) Ist master mac
<i>designated_ist_master_priority</i>	(Optional) Ist master priority
<i>designated_ist_cost</i>	(Optional) Ist master path cost

<i>vlan-map</i>	(Optional) Bitmap of vlans mapped to port
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree mst configuration

```
{ show spanning-tree mst configuration [ __readonly__ <stp-mode> <name> <rev-id> {
TABLE_instance_to_vlan_map <mst_id> <vlan_bit_map> } [ <pvlan-sync> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
configuration	MST current region configuration
<i>__readonly__</i>	(Optional) Read Only
<i>stp-mode</i>	(Optional) Spanning Tree operating mode
<i>name</i>	(Optional) Configuration name
<i>rev-id</i>	(Optional) Configuration revision number
TABLE_instance_to_vlan_map	(Optional) Instance to vlan mapping Info
<i>mst_id</i>	(Optional) MST Instance ID
<i>vlan_bit_map</i>	(Optional) VLAN Bitmap
<i>pvlan-sync</i>	(Optional) pvlan synchronization

Command Mode

- /exec

show spanning-tree mst configuration digest

```
{ show spanning-tree mst configuration digest [ __readonly__ <stp-mode> <name> <rev-id> <digest>
<prestd-digest> [ <pvlan-sync> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
configuration	MST current region configuration
digest	Display MST configuration digest
<i>__readonly__</i>	(Optional) Read Only
<i>stp-mode</i>	(Optional) Spanning Tree operating mode
<i>name</i>	(Optional) Configuration name
<i>rev-id</i>	(Optional) Configuration revision number
<i>digest</i>	(Optional) MST region configuration digest
<i>prestd-digest</i>	(Optional) MST region configuration pre-std digest
<i>pvlan-sync</i>	(Optional) pvlan synchronization

Command Mode

- /exec

show spanning-tree mst interface

```
{ show spanning-tree mst [ <mst-id> ] interface <interface-id> [ __readonly__ TABLE_port <if_index>
<port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol> <port_tree_type>
<path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost> <designated_bridge>
<designated_bridge_priority> <designated_port> <tc_acknowledge> <forward_transition_count> <self_looped>
<inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter>
<oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [
<oper_networkport> ] <forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> [
<pvstsim_inc_timer> ] <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst> <prest> [
<designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ]
} | { show spanning-tree mst [ <mst-id> ] interface <interface-id> detail [ __readonly__ TABLE_port <if_index>
<port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol> <port_tree_type>
<path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost> <designated_bridge>
<designated_bridge_priority> <designated_port> <tc_acknowledge> <forward_transition_count> <self_looped>
<inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter>
<oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [
<oper_networkport> ] <forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> [
<pvstsim_inc_timer> ] <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst> <prest> [
<designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ]
}
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
<i>mst-id</i>	(Optional) MST instance range, example: 0-3,5,7-9
interface	Spanning Tree interface status and configuration
<i>interface-id</i>	Specify an interface as a target for the command
detail	Detailed information
__readonly__	(Optional) Read Only
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>state</i>	(Optional) STP Port State
<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number

<i>port_tree_type</i>	(Optional) Tree Type
<i>port_protocol</i>	(Optional) Tree Protocol
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id
<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port
<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?
<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer

<i>peer</i>	(Optional) STP protocol of the peer
<i>boundary</i>	(Optional) Is port boundary ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>dispute</i>	(Optional) Is port Disputed ?
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>designated_ist_master</i>	(Optional) Ist master mac
<i>designated_ist_master_priority</i>	(Optional) Ist master priority
<i>designated_ist_cost</i>	(Optional) Ist master path cost
<i>vlan-map</i>	(Optional) Bitmap of vlans mapped to port
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree pathcost method

```
{ show spanning-tree pathcost method [ __readonly__ <stp-pathcost-method> [ <stp-operpathcost-method> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
pathcost	Show Spanning pathcost options
method	Default pathcost calculation method
<i>__readonly__</i>	(Optional)
<i>stp-pathcost-method</i>	(Optional) STP Pathcost Method
<i>stp-operpathcost-method</i>	(Optional) STP Pathcost Method

Command Mode

- /exec

show spanning-tree root

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] root [ priority [ system-id ] ] [ __readonly__
TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <tree_designated_root>
<tree_designated_root_priority> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <max_age> <hello_time> <forward_delay> ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] root [ { address | cost | forward-time | hello-time | id | max-age | port } ] [
__readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <tree_designated_root>
<tree_designated_root_priority> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <max_age> <hello_time> <forward_delay> ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] root [ { detail | brief } ] [ __readonly__ TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <tree_designated_root> <tree_designated_root_priority> <root_path_cost>
<root_port_if_index> <root_port_priority> <root_port_number> <max_age> <hello_time> <forward_delay>
] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
root	Status and configuration of the root bridge
address	(Optional) Mac address of this bridge
cost	(Optional) Path cost from this bridge to the root
forward-time	(Optional) Forward delay interval
hello-time	(Optional) Hello time
id	(Optional) Spanning tree bridge identifier
max-age	(Optional) Max age
port	(Optional) Root port
brief	(Optional) Brief summary of interface information
detail	(Optional) Detailed information
priority	(Optional) Bridge priority of this bridge
system-id	(Optional) Spanning tree priority with system id extension
__readonly__	(Optional) Read Only

TABLE_tree	(Optional)
<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type
<i>tree_protocol</i>	(Optional) Tree Protocol
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>root_path_cost</i>	(Optional) Root Path Cost
<i>root_port_if_index</i>	(Optional) Root Port
<i>root_port_priority</i>	(Optional) Root Port Priority
<i>root_port_number</i>	(Optional) Root Port Number
<i>max_age</i>	(Optional) Max Age
<i>hello_time</i>	(Optional) Hello Time
<i>forward_delay</i>	(Optional) Forward delay

Command Mode

- /exec

show spanning-tree summary

```
show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] summary [ __readonly__ <stp-mode> [
<stp_tree_root_info> <tree_type> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> ] + [ <stp_root_bmp_info> <stp_root_tree_type> <tree_root_bmp>
<stp_l2gstp_bmp_info> <stp_l2gstp_tree_type> [ <stp_l2gstp_bmp> ] ] <stp_global_info> <pcost_method>
<oper_pcost_method> <port_fast> <bpdu_guard> <bpdu_filter> <oper_loopguard> <bridge_assurance>
<networkport_default> <simulate_pvst> <max-hops> <peer_switch_cfg> <oper_peer_switch>
<stp_l2gstp_domain_id> <stp_lite> [ TABLE_tree <stp_tree_summary> <summary_tree_type> <disabled>
<blocking> <listening> <learning> <forwarding> <invalid> <port_count> ] [ <stp_summary_totals>
<total_tree_type> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <port_count> ] ]
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
summary	Summary of port states
<i>__readonly__</i>	(Optional) Read Only
<i>stp-mode</i>	(Optional) Spanning Tree operating mode
<i>stp_tree_root_info</i>	(Optional) STP Tree Root info marker
<i>tree_type</i>	(Optional) Tree Type
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_root_bmp_info</i>	(Optional) STP root bitmap info marker
<i>stp_root_tree_type</i>	(Optional) Tree Type
<i>tree_root_bmp</i>	(Optional) STP tree root bmp
<i>stp_l2gstp_bmp_info</i>	(Optional) L2 Gateway STP bitmap marker
<i>stp_l2gstp_tree_type</i>	(Optional) Tree Type
<i>stp_l2gstp_bmp</i>	(Optional) L2 Gateway STP bitmap

<i>stp_global_info</i>	(Optional) STP global info marker
<i>pcost_method</i>	(Optional) STP pathcost method
<i>oper_pcost_method</i>	(Optional) STP oper pathcost method
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>bridge_assurance</i>	(Optional) Bridge Assurance
<i>networkport_default</i>	(Optional) Network Port default
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>max-hops</i>	(Optional) Max Hops
<i>peer_switch_cfg</i>	(Optional) peer switch configuration status
<i>oper_peer_switch</i>	(Optional) peer switch operational status
<i>stp_l2gstp_domain_id</i>	(Optional) L2 Gateway STP Domain ID
<i>stp_lite</i>	(Optional) STP-Lite
TABLE_tree	(Optional)
<i>stp_tree_summary</i>	(Optional) STP Tree Summary
<i>summary_tree_type</i>	(Optional) Tree Type
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>port_count</i>	(Optional) Number of Ports in Tree
<i>stp_summary_totals</i>	(Optional) Total num STP trees
<i>total_tree_type</i>	(Optional) Tree Type
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking

<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>port_count</i>	(Optional) Number of Ports in Tree

Command Mode

- /exec

show spanning-tree summary totals

```
show spanning-tree summary totals [ __readonly__ <stp-mode> <stp_tree_root_info> <tree_type>
<bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority> <stp_root_bmp_info>
<stp_root_tree_type> <tree_root_bmp> <stp_l2gstp_bmp_info> <stp_l2gstp_tree_type> <stp_l2gstp_bmp>
<stp_global_info> <pcost_method> <oper_pcost_method> <port_fast> <bpdu_guard> <bpdu_filter>
<oper_loopguard> <bridge_assurance> <networkport_default> <simulate_pvst> <max-hops>
<peer_switch_cfg> <oper_peer_switch> <stp_l2gstp_domain_id> <stp_lite> <stp_summary_totals>
<total_tree_type> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <port_count> ]
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
summary	Summary of port states
totals	Only show totals
<i>__readonly__</i>	(Optional) Read Only
<i>stp-mode</i>	(Optional) Spanning Tree operating mode
<i>stp_tree_root_info</i>	(Optional) STP Tree Root info marker
<i>tree_type</i>	(Optional) Tree Type
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_root_bmp_info</i>	(Optional) STP root bitmap info marker
<i>stp_root_tree_type</i>	(Optional) Tree Type
<i>tree_root_bmp</i>	(Optional) STP tree root bmp
<i>stp_l2gstp_bmp_info</i>	(Optional) L2 Gateway STP bitmap marker
<i>stp_l2gstp_tree_type</i>	(Optional) Tree Type
<i>stp_l2gstp_bmp</i>	(Optional) L2 Gateway STP bitmap
<i>stp_global_info</i>	(Optional) STP global info marker
<i>pcost_method</i>	(Optional) STP pathcost method
<i>oper_pcost_method</i>	(Optional) STP oper pathcost method
<i>port_fast</i>	(Optional) Port Fast configured on port

<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>bridge_assurance</i>	(Optional) Bridge Assurance
<i>networkport_default</i>	(Optional) Network Port default
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>max-hops</i>	(Optional) Max Hops
<i>peer_switch_cfg</i>	(Optional) peer switch configuration status
<i>oper_peer_switch</i>	(Optional) peer switch operational status
<i>stp_l2gstp_domain_id</i>	(Optional) L2 Gateway STP Domain ID
<i>stp_lite</i>	(Optional) STP-Lite
<i>stp_summary_totals</i>	(Optional) Total num STP trees
<i>total_tree_type</i>	(Optional) Tree Type
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>port_count</i>	(Optional) Number of Ports in Tree

Command Mode

- /exec

show sprom

```

show sprom { backplane <i0> | module <module> <i1> | xbar <santa-cruz-range> <i2> | powersupply <i3>
| fan <i4> | sup | stby-sup | all | all2 | backplane2 | module2 <module2> | powersupply2 <i5> | sup2 } [
__readonly__ [ cmn_block { <blk_sig_cb> <blk_ver_cb> <blk_length_cb> <blk_checksum_cb> <eeprom_size>
<blk_count> <fru_major_type> <fru_minor_type> <oem_string> <prd_num> <serial_num> <part_num>
<part_rev> <mfg_dev> <hw_rev> <mfg_bits> <eng_use> <snmp_oid> <power_consump> <rma_code>
<clei_code> <vid> } ] [ sup_specific_block { <blk_sig_ssb> <blk_ver_ssb> <blk_length_ssb>
<blk_checksum_ssb> <feature_bits> <hw_changes_bits> <card_index> <mac_addresses> <no_of_macs>
<no_of_epld> [ TABLE_epld_ssb <epld_name_ssb> <epld_ver_ssb> ] <port_type_num> { TABLE_sensor_ssb
<sensor_num_ssb> <maj_thres_ssb> <min_thres_ssb> } <max_connector_power> <cooling_req> <amb_temp>
} ] [ lc_specific_block { <blk_sig_lc> <blk_ver_lc> <blk_length_lc> <blk_checksum_lc> <feature_bits>
<hw_changes_bits> <card_index> <mac_addresses> <no_of_macs> <no_of_epld> [ TABLE_epld_lc
<epld_name_lc> <epld_ver_lc> ] <port_type_num> { TABLE_sensor_lc <sensor_num_lc> <maj_thres_lc>
<min_thres_lc> } <max_connector_power> <cooling_req> <amb_temp> } ] [ ps_specific_block {
<blk_sig_psb> <blk_ver_psb> <blk_length_psb> <blk_checksum_psb> <feature_bits> <current_110v>
<current_220v> <stackmib_oid> } ] [ fan_specific_block { <blk_sig_fsb> <blk_ver_fsb> <blk_length_fsb>
<blk_checksum_fsb> <feature_bits> <hw_change_bits> <stackmib_oid> <cooling_capacity> <amb_temp>
} ] [ ch_specific_block { <blk_sig_csb> <blk_ver_csb> <blk_length_csb> <blk_checksum_csb> <feature_bits>
<hw_changes_bits> <stackmib_oid> <mac_addresses> <no_of_macs> <oem_enterprise> <oem_mib_offset>
<max_connector_power> } ] [ temp_sensor_block { <blk_sig_tsb> <blk_ver_tsb> <blk_length_tsb>
<blk_checksum_tsb> <no_of_sensors> { TABLE_sensor_tsb <sensor_num_tsb> <maj_thres_tsb>
<min_thres_tsb> } } ] [ wwn_specific_block { <blk_sig_wwnb> <blk_ver_wwnb> <blk_length_wwnb>
<blk_checksum_wwnb> { TABLE_wwn_usage_wsb <wwn_usage_bits> } } ] [ lic_specific_block {
<blk_sig_licb> <blk_ver_licb> <blk_length_licb> <blk_checksum_licb> { TABLE_lic_usage_lsb
<lic_usage_bits> } } ] [ second_serial_block { <blk_sig_sn2b> <blk_ver_sn2b> <blk_length_sn2b>
<blk_checksum_sn2b> <serial_num_sn2b> } ] [ psu_common_block { <format_version> <internal_info_offset>
<chassis_info_offset> <board_info_offset> <product_info_offset> <multirecord_info_offset> <checksum>
} ] [ psu_board_info_block { <format_version> <length> <language_code> <mfg_date> <mfg_type>
<mfg_info> <name_type> <product_name> <snum_type> <snum> <part_type> <partnum> <fruid_type>
<fruid> <bom_hw_pid_info> <partnum_rev> <fab_revision> <vid> <clei_len> <clei> <eof_marker> <csum>
} ] [ psu_product_info_block { <format_version> <length> <language_code> <mfg_type> <mfg_info>
<name_type> <product_name> <part_type> <partnum> <product_ver_type> <sw_certification> <snum_type>
<snum> <asset_type> <asset_string> <fruid_type> <fruid> <partnumrev> <vid> <eof_marker> <csum> } ]
[ psu_record_info_block { <record_type> <record_info> <record_len> <record_csum> <header_csum>
<record_identifier> <format_ver> <standby_pwr_budget> <psu_class> <psu_watts> } ] ]

```

Syntax Description

show	Show running system information
sprom	show SPROM contents
backplane	show backplane clock module sprom contents
<i>i0</i>	please enter instance of backplane sprom
module	show linecard module sprom contents
<i>module</i>	please enter module number
<i>i1</i>	please enter instance of module sprom

xbar	show xbar fabric sprom contents
<i>santa-cruz-range</i>	please enter the xbar number
<i>i2</i>	please enter sprom instance number
powersupply	show powersupply sprom contents
<i>i3</i>	please enter powersupply number
fan	show fan module sprom contents
<i>i4</i>	please enter fan number
sup	show supervisor sprom contents
stby-sup	show standby supervisor sprom contents
all	show all sproms contents
all2	All sprom contents
backplane2	Backplane sprom contents
module2	Linecard sprom contents
<i>module2</i>	Linecard module number
powersupply2	Powersupply sprom contents
<i>i5</i>	Powersupply module number
sup2	Supervisor sprom contents
<i>__readonly__</i>	(Optional)
<i>cmn_block</i>	(Optional)
<i>blk_sig_cb</i>	(Optional)
<i>blk_ver_cb</i>	(Optional)
<i>blk_length_cb</i>	(Optional)
<i>blk_checksum_cb</i>	(Optional)
<i>eprom_size</i>	(Optional)
<i>blk_count</i>	(Optional)
<i>fru_major_type</i>	(Optional)
<i>fru_minor_type</i>	(Optional)
<i>oem_string</i>	(Optional)
<i>prd_num</i>	(Optional)

<i>serial_num</i>	(Optional)
<i>part_num</i>	(Optional)
<i>part_rev</i>	(Optional)
<i>mfg_dev</i>	(Optional)
<i>hw_rev</i>	(Optional)
<i>mfg_bits</i>	(Optional)
<i>eng_use</i>	(Optional)
<i>snmp_oid</i>	(Optional)
<i>power_consump</i>	(Optional)
<i>rma_code</i>	(Optional)
<i>clei_code</i>	(Optional)
<i>vid</i>	(Optional)
<i>ch_specific_block</i>	(Optional)
<i>blk_sig_csb</i>	(Optional)
<i>blk_ver_csb</i>	(Optional)
<i>blk_length_csb</i>	(Optional)
<i>blk_checksum_csb</i>	(Optional)
<i>feature_bits</i>	(Optional)
<i>hw_changes_bits</i>	(Optional)
<i>stackmib_oid</i>	(Optional)
<i>mac_addresses</i>	(Optional)
<i>no_of_macs</i>	(Optional)
<i>oem_enterprise</i>	(Optional)
<i>oem_mib_offset</i>	(Optional)
<i>max_connector_power</i>	(Optional)
<i>sup_specific_block</i>	(Optional)
<i>blk_sig_ssb</i>	(Optional)
<i>blk_ver_ssb</i>	(Optional)
<i>blk_length_ssb</i>	(Optional)

<i>blk_checksum_ssb</i>	(Optional)
<i>feature_bits</i>	(Optional)
<i>hw_changes_bits</i>	(Optional)
<i>card_index</i>	(Optional)
<i>mac_addresses</i>	(Optional)
<i>no_of_macs</i>	(Optional)
<i>no_of_epld</i>	(Optional)
TABLE_epld_ssb	(Optional)
<i>epld_name_ssb</i>	(Optional)
<i>epld_ver_ssb</i>	(Optional)
<i>port_type_num</i>	(Optional)
TABLE_sensor_ssb	(Optional)
<i>sensor_num_ssb</i>	(Optional)
<i>maj_thres_ssb</i>	(Optional)
<i>min_thres_ssb</i>	(Optional)
<i>max_connector_power</i>	(Optional)
<i>cooling_reqt</i>	(Optional)
<i>amb_temp</i>	(Optional)
lc_specific_block	(Optional)
<i>blk_sig_lc</i>	(Optional)
<i>blk_ver_lc</i>	(Optional)
<i>blk_length_lc</i>	(Optional)
<i>blk_checksum_lc</i>	(Optional)
<i>feature_bits</i>	(Optional)
<i>hw_changes_bits</i>	(Optional)
<i>card_index</i>	(Optional)
<i>mac_addresses</i>	(Optional)
<i>no_of_macs</i>	(Optional)
<i>no_of_epld</i>	(Optional)

TABLE_epld_lc	(Optional)
<i>epld_name_lc</i>	(Optional)
<i>epld_ver_lc</i>	(Optional)
<i>port_type_num</i>	(Optional)
TABLE_sensor_lc	(Optional)
<i>sensor_num_lc</i>	(Optional)
<i>maj_thres_lc</i>	(Optional)
<i>min_thres_lc</i>	(Optional)
<i>max_connector_power</i>	(Optional)
<i>cooling_reqt</i>	(Optional)
<i>amb_temp</i>	(Optional)
ps_specific_block	(Optional)
<i>blk_sig_psb</i>	(Optional)
<i>blk_ver_psb</i>	(Optional)
<i>blk_length_psb</i>	(Optional)
<i>blk_checksum_psb</i>	(Optional)
<i>feature_bits</i>	(Optional)
<i>current_110v</i>	(Optional)
<i>current_220v</i>	(Optional)
<i>stackmib_oid</i>	(Optional)
fan_specific_block	(Optional)
<i>blk_sig_fsb</i>	(Optional)
<i>blk_ver_fsb</i>	(Optional)
<i>blk_length_fsb</i>	(Optional)
<i>blk_checksum_fsb</i>	(Optional)
<i>feature_bits</i>	(Optional)
<i>hw_change_bits</i>	(Optional)
<i>stackmib_oid</i>	(Optional)
<i>cooling_capacity</i>	(Optional)

<i>amb_temp</i>	(Optional)
temp_sensor_block	(Optional)
<i>blk_sig_tsb</i>	(Optional)
<i>blk_ver_tsb</i>	(Optional)
<i>blk_length_tsb</i>	(Optional)
<i>blk_checksum_tsb</i>	(Optional)
<i>no_of_sensors</i>	(Optional)
TABLE_sensor_tsb	(Optional)
<i>sensor_num_tsb</i>	(Optional)
<i>maj_thres_tsb</i>	(Optional)
<i>min_thres_tsb</i>	(Optional)
wwn_specific_block	(Optional)
<i>blk_sig_wwnb</i>	(Optional)
<i>blk_ver_wwnb</i>	(Optional)
<i>blk_length_wwnb</i>	(Optional)
<i>blk_checksum_wwnb</i>	(Optional)
TABLE_wwn_usage_wsb	(Optional)
<i>wwn_usage_bits</i>	(Optional)
lic_specific_block	(Optional)
<i>blk_sig_licb</i>	(Optional)
<i>blk_ver_licb</i>	(Optional)
<i>blk_length_licb</i>	(Optional)
<i>blk_checksum_licb</i>	(Optional)
TABLE_lic_usage_lsb	(Optional)
<i>lic_usage_bits</i>	(Optional)
second_serial_block	(Optional)
<i>blk_sig_sn2b</i>	(Optional)
<i>blk_ver_sn2b</i>	(Optional)
<i>blk_length_sn2b</i>	(Optional)

<i>blk_checksum_sn2b</i>	(Optional)
<i>serial_num_sn2b</i>	(Optional)
<i>psu_common_block</i>	(Optional)
<i>format_version</i>	(Optional)
<i>internal_info_offset</i>	(Optional)
<i>chassis_info_offset</i>	(Optional)
<i>board_info_offset</i>	(Optional)
<i>product_info_offset</i>	(Optional)
<i>multirecord_info_offset</i>	(Optional)
<i>checksum</i>	(Optional)
<i>psu_board_info_block</i>	(Optional)
<i>format_version</i>	(Optional)
<i>length</i>	(Optional)
<i>language_code</i>	(Optional)
<i>mfg_date</i>	(Optional)
<i>mfg_type</i>	(Optional)
<i>mfg_info</i>	(Optional)
<i>name_type</i>	(Optional)
<i>product_name</i>	(Optional)
<i>snum_type</i>	(Optional)
<i>snum</i>	(Optional)
<i>part_type</i>	(Optional)
<i>partnum</i>	(Optional)
<i>fruid_type</i>	(Optional)
<i>fruid</i>	(Optional)
<i>bom_hw_pid_info</i>	(Optional)
<i>partnum_rev</i>	(Optional)
<i>fab_revision</i>	(Optional)
<i>vid</i>	(Optional)

<i>clei_len</i>	(Optional)
<i>clei</i>	(Optional)
<i>eof_marker</i>	(Optional)
<i>csum</i>	(Optional)
psu_product_info_block	(Optional)
<i>format_version</i>	(Optional)
<i>length</i>	(Optional)
<i>language_code</i>	(Optional)
<i>mfg_type</i>	(Optional)
<i>mfg_info</i>	(Optional)
<i>name_type</i>	(Optional)
<i>product_name</i>	(Optional)
<i>part_type</i>	(Optional)
<i>partnum</i>	(Optional)
<i>product_ver_type</i>	(Optional)
<i>sw_certification</i>	(Optional)
<i>snum_type</i>	(Optional)
<i>snum</i>	(Optional)
<i>asset_type</i>	(Optional)
<i>asset_string</i>	(Optional)
<i>fruid_type</i>	(Optional)
<i>fruid</i>	(Optional)
<i>partnumrev</i>	(Optional)
<i>vid</i>	(Optional)
<i>eof_marker</i>	(Optional)
<i>csum</i>	(Optional)
psu_record_info_block	(Optional)
<i>record_type</i>	(Optional)
<i>record_info</i>	(Optional)

<i>record_len</i>	(Optional)
<i>record_csum</i>	(Optional)
<i>header_csum</i>	(Optional)
<i>record_identifier</i>	(Optional)
<i>format_ver</i>	(Optional)
<i>standby_pwr_budget</i>	(Optional)
<i>psu_class</i>	(Optional)
<i>psu_watts</i>	(Optional)

Command Mode

- /exec

show srte pce ipv4 peer

```
show srte pce ipv4 peer [ <pce_address> ] [ __readonly__ [ TABLE_peer <pcc_address> <pce_address>
<precedence> <state> ] ]
```

Syntax Description

show	Show running system information
srte	Show Segment-Routing Traffic Eng commands
pce	Show PCC related information
ipv4	Show ipv4 pcc information
peer	Show PCE peers
<i>pce_address</i>	(Optional) PCE address of the peer
<i>__readonly__</i>	(Optional)
TABLE_peer	(Optional) Table with a list of peers
<i>pcc_address</i>	(Optional) Address of the PCC
<i>pce_address</i>	(Optional) Address of the PCE
<i>precedence</i>	(Optional) Configured precedence of the PCE
<i>state</i>	(Optional) State of the PCE connection

Command Mode

- /exec

show srte policy

```
show srte policy [ { <policy_name_val> } | { color <color_val> endpoint <end_point_val> } | { policy-id
<policy_id_val> } ] [ holddown ] [ detail ] [ __readonly__ [ TABLE_policy <policy_name> <source>
<end_point> <state> <col> <binding_label> <policy_id> [ <flags> ] [ <holddown_time> ] [ TABLE_pref
<pref> [ TABLE_paths <exp_path_name> <deleg_pce_addr> [ TABLE_index <index> <label> ] ] ] ] ]
```

Syntax Description

show	Show running system information
srte	Show Segment-Routing Traffic Eng commands
policy	Show existing policies
color	(Optional) Show policies with the color
endpoint	(Optional) Show Policies with the destination
<i>end_point_val</i>	(Optional) Endpoint for the policy
<i>policy_name_val</i>	(Optional) Policy name of the policy
<i>color_val</i>	(Optional) Color of the policy
<i>policy_id_val</i>	(Optional) Policy_id of the policy
policy-id	(Optional) Show Policy for the policy-id
holddown	(Optional) Show Policies that are in holddown
detail	(Optional) Display detailed information
__readonly__	(Optional)
TABLE_policy	(Optional) Table with a list of policies
<i>policy_name</i>	(Optional) Unique name for the policy
<i>end_point</i>	(Optional) Endpoint for the policy
<i>source</i>	(Optional) Source address of the policy
<i>state</i>	(Optional) State of the policy
<i>col</i>	(Optional) Color of the policy
<i>binding_label</i>	(Optional) Binding label of the policy
<i>policy_id</i>	(Optional) Policy ID
<i>flags</i>	(Optional) Policy Flags
<i>holddown_time</i>	(Optional) Time when the policy was put in holddown

TABLE_pref	(Optional) Table with a list of candidate path based on pref
<i>pref</i>	(Optional) Preference for candidate paths
TABLE_paths	(Optional) Table with a list of exp path for pref
<i>exp_path_name</i>	(Optional) Name of the explicit-path
<i>deleg_pce_addr</i>	(Optional) Delegated PCE Address
TABLE_index	(Optional) Table with a list of index for the exp path
<i>index</i>	(Optional) Index for the explicit path
<i>label</i>	(Optional) Label for the explicit path

Command Mode

- /exec

show srte policy fh

show srte policy fh

Syntax Description

show	Show running system information
srte	Show Segment-Routing Traffic Eng commands
policy	Show existing policies
fh	Show existing policies firsthop state

Command Mode

- /exec

show ssh key

```
show ssh key [ { dsa [ md5 ] | rsa [ md5 ] | ecdsa [ [ md5 ] } ] [ __readonly__ { TABLE_sessions <key_type>
<key_time> <key_data> <key_bitcount> <key_fingerprint> } ]
```

Syntax Description

show	Show running system information
ssh	Show SSH information
key	Show ssh keys
dsa	(Optional) Show dsa ssh keys
rsa	(Optional) Show rsa ssh keys
ecdsa	(Optional) Show ecdsa ssh keys
md5	(Optional) Show Fingerprint in MD5 Format
__readonly__	(Optional)
TABLE_sessions	(Optional) ssh key
<i>key_type</i>	(Optional) keys type
<i>key_time</i>	(Optional) timestamp
<i>key_data</i>	(Optional) ssh key data
<i>key_bitcount</i>	(Optional) bitcount
<i>key_fingerprint</i>	(Optional) fingerprint

Command Mode

- /exec

show ssh server

```
show ssh server [ __readonly__ { operation_status <o_status> } ]
```

Syntax Description

show	Show running system information
ssh	Show SSH information
server	Show whether ssh server is enabled or not
<i>__readonly__</i>	(Optional)
<i>operation_status</i>	(Optional) run-time information about ssh
<i>o_status</i>	(Optional) operational status of ssh server

Command Mode

- /exec

show ssx details

```
show ssx details [ __readonly__ [ TABLE_ssx_details  
<arp-timer-running><asic-instance><asic-slice><io-srcid> [ <packets-sent> ] ] ]
```

Syntax Description

ssx	Display SSX information
details	Show SSX details
__readonly__	(Optional) Read Only
TABLE_ssx_details	(Optional) SSX details table

Command Mode

- /exec

show ssx exporter

```
show ssx exporter { all | <exportername> } [ __readonly__ [ TABLE_ssx_exporters <exporter-name>
<src-ip><src-udp-port><dest-ip><dest-udp-port><vrf><mtu><dscp> ] ]
```

Syntax Description

ssx	Display SSX information
exporter	Show exporter details
all	All sessions
<i>exportername</i>	SSX Exporter to display
__readonly__	(Optional) Read Only
TABLE_ssx_exporters	(Optional) SSX Exporters table

Command Mode

- /exec

show ssx monitor

```
show ssx monitor { all | <monitorname> } [ __readonly__ [ TABLE_ssx_monitors <monitor-name>
<globally-applied><status><exportername><recordname> ] ]
```

Syntax Description

ssx	Display SSX information
monitor	Show monitor details
all	All sessions
<i>monitorname</i>	SSX Monitor to display
<i>__readonly__</i>	(Optional) Read Only
TABLE_ssx_monitors	(Optional) SSX monitors table

Command Mode

- /exec

show ssx record

```
show ssx record { all | <recordname> } [ __readonly__ [ TABLE_ssx_records <record-name> [ TABLE_stats_type <stats-type> ] <interval> ] ]
```

Syntax Description

<i>ssx</i>	Display SSX information
<i>record</i>	Show record details
<i>all</i>	All sessions
<i>recordname</i>	SSX Record to display
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_ssx_records</i>	(Optional) SSX records table
<i>TABLE_stats_type</i>	(Optional) SSX records stats type table
<i>interval</i>	(Optional) SSX interval

Command Mode

- /exec

show startup-config

show startup-config

Syntax Description

show	Show running system information
startup-config	Current startup configuration

Command Mode

- /exec

show startup-config aaa

show startup-config aaa

Syntax Description

show	show startup-cfg
startup-config	show startup system information
aaa	Display aaa configuration

Command Mode

- /exec

show startup-config acllog

show startup-config acllog [all]

Syntax Description

show	Show running system information
startup-config	Displaying the startup configuration
acllog	show startup config for acllog
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config aclmgr

```
show startup-config aclmgr [ all ]
```

Syntax Description

show	Show running system information
startup-config	Display the startup configuration
aclmgr	show startup config for aclmgr
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config adjmgr

show startup-config adjmgr [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
adjmgr	Display adjmgr information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config arp

show startup-config arp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
arp	Display arp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config assoc

show startup-config assoc [all]

Syntax Description

show	Show running system information
startup-config	Current saved configuration
assoc	Original ID to Translated ID Association
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config backup

show startup-config { backup | flexlink } [all]

Syntax Description

show	Show running system information
startup-config	System startup-config commands
backup	Show startup config for Switchport Backup
flexlink	Show startup config for Switchport Backup
all	(Optional) Show config with defaults

Command Mode

- /exec

show startup-config bfd

show startup-config bfd [all]

Syntax Description

show	Show system information
startup-config	Display the startup configuration
bfd	show startup config for bfd
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config bgp

show startup-config bgp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
bgp	Display bgp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config bloggerd

show startup-config bloggerd [all]

Syntax Description

show	show startup-cfg
startup-config	show system startup configuration information
bloggerd	Display bloggerd configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config callhome

show startup-config callhome

Syntax Description

show	show startup-cfg
startup-config	show startup system information
callhome	Display callhome configuration

Command Mode

- /exec

show startup-config catena

show startup-config catena

Syntax Description

show	show startup-cfg
startup-config	show startup system information
catena	catena instances

Command Mode

- /exec

show startup-config cdp

show startup-config cdp [all]

Syntax Description

show	show startup-cfg
startup-config	show system startup configuration information
cdp	Display cdp configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config cert-enroll

show startup-config cert-enroll

Syntax Description

show	show startup-cfg
startup-config	show startup system information
cert-enroll	Display certificates configuration

Command Mode

- /exec

show startup-config cfs

show startup-config cfs [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
cfs	Display cfs configurations
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config config-profile

show startup-config config-profile [<all_conf_profile_name>]

Syntax Description

show	Show startup-config
startup-config	Current startup configuration
config-profile	Display port-profile configuration
<i>all_conf_profile_name</i>	(Optional) Enter the name of the profile

Command Mode

- /exec

show startup-config copp

show startup-config copp [all]

Syntax Description

show	Show running system information
startup-config	System startup-config commands
copp	Control-Plane Policing
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config dhcp

show startup-config dhcp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
dhcp	Display dhcp snoop configurations
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config diagnostic

show startup-config diagnostic [all]

Syntax Description

show	Show running system information
startup-config	Contents of startup configuration
diagnostic	Diagnostic configuration
all	(Optional) Display running config with defaults

Command Mode

- /exec

show startup-config dot1x

show startup-config dot1x

Syntax Description

show	show startup-cfg
startup-config	show startup system information
dot1x	Display dot1x configuration

Command Mode

- /exec

show startup-config ecp

show startup-config ecp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ecp	ECP (Edge Control Protocol)
all	(Optional) Display startup config with defaults

Command Mode

- /exec

show startup-config eem

show startup-config eem

Syntax Description

show	Show running system information
startup-config	Show the system startup configuration
eem	Show the event manager startup configuration

Command Mode

- /exec

show startup-config eigrp

show startup-config eigrp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
eigrp	Display eigrp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config eltm

show startup-config eltm

Syntax Description

show	Show running system information
startup-config	Current startup configuration
eltm	Display eltm configurations

Command Mode

- /exec

show startup-config evb

show startup-config evb [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
evb	EVB (Edge Virtual Bridge)
all	(Optional) Display startup config with defaults

Command Mode

- /exec

show startup-config exclude

show startup-config exclude <feature-list> +

Syntax Description

show	Show running system information
startup-config	Current startup configuration
exclude	Exclude startup configuration of specified features
<i>feature-list</i>	Exclude features

Command Mode

- /exec

show startup-config expand-port-profile

show startup-config expand-port-profile

Syntax Description

show	Show running system information
startup-config	System startup-config commands
expand-port-profile	Expand port profile

Command Mode

- /exec

show startup-config fabric forwarding

show startup-config fabric forwarding [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config fabric multicast

show startup-config fabric multicast [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
fabric	Fabric
multicast	Multicast information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config fcoe_mgr

show startup-config fcoe_mgr

Syntax Description

show	show startup-cfg
startup-config	show startup system information
fcoe_mgr	Display fcoe_mgr configuration

Command Mode

- /exec

show startup-config hardware-telemetry

show startup-config hardware-telemetry [all]

Syntax Description

startup-config	Current startup configuration
hardware-telemetry	show startup config for hardware-telemetry
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config hsrp

show startup-config hsrp

Syntax Description

show	Show system information
startup-config	System startup configuration
hsrp	HSRP startup configuration

Command Mode

- /exec

show startup-config icam

show startup-config icam

Syntax Description

show	show startup-cfg
startup-config	show startup system information
icam	icam services

Command Mode

- /exec

show startup-config icmpv6

show startup-config icmpv6 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
icmpv6	Display icmpv6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config igmp

show startup-config igmp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
igmp	Display igmp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config imp

show startup-config imp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
imp	Display imp information
all	(Optional) Display start config with defaults clis

Command Mode

- /exec

show startup-config interface

show startup-config interface [<if0>] [expand-port-profile]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
interface	Interface configuration
<i>if0</i>	(Optional) interface type and number in module/slot format
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show startup-config interface

show startup-config interface <if0> [membership] [expand-port-profile]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
interface	Interface configuration
<i>if0</i>	interface type and number in module/slot format
membership	(Optional) Show membership information
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show startup-config ip

show startup-config ip [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ip	Display ip information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config ipqos

show startup-config ipqos [all]

Syntax Description

show	Show running system information
startup-config	Display the startup configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config ipv6

show startup-config ipv6 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ipv6	Display ipv6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config isis

show startup-config isis [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
isis	Display isis information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config l3vm

show startup-config l3vm [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
l3vm	Display l3vm information
all	(Optional) Display running config with defaults

Command Mode

- /exec

show startup-config ldap

show startup-config ldap

Syntax Description

show	show startup-cfg
startup-config	show startup system information
ldap	Display ldap configuration

Command Mode

- /exec

show startup-config license

show startup-config license [all]

Syntax Description

show	show startup-cfg
startup-config	show startup system information
license	Display licensing configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config lisp

show startup-config lisp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
lisp	Display lisp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config lldp

```
show startup-config lldp [ all ]
```

Syntax Description

show	show startup-cfg
startup-config	show system startup configuration information
lldp	Display lldp configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config log

```
show startup-config { log | mdp-log } [ bootstrap ]
```

Syntax Description

show	Show running system information
startup-config	Current startup configuration
mdp-log	Displays execution log of last used mdp ascii startup configuration
log	Displays execution log of last used ascii startup configuration
bootstrap	(Optional) Bootstrap config replay execution log

Command Mode

- /exec

show startup-config mmode

show startup-config mmode [all]

Syntax Description

show	Show running system information
startup-config	Show startup configuration
mmode	Display maintenance mode startup configuration
all	(Optional) Show startup config with defaults

Command Mode

- /exec

show startup-config monitor

show startup-config monitor

Syntax Description

show	Show running system information
startup-config	Current startup configuration
monitor	Configure Ethernet SPAN sessions

Command Mode

- /exec

show startup-config msdp

show startup-config msdp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
msdp	Display msdp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config nat

show startup-config nat [all]

Syntax Description

show	Show system information
startup-config	Display the startup configuration
nat	show startup config for nat
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config nbm

show startup-config nbm

Syntax Description

show	Show running system information
startup-config	Current startup configuration
nbm	Non Blocking Multicast

Command Mode

- /exec

show startup-config ngoam

show startup-config ngoam

Syntax Description

show	Show running system information
startup-config	Show startup system information
ngoam	ngoam configuration

Command Mode

- /exec

show startup-config ntp

show startup-config ntp [all]

Syntax Description

show	Show information
startup-config	Show startup system configuration
ntp	Show NTP information
all	(Optional) Show all NTP startup configuration

Command Mode

- /exec

show startup-config nv overlay

show startup-config nv overlay [all]

Syntax Description

show	Show system information
startup-config	System startup configuration
nv	NVE startup configuration
overlay	NVE startup configuration
all	(Optional) Show NVE config with defaults

Command Mode

- /exec

show startup-config nxsdk

show startup-config nxsdk [all]

Syntax Description

show	Show running system information
startup-config	Display the startup configuration
nxsdk	NXOS SDK
all	(Optional) Display running config with defaults

Command Mode

- /exec

show startup-config openflow

show startup-config openflow [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
openflow	Show startup config for OpenFlow
all	(Optional) Show startup config with defaults

Command Mode

- /exec

show startup-config ospf

show startup-config ospf [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ospf	Display ospf information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config ospfv3

show startup-config ospfv3 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ospfv3	Display ospfv3 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config param-list

show startup-config param-list [<plistname>]

Syntax Description

show	Show startup-cfg
startup-config	show startup configuration
param-list	Display param-list configuration
<i>plistname</i>	(Optional) Enter the name of the param list

Command Mode

- /exec

show startup-config pim

show startup-config pim [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
pim	Display pim information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config pim6

show startup-config pim6 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
pim6	Display pim6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config plb-services

show startup-config plb-services

Syntax Description

show	show startup-cfg
startup-config	show startup system information
plb-services	PLB services

Command Mode

- /exec

show startup-config poe

show startup-config poe [all]

Syntax Description

show	Show running system information
startup-config	Current saved configuration
poe	Power over Ethernet
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config port-profile

show startup-config port-profile [<all_profile_name>]

Syntax Description

show	Show startup-config
startup-config	Current startup configuration
port-profile	Display port-profile configuration
<i>all_profile_name</i>	(Optional) Enter the name of the profile

Command Mode

- /exec

show startup-config port-security

show startup-config port-security [all]

Syntax Description

show	show startup-cfg
startup-config	show startup system information
port-security	Display port-security configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config ptp

show startup-config ptp [all]

Syntax Description

startup-config	Current startup configuration
ptp	show startup config for ptp
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config radius

show startup-config radius

Syntax Description

show	show startup-cfg
startup-config	show startup system information
radius	Display radius configuration

Command Mode

- /exec

show startup-config rip

show startup-config rip [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
rip	Display rip information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config routing ip multicast

```
show startup-config routing { ip | ipv4 } multicast [ all ]
```

Syntax Description

show	Show running system information
startup-config	Current startup configuration
routing	Display routing information
ip	Display IP information
ipv4	Display IP information
multicast	Display multicast information
all	(Optional) Display startup config with defaults clis

Command Mode

- /exec

show startup-config routing ipv6 multicast

show startup-config routing ipv6 multicast [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display multicast information
all	(Optional) Display startup config with defaults clis

Command Mode

- /exec

show startup-config rpm

show startup-config rpm [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
rpm	Display Route Policy Manager (RPM) information
all	(Optional) Display startup config with defaults

Command Mode

- /exec

show startup-config rsvp

show startup-config rsvp

Syntax Description

show	Show running system information
startup-config	Current startup configuration
rsvp	Display RSVP status

Command Mode

- /exec

show startup-config security

show startup-config security

Syntax Description

show	show startup-cfg
startup-config	show startup system information
security	Display security configuration

Command Mode

- /exec

show startup-config services

show startup-config services

Syntax Description

show	show startup-cfg
startup-config	show startup system information
services	services

Command Mode

- /exec

show startup-config sflow

show startup-config sflow [all]

Syntax Description

startup-config	Current startup configuration
sflow	show startup config for sflow
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config sla responder

show startup-config sla responder

Syntax Description

show	show startup-cfg
startup-config	show startup system information
sla	Service Level Agreement (SLA)
responder	Show information about sla-responder

Command Mode

- /exec

show startup-config sla sender

show startup-config sla sender

Syntax Description

show	show startup-cfg
startup-config	show startup system information
sla	Service Level Agreement (SLA)
sender	Show information about sla-sender

Command Mode

- /exec

show startup-config sla twamp-server

show startup-config sla twamp-server

Syntax Description

show	show startup-cfg
startup-config	show startup system information
sla	Service Level Agreement (SLA)
twamp-server	Show information about twamp-server

Command Mode

- /exec

show startup-config smart-channel

show startup-config smart-channel

Syntax Description

show	show startup-cfg
startup-config	show startup system information
smart-channel	smart-channel services

Command Mode

- /exec

show startup-config snmp

show startup-config snmp [all]

Syntax Description

show	show startup-cfg
startup-config	show startup system information
snmp	Display snmp configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config srte

show startup-config srte

Syntax Description

show	Show running system information
startup-config	Current operating configuration
srte	SRTE

Command Mode

- /exec

show startup-config switch

show startup-config { switch-profile | include-switch-profile }

Syntax Description

show	Show running system information
startup-config	System startup configuration
switch-profile	Show switch-profile information
include-switch-profile	Show startup and switch-profile configuration

Command Mode

- /exec

show startup-config tacacs

show startup-config tacacs +

Syntax Description

show	show startup-cfg
startup-config	show startup system information

Command Mode

- /exec

show startup-config track

show startup-config track

Syntax Description

show	Show running system information
startup-config	Show the system startup configuration
track	Show the track startup configuration

Command Mode

- /exec

show startup-config udd

show startup-config udd

Syntax Description

show	Show running system information
startup-config	Current startup configuration
udd	Show udd configuration

Command Mode

- /exec

show startup-config vdc-all

show startup-config vdc-all

Syntax Description

show	Show running system information
startup-config	Current startup configuration
vdc-all	Display config from all VDC

Command Mode

- /exec

show startup-config vdc

show startup-config vdc [all]

Syntax Description

show	Show running system information
startup-config	Current saved configuration
vdc	Show Virtual Device Contexts
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config virtual-service

show startup-config virtual-service

Syntax Description

show	Show running system information
startup-config	System startup-config commands
virtual-service	Show startup config for virtualization services

Command Mode

- /exec

show startup-config vlan

show startup-config vlan <vlan-id>

Syntax Description

show	Show running system information
startup-config	System startup-config commands
vlan	Vlan commands
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19

Command Mode

- /exec

show startup-config vlan

show startup-config vlan

Syntax Description

show	Show running system information
startup-config	System startup-config commands
vlan	Vlan commands

Command Mode

- /exec

show startup-config vmtracker

show startup-config vmtracker [all]

Syntax Description

show	Show system information
startup-config	System startup configuration
vmtracker	Show VMTracker configuration
all	(Optional) Show VMTracker config with defaults

Command Mode

- /exec

show startup-config vpc

show startup-config vpc [all]

Syntax Description

startup-config	Current startup configuration
vpc	show startup config for vPC
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config vrf

show startup-config vrf <vrf-cfg-name> [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
vrf	Display VRF information
<i>vrf-cfg-name</i>	Configurable VRF name
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config vrf default

show startup-config vrf default [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
vrf	Display VRF information
default	Known VRF name
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config vrrpv3

show startup-config vrrpv3 [all]

Syntax Description

show	Show system information
startup-config	System startup configuration
vrrpv3	VRRPv3 startup configuration
all	(Optional) show startup config of VRRPv3 with defaults

Command Mode

- /exec

show startup-config vshd

show startup-config vshd

Syntax Description

show	Show startup system information
startup-config	Current startup configuration
vshd	Show startup config for vshd

Command Mode

- /exec

show startup-config vtp

show startup-config vtp [all]

Syntax Description

show	Show running system information
startup-config	System startup-config commands
vtp	Show startup configuration for VTP
all	(Optional) Show startup configuration for VTP with defaults

Command Mode

- /exec

show startup-config wwnm

show startup-config wwnm

Syntax Description

show	Show running system information
startup-config	Current startup configuration
wwnm	Display WWN Manager startup configuration

Command Mode

- /exec

show summary

```
show { ip mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] all | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 [ { unicast | multicast } ] ] } summary [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
summary	Display summarized information of BGP state
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	Display BGP information for all address families

Command Mode

- /exec

show sup-monitor drops session

show sup-monitor drops session <session_number> [module <module>]

Syntax Description

show	Show running system information
sup-monitor	Show Ethernet SPAN information
drops	show drop count
session	Show session info
<i>session_number</i>	
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number

Command Mode

- /exec

show switch-profile

```
show switch-profile [ <profile-name> ] { session-history | status commit } [ __readonly__ <prof-name>
TABLE_session <session_index> <start_usec> <start_time> <end_usec> <end_time> <revision_number>
<session_type> <session_subtype> <peer_triggered> [ <profile_status> ] [ <local_status> ] [ <local_error>
] [ <peer_address> ] [ <peer_sync_status> ] [ <merge_flags> ] [ <remote_status> ] [ <remote_error> ] ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
session-history	Switch-profile session-history
<i>profile-name</i>	(Optional) switch-profile name
status	Switch-profile sync status
commit	Switch-profile last commit status
<i>__readonly__</i>	(Optional)
<i>prof-name</i>	(Optional)
TABLE_session	(Optional)
<i>session_index</i>	(Optional)
<i>start_usec</i>	(Optional)
<i>start_time</i>	(Optional)
<i>end_usec</i>	(Optional)
<i>end_time</i>	(Optional)
<i>revision_number</i>	(Optional)
<i>session_type</i>	(Optional)
<i>session_subtype</i>	(Optional)
<i>peer_triggered</i>	(Optional)
<i>profile_status</i>	(Optional)
<i>local_status</i>	(Optional)
<i>local_error</i>	(Optional)
<i>peer_address</i>	(Optional)
<i>peer_sync_status</i>	(Optional)

<i>merge_flags</i>	(Optional)
<i>remote_status</i>	(Optional)
<i>remote_error</i>	(Optional)

Command Mode

- /exec

show switch-profile

show switch-profile [*__readonly__* <profile_name> <cfg_rev>]

Syntax Description

show	Show running system information
switch-profile	Show switch-profiles
<i>__readonly__</i>	(Optional)
<i>profile_name</i>	(Optional)
<i>cfg_rev</i>	(Optional)

Command Mode

- /exec

show switch-profile buffer

```
show switch-profile [ <profile-name> ] buffer [ __readonly__ <prof-name> [ TABLE_commands <seq_no>
[ <cmd> ] + ] ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
buffer	buffered commands
<i>profile-name</i>	(Optional) switch-profile name
<i>__readonly__</i>	(Optional)
<i>prof-name</i>	(Optional)
TABLE_commands	(Optional)
<i>seq_no</i>	(Optional)
<i>cmd</i>	(Optional)

Command Mode

- /exec

show switch-profile peer

```
show switch-profile [ <profile-name> ] peer [ <dest-ip> ] [ details ] [ __readonly__ <prof-name> [ <rev> ] [ <peer_address> ] [ <peer_sync_status> ] [ <merge_flags> ] [ <remote_status> ] [ <remote_error> ] [ <cmd> ] + ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
<i>profile-name</i>	(Optional) switch-profile name
peer	peer info
<i>dest-ip</i>	(Optional) IPv4 address (A.B.C.D) of destination
details	(Optional) information in detail
<i>__readonly__</i>	(Optional)
<i>prof-name</i>	(Optional)
<i>rev</i>	(Optional)
<i>peer_address</i>	(Optional)
<i>peer_sync_status</i>	(Optional)
<i>merge_flags</i>	(Optional)
<i>remote_status</i>	(Optional)
<i>remote_error</i>	(Optional)
<i>cmd</i>	(Optional)

Command Mode

- /exec

show switch-profile status

```
show switch-profile [ <profile-name> ] status [ __readonly__ <prof-name> <start_usec> <start_time>
<end_usec> <end_time> <revision_number> <session_type> [ <session_subtype> ] <peer_triggered>
<profile_status> <local_status> <local_error> [ <peer_address> ] [ <peer_sync_status> ] [ <merge_flags> ]
[ <remote_status> ] [ <remote_error> ] ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
status	Switch-profile sync status
<i>profile-name</i>	(Optional) switch-profile name
<i>__readonly__</i>	(Optional)
<i>prof-name</i>	(Optional)
<i>start_usec</i>	(Optional)
<i>start_time</i>	(Optional)
<i>end_usec</i>	(Optional)
<i>end_time</i>	(Optional)
<i>revision_number</i>	(Optional)
<i>session_type</i>	(Optional)
<i>session_subtype</i>	(Optional)
<i>peer_triggered</i>	(Optional)
<i>profile_status</i>	(Optional)
<i>local_status</i>	(Optional)
<i>local_error</i>	(Optional)
<i>peer_address</i>	(Optional)
<i>peer_sync_status</i>	(Optional)
<i>merge_flags</i>	(Optional)
<i>remote_status</i>	(Optional)
<i>remote_error</i>	(Optional)

Command Mode

- /exec

show switch-scope controller

show switch-scope controller

Syntax Description

show	Show running system information
switch-scope	switch-scope
controller	Controller command

Command Mode

- /exec

show switching-mode

show switching-mode [__readonly__ TABLE_switching_mode <switching-mode-desc>]

Syntax Description

show	Show running system information
switching-mode	Show the operating switching mode
__readonly__	(Optional)
TABLE_switching_mode	(Optional) the xml switching_mode configuration
<i>switching-mode-desc</i>	(Optional) switching mode description

Command Mode

- /exec

show switching-mode fabric-speed

show switching-mode fabric-speed [*__readonly__* *TABLE_switching_mode* <switching-mode-desc>]

Syntax Description

show	Show running system information
switching-mode	Show the operating switching mode
<i>__readonly__</i>	(Optional)
<i>TABLE_switching_mode</i>	(Optional) the xml switching_mode configuration
<i>switching-mode-desc</i>	(Optional) switching mode description
fabric-speed	Show the fabric speed

Command Mode

- /exec

show system acl

```
show system acl [ __readonly__ TABLE_system_acl <protocol> [ TABLE_type <type> <acl_name> <inout> ] ]
```

Syntax Description

show	Show running system information
system	System management commands
acl	ACL parameters
__readonly__	(Optional)
TABLE_system_acl	(Optional)
<i>protocol</i>	(Optional) protocol
TABLE_type	(Optional)
<i>type</i>	(Optional) type
<i>acl_name</i>	(Optional)
<i>inout</i>	(Optional) Traffic direction

Command Mode

- /exec

show system auto-collect tech-support

show system auto-collect tech-support [__readonly__ <result>]

Syntax Description

show	Show running system information
system	System management commands
auto-collect	Auto collection of information
tech-support	Collect tech-support in case of service causing supervisor reset
__readonly__	(Optional)
<i>result</i>	(Optional) show tech collection enable status

Command Mode

- /exec

show system boottime

```
show system boottime [ __readonly__ { TABLE_uptimeinf <slot> <starttime> <daysup> <hoursup>
<minutesup> <secondsup> } ]
```

Syntax Description

<i>show</i>	Show running system information
<i>system</i>	System-related show commands
<i>boottime</i>	Show platform boot time of each module
<i>__readonly__</i>	(Optional)
<i>TABLE_uptimeinf</i>	(Optional) Show uptime info
<i>slot</i>	(Optional) Slot
<i>starttime</i>	(Optional) Start Time
<i>daysup</i>	(Optional) Days Up
<i>hoursup</i>	(Optional) Hours Up
<i>minutesup</i>	(Optional) Minutes Up
<i>secondsup</i>	(Optional) Seconds Up

Command Mode

- /exec

show system clis event-history

show system [internal] clis event-history { nvdb | client | errors | parser | ha | cli | objstr | objstr-errors }

Syntax Description

show	Display output
system	System-related show commands
internal	(Optional) Commands for internal use
clis	cli server
event-history	Event history logs for clis
nvdb	Log of NVDB and PSS events
client	Log of client interaction events
errors	Log of errors
parser	Log of parser events
ha	Log of ha events
cli	Log of command events
objstr	Log of Object Store events
objstr-errors	Log of Object Store error events

Command Mode

- /exec

show system config reload-pending

```
show system config reload-pending [ __readonly__ { TABLE_reload_pending <cmds_list> } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
config	Config commands which require reload
reload-pending	Commands which require a reload
__readonly__	(Optional)
TABLE_reload_pending	(Optional) reload pending commands list
cmds_list	(Optional) cmds_list

Command Mode

- /exec

show system cores

show system cores [__readonly__ { <content> }]

Syntax Description

show	Show running system information
system	System-related show commands
cores	Displays core transfer option
__readonly__	(Optional)
<i>content</i>	(Optional) Core transfer option

Command Mode

- /exec

show system default switchport

```
show system default switchport [ __readonly__ <sys_def_port_state> <sys_def_trunk_mode>
<sys_def_link_fail_syslog_level> <sys_def_tx_credit_queue_type> ]
```

Syntax Description

show	Show running system information
<i>__readonly__</i>	(Optional) read only
<i>sys_def_port_state</i>	(Optional) System default port state
<i>sys_def_trunk_mode</i>	(Optional) System default trunk mode
<i>sys_def_link_fail_syslog_level</i>	(Optional) System default link failure syslog logging level
<i>sys_def_tx_credit_queue_type</i>	(Optional) System default tx credit queue type
system	System-related show commands
default	Show system default values
switchport	Show default values for switchport attributes

Command Mode

- /exec

show system error-id

show system error-id { list | <i0> } [__readonly__ <errorid> <facility> <desc>]

Syntax Description

show	Show running system information
system	System-related show commands
error-id	Show description about errors
list	Show description about all error IDs
<i>i0</i>	Show description about specific error
<i>__readonly__</i>	(Optional)
<i>errorid</i>	(Optional)
<i>facility</i>	(Optional)
<i>desc</i>	(Optional)

Command Mode

- /exec

show system exception-info

```
show system exception-info [ __readonly__ { TABLE_exception { <second> <panic_data> <register_data>
<stack_pointer> <stack_depth> <stack_timestamp> <stacl_magic> <hdr_length> <stack_data> <pre_usec>
<pre_sec> <int_t> <reason> <service> <version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
exception-info	Show last exception log information
<i>__readonly__</i>	(Optional)
TABLE_exception	(Optional)
<i>second</i>	(Optional) Time of exception
<i>panic_data</i>	(Optional) Panic information dump
<i>register_data</i>	(Optional) CPU register dump
<i>stack_pointer</i>	(Optional) Current Stack-pointer
<i>stack_depth</i>	(Optional) Current Stack-depth
<i>stack_timestamp</i>	(Optional) Stack dump timestamp
<i>stacl_magic</i>	(Optional) Stack Magic
<i>hdr_length</i>	(Optional) Hdr length
<i>stack_data</i>	(Optional) Stack Dump
<i>pre_usec</i>	(Optional)
<i>pre_sec</i>	(Optional)
<i>int_t</i>	(Optional)
<i>reason</i>	(Optional) Reason
<i>service</i>	(Optional) Service
<i>version</i>	(Optional) Version

Command Mode

- /exec

show system fabric-mode

show system fabric-mode [__readonly__ TABLE_system_fabric_mode <system-fabric-mode-desc>]

Syntax Description

show	Show running system information
system	Show system information
fabric-mode	Show the fabric operation mode information
__readonly__	(Optional)
TABLE_system_fabric_mode	(Optional) the xml system_fabric_mode configuration
<i>system-fabric-mode-desc</i>	(Optional) system fabric mode description

Command Mode

- /exec

show system fast-reload stabilization-timer

```
show system fast-reload stabilization-timer [ __readonly__ { <timer_val> } ]
```

Syntax Description

show	Show running system information
system	System management commands
fast-reload	fast-reload software
stabilization-timer	Network stabilization time in seconds before fast-reload can be executed after the previous reload
__readonly__	(Optional) Read Only
<i>timer_val</i>	(Optional) XML attribute for timer value

Command Mode

- /exec

show system image-verification

show system image-verification

Syntax Description

show	Show running system information
system	Show system information
image-verification	image signature verification status

Command Mode

- /exec

show system inband queuing statistics

```
show system inband queuing statistics [ __readonly__ { TABLE_sys_inband_queue_stats <inbandpktunmap>
<inbandpktbpduqueue> <inbandpktmapq0> <inbandpktmapq1> <klmpktmapbpdu> <klmpktmaparp>
<klmpktmapq0> <klmpktmapq1> <klmpktmapveobc> <queuename> [ TABLE_bpdu_stats { <pmrcvpkts>
<pmdroppkts> <pmcongested> <rcvbuf> <sndbuf> <pmnodrop> } ] [ TABLE_q_stats { <indexstat>
<ipmrcvpkts> <ipmdroppkts> <ipmcongested> <ircvbuf> <isndbuf> <ipmnodrop> } ] ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
inband	Inband Commands
queuing	Inband Queuing commands
statistics	Inband statistics
<i>__readonly__</i>	(Optional)
TABLE_sys_inband_queue_stats	(Optional) System Inband Statistics
<i>inbandpktunmap</i>	(Optional) Inband packets unmapped
<i>inbandpktbpduqueue</i>	(Optional) Inband packets mapped to bpdu
<i>inbandpktmapq0</i>	(Optional) Inband packets mapped to q0
<i>inbandpktmapq1</i>	(Optional) Inband packets mapped to q1
<i>klmpktmapbpdu</i>	(Optional) In KLM packets mapped to bpdu
<i>klmpktmaparp</i>	(Optional) In KLM packets mapped to arp
<i>klmpktmapq0</i>	(Optional) In KLM packets mapped to q0
<i>klmpktmapq1</i>	(Optional) In KLM packets mapped to q1
<i>klmpktmapveobc</i>	(Optional) In KLM packets mapped to veobc
<i>queuename</i>	(Optional) Inband queue name
TABLE_bpdu_stats	(Optional) BPDU Statistics
<i>pmrcvpkts</i>	(Optional) BPDU Receive Packets
<i>pmdroppkts</i>	(Optional) BPDU Drop Packets
<i>pmcongested</i>	(Optional) BPDU Congested
<i>rcvbuf</i>	(Optional) BPDU Receive Buffer
<i>sndbuf</i>	(Optional) BPDU Send Buffer

<i>pmnoproduct</i>	(Optional) BPDU No drop
TABLE_q_stats	(Optional) Queue Statistics
<i>indexstat</i>	(Optional) Queue Index
<i>ipmrecvpkts</i>	(Optional) Queue receive packets
<i>ipmdroppkts</i>	(Optional) Queue drop packets
<i>ipmcongested</i>	(Optional) Queue Congested
<i>ircvbuf</i>	(Optional) Queue receive buffer
<i>isndbuf</i>	(Optional) Queue send buffer
<i>ipmnooproduct</i>	(Optional) Queue no drop

Command Mode

- /exec

show system inband queuing status

```
show system inband queuing status [ __readonly__ [ { TABLE_sys_inband_queue_status <pminbandweigh0>
<pminbandweigh1> <pminbandweigh2> } ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
inband	Inband Commands
queuing	Inband Queuing commands
status	Selective Packet Discard Information
<i>__readonly__</i>	(Optional)
<i>TABLE_sys_inband_queue_status</i>	(Optional) System Inband Status
<i>pminbandweigh0</i>	(Optional) BPDU Weight
<i>pminbandweigh1</i>	(Optional) Q0 Weight
<i>pminbandweigh2</i>	(Optional) Q1 Weight

Command Mode

- /exec

show system login

```
show system login [ __readonly__ [ [ <acc_list> ] [ <attempts> ] ] [ <within> <block_for> <time> ] [ <fail_count> ] [ <switch_mode> ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
login	Display Secure Login Configurations and State
<i>__readonly__</i>	(Optional)
<i>acc_list</i>	(Optional) Applied ACL's
<i>attempts</i>	(Optional) Number of login failures
<i>within</i>	(Optional) Number of login failures within time
<i>block_for</i>	(Optional) Login disabled for time
<i>time</i>	(Optional) Time remaining to re-enable login
<i>fail_count</i>	(Optional) Login failure count
<i>switch_mode</i>	(Optional) Mode of operation

Command Mode

- /exec

show system login failures

```
show system login failures [ __readonly__ [ { TABLE_loginStats <username> <port> <remote_addr>
<app_name> <time> } ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
login	Secure Login
failures	Display Login failures in the current watch period
__readonly__	(Optional)
TABLE_loginStats	(Optional)
<i>username</i>	(Optional) User name
<i>port</i>	(Optional) Login port number
<i>remote_addr</i>	(Optional) Remote address
<i>app_name</i>	(Optional) Application name
<i>time</i>	(Optional) Login time

Command Mode

- /exec

show system memory-thresholds

```
show system memory-thresholds [ __readonly__ <critical_mem_threshold> <severe_mem_threshold>
<minor_mem_threshold> ]
```

Syntax Description

show	Show running system information
<i>__readonly__</i>	(Optional)
<i>critical_mem_threshold</i>	(Optional) Critical System Memory Threshold
<i>severe_mem_threshold</i>	(Optional) Severe System Memory Threshold
<i>minor_mem_threshold</i>	(Optional) Minor System Memory Threshold
system	System management commands
memory-thresholds	Set memory thresholds on the card

Command Mode

- /exec

show system mode

```
show system mode [ __readonly__ <system_mode> [ <timer_state> ] ]
```

Syntax Description

show	Show running system information
system	System configuration commands
mode	Show system mode
<i>__readonly__</i>	(Optional)
<i>system_mode</i>	(Optional) system mode
<i>timer_state</i>	(Optional) timer state

Command Mode

- /exec

show system poap

show system poap

Syntax Description

show	Show running system information
system	Show system information
poap	Show information related to POAP

Command Mode

- /exec

show system pss shrink status

```
show system pss shrink status [ details ] [ __readonly__ { [ <summary> ] [ TABLE_per_vdc <vdc_id> [
TABLE_detail_events <service> <vdc> <event> ] ] [ TABLE_events <service> <vdc> <event> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
pss	Displays last pss shrink status
shrink	Displays last pss shrink status
status	Displays last pss shrink status
details	(Optional) Displays last pss shrink status details
<i>__readonly__</i>	(Optional)
<i>summary</i>	(Optional) PSS shrink summary
TABLE_per_vdc	(Optional)
<i>vdc_id</i>	(Optional) VDC id
TABLE_detail_events	(Optional) PSS shrink events
<i>service</i>	(Optional) Service name
<i>vdc</i>	(Optional) VDC number
<i>event</i>	(Optional) PSS evnets
TABLE_events	(Optional) PSS shrink events
<i>service</i>	(Optional) Service name
<i>vdc</i>	(Optional) VDC number
<i>event</i>	(Optional) PSS evnets

Command Mode

- /exec

show system redundancy ha status

```
show system redundancy ha status [ __readonly__ { [ TABLE_ha_status <vdc_id> <this_sup_internal_state>
<other_sup_internal_state> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
redundancy	redundancy status
ha	vdc redundancy status
status	all vdc redundancy status
<i>__readonly__</i>	(Optional)
<i>TABLE_ha_status</i>	(Optional) HA status for all vdc's
<i>vdc_id</i>	(Optional) vdc id
<i>this_sup_internal_state</i>	(Optional) This Supervisor State
<i>other_sup_internal_state</i>	(Optional) Remote Supervisor State

Command Mode

- /exec

show system redundancy status

```
show system redundancy status [ __readonly__ { <rdn_mode_admin> <rdn_mode_oper> <this_sup>
<this_sup_rdn_state> <this_sup_sup_state> <this_sup_internal_state> [ <other_sup> ] [ <other_sup_rdn_state>
] [ <other_sup_sup_state> ] [ <other_sup_internal_state> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
redundancy	redundancy status
status	Current redundancy status
<i>__readonly__</i>	(Optional) readonly
<i>rdn_mode_admin</i>	(Optional) Redundancy Mode Admin
<i>rdn_mode_oper</i>	(Optional) Redundancy Mode Operational
<i>this_sup</i>	(Optional) This Supervisor
<i>this_sup_rdn_state</i>	(Optional) Redundancy State
<i>this_sup_sup_state</i>	(Optional) Supervisor State
<i>this_sup_internal_state</i>	(Optional) Supervisor State
<i>other_sup</i>	(Optional) Other Supervisor
<i>other_sup_sup_state</i>	(Optional) Supervisor State
<i>other_sup_rdn_state</i>	(Optional) Redundancy tate
<i>other_sup_internal_state</i>	(Optional) Supervisor State

Command Mode

- /exec

show system reset-reason

```
show system reset-reason [ __readonly__ { TABLE_reason <slot> { TABLE_rr <time> <reason> <service>
<version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
reset-reason	Show last reset reason
__readonly__	(Optional)
TABLE_reason	(Optional) Reset reason info
<i>slot</i>	(Optional) slot
TABLE_rr	(Optional) reset reason
<i>time</i>	(Optional) time
<i>reason</i>	(Optional) reset reason
<i>service</i>	(Optional) service name
<i>version</i>	(Optional) version

Command Mode

- /exec

show system reset-reason

```
show system reset-reason <s0> <santa-cruz-range> [ __readonly__ { TABLE_xbarreason <slot> { TABLE_rr
<time> <reason> <service> <version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
reset-reason	Show last reset reason
<i>s0</i>	Show xbar module reset reason
<i>santa-cruz-range</i>	please enter the xbar module number
<i>__readonly__</i>	(Optional)
TABLE_xbarreason	(Optional) Reset reason info
<i>slot</i>	(Optional) slot
TABLE_rr	(Optional) reset reason
<i>time</i>	(Optional) time
<i>reason</i>	(Optional) reset reason
<i>service</i>	(Optional) service name
<i>version</i>	(Optional) version

Command Mode

- /exec

show system reset-reason module

```
show system reset-reason module <module> [ __readonly__ { TABLE_reason <slot> { TABLE_rr <time>
<reason> <service> <version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
reset-reason	Show last reset reason
module	Show per module reset-reason code
<i>module</i>	please enter module number
<i>__readonly__</i>	(Optional)
TABLE_reason	(Optional) Reset reason info
<i>slot</i>	(Optional) slot
TABLE_rr	(Optional) reset reason
<i>time</i>	(Optional) time
<i>reason</i>	(Optional) reset reason
<i>service</i>	(Optional) service name
<i>version</i>	(Optional) version

Command Mode

- /exec

show system resources

```
show system resources [ __readonly__ { [ <load_avg_1min> ] [ <load_avg_5min> ] [ <load_avg_15min> ]
[ <processes_total> ] [ <processes_running> ] [ <cpu_state_user> ] [ <cpu_state_kernel> ] [ <cpu_state_idle>
] [ TABLE_cpu_usage <cpuid> <user> <kernel> <idle> ] [ <memory_usage_total> ] [ <memory_usage_used>
] [ <memory_usage_free> ] [ <current_memory_status> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>__readonly__</i>	(Optional)
<i>TABLE_cpu_usage</i>	(Optional) All Cpu Usage Information
<i>load_avg_1min</i>	(Optional) Load Average 1 Min
<i>load_avg_5min</i>	(Optional) Load Average 5 Min
<i>load_avg_15min</i>	(Optional) Load Average 15 Min
<i>processes_total</i>	(Optional) Total processes
<i>processes_running</i>	(Optional) Running Processes
<i>cpu_state_user</i>	(Optional) CPU State User
<i>cpu_state_kernel</i>	(Optional) CPU State Kernel
<i>cpu_state_idle</i>	(Optional) CPU State Idle
<i>cpuid</i>	(Optional) CPU id
<i>user</i>	(Optional) user time
<i>kernel</i>	(Optional) kernel time
<i>idle</i>	(Optional) idle time
<i>memory_usage_total</i>	(Optional) Memory Usage Total
<i>memory_usage_used</i>	(Optional) Memory Usage Used
<i>memory_usage_free</i>	(Optional) Memory Usage Free
<i>current_memory_status</i>	(Optional) Current Memory Status

Command Mode

- /exec

show system resources

show system resources <i0>

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>i0</i>	time interval in seconds

Command Mode

- /exec

show system resources module

show system resources [*<i0>*] module *<module>*

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>i0</i>	(Optional) time interval in seconds
module	Show system resources for specified module
<i>module</i>	module number

Command Mode

- /exec

show system resources module all

```
show system resources [ <i0> ] module all [ __readonly__ { TABLE_cpuinfo <sts_msg1> <cpu_5sec>
<cpu_1min> <cpu_5min> } { TABLE_meminfo <sts_msg2> <mem_module> <mem_total> <mem_free>
<mem_used> } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>i0</i>	(Optional) time interval in seconds
module	Show system resources for specified module
all	Show system resources for all modules
<i>__readonly__</i>	(Optional)
TABLE_cpuinfo	(Optional)
<i>sts_msg1</i>	(Optional)
<i>cpu_5sec</i>	(Optional)
<i>cpu_1min</i>	(Optional)
<i>cpu_5min</i>	(Optional)
TABLE_meminfo	(Optional)
<i>sts_msg2</i>	(Optional)
<i>mem_module</i>	(Optional)
<i>mem_total</i>	(Optional)
<i>mem_free</i>	(Optional)
<i>mem_used</i>	(Optional)

Command Mode

- /exec

show system routing mode

```
show system routing mode [ __readonly__ TABLE_system_routing_mode { [ <configured-sys-routing-mode>
] [ <applied-sys-routing-mode> ] [ <svi-hardware-flood-mode> ] [ <routing-perf-mode> ] [
<mrouting-perf-mode> ] } ]
```

Syntax Description

show	Show running system information
system	Show system information
routing	Show routing related information
mode	Show mode related information
__readonly__	(Optional)
TABLE_system_routing_mode	(Optional) the xml system_routing_mode configuration
<i>configured-sys-routing-mode</i>	(Optional) Configured system routing mode description
<i>applied-sys-routing-mode</i>	(Optional) Applied system routing mode description
<i>svi-hardware-flood-mode</i>	(Optional) Configured SVI hardware flood mode description
<i>routing-perf-mode</i>	(Optional) Applied System Routing Performance Mode description
<i>mrouting-perf-mode</i>	(Optional) Applied System Mrouting Performance Mode

Command Mode

- /exec

show system security

```
show system security [ common-criteria ] [ __readonly__ { [ <common_criteria_o_status> ] } ]
```

Syntax Description

show	Show running system information
system	System Management commands
security	Security Management commands
common-criteria	(Optional) Show if common-criteria mode is enabled or disabled
__readonly__	(Optional)
<i>common_criteria_o_status</i>	(Optional) operational status of common-criteria

Command Mode

- /exec

show system simulate fan-presence

show system simulate fan-presence

Syntax Description

show	Show running system information
system	System management commands
simulate	Simulate Fan Presence
fan-presence	Simulate Fan Presence

Command Mode

- /exec

show system standby manual-boot

show system standby manual-boot [__readonly__ { <content> }]

Syntax Description

show	Show running system information
system	System-related show commands
standby	Displays system standby manual boot option
manual-boot	Displays system standby manual boot option
__readonly__	(Optional)
<i>content</i>	(Optional) Displays system standby manual boot option

Command Mode

- /exec

show system switch-mode

show system switch-mode [*__readonly__* <*op_mode*>]

Syntax Description

show	Show running system information
system	System-related show commands
switch-mode	Show current operational mode of the switch
<i>__readonly__</i>	(Optional)
<i>op_mode</i>	(Optional) Operational Mode

Command Mode

- /exec

show system uptime

```
show system uptime [ __readonly__ { <sys_st_time> <sys_up_days> <sys_up_hrs> <sys_up_mins>
<sys_up_secs> <kn_up_days> <kn_up_hrs> <kn_up_mins> <kn_up_secs> [ <as_up_days> ] [ <as_up_hrs>
] [ <as_up_mins> ] [ <as_up_secs> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
uptime	Show how long the system has been up and running
<i>__readonly__</i>	(Optional) readonly
<i>sys_st_time</i>	(Optional) System Start Time
<i>sys_up_days</i>	(Optional) System Uptime Days
<i>sys_up_hrs</i>	(Optional) System Uptime Hours
<i>sys_up_mins</i>	(Optional) System Uptime Minutes
<i>sys_up_secs</i>	(Optional) System Uptime Seconds
<i>kn_up_days</i>	(Optional) Kernel Uptime Days
<i>kn_up_hrs</i>	(Optional) Kernel Uptime Hours
<i>kn_up_mins</i>	(Optional) Kernel Uptime Minutes
<i>kn_up_secs</i>	(Optional) Kernel Uptime Seconds
<i>as_up_days</i>	(Optional) Active Sup Uptime Days
<i>as_up_hrs</i>	(Optional) Active Sup Uptime Hours
<i>as_up_mins</i>	(Optional) Active Sup Uptime Minutes
<i>as_up_secs</i>	(Optional) Active Sup Uptime Seconds

Command Mode

- /exec

show system verify bios flash

```
show system verify bios { flash <i0> [ module <module> ] | protection <i1> [ module <module1> ] } [
__readonly__ { <return> <verify_result> <protection_status> } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
verify	Verify commands
bios	Verify bios
flash	verify bios flash or protection status
<i>i0</i>	Select primary or alternate flash
module	(Optional) Module number
<i>module</i>	(Optional) Enter module number
protection	verify bios flash or protection status
<i>i1</i>	Select primary or alternate flash
module	(Optional) Module number
<i>module1</i>	(Optional) Enter module number
<i>__readonly__</i>	(Optional)
<i>return</i>	(Optional)
<i>verify_result</i>	(Optional)
<i>protection_status</i>	(Optional)

Command Mode

- /exec

show system vlan reserved

```
show system vlan reserved [ __readonly__ { TABLE_vlan <current_reserved_vlan_start>
<current_reserved_vlan_end> [ <future_reserved_vlan_start> ] [ <future_reserved_vlan_end> ] } ]
```

Syntax Description

show	Show running system information
system	system wide configuration
vlan	VLAN status
reserved	Show system VLAN allocation
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_vlan</i>	(Optional)
<i>current_reserved_vlan_start</i>	(Optional) System current running reserved vlan start
<i>current_reserved_vlan_end</i>	(Optional) System current running reserved vlan end
<i>future_reserved_vlan_start</i>	(Optional) System future running reserved vlan start
<i>future_reserved_vlan_end</i>	(Optional) System future running reserved vlan end

Command Mode

- /exec



T Show Commands

- [show table-map](#), on page 2521
- [show tacacs-server](#), on page 2522
- [show tacacs-server](#), on page 2523
- [show tacacs-server directed-request](#), on page 2524
- [show tacacs-server groups](#), on page 2525
- [show tacacs-server sorted](#), on page 2526
- [show tacacs-server statistics](#), on page 2527
- [show tech-support](#), on page 2529
- [show tech-support aaa](#), on page 2530
- [show tech-support aclmgr](#), on page 2531
- [show tech-support aclmgr compressed](#), on page 2532
- [show tech-support aclqos](#), on page 2533
- [show tech-support aclqos compressed](#), on page 2534
- [show tech-support adjmgr](#), on page 2535
- [show tech-support all-binary](#), on page 2536
- [show tech-support all](#), on page 2537
- [show tech-support analytics](#), on page 2538
- [show tech-support arp](#), on page 2539
- [show tech-support ascii-cfg](#), on page 2540
- [show tech-support assoc_mgr](#), on page 2541
- [show tech-support backup](#), on page 2542
- [show tech-support bcm](#), on page 2543
- [show tech-support bfd](#), on page 2544
- [show tech-support bgp](#), on page 2545
- [show tech-support biosd](#), on page 2546
- [show tech-support bloggerd-all](#), on page 2547
- [show tech-support bloggerd](#), on page 2548
- [show tech-support bootvar](#), on page 2549
- [show tech-support brief](#), on page 2550
- [show tech-support callhome](#), on page 2551
- [show tech-support cdp](#), on page 2552
- [show tech-support cert-enroll](#), on page 2553
- [show tech-support cfs](#), on page 2554

- [show tech-support cli](#), on page 2555
- [show tech-support clis](#), on page 2556
- [show tech-support clock_manager](#), on page 2557
- [show tech-support commands](#), on page 2558
- [show tech-support controller](#), on page 2559
- [show tech-support copp](#), on page 2560
- [show tech-support dcbx](#), on page 2561
- [show tech-support details](#), on page 2562
- [show tech-support dhclient](#), on page 2563
- [show tech-support dhcp](#), on page 2564
- [show tech-support dme](#), on page 2565
- [show tech-support dot1x](#), on page 2566
- [show tech-support ecp](#), on page 2567
- [show tech-support eem](#), on page 2568
- [show tech-support eigrp](#), on page 2569
- [show tech-support eltm](#), on page 2570
- [show tech-support ethpm](#), on page 2571
- [show tech-support ethport](#), on page 2572
- [show tech-support evb](#), on page 2573
- [show tech-support fabric forwarding](#), on page 2574
- [show tech-support fabric multicast](#), on page 2575
- [show tech-support fast-reload](#), on page 2576
- [show tech-support fc2](#), on page 2577
- [show tech-support fcoe](#), on page 2578
- [show tech-support fips](#), on page 2579
- [show tech-support forwarding l2 multicast](#), on page 2580
- [show tech-support forwarding l2 multicast vdc-all](#), on page 2581
- [show tech-support forwarding l2 unicast](#), on page 2582
- [show tech-support forwarding l3 multicast](#), on page 2583
- [show tech-support forwarding l3 multicast detail vdc-all](#), on page 2584
- [show tech-support forwarding l3 multicast detail](#), on page 2585
- [show tech-support forwarding l3 multicast vdc-all](#), on page 2586
- [show tech-support forwarding l3 unicast](#), on page 2587
- [show tech-support forwarding l3 unicast detail](#), on page 2588
- [show tech-support forwarding l3 unicast detail vdc-all](#), on page 2589
- [show tech-support forwarding l3 unicast vdc-all](#), on page 2590
- [show tech-support forwarding multicast](#), on page 2591
- [show tech-support gold](#), on page 2592
- [show tech-support gpixm](#), on page 2593
- [show tech-support ha](#), on page 2594
- [show tech-support ha module](#), on page 2595
- [show tech-support ha standby](#), on page 2596
- [show tech-support hardware-telemetry](#), on page 2597
- [show tech-support hsrp](#), on page 2598
- [show tech-support hsrp brief](#), on page 2599
- [show tech-support icam](#), on page 2600

- [show tech-support icmpv6](#), on page 2601
- [show tech-support im](#), on page 2602
- [show tech-support imp](#), on page 2603
- [show tech-support inband counters](#), on page 2604
- [show tech-support include-time](#), on page 2605
- [show tech-support install](#), on page 2606
- [show tech-support interface-vlan](#), on page 2607
- [show tech-support ip](#), on page 2608
- [show tech-support ip igmp](#), on page 2609
- [show tech-support ip igmp snooping](#), on page 2610
- [show tech-support ip msdp](#), on page 2611
- [show tech-support ip pim](#), on page 2612
- [show tech-support ipqos](#), on page 2613
- [show tech-support ipv6](#), on page 2614
- [show tech-support ipv6 mld](#), on page 2615
- [show tech-support ipv6 multicast](#), on page 2616
- [show tech-support ipv6 pim](#), on page 2617
- [show tech-support isis](#), on page 2618
- [show tech-support issu](#), on page 2619
- [show tech-support kstack](#), on page 2620
- [show tech-support l2](#), on page 2621
- [show tech-support l2fm](#), on page 2622
- [show tech-support l2fm clients](#), on page 2623
- [show tech-support l2fm detail](#), on page 2624
- [show tech-support l2fm l2dbg](#), on page 2625
- [show tech-support l2fm l2dbg](#), on page 2626
- [show tech-support l2rib](#), on page 2627
- [show tech-support l3vm](#), on page 2628
- [show tech-support l3vpn](#), on page 2629
- [show tech-support lacp](#), on page 2630
- [show tech-support ldap](#), on page 2631
- [show tech-support license](#), on page 2632
- [show tech-support lim](#), on page 2633
- [show tech-support lisp](#), on page 2634
- [show tech-support lldp](#), on page 2635
- [show tech-support logging](#), on page 2636
- [show tech-support m2rib](#), on page 2637
- [show tech-support mfwd](#), on page 2638
- [show tech-support mmode](#), on page 2639
- [show tech-support module](#), on page 2640
- [show tech-support module all](#), on page 2641
- [show tech-support monitor](#), on page 2642
- [show tech-support monitor erspan](#), on page 2643
- [show tech-support monitorc-all](#), on page 2644
- [show tech-support multicast-vxlan-evpn](#), on page 2645
- [show tech-support multicast](#), on page 2646

- [show tech-support mvpn](#), on page 2647
- [show tech-support nat](#), on page 2648
- [show tech-support nbm](#), on page 2649
- [show tech-support netstack](#), on page 2650
- [show tech-support netstack detail](#), on page 2651
- [show tech-support ngoam](#), on page 2652
- [show tech-support npacl](#), on page 2653
- [show tech-support npv](#), on page 2654
- [show tech-support ns](#), on page 2655
- [show tech-support ntp](#), on page 2656
- [show tech-support nxapi](#), on page 2657
- [show tech-support nxsdk](#), on page 2658
- [show tech-support object-store](#), on page 2659
- [show tech-support openflow](#), on page 2660
- [show tech-support ospf](#), on page 2661
- [show tech-support ospfv3](#), on page 2662
- [show tech-support page](#), on page 2663
- [show tech-support patch](#), on page 2664
- [show tech-support pbr](#), on page 2665
- [show tech-support pfstat](#), on page 2666
- [show tech-support pixm-all](#), on page 2667
- [show tech-support pixm](#), on page 2668
- [show tech-support pixmc-all](#), on page 2669
- [show tech-support pktmgr](#), on page 2670
- [show tech-support platform-sdk](#), on page 2671
- [show tech-support platform](#), on page 2672
- [show tech-support platform](#), on page 2673
- [show tech-support plb-services](#), on page 2674
- [show tech-support plcmgr](#), on page 2675
- [show tech-support pltfm-config](#), on page 2676
- [show tech-support poe](#), on page 2677
- [show tech-support port-channel](#), on page 2678
- [show tech-support port-client-all](#), on page 2679
- [show tech-support port-profile](#), on page 2680
- [show tech-support port-security](#), on page 2681
- [show tech-support port](#), on page 2682
- [show tech-support private-vlan](#), on page 2683
- [show tech-support ptp](#), on page 2684
- [show tech-support radius](#), on page 2685
- [show tech-support rip](#), on page 2686
- [show tech-support routing](#), on page 2687
- [show tech-support routing ipv6](#), on page 2688
- [show tech-support routing ipv6 multicast](#), on page 2689
- [show tech-support routing multicast](#), on page 2690
- [show tech-support rpm](#), on page 2691
- [show tech-support sal](#), on page 2692

- [show tech-support san-port-channel](#), on page 2693
- [show tech-support san](#), on page 2694
- [show tech-support satmgr](#), on page 2695
- [show tech-support security](#), on page 2696
- [show tech-support services](#), on page 2697
- [show tech-support session-mgr](#), on page 2698
- [show tech-support sflow](#), on page 2699
- [show tech-support single-gericho](#), on page 2700
- [show tech-support sksd](#), on page 2701
- [show tech-support sla responder](#), on page 2702
- [show tech-support sla sender](#), on page 2703
- [show tech-support sla twamp-server](#), on page 2704
- [show tech-support smartc](#), on page 2705
- [show tech-support smm](#), on page 2706
- [show tech-support snmp](#), on page 2707
- [show tech-support sockets](#), on page 2708
- [show tech-support spm](#), on page 2709
- [show tech-support srte](#), on page 2710
- [show tech-support statsclient](#), on page 2711
- [show tech-support stp](#), on page 2712
- [show tech-support sup-filesys](#), on page 2713
- [show tech-support sysmgr](#), on page 2714
- [show tech-support tacacs](#), on page 2715
- [show tech-support track](#), on page 2716
- [show tech-support tunnel](#), on page 2717
- [show tech-support u2rib](#), on page 2718
- [show tech-support udd](#), on page 2719
- [show tech-support usd-all](#), on page 2720
- [show tech-support vdc](#), on page 2721
- [show tech-support virtual-service](#), on page 2722
- [show tech-support vlan](#), on page 2723
- [show tech-support vmtracker](#), on page 2724
- [show tech-support vpc](#), on page 2725
- [show tech-support vrrp](#), on page 2726
- [show tech-support vrrp brief](#), on page 2727
- [show tech-support vrrpv3](#), on page 2728
- [show tech-support vsan](#), on page 2729
- [show tech-support vshd](#), on page 2730
- [show tech-support vtp](#), on page 2731
- [show tech-support vvlan](#), on page 2732
- [show tech-support xbar](#), on page 2733
- [show tech-support xml](#), on page 2734
- [show tech-support xos](#), on page 2735
- [show telnet server](#), on page 2736
- [show terminal](#), on page 2737
- [show terminal output xml version](#), on page 2738

- [show time-range](#), on page 2739
- [show time-stamp running-config last-changed](#), on page 2741
- [show track](#), on page 2742
- [show track brief](#), on page 2744
- [show troubleshoot l2 mac vlan](#), on page 2746
- [show troubleshoot l3 ipv4 vrf](#), on page 2747
- [show trunk protocol](#), on page 2748
- [show ttag brief](#), on page 2749
- [show ttag brief](#), on page 2750

show table-map

```
show table-map [ <imap-name> | <default-omap-enum-name> ] [ __readonly__ { [ TABLE_omap <imap-name>
[ <desc> ] [ <def-value> ] [ <def-copy> ] [ <def-ignore> ] [ TABLE_list <frm-list> <to-val> ] ] } ]
```

Syntax Description

show	Show running system information
table-map	Table maps
TABLE_omap	(Optional) all omap xml sessions
<i>imap-name</i>	(Optional) Show a particular table map
<i>default-omap-enum-name</i>	(Optional)
<i>__readonly__</i>	(Optional)
<i>desc</i>	(Optional) Description string
<i>def-value</i>	(Optional) Unspecified entries will default to this value
<i>def-copy</i>	(Optional) Map unspecified values to equivalent output value
<i>def-ignore</i>	(Optional) Ignore unspecified values
TABLE_list	(Optional) table map lists
<i>frm-list</i>	(Optional) Original list of values which are to be mapped
<i>to-val</i>	(Optional) To value

Command Mode

- /exec

show tacacs-server

```
show tacacs-server [ __readonly__ [ <global_secretKey> ] { <global_timeout> <global_deadtime> } [
<global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [ <global_testPassword> ] } {
<server_count> } [ TABLE_server <server_ip> <port> [ <secretKey> ] [ <timeout> ] ] [ { <host0>
<tacacs_port> <shared_key> <idle_time><test_username> <test_password> } + ] ]
```

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
<i>__readonly__</i>	(Optional)
<i>global_secretKey</i>	(Optional) Global shared secret
<i>global_timeout</i>	(Optional) Global timeout for tacacs
<i>global_deadtime</i>	(Optional) Global deadtime
<i>global_source_intf</i>	(Optional) Tacacs global source interface
<i>global_idle_time</i>	(Optional) Tacacs global idle-time for server monitoring
<i>global_testUsername</i>	(Optional) Username of global test parameters
<i>global_testPassword</i>	(Optional) Password of global test parameters
<i>server_count</i>	(Optional) Total number of tacacs servers configured
TABLE_server	(Optional)
<i>server_ip</i>	(Optional) Ip address of the server
<i>port</i>	(Optional) Port used for this server
<i>secretKey</i>	(Optional) Shared secret between the server and the tacacs client
<i>timeout</i>	(Optional) Timeout for this tacacs server
<i>host0</i>	(Optional) DNS name or IP address
<i>tacacs_port</i>	(Optional) TACACS+ server port
<i>shared_key</i>	(Optional) TACACS+ shared secret
<i>test_password</i>	(Optional) User password in test packets

Command Mode

- /exec

show tacacs-server

```
show tacacs-server { <host0> } [ __readonly__ { <host1> } ] [ <tac_port> ] [ <tac_shared_key> ] [ <time_out> ] [ <conn_type> ] [ <tac_idle_time> ] [ <test_user_name> ] <test_pwd> ]
```

Syntax Description

<code>show</code>	Show running system information
<code>tacacs-server</code>	Show TACACS+ configuration information
<i>host0</i>	DNS name or IP address
<code>__readonly__</code>	(Optional)
<i>host1</i>	(Optional) DNS name or IP address
<i>tac_port</i>	(Optional) TACACS+ server port
<i>tac_shared_key</i>	(Optional) TACACS+ shared secret
<i>time_out</i>	(Optional) radius server timeout
<i>conn_type</i>	(Optional) TACACS+ connection type
<i>test_user_name</i>	(Optional) User name in test packets
<i>test_pwd</i>	(Optional) User password in test packets
<i>tac_idle_time</i>	(Optional) Time interval for monitoring the server

Command Mode

- /exec

show tacacs-server directed-request

show tacacs-server directed-request [__readonly__ { <tacacs_directedRequest_status> }]

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
directed-request	Show directed server enable configuration
__readonly__	(Optional)
<i>tacacs_directedRequest_status</i>	(Optional) status of tacacs-server directed request

Command Mode

- /exec

show tacacs-server groups

```
show tacacs-server groups [ <s0> ] [ __readonly__ [ <num_of_groups> ] [ TABLE_group <group_name> [
TABLE_server <server_ip> [ <port> ] ] [ <dead_time> ] [ <vrf_name> ] [ <source_interface> ] ] ]
```

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
groups	Show TACACS+ server group configuration information
<i>s0</i>	(Optional) TACACS+ server group name
<i>__readonly__</i>	(Optional)
<i>num_of_groups</i>	(Optional) number of groups
TABLE_group	(Optional)
<i>group_name</i>	(Optional) name of the group
TABLE_server	(Optional)
<i>server_ip</i>	(Optional) DNS name or IP address
<i>port</i>	(Optional) TACACS+ server port
<i>dead_time</i>	(Optional) Time interval for which the server is marked as dead before sending a test command
<i>vrf_name</i>	(Optional) name of the vrf
<i>source_interface</i>	(Optional) Interface Description

Command Mode

- /exec

show tacacs-server sorted

```
show tacacs-server sorted [ __readonly__ [ <global_secretKey> ] { <global_timeout> <global_deadtime> }
[ <global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [ <global_testPassword> ] } {
<server_count> } [ TABLE_server <server_ip> <port> [ <secretKey> ] [ <timeout> ] ] ]
```

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
sorted	Show TACACS+ servers sorted by server name
<i>__readonly__</i>	(Optional)
<i>global_secretKey</i>	(Optional) Global shared secret
<i>global_timeout</i>	(Optional) Global timeout for tacacs
<i>global_deadtime</i>	(Optional) Global deadtime
<i>global_source_intf</i>	(Optional) Tacacs global source interface
<i>global_idle_time</i>	(Optional) Tacacs global idle-time for server monitoring
<i>global_testUsername</i>	(Optional) Username of global test parameters
<i>global_testPassword</i>	(Optional) Password of global test parameters
<i>server_count</i>	(Optional) Total number of tacacs servers configured
TABLE_server	(Optional)
<i>server_ip</i>	(Optional) Ip address of the server
<i>port</i>	(Optional) Port used for this server
<i>secretKey</i>	(Optional) Shared secret between the server and the tacacs client
<i>timeout</i>	(Optional) Timeout for this tacacs server

Command Mode

- /exec

show tacacs-server statistics

```
show tacacs-server statistics { <host0> } [ __readonly__ { <server_state> [ <clock_time> { monitoring_statistics
<time_in_pstate> <ndead> <tt_in_dstate> } ] } { auth_statistics <auth_failed_transactions>
<auth_succ_transactions> <auth_req_sent> <auth_req_timedout> <auth_resp_no_match>
<auth_resp_not_processed> <auth_resp_error> } { autho_statistics <autho_failed_transactions>
<autho_succ_transactions> <autho_req_sent> <autho_req_timedout> <autho_resp_no_match>
<autho_resp_not_processed> <autho_resp_error> } { acct_statistics <acct_failed_transactions>
<acct_succ_transactions> <acct_req_sent> <acct_req_timedout> <acct_resp_no_match>
<acct_resp_not_processed> <acct_resp_error> } ]
```

Syntax Description

show	Show running system information
tacacs-server	Show TACACS+ configuration information
statistics	Show TACACS statistics
<i>host0</i>	DNS name or IP address
<i>__readonly__</i>	(Optional)
<i>server_state</i>	(Optional) Show state of server
<i>clock_time</i>	(Optional) Show clock time in terms of hours, minutes and seconds
<i>monitoring_statistics</i>	(Optional) Monitoring Statistics
<i>time_in_pstate</i>	(Optional) Time in previous state
<i>ndead</i>	(Optional) Number of times dead
<i>tt_in_dstate</i>	(Optional) Total time in dead state
<i>auth_statistics</i>	(Optional) Authentication Statistics
<i>autho_statistics</i>	(Optional) Authorization Statistics
<i>acct_statistics</i>	(Optional) Accounting Statistics
<i>auth_failed_transactions</i>	(Optional) Authentication: Failed transactions
<i>auth_succ_transactions</i>	(Optional) Authentication: Successful transactions
<i>auth_req_sent</i>	(Optional) Authentication: Requests sent
<i>auth_req_timedout</i>	(Optional) Authentication: Requests timedout
<i>auth_resp_no_match</i>	(Optional) Authentication: Responses with no matching requests
<i>auth_resp_not_processed</i>	(Optional) Authentication: Responses not processed
<i>auth_resp_error</i>	(Optional) Authentication: Responses containing errors

<i>autho_failed_transactions</i>	(Optional) Authorization: Failed transactions
<i>autho_succ_transactions</i>	(Optional) Authorization: Successful transactions
<i>autho_req_sent</i>	(Optional) Authorization: Requests sent
<i>autho_req_timedout</i>	(Optional) Authorization: Requests timedout
<i>autho_resp_no_match</i>	(Optional) Authorization: Responses with no matching requests
<i>autho_resp_not_processed</i>	(Optional) Authorization: Responses not processed
<i>autho_resp_error</i>	(Optional) Authorization: Responses containing errors
<i>acct_failed_transactions</i>	(Optional) Accounting: Failed transactions
<i>acct_succ_transactions</i>	(Optional) Accounting: Successful transactions
<i>acct_req_sent</i>	(Optional) Accounting: Requests sent
<i>acct_req_timedout</i>	(Optional) Accounting: Requests timedout
<i>acct_resp_no_match</i>	(Optional) Accounting: Responses with no matching requests
<i>acct_resp_not_processed</i>	(Optional) Accounting: Responses not processed
<i>acct_resp_error</i>	(Optional) Accounting: Responses containing errors

Command Mode

- /exec

show tech-support

show tech-support [time-optimized] [forced]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
time-optimized	(Optional) Gather tech-support faster, requires more memory and disk space
forced	(Optional) Do not check for standby being present

Command Mode

- /exec

show tech-support aaa

show tech-support aaa

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
aaa	Display aaa information

Command Mode

- /exec

show tech-support aclmgr

show tech-support aclmgr [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclmgr	ACL commands
detail	(Optional) Detailed Tech Support

Command Mode

- /exec

show tech-support aclmgr compressed

show tech-support aclmgr compressed <uri0> [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclmgr	ACL commands
compressed	Save compressed aclqos technical support
<i>uri0</i>	Enter filename to store
detail	(Optional) Detailed Tech Support

Command Mode

- /exec

show tech-support aclqos

show tech-support aclqos

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclqos	Show information for aclqos technical support

Command Mode

- /exec

show tech-support aclqos compressed

show tech-support aclqos compressed <uri0>

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
aclqos	Show information for aclqos technical support
compressed	Save compressed aclqos technical support
<i>uri0</i>	Enter filename to store

Command Mode

- /exec

show tech-support adjmgr

show tech-support adjmgr [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
adjmgr	Display Adjmgr information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support all-binary

show tech-support all-binary

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
all-binary	Dump tech support for all applications in binary

Command Mode

- /exec

show tech-support all

show tech-support all [space-optimized] [time-optimized]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
all	Gather detailed information for troubleshooting
space-optimized	(Optional) Gather tech-support info. using less memory and disk space
time-optimized	(Optional) Gather tech-support faster, requires more memory and disk space

Command Mode

- /exec

show tech-support analytics

show tech-support analytics [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
analytics	Show Analytics tech-support information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support arp

show tech-support arp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
arp	Display ARP information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ascii-cfg

show tech-support ascii-cfg

Syntax Description

show	Show running system information
tech-support	Show information for technical support personnel
ascii-cfg	Show ascii-cfg information for technical support personnel

Command Mode

- /exec

show tech-support assoc_mgr

show tech-support assoc_mgr

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
assoc_mgr	Gather detailed information for assoc_mgr troubleshooting

Command Mode

- /exec

show tech-support backup

show tech-support { backup | flexlink }

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
backup	Gather detailed information for Switchport Backup troubleshooting
flexlink	Gather detailed information for Switchport Backup troubleshooting

Command Mode

- /exec

show tech-support bcm

show tech-support bcm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bcm	bcm hardware info

Command Mode

- /exec

show tech-support bfd

show tech-support bfd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bfd	BFD commands

Command Mode

- /exec

show tech-support bgp

show tech-support bgp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bgp	Display BGP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support biosd

show tech-support biosd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
biosd	Gather bios install log for trouble shooting

Command Mode

- /exec

show tech-support bloggerd-all

show tech-support bloggerd-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bloggerd-all	Gather detailed information for bloggerd troubleshooting from ALL modules

Command Mode

- /exec

show tech-support bloggerd

show tech-support bloggerd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bloggerd	Gather detailed information for bloggerd troubleshooting

Command Mode

- /exec

show tech-support bootvar

show tech-support bootvar

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
bootvar	Gather detailed information for bootvar troubleshooting

Command Mode

- /exec

show tech-support brief

show tech-support brief

Syntax Description

show	Show running system summary information
tech-support	Gather information for troubleshooting
brief	Gather summary information for troubleshooting

Command Mode

- /exec

show tech-support callhome

show tech-support callhome

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
callhome	callhome troubleshooting information

Command Mode

- /exec

show tech-support cdp

show tech-support cdp

Syntax Description

show	show running system information
tech-support	Gather information for troubleshooting
cdp	Gather information for CDP trouble shooting

Command Mode

- /exec

show tech-support cert-enroll

show tech-support cert-enroll

Syntax Description

show	show commands
tech-support	Gather information for troubleshooting
cert-enroll	Display certificates information

Command Mode

- /exec

show tech-support cfs

show tech-support cfs [{ commands | name <cfs-dyn-app-name> [commands1] }]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
cfs	Gather detailed information for cfs troubleshooting
commands	(Optional) CFS show tech commands
name	(Optional) Gather detailed information of cfs for a specified application
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
commands1	(Optional) CFS application show tech commands

Command Mode

- /exec

show tech-support cli

show tech-support cli

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
cli	Gather information for parser troubleshooting

Command Mode

- /exec

show tech-support clis

show tech-support clis [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
clis	Gather information for CLI Server troubleshooting
brief	(Optional) Detailed information

Command Mode

- /exec

show tech-support clock_manager

show tech-support clock_manager

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
clock_manager	Gather detailed information for clock manager troubleshooting

Command Mode

- /exec

show tech-support commands

show tech-support commands

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
commands	Show commands executed as part of show tech-support commands

Command Mode

- /exec

show tech-support controller

show tech-support controller

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
controller	Gather information for Controller troubleshooting

Command Mode

- /exec

show tech-support copp

show tech-support copp

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
copp	Gather information for copp trouble shooting

Command Mode

- /exec

show tech-support dcbx

show tech-support dcbx

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
dcbx	Gather detailed information for DCBX component

Command Mode

- /exec

show tech-support details

show tech-support details [space-optimized] [time-optimized]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
details	Gather detailed information for troubleshooting
space-optimized	(Optional) Gather tech-support info. using less memory and disk space
time-optimized	(Optional) Gather tech-support faster, requires more memory and disk space

Command Mode

- /exec

show tech-support dhclient

show tech-support dhclient

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
dhclient	Gather information for dhclient trouble shooting

Command Mode

- /exec

show tech-support dhcp

show tech-support dhcp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
dhcp	Gather detailed information for dhcp troubleshooting

Command Mode

- /exec

show tech-support dme

show tech-support dme

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
dme	Gather detailed information for dme troubleshooting

Command Mode

- /exec

show tech-support dot1x

show tech-support dot1x

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
dot1x	Display dot1x information

Command Mode

- /exec

show tech-support ecp

show tech-support ecp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ecp	ECP (Edge Control Protocol)

Command Mode

- /exec

show tech-support eem

show tech-support eem

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
eem	Show EEM tech-support information

Command Mode

- /exec

show tech-support eigrp

show tech-support eigrp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
eigrp	Display EIGRP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support eltm

show tech-support eltm [detail]

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
eltm	eltm debug info
detail	(Optional) Detailed information

Command Mode

- /exec

show tech-support ethpm

show tech-support ethpm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ethpm	Gather detailed information for ETHPM troubleshooting

Command Mode

- /exec

show tech-support ethport

show tech-support ethport

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ethport	Gather detailed information for ETHPORT troubleshooting

Command Mode

- /exec

show tech-support evb

show tech-support evb

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
evb	EVB (Edge Virtual Bridge)

Command Mode

- /exec

show tech-support fabric forwarding

show tech-support fabric forwarding

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)

Command Mode

- /exec

show tech-support fabric multicast

show tech-support fabric multicast

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fabric	Fabric
multicast	Multicast information

Command Mode

- /exec

show tech-support fast-reload

show tech-support fast-reload

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fast-reload	Gather information for troubleshooting fast-reload timings

Command Mode

- /exec

show tech-support fc2

show tech-support fc2 [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fc2	Show information for fc2 technical support
commands	(Optional) Show commands run as part of fc2 technical support

Command Mode

- /exec

show tech-support fcoe

show tech-support fcoe

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fcoe	Gather information for FCOE mgr trouble shooting

Command Mode

- /exec

show tech-support fips

show tech-support fips

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
fips	show tech support information for security

Command Mode

- /exec

show tech-support forwarding l2 multicast

show tech-support forwarding l2 multicast

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l2	layer 2 debug information
multicast	multicast

Command Mode

- /exec

show tech-support forwarding l2 multicast vdc-all

show tech-support forwarding l2 multicast vdc-all

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l2	layer 2 debug information
multicast	multicast
vdc-all	vdc-all

Command Mode

- /exec

show tech-support forwarding l2 unicast

show tech-support forwarding l2 unicast [module <module>]

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
forwarding	Forwarding debug info
l2	layer 2 debug info
unicast	unicast
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support forwarding l3 multicast

show tech-support forwarding l3 multicast

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
multicast	multicast

Command Mode

- /exec

show tech-support forwarding l3 multicast detail vdc-all

show tech-support forwarding l3 multicast detail vdc-all

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
multicast	multicast
detail	detail
vdc-all	vdc-all

Command Mode

- /exec

show tech-support forwarding l3 multicast detail

show tech-support forwarding l3 multicast detail

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
multicast	multicast
detail	detail

Command Mode

- /exec

show tech-support forwarding l3 multicast vdc-all

show tech-support forwarding l3 multicast vdc-all

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
multicast	multicast
vdc-all	vdc-all

Command Mode

- /exec

show tech-support forwarding l3 unicast

show tech-support forwarding l3 unicast [module <module>]

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
unicast	unicast
module	(Optional) module
<i>module</i>	(Optional) module number

Command Mode

- /exec

show tech-support forwarding l3 unicast detail

show tech-support forwarding l3 unicast detail [module <module>]

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
unicast	unicast
detail	detailed show tech including platform commands
module	(Optional) module
<i>module</i>	(Optional) module number

Command Mode

- /exec

show tech-support forwarding l3 unicast detail vdc-all

show tech-support forwarding l3 unicast detail vdc-all [module <module>]

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
unicast	unicast
detail	detailed show tech including platform commands
vdc-all	vdc-all
module	(Optional) module
<i>module</i>	(Optional) module number

Command Mode

- /exec

show tech-support forwarding l3 unicast vdc-all

show tech-support forwarding l3 unicast vdc-all [module <module>]

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
l3	layer 3 debug information
unicast	unicast
vdc-all	vdc-all
module	(Optional) module
<i>module</i>	(Optional) module number

Command Mode

- /exec

show tech-support forwarding multicast

show tech-support forwarding multicast [module <module>]

Syntax Description

show	
tech-support	tech-support information
forwarding	forwarding debug information
multicast	multicast
module	(Optional) module
<i>module</i>	(Optional) module number

Command Mode

- /exec

show tech-support gold

show tech-support gold

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
gold	Show gold tech-support information

Command Mode

- /exec

show tech-support gpixm

show tech-support gpixm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
gpixm	Gather detailed information for GLOBAL-PIXM troubleshooting

Command Mode

- /exec

show tech-support ha

show tech-support ha [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ha	Gather detailed information for HA troubleshooting
commands	(Optional) Show commands executed as part of show tech-support ha commands

Command Mode

- /exec

show tech-support ha module

show tech-support ha module <module>

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ha	Gather detailed information for HA troubleshooting
module	Gather info related to a module
<i>module</i>	Enter module number

Command Mode

- /exec

show tech-support ha standby

show tech-support ha standby [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ha	Gather detailed information for HA troubleshooting
standby	Gather detailed information for HA troubleshooting from standby supervisor
commands	(Optional) Show commands executed as part of show tech-support ha commands

Command Mode

- /exec

show tech-support hardware-telemetry

show tech-support hardware-telemetry

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
hardware-telemetry	Hardware Telemetry Information

Command Mode

- /exec

show tech-support hsrp

show tech-support hsrp

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
hsrp	Show hsrp tech-support information

Command Mode

- /exec

show tech-support hsrp brief

show tech-support hsrp brief

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
hsrp	Show hsrp tech-support information
brief	Show tech-support information in brief

Command Mode

- /exec

show tech-support icam

show tech-support icam [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
icam	icam - TCAM Analytics
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support icmpv6

show tech-support icmpv6 [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
icmpv6	Display Icmpv6 information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support im

show tech-support im

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
im	Gather detailed information for IM troubleshooting

Command Mode

- /exec

show tech-support imp

show tech-support imp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
imp	IMP commands

Command Mode

- /exec

show tech-support inband counters

show tech-support inband counters

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
inband	Gather all information about inband data path
counters	Gather all counters in inband data path

Command Mode

- /exec

show tech-support include-time

show tech-support include-time

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
include-time	Gather tech-support and capture time taken to execute each command

Command Mode

- /exec

show tech-support install

show tech-support install

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
install	Gather detailed information for rpm/package install operation

Command Mode

- /exec

show tech-support interface-vlan

show tech-support interface-vlan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
interface-vlan	Gather detailed information for interface-vlan troubleshooting

Command Mode

- /exec

show tech-support ip

show tech-support ip [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip igmp

show tech-support ip igmp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
igmp	Display IGMP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip igmp snooping

show tech-support ip igmp snooping [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
igmp	Display IGMP status and configuration
snooping	IGMP Snooping information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip msdp

show tech-support ip msdp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
msdp	Display MSDP status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ip pim

show tech-support ip pim [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	Display IP information
pim	PIM global configuration commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ipqos

show tech-support ipqos [server-only] [all] [snmp]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
server-only	(Optional) Dump the tech-support information only from IP QoS Manager server only
all	(Optional) Dump the tech-support information IP QoS Manager plus brief summary of system
snmp	(Optional) Dump the tech-support information only from IP QoS Manager server only (SNMP only)

Command Mode

- /exec

show tech-support ipv6

show tech-support ipv6 [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ipv6	Display IPV6 information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ipv6 mld

show tech-support ipv6 mld [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ipv6	Display IPv6 information
mld	Display Multicast Listener Discovery information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ipv6 multicast

show tech-support ipv6 multicast

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ipv6	Display IPv6 information
multicast	Display V6 Multicast information

Command Mode

- /exec

show tech-support ipv6 pim

show tech-support ipv6 pim [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ipv6	Display IPv6 information
pim	PIM6 global configuration commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support isis

show tech-support isis [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
isis	IS-IS events
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support issu

show tech-support issu [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
issu	Gather detailed information for issu troubleshooting
commands	(Optional) Show commands executed as part of show tech-support issu command

Command Mode

- /exec

show tech-support kstack

show tech-support kstack

Syntax Description

show	
tech-support	tech-support information
kstack	kstack information

Command Mode

- /exec

show tech-support l2

show tech-support l2

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2	Gather detailed information for layer 2 troubleshooting

Command Mode

- /exec

show tech-support l2fm

show tech-support l2fm

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
l2fm	l2fm debug info

Command Mode

- /exec

show tech-support l2fm clients

show tech-support l2fm clients [module <module>]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2fm	l2fm debug info
clients	debug info of l2fm clients only running on linecard(mtm)
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2fm detail

show tech-support l2fm detail [module <module>]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2fm	l2fm debug info
detail	All info related to l2fm
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2fm l2dbg

show tech-support l2fm l2dbg [module <module>]

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
l2fm	l2fm debug info
l2dbg	tech support capturing additional debug info for l2fm(l2dbg)
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2fm l2dbg

show tech-support l2fm l2dbg [module <module>]

Syntax Description

show	show tech-support
tech-support	Gather information for trouble-shooting
l2fm	l2fm debug info
l2dbg	tech support capturing additional debug info for l2fm(l2dbg)
module	(Optional) Slot number
<i>module</i>	(Optional) Module Number

Command Mode

- /exec

show tech-support l2rib

show tech-support l2rib

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l2rib	Display L2RIB information

Command Mode

- /exec

show tech-support l3vm

show tech-support l3vm [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l3vm	Display VRF information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support l3vpn

show tech-support l3vpn [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
l3vpn	BGP l3vpn information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support lacp

show tech-support lacp [all]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lacp	Gather detailed information for LACP component
all	(Optional) Gather detailed information of LACP and related components

Command Mode

- /exec

show tech-support ldap

show tech-support ldap

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
ldap	Display ldap information

Command Mode

- /exec

show tech-support license

show tech-support license

Syntax Description

show	show commands
tech-support	Gather information for troubleshooting
license	Display licensing information

Command Mode

- /exec

show tech-support lim

show tech-support lim

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lim	Gather detailed information for LIM troubleshooting

Command Mode

- /exec

show tech-support lisp

show tech-support lisp [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lisp	LISP show commands
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support lldp

show tech-support lldp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
lldp	Gather detailed information for LLDP troubleshooting

Command Mode

- /exec

show tech-support logging

show tech-support logging

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
logging	Show information on logging for technical support staff

Command Mode

- /exec

show tech-support m2rib

show tech-support m2rib

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
m2rib	Gather detailed information for M2RIB troubleshooting

Command Mode

- /exec

show tech-support mfwd

show tech-support mfwd [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mfwd	Display MCASTFWD status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support mmode

show tech-support mmode

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mmode	Gather information for troubleshooting mmode

Command Mode

- /exec

show tech-support module

show tech-support module <module>

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
module	Gather info related to a module
<i>module</i>	Enter module number

Command Mode

- /exec

show tech-support module all

show tech-support module all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
module	Gather info related to a module
all	Gather info related to all modules in the system

Command Mode

- /exec

show tech-support monitor

show tech-support monitor

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
monitor	Gather detailed information for monitor troubleshooting

Command Mode

- /exec

show tech-support monitor erspan

show tech-support monitor erspan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
monitor	Gather detailed information for monitor troubleshooting
erspan	Gather detailed information for erspan session troubleshooting

Command Mode

- /exec

show tech-support monitorc-all

show tech-support monitorc-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
monitorc-all	Gather detailed information for LC MONITORC troubleshooting

Command Mode

- /exec

show tech-support multicast-vxlan-evpn

show tech-support multicast-vxlan-evpn

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
multicast-vxlan-evpn	Multicast VxLAN EVPN feature

Command Mode

- /exec

show tech-support multicast

show tech-support [ip | ipv4] multicast

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display V4 Multicast information

Command Mode

- /exec

show tech-support mvpn

show tech-support mvpn [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
mvpn	Display Multicast VPN information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support nat

show tech-support nat

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
nat	Gather information for troubleshooting NAT

Command Mode

- /exec

show tech-support nbm

show tech-support nbm [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble-shooting
nbm	Non Blocking Multicast
brief	(Optional) Minimal information

Command Mode

- /exec

show tech-support netstack

show tech-support netstack

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
netstack	Gather information for NETSTACK troubleshooting

Command Mode

- /exec

show tech-support netstack detail

show tech-support netstack detail

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
netstack	Gather information for NETSTACK troubleshooting
detail	Gather detailed information for NETSTACK troubleshooting

Command Mode

- /exec

show tech-support ngoam

show tech-support ngoam

Syntax Description

show	Show running system information
tech-support	Gather information for trouble-shooting
ngoam	ngoam

Command Mode

- /exec

show tech-support npacl

show tech-support npacl [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
npacl	Display npacl information
brief	(Optional) Brief npacl information

Command Mode

- /exec

show tech-support npv

show tech-support npv

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
npv	Show information for NPV technical support staff

Command Mode

- /exec

show tech-support ns

show tech-support ns

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ns	Gather detailed information for northstar asic

Command Mode

- /exec

show tech-support ntp

show tech-support ntp

Syntax Description

show	show running system information
tech-support	Gather information for trouble shooting
ntp	Gather information for NTP trouble shooting

Command Mode

- /exec

show tech-support nxapi

show tech-support nxapi

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
nxapi	Gather detailed information for nxapi troubleshooting

Command Mode

- /exec

show tech-support nxsdk

show tech-support nxsdk

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
nxsdk	NXOS SDK

Command Mode

- /exec

show tech-support object-store

show tech-support object-store

Syntax Description

show	Show Object Store
tech-support	Gather information for troubleshooting
object-store	Gather information from object store for Controller troubleshooting

Command Mode

- /exec

show tech-support openflow

show tech-support openflow [brief | detailed]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
openflow	Show tech support for OpenFlow
brief	(Optional) Brief information
detailed	(Optional) Detailed information

Command Mode

- /exec

show tech-support ospf

show tech-support ospf [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ospf	Display OSPF status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support ospfv3

show tech-support ospfv3 [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ospfv3	Display OSPFv3 status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support page

show tech-support page [time-optimized] [forced]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
page	Page through the output
time-optimized	(Optional) Gather tech-support faster, requires more memory and disk space
forced	(Optional) Do not check for standby being present

Command Mode

- /exec

show tech-support patch

show tech-support patch

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
patch	Gather detailed information for patch troubleshooting

Command Mode

- /exec

show tech-support pbr

{ show tech-support pbr }

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pbr	Display Policy Based Routing (PBR) information

Command Mode

- /exec

show tech-support pfstat

show tech-support pfstat

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pfstat	Gather detailed information for pfstat troubleshooting

Command Mode

- /exec

show tech-support pixm-all

show tech-support pixm-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pixm-all	Gather detailed information for PIXM troubleshooting

Command Mode

- /exec

show tech-support pixm

show tech-support pixm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pixm	Gather detailed information for vdc-local-PIXM troubleshooting

Command Mode

- /exec

show tech-support pixmc-all

show tech-support pixmc-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pixmc-all	Gather detailed information for LC PIXMC troubleshooting

Command Mode

- /exec

show tech-support pktmgr

show tech-support pktmgr [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pktmgr	Display Packet Manager information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support platform-sdk

show tech-support platform-sdk

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
platform-sdk	Gather detailed information for platform-sdk troubleshooting

Command Mode

- /exec

show tech-support platform

show tech-support platform

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
platform	Get platform related information

Command Mode

- /exec

show tech-support platform

show tech-support platform

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
platform	Get platform related information

Command Mode

- /exec

show tech-support plb-services

show tech-support plb-services [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
plb-services	PLB Services
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support plcmgr

show tech-support plcmgr [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
plcmgr	Policy Manager
detail	(Optional) Print more details (e.g. messages,etc)

Command Mode

- /exec

show tech-support pltfm-config

show tech-support pltfm-config

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
pltfm-config	Gather detailed information for pltfm-config troubleshooting

Command Mode

- /exec

show tech-support poe

show tech-support poe

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
poe	Gather information for PoE trouble shooting

Command Mode

- /exec

show tech-support port-channel

show tech-support port-channel

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port-channel	Gather detailed information for port channel troubleshooting

Command Mode

- /exec

show tech-support port-client-all

show tech-support port-client-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port-client-all	Gather detailed information for LC port client troubleshooting

Command Mode

- /exec

show tech-support port-profile

show tech-support port-profile

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port-profile	Gather information for troubleshooting port-profiles

Command Mode

- /exec

show tech-support port-security

show tech-support port-security

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
port-security	Port security related command

Command Mode

- /exec

show tech-support port

show tech-support port

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
port	Gather detailed information for port manager troubleshooting

Command Mode

- /exec

show tech-support private-vlan

show tech-support private-vlan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
private-vlan	Gather detailed information for private-vlan troubleshooting

Command Mode

- /exec

show tech-support ptp

show tech-support ptp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
ptp	Gather detailed information for PTP troubleshooting

Command Mode

- /exec

show tech-support radius

show tech-support radius

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting
radius	Display radius information

Command Mode

- /exec

show tech-support rip

show tech-support rip [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
rip	Display RIP routing protocol status
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support routing

show tech-support routing [ip | ipv4] [unicast] [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
unicast	(Optional) Display unicast routing information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support routing ipv6

show tech-support routing ipv6 [unicast] [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
routing	Display routing information
ipv6	Display IPv6 information
unicast	(Optional) Display unicast routing information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support routing ipv6 multicast

show tech-support routing ipv6 multicast [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
routing	Display routing information
ipv6	Display IPv6 information
multicast	Display V6 Multicast information
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support routing multicast

show tech-support routing [ip | ipv4] multicast [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
routing	Display routing information
ip	(Optional) Display IP information
ipv4	(Optional) Display IP information
multicast	Display V4 Multicast information
brief	(Optional) Display brief information

Command Mode

- /exec

show tech-support rpm

{ show tech-support rpm }

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
rpm	Display Route Policy Manager (RPM) information

Command Mode

- /exec

show tech-support sal

show tech-support sal

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
sal	Show SAL tech-support information

Command Mode

- /exec

show tech-support san-port-channel

show tech-support san-port-channel

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
san-port-channel	Gather detailed information for san port channel troubleshooting

Command Mode

- /exec

show tech-support san

show tech-support san

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
san	Gather information for SAN trouble shooting

Command Mode

- /exec

show tech-support satmgr

show tech-support satmgr

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
satmgr	Gather detailed information for satmgr troubleshooting

Command Mode

- /exec

show tech-support security

show tech-support security

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
security	show tech support information for security

Command Mode

- /exec

show tech-support services

show tech-support services [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
services	Services
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support session-mgr

show tech-support session-mgr

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
session-mgr	Gather information for troubleshooting session manager

Command Mode

- /exec

show tech-support sflow

show tech-support sflow

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sflow	Gather detailed information for sflow feature

Command Mode

- /exec

show tech-support single-jericho

show tech-support single-jericho

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
single-jericho	Gather detailed information for single-jericho troubleshooting

Command Mode

- /exec

show tech-support sksd

show tech-support sksd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sksd	show tech support information for sksd

Command Mode

- /exec

show tech-support sla responder

show tech-support sla responder [brief | detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
sla	Service Level Agreement (SLA)
responder	Configure sla-responder tech support
brief	(Optional) Show less details
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support sla sender

show tech-support sla sender [brief | detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
sla	Service Level Agreement (SLA)
sender	Configure sla-sender tech support
brief	(Optional) Show less details
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support sla twamp-server

show tech-support sla twamp-server [brief | detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
sla	Service Level Agreement (SLA)
twamp-server	Configure sla-twamp-server tech support
brief	(Optional) Show less details
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support smartc

show tech-support smartc [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
smartc	smartc channel services
detail	(Optional) Show more details

Command Mode

- /exec

show tech-support smm

show tech-support smm

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
smm	Shared memory

Command Mode

- /exec

show tech-support snmp

show tech-support snmp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
snmp	Gather info related to snmp

Command Mode

- /exec

show tech-support sockets

show tech-support sockets [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sockets	Display sockets status and configuration
brief	(Optional) Brief information

Command Mode

- /exec

show tech-support spm

show tech-support spm [<application>] [detail]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
spm	Service Policy Manager
<i>application</i>	(Optional) Specify an application
detail	(Optional) Print more details (e.g. messages,etc)

Command Mode

- /exec

show tech-support srte

show tech-support srte

Syntax Description

show	Show running system information
tech-support	Gather SRTE information
srte	Segment-Routing Traffic Eng

Command Mode

- /exec

show tech-support statsclient

show tech-support statsclient [module <module>]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
statsclient	Gather statsclient tech-support
module	(Optional) Gather info related to one module
<i>module</i>	(Optional) Enter module number

Command Mode

- /exec

show tech-support stp

show tech-support stp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
stp	Gather detailed information for STP troubleshooting

Command Mode

- /exec

show tech-support sup-filesys

show tech-support sup-filesys

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sup-filesys	File-sys related issue

Command Mode

- /exec

show tech-support sysmgr

show tech-support sysmgr [commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
sysmgr	Gather detailed information for sysmgr troubleshooting
commands	(Optional) Show commands executed as part of show tech-support sysmgr

Command Mode

- /exec

show tech-support tacacs

show tech-support tacacs +

Syntax Description

show	show tech-support
tech-support	Gather information for troubleshooting

Command Mode

- /exec

show tech-support track

show tech-support track

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
track	Show track tech-support information

Command Mode

- /exec

show tech-support tunnel

show tech-support tunnel [{ commands | detail [commands1] }]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
tunnel	Gather detailed information for tunnel troubleshooting
commands	(Optional) Lists commands under 'show tunnel tech-support' command
detail	(Optional) Gather detailed information for tunnel troubleshooting
commands1	(Optional) Lists commands under 'Show tech-support tunnel detail' commands

Command Mode

- /exec

show tech-support u2rib

show tech-support u2rib

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
u2rib	Gather detailed information for U2RIB troubleshooting

Command Mode

- /exec

show tech-support udd

show tech-support udd

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
udd	Gather detailed information for udd troubleshooting

Command Mode

- /exec

show tech-support usd-all

show tech-support usd-all

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
usd-all	Gather detailed information for LC USD troubleshooting

Command Mode

- /exec

show tech-support vdc

show tech-support vdc

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vdc	Gather detailed information for VDC troubleshooting

Command Mode

- /exec

show tech-support virtual-service

show tech-support virtual-service

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
virtual-service	Gather information for virtualization services trouble shooting

Command Mode

- /exec

show tech-support vlan

show tech-support vlan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vlan	Gather detailed information for VLAN troubleshooting

Command Mode

- /exec

show tech-support vmtracker

show tech-support vmtracker

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vmtracker	VMTRACKER commands

Command Mode

- /exec

show tech-support vpc

show tech-support vpc

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vpc	Gather detailed information for VPC troubleshooting

Command Mode

- /exec

show tech-support vrrp

show tech-support vrrp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vrrp	Show information for vrrp technical support

Command Mode

- /exec

show tech-support vrrp brief

show tech-support vrrp brief

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vrrp	Show information for vrrp technical support
brief	Show information for vrrp technical support in brief

Command Mode

- /exec

show tech-support vrrpv3

show tech-support vrrpv3 [detail]

Syntax Description

vrrpv3	VRRPv3 configuration commands
show	Show running system information
tech-support	Gather information for trouble shooting
detail	(Optional) Detailed output

Command Mode

- /exec

show tech-support vsan

show tech-support vsan [<i0> | commands]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vsan	Gather detailed information for vsan troubleshooting
<i>i0</i>	(Optional) VSAN id range
commands	(Optional) Show commands run as part of vsan technical support

Command Mode

- /exec

show tech-support vshd

show tech-support vshd

Syntax Description

show	Show running system information
tech-support	Show information for technical support
vshd	Show vshd information for technical support

Command Mode

- /exec

show tech-support vtp

show tech-support vtp

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vtp	Gather detailed information for vtp troubleshooting

Command Mode

- /exec

show tech-support vvlan

show tech-support vvlan

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
vvlan	Gather detailed information for Voice VLAN troubleshooting

Command Mode

- /exec

show tech-support xbar

show tech-support xbar

Syntax Description

show	Show running system information
tech-support	Gather information for trouble shooting
xbar	Show xbar tech-support information

Command Mode

- /exec

show tech-support xml

show tech-support xml

Syntax Description

show	show running system information
tech-support	Gather information for trouble shooting
xml	Gather information for xml trouble shooting

Command Mode

- /exec

show tech-support xos

show tech-support xos [brief]

Syntax Description

show	Show running system information
tech-support	Gather information for troubleshooting
xos	Cross-OS Library Information and Traces
brief	(Optional) Brief information

Command Mode

- /exec

show telnet server

```
show telnet server [ __readonly__ { operation_status <o_status> } ]
```

Syntax Description

show	Show running system information
telnet	Show telnet server configuration
server	Show telnet server configuration
__readonly__	(Optional)
operation_status	(Optional) run-time information about telnet
<i>o_status</i>	(Optional) operational status of telnet server

Command Mode

- /exec

show terminal

```
show terminal [ __readonly__ { <terminal_tty> } { <terminal_type> } { <terminal_length> } {
<terminal_width> } { <session_timeout> } { <evnt_mgr_cli_evnt_bypass> } { <redirection_mode> } {
<acc_log_all_commands> } [ <vlan_mutex_value> ] { <vlan_batch_mode> } ]
```

Syntax Description

show	Show running system information
terminal	Display terminal configuration parameters
<i>__readonly__</i>	(Optional)
<i>terminal_tty</i>	(Optional)
<i>terminal_type</i>	(Optional)
<i>terminal_length</i>	(Optional)
<i>terminal_width</i>	(Optional)
<i>session_timeout</i>	(Optional)
<i>evnt_mgr_cli_evnt_bypass</i>	(Optional)
<i>redirection_mode</i>	(Optional)
<i>acc_log_all_commands</i>	(Optional)
<i>vlan_mutex_value</i>	(Optional)
<i>vlan_batch_mode</i>	(Optional)

Command Mode

- /exec

show terminal output xml version

show terminal output xml version [__readonly__ { xml_version <version> }]

Syntax Description

show	Show running system information
terminal	Display
output	Display
xml	Display
version	Display
__readonly__	(Optional)
xml_version	(Optional) xml version
<i>version</i>	(Optional) version

Command Mode

- /exec

show time-range

```
show time-range [ <name> ] [ __readonly__ TABLE_timerange <timerange_name> <active> [ TABLE_seqno
<seqno> { { absolute [ <start_abs_h> <start_abs_m> <start_abs_s> <start_abs_d> <start_abs_mon>
<start_abs_y> ] [ <end_abs_h> <end_abs_m> <end_abs_s> <end_abs_d> <end_abs_mon> <end_abs_y> ]
} | { periodic { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday | daily | weekdays |
weekend } + <start_per_h> <start_per_m> <start_per_s> [ <eday> ] <end_per_h> <end_per_m> <end_per_s>
} | { <remark> } } ] ] ]
```

Syntax Description

show	Show running system information
time-range	Define time range entries
<i>name</i>	(Optional) Time range name
<i>__readonly__</i>	(Optional)
TABLE_timerange	(Optional)
<i>timerange_name</i>	(Optional)
<i>active</i>	(Optional) active
TABLE_seqno	(Optional)
<i>seqno</i>	(Optional) Sequence number
absolute	(Optional)
periodic	(Optional)
<i>remark</i>	(Optional)
<i>start_abs_h</i>	(Optional)
<i>start_abs_m</i>	(Optional)
<i>start_abs_s</i>	(Optional)
<i>start_abs_d</i>	(Optional)
<i>start_abs_mon</i>	(Optional)
<i>start_abs_y</i>	(Optional)
<i>end_abs_h</i>	(Optional)
<i>end_abs_m</i>	(Optional)
<i>end_abs_s</i>	(Optional)
<i>end_abs_d</i>	(Optional)

<i>end_abs_mon</i>	(Optional)
<i>end_abs_y</i>	(Optional)
Monday	(Optional) Monday
Tuesday	(Optional) Tuesday
Wednesday	(Optional) Wednesday
Thursday	(Optional) Thursday
Friday	(Optional) Friday
Saturday	(Optional) Saturday
Sunday	(Optional) Sunday
daily	(Optional) Every day of the week
weekdays	(Optional) Monday thru Friday
weekend	(Optional) Saturday and Sunday
<i>start_per_h</i>	(Optional)
<i>start_per_m</i>	(Optional)
<i>start_per_s</i>	(Optional)
<i>eday</i>	(Optional) Day of the week
<i>end_per_h</i>	(Optional)
<i>end_per_m</i>	(Optional)
<i>end_per_s</i>	(Optional)

Command Mode

- /exec

show time-stamp running-config last-changed

show time-stamp running-config last-changed [__readonly__ <run_config_change_time>]

Syntax Description

show	Show running system information
time-stamp	Time running-config last chnaged
running-config	Current operating configuration
last-changed	Running configuration last changed
__readonly__	(Optional) Read only
<i>run_config_change_time</i>	(Optional) Running-cfg last change timestamp

Command Mode

- /exec

show track

```
show track { [ <object-id> | interface | ip { route | sla } | ipv6 routev6 | list boolean and | list boolean or | list
threshold weight | list threshold percentage ] } [ __readonly__ { <show_track_start> { TABLE_track_detail
<st_obj_id> <st_obj_type> [ <st_obj_instance> ] <st_obj_param> <st_obj_timer_value> [ <st_obj_state> ]
[ <st_obj_chg_cnt> ] [ <st_last_chg_time> ] [ <st_threshold_info> ] [ <st_track_list_obj> ] + [ <st_vrf> ] [
<st_ipsla_rcode> ] [ <st_ipsla_rtt> ] [ <show_track_clnt_hdr> ] [ <show_track_clnt_start> ] [ {
TABLE_track_clnt_info <st_client_name> [ <st_client_iface> ] [ <st_client_group_id> ] [ <st_client_detail>
] } ] [ <show_track_clnt_end> ] [ <st_track_list_info> ] + <st_obj_up_delay> <st_obj_down_delay> }
<show_track_end> } ]
```

Syntax Description

show	Negate a command or set its defaults
track	Tracking information
<i>object-id</i>	(Optional) Tracked object
interface	(Optional) Interface objects
ip	(Optional) IPv4 Protocol objects
route	(Optional) route (ipv4) objects
sla	(Optional) Service Level Agreement objects
ipv6	(Optional) IPv6 Protocol objects
routev6	(Optional) route (ipv6) objects
list	(Optional) Tracklist objects
boolean	(Optional) Boolean Traclist
and	(Optional) AND boolean objects
or	(Optional) OR boolean objects
threshold	(Optional) Threshold parameters
weight	(Optional) Threshold weight
percentage	(Optional) Threshold percentage
__readonly__	(Optional) Read only
<i>show_track_start</i>	(Optional) Show track start
TABLE_track_detail	(Optional) Track table detail
<i>st_obj_id</i>	(Optional) Object id
<i>st_obj_type</i>	(Optional) Object Type

<i>st_obj_instance</i>	(Optional) Object instance
<i>st_obj_param</i>	(Optional) Object parameter
<i>st_obj_timer_value</i>	(Optional) Current value of timer
<i>st_obj_state</i>	(Optional) Object status
<i>st_obj_chg_cnt</i>	(Optional) Count of Object state changes
<i>st_last_chg_time</i>	(Optional) Timestamp of last change
<i>st_threshold_info</i>	(Optional) Threshold Parameters
<i>st_track_list_obj</i>	(Optional) Objects part of this list
<i>st_vrf</i>	(Optional) VRF
<i>st_ipsla_rcode</i>	(Optional) IP SLA Return Code
<i>st_ipsla_rtt</i>	(Optional) IP SLA RTT
<i>show_track_clnt_hdr</i>	(Optional) Tracked by:
<i>show_track_clnt_start</i>	(Optional) Show track client start
TABLE_track_clnt_info	(Optional) Track client info
<i>st_client_name</i>	(Optional) Tracking client name
<i>st_client_iface</i>	(Optional) Tracking client interface
<i>st_client_group_id</i>	(Optional) Client group id
<i>st_client_detail</i>	(Optional) Tracking client detail
<i>show_track_clnt_end</i>	(Optional) End of track client
<i>st_track_list_info</i>	(Optional) Track list info
<i>st_obj_up_delay</i>	(Optional) Delay up notification
<i>st_obj_down_delay</i>	(Optional) Delay down notification
<i>show_track_end</i>	(Optional) End of Track

Command Mode

- /exec

show track brief

```
show track { [ <object-id> | interface | ip { route | sla } | ipv6 routev6 | list boolean and | list boolean or | list
threshold weight | list threshold percentage ] } brief [ __readonly__ { <show_track_brf_start>
<show_track_brf_all_begin> { TABLE_track_brief<st_brf_obj_id><st_brf_obj_type><st_brf_obj_instance>
<st_brf_obj_param><st_brf_obj_state><st_brf_last_chg_time> } <show_track_brf_end> } ]
```

Syntax Description

show	Negate a command or set its defaults
track	Tracking information
<i>object-id</i>	(Optional) Tracked object
interface	(Optional) Interface objects
ip	(Optional) IPv4 Protocol objects
route	(Optional) route (ipv4) objects
sla	(Optional) Service Level Agreement objects
ipv6	(Optional) IPv6 Protocol objects
routev6	(Optional) route (ipv6) objects
list	(Optional) Tracklist objects
boolean	(Optional) Boolean Traclist
and	(Optional) AND boolean objects
or	(Optional) OR boolean objects
threshold	(Optional) Threshold parameters
weight	(Optional) Threshold weight
percentage	(Optional) Threshold percentage
brief	Brief output
<i>__readonly__</i>	(Optional) Read only
<i>show_track_brf_start</i>	(Optional) Show track brief start
<i>show_track_brf_all_begin</i>	(Optional) Start of all brief
TABLE_track_brief	(Optional) Track table brief
<i>st_brf_obj_id</i>	(Optional) Object id
<i>st_brf_obj_type</i>	(Optional) Object Type

<i>st_brf_obj_instance</i>	(Optional) Object instance
<i>st_brf_obj_param</i>	(Optional) Object parameter
<i>st_brf_obj_state</i>	(Optional) Object status
<i>st_brf_last_chg_time</i>	(Optional) Timestamp of last change
<i>show_track_brf_end</i>	(Optional) End of Group

Command Mode

- /exec

show troubleshoot l2 mac vlan

show troubleshoot l2 mac <mac-addr> vlan <vlan-id> [detail]

Syntax Description

show	Show running system information
troubleshoot	Display troubleshoot data dump
l2	Display l2 information
mac	MAC address
<i>mac-addr</i>	address
vlan	Vlan ID
<i>vlan-id</i>	vlan number
detail	(Optional) Print detailed debugging info for mac/interface

Command Mode

- /exec

show troubleshoot l3 ipv4 vrf

```
show troubleshoot l3 { ipv4 <dip4-prefix> [ src-ip <sip4-prefix> ] | ipv6 <dip6-prefix> [ src-ip <sip6-prefix> ] } vrf <vrf-name>
```

Syntax Description

show	
troubleshoot	Display troubleshoot data dump
l3	Display l3 information
ipv4	Choose IPv4 address
ipv6	Choose IPv6 address
<i>dip4-prefix</i>	Display single exact match route for Destination IP
vrf	check routes for a specific VRF
<i>vrf-name</i>	vrf name
src-ip	(Optional) Source IP for routing hash CLI
<i>sip4-prefix</i>	(Optional) Source IPv4 address

Command Mode

- /exec

show trunk protocol

show trunk protocol [*__readonly__* <trunk_protocol_status>]

Syntax Description

show	Show running system information
trunk	Show trunk information
protocol	Show trunk protocol information
<i>__readonly__</i>	(Optional)
<i>trunk_protocol_status</i>	(Optional) trunk protocol status

Command Mode

- /exec

show ttag brief

```
show ttag brief [ __readonly__ [ TABLE_ttag <ttag-ifindex> <state> ] <ttag-end> ]
```

Syntax Description

<code>ttag</code>	enable ingress packet with ttag on this interface
<code>brief</code>	ttag port in brief list
<code>__readonly__</code>	(Optional) Read Only
<code>TABLE_ttag</code>	(Optional) ttag table
<code>ttag-ifindex</code>	(Optional) ttag ifindex
<code>state</code>	(Optional) TTAG state
<code>ttag-end</code>	(Optional) End of table

Command Mode

- /exec

show ttag brief

```
show ttag brief [ __readonly__ { TABLE_ttag <ttag-ifindex> <state> } <ttag-end> ]
```

Syntax Description

<code>ttag</code>	enable ingress packet with ttag on this interface
<code>brief</code>	ttag port in brief list
<code>__readonly__</code>	(Optional) Read Only
<code>TABLE_ttag</code>	(Optional) ttag table
<code>ttag-ifindex</code>	(Optional) ttag ifindex
<code>ttag-end</code>	(Optional) End of table
<code>state</code>	(Optional) TTAG state

Command Mode

- /exec



U Show Commands

- [show uddl](#), on page 2752
- [show uddl global](#), on page 2754
- [show uddl neighbors](#), on page 2755
- [show user-account](#), on page 2756
- [show username keypair](#), on page 2757
- [show userpassphrase](#), on page 2758
- [show users](#), on page 2759

show uddl

```
show uddl [ <if0> ] [ __readonly__ TABLE_interface <interface> <mib-port-status> <mib-oper-status>
<mib-aggressive-mode> <admin-port-mode> <operational-port-mode> <current-bidirectional-state>
<current-operational-state> <no-multiple-neighbor-detected> <message-interval> <timeout-interval>
TABLE_entry [ <entry-number> ] [ <expiration-time> ] [ <device-id> ] [ <neighbor-state> ] [ <device-name>
] [ <port-id> ] [ <neighbor-echo-device-number> ] [ <neighbor-echo-device-name> ] [
<neighbor-echo-port-number> ] [ <neighbor-echo-port-id> ] [ <neighbor-message-interval> ] [
<neighbor-timeout-interval> ] [ <cdp-device-name> ] [ <pkt-xmt-rec-time> ] + [ <pc-index> ] ]
```

Syntax Description

show	Show running system information
uddl	UDLD status and configuration on one or all interfaces
<i>if0</i>	(Optional) Enter an interface name if only one single interface status is desired
<i>__readonly__</i>	(Optional)
TABLE_interface	(Optional)
<i>interface</i>	(Optional) Interface ID
<i>mib-port-status</i>	(Optional) Port MIB enable status
<i>mib-oper-status</i>	(Optional) Port MIB Operational status
<i>mib-aggressive-mode</i>	(Optional) Port MIB aggressive mode
<i>admin-port-mode</i>	(Optional) Port enable administration configuration setting
<i>operational-port-mode</i>	(Optional) Port enable operational state
<i>current-bidirectional-state</i>	(Optional) Current bidirectional state
<i>current-operational-state</i>	(Optional) Current operational state
<i>no-multiple-neighbor-detected</i>	(Optional) No multiple neighbor detected
<i>message-interval</i>	(Optional) UDLD probe message interval
<i>timeout-interval</i>	(Optional) UDLD detection timeout interval
TABLE_entry	(Optional) Neighbor entry info
<i>entry-number</i>	(Optional) Neighbor entry number
<i>expiration-time</i>	(Optional) Expiration time
<i>device-id</i>	(Optional) Device ID
<i>neighbor-state</i>	(Optional) Current neighbor state

<i>device-name</i>	(Optional) Device name
<i>port-id</i>	(Optional) Port ID
<i>neighbor-echo-device-number</i>	(Optional) Echo device number
<i>neighbor-echo-device-name</i>	(Optional) Echo device name
<i>neighbor-echo-port-number</i>	(Optional) Echo port number
<i>neighbor-echo-port-id</i>	(Optional) Echo port ID
<i>neighbor-message-interval</i>	(Optional) UDLD probe message interval
<i>neighbor-timeout-interval</i>	(Optional) UDLD detection timeout interval
<i>cdp-device-name</i>	(Optional) CDP Device name
<i>pkt-xmt-rec-time</i>	(Optional) Last UDLD packet send/rcv time
<i>pc-index</i>	(Optional) Port channel index

Command Mode

- /exec

show udd global

show udd global [__readonly__ <udd-global-mode> <message-interval>]

Syntax Description

show	Show running system information
udd	UDLD protocol
global	UDLD global status and configuration on all interfaces
__readonly__	(Optional)
<i>udd-global-mode</i>	(Optional) UDLD global configuration setting
<i>message-interval</i>	(Optional) UDLD probe message interval

Command Mode

- /exec

show udd neighbors

show udd neighbors [*__readonly__* *TABLE_entry* <local-port-id> <neighbor-echo-device-name> <device-id> <neighbor-echo-port-id> <neighbor-state>]

Syntax Description

show	Show running system information
udd	UDLD protocol
neighbors	UDLD neighbor interfaces
<i>__readonly__</i>	(Optional)
<i>TABLE_entry</i>	(Optional)
<i>local-port-id</i>	(Optional) Local port ID
<i>neighbor-echo-device-name</i>	(Optional) Echo device name
<i>device-id</i>	(Optional) Device ID
<i>neighbor-echo-port-id</i>	(Optional) Echo port ID
<i>neighbor-state</i>	(Optional) Current neighbor state

Command Mode

- /exec

show user-account

```
show user-account [ <s0> ] [ __readonly__ TABLE_template <usr_name> [ <expire_date> ] { TABLE_role
<role> } [ <remote_login> ] [ <sshkey_info> ] { [ TABLE_keys <ssh_keys> ] }
```

Syntax Description

show	Show running system information
TABLE_template	(Optional)
TABLE_role	(Optional)
TABLE_keys	(Optional)
__readonly__	(Optional)
<i>usr_name</i>	(Optional) Name of the user
<i>expire_date</i>	(Optional) Expiry date for this user account(in YYYY-MM-DD format)
<i>role</i>	(Optional) role/s which the user is to be assigned to
<i>remote_login</i>	(Optional) Remote account information for a remote user
<i>sshkey_info</i>	(Optional) SSH key information of user
<i>ssh_keys</i>	(Optional) SSH key pairs of the user
user-account	Show user information
<i>s0</i>	(Optional) User name

Command Mode

- /exec

show username keypair

```
show username <s0> keypair [ __readonly__ { TABLE_sessions <t_type> <t_time> <t_keys> <t_bitcount>
<t_fingerprint> } ]
```

Syntax Description

show	Show running system information
username	Show user information.
keypair	Show SSH keypairs
<i>s0</i>	user name
__readonly__	(Optional)
TABLE_sessions	(Optional) username keypair
<i>t_type</i>	(Optional) keys type
<i>t_time</i>	(Optional) timestamp
<i>t_keys</i>	(Optional) ssh key
<i>t_bitcount</i>	(Optional) bitcount
<i>t_fingerprint</i>	(Optional) fingerprint

Command Mode

- /exec

show userpassphrase

```
show userpassphrase { min-length | max-length | length } [ __readonly__ [ Minimum_length <min_length>
] [ Maximum_length <max_length> ] ]
```

Syntax Description

show	Show running system information
userpassphrase	user passphrase
min-length	passphrase minimum length
max-length	passphrase maximum length
length	passphrase min and max length
__readonly__	(Optional)
Minimum_length	(Optional) minimum length of the passphrase
<i>min_length</i>	(Optional) Absolute value of the Minimum length
Maximum_length	(Optional) Maximum length of the passphrase
<i>max_length</i>	(Optional) Absolute value of max length

Command Mode

- /exec

show users

```
show users [ __readonly__ { TABLE_sessions <u_name> <t_terminal> <t_time> <t_idle> <p_pid>
<c_comment> } ]
```

Syntax Description

show	Show running system information
users	Show the current users logged in the system
__readonly__	(Optional)
TABLE_sessions	(Optional) users table
<i>u_name</i>	(Optional) user name
<i>t_terminal</i>	(Optional) terminal
<i>t_time</i>	(Optional) time
<i>t_idle</i>	(Optional) idle
<i>p_pid</i>	(Optional) pid
<i>c_comment</i>	(Optional) comment

Command Mode

- /exec



V Show Commands

- [show vdc](#), on page 2763
- [show vdc current-vdc](#), on page 2765
- [show vdc fcoe-vlan-range](#), on page 2766
- [show vdc resource](#), on page 2767
- [show vdc resource](#), on page 2768
- [show vdc resource template](#), on page 2769
- [show version](#), on page 2770
- [show version epld](#), on page 2772
- [show version image](#), on page 2773
- [show version module](#), on page 2774
- [show version module epld](#), on page 2775
- [show virtual-service](#), on page 2776
- [show virtual-service storage pool list](#), on page 2778
- [show virtual-service tech-support](#), on page 2779
- [show virtual-service utilization name](#), on page 2780
- [show virtual-service version](#), on page 2781
- [show vlan](#), on page 2782
- [show vlan access-list](#), on page 2784
- [show vlan access-map](#), on page 2788
- [show vlan all-ports](#), on page 2789
- [show vlan counters](#), on page 2790
- [show vlan dot1Q tag native](#), on page 2791
- [show vlan fcoe](#), on page 2792
- [show vlan filter](#), on page 2793
- [show vlan id](#), on page 2794
- [show vlan id counters](#), on page 2796
- [show vlan id vn-segment](#), on page 2798
- [show vlan name](#), on page 2799
- [show vlan private-vlan](#), on page 2801
- [show vlan private-vlan type](#), on page 2802
- [show vlan xbrief](#), on page 2803
- [show vlan xsummary](#), on page 2804
- [show vmtracker](#), on page 2805

- [show vmtracker certificate](#), on page 2806
- [show vmtracker fabric auto-config](#), on page 2807
- [show vmtracker status](#), on page 2808
- [show vpc](#), on page 2809
- [show vpc](#), on page 2810
- [show vpc consistency-parameters](#), on page 2813
- [show vpc consistency-parameters vlans](#), on page 2814
- [show vpc orphan-ports](#), on page 2815
- [show vpc peer-keepalive](#), on page 2816
- [show vpc role](#), on page 2817
- [show vpc statistics peer-keepalive](#), on page 2818
- [show vpc statistics vpc](#), on page 2819
- [show vrf](#), on page 2820
- [show vrf](#), on page 2822
- [show vrrp](#), on page 2823
- [show vrrp bfd-sessions](#), on page 2826
- [show vrrpv3](#), on page 2827
- [show vrrs client](#), on page 2831
- [show vrrs pathway](#), on page 2832
- [show vrrs pathway address](#), on page 2833
- [show vrrs server](#), on page 2834
- [show vrrs tag](#), on page 2835
- [show vsan](#), on page 2836
- [show vsan membership](#), on page 2837
- [show vsan membership interface](#), on page 2838
- [show vsan usage](#), on page 2839
- [show vtp counters](#), on page 2840
- [show vtp interface](#), on page 2841
- [show vtp password](#), on page 2842
- [show vtp status](#), on page 2843

show vdc

```
{ show vdc [ <e-vdc2> ] [ feature-set | detail | membership [ all | status | module <module> ] | shared membership
] [ __readonly__ [ detail2 ] [ <swmode> ] { TABLE_vdc <vdc_id> <vdc_name> <state> <mac> <hap> <sw>
<boot_order> [ <prio> <prio_per> ] [ <create_time> ] [ <reload_count> ] [ <restart_count> ] [ <restart_time>
] [ <restart_reason> ] <vtype> <lc-support> [ TABLE_fs <fs_id> <fs_name> ] [ TABLE_port <port-list> ]
} ] }
```

Syntax Description

show	Show Virtual Device Contexts
vdc	Show Virtual Device Contexts
<i>e-vdc2</i>	(Optional) Enter Virtual Device Context <vdc-id>
detail	(Optional) Show detailed vdc information
membership	(Optional) Show vdc interface membership information
shared	(Optional) Show the shared interfaces in a vdc
membership	(Optional) Show the shared interfaces in a vdc
module	(Optional) Show vdc interface membership information for a specific module only
<i>module</i>	(Optional) Show vdc interface membership information for a specific module only
status	(Optional) Show vdc related port-status
feature-set	(Optional) Show vdc feature-set information
all	(Optional) Show offline modules as well
<u>__readonly__</u>	(Optional) Read Only
detail2	(Optional)
<i>swmode</i>	(Optional)
TABLE_vdc	(Optional)
<i>vdc_id</i>	(Optional) vdc-id
TABLE_port	(Optional)
<i>port-list</i>	(Optional) port membership for VDC
<i>vdc_name</i>	(Optional) vdc-name
<i>state</i>	(Optional) state
<i>mac</i>	(Optional) mac address for VDC

<i>hap</i>	(Optional) hap policy
<i>sw</i>	(Optional) sw policy
<i>vtype</i>	(Optional)
<i>lc-support</i>	(Optional)
<i>create_time</i>	(Optional)
<i>reload_count</i>	(Optional)
<i>restart_count</i>	(Optional)
<i>restart_time</i>	(Optional)
<i>restart_reason</i>	(Optional)
TABLE_fs	(Optional)
<i>fs_id</i>	(Optional) fs id
<i>fs_name</i>	(Optional)
<i>boot_order</i>	(Optional)
<i>prio</i>	(Optional)
<i>prio_per</i>	(Optional)

Command Mode

- /exec

show vdc current-vdc

show vdc current-vdc [__readonly__ <mode> <name>]

Syntax Description

show	Show Virtual Device Contexts
vdc	Show Virtual Device Contexts
current-vdc	Show which vdc you are currently in
__readonly__	(Optional) Read Only
<i>mode</i>	(Optional) cli mode
<i>name</i>	(Optional) vdc name

Command Mode

- /exec

show vdc fcoe-vlan-range

show vdc fcoe-vlan-range [*__readonly__* <fcoe-vdc> [<fcoe-vlans>] [<sharing-vdcs>]]

Syntax Description

show	Show Virtual Device Contexts
vdc	Show Virtual Device Contexts
fcoe-vlan-range	vlans reserved for FCoE
<i>__readonly__</i>	(Optional) Read Only
<i>fcoe-vdc</i>	(Optional)
<i>sharing-vdcs</i>	(Optional)
<i>fcoe-vlans</i>	(Optional)

Command Mode

- /exec

show vdc resource

```
show vdc <id> resource [ <res-mgr-res-known-name> ] [ __readonly__ { TABLE_vdc_resource_single_vdc
<res_name> <min> <max> <used> <unused> <free> } ]
```

Syntax Description

show	Show running system information
vdc	Show Virtual Device Contexts
<i>id</i>	Enter Virtual Device Context <vdc-id>
resource	Show resource configuration for VDC
<i>res-mgr-res-known-name</i>	(Optional) Resource name
<i>__readonly__</i>	(Optional) Read Only
<i>res_name</i>	(Optional) Resource Name
<i>min</i>	(Optional) Resource min configuration
<i>max</i>	(Optional) Resource max configuration
<i>used</i>	(Optional) Resource current usage for this VDC
<i>unused</i>	(Optional) Resource reserved for this VDC but currently not used
<i>free</i>	(Optional) Resource current free for this VDC
TABLE_vdc_resource_single_vdc	(Optional)

Command Mode

- /exec

show vdc resource

```
show vdc resource [ <res-mgr-res-known-name> ] [ detail | hidden-too | with-flags ] + [ __readonly__ {
TABLE_resource <resource_name> <total_used> <total_unused> <total_free> <total_avail> <total> [
TABLE_vdc_resource_across_vdcs <vdc_name> <min> <max> <used> <unused> <free> } } ]
```

Syntax Description

show	Show running system information
vdc	Show Virtual Device Contexts
resource	Show resource configuration across VDCs
<i>res-mgr-res-known-name</i>	(Optional) Resource name
detail	(Optional) Show detail resource configuration
hidden-too	(Optional) Also show hidden resources
with-flags	(Optional) Also show resource flags
__readonly__	(Optional) Read Only
TABLE_resource	(Optional)
<i>resource_name</i>	(Optional) Resource Name
<i>total_used</i>	(Optional) Resource current usage for all VDC
<i>total_unused</i>	(Optional) Resources currently reserved but not used across all VDC
<i>total_free</i>	(Optional) Resource current free for all VDC
<i>total_avail</i>	(Optional) Resource current available across all VDC
<i>total</i>	(Optional) Resources grand total
TABLE_vdc_resource_across_vdcs	(Optional)
<i>vdc_name</i>	(Optional) VDC name
<i>min</i>	(Optional) Resource min configuration
<i>max</i>	(Optional) Resource max configuration
<i>used</i>	(Optional) Resource current usage for this VDC
<i>unused</i>	(Optional) Resource reserved for this VDC but currently not used
<i>free</i>	(Optional) Resource current free for this VDC

Command Mode

- /exec

show vdc resource template

```
show vdc resource template [ <res-mgr-template-known-name-all> ] [ __readonly__ TABLE_template
<template_name> { TABLE_resource <resource_name> <min> <max> } ]
```

Syntax Description

show	Show running system information
vdc	Show Virtual Device Contexts
resource	Show resource configuration for VDC
template	Resource template configuration
<i>res-mgr-template-known-name-all</i>	(Optional) Resource template name
<i>__readonly__</i>	(Optional) Read Only
TABLE_template	(Optional)
<i>template_name</i>	(Optional) Resource Template Name
TABLE_resource	(Optional)
<i>resource_name</i>	(Optional) Resource Name
<i>min</i>	(Optional) Resource min configuration
<i>max</i>	(Optional) Resource max configuration

Command Mode

- /exec

show version

```
show version [ __readonly__ <header_str> <bios_ver_str> [ <loader_ver_str> ] <kickstart_ver_str> [
<sys_ver_str> ] <bios_cmpl_time> <kick_file_name> <kick_cmpl_time> <kick_tmstmp> [ <isan_file_name>
] [ <isan_cmpl_time> ] [ <isan_tmstmp> ] [ <boot_lxc_mode> ] <chassis_id> [ <module_id> ] <cpu_name>
<memory> <mem_type> <proc_board_id> <host_name> <bootflash_size> [ <slot0_size> ] [ <slot1_size> ]
<kern_uptm_days> <kern_uptm_hrs> <kern_uptm_mins> <kern_uptm_secs> [ <rr_usecs> ] [ <rr_ctime> ]
<rr_reason> <rr_sys_ver> <rr_service> <manufacturer> [ TABLE_smu_list <install_smu_id> + ] [
TABLE_package_list <package_id> + ] ]
```

Syntax Description

show	
version	Show the software version
<i>__readonly__</i>	(Optional)
<i>header_str</i>	(Optional)
<i>bios_ver_str</i>	(Optional)
<i>loader_ver_str</i>	(Optional)
<i>kickstart_ver_str</i>	(Optional)
<i>sys_ver_str</i>	(Optional)
<i>bios_cmpl_time</i>	(Optional)
<i>kick_file_name</i>	(Optional)
<i>kick_cmpl_time</i>	(Optional)
<i>kick_tmstmp</i>	(Optional)
<i>isan_file_name</i>	(Optional)
<i>isan_cmpl_time</i>	(Optional)
<i>isan_tmstmp</i>	(Optional)
<i>boot_lxc_mode</i>	(Optional)
<i>chassis_id</i>	(Optional)
<i>module_id</i>	(Optional)
<i>cpu_name</i>	(Optional)
<i>memory</i>	(Optional)
<i>mem_type</i>	(Optional)
<i>proc_board_id</i>	(Optional)

<i>host_name</i>	(Optional)
<i>bootflash_size</i>	(Optional)
<i>slot0_size</i>	(Optional)
<i>slot1_size</i>	(Optional)
<i>kern_uptm_days</i>	(Optional)
<i>kern_uptm_hrs</i>	(Optional)
<i>kern_uptm_mins</i>	(Optional)
<i>kern_uptm_secs</i>	(Optional)
<i>rr_usecs</i>	(Optional)
<i>rr_ctime</i>	(Optional)
<i>rr_reason</i>	(Optional)
<i>rr_sys_ver</i>	(Optional)
<i>rr_service</i>	(Optional)
<i>manufacturer</i>	(Optional)
TABLE_smu_list	(Optional)
<i>install_smu_id</i>	(Optional)
TABLE_package_list	(Optional)
<i>package_id</i>	(Optional) Package name

Command Mode

- /exec

show version epld

```
show version epld <uri0> [ __readonly__ <image-info> [ { TABLE_module_info <module-type> <model>
<epld-device> <version> } ] ]
```

Syntax Description

show	Show running system information
version	Show the software version
epld	Show EPLD versions available in EPLD image
<i>uri0</i>	Local URI containing EPLD Image
<i>__readonly__</i>	(Optional)
<i>image-info</i>	(Optional) image file info
TABLE_module_info	(Optional)
<i>module-type</i>	(Optional) module type
<i>model</i>	(Optional) model
<i>epld-device</i>	(Optional) epld device
<i>version</i>	(Optional) version

Command Mode

- /exec

show version image

```
show version image <uri0> [ __readonly__ <md5_str> <img_file_name> [ <bios_ver_str> ] <sys_ver_str>
<img_cmpl_time> [ <img_tmstamp> ] ]
```

Syntax Description

show	Show running system information
version	Show the software version
image	Show the software version of a given image
<i>uri0</i>	Enter URI
<i>__readonly__</i>	(Optional)
<i>md5_str</i>	(Optional)
<i>img_file_name</i>	(Optional)
<i>bios_ver_str</i>	(Optional)
<i>sys_ver_str</i>	(Optional)
<i>img_cmpl_time</i>	(Optional)
<i>img_tmstamp</i>	(Optional)

Command Mode

- /exec

show version module

```
show version module <module> [ __readonly__ { TABLE_version <slot> <type> <sw> <interim> <bios> } ]
```

Syntax Description

show	Show running system information
version	Show the software version
module	Show the software version of a Module
<i>module</i>	Enter module number
<i>__readonly__</i>	(Optional)
TABLE_version	(Optional) Show version info
<i>slot</i>	(Optional) Slot
<i>type</i>	(Optional) image type
<i>sw</i>	(Optional) SW version
<i>interim</i>	(Optional) SW interim version
<i>bios</i>	(Optional) BIOS version

Command Mode

- /exec

show version module epld

```
show version module <module> epld [ __readonly__ { [ <header_info> ] [ <module> ] [ <mi_iofpga> <version> ] [ <io_fpga> <version> ] [ <mi_iofpga2> <version> ] [ <mi_iofpga3> <version> ] [ <mi_iofpga4> <version> ] [ <mi_iofpga5> <version> ] [ <mi_iofpga6> <version> ] [ <mi_iofpga7> <version> ] [ <mi_iofpga8> <version> ] [ <cpu_iofpga> <version> ] [ <db_fpga> <version> ] } ]
```

Syntax Description

show	Show running system information
version	Show the software version
module	Show the software version of a Module
<i>module</i>	Enter module number
epld	Show a module's current EPLD versions
<u>__readonly__</u>	(Optional)
<i>header_info</i>	(Optional)
<i>module</i>	(Optional)
<i>mi_iofpga</i>	(Optional)
<i>io_fpga</i>	(Optional)
<i>mi_iofpga2</i>	(Optional)
<i>mi_iofpga3</i>	(Optional)
<i>mi_iofpga4</i>	(Optional)
<i>mi_iofpga5</i>	(Optional)
<i>mi_iofpga6</i>	(Optional)
<i>mi_iofpga7</i>	(Optional)
<i>mi_iofpga8</i>	(Optional)
<i>cpu_iofpga</i>	(Optional)
<i>db_fpga</i>	(Optional)
<i>version</i>	(Optional)

Command Mode

- /exec

show virtual-service

```
show virtual-service [ { list } | { global } | { detail [ name <virt_serv_name> ] } | { core [ name
<virt_serv_name_core> ] } ] [ __readonly__ [ <infrastructure_major_version> <infrastructure_minor_version>
<total_virtual_services_installed> <total_virtual_services_activated> <machine_types_supported>
<machine_types_disabled> <maximum_vcpus_per_virtual_service> TABLE_resource_limits <media_name>
<quota> <committed> <available> ] [ TABLE_list <name> <status> <package_name> ] [ TABLE_detail
<name> <state> <package_name> <ova_path> <application_name> <application_version>
<application_description> <key_type> <signing_method> <licensing_name> <licensing_version>
<disk_reservation> <memory_reservation> <cpu_reservation> TABLE_attached_devices <type> <name>
<alias> ] [ TABLE_core <name> <name_core> ] ]
```

Syntax Description

show	Show running system information
virtual-service	Display virtualization service information
global	(Optional) Virtual service global information
list	(Optional) List virtual services
detail	(Optional) Detailed information
core	(Optional) Core information
name	(Optional) Information for a specific virtual service
<i>virt_serv_name</i>	(Optional) Name of a virtual service
<i>virt_serv_name_core</i>	(Optional) Name of a virtual service
<i>__readonly__</i>	(Optional) Read Only
<i>infrastructure_major_version</i>	(Optional) Infrastructure major version
<i>infrastructure_minor_version</i>	(Optional) Infrastructure minor version
<i>total_virtual_services_installed</i>	(Optional) Total virtual services installed
<i>total_virtual_services_activated</i>	(Optional) Total virtual services activated
<i>maximum_vcpus_per_virtual_service</i>	(Optional) Maximum VCPUs per virtual service
<i>machine_types_supported</i>	(Optional) Machine types supported
<i>machine_types_disabled</i>	(Optional) Machine types disabled
TABLE_resource_limits	(Optional) Virtual service global resource limits
<i>media_name</i>	(Optional) Resource name
<i>quota</i>	(Optional) Resource Virtualization quota
<i>committed</i>	(Optional) Resource Virtualization committed

<i>available</i>	(Optional) Resource Virtualization available
TABLE_list	(Optional) Virtual service list table
<i>name</i>	(Optional) Virtual service name
<i>status</i>	(Optional) Virtual service status
<i>package_name</i>	(Optional) Virtual service package name
TABLE_detail	(Optional) Virtual service detail table
<i>name</i>	(Optional) Virtual service name
<i>package_name</i>	(Optional) Virtual service package name
<i>application_name</i>	(Optional) Name of the application
<i>application_version</i>	(Optional) Version of the application
<i>application_description</i>	(Optional) Description of the application
<i>key_type</i>	(Optional) Virtual service key type
<i>signing_method</i>	(Optional) Method used to sign the package
<i>licensing_name</i>	(Optional) Name of the license
<i>licensing_version</i>	(Optional) Version of the license
<i>ova_path</i>	(Optional) Virtual service OVA path
<i>state</i>	(Optional) Virtual service state
<i>disk_reservation</i>	(Optional) Virtual service disk reservation
<i>memory_reservation</i>	(Optional) Virtual service memory reservation
<i>cpu_reservation</i>	(Optional) Virtual service CPU reservation
TABLE_attached_devices	(Optional) Attached devices table
<i>type</i>	(Optional) Type of the attached device
<i>name</i>	(Optional) Name of the attached device
<i>alias</i>	(Optional) Alias for the attached device
TABLE_core	(Optional) Virtual service core table
<i>name</i>	(Optional) Virtual service name
<i>name_core</i>	(Optional) Name of core

Command Mode

- /exec

show virtual-service storage pool list

```
show virtual-service storage pool list [ __readonly__ [ TABLE_storage <pool_name> <pool_type> <pool_path> ] ]
```

Syntax Description

show	Show running system information
virtual-service	Display virtualization service storage pool information
storage	Storage information about virtual service
pool	Storage pool information about virtual service
list	List storage pool for virtual service
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_storage</i>	(Optional) Virtual service storage pool list table
<i>pool_name</i>	(Optional) Virtual service storage pool name
<i>pool_type</i>	(Optional) Virtual service storage pool type
<i>pool_path</i>	(Optional) Virtual service storage pool path

Command Mode

- /exec

show virtual-service tech-support

show virtual-service tech-support

Syntax Description

show	Show running system information
virtual-service	Gather information for virtualization services trouble shooting
tech-support	Gather information for trouble shooting

Command Mode

- /exec

show virtual-service utilization name

```
show virtual-service utilization name <virt_serv_name> [ __readonly__ [ TABLE_cpu <request> <actual>
<state> ] [ TABLE_memory <allocation> <used> ] [ TABLE_storage <name> <alias> <capacity> <used>
<available> <usage> ] ]
```

Syntax Description

show	Show running system information
virtual-service	Display virtualization service utilization information
utilization	Utilization information about virtual service
name	Utilization of a virtual service
<i>virt_serv_name</i>	Name of a virtual service
<i>__readonly__</i>	(Optional) Read Only
TABLE_storage	(Optional) Virtual service storage utilization
<i>name</i>	(Optional) storage device name
<i>alias</i>	(Optional) storage device alias
<i>capacity</i>	(Optional) Capacity 1k blocks
<i>used</i>	(Optional) Used 1k blocks
<i>available</i>	(Optional) Available 1k blocks
<i>usage</i>	(Optional) Usage
TABLE_memory	(Optional) Virtual service memory utilization
<i>allocation</i>	(Optional) Memory allocation
<i>used</i>	(Optional) Memory used
TABLE_cpu	(Optional) Virtual service cpu utilization
<i>request</i>	(Optional) Requested Application Utilization
<i>actual</i>	(Optional) Actual Application Utilization
<i>state</i>	(Optional) CPU state

Command Mode

- /exec

show virtual-service version

```
show virtual-service version { { installed } | { name <virt_serv_name> installed } } [ __readonly__
<virt_service_name> <application_name> <application_version> ]
```

Syntax Description

show	Show running system information
virtual-service	Display virtualization service version information
version	Version information about virtual service
installed	Installed version
name	Version of a virtual service
<i>virt_serv_name</i>	Name of a virtual service
<i>__readonly__</i>	(Optional) Read Only
<i>virt_service_name</i>	(Optional) Virtual service name
<i>application_name</i>	(Optional) Application name
<i>application_version</i>	(Optional) Application version

Command Mode

- /exec

show vlan

```
show vlan [ controller ] [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbrief <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <vlanshowinfo-mtu-hdr> { TABLE_mtuinfo <vlanshowinfo-vlanid>
<vlanshowinfo-media-type> <vlanshowinfo-vlanmode> } [ <vlanshowrspan-hdr1> ] [
<vlanshowrspan-vlantype> ] [ <vlanshowrspan-hdr2> ] [ <vlanshowrspan-vlanbitmap> ] [ <pvlan-hdr> ] [
<pvlan-section> ] [ <pvlan-stby> ] <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
controller	(Optional) Controller VLAN status
__readonly__	(Optional) Read Only
TABLE_vlanbrief	(Optional) VLAN brief table format
TABLE_mtuinfo	(Optional) MTU information table format
<i>vlanshowbr-hdr</i>	(Optional) VLAN brief header
<i>vlanshowbr-vlanid</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanid-utf</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanname</i>	(Optional) VLAN brief VLAN name
<i>vlanshowbr-vlanstate</i>	(Optional) VLAN brief VLAN state
<i>vlanshowbr-shutstate</i>	(Optional) VLAN brief shutdown state
<i>vlanshowplist-ifidx</i>	(Optional) Port list ifindex
<i>vlanshowinfo-mtu-hdr</i>	(Optional) Vlan info mtu header
<i>vlanshowinfo-vlanid</i>	(Optional) Vlan info VLAN ID
<i>vlanshowinfo-media-type</i>	(Optional) Select media type
<i>vlanshowinfo-vlanmode</i>	(Optional) VLAN brief VLAN mode
<i>vlanshowrspan-hdr1</i>	(Optional) RSPAN VLAN header for one VLAN
<i>vlanshowrspan-hdr2</i>	(Optional) RSPAN VLAN header for multiple VLANs
<i>vlanshowrspan-vlantype</i>	(Optional) RSPAN VLAN one VLAN rspan or non-rspan
<i>vlanshowrspan-vlanbitmap</i>	(Optional) RSPAN VLAN multiple VLANs
<i>show-end</i>	(Optional) Show vlan end marker

<i>true-end</i>	(Optional) Show vlan end marker
<i>pvlan-hdr</i>	(Optional) private vlan section
<i>pvlan-section</i>	(Optional) private vlan section
<i>pvlan-stby</i>	(Optional) private vlan section on standby

Command Mode

- /exec

show vlan access-list

```
show vlan access-list <name> [ <inp_seqno> ] [ __readonly__ TABLE_vacl <vacl_name> [ <vacl_seqno> ]
[ TABLE_list <ip_ipv6_mac> <acl_name> [ TABLE_seqno <seqno> { <permitdeny> [ <proto_str> | <proto>
| <ip> | <ipv6> ] } { <src_any> | <src_ip_prefix> | <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> |
<src_ipv6_addr> <src_ipv6_mask> | <mac_src> <mac_src_wild> | <src_addrgrp> } [ <src_port_op> [
<src_port1_str> ] { <src_port1_num> } [ <src_port2_str> | <src_port2_num> ] | <src_portgrp> ] { <dest_any>
| <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> | <dest_ipv6_prefix> | <dest_ipv6_addr>
<dest_ipv6_mask> | <mac_dest> <mac_dest_wild> | <dest_addrgrp> } [ <dest_port_op> [ <dest_port1_str>
] { <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] | <dest_portgrp> ] [ { <icmp_type> [
<icmp_code> ] | <icmp_str> } | { <icmpv6_type> [ <icmpv6_code> ] | <icmpv6_str> } ] [ <igmp_type> |
<igmp_type_str> ] [ [ <precedence> | <precedence_str> ] [ <tos> | <tos_str> ] ] [ <dscp> | <dscp_str> ] [ [
<ttl> ] ] [ <log> ] [ <udfs> ] [ <capture_session> ] [ <fragments> ] [ <plen_op> <plen1> [ <plen2> ] ] [ <urg>
] [ <ack> ] [ <psh> ] [ <rst> ] [ <syn> ] [ <fin> ] [ <established> ] [ <http-method> | <http_opt_str> ] [
<tcp-option-length> ] [ <tcp-flags-mask> ] [ <flow_label> ] [ <timerange> ] [ <eth_proto> | <eth_proto_str>
] [ <vlan> ] [ <cos> ] [ <match_count> ] [ TABLE_match <module> <module_match_count> ] [ <nve_vni>
] [ <nve_vni> ] [ <label1> [ <label2> <label3> <label4> ] ] <remark> } ] [ <action> <actionid> ] ] ]
```

Syntax Description

show	Show running system information
vlan	Vlan commands
access-list	Vlan access list
<i>name</i>	List name
<i>inp_seqno</i>	(Optional) Sequence number
<i>vacl_name</i>	(Optional) List name
<i>__readonly__</i>	(Optional)
<i>vacl_seqno</i>	(Optional) Sequence number
TABLE_vacl	(Optional)
TABLE_list	(Optional)
<i>ip_ipv6_mac</i>	(Optional) IP/iIPv6/MAC
<i>acl_name</i>	(Optional) Access list name
<i>seqno</i>	(Optional) Sequence number
<i>permitdeny</i>	(Optional) Permit/deny
<i>proto</i>	(Optional) A protocol number
TABLE_seqno	(Optional)
<i>proto_str</i>	(Optional) Protocol name

<i>ip</i>	(Optional) IP
<i>ipv6</i>	(Optional) IPV6
<i>src_any</i>	(Optional) SRCAny
<i>dest_any</i>	(Optional) DESTAny
<i>src_ip_prefix</i>	(Optional) Source IP prefix
<i>src_ip_addr</i>	(Optional) Source IP address
<i>src_ip_mask</i>	(Optional) Source IP mask
<i>mac_src</i>	(Optional) Source MAC address
<i>mac_src_wild</i>	(Optional) Source MAC mask
<i>dest_ip_prefix</i>	(Optional) Destination IP prefix
<i>dest_ip_addr</i>	(Optional) Destination IP address
<i>dest_ip_mask</i>	(Optional) Destination IP mask
<i>mac_dest</i>	(Optional) Destination MAC address
<i>mac_dest_wild</i>	(Optional) Destination MAC mask
<i>src_port_op</i>	(Optional) Source Port operator
<i>dest_port_op</i>	(Optional) Destination Port operator
<i>src_port1_str</i>	(Optional) Source port name
<i>src_port1_num</i>	(Optional) Source port number
<i>src_port2_str</i>	(Optional) Source port name
<i>src_port2_num</i>	(Optional) Source port number
<i>dest_port1_str</i>	(Optional) Destination port name
<i>dest_port1_num</i>	(Optional) Destination port number
<i>dest_port2_str</i>	(Optional) Destination port name
<i>dest_port2_num</i>	(Optional) Destination port number
<i>icmp_type</i>	(Optional) ICMP type
<i>icmp_code</i>	(Optional) ICMP code
<i>icmp_str</i>	(Optional) ICMP message
<i>icmpv6_type</i>	(Optional) ICMP type
<i>icmpv6_code</i>	(Optional) ICMP code

<i>icmpv6_str</i>	(Optional) ICMP message
<i>igmp_type</i>	(Optional) IGMP type
<i>igmp_type_str</i>	(Optional) IGMP type String
<i>precedence</i>	(Optional) precedence
<i>precedence_str</i>	(Optional) precedence string
<i>tos</i>	(Optional) tos
<i>tos_str</i>	(Optional) tos string
<i>dscp</i>	(Optional) dscp
<i>dscp_str</i>	(Optional) dscp string
<i>udfs</i>	(Optional) udfs string
<i>ttl</i>	(Optional) ttl
<i>capture_session</i>	(Optional) capture session
<i>log</i>	(Optional) Log
<i>fragments</i>	(Optional) Fragments
<i>urg</i>	(Optional) URG
<i>ack</i>	(Optional) ACK
<i>psh</i>	(Optional) PSH
<i>rst</i>	(Optional) RST
<i>syn</i>	(Optional) SYN
<i>fin</i>	(Optional) FIN
<i>established</i>	(Optional) ESTABLISHED
<i>http-method</i>	(Optional) http-method
<i>http_opt_str</i>	(Optional) http_option string
<i>tcp-option-length</i>	(Optional) TCP Option size
<i>tcp-flags-mask</i>	(Optional) TCP Flags mask
<i>flow_label</i>	(Optional) IPv6 flow label
<i>timerange</i>	(Optional) Time-range
<i>eth_proto</i>	(Optional) MAC protocol number
<i>eth_proto_str</i>	(Optional) MAC protocol name

<i>vlan</i>	(Optional) VLAN number
<i>cos</i>	(Optional) CoS value
<i>match_count</i>	(Optional) Number of packets matching the ACL
TABLE_match	(Optional)
<i>module</i>	(Optional) Module name
<i>module_match_count</i>	(Optional) Number of packets matching the ACL
<i>nve_vni</i>	(Optional) nve vni
<i>remark</i>	(Optional) Remark String
<i>src_addrgrp</i>	(Optional) Source address group
<i>dest_addrgrp</i>	(Optional) Destination address group
<i>src_portgrp</i>	(Optional) Source port group
<i>dest_portgrp</i>	(Optional) Destination port group
<i>plen_op</i>	(Optional) Source Port operator
<i>plen1</i>	(Optional) Packet length minimum
<i>plen2</i>	(Optional) packet length maximum
<i>label1</i>	(Optional) mpls label one
<i>label2</i>	(Optional) mpls label two
<i>label3</i>	(Optional) mpls label three
<i>label4</i>	(Optional) mpls label four
<i>action</i>	(Optional) Action
<i>actionid</i>	(Optional) redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63> set-erspan-gre-PROTO: <1-65535>

Command Mode

- /exec

show vlan access-map

```
show vlan access-map [ <name> ] [ __readonly__ [ TABLE_vacl <vacl_name> [ TABLE_seqno [ <seqno>
] [ <ip_ipv6_mac> { <match_name> } + [ <action_drop> ] [ <action_log> ] [ <action_fwd> ] [ <action_capture>
] [ <action_redirect> <intf> ] ] [ <statistics> ] ] ] ]
```

Syntax Description

show	Show running system information
vlan	Vlan commands
access-map	List VLAN access maps
<i>name</i>	(Optional) List name
<i>vacl_name</i>	(Optional) List name
<i>__readonly__</i>	(Optional)
<i>seqno</i>	(Optional) Sequence number
TABLE_vacl	(Optional)
TABLE_seqno	(Optional)
<i>ip_ipv6_mac</i>	(Optional) IP/iIPv6/MAC
<i>match_name</i>	(Optional) Access list name
<i>action_drop</i>	(Optional) DROP
<i>action_log</i>	(Optional) LOG
<i>action_fwd</i>	(Optional) FWD
<i>action_capture</i>	(Optional) CAPTURE
<i>action_redirect</i>	(Optional) REDIRECT
<i>intf</i>	(Optional) Interface traffic is redirected to
<i>statistics</i>	(Optional) STATISTICS

Command Mode

- /exec

show vlan all-ports

```
show vlan all-ports [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefallports <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
all-ports	Show all ports on VLAN
__readonly__	(Optional) Read Only
TABLE_vlanbriefallports	(Optional) VLAN brief table format
<i>vlanshowbr-hdr</i>	(Optional) VLAN brief header
<i>vlanshowbr-vlanid</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanid-utf</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanname</i>	(Optional) VLAN brief VLAN name
<i>vlanshowbr-vlanstate</i>	(Optional) VLAN brief VLAN state
<i>vlanshowbr-shutstate</i>	(Optional) VLAN brief shutdown state
<i>vlanshowplist-ifidx</i>	(Optional) Port list ifindex
<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker

Command Mode

- /exec

show vlan counters

```
show vlan counters [ __readonly__ { TABLE_vlancounters <vlanshowbr-vlanid> [ <l2_ing_ucast_b> ] [
<l2_ing_ucast_p> ] [ <l2_ing_mcast_b> ] [ <l2_ing_mcast_p> ] [ <l2_ing_bcast_b> ] [ <l2_ing_bcast_p> ]
[ <l2_egr_ucast_b> ] [ <l2_egr_ucast_p> ] [ <l3_ucast_rcv_b> ] [ <l3_ucast_rcv_p> ] [ <total_rcv_b> ] [
<total_rcv_p> ] [ <total_sent_b> ] [ <total_sent_p> ] } ]
```

Syntax Description

show	Show running system information
vlan	Vlan commands
counters	display counters
__readonly__	(Optional) Read Only
TABLE_vlancounters	(Optional) vlan counters table format
vlanshowbr-vlanid	(Optional) VLAN brief VLAN ID
l2_ing_ucast_b	(Optional) L2 Ingress unicast octets
l2_ing_ucast_p	(Optional) L2 Ingress unicast packets
l2_ing_mcast_b	(Optional) L2 Ingress multicast octets
l2_ing_mcast_p	(Optional) L2 Ingress multicast packets
l2_ing_bcast_b	(Optional) L2 Ingress broadcast octets
l2_ing_bcast_p	(Optional) L2 Ingress broadcast packets
l2_egr_ucast_b	(Optional) L2 Egress unicast octets
l2_egr_ucast_p	(Optional) L2 Egress unicast packets
l3_ucast_rcv_b	(Optional) L3 unicast octets in
l3_ucast_rcv_p	(Optional) L3 unicast packets in
total_rcv_b	(Optional) Total octets in
total_rcv_p	(Optional) Total packets in
total_sent_b	(Optional) Total octets out
total_sent_p	(Optional) Total packets out

Command Mode

- /exec

show vlan dot1Q tag native

show vlan dot1Q tag native [__readonly__ <tag_native_mode>]

Syntax Description

show	Show running system information
vlan	VTP VLAN status
dot1Q	Display dot1q parameters
tag	Display tag parameters
native	Display native vlan tagging
<i>__readonly__</i>	(Optional) Read Only
<i>tag_native_mode</i>	(Optional) Native vlan tagging mode

Command Mode

- /exec

show vlan fcoe

show vlan fcoe [<vlan-id>] [__readonly__ { TABLE_assoc <orig-id> <tran-id> <assoc-state> }]

Syntax Description

show	Show running system information
fcoe	FCOE Congiguration
vlan	Original VLAN Status
__readonly__	(Optional) Read Only
TABLE_assoc	(Optional) Association Table Format
<i>vlan-id</i>	(Optional) VLAN ID <1-4094>
<i>orig-id</i>	(Optional) Enter original VLAN-ID being associated with translated ID
<i>tran-id</i>	(Optional) Enter VSAN-ID being associated with VLAN-ID
<i>assoc-state</i>	(Optional) Show Association Status

Command Mode

- /exec

show vlan filter

```
show vlan filter [ access-map <name> | vlan <vlan> ] [ __readonly__ TABLE_vlan_filter <name>
<configured_vlans> ]
```

Syntax Description

show	Show running system information
vlan	Vlan commands
filter	Information about VLAN filters
access-map	(Optional) Show the VLANs where an access-map is applied
<i>name</i>	(Optional) List name
vlan	(Optional) Show the access-map applied to a VLAN
<i>vlan</i>	(Optional) VLAN number
<i>__readonly__</i>	(Optional)
TABLE_vlan_filter	(Optional)
<i>configured_vlans</i>	(Optional) VLAN numbers

Command Mode

- /exec

show vlan id

```
show vlan id <vlan-id> [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefid <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <vlanshowinfo-mtu-hdr> { TABLE_mtuinfoid <vlanshowinfo-vlanid>
<vlanshowinfo-media-type> <vlanshowinfo-vlanmode> } [ <vlanshow-vlanerrbitmap> ] [
<vlanshowrspan-hdr1> ] [ <vlanshowrspan-vlantype> ] [ <vlanshowrspan-hdr2> ] [
<vlanshowrspan-vlanbitmap> ] [ <pvlan-hdr> ] [ <pvlan-id-section> ] [ <pvlan-stby> ] [ <is-vtp-manageable>
] [ <is-internal> ] [ <is-reserved> ] [ <is-rspan> ] [ <is-dynamic-gvrp> ] <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
id	VLAN status by VLAN id
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
<i>__readonly__</i>	(Optional) Read Only
TABLE_vlanbriefid	(Optional) VLAN brief table format
TABLE_mtuinfoid	(Optional) MTU information table format
<i>vlanshowbr-hdr</i>	(Optional) VLAN brief header
<i>vlanshowbr-vlanid</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanid-utf</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanname</i>	(Optional) VLAN brief VLAN name
<i>vlanshowbr-vlanstate</i>	(Optional) VLAN brief VLAN state
<i>vlanshowbr-shutstate</i>	(Optional) VLAN brief shutdown state
<i>vlanshowplist-ifidx</i>	(Optional) Port list ifindex
<i>vlanshowinfo-mtu-hdr</i>	(Optional) Vlan info mtu header
<i>vlanshowinfo-vlanid</i>	(Optional) Vlan info VLAN ID
<i>vlanshowinfo-media-type</i>	(Optional) Select media type
<i>vlanshowinfo-vlanmode</i>	(Optional) VLAN brief VLAN mode
<i>vlanshow-vlanerrbitmap</i>	(Optional) VLAN error bitmap
<i>vlanshowrspan-hdr1</i>	(Optional) RSPAN VLAN header for one VLAN
<i>vlanshowrspan-hdr2</i>	(Optional) RSPAN VLAN header for multiple VLANs
<i>vlanshowrspan-vlantype</i>	(Optional) RSPAN VLAN one VLAN rspan or non-rspan

<i>vlanshowrspan-vlanbitmap</i>	(Optional) RSPAN VLAN multiple VLANs
<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker
<i>pvlan-hdr</i>	(Optional) private vlan section
<i>pvlan-id-section</i>	(Optional) private id vlan section
<i>pvlan-stby</i>	(Optional) private vlan section on standby
<i>is-vtp-manageable</i>	(Optional) VTP Manageable VLAN flag
<i>is-internal</i>	(Optional) Internal VLAN flag
<i>is-reserved</i>	(Optional) Reserved VLAN flag
<i>is-rspan</i>	(Optional) RSPAN VLAN flag
<i>is-dynamic-gvrp</i>	(Optional) Dynamic GVRP VLAN flag

Command Mode

- /exec

show vlan id counters

```
show vlan id <vlan-id> counters [ __readonly__ { TABLE_vlancounters <vlanshowbr-vlanid> [
<l2_ing_ucast_b> ] [ <l2_ing_ucast_p> ] [ <l2_ing_mcast_b> ] [ <l2_ing_mcast_p> ] [ <l2_ing_bcast_b> ]
[ <l2_ing_bcast_p> ] [ <l2_egr_ucast_b> ] [ <l2_egr_ucast_p> ] [ <l3_ucast_rcv_b> ] [ <l3_ucast_rcv_p> ]
[ <total_rcv_b> ] [ <total_rcv_p> ] [ <total_sent_b> ] [ <total_sent_p> ] } ]
```

Syntax Description

show	Show running system information
vlan	Vlan commands
id	VLAN status by VLAN id
counters	display counters
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_vlancounters</i>	(Optional) vlan counters table format
<i>vlanshowbr-vlanid</i>	(Optional) VLAN brief VLAN ID
<i>l2_ing_ucast_b</i>	(Optional) L2 Ingress unicast octets
<i>l2_ing_ucast_p</i>	(Optional) L2 Ingress unicast packets
<i>l2_ing_mcast_b</i>	(Optional) L2 Ingress multicast octets
<i>l2_ing_mcast_p</i>	(Optional) L2 Ingress multicast packets
<i>l2_ing_bcast_b</i>	(Optional) L2 Ingress broadcast octets
<i>l2_ing_bcast_p</i>	(Optional) L2 Ingress broadcast packets
<i>l2_egr_ucast_b</i>	(Optional) L2 Egress unicast octets
<i>l2_egr_ucast_p</i>	(Optional) L2 Egress unicast packets
<i>l3_ucast_rcv_b</i>	(Optional) L3 unicast octets in
<i>l3_ucast_rcv_p</i>	(Optional) L3 unicast packets in
<i>total_rcv_b</i>	(Optional) Total octets in
<i>total_rcv_p</i>	(Optional) Total packets in
<i>total_sent_b</i>	(Optional) Total octets out
<i>total_sent_p</i>	(Optional) Total packets out

Command Mode

- /exec

show vlan id vn-segment

```
show vlan id <vlan-id> vn-segment [ __readonly__ <vlanshowinfo-segid-hdr> { TABLE_seginfoid
<vlanshowinfo-seg-vlanid> <vlanshowinfo-segment-id> } <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
id	VLAN status by VLAN id
vn-segment	Show vn-segment mapping
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_seginfoid</i>	(Optional) Segment id information table format
<i>vlanshowinfo-segid-hdr</i>	(Optional) Vlan info segment id header
<i>vlanshowinfo-seg-vlanid</i>	(Optional) Vlan info VLAN ID
<i>vlanshowinfo-segment-id</i>	(Optional) Vlan info SEGMENT ID
<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker

Command Mode

- /exec

show vlan name

```
show vlan name <vname> [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefname <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <vlanshowinfo-mtu-hdr> { TABLE_mtuinfoname <vlanshowinfo-vlanid>
<vlanshowinfo-media-type> <vlanshowinfo-vlanmode> } [ <vlanshowrspan-hdr1> ] [
<vlanshowrspan-vlantype> ] [ <vlanshowrspan-hdr2> ] [ <vlanshowrspan-vlanbitmap> ] <show-end> [
<true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
name	VLAN status by VLAN name
vname	A vlan name with size 32 (128 if long vlan name enabled)
__readonly__	(Optional) Read Only
TABLE_vlanbriefname	(Optional) VLAN brief table format
TABLE_mtuinfoname	(Optional) MTU information table format
vlanshowbr-hdr	(Optional) VLAN brief header
vlanshowbr-vlanid	(Optional) VLAN brief VLAN ID
vlanshowbr-vlanid-utf	(Optional) VLAN brief VLAN ID
vlanshowbr-vlanname	(Optional) VLAN brief VLAN name
vlanshowbr-vlanstate	(Optional) VLAN brief VLAN state
vlanshowbr-shutstate	(Optional) VLAN brief shutdown state
vlanshowplist-ifidx	(Optional) Port list ifindex
vlanshowinfo-mtu-hdr	(Optional) Vlan info mtu header
vlanshowinfo-vlanid	(Optional) Vlan info VLAN ID
vlanshowinfo-media-type	(Optional) Select media type
vlanshowinfo-vlanmode	(Optional) VLAN brief VLAN mode
vlanshowrspan-hdr1	(Optional) RSPAN VLAN header for one VLAN
vlanshowrspan-hdr2	(Optional) RSPAN VLAN header for multiple VLANs
vlanshowrspan-vlantype	(Optional) RSPAN VLAN one VLAN rspan or non-rspan
vlanshowrspan-vlanbitmap	(Optional) RSPAN VLAN multiple VLANs

<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker

Command Mode

- /exec

show vlan private-vlan

```
show vlan [ id <vlan-id> ] private-vlan [ __readonly__ [ { TABLE_pvlan_primary <vlan-key> [ <primary> ] [ <secondary> ] <pvlan-type> [ <ports> + ] } ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
id	(Optional) VLAN status by VLAN id
<i>vlan-id</i>	(Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
private-vlan	Private VLAN information
<u>__readonly__</u>	(Optional) Read Only
TABLE_pvlan_primary	(Optional) Pvlan primary vlan table
<i>vlan-key</i>	(Optional) Vlan key
<i>primary</i>	(Optional) Primary VLAN
<i>secondary</i>	(Optional) Secondary VLAN
<i>pvlan-type</i>	(Optional) PVLAN Type
<i>ports</i>	(Optional) Port list

Command Mode

- /exec

show vlan private-vlan type

```
show vlan [ id <vlan-id> ] private-vlan type [ __readonly__ [ { TABLE_pvlan-type <vlan-num> <pvlan-type> } ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
id	(Optional) VLAN status by VLAN id
<i>vlan-id</i>	(Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19
private-vlan	Private VLAN information
type	Private VLAN type information
__readonly__	(Optional) Read Only
TABLE_pvlan-type	(Optional) Pvlan type table
<i>vlan-num</i>	(Optional) vlan
<i>pvlan-type</i>	(Optional) PVLAN Type

Command Mode

- /exec

show vlan xbrief

```
show vlan xbrief [ controller | cli ] [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefxbrief
<vlanshowbr-vlanid> <vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate>
<vlanshowbr-shutstate> [ <vlanshowplist-ifidx> + ] } <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
xbrief	All VLAN status in brief
controller	(Optional) Controller VLAN status
cli	(Optional) CLI VLAN status
__readonly__	(Optional) Read Only
TABLE_vlanbriefxbrief	(Optional) VLAN brief table format
<i>vlanshowbr-hdr</i>	(Optional) VLAN brief header
<i>vlanshowbr-vlanid</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanid-utf</i>	(Optional) VLAN brief VLAN ID
<i>vlanshowbr-vlanname</i>	(Optional) VLAN brief VLAN name
<i>vlanshowbr-vlanstate</i>	(Optional) VLAN brief VLAN state
<i>vlanshowbr-shutstate</i>	(Optional) VLAN brief shutdown state
<i>vlanshowplist-ifidx</i>	(Optional) Port list ifindex
<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker

Command Mode

- /exec

show vlan xsummary

```
show vlan xsummary [ __readonly__ <vlansum-all-vlan> <vlansum-vtp-vlan> <vlansum-ext-vlan>
<vlansum-max-supported-vlan> <vlansum-carved-vlan> <show-end> [ <true-end> ] ]
```

Syntax Description

show	Show running system information
vlan	VLAN status
xsummary	VLAN summary information
<i>__readonly__</i>	(Optional) Read Only
<i>vlansum-all-vlan</i>	(Optional) Show vlan summary Total
<i>vlansum-vtp-vlan</i>	(Optional) Show vlan summary Number of normal vlans
<i>vlansum-ext-vlan</i>	(Optional) Show vlan summary Number of extended vlans
<i>vlansum-max-supported-vlan</i>	(Optional) Show vlan summary Max supported vlans
<i>vlansum-carved-vlan</i>	(Optional) Show vlan summary Number of carved sdn vlans
<i>show-end</i>	(Optional) Show vlan end marker
<i>true-end</i>	(Optional) Show vlan end marker

Command Mode

- /exec

show vmtracker

```
show vmtracker [ connection <conn_name> ] { { info { { [ interface <intf_id> ] { summary | detail | host |
vm | port-group } } } | { vxlan-segment | vxlan-vm } } } | event-history }
```

Syntax Description

show	Show running system information
vmtracker	Show vmtracker info
connection	(Optional) Show vmtracker configured connections
<i>conn_name</i>	(Optional) Show vmtracker Connection name
info	Display vmtracker information
interface	(Optional) Display vmtracker interface information
<i>intf_id</i>	(Optional) Interface name to display
summary	Display a summary of vmtracker information
detail	Display vmtracker information details
host	Display vmtracker host information
vm	Display vmtracker related Virtual Machine information
port-group	Display vmtracker related port-group information
vxlan-segment	Print all segment info
vxlan-vm	Print all vm info
event-history	Display vmtracker related event-history

Command Mode

- /exec

show vmtracker certificate

show vmtracker certificate

Syntax Description

show	Show running system information
vmtracker	VMTRACKER commands
certificate	Show the default certificate used

Command Mode

- /exec

show vmtracker fabric auto-config

```
show vmtracker fabric auto-config [ interface <intf_id> ] [ vlan <vlan_id> ] [ status { success | pending | failure | skipped } ]
```

Syntax Description

show	Show running system information
vmtracker	VMTRACKER commands
fabric	VM Tracker Fabric paramters
auto-config	VM Tracker Fabric AutoConfiguration
interface	(Optional) Display vmtracker interface information
<i>intf_id</i>	(Optional) Interface name to display
vlan	(Optional) vlan to display
<i>vlan_id</i>	(Optional) VLAN ID 1-4094 or range(s) like: 1-5, 10 or 2-5,7-19
status	(Optional) Auto-config status
success	(Optional) Success
pending	(Optional) Pending
failure	(Optional) Failure
skipped	(Optional) Skipped

Command Mode

- /exec

show vmtracker status

```
show vmtracker [ connection <conn_name> ] status [ __readonly__ { TABLE_connection <name> <host_or_ip>
<conn_status> } ]
```

Syntax Description

<i>__readonly__</i>	(Optional)
TABLE_connection	(Optional)
<i>name</i>	(Optional)
<i>host_or_ip</i>	(Optional)
<i>conn_status</i>	(Optional)
show	Show running system information
vmtracker	Show vmtracker info
connection	(Optional) Show vmtracker configured connections
<i>conn_name</i>	(Optional) Show vmtracker Connection name
status	Show vmtracker connection status

Command Mode

- /exec

show vpc

```
show vpc { <vpc-number> | brief vpc <vpc-number> } [ __readonly__ [ <vpc-hdr> ] [ <vpc-is-es> ] [ <vpc-not-es> ] [ TABLE_vpc <vpc-id> <vpc-ifindex> <vpc-port-state> <phy-port-if-removed><vpc-thru-peerlink> <vpc-consistency> { [ <vpc-consistency-reason> ] [ <vpc-consistency-status> ] } <up-vlan-bitset> <es-attr> ] <vpc-end> ]
```

Syntax Description

<code>vpc</code>	Virtual Port Channel configuration
<code>brief</code>	Brief display of vPC status
<code>vpc-number</code>	Enter a Virtual Port Channel number
<code>__readonly__</code>	(Optional) Read Only
<code>vpc-hdr</code>	(Optional) Start of vPC table
<code>vpc-is-es</code>	(Optional) Flag to indicate vPC+ complex
<code>vpc-not-es</code>	(Optional) Flag to indicate vPC complex
<code>TABLE_vpc</code>	(Optional) vPC table
<code>vpc-id</code>	(Optional) vPC id
<code>vpc-ifindex</code>	(Optional) vPC ifindex
<code>vpc-port-state</code>	(Optional) vPC port state
<code>vpc-consistency</code>	(Optional) vPC global configuration consistency
<code>vpc-consistency-reason</code>	(Optional) vPC consistency reason
<code>vpc-consistency-status</code>	(Optional) vPC consistency reason
<code>up-vlan-bitset</code>	(Optional) vPC UP VLAN bitset
<code>es-attr</code>	(Optional) vPC+ attributes
<code>vpc-end</code>	(Optional) End of table

Command Mode

- /exec

show vpc

```
show vpc [ brief ] [ __readonly__ <vpc-domain-id> [ <vpc-l2mp-switch-id> ] <vpc-peer-status>
<vpc-peer-status-reason> <vpc-peer-keepalive-status> [ <vpc-peer-l2mp-status> ] <vpc-peer-consistency> {
[ <vpc-peer-consistency-reason> ] [ <vpc-per-vlan-peer-consistency> ] <vpc-peer-consistency-status> }
<vpc-type-2-consistency> { [ <vpc-type-2-consistency-reason> ] <vpc-type-2-consistency-status> } <vpc-role>
<num-of-vpcs> [ <track-obj> ] [ <peer-gateway> ] [ <peer-gateway-excluded-vlans> ]
<dual-active-excluded-vlans> <vpc-graceful-consistency-check-status> [ <vpc-auto-recovery-status> ] [
<vpc-delay-restore-status> ] [ <vpc-delay-restore-svi-status> ] [ <vpc-delay-peer-link-status> ]
<operational-l3-peer> [ <vpc-scale-high-status> ] [ <fp-enhanced-load-balancing> ] [
<vpc-per-vlan-peer-consistency> ] <vpc-peer-link-hdr> [ { TABLE_peerlink <peer-link-id> <peerlink-ifindex>
<peer-link-port-state> <peer-up-vlan-bitset> } ] <vpc-end> <vpc-hdr> [ <vpc-is-es> ] [ <vpc-not-es> ] [ {
TABLE_vpc <vpc-id> <vpc-ifindex> <vpc-port-state> <phy-port-if-removed> <vpc-thru-peerlink>
<vpc-consistency> { [ <vpc-consistency-reason> ] [ <vpc-consistency-status> ] } <up-vlan-bitset> <es-attr>
} ] <vpc-end> ]
```

Syntax Description

vpc	Virtual Port Channel configuration
brief	(Optional) Brief display of vPC status
__readonly__	(Optional) Read Only
TABLE_peerlink	(Optional) vPC peerlink table
TABLE_vpc	(Optional) vPC table
vpc-domain-id	(Optional) vPC domain id
vpc-l2mp-switch-id	(Optional) vPC+ switch ID
vpc-peer-status	(Optional) vPC peer status
vpc-peer-status-reason	(Optional) vPC peer status reason
vpc-peer-keepalive-status	(Optional) vpc peer keepalive status
vpc-peer-l2mp-status	(Optional) vPC fabricpath status
vpc-role	(Optional) vPC role
peer-gateway	(Optional) Peer gateway status
peer-gateway-excluded-vlans	(Optional) peer-gateway excluded VLANs
dual-active-excluded-vlans	(Optional) dual-active excluded VLANs
fp-enhanced-load-balancing	(Optional) Fabricpath enhanced load balancing status
num-of-vpcs	(Optional) Number of vPCs configured
track-obj	(Optional) Track object for vPC

<i>vpc-graceful-consistency-check-status</i>	(Optional) vPC graceful consistency check
<i>vpc-consistency</i>	(Optional) vPC global configuration consistency
<i>vpc-consistency-reason</i>	(Optional) vPC consistency reason
<i>vpc-consistency-status</i>	(Optional) vPC consistency reason
<i>vpc-peer-consistency</i>	(Optional) vPC global configuration consistency
<i>vpc-peer-consistency-reason</i>	(Optional) vPC consistency reason
<i>vpc-peer-consistency-status</i>	(Optional) vPC consistency reason
<i>vpc-per-vlan-peer-consistency</i>	(Optional) vPC per-vlan global configuration consistency
<i>vpc-type-2-consistency</i>	(Optional) vPC type-2 configuration consistency status
<i>vpc-type-2-consistency-reason</i>	(Optional) vPC type-2 configuration consistency reason
<i>vpc-type-2-consistency-status</i>	(Optional) vPC type-2 configuration consistency status
<i>operational-l3-peer</i>	(Optional) Operational Layer 3 peer status
<i>vpc-scale-high-status</i>	(Optional) vPC scale high status
<i>vpc-hdr</i>	(Optional) Start of vPC table
<i>vpc-is-es</i>	(Optional) Flag to indicate vPC+ complex
<i>vpc-not-es</i>	(Optional) Flag to indicate vPC complex
<i>vpc-peer-link-hdr</i>	(Optional) Start of vPC peer-link table
<i>vpc-port-state</i>	(Optional) vPC port state
<i>vpc-end</i>	(Optional) End of table
<i>vpc-id</i>	(Optional) vPC id
<i>vpc-ifindex</i>	(Optional) vPC ifindex
<i>peer-link-id</i>	(Optional) peer link id
<i>peerlink-ifindex</i>	(Optional) peer link ifindex
<i>peer-link-port-state</i>	(Optional) peer-link port state
<i>peer-up-vlan-bitset</i>	(Optional) peer link UP VLAN bitset
<i>up-vlan-bitset</i>	(Optional) vPC UP VLAN bitset
<i>es-attr</i>	(Optional) vPC+ attributes
<i>vpc-auto-recovery-status</i>	(Optional) Auto-recovery status
<i>vpc-delay-restore-status</i>	(Optional) Delay-resotre status

<i>vpc-delay-restore-svi-status</i>	(Optional) Dealy-restore-svi status
<i>vpc-delay-peer-link-status</i>	(Optional) Delay-peer-link status

Command Mode

- /exec

show vpc consistency-parameters

```
show vpc consistency-parameters { global | vni | interface <if> | vpc <vpc-num> } [ __readonly__
TABLE_vpc_consistency <vpc-param-name> <vpc-param-type> <vpc-param-local-val> <vpc-param-peer-val>
]
```

Syntax Description

vpc	Virtual Port Channel configuration
consistency-parameters	Show vPC Consistency Parameters
global	Global Parameters
vni	Show vPC Consistency Parameters vni
<i>if</i>	
<i>vpc-num</i>	Enter a Virtual Port Channel number
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_vpc_consistency</i>	(Optional) vPC table
<i>vpc-param-name</i>	(Optional)
<i>vpc-param-type</i>	(Optional)
<i>vpc-param-local-val</i>	(Optional)
<i>vpc-param-peer-val</i>	(Optional)

Command Mode

- /exec

show vpc consistency-parameters vlans

```
show vpc consistency-parameters vlans [ vnseg ] [ __readonly__ TABLE_vpc_consistency <vpc-param-name>
<vpc-param-type> [ <reason_code> ] [ <syserr> ] <vpc-pass-vlans> [ <reason_code> ] ]
```

Syntax Description

vpc	Virtual Port Channel configuration
consistency-parameters	Show vPC Consistency Parameters
vlans	vlans
vnseg	(Optional) Display vlan to vn-segment map
__readonly__	(Optional) Read Only
TABLE_vpc_consistency	(Optional) vPC table
<i>vpc-param-name</i>	(Optional)
<i>vpc-param-type</i>	(Optional)
<i>vpc-pass-vlans</i>	(Optional)
<i>syserr</i>	(Optional) vPC consistency reason
<i>reason_code</i>	(Optional) vPC consistency reason

Command Mode

- /exec

show vpc orphan-ports

```
show vpc orphan-ports [ __readonly__ [ { TABLE_orphan_ports <vpc-vlan> <vpc-orphan-ports> } ] ]
```

Syntax Description

vpc	Virtual Port Channel configuration
orphan-ports	Show ports that are not part of vPC but have common VLANs
__readonly__	(Optional) Read Only
TABLE_orphan_ports	(Optional) vPC orphan ports table
<i>vpc-vlan</i>	(Optional) port vlan
<i>vpc-orphan-ports</i>	(Optional) description of the port

Command Mode

- /exec

show vpc peer-keepalive

```
show vpc peer-keepalive [ __readonly__ <vpc-peer-keepalive-status> <vpc-keepalive-dest>
<vpc-keepalive-send-interface> <vpc-keepalive-receive-interface> <vpc-keepalive-send-tstamp>
<vpc-keepalive-receive-tstamp> <vpc-peer-keepalive-up-time> <vpc-keepalive-send-status>
<vpc-keepalive-receive-status> <vpc-keepalive-lastupdate> [ <vpc-keepalive-dest> ] <vpc-keepalive-interval>
<vpc-keepalive-timeout> <vpc-keepalive-hold-timeout> <vpc-keepalive-vrf> <vpc-keepalive-udp-port>
<vpc-keepalive-tos> ]
```

Syntax Description

vpc	Virtual Port Channel configuration
peer-keepalive	vPC keepalive status
__readonly__	(Optional) Read Only
<i>vpc-peer-keepalive-status</i>	(Optional) vpc peer keepalive status
<i>vpc-keepalive-dest</i>	(Optional) vPC keepalive destination ip address
<i>vpc-keepalive-send-status</i>	(Optional) vPC keepalive send status
<i>vpc-keepalive-receive-status</i>	(Optional) vPC keepalive receive status
<i>vpc-peer-keepalive-up-time</i>	(Optional) keepalive- alive time
<i>vpc-keepalive-send-tstamp</i>	(Optional) vPC keepalive last send timestamp
<i>vpc-keepalive-send-interface</i>	(Optional) vPC keepalive send interface
<i>vpc-keepalive-receive-tstamp</i>	(Optional) vPC keepalive last receive timestamp
<i>vpc-keepalive-receive-interface</i>	(Optional) vPC keepalive receive interface
<i>vpc-keepalive-lastupdate</i>	(Optional) vPC keepalive last update from peer
<i>vpc-keepalive-interval</i>	(Optional) vPC keepalive timeout
<i>vpc-keepalive-timeout</i>	(Optional) vPC keepalive interval
<i>vpc-keepalive-hold-timeout</i>	(Optional) hold timeout
<i>vpc-keepalive-vrf</i>	(Optional) vrf name
<i>vpc-keepalive-udp-port</i>	(Optional) udp port
<i>vpc-keepalive-tos</i>	(Optional) tos value

Command Mode

- /exec

show vpc role

```
show vpc role [ __readonly__ <vpc-peer-status> <vpc-peer-status-reason> [ <vpc-current-role> ] [
<vpc-es-current-role> ] <dual-active-detected> <vpc-system-mac> <vpc-system-prio> <vpc-local-system-mac>
<vpc-local-system-prio><vpc-local-role-prio> <vpc-peer-system-mac>
<vpc-peer-system-prio><vpc-peer-role-prio> ]
```

Syntax Description

vpc	Virtual Port Channel configuration
role	vPC role status
<i>__readonly__</i>	(Optional) Read Only
<i>vpc-peer-status</i>	(Optional) vPC peer status
<i>vpc-peer-status-reason</i>	(Optional) vPC peer status reason
<i>vpc-current-role</i>	(Optional) vPC role
<i>vpc-es-current-role</i>	(Optional) vPC role
<i>dual-active-detected</i>	(Optional) Dual active detection status
<i>vpc-system-mac</i>	(Optional) vPC system mac
<i>vpc-local-system-mac</i>	(Optional) vPC local system mac
<i>vpc-peer-system-mac</i>	(Optional) vPC peer system mac
<i>vpc-system-prio</i>	(Optional) vPC system priority

Command Mode

- /exec

show vpc statistics peer-keepalive

```
show vpc statistics peer-keepalive [ __readonly__ <vpc-peer-keepalive-status> <vpc-keepalive-counters-tx>
<vpc-keepalive-counters-rx> <vpc-keepalive-avg-rx-interval> <vpc-keepalive-peer-state-changes> ]
```

Syntax Description

vpc	Virtual Port Channel configuration
statistics	Statistics
peer-keepalive	peer keepalive module related statistics
__readonly__	(Optional) Read Only
<i>vpc-peer-keepalive-status</i>	(Optional) vpc peer keepalive status
<i>vpc-keepalive-counters-tx</i>	(Optional) tx counters
<i>vpc-keepalive-counters-rx</i>	(Optional) rx counters
<i>vpc-keepalive-avg-rx-interval</i>	(Optional) avg rx interval in ms
<i>vpc-keepalive-peer-state-changes</i>	(Optional) peer state changes

Command Mode

- /exec

show vpc statistics vpc

```
show vpc statistics { vpc <vpc_num> | peer-link }
```

Syntax Description

vpc	Virtual Port Channel configuration
statistics	Statistics
<i>vpc_num</i>	Virtual Port Channel number
peer-link	stats for peer-link

Command Mode

- /exec

show vrf

```
show vrf [ <vrf-name> | <vrf-known-name> | all ] [ order id ] [ detail ] [ passive ] [ __readonly__ TABLE_vrf
<vrf_name> <vrf_id> <vrf_state> [ <vrf_reason> ] [ <vrf_pend> ] [ <vpnid> <rd> <vni> <max_routes>
<mid_threshold> ] [ { TABLE_tib <tib_id> <tib_af> <tib_nonce> <tib_state> [ <tib_reason> ] [ <tib_pend>
} ] ] ]
```

Syntax Description

show	Show running system information
vrf	Display VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display VRF information for all VRFs
order	(Optional) Specify ordering
id	(Optional) Order by ID
detail	(Optional) Display VRF detail information
passive	(Optional) Display passive VRF information
__readonly__	(Optional)
TABLE_vrf	(Optional)
TABLE_tib	(Optional)
<i>vrf_name</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_state</i>	(Optional)
<i>vrf_reason</i>	(Optional)
<i>vrf_pend</i>	(Optional)
<i>vpnid</i>	(Optional)
<i>rd</i>	(Optional)
<i>max_routes</i>	(Optional)
<i>mid_threshold</i>	(Optional)
<i>tib_id</i>	(Optional)
<i>tib_af</i>	(Optional)

<i>tib_nonce</i>	(Optional)
<i>tib_state</i>	(Optional)
<i>tib_reason</i>	(Optional)
<i>tib_pend</i>	(Optional)
<i>vni</i>	(Optional)

Command Mode

- /exec

show vrf

show vrf [<vrf-name> | <vrf-known-name> | all]

Syntax Description

show	Show running system information
vrf	Display VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display VRF information for all VRFs

Command Mode

- /exec

show vrrp

```
show vrrp [ [ summary ] | { [ statistics | detail ] [ interface <interface_id> ] [ vr <vr_id> ] [ master | backup |
init ] + } ] [ __readonly__ [ [ TABLE_vrrp_group <sh_if_index> <sh_group_id> <sh_group_type>
<sh_group_state> <sh_group_preempt> <sh_vip_addr> { [ TABLE_sec_vip_addr <sh_sec_vip_addr> ] }
<sh_priority> [ <sh_cfg_priority> <sh_fwd_thr_lower> <sh_fwd_thr_upper> ] <sh_adv_interval> [
<sh_auth_text> ] [ <sh_vmac> ] [ <sh_master_router> ] [ <sh_native_track_intf> <sh_native_track_priotiry>
] { [ TABLE_vrrp_track <sh_track_object_id> <sh_decrement_priority> <sh_track_object_state> } ] [
<sh_bfd_status> <sh_bfd_session> ] ] [ { TABLE_vrrp_statistics [ <if_index> ] [ <grp_id> ] [ <grp_type> ]
[ <master_cnt> ] [ <adv_pkts> ] [ <adv_intv_mismatch> ] [ <auth_failure> ] [ <ttl_err> ] [ <zero_pri_adv_rcvd>
] [ <zero_pri_adv_sent> ] [ <type_fl_mismatch> ] [ <addr_mismatch> ] [ <inv_auth> ] [ <auth_mismatch>
] [ <inv_pkt_len> ] } ] [ <total_num_of_grp> ] [ <init_grps> ] [ <backup_grps> ] [ <master_grps> ] [
<vrrp_enabled_ifs> ] [ <mts_rx> ] [ <mts_tx> ] [ <pkt_rx> ] [ <pkt_tx> ] ] + ]
```

Syntax Description

show	Show running system information
vrrp	Show vrrp information
summary	(Optional) Show vrrp summary
statistics	(Optional) Show vrrp statistics
detail	(Optional) Show detailed information
interface	(Optional) Show vrrp info for the interface
<i>interface_id</i>	(Optional)
vr	(Optional) Show vrrp info for the group
<i>vr_id</i>	(Optional) [1-255] enter IPv4 vr group
master	(Optional) Groups in Master state
backup	(Optional) Groups in Backup state
init	(Optional) Groups in Init state
<i>__readonly__</i>	(Optional) Read only
TABLE_vrrp_group	(Optional) Group detail table
<i>sh_if_index</i>	(Optional) Interface type and number
<i>sh_group_id</i>	(Optional) Group number
<i>sh_group_type</i>	(Optional) Group type
<i>sh_group_state</i>	(Optional) VRRP group state
<i>sh_group_preempt</i>	(Optional) Group preemption statue

<i>sh_vip_addr</i>	(Optional) Virtual IP Address
TABLE_sec_vip_addr	(Optional) Secondary virtual ip address table
<i>sh_sec_vip_addr</i>	(Optional) Secondary virtual ip address
<i>sh_priority</i>	(Optional) Priority of VRRP group
<i>sh_auth_text</i>	(Optional) Authentication text
<i>sh_cfg_priority</i>	(Optional) Configured priority of VRRP group
<i>sh_fwd_thr_lower</i>	(Optional) Lower forwarding threshold
<i>sh_fwd_thr_upper</i>	(Optional) Upper forwarding threshold
<i>sh_adv_interval</i>	(Optional) Advertisement interval
<i>sh_vmac</i>	(Optional) Virtual MAC
<i>sh_master_router</i>	(Optional) Master router
<i>sh_native_track_intf</i>	(Optional) Native tracked interface
<i>sh_native_track_priotiry</i>	(Optional) Decrement priority for Native tracking
TABLE_vrrp_track	(Optional) VRRP tracking table
<i>sh_track_object_id</i>	(Optional) Object id of tracking object
<i>sh_decrement_priority</i>	(Optional) Decrement priority
<i>sh_track_object_state</i>	(Optional) Tracking object state
<i>sh_bfd_status</i>	(Optional) BFD status
<i>sh_bfd_session</i>	(Optional) BFD session status
TABLE_vrrp_statistics	(Optional) VRRP statistics table
<i>if_index</i>	(Optional) Interface type and number
<i>grp_id</i>	(Optional) Group number
<i>grp_type</i>	(Optional) Group type
<i>master_cnt</i>	(Optional) VRRP Master
<i>adv_pkts</i>	(Optional) Advertisement pkts
<i>adv_intv_mismatch</i>	(Optional) Advertisement interval mismatch
<i>auth_failure</i>	(Optional) Auth failure
<i>tvl_err</i>	(Optional) TTL error
<i>zero_pri_adv_rcvd</i>	(Optional) Zero pri adv received

<i>zero_pri_adv_sent</i>	(Optional) Zero pri adv sent
<i>type_fl_mismatch</i>	(Optional) Invalid type field
<i>addr_mismatch</i>	(Optional) Address mismatch
<i>inv_auth</i>	(Optional) Invalid auth type
<i>auth_mismatch</i>	(Optional) Authentication mismatch
<i>inv_pkt_len</i>	(Optional) Invalid pkt length
<i>total_num_of_grp</i>	(Optional) Total Number of Groups Configured
<i>init_grps</i>	(Optional) Init groups
<i>backup_grps</i>	(Optional) Backup groups
<i>master_grps</i>	(Optional) Master groups
<i>vrrp_enabled_ifs</i>	(Optional) Number of VRRP enabled interfaces
<i>mts_rx</i>	(Optional) Total MTS Rx
<i>mts_tx</i>	(Optional) Total MTS Tx
<i>pkt_rx</i>	(Optional) Total Pkt Rx
<i>pkt_tx</i>	(Optional) Total Pkt Tx

Command Mode

- /exec

show vrrp bfd-sessions

```
show vrrp bfd-sessions [ interface <interface-id> [ to <ipaddress> ] ] [ __readonly__ TABLE_bfd_sess
<interface> { <src_addr> | <src_addr_v6> } { <dst_addr> | <dst_addr_v6> } <session_state> <ref_count>
<displayed_interface> { TABLE_groups <group_id> <vrrp_state> <bfd_status> <operation> <time> } ]
```

Syntax Description

show	Show running system information
vrrp	Show vrrp information
bfd-sessions	BFD sessions
interface	(Optional) Groups on this interface
<i>interface-id</i>	(Optional) Interface
to	(Optional) To IP address
<i>ipaddress</i>	(Optional) Sessions to IP address
<i>__readonly__</i>	(Optional)
TABLE_bfd_sess	(Optional)
<i>interface</i>	(Optional) Interface
<i>src_addr</i>	(Optional) IPv4 Source address
<i>dst_addr</i>	(Optional) IPv4 Destination address
<i>session_state</i>	(Optional) Session state
<i>ref_count</i>	(Optional) Ref count
<i>displayed_interface</i>	(Optional) Displayed interface
TABLE_groups	(Optional)
<i>group_id</i>	(Optional) Group id
<i>vrrp_state</i>	(Optional) VRRP STATE
<i>bfd_status</i>	(Optional) BFD STATE
<i>operation</i>	(Optional) Operation
<i>time</i>	(Optional) Time

Command Mode

- /exec

show vrrpv3

```
show vrrpv3 [ brief | detail | statistics ] [ <intf> [ <group_num> ] ] [ <opt_v4_or_v6> ] [ all ] [ __readonly__
[ <global_drops> ] [ { TABLE_istats [ <i_intf> ] [ <i_drops> ] [ <ttl> ] [ <checksum> ] [ <version> ] [
<type> ] [ <length> ] [ <badid> ] [ <other> } ] ] [ { TABLE_grp [ <intf> ] [ <id> ] [ <af> ] [ <desc> ] [ <state>
] [ <duration> ] [ <vip> ] [ { TABLE_sec [ <addr> ] [ <prefix> } ] ] [ <vmac> ] [ <adv> ] [ <owner> ] [
<preempt> ] [ <delay> ] [ <delay_rem> ] [ <priority> ] [ <cfg_priority> ] [ <m_addr> ] [ <m_priority> ] [
<m_adv> ] [ <m_expire> ] [ <down> ] [ <down_expire> ] [ <t_id> ] [ <t_dec_prio> ] [ <t_state> ] [ <adv_sent>
] [ <adv_err> ] [ <adv_rcvd> ] [ <v2adv_sent> ] [ <v2adv_err> ] [ <v2adv_rcvd> ] [ <drops> ] [ <incompat>
] [ <conflict> ] [ <bad_count> ] [ <bad_addr> ] [ <bad_config> ] [ <bad_advert> ] [ <bad_state> ] [ <bad_other>
] [ <init_master> ] [ <init_master_time> ] [ <init_backup> ] [ <init_backup_time> ] [ <back_master> ] [
<back_master_time> ] [ <master_back> ] [ <master_back_time> ] [ <mast_init> ] [ <mast_init_time> ] [
<back_init> ] [ <back_init_time> } ] ] + [ { TABLE_vbrief [ <intf_b> ] [ <id_b> ] [ <af_b> ] [ <priority_b>
] [ <down_b> ] [ <owner_b> ] [ <preempt_b> ] [ <state_b> ] [ <m_addr_b> ] [ <vip_b> } ] ] ]
```

Syntax Description

show	Show running system information
vrrpv3	VRRPv3 Show commands
all	(Optional) All VRRPV3 information
brief	(Optional) Brief output
detail	(Optional) Detail output
statistics	(Optional) Statistics output
<i>opt_v4_or_v6</i>	(Optional) Enter ipv4 or ipv6
<i>intf</i>	(Optional) Interface
<i>group_num</i>	(Optional) Group Number
<i>__readonly__</i>	(Optional)
<i>TABLE_istats</i>	(Optional) Interface-level VRRPv3 statistics
<i>TABLE_grp</i>	(Optional) VRRP Groups
<i>TABLE_sec</i>	(Optional) Secondary Addresses
<i>TABLE_vbrief</i>	(Optional) VRRP Brief
<i>global_drops</i>	(Optional) Total dropped packets
<i>i_intf</i>	(Optional) Interface
<i>i_drops</i>	(Optional) Total dropped packets
<i>ttl</i>	(Optional) Invalid TTL/Hop limit
<i>checksum</i>	(Optional) Invalid checksum

<i>version</i>	(Optional) Invalid version
<i>type</i>	(Optional) Invalid message type
<i>length</i>	(Optional) Invalid length
<i>badid</i>	(Optional) Invalid group ID
<i>other</i>	(Optional) Other
<i>intf</i>	(Optional) Interface
<i>id</i>	(Optional) Group ID
<i>af</i>	(Optional) Address family
<i>desc</i>	(Optional) Description
<i>state</i>	(Optional) Group state
<i>duration</i>	(Optional) Time in current state
<i>vip</i>	(Optional) Primary virtual IP address
<i>addr</i>	(Optional) Secondary virtual IP address
<i>prefix</i>	(Optional) Secondary vIP prefix
<i>vmac</i>	(Optional) Virtual MAC address
<i>adv</i>	(Optional) Advertisement interval
<i>preempt</i>	(Optional) Preemption status
<i>owner</i>	(Optional) Owner mode
<i>delay</i>	(Optional) Preemption delay
<i>delay_rem</i>	(Optional) Preemption delay remaining
<i>priority</i>	(Optional) Priority
<i>cfg_priority</i>	(Optional) Configured priority
<i>m_addr</i>	(Optional) Group master router address
<i>m_priority</i>	(Optional) Group master priority
<i>m_adv</i>	(Optional) Master advertisement interval
<i>m_expire</i>	(Optional) Master expiration
<i>down</i>	(Optional) Master down interval
<i>down_expire</i>	(Optional) Master down expiration
<i>t_id</i>	(Optional) Tracking object ID

<i>t_dec_prio</i>	(Optional) Priority to decrement
<i>t_state</i>	(Optional) Tracking object state
<i>adv_sent</i>	(Optional) Advertisements sent
<i>adv_err</i>	(Optional) Advertisement errors
<i>adv_rcvd</i>	(Optional) Advertisements received
<i>v2adv_sent</i>	(Optional) Advertisements sent (v2)
<i>v2adv_err</i>	(Optional) Advertisement errors (v2)
<i>v2adv_rcvd</i>	(Optional) Advertisements received (v2)
<i>drops</i>	(Optional) Total dropped packets
<i>incompat</i>	(Optional) v2, Incompatible
<i>conflict</i>	(Optional) Address owner conflicts
<i>bad_count</i>	(Optional) Invalid address count
<i>bad_addr</i>	(Optional) Invalid IP address
<i>bad_config</i>	(Optional) Invalid IP address config
<i>bad_advert</i>	(Optional) Invalid advertisement interval
<i>bad_state</i>	(Optional) Invalid group state
<i>bad_other</i>	(Optional) Other
<i>init_master</i>	(Optional) Init to Master
<i>init_master_time</i>	(Optional) Last Occurrence
<i>init_backup</i>	(Optional) Init to Backup
<i>init_backup_time</i>	(Optional) Last Occurrence
<i>back_master</i>	(Optional) Backup to Master
<i>back_master_time</i>	(Optional) Last Occurrence
<i>master_back</i>	(Optional) Master to Backup
<i>master_back_time</i>	(Optional) Last Occurrence
<i>mast_init</i>	(Optional) Master to Init
<i>mast_init_time</i>	(Optional) Last Occurrence
<i>back_init</i>	(Optional) Backup to Init
<i>back_init_time</i>	(Optional) Last Occurrence

<i>intf_b</i>	(Optional) Interface
<i>id_b</i>	(Optional) Group ID
<i>af_b</i>	(Optional) Address family
<i>priority_b</i>	(Optional) Priority
<i>down_b</i>	(Optional) Master down interval
<i>owner_b</i>	(Optional) Owner mode
<i>preempt_b</i>	(Optional) Preemption status
<i>state_b</i>	(Optional) Group state
<i>m_addr_b</i>	(Optional) Group master router address
<i>vip_b</i>	(Optional) Primary virtual IP address

Command Mode

- /exec

show vrrs client

```
show vrrs client [ <cname> ] [ __readonly__ { TABLE_client <name> <id> <all> <priority> { TABLE_tags <tname> } } ]
```

Syntax Description

vrrs	VRRS Show commands
show	Show running system information
client	Information about VRRS clients
<i>cname</i>	(Optional) VRRS client name
<i>__readonly__</i>	(Optional)
<i>TABLE_client</i>	(Optional) VRRS clients
<i>TABLE_tags</i>	(Optional) VRRS tags
<i>name</i>	(Optional) VRRS client name
<i>id</i>	(Optional) VRRS client id
<i>priority</i>	(Optional) Priority
<i>all</i>	(Optional) Client follows all tags
<i>tname</i>	(Optional) VRRS tag name

Command Mode

- /exec

show vrrs pathway

```
show vrrs pathway [ <intf> ] [ __readonly__ { TABLE_pws <name> <state> <vrrs_push_state> <vmac>
<vmac_state> <vmac_dbg> [ <pvmac> ] [ <pvmac_state> ] [ <pvmac_dbg> ] <af> [ <desc> ] <opt> <eval>
[ { TABLE_vips <addr> [ <flags> } ] } ]
```

Syntax Description

vrrs	VRRS Show commands
show	Show running system information
pathway	Information about VRRS pathways
<i>intf</i>	(Optional) Interface
<i>__readonly__</i>	(Optional)
TABLE_pws	(Optional) Show VRRS pathways
TABLE_vips	(Optional) Pathway vIP addresses
<i>name</i>	(Optional) Pathway name
<i>state</i>	(Optional) Pathway state
<i>vrrs_push_state</i>	(Optional) VRRS push state
<i>vmac</i>	(Optional) Virtual MAC address
<i>vmac_state</i>	(Optional) Virtual MAC state
<i>vmac_dbg</i>	(Optional) Virtual MAC debug flags
<i>pvmac</i>	(Optional) Previous Virtual MAC address
<i>pvmac_state</i>	(Optional) Previous MAC state
<i>pvmac_dbg</i>	(Optional) Previous MAC debug flags
<i>af</i>	(Optional) Pathway address-family
<i>desc</i>	(Optional) Pathway description
<i>opt</i>	(Optional) Option flags
<i>eval</i>	(Optional) Eval flags
<i>addr</i>	(Optional) Virtual IP address
<i>flags</i>	(Optional) Virtual IP address flags

Command Mode

- /exec

show vrrs pathway address

show vrrs pathway [<intf>] address

Syntax Description

vrrs	VRRS Show commands
show	Show running system information
pathway	Information about VRRS pathways
<i>intf</i>	(Optional) Interface
address	Internal information about pathway addresses

Command Mode

- /exec

show vrrs server

```
show vrrs server [ __readonly__ { TABLE_srv <name> <af> <intf> <state> <vmac> <vip> [ { TABLE_tag
<tag> } ] } ]
```

Syntax Description

vrrs	VRRS Show commands
show	Show running system information
server	Information about VRRS servers
__readonly__	(Optional)
TABLE_srv	(Optional) VRRS Servers
TABLE_tag	(Optional) VRRS tags associated with each server
<i>name</i>	(Optional) VRRS server name
<i>af</i>	(Optional) Address-family
<i>intf</i>	(Optional) Interface
<i>state</i>	(Optional) VRRS server state
<i>vmac</i>	(Optional) Virtual MAC address
<i>vip</i>	(Optional) Virtual IP address
<i>tag</i>	(Optional) VRRS tag

Command Mode

- /exec

show vrrs tag

```
show vrrs tag [ <tagname> ] [ __readonly__ { TABLE_tag <name> <server> [ { TABLE_client <id> <client>
<all> } ] } ]
```

Syntax Description

vrrs	VRRS Show commands
show	Show running system information
tag	Information about VRRS tags
<i>tagname</i>	(Optional) VRRS tag
<i>__readonly__</i>	(Optional)
TABLE_tag	(Optional) Known VRRS tags
TABLE_client	(Optional) VRRS clients listening
<i>name</i>	(Optional) VRRS tag name
<i>server</i>	(Optional) VRRS server name
<i>id</i>	(Optional) VRRS client id
<i>client</i>	(Optional) VRRS client name
<i>all</i>	(Optional) Client follows all tags

Command Mode

- /exec

show vsan

```
show vsan [ <id_in> ] [ __readonly__ { TABLE_vsan <id> { [ <name> <state> <interop_mode>
<load_balancing> <operational_state> ] | <inactive_vsan_name> | <evfp_control_vsan_name> } } ]
```

Syntax Description

show	Show running system information
vsan	Vsan commands
<i>id_in</i>	(Optional) VSAN ID range
<i>__readonly__</i>	(Optional) Read Only
TABLE_vsan	(Optional) Table of VSAN's
<i>id</i>	(Optional) VSAN ID
<i>name</i>	(Optional) VSAN name
<i>state</i>	(Optional) VSAN state
<i>interop_mode</i>	(Optional) Interoperability mode
<i>load_balancing</i>	(Optional) Load balancing
<i>operational_state</i>	(Optional) Operational state
<i>inactive_vsan_name</i>	(Optional) Isolated VSAN
<i>evfp_control_vsan_name</i>	(Optional) EVFP isolated VSAN

Command Mode

- /exec

show vsan membership

```
show vsan [ <id_in> ] membership [ __readonly__ { TABLE_vsan <id> [ <inactive_vsan_name> ] [
<evfp_control_vsan_name> ] [ TABLE_interface <name> ] } ]
```

Syntax Description

show	Show running system information
vsan	Vsan commands
<i>id_in</i>	(Optional) VSAN ID range
membership	VSAN membership information
<i>__readonly__</i>	(Optional) Read Only
TABLE_vsan	(Optional) VSAN table
<i>id</i>	(Optional) VSAN ID
<i>inactive_vsan_name</i>	(Optional) Isolated VSAN
<i>evfp_control_vsan_name</i>	(Optional) EVFP isolated VSAN
TABLE_interface	(Optional) List of interface members
<i>name</i>	(Optional) Interface name

Command Mode

- /exec

show vsan membership interface

```
show vsan membership interface <if_in> [ __readonly__ { TABLE_interface <name> <vsan_id_memb> [
<inactive_vsan_name> | <evfp_control_vsan_name> ] <allowed_vsan_list> } ]
```

Syntax Description

show	Show running system information
vsan	Vsan commands
membership	VSAN membership information
interface	Show interface status and information
<i>if_in</i>	Interface range
<i>__readonly__</i>	(Optional) Read Only
<i>TABLE_interface</i>	(Optional) Interface VSAN table
<i>name</i>	(Optional) Interface Name
<i>vsan_id_memb</i>	(Optional) VSAN ID to which interface belongs
<i>inactive_vsan_name</i>	(Optional) Isolated VSAN
<i>evfp_control_vsan_name</i>	(Optional) EVFP isolated VSAN
<i>allowed_vsan_list</i>	(Optional) Allowed VSAN list

Command Mode

- /exec

show vsan usage

```
show vsan usage [ __readonly__ { <num_vsans_configured> <configured_range_of_vsans>
<vsans_available_to_configure> } ]
```

Syntax Description

show	Show running system information
vsan	Vsan commands
usage	show VSAN usage in the system
<i>__readonly__</i>	(Optional) Read Only
<i>num_vsans_configured</i>	(Optional) Total VSAN's configured
<i>configured_range_of_vsans</i>	(Optional) Range of VSAN's configured
<i>vsans_available_to_configure</i>	(Optional) VSAN range available to configure

Command Mode

- /exec

show vtp counters

```
show vtp counters [ __readonly__ <start> <summary_rx> <subset_rx> <request_rx> <summary_tx>
<subset_tx> <request_tx> <num_config_rev_error> <num_config_digest_error> <num_vl_summary_error>
[ { TABLE_pruning_counters <if_index> <join_tx> <join_rx> <summary_adv_vl_rx> } ] ]
```

Syntax Description

show	Show running system information
vtp	VTP information
counters	VTP statistics
<i>__readonly__</i>	(Optional) Read Only
<i>start</i>	(Optional) Start
<i>summary_rx</i>	(Optional) Summary advertisements received
<i>subset_rx</i>	(Optional) Subset advertisements received
<i>request_rx</i>	(Optional) Request advertisements received
<i>summary_tx</i>	(Optional) Summary advertisements transmitted
<i>subset_tx</i>	(Optional) Subset advertisements transmitted
<i>request_tx</i>	(Optional) Request advertisements transmitted
<i>num_config_rev_error</i>	(Optional) Number of config revision errors
<i>num_config_digest_error</i>	(Optional) Number of config digest errors
<i>num_vl_summary_error</i>	(Optional) Number of V1 summary errors
TABLE_pruning_counters	(Optional) Pruning counters in table format
<i>if_index</i>	(Optional) Trunk
<i>join_tx</i>	(Optional) Join Transmitted
<i>join_rx</i>	(Optional) Join Received
<i>summary_adv_vl_rx</i>	(Optional) Summary advts received from non-pruning-capable device

Command Mode

- /exec

show vtp interface

```
show vtp interface [ <interface_range> ] [ __readonly__ [ <start> ] { TABLE_vtp_interface <if_index>
<status> } ]
```

Syntax Description

show	Show running system information
vtp	VTP information
interface	VTP interface status and configuration
<i>interface_range</i>	(Optional) Enter interfaces
<i>__readonly__</i>	(Optional) Read Only
<i>start</i>	(Optional) Start
TABLE_vtp_interface	(Optional) VTP interface configuration in table format
<i>if_index</i>	(Optional) Trunk
<i>status</i>	(Optional) VTP interface status

Command Mode

- /exec

show vtp password

```
show vtp password [ domain <domain-id> ] [ __readonly__ <start> <passwd> <password-type> <secret-key> ]
```

Syntax Description

show	Show running system information
vtp	VTP information
password	VTP password
domain	(Optional) VTP administrative domain
<i>domain-id</i>	(Optional) Domain index(Domain-id)
<i>__readonly__</i>	(Optional) Read Only
<i>start</i>	(Optional) Start
<i>passwd</i>	(Optional) VTP Domain Password
<i>password-type</i>	(Optional) Password Type (1=plaintext, 2=hidden)
<i>secret-key</i>	(Optional) Secret Key for the password

Command Mode

- /exec

show vtp status

```
show vtp status [ __readonly__ <start> <version> <config_rev> <max_vlan_supported_local>
<num_current_vlans> <oper_mode> <domain_name> <pruning_mode> <oper_pruning_mode> <v2_mode>
<trap_enabled> <md5_digest> <last_modified_ip> <last_modified_time> <running-version> <updater_id>
<updater_reason> ]
```

Syntax Description

show	Show running system information
vtp	VTP information
status	VTP domain status
<i>__readonly__</i>	(Optional) Read Only
<i>start</i>	(Optional) Start
<i>version</i>	(Optional) VTP version
<i>config_rev</i>	(Optional) Configuration Revision
<i>max_vlan_supported_local</i>	(Optional) Maximum VLANs supported locally
<i>num_current_vlans</i>	(Optional) Number of existing VLANs
<i>oper_mode</i>	(Optional) VTP Mode
<i>domain_name</i>	(Optional) VTP Domain Name
<i>pruning_mode</i>	(Optional) Pruning Mode
<i>oper_pruning_mode</i>	(Optional) Operational Pruning Mode
<i>v2_mode</i>	(Optional) VTP v2 Mode
<i>trap_enabled</i>	(Optional) trap enabled
<i>md5_digest</i>	(Optional) MD5 Digest
<i>last_modified_ip</i>	(Optional) Configuration last modified by
<i>last_modified_time</i>	(Optional) Configuration last modified at
<i>running-version</i>	(Optional) VTP Version Running
<i>updater_id</i>	(Optional) Local Updater id
<i>updater_reason</i>	(Optional) Local Updater id reason

Command Mode

- /exec

show vtp status



W Show Commands

- [show wred-queue qos-group-map](#), on page 2846
- [show wrr-queue qos-group-map](#), on page 2847
- [show wrr unicast-bandwidth](#), on page 2848
- [show wwn status](#), on page 2849
- [show wwn switch](#), on page 2850
- [show wwn test](#), on page 2851
- [show wwn vsan-wwn](#), on page 2853

show wred-queue qos-group-map

```
show wred-queue qos-group-map [ __readonly__ TABLE_wred_queue_qos_group_map
<wred-queue><qos-group-map> ]
```

Syntax Description

show	Show running system information
wred-queue	Show WRED qos-group information
qos-group-map	Display mapping of the qos-group information
__readonly__	(Optional)
TABLE_wred_queue_qos_group_map	(Optional) XML show wred-queue qos-group-map

Command Mode

- /exec

show wrr-queue qos-group-map

```
show wrr-queue qos-group-map [ __readonly__ <mcast_queue_id> [ TABLE_wrr_queue <wrr_queue> [
TABLE_qos_group <qos_group> ] ] ]
```

Syntax Description

show	Show running system information
wrr-queue	Display mapping of traffic priority (CoS) values to L3 Multicast
qos-group-map	Show wrr-queue qos-group-map
<i>__readonly__</i>	(Optional)
<i>mcast_queue_id</i>	(Optional) MCAST Queue ID
<i>TABLE_wrr_queue</i>	(Optional) Table wrr queue
<i>wrr_queue</i>	(Optional) Traffic priority values
<i>TABLE_qos_group</i>	(Optional) Table qos group
<i>qos_group</i>	(Optional) QoS-Group-Map

Command Mode

- /exec

show wrr unicast-bandwidth

show wrr unicast-bandwidth [__readonly__ TABLE_wrr_unicast_bandwidth <unicast-bandwidth>]

Syntax Description

show	Show running system information
wrr	unicast bandwidth configuration
unicast-bandwidth	rate in percentage of data rate
__readonly__	(Optional)
TABLE_wrr_unicast_bandwidth	(Optional) XML show wrr unicast-bandwidth
<i>unicast-bandwidth</i>	(Optional) unicast bandwidth value

Command Mode

- /exec

show wwn status

```
show wwn status [ { backplane-prom | block-id <i0> | non-volatile-pss | volatile-pss } ] [ __readonly__ [
TABLE_status <type> <configured> <available> <avbl_percent> <resd> <alarm> ] [ <wwn_start> <wwn_end>
<num_of_wwn> <allocated_wwn> <available_wwn> <alloc_status> ] ]
```

Syntax Description

show	Show running system information
wwn	show wwn information
status	Show overall WWN Usage and Alarm Status
backplane-prom	(Optional) Show WWN block in backplane PROM
block-id	(Optional) Enter a block id.
<i>i0</i>	(Optional) Enter a block id.
non-volatile-pss	(Optional) Show contents of non-volatile PSS
volatile-pss	(Optional) Show contents of volatile PSS
__readonly__	(Optional) Read Only
TABLE_status	(Optional) show wwn status table
<i>type</i>	(Optional) WWN Type
<i>configured</i>	(Optional) Number of Configured WWNs
<i>available</i>	(Optional) Number of Available WWNs
<i>avbl_percent</i>	(Optional) Available % of WWNs
<i>resd</i>	(Optional) Reserved WWNs
<i>alarm</i>	(Optional) Alarm State
<i>wwn_start</i>	(Optional) Start value of WWN-range
<i>wwn_end</i>	(Optional) End value of WWN-range
<i>num_of_wwn</i>	(Optional) Total Number of WWNs
<i>allocated_wwn</i>	(Optional) Number of Allocated WWNs
<i>available_wwn</i>	(Optional) Number of Available WWNs
<i>alloc_status</i>	(Optional) Block Allocation Status

Command Mode

- /exec

show wwn switch

```
show wwn switch [ __readonly__ { <sw_wwn> } ]
```

Syntax Description

show	Show running system information
wwn	show wwn information
switch	Show switch WWN
__readonly__	(Optional) Read Only
<i>sw_wwn</i>	(Optional) The Switch WWN

Command Mode

- /exec

show wwn test

```
show wwn test { get_swwn_from_pwwn <wwn0> | get_pwwn_from_swwn <wwn1> if_index <i0> |
get_ifindex_from_fwfn <wwn2> | get_ifindex_from_pwwn <wwn3> | validate_pwwn_given_swwn <wwn4>
pwwn <wwn5> | get_all_pwwn_for_slot <i1> | get_kc_type_given_swwn <wwn6> pwwn <wwn7> |
get_ifindex_from_pwwn_swwn <wwn8> pwwn <wwn9> }
```

Syntax Description

show	show running system information
wwn	show wwn information
test	show wwn information for testing
get_swwn_from_pwwn	show switch wwn from port wwn
<i>wwn0</i>	port wwn
get_pwwn_from_swwn	show port wwn from switch wwn
<i>wwn1</i>	switch wwn
if_index	interface index
<i>i0</i>	Interface index
get_ifindex_from_fwfn	show ifindex from fabric wwn
<i>wwn2</i>	fabric wwn
get_ifindex_from_pwwn	show ifindex from port wwn
<i>wwn3</i>	port wwn
validate_pwwn_given_swwn	validate port wwn for given swwn
<i>wwn4</i>	switch wwn
pwwn	port wwn
<i>wwn5</i>	port wwn
get_all_pwwn_for_slot	show all port wwn for a given slot
<i>i1</i>	Slot number
get_kc_type_given_swwn	show KC type
<i>wwn6</i>	switch wwn
pwwn	port wwn
<i>wwn7</i>	port wwn

get_ifindex_from_pwwn_swwn	show ifindex for given pwwn and swwn
wwn8	switch wwn
pwwn	port wwn
wwn9	port wwn

Command Mode

- /exec

show wwn vsan-wwn

```
show wwn vsan-wwn [ __readonly__ [ TABLE_wwnvsan <vsan_id> <wwn_conf> ] ]
```

Syntax Description

show	Show running system information
wwn	show wwn information
vsan-wwn	Show all user configured vsan wwn
__readonly__	(Optional) Read Only
TABLE_wwnvsan	(Optional) vsan-wwn table
<i>vsan_id</i>	(Optional) VSAN ID
<i>wwn_conf</i>	(Optional) wwn configured by user

Command Mode

- /exec



X Show Commands

- [show](#), on page 2856
- [show xml server logging configuration](#), on page 2857
- [show xml server status](#), on page 2858

show

show

Syntax Description

show	Show trigger config
------	---------------------

Command Mode

- /exec/elanms/outse10

show xml server logging configuration

show xml server logging configuration

Syntax Description

show	Show running system information
xml	Show xmlagent logging configuration
server	xml agent server
logging	Show logging configuration and contents of logfile
configuration	Show facility logging configuration

Command Mode

- /exec

show xml server status

```
show xml server status [ __readonly__ { operational_status <o_status> } { maximum_sessions_configured
<max_session> } [ { TABLE_sessions <session_id> <user_name> <start_time> <sap_id> <timeout>
<time_remaining_to_timeout> <ip_addr> } ] ]
```

Syntax Description

show	to display xml agent information
xml	xml agent
server	xml agent server
status	display xml agent information
<i>__readonly__</i>	(Optional)
<i>operational_status</i>	(Optional) run-time info about xml
<i>o_status</i>	(Optional) operational status of the xml
<i>maximum_sessions_configured</i>	(Optional) the max session configured
<i>max_session</i>	(Optional) max sessions number
<i>TABLE_sessions</i>	(Optional) all xml sessions
<i>session_id</i>	(Optional) one xml session id
<i>user_name</i>	(Optional) the xml session user name
<i>start_time</i>	(Optional) the xml session start time
<i>sap_id</i>	(Optional) the mts sap id
<i>timeout</i>	(Optional) inactivity timeout value
<i>time_remaining_to_timeout</i>	(Optional) time remaining to timeout
<i>ip_addr</i>	(Optional) ip address of the session

Command Mode

- /exec



PART II

XML Support

- [Commands with XML/JSON Support, on page 2861](#)



Commands with XML/JSON Support

- [XML Support for Show Commands, on page 2862](#)

XML Support for Show Commands

Table 1:

Show Commands	XML Support
show aaa accounting	yes
show aaa authentication	yes
show aaa authentication login	yes
show aaa authentication login ascii-authentication	yes
show aaa authentication login error-enable	yes
show aaa authentication login invalid-username-log	yes
show aaa authorization	yes
show aaa bypass-user	yes
show aaa groups	yes
show aaa local user blocked	yes
show aaa user default-role	yes
show access-list	yes
show access-list database	yes
show access-list resource	yes
show access-lists	yes
show accounting log	yes
show accounting log all	yes
show accounting log last-index	yes
show accounting log nvram	yes
show accounting log nvram last-index	yes
show accounting log nvram start-seqnum	yes
show accounting log start-seqnum	yes
show acl status	yes
show amt process	yes
show amt vrf all	yes

Show Commands	XML Support
show archive log config	yes
show arp access-lists	yes
show background	no
show banner exec	yes
show banner motd	yes
show bash-shell	yes
show bfd addrmap	yes
show bfd clients	yes
show bfd discrmap	yes
show bfd intfipmap	yes
show bfd neighbors	yes
show bfd scalar	yes
show bfd session	yes
show bfd-app session status	no
show bgp	yes
show bgp	no
show bgp bmp server	yes
show bgp community	yes
show bgp convergence	yes
show bgp convergence private	no
show bgp dampening dampened	yes
show bgp dampening flap-statistics	yes
show bgp dampening parameters	yes
show bgp event-history	no
show bgp evi	yes
show bgp extcommunity	yes
show bgp l3vpn	yes
show bgp neighbors	yes

Show Commands	XML Support
show bgp neighbors commands	yes
show bgp neighbors flap-statistics	yes
show bgp neighbors paths	yes
show bgp paths	yes
show bgp peer	yes
show bgp peer-template	yes
show bgp prefix-list	yes
show bgp private	no
show bgp private attr	no
show bgp private damp	no
show bgp private debug history	no
show bgp process	yes
show bgp received-paths	yes
show bgp regexp	yes
show bgp self-originated	yes
show bgp sessions	yes
show bgp statistics	yes
show bgp summary	yes
show boot	yes
show boot auto-copy	yes
show boot auto-copy list	yes
show boot current	yes
show boot mode	yes
show boot order	yes
show boot timings	no
show boot variables	yes
show callhome	yes
show callhome destination-profile	yes

Show Commands	XML Support
show callhome destination-profile profile	yes
show callhome destination-profile profile CiscoTAC-1	yes
show callhome destination-profile profile full-txt-destination	yes
show callhome destination-profile profile short-txt-destination	yes
show callhome transport	yes
show callhome transport-email	yes
show callhome user-def-cmds	yes
show catena	yes
show catena analytics	yes
show cdp	yes
show cdp all	yes
show cdp global	yes
show cdp neighbors	yes
show cdp neighbors detail	yes
show cdp traffic interface2	yes
show cfs application	yes
show cfs lock	yes
show cfs merge status	yes
show cfs peers	yes
show cfs regions	yes
show cfs status	yes
show checkpoint	yes
show checkpoint summary	yes
show class-map	yes
show class-map type control-plane	yes
show class-map type network-qos	yes
show cli alias	yes
show cli dynamic integers	yes

Show Commands	XML Support
show cli dynamic strings	yes
show cli dynamic-cmd	no
show cli history	no
show cli interface table	no
show cli list	no
show cli syntax	no
show cli variables	yes
show clock	yes
show config-profile	yes
show config-profile applied	yes
show config-replace log exec	yes
show config-replace status	yes
show config-template	yes
show configuration session	yes
show configuration session global-info	yes
show configuration session status	yes
show configuration session summary	yes
show consistency-checker copp	no
show consistency-checker egress-xlate private-vlan	no
show consistency-checker forwarding ipv6 show forwarding ipv6 inconsistency	yes
show consistency-checker forwarding show forwarding inconsistency	yes
show consistency-checker forwarding single-route ipv4 vrf	no
show consistency-checker kim	no
show consistency-checker l2 multicast group source vlan	no
show consistency-checker l2-tahoe module	no
show consistency-checker l2-tahoe switchport interface	no
show consistency-checker l3 multicast group source vrf	no
show consistency-checker l3-interface module	no

Show Commands	XML Support
show consistency-checker link-state fabric-eth	no
show consistency-checker link-state module	no
show consistency-checker membership port-channels	no
show consistency-checker membership vlan	no
show consistency-checker pacl module	no
show consistency-checker pacl port-channels	no
show consistency-checker racl module	no
show consistency-checker racl port-channels	no
show consistency-checker stp-state vlan	no
show consistency-checker vacl	no
show consistency-checker vpc	no
show controller accounting log	no
show copp diff profile profile2	no
show copp profile	yes
show copp status	yes
show copyright	yes
show cores	yes
show crypto ca certificates	yes
show crypto ca certstore	yes
show crypto ca crl	yes
show crypto ca remote-certstore	yes
show crypto ca trustpoints	yes
show crypto ca trustpool	yes
show crypto ca trustpool last download status	yes
show crypto ca trustpool policy	yes
show crypto certificatemap	yes
show crypto key mypubkey rsa	yes
show crypto ssh-auth-map	yes

Show Commands	XML Support
show crypto ssh-auth-map	no
show cts	yes
show current	no
show dampening interface	no
show diagnostic bootup level	yes
show diagnostic content module	yes
show diagnostic description module test all	yes
show diagnostic events	yes
show diagnostic ondemand setting	yes
show diagnostic result module	yes
show diagnostic result module all	yes
show diagnostic simulation module	yes
show diagnostic status module	yes
show diff rollback-patch	yes
show dot1q-tunnel	yes
show dot1q-tunnel interface	yes
show dot1x	yes
show dot1x all	yes
show dot1x all details	yes
show dot1x all statistics	yes
show dot1x all summary	yes
show dot1x interface	yes
show dot1x interface client statistics	yes
show dot1x interface client statistics address	yes
show dot1x supplicant interface	no
show dummy	no
show ecp	yes
show elam report	no

Show Commands	XML Support
show email	yes
show encryption service stat	yes
show environment	yes
show errdisable detect	yes
show errdisable flap	no
show evb	yes
show evb hosts	yes
show evb vsi	yes
show event manager environment	yes
show event manager event-types	yes
show event manager events action-log	yes
show event manager history events	yes
show event manager policy-state	yes
show event manager script system	yes
show event manager system-policy	yes
show fabric database dci	no
show fabric database dci	yes
show fabric database host	yes
show fabric database host statistics	yes
show fabric database host summary	yes
show fabric database profile-map	yes
show fabric database static-host	yes
show fabric database statistics	yes
show fabric forwarding host-db	yes
show fabric forwarding ip local	yes
show fabric forwarding ipv6 local	yes
show fabric multicast	yes
show fabric multicast event-history	no

Show Commands	XML Support
show fabric multicast globals	yes
show fabric multicast ipv4 l2 vni	yes
show fabric multicast ipv4 rp	no
show fabric multicast statistics	no
show fabric multicast vrf	yes
show fc2 bind	yes
show fc2 classf	yes
show fc2 exchange	yes
show fc2 exchresp	yes
show fc2 flogi	yes
show fc2 nport	yes
show fc2 plogi	yes
show fc2 plogi_pwwn	yes
show fc2 port brief	yes
show fc2 port drops	yes
show fc2 port state	yes
show fc2 socket	yes
show fc2 sockexch	yes
show fc2 socknotify	yes
show fc2 socknport	yes
show fc2 vsan	yes
show fcdroplateny	yes
show fcoe	yes
show fcoe database	yes
show fcoe-npv issu-impact	yes
show fctimer	yes
show fctimer D_S_TOV	yes
show fctimer E_D_TOV	yes

Show Commands	XML Support
show fctimer F_S_TOV	yes
show fctimer last action status	yes
show fctimer pending	yes
show fctimer pending-diff	yes
show fctimer R_A_TOV	yes
show fctimer session status	yes
show fctimer status	yes
show fctimer vsan	yes
show feature	yes
show feature-set	yes
show feature-set services	yes
show fhrp	yes
show fhrp verbose	yes
show file	yes
show fips status	yes
show flow cache	yes
show flow exporter	yes
show flow interface	yes
show flow monitor	yes
show flow record	yes
show flow timeout	yes
show flow tracer	no
show forwarding	no
show forwarding adjacency	yes
show forwarding distribution clients	yes
show forwarding distribution fib-state	yes
show forwarding distribution ip igmp snooping	yes
show forwarding distribution ipv6 multicast route	yes

Show Commands	XML Support
show forwarding distribution l2 multicast	yes
show forwarding distribution lisp counters	yes
show forwarding distribution lisp vrf enabled	yes
show forwarding distribution multicast	yes
show forwarding distribution multicast client	yes
show forwarding distribution multicast client-ack-db	yes
show forwarding distribution multicast download	no
show forwarding distribution multicast mfib	yes
show forwarding distribution multicast outgoing-interface-list	yes
show forwarding distribution multicast resp-ack-timer-msgs	no
show forwarding distribution multicast route	yes
show forwarding distribution peer-id	yes
show forwarding distribution trace	no
show forwarding ecmp	yes
show forwarding ecmp recursive	yes
show forwarding interfaces	yes
show forwarding ipv6 adjacency	yes
show forwarding ipv6 multicast route	yes
show forwarding ipv6 route	yes
show forwarding kvfib cache on	no
show forwarding l2 multicast	yes
show forwarding l2vpn ipv6 multicast route	no
show forwarding l2vpn label vpls	yes
show forwarding l2vpn label xconnect	yes
show forwarding l2vpn multicast outgoing-interface-list	no
show forwarding l2vpn multicast route	no
show forwarding l2vpn service vpls	no
show forwarding l2vpn service xconnect	no

Show Commands	XML Support
show forwarding l2vpn vlan	yes
show forwarding multicast outgoing-interface-list	yes
show forwarding multicast route	yes
show forwarding multicast-sr loopback interface	no
show forwarding security group-tag	yes
show forwarding security mac	yes
show forwarding trace	yes
show forwarding trace profile	no
show forwarding trace profile funcstats	yes
show fte event	yes
show fte exporter	yes
show fte monitor	yes
show fte record	yes
show guestshell	yes
show hardware	yes
show hardware access-list lou resource threshold	yes
show hardware access-list resource pooling	yes
show hardware access-list team	yes
show hardware capacity	no
show hardware capacity eobc	yes
show hardware capacity fabric-utilization	yes
show hardware capacity forwarding	no
show hardware capacity interface	yes
show hardware capacity module	yes
show hardware capacity power	yes
show hardware feature-capability	yes
show hardware flow aging	no
show hardware flow entry address type	no

Show Commands	XML Support
show hardware flow ip	no
show hardware flow ipv6	no
show hardware flow l2	no
show hardware flow sampler	no
show hardware flow utilization	no
show hardware forwarding interface statistics mode	yes
show hardware forwarding memory health detail	yes
show hardware forwarding memory health summary	yes
show hardware ip verify	yes
show hardware profile buffer monitor show hardware profile buffer monitor internal	yes
show hardware profile forwarding-mode	no
show hardware profile latency monitor sampling show hardware profile latency monitor	yes
show hardware profile module	no
show hardware profile packet-drop	no
show hardware profile status	yes
show hardware profile tcam region	yes
show hardware qos afd profile	yes
show hardware qos burst-detect max-records	yes
show hardware qos eoq stats-class	yes
show hardware qos include ipg	yes
show hardware qos ing-pg-hdrm-reserve	yes
show hardware qos ing-pg-no-min	yes
show hardware qos ing-pg-share	yes
show hardware qos min-buffer	yes
show hardware qos ns-buffer-profile	yes
show hardware qos ns-mcq3-alias	yes
show hardware rate-limiter	yes
show hardware rate-limiter span-egress	yes

Show Commands	XML Support
show hardware rl snmp class-id	yes
show hardware rl snmp global class-id	yes
show hardware rl snmp local snmp-index class-id	yes
show hostname	yes
show hosts	yes
show hsrp	yes
show hsrp anycast	no
show hsrp anycast interface vlan	no
show hsrp anycast remote-db	no
show hsrp anycast summary	no
show hsrp bfd-sessions	yes
show hsrp bfd-sessions	no
show hsrp delay	yes
show hsrp mgo	yes
show hsrp summary	yes
show icam entries acl module inst	yes
show icam health	yes
show icam itd	yes
show icam prediction entries acl module inst	yes
show icam prediction resource acl_team module inst	yes
show icam prediction resource acl_team module inst trend	yes
show icam prediction scale	yes
show icam resource acl_team module inst	yes
show icam scale	yes
show ieth-header-decode	no
show imp client	no
show imp client sa	no
show inband-telemetry exporter	yes

Show Commands	XML Support
show inband-telemetry flow-profile	yes
show inband-telemetry monitor	yes
show inband-telemetry queue-profile	yes
show inband-telemetry record	yes
show inband-telemetry sessions	yes
show inband-telemetry watchlist	yes
show incompatibility system	yes
show incompatibility-all system	yes
show install	yes
show install all failed-standby	yes
show install all failure-reason	yes
show install all impact	no
show install all impact epld	yes
show install all status	no
show install all time-stats	no
show install epld status	yes
show install log	yes
show install mode	yes
show install packages	yes
show install patches	yes
show interface	yes
show interface bbcredit	yes
show interface brief	yes
show interface cable-diagnostics-tdr	yes
show interface capabilities	yes
show interface counters	yes
show interface counters brief	yes
show interface counters detailed	yes

Show Commands	XML Support
show interface counters detailed all	yes
show interface counters detailed all	no
show interface counters detailed all	yes
show interface counters detailed cached	yes
show interface counters details	yes
show interface counters errors	no
show interface counters errors	yes
show interface counters snmp	yes
show interface counters storm-control	yes
show interface counters table	no
show interface counters trunk	yes
show interface dampening	yes
show interface debounce	yes
show interface description	yes
show interface detail-counters	yes
show interface fcoe	yes
show interface fec	no
show interface flowcontrol	yes
show interface hardware-mappings	no
show interface mac-address	yes
show interface priority-flow-control	yes
show interface private-vlan mapping	yes
show interface pruning	yes
show interface snmp-ifindex	yes
show interface status	yes
show interface status err-disabled	yes
show interface status err-vlans	yes
show interface switchport	yes

Show Commands	XML Support
show interface switchport backup	yes
show interface transceiver	yes
show interface trunk	yes
show interface trunk vsan	yes
show interface trunk vsan	no
show interface trunk vsan	yes
show interface untagged-cos	yes
show interface vlan mapping	yes
show inventory	yes
show ip adjacency	yes
show ip amt relay	yes
show ip amt route	yes
show ip amt tunnel	yes
show ip arp	yes
show ip arp anycast topo-info	yes
show ip arp client	yes
show ip arp controller-statistics	yes
show ip arp esi	yes
show ip arp inspection	yes
show ip arp inspection interfaces	yes
show ip arp inspection log	yes
show ip arp inspection statistics	yes
show ip arp inspection vlan	yes
show ip arp multihoming-statistics	yes
show ip arp off-list	yes
show ip arp open-flow error-statistics	yes
show ip arp statistics	yes
show ip arp suppression topo-info	yes

Show Commands	XML Support
show ip arp suppression-cache	yes
show ip arp tunnel-statistics	yes
show ip arp vpc-statistics	yes
show ip as-path-access-list	yes
show ip client	yes
show ip community-list	yes
show ip debug	no
show ip dhcp global statistics	yes
show ip dhcp option82 suboption info interface	yes
show ip dhcp relay	yes
show ip dhcp relay address	yes
show ip dhcp relay information trusted-sources	yes
show ip dhcp relay statistics	yes
show ip dhcp snooping	yes
show ip dhcp snooping binding	no
show ip dhcp snooping statistics	no
show ip dhcp status	yes
show ip dns source-interface	yes
show ip dns source-interface vrf all	yes
show ip eigrp	yes
show ip eigrp accounting	yes
show ip eigrp event	no
show ip eigrp event-history	no
show ip eigrp event-history bfd	no
show ip eigrp interfaces	yes
show ip eigrp metric	no
show ip eigrp route-map statistics	yes
show ip eigrp sia-event	no

Show Commands	XML Support
show ip eigrp sia-statistics	no
show ip eigrp timers	no
show ip eigrp traffic	yes
show ip extcommunity-list	yes
show ip fib adjacency	yes
show ip fib distribution	no
show ip fib distribution capture	yes
show ip fib distribution clients	yes
show ip fib distribution mroute	yes
show ip fib distribution multicast	yes
show ip fib distribution multicast outgoing-interface-list	yes
show ip fib distribution state	yes
show ip fib route recovered	no
show ip ftp source-interface	yes
show ip ftp source-interface vrf all	yes
show ip http source-interface	yes
show ip http source-interface vrf all	yes
show ip igmp event-history	no
show ip igmp groups	yes
show ip igmp interface	yes
show ip igmp local-groups	yes
show ip igmp policy statistics reports	yes
show ip igmp snooping	yes
show ip igmp snooping event-history	no
show ip igmp snooping explicit-tracking	yes
show ip igmp snooping filter details	yes
show ip igmp snooping groups	yes
show ip igmp snooping lookup-mode	yes

Show Commands	XML Support
show ip igmp snooping mac-oif	yes
show ip igmp snooping mrouter	yes
show ip igmp snooping pw vlan brief	yes
show ip igmp snooping querier	yes
show ip igmp snooping report statistics	yes
show ip igmp snooping statistics	yes
show ip igmp vrf all	yes
show ip interface	yes
show ip lisp	no
show ip lisp data-cache	no
show ip lisp locator-hash	no
show ip lisp map-cache	no
show ip lisp statistics	no
show ip lisp translate-cache	no
show ip load-sharing	yes
show ip local policy	yes
show ip logging	yes
show ip mbgp	no
show ip mbgp community	no
show ip mbgp dampening	no
show ip mbgp extcommunity	no
show ip mbgp flap-statistics	no
show ip mbgp neighbors	no
show ip mbgp nexthop	no
show ip mbgp nexthop-database	no
show ip mbgp prefix-list	no
show ip mbgp received-paths	no
show ip mroute	yes

Show Commands	XML Support
show ip msdp count	yes
show ip msdp event-history	no
show ip msdp mesh-group	yes
show ip msdp peer	yes
show ip msdp policy statistics sa-policy in	yes
show ip msdp rpf	yes
show ip msdp sa	yes
show ip msdp sources	yes
show ip msdp statistics	yes
show ip msdp summary	yes
show ip nat max	yes
show ip nat statistics	yes
show ip nat timeout	yes
show ip nat translations	yes
show ip nat-alias	yes
show ip ospf	yes
show ip ospf border-routers	yes
show ip ospf database	yes
show ip ospf database database-summary	yes
show ip ospf database detail	yes
show ip ospf event-history	no
show ip ospf event-history detail	no
show ip ospf interface	yes
show ip ospf interface brief	yes
show ip ospf lsa-content-changed-list	yes
show ip ospf neighbors	yes
show ip ospf neighbors detail	yes
show ip ospf neighbors summary	yes

Show Commands	XML Support
show ip ospf policy statistics	yes
show ip ospf request-list	yes
show ip ospf retransmission-list	yes
show ip ospf route	yes
show ip ospf route summary	yes
show ip ospf sham-links	yes
show ip ospf statistics	yes
show ip ospf summary-address	yes
show ip ospf traffic	yes
show ip ospf virtual-links	yes
show ip ospf virtual-links brief	yes
show ip pim config-sanity	yes
show ip pim df	yes
show ip pim event-history	no
show ip pim fabric info	yes
show ip pim fabric legacy-vlans	yes
show ip pim group-range	yes
show ip pim host-proxy	yes
show ip pim interface	yes
show ip pim mdt	yes
show ip pim mdt bgp	yes
show ip pim mdt history interval	yes
show ip pim mdt receive	yes
show ip pim mdt send	yes
show ip pim neighbor	yes
show ip pim oif-list	yes
show ip pim policy statistics	yes
show ip pim policy statistics jp	yes

Show Commands	XML Support
show ip pim route	yes
show ip pim rp	yes
show ip pim rp-hash	yes
show ip pim statistics	yes
show ip pim vrf	yes
show ip ping source-interface	yes
show ip ping source-interface vrf all	yes
show ip policy	yes
show ip prefix-list	yes
show ip process	yes
show ip rip	yes
show ip rip interface	yes
show ip rip neighbor	yes
show ip rip policy statistics redistribute	yes
show ip rip route	yes
show ip rip statistics	yes
show ip route	yes
show ip sla application	yes
show ip sla configuration	yes
show ip sla enhanced-history collection-statistics	yes
show ip sla enhanced-history distribution-statistics	yes
show ip sla group schedule	yes
show ip sla history	yes
show ip sla reaction-configuration	yes
show ip sla reaction-trigger	yes
show ip sla responder	yes
show ip sla statistics	yes
show ip sla twamp connection detail	yes

Show Commands	XML Support
show ip sla twamp connection requests	yes
show ip sla twamp session	yes
show ip sla twamp standards	yes
show ip ssh source-interface	yes
show ip ssh source-interface vrf all	yes
show ip static-route	yes
show ip tcp mss	no
show ip telnet source-interface	yes
show ip telnet source-interface vrf all	yes
show ip tftp source-interface	yes
show ip tftp source-interface vrf all	yes
show ip traceroute source-interface	yes
show ip traceroute source-interface vrf all	yes
show ip traffic	yes
show ip udp relay	yes
show ip udp relay interface	yes
show ip udp relay object-group	yes
show ip verify source	yes
show ipv6 adjacency	yes
show ipv6 amt tunnel	yes
show ipv6 bgp	no
show ipv6 bgp community	no
show ipv6 bgp dampening	no
show ipv6 bgp extcommunity	no
show ipv6 bgp flap-statistics	no
show ipv6 bgp neighbors	no
show ipv6 bgp nexthop	no
show ipv6 bgp nexthop-database	no

Show Commands	XML Support
show ipv6 bgp received-paths	no
show ipv6 bgp regexp	no
show ipv6 bgp summary	no
show ipv6 client	yes
show ipv6 dhcp guard policy	yes
show ipv6 dhcp relay	yes
show ipv6 dhcp relay statistics	yes
show ipv6 eigrp route-map statistics	yes
show ipv6 fragments	yes
show ipv6 icmp	yes
show ipv6 icmp global traffic	yes
show ipv6 icmp interface	yes
show ipv6 icmp off-list	yes
show ipv6 icmp vaddr	yes
show ipv6 icmp vpc-statistics	yes
show ipv6 interface	yes
show ipv6 lisp data-cache	no
show ipv6 local policy	yes
show ipv6 mld groups	yes
show ipv6 mld local-groups	yes
show ipv6 mroute	yes
show ipv6 mtu	yes
show ipv6 nd ra dns search-list	yes
show ipv6 nd ra dns server	yes
show ipv6 nd rguard policy	yes
show ipv6 neighbor binding	no
show ipv6 neighbor binding mac	no
show ipv6 neighbor static	yes

Show Commands	XML Support
show ipv6 pim df	yes
show ipv6 pim event-history	no
show ipv6 pim fabric info	yes
show ipv6 pim fabric legacy-vlans	yes
show ipv6 pim group-range	yes
show ipv6 pim interface show ipv6 pim interface	yes
show ipv6 pim neighbor	yes
show ipv6 pim oif-list	yes
show ipv6 pim policy statistics jp	yes
show ipv6 pim route	yes
show ipv6 pim rp	yes
show ipv6 pim rp-hash	yes
show ipv6 pim statistics	yes
show ipv6 pim vrf	yes
show ipv6 policy	yes
show ipv6 prefix-list	yes
show ipv6 process	yes
show ipv6 rguard statistics	yes
show ipv6 rip policy statistics redistribute	yes
show ipv6 route	yes
show ipv6 routers	yes
show ipv6 snooping capture-policy	yes
show ipv6 snooping counters vlan	yes
show ipv6 snooping events	yes
show ipv6 snooping features	yes
show ipv6 snooping messages	yes
show ipv6 snooping policies	yes
show ipv6 snooping policy	yes

Show Commands	XML Support
show ipv6 snooping pss database	yes
show ipv6 static-route	yes
show ipv6 traffic	yes
show isis	yes
show isis adjacency	yes
show isis csnp	yes
show isis database	yes
show isis distribute-ls	yes
show isis event-history	no
show isis hostname	yes
show isis interface	yes
show isis ipv6 redistribute route	yes
show isis ipv6 route	yes
show isis ipv6 route-map statistics	yes
show isis ipv6 summary-address	yes
show isis lslib	no
show isis lsp free-list	no
show isis mesh-group	yes
show isis non tlv overflow-list	no
show isis redistribute route	yes
show isis route	yes
show isis route-map statistics	yes
show isis rrm	yes
show isis spf-log	yes
show isis srm	yes
show isis ssn	yes
show isis statistics	yes
show isis summary-address	yes

Show Commands	XML Support
show isis topology	yes
show isis traffic	yes
show itd	yes
show itd session device-group	yes
show itd statistics	yes
show itd vrf	yes
show key chain	yes
show key chain mode decrypt	yes
show keystore	yes
show kim inconsistency	no
show kubernetes containers	no
show l2 mroute	yes
show l2 multicast ftag	yes
show l2 multicast trees	yes
show l2 route	yes
show l2fwder l2rib info	no
show l2fwder statistics	no
show l2rib clients	yes
show l2rib producers	yes
show l2rib registrations	yes
show l2route evpn ead all	yes
show l2route evpn ethernet-segment esi	yes
show l2route evpn fl all	yes
show l2route evpn fl evi	yes
show l2route evpn imet all	yes
show l2route evpn imet evi	yes
show l2route evpn mac all	yes
show l2route evpn mac evi	yes

Show Commands	XML Support
show l2route evpn mac-ip all	yes
show l2route evpn mac-ip evi	yes
show l2route evpn path-list all	yes
show l2route evpn startup-route all	yes
show l2route evpn startup-route evi	yes
show l2route fl topology	yes
show l2route peerid	yes
show l2route summary	yes
show l2route topology	yes
show lacp counters	yes
show lacp interface	yes
show lacp issu-impact	yes
show lacp neighbor	yes
show lacp port-channel	yes
show lacp system-identifier	yes
show ldap-search-map	yes
show ldap-server	yes
show ldap-server groups	yes
show ldap-server statistics	yes
show license	yes
show license brief	yes
show license default	yes
show license feature package mapping	yes
show license file	yes
show license host-id	yes
show license tech support	no
show license usage	yes
show line	yes

Show Commands	XML Support
show line console	yes
show line console connected	yes
show line console user-input-string	yes
show lisp ddt	no
show lisp ddt queue	no
show lisp ddt referral-cache	no
show lisp dynamic-eid	no
show lisp elp	no
show lisp negative-prefix	no
show lisp proxy-itr	no
show lisp site	no
show lisp site instance-id	no
show lldp all	yes
show lldp dcbx interface	yes
show lldp entry	yes
show lldp interface	yes
show lldp neighbors	yes
show lldp neighbors detail	yes
show lldp neighbors system-detail	yes
show lldp portid-subtype	yes
show lldp timers	yes
show lldp tlv-select	yes
show lldp traffic	yes
show lldp traffic interface	yes
show locator-led status	yes
show logging	no
show logging console	no
show logging info	yes

Show Commands	XML Support
show logging ip access-list cache	yes
show logging ip access-list status	yes
show logging last	no
show logging level	yes
show logging level	no
show logging level aaa	no
show logging level acllog	no
show logging level aclmgr	no
show logging level adbm	no
show logging level adjmgr	no
show logging level amt	no
show logging level arp	no
show logging level ascii-cfg	no
show logging level assoc_mgr	no
show logging level backup	no
show logging level bfd	no
show logging level bgp	no
show logging level bloggerd	no
show logging level bootvar	no
show logging level callhome	no
show logging level capability	no
show logging level catena	no
show logging level cdp	no
show logging level cert_enroll	no
show logging level cfs	no
show logging level clis	no
show logging level clk_mgr	no
show logging level confcheck	no

Show Commands	XML Support
show logging level copp	no
show logging level core	no
show logging level cts	no
show logging level dhcp_snoop	no
show logging level diagnostic diagclient	no
show logging level diagnostic diagmgr	no
show logging level dot1x	no
show logging level ecp	no
show logging level eigrp	no
show logging level eltm	no
show logging level epp	no
show logging level ethdstats	no
show logging level ethpm	no
show logging level evb	no
show logging level evmc	no
show logging level evmed	no
show logging level evms	no
show logging level fabric forwarding	no
show logging level fcoe_mgr	no
show logging level feature-mgr	no
show logging level fs-daemon	no
show logging level gpixm	no
show logging level hardware-telemetry	no
show logging level hsrp	no
show logging level icam	no
show logging level im	no
show logging level imp	no
show logging level interface-vlan	no

Show Commands	XML Support
show logging level ip igmp	no
show logging level ip msdp	no
show logging level ip sla responder	no
show logging level ip sla sender	no
show logging level ip sla twamp-server	no
show logging level ipconf	no
show logging level ipfib	no
show logging level ipqos	no
show logging level ipv6 icmp	no
show logging level iscm	no
show logging level isis	no
show logging level keystore	no
show logging level l2fm	no
show logging level l3vm	no
show logging level lacp	no
show logging level ldap	no
show logging level license	no
show logging level lim	no
show logging level lisp	no
show logging level lldp	no
show logging level m2rib	no
show logging level mfdm	no
show logging level mfwf	no
show logging level mmode	no
show logging level module	no
show logging level monitor	no
show logging level mvsh	no
show logging level nat	no

Show Commands	XML Support
show logging level nbm	no
show logging level netstack	no
show logging level nfm	no
show logging level ngoam	no
show logging level npv	no
show logging level ntp	no
show logging level nxsdk	no
show logging level openflow	no
show logging level ospf	no
show logging level ospfv3	no
show logging level pfstat	no
show logging level pim	no
show logging level pixm	no
show logging level pktmgr	no
show logging level platform	no
show logging level plbm	no
show logging level plcmgr	no
show logging level pltfm_config	no
show logging level plugin	no
show logging level poap	no
show logging level poed	no
show logging level port	no
show logging level port-channel	no
show logging level port-profile	no
show logging level port-resources	no
show logging level port-security	no
show logging level private-vlan	no
show logging level ptp	no

Show Commands	XML Support
show logging level radius	no
show logging level res_mgr	no
show logging level rip	no
show logging level routing ipv6 multicast	no
show logging level routing multicast	no
show logging level rpm	no
show logging level rsvp	no
show logging level sal	no
show logging level san-port-channel	no
show logging level scheduler	no
show logging level security	no
show logging level session-mgr	no
show logging level sflow	no
show logging level smartc	no
show logging level smm	no
show logging level snmpd	no
show logging level snmpmib_proc	no
show logging level spanning-tree	no
show logging level spm	no
show logging level stripcl	no
show logging level sysmgr	no
show logging level tacacs	no
show logging level track	no
show logging level tunnel	no
show logging level u2rib	no
show logging level u6rib	no
show logging level udld	no
show logging level ufdm	no

Show Commands	XML Support
show logging level urib	no
show logging level vdc_mgr	no
show logging level virtual-service	no
show logging level vlan_mgr	no
show logging level vmm	no
show logging level vmtracker	no
show logging level vpc	no
show logging level vrrp-cfg	no
show logging level vrrp-eng	no
show logging level vrrpv3	no
show logging level vsan	no
show logging level vshd	no
show logging level vtp	no
show logging level wwn	no
show logging level xbar	no
show logging logfile	no
show logging logfile duration	no
show logging logfile last-index	no
show logging logfile start-seqn	no
show logging logfile start-time	no
show logging loopback	no
show logging module	no
show logging monitor	no
show logging nvram	yes
show logging onboard	no
show logging onboard kernel-trace	no
show logging origin-id	no
show logging pending	no

Show Commands	XML Support
show logging pending-diff	no
show logging rate-limit	no
show logging server	yes
show logging session status	no
show logging source-interface	no
show logging status	no
show logging timestamp	no
show login on-failure log	yes
show login on-successful log	yes
show mac address-table	yes
show mac address-table aging-time	yes
show mac address-table count	yes
show mac address-table count es	no
show mac address-table learning-mode	yes
show mac address-table limit	yes
show mac address-table loop-detect	no
show mac address-table multicast	yes
show mac address-table notification mac-move	yes
show mac-list	yes
show maintenance maint-delay	yes
show maintenance on-reload reset-reasons	yes
show maintenance profile	yes
show maintenance snapshot-delay	yes
show maintenance timeout	yes
show module	yes
show module bandwidth-fairness	yes
show module uptime	yes
show monitor	yes

Show Commands	XML Support
show monitor session	yes
show mvpn bgp mdt	yes
show mvpn mdt encap	yes
show mvpn mdt route	yes
show mvr groups	yes
show mvr interface	yes
show mvr members	yes
show mvr members count	yes
show mvr members vlan	yes
show mvr receiver-ports	yes
show mvr source-ports	yes
show nbm defaults	no
show nbm flow-policy	no
show nbm flows	yes
show nbm flows bandwidth	no
show nbm flows statistics	yes
show nbm flows summary	yes
show nbm host-policy all	no
show nbm host-policy applied	no
show nbm host-policy applied receiver	no
show nbm interface bandwidth	yes
show ngoam interface statistics	yes
show ngoam loopback	yes
show ngoam pathtrace	yes
show ngoam probe	yes
show ngoam traceroute statistics	yes
show ngoam xconnect session	yes
show npv external-interface-usage	yes

Show Commands	XML Support
show npv flogi-table	yes
show npv status	yes
show npv traffic-map	yes
show ntp access-groups	yes
show ntp authentication-keys	yes
show ntp authentication-status	yes
show ntp information	yes
show ntp logging-status	yes
show ntp peer-status	yes
show ntp peers	yes
show ntp rts-update	yes
show ntp session status	yes
show ntp source	yes
show ntp source-interface	yes
show ntp statistics	yes
show ntp status	yes
show ntp trusted-keys	yes
show nxapi	yes
show nxapi syntax	no
show nxapi-server logs	no
show object-group	yes
show openflow hardware capabilities	no
show openflow switch	yes
show openflow switch flows	no
show ospfv3	yes
show ospfv3 border-routers	yes
show ospfv3 database	yes
show ospfv3 database database-summary	yes

Show Commands	XML Support
show ospfv3 database detail	yes
show ospfv3 event-history	no
show ospfv3 event-history detail	no
show ospfv3 interface	yes
show ospfv3 interface brief	yes
show ospfv3 neighbors	yes
show ospfv3 neighbors detail	yes
show ospfv3 neighbors summary	yes
show ospfv3 policy statistics	no
show ospfv3 request-list	yes
show ospfv3 retransmission-list	yes
show ospfv3 route	yes
show ospfv3 route summary	yes
show ospfv3 statistics	yes
show ospfv3 summary-address	yes
show ospfv3 traffic	yes
show ospfv3 virtual-links	yes
show ospfv3 virtual-links brief	yes
show param-list	yes
show password secure-mode	yes
show password strength-check	yes
show plb	yes
show plb analytics	yes
show plb vrf	yes
show pmap-int	no
show pmap-int-br interface br	yes
show policy-map	yes
show policy-map interface control-plane	yes

Show Commands	XML Support
show policy-map system	yes
show policy-map type control-plane	yes
show policy-map type network-qos	yes
show port naming	no
show port-channel capacity	yes
show port-channel compatibility-parameters	yes
show port-channel database	yes
show port-channel fast-convergence	no
show port-channel load-balance	yes
show port-channel load-balance forwarding-path interface	yes
show port-channel load-balance forwarding-path1 interface src-interface	yes
show port-channel load-balance hardware forwarding-path interface source	yes
show port-channel rbh-distribution	yes
show port-channel scale-fanout	no
show port-channel summary	yes
show port-channel traffic	yes
show port-channel usage	yes
show port-license	yes
show port-profile	yes
show port-profile brief	yes
show port-profile expand-interface	yes
show port-profile sync-status	yes
show port-profile usage	yes
show port-security	yes
show port-security address	yes
show port-security address interface	yes
show port-security interface	yes
show port-security state	yes

Show Commands	XML Support
show postcard-telemetry exporter	yes
show postcard-telemetry flow-profile	yes
show postcard-telemetry monitor	yes
show postcard-telemetry queue-profile	yes
show postcard-telemetry sessions	yes
show postcard-telemetry watchlist	yes
show power inline	yes
show power inline police	yes
show power inline priority	yes
show privilege	no
show processes	yes
show processes cpu	yes
show processes cpu history	no
show processes cpu history data	yes
show processes cpu module	yes
show processes log	yes
show processes log details	yes
show processes log pid	yes
show processes log vdc-all	yes
show processes memory	yes
show processes memory physical	yes
show processes memory shared	yes
show processes vdc	yes
show processes vdc cpu	yes
show processes vdc log	yes
show processes vdc log details	no
show processes vdc log pid	no
show processes vdc memory	yes

Show Commands	XML Support
show processes version	yes
show pss debug	no
show ptp brief	yes
show ptp clock	yes
show ptp clock foreign-masters record	yes
show ptp corrections	yes
show ptp cost	yes
show ptp counters interface	yes
show ptp delay summary	yes
show ptp domain data	yes
show ptp interface domain	yes
show ptp packet-trace	yes
show ptp parent	yes
show ptp port interface	yes
show ptp time-property	yes
show qos dcbxp incompatibility interface	yes
show qos dcbxp info	yes
show qos dcbxp interface	yes
show qos shared-policer	yes
show queuing	yes
show queuing burst-detect	yes
show queuing pfc-queue	yes
show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex	yes
show queuing pfc-queue snmp ifIndex	yes
show queuing tabular	yes
show queuing tah-pfc-queue	yes
show radius status	yes
show radius-cfs	yes

Show Commands	XML Support
show radius-server	yes
show radius-server directed-request	yes
show radius-server groups	yes
show radius-server sorted	yes
show radius-server statistics	yes
show redundancy status	yes
show regexp	no
show reload	yes
show resource	yes
show rmon	yes
show role	yes
show role feature	yes
show role feature-group	yes
show rollback log exec	yes
show rollback status	yes
show route-map	yes
show route-map pbr-statistics	yes
show router-guard	yes
show routing	yes
show routing clients	yes
show routing event-history	no
show routing hash	yes
show routing hidden-nh	yes
show routing ipv6	yes
show routing ipv6 clients	yes
show routing ipv6 event-history	no
show routing ipv6 hash	yes
show routing ipv6 hidden-nh	yes

Show Commands	XML Support
show routing ipv6 memory estimate	yes
show routing ipv6 memory statistics	yes
show routing ipv6 multicast	yes
show routing ipv6 multicast clients	yes
show routing ipv6 multicast event-history	no
show routing ipv6 multicast memory estimate	yes
show routing ipv6 nexthop info	no
show routing ipv6 nhlfe	yes
show routing ipv6 recursive-next-hop	yes
show routing memory estimate	yes
show routing memory statistics	yes
show routing multicast	yes
show routing multicast clients	yes
show routing multicast event-history	no
show routing multicast lisp encap	yes
show routing multicast mdt encapsulation	yes
show routing multicast memory estimate	yes
show routing multicast sr	yes
show routing nhlfe	yes
show routing recursive-next-hop	yes
show routing unresolved-next-hop	no
show routing-context	yes
show running-config	no
show running-config aaa	no
show running-config acllog	no
show running-config aclmgr	no
show running-config aclmgr active	no
show running-config adjmgr	no

Show Commands	XML Support
show running-config all	no
show running-config arp	no
show running-config assoc	no
show running-config backup	no
show running-config bfd	no
show running-config bgp	no
show running-config bloggerd	no
show running-config callhome	no
show running-config catena	no
show running-config cdp	no
show running-config cert-enroll	no
show running-config cfs	no
show running-config clock_manager	no
show running-config config-profile	no
show running-config config-template	no
show running-config controller	no
show running-config copp	no
show running-config dhcp	no
show running-config diagnostic	no
show running-config diff	no
show running-config dot1x	no
show running-config ecp	no
show running-config eem	no
show running-config eigrp	no
show running-config eltm	no
show running-config evb	no
show running-config expand-port-profile	no
show running-config fabric forwarding	no

Show Commands	XML Support
show running-config fabric multicast	no
show running-config fcoe_mgr	no
show running-config hardware-telemetry	no
show running-config hsrp	no
show running-config icam	no
show running-config icmpv6	no
show running-config igmp	no
show running-config imp	no
show running-config interface	no
show running-config interface explicit	no
show running-config ip	no
show running-config ipqos	no
show running-config ipqos active	no
show running-config ipv6	no
show running-config isis	no
show running-config l3vm	no
show running-config ldap	no
show running-config license	no
show running-config lisp	no
show running-config lldp	no
show running-config mmode	no
show running-config monitor	no
show running-config msdp	no
show running-config nat	no
show running-config nbm	no
show running-config ngoam	no
show running-config ntp	no
show running-config nv overlay	no

Show Commands	XML Support
show running-config nxsdk	no
show running-config openflow	no
show running-config ospf	no
show running-config ospfv3	no
show running-config param-list	no
show running-config pim	no
show running-config pim6	no
show running-config plb-services	no
show running-config poe	no
show running-config port-profile	no
show running-config port-security	no
show running-config ptp	no
show running-config radius	no
show running-config rip	no
show running-config routing ip multicast	no
show running-config routing ipv6 multicast	no
show running-config rpm	no
show running-config rsvp	no
show running-config section	no
show running-config security	no
show running-config services	no
show running-config sflow	no
show running-config sla responder	no
show running-config sla sender	no
show running-config sla twamp-server	no
show running-config smart-channel	no
show running-config snmp	no
show running-config spanning-tree	no

Show Commands	XML Support
show running-config srte	no
show running-config switch	no
show running-config tacacs	no
show running-config track	no
show running-config udd	no
show running-config vdc	no
show running-config vdc-all	no
show running-config virtual-service	no
show running-config vlan	no
show running-config vmtracker	no
show running-config vpc	no
show running-config vrf	no
show running-config vrf default	no
show running-config vrrp	no
show running-config vrrpv3	no
show running-config vshd	no
show running-config vtp	no
show running-config wwnm	no
show san-port-channel compatibility-parameters	yes
show san-port-channel consistency	yes
show san-port-channel consistency detail	yes
show san-port-channel database	yes
show san-port-channel summary	yes
show san-port-channel usage	yes
show scheduler config	yes
show scheduler job	yes
show scheduler logfile	yes
show scheduler schedule	yes

Show Commands	XML Support
show sflow	yes
show sflow statistics	yes
show smart-channel	yes
show snapshots	yes
show snapshots compare	yes
show snapshots compare ipv4routes	yes
show snapshots compare ipv6routes	yes
show snapshots compare summary	yes
show snapshots dump	yes
show snapshots sections	yes
show snmp	yes
show snmp community	yes
show snmp context	yes
show snmp engineID	yes
show snmp group	yes
show snmp host	yes
show snmp nms-statistics	yes
show snmp oid-statistics	yes
show snmp roledebug	no
show snmp sessions	yes
show snmp source-interface	yes
show snmp trap	yes
show snmp user	yes
show sockets client	yes
show sockets connection	yes
show sockets local-port-range	yes
show sockets ns-port-kiosk	no
show sockets statistics	yes

Show Commands	XML Support
show sockets tcp keychain binding	yes
show spanning-tree	yes
show spanning-tree blockedports	yes
show spanning-tree bridge	yes
show spanning-tree inconsistentports	yes
show spanning-tree interface	yes
show spanning-tree issu-impact	yes
show spanning-tree mst	yes
show spanning-tree mst configuration	yes
show spanning-tree mst configuration digest	yes
show spanning-tree mst interface	yes
show spanning-tree pathcost method	yes
show spanning-tree root	yes
show spanning-tree summary	yes
show spanning-tree summary totals	yes
show sprom	yes
show srte pce ipv4 peer	yes
show srte policy	yes
show srte policy fh	no
show ssh key	yes
show ssh server	yes
show ssx details	yes
show ssx exporter	yes
show ssx monitor	yes
show ssx record	yes
show startup-config	no
show startup-config aaa	no
show startup-config aclog	no

Show Commands	XML Support
show startup-config aclmgr	no
show startup-config adjmgr	no
show startup-config arp	no
show startup-config assoc	no
show startup-config backup	no
show startup-config bfd	no
show startup-config bgp	no
show startup-config bloggerd	no
show startup-config callhome	no
show startup-config catena	no
show startup-config cdp	no
show startup-config cert-enroll	no
show startup-config cfs	no
show startup-config config-profile	no
show startup-config copp	no
show startup-config dhcp	no
show startup-config diagnostic	no
show startup-config dot1x	no
show startup-config ecp	no
show startup-config eem	no
show startup-config eigrp	no
show startup-config eltm	no
show startup-config evb	no
show startup-config exclude	no
show startup-config expand-port-profile	no
show startup-config fabric forwarding	no
show startup-config fabric multicast	no
show startup-config fcoe_mgr	no

Show Commands	XML Support
show startup-config hardware-telemetry	no
show startup-config hsrp	no
show startup-config icam	no
show startup-config icmpv6	no
show startup-config igmp	no
show startup-config imp	no
show startup-config interface	no
show startup-config ip	no
show startup-config ipqos	no
show startup-config ipv6	no
show startup-config isis	no
show startup-config l3vm	no
show startup-config ldap	no
show startup-config license	no
show startup-config lisp	no
show startup-config lldp	no
show startup-config log	no
show startup-config mmode	no
show startup-config monitor	no
show startup-config msdp	no
show startup-config nat	no
show startup-config nbm	no
show startup-config ngoam	no
show startup-config ntp	no
show startup-config nv overlay	no
show startup-config nxsdk	no
show startup-config openflow	no
show startup-config ospf	no

Show Commands	XML Support
show startup-config ospfv3	no
show startup-config param-list	no
show startup-config pim	no
show startup-config pim6	no
show startup-config plb-services	no
show startup-config poe	no
show startup-config port-profile	no
show startup-config port-security	no
show startup-config ptp	no
show startup-config radius	no
show startup-config rip	no
show startup-config routing ip multicast	no
show startup-config routing ipv6 multicast	no
show startup-config rpm	no
show startup-config rsvp	no
show startup-config security	no
show startup-config services	no
show startup-config sflow	no
show startup-config sla responder	no
show startup-config sla sender	no
show startup-config sla twamp-server	no
show startup-config smart-channel	no
show startup-config snmp	no
show startup-config srte	no
show startup-config switch	no
show startup-config tacacs	no
show startup-config track	no
show startup-config udd	no

Show Commands	XML Support
show startup-config vdc	no
show startup-config vdc-all	no
show startup-config virtual-service	no
show startup-config vlan	no
show startup-config vmtracker	no
show startup-config vpc	no
show startup-config vrf	no
show startup-config vrf default	no
show startup-config vrrpv3	no
show startup-config vshd	no
show startup-config vtp	no
show startup-config wwnm	no
show summary	no
show sup-monitor drops session	no
show switch-profile	yes
show switch-profile buffer	yes
show switch-profile peer	yes
show switch-profile status	yes
show switch-scope controller	no
show switching-mode	yes
show switching-mode fabric-speed	yes
show system acl	yes
show system auto-collect tech-support	yes
show system boottime	yes
show system clis event-history	no
show system config reload-pending	yes
show system cores	yes
show system default switchport	yes

Show Commands	XML Support
show system error-id	yes
show system exception-info	yes
show system fabric-mode	yes
show system fast-reload stabilization-timer	yes
show system image-verification	no
show system inband queuing statistics	yes
show system inband queuing status	yes
show system login	yes
show system login failures	yes
show system memory-thresholds	yes
show system mode	yes
show system poap	no
show system pss shrink status	yes
show system redundancy ha status	yes
show system redundancy status	yes
show system reset-reason	yes
show system reset-reason module	yes
show system resources	yes
show system resources	no
show system routing mode	yes
show system security	yes
show system simulate fan-presence	no
show system standby manual-boot	yes
show system switch-mode	yes
show system uptime	yes
show system verify bios flash	yes
show system vlan reserved	yes
show table-map	yes

Show Commands	XML Support
show tacacs-server	yes
show tacacs-server directed-request	yes
show tacacs-server groups	yes
show tacacs-server sorted	yes
show tacacs-server statistics	yes
show tech-support	no
show tech-support aaa	no
show tech-support aclmgr	no
show tech-support aclmgr compressed	no
show tech-support aclqos	no
show tech-support aclqos compressed	no
show tech-support adjmgr	no
show tech-support all	no
show tech-support all binary	no
show tech-support analytics	no
show tech-support arp	no
show tech-support ascii-cfg	no
show tech-support assoc_mgr	no
show tech-support backup	no
show tech-support bcm	no
show tech-support bfd	no
show tech-support bgp	no
show tech-support biosd	no
show tech-support bloggerd	no
show tech-support bloggerd-all	no
show tech-support bootvar	no
show tech-support brief	no
show tech-support callhome	no

Show Commands	XML Support
show tech-support cdp	no
show tech-support cert-enroll	no
show tech-support cfs	no
show tech-support cli	no
show tech-support clis	no
show tech-support clock_manager	no
show tech-support commands	no
show tech-support controller	no
show tech-support copp	no
show tech-support dcbx	no
show tech-support details	no
show tech-support dhclient	no
show tech-support dhcp	no
show tech-support dme	no
show tech-support dot1x	no
show tech-support ecp	no
show tech-support eem	no
show tech-support eigrp	no
show tech-support eltm	no
show tech-support ethpm	no
show tech-support ethport	no
show tech-support evb	no
show tech-support fabric forwarding	no
show tech-support fabric multicast	no
show tech-support fast-reload	no
show tech-support fc2	no
show tech-support fcoe	no
show tech-support fips	no

Show Commands	XML Support
show tech-support forwarding l2 multicast	no
show tech-support forwarding l2 multicast vdc-all	no
show tech-support forwarding l2 unicast	no
show tech-support forwarding l3 multicast	no
show tech-support forwarding l3 multicast detail	no
show tech-support forwarding l3 multicast detail vdc-all	no
show tech-support forwarding l3 multicast vdc-all	no
show tech-support forwarding l3 unicast	no
show tech-support forwarding l3 unicast detail	no
show tech-support forwarding l3 unicast detail vdc-all	no
show tech-support forwarding l3 unicast vdc-all	no
show tech-support forwarding multicast	no
show tech-support gold	no
show tech-support gpixm	no
show tech-support ha	no
show tech-support ha module	no
show tech-support ha standby	no
show tech-support hardware-telemetry	no
show tech-support hsrp	no
show tech-support hsrp brief	no
show tech-support icam	no
show tech-support icmpv6	no
show tech-support im	no
show tech-support imp	no
show tech-support inband counters	no
show tech-support include-time	no
show tech-support install	no
show tech-support interface-vlan	no

Show Commands	XML Support
show tech-support ip	no
show tech-support ip igmp	no
show tech-support ip igmp snooping	no
show tech-support ip msdp	no
show tech-support ip pim	no
show tech-support ipqos	no
show tech-support ipv6	no
show tech-support ipv6 mld	no
show tech-support ipv6 multicast	no
show tech-support ipv6 pim	no
show tech-support isis	no
show tech-support issu	no
show tech-support kstack	no
show tech-support l2	no
show tech-support l2fm	no
show tech-support l2fm clients	no
show tech-support l2fm detail	no
show tech-support l2fm l2dbg	no
show tech-support l2rib	no
show tech-support l3vm	no
show tech-support l3vpn	no
show tech-support lacp	no
show tech-support ldap	no
show tech-support license	no
show tech-support lim	no
show tech-support lisp	no
show tech-support lldp	no
show tech-support logging	no

Show Commands	XML Support
show tech-support m2rib	no
show tech-support mfwd	no
show tech-support mmode	no
show tech-support module	no
show tech-support module all	no
show tech-support monitor	no
show tech-support monitor erspan	no
show tech-support monitore-all	no
show tech-support multicast	no
show tech-support multicast-vxlan-evpn	no
show tech-support mvpn	no
show tech-support nat	no
show tech-support nbm	no
show tech-support netstack	no
show tech-support netstack detail	no
show tech-support ngoam	no
show tech-support npacl	no
show tech-support npv	no
show tech-support ns	no
show tech-support ntp	no
show tech-support nxapi	no
show tech-support nxsdk	no
show tech-support object-store	no
show tech-support openflow	no
show tech-support ospf	no
show tech-support ospfv3	no
show tech-support page	no
show tech-support patch	no

Show Commands	XML Support
show tech-support pbr	no
show tech-support pfstat	no
show tech-support pixm	no
show tech-support pixm-all	no
show tech-support pixmc-all	no
show tech-support pktmgr	no
show tech-support platform-sdk	no
show tech-support plb-services	no
show tech-support plcmgr	no
show tech-support pltfm-config	no
show tech-support poe	no
show tech-support port	no
show tech-support port-channel	no
show tech-support port-client-all	no
show tech-support port-profile	no
show tech-support port-security	no
show tech-support private-vlan	no
show tech-support ptp	no
show tech-support radius	no
show tech-support rip	no
show tech-support routing	no
show tech-support routing ipv6	no
show tech-support routing ipv6 multicast	no
show tech-support routing multicast	no
show tech-support rpm	no
show tech-support sal	no
show tech-support san	no
show tech-support san-port-channel	no

Show Commands	XML Support
show tech-support satmgr	no
show tech-support security	no
show tech-support services	no
show tech-support session-mgr	no
show tech-support sflow	no
show tech-support single-jericho	no
show tech-support sksd	no
show tech-support sla responder	no
show tech-support sla sender	no
show tech-support sla twamp-server	no
show tech-support smartc	no
show tech-support smm	no
show tech-support snmp	no
show tech-support sockets	no
show tech-support spm	no
show tech-support srte	no
show tech-support statsclient	no
show tech-support stp	no
show tech-support sup-filesys	no
show tech-support sysmgr	no
show tech-support tacacs	no
show tech-support track	no
show tech-support tunnel	no
show tech-support u2rib	no
show tech-support udld	no
show tech-support usd-all	no
show tech-support vdc	no
show tech-support virtual-service	no

Show Commands	XML Support
show tech-support vlan	no
show tech-support vmtracker	no
show tech-support vpc	no
show tech-support vrrp	no
show tech-support vrrp brief	no
show tech-support vrrpv3	no
show tech-support vsan	no
show tech-support vshd	no
show tech-support vtp	no
show tech-support vvlan	no
show tech-support xbar	no
show tech-support xml	no
show tech-support xos	no
show telnet server	yes
show terminal	yes
show terminal output xml version	yes
show time-range	yes
show time-stamp running-config last-changed	yes
show track	yes
show track brief	yes
show troubleshoot l2 mac vlan	no
show troubleshoot l3 ipv4 vrf	no
show trunk protocol	yes
show ttag brief	yes
show udld	yes
show udld global	yes
show udld neighbors	yes
show user-account	yes

Show Commands	XML Support
show username keypair	yes
show userpassphrase	yes
show users	yes
show vdc	yes
show vdc current-vdc	yes
show vdc fcoe-vlan-range	yes
show vdc resource	yes
show vdc resource template	yes
show version	yes
show version epld	yes
show version image	yes
show version module	yes
show version module epld	yes
show virtual-service	yes
show virtual-service storage pool list	yes
show virtual-service tech-support	no
show virtual-service utilization name	yes
show virtual-service version	yes
show vlan	yes
show vlan access-list	yes
show vlan access-map	yes
show vlan all-ports	yes
show vlan counters	yes
show vlan dot1Q tag native	yes
show vlan fcoe	yes
show vlan filter	yes
show vlan id	yes
show vlan id counters	yes

Show Commands	XML Support
show vlan id vn-segment	yes
show vlan name	yes
show vlan private-vlan	yes
show vlan private-vlan type	yes
show vlan xbrief	yes
show vlan xsummary	yes
show vmtracker	no
show vmtracker certificate	no
show vmtracker fabric auto-config	no
show vmtracker status	yes
show vpc	yes
show vpc consistency-parameters	yes
show vpc consistency-parameters vlans	yes
show vpc orphan-ports	yes
show vpc peer-keepalive	yes
show vpc role	yes
show vpc statistics peer-keepalive	yes
show vpc statistics vpc	no
show vrf	yes
show vrf	no
show vrrp	yes
show vrrp bfd-sessions	yes
show vrrpv3	yes
show vrrs client	yes
show vrrs pathway	yes
show vrrs pathway address	no
show vrrs server	yes
show vrrs tag	yes

Show Commands	XML Support
show vsan	yes
show vsan membership	yes
show vsan membership interface	yes
show vsan usage	yes
show vtp counters	yes
show vtp interface	yes
show vtp password	yes
show vtp status	yes
show wred-queue qos-group-map	yes
show wrr unicast-bandwidth	yes
show wrr-queue qos-group-map	yes
show wwn status	yes
show wwn switch	yes
show wwn test	no
show wwn vsan-wwn	yes
show xml server logging configuration	no
show xml server status	yes