

Cisco NX-OS تارادصا

تايوتحمل

قمدملا

قماعلا ةيقرتلا تاداشرا

[Cisco Nexus 3000/9000 لاهب ىصوملا ةيقرتلا ةفوفصم](#)

[Cisco Nexus 7000 لاهب ىصوملا ةيقرتلا ةفوفصم](#)

لاهب ىصوملا رادصا لاقئاثو

[Cisco Nexus 3000 و 3100 و 3200 و 3400-S و 3500 و 3600 Series Switches تالوحملا](#)

[Cisco Nexus 9000 تالدم ةلسلس](#)

[Cisco Nexus 5500 تالدم ةلسلس](#)

[Cisco Nexus 5600 تالدم ةلسلس](#)

[Cisco Nexus 6000 تالدم ةلسلس](#)

[Cisco Nexus 7000 تالدم ةلسلس](#)

قمدملا

Cisco NX-OS ةيقرتلا Cisco Nexus زاهج دادعإ ةبولطملا ةلصلا تاذاوملا دن تسملا اذه فصى OS.

قماعلا ةيقرتلا تاداشرا

Cisco Nexus 3000/9000 لاهب ىصوملا ةيقرتلا ةفوفصم

Cisco Nexus 3000/9000 ةلسلسلا نم تالوحملا ةيقرتلا ةفوفصم:

<https://www.cisco.com/c/dam/en/us/td/docs/dcn/tools/nexus-9k3k-issu-matrix/index.html>

Cisco Nexus 7000 لاهب ىصوملا ةيقرتلا ةفوفصم

Cisco Nexus 7000 ةلسلسلا نم تالوحملا ةيقرتلا لودج:

<https://www.cisco.com/c/dam/en/us/td/docs/dcn/tools/nexus-7k-issu-matrix/index.html>

لاهب ىصوملا رادصا لاقئاثو

Cisco Nexus 3000 و 3100 و 3200 و 3400-S و 3500 و 3600 Series Switches تالوحملا

Cisco Nexus ةلسلسلا نم تالوحملا Cisco NX لاهب ىصوملا NX لىغشتلا ماظن تارادصا 3000 و 3100 و 3200 و 3400-S و 3500 و 3600:

https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus3000/sw/recommended_release/b_Minor_OS_Releases_for_Cisco_Nexus_3000_Series_Switches.html

تال د ب م ة لس لس Cisco Nexus 9000

Cisco Nexus 9000 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus9000/sw/recommended_release/b_Minior_OS_Releases_for_Cisco_Nexus_9000_Series_Switches.html

تال د ب م ة لس لس Cisco Nexus 5500

Cisco Nexus 5500 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus5500/sw/release/recommended_release/os_releases.html

تال د ب م ة لس لس Cisco Nexus 5600

Cisco Nexus 5600 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus5600/sw/release/recommended_release/os_releases.html

تال د ب م ة لس لس Cisco Nexus 6000

Cisco Nexus 6000 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

https://www.cisco.com/c/en/us/td/docs/switches/datacenter/nexus6000/sw/release/recommended_release/os_releases.html

تال د ب م ة لس لس Cisco Nexus 7000

Cisco Nexus 7000 Series Switches: ن م ا ه ب ي ص و م ل ل NX-OS ل ي غ ش ت ل ا م ا ظ ن ت ا ر ا د ص ا

https://www.cisco.com/c/en/us/td/docs/switches/datacenter/sw/nx-os/recommended_releases/recommended_nx-os_releases.html

ةمچرتل هذه ل و ح

ةلأل تاي نقتل ن م ة و مچ م ادخت ساب دن تسم ل ا ذه Cisco ت مچرت
م ل ا ل ا ا ن ا ع مچ ي ف ن ي م دخت س م ل ل م عد ي و ت ح م م ي دقت ل ة ي ر ش ب ل و
ا م ك ة ق ي ق د ن و ك ت ن ل ة ل ا ة مچرت ل ض ف ا ن ا ة ظ ح ا ل م ي ج ر ي . ة ص ا خ ل ا م ه ت غ ل ب
Cisco ي ل خ ت . ف ر ت ح م مچرت م ا ه م د ق ي ي ت ل ا ة ي ف ا ر ت ح ا ل ا ة مچرت ل ا ع م ل ا ح ل ا و ه
ي ل ا م ا ة ا د ع و ج ر ل ا ب ي ص و ت و ت ا مچرت ل ا هذه ة ق د ن ع ا ه ت ي ل و ئ س م Cisco
Systems (ر ف و ت م ط ب ا ر ل ا) ي ل ص ا ل ا ي ز ي ل ج ن ا ل ا دن ت س م ل ا