

ةيتوصولا ةباجتسالال ةمئاق ىلإ لوصولا SPA3102 ل (IVR) ةيلعافتال

فدهل

زاهل لخد ةفلتخم ل تانويوكتلل تاميلعت ةيلعافتال ةيتوصولا ةباجتسالال رفوت
امهف دن تسمل اذه مدقي. زاهل اب فتاه ليصوت دن ع تاميلعتال هذه ىل لوصولال متي
SPA3102 ب ةصاخال (IVR) ةيلعافتال ةيتوصولا ةباجتسالال ةمئاق ل اديازت م

قيبطتلل ةلباقال ةزهجال

·SPA8000

·SPA3102

·SPA9000

·SPA2102

·SPA112

·PAP2T

جماربال رادصل

·رادصلال v6.1.12

(IVR) ةيلعافتال ةيتوصولال درل ةمئاق

ةيلعافتال ةيتوصولال ةباجتسالال ةمئاق ىلإ لوصولال

نكمي. ةيتوصولال ةباوبلاب صاخال فتاهال ذفنم ب لصتم فتاه مادختسا. 1. ةوطخال
يرطانت فتاه لال خ نم طقف ةيلعافتال ةيتوصولال ةباجتسالال ةمئاق ىلإ لوصولال

(*) ةيمجن ةمالع حيتافم ةعبرأ طغضا. 2. ةوطخال

ءاچرل. Linksys نيوكت ةمئاق لوقتو ةيتوصولال ةبلاطم ل عمست ىتح رطنتا. 3. ةوطخال
چورخال ىتح فقولال وأ (لطر) # حاتفم هعبتي يذال رايلال لال خد

فاصولال ةمئاقال تارايلو رموال او تاءارجلال درس يذال يلاتال لودجلال عجار. 4. ةوطخال
فتاهال قلغأ، ةمئاقال نم چورخلل. (لطر) # حاتفم لال ىل ع طغضا، رايل ديحت دب

ةيلعافتال ةيتوصولال درل ةمئاق

IVR Action	IVR Menu	Parameter(s)	Notes
Activate IVR Menu	****	None	Ignore SIT or other tones until you hear, "Sipura configuration menu. Please enter option followed by the pound key or hang-up to exit."
Check WAN IP Address	110	None	IVR will announce the IP address of the WAN port
Check WAN Network Mask	120	None	IVR will announce the network mask of the WAN port
Check WAN Gateway	130	None	IVR will announce the gateway of the WAN port
Check MAC Address	140	None	IVR will announce MAC address of the SPA-2100
Check Firmware Version	150	None	IVR will announce the firmware version running on SPA-2100
Check Primary DNS Server IP Address	160	None	IVR will announce the primary DNS server IP address
Check WAN Port Web Server Port	170	None	IVR will announce the WAN port web server port
Check LAN IP Address	210	None	IVR will announce the IP address of the LAN port
Check WAN Internet Connection Type	100	None	IVR will announce the WAN Internet Connection Type
Set WAN Internet Connection Type (see "Wan Setup" -> "Internet Connection Settings")	101	Enter 0 to use DHCP Enter 1 to use Static IP Enter 3 to use PPPoE	Requires Password
Set Static IP address (WAN Port)	111	Enter IP address using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Network Mask	121	Enter network mask using numbers on the telephone keypad. Use the * (star) key when enter a decimal point	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set WAN Gateway	131	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	WAN Internet Connection Type must be set to "Static IP", otherwise you will hear "Invalid Option" when you try to use this option. Requires Password.
Set Primary DNS Server IP Address	161	Enter IP address using numbers on the telephone keypad. Use the * (star) key when entering a decimal point.	Requires Password.
		Press 0 to select the router/NAT mode.	If the Voice Gateway acts as the router for your network, use the

،اهريغت ب مدختس ملل حامس لا و لوؤس مل رورم ةملك نييغت مدع ةلاح ي ف :ةظحالم
رورم ةملك رورم ةملك ةزي ممل رصان علا بلطتت نلف

ةمچرتل هذه ل و ح

ةلأل تاي نقتل ن م ة و مچ م ادخت ساب دن تسم ل ا اذ ه Cisco ت مچرت
م ل ا ل ا ا ن ا ع مچ ي ف ن ي م د خ ت س م ل ل م ع د ي و ت ح م م ي د ق ت ل ة ي ر ش ب ل و
ا م ك ة ق ي ق د ن و ك ت ن ل ة ل ا ة مچرت ل ض ف ا ن ا ة ظ ح ا ل م ي ج ر ي . ة ص ا خ ل ا م ه ت غ ل ب
Cisco ي ل خ ت . ف ر ت ح م مچرت م ا ه م د ق ي ي ت ل ا ة ي ف ا ر ت ح ا ل ا ة مچرت ل ا ع م ل ا ح ل ا و ه
ي ل ا م ا ة ا د ع و ج ر ل ا ب ي ص و ت و ت ا مچرت ل ا ه ذ ه ة ق د ن ع ا ه ت ي ل و ئ س م Cisco
Systems (ر ف و ت م ط ب ا ر ل ا) ي ل ص ا ل ا ي ز ي ل ج ن ا ل ا دن ت س م ل ا