

Cisco Unified CM IM and Presence Administration
For Cisco Unified Communications Solutions

System ▾ Presence ▾ Messaging ▾ Application ▾ Bulk Administration ▾ Diagnostics ▾ Help ▾

System Configuration Troubleshooter

- System Dashboard
- System Troubleshooter
- Microsoft RCC Troubleshooter

XCP Troubleshooter

Test Description	Outcome	Problem
Verify Cisco XCP Router service is running	✓	
Verify Cisco XCP Connection Manager's service status	✓	
Verify Cisco XCP Authentication's service status	✓	

3. مل اذا في اي ودي Cisco XCP ةقداصم ةمدخو Cisco XCP لاصتا ري دم ةمدخ لي غشت ب مق .
لعل باب تامدخال لي غشت ادب متي .

```
admin:utils service start Cisco XCP Authentication Service
admin:utils service start Cisco XCP Connection Manager
```

XCP تازيم تامدخ عيمج فاقوي متي ، Cisco XCP هجوم فاقوي اب موقت امندنع : **ةظالم**
اي ئاقتل .

تامدخال لي غشت بجي ، ةي اساس ال اروضح لاو ةيروفلا ةلسارملا ةمدخ رشنل ةبسنلاب
ةيئالات :

• Cisco ن SIP ليكو .

• Cisco ن دجاوتلا كرحم .

• Cisco ب صاخلا XCP ل لاصتالا ري دم .

• Cisco ب صاخلا XCP ةقداصم ةمدخ .

عجرملا طبار :

(2) 10.5 رادصال ، Cisco Unified Communications Manager على امتداد اروضح لاو ةيروفلا ةلسارملا ةمدخ نيواكت

