



- IEC6400 ليلسلسلتال مقررلا
- IEC6400 ةكبشال فرعم

"TAM" ةروص مساب ابلالغ اهليل راشي) ةبولطملا ةصاخال ةروصلال TAC رفوت

اذه URL ناووع مادختساب ةلححتف

<https://mycase.cloudapps.cisco.com/case>

## ةيقرتال ةيلمع

- (GUI) ةيموسرللا مدختسمللا ةهجاو ربع IEC6400 تباثلال جم انربلا ةيقرتل ارجل نكمي ال
- نكمي يذل TFTP مداخل مادختساب (CLI)، رماوالا رطس ةهجاو ربع ةيقرتال ارجل متي
- IEC6400 نم هيلل لوصولال

## TFTP مداخل زي هجت

1. لوصولل لبالق IP ناووع يلع TFTP مداخل فق
2. TFTP رنجلال ليلدللا يف تافللملا هذه عض
  - ةروص TAC ةصاخال (لاثم: IEC6400\_TAM\_<timestamp>.img)
  - ةروص IEC6400 1.2.0 (لاثم: IEC6400-1.2.0.5.img)
3. دع اوق حمست) TFTP مداخل يلى IP لوصولال ةينانكم هيلل IEC6400 نأ نم دكأت (UDP/69 ب ةياملال رادلج/VLAN/هيجوتال)

## CLI (tftp-fw-upgrade) رماو ارجم

رايخ اذه دوزي ةادا نيسحتال، IEC6400 CLI نم

- tftp-server — مداخل IP ناووع نييعت
- upgrade-fw-image — ةروص ددح
- ةيئاقللال ةيقرتلال او ةيرودلال تاققحتلال ليلطعت/نيلكمت — ةيئاقللال ةيقرت
- (تاعاسلاب) يرودلال صحتلال ةرتف نييعت — صحتلال ةرتف
- ةتباثلال جم اربلل ةيروف ةيقرتل/ليلزنن/صحتف ليلغشت نأل نكمي

## ةيقرتال ارجل

1: ةوطخال

TAC نم ةمدقملا ةروصلال يلى ريشت يئال ةيقرتلال ليلغشت ب مق

- كلذ عقت نكمي. ليلغشتلال ةداعل/ةيقرتلال ةيلمع اناثأ SSH ةسلج لاصتلا عطق نكمي
- تئرتنلال يلى زاهجال دوعي يتح رطتانا -
- ةيقرتلال اناثأ ةقاطلال عطق ال

```
# tftp-fw-upgrade tftp-server 10.122.136.38 upgrade-fw-image IEC6400_TAM_20260128115452.img check-now
Starting TFTP file transfer for IEC6400_TAM_20260128115452.img, TFTP server 10.122.136.38 ...
New firmware: IEC6400_TAM_20260128115452.img. Start downloading...
1M
TFTP firmware upgrade...
WARNING: DO NOT POWER OFF THE UNIT DURING A FIRMWARE UPGRADE
starting upgrading...
Firmware already upgrading.
Rtp6395@5.69.163.198:~# Connection to 14.2.210.110 closed by remote host.
Connection to 14.2.210.110 closed.
```

## 2 ةوطخال

1.2.0 رادصلإا، IEC6400 لىل ةقرتل

مادختساب ىرخأ ةرم ةقرتل لىل ةقرب مق (1 ةوطخال دعب)، لاصتال لىل زاهجلا ةدوع دعب  
1.2.0: تباتل جامانربل ل ةروص

```
# tftp-fw-upgrade tftp-server 10.122.136.38 upgrade-fw-image IEC6400-1.2.0.5.img
Starting TFTP file transfer for IEC6400-1.2.0.5.img, TFTP server 10.122.136.38 ...
New firmware: IEC6400-1.2.0.5.img. Start downloading...
449M
TFTP firmware upgrade...
WARNING: DO NOT POWER OFF THE UNIT DURING A FIRMWARE UPGRADE
starting upgrading...
Rtp6395@5.69.163.198:~# Connection to 14.2.210.110 closed by remote host.
Connection to 14.2.210.110 closed.
```

