

This box contains:

PrecisionHD USB camera  
User's Guide  
Travel bag



**PrecisionHD USB**  
User's Guide

[www.cisco.com](http://www.cisco.com)

© 2007 Cisco Systems, Inc. All rights reserved.  
Cisco, the Cisco logo, and Cisco Systems are trademarks or  
registered trademarks of Cisco Systems, Inc. and/or its affiliates  
in the United States and certain other countries.

11977107

## Mounting and adjusting the camera

Camera angle down



Camera angle up



## Mechanical privacy shutter

Turn right to open



Turn left to shut




## Light indicators and microphone

Orange light  
starting up / capturing video



Green light  
power on / standby



## Camera specifications

16:9 wide format HD video  
1280x720 resolution at 30 fps  
High light sensitivity: F1.7  
Multicoated all glass optics  
Auto focus and auto light adjustment  
Ultra wideband microphone  
Mechanical privacy shutter  
No software installation required

Optimized for

Movi®

System requirements  
Windows® XP or higher  
Mac OS X 10.5 or higher  
Linux  
USB 2.0

Camera software upgrade  
[www.tandberg.com](http://www.tandberg.com)

USB extension cable  
The connection cable can be extended by using a standard USB extension cable. The maximum recommended extension cable length is 2 meters / 7 feet.