

FlexPod Datacenter with Oracle RAC Databases on Cisco UCS and NetApp AFF A-Series

Deployment Guide for Oracle RAC 12cR2 Databases on
Cisco Unified Computing System and NetApp AFF A-700s
Storage using Fibre Channel

Last Updated: January 8, 2019



About the Cisco Validated Design Program

The Cisco Validated Design (CVD) program consists of systems and solutions designed, tested, and documented to facilitate faster, more reliable, and more predictable customer deployments. For more information, visit:

<http://www.cisco.com/go/designzone>.

ALL DESIGNS, SPECIFICATIONS, STATEMENTS, INFORMATION, AND RECOMMENDATIONS (COLLECTIVELY, "DESIGNS") IN THIS MANUAL ARE PRESENTED "AS IS," WITH ALL FAULTS. CISCO AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE. IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THE DESIGNS, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THE DESIGNS ARE SUBJECT TO CHANGE WITHOUT NOTICE. USERS ARE SOLELY RESPONSIBLE FOR THEIR APPLICATION OF THE DESIGNS. THE DESIGNS DO NOT CONSTITUTE THE TECHNICAL OR OTHER PROFESSIONAL ADVICE OF CISCO, ITS SUPPLIERS OR PARTNERS. USERS SHOULD CONSULT THEIR OWN TECHNICAL ADVISORS BEFORE IMPLEMENTING THE DESIGNS. RESULTS MAY VARY DEPENDING ON FACTORS NOT TESTED BY CISCO.

CCDE, CCENT, Cisco Eos, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, Cisco WebEx, the Cisco logo, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unified Computing System (Cisco UCS), Cisco UCS B-Series Blade Servers, Cisco UCS C-Series Rack Servers, Cisco UCS S-Series Storage Servers, Cisco UCS Manager, Cisco UCS Management Software, Cisco Unified Fabric, Cisco Application Centric Infrastructure, Cisco Nexus 9000 Series, Cisco Nexus 7000 Series, Cisco Prime Data Center Network Manager, Cisco NX-OS Software, Cisco MDS Series, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQuick Study, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0809R)

© 2019 Cisco Systems, Inc. All rights reserved.

Table of Contents

Executive Summary	6
Solution Overview	7
Introduction.....	7
Audience	7
Purpose of this Document.....	7
FlexPod System Overview	8
What's New in this Release?	9
Solution Components	11
Cisco UCS 5108 Blade Server Chassis	11
Cisco UCS 2304 Fabric Extender	11
Cisco UCS B200 M5 Blade Servers	12
Cisco UCS Virtual Interface Card (VIC) 1340.....	12
Cisco UCS 6332-16UP Fabric Interconnect	12
Cisco UCS MDS 9148S Fabric Switch.....	13
Cisco Nexus 93180LC-EX Switch	13
NetApp AFF All Flash Array A700s.....	13
Solution Design.....	16
Physical Infrastructure	16
Physical Topology	16
Design Topology	18
Solution Configuration.....	21
Configure Cisco Nexus 93180LC-EX Switch	21
Set Up Initial Configuration.....	21
Configure Global Settings for Cisco Nexus A and Cisco Nexus B.....	23
Configure VLANs for Cisco Nexus A and Cisco Nexus B Switches.....	24
Virtual Port Channel (vPC) Summary for Data and Storage Network.....	24
Create vPC Peer-Link Between the Two Nexus Switches.....	25
Create vPC Configuration Between Nexus 9372PX-E and Fabric Interconnects.....	26
Verify All vPC Status Is Up on Both the Nexus Switches	30
Cisco UCS Configuration Overview.....	33
Perform Initial Setup of Cisco UCS 6332-16UP Fabric Interconnects for a Cluster Setup	33
Log in to Cisco UCS Manager	35
Upgrade Cisco UCS Manager Software to Version 3.2	36
Anonymous Reporting.....	36
Configure Cisco UCS Call Home	37
High Level Steps to Configure Base Cisco UCS	37

Set Fabric Interconnects to Fibre Channel End Host Mode	38
Synchronize Cisco UCS to NTP	39
Configure Fabric Interconnect for Chassis and Blade Discovery	39
Configure LAN and SAN on Cisco UCS Manager	42
Configure IP, UUID, Server, MAC, WWNN and WWPN Pools	49
Set Jumbo Frames in both the Cisco Fabric Interconnect	54
Configure Server BIOS Policy	55
Create Adapter Policy	56
Configure Update Default Maintenance Policy	58
Configure vNIC and vHBA Template	58
Create Server Boot Policy for SAN Boot	62
Configure and Create a Service Profile Template	69
Create Service Profile Template	69
Create Service Profiles from Template and Associate to Servers	80
Create Service Profiles from Template	80
Associate Service Profiles to the Servers	81
Configure Cisco MDS 9148S Switch	83
Configure feature for MDS Switch A and MDS Switch B	84
Configure VSANs for MDS Switch A and MDS Switch B	85
Create and Configure Fibre Channel Zoning	86
Create Zoning	88
Verify FC Ports on MDS Switch	91
Configure NetApp AFF A700s Storage	93
NetApp Storage Connectivity	93
Operating System and Database Deployment	96
Operating System Configuration	96
Operating System Prerequisites for Oracle Software Installation	98
Configure BIOS	98
Prerequisites Automatic Installation	99
Additional Prerequisites Setup	100
Configure Multipath Setup	100
Oracle Database 12c GRID Infrastructure Deployment	103
Install and Configure Oracle Database Grid Infrastructure Software	105
Install Oracle Database Software	113
Oracle Flex ASM	117
Scalability Test and Results	120
Hardware Calibration Test using FIO	120
4k and 8k Random Read/Write IOPs Tests	120

Bandwidth Tests.....	121
Database Creation with DBCA.....	123
SLOB Test.....	124
Swingbench Test	128
Resiliency and Failure Tests.....	140
Summary	151
Appendix.....	152
References	179
Cisco Unified Computing System.....	179
Cisco UCS Data Center Design Guides	179
FlexPod Converged Infrastructure.....	179
Cisco UCS B200 M5 Servers	179
Oracle Database 12c Release 2.....	179
NetApp AFF A-Series All Flash Storage.....	179
NetApp Support	179
About the Authors.....	180
Acknowledgements.....	180



Executive Summary

The Cisco Unified Computing System™ (Cisco UCS®) is a next-generation data center platform that unites computing, network, storage access, and virtualization into a single cohesive system. Cisco UCS is an ideal platform for the architecture of mission critical database workloads such as Oracle RAC. The combination of Cisco UCS, NetApp and Oracle Real Application Cluster Database architecture can accelerate your IT transformation by enabling faster deployments, greater flexibility of choice, efficiency, high availability and lower risk.

Cisco Validated Designs include systems and solutions that are designed, tested, and documented to facilitate and improve customer deployments. These designs incorporate a wide range of technologies and products into a portfolio of solutions that have been developed to address the business needs of customers. Cisco and NetApp have partnered to deliver FlexPod, which serves as the foundation for a variety of workloads and enables efficient architectural designs that are based on customer requirements. A FlexPod solution is a validated approach for deploying Cisco and NetApp technologies as a shared cloud infrastructure.

The FlexPod Datacenter with NetApp All Flash AFF system is a converged infrastructure platform that combines best-of breed technologies from Cisco and NetApp into a powerful converged platform for enterprise applications. Cisco and NetApp works closely with Oracle to support the most demanding transactional and response-time-sensitive databases required by today's businesses.

This Cisco Validated Design (CVD) describes the reference FlexPod Datacenter architecture using Cisco UCS and NetApp® All Flash AFF Storage for deploying a highly available Oracle RAC Database environment. This document shows the hardware and software configuration of the components involved, results of various tests and offers implementation and best practices guidance using Cisco UCS Compute Servers, Cisco Fabric Interconnect Switches, Cisco MDS Switches, Cisco Nexus Switches, NetApp AFF Storage and Oracle RAC Database.

Solution Overview

Introduction

Data powers essentially every operation in a modern enterprise, from keeping the supply chain operating efficiently to managing relationships with customers. Modern data centers face increasing demands for agile, high-performance service delivery. Digital transformations are driving an increased number of new applications, with more sources of data. Organizations of all kinds rely on their relational databases for both transaction processing (OLTP) and analytics (OLAP), but many still have challenges in meeting their goals of high availability, security, and performance. Applications must be able to move quickly from development to a reliable, scalable platform. An ideal solution integrates best-in-class components that can scale compute and storage independently to meet the needs of dynamic business requirements.

Like all the FlexPod Systems, the FlexPod Datacenter with NetApp All Flash AFF is comprised of compute (database, application and management servers from Cisco), network (three-layer network and SAN technologies from Cisco), and storage (NetApp All Flash AFF storage systems).

This CVD describes how the Cisco Unified Computing System™ (Cisco UCS®) can be used in conjunction with NetApp® AFF storage systems to implement a mission-critical applications such as an Oracle Real Application Clusters (RAC) 12cR2 database solution. This CVD documents validation of the real world performance, ease of management, and agility of the FlexPod Datacenter with Cisco UCS and All Flash AFF in high-performance Oracle RAC Databases environments.

Audience

The intended audience for this document includes, but is not limited to, sales engineers, field consultants, database administrators, IT managers, oracle database architects, and customers who want to deploy Oracle RAC 12cR2 database solution on FlexPod Converged Infrastructure with NetApp clustered Data ONTAP® and the Cisco UCS platform. A working knowledge of Oracle RAC Database, Linux, Storage technology, and Network is assumed but is not a prerequisite to read this document.

Purpose of this Document

Oracle RAC databases deployments are extremely complicated in nature and customers face enormous challenges in maintaining these landscapes in terms of time, efforts and cost. Oracle RAC databases often manage the mission critical components of a customer's IT department. Ensuring availability while also lowering the IT TCO is always their top priority. This FlexPod solution for Oracle databases delivers industry-leading storage, unprecedented scalability, continuous data access, and automated data management for immediate responses to business opportunities.

The goal of this document is to determine the Oracle database server read latency, peak sustained throughput and IOPS of this FlexPod reference architecture system while running the Oracle OLTP and OLAP workloads.

This document provides a step-by-step configuration and implementation guide for the FlexPod Datacenter with Cisco UCS Compute Servers, Cisco Fabric Interconnect Switches, Cisco MDS Switches, Cisco Nexus Switches and NetApp AFF Storage to deploy an Oracle RAC Database solution. Here are the objectives we would like to accomplish in this reference document

1. Provide reference FlexPod architecture design guidelines for the Oracle RAC Databases solution.

2. Demonstrate simplicity and agility with the software-driven architecture and high performance of Cisco UCS compute Servers.
3. Build, validate and predict performance of Servers, Network and Storage platform on a per workload basis.

FlexPod System Overview


Built on innovative technology from NetApp and Cisco, the FlexPod converged infrastructure platform meets and exceeds the challenges of simplifying deployments for best-in-class data center infrastructure. FlexPod is a defined set of hardware and software that serves as an integrated foundation for both virtualized and non-virtualized solutions. Composed of pre-validated storage, networking, and server technologies, FlexPod is designed to increase IT responsiveness to organizational needs and reduce the cost of computing with maximum uptime and minimal risk. Simplifying the delivery of data center platforms gives enterprises an advantage in delivering new services and applications.

FlexPod provides the following differentiators:

1. Flexible design with a broad range of reference architectures and validated designs.
4. Elimination of costly, disruptive downtime through Cisco UCS and NetApp® ONTAP®.
5. Leverage a pre-validated platform to minimize business disruption and improve IT agility and reduce deployment time from months to weeks.
6. Cisco Validated Designs (CVDs) and NetApp Validated Architectures (NVAs) covering a variety of use cases.

Cisco and NetApp have carefully validated and verified the FlexPod solution architecture and its many use cases while creating a portfolio of detailed documentation, information, and references to assist customers in transforming their data centers to this shared infrastructure model.

Figure 1 FlexPod System Overview



FlexPod datacenter architecture includes three components:

- Cisco Unified Computing System (Cisco UCS)
- Cisco MDS and Nexus Switches
- NetApp AFF Storage Systems

One benefit of the FlexPod architecture is the ability to customize or "flex" the environment to suit a customer's requirements. A FlexPod can easily be scaled as requirements and demand change. The unit can be scaled both up (adding resources to a FlexPod unit) and out (adding more FlexPod units). This document highlights the resiliency, cost benefit, and ease of deployment of a Fibre Channel storage solution to deploy Oracle RAC Database environments on FlexPod Infrastructure.

What's New in this Release?

This version of FlexPod CVD introduces new hardware with NetApp A-Series All Flash Storage AFF A700s along with Cisco UCS B200 M5 Blade Server featuring Intel Xeon Scalable Family of CPUs.

It incorporates the following features:

- Support for the Cisco UCS 3.2 unified software release and Cisco UCS B200 M5 Blade Servers
- Support for the latest release of NetApp ONTAP® 9.3

- Fibre channel storage design
- Validation of Oracle RAC Database 12c Release 2

Solution Components

Cisco UCS 5108 Blade Server Chassis

Cisco UCS 5108 Blade Server Chassis, is six rack units (6RU) high, can mount in an industry-standard 19-inch rack, and uses standard front-to-back cooling. A chassis can accommodate up to eight half-width or four full-width Cisco UCS B-Series Blade Servers form factors within the same chassis.



By incorporating unified fabric and fabric-extender technology, Cisco Unified Computing System eliminates the need for dedicated chassis management and blade switches, reduces cabling, and allowing scalability to 20 chassis without adding complexity. The Cisco UCS 5108 Blade Server Chassis is a critical component in delivering the simplicity and IT responsiveness for the data center as part of Cisco Unified Computing System.

Cisco UCS 2304 Fabric Extender

Cisco UCS 2304 Fabric Extender brings the unified fabric into the blade server enclosure, providing multiple 40 Gigabit Ethernet connections between blade servers and the fabric interconnect, simplifying diagnostics, cabling, and management.



The Cisco UCS 2304 connects the I/O fabric between the Cisco UCS 6300 Series Fabric Interconnects and the Cisco UCS 5100 Series Blade Server Chassis, enabling a lossless and deterministic Fibre Channel over Ethernet (FCoE) fabric to connect all blades and chassis together.

Cisco UCS B200 M5 Blade Servers

The Cisco UCS B200 M5 Blade Server delivers performance, flexibility, and optimization for deployments in data centers, in the cloud, and at remote sites. This enterprise-class server offers market-leading performance, versatility, and density without compromise for workloads including Virtual Desktop Infrastructure (VDI), web infrastructure, distributed databases, converged infrastructure, and enterprise applications such as Oracle Databases.



The Cisco UCS B200 M5 server can quickly deploy stateless physical and virtual workloads through programmable, easy-to-use Cisco UCS Manager Software and simplified server access through Cisco Single-Connect technology.

Cisco UCS Virtual Interface Card (VIC) 1340


The Cisco UCS Virtual Interface Card (VIC) 1340 is a 2-port, 40 Gigabit Ethernet, Fibre Channel over Ethernet (FCoE)-capable modular LAN on motherboard (mLOM) mezzanine adapter.



Cisco UCS 1340 VIC delivers 80 Gbps throughput to the Server and helps reduce TCO by consolidating the overall number of NICs, HBAs, cables, and switches; LAN and SAN traffic runs over the same mezzanine card and fabric.

Cisco UCS 6332-16UP Fabric Interconnect

The 6332-16UP Fabric Interconnect is the management and communication backbone for Cisco UCS B-Series Blade Servers, C-Series Rack Servers, and 5100 Series Blade Server Chassis. It implements 20x40 Gigabit Ethernet and Fibre Channel over Ethernet ports, with additional support for 16 unified ports that can be configured to 1 or 10 Gbps Ethernet, or 4/8/16 Gbps Fibre Channel.



The Fabric Interconnect provides high-speed upstream connectivity to the network, or converged traffic to servers through its 40 Gbps ports, but also allows for Fibre Channel connectivity to SAN switches like the MDS, or alternately directly attached Fibre Channel to storage arrays.

Cisco UCS MDS 9148S Fabric Switch

The Cisco® MDS 9148S 16G Multilayer Fabric Switch is the next generation of highly reliable, flexible and low-cost Cisco MDS 9100 Series Switches. It provides up to 48 auto-sensing Fibre Channel ports, which are capable of speeds of 2, 4, 8, and 16 Gbps, with 16 Gbps of dedicated bandwidth for each port.



In all, the Cisco MDS 9148S is a powerful and flexible switch that delivers high performance and comprehensive Enterprise-class features at an affordable price.

Cisco Nexus 93180LC-EX Switch

The Cisco Nexus 93180LC-EX Switch is the industry's first 50-Gbps-capable 1RU switch that supports 3.6 Tbps of bandwidth and over 2.6 bpps across up to 32 fixed 40- and 50-Gbps QSFP+ ports or up to 18 fixed 100-Gbps ports (Figure 3). The switch can support up to 72 10-Gbps ports using breakout cables. A variety of flexible port configurations are supported using templates.



NetApp AFF All Flash Array A700s

This solution includes the NetApp All flash fabric-attached storage AF 700s unified scale-out storage system for Oracle Database 12cR2.



Built on ONTAP software, AFF speeds up the operations required to meet your business requirements, without compromising efficiency or reliability, while providing great flexibility and scalability. As true enterprise-class, all-flash arrays, these systems accelerate, manage, and protect business-critical data, now and in the future.

NetApp AFF provides industry-leading performance while continuing to provide a full suite of enterprise-grade data management and data protection features. Powered by NetApp clustered Data ONTAP, the AF 700s series unifies the SAN and NAS storage infrastructure. Systems architects can choose from a range of models representing a spectrum of cost-versus-performance points. Every model, however, provides the following core benefits:

- HA and fault tolerance. Non-disruptive operations are achieved through clustering, HA pairing of controllers, hot-swappable components, NetApp RAID-TEC® and disk protection (allowing two independent disk failures without data loss), and network interface redundancy.
- Data Protection. Create thousands of instantaneous backups with NetApp Snapshot® copies, replication of both active data and snapshot backups with NetApp SnapMirror® software, and application backup integration with NetApp SnapCenter® storage management software.
- Storage efficiency. Users can store more data with less physical media. This is achieved with thin provisioning (unused space is shared among volumes), NetApp Snapshot® copies (zero-storage, read-only replicas of data over time), NetApp FlexClone® volumes, and LUNs (read/write copies of data in which only changes are stored), deduplication (dynamic detection and removal of redundant data), and data compression.
- Unified Data Management. Every model runs the same software (clustered Data ONTAP); supports all popular storage protocols (CIFS, NFS, iSCSI, FCP, and FCoE). This allows freedom of choice in upgrades and expansions, without the need to redesign the solution or retraining operations personnel.
- Advanced clustering. Storage controllers are grouped into clusters for both availability and performance pooling. Workloads can be moved between controllers, permitting dynamic load balancing and zero-downtime maintenance, upgrades, and even complete hardware refreshes. Physical media and storage controllers can be added as needed to support growing demand without downtime.

This solution utilizes the NetApp AFF A700s as seen in the above figure. This controller provides the high-performance benefits of 40GbE and all flash SSDs.

Front View



Rear View



Combined with the 3 disk shelves and 72 1TB Solid State disks (SSD), this solution can provide over ample horsepower and over 60TB of raw capacity, all while taking up minimum valuable rack space. This makes it an ideal controller for a shared workload converged infrastructure. For situations where more performance is needed, the A700s would be an ideal fit. ONTAP 9.3 is used with the AFF A700s storage platform in our design.

ONTAP data management software offers unified storage for applications that read and write data over block or file-access protocols in storage configurations that range from high-speed flash to lower-priced spinning media or cloud-based object storage. The ONTAP platform used on the AFF systems also delivers interconnection with a larger ONTAP-based storage environment. In addition to AFF hardware systems, ONTAP is also available on commodity hardware (ONTAP Select), and in private, public, or hybrid clouds (NetApp Private Storage and Cloud Volumes ONTAP).

Together these implementations form the basic framework of the NetApp Data Fabric, with a common software-defined approach to data management and fast, efficient replication across platforms. FlexPod and ONTAP can serve as the foundation for both hybrid cloud and private cloud designs

Starting with ONTAP 9, NetApp guarantees that the use of NetApp storage efficiency technologies on AFF systems reduce the total logical capacity used to store customer data by 75 percent, a data reduction ratio of 4:1. This space reduction is enabled by a combination of several different technologies, including deduplication, compression, and compaction.

Beginning with ONTAP 9.1, NetApp has extended the encryption capabilities further with NetApp Volume Encryption (NVE), a software-based mechanism for encrypting data. It allows a user to encrypt data at the per-volume level instead of requiring encryption of all data in the cluster, thereby providing more flexibility and granularity to the ONTAP administrators. This encryption extends to Snapshot copies and NetApp FlexClone® volumes that are created in the cluster. One benefit of NVE is that it executes after the implementation of the storage efficiency features, and, therefore, it does not interfere with the ability of ONTAP to create space savings.

Solution Design

Physical Infrastructure

FlexPod is a defined set of hardware and software that serves as an integrated foundation for both virtualized and non-virtualized solutions. FlexPod components are connected and configured according to best practices of both Cisco and NetApp to provide the ideal platform for running a variety of enterprise workloads with confidence. This solution provides an end-to-end architecture with Cisco Unified Computing System, Oracle, and NetApp technologies and demonstrates the FlexPod configuration benefits for running Oracle RAC Databases 12cR2 workloads with high availability and server redundancy.

The reference FlexPod architecture covered in this document is built on the NetApp All Flash AFF A700s for Storage, Cisco B200 M5 Blade Servers for Compute, Cisco Nexus 93180LC-EX Switches, Cisco MDS 9148S 16G Multilayer Fabric Switches and Cisco Fabric Interconnects 6332-16UP Fabric Interconnects for System Management in a single package. The design is flexible enough that the networking, computing, and storage can fit in one data center rack or be deployed according to a customer's data center design.

The reference architecture reinforces the "wire-once" strategy, because as additional storage is added to the architecture, no re-cabling is required from the hosts to the Cisco UCS fabric interconnect.

Physical Topology

This section describes the design considerations for the Oracle RAC Database 12c Release 2 on FlexPod deployment. In this solution design, we have used two Cisco UCS Blade Server Chassis with 4 identical Intel Xeon CPU based Cisco UCS B-Series B200 M5 Blade Servers for hosting the 4-Node Oracle RAC Databases. The Cisco UCS B200 M5 Server has Virtual Interface Card (VIC) 1340 with port expander and they were connected two ports from each Cisco Fabric extender of the Cisco UCS Chassis to the Cisco Fabric Interconnects, which were in turn connected to the Cisco MDS Switches for upstream connectivity to access the NetApp AFF Storage A700s.

Figure 2 shows the architecture diagram of the FlexPod components and the network connections to deploy a four-node Oracle RAC 12cR2 Databases solution. This reference design is a typical network configuration that can be deployed in a customer's environments.

Figure 2 FlexPod Architecture Design




Figure 2 details the cable connections used in the validation lab for the 40Gb end-to-end with Fibre Channel topology based on the Cisco UCS 6332-16UP fabric interconnect. As shown in above architecture, a pair of Cisco UCS 6332-16UP Fabric Interconnects (FI) carries both storage and network traffic from the Cisco UCS B200 M5 server blades with the help of Cisco Nexus 93180LC-EX and Cisco MDS 9148S switches. Both the Fabric Interconnects and the Cisco Nexus switches are clustered with the peer link between them to provide high availability. Two virtual Port-Channels (vPCs) are configured to provide public network and private network paths

for the server blades to northbound switches. Each vPC has VLANs created for application network data and management data paths.

As illustrated in the above architecture, four (2 x 40G link per chassis) links go to Fabric Interconnect – A. Similarly, four (2 x 40G link per chassis) links go to Fabric Interconnect – B. Fabric Interconnect – A links are used for Oracle Public network traffic shown as green lines. Fabric Interconnect – B links are used for Oracle private interconnect traffic shown as red lines. FC Storage access from Fabric Interconnect – A and Fabric Interconnect – B shown as orange lines.



For Oracle RAC configuration on Cisco Unified Computing System, we recommend to keep all private interconnects local on a single Fabric interconnect. In such case, the private traffic will stay local to that fabric interconnect and will not be routed via northbound network switch. In other words, all inter server blade (or RAC node private) communication will be resolved locally at the fabric interconnects and this significantly reduces latency for Oracle Cache Fusion traffic.

Four 16Gb uplinks are connected from Cisco UCS Fabric Interconnect A to MDS switch A. Similarly, four 16Gb uplinks are connected from Cisco UCS Fabric Interconnect B to MDS switch B. The NetApp Storage AFF A700s have eight active FC connection goes to the Cisco MDS switches. Four FC ports are connected to Cisco MDS-A, and other four FC ports are connected to Cisco MDS-B Switches. The SAN Ports FC-Port-0-Slot-2 and FC-Port-0-Slot-3 of NetApp AFF A700s Controller – 1 are connected to Cisco MDS Switch A and FC-Port-1-Slot-2 and FC-Port-1-Slot-3 are connected to Cisco MDS Switch B. Similarly, the SAN Ports FC-Port-0-Slot-2 and FC-Port-0-Slot-3 of NetApp AFF A700s Controller – 2 are connected to Cisco MDS Switch A and FC-Port-1-Slot-2 and FC-Port-1-Slot-3 are connected to Cisco MDS Switch B.

Additional 1Gb management connections will be needed for an out-of-band network switch that sits apart from the FlexPod infrastructure. Each Cisco UCS fabric interconnect and Cisco Nexus switch is connected to the out-of-band network switch, and each AFF controller has two connections to the out-of-band network switch.

The reference architecture includes the following hardware:

- Two Cisco UCS 5108 Blade Server Chassis
- Four Cisco UCS B200 M5 Blade Servers with Cisco Virtual Interface Cards (VIC)
- Two Cisco UCS 6332-16UP Fabric Interconnects
- Two Cisco MDS 9148S Multilayer Fabric Switch
- Two Cisco Nexus 93180LC-EX Switch
- One NetApp AFF A700s (HA pair) running ONTAP with Disk shelves and Solid State Drives (SSD)

Although this is the base design, each of the components can be scaled easily to support specific business requirements. For example, more servers or even blade chassis can be deployed to increase compute capacity, additional disk shelves can be deployed to improve I/O capability and throughput, and special hardware or software features can be added to introduce new features. This document guides you through the low-level steps for deploying the base architecture, as shown in Figure 2. These procedures cover everything from physical cabling to network, compute and storage device configurations.

Design Topology

This section describes the physical and logical high-level design considerations for this Oracle RAC 12cR2 Databases on FlexPod deployment.

The inventory of the components used in this Solution stack is listed in Table 1 .

Table 1 Hardware Components

Name	Model	Description	Quantity
Cisco Nexus 93180LC-EX Switch	N9K-C93180LC-EX	Cisco Nexus 9300 Series Switches	2
Cisco MDS 9148S 16G Fabric Switch	DS-C9148S-12PK9	Cisco MDS 9100 Series Multilayer Fabric Switches	2
Cisco UCS 6332-16UP Fabric Interconnect	UCS-FI-6332-16UP	Cisco 6300 Series Fabric Interconnects	2
Cisco UCS 5108 Blade Server Chassis	UCSB-5108-AC2	Cisco UCS 5100 Series Blade Server AC2 Chassis	2
Cisco UCS Fabric Extender	UCS-IOM-2304	Cisco UCS 2304XP I/O Module (4 External, 8 Internal 40Gb Ports)	4
Cisco UCS B200 M5 Blade Server	UCSB-B200-M5	Cisco UCS B-Series Blade Servers	4
Cisco UCS VIC 1340	UCSB-MLOM-40G-03	Cisco UCS Virtual Interface Card 1340	4
Cisco UCS Port Expander Card	UCSB-MLOM-PT-01	Port Expander Card for Cisco UCS MLOM	4
NetApp Storage	AFF A700s	AFF A-Series All Flash Arrays	1
NetApp Disk	DS-224C	Disk Shelves and Storage Media for NetApp AFF and FAS systems	2

Table 2 lists the Cisco UCS B200 M5 Blade Server Configuration.

Table 2 Cisco UCS B200 M5 Blade Server Configuration

Server Configuration		
Processor	2 x Intel(R) Xeon(R) Gold 6148 2.40 GHz 150W 20C 27.50MB Cache DDR4 2666MHz 768GB	UCS-CPU-6148
Memory	16 x 32GB DDR4-2666-MHz RDIMM/dual rank/x4/1.2v	UCS-MR-X32G2RS-H
Cisco UCS VIC 1340	Cisco UCS VIC 1340 Blade MLOM	UCSB-MLOM-40G-03
Cisco UCS Port Expander Card	Port Expander Card for Cisco UCS MLOM	UCSB-MLOM-PT-01

For this FlexPod solution design, we configured two VLAN and two VSAN as listed below:

Table 3 VLAN and VSAN Configurations

VLAN & VSAN Configuration		
VLAN		
Name	ID	Description
• Default VLAN	1	Native VLAN
• Public VLAN	135	VLAN for Public Network Traffic
• Private VLAN	10	VLAN for Private Network Traffic
VSAN		
Name	ID	Description
• VSAN - A	101	SAN Communication through for Fabric Interconnect A
• VSAN - B	102	SAN Communication through for Fabric Interconnect B

This FlexPod solution consists of NetApp All-Flash AFF-Series Storage as listed in Table 4 .

Table 4 NetApp AFF A700s Storage Configuration

Storage Components	Description
Flash Arrays	NetApp All Flash AFF A700s Storage Array (24 x 960GB SSD Drives)
Disk Shelves	2 x NetApp DS224C (24 x 960GB SSD Drives per Shelves)
Capacity	62.63 TB
Connectivity	8 x 16 Gb/s redundant Fibre Channel 1 Gb/s redundant Ethernet (Management port)
Physical	8U Rack Units

For this FlexPod solution, we used the following versions of the software and firmware releases.

Table 5 Software and Firmware Revisions

Software and Firmware	Version
Cisco UCS Manager System	3.2 (3c)
Cisco UCS Adapter VIC 1340	4.2 (3b)
Cisco eNIC (modinfo enic) (Cisco VIC Ethernet NIC Driver)	2.3.0.53
Cisco fNIC (modinfo fnic) (Cisco FCoE HBA Driver)	1.6.0.34
Cisco Nexus 93180LC-EX NXOS Version	7.0(3)I6(1)
Cisco MDS 9148S Switch System Version	7.3(0)D1(1)
Oracle Linux Server Release 7.5 (64 bit) operating System	Linux 4.1.12-124.16.4.el7uek.x86_64
Oracle Database 12c Release 2 Grid Infrastructure for Linux x86-64	12.2.0.1.0
Oracle Database 12c Release 2 for Linux x86-64	12.2.0.1.0
NetApp Storage AFF A700s System Version	ONTAP 9.3
Oracle Swingbench	2.5.971
SLOB	2.4.2

Solution Configuration

Configure Cisco Nexus 93180LC-EX Switch

The following procedures describe how to configure the Cisco Nexus switches for use in a base FlexPod environment. This procedure assumes the use of Cisco Nexus 93180LC-EX 7.0(3)I6(1) switches deployed with the 40Gb end-to-end topology.

Set Up Initial Configuration

Cisco Nexus A

To set up the initial configuration for the Cisco Nexus A switch on <nexus-A-hostname>, complete the following steps:

1. Configure the switch.



On initial boot and connection to the serial or console port of the switch, the NX-OS setup should automatically start and attempt to enter Power on Auto Provisioning.

```

Abort Power on Auto Provisioning and continue with normal setup? (yes/no) [n]: yes
Do you want to enforce secure password standard (yes/no) [y]: Enter
Enter the password for "admin": <password>
Confirm the password for "admin": <password>
Would you like to enter the basic configuration dialog (yes/no): yes
Create another login account (yes/no) [n]: Enter
Configure read-only SNMP community string (yes/no) [n]: Enter
Configure read-write SNMP community string (yes/no) [n]: Enter
Enter the switch name: <nexus-A-hostname>
Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]: Enter
Mgmt0 IPv4 address: <nexus-A-mgmt0-ip>
Mgmt0 IPv4 netmask: <nexus-A-mgmt0-netmask>
Configure the default gateway? (yes/no) [y]: Enter
IPv4 address of the default gateway: <nexus-A-mgmt0-gw>
Configure advanced IP options? (yes/no) [n]: Enter
Enable the telnet service? (yes/no) [n]: Enter
Enable the ssh service? (yes/no) [y]: Enter
Type of ssh key you would like to generate (dsa/rsa) [rsa]: Enter
Number of rsa key bits <1024-2048> [1024]: Enter

```

```

Configure the ntp server? (yes/no) [n]: y
NTP server IPv4 address: <global-ntp-server-ip>
Configure default interface layer (L3/L2) [L3]: L2
Configure default switchport interface state (shut/noshut) [noshut]: Enter
Configure CoPP system profile (strict/moderate/lenient/dense/skip) [strict]: Enter
Would you like to edit the configuration? (yes/no) [n]: Enter
2. Review the configuration summary before enabling the configuration.
Use this configuration and save it? (yes/no) [y]: Enter

```

Cisco Nexus B

To set up the initial configuration for the Cisco Nexus B switch on <nexus-B-hostname>, complete the following steps:

1. Configure the switch.



On initial boot and connection to the serial or console port of the switch, the NX-OS setup should automatically start and attempt to enter Power on Auto Provisioning.

```

Abort Power on Auto Provisioning and continue with normal setup? (yes/no) [n]: yes
Do you want to enforce secure password standard (yes/no) [y]: Enter
Enter the password for "admin": <password>
Confirm the password for "admin": <password>
Would you like to enter the basic configuration dialog (yes/no): yes
Create another login account (yes/no) [n]: Enter
Configure read-only SNMP community string (yes/no) [n]: Enter
Configure read-write SNMP community string (yes/no) [n]: Enter
Enter the switch name: <nexus-B-hostname>
Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]: Enter
Mgmt0 IPv4 address: <nexus-B-mgmt0-ip>
Mgmt0 IPv4 netmask: <nexus-B-mgmt0-netmask>
Configure the default gateway? (yes/no) [y]: Enter
IPv4 address of the default gateway: <nexus-B-mgmt0-gw>
Configure advanced IP options? (yes/no) [n]: Enter
Enable the telnet service? (yes/no) [n]: Enter
Enable the ssh service? (yes/no) [y]: Enter
Type of ssh key you would like to generate (dsa/rsa) [rsa]: Enter

```

```

Number of rsa key bits <1024-2048> [1024]: Enter
Configure the ntp server? (yes/no) [n]: y
NTP server IPv4 address: <global-ntp-server-ip>
Configure default interface layer (L3/L2) [L3]: L2
Configure default switchport interface state (shut/noshut) [noshut]: Enter
Configure CoPP system profile (strict/moderate/lenient/dense/skip) [strict]: Enter
Would you like to edit the configuration? (yes/no) [n]: Enter
2. Review the configuration summary before enabling the configuration.
Use this configuration and save it? (yes/no) [y]: Enter

```

Configure Global Settings for Cisco Nexus A and Cisco Nexus B

To set global configuration, follow these steps on both the nexus switches:

1. Log in as admin user into the Nexus Switch A and run the following commands to set global configurations:

```

configure terminal
feature interface-vlan
feature hsrp
feature lacp
feature vpc
spanning-tree port type network default
spanning-tree port type edge bpduguard default
port-channel load-balance src-dst l4port
policy-map type network-qos jumbo
  class type network-qos class-default
    mtu 9216
system qos
  service-policy type network-qos jumbo
vrf context management
  ip route 0.0.0.0/0 10.29.135.1
copy run start

```

2. Log in as admin user into the Nexus Switch B and run the same above commands to set global configurations.



Make sure to run `copy run start` to save the configuration on each switch after the configuration is completed.

Configure VLANs for Cisco Nexus A and Cisco Nexus B Switches

To create the necessary virtual local area networks (VLANs), follow these steps on both Nexus switches:

1. Log in as admin user into the Nexus Switch A.
2. Create VLAN 135 for Public Network Traffic and VLAN 10 for Private Network Traffic.

```
configure terminal
vlan 135
name Oracle_RAC_Public_Traffic
no shutdown
vlan 10
name Oracle_RAC_Private_Traffic
no shutdown
copy run start
```

3. Log in as admin user into the Nexus Switch B and create VLAN 135 for Public Network Traffic and VLAN 10 for Private Network Traffic.

Virtual Port Channel (vPC) Summary for Data and Storage Network

In the Cisco Nexus 93180LC-EX switch topology, a single vPC feature is enabled to provide HA, faster convergence in the event of a failure, and greater throughput. Cisco Nexus vPC configurations with the vPC domains and corresponding vPC names and IDs for Oracle Database Servers is shown in Table 6

Table 6 vPC Summary


vPC Domain	vPC Name	vPC ID
1	Peer-Link	1
1	vPC Public	51
1	vPC Private	52

As listed in Table 6 , a single vPC domain with Domain ID 1 is created across two Cisco Nexus 93180LC-EX member switches to define vPC members to carry specific VLAN network traffic. In this topology, we defined a total number of 3 vPCs.

vPC ID 1 is defined as Peer link communication between two Nexus switches in Fabric A and B.

To define vPC IDs 51 and 52 for public and private network traffic from Cisco UCS fabric interconnects, complete the steps in the following sections.

Create vPC Peer-Link Between the Two Nexus Switches



1. Login as admin user into the Nexus Switch A.



Note: For vPC 1 as Peer-link, we used interfaces 1-2 for Peer-Link. You may choose an appropriate number of ports for your needs.

2. Create the necessary port channels between devices on both Nexus Switches:

```
configure terminal
vpc domain 1
peer-keepalive destination 10.29.135.104 source 10.29.135.103
auto-recovery
```

```
interface port-channel1
description vPC peer-link
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type network
vpc peer-link
exit
```

```
interface Ethernet1/1
description Peer link connected to N9K-B-Eth1/1
switchport mode trunk
switchport trunk allowed vlan 1,10,135
channel-group 1 mode active
no shutdown
interface Ethernet1/2
description Peer link connected to N9K-B-Eth1/2
switchport mode trunk
switchport trunk allowed vlan 1,10,135
```

```
channel-group 1 mode active
no shutdown

interface Ethernet1/29
description connect to uplink switch
switchport access vlan 135
speed 1000
exit


copy run start
```

3. Log in as admin user into the Nexus Switch B and repeat the above steps to configure second nexus switch.



Note: Make sure to change peer-keepalive destination and source IP address appropriately for Nexus Switch B

Create vPC Configuration Between Nexus 9372PX-E and Fabric Interconnects



Next, you will create and configure vPC 51 and 52 for Data network between Nexus switches and Fabric Interconnects.

Table 7 lists the vPC IDs, allowed VLAN IDs, and Ethernet uplink ports.

Table 7 vPC IDs and VLAN IDs

vPC Description	vPC ID	Fabric Interconnects Ports	Nexus Ports	Allowed VLANs
Port Channel FI-A	51	FI-A Port 1/31	N9K-A Port 1/21	135, 10
		FI-A Port 1/32	N9K-A Port 1/22	

vPC Description	vPC ID	Fabric Interconnects Ports	Nexus Ports	Allowed VLANs
Port Channel FI-B	52	FI-A Port 1/33	N9K-B Port 1/21	Note: VLAN 10 Needed for Failover
		FI-A Port 1/34	N9K-B Port 1/22	
		FI-B Port 1/31	N9K-A Port 1/23	10, 135 Note: VLAN 135 Needed for Failover
		FI-B Port 1/32	N9K-A Port 1/24	
		FI-B Port 1/33	N9K-B Port 1/23	
FI-B Port 1/34	N9K-B Port 1/24			

To create the necessary port channels between devices, follow these steps on both the Nexus Switches:

1. Log in as admin user into the Nexus Switch A and follow these steps:

```
configure terminal
```

```
interface port-channel51
```

```
description Port-Channel FI-A
```

```
switchport mode trunk
```

```
switchport trunk allowed vlan 1,10,135
```

```
spanning-tree port type edge trunk
```

```
mtu 9216
```

```
vpc 51
```

```
no shutdown
```

```
interface port-channel52
```

```
description Port-Channel FI-B
```

```
switchport mode trunk
```

```
switchport trunk allowed vlan 1,10,135
```

```
spanning-tree port type edge trunk
```

```
mtu 9216
```

```
vpc 52
```

```
no shutdown
```

```
interface Ethernet1/21
```

```
description Fabric-Interconnect-A-31
```

```
switchport mode trunk
```

```
switchport trunk allowed vlan 1,10,135
```

```
spanning-tree port type edge trunk
```

```
mtu 9216
```

```
channel-group 51 mode active
```

```
no shutdown

interface Ethernet1/22
  description Fabric-Interconnect-A-32
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  spanning-tree port type edge trunk
  mtu 9216
  channel-group 51 mode active
  no shutdown

interface Ethernet1/23
  description Fabric-Interconnect-B-31
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  spanning-tree port type edge trunk
  mtu 9216
  channel-group 52 mode active
  no shutdown

interface Ethernet1/24
  description Fabric-Interconnect-B-32
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  spanning-tree port type edge trunk
  mtu 9216
  channel-group 52 mode active
  no shutdown
```

```
copy run start
```

2. Log in as admin user into the Nexus Switch B and run the following commands to complete second switch configuration:

```
configure terminal
interface port-channel51
description Port-Channel FI-A
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
vpc 51
no shutdown
```

```
interface port-channel52
description Port-Channel FI-B
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
vpc 52
no shutdown
```

```
interface Ethernet1/21
description Fabric-Interconnect-A-33
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
channel-group 51 mode active
no shutdown
```

```
interface Ethernet1/22
description Fabric-Interconnect-A-34
switchport mode trunk
switchport trunk allowed vlan 1,10,135
```

```
spanning-tree port type edge trunk
mtu 9216
channel-group 51 mode active
no shutdown

interface Ethernet1/23
description Fabric-Interconnect-B-33
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
channel-group 52 mode active
no shutdown

interface Ethernet1/24
description Fabric-Interconnect-B-34
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
channel-group 52 mode active
no shutdown

copy run start
```



Note: Make sure to change peer-keepalive destination and source IP address appropriately for Nexus Switch B

Verify All vPC Status Is Up on Both the Nexus Switches

1. Verify the port-channel summary of Nexus Switch A as shown below:

```

FLEXPOD-NEXUS-A# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
       I - Individual    H - Hot-standby (LACP only)
       s - Suspended     r - Module-removed
       b - BFD Session Wait
       S - Switched      R - Routed
       U - Up (port-channel)
       p - Up in delay-lacp mode (member)
       M - Not in use. Min-links not met
-----
Group Port-      Type   Protocol  Member Ports
  Channel
-----
1     Po1(SU)    Eth     LACP      Eth1/1(P)  Eth1/2(P)
51    Po51(SU)   Eth     LACP      Eth1/21(P) Eth1/22(P)
52    Po52(SU)   Eth     LACP      Eth1/23(P) Eth1/24(P)
FLEXPOD-NEXUS-A#

```

2. Verify the port-channel summary of Nexus Switch B as shown below:

```

FLEXPOD-NEXUS-B# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
       I - Individual    H - Hot-standby (LACP only)
       s - Suspended     r - Module-removed
       b - BFD Session Wait
       S - Switched      R - Routed
       U - Up (port-channel)
       p - Up in delay-lacp mode (member)
       M - Not in use. Min-links not met
-----
Group Port-      Type   Protocol  Member Ports
  Channel
-----
1     Po1(SU)    Eth     LACP      Eth1/1(P)  Eth1/2(P)
51    Po51(SU)   Eth     LACP      Eth1/21(P) Eth1/22(P)
52    Po52(SU)   Eth     LACP      Eth1/23(P) Eth1/24(P)
FLEXPOD-NEXUS-B#

```

3. Verify the vPC summary of Nexus Switch A as shown below:

```

FLEXPOD-NEXUS-A# show vpc brief
Legend:
      (*) - local vPC is down, forwarding via vPC peer-link

vPC domain id          : 1
Peer status            : peer adjacency formed ok
vPC keep-alive status  : peer is alive
Configuration consistency status : success
Per-vlan consistency status : success
Type-2 consistency status : success
vPC role               : primary
Number of vPCs configured : 2
Peer Gateway          : Disabled
Dual-active excluded VLANs : -
Graceful Consistency Check : Enabled
Auto-recovery status   : Enabled, timer is off.(timeout = 240s)
Delay-restore status   : Timer is off.(timeout = 30s)
Delay-restore SVI status : Timer is off.(timeout = 10s)
Operational Layer3 Peer-router : Disabled

vPC Peer-link status
-----
id   Port   Status Active vlans
---
1    Po1    up    1,10,135

vPC status
-----
Id   Port   Status Consistency Reason           Active vlans
---
51   Po51   up    success    success                    1,10,135
52   Po52   up    success    success                    1,10,135

```

4. Verify the vPC summary of Nexus Switch B as shown below:

```

FLEXPOD-NEXUS-B# show vpc brief
Legend:
      (*) - local vPC is down, forwarding via vPC peer-link

vPC domain id          : 1
Peer status            : peer adjacency formed ok
vPC keep-alive status  : peer is alive
Configuration consistency status : success
Per-vlan consistency status : success
Type-2 consistency status : success
vPC role               : secondary
Number of vPCs configured : 2
Peer Gateway          : Disabled
Dual-active excluded VLANs : -
Graceful Consistency Check : Enabled
Auto-recovery status  : Enabled, timer is off.(timeout = 240s)
Delay-restore status  : Timer is off.(timeout = 30s)
Delay-restore SVI status : Timer is off.(timeout = 10s)
Operational Layer3 Peer-router : Disabled

vPC Peer-link status
-----
id   Port   Status Active vlans
---
1    Po1    up     1,10,135

vPC status
-----
Id   Port   Status Consistency Reason           Active vlans
---
51   Po51   up     success    success           1,10,135
52   Po52   up     success    success           1,10,135

```

Cisco UCS Configuration Overview

This section details the Cisco UCS configuration that was completed as part of the infrastructure build out. The racking, power, and installation of the chassis are described in the installation guide (see www.cisco.com/c/en/us/support/servers-unified-computing/ucs-manager/products-installation-guides-list.html). It is beyond the scope of this document to cover detailed information about the UCS infrastructure setup and connectivity. The documentation guides and examples are available at http://www.cisco.com/en/US/products/ps10281/products_installation_and_configuration_guides_list.html

We will list all the tasks to configure Cisco UCS system but only include some of the screenshots in this document.

Perform Initial Setup of Cisco UCS 6332-16UP Fabric Interconnects for a Cluster Setup

This section provides detailed procedures for configuring the Cisco Unified Computing System (Cisco UCS) for use in a FlexPod environment. The steps are necessary to provision the Cisco UCS B-Series and C-Series servers and should be followed precisely to avoid improper configuration.

Cisco UCS Fabric Interconnect A and Fabric Interconnect B

To configure the Cisco UCS Fabric Interconnects, complete the following steps:

1. Verify the following physical connections on the fabric interconnect:

- a. The management Ethernet port (mgmt0) is connected to an external hub, switch, or router
- b. The L1 ports on both fabric interconnects are directly connected to each other
- c. The L2 ports on both fabric interconnects are directly connected to each other



For more information, refer to the *Cisco UCS Hardware Installation Guide* for your fabric interconnect.

2. Connect to the console port on the first Fabric Interconnect.

```

COM3 - PuTTY
Enter the configuration method. (console/gui) ? console
Enter the setup mode; setup newly or restore from backup. (setup/restore) ? setup
You have chosen to setup a new Fabric interconnect. Continue? (y/n) : y
Enforce strong password? (y/n) [y]: n
Enter the password for "admin":
Confirm the password for "admin":
Is this Fabric interconnect part of a cluster(select 'no' for standalone)? (yes/no) [n]: yes
Enter the switch fabric (A/B) []: A
Enter the system name: FLEXPOD-FI
Physical Switch Mgmt0 IP address : 10.29.135.101
Physical Switch Mgmt0 IPv4 netmask : 255.255.255.0
IPv4 address of the default gateway : 10.29.135.1
Cluster IPv4 address : 10.29.135.100
Configure the DNS Server IP address? (yes/no) [n]:
Configure the default domain name? (yes/no) [n]:
Join centralized management environment (UCS Central)? (yes/no) [n]:
Following configurations will be applied:
Switch Fabric=A
System Name=FLEXPOD-FI
Enforced Strong Password=no
Physical Switch Mgmt0 IP Address=10.29.135.101
Physical Switch Mgmt0 IP Netmask=255.255.255.0
Default Gateway=10.29.135.1
IPv6 value=0
Cluster Enabled=yes
Cluster IP Address=10.29.135.100
NOTE: Cluster IP will be configured only after both Fabric Interconnects are initialized.
      UCM will be functional only after peer FI is configured in clustering mode.
Apply and save the configuration (select 'no' if you want to re-enter)? (yes/no): yes
  
```

3. Review the settings printed to the console. Answer yes to apply and save the configuration.
4. Wait for the login prompt to make the configuration has been saved to Fabric Interconnect A.
5. Connect the console port on the second Fabric Interconnect and do the following:

```

COM3 - PuTTY
Enter the configuration method. (console/gui) ? console

Installer has detected the presence of a peer Fabric interconnect. This Fabric interconnect will be added to the cluster. Continue (y/n) ? y

Enter the admin password of the peer Fabric interconnect:
Connecting to peer Fabric interconnect... done
Retrieving config from peer Fabric interconnect... done
Peer Fabric interconnect Mgmt0 IPv4 Address: 10.29.135.101
Peer Fabric interconnect Mgmt0 IPv4 Netmask: 255.255.255.0
Cluster IPv4 address : 10.29.135.100

Peer FI is IPv4 Cluster enabled. Please Provide Local Fabric Interconnect Mgmt0 IPv4 Address
Physical Switch Mgmt0 IP address : 10.29.135.102

Apply and save the configuration (select 'no' if you want to re-enter)? (yes/no): yes
Applying configuration. Please wait.
Tue May 22 00:00:09 UTC 2018

```

6. Review the settings printed to the console. Answer yes to apply and save the configuration.
7. Wait for the login prompt to make the configuration has been saved to Fabric Interconnect B.


Log in to Cisco UCS Manager

To log in to the Cisco Unified Computing System (UCS) environment, complete the following steps:

1. Open a web browser and navigate to the Cisco UCS fabric interconnect cluster address.



You may need to wait at least 5 minutes after configuring the second fabric interconnect for Cisco UCS Manager to come up.



2. Click the Launch UCS Manager link under HTML to launch Cisco UCS Manager.
3. If prompted to accept security certificates, accept as necessary.
4. When prompted, enter admin as the user name and enter the administrative password.
5. Click Login to log into Cisco UCS Manager.


Upgrade Cisco UCS Manager Software to Version 3.2

This document assumes the use of Cisco UCS 3.2(3c). To upgrade the Cisco UCS Manager software and the Cisco UCS Fabric Interconnect software to version 3.2(3c), refer to [Cisco UCS Manager Install and Upgrade Guides](#).

Anonymous Reporting

To create anonymous reporting, complete the following step:

1. In the Anonymous Reporting window, select whether to send anonymous data to Cisco for improving future products. If you select Yes, enter the IP address of your SMTP Server. Click OK.



Configure Cisco UCS Call Home

It is highly recommended by Cisco to configure Call Home in Cisco UCS Manager. Configuring Call Home will accelerate resolution of support cases. To configure Call Home, follow these steps:

1. In Cisco UCS Manager, click Admin on the left.
2. Select All > Communication Management > Call Home.
3. Change the State to On.
4. Fill in all the fields according to your Management preferences and click Save Changes and OK to complete configuring Call Home.

High Level Steps to Configure Base Cisco UCS

Using logical servers that are disassociated from the physical hardware removes many limiting constraints around how servers are provisioned. Cisco UCS Service Profiles contain values for a server's property settings, including virtual network interface cards (vNICs), MAC addresses, boot policies, firmware policies, fabric connectivity, external management, and HA information. The service profiles represent all the attributes of a logical server in Cisco UCS model. By abstracting these settings from the physical server into a Cisco Service Profile, the Service Profile can then be deployed to any physical compute hardware within the Cisco UCS domain. Furthermore, Service Profiles can, at any time, be migrated from one physical server to another. Furthermore, Cisco is the only hardware provider to offer a truly unified management platform, with Cisco UCS Service Profiles and hardware abstraction capabilities extending to both blade and rack servers.

The following are the high-level steps for configuring the Cisco UCS for this FlexPod solution.

1. Set Fabric Interconnect to Fibre Channel End Host Mode.
2. Synchronize Cisco UCS to NTP.
3. Configure Fabric Interconnect for Chassis and Blade Discovery.

- a. Configure Global Policies
- b. Configure Server Ports
4. Configure LAN and SAN on Cisco UCS Manager
 - a. Configure Ethernet LAN Uplink Ports
 - b. Create Uplink Port Channels to Cisco Nexus Switches
 - c. Configure FC SAN Uplink Ports
 - d. Configure VLAN
 - e. Configure VSAN
5. Configure IP, UUID, Server, MAC, WWNN and WWPN Pools
 - a. IP Pool Creation
 - b. UUID Suffix Pool Creation
 - c. Server Pool Creation
 - d. MAC Pool Creation
 - e. WWNN and WWPN Pool Creation
6. Set Jumbo Frames in both the Cisco Fabric Interconnect
7. Configure Server BIOS Policy
8. Create Adapter Policy
9. Configure Update Default Maintenance Policy
10. Configure vNIC and vHBA Template
 - a. Create Public and Private vNIC Template
 - b. Create Storage vHBA Template
11. Create Server Boot Policy for SAN Boot

Details for each step are discussed in the following sections.

Set Fabric Interconnects to Fibre Channel End Host Mode

To set the Fabric Interconnects to the Fibre Channel End Host Mode, complete the following steps:

1. On the Equipment tab, expand the Fabric Interconnects node and click Fabric Interconnect A.
2. On the General tab in the Actions pane, click Set FC End Host mode.
3. Follow the dialogs to complete the change.



Both Fabric Interconnects automatically reboot sequentially when you confirm you want to operate in this mode.

Synchronize Cisco UCS to NTP

To synchronize the Cisco UCS environment to the NTP server, complete the following steps:

1. In Cisco UCS Manager, in the navigation pane, click the Admin tab.
2. Select All > Time zone Management.
3. In the Properties pane, select the appropriate time zone in the Time zone menu.
4. Click Save Changes and then click OK.
5. Click Add NTP Server.
6. Enter the NTP server IP address and click OK.
7. Click OK to finish.

Configure Fabric Interconnect for Chassis and Blade Discovery


Cisco UCS 6332-16UP Fabric Interconnects are configured for redundancy. It provides resiliency in case of failures. The first step to establish connectivity between blades and Fabric Interconnects.

Configure Global Policies


The chassis discovery policy determines how the system reacts when you add a new chassis. We recommend using the platform max value as shown. Using platform max insures that Cisco UCS Manager uses the maximum number of IOM uplinks available.

To configure Global Policies, follow these steps:

1. Go to Equipment > Policies (right pane) > Global Policies > Chassis/FEX Discovery Policies.
2. Select Action as "Platform Max" from the drop down list and set Link Grouping to Port Channel as shown below. Click Save Changes and then click OK.



The difference between Discrete mode vs Port Channel mode is shown below:



Configure Server Ports

Configure Server Ports to initiate Chassis and Blade discovery. To configure server ports, follow these steps:

1. Go to Equipment > Fabric Interconnects > Fabric Interconnect A > Fixed Module > Ethernet Ports.

2. Select the ports (for this solution ports are 17-20) which are connected to the Cisco IO Modules of the two B-Series 5108 Chassis.
3. Right-click and select “Configure as Server Port.”
4. Click Yes to confirm and click OK.



5. Repeat the same task for Fabric Interconnect B.
6. After configuring Server Ports, acknowledge both the Chassis. Go to Equipment > Chassis > Chassis 1 > General > Actions > select “Acknowledge Chassis”. Similarly, acknowledge the chassis 2.
7. After acknowledging both the chassis, Re-acknowledge all the servers placed in the chassis. Go to Equipment > Chassis 1 > Servers > Server 1 > General > Actions > select “Server Maintenance” > select option “Re-acknowledge” and click OK. Similarly, repeat the process to Re-acknowledge all the eight Servers.
8. When the acknowledgement of the Servers completed, verify “Port-channel” of Internal LAN. Go to tab LAN > Internal LAN > Internal Fabric A > Port Channels as shown below.

The screenshot shows the Cisco UCS Manager interface. The left navigation pane is expanded to show the configuration path: LAN > Internal LAN > Internal Fabric A > Port Channels. The main content area displays a table of Port Channels for Fabric A.

Name	Port	Fabric ID	Port Type	Network Type	Transport
Port-Channel 1025 (Fabric A)	1025	A	Aggregation	Lan	Dce
Port-Channel 1026 (Fabric A)	1026	A	Aggregation	Lan	Dce

9. Verify the same for Internal Fabric B.



The last 6 ports of the UCS 6332 and UCS 6332-16UP FIs will only work with optical based QSFP transceivers and AOC cables, so they can be better utilized as uplinks to upstream resources that might be optical only.

Configure LAN and SAN on Cisco UCS Manager

Configure Ethernet Uplink Ports and Fibre Channel (FC) Storage ports on Cisco UCS as explained below.

Configure Ethernet LAN Uplink Ports

To configure network ports used to uplink the Fabric Interconnects to the Cisco Nexus switches, follow these steps:

1. In Cisco UCS Manager, in the navigation pane, click the Equipment tab.
2. Select Equipment > Fabric Interconnects > Fabric Interconnect A > Fixed Module.
3. Expand Ethernet Ports.
4. Select ports (for this solution ports are 31-34) that are connected to the Nexus switches, right-click them, and select Configure as Network Port.
5. Click Yes to confirm ports and click OK.
6. Verify the Ports connected to Cisco Nexus upstream switches are now configured as network ports.
7. Repeat the above steps for Fabric Interconnect B. The screenshot shows the network uplink ports for Fabric A.

Slot	Aggr. Port ID	Port ID	MAC	If Role	If Type	Overall Status	Admin State	Peer
1	0	31	00:DE:FB:92:99:54	Network	Physical	Up	Enabled	
1	0	32	00:DE:FB:92:99:58	Network	Physical	Up	Enabled	
1	0	33	00:DE:FB:92:99:5C	Network	Physical	Up	Enabled	
1	0	34	00:DE:FB:92:99:60	Network	Physical	Up	Enabled	

We created four uplink ports on each Fabric Interconnect as shown above. These ports will be used to create Virtual Port Channel in the next section.




The last 6 ports of the UCS 6332 and UCS 6332-16UP FIs only work with optical based QSFP transceivers and AOC cables, so they can be better utilized as uplinks to upstream resources that might be optical only.


Create Uplink Port Channels to Cisco Nexus Switches

In this procedure, two port channels were created: one from Fabric A to both Cisco Nexus switch and one from Fabric B to both Cisco Nexus switch. To configure the necessary port channels in the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the LAN tab in the navigation pane.
2. Under LAN > LAN Cloud, expand node Fabric A tree:
3. Right-click Port Channels.
4. Select Create Port Channel.
5. Enter 51 as the unique ID of the port channel.



6. Enter FI-A as the name of the port channel.
7. Click Next.
8. Select Ethernet ports 31-34 for the port channel.
9. Click >> to add the ports to the port channel.
10. Click Finish to create the port channel and then click OK.




11. Repeat steps 1-10 for Fabric Interconnect B, substituting 52 for the port channel number and FI-B for the name. The resulting configuration should look like the screenshot shown above.

Configure FC SAN Uplink Ports

The fibre channel port selection options for the 6332-16UP are from the first 16 ports starting from the first port on the left, and configured in increments of the first 6, 12, or all 16 of the unified ports.

To enable the Fibre channel ports, follow these steps for the 6332-16UP:

1. In Cisco UCS Manager, click Equipment on the left.
2. Select Equipment > Fabric Interconnects > Fabric Interconnect A (primary).
3. Select Configure Unified Ports.
4. Click Yes on the pop-up window warning that changes to the fixed module will require a reboot of the fabric interconnect and changes to the expansion module will require a reboot of that module.
5. Within the Configured Fixed Ports pop-up window move the gray slider bar from the left to the right to select either 6, 12, or 16 ports to be set as FC Uplinks.



6. For this solution, we configured the first six ports on the FI as FC Uplink ports. Click OK, then click Yes, then click OK to continue



Applying this configuration will cause the immediate reboot of Fabric Interconnect and/or Expansion Module(s)

7. Select Equipment > Fabric Interconnects > Fabric Interconnect B (primary).
8. Select Configure Unified Ports.
9. Click Yes on the pop-up window warning that changes to the fixed module will require a reboot of the fabric interconnect and changes to the expansion module will require a reboot of that module.

10. Within the Configured Fixed Ports pop-up window move the gray slider bar from the left to the right to select either 6, 12, or 16 ports to be set as FC Uplinks.
11. Click OK, then Yes, then OK to continue.
12. Wait for both Fabric Interconnects to reboot.
13. Log back into Cisco UCS Manager.

Configure VLAN

To configure the necessary virtual local area networks (VLANs) for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the LAN tab in the navigation pane.




In this solution, we created two VLANs: one for private network (VLAN 10) traffic and one for public network (VLAN 135) traffic. These two VLANs will be used in the vNIC templates that are discussed later.



It is very important to create both VLANs as global across both fabric interconnects. This way, VLAN identity is maintained across the fabric interconnects in case of NIC failover.

2. Select LAN > LAN Cloud.
3. Right-click VLANs.
4. Select Create VLANs



5. Enter Public_Traffic as the name of the VLAN to be used for Public Network Traffic.

6. Keep the Common/Global option selected for the scope of the VLAN.
7. Enter 135 as the ID of the VLAN ID.
8. Keep the Sharing Type as None.
9. Click OK and then click OK again.



We have also created the second VLAN: for private network (VLAN 10) traffic.

Name	ID	Type	Transport	Native	VLAN Sharing	Primary VLAN Name	Multicast Policy Name
VLAN default (1)	1	Lan	Ether	Yes	None		
VLAN Private_Traffic...	10	Lan	Ether	No	None		
VLAN Public_Traffic...	135	Lan	Ether	No	None		



These two VLANs will be used in the vNIC templates that are discussed later.

Configure VSAN


To configure the necessary virtual storage area networks (VSANs) for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the SAN tab in the navigation pane.



In this solution, we have created two VSANs. ORA-VSAN-A 101 and ORA-VSAN-B 102 for SAN Boot and Storage Access.

2. Select SAN > SAN Cloud.
3. Under VSANs, right-click VSANs.
4. Select Create VSANs.
5. Enter ORA-VSAN-A as the name of the VSAN.
6. Leave FC Zoning set at Disabled.




7. Select Fabric A for the scope of the VSAN.
8. Enter 101 as the ID of the VSAN.



Enter a unique VSAN ID and a corresponding FCoE VLAN ID that matches the configuration in the MDS switch for Fabric A. It is recommended to use the same ID for both parameters and to use something other than 1.

9. Click OK and then click OK again.
10. Repeat these steps to create the VSANs necessary for this solution. VSAN 101 and 102 are configured as shown below:




Configure IP, UUID, Server, MAC, WWNN and WWPN Pools

IP Pool Creation

An IP address pool on the out of band management network must be created to facilitate KVM access to each compute node in the Cisco UCS domain. To create a block of IP addresses for server KVM access in the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, in the navigation pane, click the LAN tab.
2. Select Pools > root > IP Pools > Click Create IP Pool.
3. We have named IP Pool as ORA-IP-Pool for this solution.
4. Select option Sequential to assign IP in sequential order then click next.
5. Click Add IPv4 Block.
6. Enter the starting IP address of the block and the number of IP addresses required, and the subnet and gateway information as shown below.




7. Click Next and then click Finish to create the IP block.

UUID Suffix Pool Creation

To configure the necessary universally unique identifier (UUID) suffix pool for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the Servers tab in the navigation pane.
2. Select Pools > root.
3. Right-click UUID Suffix Pools and then select Create UUID Suffix Pool.
4. Enter ORA-UUID-Pool as the name of the UUID name.

5. Optional: Enter a description for the UUID pool.
6. Keep the prefix at the derived option and select Sequential in as Assignment Order then click Next.
7. Click Add to add a block of UUIDs
8. Create a starting point UUID as per your environment.



9. Specify a size for the UUID block that is sufficient to support the available blade or server resources.

Server Pool Creation

To configure the necessary server pool for the Cisco UCS environment, follow these steps:


 **Consider creating unique server pools to achieve the granularity that is required in your environment.**

1. In Cisco UCS Manager, click the Servers tab in the navigation pane.
2. Select Pools > root > Right-click Server Pools > Select Create Server Pool.
3. Enter ORA-Pool as the name of the server pool.
4. Optional: Enter a description for the server pool then click Next
5. Select all the eight servers to be used for the Oracle RAC management and click > to add them to the server pool.
6. Click Finish and then click OK

MAC Pool Creation

To configure the necessary MAC address pools for the Cisco UCS environment, follow these steps:


1. In Cisco UCS Manager, click the LAN tab in the navigation pane.
2. Select Pools > root > right-click MAC Pools under the root organization.
3. Select Create MAC Pool to create the MAC address pool.
4. Enter ORA-MAC-A as the name for MAC pool.
5. Enter the seed MAC address and provide the number of MAC addresses to be provisioned.



6. Click OK and then click Finish.
7. In the confirmation message, click OK.
8. Create MAC Pool B and assign unique MAC Addresses as shown below.




We created Oracle-MAC-A and Oracle-MAC-B as shown below for all the vNIC MAC Addresses.



WWNN and WWPN Pool Creation

To configure the necessary WWNN pools for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the SAN tab in the navigation pane.
2. Select Pools > Root > WWNN Pools > right click WWNN Pools > Select Create WWNN Pool.
3. Assign name and Assignment Order as sequential as shown below.



4. Click Next and then click Add to add block of Ports.
5. Enter Block for WWN and size of WWNN Pool as shown below.

Create WWN Block ? X

From : Size :

To ensure uniqueness of WWNs in the SAN fabric, you are strongly encouraged to use the following WWN prefix:

20:00:00:25:b5:xx:xx:xx

OK Cancel

6. Click OK and then click Finish.

To configure the necessary WWPN pools for the Cisco UCS environment, follow these steps:



We created two WWPN as ORA-WWPN-A Pool and ORA-WWPN-B as World Wide Port Name as shown below. These WWNN and WWPN entries will be used to access storage through SAN configuration.

1. In Cisco UCS Manager, click the SAN tab in the navigation pane.
2. Select Pools > Root > WWPN Pools > right-click WWPN Pools > Select Create WWPN Pool.
3. Assign name as ORA-WWPN-A and Assignment Order as sequential.

Create WWN Block ? X

From : Size :

To ensure uniqueness of WWNs in the SAN fabric, you are strongly encouraged to use the following WWN prefix:

20:00:00:25:b5:xx:xx:xx

OK Cancel

4. Click Next and then click Add to add block of ports.
5. Enter Block for WWN and size.
6. Click OK and then Finish.

7. Configure the ORA-WWPN-B Pool and assign the unique block IDs as shown below.

Create WWN Block ? X

From : Size :

To ensure uniqueness of WWNs in the SAN fabric, you are strongly encouraged to use the following WWN prefix:

20:00:00:25:b5:xx:xx:xx



When there are multiple UCS domains sitting in adjacency, it is important that these blocks, the WWNN, WWPN, and MAC, hold differing values between each set.

Set Jumbo Frames in both the Cisco Fabric Interconnect

To configure jumbo frames and enable quality of service in the Cisco UCS fabric, follow these steps:

1. In Cisco UCS Manager, click the LAN tab in the navigation pane.
2. Select LAN > LAN Cloud > QoS System Class.
3. In the right pane, click the General tab.
4. On the Best Effort row, enter 9216 in the box under the MTU column.

Priority	Enabled	CoS	Packet Drop	Weight	Weight (%)	MTU	Multicast Optimized
Platinum	<input type="checkbox"/>	5	<input type="checkbox"/>	10	N/A	normal	<input type="checkbox"/>
Gold	<input type="checkbox"/>	4	<input checked="" type="checkbox"/>	9	N/A	normal	<input type="checkbox"/>
Silver	<input type="checkbox"/>	2	<input checked="" type="checkbox"/>	8	N/A	normal	<input type="checkbox"/>
Bronze	<input type="checkbox"/>	1	<input checked="" type="checkbox"/>	7	N/A	normal	<input type="checkbox"/>
Best Effort	<input checked="" type="checkbox"/>	Any	<input checked="" type="checkbox"/>	5	50	9216	<input type="checkbox"/>
Fibre Channel	<input checked="" type="checkbox"/>	3	<input type="checkbox"/>	5	50	fc	N/A

5. Click Save Changes in the bottom of the window.
6. Click OK.




Only the Fibre Channel and Best Effort QoS System Classes are enabled in this FlexPod implementation. The UCS and Nexus switches are intentionally configured this way so that all IP traffic within the FlexPod will be treated as Best Effort. Enabling the other QoS System Classes without having a comprehensive, end-to-end QoS setup in place can cause difficult to troubleshoot issues. For example, NetApp storage controllers by default mark IP-based storage protocol packets with a CoS value of 4. With the default configuration on the Nexus switches in this implementation, storage packets pass through the switches and into the UCS Fabric Interconnects with CoS 4 set in the packet header. If the Gold QoS System Class in Cisco UCS is enabled, these storage packets will be treated according to that class; if Jumbo Frames are being used for the storage protocols but the MTU of the Gold QoS System Class is not set to Jumbo, packet drops will occur.

Configure Server BIOS Policy

To create a server BIOS policy for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click Servers on the left.
2. Select Policies > root.
3. Right-click BIOS Policies.
4. Select Create BIOS Policy.
5. Enter OLTP_BIOS as the BIOS policy name
6. Select and click the newly created BIOS Policy.
7. Click the Advanced tab, leaving the Processor tab selected within the Advanced tab.
8. Set the following within the Processor tab:



9. Click Save Changes and then click OK



All of them may have to be required on your setup. Please follow the steps appropriately according to your environment and requirement. The following changes were made on the test bed where Oracle RAC installed. Please validate and change as needed.



For further details on BIOS settings, please refer to this document https://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-b-series-blade-servers/whitepaper_c11-740098.pdf



It is recommended to disable C states in the BIOS and in addition, Oracle recommends disabling it from OS level as well by modifying grub entries.

Create Adapter Policy

To create an Adapter Policy for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the Servers tab in the navigation pane.
2. Select Policies > root > right-click Adapter Policies.
3. Select Create Ethernet Adapter Policy.

4. Provide a name for the Ethernet adapter policy. Change the following fields and click Save Changes when you are finished:


a. Resources

- i. Transmit Queues: 8
- ii. Ring Size: 4096
- iii. Receive Queues: 8
- iv. Ring Size: 4096
- v. Completion Queues: 16
- vi. Interrupts: 32

b. Options

- i. Receive Side Scaling (RSS): Enabled

5. Configure adapter policy as shown below.





RSS distributes network receive processing across multiple CPUs in multiprocessor systems. This can be one of the following:
Disabled—Network receive processing is always handled by a single processor even if additional processors are available.

Enabled—Network receive processing is shared across processors whenever possible.

6. Click OK to finish.

Configure Update Default Maintenance Policy

To update the default Maintenance Policy, follow these steps:

1. In Cisco UCS Manager, click the Servers tab in the navigation pane
2. Select Policies > root > Maintenance Policies > Default.
3. Change the Reboot Policy to User Ack.
4. Click Save Changes.
5. Click OK to accept the changes.

Configure vNIC and vHBA Template

For this solution, we created two vNIC template for Public Network and Private Network Traffic.

Create Public and Private vNIC Template

To create vNIC (virtual network interface card) template for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the LAN tab in the navigation pane.
2. Select Policies > root > vNIC Templates > right-click to vNIC Template and Select "Create vNIC Template"
3. Enter ORA-vNIC-A as the vNIC template name and keep Fabric A selected.
4. Select the Enable Failover checkbox for high availability of the vNIC.



Selecting Failover is a critical step to improve link failover time by handling it at the hardware level, and to guard against NIC any potential for NIC failure not being detected by the virtual switch.

5. Select Template Type as Updating Template.
6. Under VLANs, select the checkboxes default and Public_Traffic and set Native-VLAN as the Public_Traffic.
7. Keep MTU value 1500 for Public Network Traffic.
8. In the MAC Pool list, select ORA-MAC-A.

9. Click OK to create the vNIC template as shown below.

The screenshot shows the UCS Manager interface for configuring a vNIC template. The breadcrumb path is LAN / Policies / root / vNIC Templates / vNIC Template ORA-vNIC-A. The left sidebar shows the navigation tree with 'vNIC Templates' and 'vNIC Template ORA-vNIC-A' highlighted. The main configuration area is divided into several sections:

- Actions:** Modify VLANs, Modify VLAN Groups, Delete, Show Policy Usage, Use Global.
- Properties:**
 - Name: ORA-vNIC-A
 - Description: (empty text box)
 - Owner: Local
 - Fabric ID: Fabric A, Fabric B, Enable Failover
 - Redundancy:
 - Redundancy Type: No Redundancy, Primary Template, Secondary Template
 - Target:
 - Adaptor
 - VM
 - Template Type: Initial Template, Updating Template
 - CDN Source: vNIC Name, User Defined
 - MTU: 1500
- Policies:**
 - MAC Pool: ORA-MAC-A(246/256)
 - QoS Policy: <not set>
 - Network Control Policy: <not set>
 - Pin Group: <not set>
 - Stats Threshold Policy: default
- Connection Policies:** (empty section)

10. Click OK to finish.

11. Create another vNIC template for Private Network Traffic with few changes:

- Enter ORA-vNIC-B as the vNIC template name for Private Network Traffic.
- Select the Fabric B and Enable Failover for Fabric ID options.
- Select Template Type as Updating Template.
- Under VLANs, select the checkboxes default and Private_Traffic and set Native-VLAN as the Private_Traffic.
- Set MTU value to 9000 and MAC Pool as ORA-MAC-B.

12. Click OK to create the vNIC template as shown below.

Create Storage vHBA Template

To create multiple virtual host bus adapter (vHBA) templates for the Cisco UCS environment, follow these steps:

1. In Cisco UCS Manager, click the SAN tab in the navigation pane
2. Select Policies > root > Right Click vHBA Templates > Select “Create vHBA Template” to create vHBAs.
3. Enter name as ORA-vHBA-A and keep Fabric A selected.
4. Select VSAN as ORA-VSAN-A and template type to Updating Template.
5. Select WWPN Pool as ORA-WWPN-A from the drop-down list as shown below.

Create vHBA Template

Name : ORA-vHBA-A

Description :

Fabric ID : A B

Redundancy

Redundancy Type : No Redundancy Primary Template Secondary Template

Select VSAN : ORA-VSAN-A [Create VSAN](#)

Template Type : Initial Template Updating Template

Max Data Field Size : 2048

WWPN Pool : ORA-WWPN-A(256/256) ▼

QoS Policy : <not set> ▼

Pin Group : <not set> ▼

Stats Threshold Policy : default ▼

OK **Cancel**



For this solution, we created two vHBA as ORA-vHBA-A and ORA-vHBA-B.

6. Enter name as ORA-vHBA-B and select Fabric B. Select WWPN Pool for ORA-vHBA-B as “ORA-WWPN-B” as shown below.

Create vHBA Template ? X

Name :

Description :

Fabric ID : A B

Redundancy

Redundancy Type : No Redundancy Primary Template Secondary Template

Select VSAN : Create VSAN

Template Type : Initial Template Updating Template

Max Data Field Size :

WWPN Pool : ▼

QoS Policy : ▼

Pin Group : ▼

Stats Threshold Policy : ▼

Create Server Boot Policy for SAN Boot

All Oracle nodes were set to boot from SAN for the Cisco Validated Design as part of the Service Profile template. The benefits of booting from SAN are numerous; disaster recovery, lower cooling and power requirements for each server since a local drive is not required, and better performance.



We strongly recommend to use “Boot from SAN” to realize full benefits of Cisco UCS stateless computing feature such as service profile mobility.

This process applies to a Cisco UCS environment in which the storage SAN ports are configured as detailed in the following sections.

Create Local Disk Configuration Policy

A Local disk configuration for the Cisco UCS is necessary if the servers in the environments have a local disk.

To configure Local disk policy, follow these steps:

1. Go to tab Servers > Policies > root > right-click Local Disk Configuration Policy > enter "SAN-Boot" as the local disk configuration policy name and change the mode to "No Local Storage."
2. Click OK to create the policy as shown below.

Create Local Disk Configuration Policy ? X

Name : SAN-Boot

Description :

Mode : No Local Storage ▼

FlexFlash

FlexFlash State : Disable Enable

If **FlexFlash State** is disabled, SD cards will become unavailable immediately.
Please ensure SD cards are not in use before disabling the FlexFlash State.

FlexFlash RAID Reporting State : Disable Enable

OK Cancel

Create SAN Boot Policy

The screenshot below shows the network interface, WWPN and ports connectivity configured for NetApp AFF A700s controller. Four Fibre Channel logical interfaces (LIFs) are created on storage controller cluster node 1 (node1_lif02a, node1_lif02b, node1_lif03a and node1_lif03b) and four Fibre Channel LIFs are created on storage controller cluster node 2 (node2_lif02a, node2_lif02b, node2_lif03a and node2_lif03b).

Interface Name	Storage Virtual Machine	IP Address/WWPN	Current Port	Is Home Port	Data Protocol Access	Management Access	Subnet	Role
node1_lif02a	ORA12C_SVM	20:06:00:a0:98:af:7c:5b	FlexPod-a700s-01.2a	Yes	fcp	No	-NA-	Data
node1_lif02b	ORA12C_SVM	20:0c:00:a0:98:af:7c:5b	FlexPod-a700s-01.2b	Yes	fcp	No	-NA-	Data
node1_lif03a	ORA12C_SVM	20:07:00:a0:98:af:7c:5b	FlexPod-a700s-01.3a	Yes	fcp	No	-NA-	Data
node1_lif03b	ORA12C_SVM	20:08:00:a0:98:af:7c:5b	FlexPod-a700s-01.3b	Yes	fcp	No	-NA-	Data
node2_lif02a	ORA12C_SVM	20:09:00:a0:98:af:7c:5b	FlexPod-a700s-02.2a	Yes	fcp	No	-NA-	Data
node2_lif02b	ORA12C_SVM	20:0d:00:a0:98:af:7c:5b	FlexPod-a700s-02.2b	Yes	fcp	No	-NA-	Data
node2_lif03a	ORA12C_SVM	20:0a:00:a0:98:af:7c:5b	FlexPod-a700s-02.3a	Yes	fcp	No	-NA-	Data
node2_lif03b	ORA12C_SVM	20:0b:00:a0:98:af:7c:5b	FlexPod-a700s-02.3b	Yes	fcp	No	-NA-	Data
FlexPod-a700s-01_c1us1	Cluster	169.254.22.180	FlexPod-a700s-01.e0a	Yes	none	No	-NA-	Cluster
FlexPod-a700s-01_c1us2	Cluster	169.254.81.21	FlexPod-a700s-01.e0f	Yes	none	No	-NA-	Cluster
FlexPod-a700s-02_c1us1	Cluster	169.254.213.16	FlexPod-a700s-02.e0a	Yes	none	No	-NA-	Cluster
FlexPod-a700s-02_c1us2	Cluster	169.254.132.211	FlexPod-a700s-02.e0f	Yes	none	No	-NA-	Cluster
FlexPod-a700s-01_mgmt1	FlexPod-a700s	10.29.135.107	FlexPod-a700s-01.e0M	Yes	none	Yes	-NA-	Node Management
FlexPod-a700s-02_mgmt1	FlexPod-a700s	10.29.135.108	FlexPod-a700s-02.e0M	Yes	none	Yes	-NA-	Node Management
cluster_mgmt	FlexPod-a700s	10.29.135.115	FlexPod-a700s-01.e0M	Yes	none	Yes	-NA-	Cluster Management
ORA12C_SVM_admin_lif1	ORA12C_SVM	10.29.135.14	FlexPod-a700s-01.e0M	Yes	none	Yes	-NA-	Data



You can also obtain this information by login to the storage cluster and run the network interface show command


The SAN boot policy configures the SAN Primary's primary-target to be network interface node1_lif02a on NetApp storage cluster and SAN Primary's secondary-target to be network interface node1_lif03a on NetApp storage cluster. Similarly, the SAN Secondary's primary-target to be network interface node2_lif02b on NetApp storage cluster and SAN Secondary's secondary-target to be network interface node2_lif03b on NetApp storage cluster. Login into NetApp storage controller and verify all the port information is correct. This information can be found in the NetApp Storage GUI under Network > Network Interfaces.



You have to create SAN Primary (hba0) and SAN Secondary (hba1) in SAN Boot Policy by entering WWPN of NetApp Storage LIFs as explained below.

To create Boot Policies for the Cisco UCS environments follow these steps:

1. Go to UCS Manager and then go to tab Servers > Policies > root > Boot Policies.
2. Right-click and select Create Boot Policy. Enter SAN_Boot as the name of the boot policy as shown below.




- Expand the Local Devices drop-down menu and Choose Add CD/DVD. Expand the vHBAs drop-down menu and select Add SAN Boot.




The SAN boot paths and targets will include primary and secondary options in order to maximize resiliency and number of paths.

- In the Add SAN Boot dialog box, select Type as “Primary” and name vHBA as “hba0”. Click OK to add SAN Boot.



9. Select add SAN Boot Target to enter WWPN address of storage LIF. Keep 0 as the value for Boot Target LUN. Enter the WWPN of NetApp Storage cluster interface node1_lif02a and add SAN Boot Primary Target.



Add SAN Boot Target ? X


Boot Target LUN : 0

Boot Target WWPN : 20:06:00:A0:98:AF:7C:5B

Type : Primary Secondary

OK Cancel

10. Add secondary SAN Boot target into same hba0, enter boot target LUN as 0 and WWPN of NetApp Storage cluster interface node1_lif03a and add SAN Boot Secondary Target.



Add SAN Boot Target ? X


Boot Target LUN : 0

Boot Target WWPN : 20:07:00:A0:98:AF:7C:5B

Type : Primary Secondary

OK Cancel


11. From the vHBA drop-down list and Choose Add SAN Boot. In the Add SAN Boot dialog box, enter "hba1" in the vHBA field.
12. Click OK to SAN Boot, then choose add SAN Boot Target.



The dialog box titled "Add SAN Boot" contains the following fields and controls:

- vHBA :
- Type : Primary Secondary Any
- Buttons: OK (blue), Cancel (white)


13. Enter 0 as the value for Boot Target LUN. Enter the WWPN of NetApp Storage cluster interface node2_lif02b and add SAN Boot Primary Target.




The dialog box titled "Add SAN Boot Target" contains the following fields and controls:

- Boot Target LUN :
- Boot Target WWPN :
- Type : Primary Secondary
- Buttons: OK (blue), Cancel (white)

14. Add secondary SAN Boot target into same hba1, and enter boot target LUN as 0 and WWPN of NetApp Storage cluster interface node2_lif03b and add SAN Boot Secondary Target.



15. After creating the FC boot policies, you can view the boot order in the UCS Manager GUI. To view the boot order, navigate to Servers > Policies > Boot Policies. Click Boot Policy SAN-Boot-A to view the boot order in the right pane of the Cisco UCS Manager as shown below.



For this solution, we created one Boot Policy as “SAN_Boot”. For all 4 Oracle Database RAC Nodes(flex1, flex2, flex3 and flex4), we will assign this boot policy to the Service Profiles as explained in the following section.

Configure and Create a Service Profile Template

Service profile templates enable policy based server management that helps ensure consistent server resource provisioning suitable to meet predefined workload needs.

The Cisco UCS service profiles with SAN boot policy provides the following benefits:

- Scalability - Rapid deployment of new servers to the environment in a very few steps.
- Manageability - Enables seamless hardware maintenance and upgrades without any restrictions.
- Flexibility - Easy to repurpose physical servers for different applications and services as needed.
- Availability - Hardware failures are not impactful and critical. In rare case of a server failure, it is easier to associate the logical service profile to another healthy physical server to reduce the impact.


You will create one Service Profile Template “ORA_FLEXPOD” using boot policy created earlier to utilize four LIF ports from NetApp Storage for high-availability in case of any FC links go down.

The following sections detail how to create ORA_FLEXPOD.


Create Service Profile Template

To create a service profile template, follow these steps:

1. In the Cisco UCS Manager, go to Servers > Service Profile Templates > root and right-click to “Create Service Profile Template” as shown below.
2. Enter the Service Profile Template name, select the UUID Pool that was created earlier and click Next.



3. Select Local Disk Configuration Policy to SAN-Boot as no Local Storage.



- In the networking window, select “Expert” and click “Add” to create vNICs. Add one or more vNICs that the server should use to connect to the LAN.



We created two vNIC in the create vNIC menu. We have given name to first vNIC as “eth0” and second vNIC as “eth1”.

- Select vNIC Template as ORA-vNIC-A and Adapter Policy as ORA_Linux_Tuning which was created earlier for vNIC “eth0”.

The screenshot shows a 'Create vNIC' dialog box with the following fields and options:

- Name: eth0
- Use vNIC Template:
- Redundancy Pair:
- vNIC Template: ORA-vNIC-A
- Peer Name: (empty field)
- Adapter Performance Profile: ORA_Linux_Tuning

Buttons: OK, Cancel, Create vNIC Template, Create Ethernet Adapter Policy.

6. Select vNIC Template as ORA-vNIC-B and Adapter Policy as ORA_Linux_Tuning for vNIC "eth1". eth0 and eth1 vNICs are created so that Servers should use to connect to the LAN.

Create vNIC

Name :

Use vNIC Template :

Redundancy Pair :

Peer Name :


vNIC Template :

Create vNIC Template

Adapter Performance Profile

Adapter Policy :

Create Ethernet Adapter Policy



7. When the vNICs are created, you need to create vHBAs. Click Next.
8. In the SAN Connectivity menu, select “Expert” to configure as SAN connectivity. Select WWNN (World Wide Node Name) pool, created previously. Click “Add” to add vHBAs as shown below. The following four HBA have been created:
 - a. hba0 using vHBA Template Oracle-HBA-A
 - b. hba1 using vHBA Template Oracle-HBA-B
 - c. hba2 using vHBA Template Oracle-HBA-A
 - d. hba3 using vHBA Template Oracle-HBA-B

Create vHBA ? X

Name :

Use vHBA Template :

Redundancy Pair :

Peer Name :

vHBA Template :

[Create vHBA Template](#)

Adapter Performance Profile

Adapter Policy :

[Create Fibre Channel Adapter Policy](#)

Create vHBA ? X

Name :

Use vHBA Template :

Redundancy Pair :

Peer Name :

vHBA Template : ▼

[Create vHBA Template](#)

Adapter Performance Profile

Adapter Policy : ▼

[Create Fibre Channel Adapter Policy](#)

Create vHBA ? X

Name :

Use vHBA Template :

Redundancy Pair :

Peer Name :

vHBA Template : ▼

[Create vHBA Template](#)

Adapter Performance Profile

Adapter Policy : ▼

[Create Fibre Channel Adapter Policy](#)

Create vHBA ? X

Name :

Use vHBA Template :

Redundancy Pair :

Peer Name :

vHBA Template : ▼

Adapter Performance Profile

Adapter Policy : ▼

[Create vHBA Template](#)
[Create Fibre Channel Adapter Policy](#)

Create Service Profile Template

Optionally specify disk policies and SAN configuration information.

WWNN Assignment:

The WWNN will be assigned from the selected pool.
The available/total WWNNs are displayed after the pool name.

Name	WWPN
▶ vHBA hba3	Derived
▶ vHBA hba2	Derived <input type="button" value="Derived"/>
▶ vHBA hba1	Derived
▶ vHBA hba0	Derived



For this Oracle RAC Configuration, the Cisco MDS 9148S is used for zoning. Skip zoning and go to the next step.

9. In vNIC/vHBA Placement menu, keep option as Let System Perform Placement.
10. For this solution, do not configure any vMedia Policy. Click Next.
11. In the Server Boot Order, select "SAN_Boot" as Boot Policy created previously.

Create Service Profile Template

Optionally specify the boot policy for this service profile template.

Boot Policy: SAN_Boot Create Boot Policy

Name : **SAN_Boot**
 Description :
 Reboot on Boot Order Change : **No**
 Enforce vNIC/vHBA/iSCSI Name : **Yes**
 Boot Mode : **Legacy**

WARNINGS:
 The type (primary/secondary) does not indicate a boot order presence.
 The effective order of boot devices within the same device class (LAN/Storage/iSCSI) is determined by PCIe bus scan order.
 If **Enforce vNIC/vHBA/iSCSI Name** is selected and the vNIC/vHBA/iSCSI does not exist, a config error will be reported.
 If it is not selected, the vNICs/vHBAs are selected if they exist, otherwise the vNIC/vHBA with the lowest PCIe bus scan order is used.

Boot Order


Name	Order	vNIC/vHBA	Type	LUN	WWN	Slot	Boot	Boot	Des...
CD/DVD	1								
San	2								
SAN Primary		hba0	Pri...						
SAN Target Primary			Pri...	0	20:06:00:A0:98:AF:7C:5B				
SAN Target Secondary			Sec...	0	20:07:00:A0:98:AF:7C:5B				
SAN Secondary		hba1	Sec...						

Create iSCSI vNIC Set iSCSI Boot Parameters Set UEFI Boot Parameters

< Prev Next > Finish Cancel

12. The maintenance policy and server assignment options were left as default in the configuration.

13. In operational policies menu, select OLTP_BIOS as BIOS Policy, created previously.



14. The rest of the configuration is left as default in the configuration. However, it may vary from site-to-site depending on workloads, best practices, and policies.

15. Click Finish to create service profile template as “ORA_FLEXPOD”. This service profile template will be used to create four service profiles for four oracle RAC nodes(flex1, flex2, flex3 and flex4).

Now you have one Service profile template as “ORA_FLEXPOD” having four vHBAs and two vNICs.


Create Service Profiles from Template and Associate to Servers

Create Service Profiles from Template

For all four Oracle RAC Nodes (flex1, flex2, flex3 and flex4), you will create four Service Profiles as FLEX1, FLEX2, FLEX3 and FLEX4 from Template “ORA_FLEXPOD”.

To create Service Profiles from Template, follow these steps:

1. Go to tab Servers > Service Profiles > root > and right-click “Create Service Profiles from Template”.
2. Select the Service profile template as “ORA_FLEXPOD” which we created earlier and name the service profile as “FLEX”.
3. To create four service profiles, enter “Number of Instances” as 4 as shown below. This process creates service profiles as “FLEX1”, “FLEX2”, “FLEX3” and “FLEX4”.



Create Service Profiles From Template

Naming Prefix : FLEX

Name Suffix Starting Number : 1

Number of Instances : 4

Service Profile Template : ORA_FLEXPOD


OK Cancel

When the service profiles are created, associate them to the servers as described below.

Associate Service Profiles to the Servers

To associate service profiles to the servers, follow these steps:

1. Under the Servers tab, select the desired service profile, and select change service profile association.
2. Right-click the name of service profile you want to associate with the server and select the option "Change Service Profile Association".
3. In the Change Service Profile Association page, from the Server Assignment drop-down list, select the existing server that you want to assign and click OK.



- Assign service profiles FLEX1 to Chassis 1 Server 1 and service profile FLEX2 to Chassis 1 Server 2. Similarly, we will assign, service profiles FLEX3 to Chassis 2 Server 1 and service profile FLEX4 to Chassis 2 Server 2.



Make sure all the service profiles are associated as shown below.

Name	Chas...	PID	Model	Use...	Cores ...	Memory	Adapters	NICs	HBAs	Overall...	Operability	Pow...	Assoc State	Profile	Fault S...	
Server 1	1	UCSB-B200-M5	Cisco UCS B200 M5 2 Socket Blade Server		40	40	524288	1	2	4	OK	Operable	On	Associated	org-root/ls-FLEX1	N/A
Server 2	1	UCSB-B200-M5	Cisco UCS B200 M5 2 Socket Blade Server		40	40	524288	1	2	4	OK	Operable	On	Associated	org-root/ls-FLEX2	N/A
Server 1	2	UCSB-B200-M5	Cisco UCS B200 M5 2 Socket Blade Server		40	40	524288	1	2	4	OK	Operable	On	Associated	org-root/ls-FLEX3	N/A
Server 2	2	UCSB-B200-M5	Cisco UCS B200 M5 2 Socket Blade Server		40	40	524288	1	2	4	OK	Operable	On	Associated	org-root/ls-FLEX4	N/A

- As shown above, make sure all the server nodes have no major or critical faults and all are in an operable state.

This completes the configuration required for Cisco UCS Manager Setup.



Additional server pools, service profile templates, and service profiles can be created in the respective organizations to add more servers to the FlexPod unit. All other pools and policies are at the root level and can be shared among the organizations


Configure Cisco MDS 9148S Switch

This section provides a detailed procedure for configuring the Cisco MDS 9148S Switches.



Follow these steps precisely because failure to do so could result in an improper configuration.

We connected MDS Switches to Fabric Interconnects and NetApp AFF A700s Storage System as shown below.



For this solution, we connected four ports (ports 1 to 4) of MDS Switch A to Fabric Interconnect A (ports 1-4). We also connected four ports (ports 1 to 4) of MDS Switch B to Fabric Interconnect B (ports 1-4). All ports carry 16 Gb/s FC Traffic. Table 8 lists port connectivity of Cisco MDS Switches to the Fabric Interconnects.

Table 8 MDS Switch Connectivity to the Fabric Interconnects

MDS Switch	MDS Switch Port	FI Ports	Fabric Interconnect
MDS Switch A	FC Port 1/1	FI-A Port 1/1	Fabric Interconnect A (FI-A)

MDS Switch	MDS Switch Port	FI Ports	Fabric Interconnect
	FC Port 1/2	FI-A Port 1/2	
	FC Port 1/3	FI-A Port 1/3	
	FC Port 1/4	FI-A Port 1/4	
MDS Switch B	FC Port 1/1	FI-B Port 1/1	Fabric Interconnect B (FI-B)
	FC Port 1/2	FI-B Port 1/2	
	FC Port 1/3	FI-B Port 1/3	
	FC Port 1/4	FI-B Port 1/4	

For these solution, we have connected four ports (ports 9 to 12) of MDS Switch A to the NetApp AFF A700s Storage controller. Similarly, we have connected four ports (ports 9 to 12) of MDS Switch B to the NetApp AFF A700s Storage controller. All ports carry 16 Gb/s FC Traffic. Table 9 lists port connectivity of Cisco MDS Switches to NetApp AFF A700s Controller.

Table 9 MDS Switch Connectivity to the NetApp AFF A700s Storage

MDS Switch	MDS Switch Port	NetApp Storage Controller	NetApp Controller Ports	NetApp Port Description
MDS Switch A	FC Port 1/9	NetApp AFF A700s Controller 1	FC Port 0 - Slot 2	NetApp-A700s-01-2a
	FC Port 1/10	NetApp AFF A700s Controller 1	FC Port 0 - Slot 3	NetApp-A700s-01-3a
	FC Port 1/11	NetApp AFF A700s Controller 2	FC Port 0 - Slot 2	NetApp-A700s-02-2a
	FC Port 1/12	NetApp AFF A700s Controller 2	FC Port 0 - Slot 3	NetApp-A700s-02-3a
MDS Switch B	FC Port 1/9	NetApp AFF A700s Controller 1	FC Port 1 - Slot 2	NetApp-A700s-01-2b
	FC Port 1/10	NetApp AFF A700s Controller 1	FC Port 1 - Slot 3	NetApp-A700s-01-3b
	FC Port 1/11	NetApp AFF A700s Controller 2	FC Port 1 - Slot 2	NetApp-A700s-02-2b
	FC Port 1/12	NetApp AFF A700s Controller 2	FC Port 1 - Slot 3	NetApp-A700s-02-3b

Configure feature for MDS Switch A and MDS Switch B

To configure feature on MDS Switches, follow these steps:

1. Log in as admin user into MDS Switch A:

```
FLEXPOD-MDS-A# config terminal
FLEXPOD-MDS-A(config)# feature npiv
FLEXPOD-MDS-A(config)# feature telnet
FLEXPOD-MDS-A(config)# switchname FLEXPOD-MDS-A
FLEXPOD-MDS-A(config)# copy running-config startup-config
```

2. Login as admin user into MDS Switch B:

```
FLEXPOD-MDS-B# config terminal
FLEXPOD-MDS-B(config)# feature npiv
FLEXPOD-MDS-B(config)# feature telnet
```

```
FLEXPOD-MDS-B(config)# switchname FLEXPOD-MDS-B
FLEXPOD-MDS-B(config)# copy running-config startup-config
```

Configure VSANs for MDS Switch A and MDS Switch B

To create VSANs, follow these steps:

1. Log in as admin user into MDS Switch A.
2. Create VSAN 101 for Storage Traffic:

```
FLEXPOD-MDS-A # config terminal
FLEXPOD-MDS-A(config)# VSAN database
FLEXPOD-MDS-A(config-vsan-db)# vsan 101
FLEXPOD-MDS-A(config-vsan-db)# vsan 101 interface fc 1/1-12
FLEXPOD-MDS-A(config-vsan-db)# exit
```

```
FLEXPOD-MDS-A(config)# interface fc 1/1-12
FLEXPOD-MDS-A(config-if)# switchport trunk allowed vsan 101
FLEXPOD-MDS-A(config-if)# switchport trunk mode off
FLEXPOD-MDS-A(config-if)# port-license acquire
FLEXPOD-MDS-A(config-if)# no shutdown
FLEXPOD-MDS-A(config-if)# exit
FLEXPOD-MDS-A(config)# copy running-config startup-config
```

3. Login as admin user into MDS Switch B.
4. Create VSAN 102 for Storage Traffic:

```
FLEXPOD-MDS-B # config terminal
FLEXPOD-MDS-B(config)# VSAN database
FLEXPOD-MDS-B(config-vsan-db)# vsan 102
FLEXPOD-MDS-B(config-vsan-db)# vsan 102 interface fc 1/1-12
FLEXPOD-MDS-B(config-vsan-db)# exit
```

```
FLEXPOD-MDS-B(config)# interface fc 1/1-12
FLEXPOD-MDS-B(config-if)# switchport trunk allowed vsan 102
FLEXPOD-MDS-B(config-if)# switchport trunk mode off
FLEXPOD-MDS-B(config-if)# port-license acquire
```

```

FLEXPOD-MDS-B(config-if)# no shutdown

FLEXPOD-MDS-B(config-if)# exit

FLEXPOD-MDS-B(config)# copy running-config startup-config

```

Create and Configure Fibre Channel Zoning

This procedure sets up the Fibre Channel connections between the Cisco MDS 9148S switches, the Cisco UCS Fabric Interconnects, and the NetApp AFF Storage systems.

Before you configure the zoning details, decide how many paths are needed for each LUN and extract the WWPN numbers for each of the HBAs from each server. We used 4 HBAs for each Server. Two HBAs (HBA0 and HBA2) are connected to MDS Switch-A and other two HBAs (HBA1 and HBA3) are connected to MDS Switch-B.

To create and configure the Fibre channel zoning, follow these steps:

1. Log into the Cisco UCS Manager > Equipment > Chassis > Servers and select the desired server. On the right-hand menu, click the Inventory tab and HBA's sub-tab to get the WWPN of HBA's as shown below.



Name	Adapter ID	vHBA	Vendor	PID	Operability	WWPN
HBA 1	1	hba0	Cisco Systems Inc	UCSB-MLOM-40G-03	Operable	20:00:00:25:85:8A:A0:00
HBA 2	1	hba1	Cisco Systems Inc	UCSB-MLOM-40G-03	Operable	20:00:00:25:85:8B:80:00
HBA 3	1	hba2	Cisco Systems Inc	UCSB-MLOM-40G-03	Operable	20:00:00:25:85:8A:A0:01
HBA 4	1	hba3	Cisco Systems Inc	UCSB-MLOM-40G-03	Operable	20:00:00:25:85:8B:80:01

2. Log into NetApp storage controller and extract the WWPN of FC LIFs configured and verify all the port information is correct. This information can be found in the NetApp Storage GUI under Network > Network Interfaces.

The screenshot below shows the network interface, WWPN and ports connectivity configured for NetApp AFF A700s controller. Four Fibre Channel logical interfaces (LIFs) are created on storage controller cluster node 1 (node1_lif02a, node1_lif02b, node1_lif03a and node1_lif03b) and four Fibre Channel LIFs are created on storage controller cluster node 2 (node2_lif02a, node2_lif02b, node2_lif03a and node2_lif03b).

Interface Name	Storage Virtual Machine	IP Address/WPPN	Current Port	Is Home Port	Data Protocol Access	Management Access	Subnet	Role
node1_if02a	ORA12C_SVM	20:06:00:a0:98:af:7c5b	FlexPod-a700s-01:2a	Yes	fcp	No	-NA-	Data
node1_if02b	ORA12C_SVM	20:0c:00:a0:98:af:7c5b	FlexPod-a700s-01:2b	Yes	fcp	No	-NA-	Data
node1_if03a	ORA12C_SVM	20:07:00:a0:98:af:7c5b	FlexPod-a700s-01:3a	Yes	fcp	No	-NA-	Data
node1_if03b	ORA12C_SVM	20:08:00:a0:98:af:7c5b	FlexPod-a700s-01:3b	Yes	fcp	No	-NA-	Data
node2_if02a	ORA12C_SVM	20:09:00:a0:98:af:7c5b	FlexPod-a700s-02:2a	Yes	fcp	No	-NA-	Data
node2_if02b	ORA12C_SVM	20:0d:00:a0:98:af:7c5b	FlexPod-a700s-02:2b	Yes	fcp	No	-NA-	Data
node2_if03a	ORA12C_SVM	20:0a:00:a0:98:af:7c5b	FlexPod-a700s-02:3a	Yes	fcp	No	-NA-	Data
node2_if03b	ORA12C_SVM	20:0b:00:a0:98:af:7c5b	FlexPod-a700s-02:3b	Yes	fcp	No	-NA-	Data
FlexPod-a700s-01_clus1	Cluster	169.254.22.180	FlexPod-a700s-01:e0a	Yes	none	No	-NA-	Cluster
FlexPod-a700s-01_clus2	Cluster	169.254.81.21	FlexPod-a700s-01:e0f	Yes	none	No	-NA-	Cluster
FlexPod-a700s-02_clus1	Cluster	169.254.213.16	FlexPod-a700s-02:e0a	Yes	none	No	-NA-	Cluster
FlexPod-a700s-02_clus2	Cluster	169.254.132.211	FlexPod-a700s-02:e0f	Yes	none	No	-NA-	Cluster
FlexPod-a700s-01_mgmt1	FlexPod-a700s	10.29.135.107	FlexPod-a700s-01:e0M	Yes	none	Yes	-NA-	Node Management
FlexPod-a700s-02_mgmt1	FlexPod-a700s	10.29.135.108	FlexPod-a700s-02:e0M	Yes	none	Yes	-NA-	Node Management
cluster_mgmt	FlexPod-a700s	10.29.135.115	FlexPod-a700s-01:e0M	Yes	none	Yes	-NA-	Cluster Management
ORA12C_SVM_admin_if1	ORA12C_SVM	10.29.135.14	FlexPod-a700s-01:e0M	Yes	none	Yes	-NA-	Data



You can also obtain this information by login to the storage cluster and run the network interface show command

The NetApp Storage AFF A700s have eight active FC connection goes to the Cisco MDS switches. Four FC ports are connected to Cisco MDS-A, and other four FC ports are connected to Cisco MDS-B Switches. The SAN Ports FC-Port-0-Slot-2 and FC-Port-0-Slot-3 of NetApp AFF A700s Controller - 1 are connected to Cisco MDS Switch A and FC-Port-1-Slot-2 and FC-Port-1-Slot-3 are connected to Cisco MDS Switch B. Similarly, the SAN Ports FC-Port-0-Slot-2 and FC-Port-0-Slot-3 of NetApp AFF A700s Controller - 2 are connected to Cisco MDS Switch A and FC-Port-1-Slot-2 and FC-Port-1-Slot-3 are connected to Cisco MDS Switch B.

Create Device Aliases for Fibre Channel Zoning on Cisco MDS Switch A

To configure device aliases and zones for the SAN boot paths as well as datapaths of MDS switch A, follow these steps:

1. Log in as admin user and run the following commands:

```
configure terminal
```

```
device-alias database
```

```
device-alias name flex1-hba0 pwnn 20:00:00:25:b5:8a:a0:00
```

```
device-alias name flex1-hba2 pwnn 20:00:00:25:b5:8a:a0:01
```

```
device-alias name flex2-hba0 pwnn 20:00:00:25:b5:8a:a0:02
```

```
device-alias name flex2-hba2 pwnn 20:00:00:25:b5:8a:a0:03
```

```
device-alias name flex3-hba0 pwnn 20:00:00:25:b5:8a:a0:04
```

```
device-alias name flex3-hba2 pwnn 20:00:00:25:b5:8a:a0:05
```

```

device-alias name flex4-hba0 pwwn 20:00:00:25:b5:8a:a0:06
device-alias name flex4-hba2 pwwn 20:00:00:25:b5:8a:a0:07
device-alias name NetApp-A700s-01-2A pwwn 20:06:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-01-3A pwwn 20:07:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-02-2A pwwn 20:09:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-02-3A pwwn 20:0a:00:a0:98:af:7c:5b
device-alias commit
copy run start

```

Create Device Aliases for Fibre Channel Zoning on Cisco MDS Switch B

To configure device aliases and zones for the SAN boot paths as well as datapaths of MDS switch B, follow these steps:

1. Log in as admin user and run the following commands:

```

configure terminal
device-alias database
device-alias name flex1-hba1 pwwn 20:00:00:25:b5:8b:b0:00
device-alias name flex1-hba3 pwwn 20:00:00:25:b5:8b:b0:01
device-alias name flex2-hba1 pwwn 20:00:00:25:b5:8b:b0:02
device-alias name flex2-hba3 pwwn 20:00:00:25:b5:8b:b0:03
device-alias name flex3-hba1 pwwn 20:00:00:25:b5:8b:b0:04
device-alias name flex3-hba3 pwwn 20:00:00:25:b5:8b:b0:05
device-alias name flex4-hba1 pwwn 20:00:00:25:b5:8b:b0:06
device-alias name flex4-hba3 pwwn 20:00:00:25:b5:8b:b0:07
device-alias name NetApp-A700s-01-2B pwwn 20:0c:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-01-3B pwwn 20:08:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-02-2B pwwn 20:0d:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-02-3B pwwn 20:0b:00:a0:98:af:7c:5b
device-alias commit
copy run start

```

Create Zoning

Cisco MDS Switch A

To configure zones for the Cisco MDS Switch A, follow these steps:

1. Create a zone for each service profile as shown below.

2. Log in as admin user into MDS Switch A and run these commands to create the zone:

```
configure terminal
```

```
zone name flex1 vsan 101
```

```
member pwnn 20:00:00:25:b5:8a:a0:00
```

```
member pwnn 20:00:00:25:b5:8a:a0:01
```

```
member pwnn 20:06:00:a0:98:af:7c:5b
```

```
member pwnn 20:07:00:a0:98:af:7c:5b
```

```
member pwnn 20:09:00:a0:98:af:7c:5b
```

```
member pwnn 20:0a:00:a0:98:af:7c:5b
```

```
zone name flex2 vsan 101
```

```
member pwnn 20:00:00:25:b5:8a:a0:02
```

```
member pwnn 20:00:00:25:b5:8a:a0:03
```

```
member pwnn 20:06:00:a0:98:af:7c:5b
```

```
member pwnn 20:07:00:a0:98:af:7c:5b
```

```
member pwnn 20:09:00:a0:98:af:7c:5b
```

```
member pwnn 20:0a:00:a0:98:af:7c:5b
```

```
zone name flex3 vsan 101
```

```
member pwnn 20:00:00:25:b5:8a:a0:04
```

```
member pwnn 20:00:00:25:b5:8a:a0:05
```

```
member pwnn 20:06:00:a0:98:af:7c:5b
```

```
member pwnn 20:07:00:a0:98:af:7c:5b
```

```
member pwnn 20:09:00:a0:98:af:7c:5b
```

```
member pwnn 20:0a:00:a0:98:af:7c:5b
```

```
zone name flex4 vsan 101
```

```
member pwnn 20:00:00:25:b5:8a:a0:06
```

```
member pwnn 20:00:00:25:b5:8a:a0:07
```

```
member pwnn 20:06:00:a0:98:af:7c:5b
```

```
member pwnn 20:07:00:a0:98:af:7c:5b
```

```
member pwnn 20:09:00:a0:98:af:7c:5b
```

```
member pwwn 20:0a:00:a0:98:af:7c:5b
```

3. After the zone for the service profile has been created, create the zone set and add the necessary members.

```
zoneset name flex vsan 101
```

```
member flex1
```

```
member flex2
```

```
member flex3
```

```
member flex4
```

4. Activate the zone set by running following commands

```
zoneset activate name flex vsan 101
```

```
copy run start
```

Cisco MDS Switch B

To configure zones for the Cisco MDS Switch B, follow these steps:

1. Create a zone for each service profile.
2. Log in as admin user into MDS Switch B and run the below commands to create the zone:

```
configure terminal
```

```
zone name flex1 vsan 102
```

```
member pwwn 20:00:00:25:b5:8b:b0:00
```

```
member pwwn 20:00:00:25:b5:8b:b0:01
```

```
member pwwn 20:0c:00:a0:98:af:7c:5b
```

```
member pwwn 20:08:00:a0:98:af:7c:5b
```

```
member pwwn 20:0d:00:a0:98:af:7c:5b
```

```
member pwwn 20:0b:00:a0:98:af:7c:5b
```

```
zone name flex2 vsan 102
```

```
member pwwn 20:00:00:25:b5:8b:b0:02
```

```
member pwwn 20:00:00:25:b5:8b:b0:03
```

```
member pwwn 20:0c:00:a0:98:af:7c:5b
```

```
member pwwn 20:08:00:a0:98:af:7c:5b
```

```
member pwwn 20:0d:00:a0:98:af:7c:5b
```

```
member pwwn 20:0b:00:a0:98:af:7c:5b
```

```

zone name flex3 vsan 102
  member pwwn 20:00:00:25:b5:8b:b0:04
  member pwwn 20:00:00:25:b5:8b:b0:05
  member pwwn 20:0c:00:a0:98:af:7c:5b
  member pwwn 20:08:00:a0:98:af:7c:5b
  member pwwn 20:0d:00:a0:98:af:7c:5b
  member pwwn 20:0b:00:a0:98:af:7c:5b

```

```

zone name flex4 vsan 102
  member pwwn 20:00:00:25:b5:8b:b0:06
  member pwwn 20:00:00:25:b5:8b:b0:07
  member pwwn 20:0c:00:a0:98:af:7c:5b
  member pwwn 20:08:00:a0:98:af:7c:5b
  member pwwn 20:0d:00:a0:98:af:7c:5b
  member pwwn 20:0b:00:a0:98:af:7c:5b

```

3. After the zone for the service profile has been created, create the zone set and add the necessary members:

```

zoneset name flex vsan 102
  member flex1
  member flex2
  member flex3
  member flex4

```

4. Activate the zone set by running following commands:

```

zoneset activate name flex vsan 102
copy run start

```

Verify FC Ports on MDS Switch

To verify FC ports on the MDS switch, follow these steps:

1. Log in as admin user into MDS Switch A and run the “show flogi database vsan 101” to verify all FC ports.

```

FLEXPOD-MDS-A#
FLEXPOD-MDS-A# show flogi database vsan 101
-----
INTERFACE          VSAN    FCID          PORT NAME          NODE NAME
-----
fc1/1              101     0xa20400     20:01:00:de:fb:92:99:00 20:65:00:de:fb:92:99:01
fc1/1              101     0xa20401     20:00:00:25:b5:8a:a0:00 20:00:00:25:b5:7a:00:00
                    [flex1-hba0]
fc1/1              101     0xa20402     20:00:00:25:b5:8a:a0:01 20:00:00:25:b5:7a:00:00
                    [flex1-hba2]
fc1/2              101     0xa20500     20:02:00:de:fb:92:99:00 20:65:00:de:fb:92:99:01
fc1/2              101     0xa20501     20:00:00:25:b5:8a:a0:03 20:00:00:25:b5:7a:00:01
                    [flex2-hba2]
fc1/2              101     0xa20503     20:00:00:25:b5:8a:a0:02 20:00:00:25:b5:7a:00:01
                    [flex2-hba0]
fc1/3              101     0xa20600     20:03:00:de:fb:92:99:00 20:65:00:de:fb:92:99:01
fc1/3              101     0xa20601     20:00:00:25:b5:8a:a0:06 20:00:00:25:b5:7a:00:03
                    [flex4-hba0]
fc1/3              101     0xa20602     20:00:00:25:b5:8a:a0:07 20:00:00:25:b5:7a:00:03
                    [flex4-hba2]
fc1/4              101     0xa20700     20:04:00:de:fb:92:99:00 20:65:00:de:fb:92:99:01
fc1/4              101     0xa20701     20:00:00:25:b5:8a:a0:05 20:00:00:25:b5:7a:00:02
                    [flex3-hba2]
fc1/4              101     0xa20702     20:00:00:25:b5:8a:a0:04 20:00:00:25:b5:7a:00:02
                    [flex3-hba0]
fc1/9              101     0xa20000     50:0a:09:81:80:12:f8:47 50:0a:09:80:80:12:f8:47
fc1/9              101     0xa20002     20:06:00:a0:98:af:7c:5b 20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-01-2A]
fc1/10             101     0xa20100     50:0a:09:83:80:12:f8:47 50:0a:09:80:80:12:f8:47
fc1/10             101     0xa20102     20:07:00:a0:98:af:7c:5b 20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-01-3A]
fc1/11             101     0xa20200     50:0a:09:81:80:12:f8:3d 50:0a:09:80:80:12:f8:3d
fc1/11             101     0xa20201     20:09:00:a0:98:af:7c:5b 20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-02-2A]
fc1/12             101     0xa20300     50:0a:09:83:80:12:f8:3d 50:0a:09:80:80:12:f8:3d
fc1/12             101     0xa20301     20:0a:00:a0:98:af:7c:5b 20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-02-3A]

Total number of flogi = 20.

```

- Log in as admin user into MDS Switch B and run the “show flogi database vsan 101” to verify all FC ports.

```

FLEXPOD-MDS-B#
FLEXPOD-MDS-B# show flogi database vsan 102
-----
INTERFACE          VSAN    FCID          PORT NAME          NODE NAME
-----
fc1/1              102     0x8e0400     20:01:00:de:fb:92:95:40  20:66:00:de:fb:92:95:41
fc1/1              102     0x8e0401     20:00:00:25:b5:8b:b0:00  20:00:00:25:b5:7a:00:00
                    [flex1-hba1]
fc1/1              102     0x8e0402     20:00:00:25:b5:8b:b0:01  20:00:00:25:b5:7a:00:00
                    [flex1-hba3]
fc1/2              102     0x8e0500     20:02:00:de:fb:92:95:40  20:66:00:de:fb:92:95:41
fc1/2              102     0x8e0501     20:00:00:25:b5:8b:b0:03  20:00:00:25:b5:7a:00:01
                    [flex2-hba3]
fc1/2              102     0x8e0502     20:00:00:25:b5:8b:b0:02  20:00:00:25:b5:7a:00:01
                    [flex2-hba1]
fc1/3              102     0x8e0600     20:03:00:de:fb:92:95:40  20:66:00:de:fb:92:95:41
fc1/3              102     0x8e0601     20:00:00:25:b5:8b:b0:06  20:00:00:25:b5:7a:00:03
                    [flex4-hba1]
fc1/3              102     0x8e0603     20:00:00:25:b5:8b:b0:07  20:00:00:25:b5:7a:00:03
                    [flex4-hba3]
fc1/4              102     0x8e0700     20:04:00:de:fb:92:95:40  20:66:00:de:fb:92:95:41
fc1/4              102     0x8e0701     20:00:00:25:b5:8b:b0:05  20:00:00:25:b5:7a:00:02
                    [flex3-hba3]
fc1/4              102     0x8e0702     20:00:00:25:b5:8b:b0:04  20:00:00:25:b5:7a:00:02
                    [flex3-hba1]
fc1/9              102     0x8e0000     50:0a:09:82:80:12:f8:47  50:0a:09:80:80:12:f8:47
fc1/9              102     0x8e0002     20:0c:00:a0:98:af:7c:5b  20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-01-2B]
fc1/10             102     0x8e0100     50:0a:09:84:80:12:f8:47  50:0a:09:80:80:12:f8:47
fc1/10             102     0x8e0102     20:08:00:a0:98:af:7c:5b  20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-01-3B]
fc1/11             102     0x8e0200     50:0a:09:82:80:12:f8:3d  50:0a:09:80:80:12:f8:3d
fc1/11             102     0x8e0201     20:0d:00:a0:98:af:7c:5b  20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-02-2B]
fc1/12             102     0x8e0300     50:0a:09:84:80:12:f8:3d  50:0a:09:80:80:12:f8:3d
fc1/12             102     0x8e0301     20:0b:00:a0:98:af:7c:5b  20:01:00:a0:98:af:7c:5b
                    [NetApp-A700s-02-3B]

Total number of flogi = 20.

```

Configure NetApp AFF A700s Storage

NetApp Storage Connectivity

It is beyond the scope of this document to describe all the detailed information about NetApp storage connectivity and infrastructure configuration. Follow the link below for the installation and setup instructions for the NetApp AFF A700s System:

https://library.netapp.com/ecm/ecm_download_file/ECMLP2619982

For more technical information, refer to the following Cisco site:

<https://www.cisco.com/c/en/us/solutions/design-zone/data-center-design-guides/flexpod-design-guides.html>

Please refer to the following technical reports of “Oracle Databases on ONTAP” and “Database Data Protection: Backup, Recovery, Replication, and DR” from NetApp for the best practices:

<https://www.netapp.com/us/media/tr-3633.pdf>

<https://www.netapp.com/us/media/tr-4591.pdf>

This section describes the storage layout and design considerations for the database deployment.

A NetApp ONTAP cluster serves data through at least one and possibly multiple storage virtual machines (SVMs; formerly called Vservers). An SVM is a logical abstraction that represents the set of physical resources of the cluster. Data volumes and network logical interfaces (LIFs) are created and assigned to an SVM and might reside on any node in the cluster to which the SVM has been given access. An SVM might own resources on multiple nodes concurrently, and those resources can be moved non-disruptively from one node in the storage cluster to another. For example, a NetApp FlexVol® flexible volume can be non-disruptively moved to a new node, or a data LIF can be transparently reassigned to a different physical network port. The SVM abstracts the cluster hardware, and thus it is not tied to any specific physical hardware.



The screenshot below shows the SVM and FC Interfaces configuration. For this solution, we configured one SVM as “ORA12C_SVM.”

The screenshot displays the OnCommand System Manager interface for the SVM 'ORA12C_SVM'. The 'FC/FCoE' section is expanded, showing the following table of interfaces:

Network Interface	WWPN	Current Port	Status
node1_lif02a	20:06:00:a0:98:af:7c:5b	FlexPod-a700s-01:2a	Enabled
node1_lif02b	20:0c:00:a0:98:af:7c:5b	FlexPod-a700s-01:2b	Enabled
node1_lif03a	20:07:00:a0:98:af:7c:5b	FlexPod-a700s-01:3a	Enabled
node1_lif03b	20:08:00:a0:98:af:7c:5b	FlexPod-a700s-01:3b	Enabled
node2_lif02a	20:09:00:a0:98:af:7c:5b	FlexPod-a700s-02:2a	Enabled
node2_lif02b	20:0d:00:a0:98:af:7c:5b	FlexPod-a700s-02:2b	Enabled
node2_lif03a	20:0a:00:a0:98:af:7c:5b	FlexPod-a700s-02:3a	Enabled
node2_lif03b	20:0b:00:a0:98:af:7c:5b	FlexPod-a700s-02:3b	Enabled

As shown above, for both the storage controller nodes (FlexPod-a700s-01 and FlexPod-a700s-02), we used ports 2a, 2b and 3a, 3b to configure LIFs. WWPN of these LIFs are used for zoning into the MDS switches for storage to MDS connectivity. The screenshot below shows the network interface configuration for this solution.

The screenshot shows the 'Network Interfaces' section in OnCommand System Manager. The table lists various network interfaces across different nodes and their roles.

Interface Name	Storage Virtual Machi...	IP Address/WWPN	Current Port	Is Home Port	Data Protocol Access	Management Access	Subnet	Role
node1_lif02a	ORA12C_SVM	20:06:00:a0:98:af:7c:5b	FlexPod-a700s-01:2a	Yes	fcpl	No	-NA-	Data
node1_lif02b	ORA12C_SVM	20:0c:00:a0:98:af:7c:5b	FlexPod-a700s-01:2b	Yes	fcpl	No	-NA-	Data
node1_lif03a	ORA12C_SVM	20:07:00:a0:98:af:7c:5b	FlexPod-a700s-01:3a	Yes	fcpl	No	-NA-	Data
node1_lif03b	ORA12C_SVM	20:08:00:a0:98:af:7c:5b	FlexPod-a700s-01:3b	Yes	fcpl	No	-NA-	Data
node2_lif02a	ORA12C_SVM	20:09:00:a0:98:af:7c:5b	FlexPod-a700s-02:2a	Yes	fcpl	No	-NA-	Data
node2_lif02b	ORA12C_SVM	20:0d:00:a0:98:af:7c:5b	FlexPod-a700s-02:2b	Yes	fcpl	No	-NA-	Data
node2_lif03a	ORA12C_SVM	20:0a:00:a0:98:af:7c:5b	FlexPod-a700s-02:3a	Yes	fcpl	No	-NA-	Data
node2_lif03b	ORA12C_SVM	20:0b:00:a0:98:af:7c:5b	FlexPod-a700s-02:3b	Yes	fcpl	No	-NA-	Data
FlexPod-a700s-01_clus1	Cluster	169.254.22.180	FlexPod-a700s-01:e0a	Yes	none	No	-NA-	Cluster
FlexPod-a700s-01_clus2	Cluster	169.254.81.21	FlexPod-a700s-01:e0f	Yes	none	No	-NA-	Cluster
FlexPod-a700s-02_clus1	Cluster	169.254.213.16	FlexPod-a700s-02:e0a	Yes	none	No	-NA-	Cluster
FlexPod-a700s-02_clus2	Cluster	169.254.132.211	FlexPod-a700s-02:e0f	Yes	none	No	-NA-	Cluster
FlexPod-a700s-01_mgmt1	FlexPod-a700s	10.29.135.107	FlexPod-a700s-01:e0M	Yes	none	Yes	-NA-	Node Management
FlexPod-a700s-02_mgmt1	FlexPod-a700s	10.29.135.108	FlexPod-a700s-02:e0M	Yes	none	Yes	-NA-	Node Management
cluster_mgmt	FlexPod-a700s	10.29.135.115	FlexPod-a700s-01:e0M	Yes	none	Yes	-NA-	Cluster Management
ORA12C_SVM_admin_lif1	ORA12C_SVM	10.29.135.14	FlexPod-a700s-01:e0M	Yes	none	Yes	-NA-	Data

For all the database deployment, we configured two aggregates (one aggregate on each storage node) into a single SVM (ORA12C_SVM) and each aggregate contains 35 SSD (960GB Each) drives that were subdivided into RAID DP groups, plus one spare drive as shown below.

The screenshot shows the 'Aggregates' section in OnCommand System Manager. The table lists storage aggregates and their associated nodes and space usage.

Status	Name	Node	Used (%)	Available Space	Used Space	Total Space	FabricPool	External Capa...	Volu...	Disk C...
+	aggr0	FlexPod-a700s-01	95	48.1 GB	944.55 GB	992.65 GB	No	-NA-	1	22
+	aggr0_FlexPod_a700s_02_0	FlexPod-a700s-02	95	48.1 GB	944.56 GB	992.65 GB	No	-NA-	1	22
+	aggr1_node1	FlexPod-a700s-01	58	9.81 TB	13.42 TB	23.23 TB	No	-NA-	69	35
+	aggr1_node2	FlexPod-a700s-02	58	9.71 TB	13.52 TB	23.23 TB	No	-NA-	71	35

For each RAC database deployment, we distributed equal number of volumes and LUNs on both the storage node by placing those volumes and LUNs into both the aggregate.

Operating System and Database Deployment

The design goal of the reference architecture was to best represent a real-world environment as closely as possible. The approach included features of Cisco UCS to rapidly deploy stateless servers and use NetApp AFF Storage A700s boot LUNs to provision the O.S on top it. Zoning was performed on the Cisco MDS 9148S switches to enable the initiators discover the targets during boot process.

A Service Profile was created within Cisco UCS Manager to deploy the 4 servers quickly with a standard configuration. SAN boot volumes for these servers were hosted on the NetApp AFF Storage A700s Cluster. Once the stateless servers were provisioned, following process was performed to enable Rapid deployment of 4 RAC nodes.


Each Server node has dedicated single LUN to install operating system and all the four server node was booted off SAN. For this solution, we have installed Oracle Linux 7.5(4.1.12-124.16.4.el7uek.x86_64) on this LUNs and performed all the pre-requisite packages for Oracle Database 12cR2 to create four node Oracle RAC database solution.

Operating System Configuration



Step-by-step OS install details are not detailed in this document, but the following section describes the key steps for OS install.


1. Download Oracle Linux 7.5 OS image from <https://edelivery.oracle.com/linux>.
2. Launch KVM console on desired server by going to tab Equipment > Chassis > Chassis 1 > Servers > Server 1 > from right side windows General > and select KVM Console to open KVM.



3. Click Accept security and open KVM. Enable virtual media, map the Oracle Linux ISO image and reset the server.



- When the Server starts booting, it will detect the NetApp Storage active FC paths as shown below. If you see the following message in the KVM console while the server is rebooting along with the target WWPNs, it confirms the setup is done correctly and boot from SAN will be successful.



- During server boot order, it will detect the virtual media connected as Oracle Linux cd. It should launch the Oracle Linux installer. Select language and assign the Installation destination as NetApp Storage LUN. Apply hostname and click "Configure Network" to configure all network interfaces. Alternatively, you can only configure "Public Network" in this step. You can configure additional interfaces as part of post install steps.



As a part of additional RPM package, we recommend to select "Customize Now" and configure "UEK kernel Repo."

- After the OS install, reboot the server, complete appropriate registration steps. You can choose to synchronize the time with NTP server. Alternatively, you can choose to use Oracle RAC cluster synchronization daemon (OCSSD). Both NTP and OCSSD are mutually exclusive and OCSSD will be setup during GRID install if NTP is not configured.

Operating System Prerequisites for Oracle Software Installation

Configure BIOS

This section describes how to optimize the BIOS settings to meet requirements for the best performance and energy efficiency for the Cisco UCS M5 generation of blade servers.

Configure BIOS for OLTP Workloads

OLTP systems are often decentralized to avoid single points of failure. Spreading the work over multiple servers can also support greater transaction processing volume and reduce response time. Make sure to disable Intel IDLE driver in the OS configuration section. When Intel idle driver is disabled, the OS uses acpi_idle driver to control the c-states.



For latency sensitive workloads, it is recommended to always disable c-states in both OS and BIOS to ensure c-states are disabled.

The following options are recommended for optimizing OLTP workloads on Cisco UCS M5 platforms managed by Cisco UCS Manager.

The screenshot shows the Cisco UCS Manager interface with the following BIOS settings highlighted:

BIOS Setting	Value
Sub NUMA Clustering	Platform Default
Local X2 Apic	Platform Default
Max Variable MTRR Setting	Platform Default
P STATE Coordination	Platform Default
Package C State Limit	C0 C1 State
Autonomous Core C-state	Platform Default
Processor C State	Disabled
Processor C1E	Disabled
Processor C3 Report	Disabled
Processor C6 Report	Disabled
Processor C7 Report	Disabled
Processor CMC0	Platform Default
Power Technology	Custom
Energy Performance	Platform Default
ProcessorEppProfile	Platform Default
Adjacent Cache Line Prefetcher	Platform Default
DCU IP Prefetcher	Platform Default
DCU Streamer Prefetch	Platform Default
Hardware Prefetcher	Platform Default
UPI Prefetch	Platform Default
LLC Prefetch	Platform Default
XPT Prefetch	Platform Default
Demand Scrub	Platform Default
Patrol Scrub	Platform Default
Workload Configuration	IO Sensitive

For more information about BIOS settings, refer to:

https://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-b-series-blade-servers/whitepaper_c11-740098.pdf

If the CPU gets into a deeper C-state and not able to get out to deliver full performance quickly. The result is unwanted latency spikes for workloads. To address this, it is recommended to disable C states in the BIOS and in addition, Oracle recommends disabling it from OS level as well by modifying grub entries. For this solution, we have configured BIOS options by modifying in /etc/default/grub file as shown below:

```
[root@flex1 ~]# cat /etc/default/grub

GRUB_TIMEOUT=5

GRUB_DISTRIBUTOR="$(sed 's, release .*$,,g' /etc/system-release)"

GRUB_DEFAULT=saved

GRUB_DISABLE_SUBMENU=true

GRUB_TERMINAL_OUTPUT="console"

GRUB_CMDLINE_LINUX="crashkernel=auto rd.lvm.lv=ol/root rd.lvm.lv=ol/swap rhgb quiet
numa=off transparent_hugepage=never biosdevname=0 net.ifnames=0
intel_idle.max_cstate=0 processor.max_cstate=0 rdloaddriver=scsi_dh_alua"

GRUB_DISABLE_RECOVERY="true"
```

Prerequisites Automatic Installation

After installing Oracle Linux 7.5(4.1.12-124.16.4.el7uek.x86_64) on all the server nodes (flex1, flex2, flex3 and flex4), you have to configure operating system pre-requisites on all the four nodes to successfully install Oracle RAC Database 12cR2.

To configure operating system pre-requisite for Oracle 12cR2 software on all four nodes, follow these steps:



Follow the steps according to your environment and requirements. Refer to the Install and Upgrade Guide for Linux for Oracle Database 12c R2: <https://docs.oracle.com/en/database/oracle/oracle-database/12.2/cwlin/configuring-operating-systems-for-oracle-grid-infrastructure-on-linux.html#GUID-B8649F42-4918-49FA-A608-446F864FB7A0>.

To configure the prerequisites on all the four nodes, follow these steps:



You can perform either the Automatic Setup or the Manual Setup to complete the basic prerequisites. The Additional Setup is required for all installations.

For this solution, we have configured the prerequisites automatically by installing the "oracle-database-server-12cR2-preinstall" rpm package. You can also download the required packages from <http://public-yum.oracle.com/oracle-linux-7.html>. If you plan to use the "oracle-database-server-12cR2-preinstall" rpm package to perform all your prerequisite setup automatically, then log in as root user and issue the following command:

```
[root@flex1 ~]# yum install oracle-database-server-12cR2-preinstall
```



If you have not used the "oracle-database-server-12cR2-preinstall" package, then you will have to manually perform the prerequisites tasks on all the nodes.

Additional Prerequisites Setup

After configuring automatic or manual prerequisites steps, you have to configure a few additional steps to complete the prerequisites for the Oracle database software installations on all the four nodes as described in the following sections.

Disable SELinux

Since most Organizations might be running hardware-based firewalls to protect their corporate networks, we disabled Security Enhanced Linux (SELinux) and the firewalls at the server level for this reference architecture.

You can set secure Linux to permissive by editing the `"/etc/selinux/config"` file, making sure the SELINUX flag is set as follows.

```
SELINUX= permissive
```

Disable Firewall

Check the status of the firewall by running following commands. (The status displays as active (running) or inactive (dead)). If the firewall is active / running, enter this command below to stop it.

```
systemctl status firewalld.service
```

```
systemctl stop firewalld.service
```

Also, to completely disable the firewalld service, so it does not reload when you restart the host machine, run the following command:

```
systemctl disable firewalld.service
```

Set the User Passwords

Run the following commands to change the password for Oracle and Grid Users:

```
passwd oracle
```

```
passwd grid
```

Configure Multipath Setup



For DM-Multipath Configuration and best practice, refer to the NetApp Support <https://library.netapp.com/ecmdocs/ECMP1217221/html/GUID-34FA2578-0A83-4ED3-B4B3-8401703D65A6.html>



Follow the steps below on all the four oracle RAC nodes.

You can configure DM-Multipath for use in multipathing in environments that use native Linux solutions. With DM-Multipath, you can configure multiple I/O paths between a host and storage controllers into a single device. If one path fails, DM-Multipath reroutes I/Os to the remaining paths. Configure multipaths to access the LUNs presented from NetApp Storage to the nodes as shown below.

Add or modify `"/etc/multipath.conf"` file accordingly to give the alias name of each LUN id presented from NetApp Storage as given below into all eight nodes:

Run "multipath -ll" command to view all the LUN id:

```
[root@oraracx1 ~]# cat /etc/multipath.conf
defaults {
    find_multipaths yes
    user_friendly_names no
}
multipaths {
    multipath {
        wwid          3600a098038304173475d4c766a49744e
        alias         node1_os
    }
    multipath {
        wwid          3600a098038304173475d4c766a49754a
        alias         ocrvote_1
    }
}
}
```



Make sure the LUNs wwid address reflects the correct value for all four nodes in "/etc/multipath.conf"



We made sure the multipathing packages were installed and enabled for automatic restart across reboots. We will add more LUNs and associated wwid into "/etc/multipath.conf" file later on as we add more LUNs for Databases.

Configure UDEV Rules

You need to configure UDEV rules to assign permission in all the Oracle RAC nodes to access NetApp Storage LUNs. This includes the device details along with required permissions to enable grid and oracle user to have read/write privileges on these devices. Configure UDEV rules on all the Oracle Nodes as shown below:

Create a new file named "/etc/udev/rules.d/99-oracleasm.rules" with the following entries on all nodes:

```
[root@flex1 ~]# cat /etc/udev/rules.d/99-oracle-asmdevices.rules
#All LUNs which starts with dg_orarac_* #
ENV{DM_NAME}=="ocrvote_*", OWNER:="grid", GROUP:="oinstall", MODE:="660"
#All LUNs which starts with dg_oradata_* #
ENV{DM_NAME}=="oradata_*", OWNER:="oracle", GROUP:="oinstall", MODE:="660"
```

```
#All LUNs which starts with dg_oraredo_* #
ENV{DM_NAME}=="oraredo_*", OWNER=="oracle", GROUP=="oinstall", MODE=="660"
#All LUNs which starts with dg_oraarchive_* #
ENV{DM_NAME}=="oraarchive_*", OWNER=="oracle", GROUP=="oinstall", MODE=="660"
```



IMPORTANT: The `"/etc/multipath.conf"` for the Oracle ASM devices and udev rules for these devices should be copied on to all the RAC nodes and verified to make sure the devices are visible and permissions are enabled for grid user on all the nodes

Configure Public and Private NICs on Each RAC Node

If you have not configured network settings during OS installation, then configure it now. Each node must have at least two network interface cards (NICs), or network adapters. One adapter is for the public network traffic and the other adapter is for the private network traffic (the node interconnects).

Log in as a root user on each node and go to `"/etc/sysconfig/network-scripts"` and configure Public network and Private network IP Address. Configure the private and public NICs with the appropriate IP addresses across all the Oracle RAC nodes.

Configure `"/etc/hosts"` on Each RAC Node

Log in as a root user into node and edit `"/etc/hosts"` file. Provide the details for Public IP Address, Private IP Address, SCAN IP Address and Virtual IP Address for all nodes. Configure these settings on each Oracle RAC Nodes as shown below:

```
[root@flex1 ~]# cat /etc/hosts
127.0.0.1    localhost localhost.localdomain localhost4 localhost4.localdomain4

##### Public IP #####
10.29.135.121 flex1.cisco.com flex1
10.29.135.122 flex2.cisco.com flex2
10.29.135.123 flex3.cisco.com flex3
10.29.135.124 flex4.cisco.com flex4

##### Virtual IP #####
10.29.135.125 flex1-vip      flex1-vip.cisco.com
10.29.135.126 flex2-vip      flex2-vip.cisco.com
10.29.135.127 flex3-vip      flex3-vip.cisco.com
10.29.135.128 flex4-vip      flex4-vip.cisco.com

##### Private IP #####
10.10.10.121 flex1-priv      flex1-priv.cisco.com
10.10.10.122 flex2-priv      flex2-priv.cisco.com
```

```

10.10.10.123 flex3-priv flex3-priv.cisco.com
10.10.10.124 flex4-priv flex4-priv.cisco.com
#SCAN IP
10.29.135.129 flex-cluster flex-cluster.cisco.com
10.29.135.130 flex-cluster flex-cluster.cisco.com
10.29.135.131 flex-cluster flex-cluster.cisco.com

```



You must configure the following addresses manually in your corporate setup.

- A Public IP Address for each node
- A Virtual IP address for each node
- Three single client access name (SCAN) address for the oracle database cluster

These steps complete the prerequisite for Oracle Database 12cR2 Installation at OS level on Oracle RAC Nodes.



For this Solution, we used 4 identical Cisco UCS B-Series B200 M5 blade servers for hosting the four node Oracle RAC databases. All of the steps described above were also performed on all the four nodes to create 4 node Oracle RAC solution.



NetApp Host Utilities Kit: Please refer to this link for the best practice component for all host operating systems connected to NetApp storage via SAN protocols according to your environment: <https://mysupport.netapp.com//documentation/productlibrary/index.html?productID=61343>



Customers should download and install the host utilities kit to provide data collection tools used for NetApp support. However for this solution deployment, we did not use host utility tool kit.

When the O.S level prerequisites are completed, you are ready to install the Oracle Grid Infrastructure as a grid user. Download Oracle Database 12c Release 2 (12.2.0.1.0) for Linux x86-64 and Oracle Database 12c Release 2 Grid Infrastructure (12.2.0.1.0) for Linux x86-64 software from Oracle Software site. Copy these software binaries to Oracle RAC Node 1 and unzip all files into appropriate directories.

Oracle Database 12c GRID Infrastructure Deployment

For this Oracle Database FlexPod solution, you will install the Oracle Grid and Database software on all four nodes (flex1, flex2, flex3 and flex4). The installation guides you through the gathering of all node information and configuring the ASM devices and all the prerequisite validations for GI.



It is not within the scope of this document to include the specifics of an Oracle RAC installation; you should refer to the Oracle installation documentation for specific installation instructions for your environment. We will provide a partial summary of details that might be relevant.

This section describes the high-level steps for Oracle Database 12c R2 RAC install. Prior to GRID and database install, verify all the prerequisites are completed. As an alternative, you can install Oracle validated RPM that will make sure all prerequisites are meet before Oracle grid install.

For the Oracle Database 12c Release 2 install and upgrade guide, click this link:

<https://docs.oracle.com/en/database/oracle/oracle-database/12.2/install-and-upgrade.html>

Create Directory Structure



The directory structure should be created on all RAC nodes but unzipping grid software happens on the first node only.



You must extract the zip image software into the directory where you want your Grid home to be located. Also, download and copy the Oracle Grid Infrastructure image files to the local node only. During installation, the software is copied and installed on the other nodes in the cluster.

1. Log in as a root user and create the following directory structure.

```
mkdir -p /u01/app/grid
mkdir -p /u01/app/12.2.0/grid
mkdir -p /u01/app/oracle/product/12.2.0/dbhome_1
```

```
chown -R grid:oinstall /u01/app/grid/
chown -R grid:oinstall /u01/app/12.2.0/grid/
chown -R oracle:oinstall /u01/app/oracle/
```

2. Log in as a grid user, download the Oracle Grid Infrastructure image files and unzip the files into the Grid home:

```
cd /u01/app/12.2.0/grid
unzip -q download_location/linuxx64_12201_grid_home
```

Run Cluster Verification Utility

This step verifies that all the prerequisites are meet to install Oracle Grid Infrastructure Software. Oracle Grid Infrastructure ships with the Cluster Verification Utility (CVU) that can run to validate pre and post installation configurations. To run this utility, log in as Grid User in Oracle RAC Node 1 and go to the directory where oracle grid software binaries are located. Run script named as “runcluvfy.sh” as follows:

```
./runcluvfy.sh stage -pre crsinst -n flex1,flex2,flex3,flex4 -verbose
```

Configure HugePages

HugePages is a method to have a larger page size that is useful for working with a very large memory. For Oracle Databases, using HugePages reduces the operating system maintenance of page states and increases Translation Lookaside Buffer (TLB) hit ratio.

Advantages of HugePages:

- HugePages are not swappable so there is no page-in/page-out mechanism overhead.
- HugePages uses fewer pages to cover the physical address space, so the size of "book keeping"(mapping from the virtual to the physical address) decreases, so it requiring fewer entries in the TLB and so TLB hit ratio improves.
- HugePages reduces page table overhead. Also, HugePages eliminated page table lookup overhead: Since the pages are not subject to replacement, page table lookups are not required.
- Faster overall memory performance: On virtual memory systems each memory operation is actually two abstract memory operations. Since there are fewer pages to work on, the possible bottleneck on page table access is clearly avoided.



For our configuration, we used HugePages for all the OLTP and DSS workloads.

Please refer to the Oracle support for HugePages configuration details:

<https://docs.oracle.com/en/database/oracle/oracle-database/12.2/unxar/administering-oracle-database-on-linux.html#GUID-CC72CFDC-58AA-4065-AC7D-FD4735E14416>

Install and Configure Oracle Database Grid Infrastructure Software



It is not within the scope of this document to include the specifics of an Oracle RAC installation. However, we will provide partial summary of details that might be relevant. Please refer to the Oracle installation documentation for specific installation instructions for your environment.




For this solution, we installed Oracle binaries on the boot LUN of the nodes. The OCR and Voting Disk files resides in the Oracle ASM disk group created from CRS LUNs.

To install Oracle Database Grid Infrastructure Software, follow these steps:

1. Go to grid home where the Oracle 12c R2 Grid Infrastructure software binaries are located and launch the installer as the "grid" user.
2. Start the Oracle Grid Infrastructure installer by running the following command:


```
./gridSetup.sh
```
3. Select option "Configure Oracle Grid Infrastructure for a New Cluster" as shown below, then click Next.




4. Select cluster configuration options “Configure an Oracle Standalone Cluster”, then click Next.
5. In next window, enter the Cluster Name and SCAN Name fields.




Enter the names for your cluster and cluster scan that are unique throughout your entire enterprise network. You can select Configure GNS if you have configured your domain name server (DNS) to send to the GNS virtual IP address name resolution requests


6. In Cluster node information window, click the "Add" button to add all four nodes Public Hostname and Virtual Hostname as shown below:




7. As shown above, you will see all nodes listed in the table of cluster nodes. Make sure the Role column is set to HUB for all four nodes. Click the SSH Connectivity button at the bottom of the window. Enter the operating system user name and password for the Oracle software owner (grid). Click Setup.
8. A message window appears, indicating that it might take several minutes to configure SSH connectivity between the nodes. After sometime, another message window appears indicating that password-less SSH connectivity has been established between the cluster nodes. Click OK to continue.



- In Network Interface Usage screen, select the usage type for each network interface displayed as shown below:



10. Select the Oracle ASM storage configuration option as “Configure ASM using block devices.” Click Next and Choose “No” option into separate ASM disk group for the Grid Infrastructure Management Repository data, and then click Next.
11. In the Create ASM Disk Group window, select the OCRVOTE LUNs assigned from NetApp Storage to store OCR and Voting disk files. Enter the name of disk group as OCRVOTE and select appropriate redundancy options as show below.



For maximum resiliency, we recommend that the cluster control ASM disk group redundancy be configured with a redundancy level of “High” rather than “External” (<https://docs.oracle.com/en/database/oracle/oracle-database/12.2/cwlin/oracle-clusterware-storage-space-requirements.html#GUID-97FD5D40-A65B-4575-AD12-06C491AF3F41>), preferably with the copies distributed across both controllers. This will increase the resiliency of the cluster in case there is interrupted access to the volume, aggregate, or controller hosting the cluster control ASM disk group (in the case of a volume running out of space, for example). However, for this solution, we configured redundancy as “External.”

- Choose the password for the Oracle ASM SYS and ASMSNMP account, then click Next.
- Select the option “Do not use Intelligent Platform Management Interface (IPMI)”, then click Next. You can configure to have this instance of Oracle Grid Infrastructure and Oracle Automatic Storage Management to be managed by Enterprise Manager Cloud Control. Specify the details of the Cloud Control configuration to perform and click Next.



You can choose to set it up according to your requirements.

14. Select the appropriate operating system group names for Oracle ASM according to your environments.
15. Specify the directory to use for the Oracle base for the Oracle Grid Infrastructure installation and then click Next. The Oracle base directory must be different from the Oracle home directory. Click Next and choose Inventory Directory according to your setup.



If you copied the Oracle Grid Infrastructure installation files into the Oracle Grid home directory as instructed above, then the default location for the Oracle base directory should display as `/u01/app/grid`.

16. Click Automatically run configuration scripts to run scripts automatically and enter the relevant root user credentials. Click Next.
17. Wait while the prerequisite checks complete. If you have any issues, use the "Fix & Check Again" button.



If any of the checks have a status of Failed and are not fixable, then you must manually correct these issues. After you have fixed the issue, you can click the Check Again button to have the installer recheck the requirement and update the status. Repeat as needed until all the checks have a status of Succeeded. Click Next.

Oracle Grid Infrastructure 12c Release 2 Installer - Step 16 of 19@flex1

Perform Prerequisite Checks

ORACLE GRID INFRASTRUCTURE 12c

Configuration Option
 Cluster Configuration
 Grid Plug and Play
 Cluster Node Information
 Network Interface Usage
 Storage Option
 Grid Infrastructure Managem
 Create ASM Disk Group
ASM Password
 Failure Isolation
 Management Options
 Operating System Groups
 Installation Location
 Create Inventory
 Root script execution
Prerequisite Checks
 Summary
 Install Product
 Finish

Verification Result Fixup Result

Some of the minimum requirements for installation are not completed. Review and fix the issues listed in the following table, and recheck the system.


Check A... Fix & Check Again Show All All Nodes Ignore A

Checks	Status	Fixable
Checks		
Physical Memory	Succeeded	
Available Physical Memory	Succeeded	
Swap Size	Succeeded	
Free Space		
Free Space: flex4:/usr,flex4:/var,flex4:/etc,flex4:/u01/app/1:	Succeeded	
Free Space: flex3:/usr,flex3:/var,flex3:/etc,flex3:/u01/app/1:	Succeeded	
Free Space: flex2:/usr,flex2:/var,flex2:/etc,flex2:/u01/app/1:	Succeeded	
Free Space: flex1:/usr,flex1:/var,flex1:/etc,flex1:/u01/app/1:	Succeeded	
User Existence		
User Existence: grid		
Users With Same UID: 54322	Succeeded	
Group Existence		
Group Existence: dba	Succeeded	
Group Existence: oinstall	Succeeded	
Group Membership		
Group Membership: dba	Succeeded	

Help < Back Next > Install Cancel

18. Review the contents of the Summary window and then click Install. The installer displays a progress indicator enabling you to monitor the installation process.

19. Wait for the grid installer configuration assistants to complete.



20. When the configuration complete successfully, click Close to finish and exit the grid installer.

21. When GRID install is successful, login to each of the nodes and perform minimum health checks to make sure that Cluster state is healthy. After your Oracle Grid Infrastructure installation is complete, you can install Oracle Database on a cluster node for high availability, or install Oracle RAC.

Install Oracle Database Software




After a successful GRID install, we recommend to install Oracle Database 12c software only. You can create databases using DBCA or database creation scripts at later stage.




It is not within the scope of this document to include the specifics of an Oracle RAC database installation. However, we provide a partial summary of details that might be relevant. Please refer to the Oracle database installation documentation for specific installation instructions for your environment.

To install Oracle Database Software, follow these steps:


1. Start the runInstaller command from the Oracle Database 12c Release 2 (12.2) installation media where Oracle database software is located.
2. Select option "Install database software only" into Select Installation Option.



3. Select option "Oracle Real Application Clusters database installation" and click Next.
4. Select nodes in the cluster where installer should install Oracle RAC. For this setup, you will install software on all nodes as shown below.




5. Click the "SSH Connectivity..." button and enter the password for the "oracle" user. Click the "Setup" button to configure passwordless SSH connectivity, and the "Test" button to test it when it is complete. When the test is complete, click Next.
6. Select Database Edition Options according to your environments and then click Next.
7. Enter Oracle Base as "/u01/app/oracle" and "/u01/app/oracle/product/12.2.0/dbhome_1" as the software location, then click Next.
8. Select the desired operating system groups and then click Next.
9. Wait for the prerequisite check to complete. If there are, any problems either click the "Fix & Check Again" button or try to fix those by checking and manually installing required packages. Click Next.



10. Verify the Oracle Database summary information, click Install.


11. When prompted, run the configuration script on each node. When the scripts run successfully on each node then click OK.



12. After the installation of Oracle Database finish successful, click Close to exit of the installer.

Oracle Flex ASM

Oracle Flex ASM enables an Oracle ASM instance to run on a separate physical server from the database servers. With this deployment, larger clusters of Oracle ASM instances can support more database clients while reducing the Oracle ASM footprint for the overall system.



When using Oracle Flex ASM, Oracle ASM clients are configured with direct access to storage. With Oracle Flex ASM, you can consolidate all the storage requirements into a single set of disk groups. All these disk groups are mounted by and managed by a small set of Oracle ASM instances running in a single cluster. You can specify the number of Oracle ASM instances with a cardinality setting. The default is three instances.

Prior to Oracle 12c, if ASM instance on one of the RAC nodes crashes, all the instances running on that node will crash too. This issue has been addressed in Flex ASM; Flex ASM can be used even if all the nodes are hub nodes. However, GNS configuration is mandatory for enabling Flex ASM. We can check what instances are connected with a simple query as shown below.

```
SQL> select INST_ID, GROUP_NUMBER, INSTANCE_NAME, DB_NAME, INSTANCE_NAME||':'||DB_NAME client_id, STATUS from gv$asm_client;
```

INST_ID	GROUP_NUMBER	INSTANCE_NAME	DB_NAME	CLIENT_ID	STATUS
1	14	+ASM1	+ASM	+ASM1:+ASM	CONNECTED
1	14	-MGMTDB	_mgmtdb	-MGMTDB:_mgmtdb	CONNECTED
1	14	flex1.cisco.com	_OCR	flex1.cisco.com:_OCR	CONNECTED
2	14	+ASM2	+ASM	+ASM2:+ASM	CONNECTED
2	14	flex2.cisco.com	_OCR	flex2.cisco.com:_OCR	CONNECTED
4	14	+ASM4	+ASM	+ASM4:+ASM	CONNECTED
4	14	flex3.cisco.com	_OCR	flex3.cisco.com:_OCR	CONNECTED
4	14	flex4.cisco.com	_OCR	flex4.cisco.com:_OCR	CONNECTED

8 rows selected.

As you can see from the above query, instance 1 (flex1), instance 2 (flex2) and instance 4 (flex4) are connected to +ASM. Also, the screenshot below shows a few more commands to check the cluster and FLEX ASM details.

```

[grid@flex1 ~]$ ps -ef | grep pmon
grid      35795      1  0 13:48 ?          00:00:00 asm_pmon_+ASM1
grid      40278      1  0 13:49 ?          00:00:00 mdb_pmon_-MGMTDB
grid      174061 117814    0 14:13 pts/1    00:00:00 grep  --color=auto pmon
[grid@flex1 ~]$
[grid@flex1 ~]$ crsctl check cluster
CRS-4537: Cluster Ready Services is online
CRS-4529: Cluster Synchronization Services is online
CRS-4533: Event Manager is online
[grid@flex1 ~]$
[grid@flex1 ~]$ srvctl status asm -detail
ASM is running on flex4,flex2,flex1
ASM is enabled.
ASM instance +ASM1 is running on node flex1
Number of connected clients: 2
Client names: -MGMTDB:_mgmtdb:flex-cluster flex1.cisco.com:_OCR:flex-cluster
ASM instance +ASM2 is running on node flex2
Number of connected clients: 1
Client names: flex2.cisco.com:_OCR:flex-cluster
ASM instance +ASM4 is running on node flex4
Number of connected clients: 2
Client names: flex3.cisco.com:_OCR:flex-cluster flex4.cisco.com:_OCR:flex-cluster
[grid@flex1 ~]$
[grid@flex1 ~]$ srvctl config asm -detail
ASM home: <CRS home>
Password file: +OCRVOTE/orapwASM
Backup of Password file:
ASM listener: LISTENER
ASM is enabled.
ASM is individually enabled on nodes:
ASM is individually disabled on nodes:
ASM instance count: 3
Cluster ASM listener: ASMNET1LSNR_ASM
[grid@flex1 ~]$ asmcmd
ASMCMD> showclustermode
ASM cluster : Flex mode enabled
ASMCMD> showclusterstate
Normal

```

Scalability Test and Results

Before configuring a database for workload tests, it is extremely important to validate that this is indeed a balanced configuration that is capable of delivering expected performance. In this solution, you will test and validate node and user scalability on all 4 node Oracle RAC Databases with various database benchmarking tools as explained below.


Hardware Calibration Test using FIO

FIO is short for Flexible IO, a versatile IO workload generator. FIO is a tool that will spawn a number of threads or processes doing a particular type of I/O action as specified by the user. For our solution, we use FIO to measure the performance of a NetApp storage device over a given period of time. For the FIO Tests, we created 16 volumes and each volume has one LUN. These 16 LUNs were shared across all the four nodes for read/write IO operations.

We run various FIO tests for measuring IOPS, Latency and Throughput performance of this solution by changing block size parameter into the FIO test. For each FIO test, we also changed read/write ratio as 0/100 percent read/write, 50/50 percent read/write, 70/30 percent read/write, 90/10 percent read/write and 100/0 percent read/write to scale the performance of the system. We also ran the tests for at least 4 hours to help ensure that this configuration is capable of sustaining this type of load for longer period of time.

4k and 8k Random Read/Write IOPs Tests


The following chart shows results for the random read/write FIO test for the 4k block size.



For the 100/0 percent read/write test, we achieved about 860k IOPS with the read latency about 1.1 millisecond. Similarly, for the 90/10 percent read/write test, we achieved about 778k IOPS with the read latency about 1.1 millisecond and the write latency about 1.7 millisecond. For the 70/30 percent read/write test, we achieved 732k IOPS with the read latency about 1 millisecond and the write latency about 1.9 millisecond. For the 50/50 percent

read/write test, we achieved about 592k IOPS with the read latency about 0.4 millisecond and the write latency about 2.8 millisecond. For the 0/100 percent read/write test, we achieved 180k IOPS with the write latency about 5.3 millisecond.


The chart below shows results for the random read/write FIO test for the 8k block size representing OLTP type of workloads.



For the 100/0 percent read/write test, we achieved about 891k IOPS with the read latency about 0.8 millisecond. Similarly, for the 90/10 percent read/write test, we achieved about 800k IOPS with the read latency about 0.9 millisecond and the write latency about 1.3 millisecond. For the 70/30 percent read/write test, we achieved about 732k IOPS with the read latency about 0.7 millisecond and the write latency about 1.7 millisecond. For the 50/50 percent read/write test, we achieved about 496k IOPS with the read latency about 0.4 millisecond and the write latency about 2.6 millisecond. For the 0/100 percent read/write test, we achieved about 156k IOPS with the write latency about 4.9 millisecond.


Bandwidth Tests

The bandwidth tests are carried out with 512k and 1MB IO Size and represents the DSS database type workloads. The chart below shows results for the sequential read/write FIO test for the 512k block size.



For the 100/0 percent read/write test, we achieved about 11.3 GB/s throughput with the read latency about 2.9 millisecond. Similarly, for the 90/10 percent read/write test, we achieved about 11.5 GB/s throughput with the read latency about 2.8 millisecond and the write latency about 3.5 millisecond. For the 70/30 percent read/write test, we achieved about 8.3 GB/s throughput with the read latency about 2.3 millisecond and the write latency about 6.3 millisecond. For the 50/50 percent read/write test, we achieved about 7.1 GB/s throughput with the read latency about 3.1 millisecond and the write latency about 8 millisecond. For the 0/100 percent read/write test, we achieved about 4.1 GB/s throughput with the write latency about 8.1 millisecond.

The chart below shows results for the sequential read/write FIO test for the 1MB block size.



For the 100/0 percent read/write test, we achieved around 8.8 GB/s throughput with the read latency around 7.6 millisecond. Similarly, for the 90/10 percent read/write test, we achieved about 10.2 GB/s throughput with the read latency about 6.5 millisecond and the write latency about 6.7 millisecond. For the 70/30 percent read/write test, we achieved about 10.3 GB/s throughput with the read latency about 5.5 millisecond and the write latency about 8.8 millisecond. For the 50/50 percent read/write test, we achieved about 7.1 GB/s throughput with the read latency about 6.6 millisecond and the write latency about 7.1 millisecond. For the 0/100 percent read/write test, we achieved about 4.1 GB/s throughput with the write latency about 16.1 millisecond.

The slight decrease in bandwidth between the 90 percent read workload and 100 percent read workload is a result of ONTAP's extremely efficient write processing. Inbound write data is journaled into mirrored NVRAM. At this point, the write operation is complete and on durable media, and the IO is then acknowledged to the client. NVRAM is not cache, it is a journal that is only used for recovery of an interrupted write operation. The actual write operation to the SSD drives is a direct memory-to-drive transfer. The bandwidth and latency characteristics of NVRAM exceeds even that of SSD drives, so any tests with write IO will result in an increase in overall bandwidth compared to 100percent read tests where all IO must be drawn from slower Flash-based media.

We did not see any performance dips or degradation over the period of run time. It is also important to note that this is not a benchmarking exercise and the numbers presented are not the peak numbers where there is hardware resource saturation. These are practical and out of box test numbers that can be easily reproduced by any one. At this time, we are ready to create OLTP database(s) and continue with database tests.

Database Creation with DBCA

We used Oracle Database Configuration Assistant (DBCA) to create three OLTP (SLOB, SOE and OLTP) and one DSS (DSS) databases for SLOB and Swingbench test calibration. Alternatively, you can use Database creation scripts to create the databases as well.

For all the database deployment, we have configured two aggregates (one aggregate on each storage node) into a single SVM and each aggregate contains 35 SSD (960GB Each) drives that were subdivided into RAID DP groups, plus one spare drive as explained earlier in the storage configuration section.

For each RAC database, we have created total number of 18 volumes and each volume contains one LUN. We distributed equal number of volumes and LUNs on both the storage node by placing those volumes and LUNs into both the aggregates. All the databases files were also spread evenly across the 2 nodes of the storage system so that each storage node served data for the databases. The screenshot below shows the storage layout of all the volumes and LUN configuration for all the databases.

	Node: FlexPod-a700s-01					Node: FlexPod-a700s-02				
	Aggregate: aggr1_node1 (RAID Group - raid_dp, 23.23 TB)					Aggregate: aggr1_node2 (RAID Group - raid_dp, 23.23 TB)				
	Volume	Size (GB)	Lun	Size (GB)	Notes	Volume	Size (GB)	Lun	Size (GB)	Notes
ASM	crs_1	150	ocrvote_1	100	OCR & Voting Disks	crs_2	150	ocrvote_2	100	OCR & Voting Disks
SLOB Database	slobvol_1	400	oradata_slob_1	300	Data Files	slobvol_2	400	oradata_slob_2	300	Data Files
	slobvol_3	400	oradata_slob_3	300	Data Files	slobvol_4	400	oradata_slob_4	300	Data Files
	slobvol_5	400	oradata_slob_5	300	Data Files	slobvol_6	400	oradata_slob_6	300	Data Files
	slobvol_7	400	oradata_slob_7	300	Data Files	slobvol_8	400	oradata_slob_8	300	Data Files
	slobvol_9	400	oradata_slob_9	300	Data Files	slobvol_10	400	oradata_slob_10	300	Data Files
	slobvol_11	400	oradata_slob_11	300	Data Files	slobvol_12	400	oradata_slob_12	300	Data Files
	slobvol_13	400	oradata_slob_13	300	Data Files	slobvol_14	400	oradata_slob_14	300	Data Files
	slobvol_15	400	oradata_slob_15	300	Data Files	slobvol_16	400	oradata_slob_16	300	Data Files
	slobvol_17	150	oraredo_slob_1	100	Control Files + Redo Log Files	slobvol_18	150	oraredo_slob_2	100	Control Files + Redo Log Files
SOE Database	soevol_1	1000	oradata_soe_1	625	Data Files	soevol_2	1000	oradata_soe_2	625	Data Files
	soevol_3	1000	oradata_soe_3	625	Data Files	soevol_4	1000	oradata_soe_4	625	Data Files
	soevol_5	1000	oradata_soe_5	625	Data Files	soevol_6	1000	oradata_soe_6	625	Data Files
	soevol_7	1000	oradata_soe_7	625	Data Files	soevol_8	1000	oradata_soe_8	625	Data Files
	soevol_9	1000	oradata_soe_9	625	Data Files	soevol_10	1000	oradata_soe_10	625	Data Files
	soevol_11	1000	oradata_soe_11	625	Data Files	soevol_12	1000	oradata_soe_12	625	Data Files
	soevol_13	1000	oradata_soe_13	625	Data Files	soevol_14	1000	oradata_soe_14	625	Data Files
	soevol_15	1000	oradata_soe_15	625	Data Files	soevol_16	1000	oradata_soe_16	625	Data Files
	soevol_17	200	oraredo_soe_1	100	Control Files + Redo Log Files	soevol_18	200	oraredo_soe_2	100	Control Files + Redo Log Files
OLTP Database	oltpvol_1	900	oradata_oltp_1	500	Data Files	oltpvol_2	900	oradata_oltp_2	500	Data Files
	oltpvol_3	900	oradata_oltp_3	500	Data Files	oltpvol_4	900	oradata_oltp_4	500	Data Files
	oltpvol_5	900	oradata_oltp_5	500	Data Files	oltpvol_6	900	oradata_oltp_6	500	Data Files
	oltpvol_7	900	oradata_oltp_7	500	Data Files	oltpvol_8	900	oradata_oltp_8	500	Data Files
	oltpvol_9	900	oradata_oltp_9	500	Data Files	oltpvol_10	900	oradata_oltp_10	500	Data Files
	oltpvol_11	900	oradata_oltp_11	500	Data Files	oltpvol_12	900	oradata_oltp_12	500	Data Files
	oltpvol_13	900	oradata_oltp_13	500	Data Files	oltpvol_14	900	oradata_oltp_14	500	Data Files
	oltpvol_15	900	oradata_oltp_15	500	Data Files	oltpvol_16	900	oradata_oltp_16	500	Data Files
	oltpvol_17	200	oraredo_oltp_1	100	Control Files + Redo Log Files	oltpvol_18	200	oraredo_oltp_2	100	Control Files + Redo Log Files
DSS Database	dssvol_1	1500	oradata_dss_1	1000	Data Files	dssvol_2	1500	oradata_dss_2	1000	Data Files
	dssvol_3	1500	oradata_dss_3	1000	Data Files	dssvol_4	1500	oradata_dss_4	1000	Data Files
	dssvol_5	1500	oradata_dss_5	1000	Data Files	dssvol_6	1500	oradata_dss_6	1000	Data Files
	dssvol_7	1500	oradata_dss_7	1000	Data Files	dssvol_8	1500	oradata_dss_8	1000	Data Files
	dssvol_9	1500	oradata_dss_9	1000	Data Files	dssvol_10	1500	oradata_dss_10	1000	Data Files
	dssvol_11	1500	oradata_dss_11	1000	Data Files	dssvol_12	1500	oradata_dss_12	1000	Data Files
	dssvol_13	1500	oradata_dss_13	1000	Data Files	dssvol_14	1500	oradata_dss_14	1000	Data Files
	dssvol_15	1500	oradata_dss_15	1000	Data Files	dssvol_16	1500	oradata_dss_16	1000	Data Files
	dssvol_17	200	oraredo_dss_1	100	Control Files + Redo Log Files	dssvol_18	200	oraredo_dss_2	100	Control Files + Redo Log Files

As shown above, for each database, we created total 18 volumes and each volume contains one LUN. On these 18 LUNs, we created two disk groups to store the data and redolog files for the database. We used 16 LUNs to create Oracle ASM “Data” disk group and 2 LUNs to create Oracle ASM “redolog” disk group for each database.


We used a widely adopted SLOB and Swingbench database performance test tools to test and validate throughput, IOPS, and latency for various test scenarios as explained below.

SLOB Test

The Silly Little Oracle Benchmark (SLOB) is a toolkit for generating and testing I/O through an Oracle database. SLOB is very effective to test the I/O subsystem with genuine Oracle SGA-buffered physical I/O. SLOB supports testing physical random single-block reads (db file sequential read) and random single block writes (DBWR

flushing capability). SLOB issues single block reads for the read workload that are generally 8K (as the database block size was 8K).

To test the SLOB workload, we created one database as SLOB. For SLOB database, we created total 18 volumes and each volume contains one LUN. On these 18 LUNs, we created two disk groups to store the data and redolog files for the SLOB database. First disk-group “DATASLOB” was created with 16 LUNs (300 GB each) while second disk-group “REDOSLOB” was created with two LUNs (100 GB each) as shown below.



Those ASM disk groups provided the storage required to create the tablespaces for the SLOB Database. We loaded SLOB schema on “DATASLOB” disk-group of up to 3 TB in size.

We used SLOB2 to generate our OLTP workload. Each database server applied the workload to Oracle database, log, and temp files. The following tests were performed and various metrics like IOPS and latency were captured along with Oracle AWR reports for each test scenario.

User Scalability Test

SLOB2 was configured to run against all the four RAC nodes and the concurrent users were equally spread across all the nodes. We tested the environment by increasing the number of Oracle users in database from a minimum of 32 users up to a maximum of 512 users across all the four nodes. At each load point, we verified that the storage system and the server nodes could maintain steady-state behavior without failure. We also made sure that there were no bottlenecks across servers or networking systems.

We performed User Scalability test with 32, 64, 128, 192, 256 and 512 users on 4 Oracle RAC nodes by varying read/write ratio as explained below:


- Varying workloads
 - 100% read (0% update)
 - 90% read (10% update)
 - 70% read (30% update)
 - 50% read (50% update)

The following table illustrate total number of IOPS (both read and write) for user scalability test when run with 32, 64, 128, 192, 256 and 512 Users on the SLOB database.

Table 10 Total IOPS for SLOB User Scalability Tests

Users	IOPS for Read/Write % (100/0)	IOPS for Read/Write % (90/10)	IOPS for Read/Write % (70/30)	IOPS for Read/Write % (50/50)
32	186,386	188,906	209,264	220,718
64	316,731	324,739	333,120	343,007
128	461,265	452,060	456,660	469,478
192	518,950	504,624	503,086	514,103
256	541,849	532,473	529,033	532,116
512	603,039	559,831	547,240	555,170

The following graphs demonstrate total number of IOPS while running SLOB workload for various concurrent users for each test scenario.



The above graph shows the linear scalability with increased users and similar IOPS from 32 users to 512 users with 100% read, 90% read, 70% read and 50% read.

The AWR screenshot below was captured from a 100% Read (0% update) Test scenario while running SLOB test for 512 users. The snapshot shows a section from the Oracle AWR report from the run that highlights Physical Reads/Sec and Physical Writes/Sec for each instance.

```
System Statistics - Per Second          DB/Inst: SLOB/slob1  Snaps: 310-311
```

I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	155,795.40	148,933.1	5.2	5.5	14.6	1.4	2,369.7	5.0	0.20	0.1
2	210,927.91	149,900.2	2.4	5.9	33.7	1.4	2,388.8	5.2	0.19	0.2
3	159,063.72	151,961.7	1.5	5.3	12.1	1.4	2,416.7	4.4	0.20	0.1
4	200,586.75	152,232.4	2.5	4.4	10.5	1.6	2,424.2	4.9	0.20	0.1
Sum	726,373.78	603,027.4	11.6	21.2	70.9	5.7	9,599.4	19.5	0.78	0.6
Avg	181,593.44	150,756.9	2.9	5.3	17.7	1.4	2,399.9	4.9	0.20	0.2
Std	28,251.16	1,600.9	1.6	0.7	10.8	0.1	25.2	0.4	0.00	0.0


The screenshot above highlights that IO load is distributed across all the cluster nodes performing workload operations. Due to variations in workload randomness, we conducted multiple runs to help ensure consistency in behavior and test results.

The screenshot below was captured from a 70% Read (30% update) Test scenario while running SLOB test for 512 users. The snapshot shows a section from AWR report from the run that highlights Physical Reads/Sec and Physical Writes/Sec for each instance.

```
System Statistics - Per Second          DB/Inst: SLOB/slob1  Snaps: 334-335
```

I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	109,377.19	102,785.5	31,050.0	10,864.7	62,872.8	1.1	1,645.7	5.8	0.15	488.3
2	114,843.30	107,949.3	32,596.1	11,347.6	66,022.1	1.1	1,726.8	5.6	0.15	512.8
3	149,685.24	105,692.9	31,895.3	11,109.2	64,587.8	1.3	1,688.8	5.9	0.15	501.6
4	110,480.18	103,911.3	31,359.7	10,962.4	63,504.7	1.1	1,664.5	5.9	0.15	493.3
Sum	484,385.91	420,339.0	126,901.0	44,283.8	256,987.5	4.7	6,725.8	23.2	0.59	1,996.0
Avg	121,096.48	105,084.8	31,725.3	11,071.0	64,246.9	1.2	1,681.5	5.8	0.15	499.0
Std	19,204.75	2,253.8	677.5	210.0	1,379.2	0.1	35.0	0.1	0.00	10.7

The following graph illustrates the latency exhibited by the NetApp AFF A700s Storage across different workloads. All the workloads experienced less than 1 millisecond latency and it varies based on the workloads. As expected, the 50% read (50% update) test exhibited higher latencies as the user counts increases.



The following screenshot was captured from 100 % Read (0% Update) Test scenario while running SLOB test for 512 users. The screenshot shows a section of AWR report from the run that highlights top timed Events.

```

Top Timed Events
DB/Inst: SLOB/slob1 Snaps: 310-311
-v Instance '**' - cluster wide summary
-v '**' Waits, %Timeouts, Wait Time Total(s) : Cluster-wide total for the wait event
-v '**' 'Wait Time Avg' : Cluster-wide average computed as (Wait Time Total / Event Waits)
-v '**' Summary 'Avg Wait Time ' : Per-instance 'Wait Time Avg ' used to compute the following statistics
-v '**' [Avg/Min/Max/Std Dev] : average/minimum/maximum/standard deviation of per-instance 'Wait Time Avg'
-v '**' Cnt : count of instances with wait times for the event
    
```

I#	Class	Event	Wait		Event			Wait Time		Summary Avg Wait Time				
			Waits	%Timeouts	Total(s)	Avg Wait	%DB time	Avg	Min	Max	Std Dev	Cnt		
*	User I/O	db file sequential read	1,080,367E+09	0.0	788,506.70	729.85us	85.53	729.87us	727.62us	733.91us	2.78us	4		
	DB CPU	N/A	N/A	N/A	85,995.01	N/A	9.33					4		
	Cluster	gc cr grant 2-way	524,206,578	0.0	66,697.65	127.24us	7.24	127.29us	122.65us	134.05us	5.17us	4		
	Cluster	gc cr grant congested	5,393,910	0.0	21,808.33	4.04ms	2.37	4.04ms	3.99ms	4.12ms	91.61us	4		
	Application	enq: TX - row lock contention	5	0.0	920.63	184.13 s	0.10	186.06 s	181.05 s	195.70 s	8358.21ms	4		
	Other	gc dm freeze in enter server mode	2,380	0.0	501.40	210.67ms	0.05	210.61ms	201.53ms	224.49ms	10.56ms	4		
	Cluster	gc buffer busy release	402	0.0	193.59	481.58ms	0.02	388.31ms	170.57us	660.45ms	279.10ms	4		
	Other	latch free	67,725	0.0	192.59	2.84ms	0.02	2.86ms	1.69ms	4.32ms	1.09ms	4		
	Other	RMA: IPCO completion sync	7,534	0.0	146.25	19.41ms	0.02	19.41ms	19.37ms	19.44ms	30.68us	4		
	Concurr	library cache load lock	6,188	0.0	104.40	16.87ms	0.01	15.02ms	5.26ms	41.87ms	17.91ms	4		

Swingbench Test

We used Swingbench for OLTP and DSS workload testing. Swingbench is a simple to use, free, Java-based tool to generate database workload and perform stress testing using different benchmarks in Oracle database environments. Swingbench can be used to demonstrate and test technologies such as Real Application Clusters, Online table rebuilds, Standby databases, online backup and recovery, etc.

Swingbench provides four separate benchmarks, namely Order Entry, Sales History, Calling Circle, and Stress Test. For the tests described in this solution, Swingbench Order Entry benchmark was used for OLTP workload testing and the Sales History benchmark was used for the DSS workload testing.

The Order Entry benchmark is based on SOE schema and is TPC-C like by types of transactions. The workload uses a very balanced read/write ratio about 60/40 and can be designed to run continuously and test the

performance of a typical Order Entry workload against a small set of tables, producing contention for database resources.

The Sales History benchmark is based on the SH schema and is TPC-H like. The workload is query (read) centric and is designed to test the performance of queries against large tables.

Typically encountered in the real-world deployments, we tested a combination of scalability and stress related scenarios that ran on all the 4-node Oracle RAC cluster configuration.

- OLTP database user scalability representing small and random transactions
- DSS database workload representing larger transactions
- Mixed workload featuring OLTP and DSS database workloads running simultaneously for 24 hours

For Swingbench workload, we created two OLTP (OLTP and SOE) and one DSS (DSS) database to demonstrate database multi-tenancy capability, performance and sustainability. We created approximately 3 TB of OLTP Database, 4 TB of SOE Database and 6 TB of DSS database to perform Order Entry and Sales Entry swingbench workload testing.

The first step after the databases creation is calibration; about the number of concurrent users, nodes, throughput, IOPS and latency for database optimization. For this FlexPod solution, we have tested system performance with different databases running at a time and capture the results as explained in the following sections.

One (SOE) Database Performance

For one OLTP database workload featuring Order Entry schema, we used one SOE database. For the SOE database (4 TB), we used 128GB size of System Global Area (SGA). We also made sure that HugePages were in use. The OLTP Database scalability test was run for at least 12 hours and made sure that results are consistent for the duration of the full run.

We ran the SwingBench scripts on each node to start SOE database and generate AWR reports for each scenario as shown below.


User Scalability

Table 11 lists the Transaction Per Minutes (TPM), IOPS and System Utilization for SOE Database while running swingbench workloads from 100 users to 800 users.


Table 11 TPM, TPS, IOPS and System Utilization for SOE Database User Scale Tests

Users	Transactions		Storage IOPS (AWR)			System Utilization (%)
	Per Second (TPS)	Per Minute (TPM)	Reads/s	Writes/s	Total Phy. IOPS	
100	8,280	496,776	39,645	21,404	61,049	9.3
200	15,225	913,470	74,088	36,921	111,009	17.8
200	20,273	1,216,356	98,384	50,057	148,442	22.8
400	24,777	1,486,590	118,738	60,882	179,620	27.4
500	28,084	1,685,010	134,636	71,005	205,641	32.5
600	30,590	1,835,376	146,532	80,368	226,900	37.1
700	33,105	1,986,270	154,331	82,346	236,677	43.1
800	36,467	2,188,002	162,648	83,012	245,660	47.4

The chart below shows the IOPS and Latency of SOE database while running swingbench workload for 100 users to 800 users on all 4 RAC nodes.



The chart below shows TPM and System Utilization of the system while running swingbench workload for 100 user to 800 users.



The screenshot below was captured from the 800 User Scale Test scenario while running Swingbench workload on SOE database. The snapshot shows a section from 4-hour window of AWR Global report from the run that highlights Physical Reads/Sec and Physical Writes/Sec for each instance. Notice that IO load is distributed across all the cluster nodes performing workload operations.

System Statistics - Per Second DB/Inst: SOE/soe1 Snaps: 74-78

I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	904,296.03	38,610.9	19,668.8	29,381.9	185,892.7	25,933.3	89,726.4	10,306.8	0.45	8,643.7
2	938,176.47	40,253.8	20,390.3	30,495.9	193,291.3	27,006.9	93,437.7	10,733.3	0.45	9,001.6
3	1,136,462.10	39,304.7	19,951.9	29,485.2	187,806.4	26,314.6	91,051.3	10,457.7	0.44	8,770.8
4	1,058,048.40	44,478.6	23,001.4	33,857.1	215,500.1	30,154.1	104,323.5	11,984.7	0.45	10,050.7
Sum	4,036,983.00	162,648.0	83,012.4	123,220.1	782,490.4	109,409.0	378,538.8	43,482.5	1.80	36,466.7
Avg	1,009,245.75	40,662.0	20,753.1	30,805.0	195,622.6	27,352.2	94,634.7	10,870.6	0.45	9,116.7
Std	107,441.43	2,632.0	1,528.0	2,095.9	13,617.6	1,920.1	6,639.2	763.4	0.00	640.0

The AWR screenshot below shows top timed events for the same 800 User Scale Test while Swingbench test was running.


Top Timed Events DB/Inst: SOE/soe1 Snaps: 74-78

```

-> Instance '**' - cluster wide summary
** Waits, %Timeouts, Wait Time Total(s) : Cluster-wide total for the wait event
** 'Wait Time Avg' : Cluster-wide average computed as (Wait Time Total / Event Waits)
** Summary 'Avg Wait Time ' : Per-instance 'Wait Time Avg ' used to compute the following statistics
** [Avg/Min/Max/Std Dev] : average/minimum/maximum/standard deviation of per-instance 'Wait Time Avg'
** Cnt : count of instances with wait times for the event
    
```

I#	Class	Event	Wait		Event			Wait Time			Summary Avg Wait Time			
			Waits	%Timeouts	Total(s)	Avg Wait	%DB time	Avg	Min	Max	Std Dev	Cnt		
*	User I/O	db file sequential read	1.679536E+09	0.0	1,629,626.08	.97ms	29.13	.97ms	.95ms	.98ms	16.51us	4		
		DB CPU	N/A	N/A	1,306,367.35		23.35					4		
	Commit	log file sync	391,693,265	0.0	840,605.91	2.15ms	15.03	2.15ms	1.96ms	2.44ms	215.23us	4		
	Cluster	gc current block congested	40,536,239	0.0	247,195.21	6.10ms	4.42	6.01ms	5.62ms	6.21ms	264.28us	4		
	Cluster	gc current block busy	464,121,194	0.0	246,956.51	532.09us	4.41	535.99us	438.04us	619.00us	75.63us	4		
	Cluster	gc current grant 2-way	591,737,257	0.0	220,612.94	372.82us	3.94	372.72us	358.28us	380.07us	9.99us	4		
	Cluster	gc cr block 3-way	904,639,822	0.0	206,520.00	677.92us	3.69	662.38us	485.33us	758.60us	122.42us	4		
	Cluster	gc cr block congested	30,781,329	0.0	193,042.74	6.27ms	3.45	6.17ms	5.70ms	6.39ms	318.34us	4		
	Cluster	gc current grant busy	111,064,019	0.0	171,241.91	1.54ms	3.06	1.54ms	1.51ms	1.59ms	33.34us	4		
	Cluster	gc current block 2-way	356,478,432	0.0	122,968.64	344.95us	2.20	350.50us	261.83us	396.23us	60.41us	4		

The Oracle Enterprise Manager screenshot below shows All Wait Events, IO Requests Per Second, CPU Utilization for the same 800 User Scale Test while Swingbench test was running for 24 hours.



Two (SOE and OLTP) Database Performance

For two OLTP database workload featuring Order Entry schema, we used SOE and OLTP database. For both the databases, we used 128GB of System Global Area (SGA). We also made sure that HugePages were in use all the time while databases were running. The SOE + OLTP Database scalability test were run for at least 12 hours and ensured that results are consistent for the duration of the full run.

Notice that SOE database is of approximately 4 TB in size, while OLTP database is 3 TB in size. While running below tests on both the database together, we scaled more users on the SOE database compared to the OLTP database. We ran the Swingbench scripts on each node to start SOE and OLTP database and generate AWR reports for each scenario as shown below.

User Scalability

Table 12 lists the IOPS and System Utilization for SOE + OLTP databases running together Swingbench workloads from 200 users to 800 users across all the four RAC nodes:

Table 12 Total IOPS for SLOB + OLTP Database for User Scalability Tests

Users	IOPS for SOE DB	IOPS for OLTP DB	Total IOPS	System Utilization (%)
200	81,838	27,755	109,593	18.9
300	119,816	26,097	145,913	25.3
400	128,855	44,909	173,764	32.1
500	139,657	61,445	201,102	39.3
600	145,508	75,465	220,973	44.2
700	150,922	89,918	240,840	50.7
800	142,873	96,206	239,079	55.9

The graph below demonstrates the total IOPS for both SOE and OLTP Database while running Swingbench workload together from 200 users to 800 users.





Table 13 lists the TPM and System Utilization for SOE + OLTP databases running Swingbench workloads together from 100 users to 800 users.

Table 13 Total TPM for SLOB + OLTP Database for User Scalability Tests

Users	TPM for SOE DB	TPM for OLTP DB	Total TPM	System Utilization (%)
200	691,092	232,542	923,634	18.9
300	1,051,458	217,620	1,269,078	25.3
400	1,129,806	395,370	1,525,176	32.1
500	1,227,612	552,582	1,780,194	39.3
600	1,298,058	696,966	1,995,024	44.2
700	1,306,896	821,701	2,128,597	50.7
800	1,265,010	898,944	2,163,954	55.9

The graph below illustrates the total IOPS for both SOE and OLTP Database while running Swingbench workload together from 200 users to 800 users.



The results were in line with prior assessments where the user scalability was almost linear till 600 users and beyond 600 users the rate of IOPS increase slowed down.

The screenshot shown below was captured from the 800 Users Scale Test scenario while running Swingbench workload on two database at the same time for 24 hours. The snapshot shows a section from 24-hour window of AWR Global report from the run that highlights Physical Reads/Sec, Physical Writes/Sec and Transactions per Seconds for each instance for both the databases. Notice that IO load is distributed across all the cluster nodes performing workload operations.

```
System Statistics - Per Second DB/Inst: SOE/soe1 Snaps: 358-382
```

I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	566,176.94	20,297.2	11,410.4	17,767.1	103,924.6	14,269.6	49,389.6	5,667.3	0.17	4,754.0
2	567,314.38	20,247.1	11,329.0	17,636.6	103,050.3	14,148.4	48,974.7	5,619.4	0.17	4,713.9
3	585,066.16	20,807.2	11,567.7	17,951.8	105,003.0	14,426.0	49,936.8	5,729.9	0.17	4,806.5
4	689,140.63	23,551.8	13,308.4	20,344.8	120,754.4	16,628.9	57,557.4	6,604.3	0.16	5,540.3
Sum	2,407,698.10	84,903.2	47,615.5	73,700.3	432,732.3	59,472.9	205,858.5	23,620.9	0.67	19,814.7
Avg	601,924.52	21,225.8	11,903.9	18,425.1	108,183.1	14,868.2	51,464.6	5,905.2	0.17	4,953.7
Std	58,783.80	1,571.1	941.6	1,286.3	8,418.8	1,179.3	4,080.9	468.2	0.00	392.9

```
System Statistics - Per Second DB/Inst: OLTP/oltp1 Snaps: 318-342
```

I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	349,578.30	12,930.7	7,763.6	12,796.0	73,189.0	9,997.0	34,671.2	3,969.4	0.11	3,330.2
2	402,893.75	13,027.3	7,887.3	12,871.6	73,746.0	10,082.1	34,963.6	4,003.5	0.11	3,358.5
3	364,991.20	14,922.1	8,114.9	13,176.1	76,002.4	10,396.1	36,054.9	4,128.2	0.11	3,463.1
4	467,315.99	15,813.3	9,518.9	15,263.8	90,031.4	12,350.9	42,832.2	4,904.0	0.11	4,114.3
Sum	1,584,779.23	56,693.3	33,284.7	54,107.5	312,968.8	42,826.1	148,521.9	17,005.1	0.43	14,266.1
Avg	396,194.81	14,173.3	8,321.2	13,526.9	78,242.2	10,706.5	37,130.5	4,251.3	0.11	3,566.5
Std	52,440.00	1,426.9	811.6	1,169.5	7,953.1	1,109.6	3,847.5	440.5	0.00	369.7

The screenshot below shows top timed events for SOE database while running the same above Swingbench test for 24 hours.

```
Top Timed Events DB/Inst: SOE/soe1 Snaps: 358-382
```

```
-> Instance '*' - cluster wide summary
-> '*' Waits, %Timeouts, Wait Time Total(s) : Cluster-wide total for the wait event
-> '*' 'Wait Time Avg' : Cluster-wide average computed as (Wait Time Total / Event Waits)
-> '*' Summary 'Avg Wait Time ' : Per-instance 'Wait Time Avg ' used to compute the following statistics
-> '*' [Avg/Min/Max/Std Dev] : average/minimum/maximum/standard deviation of per-instance 'Wait Time Avg'
-> '*' Cnt : count of instances with wait times for the event
```

I#	Class	Event	Event		Wait Time		Summary Avg Wait Time					
			Waits	%Timeouts	Total(s)	Avg Wait	%DB time	Avg	Min	Max	Std Dev	Cnt
*	User I/O	db file sequential read	7.050821E+09	0.0	7,442,779.62	1.06ms	24.59	1.06ms	1.05ms	1.08ms	15.75us	4
	DB CPU	N/A	N/A	N/A	6,075,235.66	N/A	20.07					4
	Commit	log file sync	1.705457E+09	0.0	4,018,701.82	2.36ms	13.28	2.36ms	1.95ms	3.15ms	551.02us	4
	Cluster	gc current grant 2-way	2.671641E+09	0.0	1,550,173.17	580.23us	5.12	616.19us	194.39us	.96ms	317.46us	4
	Cluster	gc current block busy	1.925001E+09	0.0	1,446,570.87	751.46us	4.78	757.45us	488.76us	944.48us	192.07us	4
	Cluster	gc current block congested	42,098,159	0.0	1,360,282.90	32.31ms	4.49	31.98ms	20.19ms	43.48ms	9.52ms	4
	Cluster	gc cr block 3-way	1.494389E+09	0.0	1,341,880.74	897.95us	4.43	901.96us	531.05us	1.18ms	305.82us	4
	Cluster	gc cr grant 2-way	2.210294E+09	0.0	1,191,479.42	539.06us	3.94	556.54us	188.89us	928.93us	305.73us	4
	Cluster	gc current block 2-way	1.651133E+09	0.0	1,059,897.19	641.92us	3.50	625.57us	197.85us	780.64us	285.88us	4
	Cluster	gc cr block congested	30,264,924	0.0	1,042,665.74	34.45ms	3.45	33.51ms	20.52ms	44.32ms	9.80ms	4

The screenshot below shows top timed events for OLTP database while running the same above Swingbench test for 24 hours.

```
Top Timed Events DB/Inst: OLTP/oltp1 Snaps: 318-342
```

```
-> Instance '*' - cluster wide summary
-> '*' Waits, %Timeouts, Wait Time Total(s) : Cluster-wide total for the wait event
-> '*' 'Wait Time Avg' : Cluster-wide average computed as (Wait Time Total / Event Waits)
-> '*' Summary 'Avg Wait Time ' : Per-instance 'Wait Time Avg ' used to compute the following statistics
-> '*' [Avg/Min/Max/Std Dev] : average/minimum/maximum/standard deviation of per-instance 'Wait Time Avg'
-> '*' Cnt : count of instances with wait times for the event
```

I#	Class	Event	Event		Wait Time		Summary Avg Wait Time					
			Waits	%Timeouts	Total(s)	Avg Wait	%DB time	Avg	Min	Max	Std Dev	Cnt
*	User I/O	db file sequential read	4.576784E+09	0.0	4,544,231.69	.99ms	27.16	.99ms	.98ms	1.02ms	17.06us	4
	DB CPU	N/A	N/A	N/A	4,115,305.12	N/A	24.60					4
	Commit	log file sync	1.228804E+09	0.0	2,641,063.77	2.15ms	15.79	2.15ms	1.78ms	2.79ms	448.51us	4
	Cluster	gc current block busy	1.496741E+09	0.0	888,680.80	593.75us	5.31	601.35us	378.92us	732.51us	154.14us	4
	System I/O	db file parallel write	1.303142E+09	0.0	858,050.42	658.45us	5.13	661.20us	614.98us	698.89us	39.17us	4
	Cluster	gc cr block 3-way	1.146138E+09	0.0	846,483.49	738.55us	5.06	744.56us	389.49us	1.00ms	272.62us	4
	Cluster	gc current grant 2-way	1.763565E+09	0.0	802,341.22	454.95us	4.80	485.86us	154.32us	697.67us	233.53us	4
	Cluster	gc current block 2-way	1.250840E+09	0.0	677,436.64	541.59us	4.05	532.38us	159.00us	683.20us	250.24us	4
	Cluster	gc cr grant 2-way	1.469241E+09	0.0	593,276.94	403.80us	3.55	418.79us	150.37us	677.93us	216.05us	4
	Cluster	gc cr block 2-way	1.040361E+09	0.0	572,519.33	550.31us	3.42	531.39us	158.06us	668.10us	249.15us	4

The screenshots shown below were captured from the Oracle Enterprise Manager while running 800 users Swingbench workload test for 24 hours.

Figure 3 Wait Events, IO Requests per Second, and CPU Utilization for the SOE Database






Figure 4 Wait Events, IO Requests per Second and CPU Utilization for the OLTP Database



One (DSS) Database Performance

DSS database workloads are generally sequential in nature, read intensive and exercise large IO size. DSS database workload runs a small number of users that typically exercise extremely complex queries that run for hours. We configured 6 TB of DSS database by loading Swingbench sh schema into Datafile Tablespace.

DSS Database activity is captured using Oracle Enterprise Manager for 24 hour Swingbench workload test as shown below.



For 24 hour DSS workload test, we observed the total sustained IO bandwidth average was about 10.5 GB/sec after the initial ramp up workload. As shown in above screenshot, the IO was consistent throughout the run and we did not observe any significant dips in performance for complete period of time.


The screenshot shown below was captured from Oracle AWR report while running Swingbench SH workload on DSS database for 24 hours.

```

Top Timed Events                               DB/Inst: DSS/dss1 Snaps: 30-54
-- Instance *** - cluster wide summary
-- Waits, %Timeouts, Wait Time Total(s)      : Cluster-wide total for the wait event
-- 'Wait Time Avg'                          : Cluster-wide average computed as (Wait Time Total / Event Waits)
-- Summary 'Avg Wait Time'                  : Per-instance 'Wait Time Avg' used to compute the following statistics
-- [Avg/Min/Max/Std Dev]                    : average/minimum/maximum/standard deviation of per-instance 'Wait Time Avg'
-- Cnt                                       : count of instances with wait times for the event
    
```

I#	Class	Event	Event		Wait Time			Summary Avg Wait Time				
			Waits	%Timeouts	Total(s)	Avg Wait	%DB time	Avg	Min	Max	Std Dev	Cnt
*	User I/O	direct path read temp	92,645,271	0.0	1,967,690.73	21.24ms	35.36	21.26ms	20.76ms	22.13ms	618.92us	4
	User I/O	direct path read	59,652,703	0.0	1,372,420.31	23.01ms	24.66	23.01ms	22.30ms	23.74ms	638.35us	4
		DB CPU	N/A	N/A	1,371,639.33		24.65					4
	User I/O	direct path write temp	15,973,481	0.0	162,568.24	10.18ms	2.92	10.18ms	9.45ms	10.48ms	488.29us	4
	System I/O	control file sequential read	2,221,964	0.0	30,841.66	13.88ms	0.55	13.88ms	13.70ms	14.09ms	167.34us	4
	Cluster	gc current block busy	648,267	0.0	8,619.08	13.30ms	0.15	13.17ms	9.15ms	15.04ms	2.76ms	4
	Other	RMA: IPCO completion sync	361,383	0.0	7,009.92	19.40ms	0.13	19.40ms	19.39ms	19.40ms	4.09us	4
	Cluster	gc buffer busy acquire	21,048	0.0	5,935.45	282.00ms	0.11	277.95ms	224.45ms	322.18ms	46.40ms	4
	Cluster	gc buffer busy release	116,551	0.0	5,807.59	49.83ms	0.10	49.84ms	43.86ms	56.12ms	5.06ms	4
	Other	Sync ASM rebalance	41,264	0.0	4,812.83	116.63ms	0.09	115.65ms	20.98us	155.16ms	77.09ms	4

The screenshot below shows Wait Class events for each Instance of DSS Database while running Swingbench workload test for 24 hours.



The screenshot below shows IO throughput and CPU utilization for each instance of DSS Database while running Swingbench workload test for 24 hours.



All Three (SOE, OLTP and DSS) Database Performance

In this test, we ran both OLTP (SOE+OLTP) and DSS (DSS) Database Swingbench workload at the same time to measure the system performance on small random queries presented via OLTP databases as well as large and sequential transactions submitted via DSS database workload.

The screenshots shown below were captured from Oracle AWR reports while running the Swingbench workload tests on all three database at the same time for 24 hours. We achieved about 128k IOPS for SOE database, 68k IOPS for OLTP database and 4.8 GB/s throughput for DSS database.

SOE Database AWR snapshot that highlights Physical Reads/Sec, Physical Writes/Sec and Transactions per Seconds.

System Statistics - Per Second										
DB/Inst: SOE/soe1 Snaps: 360-385										
I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	562,479.34	19,378.5	10,856.6	17,033.1	99,294.6	13,594.0	47,056.5	5,401.4	0.12	4,530.2
2	503,273.70	19,970.1	11,283.6	17,480.4	102,079.2	14,003.0	48,472.6	5,563.3	0.11	4,666.5
3	638,590.27	22,721.7	12,458.0	18,984.4	111,824.1	15,393.2	53,283.1	6,115.3	0.11	5,129.6
4	581,833.41	20,373.0	11,578.9	17,719.4	103,659.3	14,238.1	49,284.7	5,657.1	0.11	4,745.2
Sum	2,286,176.72	82,443.4	46,177.1	71,217.2	416,857.2	57,228.3	198,096.9	22,737.1	0.46	19,071.5
Avg	571,544.18	20,610.8	11,544.3	17,804.3	104,214.3	14,307.1	49,524.2	5,684.3	0.12	4,767.9
Std	55,809.43	1,465.3	677.5	836.5	5,384.5	771.5	2,669.7	306.1	0.00	257.0

OLTP Database AWR snapshot that highlights Physical Reads/Sec, Physical Writes/Sec and Transactions per Seconds.

System Statistics - Per Second										
DB/Inst: OLTP/oltp1 Snaps: 320-345										
I#	Logical Reads/s	Physical Reads/s	Physical Writes/s	Redo Size (k)/s	Block Changes/s	User Calls/s	Execs/s	Parses/s	Logons/s	Txns/s
1	277,441.84	9,875.5	6,176.9	10,107.1	57,135.4	7,738.0	26,836.1	3,074.3	0.10	2,577.9
2	303,117.35	10,150.5	6,414.6	10,454.3	59,252.4	8,049.5	27,915.3	3,196.7	0.10	2,681.5
3	301,983.71	11,930.5	6,770.1	11,057.5	62,961.7	8,583.7	29,768.1	3,408.8	0.10	2,859.6
4	345,490.05	10,436.7	6,505.0	10,606.5	60,200.7	8,195.5	28,417.3	3,255.3	0.10	2,730.6
Sum	1,228,032.95	42,393.2	25,866.6	42,225.4	239,550.1	32,566.7	112,936.7	12,935.0	0.40	10,849.6
Avg	307,008.24	10,598.3	6,466.6	10,556.3	59,887.5	8,141.7	28,234.2	3,233.8	0.10	2,712.4
Std	28,257.19	917.2	245.1	394.1	2,417.1	351.1	1,216.9	138.9	0.00	116.9

DSS Database AWR snapshot that highlights database MB per Seconds.

```

IO Profile (Global)                                     DB/Inst: DSS/dss1  Snaps: 26-51
-----
Statistic                                         Read+Write/s      Reads/s           Writes/s
-----
Total Requests                                   6,154.03          5,290.44          863.59
Database Requests                               6,100.75          5,240.52          860.23
Optimized Requests                              0.00              0.00              0.00
Redo Requests                                   0.44              N/A               0.44
Total (MB)                                       4,814.09          4,651.36          162.72
Database (MB)                                   4,813.26          4,650.58          162.67
Optimized Total (MB)                            0.00              0.00              0.00
Redo (MB)                                        0.01              N/A               0.01
Database (blocks)                               616,096.82       595,274.70       20,822.12
Via Buffer Cache (blocks)                        95.71             2.67              93.05
Direct (blocks)                                 616,001.11       595,272.03       20,729.08
-----
    
```

The screenshots shown below were captured from the Oracle Enterprise Manager while running the Swingbench workload tests on all three database together for 24 hours.

Figure 5 SOE Database Wait Events per Instance, IO Requests per Second and CPU Utilization




Figure 6 OLTP Database Wait Events per Instance, IO Requests per Second and CPU Utilization





Figure 7 DSS Database Wait Events per Instance, IO Bytes and CPU Utilization




Resiliency and Failure Tests

The goal of these tests is to help ensure that reference architecture withstands commonly occurring failures due to either unexpected crashes, hardware failures or human errors. We conduct many hardware (disconnect power), software (process kills) and OS specific failures that simulate real world scenarios under stress condition. In the destructive testing, we also demonstrate unique failover capabilities of Cisco UCS components.

Table 14 Hardware Failover Tests

Scenario	Tests
Test 1 - UCS FI - A Failure	Run the system on Full Database work Load. Power Off Fabric Interconnect - A and check network traffic on Fabric Interconnect - B.
Test 2 - UCS FI - B Failure	Run the system on Full Database work Load. Power Off Fabric Interconnect - B and check network traffic on Fabric Interconnect - A
Test 3 - UCS Nexus Switch - A Failure	Run the system on Full Database work Load. Power Off Nexus Switch - A and check network traffic on Nexus Switch - B.
Test 4 - UCS Nexus Switch - B Failure	Run the system on Full Database work Load. Power Off Nexus Switch - B and check network traffic on Nexus Switch - A.
Test 5 - UCS MDS Switch - A Failure	Run the system on Full Database work Load. Power Off MDS Switch - A and check storage traffic on MDS Switch - B
Test 6 - UCS MDS Switch - B Failure	Run the system on Full Database work Load. Power Off MDS Switch - B and check storage traffic on MDS Switch - A
Test 7 - UCS Chassis 1 and Chassis 2 IOM Links Failure	Run the system on full Database work Load. Disconnect one link from each Chassis 1 IOM and Chassis 2 IOM by pulling it out and reconnect it after 5 minutes.

Figure 8 The FlexPod Solution Infrastructure Diagram Under Normal Operating Conditions



The screenshot below shows a complete infrastructure details of MAC address and VLAN information for Cisco UCS Fabric Interconnect - A switch before failover test.

Log into Cisco Fabric Interconnect - A and "connect nxos a" then type "show mac address-table" to see all VLAN connection on Fabric Interconnect - A as shown below:

```

FLEXPOD-FI-A(nxos)# show mac address-table
Legend:
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address      Type    age    Secure NTFY    Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----
* 135    000c.2924.00d8   dynamic 0      F      F      Veth807
* 135    000c.293a.2afe   dynamic 0      F      F      Veth807
* 135    0025.b589.aa00   static  0      F      F      Veth773
* 135    0025.b589.aa01   static  0      F      F      Veth765
* 135    0025.b589.aa02   static  0      F      F      Veth781
* 135    0025.b589.aa03   static  0      F      F      Veth789
* 135    0025.b589.aa08   static  0      F      F      Veth807
* 4044   2c33.111c.65c3   dynamic 0      F      F      Eth1/1/33
* 4044   3a0e.4d30.b365   dynamic 0      F      F      Eth1/1/33
* 4044   3a0e.4d30.d60d   dynamic 0      F      F      Eth2/1/33
* 4044   3a0e.4da5.7d1f   dynamic 0      F      F      Eth2/1/33
* 4044   727d.b9e7.b9a1   dynamic 0      F      F      Eth1/1/33
* 4044   843d.c677.609c   dynamic 0      F      F      Veth32769
* 4044   cc46.d622.c9f1   dynamic 0      F      F      Eth2/1/33

```

As shown in the screenshot above, Fabric Interconnect – A carry Oracle Public Network traffic on VLAN 135 under normal operating conditions before failover test.

Log in to Cisco Fabric Interconnect – B and “connect nxos b” then type “show mac address-table” to see all VLAN connection on Fabric – B as shown in the screenshot below:

```

FLEXPOD-FI-B(nxos)# show mac address-table
Legend:
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address      Type    age    Secure NTFY    Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----
* 10     0025.b589.bb00   static  0      F      F      Veth775
* 10     0025.b589.bb01   static  0      F      F      Veth767
* 10     0025.b589.bb02   static  0      F      F      Veth783
* 10     0025.b589.bb03   static  0      F      F      Veth791
* 10     0025.b589.bb08   static  0      F      F      Veth809
* 4044   2c33.111c.369f   dynamic 0      F      F      Eth1/1/33
* 4044   3a0e.4d30.b364   dynamic 0      F      F      Eth1/1/33
* 4044   3a0e.4d30.d60c   dynamic 0      F      F      Eth2/1/33
* 4044   3a0e.4da5.7d1e   dynamic 0      F      F      Eth2/1/33
* 4044   727d.b9e7.b9a0   dynamic 0      F      F      Eth1/1/33
* 4044   843d.c677.609d   dynamic 0      F      F      Veth32769
* 4044   cc46.d690.f929   dynamic 0      F      F      Eth2/1/33

```

As shown in the above screenshot, Fabric Interconnect – B carry Oracle Private Network traffic on VLAN 10 under normal operating conditions before failover test.




All the Hardware failover tests were conducted during all the databases (SOE, OLTP and DSS) running Swingbench workloads.


Test 1 – Cisco UCS 6332-16UP Fabric Interconnect – A Failure Test

We conducted a hardware failure test on Fabric Interconnect – A by disconnecting power cable to the switch as explained below.

The figure below illustrates how during Fabric Interconnect – A switch failure, the respective blades (flex1 and flex2) on chassis 1 and (flex3 and flex4) on chassis 2 will fail over the public network interface MAC addresses and its VLAN network traffic to fabric interconnect – B.



Unplug the power cable from Fabric Interconnect - A, and check the MAC address and VLAN information on Cisco UCS Fabric Interconnect - B.



When we disconnected the power from Fabric Interconnect – A, some performance issues on the total IOPS, latency on SOE and OLTP database, as well as throughput on DSS database, as shown in the screenshots (above). However, we did not see any interruption in any Private, Public and Storage Network Traffic.

We noticed this behavior because each server node can failover vNICs from one fabric interconnect switch to another fabric interconnect switch, but there is no vHBAs failover from one fabric interconnect switch to another fabric interconnect switch. Therefore, if one fabric interconnect failure occurred, we would lose half of the number of vHBAs and consequently experience some performance impact on the databases, as shown in the screenshot (above).

After plugging the power cable into the Fabric Interconnect – A Switch, the respective blades (flex1 and flex2) on chassis 1 and (flex3 and flex4) on chassis 2 will route back the MAC addresses and its VLAN traffic to Fabric Interconnect – A. In normal operating conditions, the operating system level multipath configuration will bring back all the failed storage path back to active and database performance will resume to peak performance as previously shown.

The figure below shows details of MAC address, VLAN information and Server connections for Cisco UCS Fabric Interconnect – A switch under normal operating condition.

```
FLEXP0D-FI-A(nxos)# show mac address-table
Legend:
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address      Type      age      Secure NTFY  Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----
* 135    000c.2924.00d8   dynamic   0        F    F    Veth807
* 135    000c.293a.2afe   dynamic   0        F    F    Veth807
* 135    0025.b589.aa00   static    0        F    F    Veth773
* 135    0025.b589.aa01   static    0        F    F    Veth765
* 135    0025.b589.aa02   static    0        F    F    Veth781
* 135    0025.b589.aa03   static    0        F    F    Veth789
* 135    0025.b589.aa08   static    0        F    F    Veth807
* 4044   2c33.111c.65c3   dynamic   0        F    F    Eth1/1/33
* 4044   3a0e.4d30.b365   dynamic   0        F    F    Eth1/1/33
* 4044   3a0e.4d30.d60d   dynamic   0        F    F    Eth2/1/33
* 4044   3a0e.4da5.7d1f   dynamic   0        F    F    Eth2/1/33
* 4044   727d.b9e7.b9a1   dynamic   0        F    F    Eth1/1/33
* 4044   843d.c677.609c   dynamic   0        F    F    Veth32769
* 4044   cc46.d622.c9f1   dynamic   0        F    F    Eth2/1/33
```

The figure below shows details of MAC address, VLAN information and Server connections for Cisco UCS Fabric Interconnect – B switch under normal operating condition.

```


FLEXPOD-FI-B(nxos)# show mac address-table
Legend:
 * - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
 age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address    Type    age    Secure NTFY    Ports/SWID.SSID.LID
-----
* 10    0025.b589.bb00  static  0      F      F      Veth775
* 10    0025.b589.bb01  static  0      F      F      Veth767
* 10    0025.b589.bb02  static  0      F      F      Veth783
* 10    0025.b589.bb03  static  0      F      F      Veth791
* 10    0025.b589.bb08  static  0      F      F      Veth809
* 4044  2c33.111c.369f  dynamic 0      F      F      Eth1/1/33
* 4044  3a0e.4d30.b364  dynamic 0      F      F      Eth1/1/33
* 4044  3a0e.4d30.d60c  dynamic 0      F      F      Eth2/1/33
* 4044  3a0e.4da5.7d1e  dynamic 0      F      F      Eth2/1/33
* 4044  727d.b9e7.b9a0  dynamic 0      F      F      Eth1/1/33
* 4044  843d.c677.609d  dynamic 0      F      F      Veth32769
* 4044  cc46.d690.f929  dynamic 0      F      F      Eth2/1/33

```

Test 2 – Cisco UCS 6332-16UP Fabric Interconnect – B Failure Test

As similar to the test above, we conducted a hardware failure test on Fabric Interconnect – B by disconnecting power cable to the switch.

The figure below illustrates how during Fabric Interconnect – B switch failure, the respective blades (flex1 and flex2) on chassis 1 and (flex3 and flex4) on chassis 2 will fail over the private network interface MAC addresses and its VLAN network traffic to fabric interconnect – A.



Unplug power cable from Fabric Interconnect - B, and check the MAC address and VLAN information on Cisco UCS Fabric Interconnect - A.

```

FLEXPOD-FI-A(nxos)# show mac address-table
Legend:
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address    Type    age    Secure NTFY    Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----
* 135    000c.2924.00d8  dynamic 0      F      F      Veth807
* 135    000c.293a.2afe  dynamic 0      F      F      Veth807
* 135    0025.b589.aa00  static  0      F      F      Veth773
* 135    0025.b589.aa01  static  0      F      F      Veth765
* 135    0025.b589.aa02  static  0      F      F      Veth781
* 135    0025.b589.aa03  static  0      F      F      Veth789
* 135    0025.b589.aa08  static  0      F      F      Veth807
* 10     0025.b589.bb00  static  0      F      F      Veth776
* 10     0025.b589.bb01  static  0      F      F      Veth768
* 10     0025.b589.bb02  static  0      F      F      Veth784
* 10     0025.b589.bb03  static  0      F      F      Veth792
* 10     0025.b589.bb08  static  0      F      F      Veth810
* 4044   2c33.111c.65c3  dynamic 0      F      F      Eth1/1/33
* 4044   3a0e.4d30.b365  dynamic 0      F      F      Eth1/1/33
* 4044   3a0e.4d30.d60d  dynamic 0      F      F      Eth2/1/33
* 4044   3a0e.4da5.7d1f  dynamic 0      F      F      Eth2/1/33
* 4044   727d.b9e7.b9a1  dynamic 0      F      F      Eth1/1/33
* 4044   843d.c677.609c  dynamic 0      F      F      Veth32769
* 4044   cc46.d622.c9f1  dynamic 0      F      F      Eth2/1/33

```

As shown in the figure above, when the Fabric Interconnect – B failed, it routed all the Private Network traffic of VLAN 10 to Fabric Interconnect – A.

When we disconnected power from Fabric Interconnect – B, some performance issues occurred on total IOPS, latency on SOE and OLTP Database as well as throughput on DSS database similar as Fabric Interconnect A failure test. Notice that, we did not see any interruption in any Private, Public and Storage Network Traffic.

We noticed this behavior because each server node can failover vNICs from one fabric interconnect switch to another fabric interconnect switch but there is no vHBAs failover from one fabric interconnect switch to another fabric interconnect switch. Therefore, in case of any one fabric interconnect failure, we would lose half of the number of vHBAs and consequently some performance impact on the databases.

After plug back power cable to Fabric Interconnect – B Switch, the respective blades (flex1 and flex2) on chassis 1 and (flex3 and flex4) on chassis 2 will route back the MAC addresses and its VLAN traffic to Fabric Interconnect – B. In normal operating conditions, the operating system level multipath configuration will bring back all the failed storage path back to active and database performance will resume to peak performance as previously shown.

Test 3 and 4 – Cisco Nexus Switch Failure Test

We conducted a hardware failure test on Nexus Switch – A by disconnecting power cable to the switch and checking the MAC address and VLAN information on Cisco UCS Nexus Switch – B. During Nexus Switch – A failure, it routed all the Private Network and Public Network Traffic of VLAN 10 and VLAN 134 to Nexus Switch – B. So, Nexus Switch – A Failover did not cause any disruption to Private, Public and Storage Network Traffic.

Similarly, we conducted a hardware failure test on Nexus Switch – B by disconnecting power cable to the switch and checking the MAC address and VLAN information on Cisco UCS Nexus Switch – A. During Nexus Switch – B failure, it routed all the Private Network and Public Network Traffic of VLAN 10 and VLAN 134 to Nexus Switch – A.

Test 5 and 6 – Cisco MDS Switch Failure Test

We conducted hardware failure test on MDS Switch – A by disconnecting power cable to the Switch and checking the storage network traffic on MDS Switch – B. As we expected, we observed some impact on all three databases performance as we lost half of the VSAN (VSAN-A 101) traffic. While VSAN-A (101) stays locally into

the switch and only carry storage traffic through the MDS switch A, VSAN-A doesn't failover to MDS Switch B therefore we reduced server to storage connectivity into half during MDS Switch A failure.

As a result, during one MDS Switch failure test, we observed similar performance impact on all the databases as Fabric Interconnect Switch failure tests.

Test 7 – Cisco UCS Chassis 1 and 2 IOM Links Failure

We conducted a Cisco UCS Chassis 1 and Chassis 2 IOM Link Failure test by disconnecting one of the server port link cable from the Chassis as explained below.

Unplug one server port cable from Chassis 1 and Chassis 2 and check the MAC address and VLAN traffic information on both UCS Fabric Interconnects. The screenshot below shows network traffic on Fabric Interconnect A when one link from Chassis 1 and one link from Chassis 2 IOM Failed.

```
FLEXPOD-FI-A(nxos)# show mac address-table
Legend:
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address      Type      age      Secure NTFY  Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----+-----
* 135    000c.2924.00d8   dynamic   0         F    F    Veth807
* 135    000c.293a.2afe   dynamic   0         F    F    Veth807
* 135    0025.b589.aa00   static    0         F    F    Veth773
* 135    0025.b589.aa01   static    0         F    F    Veth765
* 135    0025.b589.aa02   static    0         F    F    Veth781
* 135    0025.b589.aa03   static    0         F    F    Veth789
* 135    0025.b589.aa08   static    0         F    F    Veth807
* 4044   2c33.111c.65c3   dynamic   0         F    F    Eth1/1/33
* 4044   3a0e.4d30.b365   dynamic   0         F    F    Eth1/1/33
* 4044   3a0e.4d30.d60d   dynamic   0         F    F    Eth2/1/33
* 4044   3a0e.4da5.7d1f   dynamic   0         F    F    Eth2/1/33
* 4044   727d.b9e7.b9a1   dynamic   0         F    F    Eth1/1/33
* 4044   843d.c677.609c   dynamic   0         F    F    Veth32769
* 4044   cc46.d622.c9f1   dynamic   0         F    F    Eth2/1/33
```

The screenshot below shows network traffic on Fabric Interconnect B when one link from Chassis 1 and one link from Chassis 2 IOM Failed.

```
FLEXPOD-FI-B(nxos)# show mac address-table
Legend:
* - primary entry, G - Gateway MAC, (R) - Routed MAC, O - Overlay MAC
age - seconds since last seen,+ - primary entry using vPC Peer-Link
VLAN    MAC Address      Type      age      Secure NTFY  Ports/SWID.SSID.LID
-----+-----+-----+-----+-----+-----+-----
* 10     0025.b589.bb00   static    0         F    F    Veth775
* 10     0025.b589.bb01   static    0         F    F    Veth767
* 10     0025.b589.bb02   static    0         F    F    Veth783
* 10     0025.b589.bb03   static    0         F    F    Veth791
* 10     0025.b589.bb08   static    0         F    F    Veth809
* 4044   2c33.111c.369f   dynamic   0         F    F    Eth1/1/33
* 4044   3a0e.4d30.b364   dynamic   0         F    F    Eth1/1/33
* 4044   3a0e.4d30.d60c   dynamic   0         F    F    Eth2/1/33
* 4044   3a0e.4da5.7d1e   dynamic   0         F    F    Eth2/1/33
* 4044   727d.b9e7.b9a0   dynamic   0         F    F    Eth1/1/33
* 4044   843d.c677.609d   dynamic   0         F    F    Veth32769
* 4044   cc46.d690.f929   dynamic   0         F    F    Eth2/1/33
```

We noticed no disruption in public and private network traffic, even though one failed traffic link from both the Chassis because of the port-channel feature.



We completed an additional failure scenario and validated that there is no single point of failure in this reference design.

Summary

The Cisco Unified Computing System™ (Cisco UCS®) is a next-generation data center platform that unites computing, network, storage access, and virtualization into a single cohesive system. Cisco UCS is an ideal platform for the architecture of mission critical database workloads such as Oracle RAC. The FlexPod Datacenter with NetApp All Flash AFF system is a converged infrastructure platform that combines best-of breed technologies from Cisco and NetApp into a powerful converged platform for enterprise applications. The pre-validated FlexPod architecture delivers proven value, agility, and performance that drive higher productivity, faster decision making, and greater opportunities for growth.

An essential feature for Oracle databases deployed on shared enterprise system is the ability to deliver consistent and dependable high performance. High performance must be coupled with non-disruptive operations, high availability, scalability, and storage efficiency. Customers can depend on Cisco UCS and NetApp Clustered Data ONTAP Storage to provide these essential elements. Built on clustered Data ONTAP unified scale-out architecture, AFF consistently meets or exceeds the high performance demands of Oracle databases. It also provides rich data management capabilities, such as integrated data protection and non-disruptive upgrades and data migration. These features allow customers to eliminate performance silos and seamlessly integrate AFF into a shared infrastructure.

Clustered Data ONTAP 9.3 delivers an enhanced inline compression capability that significantly reduces the amount of flash storage required and carries near-zero effects on system performance. The combination of Cisco UCS, NetApp and Oracle Real Application Cluster Database architecture can provide the following benefits to accelerate your IT transformation:

- Cisco UCS stateless computing architecture provided by the Service Profile capability of Cisco UCS allows fast, non-disruptive workload changes to be executed simply and seamlessly across the integrated UCS infrastructure and Cisco x86 servers.
- A single platform built from unified compute, fabric, and storage technologies, allowing you to scale to large-scale data centers without architectural changes.
- Enabling faster deployments, greater flexibility of choice, efficiency, high availability and lower risk.

Appendix

Cisco Nexus 93180 LC-EX Configuration

```
FLEXPOD-NEXUS-A# show running-config

!Command: show running-config
!Time: Tue Nov 20 21:01:25 2018
version 7.0(3)I6(1)

switchname FLEXPOD-NEXUS-A

policy-map type network-qos jumbo

  class type network-qos class-default

    mtu 9216

vdc FLEXPOD-NEXUS-A id 1

  limit-resource vlan minimum 16 maximum 4094
  limit-resource vrf minimum 2 maximum 4096
  limit-resource port-channel minimum 0 maximum 511
  limit-resource u4route-mem minimum 248 maximum 248
  limit-resource u6route-mem minimum 96 maximum 96
  limit-resource m4route-mem minimum 58 maximum 58
  limit-resource m6route-mem minimum 8 maximum 8

cfs eth distribute

feature interface-vlan

feature hsrp

feature lacp

feature vpc

no password strength-check

username admin password 5 $5$FWM47Q8G$RxxMd920jZrjYX5GXLRCkfWgDtka29dQV1TiP/k4VmD
role network-admin

ip domain-lookup

system default switchport

system qos

  service-policy type network-qos jumbo
```

```
copp profile strict

snmp-server user admin network-admin auth md5 0x54fc9b6e68ba6a06acf4165853e18078
priv 0x54fc9b6e68ba6a06acf4165853e18078 localizedkey

rmon event 1 description FATAL(1) owner PMON@FATAL
rmon event 2 description CRITICAL(2) owner PMON@CRITICAL
rmon event 3 description ERROR(3) owner PMON@ERROR
rmon event 4 description WARNING(4) owner PMON@WARNING
rmon event 5 description INFORMATION(5) owner PMON@INFO

ntp server 72.163.32.44 use-vrf default

vlan 1,10,135
vlan 10
    name Oracle_RAC_Private_Traffic
vlan 135
    name Oracle_RAC_Public_Traffic

spanning-tree port type edge bpduguard default
spanning-tree port type network default
vrf context management
    ip route 0.0.0.0/0 10.29.135.1
port-channel load-balance src-dst 14port
vpc domain 1
    peer-keepalive destination 10.29.135.104 source 10.29.135.103
    auto-recovery

interface Vlan1

interface port-channell1
    description vPC peer-link
    switchport mode trunk
    switchport trunk allowed vlan 1,10,135
    spanning-tree port type network
    vpc peer-link
```

```
interface port-channel51
  description Port-Channel FI-A
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  spanning-tree port type edge trunk
  mtu 9216
  vpc 51
```

```
interface port-channel52
  description Port-Channel FI-B
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  spanning-tree port type edge trunk
  mtu 9216
  vpc 52
```

```
interface Ethernet1/1
  description Peer link connected to N9K-B-Eth1/1
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  channel-group 1 mode active
```

```
interface Ethernet1/2
  description Peer link connected to N9K-B-Eth1/2
  switchport mode trunk
  switchport trunk allowed vlan 1,10,135
  channel-group 1 mode active
```

```
interface Ethernet1/3
  .....
  .....
```

```
interface Ethernet1/20
```

```
interface Ethernet1/21
```

```
description Fabric-Interconnect-A-31
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
channel-group 51 mode active
```

```
interface Ethernet1/22
```

```
description Fabric-Interconnect-A-32
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
channel-group 51 mode active
```

```
interface Ethernet1/23
```

```
description Fabric-Interconnect-B-31
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
channel-group 52 mode active
```

```
interface Ethernet1/24
```

```
description Fabric-Interconnect-B-32
switchport mode trunk
switchport trunk allowed vlan 1,10,135
spanning-tree port type edge trunk
mtu 9216
```

```
channel-group 52 mode active

interface Ethernet1/25
  description NetApp Controller 1 e5e
  switchport access vlan 135

interface Ethernet1/26
  .....
interface Ethernet1/28

interface Ethernet1/29
  description connect to uplink switch
  switchport access vlan 135
  speed 1000

interface Ethernet1/30
  .....
  .....
interface Ethernet1/32

interface mgmt0
  vrf member management
  ip address 10.29.135.103/24
line console
line vty
boot nxos bootflash:/nxos.7.0.3.I6.1.bin
no system default switchport shutdown
MDS 9148S FC Switch Configuration
FLEXPOD-MDS-A# show running-config
!Command: show running-config
!Time: Tue Nov 20 21:19:36 2018
version 7.3(0)D1(1)
```

```
power redundancy-mode redundant
feature npiv
no feature http-server
role name default-role
    description This is a system defined role and applies to all users.
    rule 5 permit show feature environment
    rule 4 permit show feature hardware
    rule 3 permit show feature module
    rule 2 permit show feature snmp
    rule 1 permit show feature system
username admin password 5 $5$lC5R4cI9$rfrLLbkccOM1lwXALFaHFjx1XtCse5pPjAk3i/HJi0/
role network-admin
no password strength-check
ip domain-lookup
ip host FLEXPOD-MDS-A 10.29.135.105
aaa group server radius radius
snmp-server user admin network-admin auth md5 0xe2b9f6bd292aa43dc651e566873540cf
priv 0xe2b9f6bd292aa43dc651e566873540cf localizedkey
rmon event 1 log description FATAL(1) owner PMON@FATAL
rmon event 2 log description CRITICAL(2) owner PMON@CRITICAL
rmon event 3 log description ERROR(3) owner PMON@ERROR
rmon event 4 log description WARNING(4) owner PMON@WARNING
rmon event 5 log description INFORMATION(5) owner PMON@INFO
ntp server 72.163.32.44
vsan database
    vsan 101
device-alias database
    device-alias name flex1-hba0 pwwn 20:00:00:25:b5:8a:a0:00
    device-alias name flex1-hba2 pwwn 20:00:00:25:b5:8a:a0:01
    device-alias name flex2-hba0 pwwn 20:00:00:25:b5:8a:a0:02
    device-alias name flex2-hba2 pwwn 20:00:00:25:b5:8a:a0:03
    device-alias name flex3-hba0 pwwn 20:00:00:25:b5:8a:a0:04
    device-alias name flex3-hba2 pwwn 20:00:00:25:b5:8a:a0:05
```

```

device-alias name flex4-hba0 pwwn 20:00:00:25:b5:8a:a0:06
device-alias name flex4-hba2 pwwn 20:00:00:25:b5:8a:a0:07
device-alias name NetApp-A700s-01-2A pwwn 20:06:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-01-3A pwwn 20:07:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-02-2A pwwn 20:09:00:a0:98:af:7c:5b
device-alias name NetApp-A700s-02-3A pwwn 20:0a:00:a0:98:af:7c:5b
device-alias commit
fcdomain fcid database
vsan 1 wwn 20:06:8c:60:4f:bd:31:80 fcid 0x940000 dynamic
vsan 1 wwn 20:05:8c:60:4f:bd:31:80 fcid 0x940100 dynamic
vsan 1 wwn 20:01:00:de:fb:92:99:00 fcid 0x940300 dynamic
vsan 1 wwn 20:02:00:de:fb:92:99:00 fcid 0x940400 dynamic
vsan 1 wwn 20:03:00:de:fb:92:99:00 fcid 0x940500 dynamic
vsan 1 wwn 20:04:00:de:fb:92:99:00 fcid 0x940600 dynamic
vsan 1 wwn 50:0a:09:82:80:12:f8:47 fcid 0x940700 dynamic
vsan 1 wwn 50:0a:09:84:80:12:f8:47 fcid 0x940800 dynamic
vsan 1 wwn 50:0a:09:81:80:12:f8:47 fcid 0x940900 dynamic
vsan 1 wwn 50:0a:09:83:80:12:f8:47 fcid 0x940a00 dynamic
vsan 1 wwn 50:0a:09:81:80:12:f8:3d fcid 0x940b00 dynamic
vsan 1 wwn 50:0a:09:83:80:12:f8:3d fcid 0x940c00 dynamic
vsan 101 wwn 50:0a:09:81:80:12:f8:47 fcid 0xa20000 dynamic
vsan 101 wwn 50:0a:09:83:80:12:f8:47 fcid 0xa20100 dynamic
vsan 101 wwn 50:0a:09:81:80:12:f8:3d fcid 0xa20200 dynamic
vsan 101 wwn 50:0a:09:83:80:12:f8:3d fcid 0xa20300 dynamic
vsan 101 wwn 20:01:00:de:fb:92:99:00 fcid 0xa20400 dynamic
vsan 101 wwn 20:00:00:25:b5:8a:a0:00 fcid 0xa20702 dynamic
!
    [flex1-hba0]
vsan 101 wwn 20:00:00:25:b5:8a:a0:04 fcid 0xa20501 dynamic
!
    [flex3-hba0]
vsan 1 wwn 20:4d:54:7f:ee:76:cd:80 fcid 0x940200 dynamic
vsan 101 wwn 20:00:00:25:b5:8a:a0:06 fcid 0xa20502 dynamic
!
    [flex4-hba0]

```

```

vsan 101 wwn 20:00:00:25:b5:8a:a0:02 fcid 0xa20701 dynamic
!           [flex2-hba0]
vsan 101 wwn 20:02:00:de:fb:92:99:00 fcid 0xa20500 dynamic
vsan 101 wwn 20:03:00:de:fb:92:99:00 fcid 0xa20600 dynamic
vsan 101 wwn 20:04:00:de:fb:92:99:00 fcid 0xa20700 dynamic
vsan 101 wwn 20:02:00:a0:98:af:7c:5b fcid 0xa20001 dynamic
vsan 101 wwn 20:04:00:a0:98:af:7c:5b fcid 0xa20101 dynamic
vsan 101 wwn 20:06:00:a0:98:af:7c:5b fcid 0xa20002 dynamic
!           [NetApp-A700s-01-2A]
vsan 101 wwn 20:07:00:a0:98:af:7c:5b fcid 0xa20102 dynamic
!           [NetApp-A700s-01-3A]
vsan 101 wwn 20:09:00:a0:98:af:7c:5b fcid 0xa20201 dynamic
!           [NetApp-A700s-02-2A]
vsan 101 wwn 20:0a:00:a0:98:af:7c:5b fcid 0xa20301 dynamic
!           [NetApp-A700s-02-3A]
vsan 101 wwn 20:00:00:25:b5:8a:a0:01 fcid 0xa20601 dynamic
!           [flex1-hba2]
vsan 101 wwn 20:00:00:25:b5:8a:a0:03 fcid 0xa20404 dynamic
!           [flex2-hba2]
vsan 101 wwn 20:00:00:25:b5:8a:a0:05 fcid 0xa20401 dynamic
!           [flex3-hba2]
vsan 101 wwn 20:00:00:25:b5:8a:a0:07 fcid 0xa20603 dynamic
!           [flex4-hba2]
!Active Zone Database Section for vsan 101
zone name flex1 vsan 101
    member pwwn 20:00:00:25:b5:8a:a0:00
!           [flex1-hba0]
    member pwwn 20:00:00:25:b5:8a:a0:01
!           [flex1-hba2]
    member pwwn 20:06:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-2A]
    member pwwn 20:07:00:a0:98:af:7c:5b

```

```
!           [NetApp-A700s-01-3A]
member pwn 20:09:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-2A]
member pwn 20:0a:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-3A]
```

```
zone name flex2 vsan 101
```

```
member pwn 20:00:00:25:b5:8a:a0:02
!           [flex2-hba0]
member pwn 20:00:00:25:b5:8a:a0:03
!           [flex2-hba2]
member pwn 20:06:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-2A]
member pwn 20:07:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-3A]
member pwn 20:09:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-2A]
member pwn 20:0a:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-3A]
```

```
zone name flex3 vsan 101
```

```
member pwn 20:00:00:25:b5:8a:a0:04
!           [flex3-hba0]
member pwn 20:00:00:25:b5:8a:a0:05
!           [flex3-hba2]
member pwn 20:06:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-2A]
member pwn 20:07:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-3A]
member pwn 20:09:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-2A]
member pwn 20:0a:00:a0:98:af:7c:5b
```

```
!                               [NetApp-A700s-02-3A]

zone name flex4 vsan 101
    member pwn 20:00:00:25:b5:8a:a0:06
!                               [flex4-hba0]
    member pwn 20:00:00:25:b5:8a:a0:07
!                               [flex4-hba2]
    member pwn 20:06:00:a0:98:af:7c:5b
!                               [NetApp-A700s-01-2A]
    member pwn 20:07:00:a0:98:af:7c:5b
!                               [NetApp-A700s-01-3A]
    member pwn 20:09:00:a0:98:af:7c:5b
!                               [NetApp-A700s-02-2A]
    member pwn 20:0a:00:a0:98:af:7c:5b
!                               [NetApp-A700s-02-3A]

zoneset name flex vsan 101
    member flex1
    member flex2
    member flex3
    member flex4

zoneset activate name flex vsan 101
do clear zone database vsan 101
!Full Zone Database Section for vsan 101
zone name flex1 vsan 101
    member pwn 20:00:00:25:b5:8a:a0:00
!                               [flex1-hba0]
    member pwn 20:00:00:25:b5:8a:a0:01
!                               [flex1-hba2]
    member pwn 20:06:00:a0:98:af:7c:5b
!                               [NetApp-A700s-01-2A]
```

```
member pwn 20:07:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-3A]
member pwn 20:09:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-2A]
member pwn 20:0a:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-3A]
```

```
zone name flex2 vsan 101
```

```
member pwn 20:00:00:25:b5:8a:a0:02
!           [flex2-hba0]
member pwn 20:00:00:25:b5:8a:a0:03
!           [flex2-hba2]
member pwn 20:06:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-2A]
member pwn 20:07:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-3A]
member pwn 20:09:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-2A]
member pwn 20:0a:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-3A]
```

```
zone name flex3 vsan 101
```

```
member pwn 20:00:00:25:b5:8a:a0:04
!           [flex3-hba0]
member pwn 20:00:00:25:b5:8a:a0:05
!           [flex3-hba2]
member pwn 20:06:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-2A]
member pwn 20:07:00:a0:98:af:7c:5b
!           [NetApp-A700s-01-3A]
member pwn 20:09:00:a0:98:af:7c:5b
!           [NetApp-A700s-02-2A]
```

```
        member pwwn 20:0a:00:a0:98:af:7c:5b
!
        [NetApp-A700s-02-3A]

zone name flex4 vsan 101
    member pwwn 20:00:00:25:b5:8a:a0:06
!
        [flex4-hba0]
    member pwwn 20:00:00:25:b5:8a:a0:07
!
        [flex4-hba2]
    member pwwn 20:06:00:a0:98:af:7c:5b
!
        [NetApp-A700s-01-2A]
    member pwwn 20:07:00:a0:98:af:7c:5b
!
        [NetApp-A700s-01-3A]
    member pwwn 20:09:00:a0:98:af:7c:5b
!
        [NetApp-A700s-02-2A]
    member pwwn 20:0a:00:a0:98:af:7c:5b
!
        [NetApp-A700s-02-3A]

zoneset name flex vsan 101
    member flex1
    member flex2
    member flex3
    member flex4

interface mgmt0
    ip address 10.29.135.105 255.255.255.0

vsan database
    vsan 101 interface fc1/1
    vsan 101 interface fc1/2
    vsan 101 interface fc1/3
    vsan 101 interface fc1/4
    vsan 101 interface fc1/5
    vsan 101 interface fc1/6
```

```
vsan 101 interface fc1/7
vsan 101 interface fc1/8
vsan 101 interface fc1/9
vsan 101 interface fc1/10
vsan 101 interface fc1/11
vsan 101 interface fc1/12
switchname FLEXPOD-MDS-A
line console
line vty
boot kickstart bootflash:/m9100-s5ek9-kickstart-mz-npe.7.3.0.D1.1.bin
boot system bootflash:/m9100-s5ek9-mz-npe.7.3.0.D1.1.bin
interface fc1/1
.....
.....
interface fc1/48
interface fc1/1
    switchport trunk allowed vsan 101
    switchport trunk mode off
    port-license acquire
    no shutdown

interface fc1/2
    switchport trunk allowed vsan 101
    switchport trunk mode off
    port-license acquire
    no shutdown

interface fc1/3
    switchport trunk allowed vsan 101
    switchport trunk mode off
    port-license acquire
    no shutdown
```

```
interface fc1/4
  switchport trunk allowed vsan 101
  switchport trunk mode off
  port-license acquire
  no shutdown
```

```
interface fc1/5
  switchport trunk allowed vsan 101
  switchport trunk mode off
  port-license acquire
  no shutdown
```

```
interface fc1/6
  switchport trunk allowed vsan 101
  switchport trunk mode off
  port-license acquire
  no shutdown
```

```
interface fc1/7
  switchport trunk allowed vsan 101
  switchport trunk mode off
  port-license acquire
  no shutdown
```

```
interface fc1/8
  switchport trunk allowed vsan 101
  switchport trunk mode off
  port-license acquire
  no shutdown
```

```
interface fc1/9
```

```
switchport trunk allowed vsan 101
switchport trunk mode off
port-license acquire
no shutdown

interface fc1/10
switchport trunk allowed vsan 101
switchport trunk mode off
port-license acquire
no shutdown

interface fc1/11
switchport trunk allowed vsan 101
switchport trunk mode off
port-license acquire
no shutdown

interface fc1/12
switchport trunk allowed vsan 101
switchport trunk mode off
port-license acquire
no shutdown

interface fc1/13
port-license acquire
.....
.....
interface fc1/48
port-license acquire

no system default switchport shutdown
ip default-gateway 10.29.135.1
```

Multipath Configuration “/etc/multipath.conf”

```
defaults {
    find_multipaths yes
    user_friendly_names no
}

multipaths {
    multipath {
        wwid          3600a098038304173475d4c766a49744e
        alias         node1_os
    }

    multipath {
        wwid          3600a098038304173475d4c766a49754a
        alias         ocrvote_1
    }

    multipath {
        wwid          3600a098038304173452b4c7959614634
        alias         ocrvote_2
    }

    multipath {
        wwid          3600a098038304173475d4c766a49754b
        alias         oradata_slob_1
    }

    multipath {
        wwid          3600a098038304173452b4c7959614635
        alias         oradata_slob_2
    }

    multipath {
        wwid          3600a098038304173475d4c766a49754c
        alias         oradata_slob_3
    }

    multipath {
        wwid          3600a098038304173452b4c7959614636
```

```
        alias          oradata_slob_4
    }
    multipath {
        wwid            3600a098038304173475d4c766a49754d
        alias          oradata_slob_5
    }
    multipath {
        wwid            3600a098038304173452b4c7959614637
        alias          oradata_slob_6
    }
    multipath {
        wwid            3600a098038304173475d4c766a49754e
        alias          oradata_slob_7
    }
    multipath {
        wwid            3600a098038304173452b4c7959614638
        alias          oradata_slob_8
    }
    multipath {
        wwid            3600a098038304173475d4c766a49754f
        alias          oradata_slob_9
    }
    multipath {
        wwid            3600a098038304173452b4c7959614639
        alias          oradata_slob_10
    }
    multipath {
        wwid            3600a098038304173475d4c766a497550
        alias          oradata_slob_11
    }
    multipath {
        wwid            3600a098038304173452b4c795961462d
```

```
        alias          oradata_slob_12
    }
    multipath {
        wwid            3600a098038304173475d4c766a497551
        alias          oradata_slob_13
    }
    multipath {
        wwid            3600a098038304173452b4c7959614641
        alias          oradata_slob_14
    }
    multipath {
        wwid            3600a098038304173475d4c766a497552
        alias          oradata_slob_15
    }
    multipath {
        wwid            3600a098038304173452b4c7959614642
        alias          oradata_slob_16
    }
    multipath {
        wwid            3600a098038304173475d4c766a497553
        alias          oraredo_slob_1
    }
    multipath {
        wwid            3600a098038304173452b4c7959614643
        alias          oraredo_slob_2
    }
    multipath {
        wwid            3600a098038304173475d4c766a497563
        alias          oradata_oltp_1
    }
    multipath {
        wwid            3600a098038304173452b4c795961464e
```

```
        alias          oradata_oltp_2
    }
multipath {
    wwid              3600a098038304173475d4c766a497564
    alias            oradata_oltp_3
}
multipath {
    wwid              3600a098038304173452b4c795961464f
    alias            oradata_oltp_4
}
multipath {
    wwid              3600a098038304173475d4c766a497565
    alias            oradata_oltp_5
}
multipath {
    wwid              3600a098038304173452b4c7959614650
    alias            oradata_oltp_6
}
multipath {
    wwid              3600a098038304173475d4c766a497566
    alias            oradata_oltp_7
}
multipath {
    wwid              3600a098038304173452b4c7959614651
    alias            oradata_oltp_8
}
multipath {
    wwid              3600a098038304173475d4c766a497567
    alias            oradata_oltp_9
}
multipath {
    wwid              3600a098038304173452b4c7959614652
```

```
        alias          oradata_oltp_10
    }
multipath {
    wwid              3600a098038304173475d4c766a497568
    alias            oradata_oltp_11
}
multipath {
    wwid              3600a098038304173452b4c7959614653
    alias            oradata_oltp_12
}
multipath {
    wwid              3600a098038304173475d4c766a497569
    alias            oradata_oltp_13
}
multipath {
    wwid              3600a098038304173452b4c7959614654
    alias            oradata_oltp_14
}
multipath {
    wwid              3600a098038304173475d4c766a49756a
    alias            oradata_oltp_15
}
multipath {
    wwid              3600a098038304173452b4c7959614655
    alias            oradata_oltp_16
}
multipath {
    wwid              3600a098038304173475d4c766a49756b
    alias            oraredo_oltp_1
}
multipath {
    wwid              3600a098038304173452b4c7959614656
```

```
        alias          oraredo_oltp_2
    }
multipath {
    wwid              3600a098038304173475d4c766a49756c
    alias            oradata_soe_1
}
multipath {
    wwid              3600a098038304173452b4c7959614657
    alias            oradata_soe_2
}
multipath {
    wwid              3600a098038304173475d4c766a49756d
    alias            oradata_soe_3
}
multipath {
    wwid              3600a098038304173452b4c7959614658
    alias            oradata_soe_4
}
multipath {
    wwid              3600a098038304173475d4c766a49756e
    alias            oradata_soe_5
}
multipath {
    wwid              3600a098038304173452b4c7959614659
    alias            oradata_soe_6
}
multipath {
    wwid              3600a098038304173475d4c766a49756f
    alias            oradata_soe_7
}
multipath {
    wwid              3600a098038304173452b4c795961465a
```

```
        alias          oradata_soe_8
    }
multipath {
    wwid              3600a098038304173475d4c766a497570
    alias            oradata_soe_9
}
multipath {
    wwid              3600a098038304173452b4c795961462f
    alias            oradata_soe_10
}
multipath {
    wwid              3600a098038304173475d4c766a497571
    alias            oradata_soe_11
}
multipath {
    wwid              3600a098038304173452b4c7959614661
    alias            oradata_soe_12
}
multipath {
    wwid              3600a098038304173475d4c766a497572
    alias            oradata_soe_13
}
multipath {
    wwid              3600a098038304173452b4c7959614662
    alias            oradata_soe_14
}
multipath {
    wwid              3600a098038304173475d4c766a497573
    alias            oradata_soe_15
}
multipath {
    wwid              3600a098038304173452b4c7959614663
```

```
        alias          oradata_soe_16
    }
    multipath {
        wwid            3600a098038304173475d4c766a497574
        alias          oraredo_soe_1
    }
    multipath {
        wwid            3600a098038304173452b4c7959614664
        alias          oraredo_soe_2
    }
    multipath {
        wwid            3600a098038304173475d4c766a497575
        alias          oradata_dss_1
    }
    multipath {
        wwid            3600a098038304173452b4c7959614665
        alias          oradata_dss_2
    }
    multipath {
        wwid            3600a098038304173475d4c766a497576
        alias          oradata_dss_3
    }
    multipath {
        wwid            3600a098038304173452b4c7959614666
        alias          oradata_dss_4
    }
    multipath {
        wwid            3600a098038304173475d4c766a497577
        alias          oradata_dss_5
    }
    multipath {
        wwid            3600a098038304173452b4c7959614667
```

```
        alias          oradata_dss_6
    }
    multipath {
        wwid            3600a098038304173475d4c766a497578
        alias          oradata_dss_7
    }
    multipath {
        wwid            3600a098038304173452b4c7959614668
        alias          oradata_dss_8
    }
    multipath {
        wwid            3600a098038304173475d4c766a497579
        alias          oradata_dss_9
    }
    multipath {
        wwid            3600a098038304173452b4c7959614669
        alias          oradata_dss_10
    }
    multipath {
        wwid            3600a098038304173475d4c766a49757a
        alias          oradata_dss_11
    }
    multipath {
        wwid            3600a098038304173452b4c795961466a
        alias          oradata_dss_12
    }
    multipath {
        wwid            3600a098038304173475d4c766a497630
        alias          oradata_dss_13
    }
    multipath {
        wwid            3600a098038304173452b4c795961466b
```

```

        alias          oradata_dss_14
    }
    multipath {
        wwid            3600a098038304173475d4c766a497631
        alias           oradata_dss_15
    }
    multipath {
        wwid            3600a098038304173452b4c795961466c
        alias           oradata_dss_16
    }
    multipath {
        wwid            3600a098038304173475d4c766a497632
        alias           oraredo_dss_1
    }
    multipath {
        wwid            3600a098038304173452b4c795961466d
        alias           oraredo_dss_2
    }
}

```

Configuration of “/etc/sysctl.conf”

```

# oracle-database-server-12cR2-preinstall setting for fs.file-max is 6815744
fs.file-max = 6815744

# oracle-database-server-12cR2-preinstall setting for kernel.sem is '250 32000 100
128'
kernel.sem = 250 32000 100 128

# oracle-database-server-12cR2-preinstall setting for kernel.shmmni is 4096
kernel.shmmni = 4096

# oracle-database-server-12cR2-preinstall setting for kernel.shmall is 1073741824 on
x86_64
kernel.shmall = 1073741824

# oracle-database-server-12cR2-preinstall setting for kernel.shmmax is 4398046511104
on x86_64
kernel.shmmax = 4398046511104

```

```

# oracle-database-server-12cR2-preinstall setting for kernel.panic_on_oops is 1 per
Orabug 19212317

kernel.panic_on_oops = 1

# oracle-database-server-12cR2-preinstall setting for net.core.rmem_default is
262144

net.core.rmem_default = 262144

# oracle-database-server-12cR2-preinstall setting for net.core.rmem_max is 4194304

net.core.rmem_max = 4194304

# oracle-database-server-12cR2-preinstall setting for net.core.wmem_default is
262144

net.core.wmem_default = 262144

# oracle-database-server-12cR2-preinstall setting for net.core.wmem_max is 1048576

net.core.wmem_max = 1048576

# oracle-database-server-12cR2-preinstall setting for net.ipv4.conf.all.rp_filter is
2

net.ipv4.conf.all.rp_filter = 2

# oracle-database-server-12cR2-preinstall setting for
net.ipv4.conf.default.rp_filter is 2

net.ipv4.conf.default.rp_filter = 2

# oracle-database-server-12cR2-preinstall setting for fs.aio-max-nr is 1048576

fs.aio-max-nr = 1048576

# oracle-database-server-12cR2-preinstall setting for net.ipv4.ip_local_port_range
is 9000 65500

net.ipv4.ip_local_port_range = 9000 65500

vm.nr_hugepages=180000

```

Configuration of `/etc/security/limits.d/oracle-database-server-12cR2-preinstall.conf`

```

# oracle-database-server-12cR2-preinstall setting for nofile soft limit is 1024

oracle soft nofile 1024

# oracle-database-server-12cR2-preinstall setting for nofile hard limit is 65536

oracle hard nofile 65536

# oracle-database-server-12cR2-preinstall setting for nproc soft limit is 16384

# refer orabug15971421 for more info.

oracle soft nproc 16384

# oracle-database-server-12cR2-preinstall setting for nproc hard limit is 16384

oracle hard nproc 16384

```

```

# oracle-database-server-12cR2-preinstall setting for stack soft limit is 10240KB
oracle  soft  stack  10240

# oracle-database-server-12cR2-preinstall setting for stack hard limit is 32768KB
oracle  hard  stack  32768

# oracle-database-server-12cR2-preinstall setting for memlock hard limit is maximum
of 128GB on x86_64 or 3GB on x86 OR 90 % of RAM
oracle  hard  memlock  473985890

# oracle-database-server-12cR2-preinstall setting for memlock soft limit is maximum
of 128GB on x86_64 or 3GB on x86 OR 90% of RAM
oracle  soft  memlock  473985890

```

Configuration of "/etc/udev/rules.d/99-oracle-asmdevices.rules"

```

#All LUNs which starts with dg_orarac_* #
ENV{DM_NAME}=="ocrvote_*", OWNER:="grid", GROUP:="oinstall", MODE:="660"

#All LUNs which starts with dg_oradata_* #
ENV{DM_NAME}=="oradata_*", OWNER:="oracle", GROUP:="oinstall", MODE:="660"

#All LUNs which starts with dg_oraredo_* #
ENV{DM_NAME}=="oraredo_*", OWNER:="oracle", GROUP:="oinstall", MODE:="660"

#All LUNs which starts with dg_oraarchive_* #
ENV{DM_NAME}=="oraarchive_*", OWNER:="oracle", GROUP:="oinstall", MODE:="660"

```

References

The following references were used in preparing this document.

Cisco Unified Computing System

<https://www.cisco.com/c/en/us/products/servers-unified-computing/index.html>

Cisco UCS Data Center Design Guides

<https://www.cisco.com/c/en/us/solutions/design-zone/data-center-design-guides/data-center-design-guides-all.html#Hyperconverged>

FlexPod Converged Infrastructure

<https://www.cisco.com/c/en/us/solutions/data-center-virtualization/flexpod/index.html#~tab-resources>

<https://www.netapp.com/us/products/converged-systems/flexpod-converged-infrastructure.aspx>

Cisco UCS B200 M5 Servers

<https://www.cisco.com/c/en/us/products/collateral/servers-unified-computing/ucs-b-series-blade-servers/datasheet-c78-739296.html>

Oracle Database 12c Release 2

<https://docs.oracle.com/en/database/oracle/oracle-database/12.2/index.html>

NetApp AFF A-Series All Flash Storage

<https://www.netapp.com/us/products/storage-systems/all-flash-array/aff-a-series.aspx>

https://www.netapp.com/us/media/ds-3582_tcm10-121337.pdf

<https://hww.netapp.com/Controller/Index>

<https://www.netapp.com/us/products/storage-systems/disk-shelves-and-storage-media/index.aspx#tech-specs>

NetApp Support

<https://mysupport.netapp.com/>

For a comprehensive list of storage hardware specifications, including supported media type and capacities, see the [NetApp Hardware Universe](#).

About the Authors

Tushar Patel, Principal Engineer, CSPG UCS Product Management and Data Center Solutions Engineering Group, Cisco Systems, Inc.

Tushar Patel is a Principal Engineer in the Cisco Systems CSPG UCS Product Management and Data Center Solutions Engineering Group and a specialist in flash storage technologies and Oracle RAC RDBMS. Tushar has over 23 years of experience in Flash Storage architecture, database architecture, design and performance. Tushar also has strong background in Intel X86 architecture, hyper converged systems, storage technologies and virtualization. He has worked with large number of enterprise customers, evaluate and deploy mission critical database solutions. Tushar has presented to both internal and external audiences at various conferences and customer events.

Hardikkumar Vyas, Solution Engineer, CSPG UCS Product Management and Data Center Solutions Engineering Group, Cisco Systems, Inc.

Hardikkumar Vyas is a Solution Engineer in the Cisco Systems CSPG UCS Product Management and Data Center Solutions Engineering Group for configuring, implementing and validating infrastructure best practices for highly available Oracle RAC databases solutions on Cisco UCS Servers, Cisco Nexus Products and various storage technologies. Hardikkumar Vyas holds a Master's degree in Electrical Engineering and has over 5 years of experience working with Oracle RAC Databases and associated applications. Hardikkumar Vyas's main focus is developing database solutions on different platforms, perform benchmarks, prepare reference architectures and write technical documents for Oracle RAC Databases on Cisco UCS Platforms.

Acknowledgements

For their support and contribution to the design, validation, and creation of this Cisco Validated Design, the authors would like to thank:

James Bradshaw, NetApp