



## FM-SHIELD QUICK INSTALLATION DIAGRAM

FM-Shield is applicable to FM3500 Endo, FM4200-series and FM4500-series radios only.

This diagram shows the vital dimensions and locations of the Cisco (formerly Fluidmesh) FM-SHIELD installation components, and gives a broad outline of how to assemble FM-SHIELD.

If installing FM-SHIELD on a tubular mount of 1.75" to 2.5" (44mm to 63mm) diameter, the mounting bracket clamps (measuring 78mm from hole to hole, right) must be positioned as seen.

If installing the FM-SHIELD on a tubular mount of 0.75" to 1.5" (19mm to 38mm) diameter, the *small* crescent side of the mounting bracket must be in contact with the tubular mount.

This quick diagram is not a substitute for detailed installation instructions. For detailed instructions on how to install FM-SHIELD on flat surfaces and tubular mounting points, refer to the *FM-SHIELD installation manual*.

