

## Cisco® Stealthwatch® デフォルト設定

製品	IP	マスク	ゲートウェイ
NetFlow の FC	192.168.1.4	255.255.255.0	192.168.1.1
sFlow の FC	192.168.1.5	255.255.255.0	192.168.1.1
UDP Director™	192.168.1.2	255.255.255.0	192.168.1.1
FlowSensor	192.168.1.7	255.255.255.0	192.168.1.1
IDentity	192.168.1.100	255.255.255.0	192.168.1.1
SMC	192.168.1.11	255.255.255.0	192.168.1.1

admin = lan411cope

sysadmin = lan1cope