



END-OF-SALE AND END-OF-LIFE ANNOUNCEMENT FOR THE CISCO 6000 SERIES DSL ACCESS MULTIPLEXER

Cisco Systems® announces the end-of-sale and end-of-life dates for the Cisco® 6000 Series DSL Access Multiplexer (DSLAM). The Cisco 6000 Series DSLAM is comprised of the Cisco 6160, 6015, and 6260 platforms and all supporting DSLAM products and software (see Table 2). The last day to order the Cisco 6000 Series DSLAMs and all supporting DSLAM cards is March 31, 2006. Customers with active service contracts will continue to receive support from the Cisco Technical Assistance Center (TAC) until March 31, 2011.

Table 1 describes the end-of-life milestones, definitions, and dates for the Cisco 6000 Series DSLAMs, and all supporting DSLAM cards and software. Table 2 lists the product part numbers affected by this announcement.

There is no product migration plan.

Table 1. End-of-Life Milestones and Dates for the Cisco 6000 Series DSLAM

Milestone	Definition	Date
End-of-Life Announcement Date	The date the document that announces the end of sale and end of life of a product is distributed to the general public.	March 31, 2005
End-of-Sale Date	The last date to order the product through Cisco point-of-sale mechanisms. The product is no longer for sale after this date.	March 31, 2006
Last Shipment Date	The last-possible ship date that can be requested of Cisco and/or its contract manufacturers. Actual ship date is dependent on lead time.	June 30, 2006
End of Software Maintenance Releases Date	The last date that Cisco Engineering may release any final software maintenance releases or bug fixes. After this date, Cisco Engineering will no longer develop, repair, maintain, or test the product software.	March 31, 2008
End of Routine Failure Analysis Date	The last-possible date a routine failure analysis may be performed to determine the cause of product failure or defect.	March 31, 2007
End of New Service Attachment Date	For equipment and software that is not covered by a service-and-support contract, this is the last date to order a new service-and-support contract or add the equipment and/or software to an existing service-and-support contract.	March 31, 2007
End of Service Contract Renewal Date	The last date to extend or renew a service contract for the product. The extension or renewal period cannot extend beyond the last date of support.	December 31, 2010
Last Date of Support	The last date to receive service and support for the product. After this date, all support services for the product are unavailable, and the product becomes obsolete.	March 31, 2011

Table 2. Product Part Numbers Affected by This Announcement

End-of-Sale Product Part Number	Product Description
Cisco 6160 DSLAM Products	
CISCO6160	Cisco 6160 IPDSL Switch
CISCO6160=	Cisco 6160 IPDSL Switch---Spare
Cisco6160-RF	Cisco 6160 Refurbished
CISCO6160S1	Cisco 6160 DSL IP Low Noise
CISCO6160S1=	Cisco 6160 DSL IP Low Noise---Spare
6160CHAS-W/IO-1	Cisco 6160 Chassis with DS3/OC3 I/O Card Installed
6160CHAS-W/IO-2	Cisco 6160 Chassis with DS3/2DS3+OC3+8xT1 IMA I/O Card Installed
CHAS-6160	Chassis only for Cisco 6160
CHAS-6160=	Chassis only for Cisco 6160---Spare
CHAS-6160S1	Chassis only for Cisco 6160, Low Noise
NI-2-DS3-DS3	Network Interface, 1 DS3 WAN, 2 DS3 Subtend---Spare
NI-2-DS3-DS3=	Network Interface, 1 DS3 WAN, 2 DS3 Subtend---Spare
NI-2-155SM-DS3	Network Interface, 1 OC3/STM1 Single Mode WAN; 2 DS3 Subtend
NI-2-155SM-DS3=	Network Interface, 1 OC3/STM1 Single Mode WAN; 2 DS3 Subtend---Spare
NI-2-155MM-DS3	Network Interface, 1 OC3/STM1 Multi Mode WAN; 2 DS3 Subtend
NI-2-155MM-DS3=	Network Interface, 1 OC3/STM1 Multi Mode WAN; 2 DS3 Subtend---Spare
NI-2-DS3-T1E1	Network Interface, 1 DS3 WAN; 8 T1/E1
NI-2-DS3-T1E1=	Network Interface, 1 DS3 WAN; 8 T1/E1---Spare
6160-1-I/O-1	Cisco 6160 Network I/O Card (DS3/OC3)
6160-1-I/O-1=	Cisco 6160 Network I/O Card (DS3/OC3)---Spare
6160-1-I/O-1-RF	Cisco 6160 Network I/O Card (DS3/OC3)---Refurbished
6160-1-I/O-2	Cisco 6160 Network I/O Card (DS3/OC3/T1)
6160-1-I/O-2=	Cisco 6160 Network I/O Card (DS3/OC3/T1)---Spare
6160-1-PEM-DC	Cisco 6160 48V DC Power Entry Module
6160-1-PEM-DC=	Cisco 6160 48V DC Power Entry Module---Spare
6160-1-PEM-DC-RF	Cisco 6160 48V DC Power Entry Module---Refurbished
ATUC-8-DMT-1	8 Port DMT Issue 2 Line Card
ATUC-8-DMT-1=	8 Port DMT Issue 2 Line Card---Spare
ATUC-8-DMT-1-RF	8 Port DMT Issue 2 Line Card---Refurbished
S61AB21-12212DA	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.12
S61AB21-12212DA =	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.12---Spare

End-of-Sale Product Part Number	Product Description
S61AB21-12210DA	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.10
S61AB21-12210DA=	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.10---Spare
S61AB21-12207DA	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.07
S61AB21-12207DA=	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.07---Spare
S61AB21-12205DA	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.05
S61AB21-12205DA=	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.05---Spare
S61AB21-12201DA	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.01
S61AB21-12201DA =	Cisco 6160 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.01---Spare
FL61-02	Cisco IOS® 6100/6130 DSL Concentrator---ATM QOS
FL61-02=	Cisco IOS 6100/6130 DSL Concentrator---ATM QOS---Spare
FL61-03	Cisco IOS 61XX Series IP DSL Switch---Subtending License
FL61-03=	Cisco IOS 61XX Series IP DSL Switch---Subtending License---Spare
FL61-04	Cisco IOS 6100/6130 DSL Concentrator---Signaling
FL61-04=	Cisco IOS 6100/6130 DSL Concentrator---Signaling---Spare
FL61-05	Cisco IOS 6100/6130 DSL Concentrator---O2 to O4 Bundle
FL61-05=	Cisco IOS 6100/6130 DSL Concentrator---O2 to O4 Bundle---Spare
FL61-06	Cisco IOS 61XX Series IP DSL Switch---MPLS License
FL61-06=	Cisco IOS 61XX Series IP DSL Switch---MPLS License---Spare
FL61-07	Cisco IOS 6160 IP DSL Switch---FL61-03, FL61-06 Bundle
FL61-07=	Cisco IOS 6160 IP DSL Switch---FL61-03, FL61-06 Bundle---Spare
FL61-08	Cisco IOS 61XX Series IP DSL Switch---Open DSL Proxy Element
FL61-08=	Cisco IOS 61XX Series IP DSL Switch---Open DSL Proxy Element---Spare
FL61-09	Cisco IOS 6160 IP DSL Switch---L2TP License
FL61-09=	Cisco IOS 6160 IP DSL Switch---L2TP License---Spare
FL61-10	Cisco IOS 6160 IP DSL Switch---Redundancy
FL61-10=	Cisco IOS 6160 IP DSL Switch---Redundancy---Spare
LL-61-04	Cisco IOS 61XX Series IP DSL Concentrator --Signaling License (re-licensing for used equipment)
6160-AF-01=	Cisco 6160 Blower Tray Air Filters, Qty (5)
6160-1-BLOWER=	Cisco 6160 Spare Blower Assembly
6160-1-BLOWER-RF	Cisco 6160 Spare Blower Assembly---Refurbished
6160-2-BLOWER=	Cisco 6160 Spare Blower Assembly , Low Noise
6160-AF-01=	Cisco 6160 Blower Tray Air Filters (5)
CAB-6160-TRG	Test/Ring Generator Cable

End-of-Sale Product Part Number	Product Description
CAB-6160-TRG=	Test/Ring Generator Cable---Spare
6160-CMU	Cable management unit
6160-CMU=	Cable management unit---Spare
6160 I/O OPT	Cisco 6160 I/O Options
6160S1 I/O OPT	Cisco 6160S1 I/O Options
6160 ATM SW OPT	Cisco 6160 ATM Switching Options
6160 MODEM OPT	Cisco 6160 Modem Options
6160 NI2 OPTS	Cisco 6160 NI2 Card Options
NI2 OPTS	NI2 Card Options
6160 PEM OPT	Cisco 6160 PEM Options
6160 PEM SPARE OPT	Cisco 6160 PEM Options for a Spare Chassis
6160 PEM SOFTWARE OPT	Cisco 6160 Software options
6160-1-NI-BLANK	Blank panel for Cisco 6160 NI slot
6160-1-NI-BLANK=	Blank panel for Cisco 6160 NI slot---Spare
6160-1-PEM-BLANK	Blank panel for Cisco 6160 PEM slot
6160-1-PEM-BLANK=	Blank panel for Cisco 6160 PEM slot---Spare
6160-1-XTUC-BLANK	Blank panel for Cisco 6160 XTU-C slot
6160-1-XTUC-BLANK=	Blank panel for Cisco 6160 XTU-C slot---Spare
ATUC-BLANK-61	ATUC Blank plate for the Cisco 6100
ATUC-BLANK-61=	ATUC Blank plate for the Cisco 6100---Spare
EXPAND-6160	Cisco 6160 Expansion Items
CODSL-CIS6160-7	Two configured Cisco 6160s for a 7-ft rack
CODSL-CIS6160-11FT	11-ft Cisco 6160 Bay
CODSL-CIS6160-7F	7-ft Cisco 6160 Bay (obsolete)
CODSL-CIS6160-7FT	7-ft Cisco 6160 Bay
CODSL-CIS6160-9FT	9-ft Cisco 6160 Bay
Doc	EM Doc
Cisco 6260 DSLAM Products	
CISCO6260	Cisco 6260 Chassis with I/O
CISCO6260=	Cisco 6260 Chassis---Spare
CISCO6260-RF	Cisco 6260 Chassis---Refurbished
NI-2-155SM-155SM	Network Interface, 1 OC3/STM1 Single Mode; 1 WAN, 1 Subtend
NI-2-155SM-155SM=	Network Interface, 1 OC3/STM1 Single Mode; 1 WAN, 1 Subtend---Spare

End-of-Sale Product Part Number	Product Description
NI2-155SM-155SM2	Network Interface, 1 OC3/STM1 Single Mode; 1 WAN, 1 Subtend (Version 2)
NI2-155SM-155SM2=	Network Interface, 1 OC3/STM1 Single Mode; 1 WAN, 1 Subtend (Version 2)---Spare
NI-2-155MM-155MM	Network Interface, 1 OC3/STM1 Multi Mode; 1 WAN, 1 Subtend
NI-2-155MM-155MM=	Network Interface, 1 OC3/STM1 Multi Mode; 1 WAN, 1 Subtend---Spare
NI2-155MM-155MM2	Network Interface, 1 OC3/STM1 Multi Mode; 1 WAN, 1 Subtend (Version 2)
NI2-155MM-155MM2=	Network Interface, 1 OC3/STM1 Multi Mode; 1 WAN, 1 Subtend (Version 2)---Spare
NI-2-E3-E3	Network Interface, 1 E3 WAN, 2 E3 Subtend
NI-2-E3-E3=	Network Interface, 1 E3 WAN, 2 E3 Subtend---Spare
NI-2-DS3-T1E1	DS3 / T1E1 Network Interface
NI-2-DS3-T1E1=	DS3 / T1E1 Network Interface---Spare
PPN-NI2-DS3-T1E1-E	DS3 / T1E1---E Network Interface
IO-BOARD-1-62	Cisco 6260 Chassis Fiber I/O Connector Panel
IO-BOARD-1-62=	Cisco 6260 Chassis Fiber I/O Connector Panel---Spare
IO-E3X2E3	Cisco 6260 E3 Input/Output Module
IO-E3X2E3=	Cisco 6260 E3 Input/Output Module---Spare
I/O-8xE1IMA	Cisco 6260 8 Port E1 IMA Input/Output Module
I/O-8xE1IMA =	Cisco 6260 8 Port E1 IMA Input/Output Module---Spare
6260-E1-I/O-1	Cisco 6260 E1 Input / Output Card
6260-E1-I/O-1=	Cisco 6260 E1 Input / Output Card---Spare
6260-E3-I/O-1	Cisco 6260 E3 Input / Output Card
6260-E3-I/O-1=	Cisco 6260 E3 Input / Output Card---Spare
6260-LS1010-E3-1	Cisco 6260 LS1010 E3 Bundle
6260-LS1010-NxE1-1	Cisco 6260 LS1010 Nx E1 Bundle
6260-1-PEM-DC	Cisco 6260 48V DC Power Supply Module
6260-1-PEM-DC =	Cisco 6260 48V DC Power Supply Module---Spare
6260-1-PEM-AC	Cisco 6260 AC Power Supply Module
6260-1-PEM-AC=	Cisco 6260 AC Power Supply Module---Spare
STUC-8-SHDSL-1	8 Port G.SHDSL Line Card
STUC-8-SHDSL-1 =	8 Port G.SHDSL Line Card---Spare
ATUC-8-DMT-I-1	8 Port ADSL Annex B Line Card
ATUC-8-DMT-I-1=	8 Port ADSL Annex B Line Card---Spare
ATUC-8-DMT-I-1-RF	8 Port ADSL Annex B Line Card---Refurbished
6260-ATUC-8DMT-1	8 Port DMT Issue 2 Line Card

End-of-Sale Product Part Number	Product Description
6260-ATUC-8DMT-1=	8 Port DMT Issue 2 Line Card---Spare
S62AB21-12212DA	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.12
S62AB21-12212DA =	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.12---Spare
S62AB21-12210DA	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.10
S62AB21-12210DA=	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.10---Spare
S62AB21-12207DA	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.07
S62AB21-12207DA=	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.07---Spare
S62AB21-12205DA	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.05
S62AB21-12205DA=	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.05---Spare
S62AB21-12201DA	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.01
S62AB21-12201DA =	Cisco 6260 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.01---Spare
FL62-02	Cisco IOS 6260 Series IP DSL Switch---Subtending License
FL62-02=	Cisco IOS 6260 Series IP DSL Switch---Subtending License---Spare
FL62-03	Cisco IOS 6200 Series IP DSL Switch---QOS Upgrade
FL62-03=	Cisco IOS 6200 Series IP DSL Switch---QOS Upgrade---Spare
FL62-04	Cisco IOS 6260 Series IP DSL Switch---ATM Signaling
FL62-04=	Cisco IOS 6260 Series IP DSL Switch---ATM Signaling---Spare
FL62-05	Cisco IOS 6200 Series IP DSL Switch---02 to 05 bundle
FL62-05=	Cisco IOS 6200 Series IP DSL Switch---02 to 05 bundle---Spare
FL62-06	Cisco IOS 62XX Series IP DSL Switch---MPLS License
FL62-06=	Cisco IOS 62XX Series IP DSL Switch---MPLS License---Spare
FL62-07	Cisco IOS 62XX Series IP DSL Switch---FL62-03, FL62-06 Bundle
FL62-07=	Cisco IOS 62XX Series IP DSL Switch---FL62-03, FL62-06 Bundle---Spare
FL62-08	Cisco IOS 62XX Series IP DSL Switch---Open DSL Proxy Element
FL62-08=	Cisco IOS 62XX Series IP DSL Switch---Open DSL Proxy Element---Spare
FL62-09	Cisco IOS 6260 IP DSL Switch---L2TP License
FL62-09=	Cisco IOS 6260 IP DSL Switch---L2TP License---Spare
FL62-10	Cisco IOS 6260 IP DSL Switch---Redundancy
FL62-10=	Cisco IOS 6260 IP DSL Switch---Redundancy---Spare
FL62ZPRE-12.0(5)DA	Cisco 6260 Feature license---All features
FL62ZQOS-12.0(5)DA	Cisco 6260 Feature license---ATM QOS
FL62ZSIG-12.0(5)DA	Cisco 6260 Feature license---ATM SVCs, SPVCs
FL62ZSRC-12.0(5)DA	Cisco 6260 Feature license---1+1 System and 1:N Access redundancy

End-of-Sale Product Part Number	Product Description
FL62ZSTD-12.0(5)DA	Cisco 6260 Feature license---12x Subtending
FANTRAY-6260=	Cisco 6260 Fan Tray---Spare
FILTER-6260	Cisco 6260 Fan Tray Filter
FILTER-6260=	Cisco 6260 Fan Tray Filter---Spare
ATUC-BLANK-62	ATUC Blank Plate for Cisco 6260
ATUC-BLANK-62 =	ATUC Blank Plate for Cisco 6260---Spare
CAB-CON-NI	NI-2 Console Cable
CAB-CON-NI =	NI-2 Console Cable---Spare
CAB-6260-AC	AC Power cord for North America
CAB-6260-AC=	AC Power cord for North America---Spare
CAB-6260-ARG	AC Power cord for Argentina
CAB-6260-ARG=	AC Power cord for Argentina---Spare
CAB-6260-AUS	AC Power cord for Australia
CAB-6260-AUS=	AC Power cord for Australia---Spare
CAB-6260-EU	AC Power cord for Europe
CAB-6260-EU=	AC Power cord for Europe---Spare
CAB-6260-Italy	AC Power cord for Italy
CAB-6260-Italy=	AC Power cord for Italy---Spare
CAB-6260-UK	AC Power cord for United Kingdom
CAB-6260-UK=	AC Power cord for United Kingdom---Spare
6260 I/O OPTS	Cisco 6260 I/O Options
6260 IOS SW OPTS	Cisco 6260 Software Options
6260 LINE OPTS	Cisco 6260 Line Options
6260 NI2 OPTS	Cisco 6260 NI2 Options
6260 POWER OPTS	Cisco 6260 Power Supply Options
6260-PEM-BLANK	Cisco 6260 Power supply module blank filler panel
6260-PEM-BLANK=	Cisco 6260 Power supply module blank filler panel---Spare
NI-2-BLANK-62	NI-2 Card Filler Plate for Cisco 6260
NI-2-BLANK-62=	NI-2 Card Filler Plate for Cisco 6260---Spare
BR EXPAND 6260	BR Cisco 6260 Expansion options
EXPAND 6260	Cisco 6260 Expansion items
6260-CN-KIT	Cisco 6260 Clinch Nut replacement kit
ACS-6260	Cisco 6260 Accessory kit

End-of-Sale Product Part Number	Product Description
ACS-6260=	Cisco 6260 Accessory kit---Spare
DOC-786943=	Cisco 6260 Hardware Installation and Troubleshooting Guide
DOC-786690=	Command Ref Guide for Cisco 6000 Series DSLAMs with NI-2
DOC-786691=	Configuration Guide for Cisco 6000 Series DSLAMs with NI-2
Cisco 6015 DSLAM Products	
CISCO6015	Cisco 6015 DSL Chassis
CISCO6015=	Cisco 6015 DSL Chassis---Spare
CISCO6015-RF	Cisco 6015 DSL Chassis---Refurbished
CISCO6015-H	Hardened Cisco 6015 Chassis with I/O
CISCO6015-H=	Hardened Cisco 6015 Chassis---Spare
6015-24XDSL-I/F=	24X DSL interface card---Spare (not in use)
6015-48XDSL-I/F=	48X DSL interface card---Spare
6015-DS3/T1-IO	Cisco 6015 Network I/O Card (DS3/T1)
6015-DS3/T1-IO =	Cisco 6015 Network I/O Card (DS3/T1)---Spare
6015-E1-IO	Cisco 6015 Network I/O Card (E1)
6015-E1-IO=	Cisco 6015 Network I/O Card (E1)---Spare
6015-DS3/T1-IO-H	Cisco 6015 Network I/O Card (DS3/T1), Outside plant
6015-DS3/T1-IO-H =	Cisco 6015 Network I/O Card (DS3/T1), Outside plant---Spare
6015-DS3/T1-I/O-1	Cisco 6015 Network I/O Card (no longer in use)
6015-DS3/T1-I/O-1 =	Cisco 6015 Network I/O Card---Spare (no longer in use)
6015-E1-I/O-1	Cisco 6015 Network I/O Card (no longer in use)
6015-E1-I/O-1=	Cisco 6015 Network I/O Card---Spare (no longer in use)
PPN-6015-DS3/T1IOH	Cisco 6015 DS3/T1 input / output---H
PPN-6015-E1-IO-H	Cisco 6015 E1 input / output---H
6015-1-PEM-DC	Cisco 6015 48V DC Power Entry Module
6015-1-PEM-DC=	Cisco 6015 48V DC Power Entry Module---Spare
6015-1-PEM-AC-E	Cisco 6015 AC External Power Entry Module
6015-1-PEM-AC-E=	Cisco 6015 AC External Power Entry Module---Spare
6015-1-PEM-AC	Cisco 6015 AC PEM (No longer in use)
6015-1-PEM-DC-H	Cisco 6015 48V DC Power Entry Module, Outside plant
6015-1-PEM-DC-H=	Cisco 6015 48V DC Power Entry Module, Outside plant---Spare
PPN-6015-1-PEM-DCH	Cisco 6015 power module---H
ATUC-8-DMT-1-H	8 port DMT Issue 2 Line Card---Hardened

End-of-Sale Product Part Number	Product Description
ATUC-8-DMT-1-H=	8 port DMT Issue 2 Line Card---Hardened---Spare
S6015AB21-12212DA	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.12
S6015AB21-12212DA =	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.12---Spare
S6015AB21-12210DA	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.10
S6015AB21-12210DA=	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.10---Spare
S6015AB21-12207DA	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.07
S6015AB21-12207DA=	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.07---Spare
S6015AB21-12205DA	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.05
S6015AB21-12205DA=	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.05---Spare
S6015AB21-12201DA	Cisco 6015 IOS IP DSL SWITCH---BASE SOFTWARE---Ver 12.2.01
FL6015-03	Cisco IOS 6015 Series IP DSL Switch---Subtending License
FL6015-03=	Cisco IOS 6015 Series IP DSL Switch---Subtending License---Spare
FL6015-06	Cisco IOS 6015 Series IP DSL Switch---MPLS License
FL6015-06=	Cisco IOS 6015 Series IP DSL Switch---MPLS License---Spare
FL6015-07	Cisco IOS 6015 Series IP DSL Switch---FL61-03, FL61-06 Bundle
FL6015-07=	Cisco IOS 6015 Series IP DSL Switch---FL61-03, FL61-06 Bundle---Spare
FL6015-08	Cisco IOS 6015 Series IP DSL Switch---Open DSL proxy element
FL6015-08=	Cisco IOS 6015 Series IP DSL Switch---Open DSL proxy element---Spare
FL6015-09	Cisco IOS 6015 IP DSL Switch---L2TP License
FL6015-09=	Cisco IOS 6015 IP DSL Switch---L2TP License---Spare
FL6015-10	Cisco IOS 6015 IP DSL Switch---Redundancy
FL6015-10=	Cisco IOS 6015 IP DSL Switch---Redundancy---Spare
6015-FM-01=	Cisco 6015 Fan Module Spare
6015-AC-TRAY-1=	Cisco 6015 AC Power Supply Tray---Spare
6015 FL SW OPTS	Cisco 6015 feature license software options
6015 COMCL OPTS	Cisco 6015 commercial options
6015 I/O OPTS	Cisco 6015 input / output options
6015 IO OPTS	Cisco 6015 input / output options
6015 IOS SW OPTS	Cisco 6015 IOS software options
6015 LINE OPTS	Cisco 6015 line card options
6015 NI2 OPTS	Cisco 6015 network interface 2 options
6015 POWER OPTS	Cisco 6015 power supply options
6015 PWR CAB OPTS	Cisco 6015 power cable options

End-of-Sale Product Part Number	Product Description
6015 ITEMP LINE OC	Cisco 6015 ITEMP line card options
6015 ITEMP NI2 OC	Cisco 6015 ITEMP network interface-2 options
6015 ITEMP OPTS	Cisco 6015 ITEMP options
EXPAND 6015	Cisco 6015 Expansion items
DOC-MSSBU=	Technical manuals for this product are online only.

PRODUCT MIGRATION OPTIONS

There are no Cisco product migration options.

FOR MORE INFORMATION

For more information about the Cisco 6000 Series DSLAMs, contact your local account representative.

For more information about the Cisco End-of-Life Policy, go to: http://www.cisco.com/en/US/products/prod_end_of_life.html

To subscribe to receive end-of-life/end-of-sale information, go to: <http://www.cisco.com/cgi-bin/Support/FieldNoticeTool/field-notice>



Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
www.cisco.com
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

European Headquarters

Cisco Systems International BV
Haarlerbergpark
Haarlerbergweg 13-19
1101 CH Amsterdam
The Netherlands
www-europe.cisco.com
Tel: 31 0 20 357 1000
Fax: 31 0 20 357 1100

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
www.cisco.com
Tel: 408 526-7660
Fax: 408 527-0883

Asia Pacific Headquarters

Cisco Systems, Inc.
168 Robinson Road
#28-01 Capital Tower
Singapore 068912
www.cisco.com
Tel: +65 6317 7777
Fax: +65 6317 7799

Cisco Systems has more than 200 offices in the following countries and regions. Addresses, phone numbers, and fax numbers are listed on **the Cisco Website at www.cisco.com/go/offices.**

Argentina • Australia • Austria • Belgium • Brazil • Bulgaria • Canada • Chile • China PRC • Colombia • Costa Rica • Croatia • Cyprus
Czech Republic • Denmark • Dubai, UAE • Finland • France • Germany • Greece • Hong Kong SAR • Hungary • India • Indonesia • Ireland • Israel
Italy • Japan • Korea • Luxembourg • Malaysia • Mexico • The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal
Puerto Rico • Romania • Russia • Saudi Arabia • Scotland • Singapore • Slovakia • Slovenia • South Africa • Spain • Sweden • Switzerland • Taiwan
Thailand • Turkey • Ukraine • United Kingdom • United States • Venezuela • Vietnam • Zimbabwe

Copyright © 2005 Cisco Systems, Inc. All rights reserved. CCSP, CCVP, the Cisco Square Bridge logo, Follow Me Browsing, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Access Registrar, Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, Packet, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, StrataView Plus, TeleRouter, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0502R) 204123_r_ETMG_JC_3.05

