

Suggested Cisco IOS XE Software Releases for Cisco Catalyst 3850 and 3650 Series Switches

PB737420

This document lists the suggested Cisco[®] IOS[®] XE Software releases for use with Cisco Catalyst[®] 3850 and 3650 Series Switches. If you are running a release prior to the minimum suggested, Cisco advises upgrading the image to the suggested release. These suggestions are general and should not replace environment-specific design review efforts and should not override Advanced Services suggested releases if employed.

General Suggestion

For all the Cisco Catalyst 3650 and 3850 platforms Cisco suggests using Cisco IOS XE Software Release 16.3.6. **Customers are advised to migrate from older software releases to the suggested release.**

Cisco suggests that you review the Cisco IOS XE Software release notes for [3850/3650](#) to determine the effects of any open caveats.

In addition, consult Cisco Catalyst [3850/3650](#) release notes for minimum supported releases for specific hardware and software features.

Cisco Catalyst 3650 Product and Suggested Software

Product	Suggested Software
WS-C3650-24TS-L	16.3.6
WS-C3650-24TS-S	16.3.6
WS-C3650-24TS-E	16.3.6
WS-C3650-48TS-L	16.3.6
WS-C3650-48TS-S	16.3.6
WS-C3650-48TS-E	16.3.6
WS-C3650-24PS-L	16.3.6
WS-C3650-24PS-S	16.3.6
WS-C3650-24PS-E	16.3.6
WS-C3650-48PS-L	16.3.6
WS-C3650-48PS-S	16.3.6
WS-C3650-48PS-E	16.3.6
WS-C3650-48FS-L	16.3.6
WS-C3650-48FS-S	16.3.6
WS-C3650-48FS-E	16.3.6
WS-C3650-24TD-L	16.3.6
WS-C3650-24TD-S	16.3.6
WS-C3650-24TD-E	16.3.6

Product	Suggested Software
WS-C3650-48TD-L	16.3.6
WS-C3650-48TD-S	16.3.6
WS-C3650-48TD-E	16.3.6
WS-C3650-24PD-L	16.3.6
WS-C3650-24PD-S	16.3.6
WS-C3650-24PD-E	16.3.6
WS-C3650-48PD-L	16.3.6
WS-C3650-48PD-S	16.3.6
WS-C3650-48PD-E	16.3.6
WS-C3650-48FD-L	16.3.6
WS-C3650-48FD-S	16.3.6
WS-C3650-48FD-E	16.3.6
WS-C3650-48TQ-L	16.3.6
WS-C3650-48TQ-S	16.3.6
WS-C3650-48TQ-E	16.3.6
WS-C3650-48PQ-L	16.3.6
WS-C3650-48PQ-S	16.3.6
WS-C3650-48PQ-E	16.3.6
WS-C3650-48FQ-L	16.3.6
WS-C3650-48FQ-S	16.3.6
WS-C3650-48FQ-E	16.3.6
WS-C3650-24PDM-L	16.3.6
WS-C3650-24PDM-S	16.3.6
WS-C3650-24PDM-E	16.3.6
WS-C3650-48FQM-L	16.3.6
WS-C3650-48FQM-S	16.3.6
WS-C3650-48FQM-E	16.3.6
WS-C3650-8X24UQ-L	16.3.6
WS-C3650-8X24UQ-S	16.3.6
WS-C3650-8X24UQ-E	16.3.6
WS-C3650-12X48UQ-L	16.3.6
WS-C3650-12X48UQ-S	16.3.6
WS-C3650-12X48UQ-E	16.3.6
WS-C3650-12X48UR-L	16.3.6
WS-C3650-12X48UR-S	16.3.6
WS-C3650-12X48UR-E	16.3.6
WS-C3650-12X48UZ-L	16.3.6
WS-C3650-12X48UZ-S	16.3.6
WS-C3650-12X48UZ-E	16.3.6
WS-C3650-8X24PD-L	16.3.6
WS-C3650-8X24PD-S	16.3.6
WS-C3650-8X24PD-E	16.3.6

Product	Suggested Software
WS-C3650-12X48FD-L	16.3.6
WS-C3650-12X48FD-S	16.3.6
WS-C3650-12X48FD-E	16.3.6

Cisco Catalyst 3850 Product and Suggested Software

Product	Suggested Software
WS-C3850-24T-L	16.3.6
WS-C3850-24T-S	16.3.6
WS-C3850-24T-E	16.3.6
WS-C3850-48T-L	16.3.6
WS-C3850-48T-S	16.3.6
WS-C3850-48T-E	16.3.6
WS-C3850-24P-L	16.3.6
WS-C3850-24P-S	16.3.6
WS-C3850-24P-E	16.3.6
WS-C3850-48P-L	16.3.6
WS-C3850-48P-S	16.3.6
WS-C3850-48P-E	16.3.6
WS-C3850-48F-L	16.3.6
WS-C3850-48F-S	16.3.6
WS-C3850-48F-E	16.3.6
WS-C3850-24U-L	16.3.6
WS-C3850-24U-S	16.3.6
WS-C3850-24U-E	16.3.6
WS-C3850-48U-L	16.3.6
WS-C3850-48U-S	16.3.6
WS-C3850-48U-E	16.3.6
WS-C3850-12S-S	16.3.6
WS-C3850-12S-E	16.3.6
WS-C3850-24S-S	16.3.6
WS-C3850-24S-E	16.3.6
WS-C3850-24U-L	16.3.6
WS-C3850-24U-S	16.3.6
WS-C3850-24U-E	16.3.6
WS-C3850-48U-L	16.3.6
WS-C3850-48U-S	16.3.6
WS-C3850-48U-E	16.3.6
WS-C3850-24XU-L	16.3.6
WS-C3850-24XU-S	16.3.6
WS-C3850-24XU-E	16.3.6
WS-C3850-12X48U-L	16.3.6
WS-C3850-12X48U-S	16.3.6
WS-C3850-12X48U-E	16.3.6
WS-C3850-12XS-S	16.3.6

Product	Suggested Software
WS-C3850-12XS-E	16.3.6
WS-C3850-16XS-S	16.3.6
WS-C3850-16XS-E	16.3.6
WS-C3850-24XS-S	16.3.6
WS-C3850-24XS-E	16.3.6
WS-C3850-32XS-S	16.3.6
WS-C3850-32XS-E	16.3.6
WS-C3850-48XS-S	16.3.6
WS-C3850-48XS-E	16.3.6
WS-C3850-48XS-F-S	16.3.6
WS-C3850-48XS-F-E	16.3.6

Documentation and Software

For additional information, see the [Cisco Catalyst 3850 Series Switches](#) and [Cisco Catalyst 3650 Series Switches](#) product documentation page.

For software, see the [Download Software](#) page.

Obtaining Documentation and Submitting a Service Request

For information about obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). The RSS feeds are a free service.



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA

Asia Pacific Headquarters
Cisco Systems (USA) Pte. Ltd.
Singapore

Europe Headquarters
Cisco Systems International BV Amsterdam,
The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at <https://www.cisco.com/go/offices>.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)