

Running OROUTED to Exchange RIP Routing Updates

Document ID: 12258

Contents

Introduction

Prerequisites

- Requirements

- Components Used

- Conventions

Background Information

Configuration

Related Information

Introduction

This document gives an example of the configuration required on the router and on the mainframe to exchange RIP routing updates through the use of the OROUTED procedure. OROUTED is a procedure which runs on the mainframe and which performs essentially the same function as when you run the ROUTED daemon on a UNIX host. OROUTED runs from either the OpenEdition/Multiple Virtual Storage (OMVS) address space or as a started task.

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

This configuration was developed and tested with these software and hardware versions:

- Cisco IOS[®] Software Release 12.1(2) with Mainframe Channel Port Adapter (XCPA) microcode xcpa27-7.

This was the latest version of code released at the time, but these features should be supported in all currently maintained major versions of code.

- The router is a Cisco 7206 with a PCPA (Parallel Channel Port Adapter).

OROUTED requires these two configuration files on the mainframe in the OMVS address space, with environment variables that point to their location:

- export ROUTED_PROFILE=/etc/orouted.profile
- export RESOLVER_CONF=/etc/resolv.conf

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

Background Information

In order to start OROUTED, issue these commands from within OMVS:

```
cd /usr/lpp/tcpip/sbin  
  
orouted
```

On the MVS console, you can issue this command in order to find the process number of the OROUTED process:

```
d omvs,u=p390
```

Note: **p390** is the logon identification under which OROUTED was started.

You can also start the OROUTED process through job control language (JCL), as a started task. If you start it from OMVS, change the 520 port in the TCP/IP profile dataset to OMVS.

These are examples of the datasets:

```
/etc/orouted.profile  
RIP_SUPPLY_CONTROL: RIP1  
RIP_RECEIVE_CONTROL: ANY  
RIP2_AUTHENTICATION_KEY:  
/etc/resolv.conf  
TCPIPJobName TCPIP  
DomainOrigin cisco.com  
domain cisco.com  
Datasetprefix TCPIP  
HostName P390  
Messagecase mixed  
  
TCP/IP profile dataset configuration changes  
-----  
  
; ----- ;  
  
;  
orouted Routing Information  
;  
; if you are using orouted, comment out the GATEWAY statement and  
; update the BSDROUTINGPARMS statement to reflect your installation  
; configuration and remove the semicolon  
;  
; Link      Maxmtu   Metric   Subnet Mask      Dest Addr  
BSDROUTINGPARMS false  
LDIPTG      1500      0       255.255.255.240  10.64.3.33  
VIPALINK    1500      0       255.255.255.240  0  
ENDBSDROUTINGPARMS  
; -----  
RIP
```

Configuration

Channel Interface Processor (CIP) Router
--

```

version 12.1
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
hostname diplodocus
!
boot system flash slot1:c7200-a3js-mz.121-2.bin
!
!
!
!
!
microcode pcpa slot1:xcpa27-9
microcode reload
!
interface Channel2/0
ip address 10.64.3.33 255.255.255.240
no keepalive
csna 0100 41
csna 0100 42
cmpc 0100 24 DIPTG READ
cmpc 0100 25 DIPTG WRITE
lan TokenRing 0
source-bridge 4 1 1
adapter 0 4000.0000.0001
adapter 1 4000.0000.0002
adapter 2 4000.0000.0003
adapter 3 4000.0000.0004
adapter 4 4000.0000.0005
lan TokenRing 1
source-bridge 5 1 1
adapter 7 4000.0000.0001
tn3270-server
pu PU1      01712444 10.64.3.35      token-adapter 1  04 rmac
4000.0000.0001  lu-seed DIPL###
pu PU2      01712555 10.64.3.36      token-adapter 1  08 rmac
4000.0000.0001  lu-seed DIPL2##
tg DIPTG     ip 10.64.3.34 10.64.3.33 broadcast
!
!
router eigrp 1
redistribute rip
passive-interface Channel2/0
network 10.0.0.0
passive-interface Ethernet6/1
passive-interface Ethernet6/3
network 10.0.0.0
!
no auto-summary
!
router rip
redistribute eigrp 1
passive-interface Serial1/3
passive-interface TokenRing5/0

```

Related Information

- [Technical Support & Documentation – Cisco Systems](#)

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2014 – 2015 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Sep 09, 2005

Document ID: 12258
