

Configuring HTTPS Access on RV180

Objective

This document explains how to enable HTTPS access on the LAN interface of the Cisco RV180/RV180W. If a user connects a PC to the LAN port, web access is then allowed using secure connection.

Applicable Device

- RV180

Configuration of HTTPS Access

Step 1. In the configuration utility of the RV180, click to **Administration > Management interface > Web Access**.

Web Access

LAN

HTTPS Web Access on LAN Interface: Enable

Remote Management

Remote Management: Enable

Access Type: All IP Addresses

Start of Range: (xxx.xxx.xxx.xxx)

End of Range: (xxx.xxx.xxx.xxx)

IP Address: (xxx.xxx.xxx.xxx)

Port Number: 443 (Range: 1 - 65535, Default: 443)

Remote SNMP: Enable

Save Cancel

Step 2. Under HTTPS Web Access on LAN Interface, check **Enable** to enforce HTTPS web access on the LAN Interface.

Step 3. Click **Save** to save the configuration.