

Restart SPA300 and SPA500 Series IP Phones

Objectives

This article describes how to restart the SPA300 and SPA500 Series IP Phones. Restart will reload the phone with important files like configuration file, etc., and any changes in the configuration gets reflected after restart.


NOTE: The IP Phone should not be Rebooted, Restarted or Reset unless directed by your phone administrator as this can negatively affect the phone's function. This is because it may alter the phone's configuration as it reloads the configuration file which contains all updates and modifications pertaining to phones.

Applicable Devices

- SPA300 Series
- SPA500 Series

Restart the IP Phone

Step 1. Press the **Setup** button on the keypad.



Step 2. Scroll to **Restart** and press **Select** or alternatively, press **6**.

Step 3. To complete the restart process, press **OK** at the confirmation message or to close the message without restarting the phone, press **Cancel**.