



CLI COMMAND SUMMARY BY MODE

Configuration Mode Commands

- (config) aaa accounting [3-269](#)
- (config) adapter [3-273](#)
- (config) alarm overload-detect [3-274](#)
- (config) asset [3-276](#)
- (config) authentication [3-277](#)
- (config) auto-register [3-282](#)
- (config) banner [3-285](#)
- (config) bypass [3-288](#)
- (config) cdp [3-290](#)
- (config) central-manager [3-292](#)
- (config) clock [3-295](#)
- (config) cms [3-300](#)
- (config) device mode [3-302](#)
- (config) disk disk-name [3-304](#)
- (config) disk encrypt [3-306](#)
- (config) disk error-handling [3-308](#)
- (config) disk logical shutdown [3-310](#)
- (config) egress-method [3-311](#)
- (config) end [3-313](#)
- (config) exec-timeout [3-314](#)
- (config) exit [3-315](#)
- (config) external-ip [3-316](#)
- (config) flow monitor [3-318](#)
- (config) help [3-319](#)
- (config) hostname [3-321](#)
- (config) inetd [3-322](#)
- (config) interface [3-323](#)
- (config) ip [3-329](#)
- (config) ip access-list [3-332](#)
- (config) kerberos [3-335](#)
- (config) kernel [3-337](#)
- (config) line [3-338](#)
- (config) logging [3-339](#)
- (config) no [3-343](#)
- (config) ntp [3-345](#)
- (config) policy-engine application classifier [3-346](#)
- (config) policy-engine application map adaptor EPM [3-348](#)
- (config) policy-engine application map adaptor WAFS transport [3-350](#)
- (config) policy-engine application map basic delete [3-352](#)
- (config) policy-engine application map basic disable [3-353](#)
- (config) policy-engine application map basic insert [3-354](#)
- (config) policy-engine application map basic list [3-355](#)
- (config) policy-engine application map basic move [3-356](#)
- (config) policy-engine application map basic name [3-357](#)
- (config) policy-engine application map other optimize DRE [3-359](#)
- (config) policy-engine application map other optimize full [3-361](#)
- (config) policy-engine application map other pass-through [3-362](#)
- (config) policy-engine application name [3-363](#)
- (config) policy-engine config [3-365](#)
- (config) port-channel [3-366](#)
- (config) primary-interface [3-367](#)
- (config) print-services [3-369](#)
- (config) radius-server [3-372](#)
- (config) smb-conf [3-374](#)
- (config) snmp-server access-list [3-378](#)
- (config) snmp-server community [3-379](#)

- (config) snmp-server contact [3-381](#)
- (config) snmp-server enable traps [3-382](#)
- (config) snmp-server group [3-385](#)
- (config) snmp-server host [3-387](#)
- (config) snmp-server location [3-389](#)
- (config) snmp-server mib [3-390](#)
- (config) snmp-server notify inform [3-392](#)
- (config) snmp-server user [3-393](#)
- (config) snmp-server view [3-395](#)
- (config) sshd [3-396](#)
- (config) ssh-key-generate [3-399](#)
- (config) tacacs [3-400](#)
- (config) tcp [3-403](#)
- (config) telnet enable [3-406](#)
- (config) tfo auto-discovery [3-407](#)
- (config) tfo optimize [3-408](#)
- (config) tfo tcp keepalive [3-409](#)
- (config) tfo tcp optimized-mss [3-410](#)
- (config) tfo tcp optimized-receive-buffer [3-411](#)
- (config) tfo tcp optimized-send-buffer [3-412](#)
- (config) tfo tcp original-mss [3-413](#)
- (config) tfo tcp original-receive-buffer [3-414](#)
- (config) tfo tcp original-send-buffer [3-415](#)
- (config) transaction-logs [3-416](#)
- (config) username [3-423](#)
- (config) wccp access-list [3-426](#)
- (config) wccp flow-redirect [3-429](#)
- (config) wccp router-list [3-430](#)
- (config) wccp shutdown [3-431](#)
- (config) wccp tcp-promiscuous [3-433](#)
- (config) wccp version [3-435](#)
- (config) windows-domain [3-437](#)
- cms [3-9](#)
- configure [3-12](#)
- copy cdrom [3-13](#)
- copy compactflash [3-14](#)
- copy disk [3-15](#)
- copy ftp [3-16](#)
- copy http [3-20](#)
- copy running-config [3-24](#)
- copy startup-config [3-25](#)
- copy sysreport [3-26](#)
- copy system-status [3-28](#)
- copy tech-support [3-29](#)
- copy tftp [3-30](#)
- cpfile [3-32](#)
- debug [3-33](#)
- delfile [3-39](#)
- deltree [3-40](#)
- dir [3-41](#)
- disable [3-43](#)
- disk [3-44](#)
- dnslookup [3-48](#)
- enable [3-49](#)
- exit [3-50](#)
- find-pattern [3-51](#)
- help [3-53](#)
- install [3-54](#)
- less [3-55](#)
- lls [3-56](#)
- ls [3-58](#)
- mkdir [3-59](#)
- mkfile [3-60](#)
- ntpdate [3-61](#)
- ping [3-62](#)
- pwd [3-63](#)
- reload [3-64](#)
- rename [3-65](#)
- restore [3-66](#)
- rmdir [3-70](#)
- scp [3-71](#)

EXEC Mode Commands

- cd [3-3](#)
- cifs [3-4](#)
- clear [3-5](#)
- clock [3-8](#)
- cdrom [3-9](#)
- configure [3-12](#)
- copy cdrom [3-13](#)
- copy compactflash [3-14](#)
- copy disk [3-15](#)
- copy ftp [3-16](#)
- copy http [3-20](#)
- copy running-config [3-24](#)
- copy startup-config [3-25](#)
- copy sysreport [3-26](#)
- copy system-status [3-28](#)
- copy tech-support [3-29](#)
- copy tftp [3-30](#)
- cpfile [3-32](#)
- debug [3-33](#)
- delfile [3-39](#)
- deltree [3-40](#)
- dir [3-41](#)
- disable [3-43](#)
- disk [3-44](#)
- dnslookup [3-48](#)
- enable [3-49](#)
- exit [3-50](#)
- find-pattern [3-51](#)
- help [3-53](#)
- install [3-54](#)
- less [3-55](#)
- lls [3-56](#)
- ls [3-58](#)
- mkdir [3-59](#)
- mkfile [3-60](#)
- ntpdate [3-61](#)
- ping [3-62](#)
- pwd [3-63](#)
- reload [3-64](#)
- rename [3-65](#)
- restore [3-66](#)
- rmdir [3-70](#)
- scp [3-71](#)

script [3-73](#)
 setup [3-74](#)
 show aaa accounting [3-75](#)
 show adapter [3-77](#)
 show alarms [3-78](#)
 show arp [3-81](#)
 show authentication [3-82](#)
 show auto-register [3-84](#)
 show banner [3-85](#)
 show bypass [3-86](#)
 show cdp [3-87](#)
 show cifs [3-93](#)
 show clock [3-95](#)
 show cms [3-97](#)
 show debugging [3-100](#)
 show device-mode [3-101](#)
 show disks [3-103](#)
 show egress-methods [3-110](#)
 show flash [3-111](#)
 show hardware [3-112](#)
 show hosts [3-115](#)
 show inetd [3-116](#)
 show interface [3-117](#)
 show inventory [3-122](#)
 show ip access-list [3-123](#)
 show ip routes [3-125](#)
 show kerberos [3-126](#)
 show key-manager [3-127](#)
 show logging [3-128](#)
 show memory [3-129](#)
 show ntp [3-130](#)
 show policy-engine application [3-132](#)
 show policy-engine status [3-136](#)
 show print-services [3-138](#)
 show processes [3-140](#)
 show radius-server [3-142](#)
 show running-config [3-144](#)
 show services [3-145](#)
 show smb-conf [3-146](#)
 show snmp [3-148](#)
 show ssh [3-154](#)
 show standby [3-155](#)
 show startup-config [3-157](#)
 show statistics authentication [3-159](#)
 show statistics cifs [3-160](#)
 show statistics content-distribution-network [3-162](#)
 show statistics dre [3-163](#)
 show statistics dre connection [3-165](#)
 show statistics dre peer [3-167](#)
 show statistics epm [3-170](#)
 show statistics flow [3-171](#)
 show statistics icmp [3-174](#)
 show statistics ip [3-176](#)
 show statistics key-manager [3-179](#)
 show statistics netstat [3-180](#)
 show statistics radius [3-181](#)
 show statistics services [3-183](#)
 show statistics snmp [3-184](#)
 show statistics tacacs [3-186](#)
 show statistics tcp [3-188](#)
 show statistics tfo [3-192](#)
 show statistics udp [3-194](#)
 show statistics wccp [3-195](#)
 show statistics windows-domain [3-200](#)
 show sysfs [3-202](#)
 show tacacs [3-203](#)
 show tcp [3-205](#)
 show tech-support [3-207](#)
 show telnet [3-210](#)
 show tfo accelerators [3-211](#)
 show tfo auto-discovery [3-212](#)
 show tfo bufpool [3-214](#)
 show tfo connection [3-216](#)
 show tfo egress connection [3-218](#)
 show tfo filtering [3-222](#)
 show tfo status [3-224](#)
 show tfo synq [3-225](#)
 show transaction-logging [3-226](#)

show user [3-227](#)
 show users administrative [3-228](#)
 show version [3-230](#)
 show wccp [3-231](#)
 show windows-domain [3-237](#)
 shutdown [3-239](#)
 snmp trigger [3-242](#)
 ssh [3-245](#)
 tcpdump [3-246](#)
 telnet [3-247](#)
 terminal [3-248](#)
 tethereal [3-249](#)
 traceroute [3-251](#)
 transaction-log [3-252](#)
 type [3-253](#)
 type-tail [3-254](#)
 undebg [3-256](#)
 wafs [3-261](#)
 whoami [3-263](#)
 windows-domain [3-264](#)
 write [3-267](#)

(config-if) failover timeout [3-445](#)
 (config-if) full-duplex [3-446](#)
 (config-if) half-duplex [3-447](#)
 (config-if) inline [3-449](#)
 (config-if) ip [3-451](#)
 (config-if) ip access-group [3-453](#)
 (config-if) mtu [3-454](#)
 (config-if) no [3-455](#)
 (config-if) shutdown [3-457](#)
 (config-if) standby [3-458](#)

Standard ACL Configuration Mode Commands

(config) ip access-list standard [3-464](#)
 (config-std-nacl) delete [3-467](#)
 (config-std-nacl) deny [3-468](#)
 (config-std-nacl) exit [3-470](#)
 (config-std-nacl) list [3-471](#)
 (config-std-nacl) move [3-472](#)
 (config-std-nacl) permit [3-473](#)

Extended ACL Configuration Mode Commands

(config-ext-nacl) delete [3-478](#)
 (config-ext-nacl) deny [3-479](#)
 (config-ext-nacl) exit [3-484](#)
 (config-ext-nacl) list [3-485](#)
 (config-ext-nacl) move [3-486](#)
 (config-ext-nacl) permit [3-487](#)

Interface Configuration Mode Commands

(config-if) autosense [3-440](#)
 (config-if) bandwidth [3-441](#)
 (config-if) cdp [3-443](#)
 (config-if) exit [3-444](#)