



AppNav Controller Group Configuration Mode Commands

- (config-scg) appnav-controller [3-919](#)
- (config-scg) description [3-920](#)

Class Map Configuration Mode Commands

- (config) class-map [3-598](#)
- (config-cmap) description [3-945](#)
- (config-cmap) match peer [3-946](#)
- (config-cmap) match protocol [3-947](#)
- (config-cmap) match tcp [3-949](#)

Configuration Mode Commands

- (config) aaa accounting [3-540](#)
- (config) aaa authorization commands [3-543](#)
- (config) accelerator cifs [3-544](#)
- (config) accelerator cifs preposition [3-546](#)
- (config) accelerator epm [3-548](#)
- (config) accelerator http [3-549](#)
- (config) accelerator ica [3-552](#)
- (config) accelerator mapi [3-554](#)
- (config) accelerator nfs [3-556](#)
- (config) accelerator smb [3-557](#)
- (config) accelerator ssl [3-560](#)
- (config) accelerator video [3-562](#)
- (config) accelerator windows-print [3-564](#)
- (config) alarm overload-detect [3-565](#)
- (config) asset [3-567](#)
- (config) authentication configuration [3-568](#)

- (config) authentication content-request [3-574](#)
- (config) authentication enable [3-573](#)
- (config) authentication fail-over [3-578](#)
- (config) authentication login [3-580](#)
- (config) auto-discovery [3-587](#)
- (config) auto-register [3-588](#)
- (config) banner [3-590](#)
- (config) bridge [3-592](#)
- (config) cdp [3-595](#)
- (config) central-manager [3-596](#)
- (config) clock [3-600](#)
- (config) cms [3-604](#)
- (config) crypto pki [3-607](#)
- (config) crypto ssl [3-609](#)
- (config) device mode [3-611](#)
- (config) directed-mode [3-613](#)
- (config) disk disk-name [3-614](#)
- (config) disk encrypt [3-616](#)
- (config) disk error-handling [3-617](#)
- (config) disk logical shutdown [3-618](#)
- (config) disk object-cache extend [3-619](#)
- (config) dre [3-620](#)
- (config) end [3-621](#)
- (config) exec-timeout [3-622](#)
- (config) exit [3-623](#)
- (config) flow monitor [3-624](#)
- (config) help [3-625](#)
- (config) hostname [3-627](#)
- (config) inetd [3-629](#)
- (config) inline [3-630](#)
- (config) inline vlan-id-connection-check [3-631](#)
- (config) interception [3-632](#)
- (config) interception-method [3-634](#)

(config) interface bvi [3-636](#)
 (config) interface GigabitEthernet [3-638](#)
 (config) interface InlineGroup [3-643](#)
 (config) interface PortChannel [3-646](#)
 (config) interface standby [3-648](#)
 (config) interface TenGigabitEthernet [3-650](#)
 (config) interface virtual [3-654](#)
 (config) ip [3-657](#)
 (config) ip access-list [3-660](#)
 (config) ip icmp rate-limit unreachable [3-663](#)
 (config) ip unreachable df [3-665](#)
 (config) kerberos [3-666](#)
 (config) kernel kdb [3-668](#)
 (config) kernel kdump [3-670](#)
 (config) line [3-671](#)
 (config) logging console [3-672](#)
 (config) logging disk [3-674](#)
 (config) logging facility [3-676](#)
 (config) logging host [3-678](#)
 (config) ntp [3-680](#)
 (config) peer [3-682](#)
 (config) policy-map [3-683](#)
 (config) port-channel [3-685](#)
 (config) primary-interface [3-686](#)
 (config) radius-server [3-688](#)
 (config) service-insertion [3-690](#)
 (config) service-policy [3-693](#)
 (config) smb-conf [3-695](#)
 (config) snmp-server access-list [3-698](#)
 (config) snmp-server community [3-699](#)
 (config) snmp-server contact [3-701](#)
 (config) snmp-server enable traps [3-702](#)
 (config) snmp-server group [3-705](#)
 (config) snmp-server host [3-707](#)
 (config) snmp-server location [3-709](#)
 (config) snmp-server mib [3-710](#)
 (config) snmp-server notify inform [3-712](#)
 (config) snmp-server trap-source [3-713](#)
 (config) snmp-server user [3-715](#)

(config) snmp-server view [3-717](#)
 (config) sshd [3-718](#)
 (config) ssh-key-generate [3-720](#)
 (config) stats-collector logging [3-721](#)
 (config) system jumbomtu [3-722](#)
 (config) tacacs [3-723](#)
 (config) tcp [3-726](#)
 (config) telnet enable [3-728](#)
 (config) tfo exception [3-729](#)
 (config) tfo optimize [3-730](#)
 (config) tfo tcp adaptive-buffer-sizing [3-731](#)
 (config) tfo tcp keepalive [3-732](#)
 (config) tfo tcp optimized-mss [3-733](#)
 (config) tfo tcp optimized-receive-buffer [3-734](#)
 (config) tfo tcp optimized-send-buffer [3-735](#)
 (config) tfo tcp original-mss [3-736](#)
 (config) tfo tcp original-receive-buffer [3-737](#)
 (config) tfo tcp original-send-buffer [3-738](#)
 (config) threshold-monitor [3-739](#)
 (config) transaction-logs [3-741](#)
 (config) username [3-744](#)
 (config) virtual-blade [3-746](#)
 (config) vn-service vpath [3-748](#)
 (config) wccp access-list [3-749](#)
 (config) wccp flow-redirect [3-751](#)
 (config) wccp router-list [3-753](#)
 (config) wccp shutdown [3-755](#)
 (config) wccp tcp-promiscuous service-pair [3-757](#)
 (config) windows-domain [3-759](#)

EXEC Mode Commands

authentication strict-password-policy [3-585](#)
 cd [3-4](#)
 clear arp-cache [3-5](#)
 clear bmc [3-6](#)
 clear cache [3-7](#)
 clear cdp [3-9](#)
 clear cifs msg-signing-servers [3-10](#)

clear connection [3-11](#)
clear dre [3-12](#)
clear ip [3-13](#)
clear license [3-14](#)
clear logging [3-15](#)
clear service-policy [3-16](#)
clear statistics [3-17](#)
clear statistics accelerator [3-19](#)
clear statistics connection [3-20](#)
clear statistics vn-service vpath [3-22, 3-23](#)
clear transaction-log [3-24](#)
clear users [3-25](#)
clear windows-domain [3-27](#)
clear windows-domain-log [3-28](#)
clock [3-29](#)
cms [3-30](#)
cms secure-store [3-33](#)
configure [3-36](#)
copy cdrom [3-37](#)
copy cdrom wow-recovery [3-38](#)
copy compactflash [3-39](#)
copy disk [3-40](#)
copy ftp [3-41](#)
copy http [3-44](#)
copy monitoring-log [3-46](#)
copy running-config [3-47](#)
copy sep [3-49](#)
copy startup-config [3-51](#)
copy sysreport [3-52](#)
copy system-status [3-54](#)
copy tech-support [3-55](#)
copy tftp [3-57](#)
cpfile [3-60](#)
crypto delete [3-61](#)
crypto export [3-62](#)
crypto generate [3-64](#)
crypto import [3-66](#)
crypto pki [3-68](#)
debug aaa accounting [3-69](#)
debug accelerator [3-73](#)
debug all [3-79](#)
debug appnav-controller connection [3-81](#)
debug authentication [3-85](#)
debug auto-discovery [3-87](#)
debug buf [3-89](#)
debug cdp [3-91](#)
debug cli [3-93](#)
debug cmm [3-95](#)
debug cms [3-97](#)
debug connection [3-99](#)
debug controllers [3-101](#)
debug dataserver [3-103](#)
debug dhcp [3-105](#)
debug directed-mode [3-107](#)
debug dre [3-109](#)
debug egress-method [3-111](#)
debug encryption-service [3-113](#)
debug fda [3-115](#)
debug fdm [3-117](#)
debug filtering [3-119](#)
debug flow [3-121](#)
debug generic-gre [3-123](#)
debug hw-raid [3-125](#)
debug imd [3-127](#)
debug inline [3-129](#)
debug logging [3-133](#)
debug monapi [3-131, 3-135](#)
debug nplogd [3-137](#)
debug ntp [3-139](#)
debug punt [3-141](#)
debug rbcpl [3-143](#)
debug rmd [3-145](#)
debug rpc [3-147](#)
debug service-insertion [3-149](#)
debug service-policy [3-151](#)
debug snmp [3-153](#)
debug standby [3-155](#)
debug statistics [3-157](#)

debug synq [3-159](#)
 debug tfo [3-161](#)
 debug translog [3-163](#)
 debug wafs [3-165](#)
 debug wccp [3-167](#)
 delfile [3-169](#)
 deltree [3-170](#)
 dir [3-171](#)
 disable [3-173](#)
 disk [3-174](#)
 dnslookup [3-177](#)
 enable [3-178](#)
 exit [3-179](#)
 find-pattern [3-180](#)
 help [3-182](#)
 install [3-183](#)
 less [3-185](#)
 license add [3-186](#)
 lls [3-187](#)
 ls [3-188](#)
 lsub [3-190](#)
 mkdir [3-191](#)
 mkfile [3-192](#)
 monitor appnav-controller traffic [3-193](#)
 ntpdate [3-194](#)
 packet-capture [3-195](#)
 ping [3-197](#)
 pwd [3-198](#)
 reload [3-199](#)
 rename [3-200](#)
 restore [3-201](#)
 rmdir [3-205](#)
 scp [3-206](#)
 script [3-208](#)
 setup [3-209](#)
 show aaa accounting [3-210](#)
 show aaa authorization [3-212](#)
 show accelerator [3-213](#)
 show alarms [3-217](#)
 show appnav-controller flow-distribution [3-220](#)
 show arp [3-222](#)
 show authentication [3-223](#)
 show auto-discovery [3-225](#)
 show auto-register [3-226](#)
 show banner [3-227](#)
 show bmc [3-228](#)
 show bridge [3-230](#)
 show cache http-metadatacache [3-232](#)
 show cdp [3-234](#)
 show cifs [3-240](#)
 show class-map [3-242](#)
 show clock [3-244](#)
 show cms [3-246](#)
 show cms secure-store [3-249](#)
 show crypto [3-251](#)
 show debugging [3-253](#)
 show device-id [3-254](#)
 show device-mode [3-255](#)
 show directed-mode [3-257](#)
 show disks [3-258](#)
 show dre [3-265](#)
 show filtering list [3-266](#)
 show flash [3-268](#)
 show hardware [3-269](#)
 show hosts [3-272](#)
 show inetd [3-273](#)
 show interception-method [3-274](#)
 show interface [3-275](#)
 show inventory [3-279](#)
 show ip access-list [3-280](#)
 show ip routes [3-282](#)
 show kdump [3-283](#)
 show kerberos [3-284](#)
 show key-manager [3-285](#)
 show license [3-286](#)
 show logging [3-287](#)
 show memory [3-288](#)
 show monitor [3-289](#)

show ntp [3-290](#)
 show peer optimization [3-292](#)
 show policy-map [3-293](#)
 show policy-sub-class [3-294](#)
 show processes [3-296](#)
 show radius-server [3-298](#)
 show reload [3-300](#)
 show running-config [3-301](#)
 show service-insertion [3-303](#)
 show service-policy [3-309](#)
 show services [3-312](#)
 show smb-conf [3-313](#)
 show snmp [3-315](#)
 show ssh [3-321](#)
 show startup-config [3-322](#)
 show statistics accelerator [3-324](#)
 show statistics aoim [3-373](#)
 show statistics application [3-377](#)
 show statistics appnav-controller [3-380](#)
 show statistics authentication [3-382](#)
 show statistics auto-discovery [3-383](#)
 show statistics cifs [3-386](#)
 show statistics class-default [3-388](#)
 show statistics class-map [3-389](#)
 show statistics connection [3-391](#)
 show statistics connection auto-discovery [3-395](#)
 show statistics connection closed [3-397](#)
 show statistics connection conn-id [3-400](#)
 show statistics connection egress-methods [3-403](#)
 show statistics connection optimized [3-407](#)
 show statistics connection pass-through [3-410](#)
 show statistics crypto ssl ciphers [3-412](#)
 show statistics datamover [3-413](#)
 show statistics directed-mode [3-415](#)
 show statistics dre [3-416](#)
 show statistics filtering [3-419](#)
 show statistics flow [3-422](#)
 show statistics generic-gre [3-425](#)
 show statistics icmp [3-426](#)
 show statistics ip [3-428](#)
 show statistics monitor appnav-controller traffic [3-431](#)
 show statistics netstat [3-433](#)
 show statistics pass-through [3-434](#)
 show statistics peer [3-436](#)
 show statistics policy-sub-class [3-439](#)
 show statistics punt [3-441](#)
 show statistics radius [3-442](#)
 show statistics service-insertion [3-444](#)
 show statistics services [3-445](#)
 show statistics sessions [3-446](#)
 show statistics snmp [3-447](#)
 show statistics synq [3-449](#)
 show statistics tacacs [3-450](#)
 show statistics tcp [3-452](#)
 show statistics tfo [3-456](#)
 show statistics udp [3-460](#)
 show statistics vn-service vpath [3-461](#)
 show statistics wccp [3-463](#)
 show statistics windows-domain [3-468](#)
 show statistics windows-print requests [3-470](#)
 show synq list [3-472](#)
 show sysfs volumes [3-473](#)
 show tacacs [3-474](#)
 show tcp [3-476](#)
 show tech-support [3-478](#)
 show telnet [3-481](#)
 show tfo tcp [3-482](#)
 show transaction-logging [3-484](#)
 show user [3-486](#)
 show users administrative [3-487](#)
 show version [3-489](#)
 show virtual-blade [3-490](#)
 show wccp [3-493](#)
 show windows-domain [3-500](#)
 shutdown [3-502](#)
 snmp trigger [3-505](#)
 ssh [3-509](#)

tcpdump [3-510](#)
telnet [3-512](#)
terminal [3-513](#)
test [3-514](#)
tethered [3-517](#)
top [3-520](#)
traceroute [3-522](#)
transaction-log [3-524](#)
type [3-525](#)
type-tail [3-526](#)
virtual-blade [3-528](#)
vm [3-530](#)
waas-tcptrace [3-532](#)
whoami [3-534](#)
windows-domain [3-535](#)
write [3-538](#)

(config-if) full-duplex [3-776](#)
(config-if) half-duplex [3-778](#)
(config-if) inline [3-780](#)
(config-if) ip [3-782](#)
(config-if) ip access-group [3-784](#)
(config-if) load-interval [3-786](#)
(config-if) mtu [3-787](#)
(config-if) shutdown [3-788](#)
(config-if) standby [3-789](#)

Extended ACL Configuration Mode Commands

(config-ext-nacl) delete [3-805](#)
(config-ext-nacl) deny [3-806](#)
(config-ext-nacl) exit [3-811](#)
(config-ext-nacl) list [3-812](#)
(config-ext-nacl) move [3-813](#)
(config-ext-nacl) permit [3-814](#)

Interface Configuration Mode Commands

(config-if) autosense [3-764](#)
(config-if) bandwidth [3-765](#)
(config-if) bridge-group [3-767](#)
(config-if) cdp [3-769](#)
(config-if) channel-group [3-770](#)
(config-if) description [3-771](#)
(config-if) encapsulation dot1Q [3-772](#)
(config-if) exit [3-773](#)
(config-if) failover timeout [3-774](#)

PKI Certificate Authority Configuration Mode Commands

(config-ca) ca-certificate [3-855](#)
(config-ca) description [3-856](#)
(config-ca) revocation-check [3-857](#)

PKI Global Settings Configuration Mode Commands

(config-pki-global-settings) oosp [3-860](#)
(config-pki-global-settings) revocation-check [3-861](#)

Policy Map Class Configuration Mode Commands

(config-pmap-c) distribute [3-957](#)
(config-pmap-c) monitor-load [3-958](#)
(config-pmap-c) optimize [3-960](#)
(config-pmap-c) pass-through [3-962](#)
(config-pmap-c) service-policy [3-964](#)
(config-pmap-c) set ip dscp [3-965](#)

Policy Map Configuration Mode Commands

(config-pmap) class [3-953](#)
(config-pmap) description [3-954](#)

Preposition Configuration Mode Commands

- (config-preposition) credentials [3-821](#)
- (config-preposition) dscp [3-822](#)
- (config-preposition) duration [3-823](#)
- (config-preposition) enable [3-824](#)
- (config-preposition) ignore-hidden-dir [3-825](#)
- (config-preposition) max-cache [3-826](#)
- (config-preposition) max-file-size [3-827](#)
- (config-preposition) min-file-size [3-828](#)
- (config-preposition) name [3-829](#)
- (config-preposition) recursive [3-831](#)
- (config-preposition) root [3-832](#)
- (config-preposition) scan-type [3-830](#), [3-833](#)
- (config-preposition) schedule [3-834](#)
- (config-preposition) server [3-836](#)

Service Context Configuration Mode Commands

- (config-scx) appnav-controller-group [3-935](#)
- (config-scx) authentication [3-936](#)
- (config-scx) description [3-937](#)
- (config-scx) enable [3-938](#)
- (config-scx) service-node-group [3-940](#)
- (config-scx) service-policy [3-941](#)

Service Node Configuration Mode Commands

- (config-sn) authentication [3-927](#)
- (config-sn) description [3-928](#)
- (config-sn) enable [3-929](#)
- (config-sn) node-discovery [3-930](#)
- (config-sn) shutdown [3-932](#)

Service Node Group Configuration Mode Commands

- (config-sng) description [3-923](#)
- (config-sng) service-node [3-924](#)

SSL Accelerated Service Configuration Mode Commands

- (config-ssl-accelerated) cipher-list [3-865](#)
- (config-ssl-accelerated) client-cert-verify [3-866](#)
- (config-ssl-accelerated) client-version-rollback-check [3-867](#)
- (config-ssl-accelerated) description [3-868](#)
- (config-ssl-accelerated) inservice [3-869](#)
- (config-ssl-accelerated) server-cert-key [3-870](#)
- (config-ssl-accelerated) server-cert-verify [3-871](#)
- (config-ssl-accelerated) server-domain [3-872](#)
- (config-ssl-accelerated) server-ip [3-873](#)
- (config-ssl-accelerated) server-name [3-874](#)
- (config-ssl-accelerated) version [3-875](#)

SSL Cipher List Configuration Mode Commands

- (config-cipher-list) cipher [3-878](#)

SSL Global Service Configuration Mode Commands

- (config-ssl-global) cipher-list [3-883](#)
- (config-ssl-global) machine-cert-key [3-884](#)
- (config-ssl-global) version [3-885](#)

SSL Host Peering Service Configuration Mode Commands

- (config-ssl-peering) cipher-list [3-889](#)
- (config-ssl-peering) peer-cert-verify [3-890](#)
- (config-ssl-peering) version [3-891](#)

SSL Management Service Configuration Mode Commands

- (config-ssl-mgmt) cipher-list [3-895](#)

(config-ssl-mgmt) peer-cert-verify [3-896](#)
(config-ssl-mgmt) version [3-897](#)

Standard ACL Configuration Mode Commands

(config-std-nacl) delete [3-794](#)
(config-std-nacl) deny [3-795](#)
(config-std-nacl) exit [3-797](#)
(config-std-nacl) list [3-798](#)
(config-std-nacl) move [3-799](#)
(config-std-nacl) permit [3-800](#)

Virtual Blade Configuration Mode Commands

(config-vb) autostart [3-839](#)
(config-vb) boot [3-840](#)
(config-vb) cpu-list [3-842](#)
(config-vb) description [3-844, 3-845](#)
(config-vb) disk [3-848](#)
(config-vb) interface [3-850](#)
(config-vb) memory [3-851](#)
(config-vb) vnc [3-852](#)

WCCP Configuration Mode Commands

(config-wccp-service) assignment-method [3-901](#)
(config-wccp-service) egress-method [3-903](#)
(config-wccp-service) enable [3-905](#)
(config-wccp-service) exit [3-906](#)
(config-wccp-service) failure-detection [3-907](#)
(config-wccp-service) password [3-909](#)
(config-wccp-service) redirect-method [3-910](#)
(config-wccp-service) router-list-num [3-912](#)
(config-wccp-service) weight [3-914](#)
