



---

## AppNav Controller Group Configuration Mode Commands

- (config-scg) appnav-controller [3-971](#)
- (config-scg) description [3-972](#)

---

## Class Map Configuration Mode Commands

- (config) class-map [3-648](#)
- (config-cmap) description [3-997](#)
- (config-cmap) match peer [3-998](#)
- (config-cmap) match protocol [3-999](#)
- (config-cmap) match tcp [3-1001](#)

---

## Configuration Mode Commands

- (config) aaa accounting [3-574](#)
- (config) aaa authorization commands [3-577](#)
- (config) accelerator epm [3-578](#)
- (config) accelerator http [3-579](#), [3-590](#), [3-592](#), [3-594](#), [3-595](#)
- (config) accelerator http preposition proxy server [3-600](#)
- (config) accelerator ica [3-601](#)
- (config) accelerator mapi [3-603](#)
- (config) accelerator nfs [3-605](#)
- (config) accelerator smb [3-606](#)
- (config) accelerator smb preposition [3-610](#)
- (config) accelerator smb preposition dre [3-612](#)
- (config) accelerator ssl [3-613](#)
- (config) alarm overload-detect [3-615](#)
- (config) asset [3-617](#)
- (config) authentication configuration [3-618](#)
- (config) authentication content-request [3-624](#)

- (config) authentication enable [3-623](#)
- (config) authentication fail-over [3-628](#)
- (config) authentication login [3-630](#)
- (config) auto-discovery [3-637](#)
- (config) auto-register [3-639](#)
- (config) banner [3-641](#)
- (config) bridge [3-643](#)
- (config) cdp [3-645](#)
- (config) central-manager [3-646](#)
- (config) clock [3-650](#)
- (config) cms [3-654](#)
- (config) crypto encryption-service [3-657](#)
- (config) crypto pki [3-658](#)
- (config) crypto ssl [3-660](#)
- (config) device mode [3-662](#)
- (config) disk cache [3-665](#)
- (config) disk disk-name [3-664](#)
- (config) disk encrypt [3-667](#)
- (config) disk error-handling [3-668](#)
- (config) disk logical shutdown [3-669](#)
- (config) disk object-cache extend [3-670](#)
- (config) dre [3-671](#)
- (config) end [3-672](#)
- (config) exec-timeout [3-673](#)
- (config) exit [3-674](#)
- (config) flow exporter [3-675](#)
- (config) flow monitor [3-679](#)
- (config) flow record [3-677](#)
- (config) help [3-681](#)
- (config) hostname [3-683](#)
- (config) inetd [3-685](#)
- (config) inline [3-686](#)
- (config) inline vlan-id-connection-check [3-687](#)

- (config) interception 3-688
- (config) interception-method 3-690
- (config) interface GigabitEthernet 3-692
- (config) interface InlineGroup 3-697
- (config) interface PortChannel 3-700
- (config) interface standby 3-703
- (config) interface TenGigabitEthernet 3-705
- (config) interface virtual 3-709
- (config) ip 3-712
- (config) ip access-list 3-715
- (config) ip icmp rate-limit unreachable 3-718
- (config) ip unreachable df 3-720
- (config) ipv6 3-721
- (config) kerberos 3-723
- (config) kernel kdb 3-725
- (config) kernel kdump 3-727
- (config) line 3-728
- (config) logging console 3-729
- (config) logging disk 3-731
- (config) logging facility 3-733
- (config) logging host 3-735
- (config) ntp 3-737
- (config) peer 3-739
- (config) policy-map 3-740
- (config) port-channel 3-742
- (config) primary-interface 3-743
- (config) radius-server 3-745
- (config) service-insertion 3-747
- (config) service-policy 3-751
- (config) smb-conf 3-753
- (config) snmp-server access-list 3-757
- (config) snmp-server community 3-758
- (config) snmp-server contact 3-760
- (config) snmp-server enable traps 3-761
- (config) snmp-server group 3-764
- (config) snmp-server host 3-766
- (config) snmp-server location 3-768
- (config) snmp-server mib 3-769
- (config) snmp-server notify inform 3-772
- (config) snmp-server trap-source 3-773
- (config) snmp-server user 3-778
- (config) snmp-server view 3-780
- (config) sshd 3-781
- (config) ssh-key-generate 3-783
- (config) stats-collector logging 3-784
- (config) system jumbomtu 3-785
- (config) tacacs 3-786
- (config) tcp 3-789
- (config) telnet enable 3-791
- (config) tfo exception 3-792
- (config) tfo optimize 3-793
- (config) tfo tcp adaptive-buffer-sizing 3-794
- (config) tfo tcp keepalive 3-795
- (config) tfo tcp optimized-mss 3-796
- (config) tfo tcp optimized-receive-buffer 3-797
- (config) tfo tcp optimized-send-buffer 3-798
- (config) tfo tcp original-mss 3-799
- (config) tfo tcp original-receive-buffer 3-800
- (config) tfo tcp original-send-buffer 3-801
- (config) threshold-monitor 3-802
- (config) username 3-805
- (config) vn-service vpath 3-807
- (config) wccp access-list 3-808
- (config) wccp flow-redirect 3-810
- (config) wccp router-list 3-812
- (config) wccp shutdown 3-814
- (config) wccp tcp-promiscuous service-pair 3-816
- (config) windows-domain 3-818
- snmp-server trigger 3-775
- snmp-server user 3-771

---

## EXEC Mode Commands

- authentication strict-password-policy 3-635
- cd 3-4
- clear arp-cache 3-5
- clear bmc 3-6
- clear cache 3-7

clear cdp [3-10](#)  
clear connection [3-11](#)  
clear dre [3-12](#)  
clear ip [3-13](#)  
clear ipv6 [3-14](#)  
clear license [3-15](#)  
clear logging [3-16](#)  
clear object-cache [3-17](#)  
clear service-policy [3-18](#)  
clear statistics [3-19](#)  
clear statistics accelerator [3-21](#)  
clear statistics connection [3-23](#)  
clear statistics vn-service vpath [3-25](#), [3-26](#)  
clear transaction-log [3-27](#)  
clear users [3-28](#)  
clear windows-domain [3-30](#)  
clear windows-domain-log [3-31](#)  
clock [3-32](#)  
cms [3-33](#)  
cms secure-store [3-36](#)  
configure [3-39](#)  
copy disk [3-40](#)  
copy ftp [3-41](#)  
copy http [3-43](#)  
copy monitoring-log [3-45](#)  
copy running-config [3-46](#)  
copy scp [3-48](#)  
copy secure-http [3-50](#)  
copy startup-config [3-51](#)  
copy sysreport [3-52](#)  
copy system-status [3-55](#)  
copy tech-support [3-56](#)  
copy tftp [3-58](#)  
cpfile [3-59](#)  
crypto delete [3-60](#)  
crypto export [3-61](#)  
crypto generate [3-63](#)  
crypto import [3-65](#)  
crypto pki [3-67](#), [3-139](#), [3-140](#), [3-141](#)  
debug aaa accounting [3-68](#), [3-571](#)  
debug accelerator [3-72](#)  
debug accelerator mapi rpchttp-layer [3-78](#)  
debug all [3-79](#)  
debug appnav-controller connection [3-81](#)  
debug authentication [3-85](#)  
debug auto-discovery [3-87](#)  
debug buf [3-89](#)  
debug cdp [3-91](#)  
debug cli [3-93](#)  
debug cmm [3-95](#)  
debug cms [3-97](#)  
debug connection [3-99](#)  
debug controllers [3-101](#)  
debug dataserver [3-103](#)  
debug dhcp [3-105](#)  
debug dre [3-107](#)  
debug egress-method [3-109](#)  
debug encryption-service [3-111](#)  
debug fda [3-113](#)  
debug fdm [3-115](#)  
debug filtering [3-117](#)  
debug flow [3-119](#)  
debug generic-gre [3-121](#)  
debug hw-raid [3-123](#)  
debug imd [3-125](#)  
debug inline [3-127](#)  
debug logging [3-131](#)  
debug monapi [3-129](#), [3-133](#)  
debug nplogd [3-135](#)  
debug ntp [3-137](#)  
debug punt [3-142](#)  
debug rbcpl [3-144](#)  
debug rmd [3-146](#)  
debug rpc [3-148](#)  
debug service-insertion [3-150](#)  
debug service-policy [3-152](#)  
debug snmp [3-154](#)  
debug standby [3-156](#)

debug statistics [3-158](#)  
debug synq [3-160](#)  
debug tfo [3-162](#)  
debug translog [3-164](#)  
debug wafs [3-166](#)  
debug wccp [3-168](#)  
delfile [3-170](#)  
deltree [3-171](#)  
dir [3-172](#)  
disable [3-174](#)  
disk [3-175](#)  
dnslookup [3-178](#)  
enable [3-179](#)  
exit [3-180](#)  
find-pattern [3-181](#)  
help [3-183](#)  
install [3-184](#)  
less [3-186](#)  
license add [3-187](#)  
lls [3-188](#)  
ls [3-189](#)  
lsusb [3-191](#)  
mkdir [3-192](#)  
mkfile [3-193](#)  
monitor appnav-controller traffic [3-194](#)  
ntpdate [3-195](#)  
packet-capture [3-196](#)  
ping [3-199](#)  
ping6 [3-200](#)  
pwd [3-202](#)  
reload [3-203](#)  
rename [3-204](#)  
restore [3-205](#)  
rmdir [3-209](#)  
scp [3-210](#)  
script [3-212](#)  
setup [3-213](#)  
show aaa accounting [3-214](#)  
show aaa authorization [3-216](#)  
show accelerator [3-217](#)  
show alarms [3-222](#)  
show appnav-controller flow-distribution [3-225](#)  
show arp [3-227](#)  
show authentication [3-229](#)  
show auto-discovery [3-231](#)  
show auto-register [3-232](#)  
show banner [3-233](#)  
show bmc [3-234](#)  
show bridge [3-236](#)  
show cache http-metadacache [3-238](#)  
show cache object-cache [3-240](#)  
show cdp [3-242](#)  
show class-map [3-248](#)  
show clock [3-250](#)  
show cms [3-252](#)  
show cms secure-store [3-255](#)  
show crypto [3-257](#)  
show debugging [3-259](#)  
show device-id [3-260](#)  
show device-mode [3-261](#)  
show disks [3-263](#)  
show dre [3-271](#)  
show filtering list [3-272](#)  
show flash [3-274](#)  
show flow record [3-275](#)  
show hardware [3-277](#)  
show hosts [3-282](#)  
show inetd [3-283](#)  
show interception-method [3-284](#)  
show interface [3-285](#)  
show inventory [3-290](#)  
show ip access-list [3-291](#)  
show ip routes [3-293](#)  
show ipv6 [3-294](#)  
show kdump [3-296](#)  
show kerberos [3-297](#)  
show key-manager [3-298](#)  
show license [3-299](#)

show logging 3-300  
show memory 3-301  
show monitor 3-302  
show ntp 3-303  
show peer optimization 3-305  
show policy-map 3-306  
show policy-sub-class 3-307  
show processes 3-309  
show radius-server 3-311  
show reload 3-313  
show running-config 3-314  
show service-insertion 3-316  
show service-policy 3-322  
show services 3-325  
show smb-conf 3-326  
show snmp 3-328  
show ssh 3-334  
show startup-config 3-335  
show statistics accelerator 3-337  
show statistics aoim 3-400  
show statistics application 3-406  
show statistics appnav-controller 3-409  
show statistics authentication 3-411  
show statistics auto-discovery 3-412  
show statistics class-default 3-415  
show statistics class-map 3-416  
show statistics connection 3-418  
show statistics connection auto-discovery 3-422  
show statistics connection closed 3-424  
show statistics connection conn-id 3-426  
show statistics connection egress-methods 3-429  
show statistics connection optimized 3-433  
show statistics connection pass-through 3-436  
show statistics crypto ssl ciphers 3-438  
show statistics datamover 3-439  
show statistics dre 3-441  
show statistics encryption-services 3-446  
show statistics filtering 3-452  
show statistics flow 3-455  
show statistics generic-gre 3-458  
show statistics icmp 3-459  
show statistics icmp6 3-461  
show statistics ip 3-464  
show statistics ipv6 3-467  
show statistics monitor appnav-controller traffic 3-470  
show statistics netstat 3-472  
show statistics pass-through 3-473  
show statistics peer 3-475  
show statistics policy-sub-class 3-478  
show statistics punt 3-480  
show statistics radius 3-481  
show statistics service-insertion 3-483  
show statistics services 3-484  
show statistics sessions 3-485  
show statistics snmp 3-486  
show statistics synq 3-488  
show statistics system cpu 3-489  
show statistics tacacs 3-491  
show statistics tcp 3-493  
show statistics tfo 3-497  
show statistics udp 3-501  
show statistics vn-service vpath 3-502  
show statistics wccp 3-504  
show statistics windows-domain 3-509  
show synq list 3-511  
show sysfs volumes 3-512  
show tacacs 3-513  
show tcp 3-515  
show tech-support 3-517  
show telnet 3-520  
show tfo tcp 3-521  
show transaction-logging 3-523  
show user 3-524  
show users administrative 3-525  
show version 3-527  
show wccp 3-528  
show windows-domain 3-535, 3-537  
shutdown 3-538

ssh [3-541](#)  
 tcpdump [3-543](#)  
 telnet [3-545](#)  
 terminal [3-546](#)  
 test [3-547](#)  
 tethereal [3-550](#)  
 top [3-553](#)  
 traceroute [3-555](#)  
 traceroute6 [3-557](#)  
 transaction-log [3-558](#)  
 type [3-559](#)  
 type-tail [3-560](#)  
 vm [3-562](#)  
 waas-tcptrace [3-564](#)  
 whoami [3-566](#)  
 windows-domain [3-567](#)  
 write [3-570](#)  
 zzdebugshell [3-571](#)

(config-if) exit [3-831](#)  
 (config-if) failover timeout [3-832](#)  
 (config-if) full-duplex [3-834](#)  
 (config-if) half-duplex [3-836](#)  
 (config-if) inline [3-838](#)  
 (config-if) ip [3-840](#)  
 (config-if) ip access-group [3-842](#)  
 (config-if) load-interval [3-844](#)  
 (config-if) mtu [3-845](#)  
 (config-if) shutdown [3-846](#)  
 (config-if) standby [3-847](#)

---

## Extended ACL Configuration Mode Commands

(config-ext-nacl) delete [3-864](#)  
 (config-ext-nacl) deny [3-865](#)  
 (config-ext-nacl) exit [3-870](#)  
 (config-ext-nacl) list [3-871](#)  
 (config-ext-nacl) move [3-872](#)  
 (config-ext-nacl) permit [3-873](#)

---

## Interface Configuration Mode Commands

(config-if) autosense [3-823](#)  
 (config-if) bandwidth [3-824](#)  
 (config-if) bridge-group [3-826](#)  
 (config-if) cdp [3-827](#)  
 (config-if) channel-group [3-828](#)  
 (config-if) description [3-829](#)  
 (config-if) encapsulation dot1Q [3-830](#)

---

## PKI Certificate Authority Configuration Mode Commands

(config-ca) ca-certificate [3-905](#)  
 (config-ca) description [3-906](#)  
 (config-ca) revocation-check [3-907](#)

---

## PKI Global Settings Configuration Mode Commands

(config-pki-global-settings) ocsip [3-910](#)  
 (config-pki-global-settings) revocation-check [3-911](#)

---

## Policy Map Class Configuration Mode Commands

(config-pmap-c) distribute [3-1009](#)  
 (config-pmap-c) monitor-load [3-1010](#)  
 (config-pmap-c) optimize [3-1012](#)  
 (config-pmap-c) pass-through [3-1014](#)  
 (config-pmap-c) service-policy [3-1016](#)  
 (config-pmap-c) set ip dscp [3-1017](#)

---

## Policy Map Configuration Mode Commands

(config-pmap) class [3-1005](#)

(config-pmap) description [3-1006](#)

---

## Preposition Configuration Mode Commands

(config-preposition) credentials [3-884](#)  
 (config-preposition) dscp [3-885](#)  
 (config-preposition) duration [3-886](#)  
 (config-preposition) enable [3-887](#)  
 (config-preposition) ignore-hidden-dir [3-888](#)  
 (config-preposition) max-cache [3-889](#)  
 (config-preposition) max-file-size [3-890](#)  
 (config-preposition) min-file-size [3-891](#)  
 (config-preposition) name [3-892](#)  
 (config-preposition) recursive [3-894](#)  
 (config-preposition) root [3-895](#)  
 (config-preposition) scan-type [3-893](#), [3-896](#)  
 (config-preposition) schedule [3-897](#)  
 (config-preposition) server [3-899](#)  
 (config-preposition) user-agent [3-901](#)  
 (config-preposition) user-proxy [3-900](#)

---

## Service Context Configuration Mode Commands

(config-scxt) appnav-controller-group [3-987](#)  
 (config-scxt) authentication [3-988](#)  
 (config-scxt) description [3-989](#)  
 (config-scxt) enable [3-990](#)  
 (config-scxt) service-node-group [3-992](#)  
 (config-scxt) service-policy [3-993](#)

---

## Service Node Configuration Mode Commands

(config-sn) authentication [3-979](#)  
 (config-sn) description [3-980](#)  
 (config-sn) enable [3-981](#)  
 (config-sn) node-discovery [3-982](#)

(config-sn) shutdown [3-984](#)

---

## Service Node Group Configuration Mode Commands

(config-sng) description [3-975](#)  
 (config-sng) service-node [3-976](#)

---

## SSL Accelerated Service Configuration Mode Commands

(config-ssl-accelerated) cipher-list [3-915](#)  
 (config-ssl-accelerated) client-cert-key [3-916](#)  
 (config-ssl-accelerated) client-cert-verify [3-917](#)  
 (config-ssl-accelerated) client-version-rollback-check [3-918](#)  
 (config-ssl-accelerated) description [3-919](#)  
 (config-ssl-accelerated) inservice [3-920](#)  
 (config-ssl-accelerated) server-cert-key [3-922](#)  
 (config-ssl-accelerated) server-cert-verify [3-923](#)  
 (config-ssl-accelerated) server-domain [3-924](#)  
 (config-ssl-accelerated) server-ip [3-925](#)  
 (config-ssl-accelerated) server-name [3-926](#)  
 (config-ssl-accelerated) version [3-927](#)

---

## SSL Cipher List Configuration Mode Commands

(config-cipher-list) cipher [3-930](#)

---

## SSL Global Service Configuration Mode Commands

(config-ssl-global) cipher-list [3-935](#)  
 (config-ssl-global) machine-cert-key [3-936](#)  
 (config-ssl-global) version [3-937](#)

---

## SSL Host Peering Service Configuration Mode Commands

(config-ssl-peering) cipher-list [3-941](#)  
 (config-ssl-peering) peer-cert-verify [3-942](#)  
 (config-ssl-peering) version [3-943](#)

---

## SSL Management Service Configuration Mode Commands

- (config-ssl-mgmt) cipher-list [3-947](#)
- (config-ssl-mgmt) peer-cert-verify [3-948](#)
- (config-ssl-mgmt) version [3-949](#)

---

## Standard ACL Configuration Mode Commands

- (config-std-nacl) delete [3-853](#)
- (config-std-nacl) deny [3-854](#)
- (config-std-nacl) exit [3-856](#)
- (config-std-nacl) list [3-857](#)
- (config-std-nacl) move [3-858](#)
- (config-std-nacl) permit [3-859](#)

---

## WCCP Configuration Mode Commands

- (config-wccp-service) assignment-method [3-953](#)
  - (config-wccp-service) egress-method [3-955](#)
  - (config-wccp-service) enable [3-957](#)
  - (config-wccp-service) exit [3-958](#)
  - (config-wccp-service) failure-detection [3-959](#)
  - (config-wccp-service) password [3-961](#)
  - (config-wccp-service) redirect-method [3-962](#)
  - (config-wccp-service) router-list-num [3-964](#)
  - (config-wccp-service) weight [3-966](#)
-