

# Low Latency VOD Support

The Cisco cBR-8 router supports Low Latency Video on Demand (VOD) sessions for gaming.

#### Contents

- Information About Low Latency VOD Support, on page 1
- How to Configure Low Latency VOD Support, on page 2
- Feature Information for Low Latency VOD Support, on page 4

# **Information About Low Latency VOD Support**

### **Overview of Low Latency VOD Support**

Each Cisco cBR-8 RF linecard supports up to 1280 low latency VOD gaming sessions and up to 64 unique low latency QAMs. These numbers are applicable to both Annex A and B.

An output QAM is treated as low latency if it is associated with a virtual carrier group (VCG) that is configured as low-latency.

A table-based input session is treated as low latency if the session jitter  $\leq 50$  ms and output QAM is low latency.

A GQI input session is treated as low latency if the session type is gaming and output QAM is low latency.

Low latency VOD gaming, normal VOD, and Switched Digital Video (SDV) can share the same low latency QAM.

Each Cisco cBR-8 RF linecard supports up to 384 unique normal latency Annex B video QAMs (288 Annex A). Each QAM used for low latency reduces the number of remaining available QAMs by two. For example, the linecard can support up to 256 normal latency and 64 low latency Annex B QAMs.

The average latency of a low latency session is approximately 13 ms plus 50% of the jitter buffer size.

## How to Configure Low Latency VOD Support

### **Configuring the Low Latency Virtual Carrier Group**

To configure the low latency virtual carrier group, follow the steps below:

```
enable
configure terminal
cable video
virtual-carrier-group id
low-latency
```

If more than 64 low latency QAM channels are being configured, CLI will output the following error:

%ERROR: Number of low latency QAM channels configured has reached the linecard limit.

If a QAM is configured for low latency, it cannot be configured for broadcast and vice versa, CLI will output the following errors:

```
%ERROR: Failed to set low latency to virtual group.
Reason: Broadcast service type is set and cannot set low latency.
%ERROR: Failed to set_svctype to virtual group.
```

```
Reason: Low latency is set and cannot set service type to broadcast.
```

#### Verifying the Low Latency Virtual Carrier Group Configuration

To verify the configuration of the low latency virtual carrier group, use the **show cable video virtual-carrier-group** command as shown in the example below:

```
Router# show cable video virtual-carrier-group id 1
Name: vcg1
 ID: 1
 Service Distribution Group Name: sdg1
 Service Distribution Group ID: 1
 Logical Edge Device Name: led1
 Logical Edge Device ID: 1
 ServiceType: narrowcast
 Encrypted: N
 Low Latency: Y
 Number of VEIs: 0
 Virtual Edge Input:
 Input Port VEI
                            Bundle
 ID
           ΙP
                             ID
 _____
 Number of RF-Channels: 8
 RF-Channel Range TSID Range Output Port Number Range
 _____
                100-107 100-107
 0-7
```

#### Verifying the Low Latency in Linecard

To verify the low latency configuration in the linecard, use the **show cable video low-latency linecard** command as shown in the example below:

```
Router# show cable video low-latency linecard all
Line Card: 1
  Virtual-Carrier-Group: vcg1
  Service-Distribution-Group: sdg1
  Logical-Edge-Device: led1
  Number of RF-Channels: 8
  RF-Channel Range TSID Range Output Port Number Range
  _____
  0-7
                  100-107
                                    100-107
Line Card: 2
  Virtual-Carrier-Group: vcg2
  Service-Distribution-Group: sdg2
  Logical-Edge-Device: led1
  Number of RF-Channels: 8
  RF-Channel Range TSID Range Output Port Number Range
    _____
                         -------
  0 - 7
                   200-207
                                    200-207
```

### **Configuring the Jitter Buffer Size for Table Based Session**

To configure the jitter buffer size for table-based session, follow the steps below:

```
enable
configure terminal
cable video
table-based
vcg vcg_name
rf-channel start_rf_channel-end_rf_channel
session session_name input-port input_port_number start-udp-port
unicast_udp_port_number num-sessions-per-qam_max_sessions_per_qam_channel
processing-type [data|passthru|remap|remux] start-program program_number jitter
jitter_value
```

The default jitter buffer size for table-based video is 100 ms.

#### Configuring the Jitter Buffer Size for GQI

To configure the jitter buffer size for GQI session, follow the steps below:

enable
configure terminal
cable video
jitter session type jitter value

#### Verifying Jitter Buffer Size for GQI

To verify the jitter buffer size for GQI session, use the **show cable video jitter** command as shown in the example below:

```
Router# show cable video jitter
Session jitter:
VOD: 200
SDV: 200
broadcast: 200
gaming: 5
```

table-based: 100

### **Verifying the Low Latency Sessions**

To verify the configuration of the low latency session, use the **show cable video session logical-edge-device** command as shown in the example below:

```
Router# show cable video session logical-edge-device id 1
Total Sessions = 160
```

SessionOutputStreamingSessionSessionSourceUDPOutputInputOutputInputOutputEncryptLowSessionInputInputIdPortTypeTypeUcast Dest IP/Mcast IP (S,G)PortProgram StateStateBitrateBitrateTypeStatusLatency Name

1048576 100	Remap	UDP	174.101.1.1	49152 1	ACTIVE-PSI
ON 1723787	1722987	CLEAR	– Y	t1.1.0.1.0.49152	
1048577 100	Remap	UDP	174.101.1.1	49153 2	ACTIVE-PSI
ON 1724147	1722987	CLEAR	- Y	t1.1.0.1.0.49153	
1048578 100	Remap	UDP	174.101.1.1	49154 3	ACTIVE-PSI
ON 1722807	1722987	CLEAR	- Y	t1.1.0.1.0.49154	
1048579 100	Remap	UDP	174.101.1.1	49155 4	ACTIVE-PSI
ON 1723279	1722987	CLEAR	– Y	t1.1.0.1.0.49155	
1048580 100	Remap	UDP	174.101.1.1	49156 5	ACTIVE-PSI
ON 1723665	1722987	CLEAR	- Y	t1.1.0.1.0.49156	
1048581 100	Remap	UDP	174.101.1.1	49157 6	ACTIVE-PSI
ON 1724096	1722987	CLEAR	- Y	t1.1.0.1.0.49157	
1048582 100	Remap	UDP	174.101.1.1	49158 7	ACTIVE-PSI
ON 1724475	1722987	CLEAR	– Y	t1.1.0.1.0.49158	
1048583 100	Remap	UDP	174.101.1.1	49159 8	ACTIVE-PSI
ON 1723166	1722988	CLEAR	– Y	t1.1.0.1.0.49159	
1048584 100	Remap	UDP	174.101.1.1	49160 9	ACTIVE-PSI
ON 1723595	1722988	CLEAR	– Y	t1.1.0.1.0.49160	
1048585 100	Remap	UDP	174.101.1.1	49161 10	ACTIVE-PSI
ON 1724024	1722988	CLEAR	– Y	t1.1.0.1.0.49161	
1048586 100	Remap	UDP	174.101.1.1	49162 11	ACTIVE-PSI
ON 1724425	1722988	CLEAR	– Y	t1.1.0.1.0.49162	
1048587 100	Remap	UDP	174.101.1.1	49163 12	ACTIVE-PSI
ON 1723547	1722989	CLEAR	– Y	t1.1.0.1.0.49163	
1048588 100	Remap	UDP	174.101.1.1	49164 13	ACTIVE-PSI
ON 1722215	1722988	CLEAR	– Y	t1.1.0.1.0.49164	
1048589 100	Remap	UDP	174.101.1.1	49165 14	ACTIVE-PSI
ON 1722683	1722988	CLEAR	– Y	t1.1.0.1.0.49165	
1048590 100	Remap	UDP	174.101.1.1	49166 15	ACTIVE-PSI
ON 1723060	1723001	CLEAR	- Y	t1.1.0.1.0.49166	
More					

# **Feature Information for Low Latency VOD Support**

Use Cisco Feature Navigator to find information about the platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to the www.cisco.com/go/cfn link. An account on the Cisco.com page is not required.



**Note** The following table lists the software release in which a given feature is introduced. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Table 1: Feature Information for Low Latency VOD Support

Feature Name	Releases	Feature Information
Low Latency VOD	Cisco IOS XE Everest	This feature was integrated on the Cisco cBR
Support	16.6.1	Series Converged Broadband Routers.

I