

Redundant Multicast DEPI Pool

This document describes how to configure redundant multicast DEPI pool.

Finding Feature Information

Your software release may not support all the features that are documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. The Feature Information Table at the end of this document provides information about the documented features and lists the releases in which each feature is supported.

Use Cisco Feature Navigator to find information about the platform support and Cisco software image support. To access Cisco Feature Navigator, go to the link http://tools.cisco.com/ITDIT/CFN/. An account at the http://www.cisco.com/ site is not required.

- Redundant Multicast DEPI Pool, on page 1
- Configure Redundant Multicast DEPI Pool, on page 2
- Feature Information for Redundant Multicast DEPI Pool, on page 3

Redundant Multicast DEPI Pool

In DS sharing, the DS controller of the secondary line card uses the same multicast IP address as the primary line card DS controller. For a single RPD, the principal and standby Cores use different source IP addresses, but same group IP address in a multicast group. However, the NCS switch does not support one Group with multiple Sources in a multicast group. Hence, you must assign additional multicast IP addresses for standby cores.

Assign the additional multicast IP addresses to the DS controllers on the secondary line cards if the secondary line card is up.

When you enable the redundant multicast DEPI pool, the secondary line card is up in the redundancy line card group and the multicast IP addresses are assigned to secondary line card from the redundant multicast pool. All RPDs on standby cores are automatically cleared to be offline and later online again.

When you disable the redundant multicast pool, the IP addresses are removed from the redundant multicast pool, and all the RPD standby cores are cleared automatically. If you do not configure redundant pool, the secondary line card downstream controllers use the same IP as the downstream controllers in the primary line card.

You cannot use the redundant multicast pool in the downstream controller profile configuration.

Multicast IP address for the secondary line card is assigned based on the DS controller and the TenGE port. One DS controller can be assigned 8 IPv4/IPpv6 addresses from Tx/1/0 to Tex/1/7, where x is the secondary line card slot number. Hence, the redundant multicast DEPI pool needs a minimum of 266 IP addresses (32 controller for 8 ports for DOCSIS, 10 for OOB). If 266 IP addresses are not available, you can assign 4 IPv4/IPv6 addresses to the ports 0,2,4,6 on a single DS controller for multicast DEPI IP addresses on the secondary line card.

Configure Redundant Multicast DEPI Pool

This section describes how to configure the redundant multicast DEPI pool on Cisco cBR-8 routers.

Configuring Redundant Multicast DEPI Pool

When a secondary line card is configured, multicast IP addresses are assigned to its downstream controllers from the redundant multicast DEPI pool.

Step 1 Configure the multicast DEPI pool by using the following command:

configure terminal
cable depi multicast pool id{ip|ipv6} address ip mask

Step 2 Verify the multicast DEPI pool configuration.

show cable depi multicast pool

Example:

show cable depi multicast pool Load for five secs: 7%/1%; one minute: 7%; five minutes: 7% No time source, *15:57:05.512 CST Wed Aug 22 2018 Net Mask POOL ID Net IP Redundant DESCRIPTION 227.0.0.0255.255.255.0227.226.225.0255.255.255.0 1 FALSE 127 FALSE to TE9/1/1+TE9/1/7 POOL ID IPv6 Redundant DESCRIPTION FF3A::9000:0/120 10 FALSE

Step 3 Configure the redundant multicast DEPI pool.

```
configure terminal
  cable depi multicast pool id
  redundant
```

Step 4 Verify the redundant multicast DEPI pool configuration.

show cable depi multicast pool

Example:

 show cable depi multicast pool

 Load for five secs: 7%/1%; one minute: 7%; five minutes: 7%

 No time source, *16:27:05.552 CST Wed Aug 22 2018

 POOL ID
 Net IP

 Net Mask
 Redundant DESCRIPTION

 1
 227.0.0.0
 255.255.255.0

 127
 227.226.225.0
 255.255.255.0

 FALSE
 to TE9/1/1+TE9/1/7

POOL ID	IPv6	Redundant	DESCRIPTION
10	FF3A::9000:0/120	TRUE	

Verify Assigned Multicast IP Addresses

Verify the multicast addresses that are assigned to the secondary linecard downstream controllers by running the show cable depi multicast ip/ipv6 all command, similar to the following example:

```
show cable depi multicast ipv6 all
Load for five secs: 6%/0%; one minute: 6%; five minutes: 7%
No time source, *14:23:14.522 CST Tue Aug 28 2018
IPv6
                 POOL ID CONTROLLER
FF3E::8140:0
                            0/0/0(1-Te0/1/0)
                 2.0
FF3E::8140:8
                 20
                            0/0/1(2-Te0/1/0)
FF3E::8140:10
                  20
                            0/0/2(3-Te0/1/0)
FF3E::8140:18
                 20
                            0/0/3(4-Te0/1/0)
                            0/0/4(5-Te0/1/0)
FF3E::8140:20
                 20
FF3E::8140:28
                 2.0
                            0/0/5(6-Te0/1/0)
                            0/0/6(7-Te0/1/0)
FF3E::8140:30
                 20
```

Feature Information for Redundant Multicast DEPI Pool

Use Cisco Feature Navigator to find information about the platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to the https://cfnng.cisco.com/ link. An account on the Cisco.com page is not required.

N.

Note

The following table lists the software release in which a given feature is introduced. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Table 1: Feature Information for Redundant Multicast DEPI Pool

Feature Name	Releases	Feature Information
Redundant Multicast DEPI Pool	1	This feature was introduced on the Cisco cBR Series Converged Broadband Routers.