



## List of Pre-loaded YANG Modules for MDT Collection

This section lists the YANG modules that the Cisco Crosswork Data Gateway supports for MDT collection on Cisco IOS XR devices.

cli_xr_bgp_oper.yang	Cisco-IOS-XR-ip-bfd-oper.yang
Cisco-IOS-XR-ipv4-bgp-oper.yang	Cisco-IOS-XR-asr9k-xbar-oper.yang
Cisco-IOS-XR-ipv4-acl-oper.yang	Cisco-IOS-XR-snmp-sensormib-oper.yang
Cisco-IOS-XR-shellutil-filesystem-oper.yang	Cisco-IOS-XR-config-cfgmgr-oper.yang
Cisco-IOS-XR-infra-alarm-logger-oper.yang	Cisco-IOS-XR-infra-fti-oper.yang
Cisco-IOS-XR-icpe-infra-oper.yang	Cisco-IOS-XR-dot1x-oper.yang
Cisco-IOS-XR-fretta-bcm-dpa-stats-oper.yang	Cisco-IOS-XR-sdr-invmgr-diag-oper.yang
Cisco-IOS-XR-cofo-infra-oper.yang	Cisco-IOS-XR-wanphy-ui-oper.yang
Cisco-IOS-XR-man-ems-oper.yang	Cisco-IOS-XR-bundlemgr-oper.yang
Cisco-IOS-XR-mpls-lsd-oper.yang	Cisco-IOS-XR-l2vpn-oper.yang
Cisco-IOS-XR-show-fpd-loc-ng-oper.yang	Cisco-IOS-XR-asr9k-qos-oper.yang
Cisco-IOS-XR-telemetry-model-driven-oper.yang	Cisco-IOS-XR-segment-routing-ms-oper.yang
Cisco-IOS-XR-shellutil-oper.yang	Cisco-IOS-XR-pfi-im-cmd-oper.yang
Cisco-IOS-XR-ip-iep-oper.yang	Cisco-IOS-XR-asic-errors-oper.yang
Cisco-IOS-XR-cdp-oper.yang	Cisco-IOS-XR-lib-keychain-oper.yang
Cisco-IOS-XR-ip-sbfd-oper.yang	Cisco-IOS-XR-sdr-invmgr-oper.yang
Cisco-IOS-XR-tty-management-cmd-oper.yang	Cisco-IOS-XR-ipv4-ospf-oper.yang
Cisco-IOS-XR-upgrade-fpd-oper.yang	Cisco-IOS-XR-pfm-oper.yang
Cisco-IOS-XR-crypto-macsec-secy-oper.yang	Cisco-IOS-XR-config-valid-ccv-oper.yang
Cisco-IOS-XR-ip-iarm-v6-oper.yang	Cisco-IOS-XR-ip-iarm-v4-oper.yang
Cisco-IOS-XR-ipv4-autorp-oper.yang	Cisco-IOS-XR-infra-statsd-oper.yang

Cisco-IOS-XR-pbr-vservice-ea-oper.yang	Cisco-IOS-XR-ipv4-vrrp-oper.yang
Cisco-IOS-XR-ip-domain-oper.yang	Cisco-IOS-XR-cmproxy-oper.yang
Cisco-IOS-XR-ipv4-io-oper.yang	Cisco-IOS-XR-crypto-ssh-oper.yang
Cisco-IOS-XR-ipv4-hsrp-oper.yang	Cisco-IOS-XR-controller-optics-oper.yang
Cisco-IOS-XR-freqsync-oper.yang	Cisco-IOS-XR-atm-vcm-oper.yang
Cisco-IOS-XR-aaa-diameter-oper.yang	Cisco-IOS-XR-dnx-driver-fabric-plane-oper.yang
Cisco-IOS-XR-ip-tcp-oper.yang	Cisco-IOS-XR-asr9k-lc-fca-oper.yang
Cisco-IOS-XR-drivers-media-eth-oper.yang	Cisco-IOS-XR-mpls-vpn-oper.yang
Cisco-IOS-XR-infra-policymgr-oper.yang	Cisco-IOS-XR-asr9k-sc-envmon-oper.yang
Cisco-IOS-XR-fretta-bcm-dpa-hw-resources-oper.yang	Cisco-IOS-XR-es-acl-oper.yang
Cisco-IOS-XR-subscriber-ipsub-oper.yang	Cisco-IOS-XR-evpn-oper.yang
Cisco-IOS-XR-infra-rsi-oper.yang	Cisco-IOS-XR-rptiming-tmg-oper.yang
Cisco-IOS-XR-prm-server-oper.yang	Cisco-IOS-XR-ethernet-lldp-oper.yang
Cisco-IOS-XR-l2rib-oper.yang	Cisco-IOS-XR-ip-ntp-oper.yang
Cisco-IOS-XR-subscriber-pppoe-ma-oper.yang	Cisco-IOS-XR-mediasvr-linux-oper.yang
Cisco-IOS-XR-ocni-local-routing-oper.yang	Cisco-IOS-XR-ipv6-ma-oper.yang
Cisco-IOS-XR-reboot-history-oper.yang	Cisco-IOS-XR-infra-rmf-oper.yang
Cisco-IOS-XR-asr9k-lpts-oper.yang	Cisco-IOS-XR-infra-correlator-oper.yang
Cisco-IOS-XR-infra-serg-oper.yang	Cisco-IOS-XR-mpls-static-oper.yang
Cisco-IOS-XR-rgmgr-oper.yang	Cisco-IOS-XR-snmp-entitymib-oper.yang
Cisco-IOS-XR-ncs1k-mxp-headless-oper.yang	Cisco-IOS-XR-pbr-vservice-mgr-oper.yang
Cisco-IOS-XR-aaa-nacm-oper.yang	Cisco-IOS-XR-pfi-im-cmd-ctrlr-oper.yang
Cisco-IOS-XR-infra-rcmd-oper.yang	Cisco-IOS-XR-fretta-bcm-dpa-resources-oper.yang
Cisco-IOS-XR-crypto-macsec-mka-oper.yang	Cisco-IOS-XR-macsec-ctrlr-oper.yang
Cisco-IOS-XR-tunnel-vpdn-oper.yang	Cisco-IOS-XR-ipv6-nd-oper.yang
Cisco-IOS-XR-ipv4-dhcpd-oper.yang	Cisco-IOS-XR-tunnel-l2tun-oper.yang
Cisco-IOS-XR-ip-rip-oper.yang	Cisco-IOS-XR-infra-dumper-exception-oper.yang
Cisco-IOS-XR-ncs1001-otdr-oper.yang	Cisco-IOS-XR-syncc-oper.yang
Cisco-IOS-XR-asr9k-asic-errors-oper.yang	Cisco-IOS-XR-dnx-driver-oper.yang
Cisco-IOS-XR-pmengine-oper.yang	Cisco-IOS-XR-ncs1k-macsec-ea-oper.yang
Cisco-IOS-XR-linux-os-reboot-history-oper.yang	Cisco-IOS-XR-fretta-bcm-dpa-drop-stats-oper.yang
Cisco-IOS-XR-ppp-ea-oper.yang	Cisco-IOS-XR-infra-sla-oper.yang
Cisco-IOS-XR-asr9k-ptp-pd-oper.yang	Cisco-IOS-XR-ncs1001-ots-oper.yang

Cisco-IOS-XR-ipv4-igmp-oper.yang	Cisco-IOS-XR-nto-misc-shmem-oper.yang
Cisco-IOS-XR-ipv4-bgp-oc-oper.yang	Cisco-IOS-XR-ip-rib-ipv4-oper.yang
Cisco-IOS-XR-ip-pfilter-oper.yang	Cisco-IOS-XR-ipv4-pim-oper.yang
Cisco-IOS-XR-lpts-pre-ifib-oper.yang	Cisco-IOS-XR-pppoe-ea-oper.yang
Cisco-IOS-XR-ipv6-ospfv3-oper.yang	Cisco-IOS-XR-infra-syslog-oper.yang
Cisco-IOS-XR-asr9k-netflow-oper.yang	Cisco-IOS-XR-crypto-sam-oper.yang
Cisco-IOS-XR-infra-xtc-oper.yang	Cisco-IOS-XR-Ethernet-SPAN-oper.yang
Cisco-IOS-XR-sysdb-oper.yang	Cisco-IOS-XR-lpts-ifib-oper.yang
Cisco-IOS-XR-lib-mpp-oper.yang	Cisco-IOS-XR-ethernet-link-oam-oper.yang
Cisco-IOS-XR-infra-xtc-agent-oper.yang	Cisco-IOS-XR-mpls-ldp-oper.yang
Cisco-IOS-XR-ip-rib-ipv6-oper.yang	Cisco-IOS-XR-tty-management-oper.yang
Cisco-IOS-XR-rptiming-dti-oper.yang	Cisco-IOS-XR-lmp-oper.yang
Cisco-IOS-XR-wd-oper.yang	Cisco-IOS-XR-nto-misc-shprocmem-oper.yang
Cisco-IOS-XR-man-xml-ttyagent-oper.yang	Cisco-IOS-XR-procmem-oper.yang
Cisco-IOS-XR-ip-daps-oper.yang	Cisco-IOS-XR-Subscriber-infra-subdb-oper.yang
Cisco-IOS-XR-spirit-install-instmgr-oper.yang	Cisco-IOS-XR-asr9k-np-oper.yang
Cisco-IOS-XR-fretta-grid-svr-oper.yang	Cisco-IOS-XR-ptp-oper.yang
Cisco-IOS-XR-clns-isis-oper.yang	Cisco-IOS-XR-tunnel-nve-oper.yang
Cisco-IOS-XR-ipv4-bgp-oper.yang	Cisco-IOS-XR-ocni-oper.yang
Cisco-IOS-XR-ipv4-ma-oper.yang	Cisco-IOS-XR-ncs6k-acl-oper.yang
Cisco-IOS-XR-l2-eth-infra-oper.yang	Cisco-IOS-XR-manageability-object-tracking-oper.yang
Cisco-IOS-XR-plat-chas-invmgr-oper.yang	Cisco-IOS-XR-ocni-intfbase-oper.yang
Cisco-IOS-XR-dwdm-ui-oper.yang	Cisco-IOS-XR-infra-tc-oper.yang
Cisco-IOS-XR-policy-repository-oper.yang	Cisco-IOS-XR-subscriber-session-mon-oper.yang
Cisco-IOS-XR-ipv6-new-dhcpv6d-oper.yang	Cisco-IOS-XR-ip-udp-oper.yang
Cisco-IOS-XR-subscriber-srg-oper.yang	Cisco-IOS-XR-ipv6-acl-oper.yang
Cisco-IOS-XR-manageability-perfmngmt-oper.yang	Cisco-IOS-XR-crypto-macsec-pl-oper.yang
Cisco-IOS-XR-dnx-port-mapper-oper.yang	Cisco-IOS-XR-aaa-tacacs-oper.yang
Cisco-IOS-XR-mpls-te-oper.yang	Cisco-IOS-XR-man-ipsla-oper.yang
Cisco-IOS-XR-nto-misc-oper.yang	Cisco-IOS-XR-invmgr-oper.yang
Cisco-IOS-XR-ppp-ma-oper.yang	Cisco-IOS-XR-ipv4-arp-oper.yang
Cisco-IOS-XR-config-cfgmgr-exec-oper.yang	Cisco-IOS-XR-aaa-locald-oper.yang
Cisco-IOS-XR-perf-meas-oper.yang	Cisco-IOS-XR-ha-eem-policy-oper.yang

Cisco-IOS-XR-snmp-agent-oper.yang	Cisco-IOS-XR-ascii-ltrace-oper.yang
Cisco-IOS-XR-asr9k-lc-ethctrl-oper.yang	Cisco-IOS-XR-skp-qos-oper.yang
Cisco-IOS-XR-ifmgr-oper.yang	Cisco-IOS-XR-flowspec-oper.yang
Cisco-IOS-XR-iedge4710-oper.yang	Cisco-IOS-XR-icpe-sdacp-oper.yang
Cisco-IOS-XR-controller-otu-oper.yang	Cisco-IOS-XR-fretta-bcm-dpa-npu-stats-oper.yang
Cisco-IOS-XR-subscriber-accounting-oper.yang	Cisco-IOS-XR-alarmgr-server-oper.yang
Cisco-IOS-XR-ncs5500-qos-oper.yang	Cisco-IOS-XR-fia-internal-tcam-oper.yang
Cisco-IOS-XR-skywarp-netflow-oper.yang	Cisco-IOS-XR-tty-server-oper.yang
Cisco-IOS-XR-ncs1k-mxp-lldp-oper.yang	Cisco-IOS-XR-qos-ma-oper.yang
Cisco-IOS-XR-fib-common-oper.yang	Cisco-IOS-XR-aaa-protocol-radius-oper.yang
Cisco-IOS-XR-dnx-netflow-oper.yang	Cisco-IOS-XR-platform-pifib-oper.yang
Cisco-IOS-XR-lpts-pa-oper.yang	Cisco-IOS-XR-asr9k-fsi-oper.yang
Cisco-IOS-XR-ncs1k-mxp-oper.yang	Cisco-IOS-XR-ncs5500-coherent-node-oper.yang
Cisco-IOS-XR-asr9k-sc-invmgr-oper.yang	Cisco-IOS-XR-snmp-ifmib-oper.yang
Cisco-IOS-XR-ptp-pd-oper.yang	Cisco-IOS-XR-ip-mobileip-oper.yang
Cisco-IOS-XR-ethernet-cfm-oper.yang	Cisco-IOS-XR-wdsysmon-fd-oper.yang
Cisco-IOS-XR-pbr-oper.yang	Cisco-IOS-XR-infra-objmgr-oper.yang
Cisco-IOS-XR-ip-rsvp-oper.yang	Cisco-IOS-XR-ipv6-io-oper.yang
Cisco-IOS-XR-terminal-device-oper.yang	Cisco-IOS-XR-plat-chas-invmgr-ng-oper.yang
Cisco-IOS-XR-mpls-oam-oper.yang	Cisco-IOS-XR-ncs5500-coherent-portmode-oper.yang
Cisco-IOS-XR-sse-span-oper.yang	Cisco-IOS-XR-infra-dumper-oper.yang
Cisco-IOS-XR-asr9k-sc-diag-oper.yang	Cisco-IOS-XR-mpls-io-oper.yang