Function Packs

Overview

Function packs extend the functionality of Cisco Crosswork Optimization Engine. This section describes how to configure and use the Bandwidth on Demand (BWoD) and Bandwidth Optimization (BWopt) function packs. To obtain a Cisco Crosswork Optimization Engine function pack license, contact your Cisco representative.