



Migrating From DCNM to ND

- [Migrating from DCNM to ND, on page 1](#)

Migrating from DCNM to ND

You cannot upgrade directly from DCNM 11.5(4) to Nexus Dashboard 4.2.1. Use this workflow instead to upgrade from DCNM 11.5(4) to Nexus Dashboard 4.2.1:

1. First upgrade from DCNM 11.5(4) to Nexus Dashboard 4.1.1 using the procedures provided in the "Migrating From DCNM to ND" section in [Cisco Nexus Dashboard Deployment and Upgrade Guide, Release 4.1.x](#).
2. Then upgrade from Nexus Dashboard 4.1.1 to Nexus Dashboard 4.2.1 using the procedures provided in [Upgrading a Nexus Dashboard 4.1.1 Cluster to This Release](#).



Note There is a known issue where the Nexus Dashboard Orchestrator (NDO) app is disabled after upgrading from DCNM 11.5 to Nexus Dashboard 4.1.1. You will have to manually re-enable the NDO app before upgrading to Nexus Dashboard 4.1.1; otherwise, you will see an upgrade pre-check failure.
