



## **Cisco Nexus 9000 Series NX-OS Command Reference (Show Commands), Release 10.2(x)**

**First Published:** 2022-02-15

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## Trademarks

---

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS REFERENCED IN THIS DOCUMENTATION ARE SUBJECT TO CHANGE WITHOUT NOTICE. EXCEPT AS MAY OTHERWISE BE AGREED BY CISCO IN WRITING, ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS DOCUMENTATION ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED.

The Cisco End User License Agreement and any supplemental license terms govern your use of any Cisco software, including this product documentation, and are located at:

<http://www.cisco.com/go/softwareterms>. Cisco product warranty information is available at <http://www.cisco.com/go/warranty>. US Federal Communications Commission Notices are found here <http://www.cisco.com/c/en/us/products/us-fcc-notice.html>.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any products and features described herein as in development or available at a future date remain in varying stages of development and will be offered on a when-and-if-available basis. Any such product or feature roadmaps are subject to change at the sole discretion of Cisco and Cisco will have no liability for delay in the delivery or failure to deliver any products or feature roadmap items that may be set forth in this document.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

The documentation set for this product strives to use bias-free language. For the purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com go trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)





## CONTENTS

---

|                |                       |
|----------------|-----------------------|
| <b>PREFACE</b> | <b>Trademarks</b> iii |
|----------------|-----------------------|

---

|                  |                  |
|------------------|------------------|
| <b>CHAPTER 1</b> | <b>Notices</b> 1 |
|                  | Notice 2         |

---

|               |                            |
|---------------|----------------------------|
| <b>PART I</b> | <b>All Show Commands</b> 3 |
|---------------|----------------------------|

---

|                  |   |
|------------------|---|
| <b>CHAPTER 2</b> | <b>A Show Commands</b> 5                              |
|                  | show aaa accounting 6                                 |
|                  | show aaa authentication 7                             |
|                  | show aaa authentication login 8                       |
|                  | show aaa authentication login ascii-authentication 9  |
|                  | show aaa authentication login error-enable 10         |
|                  | show aaa authentication login invalid-username-log 11 |
|                  | show aaa authorization 12                             |
|                  | show aaa bypass-user 13                               |
|                  | show aaa client radius statistics 14                  |
|                  | show aaa groups 15                                    |
|                  | show aaa local user blocked 16                        |
|                  | show aaa server radius statistics 17                  |
|                  | show aaa user blocked 18                              |
|                  | show aaa user default-role 19                         |
|                  | show access-list 20                                   |
|                  | show access-list database 24                          |
|                  | show access-list resource 25                          |
|                  | show access-lists 27                                  |

|  |    |
|--|----|
| show access-lists                      | 32 |
| show accounting log                    | 34 |
| show accounting log all                | 35 |
| show accounting log last-index         | 36 |
| show accounting log nvram              | 37 |
| show accounting log nvram last-index   | 38 |
| show accounting log nvram start-seqnum | 39 |
| show accounting log start-seqnum       | 40 |
| show acl status                        | 41 |
| show amt process                       | 42 |
| show amt vrf all                       | 44 |
| show archive log config                | 45 |
| show arp access-lists                  | 46 |

---

**CHAPTER 3****B Show Commands 49**

|                                    |     |
|------------------------------------|-----|
| show background                    | 51  |
| show banner exec                   | 52  |
| show banner motd                   | 53  |
| show bash-shell                    | 54  |
| show bfd clients                   | 55  |
| show bfd neighbors                 | 56  |
| show bgp                           | 60  |
| show bgp                           | 62  |
| show bgp                           | 65  |
| show bgp                           | 74  |
| show bgp                           | 81  |
| show bgp                           | 88  |
| show bgp bmp server                | 91  |
| show bgp community                 | 94  |
| show bgp convergence               | 101 |
| show bgp dampening dampened        | 103 |
| show bgp dampening flap-statistics | 110 |
| show bgp dampening parameters      | 113 |
| show bgp evi                       | 116 |

|                                    |     |
|------------------------------------|-----|
| show bgp extcommunity              | 118 |
| show bgp l3vpn                     | 125 |
| show bgp neighbors                 | 127 |
| show bgp neighbors                 | 134 |
| show bgp neighbors commands        | 145 |
| show bgp neighbors flap-statistics | 147 |
| show bgp neighbors paths           | 149 |
| show bgp path-attribute discard    | 151 |
| show bgp paths                     | 158 |
| show bgp peer-template             | 159 |
| show bgp peer                      | 163 |
| show bgp prefix-list               | 165 |
| show bgp private attr              | 171 |
| show bgp private debug history     | 172 |
| show bgp process                   | 173 |
| show bgp received-paths            | 179 |
| show bgp regexp                    | 186 |
| show bgp segment-routing srv6      | 192 |
| show bgp self-originated           | 193 |
| show bgp sessions                  | 199 |
| show bgp statistics                | 201 |
| show bgp summary                   | 202 |
| show bgp summary                   | 207 |
| show boot                          | 211 |
| show boot auto-copy                | 212 |
| show boot auto-copy list           | 213 |
| show boot current                  | 214 |
| show boot mode                     | 215 |
| show boot order                    | 216 |
| show boot timings                  | 217 |
| show boot variables                | 218 |
| show buffer-drop detail            | 219 |
| show buffer-latency detail         | 220 |

## CHAPTER 4

**C Show Commands 221**

- show callhome 225
- show callhome destination-profile 227
- show callhome destination-profile profile 228
- show callhome destination-profile profile CiscoTAC-1 229
- show callhome destination-profile profile full-txt-destination 230
- show callhome destination-profile profile short-txt-destination 231
- show callhome transport-email 232
- show callhome transport 233
- show callhome user-def-cmds 235
- show cdp 236
- show cdp all 238
- show cdp global 239
- show cdp neighbors 240
- show cdp neighbors detail 241
- show cdp traffic interface2 243
- show cdp traffic interface2 all 244
- show cfs application 245
- show cfs lock 246
- show cfs lock 247
- show cfs merge status 248
- show cfs merge status 249
- show cfs peers 251
- show cfs peers 252
- show cfs regions 253
- show cfs static peers 255
- show cfs status 256
- show checkpoint 257
- show checkpoint 258
- show checkpoint summary 259
- show class-map 260
- show class-map type control-plane 262
- show class-map type network-qos 263



|   |     |
|---|-----|
| show cli alias  | 264 |
| show cli dynamic integers                                 | 265 |
| show cli dynamic strings                                  | 266 |
| show cli history  | 267 |
| show cli interface table                                  | 268 |
| show cli list   | 269 |
| show cli syntax   | 270 |
| show cli variables  | 271 |
| show clock  | 272 |
| show config-profile                                       | 273 |
| show config-profile applied                               | 274 |
| show config-replace log exec                              | 275 |
| show config-replace status                                | 277 |
| show configuration  | 278 |
| show configuration  | 279 |
| show configuration commit                                 | 280 |
| show configuration failed                                 | 281 |
| show configuration file                                   | 282 |
| show configuration session                                | 283 |
| show configuration session                                | 284 |
| show configuration session global-info                    | 285 |
| show configuration session status                         | 286 |
| show configuration session summary                        | 287 |
| show configuration session vsh                            | 288 |
| show consistency-checker copp                             | 289 |
| show consistency-checker copp extended module             | 290 |
| show consistency-checker dme interfaces                   | 291 |
| show consistency-checker egress-xlate private-vlan        | 292 |
| show consistency-checker ehm interface                    | 293 |
| show consistency-checker fcoe                             | 294 |
| show consistency-checker fex-interfaces fex               | 296 |
| show consistency-checker forwarding                       | 297 |
| show consistency-checker forwarding ipv6                  | 299 |
| show consistency-checker forwarding single-route ipv4 vrf | 301 |

|   |     |
|---|-----|
| show consistency-checker fsync                                | 302 |
| show consistency-checker gwmacdb                              | 303 |
| show consistency-checker hardware-telemetry inband brief      | 304 |
| show consistency-checker hardware-telemetry postcard brief    | 305 |
| show consistency-checker kim                                  | 306 |
| show consistency-checker kim interface                        | 307 |
| show consistency-checker l2-tahoe mac-address                 | 308 |
| show consistency-checker l2-tahoe sub-interface               | 309 |
| show consistency-checker l2-tahoe sub-interface vlan          | 310 |
| show consistency-checker l2-tahoe switchport                  | 311 |
| show consistency-checker l2 module                            | 312 |
| show consistency-checker l2 multicast group source vlan       | 313 |
| show consistency-checker l2 multicast mac vlan                | 314 |
| show consistency-checker l3-interface                         | 315 |
| show consistency-checker l3 multicast group source vrf        | 316 |
| show consistency-checker link-state fabric-eth                | 317 |
| show consistency-checker link-state module                    | 318 |
| show consistency-checker membership port-channels             | 319 |
| show consistency-checker membership vlan                      | 320 |
| show consistency-checker multicast nlb cluster-ip vrf         | 321 |
| show consistency-checker multicast vlan                       | 322 |
| show consistency-checker niv-datapath interface               | 323 |
| show consistency-checker pacl extended ingress ip interface   | 324 |
| show consistency-checker pacl extended ingress ip module      | 325 |
| show consistency-checker pacl extended ingress ipv6 module    | 326 |
| show consistency-checker pacl extended ingress ipv6 interface | 327 |
| show consistency-checker pacl extended ingress mac module     | 328 |
| show consistency-checker pacl extended ingress mac interface  | 329 |
| show consistency-checker pacl extended module                 | 330 |
| show consistency-checker pacl module                          | 331 |
| show consistency-checker pacl port-channels                   | 332 |
| show consistency-checker port-state                           | 333 |
| show consistency-checker port-state fabric-eth                | 334 |
| show consistency-checker qinq                                 | 335 |

|   |     |
|---|-----|
| show consistency-checker racl extended egress ip module       | 336 |
| show consistency-checker racl extended egress ipv6 module     | 337 |
| show consistency-checker racl extended egress ip interface    | 338 |
| show consistency-checker racl extended egress ipv6 interface  | 339 |
| show consistency-checker racl extended ingress ip module      | 340 |
| show consistency-checker racl extended ingress ipv6 module    | 341 |
| show consistency-checker racl extended ingress ip interface   | 342 |
| show consistency-checker racl extended ingress ipv6 interface | 343 |
| show consistency-checker racl extended module                 | 344 |
| show consistency-checker racl module                          | 345 |
| show consistency-checker racl port-channels                   | 346 |
| show consistency-checker racl svi interface                   | 347 |
| show consistency-checker segment-routing mpls                 | 348 |
| show consistency-checker selective-qinq                       | 349 |
| show consistency-checker selective-qinq interface             | 350 |
| show consistency-checker sflow                                | 351 |
| show consistency-checker storm-control                        | 352 |
| show consistency-checker stp-state vlan                       | 353 |
| show consistency-checker vacl                                 | 354 |
| show consistency-checker vacl extended ingress ipv6 vlan      | 355 |
| show consistency-checker vacl extended ingress ip vlan        | 356 |
| show consistency-checker vacl extended ingress mac vlan       | 357 |
| show consistency-checker vpc                                  | 358 |
| show consistency-checker vpgrouping interface                 | 359 |
| show consistency-checker vxlan config-check                   | 360 |
| show consistency-checker vxlan infra                          | 361 |
| show consistency-checker vxlan l2 mac-address module          | 362 |
| show consistency-checker vxlan l2 module                      | 363 |
| show consistency-checker vxlan l3 single-route ipv4 vrf       | 364 |
| show consistency-checker vxlan l3 vrf start                   | 365 |
| show consistency-checker vxlan mh mac-addresses               | 366 |
| show consistency-checker vxlan mh pathlist                    | 367 |
| show consistency-checker vxlan pv                             | 368 |
| show consistency-checker vxlan qinq-qinvni                    | 369 |

|   |     |
|---|-----|
| show consistency-checker vxlan qinvni                     | 370 |
| show consistency-checker vxlan selective-qinvni           | 371 |
| show consistency-checker vxlan selective-qinvni interface | 372 |
| show consistency-checker vxlan vlan                       | 373 |
| show consistency-checker vxlan xconnect                   | 374 |
| show controller accounting log                            | 375 |
| show copp diff profile profile2                           | 376 |
| show copp profile   | 377 |
| show copp status  | 382 |
| show copyright  | 383 |
| show cores  | 384 |
| show crypto ca certificates                               | 385 |
| show crypto ca certificates                               | 386 |
| show crypto ca certstore                                  | 387 |
| show crypto ca crl  | 388 |
| show crypto ca remote-certstore                           | 389 |
| show crypto ca trustpoints                                | 390 |
| show crypto ca trustpool                                  | 391 |
| show crypto ca trustpool last download status             | 392 |
| show crypto ca trustpool policy                           | 393 |
| show crypto certificatemap                                | 394 |
| show crypto key mypubkey rsa                              | 395 |
| show crypto ssh-auth-map                                  | 396 |
| show cts  | 397 |
| show current  | 398 |

---

**CHAPTER 5**
**D Show Commands 399**

|                                |     |
|--------------------------------|-----|
| show dampening interface       | 401 |
| show device-alias database     | 402 |
| show device-alias merge status | 403 |
| show device-alias name         | 404 |
| show device-alias pending-diff | 405 |
| show device-alias pending      | 406 |
| show device-alias pwwn         | 407 |

|  |     |
|--|-----|
| show device-alias session rejected             | 408 |
| show device-alias session status               | 409 |
| show device-alias statistics                   | 410 |
| show device-alias status                       | 411 |
| show diagnostic bootup level                   | 412 |
| show diagnostic content module                 | 413 |
| show diagnostic description module test all    | 414 |
| show diagnostic events                         | 415 |
| show diagnostic ondemand setting               | 416 |
| show diagnostic result module                  | 417 |
| show diagnostic result module all              | 419 |
| show diagnostic simulation module              | 421 |
| show diagnostic status module                  | 422 |
| show diff rollback-patch                       | 423 |
| show dot1q-tunnel                              | 424 |
| show dot1q-tunnel interface                    | 425 |
| show dot1x                                     | 426 |
| show dot1x all                                 | 427 |
| show dot1x all details                         | 429 |
| show dot1x all statistics                      | 432 |
| show dot1x all summary                         | 434 |
| show dot1x interface                           | 435 |
| show dot1x interface client statistics         | 440 |
| show dot1x interface client statistics address | 442 |
| show dpvm database                             | 443 |
| show dpvm fip                                  | 444 |
| show dpvm merge statistics                     | 445 |
| show dpvm merge status                         | 446 |
| show dpvm pending-diff                         | 447 |
| show dpvm pending                              | 448 |
| show dpvm ports                                | 449 |
| show dpvm session status                       | 450 |
| show dpvm status                               | 451 |

---

**CHAPTER 6****E Show Commands 453**

- show ecp 454
- show elam report 456
- show email 457
- show encryption service status 458
- show environment 459
- show epbr policy 465
- show epbr statistics policy 467
- show errdisable detect 468
- show errdisable flap 469
- show esmc counters interface 470
- show esmc packet-trace 471
- show ethanalyzer background-session 472
- show evb 473
- show evb hosts 474
- show evb vsi 476
- show event manager environment 478
- show event manager event-types 479
- show event manager events action-log 480
- show event manager history events 481
- show event manager policy-state 482
- show event manager script system 483
- show event manager system-policy 484

---

**CHAPTER 7****F Show Commands 485**

- show fabric-binding database 490
- show fabric-binding efmd statistics 491
- show fabric-binding fip 492
- show fabric-binding statistics 493
- show fabric-binding status 494
- show fabric-binding violations 495
- show fabric database dci 496
- show fabric database host 498

|                                      |     |
|--------------------------------------|-----|
| show fabric database host statistics | 502 |
| show fabric database host summary    | 505 |
| show fabric database profile-map     | 506 |
| show fabric database static-host     | 507 |
| show fabric database statistics      | 508 |
| show fabric forwarding host-db       | 510 |
| show fabric forwarding ip local      | 512 |
| show fabric forwarding ipv6 local    | 513 |
| show fabric multicast globals        | 514 |
| show fabric multicast ipv4 l2 vni    | 516 |
| show fabric multicast statistics     | 517 |
| show fabric multicast vrf            | 519 |
| show fabric switch information       | 520 |
| show fc2 bind                        | 521 |
| show fc2 classf                      | 522 |
| show fc2 exchange                    | 524 |
| show fc2 exchresp                    | 526 |
| show fc2 flogi                       | 528 |
| show fc2 nport                       | 529 |
| show fc2 plogi                       | 531 |
| show fc2 plogi_pwwn                  | 533 |
| show fc2 port brief                  | 534 |
| show fc2 port drops                  | 537 |
| show fc2 port state                  | 540 |
| show fc2 socket                      | 542 |
| show fc2 sockexch                    | 543 |
| show fc2 socknotify                  | 544 |
| show fc2 socknport                   | 545 |
| show fc2 vsan                        | 546 |
| show fcalias                         | 547 |
| show fcdomain                        | 548 |
| show fcdomain address-allocation     | 549 |
| show fcdomain allowed                | 550 |
| show fcdomain domain-list            | 551 |

|  |     |
|--|-----|
| show fcdomain fcid persistent            | 552 |
| show fcdomain pending-diff               | 553 |
| show fcdomain pending                    | 554 |
| show fcdomain session-status             | 555 |
| show fcdomain statistics                 | 556 |
| show fcdomain status                     | 557 |
| show fcdomain vsan                       | 558 |
| show fcdroplateny                        | 559 |
| show fcid-allocation area                | 560 |
| show fcid-allocation company-id-from-wwn | 561 |
| show fcns database                       | 562 |
| show fcns statistics                     | 564 |
| show fcoe-npv issu-impact                | 565 |
| show fcoe                                | 566 |
| show fcoe database                       | 567 |
| show fcs database                        | 568 |
| show fcs ie                              | 569 |
| show fcs platform                        | 570 |
| show fcs port                            | 571 |
| show fcs statistics                      | 572 |
| show fcs vsan                            | 573 |
| show fctimer                             | 574 |
| show fctimer D_S_TOV                     | 575 |
| show fctimer E_D_TOV                     | 576 |
| show fctimer F_S_TOV                     | 577 |
| show fctimer R_A_TOV                     | 578 |
| show fctimer last action status          | 579 |
| show fctimer pending-diff                | 580 |
| show fctimer pending                     | 581 |
| show fctimer session status              | 582 |
| show fctimer status                      | 583 |
| show fctimer vsan                        | 584 |
| show fdmi database                       | 585 |
| show fdmi database detail                | 586 |



|                                       |     |
|---------------------------------------|-----|
| show fdmi database detail hba-id vsan | 587 |
| show fdmi database detail vsan        | 588 |
| show fdmi database vsan               | 589 |
| show fdmi suppress-updates            | 590 |
| show feature-set                      | 591 |
| show feature-set services             | 592 |
| show feature                          | 593 |
| show fhrp                             | 594 |
| show fhrp verbose                     | 595 |
| show file                             | 597 |
| show fips status                      | 598 |
| show flogi auto-area-list             | 599 |
| show flogi database                   | 600 |
| show flow cache                       | 601 |
| show flow cache                       | 603 |
| show flow event                       | 605 |
| show flow exporter                    | 607 |
| show flow exporter                    | 609 |
| show flow filter                      | 611 |
| show flow interface                   | 612 |
| show flow interface                   | 613 |
| show flow monitor                     | 614 |
| show flow monitor                     | 615 |
| show flow profile                     | 616 |
| show flow record                      | 618 |
| show flow record                      | 621 |
| show flow rtp                         | 624 |
| show flow rtp timeout                 | 626 |
| show flow system                      | 627 |
| show flow timeout                     | 629 |
| show flow tracer                      | 630 |
| show flow vrf                         | 631 |
| show forwarding                       | 632 |
| show forwarding adjacency             | 633 |

|   |     |
|---|-----|
| show forwarding consistency-fretta l2                                   | 636 |
| show forwarding distribution clients                                    | 637 |
| show forwarding distribution evpn storm-control                         | 638 |
| show forwarding distribution fib-state                                  | 639 |
| show forwarding distribution ip igmp snooping                           | 640 |
| show forwarding distribution ipv6 multicast route                       | 641 |
| show forwarding distribution l2 multicast                               | 643 |
| show forwarding distribution lisp counters                              | 645 |
| show forwarding distribution lisp vrf enabled                           | 646 |
| show forwarding distribution multicast                                  | 647 |
| show forwarding distribution multicast client-ack-db                    | 648 |
| show forwarding distribution multicast client                           | 649 |
| show forwarding distribution multicast download                         | 650 |
| show forwarding distribution multicast mfib                             | 651 |
| show forwarding distribution multicast outgoing-interface-list L2_PRIME | 652 |
| show forwarding distribution multicast resp-ack-timer-msgs              | 653 |
| show forwarding distribution multicast route                            | 654 |
| show forwarding distribution multicast sr hash-db                       | 657 |
| show forwarding distribution multicast vxlan dsg-db                     | 658 |
| show forwarding distribution nve overlay-vlan                           | 659 |
| show forwarding distribution peer-id                                    | 660 |
| show forwarding distribution srv6 local-sid bd-mapping                  | 661 |
| show forwarding distribution trace                                      | 662 |
| show forwarding ecmp  | 663 |
| show forwarding ecmp recursive  | 665 |
| show forwarding inconsistency   | 670 |
| show forwarding interfaces  | 672 |
| show forwarding ipv6  | 673 |
| show forwarding ipv6 adjacency  | 676 |
| show forwarding ipv6 inconsistency                                      | 678 |
| show forwarding ipv6 multicast route                                    | 680 |
| show forwarding kvfib cache on  | 683 |
| show forwarding l2 multicast  | 684 |
| show forwarding l2vpn label vpls  | 686 |

|   |     |
|---|-----|
| show forwarding l2vpn label xconnect                  | 687 |
| show forwarding l2vpn vlan                            | 688 |
| show forwarding mpls                                  | 689 |
| show forwarding mpls drop-stats                       | 691 |
| show forwarding mpls ecmp                             | 692 |
| show forwarding mpls eompls                           | 694 |
| show forwarding mpls eompls ir                        | 695 |
| show forwarding mpls option_b                         | 697 |
| show forwarding mpls srte module                      | 698 |
| show forwarding mpls summary                          | 699 |
| show forwarding multicast-sr loopback interface       | 700 |
| show forwarding multicast-sr mac-trap-db              | 701 |
| show forwarding multicast outgoing-interface-list     | 702 |
| show forwarding multicast route                       | 704 |
| show forwarding nve l2 ingress-replication-peers      | 707 |
| show forwarding nve l3 adjacency tunnel               | 710 |
| show forwarding nve l3 adjacency v6-tunnel            | 712 |
| show forwarding nve l3 ecmp                           | 714 |
| show forwarding nve l3 peers                          | 715 |
| show forwarding nve underlay-interfaces               | 716 |
| show forwarding otv                                   | 717 |
| show forwarding otv ipv6 multicast route              | 718 |
| show forwarding otv multicast outgoing-interface-list | 721 |
| show forwarding otv multicast route                   | 722 |
| show forwarding otv vlan                              | 723 |
| show forwarding security group-tag                    | 724 |
| show forwarding security mac                          | 726 |
| show forwarding srv6 adjacency decap                  | 728 |
| show forwarding srv6 adjacency encap                  | 729 |
| show forwarding srv6 bsid-peer                        | 730 |
| show forwarding srv6 bsid                             | 731 |
| show forwarding srv6 ecmp                             | 732 |
| show forwarding srv6 local-sid                        | 733 |
| show forwarding srv6 peers                            | 734 |

|   |     |
|---|-----|
| show forwarding trace                                 | 735 |
| show forwarding trace profile                         | 736 |
| show forwarding trace profile funcstats               | 737 |
| show frequency synchronization clock-interface brief  | 738 |
| show frequency synchronization clock-interface detail | 740 |
| show frequency synchronization configuration errors   | 743 |
| show frequency synchronization interface              | 745 |
| show frequency synchronization interface brief        | 748 |
| show frequency synchronization selection              | 750 |
| show fspf   | 752 |
| show fspf database                                    | 753 |
| show fspf interface                                   | 754 |
| show fspf vsan  | 755 |
| show fspf vsan interface                              | 756 |
| show fte event  | 757 |
| show fte exporter                                     | 758 |
| show fte monitor                                      | 759 |
| show fte record                                       | 760 |

---

**CHAPTER 8****G Show Commands** 763

|                 |     |
|-----------------|-----|
| show guestshell | 764 |
|-----------------|-----|

---

**CHAPTER 9****H Show Commands** 767

|  |     |
|--|-----|
| show hardware                                    | 769 |
| show hardware access-list lou resource threshold | 772 |
| show hardware access-list resource pooling       | 773 |
| show hardware access-list tcam                   | 774 |
| show hardware capacity                           | 775 |
| show hardware capacity eobc                      | 776 |
| show hardware capacity fabric-utilization        | 777 |
| show hardware capacity forwarding                | 778 |
| show hardware capacity interface                 | 779 |
| show hardware capacity module                    | 780 |
| show hardware capacity power                     | 782 |

|  |     |
|--|-----|
| show hardware fabricpath mac-learning module       | 783 |
| show hardware feature-capability                   | 784 |
| show hardware flow aging                           | 785 |
| show hardware flow entry address type              | 786 |
| show hardware flow ip                              | 787 |
| show hardware flow ipv6                            | 788 |
| show hardware flow l2                              | 789 |
| show hardware flow mpls                            | 790 |
| show hardware flow sampler                         | 791 |
| show hardware flow tah-etrap                       | 792 |
| show hardware flow utilization                     | 793 |
| show hardware forwarding interface statistics mode | 794 |
| show hardware forwarding memory health detail      | 795 |
| show hardware forwarding memory health summary     | 798 |
| show hardware ip verify                            | 800 |
| show hardware profile forwarding-mode              | 801 |
| show hardware profile module                       | 802 |
| show hardware profile packet-drop                  | 803 |
| show hardware profile portmode                     | 804 |
| show hardware profile status                       | 805 |
| show hardware profile team region                  | 807 |
| show hardware qos afd profile                      | 808 |
| show hardware qos burst-detect max-records         | 809 |
| show hardware qos eoq stats-class                  | 810 |
| show hardware qos include ipg                      | 811 |
| show hardware qos ing-pg-hdrm-reserve              | 812 |
| show hardware qos ing-pg-no-min                    | 813 |
| show hardware qos ing-pg-share                     | 814 |
| show hardware qos min-buffer                       | 815 |
| show hardware qos ns-buffer-profile                | 816 |
| show hardware qos ns-mcq3-alias                    | 817 |
| show hardware rate-limiter                         | 818 |
| show hardware rate-limiter                         | 820 |
| show hardware rate-limiter span-egress             | 822 |

show hardware vxlan storm-control 823  
 show hostname 824  
 show hosts 825  
 show hsrp 827  
 show hsrp anycast 831  
 show hsrp anycast interface vlan 832  
 show hsrp anycast remote-db 833  
 show hsrp anycast summary 834  
 show hsrp bfd-sessions 835  
 show hsrp delay 837  
 show hsrp mgo 838  
 show hsrp summary 839

---

**CHAPTER 10**
**I Show Commands 841**

show icam entries acl module inst 852  
 show icam health 854  
 show icam prediction entries acl module inst 855  
 show icam prediction scale 857  
 show icam scale 864  
 show icam system 871  
 show ieth-header-decode 873  
 show inband-telemetry exporter 874  
 show inband-telemetry flow-profile 875  
 show inband-telemetry monitor 876  
 show inband-telemetry queue-profile 877  
 show inband-telemetry record 878  
 show inband-telemetry sessions 879  
 show inband-telemetry watchlist 880  
 show incompatibility-all system 881  
 show incompatibility system 882  
 show install 883  
 show install all failed-standby 884  
 show install all failure-reason 885  
 show install all impact 886

|                                      |     |
|--------------------------------------|-----|
| show install all impact epld         | 887 |
| show install all progress            | 888 |
| show install all status              | 889 |
| show install all time-stats          | 891 |
| show install epld status             | 892 |
| show install log                     | 893 |
| show install mode                    | 894 |
| show install packages                | 895 |
| show install patches                 | 896 |
| show interface                       | 897 |
| show interface                       | 902 |
| show interface                       | 907 |
| show interface                       | 916 |
| show interface                       | 920 |
| show interface                       | 941 |
| show interface                       | 945 |
| show interface                       | 947 |
| show interface                       | 953 |
| show interface                       | 955 |
| show interface                       | 957 |
| show interface aggregate-counters    | 961 |
| show interface aggregate-counters    | 964 |
| show interface bbcredit              | 967 |
| show interface brief                 | 968 |
| show interface brief                 | 969 |
| show interface brief                 | 978 |
| show interface brief                 | 979 |
| show interface brief                 | 982 |
| show interface brief                 | 983 |
| show interface brief                 | 985 |
| show interface brief                 | 986 |
| show interface brief                 | 987 |
| show interface cable-diagnostics-tdr | 988 |
| show interface capabilities          | 989 |

|   |      |
|---|------|
| show interface capabilities                           | 991  |
| show interface capabilities                           | 993  |
| show interface chassis-info                           | 995  |
| show interface counters                               | 997  |
| show interface counters                               | 1000 |
| show interface counters                               | 1004 |
| show interface counters                               | 1005 |
| show interface counters                               | 1008 |
| show interface counters                               | 1010 |
| show interface counters                               | 1012 |
| show interface counters                               | 1014 |
| show interface counters brief                         | 1015 |
| show interface counters brief                         | 1017 |
| show interface counters detailed                      | 1019 |
| show interface counters detailed                      | 1026 |
| show interface counters detailed                      | 1038 |
| show interface counters detailed                      | 1041 |
| show interface counters detailed all                  | 1043 |
| show interface counters detailed all                  | 1045 |
| show interface counters detailed all                  | 1046 |
| show interface counters detailed all                  | 1049 |
| show interface counters detailed all                  | 1050 |
| show interface counters detailed cached               | 1058 |
| show interface counters details                       | 1066 |
| show interface counters details                       | 1070 |
| show interface counters errors                        | 1071 |
| show interface counters errors                        | 1072 |
| show interface counters errors                        | 1074 |
| show interface counters fc                            | 1076 |
| show interface counters snmp                          | 1080 |
| show interface counters snmp                          | 1083 |
| show interface counters storm-control                 | 1085 |
| show interface counters storm-control                 | 1086 |
| show interface counters storm-control multi-threshold | 1087 |



|  |      |
|--|------|
| show interface counters table              | 1089 |
| show interface counters table verbose      | 1090 |
| show interface counters trunk              | 1091 |
| show interface dampening                   | 1092 |
| show interface debounce                    | 1093 |
| show interface debounce                    | 1094 |
| show interface description                 | 1095 |
| show interface description                 | 1096 |
| show interface description                 | 1097 |
| show interface description                 | 1098 |
| show interface description                 | 1099 |
| show interface description                 | 1100 |
| show interface description                 | 1101 |
| show interface description                 | 1102 |
| show interface detail-counters             | 1103 |
| show interface fcoe                        | 1107 |
| show interface fec                         | 1108 |
| show interface flowcontrol                 | 1109 |
| show interface flowcontrol                 | 1110 |
| show interface hardware-mappings           | 1111 |
| show interface mac-address                 | 1112 |
| show interface mac-address                 | 1113 |
| show interface priority-flow-control       | 1114 |
| show interface private-vlan mapping        | 1115 |
| show interface pruning                     | 1116 |
| show interface queuing-drop history brief  | 1117 |
| show interface queuing-drop history detail | 1118 |
| show interface server-info interface       | 1119 |
| show interface snmp-ifindex                | 1120 |
| show interface status                      | 1121 |
| show interface status                      | 1122 |
| show interface status                      | 1123 |
| show interface status                      | 1125 |
| show interface status                      | 1126 |

|  |      |
|--|------|
| show interface status                        | 1127 |
| show interface status                        | 1128 |
| show interface status err-disabled           | 1129 |
| show interface status err-disabled           | 1130 |
| show interface status err-vlans              | 1131 |
| show interface status err-vlans              | 1132 |
| show interface storm-control multi-threshold | 1133 |
| show interface switchport                    | 1134 |
| show interface switchport                    | 1136 |
| show interface switchport backup             | 1138 |
| show interface transceiver                   | 1140 |
| show interface transceiver                   | 1144 |
| show interface transceiver                   | 1152 |
| show interface transceiver fex-fabric        | 1162 |
| show interface transceiver fex-fabric        | 1164 |
| show interface trunk                         | 1171 |
| show interface trunk                         | 1173 |
| show interface trunk vsan                    | 1175 |
| show interface trunk vsan                    | 1176 |
| show interface untagged-cos                  | 1177 |
| show interface vlan mapping                  | 1178 |
| show inventory                               | 1179 |
| show ip adjacency                            | 1180 |
| show ip amt relay                            | 1183 |
| show ip amt route                            | 1184 |
| show ip amt tunnel                           | 1185 |
| show ip arp                                  | 1187 |
| show ip arp anycast topo-info                | 1189 |
| show ip arp client                           | 1190 |
| show ip arp controller-statistics            | 1191 |
| show ip arp esi                              | 1192 |
| show ip arp inspection                       | 1193 |
| show ip arp inspection interfaces            | 1194 |
| show ip arp inspection log                   | 1195 |

|  |      |
|--|------|
| show ip arp inspection statistics              | 1196 |
| show ip arp inspection vlan                    | 1197 |
| show ip arp l2 statistics interface            | 1198 |
| show ip arp multihoming-statistics             | 1199 |
| show ip arp off-list                           | 1201 |
| show ip arp open-flow error-statistics         | 1202 |
| show ip arp statistics                         | 1204 |
| show ip arp suppression-cache                  | 1208 |
| show ip arp suppression topo-info              | 1211 |
| show ip arp tunnel-statistics                  | 1212 |
| show ip arp vpc-statistics                     | 1214 |
| show ip as-path-access-list                    | 1217 |
| show ip client                                 | 1218 |
| show ip community-list                         | 1219 |
| show ip dhcp global statistics                 | 1220 |
| show ip dhcp option82 suboption info interface | 1222 |
| show ip dhcp relay                             | 1223 |
| show ip dhcp relay address                     | 1225 |
| show ip dhcp relay information trusted-sources | 1226 |
| show ip dhcp relay statistics                  | 1227 |
| show ip dhcp snooping                          | 1231 |
| show ip dhcp snooping binding                  | 1232 |
| show ip dhcp snooping statistics               | 1233 |
| show ip dhcp status                            | 1234 |
| show ip dns source-interface                   | 1235 |
| show ip dns source-interface vrf all           | 1236 |
| show ip eigrp                                  | 1237 |
| show ip eigrp accounting                       | 1241 |
| show ip eigrp interfaces                       | 1243 |
| show ip eigrp traffic                          | 1246 |
| show ip extcommunity-list                      | 1248 |
| show ip fib distribution                       | 1249 |
| show ip fib distribution clients               | 1250 |
| show ip fib distribution mroute                | 1251 |

|   |      |
|---|------|
| show ip fib distribution multicast      | 1253 |
| show ip fib distribution state          | 1254 |
| show ip fib mroute                      | 1255 |
| show ip fib route                       | 1257 |
| show ip ftp source-interface            | 1259 |
| show ip ftp source-interface vrf all    | 1260 |
| show ip http source-interface           | 1261 |
| show ip http source-interface vrf all   | 1262 |
| show ip igmp groups                     | 1263 |
| show ip igmp interface                  | 1265 |
| show ip igmp local-groups               | 1269 |
| show ip igmp policy statistics reports  | 1271 |
| show ip igmp snooping                   | 1272 |
| show ip igmp snooping explicit-tracking | 1274 |
| show ip igmp snooping filter details    | 1276 |
| show ip igmp snooping groups            | 1277 |
| show ip igmp snooping lookup-mode       | 1280 |
| show ip igmp snooping mac-oif           | 1281 |
| show ip igmp snooping mrouter           | 1282 |
| show ip igmp snooping otv vlan brief    | 1284 |
| show ip igmp snooping pw vlan brief     | 1285 |
| show ip igmp snooping querier           | 1286 |
| show ip igmp snooping report statistics | 1288 |
| show ip igmp snooping statistics        | 1289 |
| show ip igmp vrf all                    | 1293 |
| show ip interface                       | 1294 |
| show ip lisp                            | 1299 |
| show ip lisp data-cache                 | 1300 |
| show ip lisp locator-hash               | 1301 |
| show ip lisp map-cache                  | 1302 |
| show ip lisp statistics                 | 1303 |
| show ip lisp translate-cache            | 1304 |
| show ip load-sharing                    | 1305 |
| show ip local policy                    | 1306 |

|   |      |
|---|------|
| show ip logging                             | 1307 |
| show ip mbgp                                | 1308 |
| show ip mbgp                                | 1310 |
| show ip mbgp community                      | 1311 |
| show ip mbgp dampening                      | 1312 |
| show ip mbgp extcommunity                   | 1313 |
| show ip mbgp flap-statistics                | 1314 |
| show ip mbgp neighbors                      | 1315 |
| show ip mbgp nexthop-database               | 1317 |
| show ip mbgp nexthop                        | 1318 |
| show ip mbgp prefix-list                    | 1319 |
| show ip mbgp received-paths                 | 1320 |
| show ip mroute                              | 1321 |
| show ip msdp count                          | 1326 |
| show ip msdp mesh-group                     | 1327 |
| show ip msdp peer                           | 1328 |
| show ip msdp policy statistics sa-policy in | 1331 |
| show ip msdp rpf                            | 1333 |
| show ip msdp sa                             | 1335 |
| show ip msdp sources                        | 1337 |
| show ip msdp statistics                     | 1338 |
| show ip msdp summary                        | 1340 |
| show ip multicast vrf                       | 1342 |
| show ip nat-alias                           | 1344 |
| show ip nat max                             | 1345 |
| show ip nat statistics                      | 1346 |
| show ip nat timeout                         | 1349 |
| show ip nat translations                    | 1350 |
| show ip ospf                                | 1352 |
| show ip ospf border-routers                 | 1357 |
| show ip ospf database                       | 1359 |
| show ip ospf database database-summary      | 1362 |
| show ip ospf database detail                | 1364 |
| show ip ospf interface                      | 1370 |

|   |      |
|---|------|
| show ip ospf interface brief                  | 1373 |
| show ip ospf lsa-content-changed-list         | 1375 |
| show ip ospf neighbors                        | 1377 |
| show ip ospf neighbors detail                 | 1379 |
| show ip ospf neighbors summary                | 1382 |
| show ip ospf request-list                     | 1384 |
| show ip ospf retransmission-list              | 1386 |
| show ip ospf route                            | 1388 |
| show ip ospf route summary                    | 1390 |
| show ip ospf segment-routing adj-sid-database | 1392 |
| show ip ospf segment-routing global-block     | 1393 |
| show ip ospf segment-routing sid-database     | 1394 |
| show ip ospf sham-links                       | 1396 |
| show ip ospf sham-links brief                 | 1400 |
| show ip ospf statistics                       | 1401 |
| show ip ospf summary-address                  | 1405 |
| show ip ospf traffic                          | 1406 |
| show ip ospf virtual-links                    | 1410 |
| show ip ospf virtual-links brief              | 1414 |
| show ip pim config-sanity                     | 1415 |
| show ip pim df                                | 1417 |
| show ip pim fabric info                       | 1419 |
| show ip pim fabric legacy-vlans               | 1420 |
| show ip pim group-range                       | 1421 |
| show ip pim host-proxy                        | 1422 |
| show ip pim interface                         | 1423 |
| show ip pim mdt                               | 1427 |
| show ip pim mdt bgp                           | 1429 |
| show ip pim mdt history interval              | 1430 |
| show ip pim mdt receive                       | 1431 |
| show ip pim mdt send                          | 1432 |
| show ip pim neighbor                          | 1433 |
| show ip pim oif-list                          | 1434 |
| show ip pim policy statistics                 | 1436 |

|  |      |
|--|------|
| show ip pim policy statistics jp                     | 1438 |
| show ip pim route                                    | 1439 |
| show ip pim rp-hash                                  | 1441 |
| show ip pim rp                                       | 1442 |
| show ip pim statistics                               | 1445 |
| show ip pim vrf                                      | 1447 |
| show ip ping source-interface                        | 1448 |
| show ip ping source-interface vrf all                | 1449 |
| show ip policy                                       | 1450 |
| show ip prefix-list                                  | 1451 |
| show ip process                                      | 1452 |
| show ip rip  | 1454 |
| show ip rip interface                                | 1456 |
| show ip rip neighbor                                 | 1458 |
| show ip rip policy statistics redistribute           | 1460 |
| show ip rip route                                    | 1462 |
| show ip rip statistics                               | 1464 |
| show ip route  | 1466 |
| show ip sla application                              | 1470 |
| show ip sla configuration                            | 1471 |
| show ip sla enhanced-history collection-statistics   | 1474 |
| show ip sla enhanced-history distribution-statistics | 1478 |
| show ip sla group schedule                           | 1479 |
| show ip sla history                                  | 1480 |
| show ip sla reaction-configuration                   | 1482 |
| show ip sla reaction-trigger                         | 1483 |
| show ip sla responder                                | 1484 |
| show ip sla statistics                               | 1486 |
| show ip sla twamp connection detail                  | 1492 |
| show ip sla twamp connection requests                | 1493 |
| show ip sla twamp session                            | 1494 |
| show ip sla twamp standards                          | 1495 |
| show ip ssh source-interface                         | 1496 |
| show ip ssh source-interface vrf all                 | 1497 |

|   |      |
|---|------|
| show ip static-route                        | 1498 |
| show ip tcp mss                             | 1500 |
| show ip telnet source-interface             | 1501 |
| show ip telnet source-interface vrf all     | 1502 |
| show ip tftp source-interface               | 1503 |
| show ip tftp source-interface vrf all       | 1504 |
| show ip traceroute source-interface         | 1505 |
| show ip traceroute source-interface vrf all | 1506 |
| show ip traffic                             | 1507 |
| show ip traffic pps                         | 1514 |
| show ip udp relay                           | 1515 |
| show ip udp relay interface                 | 1516 |
| show ip udp relay object-group              | 1517 |
| show ip verify source                       | 1518 |
| show ipt details                            | 1519 |
| show ipv6 adjacency                         | 1520 |
| show ipv6 adjacency aggregate-prefix        | 1523 |
| show ipv6 adjacency subnet-prefix           | 1524 |
| show ipv6 amt tunnel                        | 1525 |
| show ipv6 bgp                               | 1527 |
| show ipv6 bgp                               | 1528 |
| show ipv6 bgp community                     | 1529 |
| show ipv6 bgp dampening                     | 1530 |
| show ipv6 bgp extcommunity                  | 1531 |
| show ipv6 bgp flap-statistics               | 1532 |
| show ipv6 bgp neighbors                     | 1533 |
| show ipv6 bgp nexthop-database              | 1534 |
| show ipv6 bgp nexthop                       | 1535 |
| show ipv6 bgp received-paths                | 1536 |
| show ipv6 bgp regexp                        | 1537 |
| show ipv6 bgp summary                       | 1538 |
| show ipv6 client                            | 1539 |
| show ipv6 dhcp guard policy                 | 1541 |
| show ipv6 dhcp relay                        | 1542 |



|  |      |
|--|------|
| show ipv6 dhcp relay statistics          | 1544 |
| show ipv6 fragments                      | 1548 |
| show ipv6 icmp                           | 1549 |
| show ipv6 icmp global traffic            | 1551 |
| show ipv6 icmp interface                 | 1554 |
| show ipv6 icmp l2 statistics             | 1559 |
| show ipv6 icmp nd local-proxy stats      | 1560 |
| show ipv6 icmp off-list                  | 1561 |
| show ipv6 icmp vaddr                     | 1562 |
| show ipv6 icmp vpc-statistics            | 1566 |
| show ipv6 interface                      | 1569 |
| show ipv6 lisp data-cache                | 1574 |
| show ipv6 local policy                   | 1575 |
| show ipv6 mld global traffic             | 1576 |
| show ipv6 mld groups                     | 1577 |
| show ipv6 mld interface                  | 1579 |
| show ipv6 mld local-groups               | 1583 |
| show ipv6 mld snooping                   | 1585 |
| show ipv6 mld snooping explicit-tracking | 1587 |
| show ipv6 mld snooping filter details    | 1589 |
| show ipv6 mld snooping groups            | 1590 |
| show ipv6 mld snooping lookup-mode       | 1593 |
| show ipv6 mld snooping mrouter           | 1594 |
| show ipv6 mld snooping otv vlan brief    | 1596 |
| show ipv6 mld snooping pw vlan brief     | 1597 |
| show ipv6 mld snooping querier           | 1598 |
| show ipv6 mld snooping report statistics | 1600 |
| show ipv6 mld snooping statistics        | 1601 |
| show ipv6 mroute                         | 1605 |
| show ipv6 mtu                            | 1610 |
| show ipv6 multicast vrf                  | 1612 |
| show ipv6 nd ra dns search-list          | 1614 |
| show ipv6 nd ra dns server               | 1615 |
| show ipv6 nd rguard policy               | 1617 |

|  |      |
|--|------|
| show ipv6 neighbor binding                   | 1618 |
| show ipv6 neighbor binding mac               | 1619 |
| show ipv6 neighbor static                    | 1620 |
| show ipv6 pim df                             | 1621 |
| show ipv6 pim fabric info                    | 1623 |
| show ipv6 pim fabric legacy-vlans            | 1624 |
| show ipv6 pim group-range                    | 1625 |
| show ipv6 pim interface                      | 1626 |
| show ipv6 pim mdt                            | 1630 |
| show ipv6 pim mdt bgp                        | 1632 |
| show ipv6 pim mdt history interval           | 1633 |
| show ipv6 pim mdt receive                    | 1634 |
| show ipv6 pim mdt send                       | 1635 |
| show ipv6 pim neighbor                       | 1636 |
| show ipv6 pim oif-list                       | 1637 |
| show ipv6 pim policy statistics jp           | 1639 |
| show ipv6 pim route                          | 1640 |
| show ipv6 pim rp-hash                        | 1642 |
| show ipv6 pim rp                             | 1643 |
| show ipv6 pim statistics                     | 1646 |
| show ipv6 pim vrf                            | 1648 |
| show ipv6 policy                             | 1649 |
| show ipv6 prefix-list                        | 1650 |
| show ipv6 process                            | 1651 |
| show ipv6 rguard statistics                  | 1653 |
| show ipv6 rip policy statistics redistribute | 1654 |
| show ipv6 route                              | 1656 |
| show ipv6 routers                            | 1659 |
| show ipv6 snooping capture-policy            | 1661 |
| show ipv6 snooping counters vlan             | 1662 |
| show ipv6 snooping events                    | 1664 |
| show ipv6 snooping features                  | 1665 |
| show ipv6 snooping messages                  | 1666 |
| show ipv6 snooping policies                  | 1667 |

|   |      |
|---|------|
| show ipv6 snooping policy               | 1668 |
| show ipv6 snooping pss database         | 1670 |
| show ipv6 static-route                  | 1671 |
| show ipv6 traffic                       | 1673 |
| show isis                               | 1676 |
| show isis adjacency                     | 1680 |
| show isis csnp                          | 1683 |
| show isis database                      | 1685 |
| show isis distribute-ls                 | 1690 |
| show isis dynamic-flooding              | 1694 |
| show isis interface                     | 1696 |
| show isis ipv6 redistribute route       | 1702 |
| show isis ipv6 route                    | 1704 |
| show isis ipv6 summary-address          | 1708 |
| show isis lslib                         | 1710 |
| show isis mesh-group                    | 1712 |
| show isis redistribute route            | 1713 |
| show isis route                         | 1715 |
| show isis rrm                           | 1719 |
| show isis segment-routing mapcache      | 1721 |
| show isis segment-routing remote-srgb   | 1723 |
| show isis segment-routing sids          | 1725 |
| show isis segment-routing srv6          | 1726 |
| show isis segment-routing srv6 locators | 1727 |
| show isis spf-log                       | 1729 |
| show isis srm                           | 1731 |
| show isis ssn                           | 1732 |
| show isis statistics                    | 1733 |
| show isis summary-address               | 1734 |
| show isis topology                      | 1736 |
| show isis traffic                       | 1738 |
| show itd                                | 1742 |
| show itd session device-group           | 1747 |
| show itd statistics                     | 1748 |

show itd vrf 1750  
 show itu channel 1751

---

**CHAPTER 11**
**K Show Commands 1753**

show key chain 1754  
 show key chain mode decrypt 1755  
 show keystore 1756  
 show kim inconsistency 1757  
 show kubernetes containers 1758

---

**CHAPTER 12**
**L Show Commands 1759**

show l2 mroute 1766  
 show l2 multicast ftag 1768  
 show l2 multicast trees 1769  
 show l2 route 1771  
 show l2rib clients 1773  
 show l2rib producers 1774  
 show l2rib registrations 1776  
 show l2route cmcast topology 1778  
 show l2route evpn ead all 1779  
 show l2route evpn ethernet-segment esi 1780  
 show l2route evpn fl all 1781  
 show l2route evpn fl evi 1782  
 show l2route evpn imet all 1783  
 show l2route evpn imet evi 1784  
 show l2route evpn mac-ip all 1785  
 show l2route evpn mac-ip evi 1787  
 show l2route evpn mac all 1789  
 show l2route evpn mac evi 1791  
 show l2route evpn path-list all 1793  
 show l2route evpn startup-route all 1794  
 show l2route evpn startup-route evi 1795  
 show l2route evpn topo-child-attr all 1796  
 show l2route evpn topo-child-attr evi 1797

|                              |      |
|------------------------------|------|
| show l2route fl topology     | 1798 |
| show l2route peerid          | 1799 |
| show l2route summary         | 1800 |
| show l2route topology        | 1801 |
| show l2route topology        | 1803 |
| show l2route topology        | 1805 |
| show lacp counters           | 1807 |
| show lacp interface          | 1808 |
| show lacp issu-impact        | 1811 |
| show lacp neighbor           | 1812 |
| show lacp port-channel       | 1813 |
| show lacp system-identifier  | 1814 |
| show lend dot1x address      | 1815 |
| show lend dot1x port         | 1816 |
| show lend stats interface    | 1817 |
| show ldap-search-map         | 1818 |
| show ldap-server             | 1819 |
| show ldap-server groups      | 1821 |
| show ldap-server statistics  | 1823 |
| show license                 | 1825 |
| show license all             | 1826 |
| show license certs           | 1829 |
| show license data conversion | 1830 |
| show license eventlog        | 1831 |
| show license history message | 1832 |
| show license host-id         | 1833 |
| show license status          | 1834 |
| show license summary         | 1837 |
| show license tech support    | 1838 |
| show license tech support    | 1839 |
| show license udi             | 1840 |
| show license usage           | 1841 |
| show license version         | 1843 |
| show line                    | 1844 |

|                                     |      |
|-------------------------------------|------|
| show line console                   | 1845 |
| show line console connected         | 1846 |
| show line console user-input-string | 1847 |
| show lisp ddt                       | 1848 |
| show lisp ddt queue                 | 1849 |
| show lisp ddt referral-cache        | 1850 |
| show lisp dynamic-eid               | 1851 |
| show lisp elp                       | 1852 |
| show lisp negative-prefix           | 1853 |
| show lisp proxy-itr                 | 1854 |
| show lisp site                      | 1855 |
| show lisp site instance-id          | 1856 |
| show lldp all                       | 1857 |
| show lldp dcba interface            | 1858 |
| show lldp entry                     | 1860 |
| show lldp interface                 | 1862 |
| show lldp neighbors                 | 1864 |
| show lldp neighbors detail          | 1866 |
| show lldp neighbors system-detail   | 1868 |
| show lldp poe interface             | 1869 |
| show lldp portid-subtype            | 1870 |
| show lldp timers                    | 1871 |
| show lldp tlv-select                | 1872 |
| show lldp traffic                   | 1873 |
| show lldp traffic interface         | 1874 |
| show lldp traffic interface all     | 1875 |
| show locator-led status             | 1876 |
| show logging                        | 1877 |
| show logging console                | 1878 |
| show logging dropcount              | 1879 |
| show logging history                | 1880 |
| show logging info                   | 1881 |
| show logging ip access-list cache   | 1883 |
| show logging ip access-list status  | 1885 |

|  |      |
|--|------|
| show logging last                          | 1886 |
| show logging level                         | 1887 |
| show logging level                         | 1889 |
| show logging level aaa                     | 1890 |
| show logging level acl                     | 1891 |
| show logging level acllog                  | 1892 |
| show logging level aclmgr                  | 1893 |
| show logging level adbm                    | 1894 |
| show logging level adjmgr                  | 1895 |
| show logging level amt                     | 1896 |
| show logging level arp                     | 1897 |
| show logging level ascii-cfg               | 1898 |
| show logging level assoc_mgr               | 1899 |
| show logging level backup                  | 1900 |
| show logging level bfd                     | 1901 |
| show logging level bgp                     | 1902 |
| show logging level bloggerd                | 1903 |
| show logging level bootvar                 | 1904 |
| show logging level callhome                | 1905 |
| show logging level capability              | 1906 |
| show logging level cdp                     | 1907 |
| show logging level cert_enroll             | 1908 |
| show logging level cfs                     | 1909 |
| show logging level clis                    | 1910 |
| show logging level clk_mgr                 | 1911 |
| show logging level confcheck               | 1912 |
| show logging level copp                    | 1913 |
| show logging level core-dmon               | 1914 |
| show logging level cts                     | 1915 |
| show logging level device-alias            | 1916 |
| show logging level dhclient                | 1917 |
| show logging level dhcp_snoop              | 1918 |
| show logging level diagnostic diag_port_lb | 1919 |
| show logging level diagnostic diagclient   | 1920 |

|   |      |
|---|------|
| show logging level diagnostic diagmgr   | 1921 |
| show logging level dot1x                | 1922 |
| show logging level dpvm                 | 1923 |
| show logging level ecp                  | 1924 |
| show logging level eigrp                | 1925 |
| show logging level eltm                 | 1926 |
| show logging level epbr                 | 1927 |
| show logging level epp                  | 1928 |
| show logging level ethdstats            | 1929 |
| show logging level ethpm                | 1930 |
| show logging level evb                  | 1931 |
| show logging level evmc                 | 1932 |
| show logging level evmed                | 1933 |
| show logging level evms                 | 1934 |
| show logging level fabric forwarding    | 1935 |
| show logging level fabricpath isis      | 1936 |
| show logging level fabricpath switch-id | 1937 |
| show logging level fc2d                 | 1938 |
| show logging level fcdomain             | 1939 |
| show logging level fcns                 | 1940 |
| show logging level fcoe_mgr             | 1941 |
| show logging level fcs                  | 1942 |
| show logging level fdmi                 | 1943 |
| show logging level feature-mgr          | 1944 |
| show logging level flogi                | 1945 |
| show logging level fs-daemon            | 1946 |
| show logging level fspf                 | 1947 |
| show logging level fsync_mgr            | 1948 |
| show logging level gpixm                | 1949 |
| show logging level hardware-telemetry   | 1950 |
| show logging level hsrp                 | 1951 |
| show logging level icam                 | 1952 |
| show logging level igmp                 | 1953 |
| show logging level im                   | 1954 |



|  |      |
|--|------|
| show logging level imp                 | 1955 |
| show logging level interface-vlan      | 1956 |
| show logging level ip sla responder    | 1957 |
| show logging level ip sla sender       | 1958 |
| show logging level ip sla twamp-server | 1959 |
| show logging level ipconf              | 1960 |
| show logging level ipfib               | 1961 |
| show logging level ipqos               | 1962 |
| show logging level ipv6 icmp           | 1963 |
| show logging level ipv6 mfw            | 1964 |
| show logging level ipv6 pim            | 1965 |
| show logging level iscm                | 1966 |
| show logging level iscm                | 1967 |
| show logging level isis                | 1968 |
| show logging level l2fm                | 1969 |
| show logging level l3vm                | 1970 |
| show logging level lacp                | 1971 |
| show logging level ldap                | 1972 |
| show logging level lim                 | 1973 |
| show logging level lisp                | 1974 |
| show logging level lldp                | 1975 |
| show logging level m2rib               | 1976 |
| show logging level mfdm                | 1977 |
| show logging level mfw                 | 1978 |
| show logging level mld                 | 1979 |
| show logging level mmode               | 1980 |
| show logging level module              | 1981 |
| show logging level monitor             | 1982 |
| show logging level mpls manager        | 1983 |
| show logging level mpls switching      | 1984 |
| show logging level msdp                | 1985 |
| show logging level mvsh                | 1986 |
| show logging level nat                 | 1987 |
| show logging level nbm                 | 1988 |

|                                   |      |
|-----------------------------------|------|
| show logging level netstack       | 1989 |
| show logging level nfm            | 1990 |
| show logging level nfm            | 1991 |
| show logging level ngmvpn         | 1992 |
| show logging level ngoam          | 1993 |
| show logging level npv            | 1994 |
| show logging level ntp            | 1995 |
| show logging level nve            | 1996 |
| show logging level nxsdk          | 1997 |
| show logging level ofm            | 1998 |
| show logging level openflow       | 1999 |
| show logging level ospf           | 2000 |
| show logging level ospfv3         | 2001 |
| show logging level otv isis       | 2002 |
| show logging level pfstat         | 2003 |
| show logging level pie            | 2004 |
| show logging level pim            | 2005 |
| show logging level pixm           | 2006 |
| show logging level pktmgr         | 2007 |
| show logging level platform       | 2008 |
| show logging level plcmgr         | 2009 |
| show logging level pltfm_config   | 2010 |
| show logging level plugin         | 2011 |
| show logging level poed           | 2012 |
| show logging level port-channel   | 2013 |
| show logging level port-profile   | 2014 |
| show logging level port-resources | 2015 |
| show logging level port-security  | 2016 |
| show logging level port           | 2017 |
| show logging level private-vlan   | 2018 |
| show logging level ptp            | 2019 |
| show logging level radius         | 2020 |
| show logging level rdl            | 2021 |
| show logging level res_mgr        | 2022 |

|   |      |
|---|------|
| show logging level rib                    | 2023 |
| show logging level rip                    | 2024 |
| show logging level routing ipv6 multicast | 2025 |
| show logging level routing multicast      | 2026 |
| show logging level rpm                    | 2027 |
| show logging level rscn                   | 2028 |
| show logging level sal                    | 2029 |
| show logging level san-port-channel       | 2030 |
| show logging level san-port-channel       | 2031 |
| show logging level scheduler              | 2032 |
| show logging level scsi-target            | 2033 |
| show logging level security               | 2034 |
| show logging level segment-routing        | 2035 |
| show logging level session-mgr            | 2036 |
| show logging level sflow                  | 2037 |
| show logging level smm                    | 2038 |
| show logging level snmpd                  | 2039 |
| show logging level snmpmib_proc           | 2040 |
| show logging level spanning-tree          | 2041 |
| show logging level spm                    | 2042 |
| show logging level stripcl                | 2043 |
| show logging level sync                   | 2044 |
| show logging level sysmgr                 | 2045 |
| show logging level tacacs                 | 2046 |
| show logging level telemetry              | 2047 |
| show logging level template_manager       | 2048 |
| show logging level track                  | 2049 |
| show logging level tunnel-encryption      | 2050 |
| show logging level tunnel                 | 2051 |
| show logging level u2rib                  | 2052 |
| show logging level u6rib                  | 2053 |
| show logging level udld                   | 2054 |
| show logging level ufdm                   | 2055 |
| show logging level urib                   | 2056 |

|                                    |      |
|------------------------------------|------|
| show logging level vdc_mgr         | 2057 |
| show logging level virtual-service | 2058 |
| show logging level vlan_mgr        | 2059 |
| show logging level vmm             | 2060 |
| show logging level vmtracker       | 2061 |
| show logging level vpc             | 2062 |
| show logging level vrrp-cfg        | 2063 |
| show logging level vrrp-eng        | 2064 |
| show logging level vrrpv3          | 2065 |
| show logging level vsan            | 2066 |
| show logging level vshd            | 2067 |
| show logging level vtp             | 2068 |
| show logging level wwn             | 2069 |
| show logging level xbar            | 2070 |
| show logging level zone            | 2071 |
| show logging logfile               | 2072 |
| show logging logfile duration      | 2073 |
| show logging logfile last-index    | 2074 |
| show logging logfile start-seqn    | 2075 |
| show logging logfile start-time    | 2076 |
| show logging loopback              | 2077 |
| show logging module                | 2078 |
| show logging monitor               | 2079 |
| show logging nvrn                  | 2080 |
| show logging onboard               | 2081 |
| show logging onboard               | 2084 |
| show logging onboard kernel-trace  | 2085 |
| show logging origin-id             | 2086 |
| show logging pending-diff          | 2087 |
| show logging pending               | 2088 |
| show logging rate-limit            | 2089 |
| show logging rfc-strict            | 2090 |
| show logging server                | 2091 |
| show logging session status        | 2092 |

[show logging source-interface](#) 2093  
[show logging status](#) 2094  
[show logging timestamp](#) 2095  
[show login on-failure log](#) 2096  
[show login on-successful log](#) 2097

---

**CHAPTER 13**
**M Show Commands** 2099

[show mac-list](#) 2101  
[show mac address-table](#) 2102  
[show mac address-table](#) 2104  
[show mac address-table aging-time](#) 2106  
[show mac address-table count](#) 2107  
[show mac address-table count es](#) 2109  
[show mac address-table limit](#) 2110  
[show mac address-table limit user-defined](#) 2111  
[show mac address-table loop-detect](#) 2112  
[show mac address-table multicast](#) 2113  
[show mac address-table notification mac-move](#) 2114  
[show macsec mka](#) 2115  
[show macsec mka session](#) 2116  
[show macsec mka statistics](#) 2119  
[show macsec policy](#) 2124  
[show macsec secy statistics](#) 2125  
[show maintenance maint-delay](#) 2129  
[show maintenance on-reload reset-reasons](#) 2130  
[show maintenance profile](#) 2131  
[show maintenance snapshot-delay](#) 2132  
[show maintenance timeout](#) 2133  
[show mcast](#) 2134  
[show module](#) 2135  
[show module bandwidth-fairness](#) 2138  
[show module port type](#) 2139  
[show module uptime](#) 2140  
[show monitor](#) 2141

|                                 |      |
|---------------------------------|------|
| show monitor session            | 2142 |
| show mpls extended-ecmp         | 2145 |
| show mpls forwarding statistics | 2146 |
| show mpls interfaces            | 2148 |
| show mpls interfaces detail     | 2149 |
| show mpls interfaces statistics | 2150 |
| show mpls ip bindings           | 2151 |
| show mpls ip bindings summary   | 2154 |
| show mpls ip ttl                | 2155 |
| show mpls label range           | 2156 |
| show mpls load-sharing          | 2157 |
| show mpls oam echo statistics   | 2158 |
| show mpls static binding        | 2160 |
| show mpls strip labels          | 2162 |
| show mpls switching             | 2163 |
| show mpls switching clients     | 2167 |
| show mvpn bgp mdt               | 2169 |
| show mvpn bgp mdt               | 2170 |
| show mvpn mdt encap             | 2171 |
| show mvpn mdt encap             | 2172 |
| show mvpn mdt route             | 2173 |
| show mvpn mdt route             | 2174 |
| show mvr                        | 2175 |
| show mvr groups                 | 2176 |
| show mvr interface              | 2177 |
| show mvr members                | 2178 |
| show mvr members count          | 2179 |
| show mvr members vlan           | 2180 |
| show mvr receiver-ports         | 2181 |
| show mvr source-ports           | 2182 |

---

**CHAPTER 14**
**N Show Commands 2183**

|                   |      |
|-------------------|------|
| show nat itd      | 2185 |
| show nbm defaults | 2186 |

|                                       |      |
|---------------------------------------|------|
| show nbm flow-policy                  | 2188 |
| show nbm flows                        | 2190 |
| show nbm flows pending-stitch         | 2194 |
| show nbm flows static                 | 2195 |
| show nbm flows statistics             | 2197 |
| show nbm flows summary                | 2199 |
| show nbm host-policy all              | 2200 |
| show nbm host-policy applied receiver | 2202 |
| show nbm host-policy applied sender   | 2204 |
| show nbm interface bandwidth          | 2206 |
| show ngoam interface statistics       | 2208 |
| show ngoam loop-detection status      | 2209 |
| show ngoam loop-detection summary     | 2210 |
| show ngoam loopback                   | 2211 |
| show ngoam pathtrace                  | 2213 |
| show ngoam probe                      | 2217 |
| show ngoam traceroute statistics      | 2219 |
| show ngoam xconnect session           | 2221 |
| show npiv status                      | 2223 |
| show npv external-interface-usage     | 2224 |
| show npv flogi-table                  | 2225 |
| show npv status                       | 2226 |
| show npv traffic-map                  | 2228 |
| show ntp access-groups                | 2229 |
| show ntp authentication-keys          | 2230 |
| show ntp authentication-status        | 2231 |
| show ntp information                  | 2232 |
| show ntp logging-status               | 2233 |
| show ntp peer-status                  | 2234 |
| show ntp peers                        | 2235 |
| show ntp rts-update                   | 2236 |
| show ntp session status               | 2237 |
| show ntp source-interface             | 2238 |
| show ntp source                       | 2239 |

|                                       |      |
|---------------------------------------|------|
| show ntp statistics                   | 2240 |
| show ntp status                       | 2243 |
| show ntp trusted-keys                 | 2244 |
| show nve adjacency mpls               | 2245 |
| show nve bfd neighbors                | 2246 |
| show nve core-links                   | 2247 |
| show nve ethernet-segment             | 2248 |
| show nve evi                          | 2250 |
| show nve interface                    | 2251 |
| show nve mpls                         | 2253 |
| show nve multisite dc-links           | 2254 |
| show nve multisite fabric-links       | 2255 |
| show nve peers                        | 2256 |
| show nve peers interface counters     | 2258 |
| show nve peers mpls                   | 2259 |
| show nve peers vni interface counters | 2260 |
| show nve replication-servers          | 2261 |
| show nve vni                          | 2262 |
| show nve vni counters                 | 2264 |
| show nve vni ingress-replication      | 2265 |
| show nve vni peer-vtep                | 2266 |
| show nve vrf                          | 2267 |
| show nve vxlan-params                 | 2268 |
| show nxapi-server logs                | 2269 |
| show nxapi                            | 2270 |

---

**CHAPTER 15****O Show Commands 2271**

|                                     |      |
|-------------------------------------|------|
| show object-group                   | 2273 |
| show openflow hardware capabilities | 2274 |
| show openflow switch                | 2275 |
| show openflow switch flows          | 2276 |
| show ospfv3                         | 2277 |
| show ospfv3 border-routers          | 2282 |
| show ospfv3 database                | 2284 |



|                                       |      |
|---------------------------------------|------|
| show ospfv3 database database-summary | 2287 |
| show ospfv3 database detail           | 2289 |
| show ospfv3 interface                 | 2294 |
| show ospfv3 interface brief           | 2297 |
| show ospfv3 neighbors                 | 2299 |
| show ospfv3 neighbors detail          | 2301 |
| show ospfv3 neighbors summary         | 2304 |
| show ospfv3 request-list              | 2306 |
| show ospfv3 retransmission-list       | 2308 |
| show ospfv3 route                     | 2310 |
| show ospfv3 route summary             | 2312 |
| show ospfv3 statistics                | 2314 |
| show ospfv3 summary-address           | 2318 |
| show ospfv3 traffic                   | 2319 |
| show ospfv3 virtual-links             | 2323 |
| show ospfv3 virtual-links brief       | 2327 |
| show otv isis                         | 2328 |
| show otv isis active-source           | 2331 |
| show otv isis adjacency               | 2333 |
| show otv isis aed-svr-req local       | 2335 |
| show otv isis database                | 2337 |
| show otv isis ed-summary local        | 2342 |
| show otv isis ed-summary remote       | 2343 |
| show otv isis fast-flood              | 2345 |
| show otv isis hostname                | 2346 |
| show otv isis interface               | 2347 |
| show otv isis ip mroute               | 2352 |
| show otv isis ip redistribute mroute  | 2354 |
| show otv isis redistribute route      | 2356 |
| show otv isis route-map statistics    | 2357 |
| show otv isis route                   | 2358 |
| show otv isis rrm                     | 2361 |
| show otv isis site-index              | 2363 |
| show otv isis site                    | 2364 |

show otv isis spf-log 2367  
show otv isis srm 2369  
show otv isis ssn 2371  
show otv isis statistics 2373  
show otv isis track-adjacency-nexthop 2374  
show otv isis traffic 2375  
show otv isis vlan-status local 2377

---

**CHAPTER 16****P Show Commands 2379**

show param-list 2382  
show password secure-mode 2383  
show password strength-check 2384  
show pie broker 2385  
show pie envmon 2386  
show pie eventdb 2387  
show pie eventid 2388  
show pie interface 2389  
show platform vnic info 2390  
show platform vnic mapped 2391  
show pmap-int-br interface br 2392  
show pmap-int 2393  
show pnp lease 2394  
show pnp posix\_pi configs 2395  
show pnp posix\_pi tech-support 2396  
show pnp profiles 2397  
show pnp status 2398  
show pnp summary 2399  
show pnp version 2400  
show policy-map 2401  
show policy-map interface control-plane 2406  
show policy-map system 2409  
show policy-map type control-plane 2414  
show policy-map type network-qos 2417  
show port-channel capacity 2419

|  |      |
|--|------|
| show port-channel compatibility-parameters                               | 2420 |
| show port-channel database   | 2421 |
| show port-channel fast-convergence                                       | 2423 |
| show port-channel load-balance   | 2424 |
| show port-channel load-balance forwarding-path1 interface src-interface  | 2426 |
| show port-channel load-balance forwarding-path interface                 | 2428 |
| show port-channel load-balance hardware forwarding-path interface source | 2430 |
| show port-channel rbh-distribution                                       | 2432 |
| show port-channel scale-fanout   | 2433 |
| show port-channel summary  | 2434 |
| show port-channel traffic  | 2435 |
| show port-channel usage  | 2436 |
| show port-license  | 2437 |
| show port-profile  | 2438 |
| show port-profile brief  | 2440 |
| show port-profile expand-interface                                       | 2441 |
| show port-profile sync-status  | 2442 |
| show port-profile usage  | 2443 |
| show port-security   | 2444 |
| show port-security address   | 2445 |
| show port-security address interface                                     | 2446 |
| show port-security interface   | 2447 |
| show port-security state   | 2448 |
| show port led-status module  | 2449 |
| show port naming   | 2450 |
| show postcard-telemetry exporter   | 2451 |
| show postcard-telemetry flow-profile                                     | 2452 |
| show postcard-telemetry monitor  | 2453 |
| show postcard-telemetry queue-profile                                    | 2454 |
| show postcard-telemetry sessions   | 2455 |
| show postcard-telemetry watchlist  | 2456 |
| show power inline  | 2457 |
| show power inline  | 2458 |
| show power inline detail   | 2459 |

|                                       |      |
|---------------------------------------|------|
| show power inline police              | 2461 |
| show power inline priority            | 2462 |
| show processes                        | 2463 |
| show processes cpu                    | 2464 |
| show processes cpu history            | 2465 |
| show processes cpu history data       | 2466 |
| show processes cpu module             | 2467 |
| show processes log                    | 2468 |
| show processes log details            | 2469 |
| show processes log pid                | 2470 |
| show processes log vdc-all            | 2471 |
| show processes memory                 | 2472 |
| show processes memory physical        | 2473 |
| show processes memory shared          | 2474 |
| show processes vdc                    | 2477 |
| show processes vdc cpu                | 2478 |
| show processes vdc log                | 2479 |
| show processes vdc log details        | 2480 |
| show processes vdc log pid            | 2481 |
| show processes vdc memory             | 2482 |
| show pss debug                        | 2483 |
| show ptp brief                        | 2484 |
| show ptp clock                        | 2485 |
| show ptp clock foreign-masters record | 2487 |
| show ptp corrections                  | 2488 |
| show ptp cost                         | 2489 |
| show ptp counters interface           | 2490 |
| show ptp delay summary                | 2491 |
| show ptp domain data                  | 2492 |
| show ptp interface domain             | 2493 |
| show ptp packet-trace                 | 2494 |
| show ptp parent                       | 2495 |
| show ptp port interface               | 2496 |
| show ptp time-property                | 2498 |

show ptp unicast-negotiation 2499

---

**CHAPTER 17**

**Q Show Commands 2501**

show qos dcbxp incompatibility interface 2502

show qos dcbxp info 2504

show qos dcbxp interface 2505

show qos shared-policer 2507

show queuing 2509

show queuing burst-detect 2512

show queuing llfc-queue 2514

show queuing pfc-queue 2515

show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex 2517

show queuing pfc-queue snmp ifIndex 2519

show queuing tabular 2520

show queuing tah-pfc-queue 2522

---

**CHAPTER 18**

**R Show Commands 2523**

show radius-cfs 2528

show radius-server 2529

show radius-server 2531

show radius-server directed-request 2532

show radius-server groups 2533

show radius-server sorted 2534

show radius-server statistics 2535

show radius status 2537

show redundancy status 2538

show regexp 2540

show reload 2541

show resource 2542

show rmon 2543

show role 2545

show role feature-group 2547

show role feature 2548

show role status 2549

|   |      |
|---|------|
| show rollback log exec                        | 2550 |
| show rollback status                          | 2551 |
| show route-map                                | 2552 |
| show route-map dynamic                        | 2553 |
| show route-map pbr-statistics                 | 2554 |
| show router-guard                             | 2555 |
| show router-guard                             | 2556 |
| show routing-context                          | 2557 |
| show routing                                  | 2558 |
| show routing clients                          | 2562 |
| show routing hash                             | 2564 |
| show routing hidden-nh                        | 2567 |
| show routing ipv6                             | 2568 |
| show routing ipv6 clients                     | 2571 |
| show routing ipv6 hash                        | 2575 |
| show routing ipv6 hidden-nh                   | 2578 |
| show routing ipv6 memory estimate             | 2579 |
| show routing ipv6 memory statistics           | 2581 |
| show routing ipv6 multicast clients           | 2583 |
| show routing ipv6 multicast lisp encap        | 2587 |
| show routing ipv6 multicast mdt encapsulation | 2588 |
| show routing ipv6 multicast memory estimate   | 2589 |
| show routing ipv6 multicast sr                | 2591 |
| show routing ipv6 nhlfe                       | 2593 |
| show routing ipv6 recursive-next-hop          | 2595 |
| show routing memory estimate                  | 2596 |
| show routing memory statistics                | 2598 |
| show routing multicast clients                | 2600 |
| show routing multicast lisp encap             | 2604 |
| show routing multicast mdt encapsulation      | 2605 |
| show routing multicast memory estimate        | 2607 |
| show routing multicast sr                     | 2609 |
| show routing nhlfe                            | 2611 |
| show routing recursive-next-hop               | 2613 |

|                                    |      |
|------------------------------------|------|
| show routing vxlan-hash peer-ip    | 2615 |
| show routing vxlan-hash peer-ipv6  | 2616 |
| show rscn event-tov vsan           | 2617 |
| show rscn pending-diff vsan        | 2618 |
| show rscn pending vsan             | 2619 |
| show rscn scr-table                | 2620 |
| show rscn session status vsan      | 2621 |
| show rscn statistics               | 2622 |
| show running-config                | 2623 |
| show running-config aaa            | 2624 |
| show running-config acllog         | 2625 |
| show running-config aclmgr         | 2626 |
| show running-config adjmgr         | 2627 |
| show running-config all            | 2628 |
| show running-config arp            | 2629 |
| show running-config assoc          | 2630 |
| show running-config backup         | 2631 |
| show running-config bfd            | 2632 |
| show running-config bgp            | 2633 |
| show running-config bloggerd       | 2634 |
| show running-config callhome       | 2635 |
| show running-config cdp            | 2636 |
| show running-config cert-enroll    | 2637 |
| show running-config cfs            | 2638 |
| show running-config clock_manager  | 2639 |
| show running-config config-profile | 2640 |
| show running-config controller     | 2641 |
| show running-config copp           | 2642 |
| show running-config dhcp           | 2643 |
| show running-config diagnostic     | 2644 |
| show running-config diff           | 2645 |
| show running-config dot1x          | 2646 |
| show running-config ecp            | 2647 |
| show running-config eem            | 2648 |

|   |      |
|---|------|
| show running-config eigrp                     | 2649 |
| show running-config eltm                      | 2650 |
| show running-config epbr                      | 2651 |
| show running-config evb                       | 2652 |
| show running-config exclude                   | 2653 |
| show running-config expand-port-profile       | 2654 |
| show running-config fabric forwarding         | 2655 |
| show running-config fabric multicast          | 2656 |
| show running-config fabricpath                | 2657 |
| show running-config fabricpath domain default | 2658 |
| show running-config fabricpath switch-id      | 2659 |
| show running-config fabricpath topology       | 2660 |
| show running-config fcoe_mgr                  | 2661 |
| show running-config fsync_mgr                 | 2662 |
| show running-config hardware-telemetry        | 2663 |
| show running-config hsrp                      | 2664 |
| show running-config icam                      | 2665 |
| show running-config icmpv6                    | 2666 |
| show running-config igmp                      | 2667 |
| show running-config imp                       | 2668 |
| show running-config interface                 | 2669 |
| show running-config interface                 | 2670 |
| show running-config ip                        | 2671 |
| show running-config ipqos                     | 2672 |
| show running-config ipv6                      | 2673 |
| show running-config isis                      | 2674 |
| show running-config l3vm                      | 2675 |
| show running-config ldap                      | 2676 |
| show running-config license                   | 2677 |
| show running-config lisp                      | 2678 |
| show running-config lldp                      | 2679 |
| show running-config macsec                    | 2680 |
| show running-config mfwd                      | 2681 |
| show running-config mfwdv6                    | 2682 |



|  |      |
|--|------|
| show running-config mld                    | 2683 |
| show running-config mmode                  | 2684 |
| show running-config monitor                | 2685 |
| show running-config mpls static            | 2686 |
| show running-config mpls strip             | 2687 |
| show running-config msdp                   | 2688 |
| show running-config nat                    | 2689 |
| show running-config nbm                    | 2690 |
| show running-config ngoam                  | 2691 |
| show running-config ntp                    | 2692 |
| show running-config nv overlay             | 2693 |
| show running-config nxsdk                  | 2694 |
| show running-config ofm                    | 2695 |
| show running-config openflow               | 2696 |
| show running-config ospf                   | 2697 |
| show running-config ospfv3                 | 2698 |
| show running-config otv-isis               | 2699 |
| show running-config param-list             | 2700 |
| show running-config pim                    | 2701 |
| show running-config pim6                   | 2702 |
| show running-config poe                    | 2703 |
| show running-config port-profile           | 2704 |
| show running-config port-security          | 2705 |
| show running-config ptp                    | 2706 |
| show running-config radius                 | 2707 |
| show running-config rip                    | 2708 |
| show running-config routing ip multicast   | 2709 |
| show running-config routing ipv6 multicast | 2710 |
| show running-config rpm                    | 2711 |
| show running-config scheduler              | 2712 |
| show running-config section                | 2713 |
| show running-config security               | 2714 |
| show running-config segment-routing        | 2715 |
| show running-config service-reflect        | 2716 |

|                                       |      |
|---------------------------------------|------|
| show running-config services          | 2717 |
| show running-config services          | 2718 |
| show running-config sflow             | 2719 |
| show running-config sla responder     | 2720 |
| show running-config sla sender        | 2721 |
| show running-config sla twamp-server  | 2722 |
| show running-config snmp              | 2723 |
| show running-config spanning-tree     | 2724 |
| show running-config srte              | 2725 |
| show running-config switch            | 2726 |
| show running-config sync              | 2727 |
| show running-config tacacs            | 2728 |
| show running-config telemetry         | 2729 |
| show running-config track             | 2730 |
| show running-config tunnel-encryption | 2731 |
| show running-config udd               | 2732 |
| show running-config vdc-all           | 2733 |
| show running-config vdc               | 2734 |
| show running-config virtual-service   | 2735 |
| show running-config vlan              | 2736 |
| show running-config vlan              | 2737 |
| show running-config vlan              | 2738 |
| show running-config vmtracker         | 2739 |
| show running-config vpc               | 2740 |
| show running-config vrf               | 2741 |
| show running-config vrf default       | 2742 |
| show running-config vrrp              | 2743 |
| show running-config vrrpv3            | 2744 |
| show running-config vshd              | 2745 |
| show running-config vtp               | 2746 |
| show running-config wwnm              | 2747 |
| show running-config zone              | 2748 |
| show running-config zone vsan         | 2749 |

---

**CHAPTER 19****S Show Commands 2751**

- show san-port-channel compatibility-parameters 2757
- show san-port-channel consistency 2758
- show san-port-channel consistency detail 2759
- show san-port-channel database 2761
- show san-port-channel summary 2763
- show san-port-channel usage 2764
- show scheduler config 2765
- show scheduler job 2767
- show scheduler logfile 2768
- show scheduler schedule 2769
- show segment-routing 2770
- show segment-routing clients 2771
- show segment-routing ipv4 connected-prefix-sid-map 2772
- show segment-routing mpls 2773
- show segment-routing mpls clients 2774
- show segment-routing mpls ipv4 connected-prefix-sid-map 2775
- show sflow 2776
- show sflow statistics 2777
- show snapshots 2778
- show snapshots compare 2779
- show snapshots compare ipv4routes 2781
- show snapshots compare ipv6routes 2782
- show snapshots compare summary 2783
- show snapshots dump 2784
- show snapshots dump 2785
- show snapshots sections 2786
- show snmp 2787
- show snmp community 2790
- show snmp context 2791
- show snmp engineID 2792
- show snmp group 2793
- show snmp host 2794

|  |      |
|--|------|
| show snmp nms-statistics                     | 2795 |
| show snmp oid-statistics                     | 2796 |
| show snmp sessions                           | 2797 |
| show snmp source-interface                   | 2798 |
| show snmp trap                               | 2799 |
| show snmp user                               | 2800 |
| show sockets client                          | 2801 |
| show sockets connection                      | 2809 |
| show sockets local-port-range                | 2812 |
| show sockets ns-port-kiosk                   | 2813 |
| show sockets statistics                      | 2814 |
| show sockets tcp keychain binding            | 2824 |
| show software authenticity file              | 2825 |
| show software authenticity keys              | 2826 |
| show spanning-tree                           | 2827 |
| show spanning-tree blockedports              | 2831 |
| show spanning-tree bridge                    | 2832 |
| show spanning-tree inconsistentports         | 2834 |
| show spanning-tree interface                 | 2835 |
| show spanning-tree interface                 | 2838 |
| show spanning-tree issu-impact               | 2839 |
| show spanning-tree mst                       | 2840 |
| show spanning-tree mst configuration         | 2845 |
| show spanning-tree mst configuration digest  | 2846 |
| show spanning-tree mst interface             | 2847 |
| show spanning-tree pathcost method           | 2850 |
| show spanning-tree root                      | 2851 |
| show spanning-tree summary                   | 2853 |
| show spanning-tree summary totals            | 2856 |
| show sprom                                   | 2858 |
| show srte pce ipv4 peer                      | 2867 |
| show srte policy                             | 2868 |
| show srte policy fh                          | 2870 |
| show srte policy proactive-policy-monitoring | 2871 |

|                                    |      |
|------------------------------------|------|
| show srte policy summary           | 2872 |
| show srv6 clients                  | 2874 |
| show srv6 locator                  | 2876 |
| show srv6 manager                  | 2877 |
| show srv6 sid                      | 2879 |
| show srv6 sid counters             | 2880 |
| show ssh key                       | 2881 |
| show ssh server                    | 2882 |
| show ssx details                   | 2883 |
| show ssx exporter                  | 2884 |
| show ssx monitor                   | 2885 |
| show ssx record                    | 2886 |
| show startup-config                | 2887 |
| show startup-config aaa            | 2888 |
| show startup-config acllog         | 2889 |
| show startup-config aclmgr         | 2890 |
| show startup-config adjmgr         | 2891 |
| show startup-config arp            | 2892 |
| show startup-config assoc          | 2893 |
| show startup-config backup         | 2894 |
| show startup-config bfd            | 2895 |
| show startup-config bgp            | 2896 |
| show startup-config bloggerd       | 2897 |
| show startup-config callhome       | 2898 |
| show startup-config cdp            | 2899 |
| show startup-config cert-enroll    | 2900 |
| show startup-config cfs            | 2901 |
| show startup-config config-profile | 2902 |
| show startup-config copp           | 2903 |
| show startup-config dhcp           | 2904 |
| show startup-config diagnostic     | 2905 |
| show startup-config dot1x          | 2906 |
| show startup-config ecp            | 2907 |
| show startup-config eem            | 2908 |

|   |      |
|---|------|
| show startup-config eigrp                     | 2909 |
| show startup-config eltm                      | 2910 |
| show startup-config epbr                      | 2911 |
| show startup-config evb                       | 2912 |
| show startup-config exclude                   | 2913 |
| show startup-config expand-port-profile       | 2914 |
| show startup-config fabric forwarding         | 2915 |
| show startup-config fabric multicast          | 2916 |
| show startup-config fabricpath                | 2917 |
| show startup-config fabricpath domain default | 2918 |
| show startup-config fabricpath switch-id      | 2919 |
| show startup-config fabricpath topology       | 2920 |
| show startup-config fcoe_mgr                  | 2921 |
| show startup-config fsync_mgr                 | 2922 |
| show startup-config glbp                      | 2923 |
| show startup-config hardware-telemetry        | 2924 |
| show startup-config hsrp                      | 2925 |
| show startup-config icam                      | 2926 |
| show startup-config icmpv6                    | 2927 |
| show startup-config igmp                      | 2928 |
| show startup-config imp                       | 2929 |
| show startup-config interface                 | 2930 |
| show startup-config interface                 | 2931 |
| show startup-config ip                        | 2932 |
| show startup-config ipqos                     | 2933 |
| show startup-config ipv6                      | 2934 |
| show startup-config isis                      | 2935 |
| show startup-config l3vm                      | 2936 |
| show startup-config ldap                      | 2937 |
| show startup-config license                   | 2938 |
| show startup-config lisp                      | 2939 |
| show startup-config lldp                      | 2940 |
| show startup-config log                       | 2941 |
| show startup-config macsec                    | 2942 |

|  |      |
|--|------|
| show startup-config mfw                    | 2943 |
| show startup-config mfwv6                  | 2944 |
| show startup-config mld                    | 2945 |
| show startup-config mmode                  | 2946 |
| show startup-config monitor                | 2947 |
| show startup-config mpls static            | 2948 |
| show startup-config mpls strip             | 2949 |
| show startup-config msdp                   | 2950 |
| show startup-config nat                    | 2951 |
| show startup-config nbm                    | 2952 |
| show startup-config ngoam                  | 2953 |
| show startup-config ntp                    | 2954 |
| show startup-config nv overlay             | 2955 |
| show startup-config nxsdk                  | 2956 |
| show startup-config ofm                    | 2957 |
| show startup-config openflow               | 2958 |
| show startup-config ospf                   | 2959 |
| show startup-config ospfv3                 | 2960 |
| show startup-config otv-isis               | 2961 |
| show startup-config param-list             | 2962 |
| show startup-config pim                    | 2963 |
| show startup-config pim6                   | 2964 |
| show startup-config poe                    | 2965 |
| show startup-config port-profile           | 2966 |
| show startup-config port-security          | 2967 |
| show startup-config ptp                    | 2968 |
| show startup-config radius                 | 2969 |
| show startup-config rip                    | 2970 |
| show startup-config routing ip multicast   | 2971 |
| show startup-config routing ipv6 multicast | 2972 |
| show startup-config rpm                    | 2973 |
| show startup-config scheduler              | 2974 |
| show startup-config security               | 2975 |
| show startup-config segment-routing        | 2976 |

|                                       |      |
|---------------------------------------|------|
| show startup-config services          | 2977 |
| show startup-config sflow             | 2978 |
| show startup-config sla responder     | 2979 |
| show startup-config sla sender        | 2980 |
| show startup-config sla twamp-server  | 2981 |
| show startup-config snmp              | 2982 |
| show startup-config srte              | 2983 |
| show startup-config switch            | 2984 |
| show startup-config sync              | 2985 |
| show startup-config tacacs            | 2986 |
| show startup-config telemetry         | 2987 |
| show startup-config track             | 2988 |
| show startup-config tunnel-encryption | 2989 |
| show startup-config udd               | 2990 |
| show startup-config vdc-all           | 2991 |
| show startup-config vdc               | 2992 |
| show startup-config virtual-service   | 2993 |
| show startup-config vlan              | 2994 |
| show startup-config vlan              | 2995 |
| show startup-config vmtracker         | 2996 |
| show startup-config vpc               | 2997 |
| show startup-config vrf               | 2998 |
| show startup-config vrf default       | 2999 |
| show startup-config vrrpv3            | 3000 |
| show startup-config vshd              | 3001 |
| show startup-config vtp               | 3002 |
| show startup-config wwnm              | 3003 |
| show startup-config zone              | 3004 |
| show startup-config zone vsan         | 3005 |
| show summary                          | 3006 |
| show switch-profile                   | 3007 |
| show switch-profile                   | 3008 |
| show switch-profile buffer            | 3010 |
| show switch-profile peer              | 3011 |



|   |      |
|---|------|
| show switch-profile status                  | 3012 |
| show switching-mode                         | 3014 |
| show switching-mode fabric-speed            | 3015 |
| show system acl                             | 3016 |
| show system auto-collect tech-support       | 3017 |
| show system boottime                        | 3018 |
| show system config reload-pending           | 3019 |
| show system cores                           | 3020 |
| show system default switchport              | 3021 |
| show system default zone                    | 3022 |
| show system error-id                        | 3023 |
| show system exception-info                  | 3024 |
| show system fabric-mode                     | 3025 |
| show system fast-reload stabilization-timer | 3026 |
| show system image-verification              | 3027 |
| show system inband cpu-mac log threshold    | 3028 |
| show system inband queuing statistics       | 3029 |
| show system inband queuing status           | 3031 |
| show system login                           | 3032 |
| show system login failures                  | 3033 |
| show system memory-thresholds               | 3034 |
| show system mode                            | 3035 |
| show system nve infra-vlans                 | 3036 |
| show system poap                            | 3037 |
| show system pss shrink status               | 3038 |
| show system redundancy ha status            | 3039 |
| show system redundancy status               | 3040 |
| show system reset-reason                    | 3041 |
| show system reset-reason                    | 3042 |
| show system reset-reason module             | 3043 |
| show system resources                       | 3044 |
| show system resources all-modules           | 3046 |
| show system routing mode                    | 3048 |
| show system security                        | 3049 |

|                                   |      |
|-----------------------------------|------|
| show system simulate fan-presence | 3050 |
| show system standby manual-boot   | 3051 |
| show system switch-mode           | 3052 |
| show system uptime                | 3053 |
| show system verify bios flash     | 3054 |
| show system vlan reserved         | 3055 |

---

**CHAPTER 20**
**T Show Commands 3057**

|                                     |      |
|-------------------------------------|------|
| show table-map                      | 3064 |
| show tacacs-server                  | 3065 |
| show tacacs-server                  | 3066 |
| show tacacs-server directed-request | 3067 |
| show tacacs-server groups           | 3068 |
| show tacacs-server sorted           | 3069 |
| show tacacs-server statistics       | 3070 |
| show tech-support                   | 3072 |
| show tech-support aaa               | 3073 |
| show tech-support acl               | 3074 |
| show tech-support aclmgr            | 3075 |
| show tech-support aclmgr compressed | 3076 |
| show tech-support aclqos            | 3077 |
| show tech-support aclqos compressed | 3078 |
| show tech-support adjmgr            | 3079 |
| show tech-support all               | 3080 |
| show tech-support all binary        | 3081 |
| show tech-support analytics         | 3082 |
| show tech-support analytics         | 3083 |
| show tech-support arp               | 3084 |
| show tech-support ascii-cfg         | 3085 |
| show tech-support assoc_mgr         | 3086 |
| show tech-support backup            | 3087 |
| show tech-support bcm               | 3088 |
| show tech-support bfd               | 3089 |
| show tech-support bgp               | 3090 |

|                                     |      |
|-------------------------------------|------|
| show tech-support biosd             | 3091 |
| show tech-support bloggerd-all      | 3092 |
| show tech-support bloggerd          | 3093 |
| show tech-support bootvar           | 3094 |
| show tech-support brief             | 3095 |
| show tech-support callhome          | 3096 |
| show tech-support cdp               | 3097 |
| show tech-support cert-enroll       | 3098 |
| show tech-support cfs               | 3099 |
| show tech-support cli               | 3100 |
| show tech-support clis              | 3101 |
| show tech-support clock_manager     | 3102 |
| show tech-support commands          | 3103 |
| show tech-support controller        | 3104 |
| show tech-support copp              | 3105 |
| show tech-support cores             | 3106 |
| show tech-support dcbx              | 3107 |
| show tech-support details           | 3108 |
| show tech-support device-alias      | 3109 |
| show tech-support dhclient          | 3110 |
| show tech-support dhcp              | 3111 |
| show tech-support dme               | 3112 |
| show tech-support dot1x             | 3113 |
| show tech-support dpvm              | 3114 |
| show tech-support ecp               | 3115 |
| show tech-support eem               | 3116 |
| show tech-support eigrp             | 3117 |
| show tech-support eltm              | 3118 |
| show tech-support epbr              | 3119 |
| show tech-support epp               | 3120 |
| show tech-support ethpm             | 3121 |
| show tech-support ethport           | 3122 |
| show tech-support evb               | 3123 |
| show tech-support fabric forwarding | 3124 |

|  |      |
|--|------|
| show tech-support fabric multicast                       | 3125 |
| show tech-support fabricpath isis                        | 3126 |
| show tech-support fabricpath topology                    | 3127 |
| show tech-support fast-reload                            | 3128 |
| show tech-support fc2                                    | 3129 |
| show tech-support fcdomain                               | 3130 |
| show tech-support fcns                                   | 3131 |
| show tech-support fcoe                                   | 3132 |
| show tech-support fcs                                    | 3133 |
| show tech-support feature                                | 3134 |
| show tech-support fib-all                                | 3135 |
| show tech-support fib module                             | 3136 |
| show tech-support fips                                   | 3137 |
| show tech-support flogi                                  | 3138 |
| show tech-support forwarding l2 multicast                | 3139 |
| show tech-support forwarding l2 multicast vdc-all        | 3140 |
| show tech-support forwarding l2 unicast                  | 3141 |
| show tech-support forwarding l3 multicast                | 3142 |
| show tech-support forwarding l3 multicast detail vdc-all | 3143 |
| show tech-support forwarding l3 multicast detail         | 3144 |
| show tech-support forwarding l3 multicast vdc-all        | 3145 |
| show tech-support forwarding l3 unicast                  | 3146 |
| show tech-support forwarding l3 unicast detail           | 3147 |
| show tech-support forwarding l3 unicast detail vdc-all   | 3148 |
| show tech-support forwarding l3 unicast vdc-all          | 3149 |
| show tech-support forwarding mpls                        | 3150 |
| show tech-support forwarding multicast                   | 3151 |
| show tech-support forwarding multicast nat               | 3152 |
| show tech-support forwarding srv6                        | 3153 |
| show tech-support frequency synchronization              | 3154 |
| show tech-support fspf                                   | 3155 |
| show tech-support fsync_mgr                              | 3156 |
| show tech-support gold                                   | 3157 |
| show tech-support gpixm                                  | 3158 |

|                                      |      |
|--------------------------------------|------|
| show tech-support ha                 | 3159 |
| show tech-support ha module          | 3160 |
| show tech-support ha_short           | 3161 |
| show tech-support ha standby         | 3162 |
| show tech-support hardware-telemetry | 3163 |
| show tech-support hsrp               | 3164 |
| show tech-support hsrp brief         | 3165 |
| show tech-support icam               | 3166 |
| show tech-support icmpv6             | 3167 |
| show tech-support im                 | 3168 |
| show tech-support imp                | 3169 |
| show tech-support inband counters    | 3170 |
| show tech-support include-time       | 3171 |
| show tech-support install            | 3172 |
| show tech-support interface-vlan     | 3173 |
| show tech-support interfaces all     | 3174 |
| show tech-support ip                 | 3175 |
| show tech-support ip igmp            | 3176 |
| show tech-support ip igmp snooping   | 3177 |
| show tech-support ip msdp            | 3178 |
| show tech-support ip pim             | 3179 |
| show tech-support ipqos              | 3180 |
| show tech-support ipv6               | 3181 |
| show tech-support ipv6 mfw           | 3182 |
| show tech-support ipv6 mld           | 3183 |
| show tech-support ipv6 mld snooping  | 3184 |
| show tech-support ipv6 multicast     | 3185 |
| show tech-support ipv6 pim           | 3186 |
| show tech-support isis               | 3187 |
| show tech-support issu               | 3188 |
| show tech-support kstack             | 3189 |
| show tech-support l2                 | 3190 |
| show tech-support l2fm               | 3191 |
| show tech-support l2fm clients       | 3192 |

|  |      |
|--|------|
| show tech-support l2fm detail                  | 3193 |
| show tech-support l2fm l2dbg                   | 3194 |
| show tech-support l2fm l2dbg                   | 3195 |
| show tech-support l2rib                        | 3196 |
| show tech-support l3vm                         | 3197 |
| show tech-support l3vpn                        | 3198 |
| show tech-support lacp                         | 3199 |
| show tech-support ldap                         | 3200 |
| show tech-support license                      | 3201 |
| show tech-support lim                          | 3202 |
| show tech-support lisp                         | 3203 |
| show tech-support lldp                         | 3204 |
| show tech-support logging                      | 3205 |
| show tech-support m2rib                        | 3206 |
| show tech-support macsec                       | 3207 |
| show tech-support macsec detail                | 3208 |
| show tech-support mfw                          | 3209 |
| show tech-support mmode                        | 3210 |
| show tech-support module                       | 3211 |
| show tech-support module all                   | 3212 |
| show tech-support monitor                      | 3213 |
| show tech-support monitor erspan               | 3214 |
| show tech-support monitorc-all                 | 3215 |
| show tech-support mpls manager                 | 3216 |
| show tech-support mpls oam                     | 3217 |
| show tech-support mpls static                  | 3218 |
| show tech-support mpls strip                   | 3219 |
| show tech-support mpls switching               | 3220 |
| show tech-support mpls fwd                     | 3221 |
| show tech-support multicast-vxlan- <i>evpn</i> | 3222 |
| show tech-support multicast                    | 3223 |
| show tech-support mvpn                         | 3224 |
| show tech-support nat                          | 3225 |
| show tech-support nbm                          | 3226 |

|                                     |      |
|-------------------------------------|------|
| show tech-support nbm group         | 3227 |
| show tech-support netflow           | 3228 |
| show tech-support netstack          | 3229 |
| show tech-support netstack detail   | 3230 |
| show tech-support nexus9000v        | 3231 |
| show tech-support ngoam             | 3232 |
| show tech-support npacl             | 3233 |
| show tech-support npv               | 3234 |
| show tech-support ns                | 3235 |
| show tech-support ntp               | 3236 |
| show tech-support nve               | 3237 |
| show tech-support nxapi             | 3238 |
| show tech-support nxsdk             | 3239 |
| show tech-support object-store      | 3240 |
| show tech-support ofm               | 3241 |
| show tech-support openflow          | 3242 |
| show tech-support openflow platform | 3243 |
| show tech-support ospf              | 3244 |
| show tech-support ospfv3            | 3245 |
| show tech-support otv isis          | 3246 |
| show tech-support page              | 3247 |
| show tech-support patch             | 3248 |
| show tech-support pbr               | 3249 |
| show tech-support pfstat            | 3250 |
| show tech-support pixm-all          | 3251 |
| show tech-support pixm              | 3252 |
| show tech-support pixmc-all         | 3253 |
| show tech-support pktmgr            | 3254 |
| show tech-support platform-sdk      | 3255 |
| show tech-support platform          | 3256 |
| show tech-support plcmgr            | 3257 |
| show tech-support pltfm-config      | 3258 |
| show tech-support pnp               | 3259 |
| show tech-support poe               | 3260 |

|  |      |
|--|------|
| show tech-support port-channel           | 3261 |
| show tech-support port-client-all        | 3262 |
| show tech-support port-profile           | 3263 |
| show tech-support port-security          | 3264 |
| show tech-support port                   | 3265 |
| show tech-support private-vlan           | 3266 |
| show tech-support pss                    | 3267 |
| show tech-support ptp                    | 3268 |
| show tech-support radius                 | 3269 |
| show tech-support rib                    | 3270 |
| show tech-support rip                    | 3271 |
| show tech-support routing                | 3272 |
| show tech-support routing ipv6           | 3273 |
| show tech-support routing ipv6 multicast | 3274 |
| show tech-support routing multicast      | 3275 |
| show tech-support rpm                    | 3276 |
| show tech-support rscn                   | 3277 |
| show tech-support sal                    | 3278 |
| show tech-support san-port-channel       | 3279 |
| show tech-support san                    | 3280 |
| show tech-support satmgr                 | 3281 |
| show tech-support security               | 3282 |
| show tech-support segment-routing        | 3283 |
| show tech-support services               | 3284 |
| show tech-support session-mgr            | 3285 |
| show tech-support sflow                  | 3286 |
| show tech-support single-gericho         | 3287 |
| show tech-support sksd                   | 3288 |
| show tech-support sla responder          | 3289 |
| show tech-support sla sender             | 3290 |
| show tech-support sla twamp-server       | 3291 |
| show tech-support slowdrain              | 3292 |
| show tech-support smm                    | 3293 |
| show tech-support snmp                   | 3294 |



|                                     |      |
|-------------------------------------|------|
| show tech-support sockets           | 3295 |
| show tech-support spm               | 3296 |
| show tech-support srte              | 3297 |
| show tech-support statsclient       | 3298 |
| show tech-support stp               | 3299 |
| show tech-support sup-filesys       | 3300 |
| show tech-support super-bridging    | 3301 |
| show tech-support sysmgr            | 3302 |
| show tech-support tacacs            | 3303 |
| show tech-support telemetry         | 3304 |
| show tech-support track             | 3305 |
| show tech-support trm               | 3306 |
| show tech-support tunnel-encryption | 3307 |
| show tech-support tunnel            | 3308 |
| show tech-support u2rib             | 3309 |
| show tech-support udd               | 3310 |
| show tech-support usd-all           | 3311 |
| show tech-support vdc               | 3312 |
| show tech-support virtual-service   | 3313 |
| show tech-support vlan              | 3314 |
| show tech-support vmtracker         | 3315 |
| show tech-support vpc               | 3316 |
| show tech-support vrrp              | 3317 |
| show tech-support vrrp brief        | 3318 |
| show tech-support vrrpv3            | 3319 |
| show tech-support vsan              | 3320 |
| show tech-support vshd              | 3321 |
| show tech-support vtp               | 3322 |
| show tech-support vvlan             | 3323 |
| show tech-support vxlan-evpn        | 3324 |
| show tech-support vxlan             | 3325 |
| show tech-support vxlan platform    | 3326 |
| show tech-support xbar              | 3327 |
| show tech-support xml               | 3328 |

|   |      |
|---|------|
| show tech-support xos                             | 3329 |
| show tech-support zone                            | 3330 |
| show telemetry control database                   | 3331 |
| show telemetry data collector brief               | 3337 |
| show telemetry dynamic configuration              | 3338 |
| show telemetry event collector stats              | 3340 |
| show telemetry pipeline stats                     | 3342 |
| show telemetry port-counters                      | 3344 |
| show telemetry syslog-filter                      | 3346 |
| show telemetry transport                          | 3347 |
| show telemetry transport                          | 3350 |
| show telemetry usability                          | 3354 |
| show telemetry yang direct-path cisco-nxos-device | 3355 |
| show telnet server                                | 3356 |
| show terminal                                     | 3357 |
| show terminal lock                                | 3358 |
| show terminal output xml version                  | 3359 |
| show time-range                                   | 3360 |
| show time-stamp running-config last-changed       | 3362 |
| show topology                                     | 3363 |
| show topology isl                                 | 3364 |
| show topology isl                                 | 3365 |
| show topology isl                                 | 3366 |
| show trace callhome                               | 3367 |
| show track  | 3368 |
| show track brief                                  | 3370 |
| show troubleshoot l2 mac vlan                     | 3372 |
| show troubleshoot l2 port-channel                 | 3373 |
| show troubleshoot l3 vrf                          | 3374 |
| show trunk protocol                               | 3375 |
| show ttag brief                                   | 3376 |
| show ttag brief                                   | 3377 |
| show tunnel-encryption info global                | 3378 |
| show tunnel-encryption policy                     | 3379 |

show tunnel-encryption session 3380  
show tunnel-encryption statistics 3382  
show tunnel-profile 3384

---

**CHAPTER 21****U Show Commands 3385**

show uddl 3386  
show uddl global 3388  
show uddl neighbors 3389  
show upgrade history 3390  
show user-account 3391  
show username keypair 3392  
show username passphrase timevalues 3393  
show userpassphrase 3394  
show userpassphrase 3395  
show users 3396

---

**CHAPTER 22****V Show Commands 3397**

show vdc 3399  
show vdc current-vdc 3401  
show vdc fcoe-vlan-range 3402  
show vdc resource 3403  
show vdc resource 3404  
show vdc resource template 3405  
show version 3406  
show version epld 3408  
show version image 3409  
show version module 3410  
show version module epld 3411  
show virtual-service 3412  
show virtual-service storage pool list 3415  
show virtual-service tech-support 3416  
show virtual-service utilization name 3417  
show virtual-service version 3418  
show vlan 3419

|  |      |
|--|------|
| show vlan access-list                      | 3421 |
| show vlan access-map                       | 3425 |
| show vlan all-ports                        | 3426 |
| show vlan counters                         | 3427 |
| show vlan dot1Q tag native                 | 3428 |
| show vlan fcoe                             | 3429 |
| show vlan filter                           | 3430 |
| show vlan id                               | 3431 |
| show vlan id counters                      | 3433 |
| show vlan id vn-segment                    | 3435 |
| show vlan name                             | 3436 |
| show vlan private-vlan                     | 3438 |
| show vlan private-vlan type                | 3439 |
| show vlan xbrief                           | 3440 |
| show vlan xsummary                         | 3441 |
| show vmtracker                             | 3442 |
| show vmtracker certificate                 | 3444 |
| show vmtracker fabric auto-config          | 3445 |
| show vmtracker status                      | 3446 |
| show vpc                                   | 3447 |
| show vpc                                   | 3450 |
| show vpc consistency-parameters            | 3451 |
| show vpc consistency-parameters vlans      | 3452 |
| show vpc fabric-ports                      | 3453 |
| show vpc orphan-ports                      | 3454 |
| show vpc peer-keepalive                    | 3455 |
| show vpc role                              | 3456 |
| show vpc statistics peer-keepalive         | 3457 |
| show vpc statistics vpc                    | 3458 |
| show vpc virtual-peerlink dest reachable   | 3459 |
| show vpc virtual-peerlink vlan consistency | 3460 |
| show vrf                                   | 3461 |
| show vrf                                   | 3462 |
| show vrrp                                  | 3464 |

[show vrrp bfd-sessions](#) 3467  
[show vrrpv3](#) 3468  
[show vrrs client](#) 3472  
[show vrrs pathway](#) 3473  
[show vrrs server](#) 3474  
[show vrrs tag](#) 3475  
[show vsan](#) 3476  
[show vsan membership](#) 3477  
[show vsan membership interface](#) 3478  
[show vsan usage](#) 3479  
[show vtp counters](#) 3480  
[show vtp interface](#) 3481  
[show vtp password](#) 3482  
[show vtp status](#) 3483

---

**CHAPTER 23**
**W Show Commands** 3485

[show wred-queue qos-group-map](#) 3486  
[show wrt-queue qos-group-map](#) 3487  
[show wrt unicast-bandwidth](#) 3488  
[show wwn oui](#) 3489  
[show wwn status](#) 3490  
[show wwn switch](#) 3491  
[show wwn test](#) 3492  
[show wwn vsan-wwn](#) 3494

---

**CHAPTER 24**
**X Show Commands** 3495

[show xml server logging configuration](#) 3496  
[show xml server status](#) 3497

---

**CHAPTER 25**
**Z Show Commands** 3499

[show zone-attribute-group](#) 3500  
[show zone](#) 3501  
[show zone active](#) 3502  
[show zone analysis](#) 3503

show zone ess 3504

show zone member 3505

show zone name 3507

show zone name active 3508

show zone name pending 3509

show zone pending-diff 3510

show zone pending 3511

show zone policy 3512

show zone smart-zoning auto-conv log errors 3513

show zone smart-zoning auto-conv status vsan 3514

show zone statistics 3515

show zone statistics vsan 3516

show zone status 3517

show zone vsan 3518

show zone vsan 3519

show zoneset 3520

---

**PART II**

**XML Support 3521**

---

**CHAPTER 26**

**Commands with XML/JSON Support 3523**

XML Support for Show Commands 3524



## Notices

---

- [Notice, on page 2](#)

# Notice



---

**Warning**

This document should be used only as a glossary reference for possible commands. The listing of a command in this document does not guarantee that the command is available or supported for your platform or application.

The command information in this reference document is auto-generated from the NX-OS source code. While we attempt to manually remove unsupported, deprecated, or internal-use commands, such commands may occasionally appear in this document. Also, with the large variety of hardware platform combinations using NX-OS software, some listed commands may not be applicable or recommended for a specific platform. Platform-based dependency information is not provided in this command reference.

We strongly encourage you to refer to the configuration guides for appropriate commands to configure and operate a feature. Command limitations, restrictions, and recommendations are documented only in the configuration guides. When in doubt, please consult your Cisco representative.

---





## PART I

# All Show Commands

- [A Show Commands, on page 5](#)
- [B Show Commands, on page 49](#)
- [C Show Commands, on page 221](#)
- [D Show Commands, on page 399](#)
- [E Show Commands, on page 453](#)
- [F Show Commands, on page 485](#)
- [G Show Commands, on page 763](#)
- [H Show Commands, on page 767](#)
- [I Show Commands, on page 841](#)
- [K Show Commands, on page 1753](#)
- [L Show Commands, on page 1759](#)
- [M Show Commands, on page 2099](#)
- [N Show Commands, on page 2183](#)
- [O Show Commands, on page 2271](#)
- [P Show Commands, on page 2379](#)
- [Q Show Commands, on page 2501](#)
- [R Show Commands, on page 2523](#)
- [S Show Commands, on page 2751](#)
- [T Show Commands, on page 3057](#)
- [U Show Commands, on page 3385](#)
- [V Show Commands, on page 3397](#)
- [W Show Commands, on page 3485](#)
- [X Show Commands, on page 3495](#)
- [Z Show Commands, on page 3499](#)





## A Show Commands

---

- [show aaa accounting](#), on page 6
- [show aaa authentication](#), on page 7
- [show aaa authentication login](#), on page 8
- [show aaa authentication login ascii-authentication](#), on page 9
- [show aaa authentication login error-enable](#), on page 10
- [show aaa authentication login invalid-username-log](#), on page 11
- [show aaa authorization](#), on page 12
- [show aaa bypass-user](#), on page 13
- [show aaa client radius statistics](#), on page 14
- [show aaa groups](#), on page 15
- [show aaa local user blocked](#), on page 16
- [show aaa server radius statistics](#), on page 17
- [show aaa user blocked](#), on page 18
- [show aaa user default-role](#), on page 19
- [show access-list](#), on page 20
- [show access-list database](#), on page 24
- [show access-list resource](#), on page 25
- [show access-lists](#), on page 27
- [show access-lists](#), on page 32
- [show accounting log](#), on page 34
- [show accounting log all](#), on page 35
- [show accounting log last-index](#), on page 36
- [show accounting log nvram](#), on page 37
- [show accounting log nvram last-index](#), on page 38
- [show accounting log nvram start-seqnum](#), on page 39
- [show accounting log start-seqnum](#), on page 40
- [show acl status](#), on page 41
- [show amt process](#), on page 42
- [show amt vrf all](#), on page 44
- [show archive log config](#), on page 45
- [show arp access-lists](#), on page 46

# show aaa accounting

```
show aaa accounting [ __readonly__ [ TABLE_acctMethods <service> <methods> ] ]
```

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                              |
| aaa               | Show aaa information   |
| accounting        | Show accounting configuration                                |
| __readonly__      | (Optional)   |
| TABLE_acctMethods | (Optional)   |
| <i>service</i>    | (Optional) service type                                      |
| <i>methods</i>    | (Optional) Accounting methods configured for the application |

## Command Mode

- /exec

# show aaa authentication

show aaa authentication [ *\_\_readonly\_\_* [ *TABLE\_AuthenMethods* <service> <method> ] ]

## Syntax Description

|                            |   |
|----------------------------|---|
| <i>show</i>                | Show running system information                       |
| <i>aaa</i>                 | Show aaa information                                  |
| <i>authentication</i>      | Show authentication configuration                     |
| <i>__readonly__</i>        | (Optional)  |
| <i>TABLE_AuthenMethods</i> | (Optional)  |
| <i>service</i>             | (Optional) Service for which authentication is needed |
| <i>method</i>              | (Optional) Authentication method used for the service |

## Command Mode

- /exec

## show aaa authentication login

```
show aaa authentication login { mschap | mschapv2 | chap } [ __readonly__ [ <mschap_status> ] [
<mschapv2_status> ] [ <chap_status> ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                          |
| aaa                    | Show aaa information                                     |
| authentication         | Show authentication configuration                        |
| login                  | Show authentication login error message configuration    |
| mschap                 | Show authentication login MSCHAP enable configuration    |
| mschapv2               | Show authentication login MSCHAP V2 enable configuration |
| chap                   | Show authentication login CHAP enable configuration      |
| __readonly__           | (Optional)   |
| <i>mschap_status</i>   | (Optional) mschap enabled or disabled                    |
| <i>mschapv2_status</i> | (Optional) mschapv2 enabled or disabled                  |
| <i>chap_status</i>     | (Optional) chap enabled or disabled                      |

### Command Mode

- /exec

# show aaa authentication login ascii-authentication

```
show aaa authentication login ascii-authentication [ __readonly__ { <ascii_authen_status> } ]
```

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                 |
| aaa                        | Show aaa information                            |
| authentication             | Show authentication configuration               |
| login                      | Show authentication login message configuration |
| ascii-authentication       | Show ascii-authentication configuration         |
| <i>__readonly__</i>        | (Optional)                                      |
| <i>ascii_authen_status</i> | (Optional) ascii authentication status          |

## Command Mode

- /exec

## show aaa authentication login error-enable

show aaa authentication login error-enable [ \_\_readonly\_\_ [ <status> ] ]

### Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                              |
| aaa            | Show aaa information   |
| authentication | Show authentication configuration                            |
| login          | Show authentication login error message configuration        |
| error-enable   | Show authentication login error message enable configuration |
| __readonly__   | (Optional)   |
| <i>status</i>  | (Optional) login error-enable enabled or disabled            |

### Command Mode

- /exec



# show aaa authentication login invalid-username-log

```
show aaa authentication login invalid-username-log [ __readonly__ [ <status> ] ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                           |
| aaa                  | Show aaa information                                      |
| authentication       | Show authentication configuration                         |
| login                | Show authentication login message configuration           |
| invalid-username-log | Show invalid username log configuration                   |
| __readonly__         | (Optional)  |
| <i>status</i>        | (Optional) login invalid-username-log enabled or disabled |

## Command Mode

- /exec

# show aaa authorization

```
show aaa authorization [ all ] [ __readonly__ [ <pki_ssh_cert_author> <pki_ssh_pubkey_author> ] [
TABLE_cmd_methods <appl_subtype> <cmd_type> <methods> ] [ TABLE_app_methods <appl> <methods>
] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information   |
| aaa                          | Show aaa information  |
| authorization                | Show authorization configuration  |
| all                          | (Optional) Show all(include defaults configurations) authorization info |
| __readonly__                 | (Optional)  |
| <i>pki_ssh_cert_author</i>   | (Optional)  |
| <i>pki_ssh_pubkey_author</i> | (Optional)  |
| TABLE_cmd_methods            | (Optional) table containing command authorization methods               |
| <i>appl_subtype</i>          | (Optional)  |
| <i>cmd_type</i>              | (Optional)  |
| <i>methods</i>               | (Optional)  |
| TABLE_app_methods            | (Optional) table containing application authorization methods           |
| <i>appl</i>                  | (Optional)  |
| <i>methods</i>               | (Optional)  |

## Command Mode

- /exec

## show aaa bypass-user

```
show aaa bypass-user [ <s0> ] [ __readonly__ [ <num_bypass_users> ] [ TABLE_bypassUsers <username>
<account> <author> ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information              |
| aaa                     | Show aaa information                         |
| bypass-user             | Show bypass user information                 |
| <i>s0</i>               | (Optional) Enter the username                |
| <i>__readonly__</i>     | (Optional)                                   |
| <i>num_bypass_users</i> | (Optional) Number of bypass users configured |
| TABLE_bypassUsers       | (Optional)                                   |
| <i>username</i>         | (Optional) Username                          |
| <i>account</i>          | (Optional) Accounting Bypass                 |
| <i>author</i>           | (Optional) Authorization bypass              |

### Command Mode

- /exec

## show aaa client radius statistics

```
show aaa client radius statistics <host0> [ __readonly__ TABLE_allstat [ <auth_client> ] TABLE_allcoastat
[ <requests> ] [ <transactions> ] [ <retransmissions> ] [ <active_trans> ] [ <ack_responses> ] [ <nak_responses>
] [ <invalid_req> ] [ <errors> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                     |
| aaa                     | Show aaa information                                |
| client                  | Show AAA client info                                |
| radius                  | show radius dynamic authorization client info       |
| statistics              | show radius dynamic authorization client statistics |
| <i>host0</i>            | IPV4/IPV6 address or DNS name of RADIUS client      |
| <i>__readonly__</i>     | (Optional)  |
| <i>TABLE_allstat</i>    | (Optional)  |
| <i>TABLE_allcoastat</i> | (Optional)  |
| <i>auth_client</i>      | (Optional) Authentication Client Port details       |
| <i>requests</i>         | (Optional) COA Request Sent count                   |
| <i>transactions</i>     | (Optional) COA transactions count                   |
| <i>retransmissions</i>  | (Optional) COA retransmission count                 |
| <i>active_trans</i>     | (Optional) COA active transactions count            |
| <i>ack_responses</i>    | (Optional) COA acknowledgement responses count      |
| <i>nak_responses</i>    | (Optional) COA nak responses count                  |
| <i>invalid_req</i>      | (Optional) Invalid requests count                   |
| <i>errors</i>           | (Optional) COA Error count                          |

### Command Mode

- /exec

# show aaa groups

```
show aaa groups [ __readonly__ { TABLE_groups <group> } ]
```

## Syntax Description

|              |                                     |
|--------------|-------------------------------------|
| show         | Show running system information     |
| aaa          | Show aaa information                |
| groups       | Show configured groups              |
| __readonly__ | (Optional)                          |
| TABLE_groups | (Optional) Table showing aaa groups |
| <i>group</i> | (Optional) Name of the group        |

## Command Mode

- /exec

# show aaa local user blocked

show aaa local user blocked [ \_\_readonly\_\_ { TABLE\_sessions <u\_name> <u\_state> } ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information          |
| aaa            | Configure aaa functions                  |
| local          | Local username                           |
| user           | Local system user                        |
| blocked        | Display Blocked users                    |
| __readonly__   | (Optional)                               |
| TABLE_sessions | (Optional) aaa local users blocked table |
| <i>u_name</i>  | (Optional) Name of the user              |
| <i>u_state</i> | (Optional) State of the user             |

## Command Mode

- /exec

## show aaa server radius statistics

```
show aaa server radius statistics [ __readonly__ TABLE_allstat [ <auth_ser> ] [ <coa_sessions> ]
TABLE_alldot1xstat [ <request_sent> ] [ <resp_received> ] [ <resp_timeout> ] [ <errors> ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information               |
| aaa                       | Show aaa information                          |
| server                    | show Local AAA server info                    |
| radius                    | show local radius server info                 |
| statistics                | show local radius server statistics           |
| <i>__readonly__</i>       | (Optional)                                    |
| <i>TABLE_allstat</i>      | (Optional)                                    |
| <i>TABLE_alldot1xstat</i> | (Optional)                                    |
| <i>auth_ser</i>           | (Optional) Authentication Server Port details |
| <i>coa_sessions</i>       | (Optional) Active COA session numbers         |
| <i>request_sent</i>       | (Optional) DOT1X Request Sent Count           |
| <i>resp_received</i>      | (Optional) DOT1X Response received Count      |
| <i>resp_timeout</i>       | (Optional) DOT1X Response Timeout Value       |
| <i>errors</i>             | (Optional) DOT1X Error count                  |

### Command Mode

- /exec

# show aaa user blocked

show aaa user blocked [ *\_\_readonly\_\_* [ *<total\_users>* ] { *TABLE\_sessions* *<u\_name>* *<u\_state>* } ]

## Syntax Description

|                       |                                    |
|-----------------------|------------------------------------|
| show                  | Show running system information    |
| aaa                   | Configure aaa functions            |
| user                  | system user                        |
| blocked               | Display blocked users              |
| <i>__readonly__</i>   | (Optional)                         |
| <i>total_users</i>    | (Optional) Number of users in list |
| <i>TABLE_sessions</i> | (Optional) aaa blocked userstable  |
| <i>u_name</i>         | (Optional) Name of the user        |
| <i>u_state</i>        | (Optional) State of the user       |

## Command Mode

- /exec



# show aaa user default-role

```
show aaa user default-role [ __readonly__ { default_role_status <udr_status> } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                              |
| aaa                 | Show aaa information   |
| user                | Remotely authenticated user                                  |
| default-role        | Default role assigned by aaa-admin for remote authentication |
| __readonly__        | (Optional)   |
| default_role_status | (Optional) user default role status                          |
| <i>udr_status</i>   | (Optional) Status of user default role                       |

## Command Mode

- /exec

## show access-list

```
show { system internal | hardware } access-list { summary | [ vdc <vdc_id> ] } [ interface <if_name> | vlan
<vlan_id> | inband table <table> ] [ { input | output } { config | { { entries | merge } [ detail ] } | statistics |
l4ops | redirect | sampler } ] } [ module <module> ] [ __readonly__ [ <type> ] [ <feature> ] [ <ply_id> ] [
<src_ip> ] [ <src_mask> ] [ <dst_ip> ] [ <dst_mask> ] [ <proto> ] [ <l4ops> ] [ <action> ] [ <mac> ] [ <cos>
] [ <vlan> ] [ <l2_proto> ] [ <ethertype> ] [ TABLE_vdc <vdc-no> <vdc-type> <dir> <policy-type> <policy-id>
<policy-name> ] [ TABLE_instance <inst> [ TABLE_tcam_resource_usage <tcam-no> [ <lbl> ] [ <hw-lbl-id>
] [ <bank> ] [ TABLE_bank <bank-no> [ TABLE_class <class-type> [ TABLE_policies <policy> ] [
<netflow-profile> ] [ <netflow-deny-profile> ] [ <tcam-entries> ] [ TABLE_tcam_entry <tcam-index>
<tcam-rule> <tcam-stats> ] ] ] [ <l4-protocol-cam-entries> ] [ TABLE_l4_proto_cam_entries <l4-protocol>
<l4-encoding> <l4-index> <l4-ref-count> ] [ <mac-etype-PROTO-cam-entries> ] [
TABLE_mac_etypePROTO_cam_entries <mac-index> <mac-etype> <mac-PROTO> <mac-ref-count> ] [ <lous>
] [ <tcp-flags-table-entries> ] [ <adjacency-entries> ] ] ]
```

### Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                  |
| system         | System-related show commands                     |
| internal       | Commands for internal use                        |
| hardware       | Show hardware information                        |
| access-list    | Access Control List                              |
| summary        | summary  |
| vdc            | (Optional) vdc id                                |
| <i>vdc_id</i>  | (Optional) vdc_id                                |
| interface      | (Optional) interface name                        |
| <i>if_name</i> | (Optional) display access list for the interface |
| vlan           | (Optional) vlan_id                               |
| <i>vlan_id</i> | (Optional) vlan_id                               |
| inband         | (Optional) inband interface                      |
| table          | (Optional) vrf table number                      |
| <i>table</i>   | (Optional) vrf table number                      |
| input          | (Optional) input/ingress policies                |
| output         | (Optional) output/egress policies                |
| config         | (Optional) parsed policy software database       |
| entries        | (Optional) tcam entries                          |

|                    |   |
|--------------------|---|
| statistics         | (Optional) aggregate statistics           |
| l4ops              | (Optional) l4 operations information      |
| redirect           | (Optional) redirect resource information  |
| sampler            | (Optional) with sampler details           |
| merge              | (Optional) tcam entries merge information |
| detail             | (Optional) detailed information           |
| module             | (Optional) Slot/module                    |
| <i>module</i>      | (Optional) Slot/module number             |
| __readonly__       | (Optional)                                |
| <i>type</i>        | (Optional) policy type eg: ACL, QOS       |
| <i>feature</i>     | (Optional) feature type eg: RACL, VACL    |
| <i>policy_id</i>   | (Optional) policy id                      |
| <i>src_ip</i>      | (Optional) src ipv4 address               |
| <i>src_mask</i>    | (Optional) src mask                       |
| <i>dst_ip</i>      | (Optional) dst ipv4 address               |
| <i>dst_mask</i>    | (Optional) dst mask                       |
| <i>proto</i>       | (Optional) protocol eg: TCP, UDP ...      |
| <i>l4ops</i>       | (Optional) layer 4 operations             |
| <i>action</i>      | (Optional) action                         |
| <i>mac</i>         | (Optional) mac address                    |
| <i>cos</i>         | (Optional) acos value                     |
| <i>vlan</i>        | (Optional) vlan id                        |
| <i>l2_proto</i>    | (Optional) L2 protocol                    |
| <i>ethertype</i>   | (Optional) ethertype                      |
| TABLE_vdc          | (Optional) show for vdc                   |
| <i>vdc-no</i>      | (Optional) vdc number                     |
| <i>vdc-type</i>    | (Optional) VDC type-COPP etc              |
| <i>dir</i>         | (Optional) Policy Direction               |
| <i>policy-type</i> | (Optional) Policy type                    |

|                                    |   |
|------------------------------------|---|
| <i>policy-id</i>                   | (Optional) Policy id                          |
| <i>policy-name</i>                 | (Optional) Policy name                        |
| TABLE_instance                     | (Optional) show for an instance               |
| <i>inst</i>                        | (Optional) instance number                    |
| TABLE_tcaml_resource_usage         | (Optional) TCAM resource usage                |
| <i>tcam-no</i>                     | (Optional) tcam number                        |
| TABLE_bank                         | (Optional) table bank                         |
| <i>bank-no</i>                     | (Optional) bank number                        |
| <i>lbl</i>                         | (Optional) lbl name                           |
| <i>hw-lbl-id</i>                   | (Optional) hw lbl id                          |
| <i>bank</i>                        | (Optional) bank number                        |
| TABLE_class                        | (Optional) table class                        |
| <i>class-type</i>                  | (Optional) Class type                         |
| TABLE_policies                     | (Optional) policy table                       |
| <i>policy</i>                      | (Optional) Policy name                        |
| <i>netflow-profile</i>             | (Optional) Netflow Profile                    |
| <i>netflow-deny-profile</i>        | (Optional) Netflow Deny Profile               |
| TABLE_tcaml_entry                  | (Optional) table tcam entries                 |
| <i>tcam-index</i>                  | (Optional) Index of tcam entry                |
| <i>tcam-rule</i>                   | (Optional) tcam rule                          |
| <i>tcam-stats</i>                  | (Optional) stats of tcam rule                 |
| <i>tcam-entries</i>                | (Optional) No. of TCAM entries                |
| <i>l4-protocol-cam-entries</i>     | (Optional) L4 protocol cam entries            |
| TABLE_l4_proto_cam_entries         | (Optional) L4 protocol cam entry table        |
| <i>l4-protocol</i>                 | (Optional) Protocol                           |
| <i>l4-encoding</i>                 | (Optional) Encoding                           |
| <i>l4-index</i>                    | (Optional) Index                              |
| <i>l4-ref-count</i>                | (Optional) Ref-count                          |
| <i>mac-etype-proto-cam-entries</i> | (Optional) No. of mac etype/proto cam entries |

|  |   |
|--|---|
| <i>TABLE_mac_etype_proto_cam_entries</i> | (Optional) MAC etype protocol cam entry table |
| <i>mac-index</i>                         | (Optional) Index                              |
| <i>mac-etype</i>                         | (Optional) Etype                              |
| <i>mac-proto</i>                         | (Optional) Protocol                           |
| <i>mac-ref-count</i>                     | (Optional) Reg-count                          |
| <i>lous</i>                              | (Optional) No. of LOU's                       |
| <i>tcp-flags-table-entries</i>           | (Optional) No. of CP flags table entries      |
| <i>adjacency-entries</i>                 | (Optional) No. of adjacency entries           |

**Command Mode**

- /exec

## show access-list database

```
show { system internal | hardware } access-list [ vdc <vdc_id> ] database { interface | vlan | policy | process
} [ module <module> ] [ __readonly__ <if_idx> <vlan> <plcy_id> <process_info> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| system              | System-related show commands                    |
| internal            | Commands for internal use                       |
| hardware            | Show hardware information                       |
| access-list         | Access Control List                             |
| vdc                 | (Optional) vdc id                               |
| <i>vdc_id</i>       | (Optional) vdc_id                               |
| database            | Show memory database                            |
| interface           | display interfaces/vlans in a vdc with policies |
| policy              | display policies in a vdc                       |
| vlan                | display vlans in a vdc                          |
| process             | display process database in a vdc               |
| module              | (Optional) Slot/module                          |
| <i>module</i>       | (Optional) Slot/module number                   |
| <i>__readonly__</i> | (Optional)                                      |
| <i>if_idx</i>       | (Optional) interface                            |
| <i>vlan</i>         | (Optional) vlan                                 |
| <i>plcy_id</i>      | (Optional) policy id                            |
| <i>process_info</i> | (Optional) process information                  |

### Command Mode

- /exec

## show access-list resource

```
show { system internal | hardware } access-list resource { { { entries | l4ops | redirect | ipv6-compression |
mac-compression | aqm-d | aqm-q | oq | opool | prm | hardware-telemetry } [ detail ] } | utilization [ per-feature
] | { entry tcam <tcam_id> bank <bank_id> index <index> } | { default-tcam-allocation } } [ no-header ] [
module <module> ] [ __readonly__ [ TABLE_instance <inst> [ TABLE_resource_util_info <resource_hdr>
<ents_use> [ <ents_free> ] [ <ents_pctage> ] ] ] ] ] ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information              |
| system                  | System-related show commands                 |
| internal                | Commands for internal use                    |
| hardware                | Show hardware information                    |
| access-list             | Access Control List                          |
| resource                | hardware resource                            |
| entries                 | tcam entries                                 |
| l4ops                   | l4 operations information                    |
| redirect                | redirect resource information                |
| entry                   | display hardware information of a tcam entry |
| tcam                    | tcam id                                      |
| <i>tcam_id</i>          | tcam_id                                      |
| bank                    | bank id                                      |
| <i>bank_id</i>          | bank_id                                      |
| index                   | index within bank                            |
| <i>index</i>            | index withing bank                           |
| default-tcam-allocation | default team allocation                      |
| utilization             | utilization matrix                           |
| per-feature             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED    |
| ipv6-compression        | ipv6 compression                             |
| mac-compression         | mac compression table info                   |
| aqm-d                   | aqm d params                                 |
| aqm-q                   | aqm q params                                 |

|                          |   |
|--------------------------|---|
| oq                       | oq profiles                                 |
| opool                    | opool profiles                              |
| prm                      | prm profiles                                |
| hardware-telemetry       | hardware-telemetry resources                |
| detail                   | (Optional) detailed information             |
| no-header                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| module                   | (Optional) Slot/module                      |
| <i>module</i>            | (Optional) Slot/module number               |
| <i>__readonly__</i>      | (Optional)                                  |
| TABLE_instance           | (Optional) show for an instance             |
| <i>inst</i>              | (Optional) instance number                  |
| TABLE_resource_util_info | (Optional) resource utilization information |
| <i>resource_hdr</i>      | (Optional) resource header                  |
| <i>ents_use</i>          | (Optional) entries in use                   |
| <i>ents_free</i>         | (Optional) free tcam entries                |
| <i>ents_pctage</i>       | (Optional) tcam entries usage percentage    |

**Command Mode**

- /exec



## show access-lists

```
show [ <ip_ipv6_mac> ] access-lists [ <name> ] [ capture session <capture_session> ] [ <expanded> |
<summary> | <private> | <brief> | <stats-detail> ] [ __readonly__ TABLE_ip_ipv6_mac <op_ip_ipv6_mac>
<show_summary> <acl_name> [ <statistics> ] [ <frag_opt_permit_deny> ] [ <global_capture_session> ] [
<ipv6_extn_hdr> ] [ <ignore_routable> ] [ TABLE_seqno <seqno> { <permitdeny> [ <proto_str> | <proto>
| <ip> | <ipv6> ] } { <src_any> | <src_ip_prefix> | <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> |
<src_ipv6_addr> <src_ipv6_mask> | <mac_src> <mac_src_wild> | <src_addrgrp> } [ <src_port_op> [
<src_port1_str> ] { <src_port1_num> } [ <src_port2_str> | <src_port2_num> ] | <src_portgrp> ] { <dest_any>
| <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> | <dest_ipv6_prefix> | <dest_ipv6_addr>
<dest_ipv6_mask> | <mac_dest> <mac_dest_wild> | <dest_addrgrp> } [ <dest_port_op> [ <dest_port1_str>
] { <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] | <dest_portgrp> ] [ { <icmp_type> [
<icmp_code> ] | <icmp_str> } | { <icmpv6_type> [ <icmpv6_code> ] | <icmpv6_str> } ] [ <igmp_type> |
<igmp_type_str> ] [ [ <precedence> | <precedence_str> ] [ <tos> | <tos_str> ] | [ <dscp> [ <dscp_mask> ] |
<dscp_str> ] ] [ <ttl> ] ] [ <log> ] [ <telemetry_queue> ] [ <telemetry_path> ] [ <udfs> ] [ <capture_session>
] [ <fragments> ] [ <plen_op> <plen1> [ <plen2> ] ] [ <urg> ] [ <ack> ] [ <psh> ] [ <rst> ] [ <syn> ] [ <fin>
] [ <established> ] [ <http-method> | <http_opt_str> ] [ <tcp-option-length> ] [ <tcp-flags-mask> ] [
<flow_label> ] [ <timerange> ] [ <eth_proto> | <eth_proto_str> ] [ <vlan> ] [ <cos> ] [ <match_count> ] [ [
TABLE_match <module> <module_match_count> ] | [ <nve_vni> ] | <remark> [ <action> <actionid> ] ] ]
[ ethertype <ethertypeid> | vlan <vlanid> | ingress_intf { <intfid> | <intfname> } | vlan_priority <vlanpriorityid>
] + [ [ <stats_enabled> ] [ <frag_option> ] [ <ign_rtable> ] { <num_ace> } { <conf_if_header> } [ <conf_if>
] ] { <active_if_header> } [ <active_if> ] ] ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information               |
| <i>name</i>                 | (Optional) List name                          |
| <i>ip_ipv6_mac</i>          | (Optional) IP/IPv6/MAC                        |
| capture                     | (Optional) capture                            |
| session                     | (Optional) session                            |
| <i>capture_session</i>      | (Optional) session id                         |
| <i>op_ip_ipv6_mac</i>       | (Optional) IP/IPv6/MAC                        |
| access-lists                | List access lists                             |
| <i>show_summary</i>         | (Optional)                                    |
| <i>acl_name</i>             | (Optional) List name                          |
| <i>__readonly__</i>         | (Optional)                                    |
| TABLE_ip_ipv6_mac           | (Optional)                                    |
| <i>frag_opt_permit_deny</i> | (Optional) frag_op_type                       |
| ethertype                   | (Optional) Configure match based on ethertype |

|                       |   |
|-----------------------|---|
| <i>vlan</i>           | (Optional) Configure match based on vlan              |
| <i>ingress_intf</i>   | (Optional) Configure match based on ingress interface |
| <i>vlan_priority</i>  | (Optional) Configure match based on priority          |
| <i>ethertypeid</i>    | (Optional) Configure the ethertype value              |
| <i>vlanid</i>         | (Optional) VLAN number                                |
| <i>intfid</i>         | (Optional) Interface index                            |
| <i>intfname</i>       | (Optional) Interface name                             |
| <i>vlanpriorityid</i> | (Optional) Vlan Priority                              |
| <i>seqno</i>          | (Optional) Sequence number                            |
| <i>permitdeny</i>     | (Optional) Permit/deny                                |
| <i>proto</i>          | (Optional) A protocol number                          |
| TABLE_seqno           | (Optional)  |
| <i>proto_str</i>      | (Optional) Protocol name                              |
| <i>ip</i>             | (Optional) IP   |
| <i>ipv6</i>           | (Optional) IPV6                                       |
| <i>src_any</i>        | (Optional) SRCAny                                     |
| <i>dest_any</i>       | (Optional) DESTAny                                    |
| <i>src_ip_prefix</i>  | (Optional) Source IP prefix                           |
| <i>src_ip_addr</i>    | (Optional) Source IP address                          |
| <i>src_ip_mask</i>    | (Optional) Source IP mask                             |
| <i>mac_src</i>        | (Optional) Source MAC address                         |
| <i>mac_src_wild</i>   | (Optional) Source MAC mask                            |
| <i>dest_ip_prefix</i> | (Optional) Destination IP prefix                      |
| <i>dest_ip_addr</i>   | (Optional) Destination IP address                     |
| <i>dest_ip_mask</i>   | (Optional) Destination IP mask                        |
| <i>mac_dest</i>       | (Optional) Destination MAC address                    |
| <i>mac_dest_wild</i>  | (Optional) Destination MAC mask                       |
| <i>src_port_op</i>    | (Optional) Source Port operator                       |
| <i>dest_port_op</i>   | (Optional) Destination Port operator                  |

|                               |                                    |
|-------------------------------|------------------------------------|
| <i>src_port1_str</i>          | (Optional) Source port name        |
| <i>src_port1_num</i>          | (Optional) Source port number      |
| <i>src_port2_str</i>          | (Optional) Source port name        |
| <i>src_port2_num</i>          | (Optional) Source port number      |
| <i>dest_port1_str</i>         | (Optional) Destination port name   |
| <i>dest_port1_num</i>         | (Optional) Destination port number |
| <i>dest_port2_str</i>         | (Optional) Destination port name   |
| <i>dest_port2_num</i>         | (Optional) Destination port number |
| <i>icmp_type</i>              | (Optional) ICMP type               |
| <i>icmp_code</i>              | (Optional) ICMP code               |
| <i>icmp_str</i>               | (Optional) ICMP message            |
| <i>icmpv6_type</i>            | (Optional) ICMP type               |
| <i>icmpv6_code</i>            | (Optional) ICMP code               |
| <i>icmpv6_str</i>             | (Optional) ICMP message            |
| <i>igmp_type</i>              | (Optional) IGMP type               |
| <i>igmp_type_str</i>          | (Optional) IGMP type String        |
| <i>precedence</i>             | (Optional) precedence              |
| <i>precedence_str</i>         | (Optional) precedence string       |
| <i>tos</i>                    | (Optional) tos                     |
| <i>tos_str</i>                | (Optional) tos string              |
| <i>dscp</i>                   | (Optional) dscp                    |
| <i>dscp_mask</i>              | (Optional) dscp mask               |
| <i>dscp_str</i>               | (Optional) dscp string             |
| <i>udfs</i>                   | (Optional) udfs string             |
| <i>ttl</i>                    | (Optional) ttl                     |
| <i>capture_session</i>        | (Optional) capture session         |
| <i>global_capture_session</i> | (Optional) capture session         |
| <i>log</i>                    | (Optional) Log                     |
| <i>telemetry_queue</i>        | (Optional) telemetry_queue         |

|                           |  |
|---------------------------|--|
| <i>telemetry_path</i>     | (Optional) telemetry_path                                |
| <i>fragments</i>          | (Optional) Fragments                                     |
| <i>urg</i>                | (Optional) URG   |
| <i>ack</i>                | (Optional) ACK   |
| <i>psh</i>                | (Optional) PSH   |
| <i>rst</i>                | (Optional) RST   |
| <i>syn</i>                | (Optional) SYN   |
| <i>fin</i>                | (Optional) FIN   |
| <i>established</i>        | (Optional) ESTABLISHED                                   |
| <i>http-method</i>        | (Optional) http-method                                   |
| <i>http_opt_str</i>       | (Optional) http_option string                            |
| <i>tcp-option-length</i>  | (Optional) TCP Option size                               |
| <i>tcp-flags-mask</i>     | (Optional) TCP Flags mask                                |
| <i>flow_label</i>         | (Optional) IPv6 flow label                               |
| <i>timerange</i>          | (Optional) Time-range                                    |
| <i>eth_proto</i>          | (Optional) MAC protocol number                           |
| <i>eth_proto_str</i>      | (Optional) MAC protocol name                             |
| <i>vlan</i>               | (Optional) VLAN number                                   |
| <i>cos</i>                | (Optional) CoS value                                     |
| <i>match_count</i>        | (Optional) Number of packets matching the ACL            |
| TABLE_match               | (Optional)   |
| <i>module</i>             | (Optional) Module name                                   |
| <i>module_match_count</i> | (Optional) Number of packets matching the ACL per module |
| <i>nve_vni</i>            | (Optional) nve vni                                       |
| <i>remark</i>             | (Optional) Remark String                                 |
| <i>statistics</i>         | (Optional) STATISTICS                                    |
| <i>src_addrgrp</i>        | (Optional) Source address group                          |
| <i>dest_addrgrp</i>       | (Optional) Destination address group                     |
| <i>src_portgrp</i>        | (Optional) Source port group                             |

|                         |   |
|-------------------------|---|
| <i>dest_portgrp</i>     | (Optional) Destination port group   |
| <i>plen_op</i>          | (Optional) Source Port operator   |
| <i>plen1</i>            | (Optional) Packet length minimum  |
| <i>plen2</i>            | (Optional) packet length maximum  |
| <i>action</i>           | (Optional) Action   |
| <i>actionid</i>         | (Optional) redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63><br>set-erspan-gre-proto: <1-65535> |
| <i>ipv6_extn_hdr</i>    | (Optional) extn_hdr_op_type   |
| <i>ignore_routable</i>  | (Optional) ignore_routable_type   |
| <i>stats_enabled</i>    | (Optional)  |
| <i>frag_option</i>      | (Optional)  |
| <i>ign_rtable</i>       | (Optional)  |
| <i>num_ace</i>          | (Optional) Total number of ACEs   |
| <i>conf_if_header</i>   | (Optional)  |
| <i>conf_if</i>          | (Optional) Configured Interfaces  |
| <i>active_if_header</i> | (Optional)  |
| <i>active_if</i>        | (Optional) Active interfaces  |
| <i>expanded</i>         | (Optional) EXPANDED   |
| <i>summary</i>          | (Optional) SUMMARY  |
| <i>private</i>          | (Optional) PRIVATE  |
| <i>brief</i>            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>stats-detail</i>     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |

**Command Mode**

- /exec

## show access-lists

```
show <mpls_acl> access-lists [ <mpls_name> ] [ __readonly__ TABLE_mpls <mpls_name> [ <statistics> ]
[ TABLE_seqno <seqno> { <permitdeny> <mpls> [ <mpls_option> ] { <label1_any> | { <label1> [ mask
<label1_mask> ] } } [ <label2_any> | { <label2> [ mask <label2_mask> ] } } ] [ <label3_any> | { <label3> [
mask <label3_mask> ] } } ] [ <label4_any> | { <label4> [ mask <label4_mask> ] } } ] <mplsaction> <mplsactionid>
} | <remark> ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information   |
| <i>mpls_acl</i>     | mpls acl value  |
| access-lists        | List access lists   |
| <i>mpls_name</i>    | (Optional) List name  |
| <i>__readonly__</i> | (Optional)  |
| <i>mpls_name</i>    | (Optional) Name of the MPLS ACL   |
| <i>seqno</i>        | (Optional) Sequence number  |
| <i>permitdeny</i>   | (Optional) Permit/deny  |
| <i>mplsaction</i>   | (Optional) mpls ACL Action  |
| <i>mplsactionid</i> | (Optional) redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63><br>set-erspan-gre-proto: <1-65535> |
| <i>statistics</i>   | (Optional) STATISTICS   |
| mask                | (Optional) mask   |
| <i>label1</i>       | (Optional) mpls label one   |
| <i>label2</i>       | (Optional) mpls label two   |
| <i>label3</i>       | (Optional) mpls label three   |
| <i>label4</i>       | (Optional) mpls label three   |
| <i>label1_mask</i>  | (Optional) mpls label one mask  |
| <i>label2_mask</i>  | (Optional) mpls label two mask  |
| <i>label3_mask</i>  | (Optional) mpls label three mask  |
| <i>label4_mask</i>  | (Optional) mpls label four mask   |
| <i>label1_any</i>   | (Optional) label one Any  |
| <i>label2_any</i>   | (Optional) label two Any  |

|                    |                            |
|--------------------|----------------------------|
| <i>label3_any</i>  | (Optional) label three Any |
| <i>label4_any</i>  | (Optional) label four Any  |
| <i>mpls</i>        | (Optional) mpls keyword    |
| <i>mpls_option</i> | (Optional) mpls option     |
| TABLE_mpls         | (Optional)                 |
| TABLE_seqno        | (Optional)                 |
| <i>remark</i>      | (Optional) Remark String   |

**Command Mode**

- /exec

# show accounting log

```
show accounting log [ { <i0> | start-time <SYYYY> <SMonth> <SDate> <STime> [ end-time <EYYYY>
<EMonth> <EDate> <ETime> ] } ] [ __readonly__ [ TABLE_acctlog_time <accountlog_starttime> ] ]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                                |
| accounting                  | Show Accounting Information                                    |
| log                         | Show Accounting Log  |
| <i>i0</i>                   | (Optional) Log Size(in bytes)                                  |
| start-time                  | (Optional) Show messages from a given start-time               |
| <i>SYYYY</i>                | (Optional) Enter year in YYYY format                           |
| <i>SMonth</i>               | (Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>SDate</i>                | (Optional) Enter day of month in dd format                     |
| <i>STime</i>                | (Optional) Enter hour, minutes, seconds as HH:MM:SS            |
| end-time                    | (Optional) Show messages from a given end-time                 |
| <i>EYYYY</i>                | (Optional) Enter year in YYYY format                           |
| <i>EMonth</i>               | (Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>EDate</i>                | (Optional) Enter day of month in dd format                     |
| <i>ETime</i>                | (Optional) Enter hour, minutes, seconds as HH:MM:SS            |
| __readonly__                | (Optional)   |
| TABLE_acctlog_time          | (Optional)   |
| <i>accountlog_starttime</i> | (Optional) accounting log starttime                            |

## Command Mode

- /exec



# show accounting log all

```
show accounting log all [ __readonly__ [ TABLE_acctlog <accountlog_all> ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information   |
| accounting            | Show accounting configuration   |
| log                   | Show Accounting Log   |
| all                   | Display accounting log including show commands (Use <terminal log-all> to enable show command accounting) |
| __readonly__          | (Optional)  |
| TABLE_acctlog         | (Optional)  |
| <i>accountlog_all</i> | (Optional) accounting log all   |

## Command Mode

- /exec

# show accounting log last-index

show accounting log last-index [ \_\_readonly\_\_ { <last\_index> } ]

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information            |
| accounting        | Show accounting configuration              |
| log               | Show Accounting Log                        |
| last-index        | Show accounting log last index information |
| __readonly__      | (Optional)                                 |
| <i>last_index</i> | (Optional) accounting log last index       |

## Command Mode

- /exec

## show accounting log nvram

```
show accounting log nvram [ { <i0> | start-time <SYYYY> <SMonth> <SDate> <STime> [ end-time
<EYYYY> <EMonth> <EDate> <ETime> ] } ] [ __readonly__ [ TABLE_acctnvramlog_time
<accountnvramlog_starttime> ] ]
```

### Syntax Description

|                                  |  |
|----------------------------------|--|
| show                             | Show running system information                                |
| accounting                       | Show Accounting Information                                    |
| log                              | Show Accounting Log  |
| nvram                            | present in nvram   |
| <i>i0</i>                        | (Optional) Log Size(in bytes)                                  |
| start-time                       | (Optional) Show messages from a given start-time               |
| <i>SYYYY</i>                     | (Optional) Enter year in YYYY format                           |
| <i>SMonth</i>                    | (Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>SDate</i>                     | (Optional) Enter day of month in dd format                     |
| <i>STime</i>                     | (Optional) Enter hour, minutes, seconds as HH:MM:SS            |
| end-time                         | (Optional) Show messages from a given end-time                 |
| <i>EYYYY</i>                     | (Optional) Enter year in YYYY format                           |
| <i>EMonth</i>                    | (Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>EDate</i>                     | (Optional) Enter day of month in dd format                     |
| <i>ETime</i>                     | (Optional) Enter hour, minutes, seconds as HH:MM:SS            |
| __readonly__                     | (Optional)   |
| TABLE_acctnvramlog_time          | (Optional)   |
| <i>accountnvramlog_starttime</i> | (Optional) accounting log nvram starttime                      |

### Command Mode

- /exec

## show accounting log nvram last-index

show accounting log nvram last-index [ *\_\_readonly\_\_* { <last\_index> } ]

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| accounting          | Show accounting configuration              |
| log                 | Show Accounting Log                        |
| nvram               | present in nvram                           |
| last-index          | Show accounting log last index information |
| <i>__readonly__</i> | (Optional)                                 |
| <i>last_index</i>   | (Optional) accounting log last index       |

### Command Mode

- /exec

## show accounting log nvram start-seqnum

```
show accounting log nvram start-seqnum <SSEQNUM> [ end-seqnum <ESEQNUM> ] [ __readonly__ [
TABLE_acctnvramlog_seq <accountnvramlog_seq> ] ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                              |
| accounting                    | Show Accounting Information                                  |
| log                           | Show Accounting Log  |
| nvram                         | present in nvram   |
| start-seqnum                  | Show messages starting from a given sequence number          |
| end-seqnum                    | (Optional) Show messages ending with a given sequence number |
| <i>SSEQNUM</i>                | Enter Starting Sequence Number                               |
| <i>ESEQNUM</i>                | (Optional) Enter Starting Sequence Number                    |
| <i>__readonly__</i>           | (Optional)   |
| <i>TABLE_acctnvramlog_seq</i> | (Optional)   |
| <i>accountnvramlog_seq</i>    | (Optional) accounting log nvram seqnum                       |

### Command Mode

- /exec

## show accounting log start-seqnum

```
show accounting log start-seqnum <SSEQNUM> [ end-seqnum <ESEQNUM> ] [ __readonly__ [
TABLE_acctlog_seq <accountlog_seq> ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                              |
| accounting               | Show Accounting Information                                  |
| log                      | Show Accounting Log  |
| start-seqnum             | Show messages starting from a given sequence number          |
| end-seqnum               | (Optional) Show messages ending with a given sequence number |
| <i>SSEQNUM</i>           | Enter Starting Sequence Number                               |
| <i>ESEQNUM</i>           | (Optional) Enter Starting Sequence Number                    |
| <i>__readonly__</i>      | (Optional)   |
| <i>TABLE_acctlog_seq</i> | (Optional)   |
| <i>accountlog_seq</i>    | (Optional) accounting log seqnum                             |

### Command Mode

- /exec

## show acl status

```
show acl status [ __readonly__ [ <current_operation> [ <current_operation_stage> ] [ <current_operation_cli>
] <last_operation> [ <last_operation_status> ] [ <last_operation_cli> ] [ <current_acl> ] [ <current_ace> ] ]
]
```

### Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | Show running system information        |
| acl                            | Show information about acl             |
| status                         | Shows the status of last acl operation |
| <i>__readonly__</i>            | (Optional)                             |
| <i>current_operation</i>       | (Optional) Current operation           |
| <i>current_operation_stage</i> | (Optional) Current operation stage     |
| <i>current_operation_cli</i>   | (Optional) Current operation CLI       |
| <i>last_operation</i>          | (Optional) Last operation              |
| <i>last_operation_status</i>   | (Optional) Last operation status       |
| <i>last_operation_cli</i>      | (Optional) Last operation CLI          |
| <i>current_acl</i>             | (Optional) Access-list being modified  |
| <i>current_ace</i>             | (Optional) ACE rule being modified     |

### Command Mode

- /exec

## show amt process

```
show amt process [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ TABLE_vrf <vrf> <pid> <uuid>
<q> <re4> <ge4> <re6> <ge6> <pi4> <ar4> <ag4> <ra4> <ga4> <dra4> <pi6> <ar6> <ag6> <ra6> <ga6>
<dra6> <qqic4> <tc4> <tl4> <rc4> <rl4> <jp4> <qqic6> <tc6> <tl6> <rc6> <rl6> <jp6> <grm4> <gjp4>
<gslp4> <gsl4> <grm6> <gjp6> <gslp6> <gsl6> ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information        |
| amt                   | AMT show commands                      |
| vrf                   | (Optional) Display information for VRF |
| <i>vrf-name</i>       | (Optional) VRF name                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name              |
| process               | Display AMT process information        |
| <i>__readonly__</i>   | (Optional)                             |
| TABLE_vrf             | (Optional)                             |
| <i>vrf</i>            | (Optional)                             |
| <i>pid</i>            | (Optional)                             |
| <i>uuid</i>           | (Optional)                             |
| <i>q</i>              | (Optional)                             |
| <i>re4</i>            | (Optional)                             |
| <i>ge4</i>            | (Optional)                             |
| <i>re6</i>            | (Optional)                             |
| <i>ge6</i>            | (Optional)                             |
| <i>pi4</i>            | (Optional)                             |
| <i>ar4</i>            | (Optional)                             |
| <i>ag4</i>            | (Optional)                             |
| <i>ra4</i>            | (Optional)                             |
| <i>ga4</i>            | (Optional)                             |
| <i>dra4</i>           | (Optional)                             |
| <i>pi6</i>            | (Optional)                             |



|              |            |
|--------------|------------|
| <i>qqic4</i> | (Optional) |
| <i>tc4</i>   | (Optional) |
| <i>tl4</i>   | (Optional) |
| <i>rc4</i>   | (Optional) |
| <i>rl4</i>   | (Optional) |
| <i>jp4</i>   | (Optional) |
| <i>qqic6</i> | (Optional) |
| <i>tc6</i>   | (Optional) |
| <i>tl6</i>   | (Optional) |
| <i>rc6</i>   | (Optional) |
| <i>rl6</i>   | (Optional) |
| <i>jp6</i>   | (Optional) |
| <i>grm4</i>  | (Optional) |
| <i>gjp4</i>  | (Optional) |
| <i>gslp4</i> | (Optional) |
| <i>gsl4</i>  | (Optional) |
| <i>grm6</i>  | (Optional) |
| <i>gjp6</i>  | (Optional) |
| <i>gslp6</i> | (Optional) |
| <i>gsl6</i>  | (Optional) |

**Command Mode**

- /exec

# show amt vrf all

show amt vrf all [ *\_\_readonly\_\_* *TABLE\_vrf* <vrf> <cid> <ip\_tid> <ipv6\_tid> ]

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| amt                 | AMT show commands                     |
| vrf                 | Display all VRFs AMT is configured in |
| all                 | Display all VRFs AMT is configured in |
| <i>__readonly__</i> | (Optional)                            |
| <i>TABLE_vrf</i>    | (Optional)                            |
| <i>vrf</i>          | (Optional)                            |
| <i>cid</i>          | (Optional)                            |
| <i>ip_tid</i>       | (Optional)                            |
| <i>ipv6_tid</i>     | (Optional)                            |

## Command Mode

- /exec

# show archive log config

```
show archive log config { all | [ user <username> ] [ first-index <first_index> [ last-index <last_index> ] ] }
[ __readonly__ [ TABLE_archivelog_time [ <archivelog_firstindex> ] ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                             |
| archive                      | Show archive configuration                                  |
| log                          | Show Archive Log  |
| config                       | Show Config Logger information                              |
| all                          | List all the records in the config log                      |
| user                         | (Optional) List records for specific user in the config log |
| <i>username</i>              | (Optional) Username   |
| first-index                  | (Optional) The first record number to display               |
| last-index                   | (Optional) The last record number to display                |
| <i>first_index</i>           | (Optional) config log first index                           |
| <i>last_index</i>            | (Optional) config log last index                            |
| __readonly__                 | (Optional)  |
| TABLE_archivelog_time        | (Optional)  |
| <i>archivelog_firstindex</i> | (Optional) archive log startindex                           |

## Command Mode

- /exec

## show arp access-lists

```
show arp access-lists [ <name> ] [ __readonly__ TABLE_arp <arp_name> [ TABLE_seqno <seqno> {
<permitdeny> <reqresp> ip { { <sender_ip_any> | { { <sender_host> <sender_ip> | { <sender_net_ip>
<sender_ip_mask> } } } } [ { <target_ip_any> | { { <target_host> <target_ip> | { <target_net_ip>
<target_ip_mask> } } } ] } mac { { <sender_mac_any> | { { <sender_mac_host> <sender_mac> | {
<sender_net_mac> <sender_mac_mask> } } } } [ { <target_mac_any> | { { <target_mac_host> <target_mac>
| { <target_net_mac> <target_mac_mask> } } } ] } [ <arp_log> ] } | <remark> ] ] [ capture session
<session-id> ]
```

### Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| arp                   | ARP access-lists                |
| access-lists          | List access lists               |
| <i>name</i>           | (Optional) List name            |
| <i>__readonly__</i>   | (Optional)                      |
| <i>arp_name</i>       | (Optional) Name of the ARP ACL  |
| <i>seqno</i>          | (Optional) Sequence number      |
| <i>permitdeny</i>     | (Optional) Permit/deny          |
| ip                    | (Optional) Any IP protocol      |
| TABLE_arp             | (Optional)                      |
| TABLE_seqno           | (Optional)                      |
| <i>reqresp</i>        | (Optional) ARP_Request          |
| <i>sender_ip_any</i>  | (Optional) Any                  |
| <i>sender_host</i>    | (Optional) Host                 |
| <i>sender_ip</i>      | (Optional) IP address <a.b.c.d> |
| <i>sender_net_ip</i>  | (Optional) IP address <a.b.c.d> |
| <i>sender_ip_mask</i> | (Optional) IP mask <a.b.c.d>    |
| <i>target_ip_any</i>  | (Optional) Any                  |
| <i>target_host</i>    | (Optional) Host                 |
| <i>target_ip</i>      | (Optional) IP address <a.b.c.d> |
| <i>target_net_ip</i>  | (Optional) IP address <a.b.c.d> |
| <i>target_ip_mask</i> | (Optional) IP mask <a.b.c.d>    |

|                        |   |
|------------------------|---|
| <i>mac</i>             | (Optional) MAC configuration commands                       |
| <i>sender_mac_any</i>  | (Optional) Any  |
| <i>sender_mac_host</i> | (Optional) Host   |
| <i>sender_mac</i>      | (Optional) MAC address EEEE.EEEE.EEEE                       |
| <i>sender_net_mac</i>  | (Optional) MAC address EEEE.EEEE.EEEE                       |
| <i>sender_mac_mask</i> | (Optional) MAC mask EEEE.EEEE.EEEE                          |
| <i>target_mac_any</i>  | (Optional) Any  |
| <i>target_mac_host</i> | (Optional) Host   |
| <i>target_mac</i>      | (Optional) MAC address EEEE.EEEE.EEEE                       |
| <i>target_net_mac</i>  | (Optional) MAC address EEEE.EEEE.EEEE                       |
| <i>target_mac_mask</i> | (Optional) MAC mask EEEE.EEEE.EEEE                          |
| <i>remark</i>          | (Optional) Remark String                                    |
| <i>arp_log</i>         | (Optional) Log  |
| <i>capture</i>         | (Optional) Enable packet capture on this filter for session |
| <i>session</i>         | (Optional) Session ID <1-48> for this session               |
| <i>session-id</i>      | (Optional) Session ID <1-48> for this session               |

**Command Mode**

- /exec

show arp access-lists



## B Show Commands

---

- [show background](#), on page 51
- [show banner exec](#), on page 52
- [show banner motd](#), on page 53
- [show bash-shell](#), on page 54
- [show bfd clients](#), on page 55
- [show bfd neighbors](#), on page 56
- [show bgp](#), on page 60
- [show bgp](#), on page 62
- [show bgp](#), on page 65
- [show bgp](#), on page 74
- [show bgp](#), on page 81
- [show bgp](#), on page 88
- [show bgp bmp server](#), on page 91
- [show bgp community](#), on page 94
- [show bgp convergence](#), on page 101
- [show bgp dampening dampened](#), on page 103
- [show bgp dampening flap-statistics](#), on page 110
- [show bgp dampening parameters](#), on page 113
- [show bgp evi](#), on page 116
- [show bgp extcommunity](#), on page 118
- [show bgp l3vpn](#), on page 125
- [show bgp neighbors](#), on page 127
- [show bgp neighbors](#), on page 134
- [show bgp neighbors commands](#), on page 145
- [show bgp neighbors flap-statistics](#), on page 147
- [show bgp neighbors paths](#), on page 149
- [show bgp path-attribute discard](#), on page 151
- [show bgp paths](#), on page 158
- [show bgp peer-template](#), on page 159
- [show bgp peer](#), on page 163
- [show bgp prefix-list](#), on page 165
- [show bgp private attr](#), on page 171
- [show bgp private debug history](#), on page 172

- [show bgp process](#), on page 173
- [show bgp received-paths](#), on page 179
- [show bgp regexp](#), on page 186
- [show bgp segment-routing srv6](#), on page 192
- [show bgp self-originated](#), on page 193
- [show bgp sessions](#), on page 199
- [show bgp statistics](#), on page 201
- [show bgp summary](#), on page 202
- [show bgp summary](#), on page 207
- [show boot](#), on page 211
- [show boot auto-copy](#), on page 212
- [show boot auto-copy list](#), on page 213
- [show boot current](#), on page 214
- [show boot mode](#), on page 215
- [show boot order](#), on page 216
- [show boot timings](#), on page 217
- [show boot variables](#), on page 218
- [show buffer-drop detail](#), on page 219
- [show buffer-latency detail](#), on page 220



# show background

```
show background [ __readonly__ [ { TABLE_jobs <pid> <user_name> <terminal> <start> <time> <script>
<args> } ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| <code>show</code>         | Show running system information   |
| <code>background</code>   | show background processes (started with 'source background <file>' command) |
| <code>__readonly__</code> | (Optional)  |
| <code>TABLE_jobs</code>   | (Optional) All background jobs  |
| <code>pid</code>          | (Optional) Process ID of the job  |
| <code>user_name</code>    | (Optional) User name of the process   |
| <code>terminal</code>     | (Optional) Terminal where job is running                                    |
| <code>start</code>        | (Optional) Start time of job  |
| <code>time</code>         | (Optional) Time   |
| <code>script</code>       | (Optional) Script name  |
| <code>args</code>         | (Optional) Arguments passed to script                                       |

## Command Mode

- /exec

## show banner exec

```
show banner exec [ __readonly__ { banner_msg <b_msg> } ]
```

### Syntax Description

|              |                                  |
|--------------|----------------------------------|
| show         | Show running system information  |
| banner       | Show current banner message      |
| exec         | Show current exec banner message |
| __readonly__ | (Optional)                       |
| banner_msg   | (Optional) The banner message    |
| <i>b_msg</i> | (Optional) The banner message    |

### Command Mode

- /exec

# show banner motd

```
show banner motd [ __readonly__ { banner_msg <b_msg> } ]
```

## Syntax Description

|              |                                  |
|--------------|----------------------------------|
| show         | Show running system information  |
| banner       | Show current banner message      |
| motd         | Show current motd banner message |
| __readonly__ | (Optional)                       |
| banner_msg   | (Optional) The banner message    |
| <i>b_msg</i> | (Optional) The banner message    |

## Command Mode

- /exec

# show bash-shell

```
show bash-shell [ __readonly__ { operation_status <o_status> } ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| bash-shell              | Show bash shell status                      |
| <i>__readonly__</i>     | (Optional)                                  |
| <i>operation_status</i> | (Optional) Bash shell status                |
| <i>o_status</i>         | (Optional) operational status of bash shell |

## Command Mode

- /exec

# show bfd clients

```
show bfd clients [ __readonly__ <header> [ { TABLE_bfdClients <client_name> <num_sess> } ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| bfd                 | BFD commands                    |
| clients             | bfd client list                 |
| <i>__readonly__</i> | (Optional)                      |
| <i>header</i>       | (Optional) print header         |
| TABLE_bfdClients    | (Optional) BFD Client table     |
| <i>client_name</i>  | (Optional) client name          |
| <i>num_sess</i>     | (Optional) Number of sessions   |

## Command Mode

- /exec

## show bfd neighbors

```
show bfd { [ vrf { <vrf-name> | <vrf-known-name> | all } ] } { [ <ip_type> ] } neighbors { [ multihop ] | [
module <module> ] | [ interface <intf_id> ] | [ application <bfd_cli_client_names> ] | [ { src-ip <src_ip> |
src-ipv6 <src_ipv6> } ] | [ { dest-ip <dest_ip> | dest-ipv6 <dest_ipv6> } ] | [ vrf { <vrf-name> |
<vrf-known-name> | all } ] } + [ details ] [ __readonly__ TABLE_bfdNeighbor <local_disc> [ <header> ] [
<sess_type> ] [ <vrf_name> ] [ <src_ip_addr> ] [ <src_ipv6_addr> ] [ <dest_ip_addr> ] [ <dest_ipv6_addr>
] [ <remote_disc> ] [ <local_state> ] [ <remote_state> ] [ <holddown> ] [ <cur_detect_mult> ] [ <intf> ] [
<echo> ] [ <echo_tx> ] [ <local_diag> ] [ <demand> ] [ <poll> ] [ <min_tx> ] [ <min_rx> ] [ <local_multi>
] [ <detect_timer> ] [ <tx_interval> ] [ <rx_count> ] [ <rx_avg> ] [ <rx_min> ] [ <rx_max> ] [ <last_rx> ] [
<tx_count> ] [ <tx_avg> ] [ <tx_min> ] [ <tx_max> ] [ <last_tx> ] [ <app> ] [ <up_time> ] [ <up_count> ] [
<down_count> ] [ <version> ] [ <diag> ] [ <state_bit> ] [ <demand_bit> ] [ <poll_bit> ] [ <final_bit> ] [
<multiplier> ] [ <length> ] [ <my_disc> ] [ <your_disc> ] [ <min_tx_interval> ] [ <req_min_rx> ] [
<min_echo_interval> ] [ <out_str> ] [ <host_lc> ] [ <down_reason> ] [ <no_host_reason> ] [ <parent> ] [
<per_link_str> ] [ <auth> ] [ <auth_bit> ] [ <print_details> ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                                    |
| bfd                         | BFD commands   |
| <i>ip_type</i>              | (Optional) ipv4 or ipv6  |
| neighbors                   | neighbors  |
| multihop                    | (Optional) Display Multihop sessions only                          |
| module                      | (Optional) module  |
| <i>module</i>               | (Optional) module number   |
| interface                   | (Optional) interface   |
| <i>intf_id</i>              | (Optional) show bfd sessions based on interface id                 |
| application                 | (Optional) application   |
| <i>bfd_cli_client_names</i> | (Optional) __nil__ Clients need to register with bfd for this list |
| src-ip                      | (Optional) Source ip   |
| src-ipv6                    | (Optional) Source ip   |
| <i>src_ip</i>               | (Optional) Source ip value   |
| dest-ip                     | (Optional) Destination ip  |
| dest-ipv6                   | (Optional) Destination ip  |
| <i>dest_ip</i>              | (Optional) Destination ip value                                    |
| vrf                         | (Optional) Display per-VRF information                             |

|                        |   |
|------------------------|---|
| <i>vrf-name</i>        | (Optional) VRF name                         |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                   |
| all                    | (Optional) Display information for all VRFs |
| details                | (Optional) details                          |
| <i>__readonly__</i>    | (Optional)                                  |
| TABLE_bfdNeighbor      | (Optional) BFD Neighbor table               |
| <i>header</i>          | (Optional) Header                           |
| <i>sess_type</i>       | (Optional) Session type                     |
| <i>vrf_name</i>        | (Optional) vrf name                         |
| <i>src_ip_addr</i>     | (Optional) Source IPV4 address              |
| <i>dest_ip_addr</i>    | (Optional) Destination IPV4 address         |
| <i>local_disc</i>      | (Optional) Local Discriminator              |
| <i>remote_disc</i>     | (Optional) Remote Discriminator             |
| <i>local_state</i>     | (Optional) Local State                      |
| <i>remote_state</i>    | (Optional) Remote State                     |
| <i>holddown</i>        | (Optional) Hold Down Time                   |
| <i>cur_detect_mult</i> | (Optional) Current Detection Multiplier     |
| <i>intf</i>            | (Optional) Interface                        |
| <i>echo</i>            | (Optional) Echo enabled                     |
| <i>echo_tx</i>         | (Optional) Echo Tx Interval                 |
| <i>local_diag</i>      | (Optional) Local Diag                       |
| <i>demand</i>          | (Optional) Demand Mode                      |
| <i>poll</i>            | (Optional) Poll Bit                         |
| <i>min_tx</i>          | (Optional) Local Min Tx Interval            |
| <i>min_rx</i>          | (Optional) Local Min Rx Interval            |
| <i>local_multi</i>     | (Optional) Local Detection Multiplier       |
| <i>detect_timer</i>    | (Optional) Current Detection Timer          |
| <i>tx_interval</i>     | (Optional) Tx Interval                      |
| <i>rx_count</i>        | (Optional) Tx Count                         |

|                          |  |
|--------------------------|--|
| <i>rx_avg</i>            | (Optional) Rx Interval Avg                     |
| <i>rx_min</i>            | (Optional) Rx Interval Min                     |
| <i>rx_max</i>            | (Optional) Rx Interval Max                     |
| <i>last_rx</i>           | (Optional) Last Rx time                        |
| <i>tx_count</i>          | (Optional) Tx Count                            |
| <i>tx_avg</i>            | (Optional) Tx Interval Avg                     |
| <i>tx_min</i>            | (Optional) Tx Interval Min                     |
| <i>tx_max</i>            | (Optional) Tx Interval Max                     |
| <i>last_tx</i>           | (Optional) Last Tx time                        |
| <i>app</i>               | (Optional) App name                            |
| <i>up_time</i>           | (Optional) Up time                             |
| <i>up_count</i>          | (Optional) Up Count                            |
| <i>down_count</i>        | (Optional) Down Count                          |
| <i>version</i>           | (Optional) Version in Last Packet              |
| <i>diag</i>              | (Optional) diag in Last Packet                 |
| <i>state_bit</i>         | (Optional) State Bit in Last Packet            |
| <i>demand_bit</i>        | (Optional) Demand Bit in Last Packet           |
| <i>poll_bit</i>          | (Optional) Poll Bit in Last Packet             |
| <i>final_bit</i>         | (Optional) Final Bit in Last Packet            |
| <i>multiplier</i>        | (Optional) Detection Multiplier in Last Packet |
| <i>length</i>            | (Optional) Length in Last Packet               |
| <i>my_disc</i>           | (Optional) My Discriminator in Last Packet     |
| <i>your_disc</i>         | (Optional) Your Discriminator in Last Packet   |
| <i>min_tx_interval</i>   | (Optional) Min Tx Interval in Last Packet      |
| <i>req_min_rx</i>        | (Optional) Required Rx Interval in Last Packet |
| <i>min_echo_interval</i> | (Optional) Min Echo Interval in Last Packet    |
| <i>out_str</i>           | (Optional) No Host LC string                   |
| <i>parent</i>            | (Optional) Parent Session                      |
| <i>per_link_str</i>      | (Optional) Per Link string                     |



|                       |                                    |
|-----------------------|------------------------------------|
| <i>host_lc</i>        | (Optional) Host LC                 |
| <i>down_reason</i>    | (Optional) Session Down Reason     |
| <i>no_host_reason</i> | (Optional) Not Hosted Reason       |
| <i>auth</i>           | (Optional) Authentication Mode     |
| <i>auth_bit</i>       | (Optional) Auth Bit in Last Packet |
| <i>print_details</i>  | (Optional) print details           |

**Command Mode**

- /exec

# show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } flap-statistics [ <ip-prefix> | <ip-addr> [ <ip-mask> ] ] | ipv6 { unicast | multicast } flap-statistics
[ <ipv6-prefix> ] | all flap-statistics } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234
} ] [ __readonly__ TABLE_vrf <vrf-name-out> [ TABLE_afi <afi> TABLE_safi <safi> <af-name> [
TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [ <dampening> <historypaths> <dampenedpaths> ] [
TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <status> ] [ <pathtype> ] [ <peer> | <ipv6peer>
] [ <flapcount> ] [ <duration> ] [ <reuse> ] [ <penalty> ] [ <suppresslimit> ] [ <reuselimit> ] [ <best> ] ] ] ]
]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| bgp                   | Display BGP status and configuration                 |
| vrf                   | (Optional) Virtual Router Context                    |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| flap-statistics       | Display route flap statistics                        |
| <i>ip-prefix</i>      | (Optional) Display flap statistics for one prefix    |
| <i>ip-addr</i>        | (Optional) Display flap statistics for one network   |
| <i>ip-mask</i>        | (Optional) Network mask                              |
| ipv4                  | Display BGP information for IPv4 address family      |
| ipv6                  | Display BGP information for IPv6 address family      |
| unicast               | Display BGP information for unicast address family   |
| multicast             | Display BGP information for multicast address family |
| all                   | Display BGP information for all address families     |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrf-name-out</i>   | (Optional)   |
| TABLE_afi             | (Optional)   |
| <i>afi</i>            | (Optional)   |
| TABLE_safi            | (Optional)   |
| <i>safi</i>           | (Optional)   |

|                      |            |
|----------------------|------------|
| <i>af-name</i>       | (Optional) |
| TABLE_rd             | (Optional) |
| <i>rd_val</i>        | (Optional) |
| <i>rd_vrf</i>        | (Optional) |
| <i>rd_vniid</i>      | (Optional) |
| <i>dampening</i>     | (Optional) |
| <i>historypaths</i>  | (Optional) |
| <i>dampenedpaths</i> | (Optional) |
| TABLE_prefix         | (Optional) |
| <i>ipprefix</i>      | (Optional) |
| <i>nonipprefix</i>   | (Optional) |
| <i>status</i>        | (Optional) |
| <i>best</i>          | (Optional) |
| <i>pathtype</i>      | (Optional) |
| <i>peer</i>          | (Optional) |
| <i>flapcount</i>     | (Optional) |
| <i>duration</i>      | (Optional) |
| <i>reuse</i>         | (Optional) |
| <i>penalty</i>       | (Optional) |
| <i>suppresslimit</i> | (Optional) |
| <i>reuselimit</i>    | (Optional) |

**Command Mode**

- /exec

## show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } policy statistics { { redistribute [ { { eigrp | isis | ospf | rip } <tag> } | static | direct | amt | lisp |
hmm | am ] } | { neighbor <neighbor-id> [ default-originate | { route-map | filter-list | prefix-list } { in | out }
] } | { dampening } | { network { <ip-addr> mask <ip-mask> | <ip-prefix> } } | { aggregate-address { <ip-addr>
<ip-mask> | <ip-prefix> } { suppress-map | advertise-map } } } | vpnv4 unicast policy statistics { neighbor
<neighbor-id> [ { route-map | filter-list | prefix-list } { in | out } ] } | ipv6 { unicast | multicast } policy statistics
{ { redistribute [ { { eigrp | isis | ospfv3 | rip } <tag> } | static | direct | amt | lisp | hmm | am ] } | { neighbor
{ <neighbor-id> | <ipv6-neighbor-id> } [ default-originate | { route-map | filter-list | prefix-list } { in | out }
] } | { dampening } | { network <ipv6-prefix> } | { aggregate-address <ipv6-prefix> { suppress-map |
advertise-map } } } } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [
__readonly__ TABLE_vrf <vrf-name-polstats> [ <rpm-handle-count> ] [ { TABLE_rmap <name> <action>
<seqnum> [ { TABLE_cmd <command> <comparecount> <matchcount> } ] [ <totalacceptcount> ] [
<totalrejectcount> ] } ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| bgp                   | Display BGP status and configuration                 |
| vrf                   | (Optional) Virtual Router Context                    |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| ipv4                  | Display BGP information for IPv4 address family      |
| ipv6                  | Display BGP information for IPv6 address family      |
| vpnv4                 | Display BGP information for VPNv4 address family     |
| unicast               | Display BGP information for unicast address family   |
| multicast             | Display BGP information for multicast address family |
| policy                | Display policy related information                   |
| statistics            | Display Route Filter statistics                      |
| redistribute          | Statistics for redistribution                        |
| isis                  | (Optional) ISO IS-IS                                 |
| ospf                  | (Optional) Open Shortest Path First                  |
| ospfv3                | (Optional) Open Shortest Path First v3               |
| rip                   | (Optional) Routing Information Protocol              |
| eigrp                 | (Optional) Enhanced Interior Gateway Protocol        |

|                          |   |
|--------------------------|---|
| static                   | (Optional) Static routes                            |
| direct                   | (Optional) Directly connected                       |
| amt                      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| lisp                     | (Optional) LISP EID-prefixes in the non-default VRF |
| hmm                      | (Optional) HMM prefix                               |
| am                       | (Optional) AM routes (learned via ARP)              |
| <i>tag</i>               | (Optional) Source protocol tag                      |
| neighbor                 | Show neighbor specific counters                     |
| <i>neighbor-id</i>       | Neighbor IPv4 address                               |
| route-map                | (Optional) Neighbor route-map                       |
| prefix-list              | (Optional) Neighbor prefix-list                     |
| filter-list              | (Optional) Neighbor filter-list                     |
| out                      | (Optional) Outbound policy                          |
| in                       | (Optional) Inbound policy                           |
| default-originate        | (Optional) Default-originate policy                 |
| dampening                | Show dampening info                                 |
| network                  | Configured IP prefix to advertise                   |
| mask                     | Configured mask of the IP prefix advertised         |
| aggregate-address        | Configured BGP aggregate prefixes                   |
| suppress-map             | Statistics of suppress policy                       |
| advertise-map            | Statistics of advertise policy                      |
| <i>ip-addr</i>           | IP network advertised                               |
| <i>ip-mask</i>           | Dotted 4-octet mask                                 |
| <i>ip-prefix</i>         | IP prefix in CIDR format                            |
| __readonly__             | (Optional)  |
| TABLE_vrf                | (Optional)  |
| <i>vrf-name-polstats</i> | (Optional)  |
| <i>rpm-handle-count</i>  | (Optional)  |
| TABLE_rmap               | (Optional)  |

|                         |            |
|-------------------------|------------|
| <i>name</i>             | (Optional) |
| <i>action</i>           | (Optional) |
| <i>seqnum</i>           | (Optional) |
| TABLE_cmd               | (Optional) |
| <i>command</i>          | (Optional) |
| <i>comparecount</i>     | (Optional) |
| <i>matchcount</i>       | (Optional) |
| <i>totalacceptcount</i> | (Optional) |
| <i>totalrejectcount</i> | (Optional) |

**Command Mode**

- /exec



### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                   |
| bgp                   | Display BGP status and configuration                              |
| vrf                   | (Optional) Virtual Router Context                                 |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| <i>ip-addr</i>        | (Optional) Display one particular network from the BRIB in detail |
| <i>ip-mask</i>        | (Optional) Mask for one particular prefix in the BRIB             |
| <i>ip-prefix</i>      | (Optional) Display one particular prefix from the BRIB in detail  |
| longer-prefixes       | (Optional) Display route and more specific routes                 |
| labels                | (Optional) Display BGP labels for prefixes                        |
| exported              | (Optional) Display only exported prefixes                         |
| imported              | (Optional) Display only imported prefixes                         |
| injected-routes       | (Optional) Display only injected prefixes                         |
| mdt-group             | (Optional) Display prefixes with MDT group address                |
| <i>mdt-group</i>      | (Optional) MDT group address                                      |
| rd                    | (Optional) Display information for a route distinguisher          |
| ve-id                 | (Optional) VPLS VE ID   |
| <i>ve-id</i>          | (Optional) VPLS VE ID   |
| route-type            | (Optional) EVPN Route Type number                                 |
| <i>rtype</i>          | (Optional) EVPN route type number                                 |
| 1                     | (Optional) Inter-AS PMSI AD                                       |
| 2                     | (Optional) Intra-AS PMSI AD                                       |
| 3                     | (Optional) SPMSI AD   |
| 4                     | (Optional) LEAF AD  |
| 5                     | (Optional) Source-Active AD                                       |
| 6                     | (Optional) Shared C-Multicast                                     |
| 7                     | (Optional) Source C-Multicast                                     |
| vni-id                | (Optional) EVPN VNI ID number                                     |



|                           |   |
|---------------------------|---|
| <i>vni_id</i>             | (Optional) EVPN VNI ID number                                     |
| <i>rt-type</i>            | (Optional) Link-State route-type                                  |
| <i>es</i>                 | (Optional) Ethernet Segment                                       |
| <i>es-id</i>              | (Optional) ESID   |
| <i>etid</i>               | (Optional) Ethernet Tag-ID for L2VPN EVPN route                   |
| <i>et</i>                 | (Optional) Ethernet Tag-ID  |
| <i>ipv4-evpn-rt</i>       | (Optional) EVPN IPv4 address                                      |
| <i>ipv4-ls-rt</i>         | (Optional) Link-State NLRI with descriptor including IPv4 address |
| <i>mac-address</i>        | (Optional) MAC address  |
| <i>block-offset</i>       | (Optional) VPLS VE Block offset                                   |
| <i>ve-bs</i>              | (Optional) VPLS VE Block offset                                   |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format      |
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format                |
| <i>ipv4</i>               | Display BGP information for IPv4 address family                   |
| <i>vpn4</i>               | Display BGP information for VPNv4 address family                  |
| <i>vpn6</i>               | Display BGP information for VPNv6 address family                  |
| <i>ipv6</i>               | Display BGP information for IPv6 address family                   |
| <i>unicast</i>            | Display BGP information for unicast address family                |
| <i>multicast</i>          | Display BGP information for multicast address family              |
| <i>mdt</i>                | Display BGP information for multicast distribution tree           |
| <i>link-state</i>         | Display BGP information for link-state address family             |
| <i>l2vpn</i>              | Display BGP information for L2VPN address family                  |
| <i>vpls</i>               | Display BGP information for L2VPN VPLS address family             |
| <i>labeled-unicast</i>    | Display BGP information for labeled-unicast address family        |
| <i>mvpn</i>               | Display BGP information for MVPN address family                   |
| <i>evpn</i>               | Display BGP information for L2VPN EVPN address family             |
| <i>all</i>                | Display BGP information for all address families                  |
| <i>join</i>               | (Optional) Display Multicast Join route                           |
| <i>detail</i>             | (Optional) Display detailed path info for routes                  |

|               |   |
|---------------|---|
| sa            | (Optional) Display Multicast Source Active AD route |
| sa-ad         | (Optional) Display Multicast Source Active AD route |
| i-pmsi        | (Optional) Display Multicast Intra-AS I-PMSI route  |
| rp            | (Optional) Display Multicast Group to RP route      |
| v4src-addr    | (Optional) Source IP Address                        |
| src-asn       | (Optional) Source ASN                               |
| v4grp-addr    | (Optional) Group IP Address                         |
| grp-v4prefix  | (Optional) Group IP prefix                          |
| pe-addr       | (Optional) PE IP Address                            |
| rp-flags      | (Optional) Flags                                    |
| rp-priority   | (Optional) RP Priority                              |
| hashlen       | (Optional) Hash mask length                         |
| l             | (Optional) vrf                                      |
| __readonly__  | (Optional)  |
| TABLE_vrf     | (Optional)  |
| vrf-name-out  | (Optional)  |
| TABLE_afi     | (Optional)  |
| afi           | (Optional)  |
| TABLE_safi    | (Optional)  |
| safi          | (Optional)  |
| af-name       | (Optional)  |
| table-version | (Optional)  |
| router-id     | (Optional)  |
| TABLE_rd      | (Optional)  |
| rd_val        | (Optional)  |
| rd_vrf        | (Optional)  |
| rd_vniid      | (Optional)  |
| TABLE_prefix  | (Optional)  |
| ipprefix      | (Optional)  |

|                            |            |
|----------------------------|------------|
| <i>nonipprefix</i>         | (Optional) |
| <i>totalpaths</i>          | (Optional) |
| <i>bestpathnr</i>          | (Optional) |
| <i>mpath</i>               | (Optional) |
| TABLE_ <i>advertisedto</i> | (Optional) |
| <i>advertisedto</i>        | (Optional) |
| TABLE_ <i>scheduledto</i>  | (Optional) |
| <i>scheduledto</i>         | (Optional) |
| <i>prefixversion</i>       | (Optional) |
| <i>on-newlist</i>          | (Optional) |
| <i>on-xmitlist</i>         | (Optional) |
| <i>suppressed</i>          | (Optional) |
| <i>needsresync</i>         | (Optional) |
| <i>locked</i>              | (Optional) |
| <i>table-map-filtered</i>  | (Optional) |
| <i>export-on-newlist</i>   | (Optional) |
| <i>export-on-xmitlist</i>  | (Optional) |
| <i>locallabel</i>          | (Optional) |
| <i>labelhldwstr</i>        | (Optional) |
| TABLE_ <i>path</i>         | (Optional) |
| <i>pathnr</i>              | (Optional) |
| <i>best</i>                | (Optional) |
| <i>status</i>              | (Optional) |
| <i>type</i>                | (Optional) |
| <i>statuscode</i>          | (Optional) |
| <i>bestcode</i>            | (Optional) |
| <i>typecode</i>            | (Optional) |
| <i>ipnexthop</i>           | (Optional) |
| <i>neighbor</i>            | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_ <i>importdests</i>   | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |
| <i>pathstaled</i>           | (Optional) |
| <i>pathhistory</i>          | (Optional) |
| <i>pathmultipath</i>        | (Optional) |
| <i>pathovermaxaslimit</i>   | (Optional) |
| <i>pathnolabeledrn</i>      | (Optional) |
| <i>pathlocator</i>          | (Optional) |
| <i>nexthopmetric</i>        | (Optional) |
| <i>aggregator</i>           | (Optional) |
| <i>aggregatoras</i>         | (Optional) |
| <i>atomicaggregate</i>      | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>inlabel</i>               | (Optional) |
| <i>originflag</i>            | (Optional) |
| <i>vpn</i>                   | (Optional) |
| <i>hold_down</i>             | (Optional) |
| <i>outlabel</i>              | (Optional) |
| <i>flappenalty</i>           | (Optional) |
| <i>dampenedtime</i>          | (Optional) |
| <i>flaps</i>                 | (Optional) |
| <i>flaptime</i>              | (Optional) |
| <i>flapflags</i>             | (Optional) |
| <i>flapindex</i>             | (Optional) |
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |

|                           |            |
|---------------------------|------------|
| TABLE_clusterlist         | (Optional) |
| <i>clusterlist</i>        | (Optional) |
| <i>remotenh</i>           | (Optional) |
| <i>remotenh_encap</i>     | (Optional) |
| <i>remotenh_vnid</i>      | (Optional) |
| <i>remotenh_mac</i>       | (Optional) |
| <i>psid</i>               | (Optional) |
| <i>psid_len</i>           | (Optional) |
| <i>psid_lindx_len</i>     | (Optional) |
| <i>psid_lindx_flag</i>    | (Optional) |
| <i>psid_lindx</i>         | (Optional) |
| <i>psid_v6sid_len</i>     | (Optional) |
| <i>psid_sub_type</i>      | (Optional) |
| <i>psid_func_len</i>      | (Optional) |
| <i>psid_trans_len</i>     | (Optional) |
| <i>psid_trans_off</i>     | (Optional) |
| <i>psid_origsrgb_len</i>  | (Optional) |
| <i>psid_origsrgb_flag</i> | (Optional) |
| <i>psid_origsrgb_base</i> | (Optional) |
| <i>psid_origsrgb_end</i>  | (Optional) |
| TABLE_path_attr_list      | (Optional) |
| <i>path_attr_list</i>     | (Optional) |
| TABLE_attr                | (Optional) |
| <i>attr_num</i>           | (Optional) |
| <i>attr_code_str</i>      | (Optional) |
| <i>attr_code_hex</i>      | (Optional) |
| <i>attr_len</i>           | (Optional) |
| <i>attr_flags</i>         | (Optional) |
| TABLE_attr_val            | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec





|                           |  |
|---------------------------|--|
| <i>rmap-name</i>          | Known route-map name   |
| filter-list               | Display routes matching the filter-list                      |
| <i>fltrlist-name</i>      | Name of filter-list  |
| community-list            | Display routes matching the community-list                   |
| <i>commlist-name</i>      | Name of community-list                                       |
| extcommunity-list         | Display routes matching the extcommunity-list                |
| <i>extcommllist-name</i>  | Name of extcommunity-list                                    |
| <i>test_pol_name</i>      | An existing test-list policy                                 |
| rd                        | (Optional) Display information for a route distinguisher     |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format |
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format           |
| ipv4                      | Display BGP information for IPv4 address family              |
| vpnv4                     | Display BGP information for VPNv4 address family             |
| vpnv6                     | Display BGP information for VPNv6 address family             |
| ipv6                      | Display BGP information for IPv6 address family              |
| unicast                   | Display BGP information for unicast address family           |
| multicast                 | Display BGP information for multicast address family         |
| mdt                       | Display BGP information for multicast distribution tree      |
| labeled-unicast           | Display BGP information for labeled-unicast address family   |
| link-state                | Display BGP information for link-state address family        |
| l2vpn                     | Display BGP information for L2VPN address family             |
| vpls                      | Display BGP information for L2VPN VPLS address family        |
| mvpn                      | Display BGP information for MVPN address family              |
| evpn                      | Display BGP information for L2VPN EVPN address family        |
| all                       | Display BGP information for all address families             |
| exact-match               | (Optional) Exact match of the communities                    |
| <u>__readonly__</u>       | (Optional)   |
| TABLE_vrf                 | (Optional)   |
| <i>vrf-name-out</i>       | (Optional)   |

|                           |            |
|---------------------------|------------|
| TABLE_afi                 | (Optional) |
| <i>afi</i>                | (Optional) |
| TABLE_safi                | (Optional) |
| <i>safi</i>               | (Optional) |
| <i>af-name</i>            | (Optional) |
| <i>table-version</i>      | (Optional) |
| <i>router-id</i>          | (Optional) |
| TABLE_rd                  | (Optional) |
| <i>rd_val</i>             | (Optional) |
| <i>rd_vrf</i>             | (Optional) |
| <i>rd_vniid</i>           | (Optional) |
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>export-on-xmitlist</i>   | (Optional) |
| <i>locallabel</i>           | (Optional) |
| <i>labelhldwstr</i>         | (Optional) |
| TABLE_path                  | (Optional) |
| <i>pathnr</i>               | (Optional) |
| <i>best</i>                 | (Optional) |
| <i>status</i>               | (Optional) |
| <i>type</i>                 | (Optional) |
| <i>statuscode</i>           | (Optional) |
| <i>bestcode</i>             | (Optional) |
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>pathbest</i>           | (Optional) |
| <i>pathreoriginated</i>   | (Optional) |
| <i>pathdeleted</i>        | (Optional) |
| <i>pathstaled</i>         | (Optional) |
| <i>pathhistory</i>        | (Optional) |
| <i>pathmultipath</i>      | (Optional) |
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappenalty</i>        | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |
| <i>flaphalf-life</i>      | (Optional) |
| <i>flapreuse</i>          | (Optional) |
| <i>flapsuppress</i>       | (Optional) |
| <i>flapmax</i>            | (Optional) |
| <i>con_type</i>           | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |
| <i>psid_v6sid_len</i>        | (Optional) |
| <i>psid_sub_type</i>         | (Optional) |
| <i>psid_func_len</i>         | (Optional) |
| <i>psid_trans_len</i>        | (Optional) |
| <i>psid_trans_off</i>        | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>psid_origrsrgb_len</i>   | (Optional) |
| <i>psid_origrsrgb_flag</i>  | (Optional) |
| <i>psid_origrsrgb_base</i>  | (Optional) |
| <i>psid_origrsrgb_end</i>   | (Optional) |
| TABLE_path_attr_list        | (Optional) |
| <i>path_attr_list</i>       | (Optional) |
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

### Command Mode

- /exec

# show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { { ipv4 { unicast |
multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv4 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | link-state | l2vpn vpls [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | l2vpn evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4
mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast } nexthop <ipnexthop>
| { { ipv6 { unicast | multicast } | vpnv6 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] |
ipv6 labeled-unicast | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] } nexthop
<ipv6nexthop> } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ [ __readonly__
TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id>
] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> |
<nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed>
<needsresync> <locked> ] [ <table-map-filtered> ] [ <export-on-newlist> <export-on-xmitlist> ] [
<srv6-local-sid> ] [ <locallabel> ] [ <labelhdlwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status>
<best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop> | <ipv6nexthop> } } { <inlabel> <outlabel>
<vpn> <hold_down> } } { <weight> <aspath> <origin> [ <metric> ] [ <localpref> ] } } | [
<policyincomplete> <pathvalid> <pathbest> <pathreoriginated> <pathdeleted> <pathstaled> <pathhistory>
<pathovermaxaslimit> <pathmultipath> <pathnolabeledrnh> <pathlocator> ] [ <importsourcen> [
<originalimportsourcen> ] ] [ <importdstscount> ] [ TABLE_importdsts <importdst> ] [ <existpath> ] [
<gwip> | <ipv6gwip> ] [ <aspath> <source> ] [ <ipnexthop> | <ipv6nexthop> ] <nexthopmetric> { <neighbor>
| <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras>
<atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> } ] [ {
TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflaps> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_sub_type> <psid_v6sid> <psid_func_len>
<psid_trans_len> <psid_trans_off> ] [ <psid_orsgrb_len> <psid_orsgrb_flag> <psid_orsgrb_base>
<psid_orsgrb_end> ] ] [ <remotenh> <remotenh_encap> <remotenh_vnid> <remotenh_mac> ] [ <pmsi> ]
[ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [ <tunnel-encap-attr-len> ] [ <mdt_grp_addr> ] [
TABLE_path_attr_list <path_attr_list> [ TABLE_attr <attr_num> <attr_code_str> <attr_code_hex> <attr_flags>
<attr_len> [ TABLE_attr_val <attr_value> ] ] ] [ <attrset_origin_as> <attrset_origin> <attrset_metric>
<attrset_localpref> [ <attrset_aspath> ] [ <attrset_originatorid> { TABLE_attrset_clusterlist <attrset_clusterlist>
} ] ] ] ] ] ] ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ] ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                              |
| bgp                       | Display BGP status and configuration                         |
| rd                        | (Optional) Display information for a route distinguisher     |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format |
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format           |
| vrf                       | (Optional) Virtual Router Context                            |
| <i>vrf-name</i>           | (Optional) VRF name  |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                                    |

|                      |  |
|----------------------|--|
| nexthop              | Display routes matching the nexthop                        |
| <i>ipnexthop</i>     | Nexthop address  |
| ipv4                 | Display BGP information for IPv4 address family            |
| ipv6                 | Display BGP information for IPv6 address family            |
| vpnv4                | Display BGP information for VPNv4 address family           |
| vpnv6                | Display BGP information for VPNv6 address family           |
| unicast              | Display BGP information for unicast address family         |
| multicast            | Display BGP information for multicast address family       |
| mdt                  | Display BGP information for multicast distribution tree    |
| link-state           | Display BGP information for link-state address family      |
| l2vpn                | Display BGP information for L2VPN address family           |
| vpls                 | Display BGP information for L2VPN VPLS address family      |
| evpn                 | Display BGP information for L2VPN EVPN address family      |
| mvpn                 | Display BGP information for MVPN address family            |
| labeled-unicast      | Display BGP information for labeled-unicast address family |
| <i>__readonly__</i>  | (Optional)   |
| TABLE_vrf            | (Optional)   |
| <i>vrf-name-out</i>  | (Optional)   |
| TABLE_afi            | (Optional)   |
| <i>afi</i>           | (Optional)   |
| TABLE_safi           | (Optional)   |
| <i>safi</i>          | (Optional)   |
| <i>af-name</i>       | (Optional)   |
| <i>table-version</i> | (Optional)   |
| <i>router-id</i>     | (Optional)   |
| TABLE_rd             | (Optional)   |
| <i>rd_val</i>        | (Optional)   |
| <i>rd_vrf</i>        | (Optional)   |
| <i>rd_vniid</i>      | (Optional)   |



|                           |            |
|---------------------------|------------|
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |
| <i>export-on-xmitlist</i> | (Optional) |
| <i>locallabel</i>         | (Optional) |
| <i>labelhldwstr</i>       | (Optional) |
| TABLE_path                | (Optional) |
| <i>pathnr</i>             | (Optional) |
| <i>best</i>               | (Optional) |
| <i>status</i>             | (Optional) |
| <i>type</i>               | (Optional) |
| <i>statuscode</i>         | (Optional) |
| <i>bestcode</i>           | (Optional) |
| <i>typecode</i>           | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_ <i>importdests</i>   | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |
| <i>pathstaled</i>           | (Optional) |
| <i>pathhistory</i>          | (Optional) |
| <i>pathmultipath</i>        | (Optional) |
| <i>pathovermaxaslimit</i>   | (Optional) |
| <i>pathnolabeledrn</i>      | (Optional) |
| <i>pathlocator</i>          | (Optional) |
| <i>nexthopmetric</i>        | (Optional) |
| <i>aggregator</i>           | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>aggregatoras</i>          | (Optional) |
| <i>atomicaggregate</i>       | (Optional) |
| <i>inlabel</i>               | (Optional) |
| <i>originflag</i>            | (Optional) |
| <i>vpn</i>                   | (Optional) |
| <i>hold_down</i>             | (Optional) |
| <i>outlabel</i>              | (Optional) |
| <i>flappenaity</i>           | (Optional) |
| <i>dampenedtime</i>          | (Optional) |
| <i>flaps</i>                 | (Optional) |
| <i>flaptime</i>              | (Optional) |
| <i>flapflags</i>             | (Optional) |
| <i>flapindex</i>             | (Optional) |
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>extcommunity</i>       | (Optional) |
| <i>originatorid</i>       | (Optional) |
| TABLE_clusterlist         | (Optional) |
| <i>clusterlist</i>        | (Optional) |
| <i>remotenh</i>           | (Optional) |
| <i>remotenh_encap</i>     | (Optional) |
| <i>remotenh_vnid</i>      | (Optional) |
| <i>remotenh_mac</i>       | (Optional) |
| <i>pmsi</i>               | (Optional) |
| <i>psid_len</i>           | (Optional) |
| <i>psid_lindx_len</i>     | (Optional) |
| <i>psid_lindx_flag</i>    | (Optional) |
| <i>psid_lindx</i>         | (Optional) |
| <i>psid_v6sid_len</i>     | (Optional) |
| <i>psid_sub_type</i>      | (Optional) |
| <i>psid_func_len</i>      | (Optional) |
| <i>psid_trans_len</i>     | (Optional) |
| <i>psid_trans_off</i>     | (Optional) |
| <i>psid_origsrgb_len</i>  | (Optional) |
| <i>psid_origsrgb_flag</i> | (Optional) |
| <i>psid_origsrgb_base</i> | (Optional) |
| <i>psid_origsrgb_end</i>  | (Optional) |
| TABLE_path_attr_list      | (Optional) |
| <i>path_attr_list</i>     | (Optional) |
| TABLE_attr                | (Optional) |
| <i>attr_num</i>           | (Optional) |
| <i>attr_code_str</i>      | (Optional) |
| <i>attr_code_hex</i>      | (Optional) |
| <i>attr_len</i>           | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { { { ipv4 { unicast
| multicast } | vpv4 unicast | ipv4 mdt | link-state | l2vpn vpls | l2vpn evpn | ipv4 mvpn } nexthop-database
[ <ipnexthop> ] } | { { ipv6 { unicast | multicast } | vpv6 unicast | ipv6 mvpn } nexthop-database [
<ip6nexthop> ] } | { all nexthop-database } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_nhvrif <nhvrif-name-out> TABLE_nhafi <nhafi>
TABLE_nhsafi <nhsafi> <af-name> <nhcriticaldelay> <nhnoncriticaldelay> [ { TABLE_nexthop {
<ipnexthop-out> | <ip6nexthop-out> } <refcount> <igpmetric> <multipath> <igptype> <igppref> [ {
TABLE_attachedhops { <attachedhop> | <ip6attachedhop> } <interface> [ { TABLE_labels <index> <label>
} ] } ] <attached> <local> <reachable> <labeled> <filtered> <suppressed> <resolvetime> { <ribroute> |
<ip6ribroute> } <pendingupdate> [ <pendingtime> ] <nextadvertise> <rnhepoch> [ <pendingrnhepoch> ]
} ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                         |
| bgp                   | Display BGP status and configuration                    |
| vrf                   | (Optional) Virtual Router Context                       |
| <i>vrf-name</i>       | (Optional) VRF name                                     |
| <i>vrf-known-name</i> | (Optional) Known VRF name                               |
| link-state            | Display BGP information for link-state address family   |
| l2vpn                 | Display BGP information for L2VPN address family        |
| vpls                  | Display BGP information for L2VPN VPLS address family   |
| nexthop-database      | Display nexthop database                                |
| ipv4                  | Display BGP information for IPv4 address family         |
| ipv6                  | Display BGP information for IPv6 address family         |
| vpnv4                 | Display BGP information for VPNv4 address family        |
| vpnv6                 | Display BGP information for VPNv6 address family        |
| mdt                   | Display BGP information for multicast distribution tree |
| mvpn                  | Display BGP information for MVPN address family         |
| evpn                  | Display BGP information for L2VPN EVPN address family   |
| unicast               | Display BGP information for unicast address family      |
| multicast             | Display BGP information for multicast address family    |
| all                   | Display BGP information for all address families        |

|                           |                            |
|---------------------------|----------------------------|
| <i>ipnexthop</i>          | (Optional) Nexthop address |
| <i>__readonly__</i>       | (Optional)                 |
| TABLE_nhvrf               | (Optional)                 |
| <i>nhvrf-name-out</i>     | (Optional)                 |
| TABLE_nhafi               | (Optional)                 |
| <i>nhafi</i>              | (Optional)                 |
| TABLE_nhsafi              | (Optional)                 |
| <i>nhsafi</i>             | (Optional)                 |
| <i>af-name</i>            | (Optional)                 |
| <i>nhcriticaldelay</i>    | (Optional)                 |
| <i>nhnoncriticaldelay</i> | (Optional)                 |
| TABLE_nexthop             | (Optional)                 |
| <i>ipnexthop-out</i>      | (Optional)                 |
| <i>refcount</i>           | (Optional)                 |
| <i>igpmetric</i>          | (Optional)                 |
| <i>multipath</i>          | (Optional)                 |
| <i>igptype</i>            | (Optional)                 |
| <i>igppref</i>            | (Optional)                 |
| TABLE_attachedhops        | (Optional)                 |
| <i>attachedhop</i>        | (Optional)                 |
| <i>interface</i>          | (Optional)                 |
| TABLE_labels              | (Optional)                 |
| <i>index</i>              | (Optional)                 |
| <i>label</i>              | (Optional)                 |
| <i>attached</i>           | (Optional)                 |
| <i>local</i>              | (Optional)                 |
| <i>reachable</i>          | (Optional)                 |
| <i>labeled</i>            | (Optional)                 |
| <i>filtered</i>           | (Optional)                 |

|                        |            |
|------------------------|------------|
| <i>suppressed</i>      | (Optional) |
| <i>resolvetime</i>     | (Optional) |
| <i>pendingupdate</i>   | (Optional) |
| <i>pendingtime</i>     | (Optional) |
| <i>ribroute</i>        | (Optional) |
| <i>nextadvertise</i>   | (Optional) |
| <i>rnhepoch</i>        | (Optional) |
| <i>pendingrnhepoch</i> | (Optional) |

**Command Mode**

- /exec





|                           |  |
|---------------------------|--|
| <i>refresh_interval</i>   | (Optional) refresh delay for bmp server                  |
| <i>stats_interval</i>     | (Optional) frequency of stat updates                     |
| <i>initiation</i>         | (Optional) number of initiation messages                 |
| <i>termination</i>        | (Optional) number of termination messages                |
| <i>peer_up</i>            | (Optional) number of peer up messages                    |
| <i>peer_down</i>          | (Optional) number of peer down messages                  |
| <i>route_monitor</i>      | (Optional) number of route monitor messages              |
| <i>route_mirror</i>       | (Optional) number of route mirror messages               |
| <i>stats</i>              | (Optional) number of stats messages                      |
| <i>messages_dropped</i>   | (Optional) number of dropped messages                    |
| <i>monitored_peers</i>    | (Optional) number of monitored peers for the bmp server  |
| TABLE_peer                | (Optional) monitored peer for the bmp server             |
| <i>peer_addr</i>          | (Optional) ip address of the peer                        |
| <i>refresh_interval</i>   | (Optional) refresh delay for the peer                    |
| <i>peer_up</i>            | (Optional) number of peer up messages for the peer       |
| <i>peer_down</i>          | (Optional) number of peer down messages for the peer     |
| <i>route_monitor</i>      | (Optional) number of route monitor messages for the peer |
| <i>route_mirror</i>       | (Optional) number of route mirror messages for the peer  |
| <i>stats</i>              | (Optional) number of stats messages for the peer         |
| <i>messages_dropped</i>   | (Optional) number of dropped messages for the peer       |
| <i>prefixes_denied</i>    | (Optional) prefixes denied for the peer                  |
| <i>dup_pfx_advmnt</i>     | (Optional) dup pfx advmnt for the peer                   |
| <i>pfx_dup_wdr_count</i>  | (Optional) pfx dup wdr count for the peer                |
| <i>cluster_list_loops</i> | (Optional) cluster list loops for the peer               |
| <i>as_path_loops</i>      | (Optional) as path loops for the peer                    |
| <i>as_confed_loops</i>    | (Optional) as confed loops for the peer                  |
| <i>invalid_originator</i> | (Optional) invalid originator for the peer               |
| <i>adj_rib_in</i>         | (Optional) adj-rib-in for the peer                       |
| <i>loc-rib</i>            | (Optional) loc-rib for the peer                          |

**Command Mode**

- /exec

# show bgp community

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ]
| vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } community {
<regexp-str> | { { <comm-id> | <wellknown-id> } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name>
| ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi>
TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [
<rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths>
<bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <table-map-filtered>
] [ <export-on-newlist> <export-on-xmitlist> ] [ <srv6-local-sid> ] [ <locallabel> ] [ <labelhlidwstr> ] [
<mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> {
<ipnexthop> | <ipv6nexthop> } } { <inlabel> <outlabel> <vpn> <hold_down> } } { <weight> <aspath>
<origin> [ <metric> ] [ <localpref> ] } } } [ <policyincomplete> <pathvalid> <pathbest> <pathreoriginated>
<pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath> <pathnolabelednrh>
<pathlocator> ] [ <importsource> [ <originalimportsource> ] ] [ <importdestscount> ] [ TABLE_importdests
<importdest> ] [ <existpath> ] [ <gwip> | <ipv6gwip> ] [ <aspath> <source> ] [ <ipnexthop> | <ipv6nexthop>
] <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight>
[ <aggregator> <aggregators> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community
<community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist
<clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife>
<flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [
<psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_sub_type> <psid_v6sid>
<psid_func_len> <psid_trans_len> <psid_trans_off> ] [ <psid_orsrgb_len> <psid_orsrgb_flag>
<psid_orsrgb_base> <psid_orsrgb_end> ] ] [ <remotenh> <remotenh_encap> <remotenh_vnid>
<remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [ <tunnel-encap-attr-len>
] [ <mdt_grp_addr> ] [ TABLE_path_attr_list <path_attr_list> [ TABLE_attr <attr_num> <attr_code_str>
<attr_code_hex> <attr_flags> <attr_len> [ TABLE_attr_val <attr_value> ] ] ] [ <attrset_origin_as>
<attrset_origin> <attrset_metric> <attrset_localpref> [ <attrset_aspath> ] [ <attrset_originatorid> {
TABLE_attrset_clusterlist <attrset_clusterlist> } ] ] } ] [ TABLE_advertisedto <advertisedto> ] [
TABLE_scheduledto <scheduledto> ] ] ] ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                              |
| bgp                       | Display BGP status and configuration                         |
| vrf                       | (Optional) Virtual Router Context                            |
| <i>vrf-name</i>           | (Optional) VRF name  |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                                    |
| rd                        | (Optional) Display information for a route distinguisher     |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format |

|                           |  |
|---------------------------|--|
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format         |
| ipv4                      | Display BGP information for IPv4 address family            |
| ipv6                      | Display BGP information for IPv6 address family            |
| vpnv4                     | Display BGP information for VPNv4 address family           |
| vpnv6                     | Display BGP information for VPNv6 address family           |
| unicast                   | Display BGP information for unicast address family         |
| multicast                 | Display BGP information for multicast address family       |
| mdt                       | Display BGP information for multicast distribution tree    |
| link-state                | Display BGP information for link-state address family      |
| l2vpn                     | Display BGP information for L2VPN address family           |
| vpls                      | Display BGP information for L2VPN VPLS address family      |
| labeled-unicast           | Display BGP information for labeled-unicast address family |
| mvpn                      | Display BGP information for MVPN address family            |
| evpn                      | Display BGP information for L2VPN EVPN address family      |
| all                       | Display BGP information for all address families           |
| community                 | Display routes matching the BGP communities                |
| <i>regexp-str</i>         | Regular expression to match the communities                |
| <i>comm-id</i>            | BGP community value  |
| <i>wellknown-id</i>       | BGP wellknown community                                    |
| exact-match               | (Optional) Exact match of the communities                  |
| __readonly__              | (Optional)   |
| TABLE_vrf                 | (Optional)   |
| <i>vrf-name-out</i>       | (Optional)   |
| TABLE_afi                 | (Optional)   |
| <i>afi</i>                | (Optional)   |
| TABLE_safi                | (Optional)   |
| <i>safi</i>               | (Optional)   |
| <i>af-name</i>            | (Optional)   |
| <i>table-version</i>      | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>router-id</i>          | (Optional) |
| TABLE_rd                  | (Optional) |
| <i>rd_val</i>             | (Optional) |
| <i>rd_vrf</i>             | (Optional) |
| <i>rd_vniid</i>           | (Optional) |
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |
| <i>export-on-xmitlist</i> | (Optional) |
| <i>locallabel</i>         | (Optional) |
| <i>labelhldwstr</i>       | (Optional) |
| TABLE_path                | (Optional) |
| <i>pathnr</i>             | (Optional) |
| <i>best</i>               | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>status</i>               | (Optional) |
| <i>type</i>                 | (Optional) |
| <i>statuscode</i>           | (Optional) |
| <i>bestcode</i>             | (Optional) |
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |
| <i>pathstaled</i>           | (Optional) |
| <i>pathhistory</i>          | (Optional) |
| <i>pathmultipath</i>        | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappentalty</i>       | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |
| <i>flaphalflife</i>       | (Optional) |
| <i>flapreuse</i>          | (Optional) |
| <i>flapsuppress</i>       | (Optional) |
| <i>flapmax</i>            | (Optional) |
| <i>con_type</i>           | (Optional) |
| <i>con_len</i>            | (Optional) |
| <i>con_rd</i>             | (Optional) |
| <i>con_ip</i>             | (Optional) |
| <i>mdt_grp_addr</i>       | (Optional) |
| <i>evpn-esi</i>           | (Optional) |
| <i>link-state-attr</i>    | (Optional) |



|                              |            |
|------------------------------|------------|
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |
| <i>psid_v6sid_len</i>        | (Optional) |
| <i>psid_sub_type</i>         | (Optional) |
| <i>psid_func_len</i>         | (Optional) |
| <i>psid_trans_len</i>        | (Optional) |
| <i>psid_trans_off</i>        | (Optional) |
| <i>psid_origsrgb_len</i>     | (Optional) |
| <i>psid_origsrgb_flag</i>    | (Optional) |
| <i>psid_origsrgb_base</i>    | (Optional) |
| <i>psid_origsrgb_end</i>     | (Optional) |
| TABLE_path_attr_list         | (Optional) |
| <i>path_attr_list</i>        | (Optional) |

|                             |            |
|-----------------------------|------------|
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp convergence

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] convergence [ detail
] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ <starttime>
<configdonetime> <juststarted> [ <initwaittime> ] [ <ldpconverged> ] [ <ulibconvergenesent> ] [ TABLE_vrf
<vrf-name-out> <bestpathtimeout> <configuredtimeout> <updatedelay> [ <firstpeerup> ] <timerrunning> [
<timerexpires> ] [ TABLE_afi <afi> TABLE_safi <safi> <af-name> <total_configured_peers>
<total_capable_peers> <firstbestpathsignalled> [ <firstbestpathsignalledtime> ] <firstbestpathdone> [
<firstbestpathdonetime> [ <lastbestpathsignalledtime> <lastbestpathdonetime> ] ] [ <riblicconvergenesent>
] [ <importtimerrunning> ] [ <importtimerexpires> ] [ { TABLE_rcvdpeers [ <peer> ] [ <ipv6peer> ] [
<signalledtimepeer> ] [ <interface-parent> ] } ] [ { TABLE_notrcvdpeers [ <notpeer> ] [ <notipv6peer> ] [
<nokeepalive> ] [ <notsignalledtime> ] } ] ] ] ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information                           |
| bgp                           | Display BGP status and configuration                      |
| vrf                           | (Optional) Virtual Router Context                         |
| <i>vrf-name</i>               | (Optional) VRF name                                       |
| <i>vrf-known-name</i>         | (Optional) Known VRF name                                 |
| convergence                   | Display information about convergence                     |
| detail                        | (Optional) Display detailed information about convergence |
| __readonly__                  | (Optional)  |
| <i>starttime</i>              | (Optional)  |
| <i>configdonetime</i>         | (Optional)  |
| <i>juststarted</i>            | (Optional)  |
| <i>initwaittime</i>           | (Optional)  |
| <i>ldpconverged</i>           | (Optional)  |
| <i>ulibconvergenesent</i>     | (Optional)  |
| TABLE_vrf                     | (Optional)  |
| <i>total_configured_peers</i> | (Optional)  |
| <i>total_capable_peers</i>    | (Optional)  |
| <i>vrf-name-out</i>           | (Optional)  |
| <i>bestpathtimeout</i>        | (Optional)  |
| <i>configuredtimeout</i>      | (Optional)  |

|                                   |            |
|-----------------------------------|------------|
| <i>updatedelay</i>                | (Optional) |
| <i>firstpeerup</i>                | (Optional) |
| <i>timerrunning</i>               | (Optional) |
| <i>timerexpires</i>               | (Optional) |
| TABLE_afi                         | (Optional) |
| <i>afi</i>                        | (Optional) |
| TABLE_safi                        | (Optional) |
| <i>safi</i>                       | (Optional) |
| <i>af-name</i>                    | (Optional) |
| <i>firstbestpathsignalled</i>     | (Optional) |
| <i>firstbestpathsignalledtime</i> | (Optional) |
| <i>firstbestpathdone</i>          | (Optional) |
| <i>firstbestpathdonetime</i>      | (Optional) |
| <i>lastbestpathsignalledtime</i>  | (Optional) |
| <i>lastbestpathdonetime</i>       | (Optional) |
| <i>ribbibconvergencesent</i>      | (Optional) |
| <i>importtimerrunning</i>         | (Optional) |
| <i>importtimerexpires</i>         | (Optional) |
| TABLE_rcvdpeers                   | (Optional) |
| <i>peer</i>                       | (Optional) |
| <i>signalledtimepeer</i>          | (Optional) |
| <i>interface-parent</i>           | (Optional) |
| TABLE_notrcvdpeers                | (Optional) |
| <i>notpeer</i>                    | (Optional) |
| <i>nokeepalive</i>                | (Optional) |
| <i>notsignalledtime</i>           | (Optional) |

**Command Mode**

- /exec

# show bgp dampening dampened

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpvnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpvnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } dampening {
dampened-paths [ regexp <regexp-str> ] | history-paths [ regexp <regexp-str> } ] [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out>
TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [
<rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } ] [ <prefixversion>
<totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [
<table-map-filtered> ] [ <export-on-newlist> <export-on-xmitlist> ] [ <srv6-local-sid> ] [ <locallabel> ] [
<labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode>
<typecode> { <ipnexthop> | <ipv6nexthop> } } { <inlabel> <outlabel> <vpn> <hold_down> } | { <weight>
<aspath> <origin> [ <metric> ] [ <localpref> ] } } | [ <policyincomplete> <pathvalid> <pathbest>
<patheoriginated> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath>
<pathnolabeledrn> <pathlocator> ] [ <importsource> [ <originalimportsource> ] ] [ <importdestscount> ] [
TABLE_importdests <importdest> ] [ <existpath> ] [ <gwip> | <ipv6gwip> ] [ <aspath> <source> ] {
<ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin>
[ <metric> ] <localpref> <weight> [ <aggregator> <aggregatoras> <atomicaggregate> ] [ <inlabel> ] [
<originflag> ] [ { TABLE_community <community> } ] [ { TABLE_extcommunity <extcommunity> } ] [
<originatorid> { TABLE_clusterlist <clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime>
<flapflags> <flapindex> <flaphalf-life> <flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len>
<con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len>
<psid_sub_type> <psid_v6sid> <psid_func_len> <psid_trans_len> <psid_trans_off> ] [ <psid_orsrgb_len>
<psid_orsrgb_flag> <psid_orsrgb_base> <psid_orsrgb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<tunnel-encap-attr-len> ] [ <mdt_grp_addr> ] [ TABLE_path_attr_list <path_attr_list> [ TABLE_attr
<attr_num> <attr_code_str> <attr_code_hex> <attr_flags> <attr_len> [ TABLE_attr_val <attr_value> ] ] ] [
<attrset_origin_as> <attrset_origin> <attrset_metric> <attrset_localpref> [ <attrset_aspath> ] [
<attrset_originatorid> { TABLE_attrset_clusterlist <attrset_clusterlist> } ] ] ] ] [ TABLE_advertisedto
<advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ] ]
```

## Syntax Description

|                       |                                      |
|-----------------------|--------------------------------------|
| show                  | Show running system information      |
| bgp                   | Display BGP status and configuration |
| vrf                   | (Optional) Virtual Router Context    |
| <i>vrf-name</i>       | (Optional) VRF name                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name            |
| dampened-paths        | Display all dampened paths           |
| history-paths         | Display all history paths            |

|                           |   |
|---------------------------|---|
| dampening                 | Display dampening info  |
| rd                        | (Optional) Display information for a route distinguisher          |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format      |
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format                |
| ipv4                      | Display BGP information for IPv4 address family                   |
| ipv6                      | Display BGP information for IPv6 address family                   |
| vpn4                      | Display BGP information for VPNv4 address family                  |
| vpn6                      | Display BGP information for VPNv6 address family                  |
| unicast                   | Display BGP information for unicast address family                |
| multicast                 | Display BGP information for multicast address family              |
| mdt                       | Display BGP information for multicast distribution tree           |
| labeled-unicast           | Display BGP information for labeled-unicast address family        |
| link-state                | Display BGP information for link-state address family             |
| l2vpn                     | Display BGP information for L2VPN address family                  |
| vpls                      | Display BGP information for L2VPN VPLS address family             |
| mvpn                      | Display BGP information for MVPN address family                   |
| evpn                      | Display BGP information for L2VPN EVPN address family             |
| all                       | Display BGP information for all address families                  |
| regexp                    | (Optional) Display routes matching the AS path regular expression |
| <i>regexp-str</i>         | (Optional) Regular expression to match the AS paths               |
| __readonly__              | (Optional)  |
| TABLE_vrf                 | (Optional)  |
| <i>vrf-name-out</i>       | (Optional)  |
| TABLE_afi                 | (Optional)  |
| <i>afi</i>                | (Optional)  |
| TABLE_safi                | (Optional)  |
| <i>safi</i>               | (Optional)  |
| <i>af-name</i>            | (Optional)  |
| <i>table-version</i>      | (Optional)  |

|                           |            |
|---------------------------|------------|
| <i>router-id</i>          | (Optional) |
| TABLE_rd                  | (Optional) |
| <i>rd_val</i>             | (Optional) |
| <i>rd_vrf</i>             | (Optional) |
| <i>rd_vniid</i>           | (Optional) |
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |
| <i>export-on-xmitlist</i> | (Optional) |
| <i>locallabel</i>         | (Optional) |
| <i>labelhldwstr</i>       | (Optional) |
| TABLE_path                | (Optional) |
| <i>pathnr</i>             | (Optional) |
| <i>best</i>               | (Optional) |

|                            |            |
|----------------------------|------------|
| <i>status</i>              | (Optional) |
| <i>type</i>                | (Optional) |
| <i>statuscode</i>          | (Optional) |
| <i>bestcode</i>            | (Optional) |
| <i>typecode</i>            | (Optional) |
| <i>ipnexthop</i>           | (Optional) |
| <i>neighbor</i>            | (Optional) |
| <i>neighborid</i>          | (Optional) |
| <i>metric</i>              | (Optional) |
| <i>localpref</i>           | (Optional) |
| <i>weight</i>              | (Optional) |
| <i>importsourc</i>         | (Optional) |
| <i>originalimportsourc</i> | (Optional) |
| <i>importdestscount</i>    | (Optional) |
| TABLE_importdests          | (Optional) |
| <i>importdest</i>          | (Optional) |
| <i>existpath</i>           | (Optional) |
| <i>gwip</i>                | (Optional) |
| <i>aspath</i>              | (Optional) |
| <i>origin</i>              | (Optional) |
| <i>source</i>              | (Optional) |
| <i>policyincomplete</i>    | (Optional) |
| <i>pathvalid</i>           | (Optional) |
| <i>pathbest</i>            | (Optional) |
| <i>pathreoriginated</i>    | (Optional) |
| <i>pathdeleted</i>         | (Optional) |
| <i>pathstaled</i>          | (Optional) |
| <i>pathhistory</i>         | (Optional) |
| <i>pathmultipath</i>       | (Optional) |



|                           |            |
|---------------------------|------------|
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappenaity</i>        | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |
| <i>flaphalflife</i>       | (Optional) |
| <i>flapreuse</i>          | (Optional) |
| <i>flapsuppress</i>       | (Optional) |
| <i>flapmax</i>            | (Optional) |
| <i>con_type</i>           | (Optional) |
| <i>con_len</i>            | (Optional) |
| <i>con_rd</i>             | (Optional) |
| <i>con_ip</i>             | (Optional) |
| <i>mdt_grp_addr</i>       | (Optional) |
| <i>evpn-esi</i>           | (Optional) |
| <i>link-state-attr</i>    | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |
| <i>psid_v6sid_len</i>        | (Optional) |
| <i>psid_sub_type</i>         | (Optional) |
| <i>psid_func_len</i>         | (Optional) |
| <i>psid_trans_len</i>        | (Optional) |
| <i>psid_trans_off</i>        | (Optional) |
| <i>psid_origsrgb_len</i>     | (Optional) |
| <i>psid_origsrgb_flag</i>    | (Optional) |
| <i>psid_origsrgb_base</i>    | (Optional) |
| <i>psid_origsrgb_end</i>     | (Optional) |
| TABLE_path_attr_list         | (Optional) |
| <i>path_attr_list</i>        | (Optional) |

|                             |            |
|-----------------------------|------------|
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec



|                            |   |
|----------------------------|---|
| <code>l2vpn</code>         | Display BGP information for L2VPN address family      |
| <code>vpls</code>          | Display BGP information for L2VPN VPLS address family |
| <code>mvpn</code>          | Display BGP information for MVPN address family       |
| <code>evpn</code>          | Display BGP information for L2VPN EVPN address family |
| <code>all</code>           | Display BGP information for all address families      |
| <code>__readonly__</code>  | (Optional)  |
| <code>TABLE_vrf</code>     | (Optional)  |
| <code>vrf-name-out</code>  | (Optional)  |
| <code>TABLE_afi</code>     | (Optional)  |
| <code>afi</code>           | (Optional)  |
| <code>TABLE_safi</code>    | (Optional)  |
| <code>safi</code>          | (Optional)  |
| <code>af-name</code>       | (Optional)  |
| <code>TABLE_rd</code>      | (Optional)  |
| <code>rd_val</code>        | (Optional)  |
| <code>rd_vrf</code>        | (Optional)  |
| <code>rd_vniid</code>      | (Optional)  |
| <code>dampening</code>     | (Optional)  |
| <code>historypaths</code>  | (Optional)  |
| <code>dampenedpaths</code> | (Optional)  |
| <code>TABLE_prefix</code>  | (Optional)  |
| <code>ipprefix</code>      | (Optional)  |
| <code>nonipprefix</code>   | (Optional)  |
| <code>status</code>        | (Optional)  |
| <code>best</code>          | (Optional)  |
| <code>pathtype</code>      | (Optional)  |
| <code>peer</code>          | (Optional)  |
| <code>flapcount</code>     | (Optional)  |
| <code>duration</code>      | (Optional)  |

|                      |            |
|----------------------|------------|
| <i>reuse</i>         | (Optional) |
| <i>penalty</i>       | (Optional) |
| <i>suppresslimit</i> | (Optional) |
| <i>reuselimit</i>    | (Optional) |

**Command Mode**

- /exec

## show bgp dampening parameters

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } dampening
parameters [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__
TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ TABLE_rd [ <rd_val> ] [
<rd_vrf> ] [ <rd_vniid> ] [ <rpmname> ] [ TABLE_rpm <rpmindex> <rpmdamphalflife> <rpm dampsuppress>
<rpm dampreuse> <rpm dampsuppress> <rpm dampmaxpenalty> ] [ <dampconfigured> <damp halflife>
<damp suppress> <damp reuse> <damp suppress time> <damp maxpenalty> ] ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                              |
| bgp                       | Display BGP status and configuration                         |
| vrf                       | (Optional) Virtual Router Context                            |
| <i>vrf-name</i>           | (Optional) VRF name  |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                                    |
| dampening                 | Display dampening info                                       |
| parameters                | Display dampening parameters                                 |
| rd                        | (Optional) Display information for a route distinguisher     |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format |
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format           |
| ipv4                      | Display BGP information for IPv4 address family              |
| ipv6                      | Display BGP information for IPv6 address family              |
| vpv4                      | Display BGP information for VPNv4 address family             |
| vpv6                      | Display BGP information for VPNv6 address family             |
| unicast                   | Display BGP information for unicast address family           |
| multicast                 | Display BGP information for multicast address family         |
| mdt                       | Display BGP information for multicast distribution tree      |
| labeled-unicast           | Display BGP information for labeled-unicast address family   |
| link-state                | Display BGP information for link-state address family        |

|                            |   |
|----------------------------|---|
| l2vpn                      | Display BGP information for L2VPN address family      |
| vpls                       | Display BGP information for L2VPN VPLS address family |
| mvpn                       | Display BGP information for MVPN address family       |
| evpn                       | Display BGP information for L2VPN EVPN address family |
| all                        | Display BGP information for all address families      |
| __readonly__               | (Optional)  |
| TABLE_vrf                  | (Optional)  |
| <i>vrf-name-out</i>        | (Optional)  |
| TABLE_afi                  | (Optional)  |
| <i>afi</i>                 | (Optional)  |
| TABLE_safi                 | (Optional)  |
| <i>safi</i>                | (Optional)  |
| <i>af-name</i>             | (Optional)  |
| TABLE_rd                   | (Optional)  |
| <i>rd_val</i>              | (Optional)  |
| <i>rd_vrf</i>              | (Optional) VRF RD                                     |
| <i>rd_vniid</i>            | (Optional)  |
| TABLE_rpm                  | (Optional)  |
| <i>rpmname</i>             | (Optional)  |
| <i>rpmindex</i>            | (Optional)  |
| <i>rpmdamphalflife</i>     | (Optional)  |
| <i>rpmdampsuppress</i>     | (Optional)  |
| <i>rpmdampreuse</i>        | (Optional)  |
| <i>rpmdampsuppresstime</i> | (Optional)  |
| <i>rpmdampmaxpenalty</i>   | (Optional)  |
| <i>dampconfigured</i>      | (Optional)  |
| <i>damphalflife</i>        | (Optional)  |
| <i>dampsuppress</i>        | (Optional)  |
| <i>dampreuse</i>           | (Optional)  |



|                         |            |
|-------------------------|------------|
| <i>dampsuppresstime</i> | (Optional) |
| <i>dampmaxpenalty</i>   | (Optional) |

**Command Mode**

- /exec

## show bgp evi

```
show bgp evi [ <evi-id> ] [ __readonly__ [ TABLE_ctx <evvid> <rd> [ <secondaryrd> ] <numlocalprefixes>
<numtotalprefixes> <created> <lastoperup> <lastoperdown> <enabled> [ <associatedvrf> ] [
TABLE_activeexportrts <exportrt> ] [ TABLE_activeimportrts <importrt> ] [ TABLE_evpnactiveexportrts
<evpnexportrt> ] [ TABLE_evpnactiveimportrts <evpnimportrt> ] [ TABLE_mvnpactiveexportrts
<mvpnexportrt> ] [ TABLE_mvnpactiveimportrts <mvpnimportrt> ] [ TABLE_activeexportrtsv6 <exportrtv6>
] [ TABLE_activeimportrtsv6 <importrtv6> ] [ TABLE_evpnactiveexportrtsv6 <evpnexportrtv6> ] [
TABLE_evpnactiveimportrtsv6 <evpnimportrtv6> ] [ TABLE_mvnpactiveexportrtsv6 <mvpnexportrtv6> ]
[ TABLE_mvnpactiveimportrtsv6 <mvpnimportrtv6> ] ] ] ]
```

### Syntax Description

|                                  |  |
|----------------------------------|--|
| show                             | Show running system information        |
| bgp                              | Display BGP status and configuration   |
| evi                              | Display information about EVI database |
| <i>evi-id</i>                    | (Optional) EVI Id                      |
| <i>__readonly__</i>              | (Optional)                             |
| <i>TABLE_ctx</i>                 | (Optional)                             |
| <i>evvid</i>                     | (Optional)                             |
| <i>rd</i>                        | (Optional)                             |
| <i>secondaryrd</i>               | (Optional)                             |
| <i>numlocalprefixes</i>          | (Optional)                             |
| <i>numtotalprefixes</i>          | (Optional)                             |
| <i>created</i>                   | (Optional)                             |
| <i>lastoperup</i>                | (Optional)                             |
| <i>lastoperdown</i>              | (Optional)                             |
| <i>enabled</i>                   | (Optional)                             |
| <i>associatedvrf</i>             | (Optional)                             |
| <i>TABLE_activeexportrts</i>     | (Optional)                             |
| <i>TABLE_activeimportrts</i>     | (Optional)                             |
| <i>TABLE_evpnactiveexportrts</i> | (Optional)                             |
| <i>TABLE_evpnactiveimportrts</i> | (Optional)                             |
| <i>TABLE_mvnpactiveexportrts</i> | (Optional)                             |

|                             |            |
|-----------------------------|------------|
| TABLE_mvpnactiveimportrts   | (Optional) |
| TABLE_activeexportrtsv6     | (Optional) |
| TABLE_activeimportrtsv6     | (Optional) |
| TABLE_evpnactiveexportrtsv6 | (Optional) |
| TABLE_evpnactiveimportrtsv6 | (Optional) |
| TABLE_mvpnactiveexportrtsv6 | (Optional) |
| TABLE_mvpnactiveimportrtsv6 | (Optional) |
| <i>importrt</i>             | (Optional) |
| <i>exportrt</i>             | (Optional) |
| <i>evpnimportrt</i>         | (Optional) |
| <i>evpnexportrt</i>         | (Optional) |
| <i>mvpnimportrt</i>         | (Optional) |
| <i>mvpnexportrt</i>         | (Optional) |
| <i>importrtv6</i>           | (Optional) |
| <i>exportrtv6</i>           | (Optional) |
| <i>evpnimportrtv6</i>       | (Optional) |
| <i>evpnexportrtv6</i>       | (Optional) |
| <i>mvpnimportrtv6</i>       | (Optional) |
| <i>mvpnexportrtv6</i>       | (Optional) |

**Command Mode**

- /exec

## show bgp extcommunity

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | ipv4 mdt [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> }
] | vpnv4 unicast [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | vpnv6 unicast [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv6 labeled-unicast | link-state | l2vpn vpls [ rd {
<ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 mvpn [ rd { <ext-comm-rd-aa2nn4> |
<ext-comm-rd-aa4nn2> } ] | ipv6 mvpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | l2vpn
evpn [ rd { <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] | ipv4 labeled-unicast | all } extcommunity
{ <regex-str> | { { 4byteas-generic { transitive <ext-comm-gen-trans> | non-transitive
<ext-comm-gen-nontrans> } } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi> TABLE_safi
<safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [ <rd_vniid> ] ] [
TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths> <bestpathnr> [
<on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <table-map-filtered> ] [
<export-on-newlist> <export-on-xmitlist> ] [ <srv6-local-sid> ] [ <locallabel> ] [ <labelhldwstr> ] [ <mpath>
] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> { <ipnexthop>
| <ipv6nexthop> } } { <inlabel> <outlabel> <vpn> <hold_down> } | { <weight> <aspath> <origin> [ <metric>
] [ <localpref> ] } } } | { [ <policyincomplete> <pathvalid> <pathbest> <pathreoriginated> <pathdeleted>
<pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath> <pathnolabeledrn> <pathlocator> ] [
<importsource> [ <originalimportsource> ] ] [ <importdestscount> ] [ TABLE_importdests <importdest> ] [
<existpath> ] [ <gwip> | <ipv6gwip> ] [ <aspath> <source> ] [ <ipnexthop> | <ipv6nexthop> ] <nexthopmetric>
{ <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight> [ <aggregator>
<aggregatoras> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community <community> }
] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist <clusterlist> } ] [
<flappenalty> <dampenedtime> <flaps> <flaptime> <flapflaps> <flapindex> <flaphalflife> <flapreuse>
<flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len>
<psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_sub_type> <psid_v6sid> <psid_func_len>
<psid_trans_len> <psid_trans_off> ] [ <psid_origsrgrb_len> <psid_origsrgrb_flag> <psid_origsrgrb_base>
<psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap> <remotenh_vnid> <remotenh_mac> ] [ <pmsi> ]
[ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [ <tunnel-encap-attr-len> ] [ <mdt_grp_addr> ] [
TABLE_path_attr_list <path_attr_list> [ TABLE_attr <attr_num> <attr_code_str> <attr_code_hex> <attr_flags>
<attr_len> [ TABLE_attr_val <attr_value> ] ] ] [ <attrset_origin_as> <attrset_origin> <attrset_metric>
<attrset_localpref> [ <attrset_aspath> ] [ <attrset_originatorid> { TABLE_attrset_clusterlist <attrset_clusterlist>
} ] ] } } ] [ TABLE_advertisedto <advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                              |
| bgp                       | Display BGP status and configuration                         |
| vrf                       | (Optional) Virtual Router Context                            |
| <i>vrf-name</i>           | (Optional) VRF name  |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                                    |
| rd                        | (Optional) Display information for a route distinguisher     |
| <i>ext-comm-rd-aa4nn2</i> | (Optional) VPN route distinguisher in aa4:nn or ip:nn format |

|                              |  |
|------------------------------|--|
| <i>ext-comm-rd-aa2nn4</i>    | (Optional) VPN route distinguisher in aa:nn format         |
| ipv4                         | Display BGP information for IPv4 address family            |
| ipv6                         | Display BGP information for IPv6 address family            |
| vpnv4                        | Display BGP information for VPNv4 address family           |
| vpnv6                        | Display BGP information for VPNv6 address family           |
| unicast                      | Display BGP information for unicast address family         |
| multicast                    | Display BGP information for multicast address family       |
| mdt                          | Display BGP information for multicast distribution tree    |
| link-state                   | Display BGP information for link-state address family      |
| labeled-unicast              | Display BGP information for labeled-unicast address family |
| l2vpn                        | Display BGP information for L2VPN address family           |
| vpls                         | Display BGP information for L2VPN VPLS address family      |
| mvpn                         | Display BGP information for MVPN address family            |
| evpn                         | Display BGP information for L2VPN EVPN address family      |
| all                          | Display BGP information for all address families           |
| extcommunity                 | Display routes matching the BGP extcommunities             |
| 4byteas-generic              | Generic extended community                                 |
| <i>regexp-str</i>            | Regular expression to match the extcommunities             |
| transitive                   | Transitive extcommunity                                    |
| non-transitive               | Non-Transitive extcommunity                                |
| <i>ext-comm-gen-trans</i>    | Extcommunity number aa4:nn format                          |
| <i>ext-comm-gen-nontrans</i> | Extcommunity number aa4:nn format                          |
| exact-match                  | (Optional) Exact match of the extcommunities               |
| <i>__readonly__</i>          | (Optional)   |
| TABLE_vrf                    | (Optional)   |
| <i>vrf-name-out</i>          | (Optional)   |
| TABLE_afi                    | (Optional)   |
| <i>afi</i>                   | (Optional)   |
| TABLE_safi                   | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>safi</i>               | (Optional) |
| <i>af-name</i>            | (Optional) |
| <i>table-version</i>      | (Optional) |
| <i>router-id</i>          | (Optional) |
| TABLE_rd                  | (Optional) |
| <i>rd_val</i>             | (Optional) |
| <i>rd_vrf</i>             | (Optional) |
| <i>rd_vniid</i>           | (Optional) |
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |
| <i>export-on-xmitlist</i> | (Optional) |
| <i>locallabel</i>         | (Optional) |
| <i>labelhldwstr</i>       | (Optional) |

|                             |            |
|-----------------------------|------------|
| TABLE_path                  | (Optional) |
| <i>pathnr</i>               | (Optional) |
| <i>best</i>                 | (Optional) |
| <i>status</i>               | (Optional) |
| <i>type</i>                 | (Optional) |
| <i>statuscode</i>           | (Optional) |
| <i>bestcode</i>             | (Optional) |
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>pathstaled</i>         | (Optional) |
| <i>pathhistory</i>        | (Optional) |
| <i>pathmultipath</i>      | (Optional) |
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappenalty</i>        | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |
| <i>flaphalflife</i>       | (Optional) |
| <i>flapreuse</i>          | (Optional) |
| <i>flapsuppress</i>       | (Optional) |
| <i>flapmax</i>            | (Optional) |
| <i>con_type</i>           | (Optional) |
| <i>con_len</i>            | (Optional) |
| <i>con_rd</i>             | (Optional) |
| <i>con_ip</i>             | (Optional) |



|                              |            |
|------------------------------|------------|
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |
| <i>psid_v6sid_len</i>        | (Optional) |
| <i>psid_sub_type</i>         | (Optional) |
| <i>psid_func_len</i>         | (Optional) |
| <i>psid_trans_len</i>        | (Optional) |
| <i>psid_trans_off</i>        | (Optional) |
| <i>psid_origsrgb_len</i>     | (Optional) |
| <i>psid_origsrgb_flag</i>    | (Optional) |
| <i>psid_origsrgb_base</i>    | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>psid_origsrgb_end</i>    | (Optional) |
| TABLE_path_attr_list        | (Optional) |
| <i>path_attr_list</i>       | (Optional) |
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp l3vpn

```
show bgp l3vpn [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [
__readonly__ TABLE_vrf <vrf-name-out> [ <vrf-id> ] [ <vrf-rd> ] [ <vrf-state> ] [ <vrf-state-rsn> ] [
<vrf-pending-rd> ] [ { TABLE_af <af-id> [ <af-name> ] [ <af-table-id> ] [ <af-state> ] [ <af-state-rsn> ] [
<af-num-peers> ] [ <af-num-active-peers> ] [ <af-peer-routes> ] [ <af-peer-paths> ] [ <af-peer-networks> ]
[ <af-peer-aggregates> ] [ <af-export-rmap> ] [ <af-import-rmap> ] [ <af-retain-rt> ] [ TABLE_export_rt
<export-rt> ] [ TABLE_import_rt <import-rt> ] [ TABLE_evpn_export_rt <evpn-export-rt> ] [
TABLE_evpn_import_rt <evpn-import-rt> ] [ TABLE_mvpn_export_rt <mvpn-export-rt> ] [
TABLE_mvpn_import_rt <mvpn-import-rt> ] [ <af-label-mode> ] [ <af-aggregate-label> } ] ] ]
```

### Syntax Description

|                       |                                      |
|-----------------------|--------------------------------------|
| show                  | Show running system information      |
| bgp                   | Display BGP status and configuration |
| l3vpn                 | BGP l3vpn information                |
| vrf                   | (Optional) Virtual Router Context    |
| detail                | (Optional) Detailed information      |
| <i>vrf-name</i>       | (Optional) VRF name                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name            |
| <i>__readonly__</i>   | (Optional) Read Only                 |
| TABLE_vrf             | (Optional)                           |
| <i>vrf-name-out</i>   | (Optional) VRF name                  |
| <i>vrf-id</i>         | (Optional) VRF ID                    |
| <i>vrf-state</i>      | (Optional) VRF State                 |
| <i>vrf-state-rsn</i>  | (Optional) VRF State Reason          |
| <i>vrf-rd</i>         | (Optional) VRF RD                    |
| <i>vrf-pending-rd</i> | (Optional) VRF pending RD            |
| TABLE_af              | (Optional)                           |
| <i>af-id</i>          | (Optional) AF ID                     |
| <i>af-table-id</i>    | (Optional) AF table                  |
| <i>af-name</i>        | (Optional) AF table name             |
| <i>af-state</i>       | (Optional) AF table state            |
| <i>af-state-rsn</i>   | (Optional) AF table state reason     |

|                            |                                     |
|----------------------------|-------------------------------------|
| <i>af-num-peers</i>        | (Optional) No. of peers             |
| <i>af-num-active-peers</i> | (Optional) No. of active peers      |
| <i>af-peer-routes</i>      | (Optional) No. of peer routes       |
| <i>af-peer-paths</i>       | (Optional) No. of peer paths        |
| <i>af-peer-networks</i>    | (Optional) No. of peer networks     |
| <i>af-peer-aggregates</i>  | (Optional) No. of aggregates        |
| <i>af-export-rmap</i>      | (Optional) Export route-map         |
| <i>af-import-rmap</i>      | (Optional) Import route-map         |
| <i>af-retain-rt</i>        | (Optional) Retain RT                |
| TABLE_export_rt            | (Optional)                          |
| <i>export-rt</i>           | (Optional) Export route-target      |
| TABLE_import_rt            | (Optional)                          |
| <i>import-rt</i>           | (Optional) Import route-target      |
| TABLE_evpn_export_rt       | (Optional)                          |
| <i>evpn-export-rt</i>      | (Optional) Export EVPN route-target |
| TABLE_evpn_import_rt       | (Optional)                          |
| <i>evpn-import-rt</i>      | (Optional) Import EVPN route-target |
| TABLE_mvpn_export_rt       | (Optional)                          |
| <i>mvpn-export-rt</i>      | (Optional) Export MVPN route-target |
| TABLE_mvpn_import_rt       | (Optional)                          |
| <i>mvpn-import-rt</i>      | (Optional) Import MVPN route-target |
| <i>af-label-mode</i>       | (Optional) Label allocation mode    |
| <i>af-aggregate-label</i>  | (Optional) Aggregate Label          |

### Command Mode

- /exec



|                   |  |
|-------------------|--|
| labeled-unicast   | Display BGP information for labeled-unicast address family     |
| ipv6              | Display BGP information for IPv6 address family                |
| unicast           | Display BGP information for unicast address family             |
| multicast         | Display BGP information for multicast address family           |
| all               | Display BGP information for all address families               |
| l2vpn             | Display BGP information for L2VPN address family               |
| evpn              | Display BGP information for L2VPN EVPN address family          |
| routes            | Display all routes advertised/received to/from peer            |
| advertised        | (Optional) Display all routes advertised to this peer          |
| received          | (Optional) Display all routes received from this peer          |
| advertised-routes | Display all the routes advertised to this peer                 |
| received-routes   | Display all the routes received from this peer                 |
| dampened          | (Optional) Display all dampened routes received from this peer |
| __readonly__      | (Optional)   |
| TABLE_vrf         | (Optional)   |
| vrf-name-out      | (Optional)   |
| TABLE_afi         | (Optional)   |
| afi               | (Optional)   |
| TABLE_safi        | (Optional)   |
| safi              | (Optional)   |
| af-name           | (Optional)   |
| table-version     | (Optional)   |
| router-id         | (Optional)   |
| TABLE_rd          | (Optional)   |
| rd_val            | (Optional)   |
| rd_vrf            | (Optional)   |
| rd_vniid          | (Optional)   |
| TABLE_prefix      | (Optional)   |
| ipprefix          | (Optional)   |

|                            |            |
|----------------------------|------------|
| <i>nonipprefix</i>         | (Optional) |
| <i>totalpaths</i>          | (Optional) |
| <i>bestpathnr</i>          | (Optional) |
| <i>mpath</i>               | (Optional) |
| TABLE_ <i>advertisedto</i> | (Optional) |
| <i>advertisedto</i>        | (Optional) |
| TABLE_ <i>scheduledto</i>  | (Optional) |
| <i>scheduledto</i>         | (Optional) |
| <i>prefixversion</i>       | (Optional) |
| <i>on-newlist</i>          | (Optional) |
| <i>on-xmitlist</i>         | (Optional) |
| <i>suppressed</i>          | (Optional) |
| <i>needsresync</i>         | (Optional) |
| <i>locked</i>              | (Optional) |
| <i>table-map-filtered</i>  | (Optional) |
| <i>export-on-newlist</i>   | (Optional) |
| <i>export-on-xmitlist</i>  | (Optional) |
| <i>locallabel</i>          | (Optional) |
| <i>labelhldwstr</i>        | (Optional) |
| TABLE_ <i>path</i>         | (Optional) |
| <i>pathnr</i>              | (Optional) |
| <i>best</i>                | (Optional) |
| <i>status</i>              | (Optional) |
| <i>type</i>                | (Optional) |
| <i>statuscode</i>          | (Optional) |
| <i>bestcode</i>            | (Optional) |
| <i>typecode</i>            | (Optional) |
| <i>ipnexthop</i>           | (Optional) |
| <i>neighbor</i>            | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |
| <i>pathstaled</i>           | (Optional) |
| <i>pathhistory</i>          | (Optional) |
| <i>pathmultipath</i>        | (Optional) |
| <i>pathovermaxaslimit</i>   | (Optional) |
| <i>pathnolabeledrn</i>      | (Optional) |
| <i>pathlocator</i>          | (Optional) |
| <i>nexthopmetric</i>        | (Optional) |
| <i>aggregator</i>           | (Optional) |
| <i>aggregatoras</i>         | (Optional) |
| <i>atomicaggregate</i>      | (Optional) |



|                              |            |
|------------------------------|------------|
| <i>inlabel</i>               | (Optional) |
| <i>originflag</i>            | (Optional) |
| <i>vpn</i>                   | (Optional) |
| <i>hold_down</i>             | (Optional) |
| <i>outlabel</i>              | (Optional) |
| <i>flappenalty</i>           | (Optional) |
| <i>dampenedtime</i>          | (Optional) |
| <i>flaps</i>                 | (Optional) |
| <i>flaptime</i>              | (Optional) |
| <i>flapflags</i>             | (Optional) |
| <i>flapindex</i>             | (Optional) |
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |

|                           |            |
|---------------------------|------------|
| TABLE_clusterlist         | (Optional) |
| <i>clusterlist</i>        | (Optional) |
| <i>remotenh</i>           | (Optional) |
| <i>remotenh_encap</i>     | (Optional) |
| <i>remotenh_vnid</i>      | (Optional) |
| <i>remotenh_mac</i>       | (Optional) |
| <i>psmi</i>               | (Optional) |
| <i>psid_len</i>           | (Optional) |
| <i>psid_lindx_len</i>     | (Optional) |
| <i>psid_lindx_flag</i>    | (Optional) |
| <i>psid_lindx</i>         | (Optional) |
| <i>psid_v6sid_len</i>     | (Optional) |
| <i>psid_sub_type</i>      | (Optional) |
| <i>psid_func_len</i>      | (Optional) |
| <i>psid_trans_len</i>     | (Optional) |
| <i>psid_trans_off</i>     | (Optional) |
| <i>psid_origsrgb_len</i>  | (Optional) |
| <i>psid_origsrgb_flag</i> | (Optional) |
| <i>psid_origsrgb_base</i> | (Optional) |
| <i>psid_origsrgb_end</i>  | (Optional) |
| TABLE_path_attr_list      | (Optional) |
| <i>path_attr_list</i>     | (Optional) |
| TABLE_attr                | (Optional) |
| <i>attr_num</i>           | (Optional) |
| <i>attr_code_str</i>      | (Optional) |
| <i>attr_code_hex</i>      | (Optional) |
| <i>attr_len</i>           | (Optional) |
| <i>attr_flags</i>         | (Optional) |
| TABLE_attr_val            | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp neighbors

```

show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | ipv6 labeled-unicast |
link-state | l2vpn vpls | l2vpn evpn | ipv4 mvpn | ipv6 mvpn | ipv4 labeled-unicast } neighbors [ { <neighbor-id>
| <ipv6-neighbor-id> | <neighbor-prefix-id> | <ipv6-neighbor-prefix-id> | <neighbor-interface> } ] [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ [ TABLE_neighbor
{ <neighbor> | <ipv6neighbor> | <templatepeer> | <ipv4prefixneighbor> | <ipv6prefixneighbor> |
<interfaceneighbor> } [ <remoteas> ] [ <localas> ] <link> [ <peertype> ] [ <index> ] [ { TABLE_conf-filter
<discard-attr> } ] [ { TABLE_filter <in-attr-type> <no-discard-attr> <dfilter-type> } ] [ { TABLE_conf-wfilter
<withdrawn-attr> } ] [ { TABLE_wfilter <in-wattr-type> <no-withdrawn-attr> <wfilter-type> } ] [ TABLE_peer
<peer> ] [ <maxprefixpeers> ] [ <configpeer> ] [ <inherit-template> ] [ <inherit-session-template> ] [ {
<prefix-parent> | <ipv6prefix-parent> | <interface-parent> } ] [ <description> ] [ <version> <remote-id>
<prevstate> <internalvpnclient> <state> <up> <vrf> [ <elapsedtime> ] [ <restarttime> ] ] [ <sourcecif> ] [
<connectedif> ] [ <connectedcheck> ] [ <lowmemexempt> ] [ <bfd> ] [ <bfdsessiontype> ] [ <bfdmintxinterval>
] [ <bfdminrxinterval> ] [ <bfdmultiplier> ] [ <bfdauthenticationtype> ] [ <ttlsecurity> ] [ <ttllimit> ] [ <dscp>
] [ <password> ] [ <passiveonly> ] [ <activepeers> <closingpeers> <maxconcurrentpeers> ] [ <allocatedpeers>
] [ <totalpeersaccepted> ] [ <localas-inactive> ] <remove-privateas> [ <gshut-activate> ] [ <gshut-map> ] {
{ [ <lastread> ] <holdtime> <keepalivetime> [ <lastwrite> ] [ <keepalive> ] <msgrecvd> <notificationsrcvd>
<recvbuffersinq> <msgsent> <notificationssent> <sentbytesoutstanding> <sentbytespacked> <enhancederr>
<discardattrs> <connsestablished> <connsdropped> [ <connattempts> ] [ <lastupdec> ] [ <lastupsent> ]
{ { [ <peerresetttime> ] <peerresetreason> <errlenrcvd> <errvalrcvd> <rstmajrcvd> <rstminrcvd> [ <resetttime>
] <resetreason> <errlensnt> <errvalsnt> <rstmajsnt> <rstminsnt> } | { [ <resetttime> ] <resetreason> <errlensnt>
<errvalsnt> <rstmajsnt> <rstminsnt> [ <peerresetttime> ] <peerresetreason> <errlenrcvd> <errvalrcvd>
<rstmajrcvd> <rstminrcvd> } } [ <capsnegotiated> <capmpadvertised> [ <caprefreshadvertised>
<capgrdynamicadvertised> ] [ <capmprecvd> <caprefreshrecvd> <capgrdynamicrecvd> ] [
<capolddynamicadvertised> <capolddynamicrecvd> <caprradvertised> <caprrrecvd> <capoldrradvertised>
<capoldrrrecvd> <capas4advertised> <capas4recvd> ] [ { TABLE_af <af-afi> TABLE_saf <af-safi>
<af-advertised> <af-recvd> <af-name> } ] [ <capgradvertised> <capgrrecvd> ] [ { TABLE_graf <gr-afi>
TABLE_grsaf <gr-safi> <gr-af-name> <gr-adv> <gr-recv> <gr-fw> } ] [ <grrestarttime> <grstaletime> ] [
<grrecvrestarttime> ] [ [ { TABLE_addpathscapaf <addpathscap-afi> TABLE_addpathscapsaf
<addpathscap-safi> <addpathscap-af-name> <addpathssendcap-adv> <addpathsrecvcap-adv>
<addpathssendcap-recv> <addpathsrecvcap-recv> } ] [ <capaddpathsadvertised> <capaddpathsrecvd> ] ] [
<capextendednhadvertised> <capextendednhrecvd> ] [ { TABLE_capextendednhaf <capextendednh-afi>
TABLE_capextendednhsaf <capextendednh-safi> <capextendednh-af-name> } ] ] } [ <configholdtime>
<configkeepalivetime> ] } ] [ <epe> ] [ <epe-adj-sids> ] [ <epe-peer-rpc-set> ] [ <epe-peer-sid> ] [
<epe-peer-set-name> ] [ <epe-peer-set-rpc-set> ] [ <epe-peer-set-sid> ] [ { TABLE_epe-adj { {
<epe-adj-ip-local> <epe-adj-ip-remote> } | { <epe-adj-ipv6-local> <epe-adj-ipv6-remote> } } ] [
<epe-adj-ifindex> <epe-adj-rpc-set> <epe-adj-sid> } ] [ <grstate> <gexpiry> ] [ <firstkeepalive> ] [
<openssent> <opensrecvd> <updatesent> <updatesrecvd> <keepalivesent> <keepaliverecvd> <rtrefreshsent>
<rtrefreshrecvd> <capabilitiesent> <capabilitiesrecvd> <bytesent> <bytesrecvd> ] [ TABLE_peraf <per-afi>
TABLE_persaf <per-safi> <per-af-name> [ <tableversion> ] [ <neighbortableversion> ] [ <pfxrecvd> ] [
<pathsrecvd> ] [ <pfxbytes> ] [ <pfxtreataswithdrawn> ] [ <pfxsent> ] [ <pathssent> ] [ <conditionmap>
<advertisemap> <advertisemapstatus> ] <insoftreconfigallowed> [ <insoftreconfigallowedalways> ] [
<sendcommunity> ] [ <sendextcommunity> ] [ { <localnexthop> | <ipv6localnexthop> } ] [ <thirdpartynexthop>
] [ <maxpfx> ] [ <maxpfx_threshold> ] [ <soo> ] [ <weight> ] [ <allowasin> ] [ <asoverride>
<peerascheckdisabled> [ <vplssignalingprotocol> ] [ { TABLE_inpolicy <inpolicynr> <inpolicytype>
<inpolicynr> [ <inpolicyhandle> } ] ] [ { TABLE_outpolicy <outpolicynr> <outpolicytype>
<outpolicynr> [ <outpolicyhandle> } ] ] [ <rrconfigured> <defaultoriginate> [ <defaultoriginatormap> ] [
<defaultsent> ] [ <grpathsaved> ] [ <firsteorrecvd> ] [ <firsteortime> ] [ <pathsflushed> ] [ <lasteorrecvtime>

```

```

]] [<lasteorsenttime> ] [<firstconvgttime> ] [<pfxsentfirsteor> ] [<unsuppress-map> ] [ {
TABLE_policy_template <preference> <inherit-policy-template> } ] ] [ [<threadid> ] [<passivethreadid>
<passivefd> ] [ { <localaddr> | <ipv6localaddr> } <localport> { <remoteaddr> | <ipv6remoteaddr> }
<remoteport> <fd> ] ] ] ]

```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                            |
| bgp                       | Display BGP status and configuration                       |
| vrf                       | (Optional) Virtual Router Context                          |
| <i>vrf-name</i>           | (Optional) VRF name  |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                                  |
| neighbors                 | Display all configured BGP neighbors                       |
| <i>neighbor-id</i>        | (Optional) Display one particular BGP neighbor             |
| <i>neighbor-prefix-id</i> | (Optional) Display details for a prefix peering            |
| <i>neighbor-interface</i> | (Optional) Display details for BGP interface peering       |
| ipv4                      | Display BGP information for IPv4 address family            |
| vpn4                      | Display BGP information for VPNv4 address family           |
| vpn6                      | Display BGP information for VPNv6 address family           |
| ipv6                      | Display BGP information for IPv6 address family            |
| unicast                   | Display BGP information for unicast address family         |
| multicast                 | Display BGP information for multicast address family       |
| labeled-unicast           | Display BGP information for labeled-unicast address family |
| link-state                | Display BGP information for link-state address family      |
| l2vpn                     | Display BGP information for L2VPN address family           |
| vpls                      | Display BGP information for L2VPN VPLS address family      |
| mvpn                      | Display BGP information for MVPN address family            |
| evpn                      | Display BGP information for L2VPN EVPN address family      |
| all                       | Display BGP information for all address families           |
| __readonly__              | (Optional)   |
| TABLE_neighbor            | (Optional)   |
| <i>neighbor</i>           | (Optional)   |

|                                 |  |
|---------------------------------|--|
| <i>templatepeer</i>             | (Optional)   |
| <i>ipv4prefixneighbor</i>       | (Optional)   |
| <i>interfaceneighbor</i>        | (Optional)   |
| <i>remoteas</i>                 | (Optional)   |
| <i>localas</i>                  | (Optional)   |
| <i>link</i>                     | (Optional)   |
| <i>index</i>                    | (Optional)   |
| TABLE_conf-filter               | (Optional)   |
| <i>discard-attr</i>             | (Optional) configured attributes those need to be discarded  |
| TABLE_filter                    | (Optional)   |
| <i>in-attr-type</i>             | (Optional) matching discarded attribute                      |
| <i>no-discard-attr</i>          | (Optional) number of matching attributes those are discarded |
| <i>dfilter-type</i>             | (Optional) filter type in or out                             |
| TABLE_conf-wfilter              | (Optional)   |
| <i>withdrawn-attr</i>           | (Optional) configured attributes those need to be withdrawn  |
| TABLE_wfilter                   | (Optional)   |
| <i>in-wattr-type</i>            | (Optional) matching withdrawn attribute                      |
| <i>no-withdrawn-attr</i>        | (Optional) number of matching attributes those are withdrawn |
| <i>wfilter-type</i>             | (Optional) filter type in or out                             |
| TABLE_peer                      | (Optional)   |
| <i>peer</i>                     | (Optional)   |
| <i>maxprefixpeers</i>           | (Optional)   |
| <i>configpeer</i>               | (Optional)   |
| <i>inherit-template</i>         | (Optional)   |
| <i>inherit-session-template</i> | (Optional)   |
| <i>prefix-parent</i>            | (Optional)   |
| <i>interface-parent</i>         | (Optional)   |
| <i>description</i>              | (Optional)   |
| <i>version</i>                  | (Optional)   |

|                              |            |
|------------------------------|------------|
| <i>remote-id</i>             | (Optional) |
| <i>state</i>                 | (Optional) |
| <i>prevstate</i>             | (Optional) |
| <i>internalvpnclient</i>     | (Optional) |
| <i>up</i>                    | (Optional) |
| <i>elapsedtime</i>           | (Optional) |
| <i>restarttime</i>           | (Optional) |
| <i>peertype</i>              | (Optional) |
| <i>sourceif</i>              | (Optional) |
| <i>connectedif</i>           | (Optional) |
| <i>connectedcheck</i>        | (Optional) |
| <i>lowmemexempt</i>          | (Optional) |
| <i>bfd</i>                   | (Optional) |
| <i>bfdsessiontype</i>        | (Optional) |
| <i>bfdmintxinterval</i>      | (Optional) |
| <i>bfdminrxinterval</i>      | (Optional) |
| <i>bfdmultiplier</i>         | (Optional) |
| <i>bfdauthenticationtype</i> | (Optional) |
| <i>ttlsecurity</i>           | (Optional) |
| <i>tllimit</i>               | (Optional) |
| <i>dscp</i>                  | (Optional) |
| <i>localas-inactive</i>      | (Optional) |
| <i>passiveonly</i>           | (Optional) |
| <i>activepeers</i>           | (Optional) |
| <i>closingpeers</i>          | (Optional) |
| <i>maxconcurrentpeers</i>    | (Optional) |
| <i>allocatedpeers</i>        | (Optional) |
| <i>totalpeersaccepted</i>    | (Optional) |
| <i>password</i>              | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>remove-privateas</i>     | (Optional) |
| <i>gshut-activate</i>       | (Optional) |
| <i>gshut-map</i>            | (Optional) |
| <i>lastread</i>             | (Optional) |
| <i>holdtime</i>             | (Optional) |
| <i>keepalivetime</i>        | (Optional) |
| <i>lastwrite</i>            | (Optional) |
| <i>keepalive</i>            | (Optional) |
| <i>msgrecvd</i>             | (Optional) |
| <i>notificationsrcvd</i>    | (Optional) |
| <i>rcvbufbytesinq</i>       | (Optional) |
| <i>msgsent</i>              | (Optional) |
| <i>notificationssent</i>    | (Optional) |
| <i>sentbytesoutstanding</i> | (Optional) |
| <i>sentbytespacked</i>      | (Optional) |
| <i>enhancederr</i>          | (Optional) |
| <i>discardattrs</i>         | (Optional) |
| <i>connsestablished</i>     | (Optional) |
| <i>connsdropped</i>         | (Optional) |
| <i>connattempts</i>         | (Optional) |
| <i>lastupdrecd</i>          | (Optional) |
| <i>lastupdsent</i>          | (Optional) |
| <i>peerresetime</i>         | (Optional) |
| <i>peerresetreason</i>      | (Optional) |
| <i>errlenrcvd</i>           | (Optional) |
| <i>errvalrcvd</i>           | (Optional) |
| <i>rstmajrcvd</i>           | (Optional) |
| <i>rstminrcvd</i>           | (Optional) |
| <i>errlensnt</i>            | (Optional) |



|                             |            |
|-----------------------------|------------|
| <i>errvalsnt</i>            | (Optional) |
| <i>rstmajsent</i>           | (Optional) |
| <i>rstminsnt</i>            | (Optional) |
| <i>resetime</i>             | (Optional) |
| <i>resetreason</i>          | (Optional) |
| <i>vrf</i>                  | (Optional) |
| <i>configholdtime</i>       | (Optional) |
| <i>configkeepalivetime</i>  | (Optional) |
| <i>grstate</i>              | (Optional) |
| <i>gexpiry</i>              | (Optional) |
| <i>firstkeepalive</i>       | (Optional) |
| <i>epe</i>                  | (Optional) |
| <i>epe-adj-sids</i>         | (Optional) |
| <i>epe-peer-rpc-set</i>     | (Optional) |
| <i>epe-peer-sid</i>         | (Optional) |
| <i>epe-peer-set-name</i>    | (Optional) |
| <i>epe-peer-set-rpc-set</i> | (Optional) |
| <i>epe-peer-set-sid</i>     | (Optional) |
| TABLE_ epe-adj              | (Optional) |
| <i>epe-adj-ip-local</i>     | (Optional) |
| <i>epe-adj-ip-remote</i>    | (Optional) |
| <i>epe-adj-ifindex</i>      | (Optional) |
| <i>epe-adj-rpc-set</i>      | (Optional) |
| <i>epe-adj-sid</i>          | (Optional) |
| <i>openssent</i>            | (Optional) |
| <i>opensrecvd</i>           | (Optional) |
| <i>updatessent</i>          | (Optional) |
| <i>updatesrecvd</i>         | (Optional) |
| <i>keepalivesent</i>        | (Optional) |

|                                |            |
|--------------------------------|------------|
| <i>keepaliverecvd</i>          | (Optional) |
| <i>rtrefreshsent</i>           | (Optional) |
| <i>rtrefreshrcvd</i>           | (Optional) |
| <i>capabilitiesent</i>         | (Optional) |
| <i>capabilitiesrcvd</i>        | (Optional) |
| <i>bytessent</i>               | (Optional) |
| <i>bytesrcvd</i>               | (Optional) |
| <i>threadid</i>                | (Optional) |
| <i>fd</i>                      | (Optional) |
| <i>passivethreadid</i>         | (Optional) |
| <i>passivefd</i>               | (Optional) |
| <i>localaddr</i>               | (Optional) |
| <i>localport</i>               | (Optional) |
| <i>remoteaddr</i>              | (Optional) |
| <i>remoteport</i>              | (Optional) |
| <i>capsnegotiated</i>          | (Optional) |
| <i>capmpadvertised</i>         | (Optional) |
| <i>capgrdynamicadvertised</i>  | (Optional) |
| <i>capaddpathsadvertised</i>   | (Optional) |
| <i>caprefreshadvertised</i>    | (Optional) |
| <i>capmprcvd</i>               | (Optional) |
| <i>capgrdynamicrcvd</i>        | (Optional) |
| <i>capaddpathsrcvd</i>         | (Optional) |
| <i>caprefreshrcvd</i>          | (Optional) |
| <i>capolddynamicadvertised</i> | (Optional) |
| <i>capolddynamicrcvd</i>       | (Optional) |
| <i>caprradvertised</i>         | (Optional) |
| <i>caprrrcvd</i>               | (Optional) |
| <i>capoldrradvertised</i>      | (Optional) |

|                            |            |
|----------------------------|------------|
| <i>capoldrrrecvd</i>       | (Optional) |
| <i>capas4advertised</i>    | (Optional) |
| <i>capas4recvd</i>         | (Optional) |
| TABLE_af                   | (Optional) |
| <i>af-afi</i>              | (Optional) |
| TABLE_saf                  | (Optional) |
| <i>af-safi</i>             | (Optional) |
| <i>af-advertised</i>       | (Optional) |
| <i>af-recvd</i>            | (Optional) |
| <i>af-name</i>             | (Optional) |
| <i>capgradvertised</i>     | (Optional) |
| <i>capgrrecvd</i>          | (Optional) |
| TABLE_graf                 | (Optional) |
| <i>gr-afi</i>              | (Optional) |
| TABLE_grsaf                | (Optional) |
| <i>gr-safi</i>             | (Optional) |
| <i>gr-af-name</i>          | (Optional) |
| <i>gr-adv</i>              | (Optional) |
| <i>gr-recv</i>             | (Optional) |
| <i>gr-fwd</i>              | (Optional) |
| <i>grrestarttime</i>       | (Optional) |
| <i>grstaletime</i>         | (Optional) |
| <i>grrecvdrestarttime</i>  | (Optional) |
| TABLE_addpathscapaf        | (Optional) |
| <i>addpathscap-afi</i>     | (Optional) |
| TABLE_addpathscapsaf       | (Optional) |
| <i>addpathscap-safi</i>    | (Optional) |
| <i>addpathscap-af-name</i> | (Optional) |
| <i>addpathsendcap-adv</i>  | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>addpathsrecvcap-adv</i>         | (Optional) |
| <i>addpathssendcap-recv</i>        | (Optional) |
| <i>addpathsrecvcap-recv</i>        | (Optional) |
| <i>capextendednhadvertised</i>     | (Optional) |
| <i>capextendednhrecvd</i>          | (Optional) |
| TABLE_capextendednhaf              | (Optional) |
| <i>capextendednh-afi</i>           | (Optional) |
| TABLE_capextendednhsaf             | (Optional) |
| <i>capextendednh-safi</i>          | (Optional) |
| <i>capextendednh-af-name</i>       | (Optional) |
| TABLE_peraf                        | (Optional) |
| <i>per-afi</i>                     | (Optional) |
| TABLE_persaf                       | (Optional) |
| <i>per-safi</i>                    | (Optional) |
| <i>per-af-name</i>                 | (Optional) |
| <i>tableversion</i>                | (Optional) |
| <i>neighbortableversion</i>        | (Optional) |
| <i>pfxrecvd</i>                    | (Optional) |
| <i>pathsrecvd</i>                  | (Optional) |
| <i>pfxbytes</i>                    | (Optional) |
| <i>pfxtreataswithdrawn</i>         | (Optional) |
| <i>pfxsent</i>                     | (Optional) |
| <i>pathsent</i>                    | (Optional) |
| <i>conditionmap</i>                | (Optional) |
| <i>advertisemap</i>                | (Optional) |
| <i>advertisemapstatus</i>          | (Optional) |
| <i>insoftreconfigallowed</i>       | (Optional) |
| <i>insoftreconfigallowedalways</i> | (Optional) |
| <i>sendcommunity</i>               | (Optional) |

|                            |            |
|----------------------------|------------|
| <i>sendextcommunity</i>    | (Optional) |
| <i>maxpfx</i>              | (Optional) |
| <i>maxpfx_threshold</i>    | (Optional) |
| <i>localnexthop</i>        | (Optional) |
| TABLE_inpolicy             | (Optional) |
| <i>inpolycynr</i>          | (Optional) |
| <i>inpolicytype</i>        | (Optional) |
| <i>inpolicyname</i>        | (Optional) |
| <i>inpolicyhandle</i>      | (Optional) |
| TABLE_outpolicy            | (Optional) |
| <i>outpolycynr</i>         | (Optional) |
| <i>outpolicytype</i>       | (Optional) |
| <i>outpolicyname</i>       | (Optional) |
| <i>outpolicyhandle</i>     | (Optional) |
| <i>rrconfigured</i>        | (Optional) |
| <i>defaultoriginate</i>    | (Optional) |
| <i>defaultoriginatemap</i> | (Optional) |
| <i>defaultsent</i>         | (Optional) |
| <i>grpahssaved</i>         | (Optional) |
| <i>firsteorrecvd</i>       | (Optional) |
| <i>firsteortime</i>        | (Optional) |
| <i>pathsflushed</i>        | (Optional) |
| <i>lasteorrecvtime</i>     | (Optional) |
| <i>lasteorsenttime</i>     | (Optional) |
| <i>firstconvgtime</i>      | (Optional) |
| <i>pxsentfirsteor</i>      | (Optional) |
| <i>unsuppress-map</i>      | (Optional) |
| <i>thirdpartynexthop</i>   | (Optional) |
| <i>soo</i>                 | (Optional) |

|                                |            |
|--------------------------------|------------|
| <i>weight</i>                  | (Optional) |
| <i>allowasin</i>               | (Optional) |
| <i>asoverride</i>              | (Optional) |
| <i>peerascheckdisabled</i>     | (Optional) |
| <i>vplssignalingprotocol</i>   | (Optional) |
| TABLE_policy_template          | (Optional) |
| <i>preference</i>              | (Optional) |
| <i>inherit-policy-template</i> | (Optional) |

**Command Mode**

- /exec

# show bgp neighbors commands

```
show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | l2vpn evpn } neighbors {
<neighbor-id> | <ipv6-neighbor-id> } commands [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ] [ __readonly__ [ { TABLE_sesscmd <sessioncmd> <sessioncmdstatus>
[ <sessioncmdtemplate> ] } ] [ TABLE_af <af-afi> TABLE_saf <af-safi> <af-name> [ { TABLE_polcmd
<polycmd> <polycmdstatus> [ <polycmdtemplate> ] } ] ] ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                       |
| bgp                       | Display BGP status and configuration                  |
| vrf                       | (Optional) Virtual Router Context                     |
| <i>vrf-name</i>           | (Optional) VRF name                                   |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                             |
| <i>neighbor-id</i>        | Display one particular BGP neighbor                   |
| ipv4                      | Display BGP information for IPv4 address family       |
| ipv6                      | Display BGP information for IPv6 address family       |
| vpnv4                     | Display BGP information for VPNv4 address family      |
| vpnv6                     | Display BGP information for VPNv6 address family      |
| unicast                   | Display BGP information for unicast address family    |
| multicast                 | Display BGP information for multicast address family  |
| all                       | Display BGP information for all address families      |
| l2vpn                     | Display BGP information for L2VPN address family      |
| evpn                      | Display BGP information for L2VPN EVPN address family |
| neighbors                 | Display all configured BGP neighbors                  |
| commands                  | Display details on commands                           |
| <i>__readonly__</i>       | (Optional)  |
| <i>TABLE_sesscmd</i>      | (Optional)  |
| <i>sessioncmd</i>         | (Optional)  |
| <i>sessioncmdstatus</i>   | (Optional)  |
| <i>sessioncmdtemplate</i> | (Optional)  |

|                        |            |
|------------------------|------------|
| TABLE_af               | (Optional) |
| <i>af-afi</i>          | (Optional) |
| TABLE_saf              | (Optional) |
| <i>af-safi</i>         | (Optional) |
| <i>af-name</i>         | (Optional) |
| TABLE_polcmd           | (Optional) |
| <i>polycmd</i>         | (Optional) |
| <i>polycmdstatus</i>   | (Optional) |
| <i>polycmdtemplate</i> | (Optional) |

**Command Mode**

- /exec



## show bgp neighbors flap-statistics

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } neighbors { <neighbor-id> | <ipv6-neighbor-id> } flap-statistics
[ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf
<vrf-name-out> [ TABLE_afi <afi> TABLE_safi <safi> <af-name> [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [
<rd_vniid> ] ] [ <dampening> <historypaths> <dampenedpaths> ] [ TABLE_prefix { <ipprefix> | <ipv6prefix>
| <nonipprefix> } ] [ <status> ] [ <pathtype> ] [ <peer> | <ipv6peer> ] [ <flapcount> ] [ <duration> ] [ <reuse>
] [ <penalty> ] [ <suppresslimit> ] [ <reuselimit> ] [ <best> ] ] ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                            |
| bgp                   | Display BGP status and configuration                       |
| vrf                   | (Optional) Virtual Router Context                          |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                  |
| neighbors             | Display all configured BGP neighbors                       |
| <i>neighbor-id</i>    | Display one particular BGP neighbor                        |
| ipv4                  | Display BGP information for IPv4 address family            |
| ipv6                  | Display BGP information for IPv6 address family            |
| unicast               | Display BGP information for unicast address family         |
| multicast             | Display BGP information for multicast address family       |
| all                   | Display BGP information for all address families           |
| flap-statistics       | Display flap statistics for routes received from this peer |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrf-name-out</i>   | (Optional)   |
| TABLE_afi             | (Optional)   |
| <i>afi</i>            | (Optional)   |
| TABLE_safi            | (Optional)   |
| <i>safi</i>           | (Optional)   |
| <i>af-name</i>        | (Optional)   |
| TABLE_rd              | (Optional)   |

|                      |            |
|----------------------|------------|
| <i>rd_val</i>        | (Optional) |
| <i>rd_vrf</i>        | (Optional) |
| <i>rd_vniid</i>      | (Optional) |
| <i>dampening</i>     | (Optional) |
| <i>historypaths</i>  | (Optional) |
| <i>dampenedpaths</i> | (Optional) |
| TABLE_prefix         | (Optional) |
| <i>ipprefix</i>      | (Optional) |
| <i>nonipprefix</i>   | (Optional) |
| <i>status</i>        | (Optional) |
| <i>best</i>          | (Optional) |
| <i>pathtype</i>      | (Optional) |
| <i>peer</i>          | (Optional) |
| <i>flapcount</i>     | (Optional) |
| <i>duration</i>      | (Optional) |
| <i>reuse</i>         | (Optional) |
| <i>penalty</i>       | (Optional) |
| <i>suppresslimit</i> | (Optional) |
| <i>reuselimit</i>    | (Optional) |

**Command Mode**

- /exec

## show bgp neighbors paths

```
show bgp { { [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] } { ipv4 { unicast
| multicast } | ipv6 { unicast | multicast } | all } } | vpnv4 unicast | vpnv6 unicast | ipv6 labeled-unicast | ipv4
labeled-unicast | link-state | l2vpn evpn } neighbors { <neighbor-id> | <ipv6-neighbor-id> } paths [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf
<vrf-name-out> TABLE_afi <afi> TABLE_safi <safi> <af-name> [ TABLE_id <id> <hashvalue> <refcount>
<metric> <aspath> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                            |
| bgp                   | Display BGP status and configuration                       |
| vrf                   | (Optional) Virtual Router Context                          |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                  |
| neighbors             | Display all configured BGP neighbors                       |
| <i>neighbor-id</i>    | Display one particular BGP neighbor                        |
| ipv4                  | Display BGP information for IPv4 address family            |
| vpnv4                 | Display BGP information for VPNv4 address family           |
| vpnv6                 | Display BGP information for VPNv6 address family           |
| ipv6                  | Display BGP information for IPv6 address family            |
| unicast               | Display BGP information for unicast address family         |
| multicast             | Display BGP information for multicast address family       |
| labeled-unicast       | Display BGP information for labeled-unicast address family |
| link-state            | Display BGP information for link-state address family      |
| all                   | Display BGP information for all address families           |
| l2vpn                 | Display BGP information for L2VPN address family           |
| evpn                  | Display BGP information for L2VPN EVPN address family      |
| paths                 | Display AS paths learned from this peer                    |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrf-name-out</i>   | (Optional)   |

|                  |            |
|------------------|------------|
| TABLE_afi        | (Optional) |
| <i>afi</i>       | (Optional) |
| TABLE_safi       | (Optional) |
| <i>safi</i>      | (Optional) |
| <i>af-name</i>   | (Optional) |
| TABLE_id         | (Optional) |
| <i>id</i>        | (Optional) |
| <i>hashvalue</i> | (Optional) |
| <i>refcount</i>  | (Optional) |
| <i>metric</i>    | (Optional) |
| <i>aspath</i>    | (Optional) |

**Command Mode**

- /exec



|                      |  |
|----------------------|--|
| ipv4                 | Display BGP information for IPv4 address family            |
| ipv6                 | Display BGP information for IPv6 address family            |
| vpnv4                | Display BGP information for VPNv4 address family           |
| vpnv6                | Display BGP information for VPNv6 address family           |
| unicast              | Display BGP information for unicast address family         |
| multicast            | Display BGP information for multicast address family       |
| mdt                  | Display BGP information for multicast distribution tree    |
| link-state           | Display BGP information for link-state address family      |
| l2vpn                | Display BGP information for L2VPN address family           |
| vpls                 | Display BGP information for L2VPN VPLS address family      |
| evpn                 | Display BGP information for L2VPN EVPN address family      |
| mvpn                 | Display BGP information for MVPN address family            |
| labeled-unicast      | Display BGP information for labeled-unicast address family |
| path-attribute       | path attribute on a route                                  |
| discard              | discard the path attribute                                 |
| unknown              | unknown path attribute                                     |
| <i>__readonly__</i>  | (Optional)   |
| TABLE_vrf            | (Optional)   |
| <i>vrf-name-out</i>  | (Optional)   |
| TABLE_afi            | (Optional)   |
| <i>afi</i>           | (Optional)   |
| TABLE_safi           | (Optional)   |
| <i>safi</i>          | (Optional)   |
| <i>af-name</i>       | (Optional)   |
| <i>table-version</i> | (Optional)   |
| <i>router-id</i>     | (Optional)   |
| TABLE_rd             | (Optional)   |
| <i>rd_val</i>        | (Optional)   |
| <i>rd_vrf</i>        | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>rd_vniid</i>           | (Optional) |
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |
| <i>export-on-xmitlist</i> | (Optional) |
| <i>locallabel</i>         | (Optional) |
| <i>labelhldwstr</i>       | (Optional) |
| TABLE_path                | (Optional) |
| <i>pathnr</i>             | (Optional) |
| <i>best</i>               | (Optional) |
| <i>status</i>             | (Optional) |
| <i>type</i>               | (Optional) |
| <i>statuscode</i>         | (Optional) |
| <i>bestcode</i>           | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |
| <i>pathstaled</i>           | (Optional) |
| <i>pathhistory</i>          | (Optional) |
| <i>pathmultipath</i>        | (Optional) |
| <i>pathovermaxaslimit</i>   | (Optional) |
| <i>pathnolabeledrn</i>      | (Optional) |
| <i>pathlocator</i>          | (Optional) |
| <i>nexthopmetric</i>        | (Optional) |



|                              |            |
|------------------------------|------------|
| <i>aggregator</i>            | (Optional) |
| <i>aggregatoras</i>          | (Optional) |
| <i>atomicaggregate</i>       | (Optional) |
| <i>inlabel</i>               | (Optional) |
| <i>originflag</i>            | (Optional) |
| <i>vpn</i>                   | (Optional) |
| <i>hold_down</i>             | (Optional) |
| <i>outlabel</i>              | (Optional) |
| <i>flappenalty</i>           | (Optional) |
| <i>dampenedtime</i>          | (Optional) |
| <i>flaps</i>                 | (Optional) |
| <i>flaptime</i>              | (Optional) |
| <i>flapflags</i>             | (Optional) |
| <i>flapindex</i>             | (Optional) |
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |

|                            |            |
|----------------------------|------------|
| TABLE_extcommunity         | (Optional) |
| <i>extcommunity</i>        | (Optional) |
| <i>originatorid</i>        | (Optional) |
| TABLE_clusterlist          | (Optional) |
| <i>clusterlist</i>         | (Optional) |
| <i>remotenh</i>            | (Optional) |
| <i>remotenh_encap</i>      | (Optional) |
| <i>remotenh_vnid</i>       | (Optional) |
| <i>remotenh_mac</i>        | (Optional) |
| <i>pmsi</i>                | (Optional) |
| <i>psid_len</i>            | (Optional) |
| <i>psid_lindx_len</i>      | (Optional) |
| <i>psid_lindx_flag</i>     | (Optional) |
| <i>psid_lindx</i>          | (Optional) |
| <i>psid_v6sid_len</i>      | (Optional) |
| <i>psid_sub_type</i>       | (Optional) |
| <i>psid_func_len</i>       | (Optional) |
| <i>psid_trans_len</i>      | (Optional) |
| <i>psid_trans_off</i>      | (Optional) |
| <i>psid_origrsrgb_len</i>  | (Optional) |
| <i>psid_origrsrgb_flag</i> | (Optional) |
| <i>psid_origrsrgb_base</i> | (Optional) |
| <i>psid_origrsrgb_end</i>  | (Optional) |
| TABLE_path_attr_list       | (Optional) |
| <i>path_attr_list</i>      | (Optional) |
| TABLE_attr                 | (Optional) |
| <i>attr_num</i>            | (Optional) |
| <i>attr_code_str</i>       | (Optional) |
| <i>attr_code_hex</i>       | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

# show bgp paths

```
show [ ip ] bgp paths [ __readonly__ TABLE_id <id> <hashvalue> <refcount> <metric> <aspath> <origin> ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | (Optional) Display IP information    |
| bgp              | Display BGP status and configuration |
| paths            | Display Path information             |
| __readonly__     | (Optional)                           |
| TABLE_id         | (Optional)                           |
| <i>id</i>        | (Optional)                           |
| <i>hashvalue</i> | (Optional)                           |
| <i>refcount</i>  | (Optional)                           |
| <i>metric</i>    | (Optional)                           |
| <i>aspath</i>    | (Optional)                           |
| <i>origin</i>    | (Optional)                           |

## Command Mode

- /exec

## show bgp peer-template

```
show [ ip ] bgp peer-template [ <peer-template-name> ] [ __readonly__ { TABLE_neighbor <templatepeer>
[ <remoteas> ] [ <inherit-template> ] [ <inherit-session-template> ] [ { <prefix-parent> | <ipv6prefix-parent>
| <interface-parent> } ] [ <description> ] [ <sourceif> ] [ <connectedcheck> ] [ <lowmemexempt> ] [ <bfd>
] [ <bfdsessiontype> ] [ <bfdmintxinterval> ] [ <bfdminrxinterval> ] [ <bfdmultiplier> ] [
<bfdauthenticationtype> ] [ <ttlsecurity> ] [ <ttllimit> ] [ <dscp> ] [ <password> ] [ <passiveonly> ]
<localas-inactive> [ <remove-privateas> ] [ <gshut-activate> ] [ <gshut-map> ] [ <configholdtime>
<configkeepalivetime> ] [ TABLE_peraf <per-afi> TABLE_persaf <per-safi> <per-af-name> [ <tableversion>
] [ <neighbortableversion> ] [ <pfxrcvd> ] [ <pathsrcvd> ] [ <pfxbytes> ] [ <pfxtreataswithdrawn> ] [
<pfxsent> ] [ <pathssent> ] [ <conditionmap> <advertisemap> <advertisemapstatus> ] <insoftreconfigallowed>
[ <insoftreconfigallowedalways> ] [ <sendcommunity> ] [ <sendextcommunity> ] [ { <localnexthop> |
<ipv6localnexthop> } ] [ <thirdpartynexthop> ] [ <maxpfx> ] [ <maxpfx_threshold> ] [ <soo> ] [ <weight>
] [ <allowasin> ] <asoverride> <peerascheckdisabled> [ <vplssignalingprotocol> ] [ { TABLE_inpolicy
<inpolicynr> <inpolicytype> <inpolicyname> [ <inpolicyhandle> } ] [ { TABLE_outpolicy <outpolicynr>
<outpolicytype> <outpolicyname> [ <outpolicyhandle> } ] ] <rrconfigured> <defaultoriginate> [
<defaultoriginatemap> ] [ <defaultsent> ] [ <grpathssaved> ] [ <firsteorrcvd> ] [ <firsteortime> ] [
<pathsflushed> ] [ <lasteorrcvtime> ] [ <lasteorsenttime> ] [ <firstconvgtime> ] [ <pfxsentfirsteor> ] [
<unsuppress-map> ] [ { TABLE_policy_template <preference> <inherit-policy-template> } ] [ TABLE_vrf
<vrf-name> [ TABLE_inheritingpeer <inheritingpeer> [ <interface-parent> ] ] ] }
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information           |
| ip                              | (Optional) Display IP information         |
| bgp                             | Display BGP status and configuration      |
| peer-template                   | Display information about a peer-template |
| <i>peer-template-name</i>       | (Optional) Peer-template name             |
| <i>__readonly__</i>             | (Optional)                                |
| TABLE_neighbor                  | (Optional)                                |
| <i>templatepeer</i>             | (Optional)                                |
| <i>remoteas</i>                 | (Optional)                                |
| <i>inherit-template</i>         | (Optional)                                |
| <i>inherit-session-template</i> | (Optional)                                |
| <i>prefix-parent</i>            | (Optional)                                |
| <i>interface-parent</i>         | (Optional)                                |
| <i>description</i>              | (Optional)                                |
| <i>sourceif</i>                 | (Optional)                                |

|                              |            |
|------------------------------|------------|
| <i>connectedcheck</i>        | (Optional) |
| <i>lowmemexempt</i>          | (Optional) |
| <i>bfd</i>                   | (Optional) |
| <i>bfdsessiontype</i>        | (Optional) |
| <i>bfdmintxinterval</i>      | (Optional) |
| <i>bfdminrxinterval</i>      | (Optional) |
| <i>bfdmultiplier</i>         | (Optional) |
| <i>bfdauthenticationtype</i> | (Optional) |
| <i>ttlsecurity</i>           | (Optional) |
| <i>tllimit</i>               | (Optional) |
| <i>dscp</i>                  | (Optional) |
| <i>passiveonly</i>           | (Optional) |
| <i>password</i>              | (Optional) |
| <i>localas-inactive</i>      | (Optional) |
| <i>remove-privateas</i>      | (Optional) |
| <i>gshut-activate</i>        | (Optional) |
| <i>gshut-map</i>             | (Optional) |
| <i>configholdtime</i>        | (Optional) |
| <i>configkeepalivetime</i>   | (Optional) |
| TABLE_vrf                    | (Optional) |
| <i>vrf-name</i>              | (Optional) |
| TABLE_inheritingpeer         | (Optional) |
| <i>inheritingpeer</i>        | (Optional) |
| <i>interface-parent</i>      | (Optional) |
| TABLE_peraf                  | (Optional) |
| <i>per-afi</i>               | (Optional) |
| TABLE_persaf                 | (Optional) |
| <i>per-safi</i>              | (Optional) |
| <i>per-af-name</i>           | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>tableversion</i>                | (Optional) |
| <i>neighbortableversion</i>        | (Optional) |
| <i>pfxrecvd</i>                    | (Optional) |
| <i>pathsrecvd</i>                  | (Optional) |
| <i>pfxbytes</i>                    | (Optional) |
| <i>pfxtreataswithdrawn</i>         | (Optional) |
| <i>pfxsent</i>                     | (Optional) |
| <i>pathsstent</i>                  | (Optional) |
| <i>conditionmap</i>                | (Optional) |
| <i>advertisemap</i>                | (Optional) |
| <i>advertisemapstatus</i>          | (Optional) |
| <i>insoftreconfigallowed</i>       | (Optional) |
| <i>insoftreconfigallowedalways</i> | (Optional) |
| <i>sendcommunity</i>               | (Optional) |
| <i>sendextcommunity</i>            | (Optional) |
| <i>maxpfx</i>                      | (Optional) |
| <i>maxpfx_threshold</i>            | (Optional) |
| <i>localnexthop</i>                | (Optional) |
| TABLE_inpolicy                     | (Optional) |
| <i>inpolicynr</i>                  | (Optional) |
| <i>inpolicytype</i>                | (Optional) |
| <i>inpolicyname</i>                | (Optional) |
| <i>inpolicyhandle</i>              | (Optional) |
| TABLE_outpolicy                    | (Optional) |
| <i>outpolicynr</i>                 | (Optional) |
| <i>outpolicytype</i>               | (Optional) |
| <i>outpolicyname</i>               | (Optional) |
| <i>outpolicyhandle</i>             | (Optional) |
| <i>rrconfigured</i>                | (Optional) |

|                                |            |
|--------------------------------|------------|
| <i>defaultoriginate</i>        | (Optional) |
| <i>defaultoriginatemap</i>     | (Optional) |
| <i>defaultsent</i>             | (Optional) |
| <i>grpahssaved</i>             | (Optional) |
| <i>firsteorrecvd</i>           | (Optional) |
| <i>firsteortime</i>            | (Optional) |
| <i>pathsflushed</i>            | (Optional) |
| <i>lasteorrecvtime</i>         | (Optional) |
| <i>lasteorsenttime</i>         | (Optional) |
| <i>firstconvgttime</i>         | (Optional) |
| <i>pxsentfirsteor</i>          | (Optional) |
| <i>unsuppress-map</i>          | (Optional) |
| <i>thirdpartynexthop</i>       | (Optional) |
| <i>soo</i>                     | (Optional) |
| <i>weight</i>                  | (Optional) |
| <i>allowasin</i>               | (Optional) |
| <i>asoverride</i>              | (Optional) |
| <i>peerascheckdisabled</i>     | (Optional) |
| <i>vplssignalingprotocol</i>   | (Optional) |
| TABLE_policy_template          | (Optional) |
| <i>preference</i>              | (Optional) |
| <i>inherit-policy-template</i> | (Optional) |

**Command Mode**

- /exec



## show bgp peer

```
show [ ip ] bgp { peer-session [ <session-template-name> ] | peer-policy [ <policy-template-name> ] } [
__readonly__ TABLE_template <template> <present> [ { TABLE_command <command> [ <polarity> ] [
<updatesource> ] [ <description> ] [ <multihop> ] [ <holdtime> ] [ <keepalive> ] [ <dscp> ] [ <routemapin>
] [ <routemapout> ] [ <filterlistin> ] [ <filterlistout> ] [ <prefixlistin> ] [ <prefixlistout> ] [ <maxprefixlimit>
] [ <defaultorigin> ] } ] [ { TABLE_vrf <vrf-name> { TABLE_peer <inheritingpeer> [ <interface-parent> ]
} } ] ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information          |
| ip                           | (Optional) Display IP information        |
| bgp                          | Display BGP status and configuration     |
| peer-session                 | Display information about a peer-session |
| peer-policy                  | Display information about a peer-policy  |
| <i>session-template-name</i> | (Optional) Peer-session name             |
| <i>policy-template-name</i>  | (Optional) Peer-policy name              |
| <i>__readonly__</i>          | (Optional)                               |
| TABLE_template               | (Optional)                               |
| <i>template</i>              | (Optional)                               |
| <i>present</i>               | (Optional)                               |
| TABLE_command                | (Optional)                               |
| <i>command</i>               | (Optional)                               |
| <i>polarity</i>              | (Optional)                               |
| <i>updatesource</i>          | (Optional)                               |
| <i>description</i>           | (Optional)                               |
| <i>multihop</i>              | (Optional)                               |
| <i>holdtime</i>              | (Optional)                               |
| <i>keepalive</i>             | (Optional)                               |
| <i>dscp</i>                  | (Optional)                               |
| <i>routemapin</i>            | (Optional)                               |
| <i>routemapout</i>           | (Optional)                               |

|                         |            |
|-------------------------|------------|
| <i>filterlistin</i>     | (Optional) |
| <i>filterlistout</i>    | (Optional) |
| <i>prefixlistin</i>     | (Optional) |
| <i>prefixlistout</i>    | (Optional) |
| <i>maxprefixlimit</i>   | (Optional) |
| <i>defaultorigin</i>    | (Optional) |
| TABLE_vrf               | (Optional) |
| <i>vrf-name</i>         | (Optional) |
| TABLE_peer              | (Optional) |
| <i>inheritingpeer</i>   | (Optional) |
| <i>interface-parent</i> | (Optional) |

**Command Mode**

- /exec

## show bgp prefix-list

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } } prefix-list { <prfxlist-name> | <test_pol_name> } [ vrf { <vrf-name>
| <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out>
TABLE_afi <afi> TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [
<rd_vrf> ] [ <rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion>
<totalpaths> <bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [
<table-map-filtered> ] [ <export-on-newlist> <export-on-xmitlist> ] [ <srv6-local-sid> ] [ <locallabel> ] [
<labelhldwstr> ] [ <mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode>
<typecode> { <ipnexthop> | <ipv6nexthop> } { { <inlabel> <outlabel> <vpn> <hold_down> } | { <weight>
<aspath> <origin> [ <metric> ] [ <localpref> ] } } } | [ <policyincomplete> <pathvalid> <pathbest>
<patheoriginated> <pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath>
<pathnolabeledrnh> <pathlocator> ] [ <importsourc> [ <originalimportsourc> ] ] [ <importdestscout> ] [
TABLE_importdests <importdest> ] [ <existpath> ] [ <gwip> | <ipv6gwip> ] [ <aspath> <source> ] {
<ipnexthop> | <ipv6nexthop> } <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin>
[ <metric> ] <localpref> <weight> [ <aggregator> <aggregators> <atomicaggregate> ] [ <inlabel> ] [
<originflag> ] [ { TABLE_community <community> } ] [ { TABLE_extcommunity <extcommunity> } ] [
<originatorid> { TABLE_clusterlist <clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime>
<flapflags> <flapindex> <flaphalf-life> <flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len>
<con_rd> <con_ip> ] [ <psid_len> [ <psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len>
<psid_sub_type> <psid_v6sid> <psid_func_len> <psid_trans_len> <psid_trans_off> ] [ <psid_origrsgb_len>
<psid_origrsgb_flag> <psid_origrsgb_base> <psid_origrsgb_end> ] ] [ <remotenh> <remotenh_encap>
<remotenh_vnid> <remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [
<tunnel-encap-attr-len> ] [ <mdt_grp_addr> ] [ TABLE_path_attr_list <path_attr_list> [ TABLE_attr
<attr_num> <attr_code_str> <attr_code_hex> <attr_flags> <attr_len> [ TABLE_attr_val <attr_value> ] ] ] [
<attrset_origin_as> <attrset_origin> <attrset_metric> <attrset_localpref> [ <attrset_aspath> ] [
<attrset_originatorid> { TABLE_attrset_clusterlist <attrset_clusterlist> } ] ] ] ] ] [ TABLE_advertisedto
<advertisedto> ] [ TABLE_scheduledto <scheduledto> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| bgp                   | Display BGP status and configuration            |
| vrf                   | (Optional) Virtual Router Context               |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| prefix-list           | Display routes matching the prefix-list         |
| <i>prfxlist-name</i>  | Name of prefix-list                             |
| <i>test_pol_name</i>  | An existing test-list policy                    |
| ipv4                  | Display BGP information for IPv4 address family |
| ipv6                  | Display BGP information for IPv6 address family |

|                      |  |
|----------------------|--|
| unicast              | Display BGP information for unicast address family   |
| multicast            | Display BGP information for multicast address family |
| <i>__readonly__</i>  | (Optional)   |
| TABLE_vrf            | (Optional)   |
| <i>vrf-name-out</i>  | (Optional)   |
| TABLE_afi            | (Optional)   |
| <i>afi</i>           | (Optional)   |
| TABLE_safi           | (Optional)   |
| <i>safi</i>          | (Optional)   |
| <i>af-name</i>       | (Optional)   |
| <i>table-version</i> | (Optional)   |
| <i>router-id</i>     | (Optional)   |
| TABLE_rd             | (Optional)   |
| <i>rd_val</i>        | (Optional)   |
| <i>rd_vrf</i>        | (Optional)   |
| <i>rd_vniid</i>      | (Optional)   |
| TABLE_prefix         | (Optional)   |
| <i>ipprefix</i>      | (Optional)   |
| <i>nonipprefix</i>   | (Optional)   |
| <i>totalpaths</i>    | (Optional)   |
| <i>bestpathnr</i>    | (Optional)   |
| <i>mpath</i>         | (Optional)   |
| TABLE_advertisedto   | (Optional)   |
| <i>advertisedto</i>  | (Optional)   |
| TABLE_scheduledto    | (Optional)   |
| <i>scheduledto</i>   | (Optional)   |
| <i>prefixversion</i> | (Optional)   |
| <i>on-newlist</i>    | (Optional)   |
| <i>on-xmitlist</i>   | (Optional)   |

|                             |            |
|-----------------------------|------------|
| <i>suppressed</i>           | (Optional) |
| <i>needsresync</i>          | (Optional) |
| <i>locked</i>               | (Optional) |
| <i>table-map-filtered</i>   | (Optional) |
| <i>export-on-newlist</i>    | (Optional) |
| <i>export-on-xmitlist</i>   | (Optional) |
| <i>locallabel</i>           | (Optional) |
| <i>labelhldwstr</i>         | (Optional) |
| TABLE_path                  | (Optional) |
| <i>pathnr</i>               | (Optional) |
| <i>best</i>                 | (Optional) |
| <i>status</i>               | (Optional) |
| <i>type</i>                 | (Optional) |
| <i>statuscode</i>           | (Optional) |
| <i>bestcode</i>             | (Optional) |
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>aspath</i>             | (Optional) |
| <i>origin</i>             | (Optional) |
| <i>source</i>             | (Optional) |
| <i>policyincomplete</i>   | (Optional) |
| <i>pathvalid</i>          | (Optional) |
| <i>pathbest</i>           | (Optional) |
| <i>pathreoriginated</i>   | (Optional) |
| <i>pathdeleted</i>        | (Optional) |
| <i>pathstaled</i>         | (Optional) |
| <i>pathhistory</i>        | (Optional) |
| <i>pathmultipath</i>      | (Optional) |
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappenalty</i>        | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>psid_v6sid_len</i>       | (Optional) |
| <i>psid_sub_type</i>        | (Optional) |
| <i>psid_func_len</i>        | (Optional) |
| <i>psid_trans_len</i>       | (Optional) |
| <i>psid_trans_off</i>       | (Optional) |
| <i>psid_origsrgb_len</i>    | (Optional) |
| <i>psid_origsrgb_flag</i>   | (Optional) |
| <i>psid_origsrgb_base</i>   | (Optional) |
| <i>psid_origsrgb_end</i>    | (Optional) |
| TABLE_path_attr_list        | (Optional) |
| <i>path_attr_list</i>       | (Optional) |
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec



## show bgp private attr

```
show bgp private attr [ { ipv4 { unicast | multicast } <ip-prefix> } | { ipv6 { unicast | multicast } <ipv6-prefix> } | database | as-path | nve-peer | community | extcommunity | srte-policy | prefix-sid | srv6 | attrset ] [ brief ]
```

### Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information                                 |
| bgp              | Display BGP status and configuration                            |
| private          | Show BGP information intended for developer eyes only           |
| attr             | Show BGP attributes   |
| ipv4             | (Optional) Display BGP information for IPv4 address family      |
| ipv6             | (Optional) Display BGP information for IPv6 address family      |
| unicast          | (Optional) Display BGP information for unicast address family   |
| multicast        | (Optional) Display BGP information for multicast address family |
| database         | (Optional) Show attribute set table                             |
| as-path          | (Optional) Show AS-PATH attribute table                         |
| nve-peer         | (Optional) Show NVE peer attribute table                        |
| community        | (Optional) Show community attribute table                       |
| extcommunity     | (Optional) Show extended community attribute table              |
| srte-policy      | (Optional) Show SRTE policy attribute table                     |
| prefix-sid       | (Optional) Show prefix SID attribute table                      |
| srv6             | (Optional) Show SRv6 attribute table                            |
| attrset          | (Optional) Show ATTRSET attribute table                         |
| brief            | (Optional) Show brief info                                      |
| <i>ip-prefix</i> | (Optional) Show attribute for a prefix                          |

### Command Mode

- /exec

# show bgp private debug history

show bgp private debug history { all | ead-es | es | mac | cloudsec }

## Syntax Description

|          |   |
|----------|---|
| show     | Show running system information                       |
| bgp      | Display BGP status and configuration                  |
| private  | Show BGP information intended for developer eyes only |
| debug    | Debug   |
| history  | history   |
| all      | all   |
| ead-es   | ead-es  |
| es       | es  |
| mac      | mac   |
| cloudsec | cloudsec  |

## Command Mode

- /exec

## show bgp process

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] process [ detail ] [
vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ [ <processid>
<protocolstartedreason> <protocoltag> <protocolstate> [ <clibinarydone> <cliasciidone> ] <isolatemode>
<gshut-aware> <gshut-activate> [ <gshut-map> ] <mmode> <memorystate> [ <mallocmemorystate> ] [
<platformmemorystate> ] [ <lowmemorytimer> ] [ <issu> ] <forwardingstatesaved> <asformat> [ <fabricsoo>
] [ <srgbmin> <srgbmax> ] [ <epeconfiguredpeers> <epeactivepeers> ] <attributeentries> <hwmattributeentries>
<bytesused> <entriespendingdelete> <hwmentriespendingdelete> <pathsperattribute> <aspathentries>
<aspathbytes> ] TABLE_vrf <vrf-name-out> [ <vrf-id> ] [ <vrf-state> ] [ <vrf-state-rsn> ] [
<vrf-delete-pending> ] [ <vrf-evpn-mpls> ] [ <vrf-vni-id> ] [ <vrf-vni-id-valid> ] [ <vrf-topo-id> ] [
<vrf-encap-type> ] [ <vrf-vtep-ip> ] [ <vrf-vtep-virtual-ip> ] [ <vrf-vtep-vip> ] [ <vrf-router-mac> ] [
<vrf-vip-router-mac> ] [ <vrf-vipr-router-mac> ] [ <vrf-router-id> ] [ <vrf-cfgd-id> ] [ <vrf-local-as> ] [
<vrf-confed-id> ] [ <vrf-cluster-id> ] [ <vrf-reconnect-interval> ] [ <vrf-peers> ] [ <vrf-pending-peers> ] [
<vrf-est-peers> ] [ <vrf-cfgd-max-as-limit> ] [ <vrf-max-as-limit> ] [ <vrf-rd-configured> ] [ <vrf-rd> ] [
<vrf-secondary-rd-configured> ] [ <vrf-secondary-rd> ] [ <vrf-pending-rd> ] [ <vrf-pending-secondary-rd>
] { TABLE_af <af-id> [ <af-name> ] [ <af-table-id> ] [ <af-state> ] [ <af-state-rsn> ] [ <af-num-peers> ] [
<af-num-active-peers> ] [ <af-peer-routes> ] [ <af-peer-paths> ] [ <af-peer-networks> ] [ <af-peer-aggregates>
] [ <af-export-rmap> ] [ <af-import-rmap> ] [ <af-retain-rt> ] [ { TABLE_redist <protocol> <route-map> }
] <wait-igp-convergence> [ { TABLE_add_paths_selection <route-map> } ] [ TABLE_export_rt <export-rt>
] [ TABLE_import_rt <import-rt> ] [ TABLE_evpn_export_rt <evpn-export-rt> ] [ TABLE_evpn_import_rt
<evpn-import-rt> ] [ TABLE_mvpn_export_rt <mvpn-export-rt> ] [ TABLE_mvpn_import_rt <mvpn-import-rt>
] [ <af-label-mode> ] [ <af-aggregate-label> ] [ <af-alloc-index> ] [ <srv6-sid-locator-name> ] [
<srv6-sid-locator-id> ] [ <srv6-sid-locator-prefix> ] [ <srv6-sid-src-enc-address> ] [ <srv6-vrf-sid-alloc> ] [
<srv6-vrf-dt46-sid> ] [ <srv6-vrf-dt-sid-alloc-pending> ] [ <srv6-vrf-dt-sid-del-pending> ] [
<srv6-vrf-sid-alloc-pending-reason> ] [ <srv6-tbl-sid-alloc> ] [ <srv6-tbl-dt-type> ] [ <srv6-tbl-dt-sid> ] [
<srv6-tbl-dt-sid-alloc-pending> ] [ <srv6-tbl-dt-sid-del-pending> ] [ <srv6-tbl-dt-sid-alloc-pending-reason>
] [ <srv6-alloc-mode> ] [ <importdefault_prefixlimit> <importdefault_prefixcount> <importdefault_map>
<importdefault_advertisevpn> ] <import_vrf_advertisevpn> [ <exportdefault_prefixlimit>
<exportdefault_prefixcount> <exportdefault_map> <exportdefault_allowvpn> ] <export_vrf_allowvpn>
<af-rr> <default-information-enabled> [ <default-information-rd> <default-information-rt> ]
<nexthop-trigger-delay-critical> <nexthop-trigger-delay-non-critical> [ <nexthop-route-map> ] } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information           |
| bgp                   | Display BGP status and configuration      |
| process               | BGP global information                    |
| detail                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| vrf                   | (Optional) Virtual Router Context         |
| <i>vrf-name</i>       | (Optional) VRF name                       |
| <i>vrf-known-name</i> | (Optional) Known VRF name                 |
| <i>__readonly__</i>   | (Optional) Read Only                      |
| <i>processid</i>      | (Optional)                                |

|                                |            |
|--------------------------------|------------|
| <i>protocolstartedreason</i>   | (Optional) |
| <i>protocoltag</i>             | (Optional) |
| <i>protocolstate</i>           | (Optional) |
| <i>clibinarydone</i>           | (Optional) |
| <i>cliasciidone</i>            | (Optional) |
| <i>isolatemode</i>             | (Optional) |
| <i>gshut-aware</i>             | (Optional) |
| <i>gshut-activate</i>          | (Optional) |
| <i>gshut-map</i>               | (Optional) |
| <i>mmode</i>                   | (Optional) |
| <i>memorystate</i>             | (Optional) |
| <i>mallocmemorystate</i>       | (Optional) |
| <i>platformmemorystate</i>     | (Optional) |
| <i>lowmemorytimer</i>          | (Optional) |
| <i>issu</i>                    | (Optional) |
| <i>forwardingstatesaved</i>    | (Optional) |
| <i>asformat</i>                | (Optional) |
| <i>attributeentries</i>        | (Optional) |
| <i>fabricsoo</i>               | (Optional) |
| <i>srgbmin</i>                 | (Optional) |
| <i>srgbmax</i>                 | (Optional) |
| <i>epeconfiguredpeers</i>      | (Optional) |
| <i>epeactivepeers</i>          | (Optional) |
| <i>hwmattributeentries</i>     | (Optional) |
| <i>bytesused</i>               | (Optional) |
| <i>entriespendingdelete</i>    | (Optional) |
| <i>hwmentriespendingdelete</i> | (Optional) |
| <i>pathsperattribute</i>       | (Optional) |
| <i>aspathentries</i>           | (Optional) |

|                               |   |
|-------------------------------|---|
| <i>aspathbytes</i>            | (Optional)  |
| TABLE_vrf                     | (Optional)  |
| <i>vrf-name-out</i>           | (Optional) VRF name                               |
| <i>vrf-id</i>                 | (Optional) VRF ID                                 |
| <i>vrf-state</i>              | (Optional) VRF State                              |
| <i>vrf-state-rsn</i>          | (Optional) VRF State Reason                       |
| <i>vrf-delete-pending</i>     | (Optional) VRF delete pending                     |
| <i>vrf-evpn-mpls</i>          | (Optional) VRF EVPN L3 MPLS                       |
| <i>vrf-vni-id</i>             | (Optional) VRF VNI ID                             |
| <i>vrf-vni-id-valid</i>       | (Optional) VRF VNI ID validity                    |
| <i>vrf-topo-id</i>            | (Optional) VRF Topo ID                            |
| <i>vrf-encap-type</i>         | (Optional) VRF encapsulation type                 |
| <i>vrf-vtep-ip</i>            | (Optional) VRF VTEP IP                            |
| <i>vrf-vtep-virtual-ip</i>    | (Optional) VRF VTEP Virtual IP                    |
| <i>vrf-vtep-vipr</i>          | (Optional) VRF VTEP Virtual IP for Re-origination |
| <i>vrf-router-mac</i>         | (Optional) VRF Router MAC                         |
| <i>vrf-vip-router-mac</i>     | (Optional) VRF VIP Router MAC                     |
| <i>vrf-vipr-router-mac</i>    | (Optional) VRF VIPR Router MAC                    |
| <i>vrf-router-id</i>          | (Optional) Router ID                              |
| <i>vrf-cfgd-id</i>            | (Optional) Configured Router-ID                   |
| <i>vrf-local-as</i>           | (Optional) Local AS                               |
| <i>vrf-confed-id</i>          | (Optional) Cluster-ID                             |
| <i>vrf-cluster-id</i>         | (Optional) Cluster-ID                             |
| <i>vrf-reconnect-interval</i> | (Optional) VRF reconnect interval                 |
| <i>vrf-peers</i>              | (Optional) No. of configured peers                |
| <i>vrf-pending-peers</i>      | (Optional) No. of pending peers                   |
| <i>vrf-est-peers</i>          | (Optional) No. of established peers               |
| <i>vrf-cfgd-max-as-limit</i>  | (Optional) Configured maxas-limit                 |
| <i>vrf-max-as-limit</i>       | (Optional) Active maxas-limit                     |

|                                    |  |
|------------------------------------|--|
| <i>vrf-rd-configured</i>           | (Optional) VRF RD Configured           |
| <i>vrf-rd</i>                      | (Optional) VRF RD                      |
| <i>vrf-secondary-rd-configured</i> | (Optional) VRF Secondary RD Configured |
| <i>vrf-secondary-rd</i>            | (Optional) VRF Secondary RD            |
| <i>vrf-pending-rd</i>              | (Optional) VRF pending RD              |
| <i>vrf-pending-secondary-rd</i>    | (Optional) VRF pending secondary RD    |
| TABLE_af                           | (Optional)                             |
| <i>af-id</i>                       | (Optional) AF ID                       |
| <i>af-table-id</i>                 | (Optional) AF table                    |
| <i>af-name</i>                     | (Optional) AF table name               |
| <i>af-state</i>                    | (Optional) AF table state              |
| <i>af-state-rsn</i>                | (Optional) AF table state reason       |
| <i>af-num-peers</i>                | (Optional) No. of peers                |
| <i>af-num-active-peers</i>         | (Optional) No. of active peers         |
| <i>af-peer-routes</i>              | (Optional) No. of peer routes          |
| <i>af-peer-paths</i>               | (Optional) No. of peer paths           |
| <i>af-peer-networks</i>            | (Optional) No. of peer networks        |
| <i>af-peer-aggregates</i>          | (Optional) No. of aggregates           |
| <i>af-export-rmap</i>              | (Optional) Export route-map            |
| <i>af-import-rmap</i>              | (Optional) Import route-map            |
| <i>af-retain-rt</i>                | (Optional) Retain RT                   |
| TABLE_redist                       | (Optional)                             |
| <i>protocol</i>                    | (Optional) Protocol                    |
| <i>route-map</i>                   | (Optional) Route Map                   |
| <i>wait-igp-convergence</i>        | (Optional)                             |
| TABLE_add_paths_selection          | (Optional)                             |
| <i>route-map</i>                   | (Optional) Route Map                   |
| TABLE_export_rt                    | (Optional)                             |
| <i>export-rt</i>                   | (Optional) Export route-target         |

|   |   |
|---|---|
| TABLE_import_rt                             | (Optional)                                      |
| <i>import-rt</i>                            | (Optional) Import route-target                  |
| TABLE_evpn_export_rt                        | (Optional)                                      |
| <i>evpn-export-rt</i>                       | (Optional) Export EVPN route-target             |
| TABLE_evpn_import_rt                        | (Optional)                                      |
| <i>evpn-import-rt</i>                       | (Optional) Import EVPN route-target             |
| TABLE_mvpn_export_rt                        | (Optional)                                      |
| <i>mvpn-export-rt</i>                       | (Optional) Export MVPN route-target             |
| TABLE_mvpn_import_rt                        | (Optional)                                      |
| <i>mvpn-import-rt</i>                       | (Optional) Import MVPN route-target             |
| <i>af-label-mode</i>                        | (Optional) Label allocation mode                |
| <i>af-aggregate-label</i>                   | (Optional) Aggregate Label                      |
| <i>af-alloc-index</i>                       | (Optional) Allocate-Index                       |
| <i>srv6-alloc-mode</i>                      | (Optional) Srv6 sid allocation mode             |
| <i>srv6-sid-locator-name</i>                | (Optional) SRv6 SID Locator Name                |
| <i>srv6-sid-locator-id</i>                  | (Optional) SRv6 SID Locator ID                  |
| <i>srv6-sid-src-enc-address</i>             | (Optional) SRv6 Source Encap Address            |
| <i>srv6-vrf-sid-alloc</i>                   | (Optional) SRv6 VRF SID Allocation Mode         |
| <i>srv6-vrf-dt-sid-alloc-pending</i>        | (Optional) Is SRv6 DT46 SID Allocation: Pending |
| <i>srv6-vrf-dt-sid-del-pending</i>          | (Optional) Is SRv6 DT46 SID Deletion: Pending   |
| <i>srv6-vrf-sid-alloc-pending-reason</i>    | (Optional) SRv6 SID Allocation pending reason:  |
| <i>srv6-tbl-sid-alloc</i>                   | (Optional) SRv6 table ctx SID allocation mode   |
| <i>srv6-tbl-dt-type</i>                     | (Optional) SRv6 DT type                         |
| <i>srv6-tbl-dt-sid</i>                      | (Optional) SRv6 table per VRF SID :             |
| <i>srv6-tbl-dt-sid-alloc-pending</i>        | (Optional) SRv6 SID Allocation: Pending         |
| <i>srv6-tbl-dt-sid-del-pending</i>          | (Optional) SRv6 SID Deletion: Pending           |
| <i>srv6-tbl-dt-sid-alloc-pending-reason</i> | (Optional) SRV6 SID Allocation Pending Reason   |
| <i>importdefault_prefixlimit</i>            | (Optional) Maximum number of prefixes allowed   |
| <i>importdefault_prefixcount</i>            | (Optional) Current number of prefixes           |

|   |   |
|---|---|
| <i>importdefault_map</i>                  | (Optional) Configured route-map                     |
| <i>importdefault_advertisevpn</i>         | (Optional) Advertise-vpn is enabled                 |
| <i>import_vrf_advertisevpn</i>            | (Optional) Advertise-vpn is enabled                 |
| <i>exportdefault_prefixlimit</i>          | (Optional) Maximum number of prefixes allowed       |
| <i>exportdefault_prefixcount</i>          | (Optional) Current number of prefixes               |
| <i>exportdefault_map</i>                  | (Optional) Configured route-map                     |
| <i>exportdefault_allowvpn</i>             | (Optional) Allow-vpn is enabled                     |
| <i>export_vrf_allowvpn</i>                | (Optional) Allow-vpn is enabled                     |
| <i>af-rr</i>                              | (Optional) Is a Route-reflector                     |
| <i>default-information-enabled</i>        | (Optional) Default-information originate is enabled |
| <i>default-information-rd</i>             | (Optional) Default-information originate RD         |
| <i>default-information-rt</i>             | (Optional) Default-information originate RT         |
| <i>nexthop-trigger-delay-critical</i>     | (Optional)  |
| <i>nexthop-trigger-delay-non-critical</i> | (Optional)  |
| <i>nexthop-route-map</i>                  | (Optional)  |

**Command Mode**

- /exec





|                           |  |
|---------------------------|--|
| <i>ext-comm-rd-aa2nn4</i> | (Optional) VPN route distinguisher in aa:nn format         |
| ipv4                      | Display BGP information for IPv4 address family            |
| ipv6                      | Display BGP information for IPv6 address family            |
| vpn4                      | Display BGP information for VPNv4 address family           |
| vpn6                      | Display BGP information for VPNv6 address family           |
| unicast                   | Display BGP information for unicast address family         |
| multicast                 | Display BGP information for multicast address family       |
| mdt                       | Display BGP information for multicast distribution tree    |
| labeled-unicast           | Display BGP information for labeled-unicast address family |
| link-state                | Display BGP information for link-state address family      |
| l2vpn                     | Display BGP information for L2VPN address family           |
| vpls                      | Display BGP information for L2VPN VPLS address family      |
| mvpn                      | Display BGP information for MVPN address family            |
| evpn                      | Display BGP information for L2VPN EVPN address family      |
| all                       | Display BGP information for all address families           |
| private                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                  |
| <i>__readonly__</i>       | (Optional)   |
| TABLE_vrf                 | (Optional)   |
| <i>vrf-name-out</i>       | (Optional)   |
| TABLE_afi                 | (Optional)   |
| <i>afi</i>                | (Optional)   |
| TABLE_safi                | (Optional)   |
| <i>safi</i>               | (Optional)   |
| <i>af-name</i>            | (Optional)   |
| <i>table-version</i>      | (Optional)   |
| <i>router-id</i>          | (Optional)   |
| TABLE_rd                  | (Optional)   |
| <i>rd_val</i>             | (Optional)   |
| <i>rd_vrf</i>             | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>rd_vniid</i>           | (Optional) |
| TABLE_prefix              | (Optional) |
| <i>ipprefix</i>           | (Optional) |
| <i>nonipprefix</i>        | (Optional) |
| <i>totalpaths</i>         | (Optional) |
| <i>bestpathnr</i>         | (Optional) |
| <i>mpath</i>              | (Optional) |
| TABLE_advertisedto        | (Optional) |
| <i>advertisedto</i>       | (Optional) |
| TABLE_scheduledto         | (Optional) |
| <i>scheduledto</i>        | (Optional) |
| <i>prefixversion</i>      | (Optional) |
| <i>on-newlist</i>         | (Optional) |
| <i>on-xmitlist</i>        | (Optional) |
| <i>suppressed</i>         | (Optional) |
| <i>needsresync</i>        | (Optional) |
| <i>locked</i>             | (Optional) |
| <i>table-map-filtered</i> | (Optional) |
| <i>export-on-newlist</i>  | (Optional) |
| <i>export-on-xmitlist</i> | (Optional) |
| <i>locallabel</i>         | (Optional) |
| <i>labelhldwstr</i>       | (Optional) |
| TABLE_path                | (Optional) |
| <i>pathnr</i>             | (Optional) |
| <i>best</i>               | (Optional) |
| <i>status</i>             | (Optional) |
| <i>type</i>               | (Optional) |
| <i>statuscode</i>         | (Optional) |
| <i>bestcode</i>           | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |
| <i>source</i>               | (Optional) |
| <i>policyincomplete</i>     | (Optional) |
| <i>pathvalid</i>            | (Optional) |
| <i>pathbest</i>             | (Optional) |
| <i>pathreoriginated</i>     | (Optional) |
| <i>pathdeleted</i>          | (Optional) |
| <i>pathstaled</i>           | (Optional) |
| <i>pathhistory</i>          | (Optional) |
| <i>pathmultipath</i>        | (Optional) |
| <i>pathovermaxaslimit</i>   | (Optional) |
| <i>pathnolabeledrn</i>      | (Optional) |
| <i>pathlocator</i>          | (Optional) |
| <i>nexthopmetric</i>        | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>aggregator</i>            | (Optional) |
| <i>aggregatoras</i>          | (Optional) |
| <i>atomicaggregate</i>       | (Optional) |
| <i>inlabel</i>               | (Optional) |
| <i>originflag</i>            | (Optional) |
| <i>vpn</i>                   | (Optional) |
| <i>hold_down</i>             | (Optional) |
| <i>outlabel</i>              | (Optional) |
| <i>flappenalty</i>           | (Optional) |
| <i>dampenedtime</i>          | (Optional) |
| <i>flaps</i>                 | (Optional) |
| <i>flaptime</i>              | (Optional) |
| <i>flapflags</i>             | (Optional) |
| <i>flapindex</i>             | (Optional) |
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |

## show bgp received-paths

|                           |            |
|---------------------------|------------|
| TABLE_extcommunity        | (Optional) |
| <i>extcommunity</i>       | (Optional) |
| <i>originatorid</i>       | (Optional) |
| TABLE_clusterlist         | (Optional) |
| <i>clusterlist</i>        | (Optional) |
| <i>remotenh</i>           | (Optional) |
| <i>remotenh_encap</i>     | (Optional) |
| <i>remotenh_vnid</i>      | (Optional) |
| <i>remotenh_mac</i>       | (Optional) |
| <i>pmsi</i>               | (Optional) |
| <i>psid_len</i>           | (Optional) |
| <i>psid_lindx_len</i>     | (Optional) |
| <i>psid_lindx_flag</i>    | (Optional) |
| <i>psid_lindx</i>         | (Optional) |
| <i>psid_v6sid_len</i>     | (Optional) |
| <i>psid_sub_type</i>      | (Optional) |
| <i>psid_func_len</i>      | (Optional) |
| <i>psid_trans_len</i>     | (Optional) |
| <i>psid_trans_off</i>     | (Optional) |
| <i>psid_origsrgb_len</i>  | (Optional) |
| <i>psid_origsrgb_flag</i> | (Optional) |
| <i>psid_origsrgb_base</i> | (Optional) |
| <i>psid_origsrgb_end</i>  | (Optional) |
| TABLE_path_attr_list      | (Optional) |
| <i>path_attr_list</i>     | (Optional) |
| TABLE_attr                | (Optional) |
| <i>attr_num</i>           | (Optional) |
| <i>attr_code_str</i>      | (Optional) |
| <i>attr_code_hex</i>      | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp regexp

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } regexp <regexp-str> [ vrf { <vrf-name> | <vrf-known-name>
| ALL_VRFS_012345678901234 } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi>
TABLE_safi <safi> <af-name> [ <table-version> <router-id> ] [ TABLE_rd [ <rd_val> [ <rd_vrf> ] [
<rd_vniid> ] ] [ TABLE_prefix { <ipprefix> | <ipv6prefix> | <nonipprefix> } [ <prefixversion> <totalpaths>
<bestpathnr> [ <on-newlist> <on-xmitlist> <suppressed> <needsresync> <locked> ] [ <table-map-filtered>
] [ <export-on-newlist> <export-on-xmitlist> ] [ <srv6-local-sid> ] [ <locallabel> ] [ <labelhldwstr> ] [
<mpath> ] ] { TABLE_path <pathnr> { { <status> <best> <type> <statuscode> <bestcode> <typecode> {
<ipnexthop> | <ipv6nexthop> } { <inlabel> <outlabel> <vpn> <hold_down> } } { <weight> <aspath>
<origin> [ <metric> ] [ <localpref> ] } } } [ <policyincomplete> <pathvalid> <pathbest> <pathreoriginated>
<pathdeleted> <pathstaled> <pathhistory> <pathovermaxaslimit> <pathmultipath> <pathnolabeledrn>
<pathlocator> ] [ <importsource> [ <originalimportsource> ] ] [ <importdestscount> ] [ TABLE_importdests
<importdest> ] [ <existpath> ] [ <gwip> | <ipv6gwip> ] [ <aspath> <source> ] { <ipnexthop> | <ipv6nexthop>
} <nexthopmetric> { <neighbor> | <ipv6neighbor> } <neighborid> <origin> [ <metric> ] <localpref> <weight>
[ <aggregator> <aggregators> <atomicaggregate> ] [ <inlabel> ] [ <originflag> ] [ { TABLE_community
<community> } ] [ { TABLE_extcommunity <extcommunity> } ] [ <originatorid> { TABLE_clusterlist
<clusterlist> } ] [ <flappenalty> <dampenedtime> <flaps> <flaptime> <flapflags> <flapindex> <flaphalflife>
<flapreuse> <flapsuppress> <flapmax> ] [ <con_type> <con_len> <con_rd> <con_ip> ] [ <psid_len> [
<psid_lindx_len> <psid_lindx_flag> <psid_lindx> ] [ <psid_v6sid_len> <psid_sub_type> <psid_v6sid>
<psid_func_len> <psid_trans_len> <psid_trans_off> ] [ <psid_origsrgrb_len> <psid_origsrgrb_flag>
<psid_origsrgrb_base> <psid_origsrgrb_end> ] ] [ <remotenh> <remotenh_encap> <remotenh_vnid>
<remotenh_mac> ] [ <pmsi> ] [ <evpn-esi> ] [ <link-state-attr> <link-state-attr-len> ] [ <tunnel-encap-attr-len>
] [ <mdt_grp_addr> ] [ TABLE_path_attr_list <path_attr_list> [ TABLE_attr <attr_num> <attr_code_str>
<attr_code_hex> <attr_flags> <attr_len> [ TABLE_attr_val <attr_value> ] ] ] [ <attrset_origin_as>
<attrset_origin> <attrset_metric> <attrset_localpref> [ <attrset_aspath> ] [ <attrset_originatorid> {
TABLE_attrset_clusterlist <attrset_clusterlist> } ] ] } } [ TABLE_advertisedto <advertisedto> ] [
TABLE_scheduledto <scheduledto> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| bgp                   | Display BGP status and configuration                 |
| vrf                   | (Optional) Virtual Router Context                    |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| ipv4                  | Display BGP information for IPv4 address family      |
| ipv6                  | Display BGP information for IPv6 address family      |
| unicast               | Display BGP information for unicast address family   |
| multicast             | Display BGP information for multicast address family |
| all                   | Display BGP information for all address families     |



|                      |  |
|----------------------|--|
| regexp               | Display routes matching the AS path regular expression |
| <i>regexp-str</i>    | Regular expression to match the AS paths               |
| <i>__readonly__</i>  | (Optional)   |
| TABLE_vrf            | (Optional)   |
| <i>vrf-name-out</i>  | (Optional)   |
| TABLE_afi            | (Optional)   |
| <i>afi</i>           | (Optional)   |
| TABLE_safi           | (Optional)   |
| <i>safi</i>          | (Optional)   |
| <i>af-name</i>       | (Optional)   |
| <i>table-version</i> | (Optional)   |
| <i>router-id</i>     | (Optional)   |
| TABLE_rd             | (Optional)   |
| <i>rd_val</i>        | (Optional)   |
| <i>rd_vrf</i>        | (Optional)   |
| <i>rd_vniid</i>      | (Optional)   |
| TABLE_prefix         | (Optional)   |
| <i>ipprefix</i>      | (Optional)   |
| <i>nonipprefix</i>   | (Optional)   |
| <i>totalpaths</i>    | (Optional)   |
| <i>bestpathnr</i>    | (Optional)   |
| <i>mpath</i>         | (Optional)   |
| TABLE_advertisedto   | (Optional)   |
| <i>advertisedto</i>  | (Optional)   |
| TABLE_scheduledto    | (Optional)   |
| <i>scheduledto</i>   | (Optional)   |
| <i>prefixversion</i> | (Optional)   |
| <i>on-newlist</i>    | (Optional)   |
| <i>on-xmitlist</i>   | (Optional)   |

|                             |            |
|-----------------------------|------------|
| <i>suppressed</i>           | (Optional) |
| <i>needsresync</i>          | (Optional) |
| <i>locked</i>               | (Optional) |
| <i>table-map-filtered</i>   | (Optional) |
| <i>export-on-newlist</i>    | (Optional) |
| <i>export-on-xmitlist</i>   | (Optional) |
| <i>locallabel</i>           | (Optional) |
| <i>labelhldwstr</i>         | (Optional) |
| TABLE_path                  | (Optional) |
| <i>pathnr</i>               | (Optional) |
| <i>best</i>                 | (Optional) |
| <i>status</i>               | (Optional) |
| <i>type</i>                 | (Optional) |
| <i>statuscode</i>           | (Optional) |
| <i>bestcode</i>             | (Optional) |
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>aspath</i>             | (Optional) |
| <i>origin</i>             | (Optional) |
| <i>source</i>             | (Optional) |
| <i>policyincomplete</i>   | (Optional) |
| <i>pathvalid</i>          | (Optional) |
| <i>pathbest</i>           | (Optional) |
| <i>pathreoriginated</i>   | (Optional) |
| <i>pathdeleted</i>        | (Optional) |
| <i>pathstaled</i>         | (Optional) |
| <i>pathhistory</i>        | (Optional) |
| <i>pathmultipath</i>      | (Optional) |
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappenalty</i>        | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>flaphalflife</i>          | (Optional) |
| <i>flapreuse</i>             | (Optional) |
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>psid_v6sid_len</i>       | (Optional) |
| <i>psid_sub_type</i>        | (Optional) |
| <i>psid_func_len</i>        | (Optional) |
| <i>psid_trans_len</i>       | (Optional) |
| <i>psid_trans_off</i>       | (Optional) |
| <i>psid_origsrgb_len</i>    | (Optional) |
| <i>psid_origsrgb_flag</i>   | (Optional) |
| <i>psid_origsrgb_base</i>   | (Optional) |
| <i>psid_origsrgb_end</i>    | (Optional) |
| TABLE_path_attr_list        | (Optional) |
| <i>path_attr_list</i>       | (Optional) |
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp segment-routing srv6

```
show bgp segment-routing srv6 [ __readonly__ [ <locator-name> <locator-id> <locator-prefix> ] [ TABLE_vrf
<vrf-name-out> [ <vrf-srv6-sid> ] [ TABLE_af <af-name> <af-dt> <table-srv6-sid> ] ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information          |
| bgp                 | Display BGP status and configuration     |
| segment-routing     | Display segment-routing information      |
| srv6                | Display segment-routing srv6 information |
| <i>__readonly__</i> | (Optional)                               |
| <i>locator-name</i> | (Optional)                               |
| <i>locator-id</i>   | (Optional)                               |
| TABLE_vrf           | (Optional)                               |
| <i>vrf-name-out</i> | (Optional)                               |
| TABLE_af            | (Optional)                               |
| <i>af-name</i>      | (Optional)                               |
| <i>af-dt</i>        | (Optional)                               |

### Command Mode

- /exec



|                                 |            |
|---------------------------------|------------|
| <code>__readonly__</code>       | (Optional) |
| <code>TABLE_vrf</code>          | (Optional) |
| <code>vrf-name-out</code>       | (Optional) |
| <code>TABLE_afi</code>          | (Optional) |
| <code>afi</code>                | (Optional) |
| <code>TABLE_safi</code>         | (Optional) |
| <code>safi</code>               | (Optional) |
| <code>af-name</code>            | (Optional) |
| <code>table-version</code>      | (Optional) |
| <code>router-id</code>          | (Optional) |
| <code>TABLE_rd</code>           | (Optional) |
| <code>rd_val</code>             | (Optional) |
| <code>rd_vrf</code>             | (Optional) |
| <code>rd_vniid</code>           | (Optional) |
| <code>TABLE_prefix</code>       | (Optional) |
| <code>ipprefix</code>           | (Optional) |
| <code>nonipprefix</code>        | (Optional) |
| <code>totalpaths</code>         | (Optional) |
| <code>bestpathnr</code>         | (Optional) |
| <code>mpath</code>              | (Optional) |
| <code>TABLE_advertisedto</code> | (Optional) |
| <code>advertisedto</code>       | (Optional) |
| <code>TABLE_scheduledto</code>  | (Optional) |
| <code>scheduledto</code>        | (Optional) |
| <code>prefixversion</code>      | (Optional) |
| <code>on-newlist</code>         | (Optional) |
| <code>on-xmitlist</code>        | (Optional) |
| <code>suppressed</code>         | (Optional) |
| <code>needsresync</code>        | (Optional) |



|                             |            |
|-----------------------------|------------|
| <i>locked</i>               | (Optional) |
| <i>table-map-filtered</i>   | (Optional) |
| <i>export-on-newlist</i>    | (Optional) |
| <i>export-on-xmitlist</i>   | (Optional) |
| <i>locallabel</i>           | (Optional) |
| <i>labelhldwstr</i>         | (Optional) |
| TABLE_path                  | (Optional) |
| <i>pathnr</i>               | (Optional) |
| <i>best</i>                 | (Optional) |
| <i>status</i>               | (Optional) |
| <i>type</i>                 | (Optional) |
| <i>statuscode</i>           | (Optional) |
| <i>bestcode</i>             | (Optional) |
| <i>typecode</i>             | (Optional) |
| <i>ipnexthop</i>            | (Optional) |
| <i>neighbor</i>             | (Optional) |
| <i>neighborid</i>           | (Optional) |
| <i>metric</i>               | (Optional) |
| <i>localpref</i>            | (Optional) |
| <i>weight</i>               | (Optional) |
| <i>importsource</i>         | (Optional) |
| <i>originalimportsource</i> | (Optional) |
| <i>importdestscount</i>     | (Optional) |
| TABLE_importdests           | (Optional) |
| <i>importdest</i>           | (Optional) |
| <i>existpath</i>            | (Optional) |
| <i>gwip</i>                 | (Optional) |
| <i>aspath</i>               | (Optional) |
| <i>origin</i>               | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>source</i>             | (Optional) |
| <i>policyincomplete</i>   | (Optional) |
| <i>pathvalid</i>          | (Optional) |
| <i>pathbest</i>           | (Optional) |
| <i>pathreoriginated</i>   | (Optional) |
| <i>pathdeleted</i>        | (Optional) |
| <i>pathstaled</i>         | (Optional) |
| <i>pathhistory</i>        | (Optional) |
| <i>pathmultipath</i>      | (Optional) |
| <i>pathovermaxaslimit</i> | (Optional) |
| <i>pathnolabeledrn</i>    | (Optional) |
| <i>pathlocator</i>        | (Optional) |
| <i>nexthopmetric</i>      | (Optional) |
| <i>aggregator</i>         | (Optional) |
| <i>aggregatoras</i>       | (Optional) |
| <i>atomicaggregate</i>    | (Optional) |
| <i>inlabel</i>            | (Optional) |
| <i>originflag</i>         | (Optional) |
| <i>vpn</i>                | (Optional) |
| <i>hold_down</i>          | (Optional) |
| <i>outlabel</i>           | (Optional) |
| <i>flappenalty</i>        | (Optional) |
| <i>dampenedtime</i>       | (Optional) |
| <i>flaps</i>              | (Optional) |
| <i>flaptime</i>           | (Optional) |
| <i>flapflags</i>          | (Optional) |
| <i>flapindex</i>          | (Optional) |
| <i>flaphalflife</i>       | (Optional) |
| <i>flapreuse</i>          | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>flapsuppress</i>          | (Optional) |
| <i>flapmax</i>               | (Optional) |
| <i>con_type</i>              | (Optional) |
| <i>con_len</i>               | (Optional) |
| <i>con_rd</i>                | (Optional) |
| <i>con_ip</i>                | (Optional) |
| <i>mdt_grp_addr</i>          | (Optional) |
| <i>evpn-esi</i>              | (Optional) |
| <i>link-state-attr</i>       | (Optional) |
| <i>link-state-attr-len</i>   | (Optional) |
| <i>tunnel-encap-attr-len</i> | (Optional) |
| TABLE_community              | (Optional) |
| <i>community</i>             | (Optional) |
| TABLE_extcommunity           | (Optional) |
| <i>extcommunity</i>          | (Optional) |
| <i>originatorid</i>          | (Optional) |
| TABLE_clusterlist            | (Optional) |
| <i>clusterlist</i>           | (Optional) |
| <i>remotenh</i>              | (Optional) |
| <i>remotenh_encap</i>        | (Optional) |
| <i>remotenh_vnid</i>         | (Optional) |
| <i>remotenh_mac</i>          | (Optional) |
| <i>pmsi</i>                  | (Optional) |
| <i>psid_len</i>              | (Optional) |
| <i>psid_lindx_len</i>        | (Optional) |
| <i>psid_lindx_flag</i>       | (Optional) |
| <i>psid_lindx</i>            | (Optional) |
| <i>psid_v6sid_len</i>        | (Optional) |
| <i>psid_sub_type</i>         | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>psid_func_len</i>        | (Optional) |
| <i>psid_trans_len</i>       | (Optional) |
| <i>psid_trans_off</i>       | (Optional) |
| <i>psid_origsrgb_len</i>    | (Optional) |
| <i>psid_origsrgb_flag</i>   | (Optional) |
| <i>psid_origsrgb_base</i>   | (Optional) |
| <i>psid_origsrgb_end</i>    | (Optional) |
| TABLE_path_attr_list        | (Optional) |
| <i>path_attr_list</i>       | (Optional) |
| TABLE_attr                  | (Optional) |
| <i>attr_num</i>             | (Optional) |
| <i>attr_code_str</i>        | (Optional) |
| <i>attr_code_hex</i>        | (Optional) |
| <i>attr_len</i>             | (Optional) |
| <i>attr_flags</i>           | (Optional) |
| TABLE_attr_val              | (Optional) |
| <i>attr_value</i>           | (Optional) |
| <i>attrset_origin_as</i>    | (Optional) |
| <i>attrset_origin</i>       | (Optional) |
| <i>attrset_metric</i>       | (Optional) |
| <i>attrset_localpref</i>    | (Optional) |
| <i>attrset_aspath</i>       | (Optional) |
| <i>attrset_originatorid</i> | (Optional) |
| TABLE_attrset_clusterlist   | (Optional) |
| <i>attrset_clusterlist</i>  | (Optional) |

**Command Mode**

- /exec

## show bgp sessions

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] sessions [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ __readonly__ <totalpeers>
<totalestablishedpeers> <localas> TABLE_vrf <vrf-name-out> <local-as> <vrfpeers> <vrfestablishedpeers>
<router-id> [ TABLE_neighbor <neighbor-id> <connectionsdropped> [ <interface-parent> ] <remoteas> [
<lastflap> ] [ <lastread> ] [ <lastwrite> ] <state> <localport> <remoteport> <notificationssent>
<notificationreceived> ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information           |
| bgp                          | Display BGP status and configuration      |
| vrf                          | (Optional) Virtual Router Context         |
| <i>vrf-name</i>              | (Optional) VRF name                       |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                 |
| sessions                     | Display session information for all peers |
| <i>__readonly__</i>          | (Optional)                                |
| TABLE_vrf                    | (Optional)                                |
| <i>vrf-name-out</i>          | (Optional)                                |
| <i>local-as</i>              | (Optional)                                |
| <i>totalpeers</i>            | (Optional)                                |
| <i>totalestablishedpeers</i> | (Optional)                                |
| <i>router-id</i>             | (Optional)                                |
| <i>localas</i>               | (Optional)                                |
| <i>vrfpeers</i>              | (Optional)                                |
| <i>vrfestablishedpeers</i>   | (Optional)                                |
| TABLE_neighbor               | (Optional)                                |
| <i>neighbor-id</i>           | (Optional)                                |
| <i>connectionsdropped</i>    | (Optional)                                |
| <i>remoteas</i>              | (Optional)                                |
| <i>interface-parent</i>      | (Optional)                                |
| <i>lastflap</i>              | (Optional)                                |

|                              |            |
|------------------------------|------------|
| <i>lastread</i>              | (Optional) |
| <i>lastwrite</i>             | (Optional) |
| <i>state</i>                 | (Optional) |
| <i>localport</i>             | (Optional) |
| <i>remoteport</i>            | (Optional) |
| <i>notificationssent</i>     | (Optional) |
| <i>notificationsreceived</i> | (Optional) |

**Command Mode**

- /exec

## show bgp statistics

```
show bgp statistics [ __readonly__ <msgsent> <msgrcvd> <bytesent> <bytercvd> <opensent> <openrcvd>
<updatesent> <updaterecvd> <kasent> <karecvd> <notifsent> <notifrcvd> <rrefreshsent> <rrefreshrcvd>
<capsent> <caprcvd> ]
```

### Syntax Description

|                     |                                      |
|---------------------|--------------------------------------|
| show                | Show running system information      |
| bgp                 | Display BGP status and configuration |
| statistics          | BGP global statistics                |
| <i>__readonly__</i> | (Optional)                           |
| <i>msgsent</i>      | (Optional)                           |
| <i>msgrcvd</i>      | (Optional)                           |
| <i>bytesent</i>     | (Optional)                           |
| <i>bytercvd</i>     | (Optional)                           |
| <i>opensent</i>     | (Optional)                           |
| <i>openrcvd</i>     | (Optional)                           |
| <i>updatesent</i>   | (Optional)                           |
| <i>updaterecvd</i>  | (Optional)                           |
| <i>kasent</i>       | (Optional)                           |
| <i>karecvd</i>      | (Optional)                           |
| <i>notifsent</i>    | (Optional)                           |
| <i>notifrcvd</i>    | (Optional)                           |
| <i>rrefreshsent</i> | (Optional)                           |
| <i>rrefreshrcvd</i> | (Optional)                           |
| <i>capsent</i>      | (Optional)                           |
| <i>caprcvd</i>      | (Optional)                           |

### Command Mode

- /exec





|                            |   |
|----------------------------|---|
| link-state                 | Display BGP information for link-state address family |
| l2vpn                      | Display BGP information for L2VPN address family      |
| vpls                       | Display BGP information for L2VPN VPLS address family |
| mvpn                       | Display BGP information for MVPN address family       |
| evpn                       | Display BGP information for L2VPN EVPN address family |
| all                        | Display BGP information for all address families      |
| <i>__readonly__</i>        | (Optional)  |
| TABLE_vrf                  | (Optional)  |
| <i>vrf-name-out</i>        | (Optional) VRF name                                   |
| <i>vrf-id</i>              | (Optional) VRF ID                                     |
| <i>vrf-state</i>           | (Optional) VRF State                                  |
| <i>vrf-state-rsn</i>       | (Optional) VRF State Reason                           |
| <i>vrf-delete-pending</i>  | (Optional) VRF delete pending                         |
| <i>vrf-evpn-mpls</i>       | (Optional) VRF EVPN L3 MPLS                           |
| <i>vrf-vni-id</i>          | (Optional) VRF VNI ID                                 |
| <i>vrf-vni-id-valid</i>    | (Optional) VRF VNI ID validity                        |
| <i>vrf-topo-id</i>         | (Optional) VRF Topo ID                                |
| <i>vrf-encap-type</i>      | (Optional) VRF encapsulation type                     |
| <i>vrf-vtep-ip</i>         | (Optional) VRF VTEP IP                                |
| <i>vrf-vtep-virtual-ip</i> | (Optional) VRF VTEP Virtual IP                        |
| <i>vrf-vtep-vipr</i>       | (Optional) VRF VTEP Virtual IP for Re-origination     |
| <i>vrf-router-mac</i>      | (Optional) VRF Router MAC                             |
| <i>vrf-vip-router-mac</i>  | (Optional) VRF VIP Router MAC                         |
| <i>vrf-vipr-router-mac</i> | (Optional) VRF VIPR Router MAC                        |
| <i>vrf-router-id</i>       | (Optional) Router ID                                  |
| <i>vrf-cfgd-id</i>         | (Optional) Configured Router-ID                       |
| <i>vrf-local-as</i>        | (Optional) Local AS                                   |
| <i>vrf-confed-id</i>       | (Optional) Cluster-ID                                 |
| <i>vrf-cluster-id</i>      | (Optional) Cluster-ID                                 |

|                                    |  |
|------------------------------------|--|
| <i>vrf-reconnect-interval</i>      | (Optional) VRF reconnect interval      |
| <i>vrf-peers</i>                   | (Optional) No. of configured peers     |
| <i>vrf-pending-peers</i>           | (Optional) No. of pending peers        |
| <i>vrf-est-peers</i>               | (Optional) No. of established peers    |
| <i>vrf-cfgd-max-as-limit</i>       | (Optional) Configured maxas-limit      |
| <i>vrf-max-as-limit</i>            | (Optional) Active maxas-limit          |
| <i>vrf-rd-configured</i>           | (Optional) VRF RD Configured           |
| <i>vrf-rd</i>                      | (Optional) VRF RD                      |
| <i>vrf-secondary-rd-configured</i> | (Optional) VRF Secondary RD Configured |
| <i>vrf-secondary-rd</i>            | (Optional) VRF Secondary RD            |
| <i>vrf-pending-rd</i>              | (Optional) VRF pending RD              |
| <i>vrf-pending-secondary-rd</i>    | (Optional) VRF pending secondary RD    |
| TABLE_af                           | (Optional)                             |
| <i>af-id</i>                       | (Optional) AF ID                       |
| <i>af-table-id</i>                 | (Optional) AF table                    |
| <i>af-name</i>                     | (Optional) AF table name               |
| <i>af-state</i>                    | (Optional) AF table state              |
| <i>af-state-rsn</i>                | (Optional) AF table state reason       |
| <i>af-num-peers</i>                | (Optional) No. of peers                |
| <i>af-num-active-peers</i>         | (Optional) No. of active peers         |
| <i>af-peer-routes</i>              | (Optional) No. of peer routes          |
| <i>af-peer-paths</i>               | (Optional) No. of peer paths           |
| <i>af-peer-networks</i>            | (Optional) No. of peer networks        |
| <i>af-peer-aggregates</i>          | (Optional) No. of aggregates           |
| <i>af-export-rmap</i>              | (Optional) Export route-map            |
| <i>af-import-rmap</i>              | (Optional) Import route-map            |
| <i>af-retain-rt</i>                | (Optional) Retain RT                   |
| TABLE_saf                          | (Optional)                             |
| <i>safi</i>                        | (Optional)                             |

|                                   |            |
|-----------------------------------|------------|
| <i>af-name</i>                    | (Optional) |
| <i>tableversion</i>               | (Optional) |
| <i>configuredpeers</i>            | (Optional) |
| <i>capablepeers</i>               | (Optional) |
| <i>totalnetworks</i>              | (Optional) |
| <i>totalpaths</i>                 | (Optional) |
| <i>memoryused</i>                 | (Optional) |
| <i>numberattrs</i>                | (Optional) |
| <i>bytesattrs</i>                 | (Optional) |
| <i>numberpaths</i>                | (Optional) |
| <i>bytespaths</i>                 | (Optional) |
| <i>numbercommunities</i>          | (Optional) |
| <i>bytescommunities</i>           | (Optional) |
| <i>numberclusterlist</i>          | (Optional) |
| <i>bytesclusterlist</i>           | (Optional) |
| <i>dampening</i>                  | (Optional) |
| <i>historypaths</i>               | (Optional) |
| <i>dampenedpaths</i>              | (Optional) |
| <i>softreconfigrecvdpaths</i>     | (Optional) |
| <i>softreconfigidenticalpaths</i> | (Optional) |
| <i>softreconfigcombopaths</i>     | (Optional) |
| <i>softreconfigfilteredrecvd</i>  | (Optional) |
| <i>softreconfigbytes</i>          | (Optional) |
| TABLE_neighbor                    | (Optional) |
| <i>neighborid</i>                 | (Optional) |
| <i>neighborversion</i>            | (Optional) |
| <i>neighboras</i>                 | (Optional) |
| <i>msgrecvd</i>                   | (Optional) |
| <i>msgsent</i>                    | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>neighbortableversion</i> | (Optional) |
| <i>inq</i>                  | (Optional) |
| <i>outq</i>                 | (Optional) |
| <i>time</i>                 | (Optional) |
| <i>state</i>                | (Optional) |
| <i>prefixreceived</i>       | (Optional) |
| <i>interface-parent</i>     | (Optional) |

**Command Mode**

- /exec

## show bgp summary

```
show bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] { ipv4 { unicast |
multicast } | ipv6 { unicast | multicast } | all } summary [ __readonly__ TABLE_vrf <vrf-name-out> ] [ <vrf-id>
] [ <vrf-state> ] [ <vrf-state-rsn> ] [ <vrf-delete-pending> ] [ <vrf-evpn-mpls> ] [ <vrf-vni-id> ] [
<vrf-vni-id-valid> ] [ <vrf-topo-id> ] [ <vrf-encap-type> ] [ <vrf-vtep-ip> ] [ <vrf-vtep-virtual-ip> ] [
<vrf-vtep-vipr> ] [ <vrf-router-mac> ] [ <vrf-vip-router-mac> ] [ <vrf-vipr-router-mac> ] [ <vrf-router-id> ]
] [ <vrf-cfgd-id> ] [ <vrf-local-as> ] [ <vrf-confed-id> ] [ <vrf-cluster-id> ] [ <vrf-reconnect-interval> ] [
<vrf-peers> ] [ <vrf-pending-peers> ] [ <vrf-est-peers> ] [ <vrf-cfgd-max-as-limit> ] [ <vrf-max-as-limit> ]
] [ <vrf-rd-configured> ] [ <vrf-rd> ] [ <vrf-secondary-rd-configured> ] [ <vrf-secondary-rd> ] [ <vrf-pending-rd>
] [ <vrf-pending-secondary-rd> ] [ TABLE_af <af-id> [ <af-name> ] [ <af-table-id> ] [ <af-state> ] [
<af-state-rsn> ] [ <af-num-peers> ] [ <af-num-active-peers> ] [ <af-peer-routes> ] [ <af-peer-paths> ] [
<af-peer-networks> ] [ <af-peer-aggregates> ] [ <af-export-rmap> ] [ <af-import-rmap> ] [ <af-retain-rt> ]
TABLE_saf <safi> [ <af-name> ] [ <tableversion> ] [ <configuredpeers> ] [ <capablepeers> ] [ <totalnetworks>
] [ <totalpaths> ] [ <memoryused> ] [ <numberattrs> ] [ <bytesattrs> ] [ <numberpaths> ] [ <bytespaths> ] [
<numbercommunities> ] [ <bytescommunities> ] [ <numberclusterlist> ] [ <bytesclusterlist> ] [ <dampening>
] [ <historypaths> ] [ <dampenedpaths> ] [ <softreconfigrecvdpaths> ] [ <softreconfigidenticalpaths> ] [
<softreconfigcombopath> ] [ <softreconfigfilteredrecvd> ] [ <softreconfigbytes> ] [ TABLE_neighbor
<neighborid> [ <neighborversion> ] [ <msgrecvd> ] [ <msgsent> ] [ <neighbortableversion> ] [ <inq> ] [
<outq> ] [ <neighboras> ] [ <time> ] [ <state> ] [ <prefixreceived> ] [ <interface-parent> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| bgp                   | Display BGP status and configuration                 |
| vrf                   | (Optional) Virtual Router Context                    |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| summary               | Display summarized information of BGP state          |
| ipv4                  | Display BGP information for IPv4 address family      |
| ipv6                  | Display BGP information for IPv6 address family      |
| unicast               | Display BGP information for unicast address family   |
| multicast             | Display BGP information for multicast address family |
| all                   | Display BGP information for all address families     |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrf-name-out</i>   | (Optional) VRF name                                  |
| <i>vrf-id</i>         | (Optional) VRF ID                                    |

|                                    |   |
|------------------------------------|---|
| <i>vrf-state</i>                   | (Optional) VRF State                              |
| <i>vrf-state-rsn</i>               | (Optional) VRF State Reason                       |
| <i>vrf-delete-pending</i>          | (Optional) VRF delete pending                     |
| <i>vrf-evpn-mpls</i>               | (Optional) VRF EVPN L3 MPLS                       |
| <i>vrf-vni-id</i>                  | (Optional) VRF VNI ID                             |
| <i>vrf-vni-id-valid</i>            | (Optional) VRF VNI ID validity                    |
| <i>vrf-topo-id</i>                 | (Optional) VRF Topo ID                            |
| <i>vrf-encap-type</i>              | (Optional) VRF encapsulation type                 |
| <i>vrf-vtep-ip</i>                 | (Optional) VRF VTEP IP                            |
| <i>vrf-vtep-virtual-ip</i>         | (Optional) VRF VTEP Virtual IP                    |
| <i>vrf-vtep-vipr</i>               | (Optional) VRF VTEP Virtual IP for Re-origination |
| <i>vrf-router-mac</i>              | (Optional) VRF Router MAC                         |
| <i>vrf-vip-router-mac</i>          | (Optional) VRF VIP Router MAC                     |
| <i>vrf-vipr-router-mac</i>         | (Optional) VRF VIPR Router MAC                    |
| <i>vrf-router-id</i>               | (Optional) Router ID                              |
| <i>vrf-cfgd-id</i>                 | (Optional) Configured Router-ID                   |
| <i>vrf-local-as</i>                | (Optional) Local AS                               |
| <i>vrf-confed-id</i>               | (Optional) Cluster-ID                             |
| <i>vrf-cluster-id</i>              | (Optional) Cluster-ID                             |
| <i>vrf-reconnect-interval</i>      | (Optional) VRF reconnect interval                 |
| <i>vrf-peers</i>                   | (Optional) No. of configured peers                |
| <i>vrf-pending-peers</i>           | (Optional) No. of pending peers                   |
| <i>vrf-est-peers</i>               | (Optional) No. of established peers               |
| <i>vrf-cfgd-max-as-limit</i>       | (Optional) Configured maxas-limit                 |
| <i>vrf-max-as-limit</i>            | (Optional) Active maxas-limit                     |
| <i>vrf-rd-configured</i>           | (Optional) VRF RD Configured                      |
| <i>vrf-rd</i>                      | (Optional) VRF RD                                 |
| <i>vrf-secondary-rd-configured</i> | (Optional) VRF Secondary RD Configured            |
| <i>vrf-secondary-rd</i>            | (Optional) VRF Secondary RD                       |

|                                 |                                     |
|---------------------------------|-------------------------------------|
| <i>vrf-pending-rd</i>           | (Optional) VRF pending RD           |
| <i>vrf-pending-secondary-rd</i> | (Optional) VRF pending secondary RD |
| TABLE_af                        | (Optional)                          |
| <i>af-id</i>                    | (Optional) AF ID                    |
| <i>af-table-id</i>              | (Optional) AF table                 |
| <i>af-name</i>                  | (Optional) AF table name            |
| <i>af-state</i>                 | (Optional) AF table state           |
| <i>af-state-rsn</i>             | (Optional) AF table state reason    |
| <i>af-num-peers</i>             | (Optional) No. of peers             |
| <i>af-num-active-peers</i>      | (Optional) No. of active peers      |
| <i>af-peer-routes</i>           | (Optional) No. of peer routes       |
| <i>af-peer-paths</i>            | (Optional) No. of peer paths        |
| <i>af-peer-networks</i>         | (Optional) No. of peer networks     |
| <i>af-peer-aggregates</i>       | (Optional) No. of aggregates        |
| <i>af-export-rmap</i>           | (Optional) Export route-map         |
| <i>af-import-rmap</i>           | (Optional) Import route-map         |
| <i>af-retain-rt</i>             | (Optional) Retain RT                |
| TABLE_saf                       | (Optional)                          |
| <i>safi</i>                     | (Optional)                          |
| <i>af-name</i>                  | (Optional)                          |
| <i>tableversion</i>             | (Optional)                          |
| <i>configuredpeers</i>          | (Optional)                          |
| <i>capablepeers</i>             | (Optional)                          |
| <i>totalnetworks</i>            | (Optional)                          |
| <i>totalpaths</i>               | (Optional)                          |
| <i>memoryused</i>               | (Optional)                          |
| <i>numberattrs</i>              | (Optional)                          |
| <i>bytesattrs</i>               | (Optional)                          |
| <i>numberpaths</i>              | (Optional)                          |

|                                   |            |
|-----------------------------------|------------|
| <i>bytespaths</i>                 | (Optional) |
| <i>numbercommunities</i>          | (Optional) |
| <i>bytescommunities</i>           | (Optional) |
| <i>numberclusterlist</i>          | (Optional) |
| <i>bytesclusterlist</i>           | (Optional) |
| <i>dampening</i>                  | (Optional) |
| <i>historypaths</i>               | (Optional) |
| <i>dampenedpaths</i>              | (Optional) |
| <i>softreconfigrecvdpaths</i>     | (Optional) |
| <i>softreconfigidenticalpaths</i> | (Optional) |
| <i>softreconfigcombopaths</i>     | (Optional) |
| <i>softreconfigfilteredrecvd</i>  | (Optional) |
| <i>softreconfigbytes</i>          | (Optional) |
| TABLE_neighbor                    | (Optional) |
| <i>neighborid</i>                 | (Optional) |
| <i>neighborversion</i>            | (Optional) |
| <i>neighbors</i>                  | (Optional) |
| <i>msgrecvd</i>                   | (Optional) |
| <i>msgsent</i>                    | (Optional) |
| <i>neighbortableversion</i>       | (Optional) |
| <i>inq</i>                        | (Optional) |
| <i>outq</i>                       | (Optional) |
| <i>time</i>                       | (Optional) |
| <i>state</i>                      | (Optional) |
| <i>prefixreceived</i>             | (Optional) |
| <i>interface-parent</i>           | (Optional) |

**Command Mode**

- /exec



# show boot

```
show boot [ __readonly__ { [ TABLE_bootvar_show <Str1> ] [ TABLE_Current_Bootvar
<current_sup_module><current_image> [<current_sup_module> ] [<current_image> ] <current_poap_status>
+ [ <current_exclude_cfg> ] ] [ TABLE_Startup_Bootvar <start_sup_module> <start_image> [
<start_sup_module> ] [ <start_image> ] <start_poap_status> + [ <configured_exclude_cfg> ] ] } ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                              |
| boot                          | Show Bootvar Variables                                       |
| <i>__readonly__</i>           | (Optional)   |
| <i>TABLE_bootvar_show</i>     | (Optional) Bootvar table                                     |
| <i>TABLE_Current_Bootvar</i>  | (Optional) Table for current boot variables                  |
| <i>TABLE_Startup_Bootvar</i>  | (Optional) Table for boot variables on next reload           |
| <i>Str1</i>                   | (Optional)   |
| <i>current_sup_module</i>     | (Optional) Current boot variable supervisor module           |
| <i>current_image</i>          | (Optional) Current image set for boot variable               |
| <i>current_poap_status</i>    | (Optional) Current status for poap                           |
| <i>current_exclude_cfg</i>    | (Optional) current value of exclude_cfg                      |
| <i>start_sup_module</i>       | (Optional) Next reload supervisor module                     |
| <i>start_image</i>            | (Optional) Next reload boot variable                         |
| <i>start_poap_status</i>      | (Optional) Next reload poap status                           |
| <i>configured_exclude_cfg</i> | (Optional) configured value of exclude_cfg in running config |

## Command Mode

- /exec

# show boot auto-copy

```
show boot auto-copy [ __readonly__ { [ TABLE_auto_copy <Str1> <status> ] } ]
```

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                  |
| boot            | Show Bootvar Variables                           |
| auto-copy       | See if autcopy is turned on                      |
| __readonly__    | (Optional)                                       |
| TABLE_auto_copy | (Optional) Auto copy table                       |
| <i>Str1</i>     | (Optional)                                       |
| <i>status</i>   | (Optional) status of auto copy is enable/disable |

## Command Mode

- /exec

# show boot auto-copy list

```
show boot auto-copy list [ __readonly__ { [ TABLE_auto_copy_list <Str1> <file> ] } ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information          |
| boot                 | Show Bootvar Variables                   |
| auto-copy            | See if autocopy is turned on             |
| list                 | Show the list of files to be auto-copied |
| __readonly__         | (Optional)                               |
| TABLE_auto_copy_list | (Optional) Auto copy table               |
| <i>Str1</i>          | (Optional)                               |
| <i>file</i>          | (Optional) file in the auto copy list    |

## Command Mode

- /exec

# show boot current

```
show boot current [ __readonly__ { [ TABLE_bootvar_current <Str1> ] [ TABLE_current_bootvar
<current_sup_module> <current_image> [ <current_sup_module> ] [ <current_image> ] ] } ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                    |
| boot                      | Show Bootvar Variables                             |
| current                   | Show Current Bootvar Variables                     |
| __readonly__              | (Optional)   |
| TABLE_bootvar_current     | (Optional) Bootvar current table                   |
| TABLE_current_bootvar     | (Optional) Current booted image table              |
| <i>Str1</i>               | (Optional)   |
| <i>current_sup_module</i> | (Optional) Current boot variable supervisor module |
| <i>current_image</i>      | (Optional) Current image set for boot variable     |

## Command Mode

- /exec

# show boot mode

```
show boot mode [ __readonly__ { [ TABLE_mode <Str1> <current_boot_mode> [ <configured_boot_mode> ] ] } ]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show boot mode information                        |
| boot                        | Show boot mode                                    |
| mode                        | See if lxc boot is turned on                      |
| __readonly__                | (Optional)  |
| TABLE_mode                  | (Optional) boot mode table                        |
| <i>Str1</i>                 | (Optional)  |
| <i>current_boot_mode</i>    | (Optional) current running boot mode              |
| <i>configured_boot_mode</i> | (Optional) configured boot mode in running config |

## Command Mode

- /exec

# show boot order

```
show boot order [ __readonly__ { [ TABLE_bootvar_order <Str1> ] [ TABLE_boot_order <current_order>
<next_order> ] } ]
```

## Syntax Description

|                      |                                       |
|----------------------|---------------------------------------|
| show                 | Show running system information       |
| boot                 | Show Bootvar Variables                |
| order                | Show Boot Order                       |
| __readonly__         | (Optional)                            |
| TABLE_bootvar_order  | (Optional) Boot order table           |
| TABLE_boot_order     | (Optional) Current boot order table   |
| <i>Str1</i>          | (Optional)                            |
| <i>current_order</i> | (Optional) order of the boot location |
| <i>next_order</i>    | (Optional) order of the boot location |

## Command Mode

- /exec

# show boot timings

show [ system internal ] boot timings [ detail ]

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information          |
| system   | (Optional) System-Related show commands  |
| internal | (Optional) Commands for internal use     |
| boot     | show boot information                    |
| timings  | show boot timings                        |
| detail   | (Optional) show detailed time statistics |

## Command Mode

- /exec

# show boot variables

```
show boot variables [ __readonly__ { [ TABLE_boot_vars <Str1> <boot_variable> ] } ]
```

## Syntax Description

|                      |                                      |
|----------------------|--------------------------------------|
| show                 | Show running system information      |
| boot                 | Show Bootvar Variables               |
| variables            | Display the list of boot variables   |
| __readonly__         | (Optional)                           |
| TABLE_boot_vars      | (Optional) Show boot variables table |
| <i>Str1</i>          | (Optional)                           |
| <i>boot_variable</i> | (Optional) available boot variable   |

## Command Mode

- /exec



# show buffer-drop detail

```
show buffer-drop detail [ __readonly__ <system-monitor-name> <monitor-name> <collector-name>
<v4-acl-name> <v6-acl-name> <queue-id> <sampler-prob-rate> <sampler-mb-rate> <sampler-mb-pkts> ]
```

## Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| buffer-drop                | Show Buffer Drop information          |
| detail                     | Show Session Configuration            |
| <i>__readonly__</i>        | (Optional) Read only                  |
| <i>system-monitor-name</i> | (Optional) system monitor name        |
| <i>monitor-name</i>        | (Optional) monitor name               |
| <i>collector-name</i>      | (Optional) collector name             |
| <i>v4-acl-name</i>         | (Optional) v4 acl name                |
| <i>v6-acl-name</i>         | (Optional) v6 acl name                |
| <i>queue-id</i>            | (Optional) queue id                   |
| <i>sampler-prob-rate</i>   | (Optional) sampler probabilistic rate |
| <i>sampler-mb-rate</i>     | (Optional) sampler mb rate            |
| <i>sampler-mb-pkts</i>     | (Optional) sampler mb max pkts        |

## Command Mode

- /exec

## show buffer-latency detail

```
show buffer-latency detail [ __readonly__ <system-monitor-name> <monitor-name> <collector-name>
<record-name> <v4-acl-name> <v6-acl-name> <queue-id> <interface> <latency-threshold>
<sampler-prob-rate> <sampler-mb-rate> <sampler-mb-pkts> ]
```

### Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| buffer-latency             | Show Buffer Drop information          |
| detail                     | Show Session Configuration            |
| <i>__readonly__</i>        | (Optional) Read only                  |
| <i>system-monitor-name</i> | (Optional) system monitor name        |
| <i>monitor-name</i>        | (Optional) monitor name               |
| <i>collector-name</i>      | (Optional) collector name             |
| <i>record-name</i>         | (Optional) record name                |
| <i>v4-acl-name</i>         | (Optional) v4 acl name                |
| <i>v6-acl-name</i>         | (Optional) v6 acl name                |
| <i>queue-id</i>            | (Optional) queue id                   |
| <i>interface</i>           | (Optional) interface                  |
| <i>latency-threshold</i>   | (Optional) latency threshold          |
| <i>sampler-prob-rate</i>   | (Optional) sampler probabilistic rate |
| <i>sampler-mb-rate</i>     | (Optional) sampler mb rate            |
| <i>sampler-mb-pkts</i>     | (Optional) sampler mb max pkts        |

### Command Mode

- /exec



## C Show Commands

---

- [show callhome](#), on page 225
- [show callhome destination-profile](#), on page 227
- [show callhome destination-profile profile](#), on page 228
- [show callhome destination-profile profile CiscoTAC-1](#), on page 229
- [show callhome destination-profile profile full-txt-destination](#), on page 230
- [show callhome destination-profile profile short-txt-destination](#), on page 231
- [show callhome transport-email](#), on page 232
- [show callhome transport](#), on page 233
- [show callhome user-def-cmds](#), on page 235
- [show cdp](#), on page 236
- [show cdp all](#), on page 238
- [show cdp global](#), on page 239
- [show cdp neighbors](#), on page 240
- [show cdp neighbors detail](#), on page 241
- [show cdp traffic interface2](#), on page 243
- [show cdp traffic interface2 all](#), on page 244
- [show cfs application](#), on page 245
- [show cfs lock](#), on page 246
- [show cfs lock](#), on page 247
- [show cfs merge status](#), on page 248
- [show cfs merge status](#), on page 249
- [show cfs peers](#), on page 251
- [show cfs peers](#), on page 252
- [show cfs regions](#), on page 253
- [show cfs static peers](#), on page 255
- [show cfs status](#), on page 256
- [show checkpoint](#), on page 257
- [show checkpoint](#), on page 258
- [show checkpoint summary](#), on page 259
- [show class-map](#), on page 260
- [show class-map type control-plane](#), on page 262
- [show class-map type network-qos](#), on page 263
- [show cli alias](#), on page 264

- [show cli dynamic integers](#), on page 265
- [show cli dynamic strings](#), on page 266
- [show cli history](#), on page 267
- [show cli interface table](#), on page 268
- [show cli list](#), on page 269
- [show cli syntax](#), on page 270
- [show cli variables](#), on page 271
- [show clock](#), on page 272
- [show config-profile](#), on page 273
- [show config-profile applied](#), on page 274
- [show config-replace log exec](#), on page 275
- [show config-replace status](#), on page 277
- [show configuration](#), on page 278
- [show configuration](#), on page 279
- [show configuration commit](#), on page 280
- [show configuration failed](#), on page 281
- [show configuration file](#), on page 282
- [show configuration session](#), on page 283
- [show configuration session](#), on page 284
- [show configuration session global-info](#), on page 285
- [show configuration session status](#), on page 286
- [show configuration session summary](#), on page 287
- [show configuration session vsh](#), on page 288
- [show consistency-checker copp](#), on page 289
- [show consistency-checker copp extended module](#), on page 290
- [show consistency-checker dme interfaces](#), on page 291
- [show consistency-checker egress-xlate private-vlan](#), on page 292
- [show consistency-checker ehm interface](#), on page 293
- [show consistency-checker fcoe](#), on page 294
- [show consistency-checker fex-interfaces fex](#), on page 296
- [show consistency-checker forwarding](#), on page 297
- [show consistency-checker forwarding ipv6](#), on page 299
- [show consistency-checker forwarding single-route ipv4 vrf](#), on page 301
- [show consistency-checker fsync](#), on page 302
- [show consistency-checker gwmacdb](#), on page 303
- [show consistency-checker hardware-telemetry inband brief](#), on page 304
- [show consistency-checker hardware-telemetry postcard brief](#), on page 305
- [show consistency-checker kim](#), on page 306
- [show consistency-checker kim interface](#), on page 307
- [show consistency-checker l2-tahoe mac-address](#), on page 308
- [show consistency-checker l2-tahoe sub-interface](#), on page 309
- [show consistency-checker l2-tahoe sub-interface vlan](#), on page 310
- [show consistency-checker l2-tahoe switchport](#), on page 311
- [show consistency-checker l2 module](#), on page 312
- [show consistency-checker l2 multicast group source vlan](#), on page 313
- [show consistency-checker l2 multicast mac vlan](#), on page 314

- [show consistency-checker l3-interface](#), on page 315
- [show consistency-checker l3 multicast group source vrf](#), on page 316
- [show consistency-checker link-state fabric-ietf](#), on page 317
- [show consistency-checker link-state module](#), on page 318
- [show consistency-checker membership port-channels](#), on page 319
- [show consistency-checker membership vlan](#), on page 320
- [show consistency-checker multicast nlb cluster-ip vrf](#), on page 321
- [show consistency-checker multicast vlan](#), on page 322
- [show consistency-checker niv-datapath interface](#), on page 323
- [show consistency-checker pacl extended ingress ip interface](#), on page 324
- [show consistency-checker pacl extended ingress ip module](#), on page 325
- [show consistency-checker pacl extended ingress ipv6 module](#), on page 326
- [show consistency-checker pacl extended ingress ipv6 interface](#), on page 327
- [show consistency-checker pacl extended ingress mac module](#), on page 328
- [show consistency-checker pacl extended ingress mac interface](#), on page 329
- [show consistency-checker pacl extended module](#), on page 330
- [show consistency-checker pacl module](#), on page 331
- [show consistency-checker pacl port-channels](#), on page 332
- [show consistency-checker port-state](#), on page 333
- [show consistency-checker port-state fabric-ietf](#), on page 334
- [show consistency-checker qinq](#), on page 335
- [show consistency-checker racl extended egress ip module](#), on page 336
- [show consistency-checker racl extended egress ipv6 module](#), on page 337
- [show consistency-checker racl extended egress ip interface](#), on page 338
- [show consistency-checker racl extended egress ipv6 interface](#), on page 339
- [show consistency-checker racl extended ingress ip module](#), on page 340
- [show consistency-checker racl extended ingress ipv6 module](#), on page 341
- [show consistency-checker racl extended ingress ip interface](#), on page 342
- [show consistency-checker racl extended ingress ipv6 interface](#), on page 343
- [show consistency-checker racl extended module](#), on page 344
- [show consistency-checker racl module](#), on page 345
- [show consistency-checker racl port-channels](#), on page 346
- [show consistency-checker racl svi interface](#), on page 347
- [show consistency-checker segment-routing mpls](#), on page 348
- [show consistency-checker selective-qinq](#), on page 349
- [show consistency-checker selective-qinq interface](#), on page 350
- [show consistency-checker sflow](#), on page 351
- [show consistency-checker storm-control](#), on page 352
- [show consistency-checker stp-state vlan](#), on page 353
- [show consistency-checker vcl](#), on page 354
- [show consistency-checker vcl extended ingress ipv6 vlan](#), on page 355
- [show consistency-checker vcl extended ingress ip vlan](#), on page 356
- [show consistency-checker vcl extended ingress mac vlan](#), on page 357
- [show consistency-checker vpc](#), on page 358
- [show consistency-checker vpgrouping interface](#), on page 359
- [show consistency-checker vxlan config-check](#), on page 360

- [show consistency-checker vxlan infra](#), on page 361
- [show consistency-checker vxlan l2 mac-address module](#), on page 362
- [show consistency-checker vxlan l2 module](#), on page 363
- [show consistency-checker vxlan l3 single-route ipv4 vrf](#), on page 364
- [show consistency-checker vxlan l3 vrf start](#), on page 365
- [show consistency-checker vxlan mh mac-addresses](#), on page 366
- [show consistency-checker vxlan mh pathlist](#), on page 367
- [show consistency-checker vxlan pv](#), on page 368
- [show consistency-checker vxlan qinq-qinvni](#), on page 369
- [show consistency-checker vxlan qinvni](#), on page 370
- [show consistency-checker vxlan selective-qinvni](#), on page 371
- [show consistency-checker vxlan selective-qinvni interface](#), on page 372
- [show consistency-checker vxlan vlan](#), on page 373
- [show consistency-checker vxlan xconnect](#), on page 374
- [show controller accounting log](#), on page 375
- [show copp diff profile profile2](#), on page 376
- [show copp profile](#), on page 377
- [show copp status](#), on page 382
- [show copyright](#), on page 383
- [show cores](#), on page 384
- [show crypto ca certificates](#), on page 385
- [show crypto ca certificates](#), on page 386
- [show crypto ca certstore](#), on page 387
- [show crypto ca crl](#), on page 388
- [show crypto ca remote-certstore](#), on page 389
- [show crypto ca trustpoints](#), on page 390
- [show crypto ca trustpool](#), on page 391
- [show crypto ca trustpool last download status](#), on page 392
- [show crypto ca trustpool policy](#), on page 393
- [show crypto certificatemap](#), on page 394
- [show crypto key mypubkey rsa](#), on page 395
- [show crypto ssh-auth-map](#), on page 396
- [show cts](#), on page 397
- [show current](#), on page 398

# show callhome

```
show callhome [ __readonly__ <output_state> <info> <per_name> [ <name> ] <email_info> [ <email_conf>
] <ph_info> [ <ph_conf> ] <str_addr> [ <str_conf> ] <site_id> [ <site_id_conf> ] <cust_id> [ <cus_id_conf>
] <contr_id> [ <contr_id_conf> ] <swi_pri> [ <swi_pri_value> ] <dup_mess> <per_inv> <per_time>
<per_timeofday> <dist> ]
```

## Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| callhome             | Show callhome information       |
| <i>__readonly__</i>  | (Optional)                      |
| <i>output_state</i>  | (Optional)                      |
| <i>info</i>          | (Optional)                      |
| <i>per_name</i>      | (Optional)                      |
| <i>name</i>          | (Optional)                      |
| <i>email_info</i>    | (Optional)                      |
| <i>email_conf</i>    | (Optional)                      |
| <i>ph_info</i>       | (Optional)                      |
| <i>ph_conf</i>       | (Optional)                      |
| <i>str_addr</i>      | (Optional)                      |
| <i>str_conf</i>      | (Optional)                      |
| <i>site_id</i>       | (Optional)                      |
| <i>site_id_conf</i>  | (Optional)                      |
| <i>cust_id</i>       | (Optional)                      |
| <i>cus_id_conf</i>   | (Optional)                      |
| <i>contr_id</i>      | (Optional)                      |
| <i>contr_id_conf</i> | (Optional)                      |
| <i>swi_pri</i>       | (Optional)                      |
| <i>swi_pri_value</i> | (Optional)                      |
| <i>dup_mess</i>      | (Optional)                      |
| <i>per_inv</i>       | (Optional)                      |

|                      |            |
|----------------------|------------|
| <i>per_time</i>      | (Optional) |
| <i>per_timeofday</i> | (Optional) |
| <i>dist</i>          | (Optional) |

**Command Mode**

- /exec



## show callhome destination-profile

```
show callhome destination-profile [ __readonly__ { TABLE_call_info [ <dest_full_info> ] [ <dest_short_info> ] [ <dest_xml_info> ] [ <dest_def_info> ] <max_mess_size> <mess_format> <mess_level> <trans_method> <email_info> [ <index> <email_conf> ] <url_info> [ <index> <url_conf> ] <alert_groups> [ <alert_conf> ] } ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information               |
| callhome               | Show callhome information                     |
| destination-profile    | Show callhome destination profile information |
| <i>__readonly__</i>    | (Optional)                                    |
| <i>TABLE_call_info</i> | (Optional)                                    |
| <i>dest_full_info</i>  | (Optional)                                    |
| <i>dest_short_info</i> | (Optional)                                    |
| <i>dest_xml_info</i>   | (Optional)                                    |
| <i>dest_def_info</i>   | (Optional)                                    |
| <i>max_mess_size</i>   | (Optional)                                    |
| <i>mess_format</i>     | (Optional)                                    |
| <i>mess_level</i>      | (Optional)                                    |
| <i>trans_method</i>    | (Optional)                                    |
| <i>index</i>           | (Optional)                                    |
| <i>email_info</i>      | (Optional)                                    |
| <i>email_conf</i>      | (Optional)                                    |
| <i>url_info</i>        | (Optional)                                    |
| <i>url_conf</i>        | (Optional)                                    |
| <i>alert_groups</i>    | (Optional)                                    |
| <i>alert_conf</i>      | (Optional)                                    |

### Command Mode

- /exec

## show callhome destination-profile profile

```
show callhome destination-profile profile <s0> [ __readonly__ <user_txt_info> <max_mess_size>
<mess_format> <mess_level> <trans_method> <email_info> [ TABLE_email [ <index> <email_conf> ] ]
<url_info> [ TABLE_url [ <index> <url_conf> ] ] <alert_groups> [ TABLE_alert [ <alert_conf> ] ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                       |
| callhome             | Show callhome information                             |
| destination-profile  | Show callhome destination profile information         |
| profile              | Specify the destination profile                       |
| <i>s0</i>            | Show information for user defined destination profile |
| <i>__readonly__</i>  | (Optional)  |
| <i>user_txt_info</i> | (Optional)  |
| <i>max_mess_size</i> | (Optional)  |
| <i>mess_format</i>   | (Optional)  |
| <i>mess_level</i>    | (Optional)  |
| <i>trans_method</i>  | (Optional)  |
| <i>email_info</i>    | (Optional)  |
| <i>index</i>         | (Optional)  |
| TABLE_email          | (Optional)  |
| <i>email_conf</i>    | (Optional)  |
| <i>url_info</i>      | (Optional)  |
| TABLE_url            | (Optional)  |
| <i>url_conf</i>      | (Optional)  |
| <i>alert_groups</i>  | (Optional)  |
| TABLE_alert          | (Optional)  |
| <i>alert_conf</i>    | (Optional)  |

### Command Mode

- /exec

# show callhome destination-profile profile CiscoTAC-1

```
show callhome destination-profile profile CiscoTAC-1 [ __readonly__ <tac_xml_info> <max_mess_size>
<mess_level> <trans_method> <email_info> [ <index> <email_conf> ] <url_info> [ <index> <url_conf> ]
<alert_groups> [ <alert_conf> ] ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                     |
| callhome             | Show callhome information                           |
| destination-profile  | Show callhome destination profile information       |
| profile              | Specify the destination profile                     |
| CiscoTAC-1           | Show information for CiscoTAC-1 destination profile |
| <i>__readonly__</i>  | (Optional)  |
| <i>tac_xml_info</i>  | (Optional)  |
| <i>max_mess_size</i> | (Optional)  |
| <i>mess_level</i>    | (Optional)  |
| <i>trans_method</i>  | (Optional)  |
| <i>email_info</i>    | (Optional)  |
| <i>index</i>         | (Optional)  |
| <i>email_conf</i>    | (Optional)  |
| <i>url_info</i>      | (Optional)  |
| <i>url_conf</i>      | (Optional)  |
| <i>alert_groups</i>  | (Optional)  |
| <i>alert_conf</i>    | (Optional)  |

## Command Mode

- /exec

## show callhome destination-profile profile full-txt-destination

```
show callhome destination-profile profile full-txt-destination [ __readonly__ <full_txt_info> <max_mess_size>
<mess_level> <trans_method> <email_info> [ <index> <email_conf> ] <url_info> [ <index> <url_conf> ]
<alert_groups> [ <alert_conf> ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                               |
| callhome             | Show callhome information                                     |
| destination-profile  | Show callhome destination profile information                 |
| profile              | Specify the destination profile                               |
| full-txt-destination | Show information for full-txt-destination destination profile |
| <i>__readonly__</i>  | (Optional)  |
| <i>full_txt_info</i> | (Optional)  |
| <i>max_mess_size</i> | (Optional)  |
| <i>mess_level</i>    | (Optional)  |
| <i>trans_method</i>  | (Optional)  |
| <i>email_info</i>    | (Optional)  |
| <i>index</i>         | (Optional)  |
| <i>email_conf</i>    | (Optional)  |
| <i>url_info</i>      | (Optional)  |
| <i>url_conf</i>      | (Optional)  |
| <i>alert_groups</i>  | (Optional)  |
| <i>alert_conf</i>    | (Optional)  |

### Command Mode

- /exec

# show callhome destination-profile profile short-txt-destination

```
show callhome destination-profile profile short-txt-destination [ __readonly__ <shrt_txt_info>
<max_mess_size> <mess_level> <trans_method> <email_info> [ <index> <email_conf> ] <url_info> [
<index> <url_conf> ] <alert_groups> [ <alert_conf> ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                |
| callhome              | Show callhome information                                      |
| destination-profile   | Show callhome destination profile information                  |
| profile               | Specify the destination profile                                |
| short-txt-destination | Show information for short-txt-destination destination profile |
| <i>__readonly__</i>   | (Optional)   |
| <i>shrt_txt_info</i>  | (Optional)   |
| <i>max_mess_size</i>  | (Optional)   |
| <i>mess_level</i>     | (Optional)   |
| <i>trans_method</i>   | (Optional)   |
| <i>email_info</i>     | (Optional)   |
| <i>index</i>          | (Optional)   |
| <i>email_conf</i>     | (Optional)   |
| <i>url_info</i>       | (Optional)   |
| <i>url_conf</i>       | (Optional)   |
| <i>alert_groups</i>   | (Optional)   |
| <i>alert_conf</i>     | (Optional)   |

## Command Mode

- /exec

# show callhome transport-email

```
show callhome transport-email [ __readonly__ { <from_email> } [ <reply_to_email> ] [ <return_receipt_addr>
] { <smtp_server> } [ <smtp_server_port> ] ]
```

## Syntax Description

|                                  |   |
|----------------------------------|---|
| <code>__readonly__</code>        | (Optional)                                  |
| <code>show</code>                | Show running system information             |
| <code>callhome</code>            | Show callhome information                   |
| <code>transport-email</code>     | Show callhome email transport configuration |
| <code>from_email</code>          | (Optional)                                  |
| <code>reply_to_email</code>      | (Optional)                                  |
| <code>return_receipt_addr</code> | (Optional)                                  |
| <code>smtp_server</code>         | (Optional)                                  |
| <code>smtp_server_port</code>    | (Optional)                                  |

## Command Mode

- /exec

## show callhome transport

```
show callhome transport [ __readonly__ <vrf> <from_email> [ <rep_email> ] [ <ret_email> ] [ <smtp_ser>
] [ <smtp_ser_port> ] [ <smtp_ser_vrf> ] [ <smtp_ser_prior> ] [ <smtp_ser_do> ] [ <smtp_ser_port_do> ] [
<smtp_ser_vrf_do> ] [ <smtp_ser_prior_do> ] [ <smtp_ser_got> ] [ <smtp_ser_port_got> ] [
<smtp_ser_vrf_got> ] [ <smtp_ser_prior_got> ] <http_prox> <http_port> <http_state> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                        |
| callhome                  | Show callhome information                              |
| transport                 | Show callhome transport configuration (email and http) |
| <i>__readonly__</i>       | (Optional)   |
| <i>vrf</i>                | (Optional)   |
| <i>from_email</i>         | (Optional)   |
| <i>rep_email</i>          | (Optional)   |
| <i>ret_email</i>          | (Optional)   |
| <i>smtp_ser</i>           | (Optional)   |
| <i>smtp_ser_port</i>      | (Optional)   |
| <i>smtp_ser_vrf</i>       | (Optional)   |
| <i>smtp_ser_prior</i>     | (Optional)   |
| <i>smtp_ser_do</i>        | (Optional)   |
| <i>smtp_ser_port_do</i>   | (Optional)   |
| <i>smtp_ser_vrf_do</i>    | (Optional)   |
| <i>smtp_ser_prior_do</i>  | (Optional)   |
| <i>smtp_ser_got</i>       | (Optional)   |
| <i>smtp_ser_port_got</i>  | (Optional)   |
| <i>smtp_ser_vrf_got</i>   | (Optional)   |
| <i>smtp_ser_prior_got</i> | (Optional)   |
| <i>http_prox</i>          | (Optional)   |
| <i>http_port</i>          | (Optional)   |
| <i>http_state</i>         | (Optional)   |

**Command Mode**

- /exec



## show callhome user-def-cmds

```
show callhome user-def-cmds [ __readonly__ { <user_configured_cmds> } [ { TABLE_user_def_cmds
<alert_group> <index> <user_defined_cmds> } ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                       |
| callhome                    | Show callhome information                             |
| user-def-cmds               | Show the cli commands configured for each alert group |
| <i>__readonly__</i>         | (Optional)  |
| <i>user_configured_cmds</i> | (Optional) List of user configured commands           |
| TABLE_user_def_cmds         | (Optional)  |
| <i>index</i>                | (Optional)  |
| <i>alert_group</i>          | (Optional)  |
| <i>user_defined_cmds</i>    | (Optional)  |

### Command Mode

- /exec

# show cdp

```
show cdp { entry { all | name <s0> } } [ __readonly__ TABLE_cdp_entry_all <device_id> [ <sysname> ]
<numaddr> [ { <v4addr> | <v6addr> } + ] <platform_id> <capability> + <intf_id> <port_id> <ttl> <version>
<version_no> [ <nativevlan> ] [ <vtpname> ] [ <duplexmode> ] [ <syslocation> ] [ <num_mgmtaddr> [ {
<v4mgmtaddr> | <v6mgmtaddr> } + ] ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| cdp                 | Show Cisco Discovery Protocol information |
| entry               | Show CDP entries in database              |
| all                 | Show all CDP entries in database          |
| name                | Show a specific CDP entry matching a name |
| s0                  |   |
| __readonly__        | (Optional) Read only                      |
| TABLE_cdp_entry_all | (Optional) output of show cdp entry all   |
| device_id           | (Optional) Device Identifier              |
| sysname             | (Optional) System Name                    |
| numaddr             | (Optional) No of IP Address configured    |
| v4addr              | (Optional) Interface IP V4 Address        |
| v6addr              | (Optional) Interface IP V6 Address        |
| platform_id         | (Optional) Platform Id                    |
| capability          | (Optional) Capability                     |
| intf_id             | (Optional) Interface Id                   |
| port_id             | (Optional) Port Identifier                |
| ttl                 | (Optional) Hold Time                      |
| version             | (Optional) Software Version               |
| version_no          | (Optional) CDP version number             |
| nativevlan          | (Optional) NativeVLAN                     |
| vtpname             | (Optional) Vtp Management Domain Name     |
| duplexmode          | (Optional) Duplex Mode                    |

|                     |  |
|---------------------|--|
| <i>syslocation</i>  | (Optional) System Location               |
| <i>num_mgmtaddr</i> | (Optional) No of Mgmt Address configured |
| <i>v4mgmtaddr</i>   | (Optional) IP V4 Mgmt Address            |
| <i>v6mgmtaddr</i>   | (Optional) IP V6 Mgmt Address            |

**Command Mode**

- /exec

# show cdp all

```
show cdp { all | interface <if0> } [ __readonly__ TABLE_cdp_all <intf_id> <port_up> [ <cdp_global_enabled>
] <cdp_intf_enabled> [ <oper_mode> ] <refresh_time> <ttl> ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information           |
| cdp                       | Show Cisco Discovery Protocol information |
| all                       | Show all interfaces in CDP database       |
| interface                 | Show CDP parameters for an interface      |
| <i>if0</i>                |   |
| <i>__readonly__</i>       | (Optional) Read only                      |
| <i>TABLE_cdp_all</i>      | (Optional) output of show cdp all         |
| <i>intf_id</i>            | (Optional) Interface Id                   |
| <i>port_up</i>            | (Optional) Port status                    |
| <i>cdp_global_enabled</i> | (Optional) CDP global status              |
| <i>cdp_intf_enabled</i>   | (Optional) CDP interface status           |
| <i>oper_mode</i>          | (Optional) CDP operation mode             |
| <i>refresh_time</i>       | (Optional) Refresh Time                   |
| <i>ttl</i>                | (Optional) Hold Time                      |

## Command Mode

- /exec

# show cdp global

```
show cdp global [ __readonly__ <cdp_global_enabled> <refresh_time> <ttl> <v2_advertisement>
<deviceid_format> ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information           |
| cdp                       | Show Cisco Discovery Protocol information |
| global                    | Show CDP global parameters                |
| <i>__readonly__</i>       | (Optional) Read only                      |
| <i>cdp_global_enabled</i> | (Optional) CDP global status              |
| <i>refresh_time</i>       | (Optional) Refresh Time                   |
| <i>ttl</i>                | (Optional) Hold Time                      |
| <i>v2_advertisement</i>   | (Optional) Show v2 advertisement          |
| <i>deviceid_format</i>    | (Optional) Show deviceId Format           |

## Command Mode

- /exec

## show cdp neighbors

```
show cdp neighbors [ interface <if> ] [ __readonly__ { TABLE_cdp_neighbor_brief_info <ifindex>
<device_id> <intf_id> <ttl> <capability> + <platform_id> <port_id> } { <neigh_count> } ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information                   |
| cdp                           | Show Cisco Discovery Protocol information         |
| neighbors                     | Show CDP neighbors                                |
| interface                     | (Optional) Show CDP neighbors on an interface     |
| <i>if</i>                     | (Optional) Specify Interface                      |
| <i>__readonly__</i>           | (Optional) Read only                              |
| TABLE_cdp_neighbor_brief_info | (Optional) output of show cdp neighbor - in brief |
| <i>ifindex</i>                | (Optional) Interface index                        |
| <i>device_id</i>              | (Optional) System Name (or) Device Identifier     |
| <i>intf_id</i>                | (Optional) Interface Id                           |
| <i>port_id</i>                | (Optional) Port Identifier                        |
| <i>platform_id</i>            | (Optional) Platform Id                            |
| <i>ttl</i>                    | (Optional) Hold Time                              |
| <i>capability</i>             | (Optional) Capability                             |
| <i>neigh_count</i>            | (Optional) Neighbor Count                         |

### Command Mode

- /exec

# show cdp neighbors detail

```
show cdp neighbors [ interface <if> ] detail [ __readonly__ TABLE_cdp_neighbor_detail_info <ifindex>
<device_id> [ <sysname> ] [ <vtpname> ] <numaddr> [ { <v4addr> | <v6addr> } + ] <platform_id>
<capability> + <intf_id> <port_id> <ttl> <version> <version_no> [ <nativevlan> ] [ <duplexmode> ] [ <mtu>
] [ <syslocation> ] [ <num_mgmtaddr> [ { <v4mgmtaddr> | <v6mgmtaddr> } + ] ] <local_intf_mac>
<remote_intf_mac> ]
```

## Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information               |
| cdp                            | Show Cisco Discovery Protocol information     |
| neighbors                      | Show CDP neighbors                            |
| detail                         | Show CDP neighbors detailed                   |
| interface                      | (Optional) Show CDP neighbors on an interface |
| <i>if</i>                      | (Optional) Specify Interface                  |
| <i>__readonly__</i>            | (Optional) Read only                          |
| TABLE_cdp_neighbor_detail_info | (Optional) output of show cdp neighbor detail |
| <i>ifindex</i>                 | (Optional) Interface index                    |
| <i>device_id</i>               | (Optional) Device Identifier                  |
| <i>sysname</i>                 | (Optional) System Name                        |
| <i>vtpname</i>                 | (Optional) Vtp Management Domain Name         |
| <i>numaddr</i>                 | (Optional) No of IP Address configured        |
| <i>v4addr</i>                  | (Optional) Interface IP V4 Address            |
| <i>v6addr</i>                  | (Optional) Interface IP V6 Address            |
| <i>platform_id</i>             | (Optional) Platform Id                        |
| <i>capability</i>              | (Optional) Capability                         |
| <i>intf_id</i>                 | (Optional) Interface Id                       |
| <i>port_id</i>                 | (Optional) Port Identifier                    |
| <i>ttl</i>                     | (Optional) Hold Time                          |
| <i>version</i>                 | (Optional) Software Version                   |
| <i>version_no</i>              | (Optional) CDP version number                 |
| <i>nativevlan</i>              | (Optional) NativeVLAN                         |

|                        |  |
|------------------------|--|
| <i>duplexmode</i>      | (Optional) Duplex Mode                   |
| <i>mtu</i>             | (Optional) MTU                           |
| <i>syslocation</i>     | (Optional) System Location               |
| <i>num_mgmtaddr</i>    | (Optional) No of Mgmt Address configured |
| <i>v4mgmtaddr</i>      | (Optional) IP V4 Mgmt Address            |
| <i>v6mgmtaddr</i>      | (Optional) IP V6 Mgmt Address            |
| <i>local_intf_mac</i>  | (Optional) Local interface MAC           |
| <i>remote_intf_mac</i> | (Optional) Remote interface MAC          |

**Command Mode**

- /exec



## show cdp traffic interface2

```
show cdp traffic interface2 <if2> [ __readonly__ <intf_id> <total_input_packets> <valid_cdp_packets>
<input_v1_packets> <input_v2_packets> <invalid_cdp_packets> <unsupported_version> <checksum_errors>
<malformed_packets> <total_output_packets> <output_v1_packets> <output_v2_packets> <send_errors>
<flap_cnt> ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information               |
| cdp                         | Show Cisco Discovery Protocol information     |
| traffic                     | Show CDP traffic statistics                   |
| interface2                  | Show CDP traffic statistics on an interface   |
| <i>if2</i>                  |   |
| <i>__readonly__</i>         | (Optional) Read only                          |
| <i>intf_id</i>              | (Optional) Interface Id                       |
| <i>total_input_packets</i>  | (Optional) Total input cdp packets            |
| <i>valid_cdp_packets</i>    | (Optional) Total valid cdp packets            |
| <i>input_v1_packets</i>     | (Optional) Input vesrion1 packets             |
| <i>input_v2_packets</i>     | (Optional) Input vesrion2 packets             |
| <i>invalid_cdp_packets</i>  | (Optional) Invalid cdp packets                |
| <i>unsupported_version</i>  | (Optional) Packets having unsupported version |
| <i>checksum_errors</i>      | (Optional) Packets having checksum errors     |
| <i>malformed_packets</i>    | (Optional) Total malformed packets            |
| <i>total_output_packets</i> | (Optional) Total output packets               |
| <i>output_v1_packets</i>    | (Optional) Output vesrion1 packets            |
| <i>output_v2_packets</i>    | (Optional) Output vesrion2 packets            |
| <i>send_errors</i>          | (Optional) Number of send errors              |
| <i>flap_cnt</i>             | (Optional) Number of PDU timeout              |

### Command Mode

- /exec

## show cdp traffic interface2 all

```
show cdp traffic interface2 all [ __readonly__ TABLE_cdp_traffic <intf_id> <total_input_packets>
<valid_cdp_packets> <input_v1_packets> <input_v2_packets> <invalid_cdp_packets> <unsupported_version>
<checksum_errors> <malformed_packets> <total_output_packets> <output_v1_packets> <output_v2_packets>
<send_errors> <flap_cnt> ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information               |
| cdp                  | Show Cisco Discovery Protocol information     |
| traffic              | Show CDP traffic statistics                   |
| interface2           | Show CDP traffic statistics on an interface   |
| all                  | Display all interface traffic                 |
| __readonly__         | (Optional) Read only                          |
| TABLE_cdp_traffic    | (Optional) output of show cdp traffic         |
| intf_id              | (Optional) Interface Id                       |
| total_input_packets  | (Optional) Total input cdp packets            |
| valid_cdp_packets    | (Optional) Total valid cdp packets            |
| input_v1_packets     | (Optional) Input vesrion1 packets             |
| input_v2_packets     | (Optional) Input vesrion2 packets             |
| invalid_cdp_packets  | (Optional) Invalid cdp packets                |
| unsupported_version  | (Optional) Packets having unsupported version |
| checksum_errors      | (Optional) Packets having checksum errors     |
| malformed_packets    | (Optional) Total malformed packets            |
| total_output_packets | (Optional) Total output packets               |
| output_v1_packets    | (Optional) Output vesrion1 packets            |
| output_v2_packets    | (Optional) Output vesrion2 packets            |
| send_errors          | (Optional) Number of send errors              |
| flap_cnt             | (Optional) Number of PDU timeout              |

### Command Mode

- /exec

# show cfs application

```
show cfs application [ { name <cfs-dyn-app-name> | sap <i0> } ] [ __readonly__ [ <enabled> <timeout>
<merge_capable> <scope> <region> ] [ { TABLE_apps <app_name> <app_enabled> <app_scope> } ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                       |
| cfs                     | CFS Show Command handler                              |
| application             | Show locally registered applications                  |
| name                    | (Optional) Show local application information by name |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application   |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>i0</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>__readonly__</i>     | (Optional)  |
| <i>enabled</i>          | (Optional) whether application is CFS enabled         |
| <i>timeout</i>          | (Optional) timeout                                    |
| <i>merge_capable</i>    | (Optional) merge_capable                              |
| <i>scope</i>            | (Optional) scope                                      |
| <i>region</i>           | (Optional) region                                     |
| TABLE_apps              | (Optional) all cfs applications                       |
| <i>app_name</i>         | (Optional) name of cfs application                    |
| <i>app_enabled</i>      | (Optional) whether application is cfs enabled         |
| <i>app_scope</i>        | (Optional) distribution scope of cfs application      |

## Command Mode

- /exec

# show cfs lock

```
show cfs lock [ { name <cfs-dyn-app-name> [ vsan <i0> ] | sap <i1> [ vsan1 <i2> ] } ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                                   |
| cfs                     | CFS Show Command handler  |
| lock                    | Show state of application's logical/physical locks                |
| name                    | (Optional) Application name for which the lock status is required |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application               |
| vsan                    | (Optional) Show application's locks per vsan                      |
| <i>i0</i>               | (Optional) Vsan Range   |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| <i>i1</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| vsan1                   | (Optional) Show application's locks per vsan                      |
| <i>i2</i>               | (Optional) Vsan Range   |

## Command Mode

- /exec

# show cfs lock

```
show cfs lock [ { name <cfs-dyn-app-name> | sap <i1> } ] [ __readonly__ [ { TABLE_locks [ <app_name>
] <app_scope> [ <vsan> ] [ <domain> ] [ <wwn> ] <ip_addr> <u_name> <u_type> [ <hostname> } ] ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                                   |
| cfs                     | CFS Show Command handler  |
| lock                    | Show state of application's logical/physical locks                |
| name                    | (Optional) Application name for which the lock status is required |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application               |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| <i>i1</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| <u>__readonly__</u>     | (Optional)  |
| TABLE_locks             | (Optional) table of all CFS locks                                 |
| <i>app_name</i>         | (Optional) name of CFS application                                |
| <i>app_scope</i>        | (Optional) scope of CFS application                               |
| <i>vsan</i>             | (Optional) vsan   |
| <i>domain</i>           | (Optional) domain   |
| <i>wwn</i>              | (Optional) wwn of switch holding CFS lock                         |
| <i>ip_addr</i>          | (Optional) ip address of switch holding CFS lock                  |
| <i>u_name</i>           | (Optional) user name  |
| <i>u_type</i>           | (Optional) user type  |
| <i>hostname</i>         | (Optional) hostname   |

## Command Mode

- /exec

## show cfs merge status

show cfs merge status [ { name <cfs-dyn-app-name> [ vsan <i0> ] | sap <i1> [ vsan1 <i2> ] } ]

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                     |
| cfs                     | CFS Show Command handler                            |
| merge                   | Show cfs merge information                          |
| status                  | Show status of merge                                |
| name                    | (Optional) Show merge status by name                |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application |
| vsan                    | (Optional) Show merge information based on vsan     |
| <i>i0</i>               | (Optional) Vsan Range                               |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| <i>i1</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| vsan1                   | (Optional) Show merge information based on vsan     |
| <i>i2</i>               | (Optional) Vsan Range                               |

### Command Mode

- /exec

## show cfs merge status

```
show cfs merge status [ { name <cfs-dyn-app-name> [ detail ] | sap <i1> [ detail2 ] } ] [ __readonly__ [ {
scope <scope> } ] [ { merge_status <status> } ] [ { failure_reason <reason> } ] [ { TABLE_all_merge
<app_name> <scope> <vsan> <status> } ] [ { TABLE_local_fabric [ <domain> ] <wwn> <ip_addr>
<app_scope> [ <master> ] [ <hostname> ] } ] [ { TABLE_remote_fabric [ <domain> ] <wwn> <ip_addr>
<app_scope> [ <master> ] [ <hostname> ] } ] [ { TABLE_remaining_fabric [ <domain> ] <wwn> <ip_addr>
[ <hostname> ] } ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                     |
| cfs                     | CFS Show Command handler                            |
| merge                   | Show cfs merge information                          |
| status                  | Show status of merge                                |
| name                    | (Optional) Show merge status by name                |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application |
| detail                  | (Optional) Show merge status by name in detail      |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| <i>i1</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| detail2                 | (Optional) Show merge status by sap in detail       |
| <u>__readonly__</u>     | (Optional)  |
| scope                   | (Optional) distribution scope of application        |
| <i>scope</i>            | (Optional) scope                                    |
| merge_status            | (Optional) status                                   |
| <i>status</i>           | (Optional) status                                   |
| failure_reason          | (Optional) reason                                   |
| <i>reason</i>           | (Optional) reason                                   |
| TABLE_all_merge         | (Optional) all                                      |
| <i>app_name</i>         | (Optional) name                                     |
| <i>scope</i>            | (Optional) scope                                    |
| <i>vsan</i>             | (Optional) vsan                                     |
| <i>status</i>           | (Optional) status                                   |

|                        |                          |
|------------------------|--------------------------|
| TABLE_local_fabric     | (Optional) local fabric  |
| <i>domain</i>          | (Optional) domain        |
| <i>wwn</i>             | (Optional) wwn           |
| <i>ip_addr</i>         | (Optional) ip_addr       |
| <i>app_scope</i>       | (Optional) scope         |
| <i>master</i>          | (Optional) master        |
| <i>hostname</i>        | (Optional) hname         |
| TABLE_remote_fabric    | (Optional) remote fabric |
| <i>domain</i>          | (Optional) domain        |
| <i>wwn</i>             | (Optional) wwn           |
| <i>ip_addr</i>         | (Optional) ip_addr       |
| <i>app_scope</i>       | (Optional) scope         |
| <i>master</i>          | (Optional) master        |
| <i>hostname</i>        | (Optional) hname         |
| TABLE_remaining_fabric | (Optional) remote fabric |
| <i>domain</i>          | (Optional) domain        |
| <i>wwn</i>             | (Optional) wwn           |
| <i>ip_addr</i>         | (Optional) ip_addr       |
| <i>hostname</i>        | (Optional) hname         |

**Command Mode**

- /exec



## show cfs peers

```
show cfs peers [ { name <cfs-dyn-app-name> | sap <i1> } ] [ __readonly__ [ { scope <scope> } ] ] [ {
TABLE_peers <wwn> <ip_addr> [ <local> ] [ <hostname> ] [ <domain> } ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                     |
| cfs                     | CFS Show Command handler                            |
| peers                   | Show all the peers in the physical fabric           |
| name                    | (Optional) Show peers for given application name    |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| <i>i1</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| <i>__readonly__</i>     | (Optional)  |
| scope                   | (Optional) scope                                    |
| <i>scope</i>            | (Optional) scope                                    |
| TABLE_peers             | (Optional) all peers                                |
| <i>wwn</i>              | (Optional) wwn                                      |
| <i>ip_addr</i>          | (Optional) ip_addr                                  |
| <i>local</i>            | (Optional) local                                    |
| <i>hostname</i>         | (Optional) hname                                    |
| <i>domain</i>           | (Optional) domain                                   |

### Command Mode

- /exec

# show cfs peers

```
show cfs peers [ { name <cfs-dyn-app-name> [ vsan <i0> ] | sap <i1> [ vsan1 <i2> ] } ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                     |
| cfs                     | CFS Show Command handler                            |
| peers                   | Show all the peers in the physical fabric           |
| name                    | (Optional) Show peers for given application name    |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application |
| vsan                    | (Optional) Show peers for a specified vsan(s)       |
| <i>i0</i>               | (Optional) Vsan Range                               |
| sap                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| <i>i1</i>               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| vsan1                   | (Optional) Show peers for a specified vsan(s)       |
| <i>i2</i>               | (Optional) Vsan Range                               |

## Command Mode

- /exec

## show cfs regions

```
show cfs regions [ { brief [ region <i0> ] | name <cfs-dyn-app-name> | region1 <i1> } ] [ __readonly__ [ {
region <id> } ] [ { application <name> } ] [ { scope <scope> } ] [ { TABLE_PEERS <wwn> <ip_addr>
<local> [ <hostname> ] [ <domain> } ] [ { TABLE_switches [ <wwn> ] [ <ip_addr> ] <region> <app_name>
<enabled> [ <scope> } ] ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                                      |
| cfs                     | CFS Show Command handler   |
| regions                 | Show all the applications with peers and region information          |
| brief                   | (Optional) Show all configured regions and applications(no peers)    |
| region                  | (Optional) Show all configured applications(no peers)                |
| <i>i0</i>               | (Optional) Region Id   |
| name                    | (Optional) Show peers and region information for a given application |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application                  |
| region1                 | (Optional) Show all configured applications with peers               |
| <i>i1</i>               | (Optional) Region Id   |
| __readonly__            | (Optional)   |
| region                  | (Optional) region  |
| <i>id</i>               | (Optional) id  |
| application             | (Optional) app   |
| <i>name</i>             | (Optional) name  |
| scope                   | (Optional) scope   |
| <i>scope</i>            | (Optional) scope   |
| TABLE_PEERS             | (Optional) all region peers  |
| <i>wwn</i>              | (Optional) wwn   |
| <i>ip_addr</i>          | (Optional) ip_address  |
| <i>local</i>            | (Optional) local   |
| <i>hostname</i>         | (Optional) hname   |
| <i>domain</i>           | (Optional) domain  |

|                       |                                   |
|-----------------------|-----------------------------------|
| <i>TABLE_switches</i> | (Optional) all switches in region |
| <i>wwn</i>            | (Optional) wwn                    |
| <i>ip_addr</i>        | (Optional) ip_addr                |
| <i>region</i>         | (Optional) region                 |
| <i>app_name</i>       | (Optional) name                   |
| <i>enabled</i>        | (Optional) enabled                |
| <i>scope</i>          | (Optional) scope                  |

**Command Mode**

- /exec

# show cfs static peers

show cfs static peers

## Syntax Description

|        |  |
|--------|--|
| show   | Show running system information              |
| cfs    | CFS Show Command handler                     |
| static | Show all static peers with status            |
| peers  | Show all configured static peers with status |

## Command Mode

- /exec

## show cfs status

```
show cfs status [ __readonly__ <distribution> <dist_over_ip> <ipv4_mcast_addr> <ipv6_mcast_addr>
<dist_over_eth> ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                   |
| cfs                    | CFS Show Command handler                          |
| status                 | Show current status of CFS                        |
| <i>__readonly__</i>    | (Optional)  |
| <i>distribution</i>    | (Optional) operational status of CFS distribution |
| <i>dist_over_ip</i>    | (Optional) operational status of CFS overIP       |
| <i>ipv4_mcast_addr</i> | (Optional) ipv4 multicast address                 |
| <i>ipv6_mcast_addr</i> | (Optional) ipv6 multicast address                 |
| <i>dist_over_eth</i>   | (Optional) operations status of CFSoE             |

### Command Mode

- /exec

# show checkpoint

```
show checkpoint [ all ] [ user | system ] [ __readonly__ TABLE_checkpoint_details <name>
<checkpoint_config> + ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                                |
| checkpoint               | Show configuration rollback checkpoints                        |
| all                      | (Optional) Show default config                                 |
| user                     | (Optional) Show only user configuration rollback checkpoints   |
| system                   | (Optional) Show only system configuration rollback checkpoints |
| __readonly__             | (Optional) Read only   |
| TABLE_checkpoint_details | (Optional) checkpoint details                                  |
| <i>name</i>              | (Optional) Checkpoint name                                     |
| <i>checkpoint_config</i> | (Optional) Configuration entry from checkpoint                 |

## Command Mode

- /exec

# show checkpoint

show checkpoint <chkpoint\_name> [ all ] [ \_\_readonly\_\_ TABLE\_checkpoint\_details <name1>  
<checkpoint\_config> + ]

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                 |
| checkpoint               | Show configuration rollback checkpoint contents |
| <i>chkpoint_name</i>     | Checkpoint name                                 |
| all                      | (Optional) Show default config                  |
| __readonly__             | (Optional) Read only                            |
| TABLE_checkpoint_details | (Optional) Checkpoint details                   |
| <i>name1</i>             | (Optional) Checkpoint name                      |
| <i>checkpoint_config</i> | (Optional) Configuration entry from checkpoint  |

## Command Mode

- /exec



# show checkpoint summary

```
show checkpoint summary [ user | system ] [ __readonly__ TABLE_checkpoint_header_info <name>
<user_name> <timestamp> <file_path> <chkpt_type> <description> ]
```

## Syntax Description

|   |  |
|---|--|
| <code>show</code>                         | Show running system information  |
| <code>checkpoint</code>                   | Show configuration rollback checkpoints                                |
| <code>summary</code>                      | Show configuration rollback checkpoints summary                        |
| <code>user</code>                         | (Optional) Show only user configuration rollback checkpoints summary   |
| <code>system</code>                       | (Optional) Show only system configuration rollback checkpoints summary |
| <code>__readonly__</code>                 | (Optional) Read only   |
| <code>TABLE_checkpoint_header_info</code> | (Optional) Checkpoint header info                                      |
| <code>user_name</code>                    | (Optional) Username  |
| <code>name</code>                         | (Optional) Checkpoint name   |
| <code>file_path</code>                    | (Optional) Checkpoint name   |
| <code>timestamp</code>                    | (Optional) Timestamp of checkpoint creation                            |
| <code>chkpt_type</code>                   | (Optional) Type of checkpoint either user or system                    |
| <code>description</code>                  | (Optional) Checkpoint description                                      |

## Command Mode

- /exec

## show class-map

```
show class-map [ { [ type qos ] [ <omap-name> | xxx <color-map-enum-name> ] } | { type queuing [ yyy
<omap-enum-name> | zzz <default-omap-enum-name> | <omap-dce-name> | <omap-name-hque> ] } ] [
__readonly__ { [ <display-all> ] [ TABLE_omap [ <omap-key> ] [ <nq-omap-key> ] [ <nq-omap-name> ] [
<nq-cos-list> ] [ <nq-qos-group-list> ] [ <protocol> ] [ <id> ] <xqos-or-q> [ <any_or_all> ] <omap-name-out>
[ <desc> ] [ <nq-desc> ] [ TABLE_match <match-key> [ <not> ] [ <dscp-list> ] [ <precedence-list> ] [
<cos-list> ] [ <qos-group-list> ] [ <discard-class-list> ] [ <vlan-list> ] [ <match-omap-name> ] [
<match-acl-name> ] [ <note-string> ] [ <pkt-len-list> ] [ <rtp-port-list> ] [ <roce-port-list> ] [ <prot> ] [
<input-iface-list> ] [ <exp-list> ] [ <cl-def> ] ] ] ] }
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| xxx                           | (Optional) xxx                             |
| yyy                           | (Optional) yyy                             |
| zzz                           | (Optional) zzz                             |
| show                          | Show running system information            |
| class-map                     | Show class maps                            |
| type                          | (Optional) Type of the class-map           |
| qos                           | (Optional) type qos                        |
| queuing                       | (Optional) type queuing                    |
| <i>omap-name</i>              | (Optional) class map name                  |
| <i>omap-enum-name</i>         | (Optional)                                 |
| <i>default-omap-enum-name</i> | (Optional)                                 |
| <i>omap-dce-name</i>          | (Optional) Queuing class-map name          |
| <i>omap-name-hque</i>         | (Optional) Hierarchical class-map name     |
| <i>color-map-enum-name</i>    | (Optional)                                 |
| <i>__readonly__</i>           | (Optional)                                 |
| <i>display-all</i>            | (Optional) Display all kinds of class-maps |
| TABLE_omap                    | (Optional) all omap xml sessions           |
| <i>omap-key</i>               | (Optional) Class-map name: xml key         |
| <i>nq-omap-key</i>            | (Optional) Class-map name nq: xml key      |
| <i>nq-omap-name</i>           | (Optional) Class-map xname                 |
| <i>protocol</i>               | (Optional) protocol                        |

|                           |  |
|---------------------------|--|
| <i>TABLE_match</i>        | (Optional) all match xml sessions  |
| <i>match-key</i>          | (Optional) match count: xml key  |
| <i>cmap-name-out</i>      | (Optional) Class-map name  |
| <i>xqos-or-q</i>          | (Optional)   |
| <i>any_or_all</i>         | (Optional) Enter match-any or match-all                                  |
| <i>id</i>                 | (Optional) Class-map ID  |
| <i>desc</i>               | (Optional) Description string  |
| <i>nq-desc</i>            | (Optional) Description xstring   |
| <i>not</i>                | (Optional) Negate this match result                                      |
| <i>dscp-list</i>          | (Optional) List of DSCP values   |
| <i>precedence-list</i>    | (Optional) List of precedence values                                     |
| <i>cos-list</i>           | (Optional) List of class-of-service values                               |
| <i>nq-cos-list</i>        | (Optional) List of class-of-service values                               |
| <i>qos-group-list</i>     | (Optional) List of qos-group values                                      |
| <i>nq-qos-group-list</i>  | (Optional) List of qos-group values                                      |
| <i>discard-class-list</i> | (Optional) List of discard-class values                                  |
| <i>vlan-list</i>          | (Optional) List of vlan-ids  |
| <i>match-cmap-name</i>    | (Optional) class-map name  |
| <i>match-acl-name</i>     | (Optional) Match class-map name  |
| <i>note-string</i>        | (Optional) Placeholder string param to display any info in string format |
| <i>pkt-len-list</i>       | (Optional) Packet length multi-range                                     |
| <i>rtp-port-list</i>      | (Optional) IP RTP UDP port multi-range                                   |
| <i>roce-port-list</i>     | (Optional) IP ROCE UDP port multi-range                                  |
| <i>prot</i>               | (Optional) Protocol  |
| <i>input-iface-list</i>   | (Optional) Input Interface multi-range                                   |
| <i>exp-list</i>           | (Optional) List of MPLS exp values                                       |
| <i>cl-def</i>             | (Optional) Match any criteria for class-default only                     |

**Command Mode**

- /exec

## show class-map type control-plane

```
show class-map type control-plane [ <omap-name> ] [ __readonly__ [ { TABLE_cmap <omap-key>
<omap-name-out> <opt_any_or_all> [ TABLE_match <match-key> [ access_grp <acc_grp_name> ] [ redirect
<opt_match_redirect> ] [ exception <opt_match_except> ] [ protocol <opt_match_protocol> ] } ] ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                  |
| class-map                 | Show class maps                                  |
| type                      | Type of the class-map                            |
| control-plane             | This is for copp policy                          |
| <i>omap-name</i>          | (Optional) Name of the class-map                 |
| <i>__readonly__</i>       | (Optional)                                       |
| TABLE_cmap                | (Optional) all cmap xml sessions                 |
| <i>omap-name-out</i>      | (Optional) Name of the class-map                 |
| <i>omap-key</i>           | (Optional) Class-map name: xml key               |
| <i>opt_any_or_all</i>     | (Optional) Enter match-any or match-all          |
| TABLE_match               | (Optional) all match xml sessions                |
| <i>match-key</i>          | (Optional) match count: xml key                  |
| access_grp                | (Optional)                                       |
| <i>acc_grp_name</i>       | (Optional)                                       |
| redirect                  | (Optional)                                       |
| <i>opt_match_redirect</i> | (Optional) Match criteria for redirected packets |
| exception                 | (Optional)                                       |
| <i>opt_match_except</i>   | (Optional) Match criteria for exception packets  |
| protocol                  | (Optional)                                       |
| <i>opt_match_protocol</i> | (Optional) Match criteria for protocol packets   |

### Command Mode

- /exec

## show class-map type network-qos

```
show class-map type network-qos [ <omap-name-nq> ] [ __readonly__ { [ <display-all> ] [ TABLE_omap
<omap-key> <xomap-name> [ <desc> ] [ <cos-list> ] [ <qos-group-list> ] [ <protocol> ] [ TABLE_xmatch
<xmatch-key> [ <xcos-list> ] [ <xqos-group-list> ] [ <xprotocol> ] ] ] } ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information               |
| class-map              | Show class maps                               |
| type                   | Type of the class-map                         |
| <i>omap-name-nq</i>    | (Optional) Class-map name                     |
| network-qos            | type network-qos                              |
| <i>__readonly__</i>    | (Optional)                                    |
| <i>display-all</i>     | (Optional) Display all network-qos class-maps |
| TABLE_omap             | (Optional) all network-qos omap xml sessions  |
| <i>omap-key</i>        | (Optional) Class-map name: xml key            |
| <i>xomap-name</i>      | (Optional) Class-map name                     |
| <i>desc</i>            | (Optional) Description string                 |
| TABLE_xmatch           | (Optional) all match xml sessions             |
| <i>xmatch-key</i>      | (Optional) match count: xml key               |
| <i>cos-list</i>        | (Optional) List of class-of-service values    |
| <i>qos-group-list</i>  | (Optional) List of qos-group values           |
| <i>protocol</i>        | (Optional) protocol                           |
| <i>xcos-list</i>       | (Optional) List of class-of-service values    |
| <i>xqos-group-list</i> | (Optional) List of qos-group values           |
| <i>xprotocol</i>       | (Optional) xprotocol                          |

### Command Mode

- /exec

# show cli alias

```
show cli alias [ name <s0> ] [ __readonly__ { TABLE_cli_alias <alias> <name> } ]
```

## Syntax Description

|                 |                                     |
|-----------------|-------------------------------------|
| show            | Show running system information     |
| cli             | Show CLI information                |
| alias           | Display the alias configuration     |
| name            | (Optional) Display a specific alias |
| s0              | (Optional) Specify the alias        |
| __readonly__    | (Optional)                          |
| TABLE_cli_alias | (Optional) cli alias table          |
| alias           | (Optional) alias                    |
| name            | (Optional) name                     |

## Command Mode

- /exec

# show cli dynamic integers

```
show cli dynamic integers [ <name> ] [ __readonly__ TABLE_dynamic_integers <name-o> <min> <max> ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                     |
| cli                    | CLI commands  |
| dynamic                | Display current range of dynamic parameters         |
| integers               | Display current range of dynamic integer parameters |
| <i>name</i>            | (Optional) name of the dynamic parameter            |
| <i>__readonly__</i>    | (Optional)  |
| TABLE_dynamic_integers | (Optional)  |
| <i>name-o</i>          | (Optional)  |
| <i>min</i>             | (Optional)  |
| <i>max</i>             | (Optional)  |

## Command Mode

- /exec

## show cli dynamic strings

show cli dynamic strings [ <name> ] [ \_\_readonly\_\_ TABLE\_dynamic\_strings <name-o> <value> + ]

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| cli                   | CLI commands                                       |
| dynamic               | Display current range of dynamic parameters        |
| strings               | Display current range of dynamic string parameters |
| <i>name</i>           | (Optional) name of the dynamic parameter           |
| <i>__readonly__</i>   | (Optional)   |
| TABLE_dynamic_strings | (Optional)   |
| <i>name-o</i>         | (Optional)   |
| <i>value</i>          | (Optional)   |

### Command Mode

- /exec



# show cli history

show cli history [ this-mode-only | exec-mode | config-mode ] [ <count> | unformatted ] +

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                    |
| cli            | debug cli  |
| history        | history of cli commands                            |
| <i>count</i>   | (Optional) number of lines to display (from end)   |
| unformatted    | (Optional) display just the commands               |
| this-mode-only | (Optional) display history from current mode only  |
| exec-mode      | (Optional) display history of exec commands only   |
| config-mode    | (Optional) display history of config commands only |

## Command Mode

- /exec

# show cli interface table

show cli interface table

## Syntax Description

|           |           |
|-----------|-----------|
| show      | show      |
| cli       | cli       |
| interface | interface |
| table     | table     |

## Command Mode

- /exec

# show cli list

show cli list [ detail | recurse | <component> | <max-per-cmd> | has-xml-out ] +

## Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| cli                | Show CLI information            |
| list               | show                            |
| <i>component</i>   | (Optional) component            |
| <i>max-per-cmd</i> | (Optional) max                  |
| has-xml-out        | (Optional) show                 |
| recurse            | (Optional) go                   |
| detail             | (Optional) formats              |

## Command Mode

- /exec

# show cli syntax

show cli syntax [ long | recurse ] + [ has-xml-out | has-no-xml-out | is-data-modeled ] [ roles [ network-admin | network-operator | <roles-mask> ] ]

## Syntax Description

|                   |                                 |
|-------------------|---------------------------------|
| show              | Show running system information |
| cli               | Show CLI information            |
| syntax            | show                            |
| long              | (Optional) use                  |
| recurse           | (Optional) also                 |
| has-xml-out       | (Optional) show                 |
| has-no-xml-out    | (Optional) show                 |
| is-data-modeled   | (Optional) show                 |
| roles             | (Optional) show                 |
| network-admin     | (Optional) show                 |
| network-operator  | (Optional) show                 |
| <i>roles-mask</i> | (Optional) show                 |

## Command Mode

- /exec

# show cli variables

```
show cli variables [ __readonly__ <switchname> <timestamp> <currentuser> [ { TABLE_variable <key>
<value> } ] [ { TABLE_session_variable <key> <value> } ] ]
```

## Syntax Description

|                        |                                   |
|------------------------|-----------------------------------|
| show                   | Show running system information   |
| cli                    | Show CLI information              |
| variables              | Show CLI variables                |
| <i>__readonly__</i>    | (Optional)                        |
| <i>switchname</i>      | (Optional) Switch Name            |
| <i>timestamp</i>       | (Optional) Timestamp              |
| <i>currentuser</i>     | (Optional) Current User           |
| TABLE_variable         | (Optional) Variable table         |
| <i>key</i>             | (Optional) key                    |
| <i>value</i>           | (Optional) value                  |
| TABLE_session_variable | (Optional) Session variable table |
| <i>key</i>             | (Optional) key                    |
| <i>value</i>           | (Optional) value                  |

## Command Mode

- /exec

# show clock

```
show clock [ detail ] [ __readonly__ { <simple_time> <time_source> [ <daylight_zone> <daylight_start_week>
<daylight_start_weekday> <daylight_start_month> <daylight_start_time> <daylight_end_week>
<daylight_end_weekday> <daylight_end_month> <daylight_end_time> <daylight_utc_min_offset> } } ]
```

## Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | Show running system information                              |
| clock                          | Display current Date   |
| detail                         | (Optional) Display current date and summertime configuration |
| __readonly__                   | (Optional)   |
| <i>simple_time</i>             | (Optional) simple clock format                               |
| <i>time_source</i>             | (Optional) Time source                                       |
| <i>daylight_zone</i>           | (Optional) summer-time daylight zone                         |
| <i>daylight_start_week</i>     | (Optional) daylight start week                               |
| <i>daylight_start_weekday</i>  | (Optional) daylight start weekday                            |
| <i>daylight_start_month</i>    | (Optional) daylight start month                              |
| <i>daylight_start_time</i>     | (Optional) daylight start time                               |
| <i>daylight_end_week</i>       | (Optional) daylight end week                                 |
| <i>daylight_end_weekday</i>    | (Optional) daylight end weekday                              |
| <i>daylight_end_month</i>      | (Optional) daylight end month                                |
| <i>daylight_end_time</i>       | (Optional) daylight end time                                 |
| <i>daylight_utc_min_offset</i> | (Optional) daylight utc offset                               |

## Command Mode

- /exec

## show config-profile

```
show config-profile [ name <all_conf_profile_name> ] [ __readonly__ TABLE_conf_profile_all
<conf_profile_name> { [ <conf_profile_desc> ] <conf_profile_cfg> + [ <conf_profile_applied> ] + [
<conf_profile_include> ] + } ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                    |
| config-profile                | Show config-profiles                               |
| name                          | (Optional) config-profile name                     |
| <i>all_conf_profile_name</i>  | (Optional) Enter the name of configuration profile |
| <i>__readonly__</i>           | (Optional)   |
| <i>TABLE_conf_profile_all</i> | (Optional)   |
| <i>conf_profile_name</i>      | (Optional)   |
| <i>conf_profile_desc</i>      | (Optional)   |
| <i>conf_profile_cfg</i>       | (Optional)   |
| <i>conf_profile_applied</i>   | (Optional)   |
| <i>conf_profile_include</i>   | (Optional)   |

### Command Mode

- /exec

## show config-profile applied

```
show config-profile { applied [ auto | manually ] | non-applied } [ match-name <profile_substring> ] [
__readonly__ [ <profiles> ] + ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information   |
| config-profile           | Show config-profiles  |
| applied                  | List of config-profiles that are applied                                    |
| auto                     | (Optional) List of config-profiles that are applied via auto-config         |
| manually                 | (Optional) List of all config-profiles which were applied directly from cli |
| non-applied              | List of config-profiles that are not applied                                |
| match-name               | (Optional) List of all config-profiles that have matching sub-string        |
| __readonly__             | (Optional)  |
| <i>profiles</i>          | (Optional)  |
| <i>profile_substring</i> | (Optional) Enter a substring to match with config-profile name              |

### Command Mode

- /exec



## show config-replace log exec

```
show config-replace log { exec | verify } [ __readonly__ [ <last_operation> ] [ <checkpoint_name> ] [ <scheme> ] [ <user> ] [ <config_replace_type> ] [ <verbose> ] [ <start_time> ] [ <start_time_utc> ] [ <log_entry> + ] [ <end_time> ] [ <end_time_utc> ] [ <status> ] [ <restoring_previous_status> + ] [ <executing_switch_profile_patch> + ] [ <tobe_removed_present> + ] [ <tobe_added_missing> + ] [ <executing_patch> + ] [ <validating_patch> + ] [ <executing_patch_post_validation> + ] [ <retrying_patch> + ] [ <restore_previous_config> + ] [ <undo_end_time> ] [ <undo_end_time_utc> ] [ <undo_status> ] ]
```

### Syntax Description

|                                       |   |
|---------------------------------------|---|
| show                                  | Show running system information                 |
| config-replace                        | Show config-replace                             |
| log                                   | show config-replace log                         |
| exec                                  | show config-replace execution log               |
| verify                                | show config-replace verify log                  |
| <i>__readonly__</i>                   | (Optional) Read only                            |
| <i>last_operation</i>                 | (Optional) last operation                       |
| <i>checkpoint_name</i>                | (Optional) checkpoint name                      |
| <i>scheme</i>                         | (Optional) scheme                               |
| <i>user</i>                           | (Optional) user                                 |
| <i>config_replace_type</i>            | (Optional) config-replace type                  |
| <i>verbose</i>                        | (Optional) verbose                              |
| <i>start_time</i>                     | (Optional) Start Time                           |
| <i>start_time_utc</i>                 | (Optional) Start Time UTC                       |
| <i>log_entry</i>                      | (Optional) log entry from configure replace log |
| <i>end_time</i>                       | (Optional) End Time                             |
| <i>end_time_utc</i>                   | (Optional) End Time UTC                         |
| <i>status</i>                         | (Optional) status                               |
| <i>restoring_previous_status</i>      | (Optional) Restoring Previous Config Status     |
| <i>executing_switch_profile_patch</i> | (Optional) Executing Switch profile Patch       |
| <i>tobe_removed_present</i>           | (Optional) log entry from configure replace log |
| <i>tobe_added_missing</i>             | (Optional) log entry from configure replace log |

|  |  |
|--|--|
| <i>undo_end_time</i>                   | (Optional) Undo End Time                   |
| <i>undo_end_time_utc</i>               | (Optional) Undo End Time UTC               |
| <i>executing_patch</i>                 | (Optional) Executing Patch                 |
| <i>validating_patch</i>                | (Optional) Validating Patch                |
| <i>executing_patch_post_validation</i> | (Optional) Executing Patch post validation |
| <i>retrying_patch</i>                  | (Optional) Retrying Rollback Patch         |
| <i>restore_previous_config</i>         | (Optional) Restoring previous config       |
| <i>undo_status</i>                     | (Optional) undo status                     |

**Command Mode**

- /exec

## show config-replace status

```
show config-replace status [ __readonly__ <last_operation> [ <config_replace_type> ] [ <name> ] [
<start_time> ] [ <end_time> ] [ <operation_status> ] [ <commit_status> ] [ <commit_timeout_remaining> ]
]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                 |
| config-replace                  | show config-replace                             |
| status                          | show status of last configure replace operation |
| <i>__readonly__</i>             | (Optional) Read only                            |
| <i>last_operation</i>           | (Optional) last operation                       |
| <i>config_replace_type</i>      | (Optional) config-replace type                  |
| <i>name</i>                     | (Optional) name                                 |
| <i>start_time</i>               | (Optional) start time                           |
| <i>end_time</i>                 | (Optional) end time                             |
| <i>operation_status</i>         | (Optional) operation status                     |
| <i>commit_status</i>            | (Optional) Commit status                        |
| <i>commit_timeout_remaining</i> | (Optional) commit timeout remaining             |

### Command Mode

- /exec

# show configuration

show configuration { commit list | dual-stage sessions }

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information               |
| configuration | Show information about configuration sessions |
| commit        | commit information                            |
| list          | Information about commit-id                   |
| dual-stage    | Active dual stage session                     |
| sessions      | Users with active configuration sessions      |

## Command Mode

- /exec

# show configuration

show configuration

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information               |
| configuration | Show information about configuration sessions |

## Command Mode

- /exec

# show configuration commit

show configuration commit { changes <conf-commit-id> | <conf-commit-id> | log }

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| configuration         | Show information about configuration sessions |
| commit                | commit information                            |
| changes               | difference in committed configs               |
| <i>conf-commit-id</i> | commit ID                                     |
| log                   | Displays execution logs of last commit        |

## Command Mode

- /exec

# show configuration failed

show configuration failed [ noerrors ]

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information                                |
| configuration | Show information about configuration sessions                  |
| failed        | Contents of failed configuration                               |
| noerrors      | (Optional) Failed items in last commit (exclude error reasons) |

## Command Mode

- /exec

# show configuration file

show configuration file <uri0> [ clear-text ]

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information               |
| configuration | Show information about configuration sessions |
| file          | Displays content of files                     |
| <i>uri0</i>   | Filename to be displayed                      |
| clear-text    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED     |

## Command Mode

- /exec



# show configuration session

```
show configuration session [ __readonly__ [ TABLE_session_all <ssn-name> [ TABLE_session_all_cmd [
<ssn-cmd-num> ] [ <command> ] ] ] <activesesscnt> ]
```

## Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information                    |
| configuration                | Show information about configuration sessions      |
| session                      | Show active configuration sessions                 |
| <i>__readonly__</i>          | (Optional) Read only                               |
| <i>TABLE_session_all</i>     | (Optional) Show session table                      |
| <i>ssn-name</i>              | (Optional)   |
| <i>TABLE_session_all_cmd</i> | (Optional) Show session related commands           |
| <i>ssn-cmd-num</i>           | (Optional)   |
| <i>command</i>               | (Optional)   |
| <i>activesesscnt</i>         | (Optional) Number of active configuration sessions |

## Command Mode

- /exec

# show configuration session

```
show configuration session <s3> [ __readonly__ <ssn-name> [ TABLE_session_details [ <ssn-cmd-num> ]
[ <command> ] ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| configuration         | Show information about configuration sessions  |
| session               | Show active configuration sessions             |
| s3                    | Shows configuration session given a name       |
| __readonly__          | (Optional) Read only                           |
| ssn-name              | (Optional)                                     |
| TABLE_session_details | (Optional) Show session details for given name |
| ssn-cmd-num           | (Optional)                                     |
| command               | (Optional)                                     |

## Command Mode

- /exec

# show configuration session global-info

```
show configuration session global-info [ __readonly__ <max-ssns> <max-cmds> <curr-num-ssns>
<curr-num-cmds> ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information               |
| configuration        | Show information about configuration sessions |
| session              | Show active configuration sessions            |
| global-info          | Show configuration sessions global-info       |
| __readonly__         | (Optional) Read only                          |
| <i>max-ssns</i>      | (Optional)                                    |
| <i>max-cmds</i>      | (Optional)                                    |
| <i>curr-num-ssns</i> | (Optional)                                    |
| <i>curr-num-cmds</i> | (Optional)                                    |

## Command Mode

- /exec

## show configuration session status

```
show configuration session status [ <s3> ] [ __readonly__ [ TABLE_session_status <ssn-name> <last-action>
<ac-status> <ac-reason> <ac-tstamp> [ <failed-cmd-num> ] [ <failed-cmd> ] [ <last-vfy-cmd-num> ] [
<last-vfy-cmd> ] [ <last-vfy-tstamp> ] [ <rollback-status> ] ] ]
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                            |
| configuration        | Show information about configuration sessions              |
| session              | Show active configuration sessions                         |
| status               | Show configuration session-mgr status                      |
| s3                   | (Optional) Shows configuration session status given a name |
| __readonly__         | (Optional) Read only                                       |
| TABLE_session_status | (Optional) Show session status table                       |
| ssn-name             | (Optional)   |
| last-action          | (Optional) Last Action                                     |
| ac-status            | (Optional) Last Action Status                              |
| ac-reason            | (Optional) Last Action Reason                              |
| ac-tstamp            | (Optional) Last Action Timestamp                           |
| failed-cmd-num       | (Optional) Failed Command Number                           |
| failed-cmd           | (Optional) Failed Command                                  |
| last-vfy-cmd-num     | (Optional) Last Verified Command Number                    |
| last-vfy-cmd         | (Optional) Last Verified Command                           |
| last-vfy-tstamp      | (Optional) Last Verified Command Timestamp                 |
| rollback-status      | (Optional) Rollback Status                                 |

### Command Mode

- /exec

# show configuration session summary

```
show configuration session summary [ __readonly__ [ TABLE_session_summary <ssn-name> <username>
<tstamp> ] [ <activesesscnt> ] ]
```

## Syntax Description

|                                    |  |
|------------------------------------|--|
| <code>show</code>                  | Show running system information                    |
| <code>configuration</code>         | Show information about configuration sessions      |
| <code>session</code>               | Show active configuration sessions                 |
| <code>summary</code>               | Show summary of the active configuration sessions  |
| <code>__readonly__</code>          | (Optional) Read only                               |
| <code>TABLE_session_summary</code> | (Optional) Show session summary table              |
| <code>ssn-name</code>              | (Optional)   |
| <code>username</code>              | (Optional) Session Owner                           |
| <code>tstamp</code>                | (Optional) Creation Time                           |
| <code>activesesscnt</code>         | (Optional) Number of active configuration sessions |

## Command Mode

- /exec

# show configuration session vsh

```
show configuration session <s3> vsh [ __readonly__ <ssn-name> [ TABLE_session_details_vsh [
<ssn-cmd-num> ] [ <command> ] ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                       |
| configuration             | Show information about configuration sessions         |
| session                   | Show active configuration sessions                    |
| s3                        | Shows configuration session given a name              |
| vsh                       |   |
| __readonly__              | (Optional) Read only                                  |
| TABLE_session_details_vsh | (Optional) Show session details for given name on vsh |
| ssn-name                  | (Optional)  |
| ssn-cmd-num               | (Optional)  |
| command                   | (Optional)  |

## Command Mode

- /exec

# show consistency-checker copp

show consistency-checker copp

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information               |
| consistency-checker | Consistency Checker                           |
| copp                | Verify copp programming from software context |

## Command Mode

- /exec

# show consistency-checker copp extended module

show consistency-checker copp extended module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| copp                | Verify copp programming from software context                   |
| extended            | extended  |
| module              | Limit display to this module                                    |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec



# show consistency-checker dme interfaces

show consistency-checker dme interfaces

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| consistency-checker | Consistency Checker             |
| dme                 | DME (ObjectStore)               |
| interfaces          | interfaces oper data            |

## Command Mode

- /exec

# show consistency-checker egress-xlate private-vlan

show consistency-checker egress-xlate private-vlan <vlan>

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                    |
| consistency-checker | Consistency Checker                                |
| egress-xlate        | Check PVLAN egress-xlate                           |
| private-vlan        | Verifies private-vlan egress-xlate in the hardware |
| <i>vlan</i>         | Enter private-vlan id                              |

## Command Mode

- /exec

# show consistency-checker ehm interface

show consistency-checker ehm interface { <intf> | all }

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| consistency-checker | Consistency Checker                   |
| ehm                 | Show EHM Info                         |
| interface           | Show interface status and information |
| <i>intf</i>         | Virtual Interface                     |
| all                 | Display All Interfaces                |

## Command Mode

- /exec

## show consistency-checker fcoe

```
show consistency-checker fcoe [ { interface <ifl> [ { exclude ping } ] } | { npv [ server-interface <svr_ifl>
external-interface <ext_ifl> ] } | { hw-table { pif | vif | ucpcfg | vsan | acl | fib [ flogi | domain [ local | remote
] ] | fcf | zone | mac } } | { [ exclude ] ping } | { drop [ ingress | egress ] } ] [ verbose [ detail ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                          |
| consistency-checker | Consistency Checker                                      |
| fcoe                | FCoE manager   |
| interface           | (Optional) Interface Test                                |
| <i>ifl</i>          | (Optional) Interface name                                |
| npv                 | (Optional) NPV server to external interface pinning test |
| server-interface    | (Optional) Server Interface Name                         |
| <i>svr_ifl</i>      | (Optional) Server Interface name                         |
| external-interface  | (Optional) External Interface Name                       |
| <i>ext_ifl</i>      | (Optional) External Interface name                       |
| hw-table            | (Optional) Consistency checker for Hardware Tables       |
| pif                 | (Optional) PIF Table Test                                |
| vif                 | (Optional) VIF Table Test                                |
| ucpcfg              | (Optional) Port-channel Program Table Test               |
| vsan                | (Optional) VSAN VLAN related tables                      |
| acl                 | (Optional) ACL Test                                      |
| fib                 | (Optional) FIB Test                                      |
| flogi               | (Optional) FIB Test for FLOGIs                           |
| domain              | (Optional) FIB Test for domains                          |
| local               | (Optional) FIB Test for local domains                    |
| remote              | (Optional) FIB Test for remote domains                   |
| fcf                 | (Optional) FCF Test                                      |
| zone                | (Optional) ZONE Test                                     |
| mac                 | (Optional) MAC Table Test                                |

|         |                                   |
|---------|-----------------------------------|
| exclude | (Optional) Exclude given test     |
| ping    | (Optional) FCPING Test            |
| drop    | (Optional) Hardware drops         |
| ingress | (Optional) Ingress Drop Test      |
| egress  | (Optional) Egress Drop Test       |
| verbose | (Optional) To get debugs          |
| detail  | (Optional) To get detailed debugs |

**Command Mode**

- /exec

# show consistency-checker fex-interfaces fex

show consistency-checker fex-interfaces { fex <id> | interface <ifid> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| fex-interfaces      | Compares software and hardware state of fex interfaces          |
| fex                 | Limit display to interfaces on this fex                         |
| <i>id</i>           | Enter module number   |
| interface           | Limit display to FEX interface                                  |
| <i>ifid</i>         | FEX interface name  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker forwarding

```
show consistency-checker forwarding [ ip | ipv4 ] [ unicast ] [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs
} ] [ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [
<slot_id> ] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adj> ] [ TABLE_inconsistency_adj { <id>
<slot> [ <unit> ] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ] <reason> } ] [ <inconsis_routes> ] [
TABLE_inconsistency_routes { <id> <slot> [ <unit> ] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ]
<reason> } ] [ <run_status> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | show  |
| consistency-checker     | Consistency Checker                           |
| forwarding              | Display Forwarding Information                |
| ip                      | (Optional) ipv4                               |
| ipv4                    | (Optional) ipv4                               |
| unicast                 | (Optional) unicast                            |
| suppress-transient      | (Optional) Suppress Transient state           |
| vrf                     | (Optional) check routes for a specific VRF    |
| <i>vrf-name</i>         | (Optional) VRF name                           |
| module                  | (Optional) check routes for a specific module |
| <i>module</i>           | (Optional) module number                      |
| all_modules             | (Optional) all module's                       |
| all_vrfs                | (Optional) all vrf's                          |
| __readonly__            | (Optional)                                    |
| <i>err_str</i>          | (Optional)                                    |
| <i>cc_header</i>        | (Optional)                                    |
| <i>table_id</i>         | (Optional)                                    |
| <i>slot_id</i>          | (Optional)                                    |
| <i>exec_time</i>        | (Optional)                                    |
| <i>elapsed_time</i>     | (Optional)                                    |
| <i>inconsis_adj</i>     | (Optional)                                    |
| TABLE_inconsistency_adj | (Optional)                                    |

|                            |            |
|----------------------------|------------|
| <i>id</i>                  | (Optional) |
| <i>slot</i>                | (Optional) |
| <i>unit</i>                | (Optional) |
| <i>vrf</i>                 | (Optional) |
| <i>ipaddr</i>              | (Optional) |
| <i>ipprefix</i>            | (Optional) |
| <i>interface</i>           | (Optional) |
| <i>reason</i>              | (Optional) |
| <i>inconsis_routes</i>     | (Optional) |
| TABLE_inconsistency_routes | (Optional) |
| <i>id</i>                  | (Optional) |
| <i>slot</i>                | (Optional) |
| <i>unit</i>                | (Optional) |
| <i>vrf</i>                 | (Optional) |
| <i>ipaddr</i>              | (Optional) |
| <i>ipprefix</i>            | (Optional) |
| <i>interface</i>           | (Optional) |
| <i>reason</i>              | (Optional) |
| <i>run_status</i>          | (Optional) |

**Command Mode**

- /exec



## show consistency-checker forwarding ipv6

```
show consistency-checker forwarding ipv6 [ unicast ] [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ]
[ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id> ]
] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adjsts> ] [ TABLE_inconsistency_adjsts { <idipv6> <slotipv6>
[ <unitipv6> ] <vrfipv6> [ <ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [
<inconsis_routes> ] [ TABLE_inconsistency_routes { <idipv6> <slotipv6> [ <unitipv6> ] <vrfipv6> [
<ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [ <run_status> ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | show  |
| consistency-checker        | Consistency Checker                           |
| forwarding                 | Display Forwarding Information                |
| ipv6                       | ipv6  |
| unicast                    | (Optional) unicast                            |
| suppress-transient         | (Optional) Suppress Transient state           |
| vrf                        | (Optional) check routes for a specific VRF    |
| <i>vrf-name</i>            | (Optional) VRF name                           |
| module                     | (Optional) check routes for a specific module |
| <i>module</i>              | (Optional) module number                      |
| all_modules                | (Optional) all module's                       |
| all_vrfs                   | (Optional) all vrf's                          |
| __readonly__               | (Optional)                                    |
| <i>err_str</i>             | (Optional)                                    |
| <i>cc_header</i>           | (Optional)                                    |
| <i>table_id</i>            | (Optional)                                    |
| <i>slot_id</i>             | (Optional)                                    |
| <i>exec_time</i>           | (Optional)                                    |
| <i>elapsed_time</i>        | (Optional)                                    |
| <i>inconsis_adjsts</i>     | (Optional)                                    |
| TABLE_inconsistency_adjsts | (Optional)                                    |
| <i>idipv6</i>              | (Optional)                                    |

|                            |            |
|----------------------------|------------|
| <i>slotipv6</i>            | (Optional) |
| <i>unitipv6</i>            | (Optional) |
| <i>vrfipv6</i>             | (Optional) |
| <i>interfaceipv6</i>       | (Optional) |
| <i>reasonipv6</i>          | (Optional) |
| <i>inconsis_routes</i>     | (Optional) |
| TABLE_inconsistency_routes | (Optional) |
| <i>idipv6</i>              | (Optional) |
| <i>slotipv6</i>            | (Optional) |
| <i>unitipv6</i>            | (Optional) |
| <i>vrfipv6</i>             | (Optional) |
| <i>interfaceipv6</i>       | (Optional) |
| <i>reasonipv6</i>          | (Optional) |
| <i>run_status</i>          | (Optional) |

**Command Mode**

- /exec

# show consistency-checker forwarding single-route ipv4 vrf

```
show consistency-checker forwarding single-route { ipv4 | ipv6 } <ip-prefix> vrf { <vrf-name> |
<vrf-known-name> } [ brief | detail ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| consistency-checker   | Consistency Checker   |
| forwarding            | Display Forwarding Information                                  |
| single-route          | Run the consistency checker for a single route                  |
| ipv4                  | IPv4 address  |
| ipv6                  | IPv6 address  |
| <i>ip-prefix</i>      | Specify an IP prefix/mask                                       |
| vrf                   | check routes for a specific VRF                                 |
| <i>vrf-name</i>       | VRF name  |
| <i>vrf-known-name</i> | Known VRF name  |
| brief                 | (Optional) Show consistency checker structured output in brief  |
| detail                | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker fsync

show consistency-checker fsync [ debug-logs ] [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| fsync               | Do consistency check for frequency synchronization              |
| debug-logs          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker gwmacdb

show consistency-checker gwmacdb [ interface { <int-id> | <ch-id> | <vlan-id> } ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| gwmacdb             | Check gateway mac table   |
| interface           | (Optional) interface  |
| <i>int-id</i>       | (Optional) Physical or Logical interface                        |
| <i>ch-id</i>        | (Optional) Port-Channel name                                    |
| <i>vlan-id</i>      | (Optional) SVI VLAN   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker hardware-telemetry inband brief

show consistency-checker hardware-telemetry inband { brief | detail }

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                      |
| consistency-checker | Consistency Checker                                  |
| hardware-telemetry  | feature hardware-telemetry                           |
| inband              | inband-telemetry version                             |
| brief               | Show consistency checker structured output in brief  |
| detail              | Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker hardware-telemetry postcard brief

show consistency-checker hardware-telemetry postcard { brief | detail }

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                      |
| consistency-checker | Consistency Checker                                  |
| hardware-telemetry  | feature hardware-telemetry                           |
| postcard            | postcard-telemetry version                           |
| brief               | Show consistency checker structured output in brief  |
| detail              | Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker kim

show consistency-checker kim

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| consistency-checker | Consistency Checker             |
| kim                 | Kernel Interface                |

## Command Mode

- /exec



# show consistency-checker kim interface

```
show consistency-checker kim { interface <ifid> } [ brief | detail ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| kim                 | kernel interface  |
| interface           | Limit display to interface                                      |
| <i>ifid</i>         | Interface   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker l2-tahoe mac-address

show consistency-checker l2-tahoe mac-address <mac-addr> [ module <module> ] [ unit <unit> ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l2-tahoe            | Verify l2 mac programming in the hardware                       |
| mac-address         | MAC address   |
| <i>mac-addr</i>     | address   |
| module              | (Optional) Module to run the consistency-checker on             |
| <i>module</i>       | (Optional) Module number  |
| unit                | (Optional) Unit to run the consistency checker on               |
| <i>unit</i>         | (Optional) Enter Unit Number                                    |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker l2-tahoe sub-interface

show consistency-checker l2-tahoe sub-interface { <if\_name> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l2-tahoe            | Verify l2 sub-interface programming in the hardware             |
| sub-interface       | sub-interface   |
| <i>if_name</i>      | Physical or Logical interface                                   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker l2-tahoe sub-interface vlan

show consistency-checker l2-tahoe sub-interface vlan <vlan-id>

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| consistency-checker | Consistency Checker                                 |
| l2-tahoe            | Verify l2 sub-interface programming in the hardware |
| sub-interface       | sub-interface                                       |
| vlan                | Do consistency check for vlan                       |
| <i>vlan-id</i>      | vlan number   |

### Command Mode

- /exec

## show consistency-checker l2-tahoe switchport

```
show consistency-checker l2-tahoe switchport { interface { <if_name> | all } | module { <module> | all } } [
brief | detail ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l2-tahoe            | Verify l2 mac programming in the hardware                       |
| switchport          | Switchport Interface  |
| interface           | interface   |
| <i>if_name</i>      | Physical or Logical interface                                   |
| all                 | All switchport interfaces                                       |
| module              | Module to run the consistency-checker on                        |
| <i>module</i>       | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker l2 module

show consistency-checker { l2-tahoe | l2-mtc } module <module> [ unit <unit> ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l2-tahoe            | Verify l2 mac programming in the hardware                       |
| l2-mtc              | Verify l2 mac programming in the hardware                       |
| module              | Module to run the consistency-checker on                        |
| <i>module</i>       | Enter module number   |
| unit                | (Optional) Unit to run the consistency checker on               |
| <i>unit</i>         | (Optional) Enter unit number                                    |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker l2 multicast group source vlan

```
show consistency-checker l2 multicast group { <grp-address> | <grp-ipv6-address> } source { <src-address>
| <src-ipv6-address> } vlan <vlan-id> [ debug-logs ] [ brief | detail ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l2                  | Verify l2 mac programming in the hardware                       |
| multicast           | multicast related information                                   |
| group               | Do consistency check for group                                  |
| <i>grp-address</i>  | group IP address  |
| source              | Do consistency check for source                                 |
| <i>src-address</i>  | source IP address   |
| vlan                | Do consistency check for vlan                                   |
| <i>vlan-id</i>      | vlan number   |
| debug-logs          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker l2 multicast mac vlan

show consistency-checker l2 multicast mac <mac-address> vlan <vlan-id> [ debug-logs ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l2                  | Verify l2 mac programming in the hardware                       |
| multicast           | multicast related information                                   |
| mac                 | Do consistency check for multicast mac address lookup           |
| <i>mac-address</i>  | mac address   |
| vlan                | Do consistency check for vlan                                   |
| <i>vlan-id</i>      | vlan number   |
| debug-logs          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec



## show consistency-checker l3-interface

```
show consistency-checker l3-interface { all | module <moduleid> | interface { <ifid> | <ch-id> | <vlan-id> }
} [ brief | detail ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| l3-interface        | Compares software and hardware properties of L3 interfaces      |
| all                 | Run on all modules on the switch                                |
| module              | Limit display to interfaces on module                           |
| <i>moduleid</i>     | Module number   |
| interface           | Limit display to interface                                      |
| <i>ifid</i>         | Interface name  |
| <i>ch-id</i>        | Port-Channel name   |
| <i>vlan-id</i>      | SVI VLAN  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker l3 multicast group source vrf

```
show consistency-checker l3 multicast group { <grp-address> [ <mask> ] | <gprefix> | <grp-ipv6-address> }
source { <src-address> | <src-ipv6-address> } vrf { <vrf-name> | <vrf-known-name> } [ debug-logs ] [ brief
| detail ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| consistency-checker   | Consistency Checker   |
| l3                    | l3 consistency  |
| multicast             | multicast related information                                   |
| group                 | Do consistency check for group                                  |
| <i>grp-address</i>    | group IP address  |
| <i>mask</i>           | (Optional) mask for group ip address                            |
| <i>gprefix</i>        | IPv4 Multicast Group Prefix                                     |
| source                | Do consistency check for source                                 |
| <i>src-address</i>    | source IP address   |
| vrf                   | Do consistency check for vrf                                    |
| <i>vrf-name</i>       | VRF name  |
| <i>vrf-known-name</i> | Known VRF name  |
| debug-logs            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| brief                 | (Optional) Show consistency checker structured output in brief  |
| detail                | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker link-state fabric-ieth

```
show consistency-checker link-state fabric-ieth { [ module <module> ] } [ brief | detail ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| link-state          | Compares software and hardware link state of interfaces         |
| fabric-ieth         | Internal Fabric ports   |
| module              | (Optional) Limit display to interfaces on module                |
| <i>module</i>       | (Optional) Enter module number                                  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker link-state module

show consistency-checker link-state { module <module> | interface <ifid> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| link-state          | Compares software and hardware link state of interfaces         |
| module              | Limit display to interfaces on module                           |
| <i>module</i>       | Module number   |
| interface           | Limit display to interface                                      |
| <i>ifid</i>         | Interface name  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker membership port-channels

show consistency-checker membership port-channels [ interface <ch-id> ] [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| membership          | Check various memberships                                       |
| port-channels       | Verifies port channel membership in the hardware                |
| interface           | (Optional) Port-channel number                                  |
| <i>ch-id</i>        | (Optional) Port-Channel name                                    |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker membership vlan

```
show consistency-checker membership vlan <vlanid> [ [ interface [ <intf-id> | <ch-id> ] ] ] [ private-vlan [
interface [ <int-id> | <ch-id> ] ] ] [ native-vlan ] [ brief | detail ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| vlan                | Verifies vlan membership in the hardware                        |
| <i>vlanid</i>       | Enter vlan id   |
| consistency-checker | Consistency Checker   |
| membership          | Check various memberships                                       |
| interface           | (Optional) Interface  |
| <i>intf-id</i>      | (Optional) Interface  |
| <i>ch-id</i>        | (Optional) Port-Channel name                                    |
| private-vlan        | (Optional) Check private-vlan primary vlan                      |
| interface           | (Optional) Interface  |
| <i>int-id</i>       | (Optional) Interface name                                       |
| <i>ch-id</i>        | (Optional) Port-Channel name                                    |
| native-vlan         | (Optional) Check for native vlans                               |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker multicast nlb cluster-ip vrf

```
show consistency-checker multicast nlb cluster-ip <ip-address> vrf { <vrf-name> | <vrf-known-name> } [
debug-logs ] [ brief | detail ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| consistency-checker   | Consistency Checker   |
| multicast             | multicast related information                                   |
| nlb                   | Do consistency check for Multicast NLB                          |
| cluster-ip            | Cluster virtual unicast IP address                              |
| <i>ip-address</i>     | Cluster IP address  |
| vrf                   | Do consistency check for vrf                                    |
| <i>vrf-name</i>       | VRF name  |
| <i>vrf-known-name</i> | Known VRF name  |
| debug-logs            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| brief                 | (Optional) Show consistency checker structured output in brief  |
| detail                | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker multicast vlan

show consistency-checker multicast vlan <vlanid> [ group <group\_ip> | destination-mac <dst\_mac> ]

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                                  |
| consistency-checker | Consistency Checker  |
| multicast           | Verify Multicast   |
| vlan                | Verifies vlan flood sharing                                      |
| <i>vlanid</i>       | Enter vlan id  |
| group               | (Optional) Do consistency check for a group                      |
| <i>group_ip</i>     | (Optional) Multicast IP address of single group to display       |
| destination-mac     | (Optional) Do consistency check for a destination-mac            |
| <i>dst_mac</i>      | (Optional) Multicast Destination mac Address for Vlan to display |

### Command Mode

- /exec



# show consistency-checker niv-datapath interface

show consistency-checker niv-datapath interface <intf>

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| consistency-checker | Consistency Checker                       |
| niv-datapath        | Verify NIV Datapath for a given interface |
| interface           | Show interface status and information     |
| <i>intf</i>         | Virtual interface                         |

## Command Mode

- /exec

# show consistency-checker pacl extended ingress ip interface

show consistency-checker pacl extended ingress ip interface { <int-id> | <ch-id> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ip                  | ip protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker pacl extended ingress ip module

show consistency-checker pacl extended ingress ip module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ip                  | ip protocol   |
| module              | Limit display to L2 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker pacl extended ingress ipv6 module

show consistency-checker pacl extended ingress ipv6 module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ipv6                | ipv6 protocol   |
| module              | Limit display to L2 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker pacl extended ingress ipv6 interface

show consistency-checker pacl extended ingress ipv6 interface { <int-id> | <ch-id> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ipv6                | ipv6 protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker pacl extended ingress mac module

show consistency-checker pacl extended ingress mac module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| mac                 | ethernet protocol   |
| module              | Limit display to L2 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker pacl extended ingress mac interface

show consistency-checker pacl extended ingress mac interface { <int-id> | <ch-id> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| mac                 | ethernet protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker pacl extended module

show consistency-checker pacl extended module { all | <module-id> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| pacl                | Verify pacl programming in the hardware                         |
| extended            | extended  |
| module              | Limit display to L2 interfaces on this module                   |
| all                 | To run cc across all the modules                                |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec



# show consistency-checker pacl module

show consistency-checker pacl module <module>

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information               |
| consistency-checker | Consistency Checker                           |
| pacl                | Verify pacl programming in the hardware       |
| module              | Limit display to L2 interfaces on this module |
| <i>module</i>       | Enter module number                           |

## Command Mode

- /exec

# show consistency-checker pacl port-channels

show consistency-checker pacl port-channels [ interface <ch-id> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                        |
| consistency-checker | Consistency Checker                                    |
| pacl                | Verify pacl programming in the hardware                |
| port-channels       | Verifies port channel pacl programming in the hardware |
| interface           | (Optional) Port-channel number                         |
| <i>ch-id</i>        | (Optional) Port-Channel name                           |

## Command Mode

- /exec

## show consistency-checker port-state

show consistency-checker port-state [ { module <module> | interface <ifid> } ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| port-state          | Validates SI, MTU and IPG Settings                              |
| module              | (Optional) Limit display to interfaces on module                |
| <i>module</i>       | (Optional) Enter module number                                  |
| interface           | (Optional) Limit display to interface                           |
| <i>ifid</i>         | (Optional) Interface name                                       |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker port-state fabric-ieth

```
show consistency-checker port-state fabric-ieth [ module <module> [ ieth-port <ieth-port> ] ] [ brief | detail ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| port-state          | Validates SI, FEC and MTU Settings                              |
| fabric-ieth         | Internal Fabric ports   |
| module              | (Optional) Limit display to interfaces on module                |
| <i>module</i>       | (Optional) Enter module number                                  |
| ieth-port           | (Optional) Enter ieth-port number                               |
| <i>ieth-port</i>    | (Optional) Enter ieth-port number                               |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker qinq

```
show consistency-checker qinq [ interface [ <int-id> | <ch-id> ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| consistency-checker | Consistency Checker             |
| qinq                | QinQ consistency checker        |
| interface           | (Optional) Interface            |
| <i>int-id</i>       | (Optional) Eth Interface        |
| <i>ch-id</i>        | (Optional) Port-Channel         |

## Command Mode

- /exec

# show consistency-checker racl extended egress ip module

show consistency-checker racl extended egress ip module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| egress              | egress direction  |
| ip                  | ip protocol   |
| module              | Limit display to L3 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker racl extended egress ipv6 module

show consistency-checker racl extended egress ipv6 module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| egress              | egress direction  |
| ipv6                | ipv6 protocol   |
| module              | Limit display to L3 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker racl extended egress ip interface

show consistency-checker racl extended egress ip interface { <int-id> | <ch-id> | <vlan-id> } [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| egress              | egress direction  |
| ip                  | ip protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| <i>vlan-id</i>      | SVI VLAN  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec



# show consistency-checker racl extended egress ipv6 interface

show consistency-checker racl extended egress ipv6 interface { <int-id> | <ch-id> | <vlan-id> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| egress              | egress direction  |
| ipv6                | ipv6 protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| <i>vlan-id</i>      | SVI VLAN  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker racl extended ingress ip module

show consistency-checker racl extended ingress ip module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ip                  | ip protocol   |
| module              | Limit display to L3 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker racl extended ingress ipv6 module

show consistency-checker racl extended ingress ipv6 module <module-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ipv6                | ipv6 protocol   |
| module              | Limit display to L3 interfaces on this module                   |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker racl extended ingress ip interface

```
show consistency-checker racl extended ingress ip interface { <int-id> | <ch-id> | <vlan-id> } [ brief | detail ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ip                  | ip protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| <i>vlan-id</i>      | SVI VLAN  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker racl extended ingress ipv6 interface

show consistency-checker racl extended ingress ipv6 interface { <int-id> | <ch-id> | <vlan-id> } [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ipv6                | ipv6 protocol   |
| interface           | Interface   |
| <i>int-id</i>       | Interface   |
| <i>ch-id</i>        | Port-Channel name   |
| <i>vlan-id</i>      | SVI VLAN  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker racl extended module

show consistency-checker racl extended module { all | <module-id> } [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| racl                | Verify racl programming in the hardware                         |
| extended            | extended  |
| module              | Limit display to L3 interfaces on this module                   |
| all                 | To run CC across all the modules                                |
| <i>module-id</i>    | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker racl module

show consistency-checker racl module <module>

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information               |
| consistency-checker | Consistency Checker                           |
| racl                | Verify racl programming in the hardware       |
| module              | Limit display to L3 interfaces on this module |
| <i>module</i>       | Enter module number                           |

## Command Mode

- /exec

# show consistency-checker racl port-channels

show consistency-checker racl port-channels [ interface <ch-id> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                        |
| consistency-checker | Consistency Checker                                    |
| racl                | Verify racl programming in the hardware                |
| port-channels       | Verifies port channel racl programming in the hardware |
| interface           | (Optional) Port-channel number                         |
| <i>ch-id</i>        | (Optional) Port-Channel name                           |

## Command Mode

- /exec



# show consistency-checker racl svi interface

show consistency-checker racl svi interface <vlan-id>

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information               |
| consistency-checker | Consistency Checker                           |
| racl                | Verify racl programming in the hardware       |
| svi                 | Verifies SVI racl programming in the hardware |
| interface           | SVI number                                    |
| <i>vlan-id</i>      | SVI VLAN                                      |

## Command Mode

- /exec

## show consistency-checker segment-routing mpls

show consistency-checker segment-routing mpls { ip <ip-address> mask <ip-mask> vrf <vrf-name> | label <label> } [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| segment-routing     | Segment-routing   |
| mpls                | MPLS Information  |
| ip                  | IP Information  |
| <i>ip-address</i>   | IP Address  |
| mask                | Mask Information  |
| <i>ip-mask</i>      | Mask Length   |
| vrf                 | VRF Information   |
| <i>vrf-name</i>     | VRF Name  |
| label               | Label Information   |
| <i>label</i>        | Label Name  |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker selective-qinq

show consistency-checker selective-qinq

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| consistency-checker | Consistency Checker                |
| selective-qinq      | Selective QinQ consistency checker |

## Command Mode

- /exec

# show consistency-checker selective-qinq interface

show consistency-checker selective-qinq interface { <int-id> | <ch-id> }

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| consistency-checker | Consistency Checker                |
| selective-qinq      | Selective QinQ consistency checker |
| interface           | Interface                          |
| <i>int-id</i>       | Interface                          |
| <i>ch-id</i>        | Port-Channel name                  |

## Command Mode

- /exec

# show consistency-checker sflow

show consistency-checker sflow [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| sflow               | Compares software and hardware sflow details                    |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker storm-control

show consistency-checker storm-control

## Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                | Show running system information   |
| consistency-checker | Consistency Checker               |
| storm-control       | Storm control consistency checker |

## Command Mode

- /exec

## show consistency-checker stp-state vlan

show consistency-checker stp-state vlan <vlan> [ interface <int-id> ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information   |
| vlan                | Verifies spanning tree state in the hardware for all interfaces in the vlan |
| <i>vlan</i>         | Enter vlan id   |
| interface           | (Optional) Interface  |
| <i>int-id</i>       | (Optional) Interface  |
| consistency-checker | Consistency Checker   |
| stp-state           | Verify spanning tree state in the hardware                                  |
| brief               | (Optional) Show consistency checker structured output in brief              |
| detail              | (Optional) Show consistency checker structured output in detail             |

### Command Mode

- /exec

# show consistency-checker vacl

show consistency-checker vacl

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information         |
| consistency-checker | Consistency Checker                     |
| vacl                | Verify vacl programming in the hardware |

## Command Mode

- /exec



# show consistency-checker vacl extended ingress ipv6 vlan

show consistency-checker vacl extended ingress ipv6 vlan <vlan-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vacl                | Verify vacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ipv6                | ipv6 protocol   |
| vlan                | VLAN  |
| <i>vlan-id</i>      | vlan number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker vacl extended ingress ip vlan

show consistency-checker vacl extended ingress ip vlan <vlan-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vacl                | Verify vacl programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| ip                  | ip protocol   |
| vlan                | VLAN  |
| <i>vlan-id</i>      | vlan number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker vACL extended ingress mac vlan

show consistency-checker vACL extended ingress mac vlan <vlan-id> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vACL                | Verify vACL programming in the hardware                         |
| extended            | extended  |
| ingress             | ingress direction   |
| mac                 | ethernet protocol   |
| vlan                | VLAN  |
| <i>vlan-id</i>      | vlan number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker vpc

show consistency-checker vpc [ source-interface [ <int-id> | <ch-id> ] ] [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vpc                 | vPC related information   |
| source-interface    | (Optional) Source vPC member                                    |
| <i>int-id</i>       | (Optional) Eth Interface  |
| <i>ch-id</i>        | (Optional) Port-Channel   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker vpgrouping interface

show consistency-checker vpgrouping interface { <intf> | all }

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| consistency-checker | Consistency Checker                   |
| vpgrouping          | Show VP Grouping Info                 |
| interface           | Show interface status and information |
| <i>intf</i>         | Physical or Logical Interface         |
| all                 | Display All Interfaces                |

## Command Mode

- /exec

# show consistency-checker vxlan config-check

show consistency-checker vxlan config-check [ verbose-mode ] [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vxlan               | VxLAN consistency checker                                       |
| config-check        | Check the inconsistencies in the config                         |
| verbose-mode        | (Optional) config-check verbose                                 |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker vxlan infra

show consistency-checker vxlan infra [ verbose-mode ] [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| vxlan               | VxLAN consistency checker                                       |
| consistency-checker | Consistency Checker   |
| infra               | infra   |
| verbose-mode        | (Optional) detailed CC output                                   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker vxlan l2 mac-address module

show consistency-checker vxlan l2 mac-address <mac-addr> module <module> [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vxlan               | VxLAN consistency checker                                       |
| l2                  | l2  |
| mac-address         | MAC address   |
| <i>mac-addr</i>     | address   |
| module              | Module to run the consistency-checker on                        |
| <i>module</i>       | Module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec



# show consistency-checker vxlan l2 module

show consistency-checker vxlan l2 module <module> [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vxlan               | VxLAN consistency checker                                       |
| l2                  | Check L2 inconsistencies  |
| module              | Module to run the consistency-checker on                        |
| <i>module</i>       | Enter module number   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

## show consistency-checker vxlan l3 single-route ipv4 vrf

```
show consistency-checker vxlan l3 single-route { ipv4 | ipv6 } <ip-prefix> vrf { <vrf-name> |
<vrf-known-name> } [ debug-logs ] [ brief | detail ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| consistency-checker   | Consistency Checker   |
| vxlan                 | VxLAN consistency checker                                       |
| l3                    | l3  |
| single-route          | Run the consistency checker for a single route                  |
| ipv4                  | IPv4 address  |
| ipv6                  | IPv6 address  |
| <i>ip-prefix</i>      | Overlay L3 Route IP Address in prefix/mask format               |
| vrf                   | Do consistency check for vrf                                    |
| <i>vrf-name</i>       | VRF name  |
| <i>vrf-known-name</i> | Known VRF name  |
| debug-logs            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| brief                 | (Optional) Show consistency checker structured output in brief  |
| detail                | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

## show consistency-checker vxlan l3 vrf start

```
show consistency-checker vxlan l3 vrf { <vrf-name> | all } { start-scan | report }
```

### Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| vxlan               | VxLAN consistency checker       |
| consistency-checker | Consistency Checker             |
| l3                  | l3                              |
| vrf                 | VRF                             |
| <i>vrf-name</i>     | vrf name                        |
| all                 | All VRFs                        |
| start-scan          | Start Route CC                  |
| report              | Show Route CC report            |

### Command Mode

- /exec

# show consistency-checker vxlan mh mac-addresses

show consistency-checker vxlan mh mac-addresses [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| consistency-checker | Consistency Checker   |
| vxlan               | VxLAN consistency checker                                       |
| mh                  | VxLAN BGP EVPN Multi Homing CC commands                         |
| mac-addresses       | Check mac address consistency between L2RIB and L2FM            |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

## Command Mode

- /exec

# show consistency-checker vxlan mh pathlist

show consistency-checker vxlan mh pathlist [ brief | detail ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information   |
| consistency-checker | Consistency Checker   |
| vxlan               | VxLAN consistency checker   |
| mh                  | VxLAN BGP EVPN Multi Homing CC commands                                   |
| pathlist            | Check Vxlan BGP EVPN MH Control plane and resultant pathlists consistency |
| brief               | (Optional) Show consistency checker structured output in brief            |
| detail              | (Optional) Show consistency checker structured output in detail           |

## Command Mode

- /exec

# show consistency-checker vxlan pv

show consistency-checker vxlan pv

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| consistency-checker | Consistency Checker             |
| vxlan               | VxLAN consistency checker       |
| pv                  | pv consistency checker          |

## Command Mode

- /exec

# show consistency-checker vxlan qinq-qinvni

show consistency-checker vxlan qinq-qinvni

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| vxlan               | VxLAN consistency checker       |
| consistency-checker | Consistency Checker             |
| qinq-qinvni         | QinQ consistency checker        |

## Command Mode

- /exec

# show consistency-checker vxlan qinvni

show consistency-checker vxlan qinvni

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| consistency-checker | Consistency Checker             |
| vxlan               | VxLAN consistency checker       |
| qinvni              | QinVNI consistency checker      |

## Command Mode

- /exec



# show consistency-checker vxlan selective-qinvni

show consistency-checker vxlan selective-qinvni

## Syntax Description

|                     |                                      |
|---------------------|--------------------------------------|
| show                | Show running system information      |
| consistency-checker | Consistency Checker                  |
| vxlan               | VxLAN consistency checker            |
| selective-qinvni    | Selective QinVNI consistency checker |

## Command Mode

- /exec

# show consistency-checker vxlan selective-qinvni interface

show consistency-checker vxlan selective-qinvni interface { <int-id> | <ch-id> }

## Syntax Description

|                     |                                      |
|---------------------|--------------------------------------|
| show                | Show running system information      |
| consistency-checker | Consistency Checker                  |
| vxlan               | VxLAN consistency checker            |
| selective-qinvni    | Selective QinVNI consistency checker |
| interface           | Interface                            |
| <i>int-id</i>       | Interface                            |
| <i>ch-id</i>        | Port-Channel name                    |

## Command Mode

- /exec

## show consistency-checker vxlan vlan

show consistency-checker vxlan vlan { <vlanid> | all } [ verbose-mode ] [ brief | detail ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                 |
| vxlan               | VxLAN consistency checker                                       |
| vlan                | Verifies flood list programming for vxlan vlans                 |
| consistency-checker | Consistency Checker   |
| <i>vlanid</i>       | Enter vlan id   |
| all                 | Check CC for all vxlans   |
| verbose-mode        | (Optional) detailed CC output                                   |
| brief               | (Optional) Show consistency checker structured output in brief  |
| detail              | (Optional) Show consistency checker structured output in detail |

### Command Mode

- /exec

# show consistency-checker vxlan xconnect

show consistency-checker vxlan xconnect

## Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                | Show running system information   |
| consistency-checker | Consistency Checker               |
| vxlan               | VxLAN consistency checker         |
| xconnect            | Cross-Connect consistency checker |

## Command Mode

- /exec

# show controller accounting log

show controller <ctrl-id> accounting log

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| controller     | Controller command              |
| <i>ctrl-id</i> | Controller id value             |
| accounting     | Accounting                      |
| log            | Show log information            |

## Command Mode

- /exec

## show copp diff profile profile2

show copp diff profile <profile\_type> [ prior-ver ] profile2 <profile\_type2>

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information        |
| copp                 | Control-Plane Policing                 |
| diff                 | Difference between CoPP Profiles       |
| profile              | CoPP Profile                           |
| <i>profile_type</i>  | CoPP Profile Types                     |
| prior-ver            | (Optional) Previous Configured Version |
| profile2             | CoPP Profile                           |
| <i>profile_type2</i> | CoPP Profile Types                     |

### Command Mode

- /exec

# show copp profile

```

show copp profile { strict | moderate | lenient | dense } [ __readonly__ { TABLE_copp prof <acl-type> {
<acl-grp-name> { TABLE_sequence <permitdeny> [ { <proto_str> | <proto> | <ip> | <ipv6> } ] [ { <src_any>
| <src_ip_prefix> | <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> | <src_addrgrp> | <src_mac_any> |
<src_mac_addr> <src_mac_mask> } ] [ <src_port_op> { <src_port1_str> | <src_port1_num> } [ <src_port2_str>
| <src_port2_num> ] | <src_portgrp> } ] { <dest_any> | <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> |
<dest_ipv6_prefix> | <dest_addrgrp> | <dest_mac_any> | <dest_mac_addr> <dest_mac_mask> } [
<dest_port_op> { <dest_port1_str> | <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] |
<dest_portgrp> } ] [ { <icmp_type> [ <icmp_code> ] | <icmp_str> } ] [ { <icmpv6_type> [ <icmpv6_code> ] |
<icmpv6_str> } ] [ <eth_proto> ] } } } <newline> [ { TABLE_classmap <opt_any_or_all> [ <omap_name>
] [ { access_grp <acc_grp_name> + } ] [ { redirect <opt_match_redirect> + } ] [ { exception <opt_match_excpt>
+ } ] [ { protocol <opt_match_protocol> + } ] } ] [ { TABLE_policymap [ <class-name> ] [ <pmap_name>
] [ <set_vld_flg> ] [ { cos [ inner ] <cos-val> } ] [ { dscp [ tunnel ] [ <dscp-val> ] } ] [ { precedence [ tunnel1
] [ <prec-val> ] } ] [ <policer_show_flags> ] [ <cir> ] [ <opt_kbps_mbps_gbps_pps_cir> ] [ { percent <cir-perc>
} ] [ <bc> + ] [ <opt_kbytes_mbytes_gbytes_bc> + ] [ <pir> ] [ <opt_kbps_mbps_gbps_pps_pir> ] [ { percent1
<pir-perc> } ] [ <be> ] [ <opt_kbytes_mbytes_gbytes_be> ] [ <opt_drop_transmit_conform> ] [
<opt_drop_transmit_violate> ] [ { { [ <opt_drop_transmit_conform1> ] } | { set-cos-transmit [ <set-cos-val>
] } } | { set-dscp-transmit [ <set-dscp-val> ] } | { set-prec-transmit [ <set-prec-val> ] } } ] [ { { {
<opt_drop_transmit_exceed> } } | { set dscp1 dscp2 table cir-markdown-map } } ] [ { { {
<opt_drop_transmit_violate1> } } | { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] } ] } ]

```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| copp                | Control-Plane Policing             |
| profile             | CoPP Profile                       |
| strict              | display strict profile             |
| moderate            | display moderate profile           |
| lenient             | display lenient profile            |
| dense               | display dense profile              |
| <u>__readonly__</u> | (Optional) Read Only               |
| <i>acl-type</i>     | (Optional) access-list type        |
| TABLE_copp prof     | (Optional) copp profile            |
| <i>acl-grp-name</i> | (Optional) name of the access-list |
| TABLE_sequence      | (Optional) ACE RULE SYNTAX TABLE   |
| <i>permitdeny</i>   | (Optional) permit/deny             |
| <i>proto</i>        | (Optional) A protocol number       |
| <i>proto_str</i>    | (Optional) Protocol name           |

|                       |                                      |
|-----------------------|--------------------------------------|
| <i>ip</i>             | (Optional) IP                        |
| <i>ipv6</i>           | (Optional) IPV6                      |
| <i>src_any</i>        | (Optional) SRCAny                    |
| <i>dest_any</i>       | (Optional) DESTAny                   |
| <i>src_ip_prefix</i>  | (Optional) Source IP prefix          |
| <i>src_ip_addr</i>    | (Optional) Source IP address         |
| <i>src_ip_mask</i>    | (Optional) Source IP mask            |
| <i>src_mac_addr</i>   | (Optional) Source MAC address        |
| <i>src_mac_mask</i>   | (Optional) Source MAC mask           |
| <i>src_mac_any</i>    | (Optional) SRCMACAny                 |
| <i>dest_ip_prefix</i> | (Optional) Destination IP prefix     |
| <i>dest_ip_addr</i>   | (Optional) Destination IP address    |
| <i>dest_ip_mask</i>   | (Optional) Destination IP mask       |
| <i>dest_mac_addr</i>  | (Optional) Destination MAC address   |
| <i>dest_mac_mask</i>  | (Optional) Destination MAC mask      |
| <i>dest_mac_any</i>   | (Optional) DESTMACAny                |
| <i>src_port_op</i>    | (Optional) Source Port operator      |
| <i>dest_port_op</i>   | (Optional) Destination Port operator |
| <i>src_port1_str</i>  | (Optional) Source port name          |
| <i>src_port1_num</i>  | (Optional) Source port number        |
| <i>src_port2_str</i>  | (Optional) Source port name          |
| <i>src_port2_num</i>  | (Optional) Source port number        |
| <i>dest_port1_str</i> | (Optional) Destination port name     |
| <i>dest_port1_num</i> | (Optional) Destination port number   |
| <i>dest_port2_str</i> | (Optional) Destination port name     |
| <i>dest_port2_num</i> | (Optional) Destination port number   |
| <i>icmp_type</i>      | (Optional) ICMP type                 |
| <i>icmp_code</i>      | (Optional) ICMP code                 |
| <i>icmp_str</i>       | (Optional) ICMP message              |



|                                    |  |
|------------------------------------|--|
| <i>icmpv6_type</i>                 | (Optional) ICMP type                             |
| <i>icmpv6_code</i>                 | (Optional) ICMP code                             |
| <i>icmpv6_str</i>                  | (Optional) ICMP message                          |
| <i>src_addrgrp</i>                 | (Optional) Source address group                  |
| <i>dest_addrgrp</i>                | (Optional) Destination address group             |
| <i>src_portgrp</i>                 | (Optional) Source port group                     |
| <i>dest_portgrp</i>                | (Optional) Destination port group                |
| <i>eth_proto</i>                   | (Optional) MAC protocol number                   |
| <i>newline</i>                     | (Optional) newline between access-list and cmaps |
| TABLE_classmap                     | (Optional) Class Map                             |
| <i>opt_any_or_all</i>              | (Optional) Enter match-any or match-all          |
| <i>cmap_name</i>                   | (Optional) Name of the class-map                 |
| access_grp                         | (Optional) Access Group                          |
| <i>acc_grp_name</i>                | (Optional)                                       |
| redirect                           | (Optional)                                       |
| <i>opt_match_redirect</i>          | (Optional) Match criteria for redirected packets |
| exception                          | (Optional)                                       |
| <i>opt_match_excpt</i>             | (Optional) Match criteria for exception packets  |
| protocol                           | (Optional)                                       |
| <i>opt_match_protocol</i>          | (Optional) Match criteria for protocol packets   |
| TABLE_policymap                    | (Optional) Policy Map table                      |
| <i>class-name</i>                  | (Optional) Name if the policy member             |
| <i>pmap_name</i>                   | (Optional) Name of the Policy-map                |
| <i>set_vld_flg</i>                 | (Optional) Set valid flag                        |
| <i>cos-val</i>                     | (Optional) Set cos val                           |
| <i>opt_kbps_mbps_gbps_pps_cir</i>  | (Optional) Units                                 |
| percent                            | (Optional)                                       |
| <i>opt_kbytes_mbytes_gbytes_bc</i> | (Optional) Units                                 |
| <i>opt_drop_transmit_conform</i>   | (Optional) Set the action                        |

|                                    |                                    |
|------------------------------------|------------------------------------|
| <i>opt_drop_transmit_violate</i>   | (Optional) Set the action          |
| <i>opt_kbps_mbps_gbps_pps_pir</i>  | (Optional) Units                   |
| percent1                           | (Optional)                         |
| <i>opt_kbytes_mbytes_gbytes_be</i> | (Optional) Units                   |
| <i>opt_drop_transmit_conform1</i>  | (Optional) Set the action          |
| set-cos-transmit                   | (Optional)                         |
| <i>set-cos-val</i>                 | (Optional) Conform action cos val  |
| set-dscp-transmit                  | (Optional)                         |
| <i>set-dscp-val</i>                | (Optional) Conform action dscp val |
| set-prec-transmit                  | (Optional)                         |
| <i>set-prec-val</i>                | (Optional) Conform action prec val |
| <i>policer_show_flags</i>          | (Optional) Policer show flags      |
| <i>opt_drop_transmit_exceed</i>    | (Optional) Set the action          |
| set                                | (Optional)                         |
| dscp1                              | (Optional)                         |
| dscp2                              | (Optional)                         |
| table                              | (Optional)                         |
| cir-markdown-map                   | (Optional)                         |
| <i>opt_drop_transmit_violate1</i>  | (Optional) Set the action          |
| set1                               | (Optional)                         |
| dscp3                              | (Optional)                         |
| dscp4                              | (Optional)                         |
| table1                             | (Optional)                         |
| pir-markdown-map                   | (Optional)                         |
| cos                                | (Optional)                         |
| inner                              | (Optional)                         |
| dscp                               | (Optional)                         |
| tunnel                             | (Optional)                         |
| <i>dscp-val</i>                    | (Optional) Set dscp val            |

|                 |                         |
|-----------------|-------------------------|
| precedence      | (Optional)              |
| tunnell         | (Optional)              |
| <i>prec-val</i> | (Optional) Set prec val |

**Command Mode**

- /exec

## show copp status

```
show copp status [ __readonly__ { last_config_operation <last_cfg_oper> } { last_config_operation_time
<last_cfg_oper_time> } { last_config_operation_status <last_cfg_oper_status> } [
last_config_operation_error_time <last_cfg_oper_error_time> ] [ last_config_operation_error
<last_cfg_oper_error> ] { service_policy <srv_policy> } ]
```

### Syntax Description

|                                  |   |
|----------------------------------|---|
| show                             | Show running system information                       |
| copp                             | Control-Plane Policing                                |
| status                           | Show the internal status of CoPP                      |
| __readonly__                     | (Optional)  |
| last_config_operation            | (Optional) last config operation                      |
| <i>last_cfg_oper</i>             | (Optional) last config operation                      |
| last_config_operation_time       | (Optional) timestamp of last config operation         |
| <i>last_cfg_oper_time</i>        | (Optional) timestamp of last config operation         |
| last_config_operation_status     | (Optional) status of last config operation            |
| <i>last_cfg_oper_status</i>      | (Optional) status of last config operation            |
| last_config_operation_error_time | (Optional) timestamp of last config operation's error |
| <i>last_cfg_oper_error_time</i>  | (Optional) timestamp of last config operation's error |
| last_config_operation_error      | (Optional) last config operation's error              |
| <i>last_cfg_oper_error</i>       | (Optional) last config operation's error              |
| service_policy                   | (Optional) policy-map attached to control-plane       |
| <i>srv_policy</i>                | (Optional) policy-map attached to control-plane       |

### Command Mode

- /exec

# show copyright

show copyright [ *\_\_readonly\_\_* { *<content>* } ]

## Syntax Description

|                     |                                  |
|---------------------|----------------------------------|
| show                | Show running system information  |
| copyright           | Copyright information            |
| <i>__readonly__</i> | (Optional)                       |
| <i>content</i>      | (Optional) Copyright information |

## Command Mode

- /exec

# show cores

```
show cores [ vdc-all | { vdc [ <e-vdc2> | <vdc-id> ] } ] [ __readonly__ { [ TABLE_cores <vdc_id>
<module_id> <instance> <process_name> <pid> <sys_time> ] } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| cores               | show all core dumps for the current vdc    |
| vdc-all             | (Optional) show core dumps from all vdes   |
| vdc                 | (Optional) show all core dumps for the vdc |
| __readonly__        | (Optional)                                 |
| TABLE_cores         | (Optional)                                 |
| <i>vdc_id</i>       | (Optional) vdc id                          |
| <i>module_id</i>    | (Optional) module id                       |
| <i>instance</i>     | (Optional) instance number                 |
| <i>process_name</i> | (Optional) name of the process             |
| <i>pid</i>          | (Optional) process id                      |
| <i>sys_time</i>     | (Optional) core generate time              |
| <i>e-vdc2</i>       | (Optional) Enter VDC <vdc-id>              |
| <i>vdc-id</i>       | (Optional) vdc number                      |

## Command Mode

- /exec

## show crypto ca certificates

```
show crypto ca certificates [ __readonly__ [ { TABLE_ca_certificates <trustpoint> [ <certificate> ] [ {
TABLE_ca_cert_chains <index> <ca_certificate> } ] } ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information              |
| crypto                       | show crypto configuration                    |
| ca                           | show trustpoint configuration                |
| certificates                 | show various certificates                    |
| <i>__readonly__</i>          | (Optional)                                   |
| <i>TABLE_ca_certificates</i> | (Optional) Table of CA certificates          |
| <i>trustpoint</i>            | (Optional) Trustpoint name                   |
| <i>certificate</i>           | (Optional) Certificate                       |
| <i>TABLE_ca_cert_chains</i>  | (Optional) Table of CA certificates in chain |
| <i>index</i>                 | (Optional) CA Certificate Index              |
| <i>ca_certificate</i>        | (Optional) CA certificate                    |

### Command Mode

- /exec

## show crypto ca certificates

```
show crypto ca certificates <s0> [ __readonly__ { Trustpoint <trustpoint> } [ { Certificate <certificate> } ]
[ { TABLE_ca_cert_chains <index> <ca_certificate> } ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information              |
| crypto                | show crypto configuration                    |
| ca                    | show trustpoint configuration                |
| certificates          | show various certificates                    |
| <i>s0</i>             | trustpoint label                             |
| <i>__readonly__</i>   | (Optional)                                   |
| Trustpoint            | (Optional) Trustpoint                        |
| <i>trustpoint</i>     | (Optional) Trustpoint                        |
| Certificate           | (Optional) Certificate                       |
| <i>certificate</i>    | (Optional) Certificate                       |
| TABLE_ca_cert_chains  | (Optional) Table of CA certificates in chain |
| <i>index</i>          | (Optional) CA Certificate Index              |
| <i>ca_certificate</i> | (Optional) CA certificate                    |

### Command Mode

- /exec



# show crypto ca certstore

```
show crypto ca certstore [ __readonly__ { certstore_lookup <lookup_type> } ]
```

## Syntax Description

|                    |                                     |
|--------------------|-------------------------------------|
| show               | Show running system information     |
| crypto             | Show crypto configuration           |
| ca                 | show crypto ca configuration        |
| certstore          | Show the configured certstore       |
| __readonly__       | (Optional)                          |
| certstore_lookup   | (Optional) Certificate store lookup |
| <i>lookup_type</i> | (Optional) Lookup type              |

## Command Mode

- /exec

# show crypto ca crl

```
show crypto ca crl <s0> [ __readonly__ { Trustpoint <trustpoint> } [ { CRL <crl> } ] ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information        |
| crypto              | show crypto configuration              |
| ca                  | show trustpoint configuration          |
| crl                 | show CRL                               |
| <i>s0</i>           | trustpoint label                       |
| <i>__readonly__</i> | (Optional)                             |
| Trustpoint          | (Optional) Trustpoint                  |
| <i>trustpoint</i>   | (Optional) Trustpoint                  |
| CRL                 | (Optional) Certificate Revocation List |
| <i>crl</i>          | (Optional) Certificate Revocation List |

## Command Mode

- /exec

## show crypto ca remote-certstore

```
show crypto ca remote-certstore [ __readonly__ { remote_cert_store <rem_cert_store> } [ { crl_timer <crltimer>
} { ldap_server_group <ldap_server_grp> } ] ]
```

### Syntax Description

|                        |                                     |
|------------------------|-------------------------------------|
| show                   | Show running system information     |
| crypto                 | Show crypto configuration           |
| ca                     | show crypto ca configuration        |
| remote-certstore       | Show remote certstore configuration |
| __readonly__           | (Optional)                          |
| remote_cert_store      | (Optional) Remote cert store        |
| <i>rem_cert_store</i>  | (Optional) Remote certificate store |
| crl_timer              | (Optional) CRL timer                |
| <i>crltimer</i>        | (Optional) CRL timer                |
| ldap_server_group      | (Optional) LDAP Server Group        |
| <i>ldap_server_grp</i> | (Optional) LDAP Server Group        |

### Command Mode

- /exec

## show crypto ca trustpoints

```
show crypto ca trustpoints [ __readonly__ [ { TABLE_ca_truspoints <trustpoint> <key-pair> [ {
TABLE_revocation_methods <revocation-method> } ] [ <ocsp-url> ] } ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information        |
| crypto                   | show crypto configuration              |
| ca                       | show trustpoint configuration          |
| trustpoints              | show trustpoint configuration          |
| __readonly__             | (Optional)                             |
| <i>trustpoint</i>        | (Optional) Trustpoint                  |
| <i>key-pair</i>          | (Optional) Key pair                    |
| TABLE_revocation_methods | (Optional) Table of revocation methods |
| <i>revocation-method</i> | (Optional) Revocation mehtod           |
| <i>ocsp-url</i>          | (Optional) OCSP URL                    |
| TABLE_ca_truspoints      | (Optional) Table of CA trustpoints     |

### Command Mode

- /exec

# show crypto ca trustpool

```
show crypto ca trustpool [ __readonly__ [ { TABLE_ca_trustpool <serial-number> <subject> <issued-by>
<validity-start> <validity-end> } ] ]
```

## Syntax Description

|                       |                                  |
|-----------------------|----------------------------------|
| show                  | Show running system information  |
| crypto                | show crypto information          |
| ca                    | show trustpool data              |
| trustpool             | trustpool contents               |
| __readonly__          | (Optional)                       |
| TABLE_ca_trustpool    | (Optional) Table of CA trustpool |
| <i>serial-number</i>  | (Optional) Serial number         |
| <i>subject</i>        | (Optional) subject               |
| <i>issued-by</i>      | (Optional) Issued by             |
| <i>validity-start</i> | (Optional) validity start date   |
| <i>validity-end</i>   | (Optional) validity end date     |

## Command Mode

- /exec

## show crypto ca trustpool last download status

```
show crypto ca trustpool last download status [ __readonly__ [ http_url <http_url> ] [ download_time
<download_time> ] [ trustpool_download_status <status> ] [ download_failure <reason> ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                |
| crypto                    | show crypto information                        |
| ca                        | show trustpool data                            |
| trustpool                 | trustpool data                                 |
| last                      | last trustpool download status                 |
| download                  | download of trustpool                          |
| status                    | download status                                |
| <i>__readonly__</i>       | (Optional)                                     |
| http_url                  | (Optional) http url configured                 |
| <i>http_url</i>           | (Optional) HTTP url                            |
| download_time             | (Optional) Download time                       |
| <i>download_time</i>      | (Optional) Download time                       |
| trustpool_download_status | (Optional) Status of trustpool policy download |
| <i>status</i>             | (Optional) Download status                     |
| download_failure          | (Optional) Download failure                    |
| <i>reason</i>             | (Optional) Download failure reason             |

### Command Mode

- /exec

# show crypto ca trustpool policy

```
show crypto ca trustpool policy [ __readonly__ [ http_url <http_url> ] [ config_vrf [ <config_vrf> ] [ <src_intf>
] ] [ proxy_server [ <proxy_server> ] [ <proxy_server_port> ] ] ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information           |
| crypto                   | show crypto information                   |
| ca                       | show Certificate authority related config |
| trustpool                | show trustpool policy                     |
| policy                   | trustpool configuration                   |
| <i>__readonly__</i>      | (Optional)                                |
| http_url                 | (Optional) http url configured            |
| <i>http_url</i>          | (Optional) HTTP url                       |
| config_vrf               | (Optional) Configured vrf                 |
| <i>config_vrf</i>        | (Optional) vrf configured                 |
| <i>src_intf</i>          | (Optional) source interface for vrf       |
| proxy_server             | (Optional) Configured proxy server        |
| <i>proxy_server</i>      | (Optional) proxy server                   |
| <i>proxy_server_port</i> | (Optional) proxy server port              |

## Command Mode

- /exec

# show crypto certificatemap

```
show crypto certificatemap [ __readonly__ [ { TABLE_certmap <map_name> <subject_name>
<alternate_email> <alternate_upn> } ] ]
```

## Syntax Description

|                        |                                     |
|------------------------|-------------------------------------|
| show                   | Show running system information     |
| crypto                 | show crypto configuration           |
| certificatemap         | show certificatemap filters         |
| <i>__readonly__</i>    | (Optional)                          |
| <i>TABLE_certmap</i>   | (Optional) Table of Certificate Map |
| <i>map_name</i>        | (Optional) Map name                 |
| <i>subject_name</i>    | (Optional) Subject name             |
| <i>alternate_email</i> | (Optional) Alternate Email          |
| <i>alternate_upn</i>   | (Optional) Alternate UPN            |

## Command Mode

- /exec



## show crypto key mypubkey rsa

```
show crypto key mypubkey rsa [ __readonly__ [ { TABLE_rsa_keys <key_label> <key_size> <exportable>
<err_string> } ] ]
```

### Syntax Description

|                       |                                       |
|-----------------------|---------------------------------------|
| show                  | Show running system information       |
| crypto                | show crypto configuration             |
| key                   | show key configuration                |
| mypubkey              | show my public keys configuration     |
| rsa                   | show my rsa public keys configuration |
| <i>__readonly__</i>   | (Optional)                            |
| <i>TABLE_rsa_keys</i> | (Optional) Table of RSA keys          |
| <i>key_label</i>      | (Optional) Key Label                  |
| <i>key_size</i>       | (Optional) Key size                   |
| <i>exportable</i>     | (Optional) Exportable                 |
| <i>err_string</i>     | (Optional) Error String               |

### Command Mode

- /exec

# show crypto ssh-auth-map

```
show crypto ssh-auth-map [ __readonly__ [ { TABLE_ssh_auth_map <issuer_name> <map1> [ <map2> ] } ] ]
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                     |
| crypto             | show crypto configuration                           |
| ssh-auth-map       | show mapping filters applied for ssh authentication |
| __readonly__       | (Optional)  |
| TABLE_ssh_auth_map | (Optional) Table of SSH Auth MAP                    |
| <i>issuer_name</i> | (Optional) Issuer Name                              |
| <i>map1</i>        | (Optional) Map 1                                    |
| <i>map2</i>        | (Optional) Map 2                                    |

## Command Mode

- /exec

# show cts

```
show cts [ __readonly__ <device-id> <cache_en> <num-dot1x> <num-man> <sgt> ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| <code>cts</code>          | Show CTS global configuration                  |
| <code>__readonly__</code> | (Optional)                                     |
| <code>device-id</code>    | (Optional) name                                |
| <code>cache_en</code>     | (Optional) enable/disable                      |
| <code>num-dot1x</code>    | (Optional) number of interfaces in dot1x mode  |
| <code>num-man</code>      | (Optional) number of interfaces in manual mode |
| <code>sgt</code>          | (Optional)                                     |

## Command Mode

- /exec

# show current

show current

## Syntax Description

|         |  |
|---------|--|
| show    | Display region configurations            |
| current | Display mst configuration currently used |

## Command Mode

- /exec/configure/spanning-tree/mst/configuration



## D Show Commands

---

- [show dampening interface](#), on page 401
- [show device-alias database](#), on page 402
- [show device-alias merge status](#), on page 403
- [show device-alias name](#), on page 404
- [show device-alias pending-diff](#), on page 405
- [show device-alias pending](#), on page 406
- [show device-alias pwnn](#), on page 407
- [show device-alias session rejected](#), on page 408
- [show device-alias session status](#), on page 409
- [show device-alias statistics](#), on page 410
- [show device-alias status](#), on page 411
- [show diagnostic bootup level](#), on page 412
- [show diagnostic content module](#), on page 413
- [show diagnostic description module test all](#), on page 414
- [show diagnostic events](#), on page 415
- [show diagnostic ondemand setting](#), on page 416
- [show diagnostic result module](#), on page 417
- [show diagnostic result module all](#), on page 419
- [show diagnostic simulation module](#), on page 421
- [show diagnostic status module](#), on page 422
- [show diff rollback-patch](#), on page 423
- [show dot1q-tunnel](#), on page 424
- [show dot1q-tunnel interface](#), on page 425
- [show dot1x](#), on page 426
- [show dot1x all](#), on page 427
- [show dot1x all details](#), on page 429
- [show dot1x all statistics](#), on page 432
- [show dot1x all summary](#), on page 434
- [show dot1x interface](#), on page 435
- [show dot1x interface client statistics](#), on page 440
- [show dot1x interface client statistics address](#), on page 442
- [show dpvm database](#), on page 443
- [show dpvm fip](#), on page 444

- [show dpvm merge statistics, on page 445](#)
- [show dpvm merge status, on page 446](#)
- [show dpvm pending-diff, on page 447](#)
- [show dpvm pending, on page 448](#)
- [show dpvm ports, on page 449](#)
- [show dpvm session status, on page 450](#)
- [show dpvm status, on page 451](#)

# show dampening interface

```
show dampening interface [ __readonly__ { <DampenedInterfaceCount> <SuppressedInterfaceCount> } ]
```

## Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information                          |
| dampening                       | Display dampening information                            |
| interface                       | Display interface dampening general information          |
| __readonly__                    | (Optional)   |
| <i>DampenedInterfaceCount</i>   | (Optional) Count of interfaces configured with dampening |
| <i>SuppressedInterfaceCount</i> | (Optional) Count of interfaces in suppressed state       |

## Command Mode

- /exec

# show device-alias database

show device-alias database

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| database     | Show Device Alias database                               |

## Command Mode

- /exec



# show device-alias merge status

show device-alias merge status

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| merge        | Show merge information                                   |
| status       | Show device-alias merge status                           |

## Command Mode

- /exec

# show device-alias name

show device-alias name <s0> [ pending ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                               |
| device-alias | Show information about Device Alias Distribution Service      |
| name         | Show Device Alias information given a name                    |
| <i>s0</i>    | Enter Device Alias name                                       |
| pending      | (Optional) Show pending Device Alias information given a name |

## Command Mode

- /exec

# show device-alias pending-diff

show device-alias pending-diff

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| pending-diff | Show pending diff for Device Alias database              |

## Command Mode

- /exec

# show device-alias pending

show device-alias pending

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| pending      | Show pending Device Alias database                       |

## Command Mode

- /exec

# show device-alias pwwn

show device-alias pwwn <wwn0> [ pending ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                                   |
| device-alias | Show information about Device Alias Distribution Service          |
| pwwn         | Show Device Alias information given a port WWN                    |
| <i>wwn0</i>  | Enter port WWN  |
| pending      | (Optional) Show pending Device Alias information given a port WWN |

## Command Mode

- /exec

# show device-alias session rejected

show device-alias session rejected

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| session      | Show session information                                 |
| rejected     | Show rejected command list                               |

## Command Mode

- /exec

# show device-alias session status

show device-alias session status

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| session      | Show session information                                 |
| status       | Show device-alias session status                         |

## Command Mode

- /exec

# show device-alias statistics

show device-alias statistics

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| statistics   | Show device-alias statistics                             |

## Command Mode

- /exec



# show device-alias status

show device-alias status

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| device-alias | Show information about Device Alias Distribution Service |
| status       | Show device-alias status                                 |

## Command Mode

- /exec

# show diagnostic bootup level

show diagnostic bootup level [ \_\_readonly\_\_ <bootup\_level> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information          |
| diagnostic          | Diagnostic commands                      |
| bootup              | Show diagnostic bootup information       |
| level               | Show diagnostic bootup level information |
| __readonly__        | (Optional)                               |
| <i>bootup_level</i> | (Optional) Bootup level                  |

## Command Mode

- /exec

# show diagnostic content module

```
show diagnostic content module { all | <module> } [ __readonly__ <attr_descr> { TABLE_Module
<module_id> <module_type> { TABLE_test <test_id> <testname> <test_attr> <test_interval> } } ]
```

## Syntax Description

|                      |                                    |
|----------------------|------------------------------------|
| show                 | Show running system information    |
| diagnostic           | Diagnostic commands                |
| content              | Show diagnostic test content       |
| module               | Module Keyword                     |
| all                  | Select all module ID               |
| <i>module</i>        | Module number                      |
| <i>__readonly__</i>  | (Optional)                         |
| <i>attr_descr</i>    | (Optional) Attribute description   |
| TABLE_Module         | (Optional) All modules table       |
| <i>module_id</i>     | (Optional) Module Number           |
| <i>module_type</i>   | (Optional) module type description |
| TABLE_test           | (Optional) All tests table         |
| <i>test_id</i>       | (Optional) Test id                 |
| <i>testname</i>      | (Optional) Test name               |
| <i>test_attr</i>     | (Optional) Test Attribute          |
| <i>test_interval</i> | (Optional) HM test interval        |

## Command Mode

- /exec

# show diagnostic description module test all

```
show diagnostic description module <module> test { all | <name> | <test-id> } [ __readonly__ { TABLE_desc
<testname> <testdesc> } ]
```

## Syntax Description

|                 |                                      |
|-----------------|--------------------------------------|
| show            | Show running system information      |
| diagnostic      | Diagnostic commands                  |
| description     | Show diagnostic test desc            |
| module          | Module keyword                       |
| <i>module</i>   | Module Number                        |
| test            | Diagnostic test selection            |
| all             | Select all test ID                   |
| <i>name</i>     | Test name                            |
| <i>test-id</i>  |                                      |
| __readonly__    | (Optional)                           |
| TABLE_desc      | (Optional) Table of test description |
| <i>testname</i> | (Optional) Test name                 |
| <i>testdesc</i> | (Optional) Description of the test   |

## Command Mode

- /exec

# show diagnostic events

```
show diagnostic events [ error | info ] [ __readonly__ { TABLE_events <event_text> } ]
```

## Syntax Description

|                   |                                   |
|-------------------|-----------------------------------|
| show              | Show running system information   |
| diagnostic        | Diagnostic commands               |
| events            | Diagnostic events                 |
| error             | (Optional) Error event-type       |
| info              | (Optional) Information event-type |
| __readonly__      | (Optional)                        |
| TABLE_events      | (Optional) list of events logged  |
| <i>event_text</i> | (Optional) Text of one event      |

## Command Mode

- /exec

# show diagnostic ondemand setting

show diagnostic ondemand setting [ *\_\_readonly\_\_* <test\_iteration\_count> <action\_on\_failure> ]

## Syntax Description

|                             |                                       |
|-----------------------------|---------------------------------------|
| show                        | Show running system information       |
| diagnostic                  | Diagnostic commands                   |
| ondemand                    | Show diagnostic on demand information |
| setting                     | Show diagnostic on demand settings    |
| <i>__readonly__</i>         | (Optional)                            |
| <i>test_iteration_count</i> | (Optional) Iteration Count            |
| <i>action_on_failure</i>    | (Optional) Action on failure          |

## Command Mode

- /exec



|                               |  |
|-------------------------------|--|
| <i>packet_loss</i>            | (Optional) Packet lost                       |
| TABLE_Test                    | (Optional) Table of tests in module          |
| <i>test_id</i>                | (Optional) Test id of tests                  |
| <i>testname</i>               | (Optional) Test name                         |
| <i>testresult</i>             | (Optional) Test Results                      |
| <i>passed_ports</i>           | (Optional) List passed ports                 |
| <i>failed_ports</i>           | (Optional) List failed ports                 |
| <i>incomplete_ports</i>       | (Optional) List of Incompletely tested ports |
| <i>untested_ports</i>         | (Optional) List of untested ports            |
| <i>aborted_ports</i>          | (Optional) List of aborted ports             |
| <i>err_disabled_ports</i>     | (Optional) List error disabled ports         |
| <i>err_code</i>               | (Optional) Error code                        |
| <i>total_run_count</i>        | (Optional) Total run count                   |
| <i>last_execution_time</i>    | (Optional) Last execution time               |
| <i>first_failure_time</i>     | (Optional) First test failure time           |
| <i>last_failure_time</i>      | (Optional) Last test failure time            |
| <i>last_pass_time</i>         | (Optional) Last test pass time               |
| <i>total_fail_count</i>       | (Optional) Total fail count                  |
| <i>consecutive_fail_count</i> | (Optional) Consecutive failure count         |
| <i>last_fail_reason</i>       | (Optional) Last failure reason               |
| <i>next_execution_time</i>    | (Optional) Next test execution time          |

### Command Mode

- /exec



# show diagnostic result module all

```
show diagnostic result module all [ detail ] [ __readonly__ { TABLE_Module <module_id> <curr_diag_level>
<module_name> [ <bootup_diag_level> ] { TABLE_Test <test_id> <testname> [ <testresult> ] [ {
<passed_ports> <failed_ports> <incomplete_ports> <untested_ports> <aborted_ports> <err_disabled_ports>
} ] [ { <err_code> <total_run_count> <last_execution_time> <first_failure_time> <last_failure_time>
<last_pass_time> <total_fail_count> <consecutive_fail_count> <last_fail_reason> <next_execution_time>
} ] } ] }
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information              |
| diagnostic                | Diagnostic commands                          |
| result                    | Show diagnostic test result                  |
| module                    | Module keyword                               |
| all                       | Select all test ID                           |
| detail                    | (Optional) Detailed result                   |
| __readonly__              | (Optional)                                   |
| TABLE_Module              | (Optional) Table of modules                  |
| <i>module_id</i>          | (Optional) Module ID                         |
| <i>curr_diag_level</i>    | (Optional) Current diag level                |
| <i>module_name</i>        | (Optional) Module name                       |
| <i>bootup_diag_level</i>  | (Optional) Diagnostic level at bootup        |
| TABLE_Test                | (Optional) Table of tests in module          |
| <i>test_id</i>            | (Optional) Test id of tests                  |
| <i>testname</i>           | (Optional) Test name                         |
| <i>testresult</i>         | (Optional) Test Results                      |
| <i>passed_ports</i>       | (Optional) List passed ports                 |
| <i>failed_ports</i>       | (Optional) List failed ports                 |
| <i>incomplete_ports</i>   | (Optional) List of Incompletely tested ports |
| <i>untested_ports</i>     | (Optional) List of untested ports            |
| <i>aborted_ports</i>      | (Optional) List of aborted ports             |
| <i>err_disabled_ports</i> | (Optional) List error disabled ports         |

|                               |                                      |
|-------------------------------|--------------------------------------|
| <i>err_code</i>               | (Optional) Error code                |
| <i>total_run_count</i>        | (Optional) Total run count           |
| <i>last_execution_time</i>    | (Optional) Last execution time       |
| <i>first_failure_time</i>     | (Optional) First test failure time   |
| <i>last_failure_time</i>      | (Optional) Last test failure time    |
| <i>last_pass_time</i>         | (Optional) Last test pass time       |
| <i>total_fail_count</i>       | (Optional) Total fail count          |
| <i>consecutive_fail_count</i> | (Optional) Consecutive failure count |
| <i>last_fail_reason</i>       | (Optional) Last failure reason       |
| <i>next_execution_time</i>    | (Optional) Next test execution time  |

**Command Mode**

- /exec

# show diagnostic simulation module

```
show diagnostic simulation module <module> [ __readonly__ <module_id> <module_name> [ { TABLE_detail
<serial_no> <testid> [ <portid> ] <mode> } ] ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information        |
| diagnostic          | Diagnostic commands                    |
| simulation          | Simulating Diagnostic result           |
| module              | Module keyword                         |
| <i>module</i>       | Module Number                          |
| <i>__readonly__</i> | (Optional)                             |
| <i>module_id</i>    | (Optional) Module ID                   |
| <i>module_name</i>  | (Optional) Module Name                 |
| TABLE_detail        | (Optional) Table of simulation details |
| <i>serial_no</i>    | (Optional) serial no                   |
| <i>testid</i>       | (Optional) Test id                     |
| <i>portid</i>       | (Optional) Port id                     |
| <i>mode</i>         | (Optional) Simulation mode             |

## Command Mode

- /exec

# show diagnostic status module

```
show diagnostic status module <module> [ __readonly__ <test_runby_mapping> <module_id> <module_name>
{ TABLE_current <cur_test_name> <cur_run_by> } { TABLE_enqueued <enq_test_name> <enq_run_by> }
]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information            |
| diagnostic                | Diagnostic commands                        |
| status                    | Show test status(running/enqueued)         |
| module                    | Module keyword                             |
| <i>module</i>             | Module number                              |
| <i>__readonly__</i>       | (Optional)                                 |
| <i>test_runby_mapping</i> | (Optional) Test type expansion             |
| <i>module_id</i>          | (Optional) Module Id                       |
| <i>module_name</i>        | (Optional) Module name                     |
| TABLE_current             | (Optional) Table of currently running test |
| <i>cur_test_name</i>      | (Optional) Currently running test          |
| <i>cur_run_by</i>         | (Optional) Test Run By                     |
| TABLE_enqueued            | (Optional) Table of enqueued tests         |
| <i>enq_test_name</i>      | (Optional) Enqueued test name              |
| <i>enq_run_by</i>         | (Optional) Test enqueued by                |

## Command Mode

- /exec

# show diff rollback-patch

```
show diff rollback-patch { src-checkpoint <chkpoint_name> | src-running-cfg | src-startup-cfg | src-file
<srcfile_uri> } { dst-checkpoint <chkpoint_name> | dst-running-cfg | dst-startup-cfg | dst-file <dstfile_uri>
} [ __readonly__ [ <patch_entry> ] + ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                                |
| diff                 | Show diff between configuration files or checkpoints           |
| rollback-patch       | Show rollback patch between configuration files or checkpoints |
| src-checkpoint       | Use checkpoint as source configuration                         |
| <i>chkpoint_name</i> | Checkpoint name  |
| src-running-cfg      | Use running configuration as source                            |
| src-startup-cfg      | Use startup configuration as source                            |
| src-file             | Src Checkpoint file  |
| <i>srcfile_uri</i>   | Src Checkpoint file path                                       |
| dst-checkpoint       | Use checkpoint as destination configuration                    |
| <i>chkpoint_name</i> | Checkpoint name  |
| dst-running-cfg      | Use running configuration as destination                       |
| dst-startup-cfg      | Use startup configuration as destination                       |
| dst-file             | Dst Checkpoint file  |
| <i>dstfile_uri</i>   | Src Checkpoint file path                                       |
| <i>__readonly__</i>  | (Optional) Read only   |
| <i>patch_entry</i>   | (Optional) rollback patch entry                                |

## Command Mode

- /exec

# show dot1q-tunnel

show dot1q-tunnel [ \_\_readonly\_\_ TABLE\_interface <interface> ]

## Syntax Description

|                  |                                   |
|------------------|-----------------------------------|
| show             | Show running system information   |
| dot1q-tunnel     | Show if port mode is dot1q-tunnel |
| __readonly__     | (Optional) Read Only              |
| <i>interface</i> | (Optional) Interface index        |
| TABLE_interface  | (Optional) show interface         |

## Command Mode

- /exec

# show dot1q-tunnel interface

```
show dot1q-tunnel interface <ifid_eth_dot1q_tunnel> [ __readonly__ TABLE_interface <interface> ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                       |
| dot1q-tunnel                 | Show if port mode is dot1q-tunnel                     |
| interface                    | Show interface status and information                 |
| <i>ifid_eth_dot1q_tunnel</i> | Enter interface type and number in module/slot format |
| <i>__readonly__</i>          | (Optional) Read Only                                  |
| <i>interface</i>             | (Optional) Interface index                            |
| <i>TABLE_interface</i>       | (Optional) show interface                             |

## Command Mode

- /exec

# show dot1x

show dot1x [ *\_\_readonly\_\_* <sys\_auth\_ctrl> <proto\_ver> <mac\_move> <server\_dead\_action\_authz> ]

## Syntax Description

|                                 |  |
|---------------------------------|--|
| dot1x                           | dot1x configuration commands                       |
| <i>__readonly__</i>             | (Optional)   |
| <i>sys_auth_ctrl</i>            | (Optional) show system auth control                |
| <i>proto_ver</i>                | (Optional) show protocol version                   |
| <i>mac_move</i>                 | (Optional) show mac move                           |
| <i>server_dead_action_authz</i> | (Optional) show server_dead_action_authz flag info |

## Command Mode

- /exec



## show dot1x all

```
show dot1x all [ __readonly__ <sys_auth_ctrl> <proto_ver> <mac_move> <server_dead_action_authz>
TABLE_all <if_index> TABLE_allpae <pae_type> [ <port_control> ] [ <host_mode> ] [ <quiet_period> ] [
<inactivity_period> ] [ <tx_period> ] [ <max_req> ] [ <reauth> ] [ <rate_limit_period> ] [ <supp_timeout>
] [ <server_timeout> ] [ <reauth_server> ] [ <reauth_period> ] [ <reauth_max> ] [ <mac_auth_bypass> ] [
<start_period> ] [ <auth_period> ] [ <held_period> ] [ <max_start> ] ]
```

### Syntax Description

| dot1x                           | dot1x configuration commands                       |
|---------------------------------|--|
| all                             | Show information for all interfaces                |
| <i>__readonly__</i>             | (Optional)   |
| TABLE_all                       | (Optional)   |
| TABLE_allpae                    | (Optional)   |
| <i>if_index</i>                 | (Optional) Interface Index                         |
| <i>sys_auth_ctrl</i>            | (Optional) Show System Auth Control                |
| <i>proto_ver</i>                | (Optional) Show Protocol Version                   |
| <i>mac_move</i>                 | (Optional) Show Mac Move                           |
| <i>server_dead_action_authz</i> | (Optional) show server_dead_action_authz flag info |
| <i>pae_type</i>                 | (Optional) Show PAE Type                           |
| <i>port_control</i>             | (Optional) Show Port Control                       |
| <i>host_mode</i>                | (Optional) Show Host Mode                          |
| <i>reauth</i>                   | (Optional) Show Reauth Enabled Status              |
| <i>quiet_period</i>             | (Optional) Show Quiet Period                       |
| <i>inactivity_period</i>        | (Optional) Show Inactivity Period                  |
| <i>server_timeout</i>           | (Optional) Show Server Timeout                     |
| <i>supp_timeout</i>             | (Optional) Show Supp Timeout                       |
| <i>reauth_period</i>            | (Optional) Show Reauth Period                      |
| <i>reauth_max</i>               | (Optional) Show Reauth Max                         |
| <i>max_req</i>                  | (Optional) Show Max Req                            |
| <i>tx_period</i>                | (Optional) Show Tx Period                          |
| <i>rate_limit_period</i>        | (Optional) Show Rate Limit Period                  |

|                        |  |
|------------------------|--|
| <i>reauth_server</i>   | (Optional) Show Reauth Server Enabled Status   |
| <i>mac_auth_bypass</i> | (Optional) Show MAC Auth Bypass Enabled Status |
| <i>start_period</i>    | (Optional) Show Supplicant Start Period        |
| <i>auth_period</i>     | (Optional) Show Supplicant Auth Period         |
| <i>held_period</i>     | (Optional) Show Supplicant Held Period         |
| <i>max_start</i>       | (Optional) Show Supplicant Max Start           |

**Command Mode**

- /exec

## show dot1x all details

```
show dot1x all details [ __readonly__ <sys_auth_ctrl> <proto_ver> <mac_move> <server_dead_action_authz>
TABLE_alldetail <if_index> TABLE_allpaedetail <pae_type> [ <port_control> ] [ <host_mode> ] [
<quiet_period> ] [ <inactivity_period> ] [ <tx_period> ] [ <max_req> ] [ <reauth> ] [ <rate_limit_period> ]
[ <supp_timeout> ] [ <server_timeout> ] [ <reauth_server> ] [ <reauth_period> ] [ <reauth_max> ] [
<mac_auth_bypass> ] [ <no_of_clients> ] [ <port_status_no_clients> ] [ { TABLE_if_auth_clients [
<supp_mac_addr> ] [ <auth_domain> ] [ <auth_sm_state> ] [ <auth_bend_sm_state> ] [ <port_status> ] [
<authentication_method> ] [ <authenticated_by> ] [ <reauth_period_client> ] [ <reauth_action> ] [
<time_to_next_reauth> ] [ <url_redirect_acl> ] [ <url_redirect_link> ] [ <aaa_at_in_acl> ] [ <auth_vlan> ] [
<acl_index> ] } ] [ <start_period> ] [ <auth_period> ] [ <held_period> ] [ <max_start> ] [
<no_of_supp_clients> ] [ <auth_mac_addr> ] [ <supp_sm_state> ] [ <supp_bend_sm_state> ] [
<supp_port_status> ] ]
```

### Syntax Description

| dot1x                           | dot1x configuration commands                       |
|---------------------------------|--|
| all                             | Show information for all interfaces                |
| details                         | 802.1x details                                     |
| <i>__readonly__</i>             | (Optional)   |
| TABLE_alldetail                 | (Optional)   |
| TABLE_allpaedetail              | (Optional)   |
| TABLE_if_auth_clients           | (Optional)   |
| <i>if_index</i>                 | (Optional) Interface Index                         |
| <i>sys_auth_ctrl</i>            | (Optional) Show System Auth Control                |
| <i>proto_ver</i>                | (Optional) Show Protocol Version                   |
| <i>mac_move</i>                 | (Optional) Show Mac Move                           |
| <i>server_dead_action_authz</i> | (Optional) show server_dead_action_authz flag info |
| <i>pae_type</i>                 | (Optional) Show PAE Type                           |
| <i>port_control</i>             | (Optional) Show Port Control                       |
| <i>host_mode</i>                | (Optional) Show Host Mode                          |
| <i>reauth</i>                   | (Optional) Show Reauth Enabled Status              |
| <i>quiet_period</i>             | (Optional) Show Quiet Period                       |
| <i>server_timeout</i>           | (Optional) Show Server Timeout                     |
| <i>supp_timeout</i>             | (Optional) Show Supp Timeout                       |

|                               |   |
|-------------------------------|---|
| <i>reauth_period</i>          | (Optional) Show Reauth Period                       |
| <i>reauth_max</i>             | (Optional) Show Reauth Max                          |
| <i>max_req</i>                | (Optional) Show Max Req                             |
| <i>tx_period</i>              | (Optional) Show Tx Period                           |
| <i>rate_limit_period</i>      | (Optional) Show Rate Limit Period                   |
| <i>inactivity_period</i>      | (Optional) Show Inactivity Period                   |
| <i>reauth_server</i>          | (Optional) Show Reauth Server Enabled Status        |
| <i>mac_auth_bypass</i>        | (Optional) Show MAC Auth Bypass Enabled Status      |
| <i>no_of_clients</i>          | (Optional) Show Supplicant Clients                  |
| <i>port_status_no_clients</i> | (Optional) Show Port Status if there are no clients |
| <i>supp_mac_addr</i>          | (Optional) Show Supplicant MAC Address              |
| <i>auth_domain</i>            | (Optional) Show Supplicant Auth Domain              |
| <i>auth_sm_state</i>          | (Optional) Show Authenticator SM State              |
| <i>auth_bend_sm_state</i>     | (Optional) Show Authenticator Backend State         |
| <i>port_status</i>            | (Optional) Show Port Status                         |
| <i>authentication_method</i>  | (Optional) show authentication method               |
| <i>authenticated_by</i>       | (Optional) show authenticated by                    |
| <i>reauth_period_client</i>   | (Optional) Show Reauth Period                       |
| <i>reauth_action</i>          | (Optional) Show Reauthentication Action             |
| <i>time_to_next_reauth</i>    | (Optional) Show Time to Next Reauth                 |
| <i>url_redirect_acl</i>       | (Optional) Show URL Re-Direct ACL                   |
| <i>url_redirect_link</i>      | (Optional) Show URL Re-Direct Link                  |
| <i>aaa_at_in_acl</i>          | (Optional) Show Filter-ID ACL                       |
| <i>auth_vlan</i>              | (Optional) Show Vlan                                |
| <i>dacl_index</i>             | (Optional) Show Dacl Index                          |
| <i>start_period</i>           | (Optional) Show Supplicant Start Period             |
| <i>auth_period</i>            | (Optional) Show Supplicant Auth Period              |
| <i>held_period</i>            | (Optional) Show Supplicant Held Period              |
| <i>max_start</i>              | (Optional) Show Supplicant Max Start                |

|                           |   |
|---------------------------|---|
| <i>no_of_supp_clients</i> | (Optional) Show Supplicant Clients          |
| <i>auth_mac_addr</i>      | (Optional) Show Authenticator MAC Address   |
| <i>supp_sm_state</i>      | (Optional) Show Supplicant SM State         |
| <i>supp_bend_sm_state</i> | (Optional) Show Supplicant Backend SM State |
| <i>supp_port_status</i>   | (Optional) Show Supplicant Port Status      |

**Command Mode**

- /exec

## show dot1x all statistics

```
show dot1x all statistics [ __readonly__ TABLE_allstat <if_index> TABLE_allpaestat <pae_type> [ <rxstart>
] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [ <rxlenerr> ] [ <rxtotal> ] [ <txreq> ] [ <txreqid>
] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemaac> ] [ <rxreq> ] [ <rxsuppinvalid> ] [ <rxsupplennerr> ] [
<rxsupptotal> ] [ <txstart> ] [ <txlogoff> ] [ <txresp> ] [ <txsupptotal> ] [ <rxsuppverson> ] [ <lastrxsrcaac>
] ]
```

### Syntax Description

| dot1x                   | dot1x configuration commands                    |
|-------------------------|---|
| all                     | Show information for all interfaces             |
| statistics              | 802.1x statistics                               |
| __readonly__            | (Optional)                                      |
| TABLE_allstat           | (Optional)                                      |
| TABLE_allpaestat        | (Optional)                                      |
| <i>if_index</i>         | (Optional) Interface Index                      |
| <i>pae_type</i>         | (Optional) Show PAE Type                        |
| <i>rxstart</i>          | (Optional) Show Received EAPOL-Start            |
| <i>rxlogoff</i>         | (Optional) Show Received EAPOL-Logoff           |
| <i>rxresp</i>           | (Optional) Show Received EAP-Response           |
| <i>rxrespid</i>         | (Optional) Show Received EAP-ResponseID         |
| <i>rxinvalid</i>        | (Optional) Show Received Invalid EAPOL Frame    |
| <i>rxlenerr</i>         | (Optional) Show Received EAPOL Bad Length Frame |
| <i>rxtotal</i>          | (Optional) Show Received Total EAPOL Frame      |
| <i>txreq</i>            | (Optional) Show Transmitted EAP-Request         |
| <i>txreqid</i>          | (Optional) Show Transmitted EAP-RequestID       |
| <i>txtotal</i>          | (Optional) Show Transmitted Total EAPOL Frame   |
| <i>rxversion</i>        | (Optional) Show Received EAPOL Version          |
| <i>lastrxsourcemaac</i> | (Optional) Show Last Source MAC                 |
| <i>rxreq</i>            | (Optional) Show Received EAP-Request            |
| <i>rxsuppinvalid</i>    | (Optional) Show received Invalid EAPOL Frame    |
| <i>rxsupplennerr</i>    | (Optional) Show received EAPOL Bad Length Frame |

|                      |   |
|----------------------|---|
| <i>rxsupptotal</i>   | (Optional) Show Received Total EAPOL Frame    |
| <i>txstart</i>       | (Optional) Show transmitted EAPOL-Start       |
| <i>txlogoff</i>      | (Optional) Show transmitted EAPOL-Logoff      |
| <i>txresp</i>        | (Optional) Show transmitted EAP-Response      |
| <i>txsupptotal</i>   | (Optional) Show transmitted Total EAPOL Frame |
| <i>rxsuppversion</i> | (Optional) Show Received EAPOL Version        |
| <i>lastrxsrmac</i>   | (Optional) Show Last Source MAC received      |

**Command Mode**

- /exec

## show dot1x all summary

```
show dot1x all summary [ __readonly__ TABLE_allsummary <if_index> <pae_type> [
<port_status_no_clients> ] [ { TABLE_if_auth_clients [ <auth_mac_addr> ] [ <port_status> ] } ] ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| dot1x                         | dot1x configuration commands                        |
| all                           | Show information for all interfaces                 |
| summary                       | 802.1x summary                                      |
| <i>__readonly__</i>           | (Optional)  |
| <i>TABLE_allsummary</i>       | (Optional)  |
| <i>TABLE_if_auth_clients</i>  | (Optional)  |
| <i>if_index</i>               | (Optional) Interface Index                          |
| <i>pae_type</i>               | (Optional) Show PAE Type                            |
| <i>auth_mac_addr</i>          | (Optional) Show Authenticator MAC Address           |
| <i>port_status_no_clients</i> | (Optional) Show Port Status if there are no clients |
| <i>port_status</i>            | (Optional) Show Port Status                         |

### Command Mode

- /exec



## show dot1x interface

```
{ show dot1x interface <if> [ __readonly__ <if_index> <pae_type> [ <port_control> ] [ <host_mode> ] [
<quiet_period> ] [ <inactivity_period> ] [ <tx_period> ] [ <max_req> ] [ <reauth> ] [ <rate_limit_period> ]
[ <supp_timeout> ] [ <server_timeout> ] [ <reauth_server> ] [ <reauth_period> ] [ <reauth_max> ] [
<mac_auth_bypass> ] [ <start_period> ] [ <auth_period> ] [ <held_period> ] [ <max_start> ] ] | { show
dot1x interface <if> details [ __readonly__ <if_index_detail> <pae_type_detail> [ <port_control_detail> ] [
<host_mode_detail> ] [ <quiet_period_detail> ] [ <inactivity_period_detail> ] [ <tx_period_detail> ] [
<max_req_detail> ] [ <reauth_detail> ] [ <rate_limit_period_detail> ] [ <supp_timeout_detail> ] [
<server_timeout_detail> ] [ <reauth_server_detail> ] [ <reauth_period_detail> ] [ <reauth_max_detail> ] [
<mac_auth_bypass_detail> ] [ <no_of_clients> ] [ <port_status_no_clients_detail> ] [ {
TABLE_if_auth_clients_detail [ <supp_mac_addr_detail> ] [ <auth_domain> ] [ <auth_sm_state> ] [
<auth_bend_sm_state> ] [ <port_status> ] [ <authentication_method> ] [ <authenticated_by> ] [
<reauth_period_client> ] [ <reauth_action> ] [ <time_to_next_reauth> ] [ <url_redirect_acl> ] [
<url_redirect_link> ] [ <aaa_at_in_acl> ] [ <auth_vlan> ] ] [ <start_period_detail> ] [ <auth_period_detail>
] [ <held_period_detail> ] [ <max_start_detail> ] [ <no_of_supp_clients> ] [ <auth_mac_addr_detail> ] [
<supp_sm_state> ] [ <supp_bend_sm_state> ] [ <supp_port_status> ] ] | { show dot1x interface <if> statistics
[ __readonly__ <if_index_stat> <pae_type_stat> [ <rxstart> ] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [
<rxinvalid> ] [ <rxlenerr> ] [ <rxtotal> ] [ <txreq> ] [ <txreqid> ] [ <txttotal> ] [ <rxversion> ] [
<lastrxsourcemac> ] [ <rxreq> ] [ <rxsuppinvalid> ] [ <rxsupplennerr> ] [ <rxsupptotal> ] [ <txstart> ] [
<txlogoff> ] [ <txresp> ] [ <txsupptotal> ] [ <rxsuppversion> ] [ <lastrxsrcmac> ] ] | { show dot1x interface
<if> summary [ __readonly__ <if_index_summary> <pae_type_summary> [ <port_status_no_clients_summary>
] [ { TABLE_if_auth_clients_summary [ <auth_mac_addr> ] [ <port_status_summary> ] ] [ <supp_mac_addr>
] [ <supp_port_status_summary> ] ] }
```

### Syntax Description

| dot1x                         | dot1x configuration commands |
|-------------------------------|------------------------------|
| <i>if</i>                     |                              |
| details                       | 802.1x details               |
| statistics                    | 802.1x statistics            |
| summary                       | 802.1x summary               |
| TABLE_if_auth_clients_detail  | (Optional)                   |
| TABLE_if_auth_clients_summary | (Optional)                   |
| __readonly__                  | (Optional)                   |
| <i>if_index</i>               | (Optional) Interface Index   |
| <i>if_index_detail</i>        | (Optional) Interface Index   |
| <i>if_index_stat</i>          | (Optional) Interface Index   |
| <i>if_index_summary</i>       | (Optional) Interface Index   |
| <i>pae_type</i>               | (Optional) Show PAE Type     |

|                                 |  |
|---------------------------------|--|
| <i>port_control</i>             | (Optional) Show Port Control                   |
| <i>host_mode</i>                | (Optional) Show Host Mode                      |
| <i>reauth</i>                   | (Optional) Show Reauth Enabled Status          |
| <i>quiet_period</i>             | (Optional) Show Quiet Period                   |
| <i>inactivity_period</i>        | (Optional) Show Inactivity Period              |
| <i>server_timeout</i>           | (Optional) Show Server Timeout                 |
| <i>supp_timeout</i>             | (Optional) Show Supp Timeout                   |
| <i>reauth_period</i>            | (Optional) Show Reauth Period                  |
| <i>reauth_max</i>               | (Optional) Show Reauth Max                     |
| <i>max_req</i>                  | (Optional) Show Max Req                        |
| <i>tx_period</i>                | (Optional) Show Tx Period                      |
| <i>rate_limit_period</i>        | (Optional) Show Rate Limit Period              |
| <i>start_period</i>             | (Optional) Show Supplicant Start Period        |
| <i>auth_period</i>              | (Optional) Show Supplicant Auth Period         |
| <i>held_period</i>              | (Optional) Show Supplicant Held Period         |
| <i>max_start</i>                | (Optional) Show Supplicant Max Start           |
| <i>reauth_server</i>            | (Optional) Show Reauth Server Enabled Status   |
| <i>mac_auth_bypass</i>          | (Optional) Show MAC Auth Bypass Enabled Status |
| <i>pae_type_detail</i>          | (Optional) Show PAE Type                       |
| <i>port_control_detail</i>      | (Optional) Show Port Control                   |
| <i>host_mode_detail</i>         | (Optional) Show Host Mode                      |
| <i>reauth_detail</i>            | (Optional) Show Reauth Enabled Status          |
| <i>quiet_period_detail</i>      | (Optional) Show Quiet Period                   |
| <i>inactivity_period_detail</i> | (Optional) Show Inactivity Period              |
| <i>server_timeout_detail</i>    | (Optional) Show Server Timeout                 |
| <i>supp_timeout_detail</i>      | (Optional) Show Supp Timeout                   |
| <i>reauth_period_detail</i>     | (Optional) Show Reauth Period                  |
| <i>reauth_max_detail</i>        | (Optional) Show Reauth Max                     |
| <i>max_req_detail</i>           | (Optional) Show Max Req                        |

|                                      |   |
|--------------------------------------|---|
| <i>tx_period_detail</i>              | (Optional) Show Tx Period                           |
| <i>rate_limit_period_detail</i>      | (Optional) Show Rate Limit Period                   |
| <i>reauth_server_detail</i>          | (Optional) Show Reauth Server Enabled Status        |
| <i>mac_auth_bypass_detail</i>        | (Optional) Show MAC Auth Bypass Enabled Status      |
| <i>no_of_clients</i>                 | (Optional) Show Supplicant Clients                  |
| <i>port_status_no_clients_detail</i> | (Optional) Show Port Status if there are no clients |
| <i>supp_mac_addr_detail</i>          | (Optional) Show Supplicant MAC Address              |
| <i>auth_domain</i>                   | (Optional) Show Supplicant Auth Domain              |
| <i>auth_sm_state</i>                 | (Optional) Show Authenticator SM State              |
| <i>auth_bend_sm_state</i>            | (Optional) Show Authenticator Backend State         |
| <i>port_status</i>                   | (Optional) Show Port Status                         |
| <i>authentication_method</i>         | (Optional) show authentication method               |
| <i>authenticated_by</i>              | (Optional) show authenticated by                    |
| <i>reauth_period_client</i>          | (Optional) Show Reauth Period                       |
| <i>reauth_action</i>                 | (Optional) Show Reauthentication Action             |
| <i>time_to_next_reauth</i>           | (Optional) Show Time to Next Reauth                 |
| <i>url_redirect_acl</i>              | (Optional) Show URL Re-Direct ACL                   |
| <i>url_redirect_link</i>             | (Optional) Show URL Re-Direct Link                  |
| <i>aaa_at_in_acl</i>                 | (Optional) Show Filter-ID ACL                       |
| <i>auth_vlan</i>                     | (Optional) Show vlan                                |
| <i>start_period_detail</i>           | (Optional) Show Supplicant Start Period             |
| <i>auth_period_detail</i>            | (Optional) Show Supplicant Auth Period              |
| <i>held_period_detail</i>            | (Optional) Show Supplicant Held Period              |
| <i>max_start_detail</i>              | (Optional) Show Supplicant Max Start                |
| <i>no_of_supp_clients</i>            | (Optional) Show Supplicant Clients                  |
| <i>auth_mac_addr_detail</i>          | (Optional) Show Authenticator MAC Address           |
| <i>supp_sm_state</i>                 | (Optional) Show Supplicant SM State                 |
| <i>supp_bend_sm_state</i>            | (Optional) Show Supplicant Backend SM State         |
| <i>supp_port_status</i>              | (Optional) Show Supplicant Port Status              |

|                                       |   |
|---------------------------------------|---|
| <i>pae_type_stat</i>                  | (Optional) Show PAE Type                            |
| <i>rxstart</i>                        | (Optional) Show Received EAPOL-Start                |
| <i>rxlogoff</i>                       | (Optional) Show Received EAPOL-Logoff               |
| <i>rxresp</i>                         | (Optional) Show Received EAP-Response               |
| <i>rxrespid</i>                       | (Optional) Show Received EAP-ResponseID             |
| <i>rxinvalid</i>                      | (Optional) Show Received Invalid EAPOL Frame        |
| <i>rxlenerr</i>                       | (Optional) Show Received EAPOL Bad Length Frame     |
| <i>rxtotal</i>                        | (Optional) Show Received Total EAPOL Frame          |
| <i>txreq</i>                          | (Optional) Show Transmitted EAP-Request             |
| <i>txreqid</i>                        | (Optional) Show Transmitted EAP-RequestID           |
| <i>txtotal</i>                        | (Optional) Show Transmitted Total EAPOL Frame       |
| <i>rxversion</i>                      | (Optional) Show Received EAPOL Version              |
| <i>lastrxsourcemac</i>                | (Optional) Show Last Source MAC                     |
| <i>rxreq</i>                          | (Optional) Show Received EAP-Request                |
| <i>rxsupinvalid</i>                   | (Optional) Show received Invalid EAPOL Frame        |
| <i>rxsupplenerr</i>                   | (Optional) Show received EAPOL Bad Length Frame     |
| <i>rxsupptotal</i>                    | (Optional) Show Received Total EAPOL Frame          |
| <i>txstart</i>                        | (Optional) Show transmitted EAPOL-Start             |
| <i>txlogoff</i>                       | (Optional) Show transmitted EAPOL-Logoff            |
| <i>txresp</i>                         | (Optional) Show transmitted EAP-Response            |
| <i>txsupptotal</i>                    | (Optional) Show transmitted Total EAPOL Frame       |
| <i>rxsuppversion</i>                  | (Optional) Show Received EAPOL Version              |
| <i>lastrxsrmac</i>                    | (Optional) Show Last Souuce MAC received            |
| <i>pae_type_summary</i>               | (Optional) Show PAE Type                            |
| <i>port_status_no_clients_summary</i> | (Optional) Show Port Status if there are no clients |
| <i>port_status_summary</i>            | (Optional) Show Port Status                         |
| <i>supp_port_status_summary</i>       | (Optional) Show Port Status                         |
| <i>supp_mac_addr</i>                  | (Optional) Show Supplicant Client MAC Address       |
| <i>auth_mac_addr</i>                  | (Optional) Show Auth Client MAC Address             |

**Command Mode**

- /exec

## show dot1x interface client statistics

```
show dot1x interface <if> client statistics [ __readonly__ <if_index_stat> <pae_type_stat> [ {
TABLE_mac_address [ <macaddr> ] [ <rxstart> ] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [
<rxlenerr> ] [ <rxtotal> ] [ <txreq> ] [ <txreqid> ] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemac> ] } ] [
<spurious_rxstart> ] [ <spurious_rxlogoff> ] [ <spurious_rxresp> ] [ <spurious_rxrespid> ] [
<spurious_rxinvalid> ] [ <spurious_rxlenerr> ] [ <spurious_rxtotal> ] [ <spurious_txreq> ] [ <spurious_txreqid>
] [ <spurious_txtotal> ] [ <spurious_rxversion> ] [ <spurious_lastrxsourcemac> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| dot1x                   | dot1x configuration commands                          |
| <i>if</i>               |   |
| client                  | 802.1x client   |
| statistics              | 802.1x statistics                                     |
| <i>__readonly__</i>     | (Optional)  |
| TABLE_mac_address       | (Optional)  |
| <i>if_index_stat</i>    | (Optional) Interface Index                            |
| <i>pae_type_stat</i>    | (Optional) Show PAE Type                              |
| <i>macaddr</i>          | (Optional) mac-address of the client                  |
| <i>rxstart</i>          | (Optional) Show Received EAPOL-Start                  |
| <i>rxlogoff</i>         | (Optional) Show Received EAPOL-Logoff                 |
| <i>rxresp</i>           | (Optional) Show Received EAP-Response                 |
| <i>rxrespid</i>         | (Optional) Show Received EAP-ResponseID               |
| <i>rxinvalid</i>        | (Optional) Show Received Invalid EAPOL Frame          |
| <i>rxlenerr</i>         | (Optional) Show Received EAPOL Bad Length Frame       |
| <i>rxtotal</i>          | (Optional) Show Received Total EAPOL Frame            |
| <i>txreq</i>            | (Optional) Show Transmitted EAP-Request               |
| <i>txreqid</i>          | (Optional) Show Transmitted EAP-RequestID             |
| <i>txtotal</i>          | (Optional) Show Transmitted Total EAPOL Frame         |
| <i>rxversion</i>        | (Optional) Show Received EAPOL Version                |
| <i>lastrxsourcemac</i>  | (Optional) Show Last Source MAC                       |
| <i>spurious_rxstart</i> | (Optional) Show Received EAPOL-Start of spurious macs |

|                                 |  |
|---------------------------------|--|
| <i>spurious_rxlogoff</i>        | (Optional) Show Received EAPOL-Logoff of spurious macs           |
| <i>spurious_rxresp</i>          | (Optional) Show Received EAP-Response of spurious macs           |
| <i>spurious_rxrespid</i>        | (Optional) Show Received EAP-ResponseID of spurious macs         |
| <i>spurious_rxinvalid</i>       | (Optional) Show Received Invalid EAPOL Frame of spurious macs    |
| <i>spurious_rxlennerr</i>       | (Optional) Show Received EAPOL Bad Length Frame of spurious macs |
| <i>spurious_rxtotal</i>         | (Optional) Show Received Total EAPOL Frame of spurious macs      |
| <i>spurious_txreq</i>           | (Optional) Show Transmitted EAP-Request of spurious macs         |
| <i>spurious_txreqid</i>         | (Optional) Show Transmitted EAP-RequestID of spurious macs       |
| <i>spurious_txtotal</i>         | (Optional) Show Transmitted Total EAPOL Frame of spurious macs   |
| <i>spurious_rxversion</i>       | (Optional) Show Received EAPOL Version of spurious macs          |
| <i>spurious_lastrxsourcemac</i> | (Optional) Show Last Source MAC of spurious macs                 |

**Command Mode**

- /exec

## show dot1x interface client statistics address

```
show dot1x interface <if> client statistics address <mac-address> [ __readonly__ <if_index_stat>
<pae_type_stat> [ <rxstart> ] [ <rxlogoff> ] [ <rxresp> ] [ <rxrespid> ] [ <rxinvalid> ] [ <rxlenerr> ] [ <rxtotal>
] [ <txreq> ] [ <txreqid> ] [ <txtotal> ] [ <rxversion> ] [ <lastrxsourcemac> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| dot1x                  | dot1x configuration commands                    |
| <i>if</i>              |   |
| client                 | 802.1x client                                   |
| statistics             | 802.1x statistics                               |
| address                | 802.1x client address                           |
| <i>mac-address</i>     | mac address EE:EE:EE:EE:EE:EE                   |
| <i>__readonly__</i>    | (Optional)                                      |
| <i>if_index_stat</i>   | (Optional) Interface Index                      |
| <i>pae_type_stat</i>   | (Optional) Show PAE Type                        |
| <i>rxstart</i>         | (Optional) Show Received EAPOL-Start            |
| <i>rxlogoff</i>        | (Optional) Show Received EAPOL-Logoff           |
| <i>rxresp</i>          | (Optional) Show Received EAP-Response           |
| <i>rxrespid</i>        | (Optional) Show Received EAP-ResponseID         |
| <i>rxinvalid</i>       | (Optional) Show Received Invalid EAPOL Frame    |
| <i>rxlenerr</i>        | (Optional) Show Received EAPOL Bad Length Frame |
| <i>rxtotal</i>         | (Optional) Show Received Total EAPOL Frame      |
| <i>txreq</i>           | (Optional) Show Transmitted EAP-Request         |
| <i>txreqid</i>         | (Optional) Show Transmitted EAP-RequestID       |
| <i>txtotal</i>         | (Optional) Show Transmitted Total EAPOL Frame   |
| <i>rxversion</i>       | (Optional) Show Received EAPOL Version          |
| <i>lastrxsourcemac</i> | (Optional) Show Last Source MAC                 |

### Command Mode

- /exec



# show dpvm database

show dpvm database [ active ]

## Syntax Description

|          |   |
|----------|---|
| show     | Show running system information         |
| dpvm     | Show dpvm                               |
| database | Show dpvm configured database           |
| active   | (Optional) Show dpvm activated database |

## Command Mode

- /exec

# show dpvm fip

show dpvm fip

## Syntax Description

|      |                                 |
|------|---------------------------------|
| show | Show running system information |
| dpvm | Show dpvm commands              |
| fip  | Display the enabled FIP         |

## Command Mode

- /exec

# show dpvm merge statistics

show dpvm merge statistics

## Syntax Description

|            |                                 |
|------------|---------------------------------|
| show       | Show running system information |
| dpvm       | Show dpvm                       |
| merge      | Show dpvm merge information     |
| statistics | Show dpvm merge statistics      |

## Command Mode

- /exec

# show dpvm merge status

show dpvm merge status

## Syntax Description

|        |                                 |
|--------|---------------------------------|
| show   | Show running system information |
| dpvm   | Show dpvm                       |
| merge  | Show dpvm merge information     |
| status | Show dpvm merge status          |

## Command Mode

- /exec

# show dpvm pending-diff

show dpvm pending-diff

## Syntax Description

|              |                                 |
|--------------|---------------------------------|
| show         | Show running system information |
| dpvm         | Show dpvm                       |
| pending-diff | Pending DPVM configuration diff |

## Command Mode

- /exec

# show dpvm pending

show dpvm pending [ activation status ]

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information              |
| dpvm       | Show dpvm                                    |
| pending    | Pending DPVM configuration                   |
| activation | (Optional) Pending activate db               |
| status     | (Optional) Show dpvm activate failure status |

## Command Mode

- /exec

# show dpvm ports

show dpvm ports [ vsan <i0> ]

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                     |
| dpvm      | Show dpvm   |
| ports     | Show dpvm dynamic ports                             |
| vsan      | (Optional) Show dpvm dynamic ports for a given VSAN |
| <i>i0</i> | (Optional) vsan id                                  |

## Command Mode

- /exec

# show dpvm session status

show dpvm session status

## Syntax Description

|         |                                 |
|---------|---------------------------------|
| show    | Show running system information |
| dpvm    | Show dpvm                       |
| session | Show dpvm session information   |
| status  | Show dpvm session status        |

## Command Mode

- /exec



# show dpvm status

show dpvm status

## Syntax Description

|        |                                 |
|--------|---------------------------------|
| show   | Show running system information |
| dpvm   | Show dpvm                       |
| status | Show dpvm status                |

## Command Mode

- /exec

**show dpvm status**



## E Show Commands

---

- [show ecp](#), on page 454
- [show elam report](#), on page 456
- [show email](#), on page 457
- [show encryption service status](#), on page 458
- [show environment](#), on page 459
- [show epbr policy](#), on page 465
- [show epbr statistics policy](#), on page 467
- [show errdisable detect](#), on page 468
- [show errdisable flap](#), on page 469
- [show esmc counters interface](#), on page 470
- [show esmc packet-trace](#), on page 471
- [show ethanalyzer background-session](#), on page 472
- [show evb](#), on page 473
- [show evb hosts](#), on page 474
- [show evb vsi](#), on page 476
- [show event manager environment](#), on page 478
- [show event manager event-types](#), on page 479
- [show event manager events action-log](#), on page 480
- [show event manager history events](#), on page 481
- [show event manager policy-state](#), on page 482
- [show event manager script system](#), on page 483
- [show event manager system-policy](#), on page 484

# show ecp

```
show ecp [ detail ] [ __readonly__ <ecp_rte> <ecp_retries> [ <ecp_mode> ] <ecp_cnt_rx_pkt>
<ecp_cnt_tx_pkt> [ { TABLE_ecp_plugin <plugin_id> <plugin_desc> <plugin_status> } ] [ {
TABLE_ecp_session <session_id> <session_interface> <session_svlan> [ <session_peer_mac> ]
<session_rx_seq> <session_tx_seq> [ <session_cnt_rx_pkt> ] [ <session_cnt_rx_dup> ] [
<session_cnt_rx_drop> ] [ <session_cnt_tx_pkt> ] [ <session_cnt_tx_retry> ] [ <session_cnt_tx_err> ] } ] ]
```

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information               |
| ecp                        | ECP (Edge Control Protocol)                   |
| detail                     | (Optional) Detailed information               |
| __readonly__               | (Optional)                                    |
| <i>ecp_rte</i>             | (Optional) Retransmission timer init exponent |
| <i>ecp_retries</i>         | (Optional) Maximal number of retransmissions  |
| <i>ecp_mode</i>            | (Optional) ECP mode                           |
| <i>ecp_cnt_rx_pkt</i>      | (Optional) No. received packet                |
| <i>ecp_cnt_tx_pkt</i>      | (Optional) No. transmitted packet             |
| TABLE_ecp_plugin           | (Optional) ECP plugin table                   |
| <i>plugin_id</i>           | (Optional) Plugin id                          |
| <i>plugin_desc</i>         | (Optional) Plugin description                 |
| <i>plugin_status</i>       | (Optional) Plugin status                      |
| TABLE_ecp_session          | (Optional) ECP session table                  |
| <i>session_id</i>          | (Optional) Session id                         |
| <i>session_svlan</i>       | (Optional) S-Vlan                             |
| <i>session_peer_mac</i>    | (Optional) Peer mac                           |
| <i>session_interface</i>   | (Optional) Interface                          |
| <i>session_rx_seq</i>      | (Optional) Receive sequence                   |
| <i>session_tx_seq</i>      | (Optional) Transmit sequence                  |
| <i>session_cnt_rx_pkt</i>  | (Optional) No. receive packet                 |
| <i>session_cnt_rx_dup</i>  | (Optional) No. receive duplicate              |
| <i>session_cnt_rx_drop</i> | (Optional) No. receive drop                   |

|                             |                                |
|-----------------------------|--------------------------------|
| <i>session_cnt_tx_pkt</i>   | (Optional) No. transmit packet |
| <i>session_cnt_tx_retry</i> | (Optional) No. transmit retry  |
| <i>session_cnt_tx_err</i>   | (Optional) No. transmit error  |

**Command Mode**

- /exec

# show elam report

show elam report [ l2 | l3 | l4 | aclqos | mcast | mpls ]

## Syntax Description

|        |                                  |
|--------|----------------------------------|
| show   | Show running system information  |
| elam   | elam                             |
| report | Show ELAM report                 |
| l2     | (Optional) Layer 2 header report |
| l3     | (Optional) Layer 3 header report |
| l4     | (Optional) Layer 4 header report |
| aclqos | (Optional) Aclqos report         |
| mcast  | (Optional) Multicast report      |
| mpls   | (Optional) MPLS report           |

## Command Mode

- /exec/elamtah/outsel2

# show email

```
show email [ __readonly__ [ <ipv4> ] [ <ipv6> ] [ <host> ] [ <port> ] [ <reply> ] [ <from> ] [ <vrfname> ] ]
```

## Syntax Description

|                           |                                 |
|---------------------------|---------------------------------|
| <code>show</code>         | Show running system information |
| <code>email</code>        | Pipe email configuration        |
| <code>__readonly__</code> | (Optional)                      |
| <code>ipv4</code>         | (Optional)                      |
| <code>ipv6</code>         | (Optional)                      |
| <code>host</code>         | (Optional)                      |
| <code>port</code>         | (Optional)                      |
| <code>reply</code>        | (Optional)                      |
| <code>from</code>         | (Optional)                      |
| <code>vrfname</code>      | (Optional)                      |

## Command Mode

- /exec

# show encryption service status

```
show encryption service status [ __readonly__ [ <encryptionService> <MasterKeyEncryption>
<Type6Encryption> ] ]
```

## Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| encryption                 | Encryption service                    |
| service                    | Encryption service                    |
| status                     | Encryption service status             |
| <i>__readonly__</i>        | (Optional)                            |
| <i>encryptionService</i>   | (Optional) Encryption service status  |
| <i>MasterKeyEncryption</i> | (Optional) Master key status          |
| <i>Type6Encryption</i>     | (Optional) Is type 6 encryption used? |

## Command Mode

- /exec



# show environment

```
show environment [ fan [ detail1 ] | power [ detail ] [ ampere ] [ input ] | temperature [ module <module> |
<s0> <santa-cruz-range> | psu ] [ _readonly_ [ { TABLE_clockinfo <clockname> <clkmodel> <clkhwver>
<clkstatus> <act_standby> } ] [ { fandetails [ { TABLE_faninfo <fanname> <fanmodel> <fanhwver> <fandir>
<fanstatus> } ] { TABLE_fan_zone_speed <zone> <zonespeed> } [ <fan_filter_status> ] [ { TABLE_fantray
<fanname> <trayfannum> <fandir> <fanperc> <fanrpm> } ] [ { TABLE_psufan <fanname> <fan1rpm>
<fan2rpm> } ] ] [ { powersup [ <voltage_level> ] [ { TABLE_psinfo <psnum> <psmodel> [ <actual_out>
] [ <actual_input> ] [ <tot_capa> ] [ <input_type> ] [ <watts> ] [ <amps> ] [ <ps_status> ] [ <ps_status_3k>
] ] ] [ { TABLE_mod_pow_info <modnum> <mod_model> [ <actual_draw> ] [ <allocated> ] [
<watts_requested> ] [ <amps_requested> ] [ <watts_allocated> ] [ <amps_allocated> ] [ <modstatus> ] [
<modstatus_3k> ] ] ] [ { power_summary [ <ps_redun_mode> ] [ <ps_redun_mode_3k> ] [ <ps_oper_mode>
] [ <ps_redun_op_mode> ] <tot_pow_capacity> [ <tot_gridA_capacity> ] [ <tot_gridB_capacity> ] [
<cumulative_power> ] [ <tot_pow_out_actual_draw> ] [ <tot_pow_input_actual_draw> ] [
<tot_pow_alloc_budgeted> ] [ <reserve_sup> ] [ <pow_used_by_mods> ] <available_pow> } ] [ {
powersup_detail [ <reserve_sup> ] [ <reserve_xbar> ] [ <reserve_fan> ] [ <reserve_supxbarfan> ] [
<pow_used_by_mods> ] ] [ <all_inlets_connected> ] [ { TABLE_ps_detail_info <det_name> <det_total_cap>
<det_volt> <det_pintot> [ <det_pina> ] <det_vin> <det_iin> <det_pout> <det_vout> <det_iout> [ <det_pinb>
] [ <det_iinb> ] [ <det_vinb> ] [ <det_cord> ] <det_sw_alarm> [ { TABLE_det_hw_alarm_regval <regnum>
<regval> } ] [ { TABLE_det_hw_alarm_str <regnumstr> <bitnumstr> <alarm_str> } ] ] ] [ {
TABLE_psinputinfo_n3k <ps_slot> <ps_input_voltage> <ps_input_current> [ <ps_in_power> ] [
<ps_output_voltage> ] [ <ps_output_current> ] <ps_state> } ] ] [ { fandetails_3k [ { TABLE_faninfo
<fanname> <fanmodel> <fanhwver> <fandir> <fanstatus> } ] { TABLE_fan_zone_speed <zone> <speed>
} <fan_filter_status> [ { TABLE_fantray <fanname> <fannum> <fandir> <fanperc> <fanrpm> } ] [ {
TABLE_psufan <fanname> <fan1rpm> <fan2rpm> } ] ] ] [ { TABLE_tempinfo <tempmod> <sensor>
<majthres> <minthres> <curtemp> <alarmstatus> [ <temptype> ] ] ] [ { TABLE_psutempinfo <psumod>
<inlet_temp> <outlet_temp> <heatsink_temp> } ] ]
```

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information  |
| environment   | system environment information   |
| fan           | (Optional) Fan information   |
| power         | (Optional) Power capacity and power distribution information   |
| detail        | (Optional) Detail Fan-tray information when used with Fan. Detail Power capacity and power distribution information when used with Power |
| detail1       | (Optional) Detail Fan-tray information when used with Fan  |
| ampere        | (Optional) Ampere Power capacity and power distribution information  |
| input         | (Optional) Power supply power input  |
| temperature   | (Optional) temperature sensor information  |
| module        | (Optional) enter a module number   |
| <i>module</i> | (Optional) please enter the module number  |

|                          |  |
|--------------------------|--|
| <i>s0</i>                | (Optional) xbar                                |
| <i>santa-cruz-range</i>  | (Optional) please enter the xbar number        |
| psu                      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED      |
| <i>__readonly__</i>      | (Optional)                                     |
| TABLE_clockinfo          | (Optional) Environment Clock                   |
| <i>clockname</i>         | (Optional) Clock Instance (A or B)             |
| <i>clkmodel</i>          | (Optional) Model number of clock               |
| <i>clkhwver</i>          | (Optional) Hardware version of the clock       |
| <i>clkstatus</i>         | (Optional) Present/Absent Status of the clock  |
| <i>act_standby</i>       | (Optional) Active/Standby Status of clock      |
| fanetails                | (Optional) Environment Fan                     |
| TABLE_faninfo            | (Optional) Fan Info                            |
| <i>fanname</i>           | (Optional) Fan Instance                        |
| <i>fanmodel</i>          | (Optional) Model number of fan                 |
| <i>fanhwver</i>          | (Optional) Hardware version of the fan         |
| <i>fandir</i>            | (Optional) Air-flow direction of the fan-tray  |
| <i>fanstatus</i>         | (Optional) Present/Absent Status of the fan    |
| TABLE_fan_zone_speed     | (Optional) Fan Zone Speeds                     |
| <i>zone</i>              | (Optional) Zone Number                         |
| <i>zonespeed</i>         | (Optional) Zone Speed                          |
| <i>fan_filter_status</i> | (Optional) Present/Absent Status of fan filter |
| TABLE_fantray            | (Optional) Fan Tray Details table              |
| <i>fanname</i>           | (Optional) Fan Tray Instance                   |
| <i>trayfannum</i>        | (Optional) Fan number in the tray              |
| <i>fandir</i>            | (Optional) Air-flow direction of the fan-tray  |
| <i>fanperc</i>           | (Optional) FAN Speed percentage                |
| <i>fanrpm</i>            | (Optional) FAN Speed RPM                       |
| TABLE_psufan             | (Optional) PSU Fan Details table               |
| <i>fanname</i>           | (Optional) PSU Fan Instance                    |

|                          |  |
|--------------------------|--|
| <i>fan1rpm</i>           | (Optional) FAN1 Speed RPM                      |
| <i>fan2rpm</i>           | (Optional) FAN2 Speed RPM                      |
| <i>fanetails_3k</i>      | (Optional) Environment Fan                     |
| TABLE_faninfo            | (Optional) Fan Info                            |
| <i>fanname</i>           | (Optional) Fan Instance                        |
| <i>fanmodel</i>          | (Optional) Model number of fan                 |
| <i>fanhwver</i>          | (Optional) Hardware version of the fan         |
| <i>fandir</i>            | (Optional) Air-flow direction of the fan-tray  |
| <i>fanstatus</i>         | (Optional) Present/Absent Status of the fan    |
| TABLE_fan_zone_speed     | (Optional) Fan Zone Speeds                     |
| <i>zone</i>              | (Optional) Zone Number                         |
| <i>speed</i>             | (Optional) Zone Speed                          |
| <i>fan_filter_status</i> | (Optional) Present/Absent Status of fan filter |
| TABLE_fantray            | (Optional) Fan Tray Details table              |
| <i>fanname</i>           | (Optional) Fan Tray Instance                   |
| <i>fannum</i>            | (Optional) Fan number in the tray              |
| <i>fandir</i>            | (Optional) Air-flow direction of the fan-tray  |
| <i>fanperc</i>           | (Optional) FAN Speed percentage                |
| <i>fanrpm</i>            | (Optional) FAN Speed RPM                       |
| TABLE_psufan             | (Optional) PSU Fan Details table               |
| <i>fanname</i>           | (Optional) PSU Fan Instance                    |
| <i>fan1rpm</i>           | (Optional) FAN1 Speed RPM                      |
| <i>fan2rpm</i>           | (Optional) FAN2 Speed RPM                      |
| <i>powersup</i>          | (Optional) Environment Power                   |
| <i>voltage_level</i>     | (Optional) Voltage Level                       |
| TABLE_psinfo             | (Optional) Power Supply Info                   |
| <i>psnum</i>             | (Optional) Power Supply Number                 |
| <i>psmodel</i>           | (Optional) Power Supply Model                  |
| <i>actual_out</i>        | (Optional) Actual Output                       |

|                                  |   |
|----------------------------------|---|
| <i>actual_input</i>              | (Optional) Actual Input                                 |
| <i>tot_capa</i>                  | (Optional) Total Capacity                               |
| <i>input_type</i>                | (Optional) Power Supply Input Type                      |
| <i>watts</i>                     | (Optional) Power in Watts                               |
| <i>amps</i>                      | (Optional) Power in Amps                                |
| <i>ps_status</i>                 | (Optional) Power Supply Status                          |
| <i>ps_status_3k</i>              | (Optional) Power Supply Status                          |
| TABLE_mod_pow_info               | (Optional) Module Power Info                            |
| <i>modnum</i>                    | (Optional) Module number                                |
| <i>mod_model</i>                 | (Optional) Model ProductID number                       |
| <i>actual_draw</i>               | (Optional) Actual Draw                                  |
| <i>allocated</i>                 | (Optional) Power allocated                              |
| <i>watts_requested</i>           | (Optional) Power requested in Watts                     |
| <i>amps_requested</i>            | (Optional) Power requested in Amps                      |
| <i>watts_alloced</i>             | (Optional) Power allocated in Watts                     |
| <i>amps_alloced</i>              | (Optional) Power allocated in Amps                      |
| <i>modstatus</i>                 | (Optional) Module Status                                |
| <i>modstatus_3k</i>              | (Optional) Module status                                |
| <i>power_summary</i>             | (Optional) Power Usage Summary                          |
| <i>ps_redun_mode</i>             | (Optional) Mode: Redundant or Non-redundant             |
| <i>ps_redun_mode_3k</i>          | (Optional) Mode: Redundant or Non-redundant             |
| <i>ps_redun_op_mode</i>          | (Optional) Operational mode: Redundant or Non-redundant |
| <i>ps_oper_mode</i>              | (Optional) Operational Mode                             |
| <i>tot_pow_capacity</i>          | (Optional) Total Power Capacity                         |
| <i>tot_gridA_capacity</i>        | (Optional) Total Grid-A Capacity                        |
| <i>tot_gridB_capacity</i>        | (Optional) Total Grid-B Capacity                        |
| <i>cumulative_power</i>          | (Optional) Total Power of all Inputs                    |
| <i>tot_pow_out_actual_draw</i>   | (Optional) Total Power Output, Actuals                  |
| <i>tot_pow_input_actual_draw</i> | (Optional) Total Power Input, Actuals                   |

|                               |   |
|-------------------------------|---|
| <i>tot_pow_alloc_budgeted</i> | (Optional) Total Power Allocated/budgeted           |
| <i>reserve_sup</i>            | (Optional) Power reserved for Supervisors           |
| <i>pow_used_by_mods</i>       | (Optional) Power currently used by Modules          |
| <i>available_pow</i>          | (Optional) Remaining Power Available                |
| <i>powersup_detail</i>        | (Optional) PowerSupply Details                      |
| <i>reserve_sup</i>            | (Optional) Power reserved for Supervisors           |
| <i>reserve_xbar</i>           | (Optional) Power reserved for Xbars                 |
| <i>reserve_fan</i>            | (Optional) Power reserved for Fans                  |
| <i>reserve_supxbarfan</i>     | (Optional) Total Power reserved for Sups,Xbars,Fans |
| <i>pow_used_by_mods</i>       | (Optional) Power currently used by Modules          |
| <i>all_inlets_connected</i>   | (Optional) Are all inlet cords connected            |
| TABLE_ps_detail_info          | (Optional) Power supply detail information          |
| <i>det_name</i>               | (Optional) Power supply name                        |
| <i>det_total_cap</i>          | (Optional) Power supply total capacity              |
| <i>det_volt</i>               | (Optional) Power supply voltage                     |
| <i>det_pintot</i>             | (Optional) Power supply pin A total power           |
| <i>det_pina</i>               | (Optional) PS pin A                                 |
| <i>det_vin</i>                | (Optional) PS Vin                                   |
| <i>det_iin</i>                | (Optional) PS Iin                                   |
| <i>det_pout</i>               | (Optional) PS Power out                             |
| <i>det_vout</i>               | (Optional) PS voltaget out                          |
| <i>det_iout</i>               | (Optional) PS current in                            |
| <i>det_pinb</i>               | (Optional) PS pin B                                 |
| <i>det_iinb</i>               | (Optional) PS Iin B                                 |
| <i>det_vinb</i>               | (Optional) PS Vin B                                 |
| <i>det_cord</i>               | (Optional) PS cord                                  |
| <i>det_sw_alarm</i>           | (Optional) PS software alarm                        |
| TABLE_det_hw_alarm_regval     | (Optional) PS hardware alarm                        |
| <i>regnum</i>                 | (Optional) HW alarm register                        |

|                          |   |
|--------------------------|---|
| <i>regval</i>            | (Optional) Alarm reg value                |
| TABLE_det_hw_alarm_str   | (Optional) PS Hardware alarm string       |
| <i>regnumstr</i>         | (Optional) Alarm reg number               |
| <i>bitnumstr</i>         | (Optional) Alarm register bit             |
| <i>alarm_str</i>         | (Optional) Alarm cause                    |
| TABLE_psinputinfo_n3k    | (Optional) Power Supply power input       |
| <i>ps_slot</i>           | (Optional) Power Supply Number            |
| <i>ps_input_voltage</i>  | (Optional) Power Supply input volatage    |
| <i>ps_input_current</i>  | (Optional) Power Supply input current     |
| <i>ps_in_power</i>       | (Optional) Power Supply input power       |
| <i>ps_output_voltage</i> | (Optional) Power Supply output volatage   |
| <i>ps_output_current</i> | (Optional) Power Supply output current    |
| <i>ps_state</i>          | (Optional) Power Supply status            |
| TABLE_tempinfo           | (Optional) Environment Temperature        |
| <i>tempmod</i>           | (Optional) Module                         |
| <i>sensor</i>            | (Optional) Sensor name                    |
| <i>majthres</i>          | (Optional) Major Threshold                |
| <i>minthres</i>          | (Optional) Minor Threshold                |
| <i>curtemp</i>           | (Optional) Current temperature            |
| <i>alarmstatus</i>       | (Optional) Alarm Status                   |
| <i>temptype</i>          | (Optional) Control or Monitor temperature |
| TABLE_psutempinfo        | (Optional) PSU temperature info table     |
| <i>psumod</i>            | (Optional) PSU Module                     |
| <i>inlet_temp</i>        | (Optional) Inlet Temperature              |
| <i>outlet_temp</i>       | (Optional) Outlet Temperature             |
| <i>heatsink_temp</i>     | (Optional) Heatsink Temperature           |

### Command Mode

- /exec

# show epbr policy

```
show epbr policy [ <policy-name> ] [ reverse ] [ __readonly__ TABLE_pmap <pname> [ {
TABLE_pmap_match <match_type> <match_stmt> <action> [ { TABLE_pmap_s_chain <seq> <sname>
<action> [ { TABLE_pmap_s_chain_entry <ip_type> <svc_ep> [ <track_id> ] [ <probe_state> } ] } ] } ] [
<intf_name> ] + ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information            |
| epbr                     | Show information about epbr                |
| policy                   | EPBR policy name                           |
| <i>policy-name</i>       | (Optional) Policy name                     |
| reverse                  | (Optional) Apply the policy in reverse dir |
| <i>__readonly__</i>      | (Optional) Read Only                       |
| TABLE_pmap               | (Optional)                                 |
| <i>pname</i>             | (Optional) Policy Name                     |
| TABLE_pmap_match         | (Optional)                                 |
| <i>match_type</i>        | (Optional) Match Type                      |
| <i>match_stmt</i>        | (Optional) Match Statement                 |
| <i>action</i>            | (Optional) Traffic action                  |
| TABLE_pmap_s_chain       | (Optional)                                 |
| <i>seq</i>               | (Optional) Sequence Number                 |
| <i>sname</i>             | (Optional) Service Name                    |
| <i>action</i>            | (Optional) Action                          |
| TABLE_pmap_s_chain_entry | (Optional)                                 |
| <i>ip_type</i>           | (Optional) IP type                         |
| <i>svc_ep</i>            | (Optional) Service Endpoint                |
| <i>track_id</i>          | (Optional) Track ID                        |
| <i>probe_state</i>       | (Optional) Probe State                     |
| <i>intf_name</i>         | (Optional) Interface Name                  |

## Command Mode

- /exec



# show epbr statistics policy

```
show epbr statistics policy <policy-name> [ reverse ] [ __readonly__ TABLE_pmap <pname> <match_stmt>
<bcount> [ { TABLE_pmap_t_match <bname> [ { TABLE_pmap_b_stats <sname> <pval> <action> } ] } ]
]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| epbr                | Show information about epbr                |
| statistics          | EPBR Statistics                            |
| policy              | EPBR Policy                                |
| <i>policy-name</i>  | Policy name                                |
| reverse             | (Optional) Apply the policy in reverse dir |
| <i>__readonly__</i> | (Optional) Read Only                       |
| TABLE_pmap          | (Optional)                                 |
| <i>pname</i>        | (Optional) Policy Name                     |
| <i>match_stmt</i>   | (Optional) Match Statement                 |
| <i>bcount</i>       | (Optional) Bucket Count                    |
| TABLE_pmap_t_match  | (Optional)                                 |
| <i>bname</i>        | (Optional) Bucket Name                     |
| TABLE_pmap_b_stats  | (Optional)                                 |
| <i>sname</i>        | (Optional) Service Name                    |
| <i>pval</i>         | (Optional) Packet Value                    |
| <i>action</i>       | (Optional) Action                          |

## Command Mode

- /exec

# show errdisable detect

```
show errdisable { detect | recovery } [ __readonly__ TABLE_errdisable <cause> <state> [ <time_interval> ] ]
```

## Syntax Description

|                  |                                       |
|------------------|---------------------------------------|
| show             | Show running system information       |
| errdisable       | Error disable                         |
| detect           | Show errdisable detect                |
| recovery         | Show errdisable recovery              |
| __readonly__     | (Optional) Read Only                  |
| TABLE_errdisable | (Optional) show errdisable            |
| cause            | (Optional) errdisable cause           |
| state            | (Optional) Interface state            |
| time_interval    | (Optional) err recovery time interval |

## Command Mode

- /exec

# show errdisable flap

show errdisable flap

## Syntax Description

|            |                                 |
|------------|---------------------------------|
| show       | Show running system information |
| errdisable | Error disable                   |
| flap       | linkstate flapping              |

## Command Mode

- /exec

## show esmc counters interface

```
show esmc counters { interface <if0> | all } [ __readonly__ [ TABLE_esmc <intf_name> <esmc_infos_sent>
<esmc_events_sent> <esmc_dnus_sent> <esmc_infos_rcvd> <esmc_events_rcvd> <esmc_dnus_rcvd>
<esmc_malformed_rcvd> <esmc_rcvd_error> ] <esmc-end> ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information            |
| esmc                       | Ethernet Synchronization Messaging Channel |
| __readonly__               | (Optional) Read Only                       |
| counters                   | Display ESMC packet counters               |
| interface                  | Enter the port interface                   |
| <i>if0</i>                 |  |
| all                        | Displays all information                   |
| TABLE_esmc                 | (Optional) Start of table                  |
| <i>intf_name</i>           | (Optional) Interface name                  |
| <i>esmc_infos_sent</i>     | (Optional) esmc infos sent                 |
| <i>esmc_events_sent</i>    | (Optional) esmc events sent                |
| <i>esmc_dnus_sent</i>      | (Optional) esmc dnus sent                  |
| <i>esmc_infos_rcvd</i>     | (Optional) esmc infos rcvd                 |
| <i>esmc_events_rcvd</i>    | (Optional) esmc events rcvd                |
| <i>esmc_dnus_rcvd</i>      | (Optional) esmc dnus rcvd                  |
| <i>esmc_malformed_rcvd</i> | (Optional) esmc malformed rcvd frames      |
| <i>esmc_rcvd_error</i>     | (Optional) esmc rcvd frame errors          |
| <i>esmc-end</i>            | (Optional) End of table                    |

### Command Mode

- /exec

## show esmc packet-trace

```
show esmc packet-trace [ __readonly__ <esmc-header> [ TABLE_esmc <intf-name> <sup-time> <pkt_dir>
<pkt_type> <pkt_info> ] <esmc-end> ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| esmc                | Ethernet Synchronization Messaging Channel |
| <i>__readonly__</i> | (Optional) Read Only                       |
| packet-trace        | Display last few packet traces             |
| <i>esmc-header</i>  | (Optional) start of table                  |
| TABLE_esmc          | (Optional) ESMC table                      |
| <i>intf-name</i>    | (Optional) interface name                  |
| <i>sup-time</i>     | (Optional) sup time                        |
| <i>pkt_dir</i>      | (Optional) packet direction                |
| <i>pkt_type</i>     | (Optional) packet type                     |
| <i>pkt_info</i>     | (Optional) packet information              |
| <i>esmc-end</i>     | (Optional) end of table                    |

### Command Mode

- /exec

# show ethanalyzer background-session

```
show ethanalyzer background-session { [ processes ] | [ config ] }
```

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information  |
| ethanalyzer        | Configure cisco packet analyzer  |
| background-session | Show background packet analyzer sessions                               |
| processes          | (Optional) Show background packet analyzer sessions processes          |
| config             | (Optional) Print background packet analyzer session configuration file |

## Command Mode

- /exec

# show evb

```
show evb [ __readonly__ <evb_role> <evb_vdp_mac> [ <evb_cisco_mac> ] [ <evb_user_mac> ] <evb_rwd>
<evb_rka> <evb_cnt_recv_vdpdu> <evb_cnt_drop_vdpdu> <evb_cnt_recv_tlv> <evb_cnt_recv_mgr_tlv>
<evb_cnt_recv_assoc_tlv> <evb_cnt_recv_cmd> ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information        |
| evb                           | EVB (Edge Virtual Bridge)              |
| __readonly__                  | (Optional)                             |
| <i>evb_role</i>               | (Optional) EVB role                    |
| <i>evb_vdp_mac</i>            | (Optional) VDP Mac address             |
| <i>evb_cisco_mac</i>          | (Optional) Cisco Mac address           |
| <i>evb_user_mac</i>           | (Optional) User mac address            |
| <i>evb_rwd</i>                | (Optional) Resource wait init exponent |
| <i>evb_rka</i>                | (Optional) Keep-alive init exponent    |
| <i>evb_cnt_recv_vdpdu</i>     | (Optional) No. received vdpdu          |
| <i>evb_cnt_drop_vdpdu</i>     | (Optional) No. dropped vdpdu           |
| <i>evb_cnt_recv_tlv</i>       | (Optional) No. received tlv            |
| <i>evb_cnt_recv_mgr_tlv</i>   | (Optional) No. received mgr tlv        |
| <i>evb_cnt_recv_assoc_tlv</i> | (Optional) No. received assoc tlv      |
| <i>evb_cnt_recv_cmd</i>       | (Optional) No. received commands       |

## Command Mode

- /exec

## show evb hosts

```
show evb hosts [ { summary | detail | internal-info } ] [ { [ mac <mac-addr> | interface <intf-name> | vlan
<vlan-id> | vni <vni-id> | ip <ip-addr> | ipv6 <ipv6-addr> | name <host-name> ] + } ] [ __readonly__
<evb_cnt_host> <evb_cnt_assoc_vsi> [ { TABLE_evb_host <host_row_id> <host_name> [ <host_uuid> ] [
{ TABLE_evb_vsi <vsi_row_id> <mgr_id> <vsi_id> [ <vsi_host_name> ] <interface> [ <vpc> ] [ <s_channel>
] [ <station_mac> ] [ <m_state> ] [ <e_state> ] [ <reason> ] [ <timer> ] [ <profile_id> ] [ {
TABLE_evb_vsi_filter <filter_row_id> [ <filter_group> ] [ <filter_vid> ] [ <filter_bd> ] [ <filter_mac> ] [
<filter_ip> ] } ] } ] } ] }
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                        |
| evb                      | EVB (Edge Virtual Bridge)                              |
| hosts                    | Host information                                       |
| summary                  | (Optional) Display summary information                 |
| detail                   | (Optional) Display detailed information                |
| internal-info            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |
| mac                      | (Optional) Display hosts by MAC address                |
| <i>mac-addr</i>          | (Optional) MAC Address                                 |
| interface                | (Optional) Display hosts by interface                  |
| <i>intf-name</i>         | (Optional) Interface name                              |
| vlan                     | (Optional) Display hosts by VLAN                       |
| <i>vlan-id</i>           | (Optional) VLAN ID                                     |
| vni                      | (Optional) Display hosts by Virtual Network Identifier |
| <i>vni-id</i>            | (Optional) VNI   |
| ip                       | (Optional) Display hosts by IP address                 |
| ipv6                     | (Optional) Display hosts by IPv6 address               |
| <i>ip-addr</i>           | (Optional) IP address                                  |
| name                     | (Optional) Display hosts by host name                  |
| <i>host-name</i>         | (Optional) Host name substring                         |
| __readonly__             | (Optional)   |
| <i>evb_cnt_host</i>      | (Optional) No. host entries                            |
| <i>evb_cnt_assoc_vsi</i> | (Optional) No. associated VSI entries                  |



|                      |                                |
|----------------------|--------------------------------|
| TABLE_evb_host       | (Optional) EVB host table      |
| <i>host_row_id</i>   | (Optional) Host row id         |
| <i>host_name</i>     | (Optional) Host name           |
| <i>host_uuid</i>     | (Optional) Host uuid           |
| TABLE_evb_vsi        | (Optional) EVB vsi table       |
| <i>vsi_row_id</i>    | (Optional) VSI row id          |
| <i>mgr_id</i>        | (Optional) Manager id          |
| <i>vsi_id</i>        | (Optional) VSI id              |
| <i>vsi_host_name</i> | (Optional) Host name           |
| <i>interface</i>     | (Optional) Interface           |
| <i>vpc</i>           | (Optional) VPC                 |
| <i>s_channel</i>     | (Optional) S-Channel           |
| <i>station_mac</i>   | (Optional) Station mac address |
| <i>profile_id</i>    | (Optional) Profile id          |
| <i>m_state</i>       | (Optional) Machine state       |
| <i>e_state</i>       | (Optional) Entry state         |
| <i>reason</i>        | (Optional) State reason        |
| <i>timer</i>         | (Optional) Countdown timer     |
| TABLE_evb_vsi_filter | (Optional) EVB filter table    |
| <i>filter_row_id</i> | (Optional) Filter row id       |
| <i>filter_group</i>  | (Optional) Group id            |
| <i>filter_vid</i>    | (Optional) Vlan id             |
| <i>filter_bd</i>     | (Optional) Bridge-domain id    |
| <i>filter_mac</i>    | (Optional) Mac address         |
| <i>filter_ip</i>     | (Optional) IP address          |

### Command Mode

- /exec

## show evb vsi

```
show evb vsi [ { summary | detail | internal-info } ] [ [ { mac <mac-addr> | interface <intf-name> | vlan
<vlan-id> | vni <vni-id> | ip <ip-addr> | ipv6 <ipv6-addr> } + } ] [ __readonly__ <evb_cnt_vsi>
<evb_cnt_assoc_vsi> [ { TABLE_evb_vsi <vsi_row_id> <mgr_id> <vsi_id> [ <vsi_host_name> ] <interface>
[ <vpc> ] [ <s_channel> ] [ <station_mac> ] [ <m_state> ] [ <e_state> ] [ <reason> ] [ <timer> ] [ <profile_id>
] [ { TABLE_evb_vsi_filter <filter_row_id> [ <filter_group> ] [ <filter_vid> ] [ <filter_bd> ] [ <filter_mac>
] [ <filter_ip> ] } } ] ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                      |
| evb                      | EVB (Edge Virtual Bridge)                            |
| vsi                      | Virtual Station Interface (VSI) information          |
| summary                  | (Optional) Display summary information               |
| detail                   | (Optional) Display detailed information              |
| internal-info            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| mac                      | (Optional) Display VSI by MAC address                |
| <i>mac-addr</i>          | (Optional) MAC Address                               |
| interface                | (Optional) Display VSI by interface                  |
| <i>intf-name</i>         | (Optional) Interface name                            |
| vlan                     | (Optional) Display VSI by VLAN                       |
| <i>vlan-id</i>           | (Optional) VLAN ID                                   |
| vni                      | (Optional) Display VSI by Virtual Network Identifier |
| <i>vni-id</i>            | (Optional) VNI                                       |
| ip                       | (Optional) Display VSI by IP address                 |
| ipv6                     | (Optional) Display VSI by IPv6 address               |
| <i>ip-addr</i>           | (Optional) IP address                                |
| <i>__readonly__</i>      | (Optional)   |
| <i>evb_cnt_vsi</i>       | (Optional) No. VSI entries                           |
| <i>evb_cnt_assoc_vsi</i> | (Optional) No. associated VSI entires                |
| TABLE_evb_vsi            | (Optional) EVB vsi table                             |
| <i>vsi_row_id</i>        | (Optional) VSI row id                                |

|                      |                                |
|----------------------|--------------------------------|
| <i>mgr_id</i>        | (Optional) Manager id          |
| <i>vsi_id</i>        | (Optional) VSI id              |
| <i>vsi_host_name</i> | (Optional) Host name           |
| <i>interface</i>     | (Optional) Interface           |
| <i>vpc</i>           | (Optional) VPC                 |
| <i>s_channel</i>     | (Optional) S-Channel           |
| <i>station_mac</i>   | (Optional) Station mac address |
| <i>profile_id</i>    | (Optional) Profile id          |
| <i>m_state</i>       | (Optional) Machine state       |
| <i>e_state</i>       | (Optional) Entry state         |
| <i>reason</i>        | (Optional) State reaon         |
| <i>timer</i>         | (Optional) Countdown timer     |
| TABLE_evb_vsi_filter | (Optional) EVB filter table    |
| <i>filter_row_id</i> | (Optional) Filter row id       |
| <i>filter_group</i>  | (Optional) Group id            |
| <i>filter_vid</i>    | (Optional) Vlan id             |
| <i>filter_bd</i>     | (Optional) Bridge-domain id    |
| <i>filter_mac</i>    | (Optional) Mac address         |
| <i>filter_ip</i>     | (Optional) IP address          |

**Command Mode**

- /exec

# show event manager environment

show event manager environment { all | <varname> } [ \_\_readonly\_\_ <environment-details> ]

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                                 |
| event                      | Event Manager commands  |
| manager                    | Event Manager commands  |
| environment                | Show information about environment variables                    |
| all                        | Show information about all the configured environment variables |
| <i>varname</i>             | The environment variable name on which information is required  |
| <i>__readonly__</i>        | (Optional)  |
| <i>environment-details</i> | (Optional) Show information about environment variables         |

## Command Mode

- /exec

## show event manager event-types

```
show event manager event-types [ all | <event-type-name> ] [ module <module-id> ] [ __readonly__ {
<event-types> } ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                |
| event                  | Event Manager commands   |
| manager                | Event Manager commands   |
| event-types            | Show information about registered event types                  |
| all                    | (Optional) Show information about advanced event types as well |
| <i>event-type-name</i> | (Optional) Show information about the specified event type     |
| module                 | (Optional) Show information about event types on other modules |
| <i>module-id</i>       | (Optional) Module Id   |
| __readonly__           | (Optional)   |
| <i>event-types</i>     | (Optional) Show information about registered event types       |

### Command Mode

- /exec

# show event manager events action-log

```
show event manager events action-log [ policy <policy-name> | event-type <event-type-name> ] [ __readonly__
{ <action-log-data> } ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                          |
| event                  | Event Manager commands                                   |
| manager                | Event Manager commands                                   |
| events                 | Show information about the history of past events        |
| action-log             | Show policy action logs                                  |
| policy                 | (Optional) Name of policy                                |
| <i>policy-name</i>     | (Optional) Enter policy name                             |
| event-type             | (Optional) Name of event                                 |
| <i>event-type-name</i> | (Optional) Enter event type                              |
| __readonly__           | (Optional)   |
| <i>action-log-data</i> | (Optional) Show information about the policy action logs |

## Command Mode

- /exec

## show event manager history events

```
show event manager history events [ detail ] [ maximum <n-events> ] [ severity <sev> ] [ __readonly__ {
<history-events> } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information   |
| event                 | Event Manager commands  |
| manager               | Event Manager commands  |
| history               | Show information about the history of past activity                       |
| events                | Show information about the history of past events                         |
| detail                | (Optional) Show information about the event parameters as well            |
| maximum               | (Optional) Specify an upper limit on the number of events to be shown     |
| <i>n-events</i>       | (Optional) Specify the maximum number of events to be shown               |
| severity              | (Optional) Show only those events whose severity is >= specified severity |
| <i>sev</i>            | (Optional) Enter the severity threshold                                   |
| __readonly__          | (Optional)  |
| <i>history-events</i> | (Optional) Show information about the history of past events              |

### Command Mode

- /exec

## show event manager policy-state

```
show event manager policy-state <name> [ module <module-id> ] [ __readonly__ { <policy-state> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                         |
| event               | Event Manager commands                                  |
| manager             | Event Manager commands                                  |
| policy-state        | Show information about the state of a policy            |
| <i>name</i>         | Name of the policy                                      |
| module              | (Optional) Get the information from a module            |
| <i>module-id</i>    | (Optional) Module Id                                    |
| <i>__readonly__</i> | (Optional)  |
| <i>policy-state</i> | (Optional) Show information about the state of a policy |

### Command Mode

- /exec



## show event manager script system

```
show event manager script system { all | <script-name> } [ __readonly__ <script_system_details> ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information                          |
| event                        | Event Manager commands                                   |
| manager                      | Event Manager commands                                   |
| script                       | Show information about a script policy                   |
| system                       | Show information about a system script policy            |
| all                          | Show all the available system script policies            |
| <i>script-name</i>           | Name of the system script policy                         |
| <i>__readonly__</i>          | (Optional)   |
| <i>script_system_details</i> | (Optional) Show Information about system script policies |

### Command Mode

- /exec

## show event manager system-policy

```
show event manager system-policy [ all | <policy-name> ] [ __readonly__ { [ TABLE_eem [ <thresh_min> ] [ <thresh_max> ] <event_name> <event_description> <event_overridable> <event_type> } } ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information  |
| event                    | Event Manager commands   |
| manager                  | Event Manager commands   |
| system-policy            | Show information about default system policies                             |
| all                      | (Optional) Show all policies (including advanced and non-overridable ones) |
| <i>policy-name</i>       | (Optional) Show detailed information about the specified policy            |
| <i>__readonly__</i>      | (Optional)   |
| TABLE_eem                | (Optional)   |
| <i>thresh_min</i>        | (Optional)   |
| <i>thresh_max</i>        | (Optional)   |
| <i>event_name</i>        | (Optional)   |
| <i>event_description</i> | (Optional)   |
| <i>event_overridable</i> | (Optional)   |
| <i>event_type</i>        | (Optional)   |

### Command Mode

- /exec



## F Show Commands

---

- [show fabric-binding database](#), on page 490
- [show fabric-binding efmd statistics](#), on page 491
- [show fabric-binding fip](#), on page 492
- [show fabric-binding statistics](#), on page 493
- [show fabric-binding status](#), on page 494
- [show fabric-binding violations](#), on page 495
- [show fabric database dci](#), on page 496
- [show fabric database host](#), on page 498
- [show fabric database host statistics](#), on page 502
- [show fabric database host summary](#), on page 505
- [show fabric database profile-map](#), on page 506
- [show fabric database static-host](#), on page 507
- [show fabric database statistics](#), on page 508
- [show fabric forwarding host-db](#), on page 510
- [show fabric forwarding ip local](#), on page 512
- [show fabric forwarding ipv6 local](#), on page 513
- [show fabric multicast globals](#), on page 514
- [show fabric multicast ipv4 l2 vni](#), on page 516
- [show fabric multicast statistics](#), on page 517
- [show fabric multicast vrf](#), on page 519
- [show fabric switch information](#), on page 520
- [show fc2 bind](#), on page 521
- [show fc2 classf](#), on page 522
- [show fc2 exchange](#), on page 524
- [show fc2 exchresp](#), on page 526
- [show fc2 flogi](#), on page 528
- [show fc2 nport](#), on page 529
- [show fc2 plogi](#), on page 531
- [show fc2 plogi\\_pwwn](#), on page 533
- [show fc2 port brief](#), on page 534
- [show fc2 port drops](#), on page 537
- [show fc2 port state](#), on page 540
- [show fc2 socket](#), on page 542

- [show fc2 sockexch](#), on page 543
- [show fc2 socknotify](#), on page 544
- [show fc2 socknport](#), on page 545
- [show fc2 vsan](#), on page 546
- [show fcalias](#), on page 547
- [show fcdomain](#), on page 548
- [show fcdomain address-allocation](#), on page 549
- [show fcdomain allowed](#), on page 550
- [show fcdomain domain-list](#), on page 551
- [show fcdomain fcid persistent](#), on page 552
- [show fcdomain pending-diff](#), on page 553
- [show fcdomain pending](#), on page 554
- [show fcdomain session-status](#), on page 555
- [show fcdomain statistics](#), on page 556
- [show fcdomain status](#), on page 557
- [show fcdomain vsan](#), on page 558
- [show fcdroplateny](#), on page 559
- [show fcid-allocation area](#), on page 560
- [show fcid-allocation company-id-from-wwn](#), on page 561
- [show fcns database](#), on page 562
- [show fcns statistics](#), on page 564
- [show fcoe-npv issu-impact](#), on page 565
- [show fcoe](#), on page 566
- [show fcoe database](#), on page 567
- [show fcs database](#), on page 568
- [show fcs ie](#), on page 569
- [show fcs platform](#), on page 570
- [show fcs port](#), on page 571
- [show fcs statistics](#), on page 572
- [show fcs vsan](#), on page 573
- [show fctimer](#), on page 574
- [show fctimer D\\_S\\_TOV](#), on page 575
- [show fctimer E\\_D\\_TOV](#), on page 576
- [show fctimer F\\_S\\_TOV](#), on page 577
- [show fctimer R\\_A\\_TOV](#), on page 578
- [show fctimer last action status](#), on page 579
- [show fctimer pending-diff](#), on page 580
- [show fctimer pending](#), on page 581
- [show fctimer session status](#), on page 582
- [show fctimer status](#), on page 583
- [show fctimer vsan](#), on page 584
- [show fdmi database](#), on page 585
- [show fdmi database detail](#), on page 586
- [show fdmi database detail hba-id vsan](#), on page 587
- [show fdmi database detail vsan](#), on page 588
- [show fdmi database vsan](#), on page 589

- [show fdmi suppress-updates](#), on page 590
- [show feature-set](#), on page 591
- [show feature-set services](#), on page 592
- [show feature](#), on page 593
- [show fhrp](#), on page 594
- [show fhrp verbose](#), on page 595
- [show file](#), on page 597
- [show fips status](#), on page 598
- [show flogi auto-area-list](#), on page 599
- [show flogi database](#), on page 600
- [show flow cache](#), on page 601
- [show flow cache](#), on page 603
- [show flow event](#), on page 605
- [show flow exporter](#), on page 607
- [show flow exporter](#), on page 609
- [show flow filter](#), on page 611
- [show flow interface](#), on page 612
- [show flow interface](#), on page 613
- [show flow monitor](#), on page 614
- [show flow monitor](#), on page 615
- [show flow profile](#), on page 616
- [show flow record](#), on page 618
- [show flow record](#), on page 621
- [show flow rtp](#), on page 624
- [show flow rtp timeout](#), on page 626
- [show flow system](#), on page 627
- [show flow timeout](#), on page 629
- [show flow tracer](#), on page 630
- [show flow vrf](#), on page 631
- [show forwarding](#), on page 632
- [show forwarding adjacency](#), on page 633
- [show forwarding consistency-fretta l2](#), on page 636
- [show forwarding distribution clients](#), on page 637
- [show forwarding distribution evpn storm-control](#), on page 638
- [show forwarding distribution fib-state](#), on page 639
- [show forwarding distribution ip igmp snooping](#), on page 640
- [show forwarding distribution ipv6 multicast route](#), on page 641
- [show forwarding distribution l2 multicast](#), on page 643
- [show forwarding distribution lisp counters](#), on page 645
- [show forwarding distribution lisp vrf enabled](#), on page 646
- [show forwarding distribution multicast](#), on page 647
- [show forwarding distribution multicast client-ack-db](#), on page 648
- [show forwarding distribution multicast client](#), on page 649
- [show forwarding distribution multicast download](#), on page 650
- [show forwarding distribution multicast mfib](#), on page 651
- [show forwarding distribution multicast outgoing-interface-list L2\\_PRIME](#), on page 652

- [show forwarding distribution multicast resp-ack-timer-msgs](#), on page 653
- [show forwarding distribution multicast route](#), on page 654
- [show forwarding distribution multicast sr hash-db](#), on page 657
- [show forwarding distribution multicast vxlan dsg-db](#), on page 658
- [show forwarding distribution nve overlay-vlan](#), on page 659
- [show forwarding distribution peer-id](#), on page 660
- [show forwarding distribution srv6 local-sid bd-mapping](#), on page 661
- [show forwarding distribution trace](#), on page 662
- [show forwarding ecmp](#), on page 663
- [show forwarding ecmp recursive](#), on page 665
- [show forwarding inconsistency](#), on page 670
- [show forwarding interfaces](#), on page 672
- [show forwarding ipv6](#), on page 673
- [show forwarding ipv6 adjacency](#), on page 676
- [show forwarding ipv6 inconsistency](#), on page 678
- [show forwarding ipv6 multicast route](#), on page 680
- [show forwarding kvfib cache on](#), on page 683
- [show forwarding l2 multicast](#), on page 684
- [show forwarding l2vpn label vpls](#), on page 686
- [show forwarding l2vpn label xconnect](#), on page 687
- [show forwarding l2vpn vlan](#), on page 688
- [show forwarding mpls](#), on page 689
- [show forwarding mpls drop-stats](#), on page 691
- [show forwarding mpls ecmp](#), on page 692
- [show forwarding mpls eompls](#), on page 694
- [show forwarding mpls eompls ir](#), on page 695
- [show forwarding mpls option\\_b](#), on page 697
- [show forwarding mpls srte module](#), on page 698
- [show forwarding mpls summary](#), on page 699
- [show forwarding multicast-sr loopback interface](#), on page 700
- [show forwarding multicast-sr mac-trap-db](#), on page 701
- [show forwarding multicast outgoing-interface-list](#), on page 702
- [show forwarding multicast route](#), on page 704
- [show forwarding nve l2 ingress-replication-peers](#), on page 707
- [show forwarding nve l3 adjacency tunnel](#), on page 710
- [show forwarding nve l3 adjacency v6-tunnel](#), on page 712
- [show forwarding nve l3 ecmp](#), on page 714
- [show forwarding nve l3 peers](#), on page 715
- [show forwarding nve underlay-interfaces](#), on page 716
- [show forwarding otv](#), on page 717
- [show forwarding otv ipv6 multicast route](#), on page 718
- [show forwarding otv multicast outgoing-interface-list](#), on page 721
- [show forwarding otv multicast route](#), on page 722
- [show forwarding otv vlan](#), on page 723
- [show forwarding security group-tag](#), on page 724
- [show forwarding security mac](#), on page 726

- [show forwarding srv6 adjacency decap, on page 728](#)
- [show forwarding srv6 adjacency encap, on page 729](#)
- [show forwarding srv6 bsid-peer, on page 730](#)
- [show forwarding srv6 bsid, on page 731](#)
- [show forwarding srv6 ecmp, on page 732](#)
- [show forwarding srv6 local-sid, on page 733](#)
- [show forwarding srv6 peers, on page 734](#)
- [show forwarding trace, on page 735](#)
- [show forwarding trace profile, on page 736](#)
- [show forwarding trace profile funcstats, on page 737](#)
- [show frequency synchronization clock-interface brief, on page 738](#)
- [show frequency synchronization clock-interface detail, on page 740](#)
- [show frequency synchronization configuration errors, on page 743](#)
- [show frequency synchronization interface, on page 745](#)
- [show frequency synchronization interface brief, on page 748](#)
- [show frequency synchronization selection, on page 750](#)
- [show fspf, on page 752](#)
- [show fspf database, on page 753](#)
- [show fspf interface, on page 754](#)
- [show fspf vsan, on page 755](#)
- [show fspf vsan interface, on page 756](#)
- [show fte event, on page 757](#)
- [show fte exporter, on page 758](#)
- [show fte monitor, on page 759](#)
- [show fte record, on page 760](#)

# show fabric-binding database

show fabric-binding database [ { active [ vsan <i0> ] | vsan1 <i1> } ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information         |
| fabric-binding | Show Fabric Binding                     |
| database       | Show Fabric Binding Configured database |
| active         | (Optional) Activated Fabric Bindings    |
| vsan           | (Optional) VSAN id                      |
| <i>i0</i>      | (Optional) VSAN range                   |
| vsan1          | (Optional) VSAN id                      |
| <i>i1</i>      | (Optional) VSAN range                   |

## Command Mode

- /exec



# show fabric-binding efmd statistics

show fabric-binding efmd statistics [ vsan <i0> ]

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fabric-binding | Show Fabric Binding             |
| efmd           | Exchange Fabric Membership Data |
| statistics     | EFMD protocol statistics        |
| vsan           | (Optional) VSAN id              |
| <i>i0</i>      | (Optional) VSAN range           |

## Command Mode

- /exec

# show fabric-binding fip

show fabric-binding fip

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fabric-binding | Fabric Binding configuration    |
| fip            | Display the enabled FIP         |

## Command Mode

- /exec

# show fabric-binding statistics

show fabric-binding statistics [ vsan <i0> ]

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fabric-binding | Show Fabric Binding             |
| statistics     | Statistics of Fabric Binding    |
| vsan           | (Optional) VSAN Id              |
| <i>i0</i>      | (Optional) VSAN range           |

## Command Mode

- /exec

# show fabric-binding status

show fabric-binding status [ vsan <i0> ]

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fabric-binding | Show Fabric Binding             |
| status         | Fabric binding Status           |
| vsan           | (Optional) VSAN Id              |
| <i>i0</i>      | (Optional) VSAN range           |

## Command Mode

- /exec

# show fabric-binding violations

show fabric-binding violations [ last <i0> ]

## Syntax Description

|                |                                       |
|----------------|---------------------------------------|
| show           | Show running system information       |
| fabric-binding | Show Fabric Binding                   |
| violations     | Violations of Fabric Binding policies |
| last           | (Optional) Latest n violations        |
| <i>i0</i>      | (Optional) Violation number           |

## Command Mode

- /exec

## show fabric database dci

```
show fabric database dci [ { vrf { <vrf-name> | <vrf-known-name> } [ peer-id <peer-ip-address> ] [ detail ]
} ] [ __readonly__ [ TABLE_database_dci <vrf_name> <state> <flags> <profile> <instance> ] [
TABLE_database_dci_detail <packet_arrival_time> <sent_to_database_manager_at>
<received_parameters_from_database_manager_at> <sent_apply_to_configuration_manager_at>
<completed_executing_all_commands_at> <sent_un_apply_to_configuration_manager_at>
<completed_unapplying_all_commands_at> ] ]
```

### Syntax Description

|   |  |
|---|--|
| show  | Show running system information                      |
| fabric  | Fabric   |
| database  | Fabric Database                                      |
| dci   | DCI Profile Database                                 |
| vrf   | (Optional) Display per-VRF information               |
| <i>vrf-name</i>                                     | (Optional) VRF name                                  |
| <i>vrf-known-name</i>                               | (Optional) Known VRF name                            |
| peer-id   | (Optional) management ip address of peer             |
| <i>peer-ip-address</i>                              | (Optional) IP address in CIDR format                 |
| detail  | (Optional) Show detailed information                 |
| __readonly__  | (Optional) Read Only                                 |
| TABLE_database_dci                                  | (Optional) table show fabric database dci            |
| <i>vrf_name</i>                                     | (Optional)   |
| <i>state</i>  | (Optional)   |
| <i>flags</i>  | (Optional)   |
| <i>profile</i>                                      | (Optional)   |
| <i>instance</i>                                     | (Optional)   |
| TABLE_database_dci_detail                           | (Optional) detail for table show fabric database dci |
| <i>packet_arrival_time</i>                          | (Optional) Profile request time                      |
| <i>sent_to_database_manager_at</i>                  | (Optional) Profile request sent to DCNM              |
| <i>received_parameters_from_database_manager_at</i> | (Optional) Profile downloaded from DCNM              |
| <i>sent_apply_to_configuration_manager_at</i>       | (Optional) Profile sent to PPM to apply              |

|  |   |
|--|---|
| <i>completed_executing_all_commands_at</i>       | (Optional) Profile applied by PPM       |
| <i>sent_un_apply_to_configuration_manager_at</i> | (Optional) Profile un-apply sent to PPM |
| <i>completed_unapplying_all_commands_at</i>      | (Optional) Profile un-applied by PPM    |

**Command Mode**

- /exec

## show fabric database host

```
show fabric database host [ detail ] [ { vni <vni-id> } | { dot1q <vlan-id> } ] [ __readonly__ [
TABLE_database_host [ <trigger_source> ] [ <client_type> ] [ <got_trigger_at> ] [ <number_of_client_hosts>
] [ <number_of_associated_interfaces> ] [ <profile_be_un_applied_in_seconds> ] [
<new_vdp_requests_be_accepted_in_seconds> ] [ <recovered_profile_be_checked_for_validity_in_seconds>
] [ <mac_aging_checked_in_seconds> ] [ <sent_to_database_manager_at> ] [
<received_parameters_from_database_manager_at> ] [ <displaying_parameters_for_profile> ] [
<displaying_parameters_for_instance> ] [ <no_parameters_for_the_profile> ] [
<displaying_re_written_parameters_for_vpc_role> ] [ TABLE_parameter [ <parameter_index> ] [ <parameter>
] ] [ TABLE_static_profile <profile> <instance> <no_parameters_for_the_profile> ] [ TABLE_migrated_profile
<profile> <instance_index> <previous_profile> <previous_instance_index> ] [ TABLE_rollback_profile
<profile> <instance_index> ] [ <got_vlan_allocated_from_vlan_manager_at> ] [
<sent_apply_to_configuration_manager_at> ] [ <completed_executing_all_commands_at> ] [
<sent_to_vpc_peer_at> ] [ <completed_executing_all_commands_on_vpc_peer_at> ] [
<sent_un_apply_to_configuration_manager_at> ] [ <completed_unapplying_all_commands_at> ] ] [
TABLE_database_host_vni { [ <vni_id> ] [ <vlan_id> ] [ <state> <flag> <profile_name> <instance_name>
] [ <packet_arrival_time> <request_profile_time> <got_profile_time> <sent_to_PPM_time>
<profile_apply_time> <del_to_PPM_time> ] [ { TABLE_database_host_detail <interface> <encap> <flags>
<state> [ <vsi_id> ] [ <client> ] [ <host> ] } ] ] [ TABLE_database_host_vlan { [ <vlan_id> ] [ <vni_id> ]
[ <state> <flag> <profile_name> <instance_name> ] [ <packet_arrival_time> <request_profile_time>
<got_profile_time> <sent_to_PPM_time> <profile_apply_time> <del_to_PPM_time> ] [ {
TABLE_database_host_detail <interface> <encap> <flags> <state> [ <vsi_id> ] } ] ] [
TABLE_extranet_vrf_entries { <vrf> <l3_vni> <state> <profile> <instance> } ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                          |
| fabric                | Fabric   |
| database              | Fabric Database  |
| host                  | Host to profile mapping                                  |
| detail                | (Optional) Show hosts and interfaces                     |
| vni                   | (Optional) Virtual Network Identifier                    |
| <i>vni-id</i>         | (Optional)   |
| dot1q                 | (Optional) Dot1Q Encapsulation                           |
| <i>vlan-id</i>        | (Optional)   |
| __readonly__          | (Optional) Read Only                                     |
| TABLE_database_host   | (Optional) table show fabric database host {dot1q   vni} |
| <i>trigger_source</i> | (Optional) TODO  |
| <i>client_type</i>    | (Optional) TODO  |



|   |                                      |
|---|--------------------------------------|
| <i>got_trigger_at</i>                                       | (Optional) TODO                      |
| <i>number_of_client_hosts</i>                               | (Optional) TODO                      |
| <i>number_of_associated_interfaces</i>                      | (Optional) TODO                      |
| <i>profile_be_un_applied_in_seconds</i>                     | (Optional) TODO                      |
| <i>new_vdp_requests_be_accepted_in_seconds</i>              | (Optional) TODO                      |
| <i>recovered_profile_be_checked_for_validity_in_seconds</i> | (Optional) TODO                      |
| <i>mac_aging_checked_in_seconds</i>                         | (Optional) TODO                      |
| <i>sent_to_database_manager_at</i>                          | (Optional) TODO                      |
| <i>received_parameters_from_database_manager_at</i>         | (Optional) TODO                      |
| <i>displaying_parameters_for_profile</i>                    | (Optional) TODO                      |
| <i>displaying_parameters_for_instance</i>                   | (Optional) TODO                      |
| <i>no_parameters_for_the_profile</i>                        | (Optional) TODO                      |
| <i>displaying_re-written_parameters_for_vpc_role</i>        | (Optional) TODO                      |
| TABLE_parameter   | (Optional) table show the parameters |
| <i>parameter_index</i>                                      | (Optional) TODO                      |
| <i>parameter</i>  | (Optional) TODO                      |
| TABLE_static_profile  | (Optional) show static profile       |
| <i>profile</i>  | (Optional) TODO                      |
| <i>instance</i>   | (Optional) TODO                      |
| <i>no_parameters_for_the_profile</i>                        | (Optional) TODO                      |
| TABLE_migrated_profile                                      | (Optional) show migrated profile     |
| <i>profile</i>  | (Optional) TODO                      |
| <i>instance_index</i>                                       | (Optional) TODO                      |
| <i>previous_profile</i>                                     | (Optional) TODO                      |
| <i>previous_instance_index</i>                              | (Optional) TODO                      |
| TABLE_rollback_profile                                      | (Optional) show rollback profile     |
| <i>profile</i>  | (Optional) TODO                      |
| <i>instance_index</i>                                       | (Optional) TODO                      |
| <i>got_vlan_allocated_from_vlan_manager_at</i>              | (Optional) TODO                      |

|  |   |
|--|---|
| <i>sent_apply_to_configuration_manager_at</i>          | (Optional) TODO                                       |
| <i>completed_executing_all_commands_at</i>             | (Optional) TODO                                       |
| <i>sent_to_vpc_peer_at</i>                             | (Optional) TODO                                       |
| <i>completed_executing_all_commands_on_vpc_peer_at</i> | (Optional) TODO                                       |
| <i>sent_un_apply_to_configuration_manager_at</i>       | (Optional) TODO                                       |
| <i>completed_unapplying_all_commands_at</i>            | (Optional) TODO                                       |
| TABLE_database_host_vni                                | (Optional) table show fabric database host vni based  |
| <i>vni_id</i>  | (Optional) TODO Add comment                           |
| <i>vlan_id</i>   | (Optional) TODO Add comment                           |
| <i>state</i>   | (Optional) TODO Add comment                           |
| <i>flag</i>  | (Optional) TODO                                       |
| <i>profile_name</i>                                    | (Optional) TODO                                       |
| <i>instance_name</i>                                   | (Optional) TODO                                       |
| <i>packet_arrival_time</i>                             | (Optional) TODO                                       |
| <i>request_profile_time</i>                            | (Optional) TODO                                       |
| <i>got_profile_time</i>                                | (Optional) TODO                                       |
| <i>sent_to_PPM_time</i>                                | (Optional) TODO                                       |
| <i>profile_apply_time</i>                              | (Optional) TODO                                       |
| <i>del_to_PPM_time</i>                                 | (Optional) TODO                                       |
| TABLE_database_host_detail                             | (Optional) table show fabric database host detail     |
| <i>interface</i>                                       | (Optional) TODO                                       |
| <i>encap</i>   | (Optional) TODO                                       |
| <i>flags</i>   | (Optional) TODO                                       |
| <i>state</i>   | (Optional) TODO                                       |
| <i>vsi_id</i>  | (Optional) TODO                                       |
| <i>client</i>  | (Optional) TODO                                       |
| <i>host</i>  | (Optional) TODO                                       |
| TABLE_database_host_vlan                               | (Optional) table show fabric database host vlan based |
| <i>vlan_id</i>   | (Optional) TODO Add comment                           |

|                             |   |
|-----------------------------|---|
| <i>vni_id</i>               | (Optional) TODO Add comment                       |
| <i>state</i>                | (Optional) TODO Add comment                       |
| <i>flag</i>                 | (Optional) TODO                                   |
| <i>profile_name</i>         | (Optional) TODO                                   |
| <i>instance_name</i>        | (Optional) TODO                                   |
| <i>packet_arrival_time</i>  | (Optional) TODO                                   |
| <i>request_profile_time</i> | (Optional) TODO                                   |
| <i>got_profile_time</i>     | (Optional) TODO                                   |
| <i>sent_to_PPM_time</i>     | (Optional) TODO                                   |
| <i>profile_apply_time</i>   | (Optional) TODO                                   |
| <i>del_to_PPM_time</i>      | (Optional) TODO                                   |
| TABLE_database_host_detail  | (Optional) table show fabric database host detail |
| <i>interface</i>            | (Optional) TODO                                   |
| <i>encap</i>                | (Optional) TODO                                   |
| <i>flags</i>                | (Optional) TODO                                   |
| <i>state</i>                | (Optional) TODO                                   |
| <i>vsi_id</i>               | (Optional) TODO                                   |
| TABLE_extranet_vrf_entries  | (Optional) table extranet VRF entries             |
| <i>vrf</i>                  | (Optional) TODO                                   |
| <i>l3_vni</i>               | (Optional) TODO                                   |
| <i>state</i>                | (Optional) TODO                                   |
| <i>profile</i>              | (Optional) TODO                                   |
| <i>instance</i>             | (Optional) TODO                                   |

### Command Mode

- /exec

## show fabric database host statistics

```
show fabric database host statistics [ __readonly__ [ TABLE_database_host_statistics { [ <data_snoop_triggers> ] [ <data_snoop_deletes> ] [ <data_snoop_responses> ] [ <vdp_association_requests> ] [ <vdp_deassociation_requests> ] [ <vdp_association_responses> ] [ <vdp_error_responses> ] [ <unsupported_interfaces> ] [ <no_profile_map_errors> ] [ <outstanding_delete_retry_add> ] [ <duplicate_add_existing_host> ] [ <hmm_api_error_cannot_add_host> ] [ <existing_profile_new_host> ] [ <profile_apply_from_vpc_peer> ] [ <profile_un_apply_from_vpc_peer> ] [ <host_apply_from_vpc_peer> ] [ <host_un_apply_from_vpc_peer> ] [ <early_delete_cancel_add> ] [ <dhcp_requests> ] [ <dhcp_responses> ] [ <dhcp_error_responses> ] [ <adbm_requests> ] [ <adbm_responses> ] [ <adbm_error_responses> ] [ <adbm_error_requests> ] [ <adbm_db_notifications> ] [ <vnseg_no_bridge_domain> ] [ <vnseg_encap_responses> ] [ <vnseg_vni_responses> ] [ <vnseg_unknown_responses> ] [ <vnseg_bd_down_notif> ] [ <bd_mgr_requests> ] [ <bd_mgr_success_responses> ] [ <bd_mgr_failure_responses> ] [ <bd_mgr_unreserve> ] [ <bd_mgr_inconsistencies> ] [ <no_mac_on_bd_notif> ] [ <refresh_failures> ] [ <profile_apply_received> ] [ <profile_vpc_queued> ] [ <profile_local_apply_queued> ] [ <profile_local_unapply_queued> ] [ <profile_apply_sent> ] [ <profile_apply_responses> ] [ <profile_apply_success> ] [ <profile_unapply_success> ] [ <profile_apply_failure> ] [ <profile_commands> ] [ <profile_error_incomplete_configs> ] [ <profile_api_error> ] [ <profile_unapply_sent> ] [ <profile_top_queue_adds> ] [ <profile_high_queue_adds> ] [ <profile_low_queue_adds> ] [ <profile_unapply_failure> ] [ <outstanding_vlan_requests> ] [ <outstanding_adbm_requests> ] [ <outstanding_profile_applies> ] [ <outstanding_vpc_profile_applies> ] [ <node_recon_pending> ] [ <node_recon_attempts> ] [ <node_recon_failures> } ] ] ]
```

### Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information                       |
| fabric                            | Fabric  |
| database                          | Fabric Database                                       |
| host                              | Auto-configured Hosts                                 |
| statistics                        | Statistics - Mostly shows non-zero values             |
| <u>__readonly__</u>               | (Optional) Read Only                                  |
| TABLE_database_host_statistics    | (Optional) table show fabric database host statistics |
| <i>data_snoop_triggers</i>        | (Optional) TODO                                       |
| <i>data_snoop_deletes</i>         | (Optional) TODO                                       |
| <i>data_snoop_responses</i>       | (Optional) TODO                                       |
| <i>vdp_association_requests</i>   | (Optional) TODO                                       |
| <i>vdp_deassociation_requests</i> | (Optional) TODO                                       |
| <i>vdp_association_responses</i>  | (Optional) TODO                                       |
| <i>vdp_error_responses</i>        | (Optional) TODO                                       |

|                                       |                 |
|---------------------------------------|-----------------|
| <i>unsupported_interfaces</i>         | (Optional) TODO |
| <i>no_profile_map_errors</i>          | (Optional) TODO |
| <i>outstanding_delete_retry_add</i>   | (Optional) TODO |
| <i>duplicate_add_existing_host</i>    | (Optional) TODO |
| <i>hmm_api_error_cannot_add_host</i>  | (Optional) TODO |
| <i>existing_profile_new_host</i>      | (Optional) TODO |
| <i>profile_apply_from_vpc_peer</i>    | (Optional) TODO |
| <i>profile_un_apply_from_vpc_peer</i> | (Optional) TODO |
| <i>host_apply_from_vpc_peer</i>       | (Optional) TODO |
| <i>host_un_apply_from_vpc_peer</i>    | (Optional) TODO |
| <i>early_delete_cancel_add</i>        | (Optional) TODO |
| <i>dhcp_requests</i>                  | (Optional) TODO |
| <i>dhcp_responses</i>                 | (Optional) TODO |
| <i>dhcp_error_responses</i>           | (Optional) TODO |
| <i>adbm_requests</i>                  | (Optional) TODO |
| <i>adbm_responses</i>                 | (Optional) TODO |
| <i>adbm_error_responses</i>           | (Optional) TODO |
| <i>adbm_error_requests</i>            | (Optional) TODO |
| <i>adbm_db_notifications</i>          | (Optional) TODO |
| <i>vnseg_no_bridge_domain</i>         | (Optional) TODO |
| <i>vnseg_encap_responses</i>          | (Optional) TODO |
| <i>vnseg_vni_responses</i>            | (Optional) TODO |
| <i>vnseg_unknown_responses</i>        | (Optional) TODO |
| <i>vnseg_bd_down_notif</i>            | (Optional) TODO |
| <i>bd_mgr_requests</i>                | (Optional) TODO |
| <i>bd_mgr_success_responses</i>       | (Optional) TODO |
| <i>bd_mgr_failure_responses</i>       | (Optional) TODO |
| <i>bd_mgr_unreserve</i>               | (Optional) TODO |
| <i>bd_mgr_inconsistencies</i>         | (Optional) TODO |

|   |                 |
|---|-----------------|
| <i>no_mac_on_bd_notif</i>               | (Optional) TODO |
| <i>refresh_failures</i>                 | (Optional) TODO |
| <i>profile_apply_received</i>           | (Optional) TODO |
| <i>profile_vpc_queued</i>               | (Optional) TODO |
| <i>profile_local_apply_queued</i>       | (Optional) TODO |
| <i>profile_local_unapply_queued</i>     | (Optional) TODO |
| <i>profile_apply_sent</i>               | (Optional) TODO |
| <i>profile_apply_responses</i>          | (Optional) TODO |
| <i>profile_apply_success</i>            | (Optional) TODO |
| <i>profile_unapply_success</i>          | (Optional) TODO |
| <i>profile_apply_failure</i>            | (Optional) TODO |
| <i>profile_commands</i>                 | (Optional) TODO |
| <i>profile_error_incomplete_configs</i> | (Optional) TODO |
| <i>profile_api_error</i>                | (Optional) TODO |
| <i>profile_unapply_sent</i>             | (Optional) TODO |
| <i>profile_top_queue_adds</i>           | (Optional) TODO |
| <i>profile_high_queue_adds</i>          | (Optional) TODO |
| <i>profile_low_queue_adds</i>           | (Optional) TODO |
| <i>profile_unapply_failure</i>          | (Optional) TODO |
| <i>outstanding_vlan_requests</i>        | (Optional) TODO |
| <i>outstanding_adbm_requests</i>        | (Optional) TODO |
| <i>outstanding_profile_applies</i>      | (Optional) TODO |
| <i>outstanding_vpc_profile_applies</i>  | (Optional) TODO |
| <i>node_recon_pending</i>               | (Optional) TODO |
| <i>node_recon_attempts</i>              | (Optional) TODO |
| <i>node_recon_failures</i>              | (Optional) TODO |

**Command Mode**

- /exec

## show fabric database host summary

```
show fabric database host summary [ __readonly__ [ TABLE_database_host_summary {
<number_of_instances_applied> <number_of_client_hosts> <recovery_timeout_minute>
<cleanup_timeout_minute> <client_add_suppression_timeout_minute> <mac_aging_timeout_minute>
<autoid_support> } ] ]
```

### Syntax Description

|  |  |
|--|--|
| show   | Show running system information                    |
| fabric                                       | Fabric   |
| database                                     | Fabric Database                                    |
| host   | Auto-configured Hosts                              |
| summary                                      | Summary  |
| <i>__readonly__</i>                          | (Optional) Read Only                               |
| <i>TABLE_database_host_summary</i>           | (Optional) table show fabric database host summary |
| <i>number_of_instances_applied</i>           | (Optional) TODO                                    |
| <i>number_of_client_hosts</i>                | (Optional) TODO                                    |
| <i>recovery_timeout_minute</i>               | (Optional) TODO                                    |
| <i>cleanup_timeout_minute</i>                | (Optional) TODO                                    |
| <i>client_add_suppression_timeout_minute</i> | (Optional) TODO                                    |
| <i>mac_aging_timeout_minute</i>              | (Optional) TODO                                    |
| <i>autoid_support</i>                        | (Optional) List of supported auto-generate ids     |

### Command Mode

- /exec

## show fabric database profile-map

```
show fabric database profile-map { global | [ <id> | interface <interface-id> ] } [ __readonly__ [
TABLE_database_profile_map { <map> <proto> <vni> <dot1q> <flags> <profile_name> } ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                   |
| fabric                     | Fabric  |
| database                   | Fabric Database                                   |
| profile-map                | Profile Map                                       |
| global                     | Global profile (apply to all interfaces)          |
| <i>id</i>                  | (Optional) Profile Map ID                         |
| interface                  | (Optional) Specified interface to display         |
| <i>interface-id</i>        | (Optional) Name of interface                      |
| <i>__readonly__</i>        | (Optional) Read Only                              |
| TABLE_database_profile_map | (Optional) table show fabric database profile-map |
| <i>map</i>                 | (Optional) TODO                                   |
| <i>proto</i>               | (Optional) TODO                                   |
| <i>vni</i>                 | (Optional) TODO                                   |
| <i>dot1q</i>               | (Optional) TODO                                   |
| <i>flags</i>               | (Optional) TODO                                   |
| <i>profile_name</i>        | (Optional) TODO                                   |

### Command Mode

- /exec



## show fabric database static-host

```
show fabric database static-host [ __readonly__ { TABLE_database_static_host <host_key> <interface>
<state> <retry_delay> <retry_attempts> } ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                   |
| fabric                     | Fabric  |
| database                   | Fabric Database                                   |
| static-host                | Configured Static Hosts                           |
| __readonly__               | (Optional) Read Only                              |
| TABLE_database_static_host | (Optional) table show fabric database static-host |
| <i>host_key</i>            | (Optional) static-host key                        |
| <i>interface</i>           | (Optional) interface name                         |
| <i>state</i>               | (Optional) static-host state                      |
| <i>retry_delay</i>         | (Optional) seconds until next retry               |
| <i>retry_attempts</i>      | (Optional) cumulative retry attempts              |

### Command Mode

- /exec

## show fabric database statistics

```
show fabric database statistics [ type { network | profile | cabling | partition | bl-dci | host } ] [ __readonly__
{ TABLE_types <dbtype> <requests> <dispatched> <not_dispatched> <re_dispatched> } [ { TABLE_dbs
<is_active> <type> <prot> <serverdb> [ <reqs> <ok> <nores> <err> <tmout> <pend> ] } ] { LastPollTime
<poll_time> } { LastUpdateTime <update_time> } [ { TABLE_updates <update_type> <update_status> } ]
]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information            |
| fabric                | Fabric                                     |
| database              | Show Fabric Database                       |
| statistics            | Show database statistics                   |
| type                  | (Optional) Enter database type             |
| network               | (Optional) Network Database                |
| profile               | (Optional) Port or Switch Profile Database |
| cabling               | (Optional) Cable Management Database       |
| partition             | (Optional) Partition Database              |
| bl-dci                | (Optional) Border Leaf - DCI               |
| host                  | (Optional) Host                            |
| __readonly__          | (Optional)                                 |
| TABLE_types           | (Optional) totals by type                  |
| <i>dbtype</i>         | (Optional) type of database                |
| <i>requests</i>       | (Optional) number of requests              |
| <i>dispatched</i>     | (Optional) number dispatched               |
| <i>not_dispatched</i> | (Optional) number not dispatched           |
| <i>re_dispatched</i>  | (Optional) number re-dispatched            |
| TABLE_dbs             | (Optional) per-database stats              |
| <i>is_active</i>      | (Optional) active/inactive                 |
| <i>type</i>           | (Optional) database type                   |
| <i>prot</i>           | (Optional) database protocol               |
| <i>serverdb</i>       | (Optional) server database                 |

|                      |  |
|----------------------|--|
| <i>reqs</i>          | (Optional) requests                              |
| <i>ok</i>            | (Optional) OK                                    |
| <i>nores</i>         | (Optional) nores                                 |
| <i>err</i>           | (Optional) err                                   |
| <i>tmout</i>         | (Optional) tmout                                 |
| <i>pend</i>          | (Optional) pend                                  |
| LastPollTime         | (Optional) last poll time                        |
| <i>poll_time</i>     | (Optional) poll time                             |
| LastUpdateTime       | (Optional) last update time for db status change |
| <i>update_time</i>   | (Optional) update time                           |
| TABLE_updates        | (Optional) totals ty type                        |
| <i>update_type</i>   | (Optional) db type                               |
| <i>update_status</i> | (Optional) db status                             |

**Command Mode**

- /exec

## show fabric forwarding host-db

```
show fabric forwarding host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ __readonly__ [
TABLE_forwarding_host_db_vrf { <vrf> <vrf_id> <vrf_state> <vrf_reason> <vni_id> <refcount>
<conversational_learning> [ TABLE_limit_type <limit_type> <enable> <threshold> <action> ] [ TABLE_ipv4
<address_family> <vrf> <table_id> <table_state> <refcount> <local_hosts> <remote_hosts> <aggregates>
[ TABLE_aggregate_list <aggregate_subnet_prefix_list> <aggregate_subnet_prefix_state> ] ] [ TABLE_ipv6
<address_family> <vrf> <table_id> <table_state> <refcount> <local_hosts> <remote_hosts> <aggregates>
[ TABLE_aggregate_list <aggregate_subnet_prefix_list> <aggregate_subnet_prefix_state> ] ] } ] ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                         |
| fabric                         | Fabric  |
| forwarding                     | Fabric Forwarding Protocol: Host Mobility Manager (HMM) |
| host-db                        | Host Database info                                      |
| vrf                            | (Optional) Display per-VRF information                  |
| <i>vrf-name</i>                | (Optional) VRF name                                     |
| <i>vrf-known-name</i>          | (Optional) Known VRF name                               |
| all                            | (Optional) Display information for all VRFs             |
| __readonly__                   | (Optional) Read Only                                    |
| TABLE_forwarding_host_db_vrf   | (Optional) table show fabric forwarding host-db vrf     |
| <i>vrf</i>                     | (Optional) TODO   |
| <i>vrf_id</i>                  | (Optional) TODO   |
| <i>vrf_state</i>               | (Optional) TODO   |
| <i>vrf_reason</i>              | (Optional) TODO   |
| <i>vni_id</i>                  | (Optional) TODO   |
| <i>refcount</i>                | (Optional) TODO   |
| <i>conversational_learning</i> | (Optional) TODO   |
| TABLE_limit_type               | (Optional) table for limit type                         |
| <i>limit_type</i>              | (Optional) TODO   |
| <i>enable</i>                  | (Optional) TODO   |
| <i>threshold</i>               | (Optional) TODO   |
| <i>action</i>                  | (Optional) TODO   |

|                                      |   |
|--------------------------------------|---|
| TABLE_ipv4                           | (Optional) Information for address family IPv4    |
| <i>address_family</i>                | (Optional) TODO                                   |
| <i>vrf</i>                           | (Optional) TODO                                   |
| <i>table_id</i>                      | (Optional) TODO                                   |
| <i>table_state</i>                   | (Optional) TODO                                   |
| <i>refcount</i>                      | (Optional) TODO                                   |
| <i>local_hosts</i>                   | (Optional) TODO                                   |
| <i>remote_hosts</i>                  | (Optional) TODO                                   |
| <i>aggregates</i>                    | (Optional) TODO                                   |
| TABLE_aggregate_list                 | (Optional) table for aggregate subnet prefix list |
| <i>aggregate_subnet_prefix_list</i>  | (Optional) TODO                                   |
| TABLE_ipv6                           | (Optional) Information for address family IPv6    |
| <i>address_family</i>                | (Optional) TODO                                   |
| <i>vrf</i>                           | (Optional) TODO                                   |
| <i>table_id</i>                      | (Optional) TODO                                   |
| <i>table_state</i>                   | (Optional) TODO                                   |
| <i>refcount</i>                      | (Optional) TODO                                   |
| <i>local_hosts</i>                   | (Optional) TODO                                   |
| <i>remote_hosts</i>                  | (Optional) TODO                                   |
| <i>aggregates</i>                    | (Optional) TODO                                   |
| TABLE_aggregate_list                 | (Optional) table for aggregate subnet prefix list |
| <i>aggregate_subnet_prefix_list</i>  | (Optional) TODO                                   |
| <i>aggregate_subnet_prefix_state</i> | (Optional) TODO                                   |

### Command Mode

- /exec

## show fabric forwarding ip local

```
show fabric forwarding ip { local-host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ <ip-prefix>
] } [ __readonly__ [ TABLE_forwarding_ip_local_host_db_vrf { <hmm_host> <vrf> <status_in> {
TABLE_hosts <host> <mac_address> <svi> <flags_0x> <physical_interface> <status> } } ] ]
```

### Syntax Description

|                                       |  |
|---------------------------------------|--|
| show                                  | Show running system information                              |
| fabric                                | Fabric   |
| forwarding                            | Fabric Forwarding Protocol: Host Mobility Manager (HMM)      |
| ip                                    | Display IP information                                       |
| local-host-db                         | HMM Local Host Database                                      |
| vrf                                   | (Optional) Display per-VRF information                       |
| <i>vrf-name</i>                       | (Optional) VRF name  |
| <i>vrf-known-name</i>                 | (Optional) Known VRF name                                    |
| all                                   | (Optional) Display information for all VRFs                  |
| <i>ip-prefix</i>                      | (Optional) IP prefix in CIDR format                          |
| <i>__readonly__</i>                   | (Optional) Read Only   |
| TABLE_forwarding_ip_local_host_db_vrf | (Optional) table show fabric forwarding ip local-host-db vrf |
| <i>hmm_host</i>                       | (Optional) TODO  |
| <i>vrf</i>                            | (Optional) TODO  |
| <i>status_in</i>                      | (Optional) TODO  |
| TABLE_hosts                           | (Optional) table show information for each hosts             |
| <i>host</i>                           | (Optional) TODO  |
| <i>mac_address</i>                    | (Optional) TODO  |
| <i>svi</i>                            | (Optional) TODO  |
| <i>flags_0x</i>                       | (Optional) TODO  |
| <i>physical_interface</i>             | (Optional) TODO  |
| <i>status</i>                         | (Optional) *-valid, x-deleted, a-aged out, c-cleaned         |

### Command Mode

- /exec

## show fabric forwarding ipv6 local

```
show fabric forwarding ipv6 { local-host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ <ipv6-prefix>
] } [ __readonly__ [ TABLE_forwarding_ipv6_local_host_db_vrf { <hmm_host> <vrf> <status_in> {
TABLE_hosts <host> <mac_address> <svi> <flags_0x> <physical_interface> <status> } } ] ]
```

### Syntax Description

|   |  |
|---|--|
| show                                    | Show running system information                                |
| fabric                                  | Fabric   |
| forwarding                              | Fabric Forwarding Protocol: Host Mobility Manager (HMM)        |
| ipv6                                    | Display IPv6 information                                       |
| local-host-db                           | HMM Local Host Database  |
| vrf                                     | (Optional) Display per-VRF information                         |
| <i>vrf-name</i>                         | (Optional) VRF name  |
| <i>vrf-known-name</i>                   | (Optional) Known VRF name                                      |
| all                                     | (Optional) Display information for all VRFs                    |
| __readonly__                            | (Optional) Read Only   |
| TABLE_forwarding_ipv6_local_host_db_vrf | (Optional) table show fabric forwarding ipv6 local-host-db vrf |
| <i>hmm_host</i>                         | (Optional) TODO  |
| <i>vrf</i>                              | (Optional) TODO  |
| <i>status_in</i>                        | (Optional) TODO  |
| TABLE_hosts                             | (Optional) table show information for each hosts               |
| <i>host</i>                             | (Optional) TODO  |
| <i>mac_address</i>                      | (Optional) TODO  |
| <i>svi</i>                              | (Optional) TODO  |
| <i>flags_0x</i>                         | (Optional) TODO  |
| <i>physical_interface</i>               | (Optional) TODO  |
| <i>status</i>                           | (Optional) *-valid, x-deleted, a-aged out, c-cleaned           |

### Command Mode

- /exec

## show fabric multicast globals

```
show fabric multicast globals [ __readonly__ [ <pruning> ] [ <switch_role> ] [ <fabric_control_seg> ] [
<peer_fabric_ctrl_addr> ] [ <advertise_vpc_rpf_routes> ] [ <created_vni_list> ] [ <fwd_encap> ] [
<mrrib_sync_delay> ] [ <bgp_eor_rcvd> ] [ <bgp_eor_rcvd_ts> ] [ <cli_done_rcvd> ] [ <cli_done_rcvd_ts>
] [ <local_nlri_req> ] [ <dist_dr> ] [ <dist_pending> ] [ <spt_only> ] [ <pim_trm_bl> ] [ <pim6_trm_bl> ] [
<l2_trm_evpn> ] ]
```

### Syntax Description

|                                 |                                 |
|---------------------------------|---------------------------------|
| show                            | Show running system information |
| fabric                          | Fabric                          |
| multicast                       | Multicast information           |
| globals                         | show the global settings        |
| <i>__readonly__</i>             | (Optional)                      |
| <i>pruning</i>                  | (Optional)                      |
| <i>switch_role</i>              | (Optional)                      |
| <i>fabric_control_seg</i>       | (Optional)                      |
| <i>peer_fabric_ctrl_addr</i>    | (Optional)                      |
| <i>advertise_vpc_rpf_routes</i> | (Optional)                      |
| <i>created_vni_list</i>         | (Optional)                      |
| <i>fwd_encap</i>                | (Optional)                      |
| <i>mrrib_sync_delay</i>         | (Optional)                      |
| <i>bgp_eor_rcvd</i>             | (Optional)                      |
| <i>bgp_eor_rcvd_ts</i>          | (Optional)                      |
| <i>cli_done_rcvd</i>            | (Optional)                      |
| <i>cli_done_rcvd_ts</i>         | (Optional)                      |
| <i>local_nlri_req</i>           | (Optional)                      |
| <i>dist_dr</i>                  | (Optional)                      |
| <i>dist_pending</i>             | (Optional)                      |
| <i>spt_only</i>                 | (Optional)                      |
| <i>pim_trm_bl</i>               | (Optional)                      |
| <i>pim6_trm_bl</i>              | (Optional)                      |



|                    |            |
|--------------------|------------|
| <i>l2_trm_evpn</i> | (Optional) |
|--------------------|------------|

**Command Mode**

- /exec

## show fabric multicast ipv4 l2 vni

```
show fabric multicast { ipv4 | ipv6 } { l2-mroute } vni { <vni-id> | all } [ __readonly__ TABLE_vni <vni-id>
[ TABLE_mroute <mroute_desc> [ TABLE_fabric <fabric_node_addr> ] ] ]
```

### Syntax Description

|                         |                                       |
|-------------------------|---------------------------------------|
| show                    | Show running system information       |
| fabric                  | Fabric                                |
| multicast               | Multicast information                 |
| ipv4                    | Display IP information                |
| ipv6                    | Display IPv6 information              |
| l2-mroute               | display l2-mroute status              |
| vni                     | Virtual Network Identifier            |
| <i>vni-id</i>           | VNI number                            |
| all                     | Display all L2 VNI NGMVPN is aware of |
| <i>__readonly__</i>     | (Optional)                            |
| <i>TABLE_vni</i>        | (Optional)                            |
| <i>vni-id</i>           | (Optional)                            |
| <i>TABLE_mroute</i>     | (Optional)                            |
| <i>mroute_desc</i>      | (Optional)                            |
| <i>TABLE_fabric</i>     | (Optional)                            |
| <i>fabric_node_addr</i> | (Optional)                            |

### Command Mode

- /exec

## show fabric multicast statistics

```
show fabric multicast statistics [ __readonly__ [ <remote_nlri_msgs_rx> ] [ <remote_nlri_msgs_rx_fail> ] [
<local_nlri_msgs_tx> ] [ <local_nlri_msgs_tx_fail> ] [ <import_rt_msgs_tx> ] [ <import_rt_msgs_tx_fail>
] [ <m2rib_msgs_tx> ] [ <m2rib_msgs_tx_fail> ] [ <mrrib_msgs_tx> ] [ <mrrib_msgs_tx_fail> ] [
<m6rib_msgs_tx> ] [ <m6rib_msgs_tx_fail> ] [ <pim_msgs_tx> ] [ <pim_msgs_tx_fail> ] [ <pim_msgs_rx> ]
] [ <pim_all_remote_ssm_rp_req_rx> ] [ <pim6_msgs_tx> ] [ <pim6_msgs_tx_fail> ] [ <pim6_msgs_rx> ]
] [ <pim6_all_remote_ssm_rp_req_rx> ] [ <remote_nlri_ack_tx> ] [ <remote_nlri_ack_tx_fail> ] [
<all_local_nlri_req_rx> ] [ <local_nlri_ack_rx> ] [ <remote_route_req_tx> ] [ <remote_route_req_tx_fail>
] [ <pim6_all_local_ssm_rp_req_tx> ] [ <pim6_all_local_ssm_rp_req_tx_fail> ] [ <igmp_local_route_rx> ]
] [ <igmp_local_route_ack_rx> ] [ <igmp_msgs_tx> ] [ <igmp_msgs_tx_fail> ] [ <igmp_l2_vni_up_down_rx>
] [ <mts_q_high_warning_rx> ] [ <mts_q_full_warning_rx> ] ]
```

### Syntax Description

|                                 |                                 |
|---------------------------------|---------------------------------|
| show                            | Show running system information |
| fabric                          | Fabric                          |
| multicast                       | Multicast information           |
| statistics                      | Show statistics                 |
| <i>__readonly__</i>             | (Optional)                      |
| <i>remote_nlri_msgs_rx</i>      | (Optional)                      |
| <i>remote_nlri_msgs_rx_fail</i> | (Optional)                      |
| <i>local_nlri_msgs_tx</i>       | (Optional)                      |
| <i>local_nlri_msgs_tx_fail</i>  | (Optional)                      |
| <i>import_rt_msgs_tx</i>        | (Optional)                      |
| <i>import_rt_msgs_tx_fail</i>   | (Optional)                      |
| <i>m2rib_msgs_tx</i>            | (Optional)                      |
| <i>m2rib_msgs_tx_fail</i>       | (Optional)                      |
| <i>mrrib_msgs_tx</i>            | (Optional)                      |
| <i>mrrib_msgs_tx_fail</i>       | (Optional)                      |
| <i>m6rib_msgs_tx</i>            | (Optional)                      |
| <i>m6rib_msgs_tx_fail</i>       | (Optional)                      |
| <i>pim_msgs_tx</i>              | (Optional)                      |
| <i>pim_msgs_tx_fail</i>         | (Optional)                      |
| <i>pim_msgs_rx</i>              | (Optional)                      |

|  |            |
|--|------------|
| <i>pim_all_remote_ssm_rp_req_rx</i>      | (Optional) |
| <i>pim6_msgs_tx</i>                      | (Optional) |
| <i>pim6_msgs_tx_fail</i>                 | (Optional) |
| <i>pim6_msgs_rx</i>                      | (Optional) |
| <i>pim6_all_remote_ssm_rp_req_rx</i>     | (Optional) |
| <i>remote_nlri_ack_tx</i>                | (Optional) |
| <i>remote_nlri_ack_tx_fail</i>           | (Optional) |
| <i>all_local_nlri_req_rx</i>             | (Optional) |
| <i>local_nlri_ack_rx</i>                 | (Optional) |
| <i>remote_route_req_tx</i>               | (Optional) |
| <i>remote_route_req_tx_fail</i>          | (Optional) |
| <i>pim6_all_local_ssm_rp_req_tx</i>      | (Optional) |
| <i>pim6_all_local_ssm_rp_req_tx_fail</i> | (Optional) |
| <i>igmp_local_route_rx</i>               | (Optional) |
| <i>igmp_local_route_ack_rx</i>           | (Optional) |
| <i>igmp_msgs_tx</i>                      | (Optional) |
| <i>igmp_msgs_tx_fail</i>                 | (Optional) |
| <i>igmp_l2_vni_up_down_rx</i>            | (Optional) |
| <i>mts_q_high_warning_rx</i>             | (Optional) |
| <i>mts_q_full_warning_rx</i>             | (Optional) |

**Command Mode**

- /exec

## show fabric multicast vrf

```
show fabric multicast vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<context_name> [ <context_id> ] [ <vprime_iod> ] [ <vnid> ] [ <l3trm> ] [ <iropt> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| fabric                | Fabric   |
| multicast             | Multicast information                          |
| vrf                   | Display per-VRF information                    |
| <i>vrf-name</i>       | (Optional) VRF name                            |
| <i>vrf-known-name</i> | (Optional) Known VRF name                      |
| all                   | (Optional) Display all VRFs NGMVPN is aware of |
| <i>__readonly__</i>   | (Optional)                                     |
| TABLE_vrf             | (Optional)                                     |
| <i>context_name</i>   | (Optional)                                     |
| <i>context_id</i>     | (Optional)                                     |
| <i>vprime_iod</i>     | (Optional)                                     |
| <i>vnid</i>           | (Optional)                                     |
| <i>l3trm</i>          | (Optional)                                     |
| <i>iropt</i>          | (Optional)                                     |

### Command Mode

- /exec

# show fabric switch information

show fabric switch information [ vsan <i0> ]

## Syntax Description

|             |  |
|-------------|--|
| show        | Show running system information              |
| fabric      | Show Fabric Information                      |
| switch      | Show switch details.                         |
| information | Show switch model, version and other details |
| vsan        | (Optional) VSAN id                           |
| <i>i0</i>   | (Optional) VSAN range                        |

## Command Mode

- /exec

# show fc2 bind

```
show fc2 bind [ __readonly__ { TABLE_fc2bind <SOCKET> <FLAGS> <NLEVEL> <RULE> <SINDEX>
<VSAN> <D_ID> <MASK> <TYPE> <SUBTYPE> <M_VALUES> } ]
```

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| fc2             | show fc2 tables and statistics  |
| bind            | show fc2 socket bindings        |
| __readonly__    | (Optional) Read only            |
| TABLE_fc2bind   | (Optional) show fc2 bind        |
| <i>SOCKET</i>   | (Optional) socket               |
| <i>FLAGS</i>    | (Optional) flags                |
| <i>NLEVEL</i>   | (Optional) nlevel               |
| <i>RULE</i>     | (Optional) rule                 |
| <i>SINDEX</i>   | (Optional) sidnex               |
| <i>VSAN</i>     | (Optional) vsan                 |
| <i>D_ID</i>     | (Optional) d_id                 |
| <i>MASK</i>     | (Optional) mask                 |
| <i>TYPE</i>     | (Optional) type                 |
| <i>SUBTYPE</i>  | (Optional) subtype              |
| <i>M_VALUES</i> | (Optional) m_values             |

## Command Mode

- /exec

# show fc2 classf

```
show fc2 classf [ __readonly__ { TABLE_fc2classf <HIX> <VSAN> <S_ID> <D_ID> <IFIDX> <R_A_TOV>
<E_D_TOV> <F-SO> <RC> <RS> <CS> <EE> <2-SO> <RS> <3-SO> <RS> <EECNT> <TCCNT> <FCNT>
<REFCNT> } ]
```

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| fc2             | show fc2 tables and statistics  |
| classf          | show fc2 classf sessions        |
| __readonly__    | (Optional) Read only            |
| TABLE_fc2classf | (Optional) show fc2 classf      |
| HIX             | (Optional) hix                  |
| VSAN            | (Optional) vsan                 |
| S_ID            | (Optional) sid                  |
| D_ID            | (Optional) did                  |
| IFIDX           | (Optional) ifidx                |
| R_A_TOV         | (Optional) r_a_tov              |
| E_D_TOV         | (Optional) e_d_tov              |
| F-SO            | (Optional) f-so                 |
| RC              | (Optional) rc                   |
| RS              | (Optional) rs                   |
| CS              | (Optional) cs                   |
| EE              | (Optional) ee                   |
| 2-SO            | (Optional) 2-so                 |
| RS              | (Optional) rs                   |
| 3-SO            | (Optional) 3-so                 |
| RS              | (Optional) rs                   |
| EECNT           | (Optional) eecnt                |
| TCCNT           | (Optional) tcnt                 |
| FCNT            | (Optional) fcnt                 |



|               |                   |
|---------------|-------------------|
| <i>REFCNT</i> | (Optional) refcnt |
|---------------|-------------------|

**Command Mode**

- /exec

# show fc2 exchange

```
show fc2 exchange [ __readonly__ { TABLE_ExchngInfo [ <ECB_INUSE> ] [ <ECB_DROPPED> ] [
<ECB_TOTAL> ] [ <ECB_MAX> ] } [ TABLE_fc2exchange <HIX> <VSAN> <X_ID> <OX_ID> <RX_ID>
<O_ID> <R_ID> <ESTAT> <STATE> <SOCKET> <DIFINDEX> <CS> <TYPE> <SEQID> <TCNT>
<RCNT> <LO> <HI> <SSTAT> <LOGIN> ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| fc2                 | show fc2 tables and statistics  |
| exchange            | show fc2 active exchanges       |
| <i>__readonly__</i> | (Optional) Read only            |
| TABLE_ExchngInfo    | (Optional) ecb info             |
| <i>ECB_INUSE</i>    | (Optional) ecb in use           |
| <i>ECB_DROPPED</i>  | (Optional) ecb dropped          |
| <i>ECB_TOTAL</i>    | (Optional) ecb total            |
| <i>ECB_MAX</i>      | (Optional) ecb threshold        |
| TABLE_fc2exchange   | (Optional) show fc2 exchange    |
| <i>HIX</i>          | (Optional) hix                  |
| <i>VSAN</i>         | (Optional) vsan                 |
| <i>X_ID</i>         | (Optional) xid                  |
| <i>OX_ID</i>        | (Optional) oxid                 |
| <i>RX_ID</i>        | (Optional) rxid                 |
| <i>O_ID</i>         | (Optional) o_id                 |
| <i>R_ID</i>         | (Optional) r_id                 |
| <i>ESTAT</i>        | (Optional) estat                |
| <i>STATE</i>        | (Optional) state                |
| <i>SOCKET</i>       | (Optional) socket               |
| <i>DIFINDEX</i>     | (Optional) dIFINDEX             |
| <i>CS</i>           | (Optional) cs                   |
| <i>TYPE</i>         | (Optional) type                 |

|              |                  |
|--------------|------------------|
| <i>SEQID</i> | (Optional) seqid |
| <i>TCNT</i>  | (Optional) tcnt  |
| <i>RCNT</i>  | (Optional) rcnt  |
| <i>LO</i>    | (Optional) lo    |
| <i>HI</i>    | (Optional) hi    |
| <i>SSTAT</i> | (Optional) sstat |
| <i>LOGIN</i> | (Optional) login |

**Command Mode**

- /exec

# show fc2 exchresp

```
show fc2 exchresp [ __readonly__ { TABLE_fc2exchresp <HIX> <VSAN> <OX_ID> <S_ID> <CS>
<SIFINDEX> <OX_ID2> <RX_ID2> <O_ID> <R_ID> <ESTAT> <STATE> <SOCKET> <TYPE> <SEQID>
<TCNT> <RCNT> <LO> <HI> <SSTAT> } ]
```

## Syntax Description

|                   |                                     |
|-------------------|-------------------------------------|
| show              | Show running system information     |
| fc2               | show fc2 tables and statistics      |
| exchresp          | show fc2 active responder exchanges |
| __readonly__      | (Optional) Read only                |
| TABLE_fc2exchresp | (Optional) show fc2 exchresp        |
| HIX               | (Optional) hix                      |
| VSAN              | (Optional) vsan                     |
| OX_ID             | (Optional) oxid                     |
| S_ID              | (Optional) sid                      |
| CS                | (Optional) cs                       |
| SIFINDEX          | (Optional) sifindex                 |
| OX_ID2            | (Optional) oxid                     |
| RX_ID2            | (Optional) rxid                     |
| O_ID              | (Optional) oid                      |
| R_ID              | (Optional) rid                      |
| ESTAT             | (Optional) estat                    |
| STATE             | (Optional) state                    |
| SOCKET            | (Optional) socket                   |
| TYPE              | (Optional) type                     |
| SEQID             | (Optional) seqid                    |
| TCNT              | (Optional) tcnt                     |
| RCNT              | (Optional) rcnt                     |
| LO                | (Optional) lo                       |
| HI                | (Optional) hi                       |

|              |                  |
|--------------|------------------|
| <i>SSTAT</i> | (Optional) sstat |
|--------------|------------------|

**Command Mode**

- /exec

# show fc2 flogi

```
show fc2 flogi [ __readonly__ { TABLE_fc2flogi <HIX> <VSAN> <S_ID> <FLOGI> <IFINDEX> <TYPE>
} ]
```

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fc2            | show fc2 tables and statistics  |
| flogi          | show fc2 flogi table            |
| __readonly__   | (Optional) Read only            |
| TABLE_fc2flogi | (Optional) show fc2 flogi       |
| <i>HIX</i>     | (Optional) hix                  |
| <i>VSAN</i>    | (Optional) vsan                 |
| <i>S_ID</i>    | (Optional) sid                  |
| <i>FLOGI</i>   | (Optional) flogi                |
| <i>IFINDEX</i> | (Optional) ifindex              |
| <i>TYPE</i>    | (Optional) type                 |

## Command Mode

- /exec

## show fc2 nport

```
show fc2 nport [ __readonly__ { TABLE_fc2nport <REF> <VSAN> <D_ID> <MASK> <FL> <ST>
<IFINDEX> <CF> <TC> <2-SO> <IC> <RC> <RS> <CS> <EE> <3-SO> <3-SO-IC> <3-SO-RC> <3-SO-RS>
<3-SO-CS> <3-SO-EE> } ]
```

### Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fc2            | show fc2 tables and statistics  |
| nport          | show fc2 local nports           |
| __readonly__   | (Optional) Read only            |
| TABLE_fc2nport | (Optional) show fc2 nport       |
| <i>REF</i>     | (Optional) ref                  |
| <i>VSAN</i>    | (Optional) vsan                 |
| <i>D_ID</i>    | (Optional) did                  |
| <i>MASK</i>    | (Optional) mask                 |
| <i>FL</i>      | (Optional) fl                   |
| <i>ST</i>      | (Optional) st                   |
| <i>IFINDEX</i> | (Optional) ifindex              |
| <i>CF</i>      | (Optional) cf                   |
| <i>TC</i>      | (Optional) tc                   |
| <i>2-SO</i>    | (Optional) 2so                  |
| <i>IC</i>      | (Optional) ic                   |
| <i>RC</i>      | (Optional) rc                   |
| <i>RS</i>      | (Optional) rs                   |
| <i>CS</i>      | (Optional) cs                   |
| <i>EE</i>      | (Optional) ee                   |
| <i>3-SO</i>    | (Optional) 3so                  |
| <i>3-SO-IC</i> | (Optional) 3so-ic               |
| <i>3-SO-RC</i> | (Optional) 3so-rc               |
| <i>3-SO-RS</i> | (Optional) 3so-rs               |

|                |                   |
|----------------|-------------------|
| <i>3-SO-CS</i> | (Optional) 3so-cs |
| <i>3-SO-EE</i> | (Optional) 3so-ee |

**Command Mode**

- /exec



## show fc2 plogi

```
show fc2 plogi [ __readonly__ { TABLE_fc2plogi <HIX> <ADDRESS> <VSAN> <S_ID> <D_ID>
<IF_INDEX> <FL> <STATE> <CF> <TC> <2-SO> <IC> <RC> <RS> <CS> <EE> <3-SO> <3SO_IC>
<3SO_RC> <3SO_RS> <3SO_CS> <3SO_EE> <EECNT> <TCCNT> <2CNT> <3CNT> <REFCNT> } ]
```

### Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| fc2             | show fc2 tables and statistics  |
| plogi           | show fc2 plogi sessions         |
| __readonly__    | (Optional) Read only            |
| TABLE_fc2plogi  | (Optional) show fc2 plogi       |
| <i>HIX</i>      | (Optional) hix                  |
| <i>ADDRESS</i>  | (Optional) address              |
| <i>VSAN</i>     | (Optional) vsan                 |
| <i>S_ID</i>     | (Optional) sid                  |
| <i>D_ID</i>     | (Optional) did                  |
| <i>IF_INDEX</i> | (Optional) ifindex              |
| <i>FL</i>       | (Optional) fl                   |
| <i>STATE</i>    | (Optional) state                |
| <i>CF</i>       | (Optional) cf                   |
| <i>TC</i>       | (Optional) tc                   |
| <i>2-SO</i>     | (Optional) 2so                  |
| <i>IC</i>       | (Optional) ic                   |
| <i>RC</i>       | (Optional) rc                   |
| <i>RS</i>       | (Optional) rs                   |
| <i>CS</i>       | (Optional) cs                   |
| <i>EE</i>       | (Optional) ee                   |
| <i>3-SO</i>     | (Optional) 3so                  |
| <i>3SO_IC</i>   | (Optional) ic                   |
| <i>3SO_RC</i>   | (Optional) rc                   |

|               |                   |
|---------------|-------------------|
| <i>3SO_RS</i> | (Optional) rs     |
| <i>3SO_CS</i> | (Optional) cs     |
| <i>3SO_EE</i> | (Optional) ee     |
| <i>EECNT</i>  | (Optional) eecnt  |
| <i>TCCNT</i>  | (Optional) TCCNT  |
| <i>2CNT</i>   | (Optional) 2cnt   |
| <i>3CNT</i>   | (Optional) 3cnt   |
| <i>REFCNT</i> | (Optional) refcnt |

**Command Mode**

- /exec

## show fc2 plogi\_pwwn

```
show fc2 plogi_pwwn [ __readonly__ { TABLE_fc2plogi_pwwn <HIX> <ADDRESS> <VSAN> <S_ID>
<D_ID> <IFINDEX> <FL> <STATE> <PWWN> } ]
```

### Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| fc2                 | show fc2 tables and statistics  |
| plogi_pwwn          | show fc2 plogi pwwn entries     |
| __readonly__        | (Optional) Read only            |
| TABLE_fc2plogi_pwwn | (Optional) show fc2 plogi_pwwn  |
| <i>HIX</i>          | (Optional) hix                  |
| <i>ADDRESS</i>      | (Optional) address              |
| <i>VSAN</i>         | (Optional) vsan                 |
| <i>S_ID</i>         | (Optional) s_id                 |
| <i>D_ID</i>         | (Optional) d_id                 |
| <i>IFINDEX</i>      | (Optional) ifindex              |
| <i>FL</i>           | (Optional) fl                   |
| <i>STATE</i>        | (Optional) state                |
| <i>PWWN</i>         | (Optional) pwwn                 |

### Command Mode

- /exec

## show fc2 port brief

```
show fc2 port brief [ __readonly__ { TABLE_fc2portbrief <BAD_FRAME_RX> } [ TABLE_FCSTAT <IX>
<ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_LBSTAT
<IX> <ST> <MOD> <EMUL> <TXLBPCKTS> <TXLBDROP> <RXLBPCKTS> <RXLBDROP> ] [
TABLE_VFCSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS>
<RXDROP> ] [ TABLE_VFCPOSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR>
<RXPKTS> <RXDROP> ] [ TABLE_VFCslotSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS>
<TXDROP> <TXERR> <RXPKTS> <RXDROP> ] ]
```

### Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                | Show running system information   |
| fc2                 | show fc2 tables and statistics    |
| port                | show fc2 physical port table      |
| brief               | display only active port counters |
| __readonly__        | (Optional) Read only              |
| TABLE_fc2portbrief  | (Optional) bad frames received    |
| <i>BAD_FRAME_RX</i> | (Optional) fc2 bad frames rx      |
| TABLE_FCSTAT        | (Optional) FC Stat table          |
| <i>IX</i>           | (Optional) index                  |
| <i>ST</i>           | (Optional) status                 |
| <i>MOD</i>          | (Optional) mode                   |
| <i>EMUL</i>         | (Optional) TEemul                 |
| <i>TXPKTS</i>       | (Optional) txpackets              |
| <i>TXDROP</i>       | (Optional) txdrops                |
| <i>TXERR</i>        | (Optional) txerrorrent            |
| <i>RXPKTS</i>       | (Optional) rx packets             |
| <i>RXDROP</i>       | (Optional) rx drop                |
| TABLE_LBSTAT        | (Optional) LB Stat table          |
| <i>IX</i>           | (Optional) index                  |
| <i>ST</i>           | (Optional) status                 |
| <i>MOD</i>          | (Optional) mode                   |
| <i>EMUL</i>         | (Optional) TEemul                 |

|                   |                                |
|-------------------|--------------------------------|
| <i>TXLBPKTS</i>   | (Optional) tx lb packets       |
| <i>TXLBDROP</i>   | (Optional) tx lb drops         |
| <i>RXLBPKTS</i>   | (Optional) rx lb packets       |
| <i>RXLBDROP</i>   | (Optional) rx lb drop          |
| TABLE_VFCSTAT     | (Optional) VFC Stat table      |
| <i>IX</i>         | (Optional) index               |
| <i>ST</i>         | (Optional) status              |
| <i>MOD</i>        | (Optional) mode                |
| <i>EMUL</i>       | (Optional) TEemul              |
| <i>TXPKTS</i>     | (Optional) txpackets           |
| <i>TXDROP</i>     | (Optional) txdrops             |
| <i>TXERR</i>      | (Optional) txerrornt           |
| <i>RXPKTS</i>     | (Optional) rx packets          |
| <i>RXDROP</i>     | (Optional) rx drop             |
| TABLE_VFCPOSTAT   | (Optional) VFC po Stat table   |
| <i>IX</i>         | (Optional) index               |
| <i>ST</i>         | (Optional) status              |
| <i>MOD</i>        | (Optional) mode                |
| <i>EMUL</i>       | (Optional) TEemul              |
| <i>TXPKTS</i>     | (Optional) txpackets           |
| <i>TXDROP</i>     | (Optional) txdrops             |
| <i>TXERR</i>      | (Optional) txerrornt           |
| <i>RXPKTS</i>     | (Optional) rx packets          |
| <i>RXDROP</i>     | (Optional) rx drop             |
| TABLE_VFCSLOTSTAT | (Optional) VFC slot Stat table |
| <i>IX</i>         | (Optional) index               |
| <i>ST</i>         | (Optional) status              |
| <i>MOD</i>        | (Optional) mode                |
| <i>EMUL</i>       | (Optional) TEemul              |

|               |                       |
|---------------|-----------------------|
| <i>TXPKTS</i> | (Optional) txpackets  |
| <i>TXDROP</i> | (Optional) txdrops    |
| <i>TXERR</i>  | (Optional) txerrorcnt |
| <i>RXPKTS</i> | (Optional) rx packets |
| <i>RXDROP</i> | (Optional) rx drop    |

**Command Mode**

- /exec

## show fc2 port drops

```
show fc2 port drops [ __readonly__ [ TABLE_FCSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS>
<TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_LBSTAT <IX> <ST> <MOD> <EMUL>
<TXLBPCKTS> <TXLBDROP> <RXLBPCKTS> <RXLBDROP> ] [ TABLE_VFCSTAT <IX> <ST> <MOD>
<EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_VFCPOSTAT <IX>
<ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [
TABLE_VFCSLOTSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS>
<RXDROP> ] ]
```

### Syntax Description

|                  |                                   |
|------------------|-----------------------------------|
| show             | Show running system information   |
| fc2              | show fc2 tables and statistics    |
| port             | show fc2 physical port table      |
| drops            | display active port drop counters |
| __readonly__     | (Optional) Read only              |
| TABLE_FCSTAT     | (Optional) FC Stat table          |
| <i>IX</i>        | (Optional) index                  |
| <i>ST</i>        | (Optional) status                 |
| <i>MOD</i>       | (Optional) mode                   |
| <i>EMUL</i>      | (Optional) TEemul                 |
| <i>TXPKTS</i>    | (Optional) txpackets              |
| <i>TXDROP</i>    | (Optional) txdrops                |
| <i>TXERR</i>     | (Optional) txerrorcnt             |
| <i>RXPKTS</i>    | (Optional) rx packets             |
| <i>RXDROP</i>    | (Optional) rx drop                |
| TABLE_LBSTAT     | (Optional) LB Stat table          |
| <i>IX</i>        | (Optional) index                  |
| <i>ST</i>        | (Optional) status                 |
| <i>MOD</i>       | (Optional) mode                   |
| <i>EMUL</i>      | (Optional) TEemul                 |
| <i>TXLBPCKTS</i> | (Optional) tx lb packets          |
| <i>TXLBDROP</i>  | (Optional) tx lb drops            |

|                   |                                |
|-------------------|--------------------------------|
| <i>RXLBPKTS</i>   | (Optional) rx lb packets       |
| <i>RXLBDROP</i>   | (Optional) rx lb drop          |
| TABLE_VFCSTAT     | (Optional) VFC Stat table      |
| <i>IX</i>         | (Optional) index               |
| <i>ST</i>         | (Optional) status              |
| <i>MOD</i>        | (Optional) mode                |
| <i>EMUL</i>       | (Optional) TEemul              |
| <i>TXPKTS</i>     | (Optional) txpackets           |
| <i>TXDROP</i>     | (Optional) txdrops             |
| <i>TXERR</i>      | (Optional) txerrorcnt          |
| <i>RXPKTS</i>     | (Optional) rx packets          |
| <i>RXDROP</i>     | (Optional) rx drop             |
| TABLE_VFCPOSTAT   | (Optional) VFC po Stat table   |
| <i>IX</i>         | (Optional) index               |
| <i>ST</i>         | (Optional) status              |
| <i>MOD</i>        | (Optional) mode                |
| <i>EMUL</i>       | (Optional) TEemul              |
| <i>TXPKTS</i>     | (Optional) txpackets           |
| <i>TXDROP</i>     | (Optional) txdrops             |
| <i>TXERR</i>      | (Optional) txerrorcnt          |
| <i>RXPKTS</i>     | (Optional) rx packets          |
| <i>RXDROP</i>     | (Optional) rx drop             |
| TABLE_VFCSLOTSTAT | (Optional) VFC slot Stat table |
| <i>IX</i>         | (Optional) index               |
| <i>ST</i>         | (Optional) status              |
| <i>MOD</i>        | (Optional) mode                |
| <i>EMUL</i>       | (Optional) TEemul              |
| <i>TXPKTS</i>     | (Optional) txpackets           |
| <i>TXDROP</i>     | (Optional) txdrops             |



|               |                       |
|---------------|-----------------------|
| <i>TXERR</i>  | (Optional) txerrorcnt |
| <i>RXPKTS</i> | (Optional) rx packets |
| <i>RXDROP</i> | (Optional) rx drop    |

**Command Mode**

- /exec

## show fc2 port state

```
show fc2 port state [ __readonly__ [ TABLE_FCPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [
<UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME> ] + [ <DOWN_STRING>
] + [ <DOWN_TIME> ] + [ <DOWN_REFTIME> ] + ] ] ] [ TABLE_VFCPORTSTATE [ <PORT_STRING>
] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME>
] + [ <DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFTIME> ] + ] ] ] [
TABLE_VFCPOPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [
<UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME> ] + [ <DOWN_STRING> ] + [ <DOWN_TIME>
] + [ <DOWN_REFTIME> ] + ] ] ] [ TABLE_VFCPORTSLOTSTATE [ <PORT_STRING> ] [ <PORT_NO>
] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFTIME> ] + [
<DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFTIME> ] + ] ] ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information          |
| fc2                       | show fc2 tables and statistics           |
| port                      | show fc2 physical port table             |
| state                     | display port state history               |
| <i>__readonly__</i>       | (Optional) Read only                     |
| <i>TABLE_FCPORTSTATE</i>  | (Optional) fc port state change history  |
| <i>PORT_STRING</i>        | (Optional) port name                     |
| <i>PORT_NO</i>            | (Optional) port number                   |
| <i>UP_DOWN_CNTR</i>       | (Optional) up-down counter               |
| <i>UP_STRING</i>          | (Optional) up                            |
| <i>UP_TIME</i>            | (Optional) up time                       |
| <i>UP_REFTIME</i>         | (Optional) up from                       |
| <i>DOWN_STRING</i>        | (Optional) down string                   |
| <i>DOWN_TIME</i>          | (Optional) down time                     |
| <i>DOWN_REFTIME</i>       | (Optional) down from                     |
| <i>TABLE_VFCPORTSTATE</i> | (Optional) vfc port state change history |
| <i>PORT_STRING</i>        | (Optional) port name                     |
| <i>PORT_NO</i>            | (Optional) port number                   |
| <i>UP_DOWN_CNTR</i>       | (Optional) up-down counter               |
| <i>UP_STRING</i>          | (Optional) up                            |

|                        |   |
|------------------------|---|
| <i>UP_TIME</i>         | (Optional) up time                            |
| <i>UP_REFTIME</i>      | (Optional) up from                            |
| <i>DOWN_STRING</i>     | (Optional) down string                        |
| <i>DOWN_TIME</i>       | (Optional) down time                          |
| <i>DOWN_REFTIME</i>    | (Optional) down from                          |
| TABLE_VFCPOPORTSTATE   | (Optional) vfc po port state change history   |
| <i>PORT_STRING</i>     | (Optional) port name                          |
| <i>PORT_NO</i>         | (Optional) port number                        |
| <i>UP_DOWN_CNTR</i>    | (Optional) up-down counter                    |
| <i>UP_STRING</i>       | (Optional) up                                 |
| <i>UP_TIME</i>         | (Optional) up time                            |
| <i>UP_REFTIME</i>      | (Optional) up from                            |
| <i>DOWN_STRING</i>     | (Optional) down string                        |
| <i>DOWN_TIME</i>       | (Optional) down time                          |
| <i>DOWN_REFTIME</i>    | (Optional) down from                          |
| TABLE_VFCPORTSLOTSTATE | (Optional) vfc port slot state change history |
| <i>PORT_STRING</i>     | (Optional) port name                          |
| <i>PORT_NO</i>         | (Optional) port number                        |
| <i>UP_DOWN_CNTR</i>    | (Optional) up-down counter                    |
| <i>UP_STRING</i>       | (Optional) up                                 |
| <i>UP_TIME</i>         | (Optional) up time                            |
| <i>UP_REFTIME</i>      | (Optional) up from                            |
| <i>DOWN_STRING</i>     | (Optional) down string                        |
| <i>DOWN_TIME</i>       | (Optional) down time                          |
| <i>DOWN_REFTIME</i>    | (Optional) down from                          |

**Command Mode**

- /exec

# show fc2 socket

```
show fc2 socket [ __readonly__ { TABLE_fc2socket <SOCKET> <REFCNT> <PROTOCOL> <FLAGS>
<PID> <RCVBUF> <RMEM_USED> <QLEN> <NOTSK> } ]
```

## Syntax Description

|                  |                                 |
|------------------|---------------------------------|
| show             | Show running system information |
| fc2              | show fc2 tables and statistics  |
| socket           | show fc2 active sockets         |
| __readonly__     | (Optional) Read only            |
| TABLE_fc2socket  | (Optional) show fc2 socket      |
| <i>SOCKET</i>    | (Optional) socket               |
| <i>REFCNT</i>    | (Optional) refcnt               |
| <i>PROTOCOL</i>  | (Optional) protocol             |
| <i>FLAGS</i>     | (Optional) flags                |
| <i>PID</i>       | (Optional) pid                  |
| <i>RCVBUF</i>    | (Optional) rcvbuf               |
| <i>RMEM_USED</i> | (Optional) rmem_used            |
| <i>QLEN</i>      | (Optional) qlen                 |
| <i>NOTSK</i>     | (Optional) not_sk               |

## Command Mode

- /exec

## show fc2 sockexch

```
show fc2 sockexch [ __readonly__ { TABLE_fc2sockexch <SOCKET> <VSAN> <X_ID> <OX_ID>
<RX_ID> <O_ID> <R_ID> <ESTAT> <STATE> <CS> <TYPE> <SK> } ]
```

### Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information           |
| fc2               | show fc2 tables and statistics            |
| sockexch          | show fc2 active exchanges for each socket |
| __readonly__      | (Optional) Read only                      |
| TABLE_fc2sockexch | (Optional) show fc2 sockexch              |
| SOCKET            | (Optional) socket                         |
| VSAN              | (Optional) vsan                           |
| X_ID              | (Optional) x_id                           |
| OX_ID             | (Optional) oxid                           |
| RX_ID             | (Optional) rxid                           |
| O_ID              | (Optional) o_id                           |
| R_ID              | (Optional) r_id                           |
| ESTAT             | (Optional) estat                          |
| STATE             | (Optional) state                          |
| CS                | (Optional) cs                             |
| TYPE              | (Optional) type                           |
| SK                | (Optional) sk                             |

### Command Mode

- /exec

## show fc2 socknotify

```
show fc2 socknotify [ __readonly__ { TABLE_fc2socknotify <SOCKET> <ADDRESS> <REF> <VSAN>
<D_ID> <MASK> <FL> <ST> <IFINDEX> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                               |
| fc2                 | show fc2 tables and statistics                                |
| socknotify          | show fc2 local nport plogi/logo notifications per each socket |
| __readonly__        | (Optional) Read only  |
| TABLE_fc2socknotify | (Optional) show fc2 socknotify                                |
| SOCKET              | (Optional) socket   |
| ADDRESS             | (Optional) address  |
| REF                 | (Optional) ref  |
| VSAN                | (Optional) vsan   |
| D_ID                | (Optional) d_id   |
| MASK                | (Optional) mask   |
| FL                  | (Optional) fl   |
| ST                  | (Optional) st   |
| IFINDEX             | (Optional) ifindex  |

### Command Mode

- /exec

# show fc2 socknport

```
show fc2 socknport [ __readonly__ { TABLE_fc2socknport <SOCKET> <ADDRESS> <REF> <VSAN>
<D_ID> <MASK> <FL> <ST> <IFINDEX> } ]
```

## Syntax Description

|                    |                                       |
|--------------------|---------------------------------------|
| show               | Show running system information       |
| fc2                | show fc2 tables and statistics        |
| socknport          | show fc2 local nports per each socket |
| __readonly__       | (Optional) Read only                  |
| TABLE_fc2socknport | (Optional) show fc2 socknport         |
| <i>SOCKET</i>      | (Optional) socket                     |
| <i>ADDRESS</i>     | (Optional) address                    |
| <i>REF</i>         | (Optional) ref                        |
| <i>VSAN</i>        | (Optional) vsan                       |
| <i>D_ID</i>        | (Optional) d_id                       |
| <i>MASK</i>        | (Optional) mask                       |
| <i>FL</i>          | (Optional) fl                         |
| <i>ST</i>          | (Optional) st                         |
| <i>IFINDEX</i>     | (Optional) ifindex                    |

## Command Mode

- /exec

## show fc2 vsan

```
show fc2 vsan [ __readonly__ { TABLE_fc2vsan <VSAN> <X_ID> <E_D_TOV> <R_A_TOV> <WWN>
<IOP_MODE> } ]
```

### Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| fc2           | show fc2 tables and statistics  |
| vsan          | show fc2 vsan table             |
| __readonly__  | (Optional) Read only            |
| TABLE_fc2vsan | (Optional) show fc2 vsan        |
| VSAN          | (Optional) vsan                 |
| X_ID          | (Optional) xid                  |
| E_D_TOV       | (Optional) e_d_tov              |
| R_A_TOV       | (Optional) r_a_tov              |
| WWN           | (Optional) wwn                  |
| IOP_MODE      | (Optional) iop_mode             |

### Command Mode

- /exec



# show fcalias

```
show fcalias [ [ name <s0> ] [ [ pending ] [ vsan <i0> ] ] ]
```

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                           |
| fcalias   | Fcalias show commands                                     |
| name      | (Optional) Show members of a specified fcalias            |
| <i>s0</i> | (Optional) Enter the name of fcalias                      |
| pending   | (Optional) Show members of a specified fcalias in session |
| vsan      | (Optional) Show aliases belonging to the specified VSAN   |
| <i>i0</i> | (Optional) VSAN id range                                  |

## Command Mode

- /exec

# show fcdomain

show fcdomain

## Syntax Description

|          |                                 |
|----------|---------------------------------|
| show     | Show running system information |
| fcdomain | Show fcdomain information       |

## Command Mode

- /exec

# show fcdomain address-allocation

```
show fcdomain address-allocation [ { cache | vsan <i0> } ]
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                       |
| fcdomain           | Show fcdomain information                             |
| address-allocation | Show statistics for the fcid allocation               |
| cache              | (Optional) Show cache content for the fcid allocation |
| vsan               | (Optional) Specify the vsan id                        |
| <i>i0</i>          | (Optional) VSAN id                                    |

## Command Mode

- /exec

# show fcdomain allowed

show fcdomain allowed [ vsan <i0> ]

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| fcdomain  | Show fcdomain information       |
| allowed   | Show list of allowed domain IDs |
| vsan      | (Optional) Specify the vsan id  |
| <i>i0</i> | (Optional) VSAN id              |

## Command Mode

- /exec

# show fcdomain domain-list

```
show fcdomain domain-list [ vsan <i0> ]
```

## Syntax Description

|             |   |
|-------------|---|
| show        | Show running system information                     |
| fcdomain    | Show fcdomain information                           |
| domain-list | Show list of domain IDs granted by the principal sw |
| vsan        | (Optional) Specify the vsan id                      |
| <i>i0</i>   | (Optional) VSAN id                                  |

## Command Mode

- /exec

# show fcdomain fcid persistent

```
show fcdomain fcid persistent [ { unused [ vsan <i0> ] | vsan1 <i1> } ]
```

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                         |
| fcdomain   | Show fcdomain information                               |
| fcid       | Show persistent FCIDs (across reboot)                   |
| persistent | Show persistent FCIDs (across reboot)                   |
| unused     | (Optional) Show unused persistent FCIDs (across reboot) |
| vsan       | (Optional) Specify the vsan id                          |
| <i>i0</i>  | (Optional) VSAN id                                      |
| vsan1      | (Optional) Specify the vsan id                          |
| <i>i1</i>  | (Optional) VSAN id                                      |

## Command Mode

- /exec

# show fcdomain pending-diff

```
show fcdomain pending-diff [ vsan <i0> ]
```

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                               |
| fcdomain     | Show fcdomain information                                     |
| pending-diff | Show the difference between running and pending configuration |
| vsan         | (Optional) Specify the vsan id                                |
| <i>i0</i>    | (Optional) VSAN id  |

## Command Mode

- /exec

# show fcdomain pending

show fcdomain pending [ vsan <i0> ]

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| fcdomain  | Show fcdomain information       |
| pending   | Show the pending configuration  |
| vsan      | (Optional) Specify the vsan id  |
| <i>i0</i> | (Optional) VSAN id              |

## Command Mode

- /exec



# show fcdomain session-status

show fcdomain session-status [ vsan <i0> ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information            |
| fcdomain       | Show fcdomain information                  |
| session-status | Show the last action performed by fcdomain |
| vsan           | (Optional) Specify the vsan id             |
| <i>i0</i>      | (Optional) VSAN id                         |

## Command Mode

- /exec

## show fcdomain statistics

show fcdomain statistics [ { interface <i>i0</i> [ vsan <i>i0</i> ] | vsan1 <i>i1</i> } ]

### Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                |
| fcdomain   | Show fcdomain information                      |
| statistics | Show the statistics of fcdomain                |
| interface  | (Optional) Specify the fibre channel interface |
| <i>i0</i>  | (Optional)                                     |
| vsan       | (Optional) Specify the vsan id                 |
| <i>i0</i>  | (Optional) VSAN id                             |
| vsan1      | (Optional) Specify the vsan id                 |
| <i>i1</i>  | (Optional) VSAN id                             |

### Command Mode

- /exec

# show fcdomain status

show fcdomain status

## Syntax Description

|          |   |
|----------|---|
| show     | Show running system information                   |
| fcdomain | Show fcdomain information                         |
| status   | Show all vsan-independent information in fcdomain |

## Command Mode

- /exec

# show fcdomain vsan

show fcdomain vsan <i0>

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| fcdomain  | Show fcdomain information       |
| vsan      | Specify the vsan id             |
| <i>i0</i> | VSAN id                         |

## Command Mode

- /exec

# show fcdroplateny

```
show fcdroplateny [ { network | switch } ] [ __readonly__ [ <switch_latency> ] [ <global_network_latency> ] ] [ TABLE_vsan_network_latency { <vsan-no> <network-latency> } ] ]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information                   |
| fcdroplateny                  | show switch or network latency                    |
| network                       | (Optional) network latency in milliseconds        |
| switch                        | (Optional) switch latency in milliseconds         |
| __readonly__                  | (Optional)  |
| <i>switch_latency</i>         | (Optional) Switch latency value                   |
| <i>global_network_latency</i> | (Optional) global network latency value           |
| TABLE_vsan_network_latency    | (Optional) VSAN specific network latency settings |
| <i>vsan-no</i>                | (Optional) vsan number                            |
| <i>network-latency</i>        | (Optional) VSAN specific network latency          |

## Command Mode

- /exec

# show fcid-allocation area

show fcid-allocation area

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information             |
| fcid-allocation | Show information about fcid-allocation list |
| area            | Show information about fcid-allocation list |

## Command Mode

- /exec

# show fcid-allocation company-id-from-wwn

show fcid-allocation company-id-from-wwn <wwn0>

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information             |
| fcid-allocation     | Show information about fcid-allocation list |
| company-id-from-wwn | Company id (or OUI).                        |
| <i>wwn0</i>         | Enter WWN to extract company_id/oui         |

## Command Mode

- /exec

## show fcns database

```
show fcns database [ { detail [ vsan <i0> ] | domain <i1> [ { detail [ vsan1 <i2> ] | vsan2 <i3> } ] | fcid <fcid4>
{ detail2 vsan3 <i5> | vsan4 <i6> } | local [ { detail1 [ vsan5 <i7> ] | vsan6 <i8> } ] | npv [ { detail1 [ vsan7
<i9> ] | node_wwn <wwn10> [ vsan8 <i11> ] | vsan9 <i12> } ] | proxy-host { detail4 vsan10 <i13> | vsan11
<i14> } | vsan12 <i15> } ]
```

### Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                            |
| fcns         | show name server tables                                    |
| database     | show name server database                                  |
| detail       | (Optional) show all objects in each entry                  |
| vsan         | (Optional) show local entries for the given vsan(s)        |
| <i>i0</i>    | (Optional) VSAN id range                                   |
| domain       | (Optional) show entries in a domain                        |
| <i>i1</i>    | (Optional) domain-id                                       |
| detail       | (Optional) show all objects in each entry                  |
| vsan1        | (Optional) show entries for a domain for the given vsan(s) |
| <i>i2</i>    | (Optional) VSAN id range                                   |
| vsan2        | (Optional) show entries for a domain for the given vsan(s) |
| <i>i3</i>    | (Optional) VSAN id range                                   |
| fcid         | (Optional) show entry for the given port                   |
| <i>fcid4</i> | (Optional) enter FCID                                      |
| detail2      | (Optional) show all objects in the entry                   |
| vsan3        | (Optional) show port entry for the given vsan              |
| <i>i5</i>    | (Optional) VSAN id   |
| vsan4        | (Optional) show port entry for the given vsan              |
| <i>i6</i>    | (Optional) VSAN id   |
| local        | (Optional) show local entries                              |
| detail1      | (Optional) show all objects in each entry                  |
| vsan5        | (Optional) show local entries for the given vsan(s)        |



|                   |   |
|-------------------|---|
| <i>i7</i>         | (Optional) VSAN id range                              |
| <i>vsan6</i>      | (Optional) show local entries for the given vsan(s)   |
| <i>i8</i>         | (Optional) VSAN id range                              |
| <i>npv</i>        | (Optional) show n-port virtualization (npv) entries   |
| <i>detail1</i>    | (Optional) show all objects in each entry             |
| <i>vsan7</i>      | (Optional) show npv entries for the given vsan(s)     |
| <i>i9</i>         | (Optional) VSAN id range                              |
| <i>node_wwn</i>   | (Optional) show end-devices logged in via an npv node |
| <i>wwn10</i>      | (Optional) Node WWN of NPV                            |
| <i>vsan8</i>      | (Optional) show npv entries for the given vsan(s)     |
| <i>i11</i>        | (Optional) VSAN id range                              |
| <i>vsan9</i>      | (Optional) show npv entries for the given vsan(s)     |
| <i>i12</i>        | (Optional) VSAN id range                              |
| <i>proxy-host</i> | (Optional) show entry for the proxy-host              |
| <i>detail4</i>    | (Optional) show all objects in the entry              |
| <i>vsan10</i>     | (Optional) show port entry for the given vsan         |
| <i>i13</i>        | (Optional) VSAN id                                    |
| <i>vsan11</i>     | (Optional) show port entry for the given vsan         |
| <i>i14</i>        | (Optional) VSAN id                                    |
| <i>vsan12</i>     | (Optional) show entries for the given vsan(s)         |
| <i>i15</i>        | (Optional) VSAN id range                              |

**Command Mode**

- /exec

# show fcns statistics

show fcns statistics [ { detail [ vsan <i0> ] | vsan1 <i1> } ]

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                     |
| fcns       | show name server tables                             |
| statistics | show name server statistics                         |
| detail     | (Optional) show detailed statistics                 |
| vsan       | (Optional) show detailed statistics for the vsan(s) |
| <i>i0</i>  | (Optional) VSAN id range                            |
| vsan1      | (Optional) show statistics for the vsan(s)          |
| <i>i1</i>  | (Optional) VSAN id range                            |

## Command Mode

- /exec

## show fcoe-npv issu-impact

```
show fcoe-npv issu-impact [ __readonly__ { <is_impact> } [ TABLE_interface <vfc_intf> <fc_id> ] ]
```

### Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information   |
| fcoe-npv         | feature fcoe-npv  |
| issu-impact      | Show feature fcoe-npv config issues if attempting to do non-disruptive ISSU |
| __readonly__     | (Optional) Read Only  |
| <i>is_impact</i> | (Optional) show issu impact   |
| TABLE_interface  | (Optional) show fcoe database   |
| <i>vfc_intf</i>  | (Optional) vfc port Interface index   |
| <i>fc_id</i>     | (Optional) vfc port FCID  |

### Command Mode

- /exec

# show fcoe

```
show fcoe [ __readonly__ { TABLE_fcf <fcf_if_index> <fcf_mac> <fc_map> <fcf_priority>
<fka_Advertisement> } [ TABLE_vfc <vfc_name> <vfcf_mac> ] ]
```

## Syntax Description

|                          |                                      |
|--------------------------|--------------------------------------|
| show                     | Show running system information      |
| fcoe                     | Show FCOE paramaters                 |
| __readonly__             | (Optional) Read Only                 |
| TABLE_fcf                | (Optional) fcf table                 |
| <i>fcf_if_index</i>      | (Optional) fcf if index              |
| <i>fcf_mac</i>           | (Optional) fcf mac                   |
| <i>fc_map</i>            | (Optional) fc map                    |
| <i>fcf_priority</i>      | (Optional) fcf priority              |
| <i>fka_Advertisement</i> | (Optional) fka Advertisement         |
| TABLE_vfc                | (Optional) vfc details table for sup |
| <i>vfc_name</i>          | (Optional) vfc name                  |
| <i>vfcf_mac</i>          | (Optional) vfcf mac                  |

## Command Mode

- /exec

# show fcoe database

```
show fcoe database [ __readonly__ { TABLE_interface <interface> [ <fcid> ] [ <port_name> ] <mac_address>
} <flogi_count> [ TABLE_veport <interface> <mac_address> <vsan> ] ]
```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| fcoe                | Show FCOE paramaters               |
| database            | Show FCOE database                 |
| <i>__readonly__</i> | (Optional) Read Only               |
| <i>interface</i>    | (Optional) Interface index         |
| TABLE_interface     | (Optional) show fcoe database      |
| <i>fcid</i>         | (Optional) fcid                    |
| <i>port_name</i>    | (Optional) port name               |
| <i>mac_address</i>  | (Optional) mac address             |
| <i>interface</i>    | (Optional) ve port Interface index |
| TABLE_veport        | (Optional) ve port details         |
| <i>mac_address</i>  | (Optional) ve port mac address     |
| <i>flogi_count</i>  | (Optional) flogi_count             |
| <i>vsan</i>         | (Optional) ve port VSAN trunking   |

## Command Mode

- /exec

# show fcs database

show fcs database [ vsan <i0> ]

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information           |
| database  | Show local database of FCS                |
| vsan      | (Optional) Show local database for a VSAN |
| <i>i0</i> | (Optional) VSAN range                     |

## Command Mode

- /exec

# show fcs ie

```
show fcs ie [ { nwwn <wwn0> vsan <i1> | vsan1 <i2> } ]
```

## Syntax Description

|             |   |
|-------------|---|
| show        | Show running system information               |
| ie          | Show Interconnect Element Objects Information |
| nwwn        | (Optional) IE WWN                             |
| <i>wwn0</i> | (Optional) IE WWN                             |
| vsan        | (Optional) VSAN id of IE                      |
| <i>i1</i>   | (Optional) VSAN id                            |
| vsan1       | (Optional) VSAN id of IE                      |
| <i>i2</i>   | (Optional) VSAN range                         |

## Command Mode

- /exec

# show fcs platform

show fcs platform { name <s0> vsan <i0> | vsan1 <i1> }

## Syntax Description

|           |                                   |
|-----------|-----------------------------------|
| show      | Show running system information   |
| platform  | Show Platform Objects Information |
| name      | Platform Name                     |
| <i>s0</i> | Platform name string              |
| vsan      | VSAN id of the platform           |
| <i>i0</i> | VSAN id                           |
| vsan1     | VSAN id of the platform           |
| <i>i1</i> | VSAN range                        |

## Command Mode

- /exec



# show fcs port

```
show fcs port { pwwn <wwn0> vsan <i1> | vsan1 <i2> }
```

## Syntax Description

|             |                                 |
|-------------|---------------------------------|
| show        | Show running system information |
| port        | Show Port Objects Information   |
| pwwn        | Port WWN                        |
| <i>wwn0</i> | Port WWN                        |
| vsan        | VSAN id of the port             |
| <i>i1</i>   | VSAN id                         |
| vsan1       | VSAN id of the port             |
| <i>i2</i>   | VSAN range                      |

## Command Mode

- /exec

# show fcs statistics

show fcs statistics [ vsan <i0> ]

## Syntax Description

|            |                                       |
|------------|---------------------------------------|
| show       | Show running system information       |
| statistics | Show statistics for FCS packets.      |
| vsan       | (Optional) Show statistics for a VSAN |
| <i>i0</i>  | (Optional) VSAN range                 |

## Command Mode

- /exec

# show fcs vsan

show fcs vsan

## Syntax Description

|      |   |
|------|---|
| show | Show running system information                         |
| vsan | Show list of all the VSANs and plat-check-mode for each |

## Command Mode

- /exec

# show fctimer

```
show fctimer [ __readonly__ { <F_S_TOV> <D_S_TOV> <E_D_TOV> <R_A_TOV> } ]
```

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show running system information |
| fctimer        | show Fibre Channel timers       |
| __readonly__   | (Optional) Read only            |
| <i>F_S_TOV</i> | (Optional) F_S_TOV              |
| <i>D_S_TOV</i> | (Optional) D_S_TOV              |
| <i>E_D_TOV</i> | (Optional) E_D_TOV              |
| <i>R_A_TOV</i> | (Optional) R_A_TOV              |

## Command Mode

- /exec

## show fctimer D\_S\_TOV

```
show fctimer D_S_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_D_S_TOV [ <vsan-no> ] <D_S_TOV> ] [ <non-exist-vcn> ] ]
```

### Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| fctimer              | show Fibre Channel timers       |
| D_S_TOV              | D_S_TOV in milliseconds         |
| vsan                 | (Optional) Specify VSAN id      |
| <i>i0</i>            | (Optional) VSAN id range        |
| <i>__readonly__</i>  | (Optional)                      |
| TABLE_D_S_TOV        | (Optional) table D_S_TOV        |
| <i>vsan-no</i>       | (Optional) vsan number          |
| <i>D_S_TOV</i>       | (Optional) D_S_TOV              |
| <i>non-exist-vcn</i> | (Optional) non configured vsans |

### Command Mode

- /exec

## show fctimer E\_D\_TOV

```
show fctimer E_D_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_E_D_TOV [ <vsan-no> ] <E_D_TOV> ] [ <non-exist-vsan> ] ]
```

### Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| fctimer        | show Fibre Channel timers       |
| E_D_TOV        | E_D_TOV in milliseconds         |
| vsan           | (Optional) Specify VSAN id      |
| i0             | (Optional) VSAN id range        |
| __readonly__   | (Optional)                      |
| TABLE_E_D_TOV  | (Optional) table                |
| vsan-no        | (Optional) vsan number          |
| E_D_TOV        | (Optional) E_D_TOV              |
| non-exist-vsan | (Optional) not exist vsans      |

### Command Mode

- /exec

## show fctimer F\_S\_TOV

```
show fctimer F_S_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_F_S_TOV [ <vsan-no> ] <F_S_TOV> ] [ <non-exist-nsan> ] ]
```

### Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| fctimer               | show Fibre Channel timers       |
| F_S_TOV               | F_S_TOV in milliseconds         |
| vsan                  | (Optional) Specify VSAN id      |
| <i>i0</i>             | (Optional) VSAN id range        |
| <i>__readonly__</i>   | (Optional)                      |
| TABLE_F_S_TOV         | (Optional) table                |
| <i>vsan-no</i>        | (Optional) vsan number          |
| <i>F_S_TOV</i>        | (Optional) F_S_TOV              |
| <i>non-exist-nsan</i> | (Optional) not exist vsans      |

### Command Mode

- /exec

## show fctimer R\_A\_TOV

```
show fctimer R_A_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_R_A_TOV [ <vsan-no> ] <R_A_TOV> ] [ <non-exist-vsan> ] ]
```

### Syntax Description

|                              |                                 |
|------------------------------|---------------------------------|
| show                         | Show running system information |
| fctimer                      | show Fibre Channel timers       |
| R_A_TOV                      | R_A_TOV in milliseconds         |
| vsan                         | (Optional) Specify VSAN id      |
| <i>i0</i>                    | (Optional) VSAN id range        |
| __readonly__                 | (Optional)                      |
| TABLE_R_A_TOV                | (Optional) table                |
| <i>vsan-no</i>               | (Optional) vsan number          |
| <i>R_A_TOV</i>               | (Optional) R_A_TOV              |
| <i>non-exist-<i>vsan</i></i> | (Optional) non exist vsans      |

### Command Mode

- /exec



## show fctimer last action status

```
show fctimer last action status [ __readonly__ [ <vsan> ] <last_action_timestamp> <last_action>
<last_action_result> <last_action_failure_reason> ]
```

### Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                        |
| fctimer                           | show Fibre Channel timers                              |
| last                              | Show the status of the last cfs commit/abort operation |
| action                            | Show the status of the last cfs commit/abort operation |
| status                            | Show the status of the last cfs commit/abort operation |
| <i>__readonly__</i>               | (Optional) Readonly                                    |
| <i>vsan</i>                       | (Optional) Vsan  |
| <i>last_action_timestamp</i>      | (Optional) Last action timestamp                       |
| <i>last_action</i>                | (Optional) Last action                                 |
| <i>last_action_result</i>         | (Optional) Last action result                          |
| <i>last_action_failure_reason</i> | (Optional) Last action failure reason                  |

### Command Mode

- /exec

## show fctimer pending-diff

show fctimer pending-diff [ \_\_readonly\_\_ <status\_fctimer> ]

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information  |
| fctimer               | show Fibre Channel timers  |
| pending-diff          | Show the difference between pending database and running config            |
| __readonly__          | (Optional)   |
| <i>status_fctimer</i> | (Optional) Show the difference between pending database and running config |

### Command Mode

- /exec

# show fctimer pending

show fctimer pending [ \_\_readonly\_\_ <status\_fctimer> ]

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| fctimer               | show Fibre Channel timers                              |
| pending               | Show the status of pending fctimer commands            |
| __readonly__          | (Optional)   |
| <i>status_fctimer</i> | (Optional) Show the status of pending fctimer commands |

## Command Mode

- /exec

## show fctimer session status

show fctimer session status [ *\_\_readonly\_\_* [ *<vsan>* ] *<last\_action\_timestamp>* *<last\_action>*  
*<last\_action\_result>* *<last\_action\_failure\_reason>* ]

### Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                        |
| fctimer                           | show Fibre Channel timers                              |
| session                           | Show the state of fctimer cfs session                  |
| status                            | Show the status of the last cfs commit/abort operation |
| <i>__readonly__</i>               | (Optional) Readonly                                    |
| <i>vsan</i>                       | (Optional) Vsan  |
| <i>last_action_timestamp</i>      | (Optional) Last action timestamp                       |
| <i>last_action</i>                | (Optional) Last action                                 |
| <i>last_action_result</i>         | (Optional) Last action result                          |
| <i>last_action_failure_reason</i> | (Optional) Last action failure reason                  |

### Command Mode

- /exec

# show fctimer status

show fctimer status [ \_\_readonly\_\_ <Distribution> ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information         |
| fctimer             | show Fibre Channel timers               |
| status              | cfs distribution is enabled or disabled |
| __readonly__        | (Optional) read only                    |
| <i>Distribution</i> | (Optional) distribution                 |

## Command Mode

- /exec

## show fctimer vsan

```
show fctimer vsan <i0> [ __readonly__ { TABLE_fctimer <vsan-no> <F_S_TOV> <D_S_TOV> <E_D_TOV>
<R_A_TOV> } [ <non-exist-vsan> ] ]
```

### Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| fctimer               | show Fibre Channel timers       |
| vsan                  | Specify VSAN id                 |
| <i>i0</i>             | VSAN id range                   |
| <i>__readonly__</i>   | (Optional) Read only            |
| <i>TABLE_fctimer</i>  | (Optional) table                |
| <i>vsan-no</i>        | (Optional) vsan number          |
| <i>F_S_TOV</i>        | (Optional) F_S_TOV              |
| <i>D_S_TOV</i>        | (Optional) D_S_TOV              |
| <i>E_D_TOV</i>        | (Optional) E_D_TOV              |
| <i>R_A_TOV</i>        | (Optional) R_A_TOV              |
| <i>non-exist-vsan</i> | (Optional) non exist vsans      |

### Command Mode

- /exec

# show fdmi database

show fdmi database

## Syntax Description

|          |                                 |
|----------|---------------------------------|
| show     | Show running system information |
| fdmi     | Show fdmi information           |
| database | show fdmi database              |

## Command Mode

- /exec

# show fdmi database detail

show fdmi database detail

## Syntax Description

|          |                                 |
|----------|---------------------------------|
| show     | Show running system information |
| fdmi     | Show fdmi information           |
| database | show fdmi database              |
| detail   | show all objects in each entry  |

## Command Mode

- /exec



# show fdmi database detail hba-id vsan

show fdmi database detail hba-id <wwn0> vsan <i1>

## Syntax Description

|             |                                   |
|-------------|-----------------------------------|
| show        | Show running system information   |
| fdmi        | Show fdmi information             |
| database    | show fdmi database                |
| detail      | show all objects in each entry    |
| hba-id      | show entries for the given HBA id |
| <i>wwn0</i> | HBA id                            |
| vsan        | show HBA id the given vsan        |
| <i>i1</i>   | VSAN id                           |

## Command Mode

- /exec

## show fdmi database detail vsan

show fdmi database detail vsan <i0>

### Syntax Description

|           |                                    |
|-----------|------------------------------------|
| show      | Show running system information    |
| fdmi      | Show fdmi information              |
| database  | show fdmi database                 |
| detail    | show all objects in each entry     |
| vsan      | show entries for the given vsan(s) |
| <i>i0</i> | VSAN id range                      |

### Command Mode

- /exec

# show fdmi database vsan

show fdmi database vsan <i0>

## Syntax Description

|           |                                    |
|-----------|------------------------------------|
| show      | Show running system information    |
| fdmi      | Show fdmi information              |
| database  | show fdmi database                 |
| vsan      | show entries for the given vsan(s) |
| <i>i0</i> | VSAN id range                      |

## Command Mode

- /exec

# show fdmi suppress-updates

show fdmi suppress-updates

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information            |
| fdmi             | Show fdmi information                      |
| suppress-updates | Show vsans on which updates are suppressed |

## Command Mode

- /exec

## show feature-set

```
show feature-set [ <name> ] [ <id> ] [ __readonly__ TABLE_cfcFeatureSetTable <cfcFeatureSetIndex>
<cfcFeatureSetName> <cfcFeatureSetAction> <cfcFeatureSetLastAction> <cfcFeatureSetLastActionResult>
<cfcFeatureSetLastFailureReason> <cfcFeatureSetOpStatus> <cfcFeatureSetOpStatusReason> ]
```

### Syntax Description

|                                       |                                    |
|---------------------------------------|------------------------------------|
| show                                  | Show running system information    |
| feature-set                           | Show feature set status            |
| <i>name</i>                           | (Optional) feature-set name        |
| <i>id</i>                             | (Optional) feature-set id          |
| <i>__readonly__</i>                   | (Optional)                         |
| <i>TABLE_cfcFeatureSetTable</i>       | (Optional) feature-set table       |
| <i>cfcFeatureSetIndex</i>             | (Optional) feature-set table index |
| <i>cfcFeatureSetName</i>              | (Optional) feature-set name        |
| <i>cfcFeatureSetAction</i>            | (Optional) action                  |
| <i>cfcFeatureSetLastAction</i>        | (Optional) last action             |
| <i>cfcFeatureSetLastActionResult</i>  | (Optional) last action result      |
| <i>cfcFeatureSetLastFailureReason</i> | (Optional) last failure reason     |
| <i>cfcFeatureSetOpStatus</i>          | (Optional) operation status        |
| <i>cfcFeatureSetOpStatusReason</i>    | (Optional) operation status        |

### Command Mode

- /exec

# show feature-set services

```
show feature-set services <s0> [ __readonly__ [ { TABLE_services <service_name> } ] { <count>
<feature_set> } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| feature-set         | Show feature set status                          |
| services            | Show services in feature set                     |
| __readonly__        | (Optional)                                       |
| TABLE_services      | (Optional) all service names in feature set      |
| <i>service_name</i> | (Optional) name of the service                   |
| <i>count</i>        | (Optional) number of services in the feature set |
| <i>feature_set</i>  | (Optional) feature set name                      |
| <i>s0</i>           | Name of feature set                              |

## Command Mode

- /exec

# show feature

```
show feature [ __readonly__ [ { TABLE_cfcFeatureCtrlTable <cfcFeatureCtrlIndex2>
<cfcFeatureCtrlInstanceNum2> <cfcFeatureCtrlName2> <cfcFeatureCtrlAction2> <cfcFeatureCtrlLastAction2>
<cfcFeatureCtrlLastActionResult2> <cfcFeatureCtrlLastFailureReason2> <cfcFeatureCtrlOpStatus2>
<cfcFeatureCtrlOpStatusReason2> <cfcFeatureCtrlTag2> } ] ]
```

## Syntax Description

|   |  |
|---|--|
| show                                    | Show running system information  |
| feature                                 | Show feature status  |
| __readonly__                            | (Optional)   |
| TABLE_cfcFeatureCtrlTable               | (Optional) feature table   |
| <i>cfcFeatureCtrlIndex2</i>             | (Optional) feature table index   |
| <i>cfcFeatureCtrlInstanceNum2</i>       | (Optional) instance number   |
| <i>cfcFeatureCtrlName2</i>              | (Optional) feature name  |
| <i>cfcFeatureCtrlAction2</i>            | (Optional) Action to be triggered for the feature                                |
| <i>cfcFeatureCtrlLastAction2</i>        | (Optional) Last action triggered for the feature                                 |
| <i>cfcFeatureCtrlLastActionResult2</i>  | (Optional) The result of execution of the last action                            |
| <i>cfcFeatureCtrlLastFailureReason2</i> | (Optional) Failure Reason  |
| <i>cfcFeatureCtrlOpStatus2</i>          | (Optional) operation status  |
| <i>cfcFeatureCtrlOpStatusReason2</i>    | (Optional) Reason for current operation status                                   |
| <i>cfcFeatureCtrlTag2</i>               | (Optional) Name of the instance in string format in case of multinstance feature |

## Command Mode

- /exec

# show fhrp

```
show fhrp [ <intf> ] [ __readonly__ { TABLE_brief <intf_name> <intf_state> <ipv4_state> <ipv6_state>
<hardware_status> <refcount> } ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| fhrp                   | FHRP Show commands                               |
| show                   | Show running system information                  |
| <i>intf</i>            | (Optional) Specify a single interface            |
| <i>__readonly__</i>    | (Optional)                                       |
| TABLE_brief            | (Optional) Show brief FHRP interface information |
| <i>intf_name</i>       | (Optional) Interface name                        |
| <i>intf_state</i>      | (Optional) Interface state                       |
| <i>ipv4_state</i>      | (Optional) Interface IPv4 state                  |
| <i>ipv6_state</i>      | (Optional) Interface IPv6 state                  |
| <i>hardware_status</i> | (Optional) Interface hardware status             |
| <i>refcount</i>        | (Optional) Interface refcount                    |

## Command Mode

- /exec



## show fhrp verbose

```
show fhrp [ <intf> ] verbose [ __readonly__ { TABLE_det <intf_name> <handle> <refcount> { TABLE_clients
<client_id> <client_name> } <running> <expired> <v_retries> <v_time> <r_delay> <min_delay>
<remaining_delay> <i_state> <ipv4_state> <ipv6_state> <h_state> <int_l2> } ]
```

### Syntax Description

|                 |  |
|-----------------|--|
| fhrp            | FHRP Show commands                             |
| show            | Show running system information                |
| intf            | (Optional) Specify a single interface          |
| verbose         | Display detailed information                   |
| __readonly__    | (Optional)                                     |
| TABLE_det       | (Optional) Detailed FHRP interface information |
| intf_name       | (Optional) Interface name                      |
| handle          | (Optional) Interface handle                    |
| refcount        | (Optional) Reference count                     |
| TABLE_clients   | (Optional) FHRP clients present on interface   |
| client_id       | (Optional) FHRP client id                      |
| client_name     | (Optional) FHRP client name                    |
| running         | (Optional) Time verify up timer running        |
| expired         | (Optional) Verify up timer has expired         |
| v_retries       | (Optional) Verify retries                      |
| v_time          | (Optional) Verify remaining time               |
| r_delay         | (Optional) Reload delay                        |
| min_delay       | (Optional) Min delay                           |
| remaining_delay | (Optional) Remaining delay                     |
| i_state         | (Optional) Interface state                     |
| ipv4_state      | (Optional) Interface IPv4 state                |
| ipv6_state      | (Optional) Interface IPv6 state                |
| h_state         | (Optional) Interface hardware state            |
| int_l2          | (Optional) Interface is L2-only                |

**Command Mode**

- /exec

# show file

```
show file <uri0> [ cksum | md5sum | sha256sum | sha512sum ] [ __readonly__ { [ <file_content> ] + [
<file_content_cksum> ] [ <file_content_md5sum> ] [ <file_content_sha256sum> ] [ <file_content_sha512sum>
] } ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                |
| file                          | Displays content of files                      |
| <i>uri0</i>                   | Filename to be displayed                       |
| cksum                         | (Optional) Displays CRC checksum for a file    |
| md5sum                        | (Optional) Displays MD5 checksum for a file    |
| sha256sum                     | (Optional) Displays SHA256 checksum for a file |
| sha512sum                     | (Optional) Displays SHA512 checksum for a file |
| <i>__readonly__</i>           | (Optional) Read only                           |
| <i>file_content</i>           | (Optional) uri file content buffer string      |
| <i>file_content_cksum</i>     | (Optional) uri file content checksum           |
| <i>file_content_md5sum</i>    | (Optional) uri file content md5sum             |
| <i>file_content_sha256sum</i> | (Optional) uri file content sha256sum          |
| <i>file_content_sha512sum</i> | (Optional) uri file content sha512sum          |

## Command Mode

- /exec

## show fips status

```
show fips status [ __readonly__ { operation_status <o_status> } { mode_state <m_state> } [ TABLE_sessions
<lc_num> <lc_status> ] ]
```

### Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information            |
| fips             | Show if FIPS mode is enabled or disabled   |
| status           | Whether FIPS mode is enabled or disabled   |
| __readonly__     | (Optional)                                 |
| operation_status | (Optional) run-time information about fips |
| <i>o_status</i>  | (Optional) operational status of fips      |
| mode_state       | (Optional) mode state                      |
| <i>m_state</i>   | (Optional) fips or non-fips state          |
| TABLE_sessions   | (Optional) all lc status                   |
| <i>lc_num</i>    | (Optional) the lc number                   |
| <i>lc_status</i> | (Optional) the lc status                   |

### Command Mode

- /exec

# show flogi auto-area-list

show flogi auto-area-list

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information            |
| flogi          | Show information about FLOGI               |
| auto-area-list | Show list of ouis that are allocated area. |

## Command Mode

- /exec

# show flogi database

```
show flogi database [ { details | [ fcid <fcid0> ] [ details ] | [ interface <if0> ] [ details ] | [ vsan <i1> ] [ details ] } ]
```

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                             |
| flogi        | Show information about FLOGI                                |
| database     | Show information about FLOGI sessions                       |
| details      | (Optional) details: shows fcid allocation details           |
| fcid         | (Optional) fcid: enter the fcid to be matched               |
| <i>fcid0</i> | (Optional) Enter fcid                                       |
| details      | (Optional) details: shows fcid allocation details           |
| interface    | (Optional) interface id: enter the interface id of the port |
| <i>if0</i>   | (Optional) Enter interface id                               |
| details      | (Optional) details: shows fcid allocation details           |
| vsan         | (Optional) vsan id: Enter the vsan number                   |
| <i>i1</i>    | (Optional) Enter vsan                                       |
| details      | (Optional) details: shows fcid allocation details           |

## Command Mode

- /exec

# show flow cache

```
show flow cache [ ipv4 | ipv6 | ce ] [ __readonly__ [ { TABLE_flow_cache <flow-cache-index> [ <flow-type> ] [ <source-ip> ] [ <destination-ip> ] [ <source-mac> ] [ <destination-mac> ] [ <bridge-domain-id> ] [ <ether-type> ] [ <source-port> ] [ <destination-port> ] [ <protocol> ] [ <ipv6-flowlabel> ] [ <byte-count> ] [ <packet-count> ] [ <tcp-flags> ] [ <tos> ] [ <if-id> ] [ <output-if-id> ] [ <flow-start> ] [ <flow-end> } } ] ] ]
```

## Syntax Description

|                         |                                     |
|-------------------------|-------------------------------------|
| show                    | Show running system information     |
| flow                    | Show NetFlow information            |
| cache                   | Show NetFlow Exporter Cache         |
| ipv4                    | (Optional) Show ipv4 cache entries  |
| ipv6                    | (Optional) Show ipv6 cache entries  |
| ce                      | (Optional) Show ce cache entries    |
| __readonly__            | (Optional)                          |
| TABLE_flow_cache        | (Optional) The XML flow cache table |
| <i>flow-cache-index</i> | (Optional) Flow Index               |
| <i>flow-type</i>        | (Optional) Flow type - v4,v6 or MAC |
| <i>source-ip</i>        | (Optional) Source IP                |
| <i>destination-ip</i>   | (Optional) Destination IP           |
| <i>source-mac</i>       | (Optional) Source MAC               |
| <i>destination-mac</i>  | (Optional) Destination MAC          |
| <i>bridge-domain-id</i> | (Optional) Bridge Domain ID         |
| <i>ether-type</i>       | (Optional) Ether Type               |
| <i>source-port</i>      | (Optional) Source Port              |
| <i>destination-port</i> | (Optional) Destination Port         |
| <i>protocol</i>         | (Optional) Protocol                 |
| <i>ipv6-flowlabel</i>   | (Optional) Ipv6 flowlabel           |
| <i>byte-count</i>       | (Optional) Byte Count               |
| <i>packet-count</i>     | (Optional) Packet Count             |
| <i>tcp-flags</i>        | (Optional) TCP Flags                |

|                     |                            |
|---------------------|----------------------------|
| <i>tos</i>          | (Optional) TOS             |
| <i>if-id</i>        | (Optional) IF ID           |
| <i>output-if-id</i> | (Optional) OUTPUT IF ID    |
| <i>flow-start</i>   | (Optional) Flow Start Time |
| <i>flow-end</i>     | (Optional) Flow End Time   |

**Command Mode**

- /exec



# show flow cache

```
show flow cache [ ipv4 | ipv6 | ce ] [ __readonly__ TABLE_flow_cache <flow-type> <source-ip>
<destination-ip> <bridge-domain-id> <source-port> <destination-port> <protocol> <ipv6-flowlabel>
<byte-count> <packet-count> <tcp-flags> <tos> <if-id> <flow-start> <flow-end> <source-mac>
<destination-mac> <ether-type> ]
```

## Syntax Description

|                         |                                     |
|-------------------------|-------------------------------------|
| show                    | Show running system information     |
| flow                    | Show NetFlow information            |
| cache                   | Show NetFlow Exporter Cache         |
| ipv4                    | (Optional) Show ipv4 cache entries  |
| ipv6                    | (Optional) Show ipv6 cache entries  |
| ce                      | (Optional) Show ce cache entries    |
| __readonly__            | (Optional)                          |
| TABLE_flow_cache        | (Optional) The XML flow cache table |
| <i>flow-type</i>        | (Optional) Flow type - v4,v6 or MAC |
| <i>source-ip</i>        | (Optional) Source IP                |
| <i>destination-ip</i>   | (Optional) Destination IP           |
| <i>bridge-domain-id</i> | (Optional) Bridge Domain ID         |
| <i>source-port</i>      | (Optional) Source Port              |
| <i>destination-port</i> | (Optional) Destination Port         |
| <i>protocol</i>         | (Optional) Protocol                 |
| <i>ipv6-flowlabel</i>   | (Optional) Ipv6 flowlabel           |
| <i>byte-count</i>       | (Optional) Byte Count               |
| <i>packet-count</i>     | (Optional) Packet Count             |
| <i>tcp-flags</i>        | (Optional) TCP Flags                |
| <i>tos</i>              | (Optional) TOS                      |
| <i>if-id</i>            | (Optional) IF ID                    |
| <i>flow-start</i>       | (Optional) Flow Start Time          |
| <i>flow-end</i>         | (Optional) Flow End Time            |

|                        |                            |
|------------------------|----------------------------|
| <i>source-mac</i>      | (Optional) Source MAC      |
| <i>destination-mac</i> | (Optional) Destination MAC |
| <i>ether-type</i>      | (Optional) Ether Type      |

**Command Mode**

- /exec



|                        |                            |
|------------------------|----------------------------|
| <i>max_burst_value</i> | (Optional) Max Burst value |
|------------------------|----------------------------|

**Command Mode**

- /exec

# show flow exporter

```
show flow exporter [ name ] [ <exporter> ] [ __readonly__ { TABLE_flow_exporter <exporter> <description>
<dest_intf> <dest> <vrf> <vrf_id> <vrf_resolved> <dest_udp> <events_dest_udp> <source_intf> <source_ip>
<dscp> <exp_vers> <seqnum> <samp_table_to> <if_table_to> <stats_to> <temp_to> <rec_sent> <temp_sent>
<pkts_sent> <bytes_sent> <dest_unreach> <buff_events> <pkts_drop_no_route> <pkts_drop_other>
<pkts_drop_lc_rp> <pkts_drop_op_drops> <time_last_cleared> } ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                    |
| flow                   | Show NetFlow information                           |
| exporter               | Show NetFlow Exporter Configuration and Statistics |
| name                   | (Optional) Show a specific Flow Exporter           |
| <i>exporter</i>        | (Optional) Specify an exporter                     |
| <i>__readonly__</i>    | (Optional)   |
| TABLE_flow_exporter    | (Optional)   |
| <i>exporter</i>        | (Optional)   |
| <i>description</i>     | (Optional)   |
| <i>dest_intf</i>       | (Optional)   |
| <i>dest</i>            | (Optional)   |
| <i>vrf</i>             | (Optional)   |
| <i>vrf_id</i>          | (Optional)   |
| <i>vrf_resolved</i>    | (Optional)   |
| <i>dest_udp</i>        | (Optional)   |
| <i>events_dest_udp</i> | (Optional)   |
| <i>source_intf</i>     | (Optional)   |
| <i>source_ip</i>       | (Optional)   |
| <i>dscp</i>            | (Optional)   |
| <i>seqnum</i>          | (Optional)   |
| <i>exp_vers</i>        | (Optional)   |
| <i>samp_table_to</i>   | (Optional)   |
| <i>if_table_to</i>     | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>stats_to</i>           | (Optional) |
| <i>temp_to</i>            | (Optional) |
| <i>rec_sent</i>           | (Optional) |
| <i>temp_sent</i>          | (Optional) |
| <i>pkts_sent</i>          | (Optional) |
| <i>bytes_sent</i>         | (Optional) |
| <i>dest_unreach</i>       | (Optional) |
| <i>buff_events</i>        | (Optional) |
| <i>pkts_drop_no_route</i> | (Optional) |
| <i>pkts_drop_other</i>    | (Optional) |
| <i>pkts_drop_lc_rp</i>    | (Optional) |
| <i>pkts_drop_op_drops</i> | (Optional) |
| <i>time_last_cleared</i>  | (Optional) |

**Command Mode**

- /exec

# show flow exporter

```
show flow exporter [ name ] [ <exporter> ] [ __readonly__ { TABLE_flow_exporter <exporter> <description>
<dest> <vrf> <vrf_id> <vrf_resolved> <dest_udp> <source_intf> <source_ip> <dscp> <exp_vers> <seqnum>
<samp_table_to> <if_table_to> <stats_to> <temp_to> <rec_sent> <temp_sent> <pkts_sent> <bytes_sent>
<dest_unreach> <buff_events> <pkts_drop_no_route> <pkts_drop_other> <pkts_drop_lc_rp>
<pkts_drop_op_drops> <time_last_cleared> } ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                    |
| flow                 | Show NetFlow information                           |
| exporter             | Show NetFlow Exporter Configuration and Statistics |
| name                 | (Optional) Show a specific Flow Exporter           |
| <i>exporter</i>      | (Optional) Specify an exporter                     |
| <i>__readonly__</i>  | (Optional)   |
| TABLE_flow_exporter  | (Optional)   |
| <i>exporter</i>      | (Optional)   |
| <i>description</i>   | (Optional)   |
| <i>dest</i>          | (Optional)   |
| <i>vrf</i>           | (Optional)   |
| <i>vrf_id</i>        | (Optional)   |
| <i>vrf_resolved</i>  | (Optional)   |
| <i>dest_udp</i>      | (Optional)   |
| <i>source_intf</i>   | (Optional)   |
| <i>source_ip</i>     | (Optional)   |
| <i>dscp</i>          | (Optional)   |
| <i>seqnum</i>        | (Optional)   |
| <i>exp_vers</i>      | (Optional)   |
| <i>samp_table_to</i> | (Optional)   |
| <i>if_table_to</i>   | (Optional)   |
| <i>stats_to</i>      | (Optional)   |
| <i>temp_to</i>       | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>rec_sent</i>           | (Optional) |
| <i>temp_sent</i>          | (Optional) |
| <i>pkts_sent</i>          | (Optional) |
| <i>bytes_sent</i>         | (Optional) |
| <i>dest_unreach</i>       | (Optional) |
| <i>buff_events</i>        | (Optional) |
| <i>pkts_drop_no_route</i> | (Optional) |
| <i>pkts_drop_other</i>    | (Optional) |
| <i>pkts_drop_lc_rp</i>    | (Optional) |
| <i>pkts_drop_op_drops</i> | (Optional) |
| <i>time_last_cleared</i>  | (Optional) |

**Command Mode**

- /exec



# show flow filter

```
show flow filter [ __readonly__ [ { TABLE_flow_filter <name> <ipv4acl> <ipv6acl> } ] ]
```

## Syntax Description

|                   |                                 |
|-------------------|---------------------------------|
| show              | Show running system information |
| flow              | Show Analytics information      |
| filter            | Show filter Configuration       |
| __readonly__      | (Optional)                      |
| TABLE_flow_filter | (Optional) flow filter data     |
| <i>name</i>       | (Optional) Filter Name          |
| <i>ipv4acl</i>    | (Optional) IPv4 ACL             |
| <i>ipv6acl</i>    | (Optional) IPv4 ACL             |

## Command Mode

- /exec

## show flow interface

```
show flow { interface [ <intf> ] | vlan [ <vlan> ] } [ __readonly__ [ { TABLE_flow_interface [ <intf_name> ] [ <vlan_id> ] [ <filter> ] } ] ]
```

### Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| flow                 | Show Analytics information      |
| interface            | Flow interface information      |
| <i>intf</i>          | (Optional) Interface            |
| vlan                 | Flow vlan information           |
| <i>vlan</i>          | (Optional) Vlan number          |
| <i>__readonly__</i>  | (Optional)                      |
| TABLE_flow_interface | (Optional) flow interface data  |
| <i>intf_name</i>     | (Optional) Interface            |
| <i>vlan_id</i>       | (Optional) VLAN ID              |
| <i>filter</i>        | (Optional) Filter name          |

### Command Mode

- /exec

# show flow interface

```
show flow { interface [ <intf> ] | vlan [ <vlan> ] } [ __readonly__ [ { TABLE_flow_interface [ <intf_name> ] [ <vlan_id> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [ <v4in_profile_id> ] [ <v6in_mon_name> ] [ <v6in_direction> ] [ <v6in_profile_id> ] [ <l2in_mon_name> ] [ <l2in_direction> ] [ <l2in_profile_id> ] } ] ]
```

## Syntax Description

|                        |                                    |
|------------------------|------------------------------------|
| show                   | Show running system information    |
| flow                   | Show NetFlow information           |
| interface              | Flow interface information         |
| <i>intf</i>            | (Optional) Interface               |
| vlan                   | Flow vlan information              |
| <i>vlan</i>            | (Optional) Vlan number             |
| <i>__readonly__</i>    | (Optional)                         |
| TABLE_flow_interface   | (Optional) flow interface data     |
| <i>intf_name</i>       | (Optional) Interface               |
| <i>vlan_id</i>         | (Optional) VLAN ID                 |
| <i>v4in_mon_name</i>   | (Optional) IPv4 Input monitor name |
| <i>v4in_direction</i>  | (Optional) IPv4 Input direction    |
| <i>v4in_profile_id</i> | (Optional) IPv4 Input profile id   |
| <i>v6in_mon_name</i>   | (Optional) IPv6 Input monitor name |
| <i>v6in_direction</i>  | (Optional) IPv6 Input direction    |
| <i>v6in_profile_id</i> | (Optional) IPv6 Input profile id   |
| <i>l2in_mon_name</i>   | (Optional) l2 Input monitor name   |
| <i>l2in_direction</i>  | (Optional) l2 Input direction      |
| <i>l2in_profile_id</i> | (Optional) l2 Input profile id     |

## Command Mode

- /exec

# show flow monitor

```
show flow monitor [ name ] [ <monitor> [ cache [ detailed ] ] ] [ __readonly__ [ { TABLE_flow_monitor
<monitor> <use_count> [ <description> ] <record> <exporter1> <exporter2> <bucket_id> <src_addr>
<dest_addr> <direction> <pkt_count> <byte_count> } ] ]
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information           |
| flow               | Show NetFlow information                  |
| monitor            | Show Monitor Configuration                |
| name               | (Optional) Show a specific Flow Monitor   |
| <i>monitor</i>     | (Optional) Specify a monitor              |
| cache              | (Optional) Flow monitor cache contents    |
| detailed           | (Optional) Show the entire cache contents |
| __readonly__       | (Optional)                                |
| TABLE_flow_monitor | (Optional)                                |
| <i>monitor</i>     | (Optional)                                |
| <i>use_count</i>   | (Optional)                                |
| <i>description</i> | (Optional)                                |
| <i>record</i>      | (Optional)                                |
| <i>exporter1</i>   | (Optional)                                |
| <i>exporter2</i>   | (Optional)                                |
| <i>bucket_id</i>   | (Optional)                                |
| <i>src_addr</i>    | (Optional)                                |
| <i>dest_addr</i>   | (Optional)                                |
| <i>direction</i>   | (Optional)                                |
| <i>pkt_count</i>   | (Optional)                                |
| <i>byte_count</i>  | (Optional)                                |

## Command Mode

- /exec

# show flow monitor

```
show flow monitor [ name ] [ <monitor> [ cache [ detailed ] ] ] [ __readonly__ [ { TABLE_flow_monitor
<monitor> <use_count> [ <description> ] <record> <exporter1> <exporter2> <bucket_id> <src_addr>
<dest_addr> <direction> <pkt_count> <byte_count> } ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| flow                | Show NetFlow information                  |
| monitor             | Show Monitor Configuration                |
| name                | (Optional) Show a specific Flow Monitor   |
| <i>monitor</i>      | (Optional) Specify a monitor              |
| cache               | (Optional) Flow monitor cache contents    |
| detailed            | (Optional) Show the entire cache contents |
| <i>__readonly__</i> | (Optional)                                |
| TABLE_flow_monitor  | (Optional)                                |
| <i>monitor</i>      | (Optional)                                |
| <i>use_count</i>    | (Optional)                                |
| <i>description</i>  | (Optional)                                |
| <i>record</i>       | (Optional)                                |
| <i>exporter1</i>    | (Optional)                                |
| <i>exporter2</i>    | (Optional)                                |
| <i>bucket_id</i>    | (Optional)                                |
| <i>src_addr</i>     | (Optional)                                |
| <i>dest_addr</i>    | (Optional)                                |
| <i>direction</i>    | (Optional)                                |
| <i>pkt_count</i>    | (Optional)                                |
| <i>byte_count</i>   | (Optional)                                |

## Command Mode

- /exec

## show flow profile

```
show flow profile [ <profile> ] [ __readonly__ [ { TABLE_flow_profile <name> [ <desc> ] <number-of-users>
<export-intvl> <source-port> <packet-id-shift> <burst-intvl-shift> <mtu> [ <guess-threshold-lo> ] [
<guess-threshold-hi> ] [ { TABLE_payload_bin <payload-bin-num> <payload-bin-lo> <payload-bin-hi> }
] [ { TABLE_tcpopthdr_bin <tcpopthdr-bin-num> <tcpopthdr-bin-lo> <tcpopthdr-bin-hi> } ] [ {
TABLE_rcvwinsize_bin <rcvwinsize-bin-num> <rcvwinsize-bin-lo> <rcvwinsize-bin-hi> } ] } ] ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information               |
| flow                      | Show Analytics information                    |
| profile                   | Show profile Configuration                    |
| <i>profile</i>            | (Optional) Specify a profile                  |
| <i>__readonly__</i>       | (Optional)                                    |
| TABLE_flow_profile        | (Optional) HW flow profile                    |
| <i>name</i>               | (Optional) HW profile name                    |
| <i>desc</i>               | (Optional) Description of HW profile          |
| <i>number-of-users</i>    | (Optional) No. of users                       |
| <i>export-intvl</i>       | (Optional) Export Interval                    |
| <i>source-port</i>        | (Optional) Source Port                        |
| <i>packet-id-shift</i>    | (Optional) IP Packet ID Shift                 |
| <i>burst-intvl-shift</i>  | (Optional) Burst Interval Shift               |
| <i>mtu</i>                | (Optional) MTU                                |
| <i>guess-threshold-lo</i> | (Optional) Sequence Number Guess Threshold Lo |
| <i>guess-threshold-hi</i> | (Optional) Sequence Number Guess Threshold Hi |
| TABLE_payload_bin         | (Optional) Payload Bin                        |
| <i>payload-bin-num</i>    | (Optional) Bin Number                         |
| <i>payload-bin-lo</i>     | (Optional) Bin Lo                             |
| <i>payload-bin-hi</i>     | (Optional) Bin Hi                             |
| TABLE_tcpopthdr_bin       | (Optional) TCP Opt Hdr Bin                    |
| <i>tcpopthdr-bin-num</i>  | (Optional) Bin Number                         |
| <i>tcpopthdr-bin-lo</i>   | (Optional) Bin Lo                             |

|                           |                                     |
|---------------------------|-------------------------------------|
| <i>tcpopthdr-bin-hi</i>   | (Optional) Bin Hi                   |
| TABLE_rcvwinsize_bin      | (Optional) Receive Windows Size Bin |
| <i>rcvwinsize-bin-num</i> | (Optional) Bin Number               |
| <i>rcvwinsize-bin-lo</i>  | (Optional) Bin Lo                   |
| <i>rcvwinsize-bin-hi</i>  | (Optional) Bin Hi                   |

**Command Mode**

- /exec

## show flow record

```
show flow record [ name ] [ { <record> } | { netflow-original } | { netflow { protocol-port | layer2-switched
{ input } | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ [ { TABLE_flow_record <record> [
<description> ] <use_count> <template> [ <match_ip_src> ] [ <match_ip_dst> ] [ <match_proto> ] [
<match_tos> ] [ <match_l4_src> ] [ <match_l4_dst> ] [ <match_ingress> ] [ <match_egress> ] [
<match_src_as_peer> ] [ <match_dst_as_peer> ] [ <match_ipv6_src> ] [ <match_ipv6_dst> ] [
<match_ipv6_flow> ] [ <match_ipv6_option> ] [ <match_ipv6_traffic> ] [ <match_l2_src> ] [ <match_l2_dst>
] [ <match_l2_src_vlan> ] [ <match_l2_dst_vlan> ] [ <match_l2_lq> ] [ <match_l2_cos> ] [ <match_l2_etype>
] [ <match_flow_dir_match> ] [ <match_ipv4v6_src> ] [ <match_ipv4v6_dst> ] [ <collect_src_as> ] [
<collect_dst_as> ] [ <collect_src_as_peer> ] [ <collect_dst_as_peer> ] [ <collect_fwd_status> ] [
<collect_ipv4_next_hop> ] [ <collect_ipv4_bgp_next> ] [ <collect_ipv6_next_hop> ] [
<collect_ipv6_bgp_next> ] [ <collect_tcp_flags> ] [ <collect_flow_dir> ] [ <collect_bytes> ] [
<collect_bytes_long> ] [ <collect_packets> ] [ <collect_packets_long> ] [ <collect_time_first> ] [
<collect_time_last> ] [ <collect_ingress_coll> ] [ <collect_egress_coll> ] [ <collect_sampler_id> ] [
<collect_ip_ver> ] [ <collect_packet_disp> ] } ] ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                              |
| flow               | Show NetFlow information                                     |
| record             | Show Record Configuration                                    |
| name               | (Optional) Show the configuration for a specific Flow Record |
| <i>record</i>      | (Optional) Specify a record                                  |
| netflow-original   | (Optional) Traditional IPv4 input NetFlow with origin ASs    |
| netflow            | (Optional) Traditional NetFlow collection schemes            |
| ipv4               | (Optional) IPv4 collection schemes                           |
| ipv6               | (Optional) IPv6 collection schemes                           |
| l2                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| layer2-switched    | (Optional) Layer2-Switched collection schemes                |
| original-input     | (Optional) Input NetFlow                                     |
| input              | (Optional) Input NetFlow                                     |
| protocol-port      | (Optional) Protocol and Ports aggregation scheme             |
| __readonly__       | (Optional)   |
| TABLE_flow_record  | (Optional) flow record data                                  |
| <i>record</i>      | (Optional)   |
| <i>description</i> | (Optional)   |



|                             |            |
|-----------------------------|------------|
| <i>use_count</i>            | (Optional) |
| <i>template</i>             | (Optional) |
| <i>match_ip_src</i>         | (Optional) |
| <i>match_ip_dst</i>         | (Optional) |
| <i>match_proto</i>          | (Optional) |
| <i>match_tos</i>            | (Optional) |
| <i>match_l4_src</i>         | (Optional) |
| <i>match_l4_dst</i>         | (Optional) |
| <i>match_ingress</i>        | (Optional) |
| <i>match_egress</i>         | (Optional) |
| <i>match_src_as_peer</i>    | (Optional) |
| <i>match_dst_as_peer</i>    | (Optional) |
| <i>match_ipv6_src</i>       | (Optional) |
| <i>match_ipv6_dst</i>       | (Optional) |
| <i>match_ipv6_flow</i>      | (Optional) |
| <i>match_ipv6_option</i>    | (Optional) |
| <i>match_ipv6_traffic</i>   | (Optional) |
| <i>match_l2_src</i>         | (Optional) |
| <i>match_l2_dst</i>         | (Optional) |
| <i>match_l2_src_vlan</i>    | (Optional) |
| <i>match_l2_dst_vlan</i>    | (Optional) |
| <i>match_l2_lq</i>          | (Optional) |
| <i>match_l2_cos</i>         | (Optional) |
| <i>match_l2_etype</i>       | (Optional) |
| <i>match_flow_dir_match</i> | (Optional) |
| <i>match_ipv4v6_src</i>     | (Optional) |
| <i>match_ipv4v6_dst</i>     | (Optional) |
| <i>collect_src_as</i>       | (Optional) |
| <i>collect_dst_as</i>       | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>collect_src_as_peer</i>   | (Optional) |
| <i>collect_dst_as_peer</i>   | (Optional) |
| <i>collect_fwd_status</i>    | (Optional) |
| <i>collect_ipv4_next_hop</i> | (Optional) |
| <i>collect_ipv4_bgp_next</i> | (Optional) |
| <i>collect_ipv6_next_hop</i> | (Optional) |
| <i>collect_ipv6_bgp_next</i> | (Optional) |
| <i>collect_tcp_flags</i>     | (Optional) |
| <i>collect_flow_dir</i>      | (Optional) |
| <i>collect_bytes</i>         | (Optional) |
| <i>collect_bytes_long</i>    | (Optional) |
| <i>collect_packets</i>       | (Optional) |
| <i>collect_packets_long</i>  | (Optional) |
| <i>collect_time_first</i>    | (Optional) |
| <i>collect_time_last</i>     | (Optional) |
| <i>collect_ingress_coll</i>  | (Optional) |
| <i>collect_egress_coll</i>   | (Optional) |
| <i>collect_sampler_id</i>    | (Optional) |
| <i>collect_ip_ver</i>        | (Optional) |
| <i>collect_packet_disp</i>   | (Optional) |

### Command Mode

- /exec

## show flow record

```
show flow record [ name ] [ { <record> } | { netflow-original } | { netflow { protocol-port | layer2-switched
{ input } | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ [ { TABLE_flow_record <record> [
<description> ] <use_count> <template> [ <match_ip_src> ] [ <match_ip_dst> ] [ <match_proto> ] [
<match_tos> ] [ <match_l4_src> ] [ <match_l4_dst> ] [ <match_ingress> ] [ <match_egress> ] [
<match_src_as_peer> ] [ <match_dst_as_peer> ] [ <match_ipv6_src> ] [ <match_ipv6_dst> ] [
<match_ipv6_flow> ] [ <match_ipv6_option> ] [ <match_ipv6_traffic> ] [ <match_l2_src> ] [ <match_l2_dst>
] [ <match_l2_src_vlan> ] [ <match_l2_dst_vlan> ] [ <match_l2_lq> ] [ <match_l2_cos> ] [ <match_l2_etype>
] [ <match_flow_dir_match> ] [ <match_ipv4v6_src> ] [ <match_ipv4v6_dst> ] [ <collect_src_as> ] [
<collect_dst_as> ] [ <collect_src_as_peer> ] [ <collect_dst_as_peer> ] [ <collect_fwd_status> ] [
<collect_ipv4_next_hop> ] [ <collect_ipv4_bgp_next> ] [ <collect_ipv6_next_hop> ] [
<collect_ipv6_bgp_next> ] [ <collect_tcp_flags> ] [ <collect_flow_dir> ] [ <collect_bytes> ] [
<collect_bytes_long> ] [ <collect_packets> ] [ <collect_packets_long> ] [ <collect_time_first> ] [
<collect_time_last> ] [ <collect_ingress_coll> ] [ <collect_egress_coll> ] [ <collect_sampler_id> ] [
<collect_ip_ver> ] [ <collect_packet_disp> ] } ] ] ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                              |
| flow               | Show NetFlow information                                     |
| record             | Show Record Configuration                                    |
| name               | (Optional) Show the configuration for a specific Flow Record |
| <i>record</i>      | (Optional) Specify a record                                  |
| netflow-original   | (Optional) Traditional IPv4 input NetFlow with origin ASs    |
| netflow            | (Optional) Traditional NetFlow collection schemes            |
| ipv4               | (Optional) IPv4 collection schemes                           |
| ipv6               | (Optional) IPv6 collection schemes                           |
| l2                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| layer2-switched    | (Optional) Layer2-Switched collection schemes                |
| original-input     | (Optional) Input NetFlow                                     |
| input              | (Optional) Input NetFlow                                     |
| protocol-port      | (Optional) Protocol and Ports aggregation scheme             |
| __readonly__       | (Optional)   |
| TABLE_flow_record  | (Optional) flow record data                                  |
| <i>record</i>      | (Optional)   |
| <i>description</i> | (Optional)   |

|                             |            |
|-----------------------------|------------|
| <i>use_count</i>            | (Optional) |
| <i>template</i>             | (Optional) |
| <i>match_ip_src</i>         | (Optional) |
| <i>match_ip_dst</i>         | (Optional) |
| <i>match_proto</i>          | (Optional) |
| <i>match_tos</i>            | (Optional) |
| <i>match_l4_src</i>         | (Optional) |
| <i>match_l4_dst</i>         | (Optional) |
| <i>match_ingress</i>        | (Optional) |
| <i>match_egress</i>         | (Optional) |
| <i>match_src_as_peer</i>    | (Optional) |
| <i>match_dst_as_peer</i>    | (Optional) |
| <i>match_ipv6_src</i>       | (Optional) |
| <i>match_ipv6_dst</i>       | (Optional) |
| <i>match_ipv6_flow</i>      | (Optional) |
| <i>match_ipv6_option</i>    | (Optional) |
| <i>match_ipv6_traffic</i>   | (Optional) |
| <i>match_l2_src</i>         | (Optional) |
| <i>match_l2_dst</i>         | (Optional) |
| <i>match_l2_src_vlan</i>    | (Optional) |
| <i>match_l2_dst_vlan</i>    | (Optional) |
| <i>match_l2_lq</i>          | (Optional) |
| <i>match_l2_cos</i>         | (Optional) |
| <i>match_l2_etype</i>       | (Optional) |
| <i>match_flow_dir_match</i> | (Optional) |
| <i>match_ipv4v6_src</i>     | (Optional) |
| <i>match_ipv4v6_dst</i>     | (Optional) |
| <i>collect_src_as</i>       | (Optional) |
| <i>collect_dst_as</i>       | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>collect_src_as_peer</i>   | (Optional) |
| <i>collect_dst_as_peer</i>   | (Optional) |
| <i>collect_fwd_status</i>    | (Optional) |
| <i>collect_ipv4_next_hop</i> | (Optional) |
| <i>collect_ipv4_bgp_next</i> | (Optional) |
| <i>collect_ipv6_next_hop</i> | (Optional) |
| <i>collect_ipv6_bgp_next</i> | (Optional) |
| <i>collect_tcp_flags</i>     | (Optional) |
| <i>collect_flow_dir</i>      | (Optional) |
| <i>collect_bytes</i>         | (Optional) |
| <i>collect_bytes_long</i>    | (Optional) |
| <i>collect_packets</i>       | (Optional) |
| <i>collect_packets_long</i>  | (Optional) |
| <i>collect_time_first</i>    | (Optional) |
| <i>collect_time_last</i>     | (Optional) |
| <i>collect_ingress_coll</i>  | (Optional) |
| <i>collect_egress_coll</i>   | (Optional) |
| <i>collect_sampler_id</i>    | (Optional) |
| <i>collect_ip_ver</i>        | (Optional) |
| <i>collect_packet_disp</i>   | (Optional) |

### Command Mode

- /exec



|                       |  |
|-----------------------|--|
| <i>start-time</i>     | (Optional) Flow Start Time               |
| <i>if-name</i>        | (Optional) IF/Vlan                       |
| <i>vrf-name</i>       | (Optional) VRF                           |
| TABLE_flow_rtp_errors | (Optional) The XML flow rtp errors table |
| <i>loss-start</i>     | (Optional) Loss Start Time               |
| <i>loss-end</i>       | (Optional) Loss End Time                 |
| <i>packet-loss</i>    | (Optional) Packet loss                   |

**Command Mode**

- /exec

# show flow rtp timeout

show flow rtp timeout [ \_\_readonly\_\_ { <flush\_cache\_to> } ]

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| flow                  | Show NetFlow information                              |
| rtp                   | Real-time Transport Protocol                          |
| timeout               | Show NetFlow RTP flow error monitoring timeout values |
| __readonly__          | (Optional)  |
| <i>flush_cache_to</i> | (Optional)  |

## Command Mode

- /exec



# show flow system

```
show flow system [ __readonly__ <system_exporter_id> <switch_latency> [ { TABLE_flow_interface [
<intf_name> ] [ <exporter_id> ] [ <profile_name> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [
<v6in_mon_name> ] [ <v6in_direction> ] [ <filter_name> ] [ <event_name> ] [ <ipv4_hit> ] [ <ipv4_create>
] [ <ipv6_hit> ] [ <ipv6_create> ] [ <ce_hit> ] [ <ce_create> ] [ <packets_seen> ] [ <skip_collect> ] [
<export_count> ] } ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                                 |
| flow                      | Show Analytics information                                      |
| system                    | Show system Configuration                                       |
| <i>__readonly__</i>       | (Optional)  |
| <i>system_exporter_id</i> | (Optional) System Exporter ID                                   |
| <i>switch_latency</i>     | (Optional) System Switch Latency Enabled                        |
| TABLE_flow_interface      | (Optional) flow interface data                                  |
| <i>intf_name</i>          | (Optional) Interface  |
| <i>exporter_id</i>        | (Optional) Exporter ID  |
| <i>profile_name</i>       | (Optional) HW Profile Name                                      |
| <i>v4in_mon_name</i>      | (Optional) IPv4 Input monitor name                              |
| <i>v4in_direction</i>     | (Optional) IPv4 Input direction                                 |
| <i>v6in_mon_name</i>      | (Optional) IPv6 Input monitor name                              |
| <i>v6in_direction</i>     | (Optional) IPv6 Input direction                                 |
| <i>filter_name</i>        | (Optional) User Filter Name                                     |
| <i>event_name</i>         | (Optional) User Event name                                      |
| <i>ipv4_hit</i>           | (Optional) Number of packets that hit an Ipv4 hash entry        |
| <i>ipv4_create</i>        | (Optional) Number of packets that created a new Ipv4 hash entry |
| <i>ipv6_hit</i>           | (Optional) Number of packets that hit an Ipv6 hash entry        |
| <i>ipv6_create</i>        | (Optional) Number of packets that created a new Ipv6 hash entry |
| <i>ce_hit</i>             | (Optional) Number of packets that hit an ce hash entry          |
| <i>ce_create</i>          | (Optional) Number of packets that created a new ce hash entry   |
| <i>packets_seen</i>       | (Optional) Number of packets seen                               |

|                     |   |
|---------------------|---|
| <i>skip_collect</i> | (Optional) Number of packets that skipped the analytics collect |
| <i>export_count</i> | (Optional) Number of Analytics packets exported                 |

**Command Mode**

- /exec

# show flow timeout

```
show flow timeout [ __readonly__ [ <active_to> ] [ <inactive_to> ] [ <fast_to> ] [ <th_pkts> ] [ <agg_age_to> ] [ <flush_cache_to> ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information        |
| flow                  | Show NetFlow information               |
| timeout               | Show NetFlow flow cache timeout values |
| <i>__readonly__</i>   | (Optional)                             |
| <i>active_to</i>      | (Optional)                             |
| <i>inactive_to</i>    | (Optional)                             |
| <i>fast_to</i>        | (Optional)                             |
| <i>th_pkts</i>        | (Optional)                             |
| <i>agg_age_to</i>     | (Optional)                             |
| <i>flush_cache_to</i> | (Optional)                             |

## Command Mode

- /exec

## show flow tracer

```
show flow tracer [ __readonly__ [ { TABLE_flow_tracer <flow-tracer-index> [ <source-ip> ] [ <destination-ip>
] [ <bridge-domain-id> ] [ <source-port> ] [ <destination-port> ] [ <protocol> ] [ <packet-count> ] [ <if-name>
] [ <fwd-drop> ] [ <rpf-fail> ] [ <policing-drop> ] [ <ids-drop> ] [ <policy-drop> ] [ <buffer-drop> ] } ] ]
```

### Syntax Description

|                          |                                  |
|--------------------------|----------------------------------|
| show                     | Show running system information  |
| flow                     | Show NetFlow information         |
| tracer                   | Show packet tracer information   |
| __readonly__             | (Optional)                       |
| TABLE_flow_tracer        | (Optional)                       |
| <i>flow-tracer-index</i> | (Optional) Flow Index            |
| <i>source-ip</i>         | (Optional) Source IP             |
| <i>destination-ip</i>    | (Optional) Destination IP        |
| <i>bridge-domain-id</i>  | (Optional) Bridge Domain ID      |
| <i>source-port</i>       | (Optional) Source Port           |
| <i>destination-port</i>  | (Optional) Destination Port      |
| <i>protocol</i>          | (Optional) Protocol              |
| <i>packet-count</i>      | (Optional) Packet Count          |
| <i>if-name</i>           | (Optional) Ingress Interface     |
| <i>fwd-drop</i>          | (Optional) Forwarding Drops      |
| <i>rpf-fail</i>          | (Optional) RPF Port Sec Failures |
| <i>policing-drop</i>     | (Optional) Policing Drops        |
| <i>ids-drop</i>          | (Optional) Ids Drops             |
| <i>policy-drop</i>       | (Optional) ACL Drops             |
| <i>buffer-drop</i>       | (Optional) Buffer Drops          |

### Command Mode

- /exec

# show flow vrf

```
show flow vrf [ <vrf_name> ] [ __readonly__ [ { TABLE_flow_vrf [ <vrf_name> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [ <v6in_mon_name> ] [ <v6in_direction> ] [ <filter_name> ] } ] ]
```

## Syntax Description

|                       |                                    |
|-----------------------|------------------------------------|
| show                  | Show running system information    |
| flow                  | Show Analytics information         |
| vrf                   | Show VRF Configuration             |
| <i>vrf_name</i>       | (Optional) Specify a vrf           |
| <i>__readonly__</i>   | (Optional)                         |
| <i>TABLE_flow_vrf</i> | (Optional) flow vrf data           |
| <i>vrf_name</i>       | (Optional) VRF name                |
| <i>v4in_mon_name</i>  | (Optional) IPv4 Input monitor name |
| <i>v4in_direction</i> | (Optional) IPv4 Input direction    |
| <i>v6in_mon_name</i>  | (Optional) IPv6 Input monitor name |
| <i>v6in_direction</i> | (Optional) IPv6 Input direction    |
| <i>filter_name</i>    | (Optional) User Filter Name        |

## Command Mode

- /exec

# show forwarding

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ ipv4 ] [ route |
rnhdb ] [ recursive ] [ summary | [ [ detail | platform | partial | ipsg ] [ max-display-count <display_count> ]
] | [ <prefix> [ longer-prefixes ] [ detail | platform ] | <address> [ detail | platform ] |
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  |  |
| forwarding            | display fib information                                |
| vrf                   | (Optional) display info per VRF                        |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| vrf-all               | (Optional) Display information for all VRFs            |
| table                 | (Optional) display info per vpn-id                     |
| <i>table_id</i>       | (Optional) table id in hex                             |
| ipv4                  | (Optional) ipv4  |
| route                 | (Optional) display IP routing table                    |
| ipsg                  | (Optional) display IPv4 IPSG routes                    |
| rnhdb                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |
| recursive             | (Optional) display routes with recursive next hops     |
| partial               | (Optional) display routes with partial ECMPs           |
| summary               | (Optional) display route counts                        |
| <i>prefix</i>         | (Optional) display single exact match route            |
| longer-prefixes       | (Optional) display longer prefixes                     |
| <i>address</i>        | (Optional) display single longest match route          |
| detail                | (Optional) show detailed information about the routes  |
| platform              | (Optional) one command to show pi and pd info together |
| max-display-count     | (Optional) displays max # of routes                    |
| <i>display_count</i>  | (Optional) count                                       |

## Command Mode

- /exec

## show forwarding adjacency

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ipv4 ] adjacency [ mpls ] [ lisp ] [ nve ] [ <aif> ] [ <anh> ] [ detail | stats | platform ] [ module <module> ] [ __readonly__ [ <adj-count> ] ] [ TABLE_adj { [ <fec> ] [ <nexthop> ] [ <intf> ] [ <rewinfo> ] [ <interface> ] [ <bgp_rnh> ] [ <bgp_orig_as> ] [ <bgp_peer_as> ] [ <pkts> ] [ <bytes> ] [ <exp> ] [ <src_addr> ] [ <dest_addr> ] [ <lisp_flags> ] [ <lisp_inst_id> ] [ <pltfm_key> ] [ <hh> ] [ <refcount> ] } ] [ TABLE_ip_adjacency { [ <nh> ] [ <rwinf> ] [ <intf> ] [ <intf_idx> ] [ <hhandle> ] [ <refcnt> ] [ <flags> ] [ <holder> ] [ <pbr_cnt> ] [ <wccp_cnt> ] [ <rewrite-p> ] [ TABLE_index { [ <hw_adj> ] [ <cmn-idx> ] [ <lif> ] [ <buf-idx> ] } } ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  |  |
| forwarding            | display fib information                                |
| ipv4                  | (Optional) ipv4  |
| adjacency             | display adjacency information                          |
| platform              | (Optional) one command to show pi and pd info together |
| vrf                   | (Optional) display info per VRF                        |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| vrf-all               | (Optional) Display information for all VRFs            |
| mpls                  | (Optional) mpls adjacency information                  |
| lisp                  | (Optional) LISP adjacency information                  |
| nve                   | (Optional) VxLAN tunnel adjacency information          |
| <i>aif</i>            | (Optional) adjacency output interface                  |
| <i>anh</i>            | (Optional) adjacency next hop                          |
| detail                | (Optional) detail                                      |
| stats                 | (Optional) adjacency statistics                        |
| module                | (Optional) slot  |
| <i>module</i>         | (Optional) slot number                                 |
| __readonly__          | (Optional)   |
| <i>adj-count</i>      | (Optional) total adj count                             |
| TABLE_adj             | (Optional) Table Adjacency                             |
| <i>fec</i>            | (Optional) FEC info                                    |

|                     |                                |
|---------------------|--------------------------------|
| <i>nexthop</i>      | (Optional) next hop address    |
| <i>intf</i>         | (Optional) output interface    |
| <i>rewinfo</i>      | (Optional) rewrite information |
| <i>interface</i>    | (Optional) output interface    |
| <i>bgp_rnh</i>      | (Optional) next hop address    |
| <i>bgp_orig_as</i>  | (Optional) bgp orig as         |
| <i>bgp_peer_as</i>  | (Optional) bgp peer as         |
| <i>exp</i>          | (Optional) exp mapping         |
| <i>pkts</i>         | (Optional) packet stats        |
| <i>bytes</i>        | (Optional) bytes stats         |
| <i>src_addr</i>     | (Optional) src address         |
| <i>dest_addr</i>    | (Optional) dest address        |
| <i>lisp_flags</i>   | (Optional) lisp flags          |
| <i>lisp_inst_id</i> | (Optional) lisp instance id    |
| <i>pltfm_key</i>    | (Optional) platform key        |
| <i>hh</i>           | (Optional) Hardware Handle     |
| <i>refcount</i>     | (Optional) reference count     |
| TABLE_ip_adjacency  | (Optional) Table ip adjacency  |
| <i>nh</i>           | (Optional) next hop address    |
| <i>rwinfo</i>       | (Optional) rewrite information |
| <i>intf</i>         | (Optional) output interface    |
| <i>intf_idx</i>     | (Optional) Interface index     |
| <i>hhandle</i>      | (Optional) Hw Handle           |
| <i>refcnt</i>       | (Optional) reference count     |
| <i>flags</i>        | (Optional) Adjacency flags     |
| <i>holder</i>       | (Optional) Holder bitmap       |
| <i>pbr_cnt</i>      | (Optional) PBR count           |
| <i>wccp_cnt</i>     | (Optional) WCCP count          |
| <i>rewrite-p</i>    | (Optional) Rewrite pointer     |



|                |                            |
|----------------|----------------------------|
| TABLE_index    | (Optional) HW index table  |
| <i>hw_adj</i>  | (Optional) v4 adj hw index |
| <i>cmn-idx</i> | (Optional) CMN Index       |
| <i>lif</i>     | (Optional) LIF             |
| <i>buf-idx</i> | (Optional) Buffer index    |

**Command Mode**

- /exec

# show forwarding consistency-fretta l2

show forwarding consistency-fretta l2 <module>

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information           |
| forwarding         | Forwarding information                    |
| consistency-fretta | consistency                               |
| l2                 | Verify l2 mac programming in the hardware |
| <i>module</i>      | Enter module number                       |

## Command Mode

- /exec

# show forwarding distribution clients

show forwarding distribution clients [ \_\_readonly\_\_ <id><pid><name><shms><shme><shmn> ]

## Syntax Description

|              |                                |
|--------------|--------------------------------|
| show         |                                |
| forwarding   | Display Forwarding Information |
| distribution | fib distribution info          |
| clients      | unicast client information     |
| __readonly__ | (Optional)                     |

## Command Mode

- /exec

## show forwarding distribution evpn storm-control

```
show forwarding distribution evpn storm-control [ __readonly__ <header> [ TABLE_storm_control_level
<type> <status> <level> ] [ TABLE_interface_bandwidth <interface> <type> <bandwidth> ] [
TABLE_total_bandwidth <type> <bandwidth> ] ]
```

### Syntax Description

|                           |                                      |
|---------------------------|--------------------------------------|
| show                      | Show running system information      |
| forwarding                | forwarding information               |
| distribution              | fib distribution info                |
| evpn                      | evpn distribution info               |
| storm-control             | storm-control information            |
| <i>__readonly__</i>       | (Optional)                           |
| <i>header</i>             | (Optional) Header                    |
| TABLE_storm_control_level | (Optional) Table storm control level |
| <i>type</i>               | (Optional) Traffic type              |
| <i>status</i>             | (Optional) Status                    |
| <i>level</i>              | (Optional) Level                     |
| TABLE_interface_bandwidth | (Optional) Table interface bandwidth |
| <i>interface</i>          | (Optional) Interface                 |
| <i>type</i>               | (Optional) Type                      |
| <i>bandwidth</i>          | (Optional) Bandwidth                 |
| TABLE_total_bandwidth     | (Optional) Table total bandwidth     |
| <i>type</i>               | (Optional) Type                      |
| <i>bandwidth</i>          | (Optional) Bandwidth                 |

### Command Mode

- /exec

## show forwarding distribution fib-state

```
show forwarding distribution fib-state [ __readonly__ <slot> <state><ttc><tprc><tv4ac><tv6ac> {
TABLE_fib_state <tid><tafi><prc><pc><tname> } ]
```

### Syntax Description

|                 |                                |
|-----------------|--------------------------------|
| show            |                                |
| forwarding      | Display Forwarding Information |
| distribution    | fib distribution info          |
| fib-state       | unicast fib state info         |
| __readonly__    | (Optional)                     |
| <i>slot</i>     | (Optional) slot number         |
| TABLE_fib_state | (Optional) fib-state table     |

### Command Mode

- /exec

## show forwarding distribution ip igmp snooping

```
show forwarding distribution ip igmp snooping [ vlan <vlan-id> [ group [ <grpaddr> | <mac-grpaddr> ] [
source <srcaddr> ] ] ] [ detail ] [ __readonly__ <refcount> <oiflist_id> <last_oiflist_id> <ftag-id> ]
```

### Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   |                                       |
| forwarding             | Display Forwarding Information        |
| distribution           | FIB distribution information          |
| ip                     | IPV4 information                      |
| igmp                   | MFDM IGMP information                 |
| snooping               | L2 mcast snooping related information |
| vlan                   | (Optional) Info specific to a vlan    |
| <i>vlan-id</i>         | (Optional) Vlan id value              |
| group                  | (Optional) Group specific information |
| <i>grpaddr</i>         | (Optional) Group address              |
| <i>mac-grpaddr</i>     | (Optional) Group MAC address          |
| source                 | (Optional) (G,S) specific information |
| <i>srcaddr</i>         | (Optional) Source address             |
| detail                 | (Optional) Detailed display           |
| <i>__readonly__</i>    | (Optional)                            |
| <i>refcount</i>        | (Optional) Reference Count            |
| <i>oiflist_id</i>      | (Optional) OIF list Identifier        |
| <i>last_oiflist_id</i> | (Optional) Last OIF list Identifier   |
| <i>ftag-id</i>         | (Optional) ftag Id                    |

### Command Mode

- /exec

# show forwarding distribution ipv6 multicast route

```
show forwarding distribution ipv6 multicast route [ table <table_id> | vrf { <vrf-name> | all } ] [ group {
<group> } [ source { <source> } ] ] | summary ] [ __readonly__ TABLE_vrf [ <vrf-name> ] [ <table-name>
] [ <table-id> ] [ <total-num-groups> ] [ TABLE_route_summary [ <vrf-name> ] [ <total-num-routes> ] [
<num-star-g-route> ] [ <num-sg-route> ] [ <num-star-g-prfx> ] [ <num-group-count> ] ] [ TABLE_one_route
[ <source-addr> ] [ <source-len> ] [ <group-addr> ] [ <group-len> ] [ <df-ordinal> ] [ <rpf-intf> ] [ <flags>
] [ <upstream-addr> ] [ <stats-pkts> ] [ <stats-bytes> ] [ <oif-count> ] [ <oiflist-index> ] [ TABLE_oif [
<oif-name> ] [ <mti-src-intf> ] [ <mti-grp-ip> ] [ <mti-src-ip> ] ] ] ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    |  |
| forwarding              | Display Forwarding Information               |
| distribution            | display fib distribution information         |
| ipv6                    | IPv6 related information                     |
| multicast               | display IPv6 multicast information           |
| route                   | display routing table                        |
| vrf                     | (Optional) display routes for a specific VRF |
| <i>vrf-name</i>         | (Optional) VRF name                          |
| all                     | (Optional) Display information for all VRFs  |
| table                   | (Optional) table                             |
| <i>table_id</i>         | (Optional) table number                      |
| group                   | (Optional) Multicast IPv6 Group Address      |
| source                  | (Optional) Multicast IPv6 Source Address     |
| summary                 | (Optional) display route counts              |
| <i>__readonly__</i>     | (Optional)                                   |
| TABLE_vrf               | (Optional)                                   |
| <i>vrf-name</i>         | (Optional)                                   |
| <i>table-name</i>       | (Optional)                                   |
| <i>table-id</i>         | (Optional)                                   |
| <i>total-num-groups</i> | (Optional)                                   |
| TABLE_route_summary     | (Optional)                                   |
| <i>total-num-routes</i> | (Optional)                                   |

|                         |            |
|-------------------------|------------|
| <i>num-star-g-route</i> | (Optional) |
| <i>num-sg-route</i>     | (Optional) |
| <i>num-star-g-prfx</i>  | (Optional) |
| <i>num-group-count</i>  | (Optional) |
| TABLE_one_route         | (Optional) |
| <i>source-addrs</i>     | (Optional) |
| <i>source-len</i>       | (Optional) |
| <i>group-addrs</i>      | (Optional) |
| <i>group-len</i>        | (Optional) |
| <i>df-ordinal</i>       | (Optional) |
| <i>rpf-intf</i>         | (Optional) |
| <i>flags</i>            | (Optional) |
| <i>stats-pkts</i>       | (Optional) |
| <i>stats-bytes</i>      | (Optional) |
| <i>oif-count</i>        | (Optional) |
| <i>oiflist-index</i>    | (Optional) |
| TABLE_oif               | (Optional) |
| <i>oif-name</i>         | (Optional) |
| <i>mti-src-intf</i>     | (Optional) |
| <i>mti-grp-ip</i>       | (Optional) |
| <i>mti-src-ip</i>       | (Optional) |

**Command Mode**

- /exec



## show forwarding distribution l2 multicast

```
show forwarding distribution l2 multicast [ ip-based | mac-based ] [ vlan <vlan-id> [ { group { <grpaddr> |
<v6grpaddr> } [ source { <srcaddr> | <v6srcaddr> } ] } | destination-mac <dmac> ] ] [ summary ] [
__readonly__ [ TABLE_sum [ <mode> ] [ <num_vlan> ] [ <num_starg> ] [ <num_sg> ] [ <num_aggstarg>
] [ TABLE_sum_info [ <ftag_id> ] [ <vlan_id> ] [ <routable_flag> ] [ <v6_routable_flag> ] [ <num_starg>
] [ <num_sg> ] [ <num_aggstarg> ] [ <total_route> ] ] ] [ TABLE_route [ <vlan> ] [ <grp_str> ] [ <v6grp_str>
] [ <src_str> ] [ <v6src_str> ] [ <grp_mac> ] [ <src_mac> ] [ TABLE_oif [ <oiflist_id> ] [ <refcount> ] [
<l3_usage> ] [ <plt_index> ] [ <num_oif> ] [ <oif_name> ] [ <flags> ] [ <dvif> ] ] ] ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                |   |
| forwarding          | Display Forwarding Information                  |
| distribution        | FIB distribution information                    |
| l2                  | L2 information                                  |
| multicast           | L2 multicast information                        |
| ip-based            | (Optional) IPv4 based                           |
| mac-based           | (Optional) MAC based                            |
| vlan                | (Optional) Info specific to a vlan              |
| <i>vlan-id</i>      | (Optional) Vlan id value                        |
| group               | (Optional) Group specific information           |
| <i>grpaddr</i>      | (Optional) Group address                        |
| source              | (Optional) (G,S) specific information           |
| <i>srcaddr</i>      | (Optional) Source address                       |
| destination-mac     | (Optional) Destination MAC specific information |
| <i>dmac</i>         | (Optional) Destination MAC address              |
| summary             | (Optional) display route counts                 |
| <i>__readonly__</i> | (Optional)                                      |
| TABLE_sum           | (Optional)                                      |
| <i>mode</i>         | (Optional) Mode                                 |
| <i>num_vlan</i>     | (Optional) Num of VLAN                          |
| <i>num_starg</i>    | (Optional) Num of Starg routes                  |
| <i>num_sg</i>       | (Optional) Num of SG routes                     |

|                         |   |
|-------------------------|---|
| <i>num_aggstarg</i>     | (Optional) Num of Aggregated Starg routes |
| TABLE_sum_info          | (Optional)                                |
| <i>vlan_id</i>          | (Optional) vlan id                        |
| <i>ftag_id</i>          | (Optional) ftag id                        |
| <i>routable_flag</i>    | (Optional) Routable flag                  |
| <i>v6_routable_flag</i> | (Optional) Routable flag                  |
| <i>num_starg</i>        | (Optional) Num of starg routes            |
| <i>num_sg</i>           | (Optional) Num of sg routes               |
| <i>num_aggstarg</i>     | (Optional) Num of Aggregated Starg routes |
| <i>total_route</i>      | (Optional) Total Routes                   |
| TABLE_route             | (Optional)                                |
| <i>vlan</i>             | (Optional) vlan                           |
| <i>grp_str</i>          | (Optional) Group Address                  |
| <i>v6grp_str</i>        | (Optional) v6 Group address               |
| <i>src_str</i>          | (Optional) Source Address                 |
| <i>v6src_str</i>        | (Optional) v6 Group address               |
| <i>grp_mac</i>          | (Optional) Group Mac                      |
| <i>src_mac</i>          | (Optional) Source Mac                     |
| TABLE_oif               | (Optional)                                |
| <i>oiflist_id</i>       | (Optional) oiflist index                  |
| <i>refcount</i>         | (Optional) reference count                |
| <i>l3_usage</i>         | (Optional) l3 usage                       |
| <i>plt_index</i>        | (Optional) platform index                 |
| <i>num_oif</i>          | (Optional) Num of outgoing interface      |
| <i>oif_name</i>         | (Optional) Oif details                    |
| <i>flags</i>            | (Optional)                                |
| <i>dvif</i>             | (Optional)                                |

**Command Mode**

- /exec

# show forwarding distribution lisp counters

show forwarding distribution lisp counters [ *\_\_readonly\_\_* <count> ]

## Syntax Description

|                     |                                |
|---------------------|--------------------------------|
| show                |                                |
| forwarding          | Display Forwarding Information |
| distribution        | fib distribution information   |
| lisp                | for lisp application           |
| counters            | counters                       |
| <i>__readonly__</i> | (Optional)                     |
| <i>count</i>        | (Optional) count               |

## Command Mode

- /exec

## show forwarding distribution lisp vrf enabled

```
show forwarding distribution lisp vrf enabled [ __readonly__ { TABLE_lisp_vrf_enabled <vrf> <lisp_enabled>
<req_id> <operation> } ]
```

### Syntax Description

|                               |                                |
|-------------------------------|--------------------------------|
| show                          |                                |
| forwarding                    | Display Forwarding Information |
| distribution                  | fib distribution information   |
| lisp                          | for lisp application           |
| vrf                           | vrf                            |
| enabled                       | enabled                        |
| <i>__readonly__</i>           | (Optional)                     |
| <i>TABLE_lisp_vrf_enabled</i> | (Optional)                     |
| <i>vrf</i>                    | (Optional) vrf key             |
| <i>lisp_enabled</i>           | (Optional) lisp enabled status |
| <i>req_id</i>                 | (Optional) req id              |
| <i>operation</i>              | (Optional) operation           |

### Command Mode

- /exec

# show forwarding distribution multicast

```
show forwarding distribution multicast [ messages ] [ __readonly__ <num_accepting_routes> <slot> <fibstate> ]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| show                        |  |
| forwarding                  | Display Forwarding Information             |
| distribution                | FIB distribution information               |
| multicast                   | Multicast FIB distribution information     |
| messages                    | (Optional) Outstanding Message Information |
| <i>__readonly__</i>         | (Optional)                                 |
| <i>num_accepting_routes</i> | (Optional) Number of fibs accepting routes |
| <i>slot</i>                 | (Optional) Slot                            |
| <i>fibstate</i>             | (Optional) IP Multicast FIB process state  |

## Command Mode

- /exec

## show forwarding distribution multicast client-ack-db

```
show forwarding distribution multicast client-ack-db [ __readonly__ <xid> <num_receipients> <num_responses> ]
```

### Syntax Description

|                        |                                  |
|------------------------|----------------------------------|
| show                   | show                             |
| forwarding             | Display Forwarding Information   |
| distribution           | FIB distribution information     |
| multicast              | Multicast                        |
| client-ack-db          | Displays the client ack db       |
| <i>__readonly__</i>    | (Optional)                       |
| <i>xid</i>             | (Optional) XID                   |
| <i>num_receipients</i> | (Optional) Number of receipients |
| <i>num_responses</i>   | (Optional) Number of responses   |

### Command Mode

- /exec

# show forwarding distribution multicast client

show forwarding distribution multicast client [ *\_\_readonly\_\_* <num-clients> <client-name> <client-id> <shmem-name> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                |  |
| forwarding          | Display Forwarding Information                 |
| distribution        | FIB distribution information                   |
| multicast           | Multicast information                          |
| client              | Show multicast distribution client information |
| <i>__readonly__</i> | (Optional)                                     |
| <i>num-clients</i>  | (Optional) Number of Clients registered        |
| <i>client-name</i>  | (Optional) Client Name                         |
| <i>client-id</i>    | (Optional) Client-id                           |
| <i>shmem-name</i>   | (Optional) Shared Memory Segment Name          |

## Command Mode

- /exec

# show forwarding distribution multicast download

```
show forwarding distribution multicast download [ __readonly__ [ TABLE_MFDM_DOWNLOAD_INFO
<db_type> [ TABLE_MFDM_PENDING_INFO [ <table_id> ] ] ] ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     |  |
| forwarding               | forwarding information                 |
| distribution             | FIB distribution information           |
| multicast                | Multicast FIB distribution information |
| download                 | show download queues                   |
| <i>__readonly__</i>      | (Optional)                             |
| TABLE_MFDM_DOWNLOAD_INFO | (Optional) MFDM download info          |
| <i>db_type</i>           | (Optional) Database type               |
| TABLE_MFDM_PENDING_INFO  | (Optional) Routes Pending info         |
| <i>table_id</i>          | (Optional) Table ID                    |

## Command Mode

- /exec



# show forwarding distribution multicast mfib

```
show forwarding distribution multicast { mfib-txlist [ vrf <vrf-name> ] | mfib-buffers } [ __readonly__
<no-free-buffers> <no-used-buffers> ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   |   |
| forwarding             | Display Forwarding Information                |
| distribution           | FIB distribution information                  |
| multicast              | Multicast information                         |
| mfib-txlist            | Show MFIB transmission-list information       |
| vrf                    | (Optional) Specify VRF                        |
| <i>vrf-name</i>        | (Optional) Specify VRF name                   |
| mfib-buffers           | Show MFIB route buffer information            |
| __readonly__           | (Optional)                                    |
| <i>no-free-buffers</i> | (Optional) Number of Free txlist MFIB buffers |
| <i>no-used-buffers</i> | (Optional) Number of Used txlist MFIB buffers |

## Command Mode

- /exec

# show forwarding distribution multicast outgoing-interface-list L2\_PRIME

```
show forwarding distribution multicast outgoing-interface-list L2_PRIME [ __readonly__ <index> <dvif>
<platform_index> <ref_count> <l2-oifs> <port_set> ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    |  |
| forwarding              | Display Forwarding Information           |
| distribution            | FIB distribution information             |
| multicast               | Multicast FIB distribution information   |
| outgoing-interface-list | Outgoing interface list                  |
| L2_PRIME                | Layer 2 oiflist                          |
| <i>index</i>            | (Optional) Outgoing Interface List index |
| <i>__readonly__</i>     | (Optional)                               |
| <i>dvif</i>             | (Optional) Destination VIF               |
| <i>platform_index</i>   | (Optional) Platform index                |
| <i>ref_count</i>        | (Optional) Reference count               |
| <i>l2-oifs</i>          | (Optional) L2 oifs                       |
| <i>port_set</i>         | (Optional) Port set                      |

## Command Mode

- /exec

# show forwarding distribution multicast resp-ack-timer-msgs

show forwarding distribution multicast resp-ack-timer-msgs

## Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                |                                   |
| forwarding          | Display Forwarding Information    |
| distribution        | FIB distribution information      |
| multicast           | Multicast information             |
| resp-ack-timer-msgs | show response ack timers for MFDM |

## Command Mode

- /exec

## show forwarding distribution multicast route

```
show forwarding distribution [ ip ] multicast route [ table <id> | vrf { <vrf_name> | <vrf-known-name> | all } ] [ [ group { <gaddr> [ <mask> ] | <gprefix> } [ source { <saddr> [ <smask> ] | <sprefix> } ] ] | summary ] [ __readonly__ TABLE_vrf [ <vrf-name> ] [ <table-name> ] [ <table-id> ] [ <table-wildcard> ] [ <total-num-groups> ] [ TABLE_route_summary [ <vrf-name> ] [ <total-num-routes> ] [ <num-star-g-route> ] [ <num-sg-route> ] [ <num-star-g-prfx> ] [ <num-group-count> ] ] [ TABLE_one_route [ <source-addr> ] [ <source-len> ] [ <group-addr> ] [ <group-len> ] [ <df-ordinal> ] [ <rpf-intf> ] [ <flags> ] [ <upstream-addr> ] [ <stats-state> ] [ <stats-pkts> ] [ <stats-bytes> ] [ <oif-count> ] [ <oiflist-index> ] [ TABLE_oif [ <oif-name> ] [ <mti-src-intf> ] [ <mti-grp-ip> ] [ <mti-src-ip> ] [ <next-hop> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  |   |
| forwarding            | Display Forwarding Information                |
| distribution          | FIB distribution information                  |
| ip                    | (Optional) IPV4 information                   |
| multicast             | Multicast information                         |
| route                 | Multicast route related information           |
| vrf                   | (Optional) Specify VRF                        |
| <i>vrf_name</i>       | (Optional) Specify VRF name                   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                     |
| all                   | (Optional) Display information for all VRFs   |
| table                 | (Optional) Specify Multicast Routing Table    |
| <i>id</i>             | (Optional) Multicast Routing Table Identifier |
| group                 | (Optional) IPv4 Multicast Group specific      |
| <i>gaddr</i>          | (Optional) IPv4 Multicast Group Address       |
| <i>mask</i>           | (Optional) mask for group ip address          |
| <i>gprefix</i>        | (Optional) IPv4 Multicast Group Prefix        |
| source                | (Optional) IPv4 Multicast Source specific     |
| <i>saddr</i>          | (Optional) IPv4 Source Address                |
| <i>smask</i>          | (Optional) mask for group ip address          |
| <i>sprefix</i>        | (Optional) IPv4 Multicast Source Prefix       |
| summary               | (Optional) display route counts               |

|                         |            |
|-------------------------|------------|
| <i>__readonly__</i>     | (Optional) |
| TABLE_vrf               | (Optional) |
| <i>vrf-name</i>         | (Optional) |
| <i>table-name</i>       | (Optional) |
| <i>table-id</i>         | (Optional) |
| <i>table-wildcard</i>   | (Optional) |
| <i>total-num-groups</i> | (Optional) |
| TABLE_route_summary     | (Optional) |
| <i>total-num-routes</i> | (Optional) |
| <i>num-star-g-route</i> | (Optional) |
| <i>num-sg-route</i>     | (Optional) |
| <i>num-star-g-prfx</i>  | (Optional) |
| <i>num-group-count</i>  | (Optional) |
| TABLE_one_route         | (Optional) |
| <i>source-addr</i>      | (Optional) |
| <i>source-len</i>       | (Optional) |
| <i>group-addr</i>       | (Optional) |
| <i>group-len</i>        | (Optional) |
| <i>df-ordinal</i>       | (Optional) |
| <i>rpf-intf</i>         | (Optional) |
| <i>upstream-addr</i>    | (Optional) |
| <i>flags</i>            | (Optional) |
| <i>stats-state</i>      | (Optional) |
| <i>stats-pkts</i>       | (Optional) |
| <i>stats-bytes</i>      | (Optional) |
| <i>oif-count</i>        | (Optional) |
| <i>oiflist-index</i>    | (Optional) |
| TABLE_oif               | (Optional) |
| <i>oif-name</i>         | (Optional) |

|                     |            |
|---------------------|------------|
| <i>mti-src-intf</i> | (Optional) |
| <i>mti-grp-ip</i>   | (Optional) |
| <i>mti-src-ip</i>   | (Optional) |
| <i>next-hop</i>     | (Optional) |

**Command Mode**

- /exec

# show forwarding distribution multicast sr hash-db

show forwarding distribution multicast sr hash-db

## Syntax Description

|              |                                |
|--------------|--------------------------------|
| show         | show                           |
| forwarding   | Display Forwarding Information |
| distribution | FIB distribution information   |
| multicast    | Multicast                      |
| sr           | Service reflect rules          |
| hash-db      | Hash database                  |

## Command Mode

- /exec

# show forwarding distribution multicast vxlan dsg-db

show forwarding distribution multicast vxlan dsg-db

## Syntax Description

|              |                                |
|--------------|--------------------------------|
| show         | show                           |
| forwarding   | Display Forwarding Information |
| distribution | FIB distribution information   |
| multicast    | Multicast                      |
| vxlan        | vxlan                          |
| dsg-db       | delivery group/source db       |

## Command Mode

- /exec



## show forwarding distribution nve overlay-vlan

show forwarding distribution nve overlay-vlan [ *\_\_readonly\_\_* *TABLE\_overlay\_vlan\_peer\_id* <Vlan> <SVP> <install> <Origin> <VFP-region> <peercount> <peer\_id> + ]

### Syntax Description

|                                   |                                       |
|-----------------------------------|---------------------------------------|
| show                              | Show running system information       |
| forwarding                        | forwarding information                |
| distribution                      | fib distribution info                 |
| nve                               | nve distribution info                 |
| overlay-vlan                      | overlay-vlan adjacency info           |
| <i>__readonly__</i>               | (Optional)                            |
| <i>TABLE_overlay_vlan_peer_id</i> | (Optional) overlay vlan peer id table |
| <i>Vlan</i>                       | (Optional) VLAN                       |
| <i>SVP</i>                        | (Optional) SVP                        |
| <i>install</i>                    | (Optional) install                    |
| <i>Origin</i>                     | (Optional) Origin                     |
| <i>VFP-region</i>                 | (Optional) VFP-region                 |
| <i>peercount</i>                  | (Optional) Total count of Peers       |
| <i>peer_id</i>                    | (Optional) Peer-ID                    |

### Command Mode

- /exec

## show forwarding distribution peer-id

```
show forwarding distribution peer-id [ vpls | otv ] [ __readonly__ <header> TABLE_peer_id <app> <vlan>
<id> <peer_id> ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| forwarding     | forwarding information                    |
| distribution   | fib distribution info                     |
| peer-id        | HW Peer-id allocation info                |
| vpls           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| otv            | (Optional) OTV                            |
| __readonly__   | (Optional)                                |
| <i>header</i>  | (Optional) Header                         |
| TABLE_peer_id  | (Optional) Peer ID table                  |
| <i>app</i>     | (Optional) OTV/VPLS                       |
| <i>vlan</i>    | (Optional) VLAN                           |
| <i>id</i>      | (Optional) ID                             |
| <i>peer_id</i> | (Optional) Peer-ID                        |

### Command Mode

- /exec

## show forwarding distribution srv6 local-sid bd-mapping

```
show forwarding distribution srv6 local-sid bd-mapping [ __readonly__ { local_sid_bd_map <sid_bd_map>
} [ { TABLE_local_sid <local_sid> <Table_id> <func_type> <bd> <locator> <function> <args> } ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                |
| forwarding              | forwarding information                         |
| distribution            | fib distribution info                          |
| srv6                    | Srv6 related                                   |
| local-sid               | Local SID                                      |
| bd-mapping              | Local Sid to BD mappings                       |
| <i>__readonly__</i>     | (Optional)                                     |
| <i>local_sid_bd_map</i> | (Optional) Local-sid to BD mapping             |
| <i>sid_bd_map</i>       | (Optional) Local-sid to BD mappingi number     |
| <i>TABLE_local_sid</i>  | (Optional) Table with local SID's              |
| <i>local_sid</i>        | (Optional) V6 prefix associated with local-sid |
| <i>Table_id</i>         | (Optional) Table ID                            |
| <i>func_type</i>        | (Optional) Function behavior type              |
| <i>bd</i>               | (Optional) Bridge domain                       |
| <i>locator</i>          | (Optional) Locator V6 address                  |
| <i>function</i>         | (Optional) function                            |
| <i>args</i>             | (Optional) args                                |

### Command Mode

- /exec

# show forwarding distribution trace

show forwarding distribution trace

## Syntax Description

|              |                                |
|--------------|--------------------------------|
| show         |                                |
| forwarding   | Display Forwarding Information |
| distribution | fib distribution info          |
| trace        | unicast trace information      |

## Command Mode

- /exec

## show forwarding ecmp

```
show forwarding ecmp [ { [ vrf { <vrf-name> | <vrf-known-name> } ] lisp } ] [ platform ] [ module <module> ] [ partial ] [ __readonly__ [ <header> <ecmp_hash> <intf> <nh> <v6nh> <hw_index> <num_mpls> <holder> <refcount> <num_paths> <sw_ptr> <ecmp_partial> ] [ TABLE_ecmp { [ <hash> ] [ <num_paths> ] [ <hwinde> ] [ <ecmppartial> ] [ TABLE_index { [ <ecmp_idx> ] [ <cmn_idx> ] } ] [ <refcnt> ] [ <ecmp_holder> ] } ] [ TABLE_adjacency { [ <intf> ] [ <nh> ] [ <v6nh> ] [ <hw_adj_idx> ] [ <hw_cmn_idx> ] [ <lif> ] [ <hw_nve_adj_idx> ] [ <hw_nve_cmn_idx> ] [ <nve_lif> ] } ] [ <vobj_count> ] [ <vxlan_vobj_count> ] [ <vxlan> ] [ <vobj_list_header> ] [ <vobj-id> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  |  |
| forwarding            | Display fib information                                |
| ecmp                  | Show information about ECMPs                           |
| vrf                   | (Optional) display info per VRF                        |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| lisp                  | (Optional) Show information about LISP ECMPs           |
| platform              | (Optional) one command to show pi and pd info together |
| module                | (Optional) slot  |
| <i>module</i>         | (Optional) slot number                                 |
| partial               | (Optional) Show partially installed ECMPs              |
| __readonly__          | (Optional)   |
| <i>header</i>         | (Optional) o/p header                                  |
| <i>ecmp_hash</i>      | (Optional) ecmp hash                                   |
| <i>intf</i>           | (Optional) interface                                   |
| <i>nh</i>             | (Optional) next hop                                    |
| <i>v6nh</i>           | (Optional) V6 next hop                                 |
| <i>hw_index</i>       | (Optional) Hw index                                    |
| <i>num_mpls</i>       | (Optional) No of MPLS ecmp                             |
| <i>holder</i>         | (Optional) holder bitmap                               |
| <i>refcount</i>       | (Optional) refcount                                    |
| <i>sw_ptr</i>         | (Optional) Software pointer                            |

|                         |                             |
|-------------------------|-----------------------------|
| <i>num_paths</i>        | (Optional) No of paths      |
| <i>ecmp_partial</i>     | (Optional) partial ecmp     |
| TABLE_ecmp              | (Optional) ecmp table       |
| <i>hash</i>             | (Optional) ecmp hash        |
| <i>num_paths</i>        | (Optional) No of paths      |
| <i>hwindex</i>          | (Optional) Hw index         |
| <i>ecmppartial</i>      | (Optional) partial ecmp     |
| TABLE_index             | (Optional) index table      |
| <i>ecmp_idx</i>         | (Optional) hw ecmp index    |
| <i>cmn_idx</i>          | (Optional) cmn index        |
| <i>refcnt</i>           | (Optional) refcount         |
| <i>ecmp_holder</i>      | (Optional) holder bitmap    |
| TABLE_adjacency         | (Optional) adjacency table  |
| <i>intf</i>             | (Optional) interface        |
| <i>nh</i>               | (Optional) next hop         |
| <i>v6nh</i>             | (Optional) v6 next hop      |
| <i>hw_adj_idx</i>       | (Optional) hw adj index     |
| <i>hw_cmn_idx</i>       | (Optional) hw cmn index     |
| <i>lif</i>              | (Optional) lif              |
| <i>hw_nve_adj_idx</i>   | (Optional) nve adj index    |
| <i>hw_nve_cmn_idx</i>   | (Optional) nve cmn index    |
| <i>nve_lif</i>          | (Optional) nve lif          |
| <i>vobj_count</i>       | (Optional) vobj count       |
| <i>vxlan_vobj_count</i> | (Optional) vxlan vobj count |
| <i>vxlan</i>            | (Optional) vxlan            |
| <i>vobj_list_header</i> | (Optional) vobj list header |
| <i>vobj-id</i>          | (Optional) vobj id          |

**Command Mode**

- /exec

## show forwarding ecmp recursive

```
show forwarding ecmp recursive [ platform ] [ srv6 ] [ max-display-count <display_count> ] [ module <module> ] [ partial ] [ __readonly__ [ TABLE_vobj { [ <header_vobj> ] [ <header_ecmp> } ] [ TABLE_vobj_idx { [ <hw_vobj_index> ] [ <cmn_index> } ] ] [ <num_pfxs> ] [ <ecmp_partial> ] [ <activepath_hdr> ] [ <ecmp_hw_prog_fail> ] [ TABLE_active { [ TABLE_activepath { [ <ap_nh> ] [ <ap_v6nh> ] [ <ap_rnh_len> ] [ <ap_nh_vpn_label> ] [ <ap_rnh_table_id> ] [ <ap_nh_weight> } ] } ] [ <backuppath_hdr> ] [ TABLE_backuppath { [ <bp_nh> ] [ <bp_v6nh> ] [ <bp_nh_vpn_label> ] [ <bp_rnh_table_id> ] [ <bp_nh_weight> } ] ] [ <cnh_hdr> ] [ TABLE_cnh { [ <nh> ] [ <v6nh> ] [ <intf> ] [ TABLE_cnh_adj { [ <hw_adj> ] [ <hw_cmn_index> ] [ <lif> } ] } ] [ <hw_inst_n> ] [ <ls_count_n> ] [ <hw_inst_o> ] [ <ls_count_o> ] [ <fec_type> ] [ <header_fec_ecmp> ] [ <hw_vobj_fec_idx> ] [ <cmn_idx> ] [ <vobj_hw_inst_n> ] [ <vobj_ls_count_n> ] [ <vobj_hw_inst_o> ] [ <vobj_ls_count_o> ] [ <vobj_refcount> ] [ <vobj_function> ] [ TABLE_vobj_ecmp { [ <ec_hash> ] [ <ec_num_paths> ] [ <ec_hwinde> ] [ <ec_ecmpartial> ] [ <ec_refcnt> ] [ <ec_ecmp_holder> } ] [ TABLE_adjacency_ec { [ <ec_intf> ] [ <ec_nh> ] [ <ec_v6nh> ] [ <ec_hw_adj_idx> ] [ <ec_hw_cmn_idx> ] [ <ec_lif> ] [ <ec_hw_nve_adj_idx> ] [ <ec_hw_nve_cmn_idx> ] [ <ec_nve_lif> } ] } ] [ <ec_vobj_count> ] [ <ec_vxlan_vobj_count> ] [ <ec_vxlan> ] [ <ec_vobj_list_header> ] ] ] [ <header> <num_pfxs> <rn timer_id> <rn timer_len> <v6nh> <hw_instance> <nh_vpn_label> <nh_weight> <cnh_intf> <ecmp_partial> ] [ TABLE_ecmp { [ <hash> ] [ <num_paths> ] [ <hwinde> ] [ <ecmpartial> ] [ TABLE_index { [ <ecmp_idx> ] [ <cmn_idx> } ] ] [ <refcnt> ] [ <ecmp_holder> } ] [ TABLE_adjacency { [ <intf> ] [ <nh> ] [ <v6nh> ] [ <hw_adj_idx> ] [ <hw_cmn_idx> ] [ <lif> ] [ <hw_nve_adj_idx> ] [ <hw_nve_cmn_idx> ] [ <nve_lif> } ] } ] [ <vobj_count> ] [ <vxlan_vobj_count> ] [ <vxlan> ] [ <vobj_list_header> ] [ TABLE_vobj_id { [ <vobj-id> } ] ] [ <vobj_function> ] ] ]
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 |  |
| forwarding           | Display fib information                                |
| ecmp                 | Show information about ECMPs                           |
| recursive            | Show information about recursive ECMPs                 |
| platform             | (Optional) one command to show pi and pd info together |
| srv6                 | (Optional) Show information about SRV6 encap           |
| module               | (Optional) slot  |
| partial              | (Optional) Show partially installed ECMPs              |
| <i>module</i>        | (Optional) slot number                                 |
| max-display-count    | (Optional) displays max # of routes                    |
| <i>display_count</i> | (Optional) count                                       |
| <i>__readonly__</i>  | (Optional)   |
| TABLE_vobj           | (Optional) Table vobj                                  |
| <i>header_vobj</i>   | (Optional) vobj o/p header                             |

|                          |   |
|--------------------------|---|
| <i>header_ecmp</i>       | (Optional) ecmp o/p header                              |
| TABLE_vobj_idx           | (Optional) Table vobj index                             |
| <i>hw_vobj_index</i>     | (Optional) HW VOBJ Index                                |
| <i>cmn_index</i>         | (Optional) cmn index                                    |
| <i>num_pfxs</i>          | (Optional) Number of prefixes using this virtual object |
| <i>ecmp_partial</i>      | (Optional) partial ecmp                                 |
| <i>ecmp_hw_prog_fail</i> | (Optional) Ecmp Hardware Program failure                |
| <i>actvepath_hdr</i>     | (Optional) o/p header                                   |
| TABLE_active             | (Optional) table active                                 |
| TABLE_activepath         | (Optional) table active path                            |
| <i>ap_nh</i>             | (Optional) Next hop info                                |
| <i>ap_v6nh</i>           | (Optional) v6 Next hop info                             |
| <i>ap_rnh_len</i>        | (Optional) Next hop mask length                         |
| <i>ap_nh_vpn_label</i>   | (Optional) NH VPN label                                 |
| <i>ap_rnh_table_id</i>   | (Optional) The table id where the RNHs are present      |
| <i>ap_nh_weight</i>      | (Optional) weighted ecmp info                           |
| <i>backuppath_hdr</i>    | (Optional) o/p header                                   |
| TABLE_backuppath         | (Optional) backup path table                            |
| <i>bp_nh</i>             | (Optional) Next hop info                                |
| <i>bp_v6nh</i>           | (Optional) v6 Next hop info                             |
| <i>bp_nh_vpn_label</i>   | (Optional) NH VPN label                                 |
| <i>bp_rnh_table_id</i>   | (Optional) The table id where the RNHs are present      |
| <i>bp_nh_weight</i>      | (Optional) weighted ecmp info                           |
| <i>cnh_hdr</i>           | (Optional) o/p header                                   |
| TABLE_cnh                | (Optional) cnh table                                    |
| <i>nh</i>                | (Optional) Next hop info                                |
| <i>v6nh</i>              | (Optional) v6 Next hop info                             |
| <i>intf</i>              | (Optional) cnh output interface                         |
| TABLE_cnh_adj            | (Optional) Table cnh adjacency                          |



|                        |                                       |
|------------------------|---------------------------------------|
| <i>hw_adj</i>          | (Optional) cnh hw adjacency           |
| <i>hw_cmn_index</i>    | (Optional) cnh hw cmn idx             |
| <i>lif</i>             | (Optional) lif                        |
| <i>hw_inst_n</i>       | (Optional) Hardware instance info new |
| <i>ls_count_n</i>      | (Optional) ls count new               |
| <i>hw_inst_o</i>       | (Optional) Hardware instance info old |
| <i>ls_count_o</i>      | (Optional) ls count old               |
| <i>fec_type</i>        | (Optional) fec type                   |
| <i>header_fec_ecmp</i> | (Optional) o/p header                 |
| <i>hw_vobj_fec_idx</i> | (Optional) hw fec idx                 |
| <i>cmn_idx</i>         | (Optional) cmn idx                    |
| <i>vobj_hw_inst_n</i>  | (Optional) vobj hw instance           |
| <i>vobj_ls_count_n</i> | (Optional) ls count new               |
| <i>vobj_hw_inst_o</i>  | (Optional) hw instnace info old       |
| <i>vobj_ls_count_o</i> | (Optional) ls count old               |
| <i>vobj_refcount</i>   | (Optional) vobj refcount              |
| <i>vobj_function</i>   | (Optional) vobj function              |
| TABLE_vobj_ecmp        | (Optional) ecmp table                 |
| <i>ec_hash</i>         | (Optional) ecmp hash                  |
| <i>ec_num_paths</i>    | (Optional) No of paths                |
| <i>ec_hwindex</i>      | (Optional) Hw index                   |
| <i>ec_ecmppartial</i>  | (Optional) partial ecmp               |
| <i>ec_refcnt</i>       | (Optional) refcount                   |
| <i>ec_ecmp_holder</i>  | (Optional) holder bitmap              |
| TABLE_adjacency_ec     | (Optional) adjacency table            |
| <i>ec_intf</i>         | (Optional) interface                  |
| <i>ec_nh</i>           | (Optional) next hop                   |
| <i>ec_v6nh</i>         | (Optional) v6 next hop                |
| <i>ec_hw_adj_idx</i>   | (Optional) hw adj index               |

|                            |   |
|----------------------------|---|
| <i>ec_hw_cmn_idx</i>       | (Optional) hw cmn index                                 |
| <i>ec_lif</i>              | (Optional) lif  |
| <i>ec_hw_nve_adj_idx</i>   | (Optional) nve adj index                                |
| <i>ec_hw_nve_cmn_idx</i>   | (Optional) nve cmn index                                |
| <i>ec_nve_lif</i>          | (Optional) nve lif                                      |
| <i>ec_vobj_count</i>       | (Optional) vobj count                                   |
| <i>ec_vxlan_vobj_count</i> | (Optional) vxlan vobj count                             |
| <i>ec_vxlan</i>            | (Optional) vxlan  |
| <i>ec_vobj_list_header</i> | (Optional) vobj list header                             |
| <i>vobj_function</i>       | (Optional) vobj function                                |
| <i>header</i>              | (Optional) o/p header                                   |
| <i>num_pfxs</i>            | (Optional) Number of prefixes using this virtual object |
| <i>rnh_table_id</i>        | (Optional) The table id where the RNHs are present      |
| <i>nh</i>                  | (Optional) Next hop info                                |
| <i>rnh_len</i>             | (Optional) Next hop mask length                         |
| <i>v6nh</i>                | (Optional) V6 Next hop info                             |
| <i>hw_instance</i>         | (Optional) Hardware instance info                       |
| <i>nh_vpn_label</i>        | (Optional) NH VPN label                                 |
| <i>nh_weight</i>           | (Optional) weighted ecmp info                           |
| <i>cnh_intf</i>            | (Optional) cnh output interface                         |
| <i>ecmp_partial</i>        | (Optional) partial ecmp                                 |
| TABLE_ecmp                 | (Optional) ecmp table                                   |
| <i>hash</i>                | (Optional) ecmp hash                                    |
| <i>num_paths</i>           | (Optional) No of paths                                  |
| <i>hwindex</i>             | (Optional) Hw index                                     |
| <i>ecmppartial</i>         | (Optional) partial ecmp                                 |
| TABLE_index                | (Optional) index table                                  |
| <i>ecmp_idx</i>            | (Optional) hw ecmp index                                |
| <i>cmn_idx</i>             | (Optional) cmn index                                    |

|                         |                             |
|-------------------------|-----------------------------|
| <i>refcnt</i>           | (Optional) refcount         |
| <i>ecmp_holder</i>      | (Optional) holder bitmap    |
| TABLE_adjacency         | (Optional) adjacency table  |
| <i>intf</i>             | (Optional) interface        |
| <i>nh</i>               | (Optional) next hop         |
| <i>v6nh</i>             | (Optional) v6 next hop      |
| <i>hw_adj_idx</i>       | (Optional) hw adj index     |
| <i>hw_cmn_idx</i>       | (Optional) hw cmn index     |
| <i>lif</i>              | (Optional) lif              |
| <i>hw_nve_adj_idx</i>   | (Optional) nve adj index    |
| <i>hw_nve_cmn_idx</i>   | (Optional) nve cmn index    |
| <i>nve_lif</i>          | (Optional) nve lif          |
| <i>vobj_count</i>       | (Optional) vobj count       |
| <i>vxlان_vobj_count</i> | (Optional) vxlan vobj count |
| <i>vxlان</i>            | (Optional) vxlan            |
| <i>vobj_list_header</i> | (Optional) vobj list header |
| TABLE_vobj_id           | (Optional) vobj_id table    |
| <i>vobj-id</i>          | (Optional) vobj id          |

**Command Mode**

- /exec

## show forwarding inconsistency

```
show forwarding [ ip | ipv4 ] [ unicast ] inconsistency [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ]
[ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id> ]
] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adj> ] [ TABLE_inconsistency_adj { <id> <slot> [ <unit> ]
] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ] <reason> } ] [ <inconsis_routes> ] [
TABLE_inconsistency_routes { <id> <slot> [ <unit> ] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ]
<reason> } ] [ <run_status> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | show  |
| forwarding              | Display Forwarding Information                |
| ip                      | (Optional) ipv4                               |
| ipv4                    | (Optional) ipv4                               |
| unicast                 | (Optional) unicast                            |
| inconsistency           | route inconsistency check                     |
| suppress-transient      | (Optional) Suppress Transient state           |
| vrf                     | (Optional) check routes for a specific VRF    |
| <i>vrf-name</i>         | (Optional) VRF name                           |
| module                  | (Optional) check routes for a specific module |
| <i>module</i>           | (Optional) module number                      |
| all_modules             | (Optional) all module's                       |
| all_vrfs                | (Optional) all vrf's                          |
| <i>__readonly__</i>     | (Optional)                                    |
| <i>err_str</i>          | (Optional)                                    |
| <i>cc_header</i>        | (Optional)                                    |
| <i>table_id</i>         | (Optional)                                    |
| <i>slot_id</i>          | (Optional)                                    |
| <i>exec_time</i>        | (Optional)                                    |
| <i>elapsed_time</i>     | (Optional)                                    |
| <i>inconsis_adj</i>     | (Optional)                                    |
| TABLE_inconsistency_adj | (Optional)                                    |

|                            |            |
|----------------------------|------------|
| <i>id</i>                  | (Optional) |
| <i>slot</i>                | (Optional) |
| <i>unit</i>                | (Optional) |
| <i>vrf</i>                 | (Optional) |
| <i>ipaddr</i>              | (Optional) |
| <i>ipprefix</i>            | (Optional) |
| <i>interface</i>           | (Optional) |
| <i>reason</i>              | (Optional) |
| <i>inconsis_routes</i>     | (Optional) |
| TABLE_inconsistency_routes | (Optional) |
| <i>id</i>                  | (Optional) |
| <i>slot</i>                | (Optional) |
| <i>unit</i>                | (Optional) |
| <i>vrf</i>                 | (Optional) |
| <i>ipaddr</i>              | (Optional) |
| <i>ipprefix</i>            | (Optional) |
| <i>interface</i>           | (Optional) |
| <i>reason</i>              | (Optional) |
| <i>run_status</i>          | (Optional) |

**Command Mode**

- /exec

# show forwarding interfaces

```
show forwarding interfaces [ module <module> ] [ __readonly__ TABLE_intf_str <intf> <v4adjcnt> <v6adjcnt>
<v4rpfmode> <v6rpfmode> <mac> ]
```

## Syntax Description

|                  |                                    |
|------------------|------------------------------------|
| show             |                                    |
| forwarding       | fib information                    |
| interfaces       | show fib interface info            |
| __readonly__     | (Optional)                         |
| TABLE_intf_str   | (Optional) show interface string   |
| <i>intf</i>      | (Optional) interface name          |
| module           | (Optional) slot                    |
| <i>module</i>    | (Optional) slot number             |
| <i>v4adjcnt</i>  | (Optional) count of v4 adjacencies |
| <i>v6adjcnt</i>  | (Optional) count of v6 adjacencies |
| <i>mac</i>       | (Optional) mac address             |
| <i>v4rpfmode</i> | (Optional) v4 uRPF mode            |
| <i>v6rpfmode</i> | (Optional) v6 uRPF mode            |

## Command Mode

- /exec

## show forwarding ipv6

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] ipv6 [ route | rnhdb
] [ recursive ] [ detail | summary | platform | partial | <prefix> [ longer-prefixes ] [ detail | platform ] | <address>
] [ detail | platform ] | interface <interface> | next-hop <nh> | attached | unresolved | adjacency { <aif> <anh>
| drop | glean | punt } ] [ max-display-count <display_count> ] [ module <module> | vrf { <vrf-name> |
<vrf-known-name> | <vrf-all> } ] + [ __readonly__ [ <prefix_count> ] [ TABLE_vrf { [ <vrfname> ] [
<tblname> ] [ <tableid> ] [ TABLE_prefix { [ <pxf> ] [ <num_paths> ] [ TABLE_path { [ <nexthop> |
<special> ] [ <intf> ] [ <route_updates> ] [ <route_inserts> ] [ <route_deletes> ] [ <route_count> ] [
<path_count> ] [ TABLE_mask { [ <mask_length> ] [ <routes_per_mask> ] } } ] [ <hw_handle> ] [ <flags>
] [ <holder> ] [ <nxt_obj_type> ] [ <hw_idx_v6adj> ] [ <cmn-idx> ] [ <lif> ] [ <buf-idx> ] } } ] [ <packet_cnt>
] [ <byte_cnt> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  |  |
| forwarding            | display fib information                                |
| vrf                   | (Optional) display info per VRF                        |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| vrf-all               | (Optional) Display information for all VRFs            |
| table                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |
| <i>table_id</i>       | (Optional) table id in hex                             |
| ipv6                  | ipv6   |
| route                 | (Optional) display IP routing table                    |
| platform              | (Optional) one command to show pi and pd info together |
| rnhdb                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |
| recursive             | (Optional) display routes with recursive next hops     |
| detail                | (Optional) show detailed information about the routes  |
| summary               | (Optional) display route counts                        |
| partial               | (Optional) display routes with partial ECMPs           |
| longer-prefixes       | (Optional) display longer prefixes                     |
| interface             | (Optional) display routes with this output i/f only    |
| <i>interface</i>      | (Optional) output interface                            |
| next-hop              | (Optional) display routes with this next-hop only      |

|                      |   |
|----------------------|---|
| attached             | (Optional) display directly connected routes  |
| unresolved           | (Optional) display unresolved routes          |
| adjacency            | (Optional) display adjacency information      |
| <i>aif</i>           | (Optional) adjacency output interface         |
| drop                 | (Optional) display routes via drop adjacency  |
| glean                | (Optional) display routes via glean adjacency |
| punt                 | (Optional) display routes via punt adjacency  |
| module               | (Optional) slot                               |
| <i>module</i>        | (Optional) slot number                        |
| max-display-count    | (Optional) displays max # of routes           |
| <i>display_count</i> | (Optional) count                              |
| __readonly__         | (Optional)                                    |
| TABLE_vrf            | (Optional) vrf table                          |
| <i>vrfname</i>       | (Optional) VRF name                           |
| <i>tblname</i>       | (Optional) table name                         |
| <i>tableid</i>       | (Optional) table id                           |
| <i>prefix_count</i>  | (Optional) total number of prefix in VRF      |
| TABLE_prefix         | (Optional) all xml prefix entries             |
| <i>px</i>            | (Optional) ipv6 prefix                        |
| <i>num_paths</i>     | (Optional) no of paths                        |
| TABLE_path           | (Optional) path table                         |
| <i>nexthop</i>       | (Optional) next hop address                   |
| <i>special</i>       | (Optional) special adjacencies                |
| <i>intf</i>          | (Optional) output interface                   |
| <i>route_updates</i> | (Optional) route update in VRF                |
| <i>route_inserts</i> | (Optional) route insert in VRF                |
| <i>route_deletes</i> | (Optional) route delete in VRF                |
| <i>route_count</i>   | (Optional) total number of routes in VRF      |
| <i>path_count</i>    | (Optional) total number of paths in VRF       |



|                        |                            |
|------------------------|----------------------------|
| <i>TABLE_mask</i>      | (Optional) mask table      |
| <i>mask_length</i>     | (Optional) length of mask  |
| <i>routes_per_mask</i> | (Optional) routes per mask |
| <i>hw_handle</i>       | (Optional) hw handle       |
| <i>flags</i>           | (Optional) flags           |
| <i>holder</i>          | (Optional) holder          |
| <i>nxt_obj_type</i>    | (Optional) next obj type   |
| <i>hw_idx_v6adj</i>    | (Optional) v6 adj hw idx   |
| <i>cmn-idx</i>         | (Optional) cmn idx         |
| <i>lif</i>             | (Optional) lif             |
| <i>buf-idx</i>         | (Optional) Buffer index    |
| <i>packet_cnt</i>      | (Optional) Packet count    |
| <i>byte_cnt</i>        | (Optional) Byte count      |

**Command Mode**

- /exec

## show forwarding ipv6 adjacency

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 adjacency [ mpls ] [ nve ] [ <aif> ] [ <anh> ] [ detail | stats | platform ] [ module <module> ] [ __readonly__ [ <adj-count> ] [ TABLE_adj { [ <fec> ] <nexthop> <rewinfo> [ <interface> ] [ <pkts> ] [ <bytes> ] [ <bgp_rnh> ] [ <bgp_orig_as> ] [ <bgp_peer_as> ] [ <hh> ] [ <refcount> ] } ] ] [ TABLE_v6_adj { [ <nh> ] [ <rwinfo> ] [ <intf> ] [ <intf_idx> ] [ <hh> ] [ <refcnt> ] [ <flags> ] [ <holder> ] [ <pbr_cnt> ] [ <wccp_cnt> ] [ TABLE_index { [ <hw_adj> ] [ <cmn-idx> ] [ <lif> ] } ] } ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  |  |
| forwarding            | display fib information                                |
| ipv6                  | ipv6   |
| adjacency             | display adjacency information                          |
| platform              | (Optional) one command to show pi and pd info together |
| vrf                   | (Optional) display info per VRF                        |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| vrf-all               | (Optional) Display information for all VRFs            |
| mpls                  | (Optional) mpls adjacency information                  |
| nve                   | (Optional) nve adjacency information                   |
| <i>aif</i>            | (Optional) adjacency output interface                  |
| detail                | (Optional) detail                                      |
| stats                 | (Optional) adjacency statistics                        |
| module                | (Optional) slot  |
| <i>module</i>         | (Optional) slot number                                 |
| __readonly__          | (Optional)   |
| <i>adj-count</i>      | (Optional) total adj count                             |
| TABLE_adj             | (Optional) Table Adjacency                             |
| <i>fec</i>            | (Optional) FEC info                                    |
| <i>nexthop</i>        | (Optional) next hop address                            |
| <i>rewinfo</i>        | (Optional) rewrite information                         |

|                    |                                |
|--------------------|--------------------------------|
| <i>interface</i>   | (Optional) output interface    |
| <i>pkts</i>        | (Optional) packet stats        |
| <i>bytes</i>       | (Optional) bytes stats         |
| <i>bgp_rnh</i>     | (Optional) next hop address    |
| <i>bgp_orig_as</i> | (Optional) bgp orig as         |
| <i>bgp_peer_as</i> | (Optional) bgp peer as         |
| <i>hh</i>          | (Optional) Hardware Handle     |
| <i>refcount</i>    | (Optional) reference count     |
| TABLE_v6_adj       | (Optional) Table Adjacency     |
| <i>nh</i>          | (Optional) next hop address    |
| <i>rwinfo</i>      | (Optional) rewrite information |
| <i>intf</i>        | (Optional) output interface    |
| <i>intf_idx</i>    | (Optional) Interface index     |
| <i>hh</i>          | (Optional) Hardware Handle     |
| <i>refcnt</i>      | (Optional) reference count     |
| <i>flags</i>       | (Optional) Adjacency flags     |
| <i>holder</i>      | (Optional) Holder bitmap       |
| <i>pbr_cnt</i>     | (Optional) PBR count           |
| <i>wccp_cnt</i>    | (Optional) WCCP count          |
| TABLE_index        | (Optional) HW index table      |
| <i>hw_adj</i>      | (Optional) v4 adj hw index     |
| <i>cmn-idx</i>     | (Optional) CMN Index           |
| <i>lif</i>         | (Optional) LIF                 |

**Command Mode**

- /exec

## show forwarding ipv6 inconsistency

```
show forwarding ipv6 [ unicast ] inconsistency [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ] [ module
{ <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id> ] [
<exec_time> ] [ <elapsed_time> ] [ <inconsis_adjs> ] [ TABLE_inconsistency_adjs { <idipv6> <slotipv6>
[ <unitipv6> ] <vrfipv6> [ <ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [
<inconsis_routes> ] [ TABLE_inconsistency_routes { <idipv6> <slotipv6> [ <unitipv6> ] <vrfipv6> [
<ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [ <run_status> ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | show  |
| forwarding               | Display Forwarding Information                |
| ipv6                     | ipv6  |
| unicast                  | (Optional) unicast                            |
| inconsistency            | route inconsistency check                     |
| suppress-transient       | (Optional) Suppress Transient state           |
| vrf                      | (Optional) check routes for a specific VRF    |
| <i>vrf-name</i>          | (Optional) VRF name                           |
| module                   | (Optional) check routes for a specific module |
| <i>module</i>            | (Optional) module number                      |
| all_modules              | (Optional) all module's                       |
| all_vrfs                 | (Optional) all vrf's                          |
| __readonly__             | (Optional)                                    |
| <i>err_str</i>           | (Optional)                                    |
| <i>cc_header</i>         | (Optional)                                    |
| <i>table_id</i>          | (Optional)                                    |
| <i>slot_id</i>           | (Optional)                                    |
| <i>exec_time</i>         | (Optional)                                    |
| <i>elapsed_time</i>      | (Optional)                                    |
| <i>inconsis_adjs</i>     | (Optional)                                    |
| TABLE_inconsistency_adjs | (Optional)                                    |
| <i>idipv6</i>            | (Optional)                                    |

|                            |            |
|----------------------------|------------|
| <i>slotipv6</i>            | (Optional) |
| <i>unitipv6</i>            | (Optional) |
| <i>vrfigpv6</i>            | (Optional) |
| <i>interfaceipv6</i>       | (Optional) |
| <i>reasonipv6</i>          | (Optional) |
| <i>inconsis_routes</i>     | (Optional) |
| TABLE_inconsistency_routes | (Optional) |
| <i>idipv6</i>              | (Optional) |
| <i>slotipv6</i>            | (Optional) |
| <i>unitipv6</i>            | (Optional) |
| <i>vrfigpv6</i>            | (Optional) |
| <i>interfaceipv6</i>       | (Optional) |
| <i>reasonipv6</i>          | (Optional) |
| <i>run_status</i>          | (Optional) |

**Command Mode**

- /exec

## show forwarding ipv6 multicast route

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | all } | table <tab_id> ] ipv6 multicast route { [
group { <group> | <group_addr> } [ source { <source> | <source_addr> } ] | module <module> | vrf {
<vrf-name> | all } ] + | summary [ module <module> | vrf { <vrf-name> | <vrf-known-name> | all } ] + } [
__readonly__ [ <table_type> ] [ <vrfname> ] [ <table_id> ] [ <num_routes> <num_starg_routes>
<num_sg_routes> <num_gprefix_routes> ] [ <num_groups> ] [ <num_sources> ] [ <num_prefix_insert_fail>
] [ [ TABLE_MROUTE_INFO <address> [ <src_len> <grp_len> ] [ <df_ordinal> ] [ <rpfif> ] [ <rpf_ifindex>
] <flag> [ <flag_value> ] <route_pkts> <route_bytes> <oiflist_id> <oif_count> <oiflist_flag> [
TABLE_OIF_INFO <oifindex> [ <vlan> ] [ TABLE_MCAST_OIF_INTF_INFO [ <oifname> ] [ <dviif> ] ]
[ <platform_id> ] [ <encap_id> ] [ <hw_index> ] ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  |   |
| forwarding            | display fib information                     |
| ipv6                  | ipv6  |
| multicast             | IPV6 related Multicast information          |
| route                 | Multicast route information                 |
| vrf                   | (Optional) display info per VRF             |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| table                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>tab_id</i>         | (Optional) table number                     |
| group                 | (Optional) Multicast IPv6 Group Address     |
| source                | (Optional) Multicast IPv6 Source Address    |
| summary               | display route counts                        |
| module                | (Optional) slot                             |
| <i>module</i>         | (Optional) slot number                      |
| __readonly__          | (Optional)                                  |
| <i>table_type</i>     | (Optional) Table Type                       |
| <i>vrfname</i>        | (Optional) VRF name                         |
| <i>table_id</i>       | (Optional) Table ID                         |

|                               |   |
|-------------------------------|---|
| <i>num_routes</i>             | (Optional) Number of routes                               |
| <i>num_starg_routes</i>       | (Optional) Number of (*,G) routes                         |
| <i>num_sg_routes</i>          | (Optional) Number of (S,G) routes                         |
| <i>num_gprefix_routes</i>     | (Optional) Number of (*,G-prefix) routes                  |
| <i>num_groups</i>             | (Optional) Number of group entries in the table           |
| <i>num_prefix_insert_fail</i> | (Optional) Prefix insert fail count                       |
| <i>num_sources</i>            | (Optional) Number of (S, G) entries for the group address |
| TABLE_MROUTE_INFO             | (Optional) Mroute info                                    |
| <i>address</i>                | (Optional) Mcast address                                  |
| <i>src_len</i>                | (Optional) Source Address Mask                            |
| <i>grp_len</i>                | (Optional) Group address Mask                             |
| <i>df_ordinal</i>             | (Optional) DF ordinal                                     |
| <i>rpfif</i>                  | (Optional) RPF interface                                  |
| <i>rpf_ifindex</i>            | (Optional) RPF Interface ifIndex                          |
| <i>flag</i>                   | (Optional) Route type flag                                |
| <i>flag_value</i>             | (Optional) hex value of route flag                        |
| <i>route_pkts</i>             | (Optional) Route packet count                             |
| <i>route_bytes</i>            | (Optional) Route bytes                                    |
| <i>oiflist_id</i>             | (Optional) OIF list Identifier                            |
| <i>oif_count</i>              | (Optional) Number of OIFs                                 |
| <i>oiflist_flag</i>           | (Optional) OIF List flag                                  |
| TABLE_OIF_INFO                | (Optional) OIF Info                                       |
| <i>oifindex</i>               | (Optional) OIF Interface ifIndex                          |
| <i>vlan</i>                   | (Optional) Vlan id  |
| TABLE_MCAST_OIF_INTF_INFO     | (Optional) OIF Interfaces                                 |
| <i>oifname</i>                | (Optional) OIF Interface name                             |
| <i>dvif</i>                   | (Optional) DVIF   |
| <i>platform_id</i>            | (Optional) Platform-index                                 |
| <i>encap_id</i>               | (Optional) Encap ID                                       |

|                 |                           |
|-----------------|---------------------------|
| <i>hw_index</i> | (Optional) Hardware index |
|-----------------|---------------------------|

**Command Mode**

- /exec



# show forwarding kvfib cache on

show forwarding kvfib cache { on | off }

## Syntax Description

|            |                 |
|------------|-----------------|
| show       |                 |
| forwarding | fib information |
| kvfib      | kvfib           |
| cache      | cache           |
| on         | set variable    |
| off        | reset variable  |

## Command Mode

- /exec

# show forwarding l2 multicast

```
show forwarding l2 multicast { [ { vlan <vlan-id> [ { group <grpaddr> source <srcaddr> } | { group
<v6grpaddr> source <v6srcaddr> } | destination-mac <dstmac> } ] } ] [ vdc <vdc-id> ] [ module <num> ] [
__readonly__ [ TABLE_L2_MCAST_INFO <vlan_id> [ <group> ] [ <group_v6> ] [ <source> ] [ <source_v6>
] [ <dmac> ] <epoch> <resource_id> <dest_index> [ <hw_handle> ] [ <text> ] [ <value> ] ] ] }
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| forwarding          | Forwarding information                    |
| l2                  | L2 related information                    |
| multicast           | Multicast related information             |
| vlan                | (Optional) Information Specific to a Vlan |
| <i>vlan-id</i>      | (Optional) Vlan id value                  |
| group               | (Optional) (S,G) specific information     |
| <i>grpaddr</i>      | (Optional) Group address                  |
| source              | (Optional) source specific information    |
| <i>srcaddr</i>      | (Optional) Source address                 |
| destination-mac     | (Optional) Destination MAC address        |
| <i>dstmac</i>       | (Optional) Ethernet MAC address           |
| vdc                 | (Optional) VDC                            |
| <i>vdc-id</i>       | (Optional) VDC id                         |
| module              | (Optional) Slot                           |
| <i>num</i>          | (Optional) Slot number                    |
| <i>__readonly__</i> | (Optional)                                |
| TABLE_L2_MCAST_INFO | (Optional) L2 Multicast Info              |
| <i>vlan_id</i>      | (Optional) Vlan Identifier                |
| <i>group</i>        | (Optional) Multicast IPv4 Group Address   |
| <i>group_v6</i>     | (Optional) Multicast IPv6 Group Address   |
| <i>source</i>       | (Optional) Multicast IPv4 Source Address  |
| <i>source_v6</i>    | (Optional) Multicast IPv6 Source Address  |

|                    |   |
|--------------------|---|
| <i>dmac</i>        | (Optional) Destination MAC address      |
| <i>epoch</i>       | (Optional) Epoch number                 |
| <i>resource_id</i> | (Optional) Resource Identifier          |
| <i>dest_index</i>  | (Optional) Destination Index Identifier |
| <i>hw_handle</i>   | (Optional) Hardware Handle              |
| <i>text</i>        | (Optional) String                       |
| <i>value</i>       | (Optional) Value                        |

**Command Mode**

- /exec

# show forwarding l2vpn label vpls

show forwarding l2vpn label [ <label\_id> ] vpls [ module module ] [ \_\_readonly\_\_ <label\_id> ]

## Syntax Description

|                 |                        |
|-----------------|------------------------|
| show            | show                   |
| forwarding      | forwarding             |
| l2vpn           | l2vpn forwarding       |
| label           | VC label               |
| <i>label_id</i> | (Optional) VC label    |
| vpls            | VPLS                   |
| module          | (Optional) slot        |
| <i>module</i>   | (Optional) slot number |
| __readonly__    | (Optional)             |
| <i>label_id</i> | (Optional) Label ID    |

## Command Mode

- /exec

## show forwarding l2vpn label xconnect

show forwarding l2vpn label [ <label\_id> ] xconnect [ module module ] [ \_\_readonly\_\_ <label\_id> ]

### Syntax Description

|                 |                        |
|-----------------|------------------------|
| show            | show                   |
| forwarding      | forwarding             |
| l2vpn           | l2vpn forwarding       |
| label           | VC label               |
| <i>label_id</i> | (Optional) VC label    |
| xconnect        | xconnect or VPWS       |
| module          | (Optional) slot        |
| <i>module</i>   | (Optional) slot number |
| __readonly__    | (Optional)             |
| <i>label_id</i> | (Optional) Label ID    |

### Command Mode

- /exec

# show forwarding l2vpn vlan

show forwarding l2vpn vlan [ <vlan\_id> ] [ module <module> ] [ \_\_readonly\_\_ <vlan> ]

## Syntax Description

|                     |                        |
|---------------------|------------------------|
| show                | show                   |
| forwarding          | forwarding             |
| l2vpn               | l2vpn forwarding       |
| vlan                | vlan                   |
| <i>vlan_id</i>      | (Optional) vlan id     |
| module              | (Optional) slot        |
| <i>module</i>       | (Optional) slot number |
| <i>__readonly__</i> | (Optional)             |
| <i>vlan</i>         | (Optional) vlan        |

## Command Mode

- /exec

## show forwarding mpls

```
show forwarding mpls [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } [ label <label-id> | <prefix> |
<v6prefix> ] | table <table_id> [ label <label-id> | <prefix> | <v6prefix> ] | label-space <label-space-id> |
label <label-id> | <prefix> | <v6prefix> ] [ stats ] [ module <module> ] [ implicit ] [ platform ] [ __readonly__
[ { TABLE_mpls <label> [ { TABLE_table_id [ <out-table-id> ] [ <fec> ] [ <out-ip> ] [ <out-intf> ] [
<out-label> ] [ <out-op> ] [ <hh> ] [ <ref-count> ] [ <hw-index> ] } ] [ <in-pkts> ] [ <in-bytes> ] [
<swap-out-pkts> ] [ <swap-out-bytes> ] [ <tunnel-out-pkts> ] [ <tunnel-out-bytes> ] } ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | show   |
| forwarding            | forwarding                                     |
| mpls                  | mpls forwarding                                |
| vrf                   | (Optional) display info per VRF                |
| <i>vrf-name</i>       | (Optional) VRF name                            |
| <i>vrf-known-name</i> | (Optional) Known vrf name                      |
| vrf-all               | (Optional) Display information for all VRFs    |
| table                 | (Optional) display info per vpn-id             |
| <i>table_id</i>       | (Optional) table number                        |
| label-space           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED      |
| <i>label-space-id</i> | (Optional) label space id                      |
| label                 | (Optional) mpls labels                         |
| <i>label-id</i>       | (Optional) mpls label value                    |
| <i>prefix</i>         | (Optional) Labels for single exact match route |
| module                | (Optional) slot                                |
| <i>module</i>         | (Optional) slot number                         |
| stats                 | (Optional) Label Statistics                    |
| implicit              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED      |
| platform              | (Optional) Display platform information        |
| <i>__readonly__</i>   | (Optional)                                     |
| TABLE_mpls            | (Optional)                                     |
| <i>label</i>          | (Optional) mpls label value                    |

|                         |   |
|-------------------------|---|
| <i>TABLE_table_id</i>   | (Optional) Table table id                   |
| <i>out-table-id</i>     | (Optional) Output table-id                  |
| <i>fec</i>              | (Optional) Prefix/Tunnel ID                 |
| <i>out-ip</i>           | (Optional) Output Next Hop                  |
| <i>out-intf</i>         | (Optional) Output Interface                 |
| <i>out-label</i>        | (Optional) Output Label                     |
| <i>out-op</i>           | (Optional) Output Label op                  |
| <i>hh</i>               | (Optional) Hardware Handle                  |
| <i>ref-count</i>        | (Optional) Ref Count                        |
| <i>hw-index</i>         | (Optional) HW index for adj                 |
| <i>in-pkts</i>          | (Optional) Label Input Packet Stats         |
| <i>in-bytes</i>         | (Optional) Label Input Bytes Stats          |
| <i>swap-out-pkts</i>    | (Optional) Label Swap Output Packet Stats   |
| <i>swap-out-bytes</i>   | (Optional) Label Swap Output Bytes Stats    |
| <i>tunnel-out-pkts</i>  | (Optional) Label Tunnel Output Packet Stats |
| <i>tunnel-out-bytes</i> | (Optional) Label Tunnel Output Bytes Stats  |

**Command Mode**

- /exec



## show forwarding mpls drop-stats

```
show forwarding mpls drop-stats [ platform | label0-fwd-stats ] [ __readonly__ [ { TABLE_drop_stats
<unit-number> <pkts> <bytes> } ] ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | show   |
| forwarding         | forwarding                                     |
| mpls               | mpls forwarding                                |
| drop-stats         | MPLS dropped packets                           |
| platform           | (Optional) command to display stats per chip   |
| label0-fwd-stats   | (Optional) command to display stats for label0 |
| __readonly__       | (Optional)                                     |
| TABLE_drop_stats   | (Optional) Table for mpls drop stats           |
| <i>unit-number</i> | (Optional) unit number                         |
| <i>pkts</i>        | (Optional) Label Packet Stats                  |
| <i>bytes</i>       | (Optional) Label Bytes Stats                   |

### Command Mode

- /exec



|                  |                                      |
|------------------|--------------------------------------|
| <i>hh</i>        | (Optional) Hardware Handle           |
| <i>ecmp-type</i> | (Optional) type for per path in ecmp |

**Command Mode**

- /exec

# show forwarding mpls eompls

```
show forwarding mpls eompls [ peers { <addr> | all } ] [ __readonly__ [ { TABLE_peer_ip <peer_ip>
<peer_id> <vlan_bmp> <rx_pkts> <rx_bytes> } ] ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show                                       |
| forwarding          | Forwarding information                     |
| mpls                | mpls forwarding                            |
| eompls              | eompls                                     |
| peers               | (Optional) nve peers                       |
| <i>addr</i>         | (Optional) peer ipaddress                  |
| all                 | (Optional) Display peer info for all peers |
| <i>__readonly__</i> | (Optional)                                 |
| TABLE_peer_ip       | (Optional)                                 |
| <i>peer_ip</i>      | (Optional) peer address                    |
| <i>peer_id</i>      | (Optional) peer id                         |
| <i>vlan_bmp</i>     | (Optional) vlan bitmap                     |
| <i>rx_pkts</i>      | (Optional) packet stats                    |
| <i>rx_bytes</i>     | (Optional) bytes stats                     |

## Command Mode

- /exec

## show forwarding mpls eompls ir

```
show forwarding mpls eompls ir { [ vlan [ all | <vlan_id> ] ] | [ peer [ all | <peer_ip> ] ] } [ __readonly__ [ {
TABLE_VLAN <vlan_id> <vni> <ifindex> <plt_space> <bitmap> <peer> + <marked> + } ] [ {
TABLE_ONE_PEER <peer> <id> <repl_id> <oif> <path_intf> + <vcount> <vlan_id> + <plt_space> } ] ]
```

### Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information        |
| forwarding       | Forwarding information                 |
| mpls             | mpls                                   |
| eompls           | eompls                                 |
| ir               | ir                                     |
| vlan             | (Optional) vlans all                   |
| all              | (Optional) all                         |
| <i>vlan_id</i>   | (Optional) vlan-id                     |
| peer             | (Optional) peers-all                   |
| all              | (Optional) all                         |
| <i>peer_ip</i>   | (Optional) show detailed info for peer |
| __readonly__     | (Optional)                             |
| TABLE_VLAN       | (Optional) vlan peer ids table         |
| <i>vlan_id</i>   | (Optional) vlan id                     |
| <i>vni</i>       | (Optional) vni                         |
| <i>ifindex</i>   | (Optional) ifindex                     |
| <i>plt_space</i> | (Optional) platform space              |
| <i>bitmap</i>    | (Optional) peer bitmap                 |
| <i>peer</i>      | (Optional) peer_address                |
| <i>marked</i>    | (Optional) marked                      |
| TABLE_ONE_PEER   | (Optional) vlan peer ids table         |
| <i>peer</i>      | (Optional) vlan id                     |
| <i>id</i>        | (Optional) vni                         |
| <i>repl_id</i>   | (Optional) repli id                    |

|                  |                           |
|------------------|---------------------------|
| <i>oif</i>       | (Optional) ifindex        |
| <i>path_intf</i> | (Optional) pathintf name  |
| <i>vcount</i>    | (Optional) vlan count     |
| <i>vlan_id</i>   | (Optional) vlanid         |
| <i>plt_space</i> | (Optional) platform space |

**Command Mode**

- /exec

## show forwarding mpls option\_b

```
show forwarding mpls option_b [ label <label> ] [ module <module> ] [ platform ] [ __readonly__ [ {
TABLE_mpls_opt_b <label> [ <prefix> ] [ <v6prefix> ] [ <nxhop> ] [ <out-interface> ] [ <out-op> } ] ] ]
```

### Syntax Description

|                      |                             |
|----------------------|-----------------------------|
| show                 | show                        |
| forwarding           | forwarding                  |
| mpls                 | mpls forwarding             |
| option_b             | Option B                    |
| label                | (Optional) mpls labels      |
| <i>label</i>         | (Optional) mpls label value |
| module               | (Optional) slot             |
| <i>module</i>        | (Optional) slot number      |
| platform             | (Optional) show pd info     |
| __readonly__         | (Optional)                  |
| TABLE_mpls_opt_b     | (Optional)                  |
| <i>label</i>         | (Optional) mpls label value |
| <i>prefix</i>        | (Optional) Output Interface |
| <i>nxhop</i>         | (Optional) Output Next Hop  |
| <i>out-interface</i> | (Optional) Output Label op  |
| <i>out-op</i>        | (Optional) Output Label op  |

### Command Mode

- /exec





# show forwarding mpls summary

```
show forwarding mpls summary [ module <module> ] [ __readonly__ [ { TABLE_labels <space> <count>
} <total_deagg_labels> <feature_evpn_status> ] ]
```

## Syntax Description

|                            |                                |
|----------------------------|--------------------------------|
| show                       | show                           |
| forwarding                 | display fib information        |
| mpls                       | mpls forwarding                |
| summary                    | summary                        |
| module                     | (Optional) slot                |
| <i>module</i>              | (Optional) slot number         |
| <i>__readonly__</i>        | (Optional)                     |
| TABLE_labels               | (Optional)                     |
| <i>space</i>               | (Optional) label space         |
| <i>count</i>               | (Optional) number of labels    |
| <i>total_deagg_labels</i>  | (Optional) total deagg labels  |
| <i>feature_evpn_status</i> | (Optional) feature evpn status |

## Command Mode

- /exec

# show forwarding multicast-sr loopback interface

show forwarding multicast-sr loopback interface [ *\_\_readonly\_\_* [ *<port-num>* ] ]

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                |                                       |
| forwarding          | display fib information               |
| multicast-sr        | multicast service reflect information |
| interface           | loopback interface                    |
| loopback            | loopback interface                    |
| <i>__readonly__</i> | (Optional)                            |
| <i>port-num</i>     | (Optional) Port number                |

## Command Mode

- /exec

## show forwarding multicast-sr mac-trap-db

```
show forwarding multicast-sr mac-trap-db [ __readonly__ { [ TABLE_mac_trap_db <mac-addr> <mac-trap-id>
<ref-cnt> ] <total-count> } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information         |
| forwarding               | display platform fib information        |
| multicast-sr             | multicast service reflect information   |
| mac-trap-db              | display internal mac-trap db            |
| <i>__readonly__</i>      | (Optional)                              |
| <i>TABLE_mac_trap_db</i> | (Optional) display internal mac-trap db |
| <i>mac-addr</i>          | (Optional) MAC address                  |
| <i>mac-trap-id</i>       | (Optional) MAC trap ID                  |
| <i>ref-cnt</i>           | (Optional) Reference Count              |
| <i>total-count</i>       | (Optional) total count                  |

### Command Mode

- /exec

## show forwarding multicast outgoing-interface-list

```
show forwarding multicast outgoing-interface-list { L2 | L3 | vxlan-encap | vxlan-ir-dci-encap | mvpn } [
platform ] [ module <module> ] [ <index> ] [ __readonly__ [ <refcount> ] [ <total_l2_oiflist> ] [
<total_l3_oiflist> ] [ <slot> ] [ TABLE_MCAST_OIF_INFO [ <oiflist_idx> ] [ <vlan> ] [ <num_oif> ] [
TABLE_MCAST_OIF_INTF_INFO [ <intf> ] [ <dvtif> ] ] [ <encap_id> ] [ <hw_oiflist_idx> ] [ <mcidx> ]
] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      |  |
| forwarding                | Forwarding information                   |
| multicast                 | Multicast IPv4 information               |
| outgoing-interface-list   | show outgoing interface list info        |
| L2                        | Layer 2 oiflist                          |
| L3                        | Layer 3 oiflist                          |
| vxlan-encap               | vxlan-encap oiflist                      |
| vxlan-ir-dci-encap        | vxlan-ir-dci-encap oiflist               |
| mvpn                      | MVPN oiflist                             |
| platform                  | (Optional) Display PI/PD                 |
| module                    | (Optional) slot                          |
| <i>module</i>             | (Optional) slot number                   |
| <i>index</i>              | (Optional) Outgoing Interface List Index |
| <i>__readonly__</i>       | (Optional)                               |
| <i>refcount</i>           | (Optional) Reference count               |
| <i>total_l2_oiflist</i>   | (Optional) total l2 oiflist              |
| <i>total_l3_oiflist</i>   | (Optional) total l3 oiflist              |
| <i>slot</i>               | (Optional) slot number                   |
| TABLE_MCAST_OIF_INFO      | (Optional) Mcast OIF Info                |
| <i>oiflist_idx</i>        | (Optional) Outgoing Interface List Index |
| <i>vlan</i>               | (Optional) Vlan id                       |
| <i>num_oif</i>            | (Optional) Number of outgoing interfaces |
| TABLE_MCAST_OIF_INTF_INFO | (Optional) OIF Interfaces                |

|                       |   |
|-----------------------|---|
| <i>intf</i>           | (Optional) OIF name                               |
| <i>dvif</i>           | (Optional) DVIF                                   |
| <i>encap_id</i>       | (Optional) encap_id                               |
| <i>hw_oiflist_idx</i> | (Optional) Hardware Outgoing Interface List Index |
| <i>mcidx</i>          | (Optional) MC Index                               |

**Command Mode**

- /exec

## show forwarding multicast route

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | all } | table <table_id> ] [ ipv4 ] multicast route [
platform ] { [ group { <gaddr> [ <mask> ] | <gprefix> } | source { <saddr> [ <smask> ] | <sprefix> } ] |
module <module> | vrf { <vrf-name> | <vrf-known-name> | all } ] + | summary [ module <module> | vrf {
<vrf-name> | <vrf-known-name> | all } ] + } [ _readonly_ [ <table_type> ] [ <vrfname> ] [ <table_id> ] [
<num_routes> <num_starg_routes> <num_sg_routes> <num_gprefix_routes> ] [ <num_groups> ] [
<num_sources> ] [ <num_prefix_insert_fail> ] [ [ TABLE_MROUTE_INFO <mcast_addr> [ <src_len>
<grp_len> ] [ <df_ordinal> ] [ <rpfi> ] [ <rpfi_index> ] <flag> [ <flag_value> ] <route_pkts> <route_bytes>
<oiflist_id> <oif_count> [ <refcount> ] <oiflist_flag> [ TABLE_OIF_INFO <oifindex> [
TABLE_MCAST_VLAN_INFO [ <vlan> ] [ TABLE_MCAST_OIF_INFO [ <oifname> ] [ <dvif> ] ] ] [
<platform_id> ] [ <encap_id> ] [ TABLE_MCAST_CORE_OIF_INFO [ <core_oifname> ] ] [ <hw_index>
] [ <oif_pkts> <oif_bytes> ] ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  |  |
| forwarding            | Forwarding information                         |
| ipv4                  | (Optional) ipv4                                |
| multicast             | Multicast IPv4 information                     |
| route                 | Mcast route information                        |
| platform              | (Optional) Platform Details                    |
| table                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED      |
| <i>table_id</i>       | (Optional) table number                        |
| vrf                   | (Optional) display info per VRF                |
| <i>vrf-name</i>       | (Optional) VRF name                            |
| <i>vrf-known-name</i> | (Optional) Known VRF name                      |
| all                   | (Optional) Display information for all VRFs    |
| group                 | (Optional) Multicast IPv4 Group specific info  |
| <i>gaddr</i>          | (Optional) Multicast IPv4 Group Address        |
| <i>mask</i>           | (Optional) Multicast IPv4 Group Address mask   |
| <i>gprefix</i>        | (Optional) Multicast IPv4 Group Prefix         |
| source                | (Optional) Multicast IPv4 Source specific info |
| <i>saddr</i>          | (Optional) Multicast IPv4 Source Address       |
| <i>smask</i>          | (Optional) Multicast IPv4 Source Address mask  |

|                               |   |
|-------------------------------|---|
| <i>sprefix</i>                | (Optional) Multicast IPv4 Source Prefix                   |
| summary                       | display route counts                                      |
| module                        | (Optional) slot   |
| <i>module</i>                 | (Optional) slot number                                    |
| <i>__readonly__</i>           | (Optional)  |
| <i>table_type</i>             | (Optional) Table Type                                     |
| <i>vrfname</i>                | (Optional) VRF name                                       |
| <i>table_id</i>               | (Optional) Table ID                                       |
| <i>num_routes</i>             | (Optional) Number of routes                               |
| <i>num_starg_routes</i>       | (Optional) Number of (*,G) routes                         |
| <i>num_sg_routes</i>          | (Optional) Number of (S,G) routes                         |
| <i>num_gprefix_routes</i>     | (Optional) Number of (*,G-prefix) routes                  |
| <i>num_groups</i>             | (Optional) Number of group entries in the table           |
| <i>num_prefix_insert_fail</i> | (Optional) Prefix insert fail count                       |
| <i>num_sources</i>            | (Optional) Number of (S, G) entries for the group address |
| TABLE_MROUTE_INFO             | (Optional) Mroute info                                    |
| <i>mcast_addr</i>             | (Optional) Mcast address                                  |
| <i>src_len</i>                | (Optional) Source Address Mask                            |
| <i>grp_len</i>                | (Optional) Group address Mask                             |
| <i>df_ordinal</i>             | (Optional) DF ordinal                                     |
| <i>rpfif</i>                  | (Optional) RPF interface                                  |
| <i>rpf_ifindex</i>            | (Optional) RPF Interface ifIndex                          |
| <i>flag</i>                   | (Optional) Route type flag                                |
| <i>flag_value</i>             | (Optional) hex value of route flag                        |
| <i>route_pkts</i>             | (Optional) Route packet count                             |
| <i>route_bytes</i>            | (Optional) Route bytes                                    |
| <i>oiflist_id</i>             | (Optional) OIF list Identifier                            |
| <i>oif_count</i>              | (Optional) Number of OIFs                                 |
| <i>oiflist_flag</i>           | (Optional) OIF List flag                                  |

|                           |   |
|---------------------------|---|
| <i>refcount</i>           | (Optional) OIF list Reference Count       |
| TABLE_OIF_INFO            | (Optional) OIF Info                       |
| <i>oifindex</i>           | (Optional) OIF Interface ifIndex          |
| TABLE_MCAST_VLAN_INFO     | (Optional) Vlan Interfaces                |
| <i>vlan</i>               | (Optional) Vlan id                        |
| TABLE_MCAST_OIF_INFO      | (Optional) OIF Interfaces                 |
| <i>oifname</i>            | (Optional) OIF Interface name             |
| <i>dvif</i>               | (Optional) DVIF                           |
| TABLE_MCAST_CORE_OIF_INFO | (Optional) Core-facing OIF Interfaces     |
| <i>core_oifname</i>       | (Optional) Core-facing OIF Interface name |
| <i>platform_id</i>        | (Optional) Platform-index                 |
| <i>encap_id</i>           | (Optional) Encap ID                       |
| <i>hw_index</i>           | (Optional) Hardware index                 |
| <i>oif_pkts</i>           | (Optional) OIF packets                    |
| <i>oif_bytes</i>          | (Optional) OIF bytes                      |

**Command Mode**

- /exec



## show forwarding nve l2 ingress-replication-peers

```
show forwarding nve l2 ingress-replication-peers [ ipv4 <peer_ip> | ipv6 <v6_peer_ip> ] + [ __readonly__ [
{ TABLE_VLAN <vlan_id> <vni> <ifindex> <plt_space> <peer_bmp> <peer> + } { TABLE_PSS_VLAN
<vlan_pss_id> <VNI> <vtep> <peercnt> <pss_peer_bmp> { <pss_peer> <marked> } + } ] + [ [ <peer> <id>
<repl_id> <oif> <hash_algo> <path_intf> + <vcount> <vlan_id> + <resync_vcount> <resync_vlan_id> + [
<path> <hash> <flags> <nh> <intf> + ] ] [ <pss_peer> <pss_id> <pss_repl_id> <pss_oif> <pss_hash_algo>
<pss_path_intf> + <pss_vcount> <vlan_pss_id> + [ <pss_path> <pss_hash> <pss_flags> <pss_nh> <pss_intf>
+ ] ] ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | show                                    |
| forwarding                | display fib information                 |
| nve                       | nve related info                        |
| l2                        | L2 info                                 |
| ingress-replication-peers | ingress replication peer info           |
| ipv4                      | (Optional) ipv4 peer                    |
| <i>peer_ip</i>            | (Optional) show detailed info of a peer |
| ipv6                      | (Optional) ipv6 peer                    |
| __readonly__              | (Optional)                              |
| TABLE_VLAN                | (Optional) vlan peer ids table          |
| <i>vlan_id</i>            | (Optional) vlan id                      |
| <i>vni</i>                | (Optional) vni                          |
| <i>ifindex</i>            | (Optional) ifindex                      |
| <i>plt_space</i>          | (Optional) platform space               |
| <i>peer_bmp</i>           | (Optional) peer bitmap                  |
| <i>peer</i>               | (Optional) peer_address                 |
| TABLE_PSS_VLAN            | (Optional) vlan-peer in pss             |
| <i>vlan_pss_id</i>        | (Optional) pss_peer_id                  |
| <i>VNI</i>                | (Optional) vni                          |
| <i>vtep</i>               | (Optional) vtep                         |
| <i>peercnt</i>            | (Optional) peer count                   |
| <i>pss_peer_bmp</i>       | (Optional) PSS peer bitmap              |

|                       |                              |
|-----------------------|------------------------------|
| <i>pss_peer</i>       | (Optional) peer address      |
| <i>marked</i>         | (Optional) marked            |
| <i>peer</i>           | (Optional) peer              |
| <i>id</i>             | (Optional) id                |
| <i>repl_id</i>        | (Optional) repl_id           |
| <i>oif</i>            | (Optional) oif               |
| <i>path_intf</i>      | (Optional) path intf name    |
| <i>hash_algo</i>      | (Optional) hash algo used    |
| <i>vcount</i>         | (Optional) vlan count        |
| <i>vlan_id</i>        | (Optional) vlan id           |
| <i>resync_vcount</i>  | (Optional) resync vlan count |
| <i>resync_vlan_id</i> | (Optional) resync vlan id    |
| <i>path</i>           | (Optional) ecmp path         |
| <i>hash</i>           | (Optional) ecmp hash         |
| <i>flags</i>          | (Optional) ecmp flags        |
| <i>nh</i>             | (Optional) ecmp nh           |
| <i>intf</i>           | (Optional) ecmp interfaces   |
| <i>pss_peer</i>       | (Optional) peer              |
| <i>pss_id</i>         | (Optional) id                |
| <i>pss_repl_id</i>    | (Optional) repl_id           |
| <i>pss_oif</i>        | (Optional) oif               |
| <i>pss_path_intf</i>  | (Optional) path intf name    |
| <i>pss_hash_algo</i>  | (Optional) hash algo used    |
| <i>pss_vcount</i>     | (Optional) vlan count        |
| <i>vlan_pss_id</i>    | (Optional) vlan id           |
| <i>pss_path</i>       | (Optional) pss path          |
| <i>pss_hash</i>       | (Optional) pss hash          |
| <i>pss_flags</i>      | (Optional) pss flags         |
| <i>pss_nh</i>         | (Optional) pss nh            |

|                 |                     |
|-----------------|---------------------|
| <i>pss_intf</i> | (Optional) pss intf |
|-----------------|---------------------|

**Command Mode**

- /exec

## show forwarding nve l3 adjacency tunnel

```
show forwarding nve l3 adjacency tunnel [ <tunnel_id> | all ] [ bd <bd_id> | detail | module <module> | table
<table_id> ] [ __readonly__ TABLE_nvel3adj <tunnel_id> <bd_id> <table_id> <VNI> <DownStream>
<Drop> <Refcount> <Origin> <State> <Del> [ <sw_index> <hw_index0> <hw_index1> <hw_index2> ] ]
```

### Syntax Description

|                   |  |
|-------------------|--|
| show              |  |
| forwarding        | display fib information                      |
| nve               | nve related info                             |
| l3                | Layer 3                                      |
| adjacency         | Adjacency info                               |
| tunnel            | VXLAN tunnel                                 |
| <i>tunnel_id</i>  | (Optional) tunnel_id                         |
| all               | (Optional) show adjacency info for all peers |
| bd                | (Optional) BD info                           |
| <i>bd_id</i>      | (Optional) bd id                             |
| detail            | (Optional) Show detailed information         |
| module            | (Optional) Slot/module                       |
| <i>module</i>     | (Optional) Slot/module number                |
| table             | (Optional) Tenant table-id                   |
| <i>table_id</i>   | (Optional) tenant table-id                   |
| __readonly__      | (Optional)                                   |
| TABLE_nvel3adj    | (Optional)                                   |
| <i>tunnel_id</i>  | (Optional) tunnel_id                         |
| <i>bd_id</i>      | (Optional) bd id                             |
| <i>table_id</i>   | (Optional) tenant table-id                   |
| VNI               | (Optional) vni                               |
| <i>DownStream</i> | (Optional) DownStream                        |
| <i>Drop</i>       | (Optional) Drop                              |
| <i>Refcount</i>   | (Optional) Refcount                          |

|                  |                   |
|------------------|-------------------|
| <i>Origin</i>    | (Optional) origin |
| <i>State</i>     | (Optional) state  |
| <i>Del</i>       | (Optional) del    |
| <i>sw_index</i>  | (Optional)        |
| <i>hw_index0</i> | (Optional)        |
| <i>hw_index1</i> | (Optional)        |
| <i>hw_index2</i> | (Optional)        |

**Command Mode**

- /exec

## show forwarding nve l3 adjacency v6-tunnel

```
show forwarding nve l3 adjacency v6-tunnel [ <peer-ip> | all ] [ bd <bd_id> | detail | module <num> | table
<table_id> ] [ __readonly__ TABLE_nve13adj <peer-ip> <bd_id> <table_id> <VNI> <Drop> <Refcount>
<Origin> <State> <Del> <sw_index> <hw_index0> <hw_index1> <hw_index2> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                |   |
| forwarding          | display fib information                 |
| nve                 | nve related info                        |
| l3                  | Layer 3                                 |
| adjacency           | Adjacency info                          |
| v6-tunnel           | VXLAN V6 tunnel                         |
| all                 | (Optional) Show adjacency for all peers |
| bd                  | (Optional) BD info                      |
| <i>bd_id</i>        | (Optional) bd id                        |
| detail              | (Optional) Show detailed information    |
| module              | (Optional) Slot/module                  |
| <i>num</i>          | (Optional) Slot/module number           |
| table               | (Optional) Tenant table-id              |
| <i>table_id</i>     | (Optional) tenant table-id              |
| <i>__readonly__</i> | (Optional)                              |
| TABLE_nve13adj      | (Optional)                              |
| <i>bd_id</i>        | (Optional) bd id                        |
| <i>table_id</i>     | (Optional) tenant table-id              |
| VNI                 | (Optional) vni                          |
| Drop                | (Optional) Drop                         |
| Refcount            | (Optional) Refcount                     |
| Origin              | (Optional) origin                       |
| State               | (Optional) state                        |
| Del                 | (Optional) del                          |

|                  |            |
|------------------|------------|
| <i>sw_index</i>  | (Optional) |
| <i>hw_index0</i> | (Optional) |
| <i>hw_index1</i> | (Optional) |
| <i>hw_index2</i> | (Optional) |

**Command Mode**

- /exec

## show forwarding nve l3 ecmp

```
show forwarding nve l3 ecmp [ __readonly__ { TABLE_nve13ecmp <hw_index> <ecmp_hash> <num_paths>
<table_id> <flags> <adj_flags> <ref_count> { TABLE_tunnel_info [ <tunnel_id> | <tunnel_ip> ] <segment_id>
} <hw_ecmp_index0> <hw_ecmp_index1> <hw_ecmp_index2> } ]
```

### Syntax Description

|                       |                                      |
|-----------------------|--------------------------------------|
| show                  |                                      |
| forwarding            | display fib information              |
| nve                   | nve related info                     |
| l3                    | Layer 3                              |
| ecmp                  | nve ecmp info                        |
| <i>__readonly__</i>   | (Optional)                           |
| TABLE_nve13ecmp       | (Optional) nve l3 ecmp table         |
| <i>hw_index</i>       | (Optional) hw_index address pointer  |
| <i>ecmp_hash</i>      | (Optional) ecmp hash                 |
| <i>num_paths</i>      | (Optional) number of members in ECMP |
| <i>table_id</i>       | (Optional) table id                  |
| <i>flags</i>          | (Optional) flags                     |
| <i>adj_flags</i>      | (Optional) adj flags                 |
| <i>ref_count</i>      | (Optional) num of references         |
| TABLE_tunnel_info     | (Optional)                           |
| <i>tunnel_id</i>      | (Optional) tunnel id                 |
| <i>tunnel_ip</i>      | (Optional) v6 tunnel ip              |
| <i>segment_id</i>     | (Optional) segment id                |
| <i>hw_ecmp_index0</i> | (Optional) HW ECMP Index Unit 0      |
| <i>hw_ecmp_index1</i> | (Optional) HW ECMP Index Unit 1      |
| <i>hw_ecmp_index2</i> | (Optional) HW ECMP Index Unit 2      |

### Command Mode

- /exec



## show forwarding nve l3 peers

```
show forwarding nve l3 peers [ peers <peer_id> | tunnel <tunnel_id> | detail | module <module> ] + [
__readonly__ { TABLE_l3peers <tunnel_id> <peer_id> <peer_address> <interface> <rmac> <origin> <state>
<del> <count> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | show  |
| forwarding          | display fib information                     |
| nve                 | nve related info                            |
| l3                  | Layer 3                                     |
| peers               | nve peers                                   |
| <i>peer_id</i>      | (Optional) nve peer-id                      |
| tunnel              | (Optional) VXLAN tunnel                     |
| <i>tunnel_id</i>    | (Optional) Unique identifier for the tunnel |
| detail              | (Optional) Show detailed information        |
| module              | (Optional) Slot/module                      |
| <i>module</i>       | (Optional) Slot/module number               |
| __readonly__        | (Optional)                                  |
| TABLE_l3peers       | (Optional) all l3 nve peers                 |
| <i>tunnel_id</i>    | (Optional) tunnel_id                        |
| <i>peer_id</i>      | (Optional) peer_id                          |
| <i>peer_address</i> | (Optional) peer_address                     |
| <i>interface</i>    | (Optional) interface                        |
| <i>rmac</i>         | (Optional) rmac                             |
| <i>origin</i>       | (Optional) origin                           |
| <i>state</i>        | (Optional) state                            |
| <i>del</i>          | (Optional) del                              |
| <i>count</i>        | (Optional) count                            |

### Command Mode

- /exec

# show forwarding nve underlay-interfaces

```
show forwarding nve underlay-interfaces [ __readonly__ { <broadcast_status> <broadcast_level>
<multicast_status> <multicast_level> <unicast_status> <unicast_level> <no_of_uplink_interfaces> } [ {
TABLE_uplinks <ifindex> <peerid_bmp> <is_dci> [ <phy_if> ] } ] ]
```

## Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | show                                   |
| forwarding                     | display fib information                |
| nve                            | NVE related info                       |
| underlay-interfaces            | underlay interfaces info               |
| <i>__readonly__</i>            | (Optional)                             |
| <i>broadcast_status</i>        | (Optional) status                      |
| <i>broadcast_level</i>         | (Optional) broadcast level             |
| <i>multicast_status</i>        | (Optional) multicast status            |
| <i>multicast_level</i>         | (Optional) multicast level             |
| <i>unicast_status</i>          | (Optional) unicast status              |
| <i>unicast_level</i>           | (Optional) unicast level               |
| <i>no_of_uplink_interfaces</i> | (Optional) Number of uplink interfaces |
| TABLE_uplinks                  | (Optional)                             |
| <i>ifindex</i>                 | (Optional) uplink ifindex              |
| <i>phy_if</i>                  | (Optional) uplink physical interface   |
| <i>peerid_bmp</i>              | (Optional) peerid bitmap               |
| <i>is_dci</i>                  | (Optional) dci flag                    |

## Command Mode

- /exec

# show forwarding otv

```
show forwarding otv <intf> [ peer <peer-id> ] [ module <module> ] [ __readonly__ <vlan> <peer-id>
<peer_vlan_count><tunnel_ifindex><tunnel_ifname> ]
```

## Syntax Description

|                |                                  |
|----------------|----------------------------------|
| show           |                                  |
| forwarding     | fib information                  |
| otv            | overlay-transport-virtualization |
| <i>intf</i>    | overlay interface                |
| peer           | (Optional) overlay peer          |
| <i>peer-id</i> | (Optional) overlay peer-id       |
| module         | (Optional) slot                  |
| <i>module</i>  | (Optional) slot number           |
| __readonly__   | (Optional)                       |
| <i>vlan</i>    | (Optional) Vlan information      |
| <i>peer-id</i> | (Optional) peer-id               |

## Command Mode

- /exec



|                        |  |
|------------------------|--|
| TABLE_otv_mroute       | (Optional)                               |
| <i>src_addr</i>        | (Optional) Ipv6 address string           |
| <i>src_len</i>         | (Optional) Source Address Mask           |
| <i>grp_addr</i>        | (Optional) Ipv6 address string           |
| <i>grp_len</i>         | (Optional) Group address Mask            |
| <i>df_ordinal</i>      | (Optional) DF ordinal                    |
| <i>rpfif</i>           | (Optional) RPF interface                 |
| <i>flag</i>            | (Optional) Route type flag               |
| <i>route_pkts</i>      | (Optional) Route packet count            |
| <i>route_bytes</i>     | (Optional) Route bytes                   |
| <i>otv_route_pkts</i>  | (Optional) OTV Route packet count        |
| <i>otv_route_bytes</i> | (Optional) OTV Route bytes               |
| TABLE_OIF              | (Optional)                               |
| <i>oif_count</i>       | (Optional) Number of OIFs                |
| <i>oiflist_id</i>      | (Optional) OIF list Identifier           |
| <i>index</i>           | (Optional) outgoing interface list index |
| <i>refcount</i>        | (Optional) reference count               |
| TABLE_OIFLIST          | (Optional)                               |
| <i>oifindex</i>        | (Optional) OIF Interface ifIndex         |
| <i>oif_pkts</i>        | (Optional) OIF packets                   |
| <i>oif_bytes</i>       | (Optional) OIF bytes                     |
| <i>src_addr</i>        | (Optional) Multicast IPv4 Source Address |
| <i>src_len</i>         | (Optional) Source Address Mask           |
| <i>oifname</i>         | (Optional) OIF Interface name            |
| <i>vlanid</i>          | (Optional) vlan id of the route          |
| <i>grp_addr</i>        | (Optional) Multicast IPv4 Group Address  |
| <i>grp_len</i>         | (Optional) Group address Mask            |
| <i>otv_src_addr</i>    | (Optional) Multicast IPv4 Source Address |
| <i>otv_grp_addr</i>    | (Optional) Multicast IPv4 Group Address  |

**Command Mode**

- /exec

## show forwarding otv multicast outgoing-interface-list

```
show forwarding otv multicast outgoing-interface-list [ __readonly__ { TABLE_OIF <index> [ <refcount>
] [ <intf> ] [ { TABLE_OIFLIST <oifindex> [ <src_addr> ] [ <src_len> ] [ <oifname> ] [ <vlanid> ] [
<grp_addr> ] [ <grp_len> ] } ] } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    |  |
| forwarding              | Forwarding information                   |
| otv                     | over-the-top virtualization              |
| multicast               | Multicast IPv4 information               |
| outgoing-interface-list | show outgoing interface list info        |
| <i>__readonly__</i>     | (Optional)                               |
| TABLE_OIF               | (Optional) outgoing interface list table |
| <i>index</i>            | (Optional) outgoing interface list index |
| <i>refcount</i>         | (Optional) reference count               |
| <i>intf</i>             | (Optional) interface name                |
| TABLE_OIFLIST           | (Optional) outgoing interface list table |
| <i>oifindex</i>         | (Optional) OIF Interface ifIndex         |
| <i>src_addr</i>         | (Optional) Multicast IPv4 Source Address |
| <i>src_len</i>          | (Optional) Source Address Mask           |
| <i>oifname</i>          | (Optional) OIF Interface name            |
| <i>vlanid</i>           | (Optional) vlan id of the route          |
| <i>grp_addr</i>         | (Optional) Multicast IPv4 Group Address  |
| <i>grp_len</i>          | (Optional) Group address Mask            |

### Command Mode

- /exec

## show forwarding otv multicast route

```
show forwarding otv multicast route [ [ vlan <vlan-id> ] | [ softwarebd <software-bd> ] ] [ module <module> ] [ __readonly__ <replicator> ]
```

### Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                | show                              |
| forwarding          | forwarding                        |
| otv                 | over-the-top virtualization       |
| multicast           | Multicast IPv4 information        |
| route               | Mcast route information           |
| vlan                | (Optional) vlan                   |
| <i>vlan-id</i>      | (Optional) vlan id                |
| softwarebd          | (Optional) Software Bridge Domain |
| <i>software-bd</i>  | (Optional) Software bd            |
| module              | (Optional) slot                   |
| <i>module</i>       | (Optional) slot number            |
| <i>__readonly__</i> | (Optional)                        |
| <i>replicator</i>   | (Optional) replicator name        |

### Command Mode

- /exec



# show forwarding otv vlan

```
show forwarding otv vlan [ <vlan_id> ] [ module <module> ] [ __readonly__ <vlan> ]
```

## Syntax Description

|                     |                        |
|---------------------|------------------------|
| show                | show                   |
| forwarding          | forwarding             |
| otv                 | otv                    |
| vlan                | vlan                   |
| <i>vlan_id</i>      | (Optional) vlan id     |
| module              | (Optional) slot        |
| <i>module</i>       | (Optional) slot number |
| <i>__readonly__</i> | (Optional)             |
| <i>vlan</i>         | (Optional) vlan        |

## Command Mode

- /exec

## show forwarding security group-tag

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> | vlan <vlan_id> ] [
ipv4 ] security group-tag [ <addr> ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all>
} ] + [ __readonly__ TABLE_sgt_vrf { <tid> <pfx-count> [ TABLE_sgt_prefix [ <ipa> ] [ <tag> ] [ <tv> ]
} ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  |   |
| forwarding            | display fib information                     |
| vrf                   | (Optional) display info per VRF             |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| vrf-all               | (Optional) Display information for all VRFs |
| table                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>table_id</i>       | (Optional) table number                     |
| vlan                  | (Optional) vlan                             |
| <i>vlan_id</i>        | (Optional) vlan number                      |
| ipv4                  | (Optional) ipv4                             |
| security              | display IP security information             |
| group-tag             | ip_address->security_group_tag              |
| <i>addr</i>           | (Optional) specific ip address              |
| module                | (Optional) slot                             |
| <i>module</i>         | (Optional) slot number                      |
| __readonly__          | (Optional)                                  |
| TABLE_sgt_vrf         | (Optional) vrf table                        |
| <i>tid</i>            | (Optional) table identifier                 |
| <i>pfx-count</i>      | (Optional) total prefix count in VRF        |
| TABLE_sgt_prefix      | (Optional) all xml prefix entries           |
| <i>ipa</i>            | (Optional) ip address                       |
| <i>tag</i>            | (Optional) security group tag               |

|           |                      |
|-----------|----------------------|
| <i>tv</i> | (Optional) sgt valid |
|-----------|----------------------|

**Command Mode**

- /exec

## show forwarding security mac

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ ipv4 ] security
mac [ <addr> ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] + [ __readonly__
TABLE_sec_vrf { <tid> <pfx-count> [ TABLE_sec_prefix <ipa> <mac> <p> <m> <v> <intf> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  |   |
| forwarding            | display fib information                     |
| vrf                   | (Optional) display info per VRF             |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| vrf-all               | (Optional) Display information for all VRFs |
| table                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>table_id</i>       | (Optional) table number                     |
| ipv4                  | (Optional) ipv4                             |
| security              | display IP security information             |
| mac                   | ip_address->mac_address                     |
| <i>addr</i>           | (Optional) specific ip address              |
| module                | (Optional) slot                             |
| <i>module</i>         | (Optional) slot number                      |
| __readonly__          | (Optional)                                  |
| TABLE_sec_vrf         | (Optional) security vrf table               |
| <i>tid</i>            | (Optional) table identifier                 |
| <i>pfx-count</i>      | (Optional) total prefix count in VRF        |
| TABLE_sec_prefix      | (Optional) all xml security prefix entries  |
| <i>ipa</i>            | (Optional) ip address                       |
| <i>mac</i>            | (Optional) mac address                      |
| <i>m</i>              | (Optional) 1 => ip->mac binding             |
| <i>v</i>              | (Optional) 1 => ip->vlan binding            |
| <i>p</i>              | (Optional) 1 => ip->port binding            |

|             |                               |
|-------------|-------------------------------|
| <i>intf</i> | (Optional) ip->port interface |
|-------------|-------------------------------|

**Command Mode**

- /exec

## show forwarding srv6 adjacency decap

```
show forwarding srv6 adjacency decap [ table <table_id> ] [ module <num> ] [ __readonly__ {
TABLE_adj_decap <locator> <function> <behavior> <tableid> <bd> <is_drop> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | show  |
| forwarding          | display fib information                     |
| srv6                | Segment routing V6                          |
| adjacency           | SRV6 adjacency                              |
| decap               | Decapsulation adjacency                     |
| table               | (Optional) display info per vpn-id          |
| <i>table_id</i>     | (Optional) table number                     |
| <i>bd</i>           | (Optional) Bridge domain                    |
| module              | (Optional) Slot/module                      |
| <i>num</i>          | (Optional) Slot/module number               |
| <i>__readonly__</i> | (Optional)                                  |
| TABLE_adj_decap     | (Optional) all SRV6 decap adjacencies       |
| <i>locator</i>      | (Optional) Locator or binding sid           |
| <i>function</i>     | (Optional) Function                         |
| <i>behavior</i>     | (Optional) Behavior                         |
| <i>tableid</i>      | (Optional) tabled number                    |
| <i>is_drop</i>      | (Optional) Indicates if adjacency is a drop |

### Command Mode

- /exec

## show forwarding srv6 adjacency encap

```
show forwarding srv6 adjacency encap [ table <table_id> ] [ module <num> ] [ __readonly__ {
TABLE_adj_encap <loc_bsid> <source_ip> <function> <tableid> <is_drop> <bsid> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | show  |
| forwarding          | display fib information                     |
| srv6                | Segment routing V6                          |
| adjacency           | SRV6 adjacency                              |
| encap               | Encapsulation adjacency                     |
| table               | (Optional) display info per vpn-id          |
| <i>table_id</i>     | (Optional) table number                     |
| module              | (Optional) Slot/module                      |
| <i>num</i>          | (Optional) Slot/module number               |
| <i>__readonly__</i> | (Optional)                                  |
| TABLE_adj_encap     | (Optional) all SRV6 encap adjacencies       |
| <i>loc_bsid</i>     | (Optional) Locator or binding sid           |
| <i>source_ip</i>    | (Optional) Source IPV6 address              |
| <i>function</i>     | (Optional) Function                         |
| <i>tableid</i>      | (Optional) tabled number                    |
| <i>is_drop</i>      | (Optional) Indicates if adjacency is a drop |
| <i>bsid</i>         | (Optional) binding sid                      |

### Command Mode

- /exec

## show forwarding srv6 bsid-peer

```
show forwarding srv6 bsid-peer [ <bsid_value> ] [ <endpoint> ] [ module <num> ] [ __readonly__ {
TABLE_bsid_peer <bsid> <endpoint> <type> <table_id> <peer-id> } ]
```

### Syntax Description

|                     |                               |
|---------------------|-------------------------------|
| show                | show                          |
| forwarding          | display fib information       |
| srv6                | Segment routing V6            |
| bsid-peer           | Binding SID identifier        |
| module              | (Optional) Slot/module        |
| <i>num</i>          | (Optional) Slot/module number |
| <i>__readonly__</i> | (Optional)                    |
| TABLE_bsid_peer     | (Optional) BSID peer table    |
| <i>bsid</i>         | (Optional) Bsid value         |
| <i>endpoint</i>     | (Optional) Endpoint           |
| <i>type</i>         | (Optional) BSID type          |
| <i>table_id</i>     | (Optional) Table ID           |
| <i>peer-id</i>      | (Optional) Peer ID            |

### Command Mode

- /exec



# show forwarding srv6 bsid

```
show forwarding srv6 bsid [ <bsid_value> ] [ module <num> ] [ __readonly__ { TABLE_bsid <bsid> <type>
<table_id> <num_sids> <sid_list> <list_count> } ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | show  |
| forwarding          | display fib information                     |
| srv6                | Segment routing V6                          |
| bsid                | Binding SID                                 |
| module              | (Optional) Slot/module                      |
| <i>num</i>          | (Optional) Slot/module number               |
| <i>__readonly__</i> | (Optional)                                  |
| TABLE_bsid          | (Optional) BSID table                       |
| <i>table_id</i>     | (Optional) Table ID                         |
| <i>type</i>         | (Optional) BSID type                        |
| <i>num_sids</i>     | (Optional) Number of SID's in list          |
| <i>bsid</i>         | (Optional) Bsid value                       |
| <i>sid_list</i>     | (Optional) SID in list                      |
| <i>list_count</i>   | (Optional) Number of dependent peer objects |

## Command Mode

- /exec

## show forwarding srv6 ecmp

```
show forwarding srv6 ecmp [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ table <table_id> ] [ module <num> ] [ __readonly__ { TABLE_ecmp <num_paths> <table_id> { TABLE_adj <loc_bsid> <source_ip> <function> } } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | show  |
| forwarding            | display fib information                     |
| srv6                  | Segment routing V6                          |
| ecmp                  | SRV6 ecmp                                   |
| vrf                   | (Optional) display info per VRF             |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| vrf-all               | (Optional) Display information for all VRFs |
| table                 | (Optional) display info per vpn-id          |
| <i>table_id</i>       | (Optional) table number                     |
| module                | (Optional) Slot/module                      |
| <i>num</i>            | (Optional) Slot/module number               |
| __readonly__          | (Optional)                                  |
| TABLE_ecmp            | (Optional) ecmp table                       |
| <i>num_paths</i>      | (Optional) No of paths                      |
| <i>table_id</i>       | (Optional) table number                     |
| TABLE_adj             | (Optional) Adjacency table                  |
| <i>loc_bsid</i>       | (Optional) Locator or binding sid           |
| <i>source_ip</i>      | (Optional) Source IPV6 address              |
| <i>function</i>       | (Optional) Function                         |

### Command Mode

- /exec

## show forwarding srv6 local-sid

```
show forwarding srv6 local-sid [ <sid_value> ] [ detail ] [ module <num> ] [ __readonly__ { TABLE_local_sid
<locator> <source_ip> <function> <behavior> <sid> } ]
```

### Syntax Description

|                     |                                |
|---------------------|--------------------------------|
| show                | show                           |
| forwarding          | display fib information        |
| srv6                | Segment routing V6             |
| local-sid           | local segment identifier       |
| detail              | (Optional) Details about SID   |
| module              | (Optional) Slot/module         |
| <i>num</i>          | (Optional) Slot/module number  |
| <i>__readonly__</i> | (Optional)                     |
| TABLE_local_sid     | (Optional) Local SID info      |
| <i>locator</i>      | (Optional) Locator             |
| <i>source_ip</i>    | (Optional) Source IPV6 address |
| <i>function</i>     | (Optional) function            |
| <i>behavior</i>     | (Optional) Behavior            |
| <i>sid</i>          | (Optional) Segment identifier  |

### Command Mode

- /exec

## show forwarding srv6 peers

```
show forwarding srv6 peers [ module <num> ] [ __readonly__ { TABLE_peers <peer_id> <locator>
<source_ip> <vobj_count> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | show  |
| forwarding          | display fib information                           |
| srv6                | Segment routing V6                                |
| peers               | SRV6 peer   |
| module              | (Optional) Slot/module                            |
| <i>num</i>          | (Optional) Slot/module number                     |
| <i>__readonly__</i> | (Optional)  |
| TABLE_peers         | (Optional) all SRV6 peers                         |
| <i>peer_id</i>      | (Optional) peer_id                                |
| <i>locator</i>      | (Optional) Locator                                |
| <i>source_ip</i>    | (Optional) Source IPV6 address                    |
| <i>vobj_count</i>   | (Optional) Number of VOBJs dependent on this peer |

### Command Mode

- /exec

# show forwarding trace

show forwarding trace [ clear ] [ module <module> ] [ \_\_readonly\_\_ <op> ]

## Syntax Description

|               |                                   |
|---------------|-----------------------------------|
| show          |                                   |
| forwarding    | display fib information           |
| trace         | display trace buffer              |
| clear         | (Optional) clear the trace buffer |
| module        | (Optional) slot                   |
| <i>module</i> | (Optional) slot number            |
| __readonly__  | (Optional)                        |
| <i>op</i>     | (Optional) output                 |

## Command Mode

- /exec

# show forwarding trace profile

show forwarding trace profile

## Syntax Description

|            |   |
|------------|---|
| show       |   |
| forwarding | display fib information                   |
| trace      | display trace buffer                      |
| profile    | show the collection profiling information |

## Command Mode

- /exec

## show forwarding trace profile funcstats

show forwarding trace profile funcstats [ enable | disable ] [ module <module> ] [ \_\_readonly\_\_ <op> ]

### Syntax Description

|               |   |
|---------------|---|
| show          |   |
| forwarding    | display fib information                   |
| trace         | display trace buffer                      |
| profile       | show the collection profiling information |
| funcstats     | function statistics                       |
| enable        | (Optional) enable function statistics     |
| disable       | (Optional) disable function statistics    |
| module        | (Optional) slot                           |
| <i>module</i> | (Optional) slot number                    |
| __readonly__  | (Optional)                                |
| <i>op</i>     | (Optional) output                         |

### Command Mode

- /exec

## show frequency synchronization clock-interface brief

```
show frequency synchronization clock-interface brief [ __readonly__ [ TABLE_fsync <clock_name>
<source_class> <clock_node> <clock_id> <clock_state> <assigned_for_selection> <ssm_support>
<ssm_enabled> <loop_back> <sqlched> <input_disabled> <output_disabled> <ql_rcv_option> <ql_rcv>
<ql_use_option> <ql_use> <priority> <ql_snt_option> <ql_snt> <selected_source_class> <selected_source_ifh>
<selected_source_clock_node> <selected_source_clock_id> <selected_source_clock_name> ] <fsync-end>
]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                |
| frequency                     | Frequency Synchronization Manager              |
| synchronization               | Frequency Synchronization Manager              |
| clock-interface               | Display clock-interface information            |
| brief                         | Displays all interfaces                        |
| <i>__readonly__</i>           | (Optional) Read Only                           |
| <i>TABLE_fsync</i>            | (Optional) fsync_mgr table                     |
| <i>source_class</i>           | (Optional) class of the source                 |
| <i>clock_node</i>             | (Optional) clock's node id                     |
| <i>clock_id</i>               | (Optional) clock's id                          |
| <i>clock_name</i>             | (Optional) clock name                          |
| <i>clock_state</i>            | (Optional) clock state                         |
| <i>assigned_for_selection</i> | (Optional) whether assigned as selection input |
| <i>ssm_support</i>            | (Optional) ssm support - enabled or disabled   |
| <i>ssm_enabled</i>            | (Optional) ssm enabled - enabled or disabled   |
| <i>loop_back</i>              | (Optional) loopback enabled or disabled        |
| <i>sqlched</i>                | (Optional) output is sqlched or not            |
| <i>input_disabled</i>         | (Optional) input disabled or enabled           |
| <i>output_disabled</i>        | (Optional) output disabled or enabled          |
| <i>ql_rcv_option</i>          | (Optional) ql rcv option                       |
| <i>ql_rcv</i>                 | (Optional) ql rcv                              |
| <i>ql_use_option</i>          | (Optional) ql use option                       |



|                                   |  |
|-----------------------------------|--|
| <i>ql_use</i>                     | (Optional) ql use                      |
| <i>priority</i>                   | (Optional) priority of synce port      |
| <i>ql_snt_option</i>              | (Optional) ql snt option               |
| <i>ql_snt</i>                     | (Optional) ql snt                      |
| <i>selected_source_class</i>      | (Optional) selected source class type  |
| <i>selected_source_ifh</i>        | (Optional) selected source ifh         |
| <i>selected_source_clock_node</i> | (Optional) selected source clock node  |
| <i>selected_source_clock_id</i>   | (Optional) selected source clock id    |
| <i>selected_source_clock_name</i> | (Optional) selected sourced clock name |
| <i>fsync-end</i>                  | (Optional) End of table                |

**Command Mode**

- /exec

## show frequency synchronization clock-interface detail

```
show frequency synchronization clock-interface detail [ __readonly__ [ TABLE_fsyc <clock_name>
<source_class> <clock_node> <clock_id> <clock_state> <clock_type> <pd_down_reason> <selection_input>
<wtr_time> <ssm_state> <ssm_support> <input_disabled> <input_damping_state> <input_damping_time>
<cfgd_in_ql_min_option> <cfgd_in_ql_min> <cfgd_in_ql_max_option> <cfgd_in_ql_max>
<cfgd_in_ql_exact_option> <cfgd_in_ql_exact> <effective_in_ql_option> <effective_in_ql> <priority>
<tod_priority> <supp_freq> <supp_time> <loop_back> <output_disabled> <selected_source_class>
<selected_source_ifh> <selected_source_clock_node> <selected_source_clock_id>
<selected_source_clock_name> <selected_source_ql_option> <selected_source_ql> <cfgd_out_ql_min_option>
<cfgd_out_ql_min> <cfgd_out_ql_max_option> <cfgd_out_ql_max> <cfgd_out_ql_exact_option>
<cfgd_out_ql_exact> <effective_out_ql_option> <effective_out_ql> <sqlched> <num_next_seln_points>
<next_selection_points> + <current_clock_end> ] <fsync-end> ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                |
| frequency              | Frequency Synchronization Manager              |
| synchronization        | Frequency Synchronization Manager              |
| clock-interface        | Display clock-interface information            |
| detail                 | details  |
| <i>__readonly__</i>    | (Optional) Read Only                           |
| <i>TABLE_fsyc</i>      | (Optional) fsync_mgr table                     |
| <i>source_class</i>    | (Optional) class of the source                 |
| <i>clock_node</i>      | (Optional) clock's node id                     |
| <i>clock_id</i>        | (Optional) clock's id                          |
| <i>clock_name</i>      | (Optional) clock name                          |
| <i>clock_state</i>     | (Optional) clock state                         |
| <i>clock_type</i>      | (Optional) clock's type                        |
| <i>pd_down_reason</i>  | (Optional) clock pd down reason                |
| <i>selection_input</i> | (Optional) whether assigned as selection input |
| <i>wtr_time</i>        | (Optional) wait to restore timer value         |
| <i>ssm_state</i>       | (Optional) ssm state - enabled or disabled     |
| <i>ssm_support</i>     | (Optional) ssm supprt                          |
| <i>input_disabled</i>  | (Optional) input disabled or enabled           |

|                                   |  |
|-----------------------------------|--|
| <i>input_damping_state</i>        | (Optional) input dampiung state              |
| <i>input_damping_time</i>         | (Optional) input damping time                |
| <i>cfgd_in_ql_min_option</i>      | (Optional) cfg in min ql option              |
| <i>cfgd_in_ql_min</i>             | (Optional) cfg in min ql option              |
| <i>cfgd_in_ql_max_option</i>      | (Optional) cfg in max ql option              |
| <i>cfgd_in_ql_max</i>             | (Optional) cfg in max ql option              |
| <i>cfgd_in_ql_exact_option</i>    | (Optional) cfg in exact ql option            |
| <i>cfgd_in_ql_exact</i>           | (Optional) cfg in exact ql option            |
| <i>effective_in_ql_option</i>     | (Optional) cfg in ql option                  |
| <i>effective_in_ql</i>            | (Optional) cfg in ql option                  |
| <i>priority</i>                   | (Optional) priority                          |
| <i>tod_priority</i>               | (Optional) time of day priority              |
| <i>supp_freq</i>                  | (Optional) supporting freq sync or time sync |
| <i>supp_time</i>                  | (Optional) supporting time sync              |
| <i>loop_back</i>                  | (Optional) loopback enabled or disabled      |
| <i>output_disabled</i>            | (Optional) output disabled or enabled        |
| <i>selected_source_class</i>      | (Optional) selected source class type        |
| <i>selected_source_ifh</i>        | (Optional) selected source ifh               |
| <i>selected_source_clock_node</i> | (Optional) selected source clock node        |
| <i>selected_source_clock_id</i>   | (Optional) selected source clock id          |
| <i>selected_source_clock_name</i> | (Optional) selected sourced clock name       |
| <i>selected_source_ql_option</i>  | (Optional) selected source ql option         |
| <i>selected_source_ql</i>         | (Optional) effective out ql option           |
| <i>cfgd_out_ql_min_option</i>     | (Optional) cfg out min ql option             |
| <i>cfgd_out_ql_min</i>            | (Optional) cfg out min ql option             |
| <i>cfgd_out_ql_max_option</i>     | (Optional) cfg out max ql option             |
| <i>cfgd_out_ql_max</i>            | (Optional) cfg out max ql option             |
| <i>cfgd_out_ql_exact_option</i>   | (Optional) cfg out exact ql option           |
| <i>cfgd_out_ql_exact</i>          | (Optional) cfg out exact ql option           |

|                                |                                       |
|--------------------------------|---------------------------------------|
| <i>effective_out_ql_option</i> | (Optional) effective out ql option    |
| <i>effective_out_ql</i>        | (Optional) effective out ql option    |
| <i>squelched</i>               | (Optional) output is squelched or not |
| <i>num_next_seln_points</i>    | (Optional) num of next seln points    |
| <i>next_selection_points</i>   | (Optional) next selection points      |
| <i>current_clock_end</i>       | (Optional) cuurent clock end          |
| <i>fsync-end</i>               | (Optional) End of table               |

**Command Mode**

- /exec

## show frequency synchronization configuration errors

```
show frequency synchronization configuration errors [ __readonly__ [ TABLE_fsync <fsync_src> <enable_err>
<input_min_err> <input_exact_err> <input_max_err> <output_min_err> <output_exact_err> <output_max_err>
<ext_ql_input_min_err> <ext_ql_input_exact_err> <ext_ql_input_max_err> <ext_ql_output_min_err>
<ext_ql_output_exact_err> <ext_ql_output_max_err> <input_output_mismatch> <input_min_ql_option>
<input_min_ql> <input_exact_ql_option> <input_exact_ql> <input_max_ql_option> <input_max_ql>
<output_min_ql_option> <output_min_ql> <output_exact_ql_option> <output_exact_ql>
<output_max_ql_option> <output_max_ql> <cmd_src_index> ] <fsync-end> ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                   |
| frequency               | Frequency Synchronization Manager                 |
| synchronization         | Frequency Synchronization Manager                 |
| configuration           | configuration                                     |
| errors                  | errors  |
| <u>__readonly__</u>     | (Optional) Read Only                              |
| TABLE_fsync             | (Optional) fsync_mgr table                        |
| fsync_src               | (Optional) Interface Index                        |
| enable_err              | (Optional) freq sync enable error                 |
| input_min_err           | (Optional) Minimum input QL option config error   |
| input_exact_err         | (Optional) Exact input QL config error            |
| input_max_err           | (Optional) Maximum input QL option config error   |
| output_min_err          | (Optional) Minimum output QL option config error  |
| output_exact_err        | (Optional) Exact output QL option config error    |
| output_max_err          | (Optional) Maximum output QL option config error  |
| ext_ql_input_min_err    | (Optional) minimum input extended Ql config error |
| ext_ql_input_exact_err  | (Optional) exact input extended Ql config error   |
| ext_ql_input_max_err    | (Optional) maximum input extended Ql config error |
| ext_ql_output_min_err   | (Optional) min output extended ql config error    |
| ext_ql_output_exact_err | (Optional) exact output extended ql config error  |
| ext_ql_output_max_err   | (Optional) max output extended ql config error    |
| input_output_mismatch   | (Optional) input/output mismatch error            |

|                               |                                       |
|-------------------------------|---------------------------------------|
| <i>input_min_ql_option</i>    | (Optional) input min ql option        |
| <i>input_min_ql</i>           | (Optional) configured min input ql    |
| <i>input_exact_ql_option</i>  | (Optional) input exact ql option      |
| <i>input_exact_ql</i>         | (Optional) configured exact input ql  |
| <i>input_max_ql_option</i>    | (Optional) input exact ql option      |
| <i>input_max_ql</i>           | (Optional) configured max input ql    |
| <i>output_min_ql_option</i>   | (Optional) output min ql option       |
| <i>output_min_ql</i>          | (Optional) configured min output ql   |
| <i>output_exact_ql_option</i> | (Optional) output exact ql option     |
| <i>output_exact_ql</i>        | (Optional) configured exact output ql |
| <i>output_max_ql_option</i>   | (Optional) output exact ql option     |
| <i>output_max_ql</i>          | (Optional) configured max output ql   |
| <i>cmd_src_index</i>          | (Optional) index for source array     |
| <i>fsync-end</i>              | (Optional) End of table               |

**Command Mode**

- /exec

## show frequency synchronization interface

```
show frequency synchronization interface <if0> [ __readonly__ <if_state> <selection_input> <wtr_time>
<ssm_state> <esmc_peer_state> <esmc_peer_time_secs> <esmc_peer_time_nsecs> <last_ssm_time_secs>
<last_ssm_time_nsecs> <peer_up_count> <peer_timeout_count> <esmc_infos_sent> <esmc_events_sent>
<esmc_dnus_sent> <esmc_infos_rcvd> <esmc_events_rcvd> <esmc_dnus_rcvd> <esmc_malformed_rcvd>
<esmc_rcvd_error> <input_damping_state> <input_damping_time> [ <last_rcvd_ql_option> ] [ <last_rcvd_ql>
] <cfgd_in_ql_min_option> <cfgd_in_ql_min> <cfgd_in_ql_max_option> <cfgd_in_ql_max>
<cfgd_in_ql_exact_option> <cfgd_in_ql_exact> [ <effective_in_ql_option> ] [ <effective_in_ql> ] <priority>
<tod_priority> [ <ql_data_rcvd_has_ext_data> ] [ <ql_data_rcvd_orig_clock_id> ] [
<ql_data_rcvd_synce_steps> ] [ <ql_data_rcvd_esynce_steps> ] [ <ql_data_rcvd_all_steps_synce> ] [
<ql_data_rcvd_chain_complete> ] <supp_freq> <supp_time> [ <selected_source_class> ] [
<selected_source_ifh> ] [ <selected_source_clock_node> ] [ <selected_source_clock_id> ] [
<selected_source_clock_name> ] [ <selected_source_ql_option> ] [ <selected_source_ql> ]
<cfgd_out_ql_min_option> <cfgd_out_ql_min> <cfgd_out_ql_max_option> <cfgd_out_ql_max>
<cfgd_out_ql_exact_option> <cfgd_out_ql_exact> [ <effective_out_ql_option> ] [ <effective_out_ql> ] [
<ql_data_to_send_has_ext_data> ] [ <ql_data_to_send_orig_clock_id> ] [ <ql_data_to_send_synce_steps>
] [ <ql_data_to_send_esynce_steps> ] [ <ql_data_to_send_all_steps_synce> ] [
<ql_data_to_send_chain_complete> ] <sqelched> <num_next_seln_points> <next_selection_points> + ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                |
| frequency                   | Frequency Synchronization Manager              |
| synchronization             | Frequency Synchronization Manager              |
| interface                   | Display interface information                  |
| <i>if0</i>                  |  |
| <i>__readonly__</i>         | (Optional) Read Only                           |
| <i>if_state</i>             | (Optional) interface state                     |
| <i>selection_input</i>      | (Optional) whether assigned as selection input |
| <i>wtr_time</i>             | (Optional) wait to restore timer value         |
| <i>ssm_state</i>            | (Optional) ssm state - enabled or disabled     |
| <i>esmc_peer_state</i>      | (Optional) esmc peer state                     |
| <i>esmc_peer_time_secs</i>  | (Optional) peer up or down time recorded secs  |
| <i>esmc_peer_time_nsecs</i> | (Optional) peer up or down time recorded nsecs |
| <i>last_ssm_time_secs</i>   | (Optional) last ssm received time in secs      |
| <i>last_ssm_time_nsecs</i>  | (Optional) last ssm received time in nsecs     |
| <i>peer_up_count</i>        | (Optional) no of times peer went up            |

## show frequency synchronization interface

|                                     |  |
|-------------------------------------|--|
| <i>peer_timeout_count</i>           | (Optional) no of times peer timed out          |
| <i>esmc_infos_sent</i>              | (Optional) esmc infos sent                     |
| <i>esmc_events_sent</i>             | (Optional) esmc events sent                    |
| <i>esmc_dnus_sent</i>               | (Optional) esmc dnus sent                      |
| <i>esmc_infos_rcvd</i>              | (Optional) esmc infos rcvd                     |
| <i>esmc_events_rcvd</i>             | (Optional) esmc events rcvd                    |
| <i>esmc_dnus_rcvd</i>               | (Optional) esmc dnus rcvd                      |
| <i>esmc_malformed_rcvd</i>          | (Optional) esmc malformed rcvd frames          |
| <i>esmc_rcvd_error</i>              | (Optional) esmc rcvd frame errors              |
| <i>input_damping_state</i>          | (Optional) input dampiung state                |
| <i>input_damping_time</i>           | (Optional) input damping time                  |
| <i>last_rcvd_ql_option</i>          | (Optional) last ql rcv option                  |
| <i>last_rcvd_ql</i>                 | (Optional) last rcvd ql                        |
| <i>cfgd_in_ql_min_option</i>        | (Optional) cfgd in ql min option               |
| <i>cfgd_in_ql_min</i>               | (Optional) cfg in ql min                       |
| <i>cfgd_in_ql_max_option</i>        | (Optional) cfgd in ql mAX option               |
| <i>cfgd_in_ql_max</i>               | (Optional) cfgd in max ql                      |
| <i>cfgd_in_ql_exact_option</i>      | (Optional) cfgd in ql exact option             |
| <i>cfgd_in_ql_exact</i>             | (Optional) cfgd in exact ql                    |
| <i>effective_in_ql_option</i>       | (Optional) effe in ql option                   |
| <i>effective_in_ql</i>              | (Optional) eff in ql                           |
| <i>priority</i>                     | (Optional) priority                            |
| <i>tod_priority</i>                 | (Optional) time of day priority                |
| <i>ql_data_rcvd_has_ext_data</i>    | (Optional) ql data rcvd extended data or not   |
| <i>ql_data_rcvd_synce_steps</i>     | (Optional) ql data rcvd synce steps            |
| <i>ql_data_rcvd_esynce_steps</i>    | (Optional) ql data rcvd extended synce steps   |
| <i>ql_data_rcvd_all_steps_synce</i> | (Optional) ql data rcvd all steps synce or not |
| <i>ql_data_rcvd_chain_complete</i>  | (Optional) ql data rcvd chain complete         |
| <i>supp_freq</i>                    | (Optional) supporting freq sync or time sync   |



|  |   |
|--|---|
| <i>supp_time</i>                       | (Optional) supporting time sync                 |
| <i>selected_source_class</i>           | (Optional) selected source class type           |
| <i>selected_source_ifh</i>             | (Optional) selected source ifh                  |
| <i>selected_source_clock_node</i>      | (Optional) selected source clock node           |
| <i>selected_source_clock_id</i>        | (Optional) selected source clock id             |
| <i>selected_source_clock_name</i>      | (Optional) selected sourced clock name          |
| <i>selected_source_ql_option</i>       | (Optional) selected source ql option            |
| <i>selected_source_ql</i>              | (Optional) selected source ql                   |
| <i>cfgd_out_ql_min_option</i>          | (Optional) cfgd out ql min option               |
| <i>cfgd_out_ql_min</i>                 | (Optional) cfg out ql min                       |
| <i>cfgd_out_ql_max_option</i>          | (Optional) cfgd out ql max option               |
| <i>cfgd_out_ql_max</i>                 | (Optional) cfgd out max ql                      |
| <i>cfgd_out_ql_exact_option</i>        | (Optional) cfgd out ql exact option             |
| <i>cfgd_out_ql_exact</i>               | (Optional) cfgd out exact ql                    |
| <i>effective_out_ql_option</i>         | (Optional) eff out ql option                    |
| <i>effective_out_ql</i>                | (Optional) effec out ql                         |
| <i>ql_data_to_send_has_ext_data</i>    | (Optional) ql data to send extended data or not |
| <i>ql_data_to_send_synce_steps</i>     | (Optional) ql data send synce steps             |
| <i>ql_data_to_send_esynce_steps</i>    | (Optional) ql data send extended synce steps    |
| <i>ql_data_to_send_all_steps_synce</i> | (Optional) ql data send all steps synce or not  |
| <i>ql_data_to_send_chain_complete</i>  | (Optional) ql data send chain complete          |
| <i>squelched</i>                       | (Optional) output is squelched or not           |
| <i>num_next_seln_points</i>            | (Optional) num of next seln points              |
| <i>next_selection_points</i>           | (Optional) next selection points                |

### Command Mode

- /exec

## show frequency synchronization interface brief

```
show frequency synchronization interface brief [ __readonly__ [ TABLE_fsync <fsync_port> <if_state>
<assigned_for_selection> <ssm_state> <esmc_peer_state> <sqlched> [ <ql_rcv_option> ] [ <ql_rcv> ] [
<ql_use_option> ] [ <ql_use> ] <priority> [ <ql_snt_option> ] [ <ql_snt> ] [ <selected_source_class> ] [
<selected_source_ifh> ] [ <selected_source_clock_node> ] [ <selected_source_clock_id> ] [
<selected_source_clock_name> ] <port_end> ] <fsync-end> ]
```

### Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                |
| frequency                         | Frequency Synchronization Manager              |
| synchronization                   | Frequency Synchronization Manager              |
| interface                         | Display interface information                  |
| brief                             | Displays all interfaces                        |
| <i>__readonly__</i>               | (Optional) Read Only                           |
| <i>TABLE_fsync</i>                | (Optional) fsync_mgr table                     |
| <i>fsync_port</i>                 | (Optional) Interface Index                     |
| <i>if_state</i>                   | (Optional) interface state                     |
| <i>assigned_for_selection</i>     | (Optional) whether assigned as selection input |
| <i>ssm_state</i>                  | (Optional) ssm state - enabled or disabled     |
| <i>esmc_peer_state</i>            | (Optional) esmc peer state                     |
| <i>sqlched</i>                    | (Optional) output is sqlched or not            |
| <i>ql_rcv_option</i>              | (Optional) ql rcv option                       |
| <i>ql_rcv</i>                     | (Optional) ql rcv                              |
| <i>ql_use_option</i>              | (Optional) ql use option                       |
| <i>ql_use</i>                     | (Optional) ql use                              |
| <i>priority</i>                   | (Optional) priority of synce port              |
| <i>ql_snt_option</i>              | (Optional) ql snt option                       |
| <i>ql_snt</i>                     | (Optional) ql snt                              |
| <i>selected_source_class</i>      | (Optional) selected source class type          |
| <i>selected_source_ifh</i>        | (Optional) selected source ifh                 |
| <i>selected_source_clock_node</i> | (Optional) selected source clock node          |

|                                   |  |
|-----------------------------------|--|
| <i>selected_source_clock_id</i>   | (Optional) selected source clock id    |
| <i>selected_source_clock_name</i> | (Optional) selected sourced clock name |
| <i>port_end</i>                   | (Optional) end of current port         |
| <i>fsync-end</i>                  | (Optional) End of table                |

**Command Mode**

- /exec

## show frequency synchronization selection

```
show frequency synchronization selection [ __readonly__ [ TABLE_sp <seln_pt> <num_inputs>
<num_inputs_selected> <last_programmed_secs> <last_programmed_nsecs> <last_selection_secs>
<last_selection_nsecs> [ <spa_selection_points> + ] [ <spa_selection_points_num> ] [ <node_selection_points>
+ ] [ <node_selection_points_num> ] [ <chassis_selection_points> + ] [ <chassis_selection_points_num> ] [
<router_selection_points> + ] [ <router_selection_points_num> ] <tod_sp> <local_line_output>
<local_clock_output> <local_tod_output> <stream_table_start> [ TABLE_stream <output_id> <input>
<last_sp> <ql> [ <tod_priority> ] <priority> <state> ] <stream-end> ] <sp-end> ]
```

### Syntax Description

|                                     |   |
|-------------------------------------|---|
| show                                | Show running system information                         |
| frequency                           | Frequency Synchronization Manager                       |
| synchronization                     | Frequency Synchronization Manager                       |
| selection                           | Display selection information                           |
| <i>__readonly__</i>                 | (Optional) Read Only                                    |
| <i>TABLE_sp</i>                     | (Optional) fsync_mgr table                              |
| <i>seln_pt</i>                      | (Optional) selection points                             |
| <i>num_inputs</i>                   | (Optional) num of inputs                                |
| <i>num_inputs_selected</i>          | (Optional) num of inputs                                |
| <i>last_programmed_secs</i>         | (Optional) last programmed time:secs                    |
| <i>last_programmed_nsecs</i>        | (Optional) last programmed time:nsecs                   |
| <i>last_selection_secs</i>          | (Optional) last selection time:secs                     |
| <i>last_selection_nsecs</i>         | (Optional) last selection time:nsecs                    |
| <i>spa_selection_points</i>         | (Optional) SPA selection points                         |
| <i>spa_selection_points_num</i>     | (Optional) Number of SPA selection points               |
| <i>node_selection_points</i>        | (Optional) Node selection points                        |
| <i>node_selection_points_num</i>    | (Optional) Number of node selection points              |
| <i>chassis_selection_points</i>     | (Optional) chassis selection points                     |
| <i>chassis_selection_points_num</i> | (Optional) Number of chassis selection points           |
| <i>router_selection_points</i>      | (Optional) router selection points                      |
| <i>router_selection_points_num</i>  | (Optional) Number of Router selection points            |
| <i>tod_sp</i>                       | (Optional) Use Time of day selection point else freq sp |

|                           |   |
|---------------------------|---|
| <i>local_line_output</i>  | (Optional) used for local line output or not        |
| <i>local_clock_output</i> | (Optional) used for local clock output or not       |
| <i>local_tod_output</i>   | (Optional) used for local time of day output or not |
| <i>stream_table_start</i> | (Optional) stream table start                       |
| TABLE_stream              | (Optional) stream table                             |
| <i>output_id</i>          | (Optional) output id of stream                      |
| <i>input</i>              | (Optional) source input for the stream              |
| <i>last_sp</i>            | (Optional) last selection point string              |
| <i>ql</i>                 | (Optional) QL of the selected source                |
| <i>tod_priority</i>       | (Optional) time of day priority                     |
| <i>priority</i>           | (Optional) priority of source                       |
| <i>state</i>              | (Optional) state of the stream                      |
| <i>stream-end</i>         | (Optional) End of SP table                          |
| <i>sp-end</i>             | (Optional) End of SP table                          |

**Command Mode**

- /exec

# show fspf

show fspf

## Syntax Description

|      |                                 |
|------|---------------------------------|
| show | Show running system information |
|------|---------------------------------|

## Command Mode

- /exec

# show fspf database

```
show fspf database [ vsan <i0> [ [ domain <i1> ] [ detail ] ] ]
```

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                  |
| database  | Show FSPF link state database                    |
| vsan      | (Optional) Enter VSAN                            |
| <i>i0</i> | (Optional) VSAN id                               |
| domain    | (Optional) Show LSR of a domain                  |
| <i>i1</i> | (Optional) domain index                          |
| detail    | (Optional) Gives detailed information on the LSR |

## Command Mode

- /exec

# show fspf interface

show fspf interface

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                  |
| interface | Show FSPF related information about an interface |

## Command Mode

- /exec



# show fspf vsan

show fspf vsan <i0>

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| vsan      | Enter VSAN                      |
| <i>i0</i> | VSAN id                         |

## Command Mode

- /exec

# show fspf vsan interface

show fspf vsan <i0> interface [ <if0> ]

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                             |
| vsan       | Enter VSAN  |
| <i>i0</i>  | VSAN id   |
| interface  | Show FSPF related information about an interface            |
| <i>if0</i> | (Optional) Show FSPF related information about an interface |

## Command Mode

- /exec



# show fte exporter

```
show fte exporter [ name ] [ <exportername> ] [ __readonly__ <exporter> <description> <dest> <vrf> <vrf_id>
<vrf_resolved> <dest_udp> <source_intf> <source_ip> <exporter-id> ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information         |
| fte                 | Show FTE information                    |
| exporter            | Show FTE Exporter Configuration         |
| name                | (Optional) Show a specific FTE Exporter |
| <i>exportername</i> | (Optional) Specify an exporter          |
| <i>__readonly__</i> | (Optional)                              |
| <i>exporter</i>     | (Optional)                              |
| <i>description</i>  | (Optional)                              |
| <i>dest</i>         | (Optional)                              |
| <i>vrf</i>          | (Optional)                              |
| <i>vrf_id</i>       | (Optional)                              |
| <i>vrf_resolved</i> | (Optional)                              |
| <i>dest_udp</i>     | (Optional)                              |
| <i>source_intf</i>  | (Optional)                              |
| <i>source_ip</i>    | (Optional)                              |
| <i>exporter-id</i>  | (Optional)                              |

## Command Mode

- /exec

# show fte monitor

```
show fte monitor [ name ] [ <monitorname> [ cache [ detailed ] ] ] [ __readonly__ <monitor> <use_count>
<description> <record> <event> <exporter1> <exporter2> <bucket_id> <src_addr> <dest_addr> ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| fte                 | Show FTE information                      |
| monitor             | Show Monitor Configuration                |
| name                | (Optional) Show a specific FTE Monitor    |
| <i>monitorname</i>  | (Optional) Specify a monitor              |
| cache               | (Optional) Flow monitor cache contents    |
| detailed            | (Optional) Show the entire cache contents |
| <i>__readonly__</i> | (Optional)                                |
| <i>monitor</i>      | (Optional)                                |
| <i>use_count</i>    | (Optional)                                |
| <i>description</i>  | (Optional)                                |
| <i>record</i>       | (Optional)                                |
| <i>event</i>        | (Optional)                                |
| <i>exporter1</i>    | (Optional)                                |
| <i>exporter2</i>    | (Optional)                                |
| <i>bucket_id</i>    | (Optional)                                |
| <i>src_addr</i>     | (Optional)                                |
| <i>dest_addr</i>    | (Optional)                                |

## Command Mode

- /exec

## show fte record

```
show fte record [ name ] [ { <recordname> } | { fte-original } | { fte { protocol-port | layer2-switched { input
} | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ [ { TABLE_fte_record <record> [ <description>
] <use_count> [ <match_ipv4_params> + ] [ <match_ipv6_params> + ] [ <match_datalink_params> + } ] ]
]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                             |
| fte                          | Show FTE information  |
| record                       | Show Record Configuration                                   |
| name                         | (Optional) Show the configuration for a specific FTE Record |
| <i>recordname</i>            | (Optional) Specify a record                                 |
| fte-original                 | (Optional) Traditional IPv4 input FTE with origin ASs       |
| fte                          | (Optional) Traditional FTE collection schemes               |
| ipv4                         | (Optional) IPv4 collection schemes                          |
| ipv6                         | (Optional) IPv6 collection schemes                          |
| l2                           | (Optional) L2 collection schemes                            |
| layer2-switched              | (Optional) Layer2-Switched collection schemes               |
| original-input               | (Optional) Input FTE  |
| input                        | (Optional) Input FTE  |
| protocol-port                | (Optional) Protocol and Ports aggregation scheme            |
| __readonly__                 | (Optional)  |
| TABLE_fte_record             | (Optional) Record Table                                     |
| <i>record</i>                | (Optional) FTE Record                                       |
| <i>description</i>           | (Optional) Description for FTE description                  |
| <i>use_count</i>             | (Optional) Use count for FTE record                         |
| <i>match_ipv4_params</i>     | (Optional) Match IPv4 parameters under record               |
| <i>match_ipv6_params</i>     | (Optional) Match IPv6 parameters under record               |
| <i>match_datalink_params</i> | (Optional) Match datalink parameters under record           |

### Command Mode

- /exec







## G Show Commands

---

- [show guestshell](#), on page 764

# show guestshell

```
show guestshell [ { detail } ] [ __readonly__ [ TABLE_detail <name> <state> <package_name> <ova_path>
<application_name> <application_version> <application_description> <key_type> <signing_method>
<licensing_name> <licensing_version> <disk_reservation> <memory_reservation> <cpu_reservation>
TABLE_attached_devices <type> <name> <alias> ] ]
```

## Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                     |
| guestshell                     | Display guest shell service information             |
| detail                         | (Optional) Detailed guest shell service information |
| __readonly__                   | (Optional) Read Only                                |
| TABLE_detail                   | (Optional) Virtual service detail table             |
| <i>name</i>                    | (Optional) Virtual service name                     |
| <i>package_name</i>            | (Optional) Virtual service package name             |
| <i>application_name</i>        | (Optional) Name of the application                  |
| <i>application_version</i>     | (Optional) Version of the application               |
| <i>application_description</i> | (Optional) Description of the application           |
| <i>key_type</i>                | (Optional) Virtual service key type                 |
| <i>signing_method</i>          | (Optional) Method used to sign the package          |
| <i>licensing_name</i>          | (Optional) Name of the license                      |
| <i>licensing_version</i>       | (Optional) Version of the license                   |
| <i>ova_path</i>                | (Optional) Virtual service OVA path                 |
| <i>state</i>                   | (Optional) Virtual service state                    |
| <i>disk_reservation</i>        | (Optional) Virtual service disk reservation         |
| <i>memory_reservation</i>      | (Optional) Virtual service memory reservation       |
| <i>cpu_reservation</i>         | (Optional) Virtual service CPU reservation          |
| TABLE_attached_devices         | (Optional) Attached devices table                   |
| <i>type</i>                    | (Optional) Type of the attached device              |
| <i>name</i>                    | (Optional) Name of the attached device              |
| <i>alias</i>                   | (Optional) Alias for the attached device            |

## Command Mode

- /exec





## H Show Commands

---

- [show hardware, on page 769](#)
- [show hardware access-list lou resource threshold, on page 772](#)
- [show hardware access-list resource pooling, on page 773](#)
- [show hardware access-list tcam, on page 774](#)
- [show hardware capacity, on page 775](#)
- [show hardware capacity eobc, on page 776](#)
- [show hardware capacity fabric-utilization, on page 777](#)
- [show hardware capacity forwarding, on page 778](#)
- [show hardware capacity interface, on page 779](#)
- [show hardware capacity module, on page 780](#)
- [show hardware capacity power, on page 782](#)
- [show hardware fabricpath mac-learning module, on page 783](#)
- [show hardware feature-capability, on page 784](#)
- [show hardware flow aging, on page 785](#)
- [show hardware flow entry address type, on page 786](#)
- [show hardware flow ip, on page 787](#)
- [show hardware flow ipv6, on page 788](#)
- [show hardware flow l2, on page 789](#)
- [show hardware flow mpls, on page 790](#)
- [show hardware flow sampler, on page 791](#)
- [show hardware flow tah-etrap, on page 792](#)
- [show hardware flow utilization, on page 793](#)
- [show hardware forwarding interface statistics mode, on page 794](#)
- [show hardware forwarding memory health detail, on page 795](#)
- [show hardware forwarding memory health summary, on page 798](#)
- [show hardware ip verify, on page 800](#)
- [show hardware profile forwarding-mode, on page 801](#)
- [show hardware profile module, on page 802](#)
- [show hardware profile packet-drop, on page 803](#)
- [show hardware profile portmode, on page 804](#)
- [show hardware profile status, on page 805](#)
- [show hardware profile tcam region, on page 807](#)
- [show hardware qos afd profile, on page 808](#)

- [show hardware qos burst-detect max-records](#), on page 809
- [show hardware qos eoq stats-class](#), on page 810
- [show hardware qos include ipg](#), on page 811
- [show hardware qos ing-pg-hdrm-reserve](#), on page 812
- [show hardware qos ing-pg-no-min](#), on page 813
- [show hardware qos ing-pg-share](#), on page 814
- [show hardware qos min-buffer](#), on page 815
- [show hardware qos ns-buffer-profile](#), on page 816
- [show hardware qos ns-mcq3-alias](#), on page 817
- [show hardware rate-limiter](#), on page 818
- [show hardware rate-limiter](#), on page 820
- [show hardware rate-limiter span-egress](#), on page 822
- [show hardware vxlan storm-control](#), on page 823
- [show hostname](#), on page 824
- [show hosts](#), on page 825
- [show hsrp](#), on page 827
- [show hsrp anycast](#), on page 831
- [show hsrp anycast interface vlan](#), on page 832
- [show hsrp anycast remote-db](#), on page 833
- [show hsrp anycast summary](#), on page 834
- [show hsrp bfd-sessions](#), on page 835
- [show hsrp delay](#), on page 837
- [show hsrp mgo](#), on page 838
- [show hsrp summary](#), on page 839

# show hardware

```
show hardware [ __readonly__ <header_str> <bios_ver_str> [ <loader_ver_str> ] <kickstart_ver_str>
<nxos_ver_str> [ <sys_ver_str> ] <bios_cmpl_time> <kick_file_name> <nxos_file_name> <kick_cmpl_time>
<nxos_cmpl_time> <kick_tmstamp> <nxos_tmstamp> [ <isan_file_name> ] [ <isan_cmpl_time> ] [
<isan_tmstamp> ] <chassis_id> [ <module_id> ] <cpu_name> <memory> <mem_type> <proc_board_id> [
<host_name> ] <bootflash_size> [ <slot0_size> ] [ <slot1_size> ] <kern_uptm_days> <kern_uptm_hrs>
<kern_uptm_mins> <kern_uptm_secs> [ <rr_usecs> ] [ <rr_ctime> ] <rr_reason> [ <rr_sys_ver> ] [
<rr_service> ] <plugins> [ <manufacturer> ] { TABLE_slot [ TABLE_slot_info [ [ <num_slot_str> ] [
<status_ok_empty> ] [ [ <type> [ <num_submods> ] ] <model_num> <hw_ver> <part_num> <part_revision>
<manuf_date> <serial_num> <CLEI_code> [ <num_slot_str> ] ] ] ] }
```

## Syntax Description

|                          |                                 |
|--------------------------|---------------------------------|
| show                     | Show running system information |
| hardware                 | Show hardware information       |
| <i>__readonly__</i>      | (Optional)                      |
| <i>header_str</i>        | (Optional)                      |
| <i>bios_ver_str</i>      | (Optional)                      |
| <i>loader_ver_str</i>    | (Optional)                      |
| <i>kickstart_ver_str</i> | (Optional)                      |
| <i>nxos_ver_str</i>      | (Optional)                      |
| <i>sys_ver_str</i>       | (Optional)                      |
| <i>bios_cmpl_time</i>    | (Optional)                      |
| <i>kick_file_name</i>    | (Optional)                      |
| <i>nxos_file_name</i>    | (Optional)                      |
| <i>kick_cmpl_time</i>    | (Optional)                      |
| <i>nxos_cmpl_time</i>    | (Optional)                      |
| <i>kick_tmstamp</i>      | (Optional)                      |
| <i>nxos_tmstamp</i>      | (Optional)                      |
| <i>isan_file_name</i>    | (Optional)                      |
| <i>isan_cmpl_time</i>    | (Optional)                      |
| <i>isan_tmstamp</i>      | (Optional)                      |
| <i>chassis_id</i>        | (Optional)                      |

|                        |                                       |
|------------------------|---------------------------------------|
| <i>module_id</i>       | (Optional)                            |
| <i>cpu_name</i>        | (Optional)                            |
| <i>memory</i>          | (Optional)                            |
| <i>mem_type</i>        | (Optional)                            |
| <i>proc_board_id</i>   | (Optional)                            |
| <i>bootflash_size</i>  | (Optional)                            |
| <i>slot0_size</i>      | (Optional)                            |
| <i>slot1_size</i>      | (Optional)                            |
| <i>host_name</i>       | (Optional)                            |
| <i>kern_uptm_days</i>  | (Optional)                            |
| <i>kern_uptm_hrs</i>   | (Optional)                            |
| <i>kern_uptm_mins</i>  | (Optional)                            |
| <i>kern_uptm_secs</i>  | (Optional)                            |
| <i>rr_usecs</i>        | (Optional)                            |
| <i>rr_ctime</i>        | (Optional)                            |
| <i>rr_reason</i>       | (Optional)                            |
| <i>rr_sys_ver</i>      | (Optional)                            |
| <i>rr_service</i>      | (Optional)                            |
| <i>plugins</i>         | (Optional)                            |
| <i>manufacturer</i>    | (Optional)                            |
| TABLE_slot             | (Optional) Slot                       |
| <i>num_slot_str</i>    | (Optional) Number of elements         |
| TABLE_slot_info        | (Optional) Slot Info                  |
| <i>status_ok_empty</i> | (Optional) Status (Present or Absent) |
| <i>type</i>            | (Optional) Description of the element |
| <i>num_submods</i>     | (Optional) Number of Submodules       |
| <i>model_num</i>       | (Optional) Model Number               |
| <i>hw_ver</i>          | (Optional) Hardware version           |
| <i>part_num</i>        | (Optional) Part Number                |



|                      |                               |
|----------------------|-------------------------------|
| <i>part_revision</i> | (Optional) Part revision      |
| <i>manuf_date</i>    | (Optional) Manufacturing date |
| <i>serial_num</i>    | (Optional) Serial Number      |
| <i>CLEI_code</i>     | (Optional) CLEI code          |

**Command Mode**

- /exec

## show hardware access-list lou resource threshold

```
show hardware access-list lou resource threshold [ __readonly__ { current [ { lou [ { resource [ { threshold [
{ <threshold_value> } ] } ] } ] } ] }
```

### Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| hardware               | Show hardware information       |
| access-list            | Access Control List             |
| lou                    | LOU                             |
| resource               | hardware resource               |
| threshold              | port expansion threshold        |
| <i>__readonly__</i>    | (Optional)                      |
| current                | (Optional)                      |
| lou                    | (Optional)                      |
| resource               | (Optional)                      |
| threshold              | (Optional)                      |
| <i>threshold_value</i> | (Optional)                      |

### Command Mode

- /exec

# show hardware access-list resource pooling

show hardware access-list resource pooling [ *\_\_readonly\_\_* <mod-num> <status> ]

## Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                | Show running system information   |
| hardware            | Show hardware information         |
| access-list         | Access Control List               |
| resource            | Hardware resource                 |
| pooling             | ACL programming across TCAM banks |
| <i>__readonly__</i> | (Optional)                        |
| <i>mod-num</i>      | (Optional) module number          |
| <i>status</i>       | (Optional) Banchaining status     |

## Command Mode

- /exec

## show hardware access-list tcam

```
show hardware access-list tcam { { template { nfe | nfe2 | l2-l3 | l3 | <name> | all } } | { region } } [
__readonly__ { TCAM_Region [ { TABLE_Sizes <type> <tcam_size> <tcam_width> } ] } ]
```

### Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information         |
| hardware          | Show hardware information               |
| access-list       | Access Control List                     |
| tcam              | Show tcam parameters                    |
| region            | Show tcam region sizes                  |
| __readonly__      | (Optional)                              |
| TCAM_Region       | (Optional)                              |
| TABLE_Sizes       | (Optional)                              |
| <i>type</i>       | (Optional)                              |
| <i>tcam_size</i>  | (Optional)                              |
| <i>tcam_width</i> | (Optional)                              |
| template          | Specify template name                   |
| nfe               | NFE (Trident2) TCAM template            |
| nfe2              | NFE2 (Tomahawk) tcam template           |
| l2-l3             | L2-L3 default tcam template             |
| l3                | L3 default tcam template                |
| <i>name</i>       | Name of custom template to be displayed |
| all               | Display all custom templates            |

### Command Mode

- /exec

# show hardware capacity

show hardware capacity

## Syntax Description

|          |   |
|----------|---|
| show     | Show running system information                               |
| hardware | Hardware related  |
| capacity | Hardware usage levels for Power, Switching Fabric, Flash, etc |

## Command Mode

- /exec

## show hardware capacity eobc

```
show hardware capacity eobc [ __readonly__ { eobc_usage [ <eobc_tx_pps> ] [ <eobc_tx_packets> ] [ <eobc_tx_dropped> ] [ <eobc_rx_pps> ] [ <eobc_rx_packets> ] [ <eobc_rx_dropped> ] } ]
```

### Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   | Show running system information       |
| hardware               | Hardware related                      |
| capacity               | resource inventory and/or usage level |
| eobc                   | EOBC resources                        |
| <i>__readonly__</i>    | (Optional)                            |
| <i>eobc_usage</i>      | (Optional)                            |
| <i>eobc_tx_packets</i> | (Optional)                            |
| <i>eobc_tx_dropped</i> | (Optional)                            |
| <i>eobc_tx_pps</i>     | (Optional)                            |
| <i>eobc_rx_packets</i> | (Optional)                            |
| <i>eobc_rx_dropped</i> | (Optional)                            |
| <i>eobc_rx_pps</i>     | (Optional)                            |

### Command Mode

- /exec

# show hardware capacity fabric-utilization

```
show hardware capacity fabric-utilization [ __readonly__ { TABLE_fabutl <mod> <bandwidth> <ingress>
<egress> } ]
```

## Syntax Description

|                    |                                       |
|--------------------|---------------------------------------|
| show               | Show running system information       |
| hardware           | Show hardware information             |
| capacity           | resource inventory and/or usage level |
| fabric-utilization | Show per module Fabric utilization    |
| __readonly__       | (Optional)                            |
| TABLE_fabutl       | (Optional) fabric utilization table   |
| <i>mod</i>         | (Optional)                            |
| <i>bandwidth</i>   | (Optional)                            |
| <i>ingress</i>     | (Optional)                            |
| <i>egress</i>      | (Optional)                            |

## Command Mode

- /exec

# show hardware capacity forwarding

show hardware capacity forwarding

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                               |
| hardware   | Hardware related  |
| capacity   | Hardware usage levels for Power, Switching Fabric, Flash, etc |
| forwarding | L2/L3 Forwarding resources                                    |

## Command Mode

- /exec



# show hardware capacity interface

```
show hardware capacity interface [ __readonly__ { TABLE_moddrops <mod_num_drops> <tx_drops>
<rx_drops> <max_tx_port> <max_rx_port> } { TABLE_modbuffers <mod_num_buffers> <tx_buffers>
<rx_buffers> } ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                     |
| hardware               | Hardware related                                    |
| capacity               | Usage levels  |
| interface              | Interface Resources - Tx/Rx drops and Tx/Rx buffers |
| __readonly__           | (Optional) Read Only                                |
| <i>mod_num_drops</i>   | (Optional) Module number for Tx/Rx drops            |
| TABLE_moddrops         | (Optional) show module                              |
| <i>tx_drops</i>        | (Optional) Tx drops                                 |
| <i>rx_drops</i>        | (Optional) Rx drops                                 |
| <i>max_tx_port</i>     | (Optional) Port with max Tx drops                   |
| <i>max_rx_port</i>     | (Optional) Port with max Rx drops                   |
| <i>mod_num_buffers</i> | (Optional) Module number for Tx/Rx buffers          |
| TABLE_modbuffers       | (Optional) show module                              |
| <i>tx_buffers</i>      | (Optional) Tx buffers                               |
| <i>rx_buffers</i>      | (Optional) Rx buffers                               |

## Command Mode

- /exec

## show hardware capacity module

```
show hardware capacity module [ __readonly__ { sup_ha_status [ <sup_ha_admin_status> ] [
<sup_ha_oper_status> ] [ <dual_sup_hw_state> ] [ <redundancy_state> ] } { switch_resouces { TABLE_lcinfo
<mod_num> <model_num> <part_num> <serial_num> } [ { TABLE_xbarinfo <mod_num1> <model_num1>
<part_num1> <serial_num1> } ] } { TABLE_flash_nvram_info <mod_num2> <dev_name> <total_bytes>
<free_bytes> <percent_used> } ]
```

### Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| hardware                   | Hardware related                      |
| capacity                   | resource inventory and/or usage level |
| module                     | SUP, LC, XBAR                         |
| <i>__readonly__</i>        | (Optional)                            |
| <i>sup_ha_status</i>       | (Optional)                            |
| <i>sup_ha_admin_status</i> | (Optional)                            |
| <i>sup_ha_oper_status</i>  | (Optional)                            |
| <i>dual_sup_hw_state</i>   | (Optional)                            |
| <i>redundancy_state</i>    | (Optional)                            |
| <i>switch_resouces</i>     | (Optional)                            |
| TABLE_lcinfo               | (Optional)                            |
| <i>mod_num</i>             | (Optional)                            |
| <i>model_num</i>           | (Optional)                            |
| <i>part_num</i>            | (Optional)                            |
| <i>serial_num</i>          | (Optional)                            |
| TABLE_xbarinfo             | (Optional)                            |
| <i>mod_num1</i>            | (Optional)                            |
| <i>model_num1</i>          | (Optional)                            |
| <i>part_num1</i>           | (Optional)                            |
| <i>serial_num1</i>         | (Optional)                            |
| TABLE_flash_nvram_info     | (Optional)                            |
| <i>mod_num2</i>            | (Optional)                            |

|                     |            |
|---------------------|------------|
| <i>dev_name</i>     | (Optional) |
| <i>total_bytes</i>  | (Optional) |
| <i>free_bytes</i>   | (Optional) |
| <i>percent_used</i> | (Optional) |

**Command Mode**

- /exec

## show hardware capacity power

```
show hardware capacity power [ __readonly__ { power_summary <ps_redun_mode_admin>
<ps_redun_mode_oper> <power_total> <power_rsvd> <power_rsvd_percent> <power_given_mod>
<power_given_mod_percent> <power_avail> <power_avail_percent> <power_out_actual_draw>
<power_input_actual_draw> } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information             |
| hardware                       | Hardware related                            |
| capacity                       | resource inventory and/or usage level       |
| power                          | power summary                               |
| __readonly__                   | (Optional)                                  |
| power_summary                  | (Optional)                                  |
| <i>ps_redun_mode_admin</i>     | (Optional) Mode: Redundant or Non-redundant |
| <i>ps_redun_mode_oper</i>      | (Optional) Mode: Redundant or Non-redundant |
| <i>power_total</i>             | (Optional)                                  |
| <i>power_rsvd</i>              | (Optional)                                  |
| <i>power_rsvd_percent</i>      | (Optional)                                  |
| <i>power_given_mod</i>         | (Optional)                                  |
| <i>power_given_mod_percent</i> | (Optional)                                  |
| <i>power_avail</i>             | (Optional)                                  |
| <i>power_avail_percent</i>     | (Optional)                                  |
| <i>power_out_actual_draw</i>   | (Optional) Total Power Output, Actuals      |
| <i>power_input_actual_draw</i> | (Optional) Total Power Input, Actuals       |

### Command Mode

- /exec

# show hardware fabricpath mac-learning module

```
show hardware fabricpath mac-learning module <module> [ __readonly__ { [ { TABLE_module
<module_num> <port_group> <mac_learning> } ] } ]
```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| hardware            | Show hardware information          |
| fabricpath          | Fabric Path                        |
| mac-learning        | MAC Learning                       |
| module              | Specify a module number            |
| <i>module</i>       | Specify a module number            |
| <i>__readonly__</i> | (Optional)                         |
| TABLE_module        | (Optional)                         |
| <i>module_num</i>   | (Optional) Specify a module number |
| <i>port_group</i>   | (Optional)                         |
| <i>mac_learning</i> | (Optional)                         |

## Command Mode

- /exec

# show hardware feature-capability

```
show hardware feature-capability [ detailed ] [ __readonly__ [ { TABLE_feature_support <feature_name> [
{ TABLE_mod_support <mod_inst> <support> } ] } ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| hardware              | Show hardware information                     |
| feature-capability    | show registered features supported            |
| detailed              | (Optional) detailed                           |
| __readonly__          | (Optional) Read_Only                          |
| TABLE_feature_support | (Optional) show features supported            |
| <i>feature_name</i>   | (Optional) feature name                       |
| TABLE_mod_support     | (Optional) show registered features supported |
| <i>mod_inst</i>       | (Optional) module instance                    |
| <i>support</i>        | (Optional) support details                    |

## Command Mode

- /exec

# show hardware flow aging

show hardware flow aging [ instance <inst> ] [ module <num> ]

## Syntax Description

|             |                                 |
|-------------|---------------------------------|
| show        | Show running system information |
| hardware    | Show hardware information       |
| flow        | Netflow Module                  |
| aging       | Aging Info                      |
| instance    | (Optional) Instance             |
| <i>inst</i> | (Optional) Earl Instance        |
| module      | (Optional) Line card module     |
| <i>num</i>  | (Optional) slot number          |

## Command Mode

- /exec

## show hardware flow entry address type

show hardware flow entry address <addr> type { ip | ipv6 | l2 | mpls } [ instance <inst> ] [ module <num> ]

### Syntax Description

|             |                                 |
|-------------|---------------------------------|
| show        | Show running system information |
| hardware    | Show hardware information       |
| flow        | Netflow Module                  |
| entry       | Netflow Table Entry             |
| address     | Netflow Table Address           |
| <i>addr</i> | Netflow Table Address           |
| type        | Flow Type                       |
| ip          | Internet Protocol Version 4     |
| ipv6        | Internet Protocol Version 6     |
| l2          | Layer 2 Protocol                |
| mpls        | MPLS Protocol                   |
| instance    | (Optional) Instance             |
| <i>inst</i> | (Optional) Earl Instance        |
| module      | (Optional) Line card module     |
| <i>num</i>  | (Optional) slot number          |

### Command Mode

- /exec



# show hardware flow ip

```
show hardware flow ip [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } | { interface
<interface> } } ] [ instance <inst> ] [ detail ] [ module <num> ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| hardware         | Show hardware information            |
| flow             | Netflow Module                       |
| ip               | Internet Protocol Version 4          |
| monitor          | (Optional) Netflow Flow Monitor      |
| <i>mname</i>     | (Optional) Netflow Flow Monitor Name |
| profile          | (Optional) Flow Profile              |
| <i>prof_id</i>   | (Optional) Netflow Profile ID        |
| vlan             | (Optional) Vlan commands             |
| <i>vlan_id</i>   | (Optional) VLAN ID 1-4094            |
| interface        | (Optional) Interface                 |
| <i>interface</i> | (Optional) Interface Name            |
| instance         | (Optional) Instance                  |
| <i>inst</i>      | (Optional) Earl Instance             |
| detail           | (Optional) Detailed Output Display   |
| module           | (Optional) Line card module          |
| <i>num</i>       | (Optional) slot number               |

## Command Mode

- /exec

## show hardware flow ipv6

```
show hardware flow ipv6 [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } | { interface
<interface> } } ] [ instance <inst> ] [ detail ] [ module <num> ]
```

### Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| hardware         | Show hardware information            |
| flow             | Netflow Module                       |
| ipv6             | Internet Protocol Version 6          |
| monitor          | (Optional) Netflow Flow Monitor      |
| <i>mname</i>     | (Optional) Netflow Flow Monitor Name |
| profile          | (Optional) Flow Profile              |
| <i>prof_id</i>   | (Optional) Netflow Profile ID        |
| vlan             | (Optional) Vlan commands             |
| <i>vlan_id</i>   | (Optional) VLAN ID 1-4094            |
| interface        | (Optional) Interface                 |
| <i>interface</i> | (Optional) Interface Name            |
| instance         | (Optional) Instance                  |
| <i>inst</i>      | (Optional) Earl Instance             |
| detail           | (Optional) Detailed Output Display   |
| module           | (Optional) Line card module          |
| <i>num</i>       | (Optional) slot number               |

### Command Mode

- /exec

## show hardware flow l2

```
show hardware flow l2 [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } } ] [ instance
<inst> ] [ detail ] [ module <num> ]
```

### Syntax Description

|                |                                      |
|----------------|--------------------------------------|
| show           | Show running system information      |
| hardware       | Show hardware information            |
| flow           | Netflow Module                       |
| l2             | Layer 2 Protocol                     |
| monitor        | (Optional) Netflow Flow Monitor      |
| <i>mname</i>   | (Optional) Netflow Flow Monitor Name |
| profile        | (Optional) Flow Profile              |
| <i>prof_id</i> | (Optional) Netflow Profile ID        |
| vlan           | (Optional) Vlan commands             |
| <i>vlan_id</i> | (Optional) VLAN ID 1-4094            |
| instance       | (Optional) Instance                  |
| <i>inst</i>    | (Optional) Earl Instance             |
| detail         | (Optional) Detailed Output Display   |
| module         | (Optional) Line card module          |
| <i>num</i>     | (Optional) slot number               |

### Command Mode

- /exec

# show hardware flow mpls

```
show hardware flow mpls [ { { monitor <mname> } | { profile <prof_id> } | { vlan <vlan_id> } | { interface
<interface> } } ] [ instance <inst> ] [ detail ] [ module <num> ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| hardware         | Show hardware information            |
| flow             | Netflow Module                       |
| mpls             | MPLS Protocol                        |
| monitor          | (Optional) Netflow Flow Monitor      |
| <i>mname</i>     | (Optional) Netflow Flow Monitor Name |
| profile          | (Optional) Flow Profile              |
| <i>prof_id</i>   | (Optional) Netflow Profile ID        |
| vlan             | (Optional) Vlan commands             |
| <i>vlan_id</i>   | (Optional) VLAN ID 1-4094            |
| interface        | (Optional) Interface                 |
| <i>interface</i> | (Optional) Interface Name            |
| instance         | (Optional) Instance                  |
| <i>inst</i>      | (Optional) Earl Instance             |
| detail           | (Optional) Detailed Output Display   |
| module           | (Optional) Line card module          |
| <i>num</i>       | (Optional) slot number               |

## Command Mode

- /exec

# show hardware flow sampler

show hardware flow sampler { all | count | index <index> | name <sname> } [ detail ] [ instance <inst> ] [ module <num> ]

## Syntax Description

|              |                                    |
|--------------|------------------------------------|
| show         | Show running system information    |
| hardware     | Show hardware information          |
| flow         | Netflow Module                     |
| sampler      | Flow Sampler                       |
| all          | Netflow Sampler Usage              |
| count        | Netflow Sampler Utilization        |
| index        | Netflow Sampler Index              |
| <i>index</i> | Netflow Sampler Index              |
| name         | Netflow Sampler Name               |
| <i>sname</i> | Netflow Sampler Name               |
| detail       | (Optional) Detailed Output Display |
| instance     | (Optional) Instance                |
| <i>inst</i>  | (Optional) Clipper Instance        |
| module       | (Optional) Line card module        |
| <i>num</i>   | (Optional) slot number             |

## Command Mode

- /exec

## show hardware flow tah-etrap

```
show hardware flow tah-etrap [ module <module> ] [ { unit <unit> slice <slice> } ] [ __readonly__ [ {
TABLE_etrap_flows <unit> <slice> <index> <keytype> <src_addr> <dst_addr> <src_port> <dst_port>
<proto> <rate> } ] ]
```

### Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information           |
| hardware          | Show hardware information                 |
| flow              | Traffic flow information                  |
| tah-etrap         | Elephant Trap information                 |
| module            | (Optional) Slot/module                    |
| <i>module</i>     | (Optional) Slot/module number             |
| unit              | (Optional) Asic Number                    |
| <i>unit</i>       | (Optional) Asic Number on the module      |
| slice             | (Optional) slice num on asic              |
| <i>slice</i>      | (Optional) slice number on asic           |
| __readonly__      | (Optional) Read Only                      |
| TABLE_etrap_flows | (Optional) Elephant trap flows            |
| <i>unit</i>       | (Optional) ASIC number on the module      |
| <i>slice</i>      | (Optional) Slice number on the ASIC       |
| <i>index</i>      | (Optional) Elephant trap table index      |
| <i>keytype</i>    | (Optional) Elephant trap table key type   |
| <i>src_addr</i>   | (Optional) Elephant trap flow src address |
| <i>dst_addr</i>   | (Optional) Elephant trap flow dst address |
| <i>src_port</i>   | (Optional) Elephant trap flow src port    |
| <i>dst_port</i>   | (Optional) Elephant trap flow src port    |
| <i>proto</i>      | (Optional) Elephant trap flow protocol    |
| <i>rate</i>       | (Optional) Elephant trap flow protocol    |

### Command Mode

- /exec

# show hardware flow utilization

show hardware flow utilization [ instance <inst> ] [ module <num> ]

## Syntax Description

|             |                                 |
|-------------|---------------------------------|
| show        | Show running system information |
| hardware    | Show hardware information       |
| flow        | Netflow Module                  |
| utilization | NT Table Utilization            |
| instance    | (Optional) Instance             |
| <i>inst</i> | (Optional) Earl Instance        |
| module      | (Optional) Line card module     |
| <i>num</i>  | (Optional) slot number          |

## Command Mode

- /exec

# show hardware forwarding interface statistics mode

```
show hardware forwarding interface statistics mode [ __readonly__ { system [ { <sysmode> } ] [ {
TABLE_module <module> <modmode> } ] ] ]
```

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information               |
| hardware       | Show hardware information                     |
| forwarding     | Show hardware information for forwarding path |
| interface      | Interface                                     |
| statistics     | Statistics                                    |
| mode           | Statistics mode                               |
| __readonly__   | (Optional)                                    |
| system         | (Optional)                                    |
| <i>sysmode</i> | (Optional)                                    |
| TABLE_module   | (Optional)                                    |
| <i>module</i>  | (Optional) Specify a module number            |
| <i>modmode</i> | (Optional)                                    |

## Command Mode

- /exec



## show hardware forwarding memory health detail

```
show hardware forwarding memory health detail [ __readonly__ { memscan_interval <mscan_interval> } {
memscan_rate <mscan_rate> } [ TABLE_ser <table_name> <entry_count> <table_head> <table_tail> [
TABLE_ser_entry_new <n_entry_index> [ <reg_id> ] [ <reg_port> ] [ <reg_index> ] [ <table_id> ] [
<table_index> ] <detections> <corrections> [ <last_detection_ts> ] [ <last_correction_ts> ] ] [
TABLE_ser_entry_old <o_entry_index> <mem_addr> <cause_bits> <event_type> <last_event> <last_time>
] ] [ { parity_detect_counter <parity_detect_cnt> } ] [ { parity_correct_counter <parity_correct_cnt> } ] [ {
reg_parity_detect_counter <reg_parity_detect_cnt> } ] [ { reg_parity_correct_counter <reg_parity_correct_cnt>
} ] [ { tcam_parity_detect_counter <tcam_parity_detect_cnt> } ] [ { tcam_parity_correct_counter
<tcam_parity_correct_cnt> } ] [ { sram_parity_detect_counter <sram_parity_detect_cnt> } ] [ {
sram_parity_correct_counter <sram_parity_correct_cnt> } ] [ { TABLE_ser_tbl_parity <table_id> <detections>
<corrections> } ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information            |
| hardware              | Show hardware information                  |
| forwarding            | forwarding information                     |
| memory                | memory information                         |
| health                | memory health information                  |
| detail                | show the detail                            |
| __readonly__          | (Optional) Read Only                       |
| memscan_interval      | (Optional) memory scan interval value      |
| <i>mscan_interval</i> | (Optional) mem scan interval               |
| memscan_rate          | (Optional) memory scan rate value          |
| <i>mscan_rate</i>     | (Optional) mem scan rate                   |
| TABLE_ser             | (Optional) ser table list                  |
| <i>table_name</i>     | (Optional) table name                      |
| <i>entry_count</i>    | (Optional) total entries in table          |
| <i>table_head</i>     | (Optional) start of entry index            |
| <i>table_tail</i>     | (Optional) end of entry index              |
| TABLE_ser_entry_new   | (Optional) ser table entry with new format |
| <i>n_entry_index</i>  | (Optional) entry index                     |
| <i>reg_id</i>         | (Optional) register id                     |

|                                |  |
|--------------------------------|--|
| <i>reg_port</i>                | (Optional) port                            |
| <i>reg_index</i>               | (Optional) register index                  |
| <i>table_id</i>                | (Optional) table id                        |
| <i>table_index</i>             | (Optional) table_index                     |
| <i>detections</i>              | (Optional) parity detetction count         |
| <i>corrections</i>             | (Optional) parity correction count         |
| <i>last_detection_ts</i>       | (Optional) last detetction timestamp       |
| <i>last_correction_ts</i>      | (Optional) last correction timestamp       |
| TABLE_ser_entry_old            | (Optional) ser table entry with new format |
| <i>o_entry_index</i>           | (Optional) table entry index               |
| <i>mem_addr</i>                | (Optional) memory address                  |
| <i>cause_bits</i>              | (Optional) cause bit                       |
| <i>event_type</i>              | (Optional) type of event                   |
| <i>last_event</i>              | (Optional) last event that occurred        |
| <i>last_time</i>               | (Optional) last time of event              |
| parity_detect_counter          | (Optional) parity detect count             |
| <i>parity_detect_cnt</i>       | (Optional) count of parity detect          |
| parity_correct_counter         | (Optional) parity correct count            |
| <i>parity_correct_cnt</i>      | (Optional) count of parity correct         |
| reg_parity_detect_counter      | (Optional) reg parity detect count         |
| <i>reg_parity_detect_cnt</i>   | (Optional) count of reg parity detect      |
| reg_parity_correct_counter     | (Optional) reg parity correct count        |
| <i>reg_parity_correct_cnt</i>  | (Optional) count of reg parity correct     |
| tcam_parity_detect_counter     | (Optional) tcam parity detect count        |
| <i>tcam_parity_detect_cnt</i>  | (Optional) count of tcam parity detect     |
| tcam_parity_correct_counter    | (Optional) tcam parity correct count       |
| <i>tcam_parity_correct_cnt</i> | (Optional) count of tcam parity correct    |
| sram_parity_detect_counter     | (Optional) sram parity detect count        |
| <i>sram_parity_detect_cnt</i>  | (Optional) count of sram parity detect     |

|                                    |  |
|------------------------------------|--|
| <i>sram_parity_correct_counter</i> | (Optional) sram parity correct count             |
| <i>sram_parity_correct_cnt</i>     | (Optional) count of sram parity correct          |
| <i>TABLE_ser_tbl_parity</i>        | (Optional) all ser tables                        |
| <i>table_id</i>                    | (Optional) table name                            |
| <i>detections</i>                  | (Optional) parity detection count for ser table  |
| <i>corrections</i>                 | (Optional) parity correction count for ser table |

**Command Mode**

- /exec

## show hardware forwarding memory health summary

```
show hardware forwarding memory health summary [ __readonly__ [ { parity_detect_counter
<parity_detect_cnt> } ] [ { parity_correct_counter <parity_correct_cnt> } ] [ { reg_parity_detect_counter
<reg_parity_detect_cnt> } ] [ { reg_parity_correct_counter <reg_parity_correct_cnt> } ] [ {
tcam_parity_detect_counter <tcam_parity_detect_cnt> } ] [ { tcam_parity_correct_counter
<tcam_parity_correct_cnt> } ] [ { sram_parity_detect_counter <sram_parity_detect_cnt> } ] [ {
sram_parity_correct_counter <sram_parity_correct_cnt> } ] [ { TABLE_ser_tbl_parity <table_id> <detections>
<corrections> } ] ] ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information         |
| hardware                       | Show hardware information               |
| forwarding                     | forwarding information                  |
| memory                         | memory information                      |
| health                         | memory health information               |
| summary                        | show the summary                        |
| <i>__readonly__</i>            | (Optional) Read Only                    |
| parity_detect_counter          | (Optional) parity detect count          |
| <i>parity_detect_cnt</i>       | (Optional) count of parity detect       |
| parity_correct_counter         | (Optional) parity correct count         |
| <i>parity_correct_cnt</i>      | (Optional) count of parity correct      |
| reg_parity_detect_counter      | (Optional) reg parity detect count      |
| <i>reg_parity_detect_cnt</i>   | (Optional) count of reg parity detect   |
| reg_parity_correct_counter     | (Optional) reg parity correct count     |
| <i>reg_parity_correct_cnt</i>  | (Optional) count of reg parity correct  |
| tcam_parity_detect_counter     | (Optional) tcam parity detect count     |
| <i>tcam_parity_detect_cnt</i>  | (Optional) count of tcam parity detect  |
| tcam_parity_correct_counter    | (Optional) tcam parity correct count    |
| <i>tcam_parity_correct_cnt</i> | (Optional) count of tcam parity correct |
| sram_parity_detect_counter     | (Optional) sram parity detect count     |
| <i>sram_parity_detect_cnt</i>  | (Optional) count of sram parity detect  |
| sram_parity_correct_counter    | (Optional) sram parity correct count    |

|                                |  |
|--------------------------------|--|
| <i>sram_parity_correct_cnt</i> | (Optional) count of sram parity correct          |
| TABLE_ser_tbl_parity           | (Optional) all ser tables                        |
| <i>table_id</i>                | (Optional) table name                            |
| <i>detections</i>              | (Optional) parity detection count for ser table  |
| <i>corrections</i>             | (Optional) parity correction count for ser table |

**Command Mode**

- /exec

# show hardware ip verify

show hardware [ forwarding ] ip verify [ module <module> ] [ \_\_readonly\_\_ <info\_str> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                          |
| hardware            | Show hardware information                                |
| forwarding          | (Optional) Show hardware information for forwarding path |
| ip                  | IP   |
| verify              | Show IP packet verification checks enabled in hardware   |
| module              | (Optional) Specify a module number                       |
| <i>module</i>       | (Optional) Specify a module number                       |
| <i>__readonly__</i> | (Optional)   |
| <i>info_str</i>     | (Optional) IDS Check Stats                               |

## Command Mode

- /exec

## show hardware profile forwarding-mode

```
show hardware profile forwarding-mode [ __readonly__ <forwarding-mode> [ <host-size> ] [ <unicast-size>
] [ <unicast-rpf-size> ] [ <unicast-ipv4-size> ] [ <unicast-ipv4-rpf-size> ] [ <unicast-ipv6-size> ] [
<multicast-size> ] [ <l2-size> ] [ <unified-size> ] ]
```

### Syntax Description

|                              |                                       |
|------------------------------|---------------------------------------|
| show                         | Show running system information       |
| hardware                     | Show hardware profile forwarding-mode |
| profile                      | profile forwarding-mode               |
| forwarding-mode              | forwarding-mode                       |
| <i>__readonly__</i>          | (Optional)                            |
| <i>forwarding-mode</i>       | (Optional)                            |
| <i>host-size</i>             | (Optional)                            |
| <i>unicast-size</i>          | (Optional)                            |
| <i>unicast-rpf-size</i>      | (Optional)                            |
| <i>unicast-ipv4-size</i>     | (Optional)                            |
| <i>l2-size</i>               | (Optional)                            |
| <i>unified-size</i>          | (Optional)                            |
| <i>unicast-ipv4-rpf-size</i> | (Optional)                            |
| <i>unicast-ipv6-size</i>     | (Optional)                            |
| <i>multicast-size</i>        | (Optional)                            |

### Command Mode

- /exec

# show hardware profile module

show hardware profile module <module> [ \_\_readonly\_\_ { TABLE\_profile <slot> <type> } ]

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| hardware            | Show hardware profile           |
| profile             | Profile settings                |
| module              | Enter module number             |
| <i>module</i>       |                                 |
| <i>__readonly__</i> | (Optional)                      |
| TABLE_profile       | (Optional) Show version info    |
| <i>slot</i>         | (Optional) Slot                 |
| <i>type</i>         | (Optional) Profile type         |

## Command Mode

- /exec



# show hardware profile packet-drop

```
show hardware profile packet-drop { status | data [ instance <cap_instance> ] | event [ instance <cap_instance> ] } [ __readonly__ [ <enable><state> <cap-scope><drop-trigger> <cap-count><cap-time> <file-inst> ] [ TABLE_hardware_packet_drop_status <profile-name><start-thres><stop-thres> ] [ TABLE_hardware_packet_drop_data <src-port><dst-port> <qos-grp><que-depth> <payload> ] [ TABLE_hardware_packet_drop_event <src-port><dst-port> <qos-grp><que-depth> <drop-reason> ] ]
```

## Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                      |
| hardware                          | Change hardware usage settings                       |
| profile                           | Profile settings                                     |
| packet-drop                       | Packet Drop parameters                               |
| status                            | Packet Drop status                                   |
| data                              | Packet Drop circular-buffer data                     |
| instance                          | (Optional) Packet Drop captured instance             |
| <i>cap_instance</i>               | (Optional) Value 1-5                                 |
| event                             | Packet Drop event-buffer data                        |
| instance                          | (Optional) Packet Drop captured instance             |
| <i>cap_instance</i>               | (Optional) Value 1-5                                 |
| <i>__readonly__</i>               | (Optional)   |
| <i>file-inst</i>                  | (Optional) Packet-Drop file instance                 |
| TABLE_hardware_packet_drop_status | (Optional) XML Packet-drop stats                     |
| TABLE_hardware_packet_drop_data   | (Optional) XML Packet-drop data                      |
| <i>payload</i>                    | (Optional) Packet-Drop Data Packet Payload (80bytes) |
| TABLE_hardware_packet_drop_event  | (Optional) XML Packet-drop event                     |
| <i>drop-reason</i>                | (Optional) PacketDrop Event Drop trigger             |

## Command Mode

- /exec

# show hardware profile portmode

{ show hardware profile portmode }

## Syntax Description

|          |                                 |
|----------|---------------------------------|
| show     | Show running system information |
| hardware | Change hardware usage settings  |
| profile  | profile settings                |
| portmode | QSFP port mode setting          |

## Command Mode

- /exec

## show hardware profile status

```
show hardware profile status [ module <module> ] [ detail ] [ __readonly__ { <total_lpm> <total_host>
<reserved_lpm> <max_host4_limit> <max_host6_limit> <max_mcast_limit> <max_mcast6_limit> [
<max_mcast_transit_route_limit> ] [ <max_v6_lpm_limit> ] [ <max_v6_lpm_65_to_127_limit> ] [
<used_lpm_total> ] <used_v4_lpm> <used_v6_lpm> [ <used_v6_lpm_128> ] <used_host_lpm_total>
<used_host_v4_lpm> <used_host_v6_lpm> <used_mcast> <used_mcast6> [ <used_mcast_transit_routes> ]
<used_mcast_oifl> <used_host_in_host_total> <used_host4_in_host> <used_host6_in_host>
<max_ecmp_table_limit> <used_ecmp_table> <max_ecmp_nh_table_limit> <used_ecmp_nh_table> [
<mfib_fd_status> ] [ <mfib_fd_maxroute> ] [ <mfib_fd_count> ] [ <lpm_to_host_migrate_table> ] [
<host_to_lpm_migrate_table> ] }
```

### Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information                       |
| hardware                          | Show hardware usage settings                          |
| profile                           | Show current table usage                              |
| status                            | Show status of dynamic resource allocation            |
| module                            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>module</i>                     | (Optional) Slot/module number                         |
| detail                            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>__readonly__</i>               | (Optional) Read only                                  |
| <i>total_lpm</i>                  | (Optional) Total LPM Entries                          |
| <i>total_host</i>                 | (Optional) Total Host Entries                         |
| <i>reserved_lpm</i>               | (Optional) Reserved LPM Entries                       |
| <i>max_host4_limit</i>            | (Optional) Max Host4 Limit Entries                    |
| <i>max_host6_limit</i>            | (Optional) Max Host6 Limit Entries                    |
| <i>max_mcast_limit</i>            | (Optional) Max Mcast Limit Entries                    |
| <i>max_mcast6_limit</i>           | (Optional) Max IPv6 Mcast Limit Entries               |
| <i>max_v6_lpm_limit</i>           | (Optional) Max Ucast IPv6 LPM Limit Entries           |
| <i>max_v6_lpm_65_to_127_limit</i> | (Optional) Max Ucast IPv6 LPM_65_to_127 Limit Entries |
| <i>used_lpm_total</i>             | (Optional) Used LPM Entries (Total)                   |
| <i>used_v4_lpm</i>                | (Optional) Used IPv4 LPM Entries                      |
| <i>used_v6_lpm</i>                | (Optional) Used IPv6 LPM Entries                      |

|                                      |  |
|--------------------------------------|--|
| <i>used_v6_lpm_128</i>               | (Optional) Used IPv6 LPM_128 Entries                   |
| <i>used_host_lpm_total</i>           | (Optional) Used Host Entries in LPM (Total)            |
| <i>used_host_v4_lpm</i>              | (Optional) Used Host4 Entries in LPM                   |
| <i>used_host_v6_lpm</i>              | (Optional) Used Host6 Entries in LPM                   |
| <i>used_mcast</i>                    | (Optional) Used Mcast Entries                          |
| <i>used_mcast6</i>                   | (Optional) Used IPv6 Mcast Entries                     |
| <i>used_mcast_oifl</i>               | (Optional) Used Mcast OIFL Entries                     |
| <i>used_host_in_host_total</i>       | (Optional) Used Host Entries in Host (Total)           |
| <i>used_host4_in_host</i>            | (Optional) Used Host4 Entries in Host                  |
| <i>used_host6_in_host</i>            | (Optional) Used Host6 Entries in Host                  |
| <i>max_ecmp_table_limit</i>          | (Optional) Max ECMP table Limit Entries                |
| <i>used_ecmp_table</i>               | (Optional) Used ECMP Table Entries                     |
| <i>max_ecmp_nh_table_limit</i>       | (Optional) Max ECMP NH table Limit Entries             |
| <i>used_ecmp_nh_table</i>            | (Optional) Used ECMP NH Table Entries                  |
| <i>mfib_fd_status</i>                | (Optional) MFIB fd status                              |
| <i>mfib_fd_maxroute</i>              | (Optional) MFIB fd maxroute                            |
| <i>mfib_fd_count</i>                 | (Optional) MFIB fd count                               |
| <i>lpm_to_host_migrate_table</i>     | (Optional) Times Route Migrated from LPM to Host Table |
| <i>host_to_lpm_migrate_table</i>     | (Optional) Times Route Migrated from Host to LPM Table |
| <i>max_mcast_transit_route_limit</i> | (Optional) Max Mcast Transit Route Limit Entries       |
| <i>used_mcast_transit_routes</i>     | (Optional) Used Mcast Transit Routes                   |

**Command Mode**

- /exec

## show hardware profile tcam region

```
show hardware profile tcam region [ __readonly__ { TCAM_Region [ { TABLE_Sizes <tcam_compat_type>
<tcam_compat_size> <tcam_compat_width> } ] } ]
```

### Syntax Description

|                          |                                 |
|--------------------------|---------------------------------|
| show                     | Show running system information |
| hardware                 | Show hardware information       |
| profile                  | profile                         |
| tcam                     | Show tcam parameters            |
| region                   | Show tcam region sizes          |
| <i>__readonly__</i>      | (Optional)                      |
| TCAM_Region              | (Optional)                      |
| TABLE_Sizes              | (Optional)                      |
| <i>tcam_compat_type</i>  | (Optional)                      |
| <i>tcam_compat_size</i>  | (Optional)                      |
| <i>tcam_compat_width</i> | (Optional)                      |

### Command Mode

- /exec

## show hardware qos afd profile

show hardware qos afd profile [ module <module> ] [ \_\_readonly\_\_ TABLE\_qos\_afd\_profile [ <module> ] <prof-desc> ]

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                  |
| hardware              | Show hardware information                        |
| qos                   | Show qos related information                     |
| afd                   | Show Approximate Fair Dropping config            |
| profile               | Show AFD profile config                          |
| module                | (Optional) Specify a module number               |
| <i>module</i>         | (Optional) Specify a module number               |
| __readonly__          | (Optional)                                       |
| TABLE_qos_afd_profile | (Optional) the xml qos_afd_profile configuration |
| <i>prof-desc</i>      | (Optional) profile description                   |

### Command Mode

- /exec

# show hardware qos burst-detect max-records

show hardware qos burst-detect max-records [ *\_\_readonly\_\_* <*max\_records*> ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                   |
| hardware            | Show hardware information                         |
| qos                 | Show qos related information                      |
| burst-detect        | Show oobst burst-detect info                      |
| max-records         | Show oobst burst-detect max-records               |
| <i>__readonly__</i> | (Optional)  |
| <i>max_records</i>  | (Optional) max number of burst records configured |

## Command Mode

- /exec

## show hardware qos eoq stats-class

```
show hardware qos eoq stats-class [ module <module> ] [ __readonly__ TABLE_qos_eoq_stats_class [
<module> ] <eoq-stats-class-desc> ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                      |
| hardware                    | Show hardware information                            |
| qos                         | Show QoS related information                         |
| eoq                         | Show Extended Output Queue(EOQ) related information  |
| stats-class                 | Show EOQ Statistics class selection config           |
| module                      | (Optional) Specify a module number                   |
| <i>module</i>               | (Optional) Specify a module number                   |
| <i>__readonly__</i>         | (Optional)   |
| TABLE_qos_eoq_stats_class   | (Optional) the xml qos_eoq_stats_class configuration |
| <i>eoq-stats-class-desc</i> | (Optional) selected class description                |

### Command Mode

- /exec



## show hardware qos include ipg

show hardware qos include ipg [ module <module> ] [ \_\_readonly\_\_ TABLE\_qos\_include\_ipg <module> ]

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| hardware              | Show hardware information                              |
| qos                   | Show qos related information                           |
| include               | Show include config                                    |
| ipg                   | Show whether to include IPG in Shaping/Policing config |
| module                | (Optional) Specify a module number                     |
| <i>module</i>         | (Optional) Specify a module number                     |
| <i>__readonly__</i>   | (Optional)   |
| TABLE_qos_include_ipg | (Optional) the xml qos_include_ipg configuration       |

### Command Mode

- /exec

## show hardware qos ing-pg-hdrm-reserve

```
show hardware qos ing-pg-hdrm-reserve [ module <module> ] [ __readonly__
TABLE_qos_ing_pg_hdrm_reserve <module> ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                          |
| hardware                      | Show hardware information                                |
| qos                           | Show qos related information                             |
| ing-pg-hdrm-reserve           | Show ing-pg-hdrm-reserve config                          |
| module                        | (Optional) Specify a module number                       |
| <i>module</i>                 | (Optional) Specify a module number                       |
| __readonly__                  | (Optional)   |
| TABLE_qos_ing_pg_hdrm_reserve | (Optional) the xml qos_ing_pg_hdrm_reserve configuration |

### Command Mode

- /exec

## show hardware qos ing-pg-no-min

```
show hardware qos ing-pg-no-min [ module <module> ] [ __readonly__ TABLE_qos_ing_pg_no_min [
<module> ] <ingress_pg_min> <pg_min_value> ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                    |
| hardware                | Show hardware information                          |
| qos                     | Show qos related information                       |
| ing-pg-no-min           | Show ing-pg-no-min config                          |
| module                  | (Optional) Specify a module number                 |
| <i>module</i>           | (Optional) Specify a module number                 |
| <i>__readonly__</i>     | (Optional)   |
| TABLE_qos_ing_pg_no_min | (Optional) the xml qos_ing_pg_no_min configuration |
| <i>ingress_pg_min</i>   | (Optional) Enable/Disable PG Min                   |
| <i>pg_min_value</i>     | (Optional) PG Min Value                            |

### Command Mode

- /exec

## show hardware qos ing-pg-share

```
show hardware qos ing-pg-share [ module <module> ] [ __readonly__ TABLE_qos_ing_pg_share <module> ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                   |
| hardware               | Show hardware information                         |
| qos                    | Show qos related information                      |
| ing-pg-share           | Show ing-pg-share config                          |
| module                 | (Optional) Specify a module number                |
| <i>module</i>          | (Optional) Specify a module number                |
| <i>__readonly__</i>    | (Optional)  |
| TABLE_qos_ing_pg_share | (Optional) the xml qos_ing_pg_share configuration |

### Command Mode

- /exec

## show hardware qos min-buffer

```
show hardware qos min-buffer [ module <module> ] [ __readonly__ TABLE_qos_min_buffer_profile [
<module> ] <buff-prof-desc> ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                         |
| hardware                     | Show hardware information                               |
| qos                          | Show qos related information                            |
| min-buffer                   | Show min-buffer config                                  |
| module                       | (Optional) Specify a module number                      |
| <i>module</i>                | (Optional) Specify a module number                      |
| <i>__readonly__</i>          | (Optional)  |
| TABLE_qos_min_buffer_profile | (Optional) the xml qos_min_buffer_profile configuration |
| <i>buff-prof-desc</i>        | (Optional) buffer profile description                   |

### Command Mode

- /exec

## show hardware qos ns-buffer-profile

show hardware qos ns-buffer-profile [ module <module> ] [ \_\_readonly\_\_ TABLE\_qos\_ns\_buffer\_profile <module> <buff-prof-desc> ]

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                        |
| hardware                    | Show hardware information                              |
| qos                         | Show qos related information                           |
| ns-buffer-profile           | Show ns-buffer-profile config                          |
| module                      | (Optional) Specify a module number                     |
| <i>module</i>               | (Optional) Specify a module number                     |
| <i>__readonly__</i>         | (Optional)   |
| TABLE_qos_ns_buffer_profile | (Optional) the xml qos_ns_buffer_profile configuration |
| <i>buff-prof-desc</i>       | (Optional) buffer profile description                  |

### Command Mode

- /exec

## show hardware qos ns-mcq3-alias

```
show hardware qos ns-mcq3-alias [ module <module> ][ __readonly__ TABLE_qos_ns_mcq3_alias <module>
<ns-mcq3-alias-desc> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                    |
| hardware                  | Show hardware information                          |
| qos                       | Show QoS related information                       |
| ns-mcq3-alias             | Show NS mc-queue-3 alias class selection config    |
| module                    | (Optional) Specify a module number                 |
| <i>module</i>             | (Optional) Specify a module number                 |
| <i>__readonly__</i>       | (Optional)   |
| TABLE_qos_ns_mcq3_alias   | (Optional) the xml qos_ns_mcq3_alias configuration |
| <i>ns-mcq3-alias-desc</i> | (Optional) selected class description              |

### Command Mode

- /exec

## show hardware rate-limiter

```
show hardware rate-limiter [ module <module> ] [ layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2
<l2-opts> | <opts> | fl <fl-opts> | span-egress | urpf-fail ] [ __readonly__ TABLE hardware_rate_limiter
<rate-limit-class> <class-descr> <module> <rate-limit-configured> [ <rate-limit-allowed> ] [
<rate-limit-dropped> ] [ <rate-limit-total> ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information                              |
| hardware                     | Show hardware information                                    |
| rate-limiter                 | Show Rate-Limiter configs and statistics                     |
| layer-3                      | (Optional) Layer-3 control and Routed packets                |
| <i>l3-opts</i>               | (Optional)   |
| multicast                    | (Optional) Multicast data packets                            |
| <i>mcast-opts</i>            | (Optional)   |
| layer-2                      | (Optional) Layer-2 control and Bridged packets               |
| <i>l2-opts</i>               | (Optional)   |
| <i>opts</i>                  | (Optional)   |
| fl                           | (Optional) Control packets from F1 modules to supervisor     |
| <i>fl-opts</i>               | (Optional)   |
| span-egress                  | (Optional) SPAN/ERSPAN egress packets                        |
| urpf-fail                    | (Optional) URPF fail packets                                 |
| module                       | (Optional) Specify a module number                           |
| <i>module</i>                | (Optional) Specify a module number                           |
| <i>__readonly__</i>          | (Optional)   |
| TABLE hardware_rate_limiter  | (Optional) the xml Rate-Limiter configuration and statistics |
| <i>rate-limit-class</i>      | (Optional) the xml rate limiter class                        |
| <i>class-descr</i>           | (Optional) class description                                 |
| <i>module</i>                | (Optional) the xml module number                             |
| <i>rate-limit-configured</i> | (Optional) the xml rate-limit-configured                     |
| <i>rate-limit-allowed</i>    | (Optional) the xml rate-limit-allowed                        |



|                           |                                       |
|---------------------------|---------------------------------------|
| <i>rate-limit-dropped</i> | (Optional) the xml rate-limit-dropped |
| <i>rate-limit-total</i>   | (Optional) the xml rate-limit-total   |

**Command Mode**

- /exec

## show hardware rate-limiter

```
show hardware rate-limiter [ module <module> ] [ layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2
<l2-opts> | <opts> | fl <fl-opts> | span-egress | urpf-fail ] [ __readonly__ TABLE hardware_rate_limiter
<rate-limit-class> <class-descr> <module> <rate-limit-configured> [ <rate-limit-allowed> ] [
<rate-limit-dropped> ] [ <rate-limit-total> ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information                              |
| hardware                     | Show hardware information                                    |
| rate-limiter                 | Show Rate-Limiter configs and statistics                     |
| layer-3                      | (Optional) Layer-3 control and Routed packets                |
| <i>l3-opts</i>               | (Optional)   |
| multicast                    | (Optional) Multicast data packets                            |
| <i>mcast-opts</i>            | (Optional)   |
| layer-2                      | (Optional) Layer-2 control and Bridged packets               |
| <i>l2-opts</i>               | (Optional)   |
| <i>opts</i>                  | (Optional)   |
| fl                           | (Optional) Control packets from F1 modules to supervisor     |
| <i>fl-opts</i>               | (Optional)   |
| span-egress                  | (Optional) SPAN/ERSPAN egress packets                        |
| urpf-fail                    | (Optional) URPF fail packets                                 |
| module                       | (Optional) Specify a module number                           |
| <i>module</i>                | (Optional) Specify a module number                           |
| <i>__readonly__</i>          | (Optional)   |
| TABLE hardware_rate_limiter  | (Optional) the xml Rate-Limiter configuration and statistics |
| <i>rate-limit-class</i>      | (Optional) the xml rate limiter class                        |
| <i>class-descr</i>           | (Optional) class description                                 |
| <i>module</i>                | (Optional) the xml module number                             |
| <i>rate-limit-configured</i> | (Optional) the xml rate-limit-configured                     |
| <i>rate-limit-allowed</i>    | (Optional) the xml rate-limit-allowed                        |

|                           |                                       |
|---------------------------|---------------------------------------|
| <i>rate-limit-dropped</i> | (Optional) the xml rate-limit-dropped |
| <i>rate-limit-total</i>   | (Optional) the xml rate-limit-total   |

**Command Mode**

- /exec

## show hardware rate-limiter span-egress

```
show hardware rate-limiter span-egress [ __readonly__ TABLE hardware_rate_limiter <rate-limit-class>
<class-descr> <module> <rate-limit-configured> <rate-limit-allowed> <rate-limit-dropped> <rate-limit-total>
]
```

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                              |
| hardware                           | Show hardware information                                    |
| rate-limiter                       | Show Rate-Limiter configs and statistics                     |
| span-egress                        | SPAN/ERSPAN egress packets                                   |
| <i>__readonly__</i>                | (Optional)   |
| <i>TABLE hardware_rate_limiter</i> | (Optional) the xml Rate-Limiter configuration and statistics |
| <i>rate-limit-class</i>            | (Optional) the xml rate limiter class                        |
| <i>class-descr</i>                 | (Optional) class description                                 |
| <i>module</i>                      | (Optional) the xml module number                             |
| <i>rate-limit-configured</i>       | (Optional) the xml rate-limit-configured                     |
| <i>rate-limit-allowed</i>          | (Optional) the xml rate-limit-allowed                        |
| <i>rate-limit-dropped</i>          | (Optional) the xml rate-limit-dropped                        |
| <i>rate-limit-total</i>            | (Optional) the xml rate-limit-total                          |

### Command Mode

- /exec

# show hardware vxlan storm-control

show hardware vxlan storm-control

## Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| hardware      | Show hardware information       |
| vxlan         | VxLAN Information               |
| storm-control | Storm Control Information       |

## Command Mode

- /exec

# show hostname

```
show { hostname | switchname } [ __readonly__ { <hostname> } ]
```

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| hostname        | show the system's hostname      |
| switchname      | show the system's hostname      |
| __readonly__    | (Optional) Read Only            |
| <i>hostname</i> | (Optional)                      |

## Command Mode

- /exec

# show hosts

```
show hosts [ __readonly__ [ <dnslookup> ] [ <dnsnameservice> ] [ { TABLE_vrf <vrfname> [
<defaultdomains> ] [ <additionaldomainserver> ] [ <domainservers> ] [ <nameservice> ] [ <dhcpdomains>
] [ <dhcpdomainservers> ] } ] [ { TABLE_dnsconfigvrf <dnsvrfname> [ <usevrf> ] [ <token> ] [ {
TABLE_dnsconfigvrfconfig <config> } ] } ] [ { TABLE_hosts <host> [ <address> } ] ] ]
```

## Syntax Description

|                               |                                     |
|-------------------------------|-------------------------------------|
| show                          | Show running system information     |
| hosts                         | Show information about DNS          |
| <i>__readonly__</i>           | (Optional)                          |
| <i>dnslookup</i>              | (Optional) dns lookup enable status |
| <i>dnsnameservice</i>         | (Optional) name service             |
| TABLE_vrf                     | (Optional) vrf domain servers       |
| <i>vrfname</i>                | (Optional) vrf name                 |
| <i>defaultdomains</i>         | (Optional) default domain           |
| <i>additionaldomainserver</i> | (Optional) additionaldomain         |
| <i>domainservers</i>          | (Optional) domain server            |
| <i>nameservice</i>            | (Optional) name service             |
| <i>dhcpdomains</i>            | (Optional) dhcp domains             |
| <i>dhcpdomainservers</i>      | (Optional) dhcpservers              |
| TABLE_dnsconfigvrf            | (Optional) dns config vrf           |
| <i>dnsvrfname</i>             | (Optional) vrfname                  |
| <i>usevrf</i>                 | (Optional) usevrf                   |
| <i>token</i>                  | (Optional) token                    |
| TABLE_dnsconfigvrfconfig      | (Optional) dns config vrf config    |
| <i>config</i>                 | (Optional) token                    |
| TABLE_hosts                   | (Optional) all configured dns hosts |
| <i>host</i>                   | (Optional) xml host information     |
| <i>address</i>                | (Optional) xml address information  |

## Command Mode

- /exec



# show hsrp

```
show hsrp [ interface <interface-id> ] [ group <group-number> ] [ active | init | learn | listen | speak | standby
] + [ all ] [ brief [ all ] | detail ] [ ipv4 | ipv6 ] [ _readonly_ <show_hsrp_start> { TABLE_grp_detail
<sh_if_index> <sh_group_num> <sh_group_type> <sh_group_version> <sh_group_state> [ <sh_state_reason>
] <sh_prio> <sh_cfg_prio> <sh_fwd_lower_threshold> <sh_fwd_upper_threshold> <sh_can_forward>
<sh_preempt> [ <sh_preempt_min_delay> ] [ <sh_preempt_min_delay_active> ] [ <sh_preempt_reload_delay>
] [ <sh_preempt_reload_delay_active> ] [ <sh_preempt_sync_delay> ] [ <sh_preempt_sync_delay_active> ]
<sh_cur_hello> <sh_cur_hello_attr> [ <sh_cfg_hello> ] [ <sh_cfg_hello_attr> ] [ <sh_active_hello> ]
<sh_cur_hold> <sh_cur_hold_attr> [ <sh_cfg_hold> ] [ <sh_cfg_hold_attr> ] [ <sh_vip> | <sh_vip_v6> ]
<sh_vip_attr> <sh_num_vip_sec> { [ TABLE_grp_vip_sec <sh_vip_sec> } } [ <sh_active_router_addr> |
<sh_active_router_addr_v6> ] <sh_active_router_prio> [ <sh_active_router_timer> ] [
<sh_standby_router_addr> | <sh_standby_router_addr_v6> ] <sh_standby_router_prio>
<sh_authentication_type> <sh_authentication_data> [ <sh_keystring_attr> ] [ <sh_keystring_timeout> ] [
<sh_keystring_cur_valid> ] <sh_vmac> <sh_vmac_attr> <sh_num_of_state_changes> [ <sh_last_state_change>
] <sh_num_of_total_state_changes> [ <sh_last_total_state_change> ] { [ TABLE_grp_track_obj <sh_track_obj>
<sh_track_obj_state> <sh_track_obj_prio> ] } <sh_num_track_obj> <sh_ip_redund_name>
<sh_ip_redund_name_attr> } <show_hsrp_end> ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                |
| hsrp                | Hot Standby Router Protocol (HSRP) information |
| interface           | (Optional) Groups on this interface            |
| <i>interface-id</i> | (Optional) Interface                           |
| active              | (Optional) Groups in active state              |
| init                | (Optional) Groups in init state                |
| listen              | (Optional) Groups in listen state              |
| standby             | (Optional) Groups in standby state             |
| learn               | (Optional) Groups in learn state               |
| speak               | (Optional) Groups in speak state               |
| group               | (Optional) Group number                        |
| <i>group-number</i> | (Optional) Group Number                        |
| all                 | (Optional) Include groups in disabled state    |
| brief               | (Optional) Brief output                        |
| detail              | (Optional) Detailed output                     |
| ipv4                | (Optional) HSRP V4 Groups                      |
| ipv6                | (Optional) HSRP V6 Groups                      |

|                                |   |
|--------------------------------|---|
| all                            | (Optional) Display all VIPs               |
| __readonly__                   | (Optional) Read only                      |
| show_hsrp_start                | (Optional) Show hsrp start                |
| TABLE_grp_detail               | (Optional) Group table detail             |
| sh_if_index                    | (Optional) Interface type and number      |
| sh_group_num                   | (Optional) Group number                   |
| sh_group_state                 | (Optional) HSRP state                     |
| sh_state_reason                | (Optional) Reason                         |
| sh_group_type                  | (Optional) Group type                     |
| sh_group_version               | (Optional) Group version                  |
| sh_prio                        | (Optional) Priority                       |
| sh_cfg_prio                    | (Optional) Configured priority            |
| sh_fwd_lower_threshold         | (Optional) Lower threshold value          |
| sh_fwd_upper_threshold         | (Optional) Upper threshold value          |
| sh_can_forward                 | (Optional) Current forwarding status      |
| sh_preempt                     | (Optional) Preemption enabled/not         |
| sh_preempt_min_delay           | (Optional) Preemption min delay           |
| sh_preempt_min_delay_active    | (Optional) Active preemption min delay    |
| sh_preempt_reload_delay        | (Optional) Preemption reload delay        |
| sh_preempt_reload_delay_active | (Optional) Active preemption reload delay |
| sh_preempt_sync_delay          | (Optional) Preemption sync delay          |
| sh_preempt_sync_delay_active   | (Optional) Active preemption sync delay   |
| sh_cur_hello                   | (Optional) Current hello time             |
| sh_cur_hello_attr              | (Optional) Hello time in ms/not           |
| sh_cfg_hello                   | (Optional) Configured hello time          |
| sh_cfg_hello_attr              | (Optional) Hello time in ms/not           |
| sh_active_hello                | (Optional) Active hello time              |
| sh_cur_hold                    | (Optional) Current hold time              |
| sh_cur_hold_attr               | (Optional) Hello time in ms/not           |

|                                      |   |
|--------------------------------------|---|
| <i>sh_cfg_hold</i>                   | (Optional) Configured hold time                   |
| <i>sh_cfg_hold_attr</i>              | (Optional) Hello time in ms/not                   |
| <i>sh_vip</i>                        | (Optional) Virtual IP address                     |
| <i>sh_vip_attr</i>                   | (Optional) Virtual IP address attribute           |
| <i>sh_num_vip_sec</i>                | (Optional) Number of Secondary virtual IP address |
| TABLE_grp_vip_sec                    | (Optional) Group secondary ip address             |
| <i>sh_vip_sec</i>                    | (Optional) Secondary virtual IP address           |
| <i>sh_active_router_addr</i>         | (Optional) Active router address                  |
| <i>sh_active_router_prio</i>         | (Optional) Active router priority                 |
| <i>sh_active_router_timer</i>        | (Optional) Active router expiry timer             |
| <i>sh_standby_router_addr</i>        | (Optional) Standby router address                 |
| <i>sh_standby_router_prio</i>        | (Optional) Standby router priority                |
| <i>sh_authentication_type</i>        | (Optional) Authentication type                    |
| <i>sh_authentication_data</i>        | (Optional) Authentication data                    |
| <i>sh_keystring_attr</i>             | (Optional) Keysting attribute                     |
| <i>sh_keystring_timeout</i>          | (Optional) Keysting timeout                       |
| <i>sh_keystring_cur_valid</i>        | (Optional) Keysting current valid time            |
| <i>sh_vmac</i>                       | (Optional) Virtual MAC                            |
| <i>sh_vmac_attr</i>                  | (Optional) Virtual MAC attribute                  |
| <i>sh_num_of_state_changes</i>       | (Optional) Number of state changes                |
| <i>sh_last_state_change</i>          | (Optional) Last state change time                 |
| <i>sh_num_of_total_state_changes</i> | (Optional) Number of total state changes          |
| <i>sh_last_total_state_change</i>    | (Optional) Last total state change time           |
| <i>sh_num_track_obj</i>              | (Optional) Number of tracked objects              |
| TABLE_grp_track_obj                  | (Optional) Group tracked objects                  |
| <i>sh_track_obj</i>                  | (Optional) Tracked object                         |
| <i>sh_track_obj_state</i>            | (Optional) State of tracked object                |
| <i>sh_track_obj_prio</i>             | (Optional) Tracked object priority decrement      |
| <i>sh_ip_redund_name</i>             | (Optional) IP redundancy name                     |

|                               |   |
|-------------------------------|---|
| <i>sh_ip_redund_name_attr</i> | (Optional) IP redundancy name attribute |
| <i>show_hsrp_end</i>          | (Optional) End of Group                 |

**Command Mode**

- /exec

# show hsrp anycast

```
show hsrp anycast [ <id> { ipv4 | ipv6 | both } ] [ brief ]
```

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                        |
| hsrp      | Hot Standby Router Protocol (HSRP) information         |
| anycast   | Anycast related commands                               |
| <i>id</i> | (Optional) Bundle number                               |
| ipv4      | (Optional) Associate IP Version 4 for the bundle       |
| ipv6      | (Optional) Associate IP Version 6 for the bundle       |
| both      | (Optional) Associate IP Version 4 and 6 for the bundle |
| brief     | (Optional) Brief output                                |

## Command Mode

- /exec

## show hsrp anycast interface vlan

show hsrp anycast interface { vlan | bdi } <id>

### Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                |
| hsrp      | Hot Standby Router Protocol (HSRP) information |
| anycast   | Anycast related commands                       |
| interface | Bundle on this interface Interface             |
| vlan      | VLAN interface                                 |
| bdi       | Bridge-Domain interface                        |
| <i>id</i> | VLAN number                                    |

### Command Mode

- /exec

## show hsrp anycast remote-db

show hsrp anycast remote-db [ <id> { ipv4 | ipv6 | both } ]

### Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                        |
| hsrp      | Hot Standby Router Protocol (HSRP) information         |
| anycast   | Anycast related commands                               |
| remote-db | Remote data base for the bundle                        |
| <i>id</i> | (Optional) Bundle number                               |
| ipv4      | (Optional) Associate IP Version 4 for the bundle       |
| ipv6      | (Optional) Associate IP Version 6 for the bundle       |
| both      | (Optional) Associate IP Version 4 and 6 for the bundle |

### Command Mode

- /exec

# show hsrp anycast summary

show hsrp anycast summary

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                |
| hsrp    | Hot Standby Router Protocol (HSRP) information |
| anycast | Anycast related commands                       |
| summary | Show HSRP summary                              |

## Command Mode

- /exec



## show hsrp bfd-sessions

```
show hsrp bfd-sessions [ interface <interface-id> [ to <ipaddress> ] ] [ __readonly__ [ TABLE_bfd_sess [
<interface> ] [ <list_size> ] { [ <src_addr> ] } { [ <dst_addr> ] } [ <ref_count> ] { [ TABLE_ref_groups [
<ref_group_id> ] } ] } { [ TABLE_hist_groups [ <hist_group_id> ] [ <hist_operation> ] [ <hist_rel_time> ] [
<hist_abs_time> ] [ <hist_ref_count> ] [ <hist_group_state> ] [ <hist_status> ] [ <hist_op_reason> ] ] } ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                |
| hsrp                    | Hot Standby Router Protocol (HSRP) information |
| bfd-sessions            | BFD sessions                                   |
| interface               | (Optional) Groups on this interface            |
| <i>interface-id</i>     | (Optional) Interface                           |
| to                      | (Optional) To IP address                       |
| <i>ipaddress</i>        | (Optional) Sessions to IP address              |
| <i>__readonly__</i>     | (Optional)                                     |
| TABLE_bfd_sess          | (Optional)                                     |
| <i>interface</i>        | (Optional) Interface                           |
| <i>list_size</i>        | (Optional) List size                           |
| <i>src_addr</i>         | (Optional) IPv4 Source address                 |
| <i>dst_addr</i>         | (Optional) IPv4 Destination address            |
| <i>ref_count</i>        | (Optional) Ref count                           |
| TABLE_ref_groups        | (Optional)                                     |
| <i>ref_group_id</i>     | (Optional) Group id                            |
| TABLE_hist_groups       | (Optional)                                     |
| <i>hist_group_id</i>    | (Optional) Group id                            |
| <i>hist_operation</i>   | (Optional) Operation                           |
| <i>hist_rel_time</i>    | (Optional) Relative time                       |
| <i>hist_abs_time</i>    | (Optional) Absolute time                       |
| <i>hist_ref_count</i>   | (Optional) Ref count                           |
| <i>hist_group_state</i> | (Optional) Group state                         |

|                       |                      |
|-----------------------|----------------------|
| <i>hist_status</i>    | (Optional) Status    |
| <i>hist_op_reason</i> | (Optional) Op reason |

**Command Mode**

- /exec

# show hsrp delay

```
show hsrp delay [ interface <interface-id> ] [ __readonly__ TABLE_delay <interface> <min_delay>
<reload_delay> ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                |
| hsrp                | Hot Standby Router Protocol (HSRP) information |
| delay               | Group initialisation delay                     |
| interface           | (Optional) Groups on this interface            |
| <i>interface-id</i> | (Optional) Interface                           |
| <i>__readonly__</i> | (Optional)                                     |
| <i>TABLE_delay</i>  | (Optional)                                     |
| <i>interface</i>    | (Optional) Interface                           |
| <i>min_delay</i>    | (Optional) Min delay                           |
| <i>reload_delay</i> | (Optional) Reload delay                        |

## Command Mode

- /exec

# show hsrp mgo

```
show hsrp mgo [ name <name> | brief ] [ __readonly__ TABLE_hsrp_mgo <master_name> <master_interface>
<master_address_family> <master_group_id> [ <master_version> ] <master_state> [ <master_down_reason>
] [ { TABLE_slave <slave_interface> <slave_group_id> <slave_state> [ <slave_down_reason> } ] [
<num_slave_group> ] ]
```

## Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information                |
| hsrp                         | Hot Standby Router Protocol (HSRP) information |
| mgo                          | Show HSRP mgo details                          |
| name                         | (Optional) Redundancy name string              |
| <i>name</i>                  | (Optional) name string                         |
| brief                        | (Optional) show HSPR mgo brief                 |
| <i>__readonly__</i>          | (Optional)                                     |
| TABLE_hsrp_mgo               | (Optional)                                     |
| <i>master_name</i>           | (Optional) HSRP master name                    |
| <i>master_interface</i>      | (Optional) HSRP master interface               |
| <i>master_address_family</i> | (Optional) HSRP master AF                      |
| <i>master_group_id</i>       | (Optional) HSRP master group ID                |
| <i>master_version</i>        | (Optional) HSRP master version                 |
| <i>master_state</i>          | (Optional) HSRP master state                   |
| <i>master_down_reason</i>    | (Optional) HSRP master down reason             |
| TABLE_slave                  | (Optional) Slave table                         |
| <i>slave_interface</i>       | (Optional) HSRP slave interface                |
| <i>slave_group_id</i>        | (Optional) HSRP slave group id                 |
| <i>slave_state</i>           | (Optional) HSRP slave state                    |
| <i>slave_down_reason</i>     | (Optional) HSRP slave down reason              |
| <i>num_slave_group</i>       | (Optional) HSRP number of slave groups         |

## Command Mode

- /exec

## show hsrp summary

```
show hsrp summary [ __readonly__ <switchover_notify_rxed> <bfd_enabled> <num_of_groups>
<num_of_v4_v1_groups> <num_of_v4_v2_groups> <num_of_v6_v2_groups> <num_of_active_groups>
<num_of_standby_groups> <num_of_listen_groups> <num_of_v6_active_groups>
<num_of_v6_standby_groups> <num_of_v6_listen_groups> <num_of_hsrp_enabled_ifs> <counter_pkts_tx>
<counter_pkts_tx_failure> <counter_pkts_in> <counter_pkts_bad_vr> <counter_mts_rx> ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                           |
| hsrp                            | Hot Standby Router Protocol (HSRP) information            |
| summary                         | Show HSRP summary   |
| <i>__readonly__</i>             | (Optional)  |
| <i>switchover_notify_rxed</i>   | (Optional) Switchover notification received (1 => active) |
| <i>bfd_enabled</i>              | (Optional) BFD status                                     |
| <i>num_of_groups</i>            | (Optional) Total number of groups                         |
| <i>num_of_v4_v1_groups</i>      | (Optional) Number of IPv4 V1 groups                       |
| <i>num_of_v4_v2_groups</i>      | (Optional) Number of IPv4 V2 groups                       |
| <i>num_of_v6_v2_groups</i>      | (Optional) Number of IPv6 V2 groups                       |
| <i>num_of_active_groups</i>     | (Optional) Number of active groups                        |
| <i>num_of_standby_groups</i>    | (Optional) Number of standby groups                       |
| <i>num_of_listen_groups</i>     | (Optional) Number of listen groups                        |
| <i>num_of_v6_active_groups</i>  | (Optional) Number of IPv6 active groups                   |
| <i>num_of_v6_standby_groups</i> | (Optional) Number of IPv6 standby groups                  |
| <i>num_of_v6_listen_groups</i>  | (Optional) Number of IPv6 listen groups                   |
| <i>num_of_hsrp_enabled_ifs</i>  | (Optional) Number of HSRP enabled interfaces              |
| <i>counter_pkts_tx</i>          | (Optional) Number of packet transmission successes        |
| <i>counter_pkts_tx_failure</i>  | (Optional) Number of packet transmission failure          |
| <i>counter_pkts_in</i>          | (Optional) Number of packets received successfully        |
| <i>counter_pkts_bad_vr</i>      | (Optional) Number of packets for unknown groups           |
| <i>counter_mts_rx</i>           | (Optional) Number of MTS messages received                |

### Command Mode

- /exec



## I Show Commands

---

- [show icam entries acl module inst](#), on page 852
- [show icam health](#), on page 854
- [show icam prediction entries acl module inst](#), on page 855
- [show icam prediction scale](#), on page 857
- [show icam scale](#), on page 864
- [show icam system](#), on page 871
- [show ieth-header-decode](#), on page 873
- [show inband-telemetry exporter](#), on page 874
- [show inband-telemetry flow-profile](#), on page 875
- [show inband-telemetry monitor](#), on page 876
- [show inband-telemetry queue-profile](#), on page 877
- [show inband-telemetry record](#), on page 878
- [show inband-telemetry sessions](#), on page 879
- [show inband-telemetry watchlist](#), on page 880
- [show incompatibility-all system](#), on page 881
- [show incompatibility system](#), on page 882
- [show install](#), on page 883
- [show install all failed-standby](#), on page 884
- [show install all failure-reason](#), on page 885
- [show install all impact](#), on page 886
- [show install all impact epld](#), on page 887
- [show install all progress](#), on page 888
- [show install all status](#), on page 889
- [show install all time-stats](#), on page 891
- [show install epld status](#), on page 892
- [show install log](#), on page 893
- [show install mode](#), on page 894
- [show install packages](#), on page 895
- [show install patches](#), on page 896
- [show interface](#), on page 897
- [show interface](#), on page 902
- [show interface](#), on page 907
- [show interface](#), on page 916

- [show interface](#), on page 920
- [show interface](#), on page 941
- [show interface](#), on page 945
- [show interface](#), on page 947
- [show interface](#), on page 953
- [show interface](#), on page 955
- [show interface](#), on page 957
- [show interface aggregate-counters](#), on page 961
- [show interface aggregate-counters](#), on page 964
- [show interface bcredit](#), on page 967
- [show interface brief](#), on page 968
- [show interface brief](#), on page 969
- [show interface brief](#), on page 978
- [show interface brief](#), on page 979
- [show interface brief](#), on page 982
- [show interface brief](#), on page 983
- [show interface brief](#), on page 985
- [show interface brief](#), on page 986
- [show interface brief](#), on page 987
- [show interface cable-diagnostics-tdr](#), on page 988
- [show interface capabilities](#), on page 989
- [show interface capabilities](#), on page 991
- [show interface capabilities](#), on page 993
- [show interface chassis-info](#), on page 995
- [show interface counters](#), on page 997
- [show interface counters](#), on page 1000
- [show interface counters](#), on page 1004
- [show interface counters](#), on page 1005
- [show interface counters](#), on page 1008
- [show interface counters](#), on page 1010
- [show interface counters](#), on page 1012
- [show interface counters](#), on page 1014
- [show interface counters brief](#), on page 1015
- [show interface counters brief](#), on page 1017
- [show interface counters detailed](#), on page 1019
- [show interface counters detailed](#), on page 1026
- [show interface counters detailed](#), on page 1038
- [show interface counters detailed](#), on page 1041
- [show interface counters detailed all](#), on page 1043
- [show interface counters detailed all](#), on page 1045
- [show interface counters detailed all](#), on page 1046
- [show interface counters detailed all](#), on page 1049
- [show interface counters detailed all](#), on page 1050
- [show interface counters detailed cached](#), on page 1058
- [show interface counters details](#), on page 1066
- [show interface counters details](#), on page 1070



- [show interface counters errors, on page 1071](#)
- [show interface counters errors, on page 1072](#)
- [show interface counters errors, on page 1074](#)
- [show interface counters fc, on page 1076](#)
- [show interface counters snmp, on page 1080](#)
- [show interface counters snmp, on page 1083](#)
- [show interface counters storm-control, on page 1085](#)
- [show interface counters storm-control, on page 1086](#)
- [show interface counters storm-control multi-threshold, on page 1087](#)
- [show interface counters table, on page 1089](#)
- [show interface counters table verbose, on page 1090](#)
- [show interface counters trunk, on page 1091](#)
- [show interface dampening, on page 1092](#)
- [show interface debounce, on page 1093](#)
- [show interface debounce, on page 1094](#)
- [show interface description, on page 1095](#)
- [show interface description, on page 1096](#)
- [show interface description, on page 1097](#)
- [show interface description, on page 1098](#)
- [show interface description, on page 1099](#)
- [show interface description, on page 1100](#)
- [show interface description, on page 1101](#)
- [show interface description, on page 1102](#)
- [show interface detail-counters, on page 1103](#)
- [show interface fcoe, on page 1107](#)
- [show interface fec, on page 1108](#)
- [show interface flowcontrol, on page 1109](#)
- [show interface flowcontrol, on page 1110](#)
- [show interface hardware-mappings, on page 1111](#)
- [show interface mac-address, on page 1112](#)
- [show interface mac-address, on page 1113](#)
- [show interface priority-flow-control, on page 1114](#)
- [show interface private-vlan mapping, on page 1115](#)
- [show interface pruning, on page 1116](#)
- [show interface queuing-drop history brief, on page 1117](#)
- [show interface queuing-drop history detail, on page 1118](#)
- [show interface server-info interface, on page 1119](#)
- [show interface snmp-ifindex, on page 1120](#)
- [show interface status, on page 1121](#)
- [show interface status, on page 1122](#)
- [show interface status, on page 1123](#)
- [show interface status, on page 1125](#)
- [show interface status, on page 1126](#)
- [show interface status, on page 1127](#)
- [show interface status, on page 1128](#)
- [show interface status err-disabled, on page 1129](#)

- [show interface status err-disabled](#), on page 1130
- [show interface status err-vlans](#), on page 1131
- [show interface status err-vlans](#), on page 1132
- [show interface storm-control multi-threshold](#), on page 1133
- [show interface switchport](#), on page 1134
- [show interface switchport](#), on page 1136
- [show interface switchport backup](#), on page 1138
- [show interface transceiver](#), on page 1140
- [show interface transceiver](#), on page 1144
- [show interface transceiver](#), on page 1152
- [show interface transceiver fex-fabric](#), on page 1162
- [show interface transceiver fex-fabric](#), on page 1164
- [show interface trunk](#), on page 1171
- [show interface trunk](#), on page 1173
- [show interface trunk vsan](#), on page 1175
- [show interface trunk vsan](#), on page 1176
- [show interface untagged-cos](#), on page 1177
- [show interface vlan mapping](#), on page 1178
- [show inventory](#), on page 1179
- [show ip adjacency](#), on page 1180
- [show ip amt relay](#), on page 1183
- [show ip amt route](#), on page 1184
- [show ip amt tunnel](#), on page 1185
- [show ip arp](#), on page 1187
- [show ip arp anycast topo-info](#), on page 1189
- [show ip arp client](#), on page 1190
- [show ip arp controller-statistics](#), on page 1191
- [show ip arp esi](#), on page 1192
- [show ip arp inspection](#), on page 1193
- [show ip arp inspection interfaces](#), on page 1194
- [show ip arp inspection log](#), on page 1195
- [show ip arp inspection statistics](#), on page 1196
- [show ip arp inspection vlan](#), on page 1197
- [show ip arp l2 statistics interface](#), on page 1198
- [show ip arp multihoming-statistics](#), on page 1199
- [show ip arp off-list](#), on page 1201
- [show ip arp open-flow error-statistics](#), on page 1202
- [show ip arp statistics](#), on page 1204
- [show ip arp suppression-cache](#), on page 1208
- [show ip arp suppression topo-info](#), on page 1211
- [show ip arp tunnel-statistics](#), on page 1212
- [show ip arp vpc-statistics](#), on page 1214
- [show ip as-path-access-list](#), on page 1217
- [show ip client](#), on page 1218
- [show ip community-list](#), on page 1219
- [show ip dhcp global statistics](#), on page 1220

- [show ip dhcp option82 suboption info interface](#), on page 1222
- [show ip dhcp relay](#), on page 1223
- [show ip dhcp relay address](#), on page 1225
- [show ip dhcp relay information trusted-sources](#), on page 1226
- [show ip dhcp relay statistics](#), on page 1227
- [show ip dhcp snooping](#), on page 1231
- [show ip dhcp snooping binding](#), on page 1232
- [show ip dhcp snooping statistics](#), on page 1233
- [show ip dhcp status](#), on page 1234
- [show ip dns source-interface](#), on page 1235
- [show ip dns source-interface vrf all](#), on page 1236
- [show ip eigrp](#), on page 1237
- [show ip eigrp accounting](#), on page 1241
- [show ip eigrp interfaces](#), on page 1243
- [show ip eigrp traffic](#), on page 1246
- [show ip extcommunity-list](#), on page 1248
- [show ip fib distribution](#), on page 1249
- [show ip fib distribution clients](#), on page 1250
- [show ip fib distribution mroute](#), on page 1251
- [show ip fib distribution multicast](#), on page 1253
- [show ip fib distribution state](#), on page 1254
- [show ip fib mroute](#), on page 1255
- [show ip fib route](#), on page 1257
- [show ip ftp source-interface](#), on page 1259
- [show ip ftp source-interface vrf all](#), on page 1260
- [show ip http source-interface](#), on page 1261
- [show ip http source-interface vrf all](#), on page 1262
- [show ip igmp groups](#), on page 1263
- [show ip igmp interface](#), on page 1265
- [show ip igmp local-groups](#), on page 1269
- [show ip igmp policy statistics reports](#), on page 1271
- [show ip igmp snooping](#), on page 1272
- [show ip igmp snooping explicit-tracking](#), on page 1274
- [show ip igmp snooping filter details](#), on page 1276
- [show ip igmp snooping groups](#), on page 1277
- [show ip igmp snooping lookup-mode](#), on page 1280
- [show ip igmp snooping mac-oif](#), on page 1281
- [show ip igmp snooping mrouter](#), on page 1282
- [show ip igmp snooping otv vlan brief](#), on page 1284
- [show ip igmp snooping pw vlan brief](#), on page 1285
- [show ip igmp snooping querier](#), on page 1286
- [show ip igmp snooping report statistics](#), on page 1288
- [show ip igmp snooping statistics](#), on page 1289
- [show ip igmp vrf all](#), on page 1293
- [show ip interface](#), on page 1294
- [show ip lisp](#), on page 1299

- [show ip lisp data-cache](#), on page 1300
- [show ip lisp locator-hash](#), on page 1301
- [show ip lisp map-cache](#), on page 1302
- [show ip lisp statistics](#), on page 1303
- [show ip lisp translate-cache](#), on page 1304
- [show ip load-sharing](#), on page 1305
- [show ip local policy](#), on page 1306
- [show ip logging](#), on page 1307
- [show ip mbgp](#), on page 1308
- [show ip mbgp](#), on page 1310
- [show ip mbgp community](#), on page 1311
- [show ip mbgp dampening](#), on page 1312
- [show ip mbgp extcommunity](#), on page 1313
- [show ip mbgp flap-statistics](#), on page 1314
- [show ip mbgp neighbors](#), on page 1315
- [show ip mbgp nexthop-database](#), on page 1317
- [show ip mbgp nexthop](#), on page 1318
- [show ip mbgp prefix-list](#), on page 1319
- [show ip mbgp received-paths](#), on page 1320
- [show ip mroute](#), on page 1321
- [show ip msdp count](#), on page 1326
- [show ip msdp mesh-group](#), on page 1327
- [show ip msdp peer](#), on page 1328
- [show ip msdp policy statistics sa-policy in](#), on page 1331
- [show ip msdp rpf](#), on page 1333
- [show ip msdp sa](#), on page 1335
- [show ip msdp sources](#), on page 1337
- [show ip msdp statistics](#), on page 1338
- [show ip msdp summary](#), on page 1340
- [show ip multicast vrf](#), on page 1342
- [show ip nat-alias](#), on page 1344
- [show ip nat max](#), on page 1345
- [show ip nat statistics](#), on page 1346
- [show ip nat timeout](#), on page 1349
- [show ip nat translations](#), on page 1350
- [show ip ospf](#), on page 1352
- [show ip ospf border-routers](#), on page 1357
- [show ip ospf database](#), on page 1359
- [show ip ospf database database-summary](#), on page 1362
- [show ip ospf database detail](#), on page 1364
- [show ip ospf interface](#), on page 1370
- [show ip ospf interface brief](#), on page 1373
- [show ip ospf lsa-content-changed-list](#), on page 1375
- [show ip ospf neighbors](#), on page 1377
- [show ip ospf neighbors detail](#), on page 1379
- [show ip ospf neighbors summary](#), on page 1382

- [show ip ospf request-list](#), on page 1384
- [show ip ospf retransmission-list](#), on page 1386
- [show ip ospf route](#), on page 1388
- [show ip ospf route summary](#), on page 1390
- [show ip ospf segment-routing adj-sid-database](#), on page 1392
- [show ip ospf segment-routing global-block](#), on page 1393
- [show ip ospf segment-routing sid-database](#), on page 1394
- [show ip ospf sham-links](#), on page 1396
- [show ip ospf sham-links brief](#), on page 1400
- [show ip ospf statistics](#), on page 1401
- [show ip ospf summary-address](#), on page 1405
- [show ip ospf traffic](#), on page 1406
- [show ip ospf virtual-links](#), on page 1410
- [show ip ospf virtual-links brief](#), on page 1414
- [show ip pim config-sanity](#), on page 1415
- [show ip pim df](#), on page 1417
- [show ip pim fabric info](#), on page 1419
- [show ip pim fabric legacy-vlans](#), on page 1420
- [show ip pim group-range](#), on page 1421
- [show ip pim host-proxy](#), on page 1422
- [show ip pim interface](#), on page 1423
- [show ip pim mdt](#), on page 1427
- [show ip pim mdt bgp](#), on page 1429
- [show ip pim mdt history interval](#), on page 1430
- [show ip pim mdt receive](#), on page 1431
- [show ip pim mdt send](#), on page 1432
- [show ip pim neighbor](#), on page 1433
- [show ip pim oif-list](#), on page 1434
- [show ip pim policy statistics](#), on page 1436
- [show ip pim policy statistics jp](#), on page 1438
- [show ip pim route](#), on page 1439
- [show ip pim rp-hash](#), on page 1441
- [show ip pim rp](#), on page 1442
- [show ip pim statistics](#), on page 1445
- [show ip pim vrf](#), on page 1447
- [show ip ping source-interface](#), on page 1448
- [show ip ping source-interface vrf all](#), on page 1449
- [show ip policy](#), on page 1450
- [show ip prefix-list](#), on page 1451
- [show ip process](#), on page 1452
- [show ip rip](#), on page 1454
- [show ip rip interface](#), on page 1456
- [show ip rip neighbor](#), on page 1458
- [show ip rip policy statistics redistribute](#), on page 1460
- [show ip rip route](#), on page 1462
- [show ip rip statistics](#), on page 1464

- [show ip route](#), on page 1466
- [show ip sla application](#), on page 1470
- [show ip sla configuration](#), on page 1471
- [show ip sla enhanced-history collection-statistics](#), on page 1474
- [show ip sla enhanced-history distribution-statistics](#), on page 1478
- [show ip sla group schedule](#), on page 1479
- [show ip sla history](#), on page 1480
- [show ip sla reaction-configuration](#), on page 1482
- [show ip sla reaction-trigger](#), on page 1483
- [show ip sla responder](#), on page 1484
- [show ip sla statistics](#), on page 1486
- [show ip sla twamp connection detail](#), on page 1492
- [show ip sla twamp connection requests](#), on page 1493
- [show ip sla twamp session](#), on page 1494
- [show ip sla twamp standards](#), on page 1495
- [show ip ssh source-interface](#), on page 1496
- [show ip ssh source-interface vrf all](#), on page 1497
- [show ip static-route](#), on page 1498
- [show ip tcp mss](#), on page 1500
- [show ip telnet source-interface](#), on page 1501
- [show ip telnet source-interface vrf all](#), on page 1502
- [show ip tftp source-interface](#), on page 1503
- [show ip tftp source-interface vrf all](#), on page 1504
- [show ip traceroute source-interface](#), on page 1505
- [show ip traceroute source-interface vrf all](#), on page 1506
- [show ip traffic](#), on page 1507
- [show ip traffic pps](#), on page 1514
- [show ip udp relay](#), on page 1515
- [show ip udp relay interface](#), on page 1516
- [show ip udp relay object-group](#), on page 1517
- [show ip verify source](#), on page 1518
- [show ipt details](#), on page 1519
- [show ipv6 adjacency](#), on page 1520
- [show ipv6 adjacency aggregate-prefix](#), on page 1523
- [show ipv6 adjacency subnet-prefix](#), on page 1524
- [show ipv6 amt tunnel](#), on page 1525
- [show ipv6 bgp](#), on page 1527
- [show ipv6 bgp](#), on page 1528
- [show ipv6 bgp community](#), on page 1529
- [show ipv6 bgp dampening](#), on page 1530
- [show ipv6 bgp extcommunity](#), on page 1531
- [show ipv6 bgp flap-statistics](#), on page 1532
- [show ipv6 bgp neighbors](#), on page 1533
- [show ipv6 bgp nexthop-database](#), on page 1534
- [show ipv6 bgp nexthop](#), on page 1535
- [show ipv6 bgp received-paths](#), on page 1536

- [show ipv6 bgp regexp](#), on page 1537
- [show ipv6 bgp summary](#), on page 1538
- [show ipv6 client](#), on page 1539
- [show ipv6 dhcp guard policy](#), on page 1541
- [show ipv6 dhcp relay](#), on page 1542
- [show ipv6 dhcp relay statistics](#), on page 1544
- [show ipv6 fragments](#), on page 1548
- [show ipv6 icmp](#), on page 1549
- [show ipv6 icmp global traffic](#), on page 1551
- [show ipv6 icmp interface](#), on page 1554
- [show ipv6 icmp l2 statistics](#), on page 1559
- [show ipv6 icmp nd local-proxy stats](#), on page 1560
- [show ipv6 icmp off-list](#), on page 1561
- [show ipv6 icmp vaddr](#), on page 1562
- [show ipv6 icmp vpc-statistics](#), on page 1566
- [show ipv6 interface](#), on page 1569
- [show ipv6 lisp data-cache](#), on page 1574
- [show ipv6 local policy](#), on page 1575
- [show ipv6 mld global traffic](#), on page 1576
- [show ipv6 mld groups](#), on page 1577
- [show ipv6 mld interface](#), on page 1579
- [show ipv6 mld local-groups](#), on page 1583
- [show ipv6 mld snooping](#), on page 1585
- [show ipv6 mld snooping explicit-tracking](#), on page 1587
- [show ipv6 mld snooping filter details](#), on page 1589
- [show ipv6 mld snooping groups](#), on page 1590
- [show ipv6 mld snooping lookup-mode](#), on page 1593
- [show ipv6 mld snooping mrouter](#), on page 1594
- [show ipv6 mld snooping otv vlan brief](#), on page 1596
- [show ipv6 mld snooping pw vlan brief](#), on page 1597
- [show ipv6 mld snooping querier](#), on page 1598
- [show ipv6 mld snooping report statistics](#), on page 1600
- [show ipv6 mld snooping statistics](#), on page 1601
- [show ipv6 mroute](#), on page 1605
- [show ipv6 mtu](#), on page 1610
- [show ipv6 multicast vrf](#), on page 1612
- [show ipv6 nd ra dns search-list](#), on page 1614
- [show ipv6 nd ra dns server](#), on page 1615
- [show ipv6 nd rguard policy](#), on page 1617
- [show ipv6 neighbor binding](#), on page 1618
- [show ipv6 neighbor binding mac](#), on page 1619
- [show ipv6 neighbor static](#), on page 1620
- [show ipv6 pim df](#), on page 1621
- [show ipv6 pim fabric info](#), on page 1623
- [show ipv6 pim fabric legacy-vlans](#), on page 1624
- [show ipv6 pim group-range](#), on page 1625

- [show ipv6 pim interface](#), on page 1626
- [show ipv6 pim mdt](#), on page 1630
- [show ipv6 pim mdt bgp](#), on page 1632
- [show ipv6 pim mdt history interval](#), on page 1633
- [show ipv6 pim mdt receive](#), on page 1634
- [show ipv6 pim mdt send](#), on page 1635
- [show ipv6 pim neighbor](#), on page 1636
- [show ipv6 pim oif-list](#), on page 1637
- [show ipv6 pim policy statistics jp](#), on page 1639
- [show ipv6 pim route](#), on page 1640
- [show ipv6 pim rp-hash](#), on page 1642
- [show ipv6 pim rp](#), on page 1643
- [show ipv6 pim statistics](#), on page 1646
- [show ipv6 pim vrf](#), on page 1648
- [show ipv6 policy](#), on page 1649
- [show ipv6 prefix-list](#), on page 1650
- [show ipv6 process](#), on page 1651
- [show ipv6 rguard statistics](#), on page 1653
- [show ipv6 rip policy statistics redistribute](#), on page 1654
- [show ipv6 route](#), on page 1656
- [show ipv6 routers](#), on page 1659
- [show ipv6 snooping capture-policy](#), on page 1661
- [show ipv6 snooping counters vlan](#), on page 1662
- [show ipv6 snooping events](#), on page 1664
- [show ipv6 snooping features](#), on page 1665
- [show ipv6 snooping messages](#), on page 1666
- [show ipv6 snooping policies](#), on page 1667
- [show ipv6 snooping policy](#), on page 1668
- [show ipv6 snooping pss database](#), on page 1670
- [show ipv6 static-route](#), on page 1671
- [show ipv6 traffic](#), on page 1673
- [show isis](#), on page 1676
- [show isis adjacency](#), on page 1680
- [show isis csnp](#), on page 1683
- [show isis database](#), on page 1685
- [show isis distribute-ls](#), on page 1690
- [show isis dynamic-flooding](#), on page 1694
- [show isis interface](#), on page 1696
- [show isis ipv6 redistribute route](#), on page 1702
- [show isis ipv6 route](#), on page 1704
- [show isis ipv6 summary-address](#), on page 1708
- [show isis lslib](#), on page 1710
- [show isis mesh-group](#), on page 1712
- [show isis redistribute route](#), on page 1713
- [show isis route](#), on page 1715
- [show isis rrm](#), on page 1719



- [show isis segment-routing mapcache](#), on page 1721
- [show isis segment-routing remote-srgb](#), on page 1723
- [show isis segment-routing sids](#), on page 1725
- [show isis segment-routing srv6](#), on page 1726
- [show isis segment-routing srv6 locators](#), on page 1727
- [show isis spf-log](#), on page 1729
- [show isis srm](#), on page 1731
- [show isis ssn](#), on page 1732
- [show isis statistics](#), on page 1733
- [show isis summary-address](#), on page 1734
- [show isis topology](#), on page 1736
- [show isis traffic](#), on page 1738
- [show itd](#), on page 1742
- [show itd session device-group](#), on page 1747
- [show itd statistics](#), on page 1748
- [show itd vrf](#), on page 1750
- [show itu channel](#), on page 1751

## show icam entries acl module inst

```
show icam entries acl module <module> inst <inst> [ history <num_intervals> ] [ sort { top <top_x> | sort-order
{ ascending | descending } | filter <f_f> [ exact ] | top <top_x> sort-order { ascending | descending } | top
<top_x> filter <f_f> [ exact ] | top <top_x> sort-order { ascending | descending } filter <f_f> [ exact ] | top
<top_x> filter <f_f> [ exact ] sort-order { ascending | descending } | sort-order { ascending | descending } top
<top_x> | sort-order { ascending | descending } filter <f_f> [ exact ] | sort-order { ascending | descending }
filter <f_f> [ exact ] top <top_x> | sort-order { ascending | descending } top <top_x> filter <f_f> [ exact ] |
filter <f_f> [ exact ] top <top_x> | filter <f_f> [ exact ] sort-order { ascending | descending } | filter <f_f> [
exact ] top <top_x> sort-order { ascending | descending } | filter <f_f> [ exact ] sort-order { ascending |
descending } top <top_x> } ] [ __readonly__ <module> <instance> [ <num_intervals> ] [ {
TABLE_ACL_entries <Feature> <Pkt_Type> <SourceIP_Mask_DestIP_Mask> <Action> <Intf_name>
<Stats> [ <Rate> } ] ] ]
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information  |
| icam                 | intelligent CAM  |
| entries              | TCAM Entries with result and stats   |
| acl                  | ACL entries  |
| module               | Module Number  |
| <i>module</i>        | Enter Module Number  |
| inst                 | ASIC/Forwarding Engine Instance Number   |
| <i>inst</i>          | Enter Instance Number  |
| sort                 | (Optional) Sorted display  |
| top                  | (Optional) Show top x% entries (Default:100%)                                    |
| <i>top_x</i>         | (Optional) x% of entries to be displayed   |
| sort-order           | (Optional) Choose the order of displaying sorted entries<br>(Default:descending) |
| ascending            | (Optional) Sort in Ascending order of Stats                                      |
| descending           | (Optional) Sort in Descending order of Stats                                     |
| filter               | (Optional) Feature to be filtered (Default:All)                                  |
| <i>f_f</i>           | (Optional) Enter feature to be filtered  |
| exact                | (Optional) Exact match for feature filter  |
| history              | (Optional) Show entries history  |
| <i>num_intervals</i> | (Optional) Number of intervals to display  |

|                                  |  |
|----------------------------------|--|
| <i>__readonly__</i>              | (Optional) Read Only                     |
| <i>module</i>                    | (Optional) Module number                 |
| <i>instance</i>                  | (Optional) Instance number               |
| <i>num_intervals</i>             | (Optional) Number of intervals displayed |
| TABLE_ACL_entries                | (Optional) Table for ACL entries         |
| <i>Feature</i>                   | (Optional) Feature name                  |
| <i>Pkt_Type</i>                  | (Optional) Packet type                   |
| <i>SourceIP_Mask_DestIP_Mask</i> | (Optional) IP addresses                  |
| <i>Action</i>                    | (Optional) Action                        |
| <i>Intf_name</i>                 | (Optional) Interface name                |
| <i>Stats</i>                     | (Optional) Total stats                   |
| <i>Rate</i>                      | (Optional) Rate packets/sec              |

**Command Mode**

- /exec

## show icam health

```
show icam health [ __readonly__ { <Version> } [ [ { TABLE_cpu <CpuTypeName> <CpuTypeValue> } ] [
{ TABLE_mem <MemTypeName> <MemTypeValue> } ] [ { TABLE_ps <PsTypeName> <PsTypeValue>
} ] ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| icam                | iCAM - intelligent CAM                    |
| health              | Health status                             |
| __readonly__        | (Optional)                                |
| <i>Version</i>      | (Optional) Version of output format       |
| TABLE_cpu           | (Optional) Table CPU Usage                |
| <i>CpuTypeName</i>  | (Optional) CPU Usage Type                 |
| <i>CpuTypeValue</i> | (Optional) CPU Usage Value                |
| TABLE_mem           | (Optional) Table Memory Usage             |
| <i>MemTypeName</i>  | (Optional) Memory Usage Type              |
| <i>MemTypeValue</i> | (Optional) Memory Usage Value             |
| TABLE_ps            | (Optional) Table Power Supply Usage       |
| <i>PsTypeName</i>   | (Optional) Power Supply Information Type  |
| <i>PsTypeValue</i>  | (Optional) Power Supply Information Value |

### Command Mode

- /exec

## show icam prediction entries acl module inst

```
show icam prediction entries acl module <module> inst <inst> <YYYY> <Month> <Date> <Time> [ top
<top_x> ] [ __readonly__ <module> <instance> [ { TABLE_PREDICTION_ACL_entries <Feature>
<Pkt_Type> <Value_Mask> <Action> <Intf_name> <Stats> <Prediction> } ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                     |
| icam                         | intelligent CAM                                     |
| prediction                   | Machine learning prediction                         |
| entries                      | TCAM Entries with result and stats                  |
| acl                          | ACL entries   |
| module                       | Module Number                                       |
| <i>module</i>                | Enter Module Number                                 |
| inst                         | ASIC/Forwarding Engine Instance Number              |
| <i>inst</i>                  | Enter Instance Number                               |
| <i>YYYY</i>                  | Enter year in YYYY format                           |
| <i>Month</i>                 | Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>Date</i>                  | Enter day of month in dd format                     |
| <i>Time</i>                  | Enter hour, minutes, seconds as HH:MM:SS            |
| top                          | (Optional) Show top x% entries (Default:1%)         |
| <i>top_x</i>                 | (Optional) x% of entries to be displayed            |
| <i>__readonly__</i>          | (Optional) Read Only                                |
| <i>module</i>                | (Optional) Module number                            |
| <i>instance</i>              | (Optional) Instance number                          |
| TABLE_PREDICTION_ACL_entries | (Optional) Table for ACL entries prediction         |
| <i>Feature</i>               | (Optional) Feature name                             |
| <i>Pkt_Type</i>              | (Optional) Packet type                              |
| <i>Value_Mask</i>            | (Optional) Value mask                               |
| <i>Action</i>                | (Optional) Action                                   |
| <i>Intf_name</i>             | (Optional) Interface name                           |

|                   |                          |
|-------------------|--------------------------|
| <i>Stats</i>      | (Optional) Current stats |
| <i>Prediction</i> | (Optional) Prediction    |

**Command Mode**

- /exec

## show icam prediction scale

```
show icam prediction scale [ { { l2-switching [ mac-addresses | mst-instances | mst-vports | rpvst-vports |
rpvst-vlans | total-vlans-x-ports | vlans | infra { mac } | stp { mst-instance | mst-vport | rpvst-vport | rpvst-vlan
| isolated-portvlan } | vlan { vlan-count } ] } | { multicast-routing [ multicast-routes | igmp-groups |
pim-neighbors | outgoing-interfaces | routing-forwarding { route-v4 | route-v6 | route-sg-v4 | route-starg-v4 |
route-sg-v6 | route-starg-v6 | outgoing-interface } | igmp { group } | pim { neighbor } ] } | { unicast-routing
[ bfd-sessions | eigrp-routes | ipv4-arp | ipv4-host-routes | ipv6-host-routes | ipv4-isis-routes | ospf-nbr | ospf-lsa
| ospf-area | ospf-vrf | ospf-passive-intf | bfd { session } | bgp { neighbor } | eigrp { route | neighbor } | hsrp
{ mac } | arp { arp-count } | ipv6-nd { nd-count } | routing { host-route-v4 | host-route-v6 | lpm-route-v4 |
lpm-route-v6 } | isis { adjacency | bfd-session | route } | ospf { neighbor | lsa | area } | vrf { vrf-count } | vrrp
{ grp-per-intf } | pbr { seq-per-policy | nh-per-policy | ace-v4 | ace-v6 | ace-v4v6 | intf } | vrrp3 { grp-per-intf
| grp-dft-timer | grp-relax-timer | path-dft-timer | grp-and-path } ] } | { vxlan [ igmp { vlan | vtep |
underlay-mcast-group } | fl { vni | underlay-mcast-group | overlay-mac | total-mac | vtep | ir-peer | ir-vni |
ir-mac | vlan-mapping-under-intf | vlan-mapping-in-switch | static-mac-to-vtep | vlan-logical-port-vp |
vlan-per-fex-port | vni-for-vpc-gw | igmp-group } | bgp { vni | svi | vrf | underlay-mcast-group | vtep | mac |
host-route-v4 | host-route-v6 | overlay-lpm-route-v4 | overlay-lpm-route-v6 | vlan-logical-port-vp |
vlan-per-fex-port | igmp-group } | bgp-ir { vni | svi | vrf | vtep | mac | host-route-v4 | host-route-v6 |
overlay-lpm-route-v4 | overlay-lpm-route-v6 | vlan-logical-port-vp | vlan-per-fex-port | igmp-group } ] } ] } ]
<YYYY> <Month> <Date> <Time> [ __readonly__ [ <Info_Thres> <Warn_Thres> <Crit_Thres> ] [ {
TABLE_technology <Technology> [ { TABLE_feature <Feature> <Verified_Scale> <Config_Scale> [ {
TABLE_feature_stats <Used_Entries> [ <Cur_Util> ] } ] } ] } ] }
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| icam                | intelligent CAM                           |
| scale               | Verified scale                            |
| prediction          | Machine learning prediction               |
| l2-switching        | (Optional) Layer 2 switching              |
| multicast-routing   | (Optional) Multicast routing              |
| unicast-routing     | (Optional) Unicast routing                |
| vxlan               | (Optional) VxLAN                          |
| mac-addresses       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| mst-instances       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| mst-vports          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| rpvst-vports        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| rpvst-vlans         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| total-vlans-x-ports | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

|                     |   |
|---------------------|---|
| vlan                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| infra               | (Optional) Infrastrure  |
| mac                 | (Optional) MAC Address  |
| vlan                | (Optional) VLAN   |
| vlan-count          | (Optional) Number of VLANs  |
| stp                 | (Optional) Spanning Tree Protocol                                 |
| mst-instance        | (Optional) MST instances  |
| mst-vport           | (Optional) MST virtual ports                                      |
| rpvst-vport         | (Optional) RPVST virtual ports                                    |
| rpvst-vlan          | (Optional) RPVST VLANs  |
| isolated-portvlan   | (Optional) Total number of VLANs x ports with switchport isolated |
| multicast-routes    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| igmp-groups         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| pim-neighbors       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| outgoing-interfaces | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| routing-forwarding  | (Optional) Routing and forwarding                                 |
| route-v4            | (Optional) IPv4 Route   |
| route-v6            | (Optional) IPv6 Route   |
| route-sg-v4         | (Optional) IPv4 S,G Route   |
| route-starg-v4      | (Optional) IPv4 *,G Route   |
| route-sg-v6         | (Optional) IPv6 S,G Route   |
| route-starg-v6      | (Optional) IPv6 *,G Route   |
| outgoing-interface  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| igmp                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| group               | (Optional) IGMP snooping group                                    |
| pim                 | (Optional) PIM  |
| neighbor            | (Optional) PIM neighbor   |
| bfd-sessions        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| eigrp-routes        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |



|                   |   |
|-------------------|---|
| ipv4-arp          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ipv4-host-routes  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ipv6-host-routes  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ipv4-isis-routes  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-nbr          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-lsa          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-area         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-vrf          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-passive-intf | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| bfd               | (Optional) BFD                            |
| session           | (Optional) BFD session                    |
| bgp               | (Optional) BGP                            |
| neighbor          | (Optional) BGP neighbor                   |
| eigrp             | (Optional) EIGRP                          |
| route             | (Optional) EIGRP route                    |
| neighbor          | (Optional) EIGRP neighbor                 |
| hsrp              | (Optional) HSRP                           |
| mac               | (Optional) HSRP MAC                       |
| arp               | (Optional) ARP                            |
| arp-count         | (Optional) ARP count                      |
| ipv6-nd           | (Optional) IPv6 ND                        |
| nd-count          | (Optional) ND count                       |
| routing           | (Optional) Routing                        |
| host-route-v4     | (Optional) IPv4 host route                |
| host-route-v6     | (Optional) IPv6 host route                |
| lpm-route-v4      | (Optional) IPv4 LPM route                 |
| lpm-route-v6      | (Optional) IPv6 LPM route                 |
| isis              | (Optional) IS-IS                          |
| adjacency         | (Optional) IS-ISv4 adjacency              |

|                      |  |
|----------------------|--|
| bfd-session          | (Optional) IS-ISv4 BFD session                                     |
| route                | (Optional) IS-ISv4 route   |
| ospf                 | (Optional) OSPF  |
| neighbor             | (Optional) OSPF neighbor   |
| lsa                  | (Optional) OSPF LSA  |
| area                 | (Optional) OSPF Area   |
| vrf                  | (Optional) VRF   |
| vrf-count            | (Optional) VRF count   |
| vrrp                 | (Optional) VRRP  |
| grp-per-intf         | (Optional) VRRP groups per interface                               |
| pbr                  | (Optional) PBR   |
| seq-per-policy       | (Optional) PBR Configured sequences per policy                     |
| nh-per-policy        | (Optional) PBR NextHop per policy                                  |
| ace-v4               | (Optional) PBR IPv4 ACEs   |
| ace-v6               | (Optional) PBR IPv6 ACEs   |
| ace-v4v6             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                          |
| intf                 | (Optional) Interfaces with PBR policy                              |
| vrrp3                | (Optional) VRRPv3  |
| grp-per-intf         | (Optional) VRRPv3 groups per interface                             |
| grp-dft-timer        | (Optional) VRRPv3 groups with default timers (1 s)                 |
| grp-relax-timer      | (Optional) VRRPv3 groups with relaxed timers (3 s)                 |
| path-dft-timer       | (Optional) Pathways with one VRRPv3 group with default timer (1 s) |
| grp-and-path         | (Optional) VRRPv3 groups and pathways combined                     |
| igmp                 | (Optional) IGMP snooping over VXLAN                                |
| vlan                 | (Optional) VLAN  |
| vtep                 | (Optional) VTEP Peers  |
| underlay-mcast-group | (Optional) Underlay multicast group                                |
| fl                   | (Optional) VXLAN Flood and Learn                                   |
| vni                  | (Optional) VNI   |

|                         |   |
|-------------------------|---|
| underlay-mcast-group    | (Optional) Underlay multicast group                   |
| overlay-mac             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| total-mac               | (Optional) Total MAC address                          |
| vtep                    | (Optional) Remote VTEP                                |
| ir-peer                 | (Optional) Ingress replication peer                   |
| ir-vni                  | (Optional) Ingress replication L2 VNI                 |
| ir-mac                  | (Optional) Ingress replication MAC address            |
| vlan-mapping-under-intf | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| vlan-mapping-in-switch  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| static-mac-to-vtep      | (Optional) Static MACs to remote VTEP                 |
| vlan-logical-port-vp    | (Optional) VLAN logical port VP count                 |
| vlan-per-fex-port       | (Optional) VLANs per FEX port                         |
| vni-for-vpc-gw          | (Optional) L2 routed VNIs for vPC-centralized gateway |
| igmp-group              | (Optional) IGMP group                                 |
| bgp                     | (Optional) BGP eVPN                                   |
| vni                     | (Optional) VNI  |
| svi                     | (Optional) SVI with Anycast Gateway                   |
| vrf                     | (Optional) VRF  |
| underlay-mcast-group    | (Optional) Underlay multicast group                   |
| vtep                    | (Optional) VTEP                                       |
| mac                     | (Optional) MAC address                                |
| host-route-v4           | (Optional) IPv4 host route                            |
| host-route-v6           | (Optional) IPv6 host route                            |
| overlay-lpm-route-v4    | (Optional) IPv4 LPM route                             |
| overlay-lpm-route-v6    | (Optional) IPv6 LPM route                             |
| vlan-logical-port-vp    | (Optional) VLAN logical port VP count                 |
| vlan-per-fex-port       | (Optional) VLAN per FEX port                          |
| igmp-group              | (Optional) IGMP group                                 |
| bgp-ir                  | (Optional) BGP eVPN Ingress Replication               |

|                       |   |
|-----------------------|---|
| vni                   | (Optional) VNI                                      |
| svi                   | (Optional) SVI with Anycast Gateway                 |
| vrf                   | (Optional) VRF                                      |
| vtep                  | (Optional) VTEP                                     |
| mac                   | (Optional) MAC address                              |
| host-route-v4         | (Optional) IPv4 host route                          |
| host-route-v6         | (Optional) IPv6 host route                          |
| overlay-lpm-route-v4  | (Optional) IPv4 LPM route                           |
| overlay-lpm-route-v6  | (Optional) IPv6 LPM route                           |
| vlan-logical-port-vp  | (Optional) VLAN logical port VP count               |
| vlan-per-fex-port     | (Optional) VLAN per FEX port                        |
| igmp-group            | (Optional) IGMP group                               |
| __readonly__          | (Optional) Read Only                                |
| <i>Info_Thres</i>     | (Optional) Configured info threshold percent        |
| <i>Warn_Thres</i>     | (Optional) Configured warning threshold percent     |
| <i>Crit_Thres</i>     | (Optional) Configured critical threshold percent    |
| TABLE_technology      | (Optional) Table technology                         |
| <i>Technology</i>     | (Optional) Technology name                          |
| TABLE_feature         | (Optional) Table feature                            |
| <i>Feature</i>        | (Optional) Feature name                             |
| <i>Verified_Scale</i> | (Optional) Verified scale                           |
| <i>Config_Scale</i>   | (Optional) Configured scale                         |
| TABLE_feature_stats   | (Optional) Table feature stats                      |
| <i>Used_Entries</i>   | (Optional) Used entries                             |
| <i>Cur_Util</i>       | (Optional) Current utilization                      |
| <i>YYYY</i>           | Enter year in YYYY format                           |
| <i>Month</i>          | Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>Date</i>           | Enter day of month in dd format                     |
| <i>Time</i>           | Enter hour, minutes, seconds as HH:MM:SS            |

**Command Mode**

- /exec



|                     |   |
|---------------------|---|
| vlan                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| infra               | (Optional) Infrastructure   |
| mac                 | (Optional) MAC Address  |
| vlan                | (Optional) VLAN   |
| vlan-count          | (Optional) Number of VLANs  |
| stp                 | (Optional) Spanning Tree Protocol                                 |
| mst-instance        | (Optional) MST instances  |
| mst-vport           | (Optional) MST virtual ports                                      |
| rpvst-vport         | (Optional) RPVST virtual ports                                    |
| rpvst-vlan          | (Optional) RPVST VLANs  |
| isolated-portvlan   | (Optional) Total number of VLANs x ports with switchport isolated |
| multicast-routes    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| igmp-groups         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| pim-neighbors       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| outgoing-interfaces | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| routing-forwarding  | (Optional) Routing and forwarding                                 |
| route-v4            | (Optional) IPv4 Route   |
| route-v6            | (Optional) IPv6 Route   |
| route-sg-v4         | (Optional) IPv4 S,G Route   |
| route-starg-v4      | (Optional) IPv4 *,G Route   |
| route-sg-v6         | (Optional) IPv6 S,G Route   |
| route-starg-v6      | (Optional) IPv6 *,G Route   |
| outgoing-interface  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| igmp                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| group               | (Optional) IGMP snooping group                                    |
| pim                 | (Optional) PIM  |
| neighbor            | (Optional) PIM neighbor   |
| bfd-sessions        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| eigrp-routes        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |

|                   |   |
|-------------------|---|
| ipv4-arp          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ipv4-host-routes  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ipv6-host-routes  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ipv4-isis-routes  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-nbr          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-lsa          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-area         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-vrf          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| ospf-passive-intf | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| bfd               | (Optional) BFD                            |
| session           | (Optional) BFD session                    |
| bgp               | (Optional) BGP                            |
| neighbor          | (Optional) BGP neighbor                   |
| eigrp             | (Optional) EIGRP                          |
| route             | (Optional) EIGRP route                    |
| neighbor          | (Optional) EIGRP neighbor                 |
| hsrp              | (Optional) HSRP                           |
| mac               | (Optional) HSRP MAC                       |
| arp               | (Optional) ARP                            |
| arp-count         | (Optional) ARP count                      |
| ipv6-nd           | (Optional) IPv6 ND                        |
| nd-count          | (Optional) ND count                       |
| routing           | (Optional) Routing                        |
| host-route-v4     | (Optional) IPv4 host route                |
| host-route-v6     | (Optional) IPv6 host route                |
| lpm-route-v4      | (Optional) IPv4 LPM route                 |
| lpm-route-v6      | (Optional) IPv6 LPM route                 |
| isis              | (Optional) IS-IS                          |
| adjacency         | (Optional) IS-ISv4 adjacency              |



|                      |  |
|----------------------|--|
| bfd-session          | (Optional) IS-ISv4 BFD session                                     |
| route                | (Optional) IS-ISv4 route   |
| ospf                 | (Optional) OSPF  |
| neighbor             | (Optional) OSPF neighbor   |
| lsa                  | (Optional) OSPF LSA  |
| area                 | (Optional) OSPF Area   |
| vrf                  | (Optional) VRF   |
| vrf-count            | (Optional) VRF count   |
| vrrp                 | (Optional) VRRP  |
| grp-per-intf         | (Optional) VRRP groups per interface                               |
| pbr                  | (Optional) PBR   |
| seq-per-policy       | (Optional) PBR Configured sequences per policy                     |
| nh-per-policy        | (Optional) PBR NextHop per policy                                  |
| ace-v4               | (Optional) PBR IPv4 ACEs   |
| ace-v6               | (Optional) PBR IPv6 ACEs   |
| ace-v4v6             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                          |
| intf                 | (Optional) Interfaces with PBR policy                              |
| vrrp3                | (Optional) VRRPv3  |
| grp-per-intf         | (Optional) VRRPv3 groups per interface                             |
| grp-dft-timer        | (Optional) VRRPv3 groups with default timers (1 s)                 |
| grp-relax-timer      | (Optional) VRRPv3 groups with relaxed timers (3 s)                 |
| path-dft-timer       | (Optional) Pathways with one VRRPv3 group with default timer (1 s) |
| grp-and-path         | (Optional) VRRPv3 groups and pathways combined                     |
| igmp                 | (Optional) IGMP snooping over VXLAN                                |
| vlan                 | (Optional) VLAN  |
| vtep                 | (Optional) VTEP Peers  |
| underlay-mcast-group | (Optional) Underlay multicast group                                |
| fl                   | (Optional) VXLAN Flood and Learn                                   |
| vni                  | (Optional) VNI   |

|                         |   |
|-------------------------|---|
| underlay-mcast-group    | (Optional) Underlay multicast group                   |
| overlay-mac             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| total-mac               | (Optional) Total MAC address                          |
| vtep                    | (Optional) Remote VTEP                                |
| ir-peer                 | (Optional) Ingress replication peer                   |
| ir-vni                  | (Optional) Ingress replication L2 VNI                 |
| ir-mac                  | (Optional) Ingress replication MAC address            |
| vlan-mapping-under-intf | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| vlan-mapping-in-switch  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| static-mac-to-vtep      | (Optional) Static MACs to remote VTEP                 |
| vlan-logical-port-vp    | (Optional) VLAN logical port VP count                 |
| vlan-per-fex-port       | (Optional) VLANs per FEX port                         |
| vni-for-vpc-gw          | (Optional) L2 routed VNIs for vPC-centralized gateway |
| igmp-group              | (Optional) IGMP group                                 |
| bgp                     | (Optional) BGP eVPN                                   |
| vni                     | (Optional) VNI  |
| svi                     | (Optional) SVI with Anycast Gateway                   |
| vrf                     | (Optional) VRF  |
| underlay-mcast-group    | (Optional) Underlay multicast group                   |
| vtep                    | (Optional) VTEP                                       |
| mac                     | (Optional) MAC address                                |
| host-route-v4           | (Optional) IPv4 host route                            |
| host-route-v6           | (Optional) IPv6 host route                            |
| overlay-lpm-route-v4    | (Optional) IPv4 LPM route                             |
| overlay-lpm-route-v6    | (Optional) IPv6 LPM route                             |
| vlan-logical-port-vp    | (Optional) VLAN logical port VP count                 |
| vlan-per-fex-port       | (Optional) VLAN per FEX port                          |
| igmp-group              | (Optional) IGMP group                                 |
| bgp-ir                  | (Optional) BGP eVPN Ingress Replication               |

|                      |  |
|----------------------|--|
| vni                  | (Optional) VNI   |
| svi                  | (Optional) SVI with Anycast Gateway                      |
| vrf                  | (Optional) VRF   |
| vtep                 | (Optional) VTEP  |
| mac                  | (Optional) MAC address                                   |
| host-route-v4        | (Optional) IPv4 host route                               |
| host-route-v6        | (Optional) IPv6 host route                               |
| overlay-lpm-route-v4 | (Optional) IPv4 LPM route                                |
| overlay-lpm-route-v6 | (Optional) IPv6 LPM route                                |
| vlan-logical-port-vp | (Optional) VLAN logical port VP count                    |
| vlan-per-fex-port    | (Optional) VLAN per FEX port                             |
| igmp-group           | (Optional) IGMP group                                    |
| history              | (Optional) Show scale history                            |
| <i>num_intervals</i> | (Optional) Number of intervals in history                |
| sort                 | (Optional) Sorted display                                |
| current-scale        | (Optional) Sort records by current-scale value           |
| ascending            | (Optional) Sort current-scale values in ascending order  |
| descending           | (Optional) Sort current-scale values in descending order |
| polled-timestamp     | (Optional) Sort records by polled-timestamp              |
| newest               | (Optional) Sort with newest record first                 |
| oldest               | (Optional) Sort with oldest record first                 |
| utilization          | (Optional) Show utilization statistics                   |
| thresholds           | (Optional) Show thresholds statistics                    |
| <i>__readonly__</i>  | (Optional) Read Only                                     |
| <i>Info_Thres</i>    | (Optional) Configured info threshold percent             |
| <i>Warn_Thres</i>    | (Optional) Configured warning threshold percent          |
| <i>Crit_Thres</i>    | (Optional) Configured critical threshold percent         |
| TABLE_technology     | (Optional) Table technology                              |
| <i>Technology</i>    | (Optional) Technology name                               |

|                             |  |
|-----------------------------|--|
| <i>TABLE_feature</i>        | (Optional) Table feature   |
| <i>Feature</i>              | (Optional) Feature name  |
| <i>Instance</i>             | (Optional) Instance name. Present if the record is for a specific instance on the system (i.e. module, port combination or specific application instance in a VDC) |
| <i>Verified_Scale</i>       | (Optional) Verified scale  |
| <i>Config_Scale</i>         | (Optional) Configured scale  |
| <i>TABLE_feature_stats</i>  | (Optional) Table feature stats   |
| <i>Used_Entries</i>         | (Optional) Used entries  |
| <i>Cur_Util</i>             | (Optional) Current utilization   |
| <i>Thres_Exceeded</i>       | (Optional) Threshold type exceeded   |
| <i>Polled_TS</i>            | (Optional) Polled timestamp  |
| <i>Avg_Util</i>             | (Optional) Average utilization   |
| <i>Week_Util</i>            | (Optional) 1 week utilization  |
| <i>Week_TS</i>              | (Optional) 1 week peak utilization timestamp   |
| <i>Peak_Util</i>            | (Optional) Peak utilization  |
| <i>Peak_TS</i>              | (Optional) Peak utilization timestamp  |
| <i>Info_Thres_Exceed</i>    | (Optional) Number of times info threshold exceeded   |
| <i>Info_Thres_Exceed_TS</i> | (Optional) Last info threshold exceeded timestamp  |
| <i>Warn_Thres_Exceed</i>    | (Optional) Number of times warning threshold exceeded  |
| <i>Warn_Thres_Exceed_TS</i> | (Optional) Last warning threshold exceeded timestamp   |
| <i>Crit_Thres_Exceed</i>    | (Optional) Number of times critical threshold exceeded   |
| <i>Crit_Thres_Exceed_TS</i> | (Optional) Last critical threshold exceeded timestamp  |

**Command Mode**

- /exec



|                             |  |
|-----------------------------|--|
| TABLE_item                  | (Optional) Table item                                  |
| <i>Name</i>                 | (Optional) Item name                                   |
| <i>Instance</i>             | (Optional) Instance information                        |
| <i>Unit</i>                 | (Optional) Unit of the usage value                     |
| <i>Usage</i>                | (Optional) Usage value                                 |
| <i>Limit</i>                | (Optional) Limit                                       |
| <i>Util</i>                 | (Optional) Utilization percentage                      |
| <i>Thres_Exceeded</i>       | (Optional) Threshold type exceeded                     |
| <i>Polled_TS</i>            | (Optional) Polled timestamp                            |
| <i>Avg_Util</i>             | (Optional) Average utilization                         |
| <i>Peak_Util</i>            | (Optional) Peak utilization                            |
| <i>Peak_TS</i>              | (Optional) Peak utilization timestamp                  |
| <i>Info_Thres_Exceed</i>    | (Optional) Number of times info threshold exceeded     |
| <i>Info_Thres_Exceed_TS</i> | (Optional) Last info threshold exceeded timestamp      |
| <i>Warn_Thres_Exceed</i>    | (Optional) Number of times warning threshold exceeded  |
| <i>Warn_Thres_Exceed_TS</i> | (Optional) Last warning threshold exceeded timestamp   |
| <i>Crit_Thres_Exceed</i>    | (Optional) Number of times critical threshold exceeded |
| <i>Crit_Thres_Exceed_TS</i> | (Optional) Last critical threshold exceeded timestamp  |

### Command Mode

- /exec

# show ieth-header-decode

show ieth-header-decode <ieth>

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                    |
| ieth-header-decode | Show decode of ieth header                         |
| <i>ieth</i>        | ieth header in hex (0xFF...) or string (FF..) form |

## Command Mode

- /exec

# show inband-telemetry exporter

```
show inband-telemetry exporter [ <exportername> ] [ __readonly__ <exporter> <description> <dest> <vrf>
<vrf_id> <vrf_resolved> <dest_udp> <source_intf> <source_ip> <dscp> <seq_num> ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| inband-telemetry    | Show INT information            |
| exporter            | Show INT Exporter Configuration |
| <i>exportername</i> | (Optional) Specify an exporter  |
| <i>__readonly__</i> | (Optional)                      |
| <i>exporter</i>     | (Optional)                      |
| <i>description</i>  | (Optional)                      |
| <i>dest</i>         | (Optional)                      |
| <i>vrf</i>          | (Optional)                      |
| <i>vrf_id</i>       | (Optional)                      |
| <i>vrf_resolved</i> | (Optional)                      |
| <i>dest_udp</i>     | (Optional)                      |
| <i>source_intf</i>  | (Optional)                      |
| <i>source_ip</i>    | (Optional)                      |
| <i>dscp</i>         | (Optional)                      |
| <i>seq_num</i>      | (Optional)                      |

## Command Mode

- /exec



# show inband-telemetry flow-profile

```
show inband-telemetry flow-profile [ <flow-profilename> ] [ __readonly__ <flow-profile> <description>
<dscp> <age> <latency> ]
```

## Syntax Description

|                         |                                     |
|-------------------------|-------------------------------------|
| show                    | Show running system information     |
| inband-telemetry        | Show INT information                |
| flow-profile            | Show INT flow Profile Configuration |
| <i>flow-profilename</i> | (Optional) Specify an flow Profile  |
| <i>__readonly__</i>     | (Optional)                          |
| <i>flow-profile</i>     | (Optional)                          |
| <i>description</i>      | (Optional)                          |
| <i>dscp</i>             | (Optional)                          |
| <i>age</i>              | (Optional)                          |
| <i>latency</i>          | (Optional)                          |

## Command Mode

- /exec

## show inband-telemetry monitor

```
show inband-telemetry monitor [ <monitorname> [ cache [ detailed ] ] ] [ __readonly__ <monitor> <use_count>
<description> <record> <event> <exporter> <bucket_id> <src_addr> <dest_addr> <watchlist> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| inband-telemetry    | Show INT information                      |
| monitor             | Show Monitor Configuration                |
| <i>monitorname</i>  | (Optional) Specify a monitor              |
| cache               | (Optional) Flow monitor cache contents    |
| detailed            | (Optional) Show the entire cache contents |
| <i>__readonly__</i> | (Optional)                                |
| <i>monitor</i>      | (Optional)                                |
| <i>use_count</i>    | (Optional)                                |
| <i>description</i>  | (Optional)                                |
| <i>record</i>       | (Optional)                                |
| <i>event</i>        | (Optional)                                |
| <i>exporter</i>     | (Optional)                                |
| <i>bucket_id</i>    | (Optional)                                |
| <i>src_addr</i>     | (Optional)                                |
| <i>dest_addr</i>    | (Optional)                                |
| <i>watchlist</i>    | (Optional)                                |

### Command Mode

- /exec

# show inband-telemetry queue-profile

```
show inband-telemetry queue-profile [ <queue-profilename> | queue-profile-default ] [ __readonly__
<queue-profile> <description> <depth> <latency> ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                         |
| inband-telemetry         | Show INT information                                    |
| queue-profile            | Show INT Queue Profile Configuration                    |
| <i>queue-profilename</i> | (Optional) Specify an Queue Profile                     |
| queue-profile-default    | (Optional) Show INT Queue Profile Default Configuration |
| __readonly__             | (Optional)  |
| <i>queue-profile</i>     | (Optional)  |
| <i>description</i>       | (Optional)  |
| <i>depth</i>             | (Optional)  |
| <i>latency</i>           | (Optional)  |

## Command Mode

- /exec

# show inband-telemetry record

show inband-telemetry record [ { <recordname> } ] [ \_\_readonly\_\_ <record> <description> <use\_count> ]

## Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| inband-telemetry   | Show INT information            |
| record             | Show Record Configuration       |
| <i>recordname</i>  | (Optional) Specify a record     |
| __readonly__       | (Optional)                      |
| <i>record</i>      | (Optional)                      |
| <i>description</i> | (Optional)                      |
| <i>use_count</i>   | (Optional)                      |

## Command Mode

- /exec

# show inband-telemetry sessions

show inband-telemetry sessions [ <monitorname> ] [ \_\_readonly\_\_ <monitor> ]

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| inband-telemetry    | Show INT information            |
| sessions            | Show Session Configuration      |
| <i>monitorname</i>  | (Optional) Specify a monitor    |
| <i>__readonly__</i> | (Optional)                      |
| <i>monitor</i>      | (Optional)                      |

## Command Mode

- /exec

# show inband-telemetry watchlist

```
show inband-telemetry watchlist [ { <watchlistname> } ] [ __readonly__ <watchlist> <use_count>
<description> <num_aces> <ace_seq_num> <ace_action> <ace_type> <ace_sip> <ace_sip_len> <ace_dip>
<ace_dip_len> ]
```

## Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| inband-telemetry     | Show INT information            |
| watchlist            | Show watchlist Configuration    |
| <i>watchlistname</i> | (Optional) Specify a watchlist  |
| <i>__readonly__</i>  | (Optional)                      |
| <i>watchlist</i>     | (Optional)                      |
| <i>use_count</i>     | (Optional)                      |
| <i>description</i>   | (Optional)                      |
| <i>num_aces</i>      | (Optional)                      |
| <i>ace_seq_num</i>   | (Optional)                      |
| <i>ace_action</i>    | (Optional)                      |
| <i>ace_type</i>      | (Optional)                      |
| <i>ace_sip</i>       | (Optional)                      |
| <i>ace_sip_len</i>   | (Optional)                      |
| <i>ace_dip</i>       | (Optional)                      |
| <i>ace_dip_len</i>   | (Optional)                      |

## Command Mode

- /exec

## show incompatibility-all system

```
show incompatibility-all { system <uri0> | nxos <uri1> } [ __readonly__ { [ TABLE_incompat_all <Str1> [
<Serv> ] [ <Cap> ] [ <Desc> ] [ <Req> ] [ <Enable> ] ] [ <Dynamic> ] } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                        |
| incompatibility-all | Show incompatible configurations for the entire system |
| system              | show incompatibilities with an image                   |
| <i>uri0</i>         | Enter image uri  |
| nxos                | show incompatibilities with an image                   |
| <i>uri1</i>         | Enter image uri  |
| <i>__readonly__</i> | (Optional)   |
| TABLE_incompat_all  | (Optional) Show incompatibility system table           |
| <i>Str1</i>         | (Optional)   |
| <i>Serv</i>         | (Optional)   |
| <i>Cap</i>          | (Optional)   |
| <i>Desc</i>         | (Optional)   |
| <i>Req</i>          | (Optional)   |
| <i>Enable</i>       | (Optional)   |
| <i>Dynamic</i>      | (Optional)   |

### Command Mode

- /exec

# show incompatibility system

```
show incompatibility { system <uri0> | nxos <uri1> } [ __readonly__ { [ TABLE_incompat <Str1> [ <Serv>
] [ <Cap> ] [ <Desc> ] [ <Req> ] [ <Enable> ] [ <Dynamic> ] } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information              |
| incompatibility     | Show incompatible configurations             |
| system              | show incompatibilities with an image         |
| <i>uri0</i>         | Enter image uri                              |
| nxos                | show incompatibilities with an image         |
| <i>uri1</i>         | Enter image uri                              |
| <i>__readonly__</i> | (Optional)                                   |
| TABLE_incompat      | (Optional) Show incompatibility system table |
| <i>Str1</i>         | (Optional)                                   |
| <i>Serv</i>         | (Optional)                                   |
| <i>Cap</i>          | (Optional)                                   |
| <i>Desc</i>         | (Optional)                                   |
| <i>Req</i>          | (Optional)                                   |
| <i>Enable</i>       | (Optional)                                   |
| <i>Dynamic</i>      | (Optional)                                   |

## Command Mode

- /exec



# show install

```
show install { inactive | active [ brief ] | committed } [ __readonly__ { <curr_nxos_image> [ TABLE_smu_list
<install_smu_id> <install_smu_state> ] [ TABLE_package_list <package_id> + ] [ TABLE_base_package_list
<base_package_id> + ] } ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information             |
| install                  | Install related show commands               |
| inactive                 | Inactive packages                           |
| active                   | Active packages                             |
| brief                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| committed                | Committed packages                          |
| __readonly__             | (Optional)                                  |
| <i>curr_nxos_image</i>   | (Optional) NXOS image                       |
| TABLE_smu_list           | (Optional)                                  |
| <i>install_smu_id</i>    | (Optional) install operation smu identifier |
| <i>install_smu_state</i> | (Optional) install operation smu state      |
| TABLE_package_list       | (Optional)                                  |
| <i>package_id</i>        | (Optional) Package name                     |
| TABLE_base_package_list  | (Optional)                                  |
| <i>base_package_id</i>   | (Optional) Base package name                |

## Command Mode

- /exec

## show install all failed-standby

```
show install all failed-standby [ __readonly__ { [ TABLE_installFailStandby <Str1> ] } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                     |
| install                  | Show the software install impact between two images |
| all                      | Show install all information                        |
| failed-standby           | show log from failed standby                        |
| __readonly__             | (Optional)  |
| TABLE_installFailStandby | (Optional) Install failed-standby table             |
| <i>Str1</i>              | (Optional)  |

### Command Mode

- /exec

## show install all failure-reason

```
show install all failure-reason [ __readonly__ { [ TABLE_installFailReason <installFailReasonStr> ] } ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                     |
| install                     | Show the software install impact between two images |
| all                         | show install all information                        |
| failure-reason              | Show failure reason for the last install all        |
| __readonly__                | (Optional)  |
| TABLE_installFailReason     | (Optional) Install failure-reason table             |
| <i>installFailReasonStr</i> | (Optional)  |

### Command Mode

- /exec

# show install all impact

show install all impact [ nxos <uri> ] + [ non-disruptive ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                     |
| install        | Show the software install impact between two images |
| all            | show install all information                        |
| impact         | show impact of the install all command              |
| nxos           | (Optional) boot-variable name                       |
| <i>uri</i>     | (Optional) Enter image uri                          |
| non-disruptive | (Optional) non-disruptive show install              |

## Command Mode

- /exec

# show install all impact epld

```
show install all impact epld <uri> [ __readonly__ [ { TABLE_verinfo <ver_module> <ver_type> <epld_name>
<run_ver> <new_ver> <upg_req> } ] [ { TABLE_compat <module> <type> <upgradable> <impact> <reason>
} ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information             |
| install             | Show the software install status            |
| all                 | show install all information                |
| impact              | show impact of the install all epld command |
| epld                | Show EPLD install information               |
| <i>uri</i>          | Local URI containing EPLD Image             |
| <i>__readonly__</i> | (Optional)                                  |
| TABLE_verinfo       | (Optional)                                  |
| <i>ver_module</i>   | (Optional)                                  |
| <i>ver_type</i>     | (Optional)                                  |
| <i>epld_name</i>    | (Optional)                                  |
| <i>run_ver</i>      | (Optional)                                  |
| <i>new_ver</i>      | (Optional)                                  |
| <i>upg_req</i>      | (Optional)                                  |
| TABLE_compat        | (Optional)                                  |
| <i>module</i>       | (Optional)                                  |
| <i>type</i>         | (Optional)                                  |
| <i>upgradable</i>   | (Optional)                                  |
| <i>impact</i>       | (Optional)                                  |
| <i>reason</i>       | (Optional)                                  |

## Command Mode

- /exec

# show install all progress

show install all progress

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information          |
| install  | Show the software install progress       |
| all      | show install all information             |
| progress | show progress of the current install all |

## Command Mode

- /exec

## show install all status

```
show install all status [ __readonly__ { [ <no_install_status> ] [ TABLE_installstage <rownum> <moduleid>
<starttime> <stage> <stagesstatus> <endtime> ] [ TABLE_installcompatibility <compat_module_id> <bootable>
<impact> <install_type> [ <reason> ] ] [ TABLE_installversion <entryid> <version_module_id> <image>
<running_version> <new_version> <upg_required> ] [ TABLE_installadditionalinfo <add_info> ] } ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                     |
| install                    | Show the software install impact between two images |
| all                        | show install all information                        |
| status                     | show status of the current or last install all      |
| <i>__readonly__</i>        | (Optional)  |
| TABLE_installstage         | (Optional) install preupgrade stage table           |
| TABLE_installcompatibility | (Optional) Compatibility table                      |
| <i>no_install_status</i>   | (Optional) no recent install output                 |
| <i>rownum</i>              | (Optional) row number of this stage in table        |
| <i>moduleid</i>            | (Optional) module id                                |
| <i>starttime</i>           | (Optional) install step start time                  |
| <i>stage</i>               | (Optional) install stage                            |
| <i>stagesstatus</i>        | (Optional) success or failure of stage              |
| <i>endtime</i>             | (Optional) install stage end time                   |
| <i>compat_module_id</i>    | (Optional) compat_module_id                         |
| <i>bootable</i>            | (Optional) module bootable, yes or no               |
| <i>impact</i>              | (Optional) impact, disruptive or nondisruptive      |
| <i>install_type</i>        | (Optional) type of install, reset or none           |
| <i>reason</i>              | (Optional) reason                                   |
| TABLE_installversion       | (Optional) module new version information           |
| <i>entryid</i>             | (Optional)  |
| <i>version_module_id</i>   | (Optional)  |
| <i>image</i>               | (Optional)  |

|                             |                                   |
|-----------------------------|-----------------------------------|
| <i>running_version</i>      | (Optional)                        |
| <i>new_version</i>          | (Optional)                        |
| <i>upg_required</i>         | (Optional)                        |
| TABLE_installadditionalinfo | (Optional) additional info        |
| <i>add_info</i>             | (Optional) additional info string |

**Command Mode**

- /exec



# show install all time-stats

show install all time-stats [ detail | handshake ]

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information   |
| install    | Show the software install impact between two images   |
| all        | show install all information  |
| time-stats | show overall time statistics of the last install all  |
| detail     | (Optional) show detailed time statistics of the last install all                              |
| handshake  | (Optional) show handshake time statistics for sysmgr and lc processes of the last install all |

## Command Mode

- /exec

## show install epld status

```
show install epld status [ __readonly__ [ { TABLE_data <entry_num> [ <header_info> ] <module_num>
<time> [ <epld_install_name> ] [ <reason> ] [ <status> ] [ TABLE_epld [ <epld_name> ] [ <curr_ver> ] [
<old_ver> ] ] } ] ] ]
```

### Syntax Description

|                          |                                       |
|--------------------------|---------------------------------------|
| show                     | Show running system information       |
| install                  | Show the software install status      |
| epld                     | Show EPLD install information         |
| status                   | Show status of previous EPLD upgrades |
| <i>__readonly__</i>      | (Optional)                            |
| <i>TABLE_data</i>        | (Optional)                            |
| <i>entry_num</i>         | (Optional)                            |
| <i>header_info</i>       | (Optional)                            |
| <i>module_num</i>        | (Optional)                            |
| <i>time</i>              | (Optional)                            |
| <i>epld_install_name</i> | (Optional)                            |
| <i>reason</i>            | (Optional)                            |
| <i>status</i>            | (Optional)                            |
| <i>TABLE_epld</i>        | (Optional)                            |
| <i>epld_name</i>         | (Optional)                            |
| <i>curr_ver</i>          | (Optional)                            |
| <i>old_ver</i>           | (Optional)                            |

### Command Mode

- /exec

# show install log

```
show install log { [ <id> | from <id1> ] [ detail ] [ reverse ] [ last ] } [ __readonly__ { current_time <curr_time>
[ TABLE_show_log_output <install_id> <install_log_entry> + ] }
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                              |
| install                  | Install related show commands                                |
| log                      | log  |
| <i>id</i>                | (Optional) Install Identifies                                |
| from                     | (Optional) Starting at this install identifier               |
| <i>id1</i>               | (Optional) Install Identifier                                |
| detail                   | (Optional) Detailed information including impacted processes |
| reverse                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| last                     | (Optional) Display the logs for last install operation       |
| __readonly__             | (Optional)   |
| current_time             | (Optional) current time                                      |
| <i>curr_time</i>         | (Optional) current time                                      |
| TABLE_show_log_output    | (Optional)   |
| <i>install_id</i>        | (Optional) install operation id                              |
| <i>install_log_entry</i> | (Optional) install log entry                                 |

## Command Mode

- /exec

# show install mode

```
show install mode [ __readonly__ { <install_mode> <image_type> } ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| install             | Install related show commands         |
| mode                | Display mode and type of booted image |
| <i>__readonly__</i> | (Optional)                            |
| <i>install_mode</i> | (Optional) install mode               |
| <i>image_type</i>   | (Optional) image type                 |

## Command Mode

- /exec

# show install packages

```
show install packages [ __readonly__ { <curr_nxos_image> [ TABLE_package_list <package_name>
<version> <state> <signature> ] } ]
```

## Syntax Description

|                           |                                 |
|---------------------------|---------------------------------|
| show                      | Show running system information |
| install                   | Install related show commands   |
| packages                  | All packages                    |
| <i>__readonly__</i>       | (Optional)                      |
| <i>curr_nxos_image</i>    | (Optional) NXOS image           |
| <i>TABLE_package_list</i> | (Optional)                      |
| <i>package_name</i>       | (Optional) Package name         |
| <i>version</i>            | (Optional) Package version      |
| <i>state</i>              | (Optional) package state        |
| <i>signature</i>          | (Optional) Signature            |

## Command Mode

- /exec

## show install patches

```
show install patches [ __readonly__ { <curr_nxos_image> [ TABLE_smu_list <install_smu_id>
<install_smu_state> [ TABLE_module_list <install_modno> <install_mod_smu_state> ] ] } ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information             |
| install                      | Install related show commands               |
| patches                      | All Patches                                 |
| <i>__readonly__</i>          | (Optional)                                  |
| <i>TABLE_smu_list</i>        | (Optional)                                  |
| <i>curr_nxos_image</i>       | (Optional) NXOS image                       |
| <i>install_smu_id</i>        | (Optional) install operation smu identifier |
| <i>install_smu_state</i>     | (Optional) install operation smu state      |
| <i>TABLE_module_list</i>     | (Optional)                                  |
| <i>install_modno</i>         | (Optional) install operation module number  |
| <i>install_mod_smu_state</i> | (Optional) install operation module state   |

### Command Mode

- /exec

# show interface

```

show interface <ifid_brief2> [brief] [__readonly__] [ {TABLE_interface_fc [ <interface_vfc> ] [ <vsan_brief>
] [ <oper_port_state> ] [ <port_state> ] [ <bound_interface> ] [ <port_desc> ] [ <port_des> ] [
<mgmt_hw_desc1> ] [ <mgmt_hw_addr1> ] [ <port_name> ] [ <hardware> ] [ <sfp> ] [ <port_wwn> ] [
<peer_port_wwn> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <snmp_trap> ] [ <status> ] [ <state_rsn1>
] [ <fcot_info> ] [ <bind_info> ] [ <bind_mac> ] [ <bind_type> ] [ <port_mode> ] [ <fcid> ] [ <cfg_port_vsan>
] [ <vsan> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <admin_speed> ] [ <port_channel> ] [ <ip_addr1> ] [
<oper_txbbcredit> ] [ <oper_rxbbcredit> ] [ <port_bb_scn> ] [ <admin_rxbufsize> ] [ <admin_port_encap>
] [ <admin_beacon_mode> ] [ <admin_fec_state> ] [ <oper_fec_state> ] [ <bundle_if_index> ] [
<trkd_if_index> ] [ <trk_cfg_vsans> ] [ <trkd_port_state> ] [ <num_ports> ] [ TABLE_trk_intf [ <trk_intf>
] ] [ <info_type_num> ] [ <info_model_num> ] [ <info_manufacturer> ] [ <info_port_id> ] [ <active_vsan>
] [ <trunk_vsan_up> ] [ <trunk_vsan_isolated> ] [ <trunk_vsan_initializing> ] [ <in_bps> ] [ <in_byps> ] [
<in_fps> ] [ <out_bps> ] [ <out_byps> ] [ <out_fps> ] [ <total_in_frames> ] [ <total_in_bytes> ] [
<total_in_discards> ] [ <total_in_errors> ] [ <invalid_crc> ] [ <unknown_class_frames> ] [ <frames_too_long>
] [ <frames_too_short> ] [ <total_out_frames> ] [ <total_out_bytes> ] [ <total_out_discards> ] [
<total_out_errors> ] [ <in_ols> ] [ <in_lrr> ] [ <in_nos> ] [ <in_loop_inits> ] [ <out_ols> ] [ <out_lrr> ] [
<out_nos> ] [ <out_loop_inits> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [
<tx_b2b_low_pri_cre> ] [ <fcoe_in_pkts> ] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ]
] [ TABLE_members [ <port_channel_member> ] ] [ <interface_last_changed> ] [ <time_last_cleared> ] } ] [
{ TABLE_interface_brief_fc [ <interface_fc> ] [ <vsan_brief> ] [ <admin_mode> ] [ <admin_trunk_mode>
] [ <status> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <port_rate_mode> ] [
<oper_speed> ] [ <port_channel> ] [ <ip_addr> ] } ] [ { TABLE_interface_brief_san_pc [ <interface_san> ]
] [ <vsan_brief> ] [ <admin_trunk_mode> ] [ <status> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <ip_addr> ]
} ] ]

```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifid_brief2</i>     | Enter interface type and number in module/slot format |
| brief                  | (Optional) Show brief info of interface               |
| __readonly__           | (Optional) Read Only                                  |
| <i>interface_vfc</i>   | (Optional) Interface index                            |
| TABLE_interface_fc     | (Optional) show interface                             |
| <i>vsan_brief</i>      | (Optional) vsan for brief                             |
| <i>oper_port_state</i> | (Optional) oper port state                            |
| <i>port_state</i>      | (Optional) port state                                 |
| <i>bound_interface</i> | (Optional) bound interface                            |
| <i>port_desc</i>       | (Optional) port description                           |
| <i>port_des</i>        | (Optional) port description                           |

|                         |                                     |
|-------------------------|-------------------------------------|
| <i>mgmt_hw_desc1</i>    | (Optional) HW description           |
| <i>mgmt_hw_addr1</i>    | (Optional) HW address               |
| <i>port_name</i>        | (Optional) port description         |
| <i>hardware</i>         | (Optional) Hardware is              |
| <i>sfp</i>              | (Optional) sfp                      |
| <i>port_wwn</i>         | (Optional) port wwn                 |
| <i>peer_port_wwn</i>    | (Optional) peer port wwn            |
| <i>admin_mode</i>       | (Optional) admin mode               |
| <i>admin_trunk_mode</i> | (Optional) admin trunk mode         |
| <i>snmp_trap</i>        | (Optional) snmp trap                |
| <i>status</i>           | (Optional) Status                   |
| <i>state_rsn1</i>       | (Optional) state reason             |
| <i>fcot_info</i>        | (Optional) fcot info                |
| <i>bind_info</i>        | (Optional) bind interface           |
| <i>bind_mac</i>         | (Optional) bind mac                 |
| <i>bind_type</i>        | (Optional) bind type                |
| <i>port_mode</i>        | (Optional) port mode                |
| <i>fcid</i>             | (Optional) fcid                     |
| <i>cfg_port_vsan</i>    | (Optional) config port vsan         |
| <i>vsan</i>             | (Optional) vsan for brief           |
| <i>port_rate_mode</i>   | (Optional) operation port rate mode |
| <i>oper_speed</i>       | (Optional) speed                    |
| <i>admin_speed</i>      | (Optional) admin speed              |
| <i>port_channel</i>     | (Optional) port channel             |
| <i>ip_addr1</i>         | (Optional) Ip address               |
| <i>oper_txbbcredit</i>  | (Optional) oper tx bbcredit         |
| <i>oper_rxbbcredit</i>  | (Optional) oper rx bbcredit         |
| <i>port_bb_scn</i>      | (Optional) port bb scn              |
| <i>admin_rxbufsize</i>  | (Optional) admin rx bufsize         |



|                                |                                    |
|--------------------------------|------------------------------------|
| <i>admin_port_encap</i>        | (Optional) admin port encap        |
| <i>admin_beacon_mode</i>       | (Optional) admin beacon mode       |
| <i>admin_fec_state</i>         | (Optional) admin fec state         |
| <i>oper_fec_state</i>          | (Optional) oper fec state          |
| <i>bundle_if_index</i>         | (Optional) bundle if index         |
| <i>trkd_if_index</i>           | (Optional) Trunk interfaces        |
| <i>trk_cfg_vsans</i>           | (Optional) Trunk vsans             |
| <i>trkd_port_state</i>         | (Optional) trunk port state        |
| <i>num_ports</i>               | (Optional) number of ports         |
| TABLE_trk_intf                 | (Optional) trunk interfaces        |
| <i>trk_intf</i>                | (Optional) track interface         |
| <i>info_type_num</i>           | (Optional) info type num           |
| <i>info_model_num</i>          | (Optional) info model num          |
| <i>info_manufacturer</i>       | (Optional) info manufacturer       |
| <i>info_port_id</i>            | (Optional) info port id            |
| <i>active_vsan</i>             | (Optional) allowed and active vsan |
| <i>trunk_vsan_up</i>           | (Optional) trunk vsan up           |
| <i>trunk_vsan_isolated</i>     | (Optional) trunk vsan isolated     |
| <i>trunk_vsan_initializing</i> | (Optional) trunk vsan initializing |
| <i>in_bps</i>                  | (Optional) input bits/sec          |
| <i>in_byps</i>                 | (Optional) input bytes/sec         |
| <i>in_fps</i>                  | (Optional) input frames/sec        |
| <i>out_bps</i>                 | (Optional) output bits/sec         |
| <i>out_byps</i>                | (Optional) output bytes/sec        |
| <i>out_fps</i>                 | (Optional) output frames/sec       |
| <i>total_in_frames</i>         | (Optional) total in frames         |
| <i>total_in_bytes</i>          | (Optional) total in bytes          |
| <i>total_in_discards</i>       | (Optional) total in discards       |
| <i>total_in_errors</i>         | (Optional) total in errors         |

|                               |  |
|-------------------------------|--|
| <i>invalid_crc</i>            | (Optional) invalid crc                             |
| <i>unknown_class_frames</i>   | (Optional) unknown class frames                    |
| <i>frames_too_long</i>        | (Optional) frames too long                         |
| <i>frames_too_short</i>       | (Optional) frames too short                        |
| <i>total_out_frames</i>       | (Optional) total out frames                        |
| <i>total_out_bytes</i>        | (Optional) total out bytes                         |
| <i>total_out_discards</i>     | (Optional) total out discards                      |
| <i>total_out_errors</i>       | (Optional) total out errors                        |
| <i>in_ols</i>                 | (Optional) input OLS                               |
| <i>in_lrr</i>                 | (Optional) input LRR                               |
| <i>in_nos</i>                 | (Optional) input NOS                               |
| <i>in_loop_inits</i>          | (Optional) input loop inits                        |
| <i>out_ols</i>                | (Optional) output OLS                              |
| <i>out_lrr</i>                | (Optional) output LRR                              |
| <i>out_nos</i>                | (Optional) output NOS                              |
| <i>out_loop_inits</i>         | (Optional) output loop inits                       |
| <i>rx_b2b_perf_buff</i>       | (Optional) rx b2b performance buff                 |
| <i>rx_b2b_credit</i>          | (Optional) rx b2b credit                           |
| <i>tx_b2b_credit</i>          | (Optional) tx b2b credit                           |
| <i>tx_b2b_low_pri_cre</i>     | (Optional) tx b2b low pri credit                   |
| <i>fcoe_in_pkts</i>           | (Optional) fcoe in pkts                            |
| <i>fcoe_in_octets</i>         | (Optional) fcoe in octets                          |
| <i>fcoe_out_pkts</i>          | (Optional) fcoe out pkts                           |
| <i>fcoe_out_octets</i>        | (Optional) fcoe out octets                         |
| TABLE_members                 | (Optional) table for port-channel member interface |
| <i>port_channel_member</i>    | (Optional) port-channel member interface           |
| <i>interface_last_changed</i> | (Optional) interface last changed                  |
| <i>time_last_cleared</i>      | (Optional) counters last cleared                   |
| TABLE_interface_brief_fc      | (Optional) show interface brief table              |

|                              |  |
|------------------------------|--|
| <i>interface_fc</i>          | (Optional) Interface index                 |
| <i>ip_addr</i>               | (Optional) IP address                      |
| <i>vsan_brief</i>            | (Optional) vsan brief                      |
| <i>admin_mode</i>            | (Optional) admin mode                      |
| <i>admin_trunk_mode</i>      | (Optional) admin trunk mode                |
| <i>status</i>                | (Optional) status                          |
| <i>fcot_info</i>             | (Optional) fcot info                       |
| <i>bind_info</i>             | (Optional) bind interface                  |
| <i>bind_type</i>             | (Optional) bind type                       |
| <i>bind_mac</i>              | (Optional) bind mac address                |
| <i>port_rate_mode</i>        | (Optional) rate mode                       |
| <i>oper_speed</i>            | (Optional) speed                           |
| <i>port_channel</i>          | (Optional) port channel number             |
| TABLE_interface_brief_san_pc | (Optional) show interface brief for san-po |
| <i>interface_san</i>         | (Optional) san_po interface                |
| <i>vsan_brief</i>            | (Optional) vsan brief                      |
| <i>admin_trunk_mode</i>      | (Optional) admin trunk mode                |
| <i>status</i>                | (Optional) status                          |
| <i>port_rate_mode</i>        | (Optional) rate mode                       |
| <i>oper_speed</i>            | (Optional) speed                           |
| <i>ip_addr</i>               | (Optional) IP address                      |

**Command Mode**

- /exec

## show interface

```
show interface <ifid_brief1> [ brief ] [ __readonly__ ] [ { TABLE_interface_vfc [ <interface_vfc> ] [
<vsan_brief> ] [ <oper_port_state> ] [ <port_state> ] [ <bound_interface> ] [ <port_desc> ] [ <port_des> ] [
<mgmt_hw_desc1> ] [ <mgmt_hw_addr1> ] [ <port_name> ] [ <hardware> ] [ <sfp> ] [ <port_wn> ] [
<peer_port_wn> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <snmp_trap> ] [ <status> ] [ <state_rsn1>
] [ <fcot_info> ] [ <bind_info> ] [ <bind_mac> ] [ <bind_type> ] [ <port_mode> ] [ <fcid> ] [ <cfg_port_vsan>
] [ <vsan> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <admin_speed> ] [ <port_channel> ] [ <ip_addr1> ] [
<oper_txbbcredit> ] [ <oper_rxbbcredit> ] [ <port_bb_scn> ] [ <admin_rxbufsize> ] [ <admin_port_encap>
] [ <admin_beacon_mode> ] [ <admin_fec_state> ] [ <oper_fec_state> ] [ <bundle_if_index> ] [
<trkd_if_index> ] [ <trk_cfg_vsans> ] [ <trkd_port_state> ] [ <num_ports> ] [ TABLE_trk_intf [ <trk_intf>
] ] [ <info_type_num> ] [ <info_model_num> ] [ <info_manufacturer> ] [ <info_port_id> ] [ <active_vsan>
] [ <trunk_vsan_up> ] [ <trunk_vsan_isolated> ] [ <trunk_vsan_initializing> ] [ <in_bps> ] [ <in_byps> ] [
<in_fps> ] [ <out_bps> ] [ <out_byps> ] [ <out_fps> ] [ <total_in_frames> ] [ <total_in_bytes> ] [
<total_in_discards> ] [ <total_in_errors> ] [ <invalid_crc> ] [ <unknown_class_frames> ] [ <frames_too_long>
] [ <frames_too_short> ] [ <total_out_frames> ] [ <total_out_bytes> ] [ <total_out_discards> ] [
<total_out_errors> ] [ <in_ols> ] [ <in_lrr> ] [ <in_nos> ] [ <in_loop_inits> ] [ <out_ols> ] [ <out_lrr> ] [
<out_nos> ] [ <out_loop_inits> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [
<tx_b2b_low_pri_cre> ] [ <fcoe_in_pkts> ] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ]
] [ TABLE_members [ <port_channel_member> ] ] [ <interface_last_changed> ] [ <time_last_cleared> ] } ] [
{ TABLE_interface_brief_vfc [ <interface_vfc> ] [ <vsan_brief> ] [ <admin_mode> ] [ <admin_trunk_mode>
] [ <status> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <port_rate_mode> ] [
<oper_speed> ] [ <port_channel> ] [ <ip_addr> ] } ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifid_brief1</i>     | Enter interface type and number in module/slot format |
| brief                  | (Optional) Show brief info of interface               |
| __readonly__           | (Optional) Read Only                                  |
| <i>interface_vfc</i>   | (Optional) Interface index                            |
| TABLE_interface_vfc    | (Optional) show interface                             |
| <i>vsan_brief</i>      | (Optional) vsan for brief                             |
| <i>oper_port_state</i> | (Optional) oper port state                            |
| <i>port_state</i>      | (Optional) port state                                 |
| <i>bound_interface</i> | (Optional) bound interface                            |
| <i>port_desc</i>       | (Optional) port description                           |
| <i>port_des</i>        | (Optional) port description                           |
| <i>mgmt_hw_desc1</i>   | (Optional) HW description                             |

|                         |                                     |
|-------------------------|-------------------------------------|
| <i>mgmt_hw_addr1</i>    | (Optional) HW address               |
| <i>port_name</i>        | (Optional) port description         |
| <i>hardware</i>         | (Optional) Hardware is              |
| <i>sfp</i>              | (Optional) sfp                      |
| <i>port_wwn</i>         | (Optional) port wwn                 |
| <i>peer_port_wwn</i>    | (Optional) peer port wwn            |
| <i>admin_mode</i>       | (Optional) admin mode               |
| <i>admin_trunk_mode</i> | (Optional) admin trunk mode         |
| <i>snmp_trap</i>        | (Optional) snmp trap                |
| <i>status</i>           | (Optional) Status                   |
| <i>state_rsn1</i>       | (Optional) state reason             |
| <i>fcot_info</i>        | (Optional) fcot info                |
| <i>bind_info</i>        | (Optional) bind interface           |
| <i>bind_mac</i>         | (Optional) bind mac                 |
| <i>bind_type</i>        | (Optional) bind type                |
| <i>port_mode</i>        | (Optional) port mode                |
| <i>fcid</i>             | (Optional) fcid                     |
| <i>cfg_port_vsan</i>    | (Optional) config port vsan         |
| <i>vsan</i>             | (Optional) vsan for brief           |
| <i>port_rate_mode</i>   | (Optional) operation port rate mode |
| <i>oper_speed</i>       | (Optional) speed                    |
| <i>admin_speed</i>      | (Optional) admin speed              |
| <i>port_channel</i>     | (Optional) port channel             |
| <i>ip_addr1</i>         | (Optional) Ip address               |
| <i>oper_txbbcredit</i>  | (Optional) oper tx bbcredit         |
| <i>oper_rxbbcredit</i>  | (Optional) oper rx bbcredit         |
| <i>port_bb_scn</i>      | (Optional) port bb scn              |
| <i>admin_rxbufsize</i>  | (Optional) admin rx bufsize         |
| <i>admin_port_encap</i> | (Optional) admin port encap         |

|                                |                                    |
|--------------------------------|------------------------------------|
| <i>admin_beacon_mode</i>       | (Optional) admin beacon mode       |
| <i>admin_fec_state</i>         | (Optional) admin fec state         |
| <i>oper_fec_state</i>          | (Optional) oper fec state          |
| <i>bundle_if_index</i>         | (Optional) bundle if index         |
| <i>trkd_if_index</i>           | (Optional) Trunk interfaces        |
| <i>trk_cfg_vsans</i>           | (Optional) Trunk vsans             |
| <i>trkd_port_state</i>         | (Optional) trunk port state        |
| <i>num_ports</i>               | (Optional) number of ports         |
| TABLE_trk_intf                 | (Optional) trunk interfaces        |
| <i>trk_intf</i>                | (Optional) track interface         |
| <i>info_type_num</i>           | (Optional) info type num           |
| <i>info_model_num</i>          | (Optional) info model num          |
| <i>info_manufacturer</i>       | (Optional) info manufacturer       |
| <i>info_port_id</i>            | (Optional) info port id            |
| <i>active_vsan</i>             | (Optional) allowed and active vsan |
| <i>trunk_vsan_up</i>           | (Optional) trunk vsan up           |
| <i>trunk_vsan_isolated</i>     | (Optional) trunk vsan isolated     |
| <i>trunk_vsan_initializing</i> | (Optional) trunk vsan initializing |
| <i>in_bps</i>                  | (Optional) input bits/sec          |
| <i>in_byps</i>                 | (Optional) input bytes/sec         |
| <i>in_fps</i>                  | (Optional) input frames/sec        |
| <i>out_bps</i>                 | (Optional) output bits/sec         |
| <i>out_byps</i>                | (Optional) output bytes/sec        |
| <i>out_fps</i>                 | (Optional) output frames/sec       |
| <i>total_in_frames</i>         | (Optional) total in frames         |
| <i>total_in_bytes</i>          | (Optional) total in bytes          |
| <i>total_in_discards</i>       | (Optional) total in discards       |
| <i>total_in_errors</i>         | (Optional) total in errors         |
| <i>invalid_crc</i>             | (Optional) invalid crc             |

|                               |  |
|-------------------------------|--|
| <i>unknown_class_frames</i>   | (Optional) unknown class frames                    |
| <i>frames_too_long</i>        | (Optional) frames too long                         |
| <i>frames_too_short</i>       | (Optional) frames too short                        |
| <i>total_out_frames</i>       | (Optional) total out frames                        |
| <i>total_out_bytes</i>        | (Optional) total out bytes                         |
| <i>total_out_discards</i>     | (Optional) total out discards                      |
| <i>total_out_errors</i>       | (Optional) total out errors                        |
| <i>in_ols</i>                 | (Optional) input OLS                               |
| <i>in_lrr</i>                 | (Optional) input LRR                               |
| <i>in_nos</i>                 | (Optional) input NOS                               |
| <i>in_loop_inits</i>          | (Optional) input loop inits                        |
| <i>out_ols</i>                | (Optional) output OLS                              |
| <i>out_lrr</i>                | (Optional) ouput LRR                               |
| <i>out_nos</i>                | (Optional) output NOS                              |
| <i>out_loop_inits</i>         | (Optional) output loop inits                       |
| <i>rx_b2b_perf_buff</i>       | (Optional) rx b2b performance buff                 |
| <i>rx_b2b_credit</i>          | (Optional) rx b2b credit                           |
| <i>tx_b2b_credit</i>          | (Optional) tx b2b credit                           |
| <i>tx_b2b_low_pri_cre</i>     | (Optional) tx b2b low pri credit                   |
| <i>fcoe_in_pkts</i>           | (Optional) fcoe in pkts                            |
| <i>fcoe_in_octets</i>         | (Optional) fcoe in octets                          |
| <i>fcoe_out_pkts</i>          | (Optional) fcoe out pkts                           |
| <i>fcoe_out_octets</i>        | (Optional) fcoe out octets                         |
| TABLE_members                 | (Optional) table for port-channel member interface |
| <i>port_channel_member</i>    | (Optional) port-channel member interface           |
| <i>interface_last_changed</i> | (Optional) interface last changed                  |
| <i>time_last_cleared</i>      | (Optional) counters last cleared                   |
| TABLE_interface_brief_vfc     | (Optional) show interface brief table              |
| <i>interface_vfc</i>          | (Optional) Interface index                         |

|                         |                                |
|-------------------------|--------------------------------|
| <i>vsan_brief</i>       | (Optional) vsan brief          |
| <i>admin_mode</i>       | (Optional) admin mode          |
| <i>admin_trunk_mode</i> | (Optional) admin trunk mode    |
| <i>status</i>           | (Optional) status              |
| <i>fcot_info</i>        | (Optional) fcot info           |
| <i>bind_info</i>        | (Optional) bind interface      |
| <i>bind_type</i>        | (Optional) bind type           |
| <i>bind_mac</i>         | (Optional) bind mac address    |
| <i>port_rate_mode</i>   | (Optional) rate mode           |
| <i>oper_speed</i>       | (Optional) speed               |
| <i>port_channel</i>     | (Optional) port channel number |
| <i>ip_addr</i>          | (Optional) IP address          |

**Command Mode**

- /exec



## show interface

```

show interface <ifid> [ quick ] [ __readonly__ TABLE interface <interface> [ <desc> ] [ [ <svi_if_index> ]
[ <svi_admin_state> ] [ <oper_state> ] [ <svi_rsn_desc> ] [ <svi_line_proto> ] [ <svi_hw> ] [ <svi_mac> ] [
<svi_desc> ] [ <svi_ip_addr> ] [ <svi_ip_mask> ] [ <svi_mtu> ] [ <svi_bw> ] [ <svi_delay> ] [ <vlan_id> ]
[ <type> ] ] [ [ <svi_tx_load> ] [ <svi_rx_load> ] ] [ [ <svi_carrier_delay_sec> ] [ <svi_carrier_delay_msec>
] [ <svi_arp_type> ] [ <svi_arp_timeout> ] ] [ [ <svi_time_last_cleared> ] ] [ { [ TABLE_sec_vlan ] [
<sec_vlan> ] [ <sec_vlan_type> ] } ] [ [ <eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts>
] [ <eth_load_interval1_tx> ] [ <eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits>
] [ <eth_inrate1_summary_pkts> ] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [
<eth_load_interval2_rx> ] [ <eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [
<eth_outrate2_bits> ] [ <eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts>
] [ <eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes>
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes>
] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_l3avg2_inbytes> ] [ <eth_l3avg2_inpkts> ] [ <eth_l3avg2_outbytes> ] [ <eth_l3avg2_outpkts> ] [
<eth_l3avg3_inbytes> ] [ <eth_l3avg3_inpkts> ] [ <eth_l3avg3_outbytes> ] [ <eth_l3avg3_outpkts> ] [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_nobuf> ] [ <eth_inbcast> ] [ <eth_inmcast> ] [ <eth_inucast> ] [
<eth_ingiants> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [ <eth_insw_switched> ] [ <eth_runts> ] [
<eth_storm_supp> ] [ <eth_throtles> ] [ <eth_inerr> ] [ <eth_crc> ] [ <eth_ecc> ] [ <eth_frame> ] [
<eth_overrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_outbcast> ] [ <eth_outmcast> ] [ <eth_outucast>
] [ <eth_outgiants> ] [ <eth_inpause> ] [ <eth_dribble> ] [ <eth_in_ifdown_drops> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_underrun> ] [ <eth_outhw_switched> ] [
<eth_outsw_switched> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_resets> ] [ <eth_babbles> ] [ <eth_latecoll> ]
[ <eth_deferred> ] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_outpause> ] [ <eth_buffail> ] [
<eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_single_coll> ] [ <eth_multi_coll>
] [ <eth_excess_coll> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [
<eth_outcrc> ] [ <eth_symbol> ] [ <eth_out_drops> ] [ <eth_sqetest> ] [ <eth_inb64> ] [ <eth_inb65_127>
] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [ <eth_inb1024_1518> ] [
<eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outb64> ] [ <eth_outb65_127> ] [ <eth_outb128_255> ] [
<eth_outb256_511> ] [ <eth_outb512_1023> ] [ <eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [
<eth_outtrunk> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_fcoe_in_pkts> ] [ <eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [
<eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [ <eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [
<eth_nfcoe_out_octets> ] [ <eth_eee_atx_lpi_msec> ] [ <eth_eee_arcv_lpi_msec> ] [
<eth_eee_atx_lpi_transitions> ] [ <eth_eee_arcv_lpi_transitions> ] [ <eth_phy_ber_count> ] [
<eth_phy_errblks_count> ] [ <eth_tx_frm_error> ] [ <eth_rx_toolong> ] [ <eth_rx_undersize> ] [
<eth_rx_fragment> ] [ <eth_rx_crcerr_not_stomped> ] [ <eth_rx_crcerr_stomped> ] [ <eth_rx_inrangeerr>
] ] [ [ <svi_routed_pkts_in> ] [ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out> ] [ <svi_routed_bytes_out>
] [ <svi_ucast_pkts_in> ] [ <svi_ucast_bytes_in> ] [ <svi_mcast_pkts_in> ] [ <svi_mcast_bytes_in> ] [
<svi_ucast_pkts_out> ] [ <svi_ucast_bytes_out> ] [ <svi_mcast_pkts_out> ] [ <svi_mcast_bytes_out> ] [
<svi_ipv4_ucast_pkts_in> ] [ <svi_ipv4_ucast_bytes_in> ] [ <svi_ipv4_ucast_pkts_out> ] [

```

```
<svi_ipv4_ucast_bytes_out> ][ <svi_ipv4_mcast_pkts_in> ][ <svi_ipv4_mcast_bytes_in> ][
<svi_ipv4_mcast_pkts_out> ][ <svi_ipv4_mcast_bytes_out> ][ <svi_ipv6_ucast_pkts_in> ][
<svi_ipv6_ucast_bytes_in> ][ <svi_ipv6_ucast_pkts_out> ][ <svi_ipv6_ucast_bytes_out> ][
<svi_ipv6_mcast_pkts_in> ][ <svi_ipv6_mcast_bytes_in> ][ <svi_ipv6_mcast_pkts_out> ][
<svi_ipv6_mcast_bytes_out> ][ <svi_average_input_bits> ][ <svi_average_input_packets> ][
<svi_average_output_bits> ][ <svi_average_output_packets> ][ <svi_rate_in_mins> ]][ [ <svi_reliability>
] ][ <switchport> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifid</i>            | Enter interface type and number in module/slot format |
| quick                  | (Optional) Show info of interface skipping stats      |
| __readonly__           | (Optional) Read Only                                  |
| TABLE_interface        | (Optional) show interface                             |
| <i>interface</i>       | (Optional) Interface index                            |
| <i>desc</i>            | (Optional) Interface description                      |
| <i>svi_if_index</i>    | (Optional) Interface                                  |
| <i>svi_admin_state</i> | (Optional)  |
| <i>oper_state</i>      | (Optional)  |
| <i>svi_rsn_desc</i>    | (Optional) Interface state reason detailed            |
| <i>svi_line_proto</i>  | (Optional)  |
| <i>svi_hw</i>          | (Optional) Hardware                                   |
| <i>svi_mac</i>         | (Optional) Address                                    |
| <i>svi_desc</i>        | (Optional) Interface Description                      |
| <i>svi_ip_addr</i>     | (Optional) IP Address                                 |
| <i>svi_ip_mask</i>     | (Optional) IP address mask                            |
| <i>svi_mtu</i>         | (Optional) MTU size in bytes                          |
| <i>svi_bw</i>          | (Optional) Bandwidth in kilobits                      |
| <i>svi_delay</i>       | (Optional) Throughput delay (tens of microseconds)    |
| <i>vlan_id</i>         | (Optional) Vlan                                       |
| <i>type</i>            | (Optional) type                                       |
| <i>svi_tx_load</i>     | (Optional) Tx Load                                    |

|                                  |   |
|----------------------------------|---|
| <i>svi_rx_load</i>               | (Optional) Rx Load                              |
| <i>svi_carrier_delay_sec</i>     | (Optional) carrier delay value in seconds       |
| <i>svi_carrier_delay_msec</i>    | (Optional) carrier delay value in milli-seconds |
| <i>svi_arp_type</i>              | (Optional) ARP type                             |
| <i>svi_arp_timeout</i>           | (Optional) ARP timeout value                    |
| <i>svi_time_last_cleared</i>     | (Optional) Time last cleared                    |
| TABLE_sec_vlan                   | (Optional) secondary vlans                      |
| <i>sec_vlan</i>                  | (Optional) vlan id                              |
| <i>sec_vlan_type</i>             | (Optional) secondary vlan type                  |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec        |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec       |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec       |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec        |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec      |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec      |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary    |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary    |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary   |
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary   |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec        |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec       |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec       |
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec        |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec      |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec      |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary    |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary    |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary   |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary   |

|                                  |   |
|----------------------------------|---|
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec    |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary  |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary  |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary |
| <i>eth_l2_ucastpkts</i>          | (Optional) L2 switched ucast pkts             |
| <i>eth_l2_ucastbytes</i>         | (Optional) L2 switched ucast bytes            |
| <i>eth_l2_mcastpkts</i>          | (Optional) L2 switched mcast pkts             |
| <i>eth_l2_mcastbytes</i>         | (Optional) L2 switched mcast bytes            |
| <i>eth_l2_bcastpkts</i>          | (Optional) L2 switched bcast pkts             |
| <i>eth_l2_bcastbytes</i>         | (Optional) L2 switched bcast bytes            |
| <i>eth_l3in_ucastpkts</i>        | (Optional) IPv4 L3 in switched ucast pkts     |
| <i>eth_l3in_ucastbytes</i>       | (Optional) IPv4 L3 in switched ucast bytes    |
| <i>eth_l3in_mcastpkts</i>        | (Optional) IPv4 L3 in switched mcast pkts     |
| <i>eth_l3in_mcastbytes</i>       | (Optional) IPv4 L3 in switched mcast bytes    |
| <i>eth_l3in_bcastpkts</i>        | (Optional) L3 in switched bcast pkts          |
| <i>eth_l3in_bcastbytes</i>       | (Optional) L3 in switched bcast bytes         |
| <i>eth_l3out_ucastpkts</i>       | (Optional) IPv4 L3 out switched ucast pkts    |
| <i>eth_l3out_ucastbytes</i>      | (Optional) IPv4 L3 out switched ucast bytes   |
| <i>eth_l3out_mcastpkts</i>       | (Optional) IPv4 L3 out switched mcast pkts    |
| <i>eth_l3out_mcastbytes</i>      | (Optional) IPv4 L3 out switched mcast bytes   |
| <i>eth_l3out_bcastpkts</i>       | (Optional) L3 out switched bcast pkts         |
| <i>eth_l3out_bcastbytes</i>      | (Optional) L3 out switched bcast bytes        |
| <i>eth_l3in_routed_pkts</i>      | (Optional) L3 in routed pkts                  |

|                               |  |
|-------------------------------|--|
| <i>eth_l3in_routed_bytes</i>  | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>  | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i> | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>     | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>      | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>    | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>     | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_l3avg2_inbytes</i>     | (Optional) Load interval 2 L3 average in switched bytes  |
| <i>eth_l3avg2_inpkts</i>      | (Optional) Load interval 2 L3 average in switched pkts   |
| <i>eth_l3avg2_outbytes</i>    | (Optional) Load interval 2 L3 average out switched bytes |
| <i>eth_l3avg2_outpkts</i>     | (Optional) Load interval 2 L3 average out switched pkts  |
| <i>eth_l3avg3_inbytes</i>     | (Optional) Load interval 3 L3 average in switched bytes  |
| <i>eth_l3avg3_inpkts</i>      | (Optional) Load interval 3 L3 average in switched pkts   |
| <i>eth_l3avg3_outbytes</i>    | (Optional) Load interval 3 L3 average out switched bytes |
| <i>eth_l3avg3_outpkts</i>     | (Optional) Load interval 3 L3 average out switched pkts  |
| <i>eth_inpkts</i>             | (Optional) Packets input                                 |
| <i>eth_inbytes</i>            | (Optional) Bytes input                                   |
| <i>eth_nobuf</i>              | (Optional) No buffer received                            |
| <i>eth_inbcast</i>            | (Optional) Broadcasts                                    |
| <i>eth_inmcast</i>            | (Optional) Multicasts                                    |
| <i>eth_inucast</i>            | (Optional) Unicasts                                      |
| <i>eth_ingiants</i>           | (Optional) giants  |
| <i>eth_ipmcast</i>            | (Optional) IP multicast                                  |
| <i>eth_inhw_switched</i>      | (Optional) Input H/W Switched                            |
| <i>eth_insw_switched</i>      | (Optional) Input S/W Switched                            |
| <i>eth_runts</i>              | (Optional) runts   |
| <i>eth_storm_supp</i>         | (Optional) storm suppression                             |
| <i>eth_throtles</i>           | (Optional) throttles                                     |
| <i>eth_inerr</i>              | (Optional) input errors                                  |

|                            |   |
|----------------------------|---|
| <i>eth_crc</i>             | (Optional) CRC                                  |
| <i>eth_ecc</i>             | (Optional) ECC                                  |
| <i>eth_frame</i>           | (Optional) frame                                |
| <i>eth_overrun</i>         | (Optional) overrun                              |
| <i>eth_ignored</i>         | (Optional) ignored                              |
| <i>eth_watchdog</i>        | (Optional) watchdog                             |
| <i>eth_outbcast</i>        | (Optional) Broadcasts                           |
| <i>eth_outmcast</i>        | (Optional) Multicasts                           |
| <i>eth_outucast</i>        | (Optional) Unicasts                             |
| <i>eth_outgiants</i>       | (Optional) giants                               |
| <i>eth_inpause</i>         | (Optional) pause input                          |
| <i>eth_dribble</i>         | (Optional) input packets with dribble condition |
| <i>eth_in_ifdown_drops</i> | (Optional) Input if-down drops                  |
| <i>eth_bad_eth</i>         | (Optional) bad ether type drop                  |
| <i>eth_bad_proto</i>       | (Optional) bad protocol drops                   |
| <i>eth_outpkts</i>         | (Optional) packets output                       |
| <i>eth_outbytes</i>        | (Optional) bytes output                         |
| <i>eth_underrun</i>        | (Optional) underruns                            |
| <i>eth_outhw_switched</i>  | (Optional) Out H/W Switched                     |
| <i>eth_outsw_switched</i>  | (Optional) Out S/W Switched                     |
| <i>eth_outerr</i>          | (Optional) output errors                        |
| <i>eth_coll</i>            | (Optional) collisions                           |
| <i>eth_resets</i>          | (Optional) interface resets                     |
| <i>eth_babbles</i>         | (Optional) babbles                              |
| <i>eth_latecoll</i>        | (Optional) late collision                       |
| <i>eth_deferred</i>        | (Optional) deferred                             |
| <i>eth_lostcarrier</i>     | (Optional) lost carrier                         |
| <i>eth_nocarrier</i>       | (Optional) no carrier                           |
| <i>eth_outpause</i>        | (Optional) PAUSE output                         |

|                             |  |
|-----------------------------|--|
| <i>eth_buffail</i>          | (Optional) output buffer failures                  |
| <i>eth_bufswapped</i>       | (Optional) output buffers swapped out              |
| <i>eth_arpdrops</i>         | (Optional) arp drops                               |
| <i>eth_out_ifdown_drops</i> | (Optional) Output if-down drops                    |
| <i>eth_single_coll</i>      | (Optional) single collisions                       |
| <i>eth_multi_coll</i>       | (Optional) multi collisions                        |
| <i>eth_excess_coll</i>      | (Optional) excessive collisions                    |
| <i>eth_jabbers</i>          | (Optional) jabbers                                 |
| <i>eth_shortframe</i>       | (Optional) short frames                            |
| <i>eth_indiscard</i>        | (Optional) discards                                |
| <i>eth_bad_encap</i>        | (Optional) bad encapsulation                       |
| <i>eth_outcrc</i>           | (Optional) Output CRC                              |
| <i>eth_symbol</i>           | (Optional) symbol errors                           |
| <i>eth_out_drops</i>        | (Optional) output drops                            |
| <i>eth_sqetest</i>          | (Optional) SQE test                                |
| <i>eth_inb64</i>            | (Optional) input pkts between 0 and 64 bytes       |
| <i>eth_inb65_127</i>        | (Optional) input pkts between 65 and 127 bytes     |
| <i>eth_inb128_255</i>       | (Optional) input pkts between 128 and 255 bytes    |
| <i>eth_inb256_511</i>       | (Optional) input pkts between 256 and 511 bytes    |
| <i>eth_inb512_1023</i>      | (Optional) input pkts between 512 and 1023 bytes   |
| <i>eth_inb1024_1518</i>     | (Optional) input pkts between 1024 and 1518 bytes  |
| <i>eth_inb1519_1548</i>     | (Optional) input pkts between 1519 and 1548 bytes  |
| <i>eth_intrunk</i>          | (Optional) input trunk pkts                        |
| <i>eth_outb64</i>           | (Optional) output pkts between 0 and 64 bytes      |
| <i>eth_outb65_127</i>       | (Optional) output pkts between 65 and 127 bytes    |
| <i>eth_outb128_255</i>      | (Optional) output pkts between 128 and 255 bytes   |
| <i>eth_outb256_511</i>      | (Optional) output pkts between 256 and 511 bytes   |
| <i>eth_outb512_1023</i>     | (Optional) output pkts between 512 and 1023 bytes  |
| <i>eth_outb1024_1518</i>    | (Optional) output pkts between 1024 and 1518 bytes |

|                                     |  |
|-------------------------------------|--|
| <i>eth_outb1519_1548</i>            | (Optional) output pkts between 1519 and 1548 bytes |
| <i>eth_outtrunk</i>                 | (Optional) output trunk pkts                       |
| <i>eth_bpdu_outlost</i>             | (Optional) BPDU output lost                        |
| <i>eth_cos0_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos1_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos2_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos3_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos4_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos5_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos6_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos7_outlost</i>             | (Optional) output pkts                             |
| <i>eth_fcoe_in_pkts</i>             | (Optional) fcoe in pkts                            |
| <i>eth_fcoe_in_octets</i>           | (Optional) fcoe in octets                          |
| <i>eth_fcoe_out_pkts</i>            | (Optional) fcoe out pkts                           |
| <i>eth_fcoe_out_octets</i>          | (Optional) fcoe out octets                         |
| <i>eth_nfcoe_in_pkts</i>            | (Optional) nfcoe in pkts                           |
| <i>eth_nfcoe_in_octets</i>          | (Optional) nfcoe in octets                         |
| <i>eth_nfcoe_out_pkts</i>           | (Optional) nfcoe out pkts                          |
| <i>eth_nfcoe_out_octets</i>         | (Optional) nfcoe out octets                        |
| <i>eth_eee_atx_lpi_msec</i>         | (Optional) Tx Lpi usec                             |
| <i>eth_eee_arcv_lpi_msec</i>        | (Optional) Rx Lpi usec                             |
| <i>eth_eee_atx_lpi_transitions</i>  | (Optional) Tx Lpi requests                         |
| <i>eth_eee_arcv_lpi_transitions</i> | (Optional) Rx Lpi indications                      |
| <i>eth_phy_ber_count</i>            | (Optional) Bit error rate counter                  |
| <i>eth_phy_errblks_count</i>        | (Optional) Errored blocks counter                  |
| <i>eth_tx_frm_error</i>             | (Optional) tx frame error                          |
| <i>eth_rx_toolong</i>               | (Optional) rx toolong error                        |
| <i>eth_rx_undersize</i>             | (Optional) rx undersize                            |
| <i>eth_rx_fragment</i>              | (Optional) rx fragment                             |



|                                  |                                  |
|----------------------------------|----------------------------------|
| <i>eth_rx_crcerr_not_stomped</i> | (Optional) rx crcerr not stomped |
| <i>eth_rx_crcerr_stomped</i>     | (Optional) rx crcerr stomped     |
| <i>eth_rx_inrangeerr</i>         | (Optional) rx inrange error      |
| <i>svi_reliability</i>           | (Optional) Reliability           |
| <i>switchport</i>                | (Optional) Switchport enabled    |

**Command Mode**

- /exec

## show interface

```
show interface <ifmgmt> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ] [
<state_rsn> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [ <admin_state> ] [ <share_state> ] [ <eth_bundle> ] [
<eth_dce_mode> ] [ <vpc_status> ] [ <eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [
<eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix> ] [ <eth_mtu> ] [ <eth_bw> ] [ <eth_encap_vlan> ] [
<eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [ <eth_rxload> ] [ <encapsulation> ] [ <medium> ] [
<eth_loopback> ] [ <eth_keepalive> ] [ <eth_duplex> ] [ <eth_speed> ] [ <eth_mode> ] [ <eth_ratemode> ] [
<eth_autoneg> ] [ <eth_beacon> ] [ <eth_media> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [
<eth_sw_t_monitor> ] [ <eth_ethertype> ] [ <eth_members> ] [ <eth_clk_mode> ] [ <eth_arp_type> ] [
<eth_arp_timeout> ] [ <eth_last_in> ] [ <eth_last_out> ] [ <eth_out_hang> ] [ <eth_clear_counters> ] [
<eth_link_flapped> ] [ <eth_inq_size> ] [ <eth_inq_max> ] [ <eth_inq_drops> ] [ <eth_inq_flush> ] [
<eth_out_drop> ] [ <eth_q_strategy> ] [ <eth_outq_size> ] [ <eth_outq_max> ] [ <eth_reset_cntr> ] [
<mgmt_hw_desc> ] [ <mgmt_hw_addr> ] [ <mgmt_ip_addr> ] [ <mgmt_ip_mask> ] [ <mgmt_mtu> ] [
<mgmt_speed> ] [ <mgmt_duplex> ] [ <vdc_lvl_in_avg_bits> ] [ <vdc_lvl_in_avg_pkts> ] [
<vdc_lvl_out_avg_bits> ] [ <vdc_lvl_out_avg_pkts> ] [ <vdc_lvl_in_pkts> ] [ <vdc_lvl_in_ucast> ] [
<vdc_lvl_in_mcast> ] [ <vdc_lvl_in_bcast> ] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [
<vdc_lvl_out_pkts> ] [ <vdc_lvl_out_ucast> ] [ <vdc_lvl_out_mcast> ] [ <vdc_lvl_out_bcast> ] [
<vdc_lvl_out_bytes> ] [ <vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifmgmt</i>          | Enter interface type and number in module/slot format |
| <u>__readonly__</u>    | (Optional) Read Only                                  |
| <u>TABLE_interface</u> | (Optional) show interface                             |
| <i>interface</i>       | (Optional) Interface index                            |
| <i>state</i>           | (Optional) Interface state                            |
| <i>state_rsn_desc</i>  | (Optional) Interface state reason detailed            |
| <i>state_rsn</i>       | (Optional) Interface state reason                     |
| <i>eth_rsn_fac</i>     | (Optional) State reason facility                      |
| <i>eth_rsn_code</i>    | (Optional) State reason code                          |
| <i>admin_state</i>     | (Optional) Interface admin state                      |
| <i>share_state</i>     | (Optional) Interface ownership                        |
| <i>eth_bundle</i>      | (Optional) Belongs to bundle                          |
| <i>eth_dce_mode</i>    | (Optional) DCE mode description                       |
| <i>vpc_status</i>      | (Optional) VPC status                                 |

|                         |                                  |
|-------------------------|----------------------------------|
| <i>eth_hw_desc</i>      | (Optional) HW description        |
| <i>eth_hw_addr</i>      | (Optional) HW address            |
| <i>eth_bia_addr</i>     | (Optional) bia address           |
| <i>desc</i>             | (Optional) Interface description |
| <i>eth_ip_addr</i>      | (Optional) IP Address            |
| <i>eth_ip_mask</i>      | (Optional) IP address mask       |
| <i>eth_ip_prefix</i>    | (Optional) IP address prefix     |
| <i>eth_mtu</i>          | (Optional) MTU                   |
| <i>eth_bw</i>           | (Optional) Bandwidth             |
| <i>eth_encap_vlan</i>   | (Optional) Encapsulation Vlan    |
| <i>eth_dly</i>          | (Optional) Delay                 |
| <i>eth_reliability</i>  | (Optional) Reliability           |
| <i>eth_txload</i>       | (Optional) Tx load               |
| <i>eth_rxload</i>       | (Optional) Rx load               |
| <i>encapsulation</i>    | (Optional) Encapsulation         |
| <i>medium</i>           | (Optional) medium type           |
| <i>eth_loopback</i>     | (Optional) Loopback              |
| <i>eth_keepalive</i>    | (Optional) Keepalive             |
| <i>eth_duplex</i>       | (Optional) Duplex                |
| <i>eth_speed</i>        | (Optional) Speed                 |
| <i>eth_mode</i>         | (Optional) Port mode             |
| <i>eth_ratemode</i>     | (Optional) Rate mode             |
| <i>eth_autoneg</i>      | (Optional) Autonegotiation       |
| <i>eth_beacon</i>       | (Optional) Beacon                |
| <i>eth_media</i>        | (Optional) Media type            |
| <i>eth_in_flowctrl</i>  | (Optional) Input flowcontrol     |
| <i>eth_out_flowctrl</i> | (Optional) Output flowcontrol    |
| <i>eth_mdix</i>         | (Optional) Mdx                   |
| <i>eth_sw_t_monitor</i> | (Optional) Switchport Monitor    |

|                             |   |
|-----------------------------|---|
| <i>eth_etherType</i>        | (Optional) EtherType                                |
| <i>eth_members</i>          | (Optional) Members in this channel                  |
| <i>eth_clk_mode</i>         | (Optional) Clock mode                               |
| <i>eth_arp_type</i>         | (Optional) ARP type                                 |
| <i>eth_arp_timeout</i>      | (Optional) ARP timeout                              |
| <i>eth_last_in</i>          | (Optional) Last input                               |
| <i>eth_last_out</i>         | (Optional) Last output                              |
| <i>eth_out_hang</i>         | (Optional) Last output hang                         |
| <i>eth_clear_counters</i>   | (Optional) Last clearing of show interface counters |
| <i>eth_link_flapped</i>     | (Optional) Last link flapped                        |
| <i>eth_inq_size</i>         | (Optional) Input queue size                         |
| <i>eth_inq_max</i>          | (Optional) Input queue max                          |
| <i>eth_inq_drops</i>        | (Optional) Input queue drops                        |
| <i>eth_inq_flush</i>        | (Optional) Input queue flushes                      |
| <i>eth_out_drop</i>         | (Optional) Output drops                             |
| <i>eth_q_strategy</i>       | (Optional) Queuing strategy                         |
| <i>eth_outq_size</i>        | (Optional) Output queue size                        |
| <i>eth_outq_max</i>         | (Optional) Output queue max                         |
| <i>eth_reset_cntr</i>       | (Optional) Interface resets                         |
| <i>mgmt_hw_desc</i>         | (Optional) HW description                           |
| <i>mgmt_hw_addr</i>         | (Optional) HW address                               |
| <i>mgmt_ip_addr</i>         | (Optional) IP address                               |
| <i>mgmt_ip_mask</i>         | (Optional) IP address mask                          |
| <i>mgmt_mtu</i>             | (Optional) MTU                                      |
| <i>mgmt_speed</i>           | (Optional) Speed                                    |
| <i>mgmt_duplex</i>          | (Optional) Duplex                                   |
| <i>vdc_lvl_in_avg_bits</i>  | (Optional) VDC level average input bits             |
| <i>vdc_lvl_in_avg_pkts</i>  | (Optional) VDC level average input packets          |
| <i>vdc_lvl_out_avg_bits</i> | (Optional) VDC level average output bits            |

|                             |  |
|-----------------------------|--|
| <i>vdc_lvl_out_avg_pkts</i> | (Optional) VDC level average output packets    |
| <i>vdc_lvl_in_pkts</i>      | (Optional) VDC level input packets             |
| <i>vdc_lvl_in_ucast</i>     | (Optional) VDC level input unicast packets     |
| <i>vdc_lvl_in_mcast</i>     | (Optional) VDC level input multicast packets   |
| <i>vdc_lvl_in_bcast</i>     | (Optional) VDC level input broadcast packets   |
| <i>vdc_lvl_in_bytes</i>     | (Optional) VDC level input bytes               |
| <i>vdc_lvl_in_bps</i>       | (Optional) VDC level input bytes per second    |
| <i>vdc_lvl_in_pps</i>       | (Optional) VDC level input packets per second  |
| <i>vdc_lvl_out_pkts</i>     | (Optional) VDC level output packets            |
| <i>vdc_lvl_out_ucast</i>    | (Optional) VDC level output unicast packets    |
| <i>vdc_lvl_out_mcast</i>    | (Optional) VDC level output multicast packets  |
| <i>vdc_lvl_out_bcast</i>    | (Optional) VDC level output broadcast packets  |
| <i>vdc_lvl_out_bytes</i>    | (Optional) VDC level output bytes              |
| <i>vdc_lvl_out_bps</i>      | (Optional) VDC level output bytes per second   |
| <i>vdc_lvl_out_pps</i>      | (Optional) VDC level output packets per second |

**Command Mode**

- /exec

## show interface

```

show interface [ controller | quick ] [ __readonly__ TABLE_interface <interface> [ <state> ] [ <state_rsn> ]
[ <state_rsn_desc> ] [ <vsan_brief> ] [ <oper_port_state> ] [ <port_state> ] [ <bound_interface> ] [
<port_desc> ] [ <port_des> ] [ <mgmt_hw_desc1> ] [ <mgmt_hw_addr1> ] [ <port_name> ] [ <hardware>
] [ <sfp> ] [ <port_wwn> ] [ <peer_port_wwn> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <snmp_trap>
] [ <status> ] [ <state_rsn1> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_mac> ] [ <bind_type> ] [ <port_mode>
] [ <fcid> ] [ <cfg_port_vsan> ] [ <vsan> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <admin_speed> ] [
<port_channel> ] [ <ip_addr1> ] [ <oper_txbbcredit> ] [ <oper_rxbbcredit> ] [ <port_bb_scn> ] [
<admin_rxbufsize> ] [ <admin_port_encap> ] [ <admin_beacon_mode> ] [ <admin_fec_state> ] [
<oper_fec_state> ] [ <bundle_if_index> ] [ <trkd_if_index> ] [ <trk_cfg_vsans> ] [ <trkd_port_state> ] [
<num_ports> ] [ TABLE_trk_intf [ <trk_intf> ] ] [ <info_type_num> ] [ <info_model_num> ] [
<info_manufacturer> ] [ <info_port_id> ] [ <active_vsan> ] [ <trunk_vsan_up> ] [ <trunk_vsan_isolated> ]
[ <trunk_vsan_initializing> ] [ <in_bps> ] [ <in_byps> ] [ <in_fps> ] [ <out_bps> ] [ <out_byps> ] [ <out_fps>
] [ <total_in_frames> ] [ <total_in_bytes> ] [ <total_in_discards> ] [ <total_in_errors> ] [ <invalid_crc> ] [
<unknown_class_frames> ] [ <frames_too_long> ] [ <frames_too_short> ] [ <total_out_frames> ] [
<total_out_bytes> ] [ <total_out_discards> ] [ <total_out_errors> ] [ <in_ols> ] [ <in_lrr> ] [ <in_nos> ] [
<in_loop_inits> ] [ <out_ols> ] [ <out_lrr> ] [ <out_nos> ] [ <out_loop_inits> ] [ <rx_b2b_perf_buff> ] [
<rx_b2b_credit> ] [ <tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] [ <fcoe_in_pkts> ] [ <fcoe_in_octets> ] [
<fcoe_out_pkts> ] [ <fcoe_out_octets> ] [ TABLE_members [ <port_channel_member> ] ] [
<interface_last_changed> ] [ <time_last_cleared> ] [ <interface_quick> ] [ <vsan_brief_quick> ] [
<oper_port_state_quick> ] [ <port_state_quick> ] [ <bound_interface_quick> ] [ <port_desc_quick> ] [
<port_des_quick> ] [ <mgmt_hw_desc1_quick> ] [ <mgmt_hw_addr1_quick> ] [ <port_name_quick> ] [
<hardware_quick> ] [ <sfp_quick> ] [ <port_wwn_quick> ] [ <peer_port_wwn_quick> ] [
<admin_mode_quick> ] [ <admin_trunk_mode_quick> ] [ <snmp_trap_quick> ] [ <status_quick> ] [
<state_rsn1_quick> ] [ <fcot_info_quick> ] [ <bind_info_quick> ] [ <bind_mac_quick> ] [ <bind_type_quick>
] [ <port_mode_quick> ] [ <fcid_quick> ] [ <cfg_port_vsan_quick> ] [ <vsan_quick> ] [
<port_rate_mode_quick> ] [ <oper_speed_quick> ] [ <admin_speed_quick> ] [ <port_channel_quick> ] [
<ip_addr1_quick> ] [ <oper_txbbcredit_quick> ] [ <oper_rxbbcredit_quick> ] [ <port_bb_scn_quick> ] [
<admin_rxbufsize_quick> ] [ <admin_port_encap_quick> ] [ <admin_beacon_mode_quick> ] [
<admin_fec_state_quick> ] [ <oper_fec_state_quick> ] [ <bundle_if_index_quick> ] [ <trkd_if_index_quick>
] [ <trk_cfg_vsans_quick> ] [ <trkd_port_state_quick> ] [ <num_ports_quick> ] [ TABLE_trk_intf_quick [
<trk_intf_quick> ] ] [ <info_type_num_quick> ] [ <info_model_num_quick> ] [ <info_manufacturer_quick>
] [ <info_port_id_quick> ] [ <active_vsan_quick> ] [ <trunk_vsan_up_quick> ] [ <trunk_vsan_isolated_quick>
] [ <trunk_vsan_initializing_quick> ] [ <in_bps_quick> ] [ <in_byps_quick> ] [ <in_fps_quick> ] [
<out_bps_quick> ] [ <out_byps_quick> ] [ <out_fps_quick> ] [ <total_in_frames_quick> ] [
<total_in_bytes_quick> ] [ <total_in_discards_quick> ] [ <total_in_errors_quick> ] [ <invalid_crc_quick> ]
[ <unknown_class_frames_quick> ] [ <frames_too_long_quick> ] [ <frames_too_short_quick> ] [
<total_out_frames_quick> ] [ <total_out_bytes_quick> ] [ <total_out_discards_quick> ] [
<total_out_errors_quick> ] [ <in_ols_quick> ] [ <in_lrr_quick> ] [ <in_nos_quick> ] [ <in_loop_inits_quick>
] [ <out_ols_quick> ] [ <out_lrr_quick> ] [ <out_nos_quick> ] [ <out_loop_inits_quick> ] [
<rx_b2b_perf_buff_quick> ] [ <rx_b2b_credit_quick> ] [ <tx_b2b_credit_quick> ] [
<tx_b2b_low_pri_cre_quick> ] [ <fcoe_in_pkts_quick> ] [ <fcoe_in_octets_quick> ] [ <fcoe_out_pkts_quick>
] [ <fcoe_out_octets_quick> ] [ TABLE_members_quick [ <port_channel_member_quick> ] ] [
<interface_last_changed_quick> ] [ <time_last_cleared_quick> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [
<admin_state> ] [ <share_state> ] [ <parent_interface> ] [ <vpc_status> ] [ <eth_bundle> ] [ <eth_hw_desc>
] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [ <eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix> ]
[ <eth_mtu> ] + [ <eth_bw> ] [ <eth_bw_str> ] [ <eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [
<eth_rxload> ] [ <eth_encap_vlan> ] [ <encapsulation> ] [ <medium> ] [ <eth_mode> ] [ <eth_duplex> ] [
<eth_speed> ] [ <eth_media> ] [ <eth_beacon> ] [ <eth_autoneg> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl>

```

```

]] [<eth_mdix>]] [<eth_ratemode>]] [<eth_sw_t_monitor>]] [<eth_etherstype>]] [<eth_eee_state>]]
<eth_admin_fec_state>]] [<eth_oper_fec_state>]] [<eth_members>]] [<eth_link_flapped>]]
<eth_clear_counters>]] [<eth_reset_cntr>]] [[ [<eth_load_interval1_rx>]] [<eth_inrate1_bits>]]
<eth_inrate1_pkts>]] [<eth_load_interval1_tx>]] [<eth_outrate1_bits>]] [<eth_outrate1_pkts>]]
<eth_inrate1_summary_bits>]] [<eth_inrate1_summary_pkts>]] [<eth_outrate1_summary_bits>]]
<eth_outrate1_summary_pkts>]] [<eth_load_interval2_rx>]] [<eth_inrate2_bits>]] [<eth_inrate2_pkts>]]
<eth_load_interval2_tx>]] [<eth_outrate2_bits>]] [<eth_outrate2_pkts>]] [<eth_inrate2_summary_bits>]]
<eth_inrate2_summary_pkts>]] [<eth_outrate2_summary_bits>]] [<eth_outrate2_summary_pkts>]]
<eth_load_interval3_rx>]] [<eth_inrate3_bits>]] [<eth_inrate3_pkts>]] [<eth_load_interval3_tx>]]
<eth_outrate3_bits>]] [<eth_outrate3_pkts>]] [<eth_inrate3_summary_bits>]] [<eth_inrate3_summary_pkts>]]
]] [<eth_outrate3_summary_bits>]] [<eth_outrate3_summary_pkts>]] [[ [<eth_l2_ucastpkts>]]
<eth_l2_ucastbytes>]] [<eth_l2_mcastpkts>]] [<eth_l2_mcastbytes>]] [<eth_l2_bcastpkts>]]
<eth_l2_bcastbytes>]] [<eth_l3in_routed_pkts>]] [<eth_l3in_routed_bytes>]] [<eth_l3out_routed_pkts>]]
<eth_l3out_routed_bytes>]] [<eth_l3in_ucastpkts>]] [<eth_l3in_ucastbytes>]] [<eth_l3in_mcastpkts>]]
<eth_l3in_mcastbytes>]] [<eth_l3in_bcastpkts>]] [<eth_l3in_bcastbytes>]] [<eth_l3out_ucastpkts>]]
<eth_l3out_ucastbytes>]] [<eth_l3out_mcastpkts>]] [<eth_l3out_mcastbytes>]] [<eth_l3out_bcastpkts>]]
<eth_l3out_bcastbytes>]] [<eth_l3avg1_inbytes>]] [<eth_l3avg1_inpkts>]] [<eth_l3avg1_outbytes>]]
<eth_l3avg1_outpkts>]] [[ [<eth_inucast>]] [<eth_inmcast>]] [<eth_inbcast>]] [<eth_inpkts>]]
<eth_inbytes>]] [<eth_jumbo_inpkts>]] [<eth_storm_supp>]] [<eth_runts>]] [<eth_giants>]] [<eth_crc>]]
]] [<eth_nobuf>]] [<eth_inerr>]] [<eth_frame>]] [<eth_outrun>]] [<eth_underrun>]] [<eth_ignored>]]
<eth_watchdog>]] [<eth_bad_eth>]] [<eth_bad_proto>]] [<eth_in_ifdown_drops>]] [<eth_dribble>]]
<eth_indiscard>]] [<eth_inpause>]] [<eth_stomped_crc>]] [[ [<eth_outucast>]] [<eth_outmcast>]]
<eth_outbcast>]] [<eth_outpkts>]] [<eth_outbytes>]] [<eth_jumbo_outpkts>]] [<eth_outerr>]] [<eth_coll>]]
]] [<eth_deferred>]] [<eth_latecoll>]] [<eth_lostcarrier>]] [<eth_nocarrier>]] [<eth_babbles>]]
<eth_outdiscard>]] [<eth_outpause>]] [[ [<mgmt_hw_desc>]] [<mgmt_hw_addr>]] [<mgmt_ip_addr>]]
<mgmt_ip_mask>]] [<mgmt_mtu>]] [<mgmt_speed>]] [<mgmt_duplex>]] [[ [<vdc_lvl_in_avg_bits>]]
<vdc_lvl_in_avg_pkts>]] [<vdc_lvl_out_avg_bits>]] [<vdc_lvl_out_avg_pkts>]] [<vdc_lvl_in_pkts>]]
<vdc_lvl_in_ucast>]] [<vdc_lvl_in_mcast>]] [<vdc_lvl_in_bcast>]] [<vdc_lvl_in_bytes>]] [<vdc_lvl_in_bps>]]
]] [<vdc_lvl_in_pps>]] [<vdc_lvl_out_pkts>]] [<vdc_lvl_out_ucast>]] [<vdc_lvl_out_mcast>]]
<vdc_lvl_out_bcast>]] [<vdc_lvl_out_bytes>]] [<vdc_lvl_out_bps>]] [<vdc_lvl_out_pps>]] [[
<mgmt_in_pkts>]] [<mgmt_in_bytes>]] [<mgmt_in_mcast>]] [<mgmt_in_compressed>]] [<mgmt_in_errors>]]
]] [<mgmt_in_frame>]] [<mgmt_in_outrun>]] [<mgmt_in_fifo>]] [<mgmt_out_pkts>]] [<mgmt_out_bytes>]]
]] [<mgmt_out_underruns>]] [<mgmt_out_errors>]] [<mgmt_out_collisions>]] [<mgmt_out_fifo>]]
<mgmt_out_carrier>]] [<mgmt_align_err>]] [<mgmt_fcs_err>]] [<mgmt_xmit_err>]] [<mgmt_rcv_err>]]
]] [<mgmt_undersize>]] [<mgmt_outdisc>]] [<mgmt_single_col>]] [<mgmt_multi_col>]] [<mgmt_late_col>]]
]] [<mgmt_excess_col>]] [<mgmt_carri_sen>]] [<mgmt_runts>]] [<mgmt_giants>]] [<mgmt_sqetest_err>]]
]] [<mgmt_deferred_tx>]] [<mgmt_inmactx_err>]] [<mgmt_inmacrx_err>]] [<mgmt_symbol_err>]] [[
<loop_in_pkts>]] [<loop_in_bytes>]] [<loop_in_mcast>]] [<loop_in_compressed>]] [<loop_in_errors>]]
]] [<loop_in_frame>]] [<loop_in_outrun>]] [<loop_in_fifo>]] [<loop_out_pkts>]] [<loop_out_bytes>]]
]] [<loop_out_underruns>]] [<loop_out_errors>]] [<loop_out_collisions>]] [<loop_out_fifo>]]
<loop_out_carriers>]] [[ [<svi_if_index>]] [<svi_admin_state>]] [<oper_state>]] [<svi_rsn_desc>]]
]] [<svi_line_proto>]] [<svi_hw>]] [<svi_mac>]] [<svi_desc>]] [<svi_ip_addr>]] [<svi_ip_mask>]] [<svi_mtu>]]
]] [<svi_bw>]] [<svi_delay>]] [<vlan_id>]] [<type>]] [[ [<svi_tx_load>]] [<svi_rx_load>]] [[
<svi_carrier_delay_sec>]] [<svi_carrier_delay_msec>]] [<svi_arp_type>]] [<svi_arp_timeout>]] [[
<svi_time_last_cleared>]] [[ { [TABLE_sec_vlan] [<sec_vlan>]] [<sec_vlan_type>] } ] [[
<svi_routed_pkts_in>]] [<svi_routed_bytes_in>]] [<svi_routed_pkts_out>]] [<svi_routed_bytes_out>]]
]] [<svi_ucast_pkts_in>]] [<svi_ucast_bytes_in>]] [<svi_mcast_pkts_in>]] [<svi_mcast_bytes_in>]]
]] [<svi_ucast_pkts_out>]] [<svi_ucast_bytes_out>]] [<svi_mcast_pkts_out>]] [<svi_mcast_bytes_out>]]
]] [<svi_ipv4_ucast_pkts_in>]] [<svi_ipv4_ucast_bytes_in>]] [<svi_ipv4_ucast_pkts_out>]]
]] [<svi_ipv4_ucast_bytes_out>]] [<svi_ipv4_mcast_pkts_in>]] [<svi_ipv4_mcast_bytes_in>]]
]] [<svi_ipv4_mcast_pkts_out>]] [<svi_ipv4_mcast_bytes_out>]] [<svi_ipv6_ucast_pkts_in>]]
]]

```

```

<svi_ipv6_ucast_bytes_in> ][ <svi_ipv6_ucast_pkts_out> ][ <svi_ipv6_ucast_bytes_out> ][
<svi_ipv6_mcast_pkts_in> ][ <svi_ipv6_mcast_bytes_in> ][ <svi_ipv6_mcast_pkts_out> ][
<svi_ipv6_mcast_bytes_out> ][ <svi_average_input_bits> ][ <svi_average_input_packets> ][
<svi_average_output_bits> ][ <svi_average_output_packets> ][ <svi_rate_in_mins> ]][ [ <svi_reliability>
] ][ [ <overlay_addr> ][ <overlay_addr_mask> ][ <overlay_mtu> ][ <overlay_bandwidth> ][
<overlay_encap_str> ][ <overlay_vrf> ][ <overlay_src_addr> ][ <overlay_dst_addr> ][
<overlay_last_link_flap> ][ <overlay_clear_counters> ]][ [ <overlay_load_interval> ][
<overlay_rx_ucastpkts> ][ <overlay_rx_ucastbytes> ][ <overlay_rx_mcastpkts> ][ <overlay_rx_mcastbytes>
] ][ <overlay_rx_pkts> ][ <overlay_rx_bytes> ][ <overlay_rx_bcastpkts> ][ <overlay_rx_bcastbytes> ][
<overlay_rx_bitrate> ][ <overlay_rx_pktrate> ][ <overlay_tx_ucastpkts> ][ <overlay_tx_ucastbytes> ][
<overlay_tx_mcastpkts> ][ <overlay_tx_mcastbytes> ][ <overlay_tx_bcastpkts> ][ <overlay_tx_bcastbytes>
] ][ <overlay_tx_pkts> ][ <overlay_tx_bytes> ][ <overlay_tx_bitrate> ][ <overlay_tx_pktrate> ]][
<veth_hw_desc> <veth_hw_addr> <veth_bia_addr> [ <veth_conn_name> ][ <veth_conn_dev_name> ][
<veth_vem_num> ][ <veth_vmware_dvport_num> ][ <veth_port_profile> ] <veth_mode> ][
<veth_inrate_bits> <veth_inrate_pkts> <veth_outrate_bits> <veth_outrate_pkts> <veth_inpkts> <veth_inucast>
<veth_inmcast> <veth_inbcast> <veth_inbytes> <veth_outpkts> <veth_outucast> <veth_outmcast>
<veth_outbcast> <veth_outfloods> <veth_outbytes> <veth_inpktdrops> <veth_outpktdrops> ]][ <switchport>
] ][ [ <admin-state> ][ { <tunnel-ipv4> | <tunnel-ipv6> } ]][ <mtu> ][ <bandwidth> ][ <encap-type> ][
<keepalive-period> ][ <keepalive-retries> ]][ { <src-ipv4> | <src-ipv6> } ]][ <src-intf> ]][ { <dest-ipv4> |
<dest-ipv6> } ]][ <dest-hostname> ][ <vrf_name> ][ <tunnel_vrf_name> ][ <wccp_header> ][ <ttl_val> ]
[ <tunnel_pmtud_age_time> ][ <tunnel_pmtud_min_mtu> ][ <tunnel_pmtud> ][ <tunnel_pgm_mtu> ]][
<tunnel_clear_counter> ][ <tunnel_tx_pkt_count> ][ <tunnel_tx_byte_count> ][ <tunnel_tx_rate> ][
<tunnel_rx_pkt_count> ][ <tunnel_rx_byte_count> ][ <tunnel_rx_rate> ]][ ]

```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                  |
| interface              | Show interface status and information            |
| controller             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED        |
| quick                  | (Optional) Show info of interface skipping stats |
| __readonly__           | (Optional) Read Only                             |
| <i>interface</i>       | (Optional) Interface index                       |
| TABLE_interface        | (Optional) show interface                        |
| <i>state</i>           | (Optional) Interface state                       |
| <i>state_rsn</i>       | (Optional) Interface state reason                |
| <i>state_rsn_desc</i>  | (Optional) Interface state reason detailed       |
| <i>vsan_brief</i>      | (Optional) vsan for brief                        |
| <i>oper_port_state</i> | (Optional) oper port state                       |
| <i>port_state</i>      | (Optional) port state                            |
| <i>bound_interface</i> | (Optional) bound interface                       |
| <i>port_desc</i>       | (Optional) port description                      |



|                         |                                     |
|-------------------------|-------------------------------------|
| <i>port_des</i>         | (Optional) port description         |
| <i>mgmt_hw_desc1</i>    | (Optional) HW description           |
| <i>mgmt_hw_addr1</i>    | (Optional) HW address               |
| <i>port_name</i>        | (Optional) port description         |
| <i>hardware</i>         | (Optional) Hardware is              |
| <i>sfp</i>              | (Optional) sfp                      |
| <i>port_wwn</i>         | (Optional) port wwn                 |
| <i>peer_port_wwn</i>    | (Optional) peer port wwn            |
| <i>admin_mode</i>       | (Optional) admin mode               |
| <i>admin_trunk_mode</i> | (Optional) admin trunk mode         |
| <i>snmp_trap</i>        | (Optional) snmp trap                |
| <i>status</i>           | (Optional) Status                   |
| <i>state_rsn1</i>       | (Optional) state reason             |
| <i>fcot_info</i>        | (Optional) fcot info                |
| <i>bind_info</i>        | (Optional) bind interface           |
| <i>bind_mac</i>         | (Optional) bind mac                 |
| <i>bind_type</i>        | (Optional) bind type                |
| <i>port_mode</i>        | (Optional) port mode                |
| <i>fcid</i>             | (Optional) fcid                     |
| <i>cfg_port_vsan</i>    | (Optional) config port vsan         |
| <i>vsan</i>             | (Optional) vsan for brief           |
| <i>port_rate_mode</i>   | (Optional) operation port rate mode |
| <i>oper_speed</i>       | (Optional) speed                    |
| <i>admin_speed</i>      | (Optional) admin speed              |
| <i>port_channel</i>     | (Optional) port channel             |
| <i>ip_addr1</i>         | (Optional) Ip address               |
| <i>oper_txbbcredit</i>  | (Optional) oper tx bbcredit         |
| <i>oper_rxbbcredit</i>  | (Optional) oper rx bbcredit         |
| <i>port_bb_scn</i>      | (Optional) port bb scn              |

|                                |                                    |
|--------------------------------|------------------------------------|
| <i>admin_rxbufsize</i>         | (Optional) admin rx bufsize        |
| <i>admin_port_encap</i>        | (Optional) admin port encap        |
| <i>admin_beacon_mode</i>       | (Optional) admin beacon mode       |
| <i>admin_fec_state</i>         | (Optional) admin fec state         |
| <i>oper_fec_state</i>          | (Optional) oper fec state          |
| <i>bundle_if_index</i>         | (Optional) bundle if index         |
| <i>trkd_if_index</i>           | (Optional) Trunk interfaces        |
| <i>trk_cfg_vsans</i>           | (Optional) Trunk vsans             |
| <i>trkd_port_state</i>         | (Optional) trunk port state        |
| <i>num_ports</i>               | (Optional) number of ports         |
| TABLE_trk_intf                 | (Optional) trunk interfaces        |
| <i>trk_intf</i>                | (Optional) track interface         |
| <i>info_type_num</i>           | (Optional) info type num           |
| <i>info_model_num</i>          | (Optional) info model num          |
| <i>info_manufacturer</i>       | (Optional) info manufacturer       |
| <i>info_port_id</i>            | (Optional) info port id            |
| <i>active_vsan</i>             | (Optional) allowed and active vsan |
| <i>trunk_vsan_up</i>           | (Optional) trunk vsan up           |
| <i>trunk_vsan_isolated</i>     | (Optional) trunk vsan isolated     |
| <i>trunk_vsan_initializing</i> | (Optional) trunk vsan initializing |
| <i>in_bps</i>                  | (Optional) input bits/sec          |
| <i>in_byps</i>                 | (Optional) input bytes/sec         |
| <i>in_fps</i>                  | (Optional) input frames/sec        |
| <i>out_bps</i>                 | (Optional) output bits/sec         |
| <i>out_byps</i>                | (Optional) output bytes/sec        |
| <i>out_fps</i>                 | (Optional) output frames/sec       |
| <i>total_in_frames</i>         | (Optional) total in frames         |
| <i>total_in_bytes</i>          | (Optional) total in bytes          |
| <i>total_in_discards</i>       | (Optional) total in discards       |

|                               |  |
|-------------------------------|--|
| <i>total_in_errors</i>        | (Optional) total in errors                         |
| <i>invalid_crc</i>            | (Optional) invalid crc                             |
| <i>unknown_class_frames</i>   | (Optional) unknown class frames                    |
| <i>frames_too_long</i>        | (Optional) frames too long                         |
| <i>frames_too_short</i>       | (Optional) frames too short                        |
| <i>total_out_frames</i>       | (Optional) total out frames                        |
| <i>total_out_bytes</i>        | (Optional) total out bytes                         |
| <i>total_out_discards</i>     | (Optional) total out discards                      |
| <i>total_out_errors</i>       | (Optional) total out errors                        |
| <i>in_ols</i>                 | (Optional) input OLS                               |
| <i>in_lrr</i>                 | (Optional) input LRR                               |
| <i>in_nos</i>                 | (Optional) input NOS                               |
| <i>in_loop_inits</i>          | (Optional) input loop inits                        |
| <i>out_ols</i>                | (Optional) output OLS                              |
| <i>out_lrr</i>                | (Optional) output LRR                              |
| <i>out_nos</i>                | (Optional) output NOS                              |
| <i>out_loop_inits</i>         | (Optional) output loop inits                       |
| <i>rx_b2b_perf_buff</i>       | (Optional) rx b2b performance buff                 |
| <i>rx_b2b_credit</i>          | (Optional) rx b2b credit                           |
| <i>tx_b2b_credit</i>          | (Optional) tx b2b credit                           |
| <i>tx_b2b_low_pri_cre</i>     | (Optional) tx b2b low pri credit                   |
| <i>fcoe_in_pkts</i>           | (Optional) fcoe in pkts                            |
| <i>fcoe_in_octets</i>         | (Optional) fcoe in octets                          |
| <i>fcoe_out_pkts</i>          | (Optional) fcoe out pkts                           |
| <i>fcoe_out_octets</i>        | (Optional) fcoe out octets                         |
| <i>TABLE_members</i>          | (Optional) table for port-channel member interface |
| <i>port_channel_member</i>    | (Optional) port-channel member interface           |
| <i>interface_last_changed</i> | (Optional) interface last changed                  |
| <i>time_last_cleared</i>      | (Optional) counters last cleared                   |

|                               |                                     |
|-------------------------------|-------------------------------------|
| <i>interface_quick</i>        | (Optional) Interface index          |
| <i>vsan_brief_quick</i>       | (Optional) vsan for brief           |
| <i>oper_port_state_quick</i>  | (Optional) oper port state          |
| <i>port_state_quick</i>       | (Optional) port state               |
| <i>bound_interface_quick</i>  | (Optional) bound interface          |
| <i>port_desc_quick</i>        | (Optional) port description         |
| <i>port_des_quick</i>         | (Optional) port description         |
| <i>mgmt_hw_desc1_quick</i>    | (Optional) HW description           |
| <i>mgmt_hw_addr1_quick</i>    | (Optional) HW address               |
| <i>port_name_quick</i>        | (Optional) port description         |
| <i>hardware_quick</i>         | (Optional) Hardware is              |
| <i>sfp_quick</i>              | (Optional) sfp                      |
| <i>port_wwn_quick</i>         | (Optional) port wwn                 |
| <i>peer_port_wwn_quick</i>    | (Optional) peer port wwn            |
| <i>admin_mode_quick</i>       | (Optional) admin mode               |
| <i>admin_trunk_mode_quick</i> | (Optional) admin trunk mode         |
| <i>snmp_trap_quick</i>        | (Optional) snmp trap                |
| <i>status_quick</i>           | (Optional) Status                   |
| <i>state_rsn1_quick</i>       | (Optional) state reason             |
| <i>fcot_info_quick</i>        | (Optional) fcot info                |
| <i>bind_info_quick</i>        | (Optional) bind interface           |
| <i>bind_mac_quick</i>         | (Optional) bind mac                 |
| <i>bind_type_quick</i>        | (Optional) bind type                |
| <i>port_mode_quick</i>        | (Optional) port mode                |
| <i>fcid_quick</i>             | (Optional) fcid                     |
| <i>cfg_port_vsan_quick</i>    | (Optional) config port vsan         |
| <i>vsan_quick</i>             | (Optional) vsan for brief           |
| <i>port_rate_mode_quick</i>   | (Optional) operation port rate mode |
| <i>oper_speed_quick</i>       | (Optional) speed                    |

|                                      |                                    |
|--------------------------------------|------------------------------------|
| <i>admin_speed_quick</i>             | (Optional) admin speed             |
| <i>port_channel_quick</i>            | (Optional) port channel            |
| <i>ip_addr1_quick</i>                | (Optional) Ip address              |
| <i>oper_txbbcredit_quick</i>         | (Optional) oper tx bbcredit        |
| <i>oper_rxbbcredit_quick</i>         | (Optional) oper rx bbcredit        |
| <i>port_bb_scn_quick</i>             | (Optional) port bb scn             |
| <i>admin_rxbufsize_quick</i>         | (Optional) admin rx bufsize        |
| <i>admin_port_encap_quick</i>        | (Optional) admin port encap        |
| <i>admin_beacon_mode_quick</i>       | (Optional) admin beacon mode       |
| <i>admin_fec_state_quick</i>         | (Optional) admin fec state         |
| <i>oper_fec_state_quick</i>          | (Optional) oper fec state          |
| <i>bundle_if_index_quick</i>         | (Optional) bundle if index         |
| <i>trkd_if_index_quick</i>           | (Optional) Trunk interfaces        |
| <i>trk_cfg_vsans_quick</i>           | (Optional) Trunk vsans             |
| <i>trkd_port_state_quick</i>         | (Optional) trunk port state        |
| <i>num_ports_quick</i>               | (Optional) number of ports         |
| TABLE_trk_intf_quick                 | (Optional) trunk interfaces        |
| <i>trk_intf_quick</i>                | (Optional) track interface         |
| <i>info_type_num_quick</i>           | (Optional) info type num           |
| <i>info_model_num_quick</i>          | (Optional) info model num          |
| <i>info_manufacturer_quick</i>       | (Optional) info manufacturer       |
| <i>info_port_id_quick</i>            | (Optional) info port id            |
| <i>active_vsan_quick</i>             | (Optional) allowed and active vsan |
| <i>trunk_vsan_up_quick</i>           | (Optional) trunk vsan up           |
| <i>trunk_vsan_isolated_quick</i>     | (Optional) trunk vsan isolated     |
| <i>trunk_vsan_initializing_quick</i> | (Optional) trunk vsan initializing |
| <i>in_bps_quick</i>                  | (Optional) input bits/sec          |
| <i>in_byts_quick</i>                 | (Optional) input bytes/sec         |
| <i>in_fps_quick</i>                  | (Optional) input frames/sec        |

|                                   |                                    |
|-----------------------------------|------------------------------------|
| <i>out_bps_quick</i>              | (Optional) output bits/sec         |
| <i>out_byts_quick</i>             | (Optional) output bytes/sec        |
| <i>out_fps_quick</i>              | (Optional) output frames/sec       |
| <i>total_in_frames_quick</i>      | (Optional) total in frames         |
| <i>total_in_bytes_quick</i>       | (Optional) total in bytes          |
| <i>total_in_discards_quick</i>    | (Optional) total in discards       |
| <i>total_in_errors_quick</i>      | (Optional) total in errors         |
| <i>invalid_crc_quick</i>          | (Optional) invalid crc             |
| <i>unknown_class_frames_quick</i> | (Optional) unknown class frames    |
| <i>frames_too_long_quick</i>      | (Optional) frames too long         |
| <i>frames_too_short_quick</i>     | (Optional) frames too short        |
| <i>total_out_frames_quick</i>     | (Optional) total out frames        |
| <i>total_out_bytes_quick</i>      | (Optional) total out bytes         |
| <i>total_out_discards_quick</i>   | (Optional) total out discards      |
| <i>total_out_errors_quick</i>     | (Optional) total out errors        |
| <i>in_ols_quick</i>               | (Optional) input OLS               |
| <i>in_lrr_quick</i>               | (Optional) input LRR               |
| <i>in_nos_quick</i>               | (Optional) input NOS               |
| <i>in_loop_inits_quick</i>        | (Optional) input loop inits        |
| <i>out_ols_quick</i>              | (Optional) output OLS              |
| <i>out_lrr_quick</i>              | (Optional) output LRR              |
| <i>out_nos_quick</i>              | (Optional) output NOS              |
| <i>out_loop_inits_quick</i>       | (Optional) output loop inits       |
| <i>rx_b2b_perf_buff_quick</i>     | (Optional) rx b2b performance buff |
| <i>rx_b2b_credit_quick</i>        | (Optional) rx b2b credit           |
| <i>tx_b2b_credit_quick</i>        | (Optional) tx b2b credit           |
| <i>tx_b2b_low_pri_cre_quick</i>   | (Optional) tx b2b low pri credit   |
| <i>fcoe_in_pkts_quick</i>         | (Optional) fcoe in pkts            |
| <i>fcoe_in_octets_quick</i>       | (Optional) fcoe in octets          |

|                                     |  |
|-------------------------------------|--|
| <i>fcoe_out_pkts_quick</i>          | (Optional) fcoe out pkts                           |
| <i>fcoe_out_octets_quick</i>        | (Optional) fcoe out octets                         |
| <i>TABLE_members_quick</i>          | (Optional) table for port-channel member interface |
| <i>port_channel_member_quick</i>    | (Optional) port-channel member interface           |
| <i>interface_last_changed_quick</i> | (Optional) interface last changed                  |
| <i>time_last_cleared_quick</i>      | (Optional) counters last cleared                   |
| <i>eth_rsn_fac</i>                  | (Optional) State reason facility                   |
| <i>eth_rsn_code</i>                 | (Optional) State reason code                       |
| <i>admin_state</i>                  | (Optional) admin state                             |
| <i>share_state</i>                  | (Optional) Interface ownership                     |
| <i>parent_interface</i>             | (Optional) parent interface                        |
| <i>vpc_status</i>                   | (Optional) VPC status                              |
| <i>eth_bundle</i>                   | (Optional) Belongs to bundle                       |
| <i>eth_hw_desc</i>                  | (Optional) HW description                          |
| <i>eth_hw_addr</i>                  | (Optional) HW address                              |
| <i>eth_bia_addr</i>                 | (Optional) bia address                             |
| <i>desc</i>                         | (Optional) Interface description                   |
| <i>eth_ip_addr</i>                  | (Optional) IP Address                              |
| <i>eth_ip_mask</i>                  | (Optional) IP address mask                         |
| <i>eth_ip_prefix</i>                | (Optional) IP address prefix                       |
| <i>eth_mtu</i>                      | (Optional) MTU                                     |
| <i>eth_bw</i>                       | (Optional) Bandwidth                               |
| <i>eth_bw_str</i>                   | (Optional) Bandwidth                               |
| <i>eth_dly</i>                      | (Optional) Delay                                   |
| <i>eth_reliability</i>              | (Optional) Reliability                             |
| <i>eth_txload</i>                   | (Optional) Tx load                                 |
| <i>eth_rxload</i>                   | (Optional) Rx load                                 |
| <i>eth_encap_vlan</i>               | (Optional) Encapsulation Vlan                      |
| <i>encapsulation</i>                | (Optional) Encapsulation                           |

|                                  |   |
|----------------------------------|---|
| <i>medium</i>                    | (Optional) medium type                              |
| <i>eth_mode</i>                  | (Optional) Port mode                                |
| <i>eth_duplex</i>                | (Optional) Duplex                                   |
| <i>eth_speed</i>                 | (Optional) Speed                                    |
| <i>eth_media</i>                 | (Optional) Media type                               |
| <i>eth_beacon</i>                | (Optional) Beacon                                   |
| <i>eth_autoneg</i>               | (Optional) Autonegotiation                          |
| <i>eth_in_flowctrl</i>           | (Optional) Input flowcontrol                        |
| <i>eth_out_flowctrl</i>          | (Optional) Output flowcontrol                       |
| <i>eth_mdix</i>                  | (Optional) Mdx                                      |
| <i>eth_ratemode</i>              | (Optional) Rate mode                                |
| <i>eth_swt_monitor</i>           | (Optional) Switchport Monitor                       |
| <i>eth_ethertype</i>             | (Optional) EtherType                                |
| <i>eth_eee_state</i>             | (Optional) EEE state                                |
| <i>eth_admin_fec_state</i>       | (Optional) Admin FEC state                          |
| <i>eth_oper_fec_state</i>        | (Optional) Oper FEC state                           |
| <i>eth_members</i>               | (Optional) Members in this channel                  |
| <i>eth_link_flapped</i>          | (Optional) Last link flapped                        |
| <i>eth_clear_counters</i>        | (Optional) Last clearing of show interface counters |
| <i>eth_reset_cntr</i>            | (Optional) Interface resets                         |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec            |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec           |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec           |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec            |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec          |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec          |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary        |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary        |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary       |



|                                  |   |
|----------------------------------|---|
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec     |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec     |
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec    |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec    |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary  |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary  |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary |
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec    |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary  |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary  |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary |
| <i>eth_l2_ucastpkts</i>          | (Optional) L2 switched ucast pkts             |
| <i>eth_l2_ucastbytes</i>         | (Optional) L2 switched ucast bytes            |
| <i>eth_l2_mcastpkts</i>          | (Optional) L2 switched mcast pkts             |
| <i>eth_l2_mcastbytes</i>         | (Optional) L2 switched mcast bytes            |
| <i>eth_l2_bcastpkts</i>          | (Optional) L2 switched bcast pkts             |
| <i>eth_l2_bcastbytes</i>         | (Optional) L2 switched bcast bytes            |
| <i>eth_l3in_ucastpkts</i>        | (Optional) L3 in switched ucast pkts          |
| <i>eth_l3in_ucastbytes</i>       | (Optional) L3 in switched ucast bytes         |

|                               |  |
|-------------------------------|--|
| <i>eth_l3in_mcastpkts</i>     | (Optional) L3 in switched mcast pkts                     |
| <i>eth_l3in_mcastbytes</i>    | (Optional) L3 in switched mcast bytes                    |
| <i>eth_l3in_bcastpkts</i>     | (Optional) L3 in switched bcast pkts                     |
| <i>eth_l3in_bcastbytes</i>    | (Optional) L3 in switched bcast bytes                    |
| <i>eth_l3out_ucastpkts</i>    | (Optional) L3 out switched ucast pkts                    |
| <i>eth_l3out_ucastbytes</i>   | (Optional) L3 out switched ucast bytes                   |
| <i>eth_l3out_mcastpkts</i>    | (Optional) L3 out switched mcast pkts                    |
| <i>eth_l3out_mcastbytes</i>   | (Optional) L3 out switched mcast bytes                   |
| <i>eth_l3out_bcastpkts</i>    | (Optional) L3 out switched bcast pkts                    |
| <i>eth_l3out_bcastbytes</i>   | (Optional) L3 out switched bcast bytes                   |
| <i>eth_l3in_routed_pkts</i>   | (Optional) L3 in routed pkts                             |
| <i>eth_l3in_routed_bytes</i>  | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>  | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i> | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>     | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>      | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>    | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>     | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_inucast</i>            | (Optional) Unicasts                                      |
| <i>eth_inmcast</i>            | (Optional) Multicasts                                    |
| <i>eth_inbcast</i>            | (Optional) Broadcasts                                    |
| <i>eth_inpkts</i>             | (Optional) Packets input                                 |
| <i>eth_inbytes</i>            | (Optional) Bytes input                                   |
| <i>eth_jumbo_inpkts</i>       | (Optional) Incoming jumbo pkts                           |
| <i>eth_storm_supp</i>         | (Optional) storm suppression                             |
| <i>eth_runts</i>              | (Optional) runts   |
| <i>eth_giants</i>             | (Optional) giants  |
| <i>eth_crc</i>                | (Optional) CRC   |
| <i>eth_nobuf</i>              | (Optional) No buffer received                            |

|                            |   |
|----------------------------|---|
| <i>eth_inerr</i>           | (Optional) input errors                         |
| <i>eth_frame</i>           | (Optional) frame                                |
| <i>eth_overrun</i>         | (Optional) overrun                              |
| <i>eth_underrun</i>        | (Optional) underruns                            |
| <i>eth_ignored</i>         | (Optional) ignored                              |
| <i>eth_watchdog</i>        | (Optional) watchdog                             |
| <i>eth_bad_eth</i>         | (Optional) bad ether type drop                  |
| <i>eth_bad_proto</i>       | (Optional) bad protocol drops                   |
| <i>eth_in_ifdown_drops</i> | (Optional) Input if-down drops                  |
| <i>eth_dribble</i>         | (Optional) input packets with dribble condition |
| <i>eth_indiscard</i>       | (Optional) discards                             |
| <i>eth_inpause</i>         | (Optional) pause input                          |
| <i>eth_stomped_crc</i>     | (Optional) Stomped CRC                          |
| <i>eth_outucast</i>        | (Optional) Unicasts                             |
| <i>eth_outmcast</i>        | (Optional) Multicasts                           |
| <i>eth_outbcast</i>        | (Optional) Broadcasts                           |
| <i>eth_outpkts</i>         | (Optional) packets output                       |
| <i>eth_outbytes</i>        | (Optional) bytes output                         |
| <i>eth_jumbo_outpkts</i>   | (Optional) Outgoing jumbo pkts                  |
| <i>eth_outerr</i>          | (Optional) output errors                        |
| <i>eth_coll</i>            | (Optional) collisions                           |
| <i>eth_deferred</i>        | (Optional) deferred                             |
| <i>eth_latecoll</i>        | (Optional) late collision                       |
| <i>eth_lostcarrier</i>     | (Optional) lost carrier                         |
| <i>eth_nocarrier</i>       | (Optional) no carrier                           |
| <i>eth_babbles</i>         | (Optional) babbles                              |
| <i>eth_outdiscard</i>      | (Optional) output discard                       |
| <i>eth_outpause</i>        | (Optional) PAUSE output                         |
| <i>mgmt_hw_desc</i>        | (Optional) HW description                       |

|                             |  |
|-----------------------------|--|
| <i>mgmt_hw_addr</i>         | (Optional) HW address                          |
| <i>mgmt_ip_addr</i>         | (Optional) IP address                          |
| <i>mgmt_ip_mask</i>         | (Optional) IP address mask                     |
| <i>mgmt_mtu</i>             | (Optional) MTU                                 |
| <i>mgmt_speed</i>           | (Optional) Speed                               |
| <i>mgmt_duplex</i>          | (Optional) Duplex                              |
| <i>vdc_lvl_in_avg_bits</i>  | (Optional) VDC level average input bits        |
| <i>vdc_lvl_in_avg_pkts</i>  | (Optional) VDC level average input packets     |
| <i>vdc_lvl_out_avg_bits</i> | (Optional) VDC level average output bits       |
| <i>vdc_lvl_out_avg_pkts</i> | (Optional) VDC level average output packets    |
| <i>vdc_lvl_in_pkts</i>      | (Optional) VDC level input packets             |
| <i>vdc_lvl_in_ucast</i>     | (Optional) VDC level input unicast packets     |
| <i>vdc_lvl_in_mcast</i>     | (Optional) VDC level input multicast packets   |
| <i>vdc_lvl_in_bcast</i>     | (Optional) VDC level input broadcast packets   |
| <i>vdc_lvl_in_bytes</i>     | (Optional) VDC level input bytes               |
| <i>vdc_lvl_in_bps</i>       | (Optional) VDC level input bytes per second    |
| <i>vdc_lvl_in_pps</i>       | (Optional) VDC level input packets per second  |
| <i>vdc_lvl_out_pkts</i>     | (Optional) VDC level output packets            |
| <i>vdc_lvl_out_ucast</i>    | (Optional) VDC level output unicast packets    |
| <i>vdc_lvl_out_mcast</i>    | (Optional) VDC level output multicast packets  |
| <i>vdc_lvl_out_bcast</i>    | (Optional) VDC level output broadcast packets  |
| <i>vdc_lvl_out_bytes</i>    | (Optional) VDC level output bytes              |
| <i>vdc_lvl_out_bps</i>      | (Optional) VDC level output bytes per second   |
| <i>vdc_lvl_out_pps</i>      | (Optional) VDC level output packets per second |
| <i>mgmt_in_pkts</i>         | (Optional) Input packets                       |
| <i>mgmt_in_bytes</i>        | (Optional) Input bytes                         |
| <i>mgmt_in_mcast</i>        | (Optional) Input multicast frames              |
| <i>mgmt_in_compressed</i>   | (Optional) Input compressed                    |
| <i>mgmt_in_errors</i>       | (Optional) Input errors                        |

|                            |                                  |
|----------------------------|----------------------------------|
| <i>mgmt_in_frame</i>       | (Optional) Input frame errors    |
| <i>mgmt_in_overrun</i>     | (Optional) Input overrun         |
| <i>mgmt_in_fifo</i>        | (Optional) Input fifo            |
| <i>mgmt_out_pkts</i>       | (Optional) Output packets        |
| <i>mgmt_out_bytes</i>      | (Optional) Output bytes          |
| <i>mgmt_out_underruns</i>  | (Optional) Output overruns       |
| <i>mgmt_out_errors</i>     | (Optional) Output errors         |
| <i>mgmt_out_collisions</i> | (Optional) Output collisions     |
| <i>mgmt_out_fifo</i>       | (Optional) Output fifo           |
| <i>mgmt_out_carrier</i>    | (Optional) Output carrier errors |
| <i>mgmt_align_err</i>      | (Optional) Align error           |
| <i>mgmt_fcs_err</i>        | (Optional) FCS error             |
| <i>mgmt_xmit_err</i>       | (Optional) Transmit error        |
| <i>mgmt_rcv_err</i>        | (Optional) Receive error         |
| <i>mgmt_undersize</i>      | (Optional) Undersize             |
| <i>mgmt_outdisc</i>        | (Optional) Out discard           |
| <i>mgmt_single_col</i>     | (Optional) Single collision      |
| <i>mgmt_multi_col</i>      | (Optional) Multiple collision    |
| <i>mgmt_late_col</i>       | (Optional) Late collision        |
| <i>mgmt_excess_col</i>     | (Optional) Excess collision      |
| <i>mgmt_carri_sen</i>      | (Optional) Carrier sense         |
| <i>mgmt_runts</i>          | (Optional) Runts                 |
| <i>mgmt_giants</i>         | (Optional) Giants                |
| <i>mgmt_sqetest_err</i>    | (Optional) SQETest error         |
| <i>mgmt_deferred_tx</i>    | (Optional) Deferred tx           |
| <i>mgmt_inmactx_err</i>    | (Optional) In MAC tx             |
| <i>mgmt_inmacrx_err</i>    | (Optional) In MAC rx             |
| <i>mgmt_symbol_err</i>     | (Optional) Symbol error          |
| <i>loop_in_pkts</i>        | (Optional) Input packets         |

|                            |  |
|----------------------------|--|
| <i>loop_in_bytes</i>       | (Optional) Input bytes                             |
| <i>loop_in_mcast</i>       | (Optional) Input multicast                         |
| <i>loop_in_compressed</i>  | (Optional) Input compressed                        |
| <i>loop_in_errors</i>      | (Optional) Input errors                            |
| <i>loop_in_frame</i>       | (Optional) Input frame errors                      |
| <i>loop_in_overrun</i>     | (Optional) Input overrun                           |
| <i>loop_in_fifo</i>        | (Optional) Input fifo                              |
| <i>loop_out_pkts</i>       | (Optional) Output packets                          |
| <i>loop_out_bytes</i>      | (Optional) Output bytes                            |
| <i>loop_out_underruns</i>  | (Optional) Output underruns                        |
| <i>loop_out_errors</i>     | (Optional) Output errors                           |
| <i>loop_out_collisions</i> | (Optional) Output collisions                       |
| <i>loop_out_fifo</i>       | (Optional) Output fifo                             |
| <i>loop_out_carriers</i>   | (Optional) Output carrier errors                   |
| <i>svi_if_index</i>        | (Optional) Interface                               |
| <i>svi_admin_state</i>     | (Optional)   |
| <i>oper_state</i>          | (Optional)   |
| <i>svi_rsn_desc</i>        | (Optional) Interface state reason detailed         |
| <i>svi_line_proto</i>      | (Optional)   |
| <i>svi_hw</i>              | (Optional) Hardware                                |
| <i>svi_mac</i>             | (Optional) Address                                 |
| <i>svi_desc</i>            | (Optional) Interface Description                   |
| <i>svi_ip_addr</i>         | (Optional) IP Address                              |
| <i>svi_ip_mask</i>         | (Optional) IP address mask                         |
| <i>svi_mtu</i>             | (Optional) MTU size in bytes                       |
| <i>svi_bw</i>              | (Optional) Bandwidth in kilobits                   |
| <i>svi_delay</i>           | (Optional) Throughput delay (tens of microseconds) |
| <i>vlan_id</i>             | (Optional) Vlan                                    |
| <i>type</i>                | (Optional) type                                    |

|                               |   |
|-------------------------------|---|
| <i>svi_tx_load</i>            | (Optional) Tx Load                              |
| <i>svi_rx_load</i>            | (Optional) Rx Load                              |
| <i>svi_carrier_delay_sec</i>  | (Optional) carrier delay value in seconds       |
| <i>svi_carrier_delay_msec</i> | (Optional) carrier delay value in milli-seconds |
| <i>svi_arp_type</i>           | (Optional) ARP type                             |
| <i>svi_arp_timeout</i>        | (Optional) ARP timeout value                    |
| <i>svi_time_last_cleared</i>  | (Optional) Time last cleared                    |
| TABLE_sec_vlan                | (Optional) secondary vlans                      |
| <i>sec_vlan</i>               | (Optional) vlan id                              |
| <i>sec_vlan_type</i>          | (Optional) secondary vlan type                  |
| <i>svi_reliability</i>        | (Optional) Reliability                          |
| <i>veth_hw_desc</i>           | (Optional) HW description                       |
| <i>veth_hw_addr</i>           | (Optional) HW address                           |
| <i>veth_bia_addr</i>          | (Optional) bia address                          |
| <i>veth_conn_name</i>         | (Optional) Connectee name                       |
| <i>veth_conn_dev_name</i>     | (Optional) Connectee device name                |
| <i>veth_vem_num</i>           | (Optional) VEM the veth is active on            |
| <i>veth_vmware_dyport_num</i> | (Optional) VMware DVPort number                 |
| <i>veth_port_profile</i>      | (Optional) Port Profile name                    |
| <i>veth_mode</i>              | (Optional) Port mode                            |
| <i>veth_inrate_bits</i>       | (Optional) input rate bits/sec                  |
| <i>veth_inrate_pkts</i>       | (Optional) input rate pkts/sec                  |
| <i>veth_outrate_bits</i>      | (Optional) output rate bits/sec                 |
| <i>veth_outrate_pkts</i>      | (Optional) output rate pkts/sec                 |
| <i>veth_inpkts</i>            | (Optional) Packets input                        |
| <i>veth_inucast</i>           | (Optional) Unicasts input                       |
| <i>veth_inmcast</i>           | (Optional) Multicasts input                     |
| <i>veth_inbcast</i>           | (Optional) Broadcasts input                     |
| <i>veth_inbytes</i>           | (Optional) Bytes input                          |

|                              |  |
|------------------------------|--|
| <i>veth_outpkts</i>          | (Optional) Packets output                      |
| <i>veth_outucast</i>         | (Optional) Unicasts output                     |
| <i>veth_outmcast</i>         | (Optional) Multicasts output                   |
| <i>veth_outbcast</i>         | (Optional) Broadcasts output                   |
| <i>veth_outfloods</i>        | (Optional) Flood packets output                |
| <i>veth_outbytes</i>         | (Optional) Bytes output                        |
| <i>veth_inpktdrops</i>       | (Optional) Packet drops input                  |
| <i>veth_outpktdrops</i>      | (Optional) Packet drops output                 |
| <i>admin-state</i>           | (Optional)                                     |
| <i>tunnel-ipv4</i>           | (Optional) interface IPv4 address              |
| <i>mtu</i>                   | (Optional) interface Maximum Transmission Unit |
| <i>bandwidth</i>             | (Optional) interface Bandwidth in kilobits     |
| <i>encap-type</i>            | (Optional)                                     |
| <i>keepalive-period</i>      | (Optional) keealive period                     |
| <i>keepalive-retries</i>     | (Optional) number of retries                   |
| <i>src-ipv4</i>              | (Optional) tunnel source IPv4 address          |
| <i>src-intf</i>              | (Optional) tunnel source interface             |
| <i>dest-ipv4</i>             | (Optional) tunnel destination IPv4 address     |
| <i>dest-hostname</i>         | (Optional) tunnel destination hostname         |
| <i>vrf_name</i>              | (Optional) transport VRF name                  |
| <i>tunnel_vrf_name</i>       | (Optional) tunnel VRF name                     |
| <i>wccp_header</i>           | (Optional) wccp header                         |
| <i>ttl_val</i>               | (Optional) tunnel time to live value           |
| <i>tunnel_pmtud_age_time</i> | (Optional) tunnel path MTU discovery age time  |
| <i>tunnel_pmtud_min_mtu</i>  | (Optional) tunnel path MTU discovery min mtu   |
| <i>tunnel_pmtud</i>          | (Optional) tunnel path MTU discovered          |
| <i>tunnel_pgm_mtu</i>        | (Optional) tunnel actual programmed MTU        |
| <i>tunnel_rx_pkt_count</i>   | (Optional) total number of packets received    |
| <i>tunnel_rx_byte_count</i>  | (Optional) total number of bytes received      |



|                               |   |
|-------------------------------|---|
| <i>tunnel_rx_rate</i>         | (Optional) packets input rate per 5 minutes         |
| <i>tunnel_tx_pkt_count</i>    | (Optional) total number of packets transmitted      |
| <i>tunnel_tx_byte_count</i>   | (Optional) total number of bytes transmitted        |
| <i>tunnel_tx_rate</i>         | (Optional) packets transmitted per 5 minutes        |
| <i>tunnel_clear_counter</i>   | (Optional) Last clearing of show interface counters |
| <i>overlay_addr</i>           | (Optional) Overlay address                          |
| <i>overlay_addr_mask</i>      | (Optional) Overlay address mask                     |
| <i>overlay_mtu</i>            | (Optional) MTU                                      |
| <i>overlay_bandwidth</i>      | (Optional) Bandwidth                                |
| <i>overlay_encap_str</i>      | (Optional) Encap type                               |
| <i>overlay_vrf</i>            | (Optional) VRF                                      |
| <i>overlay_src_addr</i>       | (Optional) Source address                           |
| <i>overlay_dst_addr</i>       | (Optional) Destination address                      |
| <i>overlay_last_link_flap</i> | (Optional) Last link flap                           |
| <i>overlay_clear_counters</i> | (Optional) Last clearing of show interface counters |
| <i>overlay_load_interval</i>  | (Optional) Load interval                            |
| <i>overlay_rx_ucastpkts</i>   | (Optional) Received ucast pkts                      |
| <i>overlay_rx_ucastbytes</i>  | (Optional) Received ucast bytes                     |
| <i>overlay_rx_mcastpkts</i>   | (Optional) Received mcast pkts                      |
| <i>overlay_rx_mcastbytes</i>  | (Optional) Received mcast bytes                     |
| <i>overlay_rx_bcastpkts</i>   | (Optional) Received bcast pkts                      |
| <i>overlay_rx_bcastbytes</i>  | (Optional) Received bcast bytes                     |
| <i>overlay_rx_pkts</i>        | (Optional) Total received pkts                      |
| <i>overlay_rx_bytes</i>       | (Optional) Total received bytes                     |
| <i>overlay_rx_bitrate</i>     | (Optional) Receive bit rate                         |
| <i>overlay_rx_pktrate</i>     | (Optional) Receive pkt rate                         |
| <i>overlay_tx_ucastpkts</i>   | (Optional) Trasnmitted ucast pkts                   |
| <i>overlay_tx_ucastbytes</i>  | (Optional) Trasnmitted ucast bytes                  |
| <i>overlay_tx_mcastpkts</i>   | (Optional) Trasnmitted mcast pkts                   |

|                              |                                    |
|------------------------------|------------------------------------|
| <i>overlay_tx_mcastbytes</i> | (Optional) Trasnmitted mcast bytes |
| <i>overlay_tx_bcastpkts</i>  | (Optional) Trasnmitted bcast pkts  |
| <i>overlay_tx_bcastbytes</i> | (Optional) Trasnmitted bcast bytes |
| <i>overlay_tx_pkts</i>       | (Optional) Total transmitted pkts  |
| <i>overlay_tx_bytes</i>      | (Optional) Total transmitted bytes |
| <i>overlay_tx_bitrate</i>    | (Optional) Transmit bit rate       |
| <i>overlay_tx_pktrate</i>    | (Optional) Transmit pkt rate       |
| <i>switchport</i>            | (Optional) Switchport enabled      |

**Command Mode**

- /exec

# show interface

```
show interface <ifloop> [ __readonly__ TABLE_interface <interface> [ <state> ] [ <admin_state> ] [
<share_state> ] [ <state_rsn> ] [ <state_rsn_desc> ] [ <desc> ] [ <eth_bundle> ] [ <mgmt_sfp> ] [ <mgmt_type>
] [ <eth_eee_state> ] [ <eth_dce_mode> ] [ <vpc_status> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [
<eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix>
] [ <eth_mtu> ] [ <eth_bw> ] [ <eth_encap_vlan> ] [ <encapsulation> ] [ <eth_dly> ] [ <eth_reliability> ] [
<eth_txload> ] [ <eth_rxload> ] [ <eth_loopback> ] [ <eth_keepalive> ] [ <eth_duplex> ] [ <eth_speed> ] [
<eth_mode> ] [ <eth_ratemode> ] [ <eth_autoneg> ] [ <eth_beacon> ] [ <eth_media> ] [ <eth_in_flowctrl>
] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [ <eth_swt_monitor> ] [ <eth_ethertype> ] [ <eth_members> ] [
<eth_clk_mode> ] [ <eth_arp_type> ] [ <eth_arp_timeout> ] [ <eth_last_in> ] [ <eth_last_out> ] [
<eth_out_hang> ] [ <eth_clear_counters> ] [ <eth_link_flapped> ] [ <eth_inq_size> ] [ <eth_inq_max> ] [
<eth_inq_drops> ] [ <eth_inq_flush> ] [ <eth_out_drop> ] [ <eth_q_strategy> ] [ <eth_outq_size> ] [
<eth_outq_max> ] [ <eth_reset_cnt> ] [ <eth_tx_frm_error> ] [ <eth_rx_toolong> ] [ <eth_rx_undersize> ]
[ <eth_rx_fragment> ] [ <eth_rx_crcerr_not_stomped> ] [ <eth_rx_crcerr_stomped> ] [ <eth_rx_inrangeerr>
] [ <loop_in_pkts> ] [ <loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors>
] [ <loop_in_frame> ] [ <loop_in_overrun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [
<loop_out_underruns> ] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [
<loop_out_carriers> ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifloop</i>         | Enter interface type and number in module/slot format |
| <i>__readonly__</i>   | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>state</i>          | (Optional) Interface state                            |
| <i>admin_state</i>    | (Optional) Interface admin state                      |
| <i>share_state</i>    | (Optional) Interface ownership                        |
| <i>state_rsn</i>      | (Optional) Interface state reason                     |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed            |
| <i>desc</i>           | (Optional) Interface description                      |
| <i>mgmt_sfp</i>       | (Optional) mgmt sfp                                   |
| <i>mgmt_type</i>      | (Optional) mgmt type                                  |
| <i>eth_bundle</i>     | (Optional) Belongs to bundle                          |
| <i>eth_eee_state</i>  | (Optional) EEE state                                  |

|                         |                                  |
|-------------------------|----------------------------------|
| <i>eth_dce_mode</i>     | (Optional) DCE mode description  |
| <i>vpc_status</i>       | (Optional) VPC status            |
| <i>eth_rsn_fac</i>      | (Optional) State reason facility |
| <i>eth_rsn_code</i>     | (Optional) State reason code     |
| <i>eth_hw_desc</i>      | (Optional) HW description        |
| <i>eth_hw_addr</i>      | (Optional) HW address            |
| <i>eth_bia_addr</i>     | (Optional) bia address           |
| <i>eth_ip_addr</i>      | (Optional) IP Address            |
| <i>eth_ip_mask</i>      | (Optional) IP address mask       |
| <i>eth_ip_prefix</i>    | (Optional) IP Prefix             |
| <i>eth_mtu</i>          | (Optional) MTU                   |
| <i>eth_bw</i>           | (Optional) Bandwidth             |
| <i>eth_encap_vlan</i>   | (Optional) Encapsulation Vlan    |
| <i>encapsulation</i>    | (Optional) Encapsulation         |
| <i>eth_dly</i>          | (Optional) Delay                 |
| <i>eth_reliability</i>  | (Optional) Reliability           |
| <i>eth_txload</i>       | (Optional) Tx load               |
| <i>eth_rxload</i>       | (Optional) Rx load               |
| <i>eth_loopback</i>     | (Optional) Loopback              |
| <i>eth_keepalive</i>    | (Optional) Keepalive             |
| <i>eth_duplex</i>       | (Optional) Duplex                |
| <i>eth_speed</i>        | (Optional) Speed                 |
| <i>eth_mode</i>         | (Optional) Port mode             |
| <i>eth_ratemode</i>     | (Optional) Rate mode             |
| <i>eth_autoneg</i>      | (Optional) Autonegotiation       |
| <i>eth_beacon</i>       | (Optional) Beacon                |
| <i>eth_media</i>        | (Optional) Media type            |
| <i>eth_in_flowctrl</i>  | (Optional) Input flowcontrol     |
| <i>eth_out_flowctrl</i> | (Optional) Output flowcontrol    |

|                                  |   |
|----------------------------------|---|
| <i>eth_mdix</i>                  | (Optional) Mdx                                      |
| <i>eth_swt_monitor</i>           | (Optional) Switchport Monitor                       |
| <i>eth_ethertype</i>             | (Optional) EtherType                                |
| <i>eth_members</i>               | (Optional) Members in this channel                  |
| <i>eth_clk_mode</i>              | (Optional) Clock mode                               |
| <i>eth_arp_type</i>              | (Optional) ARP type                                 |
| <i>eth_arp_timeout</i>           | (Optional) ARP timeout                              |
| <i>eth_last_in</i>               | (Optional) Last input                               |
| <i>eth_last_out</i>              | (Optional) Last output                              |
| <i>eth_out_hang</i>              | (Optional) Last output hang                         |
| <i>eth_clear_counters</i>        | (Optional) Last clearing of show interface counters |
| <i>eth_link_flapped</i>          | (Optional) Last link flapped                        |
| <i>eth_inq_size</i>              | (Optional) Input queue size                         |
| <i>eth_inq_max</i>               | (Optional) Input queue max                          |
| <i>eth_inq_drops</i>             | (Optional) Input queue drops                        |
| <i>eth_inq_flush</i>             | (Optional) Input queue flushes                      |
| <i>eth_out_drop</i>              | (Optional) Output drops                             |
| <i>eth_q_strategy</i>            | (Optional) Queuing strategy                         |
| <i>eth_outq_size</i>             | (Optional) Output queue size                        |
| <i>eth_outq_max</i>              | (Optional) Output queue max                         |
| <i>eth_reset_cntr</i>            | (Optional) Interface resets                         |
| <i>eth_tx_frm_error</i>          | (Optional) tx frame error                           |
| <i>eth_rx_toolong</i>            | (Optional) rx toolong error                         |
| <i>eth_rx_undersize</i>          | (Optional) rx undersize                             |
| <i>eth_rx_fragment</i>           | (Optional) rx fragment                              |
| <i>eth_rx_crcerr_not_stomped</i> | (Optional) rx crcerr not stomped                    |
| <i>eth_rx_crcerr_stomped</i>     | (Optional) rx crcerr stomped                        |
| <i>eth_rx_inrangeerr</i>         | (Optional) rx inrange error                         |
| <i>loop_in_pkts</i>              | (Optional) Input packets                            |

|                            |                                  |
|----------------------------|----------------------------------|
| <i>loop_in_bytes</i>       | (Optional) Input bytes           |
| <i>loop_in_mcast</i>       | (Optional) Input multicast       |
| <i>loop_in_compressed</i>  | (Optional) Input compressed      |
| <i>loop_in_errors</i>      | (Optional) Input errors          |
| <i>loop_in_frame</i>       | (Optional) Input frame errors    |
| <i>loop_in_overrun</i>     | (Optional) Input overrun         |
| <i>loop_in_fifo</i>        | (Optional) Input fifo            |
| <i>loop_out_pkts</i>       | (Optional) Output packets        |
| <i>loop_out_bytes</i>      | (Optional) Output bytes          |
| <i>loop_out_underruns</i>  | (Optional) Output underruns      |
| <i>loop_out_errors</i>     | (Optional) Output errors         |
| <i>loop_out_collisions</i> | (Optional) Output collisions     |
| <i>loop_out_fifo</i>       | (Optional) Output fifo           |
| <i>loop_out_carriers</i>   | (Optional) Output carrier errors |

#### Command Mode

- /exec

# show interface

```
show interface <iftun_desc> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ] [
<desc> ] [ <admin-state> ] [ { <tunnel-ipv4> | <tunnel-ipv6> } ] [ <mtu> ] [ <bandwidth> ] [ <encap-type>
] [ <keepalive-period> ] [ <keepalive-retries> ] [ { <src-ipv4> | <src-ipv6> } ] [ <src-intf> ] [ { <dest-ipv4>
| <dest-ipv6> } ] [ <dest-hostname> ] [ <vrf_name> ] [ <tunnel_vrf_name> ] [ <wccp_header> ] [ <ttl_val>
] [ <tunnel_pmtud_age_time> ] [ <tunnel_pmtud_min_mtu> ] [ <tunnel_pmtud> ] [ <tunnel_pgm_mtu> ] [
<tunnel_clear_counter> ] [ <tunnel_tx_pkt_count> ] [ <tunnel_tx_byte_count> ] [ <tunnel_tx_rate> ] [
<tunnel_rx_pkt_count> ] [ <tunnel_rx_byte_count> ] [ <tunnel_rx_rate> ] ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                |
| interface                | Show interface status and information          |
| <i>iftun_desc</i>        | Enter tunnel interface number                  |
| <i>__readonly__</i>      | (Optional) Read Only                           |
| <i>interface</i>         | (Optional) Interface index                     |
| TABLE_interface          | (Optional) show interface                      |
| <i>state</i>             | (Optional) Interface state                     |
| <i>state_rsn_desc</i>    | (Optional) Interface state reason detailed     |
| <i>desc</i>              | (Optional) Interface description               |
| <i>admin-state</i>       | (Optional)                                     |
| <i>tunnel-ipv4</i>       | (Optional) interface IPv4 address              |
| <i>mtu</i>               | (Optional) interface Maximum Transmission Unit |
| <i>bandwidth</i>         | (Optional) interface Bandwidth in kilobits     |
| <i>encap-type</i>        | (Optional)                                     |
| <i>keepalive-period</i>  | (Optional) keealive period                     |
| <i>keepalive-retries</i> | (Optional) number of retries                   |
| <i>src-ipv4</i>          | (Optional) tunnel source IPv4 address          |
| <i>src-intf</i>          | (Optional) tunnel source interface             |
| <i>dest-ipv4</i>         | (Optional) tunnel destination IPv4 address     |
| <i>dest-hostname</i>     | (Optional) tunnel destination hostname         |
| <i>vrf_name</i>          | (Optional) transport VRF name                  |
| <i>tunnel_vrf_name</i>   | (Optional) tunnel VRF name                     |

|                              |   |
|------------------------------|---|
| <i>wccp_header</i>           | (Optional) wccp header                              |
| <i>ttl_val</i>               | (Optional) tunnel time to live value                |
| <i>tunnel_pmtud_age_time</i> | (Optional) tunnel path MTU discovery age time       |
| <i>tunnel_pmtud_min_mtu</i>  | (Optional) tunnel path MTU discovery min mtu        |
| <i>tunnel_pmtud</i>          | (Optional) tunnel path MTU discovered               |
| <i>tunnel_pgm_mtu</i>        | (Optional) tunnel actual programmed MTU             |
| <i>tunnel_rx_pkt_count</i>   | (Optional) total number of packets received         |
| <i>tunnel_rx_byte_count</i>  | (Optional) total number of bytes received           |
| <i>tunnel_rx_rate</i>        | (Optional) packets input rate per 5 minutes         |
| <i>tunnel_tx_pkt_count</i>   | (Optional) total number of packets transmitted      |
| <i>tunnel_tx_byte_count</i>  | (Optional) total number of bytes transmitted        |
| <i>tunnel_tx_rate</i>        | (Optional) packets transmitted per 5 minutes        |
| <i>tunnel_clear_counter</i>  | (Optional) Last clearing of show interface counters |

**Command Mode**

- /exec



## show interface

```
show interface <ifeth> [ quick ] [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ]
[ <state_rsn> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [ <admin_state> ] [ <share_state> ] [ <parent_interface> ]
[ <vpc_status> ] [ <eth_bundle> ] [ <eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [
<eth_ip_addr> ] [ <eth_ip_mask> ] [ <eth_ip_prefix> ] [ <eth_mtu> ] + [ <eth_bw> ] [ <eth_bw_str> ] [
<eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [ <eth_rxload> ] [ <eth_encap_vlan> ] [ <encapsulation> ]
[ <medium> ] [ <eth_mode> ] [ <eth_duplex> ] [ <eth_speed> ] [ <eth_media> ] [ <eth_beacon> ] [
<eth_autoneg> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [ <eth_ratemode> ] [
<eth_swt_monitor> ] [ <eth_ethertype> ] [ <eth_eee_state> ] [ <eth_admin_fec_state> ] [ <eth_oper_fec_state> ]
] [ <eth_members> ] [ <eth_link_flapped> ] [ <eth_clear_counters> ] [ <eth_reset_cntr> ] [
<eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [ <eth_load_interval1_tx> ] [
<eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ] [ <eth_inrate1_summary_pkts> ]
] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [ <eth_load_interval2_rx> ] [
<eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [ <eth_outrate2_bits> ] [
<eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ] [
<eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes> ]
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes> ]
] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_inpkts> ] [ <eth_inbytes> ] [ <eth_jumbo_inpkts> ]
] [ <eth_storm_supp> ] [ <eth_runts> ] [ <eth_giants> ] [ <eth_crc> ] [ <eth_nobuf> ] [ <eth_inerr> ] [
<eth_frame> ] [ <eth_overrun> ] [ <eth_underrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_bad_eth> ]
] [ <eth_bad_proto> ] [ <eth_in_ifdown_drops> ] [ <eth_dribble> ] [ <eth_indiscard> ] [ <eth_inpause> ] [
<eth_stomped_crc> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_outpkts> ] [
<eth_outbytes> ] [ <eth_jumbo_outpkts> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_deferred> ] [ <eth_latecoll> ]
] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_babbles> ] [ <eth_outdiscard> ] [ <eth_outpause> ] [
<switchport> ] ] ]
```

### Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information                       |
| interface        | Show interface status and information                 |
| <i>ifeth</i>     | Enter interface type and number in module/slot format |
| quick            | (Optional) Show info of interface skipping stats      |
| __readonly__     | (Optional) Read Only                                  |
| <i>interface</i> | (Optional) Interface index                            |
| TABLE_interface  | (Optional) show interface                             |
| <i>state</i>     | (Optional) Interface state                            |

|                         |  |
|-------------------------|--|
| <i>state_rsn_desc</i>   | (Optional) Interface state reason detailed |
| <i>state_rsn</i>        | (Optional) Interface state reason          |
| <i>eth_rsn_fac</i>      | (Optional) State reason facility           |
| <i>eth_rsn_code</i>     | (Optional) State reason code               |
| <i>admin_state</i>      | (Optional) admin state                     |
| <i>share_state</i>      | (Optional) Interface ownership             |
| <i>parent_interface</i> | (Optional) parent interface                |
| <i>vpc_status</i>       | (Optional) VPC status                      |
| <i>eth_bundle</i>       | (Optional) Belongs to bundle               |
| <i>eth_hw_desc</i>      | (Optional) HW description                  |
| <i>eth_hw_addr</i>      | (Optional) HW address                      |
| <i>eth_bia_addr</i>     | (Optional) bia address                     |
| <i>desc</i>             | (Optional) Interface description           |
| <i>eth_ip_addr</i>      | (Optional) IP Address                      |
| <i>eth_ip_mask</i>      | (Optional) IP address mask                 |
| <i>eth_ip_prefix</i>    | (Optional) IP address prefix               |
| <i>eth_mtu</i>          | (Optional) MTU                             |
| <i>eth_bw</i>           | (Optional) Bandwidth                       |
| <i>eth_bw_str</i>       | (Optional) Bandwidth                       |
| <i>eth_dly</i>          | (Optional) Delay                           |
| <i>eth_reliability</i>  | (Optional) Reliability                     |
| <i>eth_txload</i>       | (Optional) Tx load                         |
| <i>eth_rxload</i>       | (Optional) Rx load                         |
| <i>eth_encap_vlan</i>   | (Optional) Encapsulation Vlan              |
| <i>encapsulation</i>    | (Optional) Encapsulation                   |
| <i>medium</i>           | (Optional) medium type                     |
| <i>eth_mode</i>         | (Optional) Port mode                       |
| <i>eth_duplex</i>       | (Optional) Duplex                          |
| <i>eth_speed</i>        | (Optional) Speed                           |

|                                  |   |
|----------------------------------|---|
| <i>eth_media</i>                 | (Optional) Media type                               |
| <i>eth_beacon</i>                | (Optional) Beacon                                   |
| <i>eth_autoneg</i>               | (Optional) Autonegotiation                          |
| <i>eth_in_flowctrl</i>           | (Optional) Input flowcontrol                        |
| <i>eth_out_flowctrl</i>          | (Optional) Output flowcontrol                       |
| <i>eth_mdix</i>                  | (Optional) Mdx                                      |
| <i>eth_ratemode</i>              | (Optional) Rate mode                                |
| <i>eth_swt_monitor</i>           | (Optional) Switchport Monitor                       |
| <i>eth_ethertype</i>             | (Optional) EtherType                                |
| <i>eth_eee_state</i>             | (Optional) EEE state                                |
| <i>eth_admin_fec_state</i>       | (Optional) Admin FEC state                          |
| <i>eth_oper_fec_state</i>        | (Optional) Oper FEC state                           |
| <i>eth_members</i>               | (Optional) Members in this channel                  |
| <i>eth_link_flapped</i>          | (Optional) Last link flapped                        |
| <i>eth_clear_counters</i>        | (Optional) Last clearing of show interface counters |
| <i>eth_reset_cnr</i>             | (Optional) Interface resets                         |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec            |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec           |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec           |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec            |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec          |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec          |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary        |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary        |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary       |
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary       |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec            |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec           |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec           |

|                                  |   |
|----------------------------------|---|
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec    |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec    |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary  |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary  |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary |
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec    |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary  |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary  |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary |
| <i>eth_l2_ucastpkts</i>          | (Optional) L2 switched ucast pkts             |
| <i>eth_l2_ucastbytes</i>         | (Optional) L2 switched ucast bytes            |
| <i>eth_l2_mcastpkts</i>          | (Optional) L2 switched mcast pkts             |
| <i>eth_l2_mcastbytes</i>         | (Optional) L2 switched mcast bytes            |
| <i>eth_l2_bcastpkts</i>          | (Optional) L2 switched bcast pkts             |
| <i>eth_l2_bcastbytes</i>         | (Optional) L2 switched bcast bytes            |
| <i>eth_l3in_ucastpkts</i>        | (Optional) L3 in switched ucast pkts          |
| <i>eth_l3in_ucastbytes</i>       | (Optional) L3 in switched ucast bytes         |
| <i>eth_l3in_mcastpkts</i>        | (Optional) L3 in switched mcast pkts          |
| <i>eth_l3in_mcastbytes</i>       | (Optional) L3 in switched mcast bytes         |
| <i>eth_l3in_bcastpkts</i>        | (Optional) L3 in switched bcast pkts          |
| <i>eth_l3in_bcastbytes</i>       | (Optional) L3 in switched bcast bytes         |

|                               |  |
|-------------------------------|--|
| <i>eth_l3out_ucastpkts</i>    | (Optional) L3 out switched ucast pkts                    |
| <i>eth_l3out_ucastbytes</i>   | (Optional) L3 out switched ucast bytes                   |
| <i>eth_l3out_mcastpkts</i>    | (Optional) L3 out switched mcast pkts                    |
| <i>eth_l3out_mcastbytes</i>   | (Optional) L3 out switched mcast bytes                   |
| <i>eth_l3out_bcastpkts</i>    | (Optional) L3 out switched bcast pkts                    |
| <i>eth_l3out_bcastbytes</i>   | (Optional) L3 out switched bcast bytes                   |
| <i>eth_l3in_routed_pkts</i>   | (Optional) L3 in routed pkts                             |
| <i>eth_l3in_routed_bytes</i>  | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>  | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i> | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>     | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>      | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>    | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>     | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_inucast</i>            | (Optional) Unicasts                                      |
| <i>eth_inmcast</i>            | (Optional) Multicasts                                    |
| <i>eth_inbcast</i>            | (Optional) Broadcasts                                    |
| <i>eth_inpkts</i>             | (Optional) Packets input                                 |
| <i>eth_inbytes</i>            | (Optional) Bytes input                                   |
| <i>eth_jumbo_inpkts</i>       | (Optional) Incoming jumbo pkts                           |
| <i>eth_storm_supp</i>         | (Optional) storm suppression                             |
| <i>eth_runts</i>              | (Optional) runts   |
| <i>eth_giants</i>             | (Optional) giants  |
| <i>eth_crc</i>                | (Optional) CRC   |
| <i>eth_nobuf</i>              | (Optional) No buffer received                            |
| <i>eth_inerr</i>              | (Optional) input errors                                  |
| <i>eth_frame</i>              | (Optional) frame   |
| <i>eth_overrun</i>            | (Optional) overrun                                       |
| <i>eth_underrun</i>           | (Optional) underruns                                     |

|                            |   |
|----------------------------|---|
| <i>eth_ignored</i>         | (Optional) ignored                              |
| <i>eth_watchdog</i>        | (Optional) watchdog                             |
| <i>eth_bad_eth</i>         | (Optional) bad ether type drop                  |
| <i>eth_bad_proto</i>       | (Optional) bad protocol drops                   |
| <i>eth_in_ifdown_drops</i> | (Optional) Input if-down drops                  |
| <i>eth_dribble</i>         | (Optional) input packets with dribble condition |
| <i>eth_indiscard</i>       | (Optional) discards                             |
| <i>eth_inpause</i>         | (Optional) pause input                          |
| <i>eth_stomped_crc</i>     | (Optional) Stomped CRC                          |
| <i>eth_outucast</i>        | (Optional) Unicasts                             |
| <i>eth_outmcast</i>        | (Optional) Multicasts                           |
| <i>eth_outbcast</i>        | (Optional) Broadcasts                           |
| <i>eth_outpkts</i>         | (Optional) packets output                       |
| <i>eth_outbytes</i>        | (Optional) bytes output                         |
| <i>eth_jumbo_outpkts</i>   | (Optional) Outgoing jumbo pkts                  |
| <i>eth_outerr</i>          | (Optional) output errors                        |
| <i>eth_coll</i>            | (Optional) collisions                           |
| <i>eth_deferred</i>        | (Optional) deferred                             |
| <i>eth_latecoll</i>        | (Optional) late collision                       |
| <i>eth_lostcarrier</i>     | (Optional) lost carrier                         |
| <i>eth_nocarrier</i>       | (Optional) no carrier                           |
| <i>eth_babbles</i>         | (Optional) babbles                              |
| <i>eth_outdiscard</i>      | (Optional) output discard                       |
| <i>eth_outpause</i>        | (Optional) PAUSE output                         |
| <i>switchport</i>          | (Optional) Switchport enabled                   |

### Command Mode

- /exec

# show interface

```
show interface <ifveth> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn> ] <state_rsn_desc>
[ <desc> ] <veth_hw_desc> <veth_hw_addr> <veth_bia_addr> [ <veth_conn_name> ] [
<veth_conn_dev_name> ] [ <veth_vem_num> ] [ <veth_vmware_dvport_num> ] [ <veth_port_profile> ]
<veth_mode> <veth_inrate_bits> <veth_inrate_pkts> <veth_outrate_bits> <veth_outrate_pkts> <veth_inpkts>
<veth_inucast> <veth_inmcast> <veth_inbcast> <veth_inbytes> <veth_outpkts> <veth_outucast>
<veth_outmcast> <veth_outbcast> <veth_outfloods> <veth_outbytes> <veth_inpktdrops> <veth_outpktdrops>
]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information                       |
| interface                     | Show interface status and information                 |
| <i>ifveth</i>                 | Enter interface type and number in module/slot format |
| <i>__readonly__</i>           | (Optional) Read Only                                  |
| <i>interface</i>              | (Optional) Interface index                            |
| <i>TABLE_interface</i>        | (Optional) show interface                             |
| <i>state</i>                  | (Optional) Interface state                            |
| <i>state_rsn</i>              | (Optional) Interface state reason                     |
| <i>state_rsn_desc</i>         | (Optional) Interface state reason detailed            |
| <i>desc</i>                   | (Optional) Interface description                      |
| <i>veth_hw_desc</i>           | (Optional) HW description                             |
| <i>veth_hw_addr</i>           | (Optional) HW address                                 |
| <i>veth_bia_addr</i>          | (Optional) bia address                                |
| <i>veth_conn_name</i>         | (Optional) Connectee name                             |
| <i>veth_conn_dev_name</i>     | (Optional) Connectee device name                      |
| <i>veth_vem_num</i>           | (Optional) VEM the veth is active on                  |
| <i>veth_vmware_dvport_num</i> | (Optional) VMware DVPort number                       |
| <i>veth_port_profile</i>      | (Optional) Port Profile name                          |
| <i>veth_mode</i>              | (Optional) Port mode                                  |
| <i>veth_inrate_bits</i>       | (Optional) input rate bits/sec                        |
| <i>veth_inrate_pkts</i>       | (Optional) input rate pkts/sec                        |
| <i>veth_outrate_bits</i>      | (Optional) output rate bits/sec                       |

|                          |                                 |
|--------------------------|---------------------------------|
| <i>veth_outrate_pkts</i> | (Optional) output rate pkts/sec |
| <i>veth_inpkts</i>       | (Optional) Packets input        |
| <i>veth_inucast</i>      | (Optional) Unicasts input       |
| <i>veth_inmcast</i>      | (Optional) Multicasts input     |
| <i>veth_inbcast</i>      | (Optional) Broadcasts input     |
| <i>veth_inbytes</i>      | (Optional) Bytes input          |
| <i>veth_outpkts</i>      | (Optional) Packets output       |
| <i>veth_outucast</i>     | (Optional) Unicasts output      |
| <i>veth_outmcast</i>     | (Optional) Multicasts output    |
| <i>veth_outbcast</i>     | (Optional) Broadcasts output    |
| <i>veth_outfloods</i>    | (Optional) Flood packets output |
| <i>veth_outbytes</i>     | (Optional) Bytes output         |
| <i>veth_inpktdrops</i>   | (Optional) Packet drops input   |
| <i>veth_outpktdrops</i>  | (Optional) Packet drops output  |

**Command Mode**

- /exec



# show interface

```
show interface <ifrange> [ __readonly__ TABLE_interface <interface> <state> <state_rsn> <state_rsn_desc>
<desc> [ <overlay_addr> ] [ <overlay_addr_mask> ] [ <overlay_mtu> ] [ <overlay_bandwidth> ] [
<overlay_encap_str> ] [ <overlay_vrf> ] [ <overlay_src_addr> ] [ <overlay_dst_addr> ] [
<overlay_last_link_flap> ] [ <overlay_clear_counters> ] [ <overlay_load_interval> ] [ <overlay_rx_ucastpkts>
] [ <overlay_rx_ucastbytes> ] [ <overlay_rx_mcastpkts> ] [ <overlay_rx_mcastbytes> ] [ <overlay_rx_pkts>
] [ <overlay_rx_bytes> ] [ <overlay_rx_bcastpkts> ] [ <overlay_rx_bcastbytes> ] [ <overlay_rx_bitrate> ] [
<overlay_rx_pktrate> ] [ <overlay_tx_ucastpkts> ] [ <overlay_tx_ucastbytes> ] [ <overlay_tx_mcastpkts> ]
[ <overlay_tx_mcastbytes> ] [ <overlay_tx_bcastpkts> ] [ <overlay_tx_bcastbytes> ] [ <overlay_tx_pkts> ]
[ <overlay_tx_bytes> ] [ <overlay_tx_bitrate> ] [ <overlay_tx_pktrate> ] ]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information                     |
| interface                     | Show interface status and information               |
| <i>ifrange</i>                | Enter interface type and number                     |
| <i>__readonly__</i>           | (Optional) Read Only                                |
| <i>interface</i>              | (Optional) Interface index                          |
| TABLE_interface               | (Optional) show interface                           |
| <i>state</i>                  | (Optional) Interface state                          |
| <i>state_rsn</i>              | (Optional) Interface state reason                   |
| <i>state_rsn_desc</i>         | (Optional) Interface state reason detailed          |
| <i>desc</i>                   | (Optional) Interface description                    |
| <i>overlay_addr</i>           | (Optional) Overlay address                          |
| <i>overlay_addr_mask</i>      | (Optional) Overlay address mask                     |
| <i>overlay_mtu</i>            | (Optional) MTU                                      |
| <i>overlay_bandwidth</i>      | (Optional) Bandwidth                                |
| <i>overlay_encap_str</i>      | (Optional) Encap type                               |
| <i>overlay_vrf</i>            | (Optional) VRF                                      |
| <i>overlay_src_addr</i>       | (Optional) Source address                           |
| <i>overlay_dst_addr</i>       | (Optional) Destination address                      |
| <i>overlay_last_link_flap</i> | (Optional) Last link flap                           |
| <i>overlay_clear_counters</i> | (Optional) Last clearing of show interface counters |

|                              |                                    |
|------------------------------|------------------------------------|
| <i>overlay_load_interval</i> | (Optional) Load interval           |
| <i>overlay_rx_ucastpkts</i>  | (Optional) Received ucast pkts     |
| <i>overlay_rx_ucastbytes</i> | (Optional) Received ucast bytes    |
| <i>overlay_rx_mcastpkts</i>  | (Optional) Received mcast pkts     |
| <i>overlay_rx_mcastbytes</i> | (Optional) Received mcast bytes    |
| <i>overlay_rx_bcastpkts</i>  | (Optional) Received bcast pkts     |
| <i>overlay_rx_bcastbytes</i> | (Optional) Received bcast bytes    |
| <i>overlay_rx_pkts</i>       | (Optional) Total received pkts     |
| <i>overlay_rx_bytes</i>      | (Optional) Total received bytes    |
| <i>overlay_rx_bitrate</i>    | (Optional) Receive bit rate        |
| <i>overlay_rx_pktrate</i>    | (Optional) Receive pkt rate        |
| <i>overlay_tx_ucastpkts</i>  | (Optional) Trasnmitted ucast pkts  |
| <i>overlay_tx_ucastbytes</i> | (Optional) Trasnmitted ucast bytes |
| <i>overlay_tx_mcastpkts</i>  | (Optional) Trasnmitted mcast pkts  |
| <i>overlay_tx_mcastbytes</i> | (Optional) Trasnmitted mcast bytes |
| <i>overlay_tx_bcastpkts</i>  | (Optional) Trasnmitted bcast pkts  |
| <i>overlay_tx_bcastbytes</i> | (Optional) Trasnmitted bcast bytes |
| <i>overlay_tx_pkts</i>       | (Optional) Total transmitted pkts  |
| <i>overlay_tx_bytes</i>      | (Optional) Total transmitted bytes |
| <i>overlay_tx_bitrate</i>    | (Optional) Transmit bit rate       |
| <i>overlay_tx_pktrate</i>    | (Optional) Transmit pkt rate       |

### Command Mode

- /exec

## show interface

```
show interface <ifrange> [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn_desc> ] [
<state_rsn> ] [ <admin_state> ] [ <eth_rsn_fac> ] [ <eth_rsn_code> ] [ <share_state> ] [ <vpc_status> ] [
<eth_bundle> ] [ <eth_hw_desc> ] [ <eth_hw_addr> ] [ <eth_bia_addr> ] [ <desc> ] [ <eth_ip_addr> ] [
<eth_ip_mask> ] [ <eth_mtu> ] [ <eth_bw> ] [ <eth_dly> ] [ <eth_reliability> ] [ <eth_txload> ] [ <eth_rxload>
] [ <eth_encap_vlan> ] [ <encapsulation> ] [ <eth_mode> ] [ <eth_duplex> ] [ <eth_speed> ] [ <eth_media>
] [ <eth_beacon> ] [ <eth_autoneg> ] [ <eth_in_flowctrl> ] [ <eth_out_flowctrl> ] [ <eth_mdix> ] [
<eth_ratemode> ] [ <eth_swt_monitor> ] [ <eth_etherstype> ] [ <eth_members> ] [ <eth_link_flapped> ] [
<eth_clear_counters> ] [ <eth_reset_cntr> ] [ <nve_addr> ] [ <nve_addr_mask> ] [ <nve_vcid> ] [ <nve_mtu>
] [ <nve_bandwidth> ] [ <nve_encap_str> ] [ <nve_vrf> ] [ <nve_src_addr> ] [ <nve_dst_addr> ] [
<nve_last_link_flap> ] [ <nve_clear_counters> ] [ <nve_load_interval> ] [ <nve_rx_ucastpkts> ] [
<nve_rx_ucastbytes> ] [ <nve_rx_mcastpkts> ] [ <nve_rx_mcastbytes> ] [ <nve_rx_pkts> ] [ <nve_rx_bytes>
] [ <nve_rx_bcastpkts> ] [ <nve_rx_bcastbytes> ] [ <nve_rx_bitrate> ] [ <nve_rx_pktrate> ] [
<nve_tx_ucastpkts> ] [ <nve_tx_ucastbytes> ] [ <nve_tx_mcastpkts> ] [ <nve_tx_mcastbytes> ] [
<nve_tx_bcastpkts> ] [ <nve_tx_bcastbytes> ] [ <nve_tx_pkts> ] [ <nve_tx_bytes> ] [ <nve_tx_bitrate> ] [
<nve_tx_pktrate> ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information            |
| interface             | Show interface status and information      |
| <i>ifrange</i>        | Enter interface type and number            |
| <i>__readonly__</i>   | (Optional) Read Only                       |
| <i>interface</i>      | (Optional) Interface index                 |
| TABLE_interface       | (Optional) show interface                  |
| <i>state</i>          | (Optional) Interface state                 |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed |
| <i>state_rsn</i>      | (Optional) Interface state reason          |
| <i>admin_state</i>    | (Optional) admin state                     |
| <i>eth_rsn_fac</i>    | (Optional) State reason facility           |
| <i>eth_rsn_code</i>   | (Optional) State reason code               |
| <i>share_state</i>    | (Optional) Interface ownership             |
| <i>vpc_status</i>     | (Optional) VPC status                      |
| <i>eth_bundle</i>     | (Optional) Belongs to bundle               |
| <i>eth_hw_desc</i>    | (Optional) HW description                  |
| <i>eth_hw_addr</i>    | (Optional) HW address                      |

|                           |   |
|---------------------------|---|
| <i>eth_bia_addr</i>       | (Optional) bia address                              |
| <i>desc</i>               | (Optional) Interface description                    |
| <i>eth_ip_addr</i>        | (Optional) IP Address                               |
| <i>eth_ip_mask</i>        | (Optional) IP address mask                          |
| <i>eth_mtu</i>            | (Optional) MTU                                      |
| <i>eth_bw</i>             | (Optional) Bandwidth                                |
| <i>eth_dly</i>            | (Optional) Delay                                    |
| <i>eth_reliability</i>    | (Optional) Reliability                              |
| <i>eth_txload</i>         | (Optional) Tx load                                  |
| <i>eth_rxload</i>         | (Optional) Rx load                                  |
| <i>eth_encap_vlan</i>     | (Optional) Encapsulation Vlan                       |
| <i>encapsulation</i>      | (Optional) Encapsulation                            |
| <i>eth_mode</i>           | (Optional) Port mode                                |
| <i>eth_duplex</i>         | (Optional) Duplex                                   |
| <i>eth_speed</i>          | (Optional) Speed                                    |
| <i>eth_media</i>          | (Optional) Media type                               |
| <i>eth_beacon</i>         | (Optional) Beacon                                   |
| <i>eth_autoneg</i>        | (Optional) Autonegotiation                          |
| <i>eth_in_flowctrl</i>    | (Optional) Input flowcontrol                        |
| <i>eth_out_flowctrl</i>   | (Optional) Output flowcontrol                       |
| <i>eth_mdix</i>           | (Optional) Mdix                                     |
| <i>eth_ratemode</i>       | (Optional) Rate mode                                |
| <i>eth_swt_monitor</i>    | (Optional) Switchport Monitor                       |
| <i>eth_etherstype</i>     | (Optional) EtherType                                |
| <i>eth_members</i>        | (Optional) Members in this channel                  |
| <i>eth_link_flapped</i>   | (Optional) Last link flapped                        |
| <i>eth_clear_counters</i> | (Optional) Last clearing of show interface counters |
| <i>eth_reset_cntr</i>     | (Optional) Interface resets                         |
| <i>nve_addr</i>           | (Optional) Peer address                             |

|                           |   |
|---------------------------|---|
| <i>nve_addr_mask</i>      | (Optional) Peer address mask                        |
| <i>nve_vcid</i>           | (Optional) VCID                                     |
| <i>nve_mtu</i>            | (Optional) MTU                                      |
| <i>nve_bandwidth</i>      | (Optional) Bandwidth                                |
| <i>nve_encap_str</i>      | (Optional) Encap type                               |
| <i>nve_vrf</i>            | (Optional) VRF                                      |
| <i>nve_src_addr</i>       | (Optional) Source address                           |
| <i>nve_dst_addr</i>       | (Optional) Destination address                      |
| <i>nve_last_link_flap</i> | (Optional) Last link flap                           |
| <i>nve_clear_counters</i> | (Optional) Last clearing of show interface counters |
| <i>nve_load_interval</i>  | (Optional) Load interval                            |
| <i>nve_rx_ucastpkts</i>   | (Optional) Received ucast pkts                      |
| <i>nve_rx_ucastbytes</i>  | (Optional) Received ucast bytes                     |
| <i>nve_rx_mcastpkts</i>   | (Optional) Received mcast pkts                      |
| <i>nve_rx_mcastbytes</i>  | (Optional) Received mcast bytes                     |
| <i>nve_rx_bcastpkts</i>   | (Optional) Received bcast pkts                      |
| <i>nve_rx_bcastbytes</i>  | (Optional) Received bcast bytes                     |
| <i>nve_rx_pkts</i>        | (Optional) Total received pkts                      |
| <i>nve_rx_bytes</i>       | (Optional) Total received bytes                     |
| <i>nve_rx_bitrate</i>     | (Optional) Receive bit rate                         |
| <i>nve_rx_pktrate</i>     | (Optional) Receive pkt rate                         |
| <i>nve_tx_ucastpkts</i>   | (Optional) Trasnmitted ucast pkts                   |
| <i>nve_tx_ucastbytes</i>  | (Optional) Trasnmitted ucast bytes                  |
| <i>nve_tx_mcastpkts</i>   | (Optional) Trasnmitted mcast pkts                   |
| <i>nve_tx_mcastbytes</i>  | (Optional) Trasnmitted mcast bytes                  |
| <i>nve_tx_bcastpkts</i>   | (Optional) Trasnmitted bcast pkts                   |
| <i>nve_tx_bcastbytes</i>  | (Optional) Trasnmitted bcast bytes                  |
| <i>nve_tx_pkts</i>        | (Optional) Total transmitted pkts                   |
| <i>nve_tx_bytes</i>       | (Optional) Total transmitted bytes                  |

|                       |                              |
|-----------------------|------------------------------|
| <i>nve_tx_bitrate</i> | (Optional) Transmit bit rate |
| <i>nve_tx_pktrate</i> | (Optional) Transmit pkt rate |

**Command Mode**

- /exec

## show interface aggregate-counters

```
show interface <ifid_aggr_ctrs> aggregate-counters [ brief ] [ __readonly__ TABLE_interface <interface_aggr>
[ <str_aggr> ] [ <if_index_aggr> ] [ <in_bps_aggr> ] [ <in_byps_aggr> ] [ <in_fps_aggr> ] [ <out_bps_aggr> ]
[ <out_byps_aggr> ] [ <out_fps_aggr> ] [ <total_in_frames_aggr> ] [ <total_in_bytes_aggr> ] [
<C2InFrames_aggr> ] [ <C2InOctets_aggr> ] [ <C3InFrames_aggr> ] [ <C3InOctets_aggr> ] [
<CfInFrames_aggr> ] [ <CfInOctets_aggr> ] [ <total_in_discards_aggr> ] [ <total_in_errors_aggr> ] [
<InvalidCrcs_aggr> ] [ <UnknownClassFrames_aggr> ] [ <FramesTooLong_aggr> ] [ <FramesTooShort_aggr> ]
[ <total_out_frames_aggr> ] [ <total_out_bytes_aggr> ] [ <C2OutFrames_aggr> ] [ <C2OutOctets_aggr> ]
[ <C3OutFrames_aggr> ] [ <C3OutOctets_aggr> ] [ <CfOutFrames_aggr> ] [ <CfOutOctets_aggr> ] [
<total_out_discards_aggr> ] [ <total_out_errors_aggr> ] [ <OlsIns_aggr> ] [ <LRRIn_aggr> ] [ <NOSIn_aggr> ]
[ <in_lip_aggr> ] [ <OlsOuts_aggr> ] [ <LRROut_aggr> ] [ <NOSOut_aggr> ] [ <out_lip_aggr> ] [
<LinkFailures_aggr> ] [ <SyncLosses_aggr> ] [ <SigLosses_aggr> ] [ <TxBBCreditTransistionToZero_aggr> ]
[ <RxBBCreditTransistionToZero_aggr> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit> ]
[ <tx_b2b_low_pri_cre> ] [ <InputRate_aggr_brief> ] [ <TotalIpFrame_aggr_brief> ] [ <OutRate_aggr_brief> ]
[ <TotalOpFrame_aggr_brief> ] [ <line_aggr_brief> ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                       |
| interface                   | Show interface status and information                 |
| <i>ifid_aggr_ctrs</i>       | Enter interface type and number in module/slot format |
| aggregate-counters          | Show interface aggregate counters                     |
| brief                       | (Optional) Show interface aggregate counters in brief |
| __readonly__                | (Optional) Read Only                                  |
| <i>interface_aggr</i>       | (Optional) Interface index                            |
| TABLE_interface             | (Optional) show interface                             |
| <i>str_aggr</i>             | (Optional) string                                     |
| <i>if_index_aggr</i>        | (Optional) index                                      |
| <i>in_bps_aggr</i>          | (Optional) input rate in bits/s                       |
| <i>in_byps_aggr</i>         | (Optional) input rate in bytes/s                      |
| <i>in_fps_aggr</i>          | (Optional) input rate in frames/s                     |
| <i>out_bps_aggr</i>         | (Optional) output rate in bits/s                      |
| <i>out_byps_aggr</i>        | (Optional) output rate in bytes/s                     |
| <i>out_fps_aggr</i>         | (Optional) output rate in frames/s                    |
| <i>total_in_frames_aggr</i> | (Optional) total input frames                         |
| <i>total_in_bytes_aggr</i>  | (Optional) total input frames                         |

|                                |  |
|--------------------------------|--|
| <i>C2InFrames_aggr</i>         | (Optional) class-2 frames              |
| <i>C2InOctets_aggr</i>         | (Optional) class-2 frames in bytes     |
| <i>C3InFrames_aggr</i>         | (Optional) class-3 frames              |
| <i>C3InOctets_aggr</i>         | (Optional) class-3 frames in bytes     |
| <i>CfInFrames_aggr</i>         | (Optional) class-f frames              |
| <i>CfInOctets_aggr</i>         | (Optional) class-f frames in bytes     |
| <i>total_in_discards_aggr</i>  | (Optional) total in discards           |
| <i>total_in_errors_aggr</i>    | (Optional) total in errors             |
| <i>InvalidCrcs_aggr</i>        | (Optional) invalid CRC                 |
| <i>UnknownClassFrames_aggr</i> | (Optional) unknown class               |
| <i>FramesTooLong_aggr</i>      | (Optional) too long                    |
| <i>FramesTooShort_aggr</i>     | (Optional) too short                   |
| <i>total_out_frames_aggr</i>   | (Optional) total out frames            |
| <i>total_out_bytes_aggr</i>    | (Optional) total out frames in byte    |
| <i>C2OutFrames_aggr</i>        | (Optional) class-2 out frames          |
| <i>C2OutOctets_aggr</i>        | (Optional) class-2 out frames in bytes |
| <i>C3OutFrames_aggr</i>        | (Optional) class-3 out frames          |
| <i>C3OutOctets_aggr</i>        | (Optional) class-3 out frames in bytes |
| <i>CfOutFrames_aggr</i>        | (Optional) class-f out frames          |
| <i>CfOutOctets_aggr</i>        | (Optional) class-f out frames in bytes |
| <i>total_out_discards_aggr</i> | (Optional) total out discards          |
| <i>total_out_errors_aggr</i>   | (Optional) total out errors            |
| <i>OlsIns_aggr</i>             | (Optional) input OLS                   |
| <i>LRRIn_aggr</i>              | (Optional) input LRR                   |
| <i>NOSIn_aggr</i>              | (Optional) input NOS                   |
| <i>in_lip_aggr</i>             | (Optional) loop inits                  |
| <i>OlsOuts_aggr</i>            | (Optional) output OLS                  |
| <i>LRROut_aggr</i>             | (Optional) output LRR                  |
| <i>NOSOut_aggr</i>             | (Optional) output NOS                  |



|   |   |
|---|---|
| <i>out_lip_aggr</i>                     | (Optional) loop inits                     |
| <i>LinkFailures_aggr</i>                | (Optional) link failure                   |
| <i>SyncLosses_aggr</i>                  | (Optional) sync losses                    |
| <i>SigLosses_aggr</i>                   | (Optional) signal losses                  |
| <i>TxBBCreditTransistionToZero_aggr</i> | (Optional) B2B credit transitions to zero |
| <i>RxBBCreditTransistionToZero_aggr</i> | (Optional) B2B credit transitions to zero |
| <i>rx_b2b_perf_buff</i>                 | (Optional) rx B2B performance buff        |
| <i>rx_b2b_credit</i>                    | (Optional) rx B2B credit                  |
| <i>tx_b2b_credit</i>                    | (Optional) tx B2B credit                  |
| <i>tx_b2b_low_pri_cre</i>               | (Optional) tx B2B low price credit        |
| <i>InputRate_aggr_brief</i>             | (Optional) Input rate in MBps             |
| <i>TotalIpFrame_aggr_brief</i>          | (Optional) Total input frames             |
| <i>OutRate_aggr_brief</i>               | (Optional) Output rate in MBps            |
| <i>TotalOpFrame_aggr_brief</i>          | (Optional) Total output frames            |
| <i>line_aggr_brief</i>                  | (Optional) to print a line                |

### Command Mode

- /exec

## show interface aggregate-counters

```
show interface aggregate-counters [ brief ] [ __readonly__ TABLE_interface <interface_aggr> [ <str_aggr>
] [ <if_index_aggr> ] [ <in_bps_aggr> ] [ <in_byps_aggr> ] [ <in_fps_aggr> ] [ <out_bps_aggr> ] [
<out_byps_aggr> ] [ <out_fps_aggr> ] [ <total_in_frames_aggr> ] [ <total_in_bytes_aggr> ] [
<C2InFrames_aggr> ] [ <C2InOctets_aggr> ] [ <C3InFrames_aggr> ] [ <C3InOctets_aggr> ] [
<CfInFrames_aggr> ] [ <CfInOctets_aggr> ] [ <total_in_discards_aggr> ] [ <total_in_errors_aggr> ] [
<InvalidCrcs_aggr> ] [ <UnknownClassFrames_aggr> ] [ <FramesTooLong_aggr> ] [ <FramesTooShort_aggr>
] [ <total_out_frames_aggr> ] [ <total_out_bytes_aggr> ] [ <C2OutFrames_aggr> ] [ <C2OutOctets_aggr> ] [
<C3OutFrames_aggr> ] [ <C3OutOctets_aggr> ] [ <CfOutFrames_aggr> ] [ <CfOutOctets_aggr> ] [
<total_out_discards_aggr> ] [ <total_out_errors_aggr> ] [ <OlsIns_aggr> ] [ <LRRIn_aggr> ] [ <NOSIn_aggr>
] [ <in_lip_aggr> ] [ <OlsOuts_aggr> ] [ <LRROut_aggr> ] [ <NOSOut_aggr> ] [ <out_lip_aggr> ] [
<LinkFailures_aggr> ] [ <SyncLosses_aggr> ] [ <SigLosses_aggr> ] [ <TxBBCreditTransistionToZero_aggr>
] [ <RxBBCreditTransistionToZero_aggr> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [ <tx_b2b_credit>
] [ <tx_b2b_low_pri_cre> ] [ <InputRate_aggr_brief> ] [ <TotalIpFrame_aggr_brief> ] [ <OutRate_aggr_brief>
] [ <TotalOpFrame_aggr_brief> ] [ <line_aggr_brief> ] ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                       |
| interface                   | Show interface status and information                 |
| aggregate-counters          | Show interface aggregate counters                     |
| brief                       | (Optional) Show interface aggregate counters in brief |
| __readonly__                | (Optional) Read Only                                  |
| <i>interface_aggr</i>       | (Optional) Interface index                            |
| TABLE_interface             | (Optional) show interface                             |
| <i>str_aggr</i>             | (Optional) string                                     |
| <i>if_index_aggr</i>        | (Optional) index                                      |
| <i>in_bps_aggr</i>          | (Optional) input rate in bits/s                       |
| <i>in_byps_aggr</i>         | (Optional) input rate in bytes/s                      |
| <i>in_fps_aggr</i>          | (Optional) input rate in frames/s                     |
| <i>out_bps_aggr</i>         | (Optional) output rate in bits/s                      |
| <i>out_byps_aggr</i>        | (Optional) output rate in bytes/s                     |
| <i>out_fps_aggr</i>         | (Optional) output rate in frames/s                    |
| <i>total_in_frames_aggr</i> | (Optional) total input frames                         |
| <i>total_in_bytes_aggr</i>  | (Optional) total input frames                         |
| <i>C2InFrames_aggr</i>      | (Optional) class-2 frames                             |

|                                |  |
|--------------------------------|--|
| <i>C2InOctets_aggr</i>         | (Optional) class-2 frames in bytes     |
| <i>C3InFrames_aggr</i>         | (Optional) class-3 frames              |
| <i>C3InOctets_aggr</i>         | (Optional) class-3 frames in bytes     |
| <i>CfInFrames_aggr</i>         | (Optional) class-f frames              |
| <i>CfInOctets_aggr</i>         | (Optional) class-f frames in bytes     |
| <i>total_in_discards_aggr</i>  | (Optional) total in discards           |
| <i>total_in_errors_aggr</i>    | (Optional) total in errors             |
| <i>InvalidCrcs_aggr</i>        | (Optional) invalid CRC                 |
| <i>UnknownClassFrames_aggr</i> | (Optional) unknown class               |
| <i>FramesTooLong_aggr</i>      | (Optional) too long                    |
| <i>FramesTooShort_aggr</i>     | (Optional) too short                   |
| <i>total_out_frames_aggr</i>   | (Optional) total out frames            |
| <i>total_out_bytes_aggr</i>    | (Optional) total out frames in byte    |
| <i>C2OutFrames_aggr</i>        | (Optional) class-2 out frames          |
| <i>C2OutOctets_aggr</i>        | (Optional) class-2 out frames in bytes |
| <i>C3OutFrames_aggr</i>        | (Optional) class-3 out frames          |
| <i>C3OutOctets_aggr</i>        | (Optional) class-3 out frames in bytes |
| <i>CfOutFrames_aggr</i>        | (Optional) class-f out frames          |
| <i>CfOutOctets_aggr</i>        | (Optional) class-f out frames in bytes |
| <i>total_out_discards_aggr</i> | (Optional) total out discards          |
| <i>total_out_errors_aggr</i>   | (Optional) total out errors            |
| <i>OlsIns_aggr</i>             | (Optional) input OLS                   |
| <i>LRRIn_aggr</i>              | (Optional) input LRR                   |
| <i>NOSIn_aggr</i>              | (Optional) input NOS                   |
| <i>in_lip_aggr</i>             | (Optional) loop inits                  |
| <i>OlsOuts_aggr</i>            | (Optional) output OLS                  |
| <i>LRROut_aggr</i>             | (Optional) output LRR                  |
| <i>NOSOut_aggr</i>             | (Optional) output NOS                  |
| <i>out_lip_aggr</i>            | (Optional) loop inits                  |

|   |   |
|---|---|
| <i>LinkFailures_aggr</i>                | (Optional) link failure                   |
| <i>SyncLosses_aggr</i>                  | (Optional) sync losses                    |
| <i>SigLosses_aggr</i>                   | (Optional) signal losses                  |
| <i>TxBBCreditTransistionToZero_aggr</i> | (Optional) B2B credit transitions to zero |
| <i>RxBBCreditTransistionToZero_aggr</i> | (Optional) B2B credit transitions to zero |
| <i>rx_b2b_perf_buff</i>                 | (Optional) rx B2B performance buff        |
| <i>rx_b2b_credit</i>                    | (Optional) rx B2B credit                  |
| <i>tx_b2b_credit</i>                    | (Optional) tx B2B credit                  |
| <i>tx_b2b_low_pri_cre</i>               | (Optional) tx B2B low price credit        |
| <i>InputRate_aggr_brief</i>             | (Optional) Input rate in MBps             |
| <i>TotalIpFrame_aggr_brief</i>          | (Optional) Total input frames             |
| <i>OutRate_aggr_brief</i>               | (Optional) Output rate in MBps            |
| <i>TotalOpFrame_aggr_brief</i>          | (Optional) Total output frames            |
| <i>line_aggr_brief</i>                  | (Optional) to print a line                |

**Command Mode**

- /exec

## show interface bbcredit

```
show interface <ifid_bbcrd> bbcredit [ __readonly__ TABLE_interface [ <interface_sfp> <state> [
<down_reason> ] [ <transmit_b2b> ] [ <receive_b2b> ] [ <rx_b2b_perf_buff> ] [ <rx_b2b_credit> ] [
<tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                       |
| interface                 | Show interface status and information                 |
| <i>ifid_bbcrd</i>         | Enter interface type and number in module/slot format |
| bbcredit                  | Show BB_credit information for interface              |
| <i>__readonly__</i>       | (Optional) Read Only                                  |
| <i>interface_sfp</i>      | (Optional) Interface index                            |
| TABLE_interface           | (Optional) show interface                             |
| <i>state</i>              | (Optional) State                                      |
| <i>down_reason</i>        | (Optional) Reason for interface being down            |
| <i>transmit_b2b</i>       | (Optional) Transmit B2B                               |
| <i>receive_b2b</i>        | (Optional) Receive B2B                                |
| <i>rx_b2b_perf_buff</i>   | (Optional) RX B2B performance buffer                  |
| <i>rx_b2b_credit</i>      | (Optional) RX B2B credit remaining                    |
| <i>tx_b2b_credit</i>      | (Optional) TX B2B credit remaining                    |
| <i>tx_b2b_low_pri_cre</i> | (Optional) TX B2B low priority Credit                 |

### Command Mode

- /exec

## show interface brief

```
show interface <ifrange> brief [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn> ] [
<state_rsn_desc> ] [ <admin_state> ] [ <nve_addr> ] [ <nve_vcid> ] [ <nve_mtu> ] [ <nve_bandwidth> ] [
<nve_vrf> ] [ <nve_src_addr> ] [ <nve_dst_addr> ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information            |
| interface              | Show interface status and information      |
| <i>ifrange</i>         | Enter interface type and number            |
| brief                  | Show brief info of interface               |
| <i>__readonly__</i>    | (Optional) Read Only                       |
| <i>interface</i>       | (Optional) Interface index                 |
| <i>TABLE_interface</i> | (Optional) show interface                  |
| <i>state</i>           | (Optional) Interface state                 |
| <i>state_rsn</i>       | (Optional) Interface state reason          |
| <i>state_rsn_desc</i>  | (Optional) Interface state reason detailed |
| <i>admin_state</i>     | (Optional) admin state                     |
| <i>nve_addr</i>        | (Optional) Peer address                    |
| <i>nve_vcid</i>        | (Optional) VCID                            |
| <i>nve_mtu</i>         | (Optional) MTU                             |
| <i>nve_bandwidth</i>   | (Optional) Bandwidth                       |
| <i>nve_vrf</i>         | (Optional) VRF                             |
| <i>nve_src_addr</i>    | (Optional) Source address                  |
| <i>nve_dst_addr</i>    | (Optional) Destination address             |

### Command Mode

- /exec

## show interface brief

```

show interface <ifid_brf> brief [ __readonly__ { TABLE_interface <interface> [ <desc> ] [ <svi_if_index>
] [ <svi_admin_state> ] [ <oper_state> ] [ <svi_rsn_desc> ] [ <svi_line_proto> ] [ <svi_hw> ] [ <svi_mac> ]
[ <svi_desc> ] [ <svi_ip_addr> ] [ <svi_ip_mask> ] [ <svi_mtu> ] [ <svi_bw> ] [ <svi_delay> ] [ <vlan_id>
] [ <type> ] ] [ <svi_tx_load> ] [ <svi_rx_load> ] ] [ <svi_carrier_delay_sec> ] [ <svi_carrier_delay_msec>
] [ <svi_arp_type> ] [ <svi_arp_timeout> ] ] [ <svi_time_last_cleared> ] ] [ { TABLE_secondary_vlan
<sec_vlan> <sec_vlan_type> } ] [ <eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ]
[ <eth_load_interval1_tx> ] [ <eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits>
] [ <eth_inrate1_summary_pkts> ] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [
<eth_load_interval2_rx> ] [ <eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [
<eth_outrate2_bits> ] [ <eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts>
] [ <eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes>
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes>
] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_l3avg2_inbytes> ] [ <eth_l3avg2_inpkts> ] [ <eth_l3avg2_outbytes> ] [ <eth_l3avg2_outpkts> ] [
<eth_l3avg3_inbytes> ] [ <eth_l3avg3_inpkts> ] [ <eth_l3avg3_outbytes> ] [ <eth_l3avg3_outpkts> ] [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_nobuf> ] [ <eth_inbcast> ] [ <eth_inmcast> ] [ <eth_inucast> ] [
<eth_ingiants> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [ <eth_insw_switched> ] [ <eth_runts> ] [
<eth_storm_supp> ] [ <eth_throtles> ] [ <eth_inerr> ] [ <eth_crc> ] [ <eth_ecc> ] [ <eth_frame> ] [
<eth_overrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_outbcast> ] [ <eth_outmcast> ] [ <eth_outucast>
] [ <eth_outgiants> ] [ <eth_inpause> ] [ <eth_dribble> ] [ <eth_in_ifdown_drops> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_underrun> ] [ <eth_outhw_switched> ] [
<eth_outsw_switched> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_resets> ] [ <eth_babbles> ] [ <eth_latecoll> ]
[ <eth_deferred> ] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_outpause> ] [ <eth_buffail> ] [
<eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_single_coll> ] [ <eth_multi_coll>
] [ <eth_excess_coll> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [
<eth_outcrc> ] [ <eth_symbol> ] [ <eth_out_drops> ] [ <eth_sqetest> ] [ <eth_inb64> ] [ <eth_inb65_127>
] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [ <eth_inb1024_1518> ] [
<eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outb64> ] [ <eth_outb65_127> ] [ <eth_outb128_255> ] [
<eth_outb256_511> ] [ <eth_outb512_1023> ] [ <eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [
<eth_outtrunk> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_fcoe_in_pkts> ] [ <eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [
<eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [ <eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [
<eth_nfcoe_out_octets> ] [ <eth_eee_atx_lpi_msec> ] [ <eth_eee_arcv_lpi_msec> ] [
<eth_eee_atx_lpi_transitions> ] [ <eth_eee_arcv_lpi_transitions> ] [ <eth_phy_ber_count> ] [
<eth_phy_errblks_count> ] [ <eth_tx_frm_error> ] [ <eth_rx_toolong> ] [ <eth_rx_undersize> ] [
<eth_rx_fragment> ] [ <eth_rx_crcerr_not_stomped> ] [ <eth_rx_crcerr_stomped> ] [ <eth_rx_inrangeerr>
] ] [ <svi_routed_pkts_in> ] [ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out> ] [ <svi_routed_bytes_out>
] [ <svi_ucast_pkts_in> ] [ <svi_ucast_bytes_in> ] [ <svi_mcast_pkts_in> ] [ <svi_mcast_bytes_in> ] [
<svi_ucast_pkts_out> ] [ <svi_ucast_bytes_out> ] [ <svi_mcast_pkts_out> ] [ <svi_mcast_bytes_out> ] [
<svi_ipv4_ucast_pkts_in> ] [ <svi_ipv4_ucast_bytes_in> ] [ <svi_ipv4_ucast_pkts_out> ] [

```

```
<svi_ipv4_ucast_bytes_out> ][ <svi_ipv4_mcast_pkts_in> ][ <svi_ipv4_mcast_bytes_in> ][
<svi_ipv4_mcast_pkts_out> ][ <svi_ipv4_mcast_bytes_out> ][ <svi_ipv6_ucast_pkts_in> ][
<svi_ipv6_ucast_bytes_in> ][ <svi_ipv6_ucast_pkts_out> ][ <svi_ipv6_ucast_bytes_out> ][
<svi_ipv6_mcast_pkts_in> ][ <svi_ipv6_mcast_bytes_in> ][ <svi_ipv6_mcast_pkts_out> ][
<svi_ipv6_mcast_bytes_out> ][ <svi_average_input_bits> ][ <svi_average_input_packets> ][
<svi_average_output_bits> ][ <svi_average_output_packets> ][ <svi_rate_in_mins> ]][ [ <svi_reliability>
] ][ <switchport> } } ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifid_brf</i>        | Enter interface type and number in module/slot format |
| brief                  | Show brief info of interface                          |
| <u>__readonly__</u>    | (Optional) Read Only                                  |
| TABLE_interface        | (Optional) show interface                             |
| <i>interface</i>       | (Optional) Interface index                            |
| <i>desc</i>            | (Optional) Interface description                      |
| <i>svi_if_index</i>    | (Optional) Interface                                  |
| <i>svi_admin_state</i> | (Optional)  |
| <i>oper_state</i>      | (Optional)  |
| <i>svi_rsn_desc</i>    | (Optional) Interface state reason detailed            |
| <i>svi_line_proto</i>  | (Optional)  |
| <i>svi_hw</i>          | (Optional) Hardware                                   |
| <i>svi_mac</i>         | (Optional) Address                                    |
| <i>svi_desc</i>        | (Optional) Interface Description                      |
| <i>svi_ip_addr</i>     | (Optional) IP Address                                 |
| <i>svi_ip_mask</i>     | (Optional) IP address mask                            |
| <i>svi_mtu</i>         | (Optional) MTU size in bytes                          |
| <i>svi_bw</i>          | (Optional) Bandwidth in kilobits                      |
| <i>svi_delay</i>       | (Optional) Throughput delay (tens of microseconds)    |
| <i>vlan_id</i>         | (Optional) Vlan                                       |
| <i>type</i>            | (Optional) type                                       |
| <i>svi_tx_load</i>     | (Optional) Tx Load                                    |



|                                  |   |
|----------------------------------|---|
| <i>svi_rx_load</i>               | (Optional) Rx Load                              |
| <i>svi_carrier_delay_sec</i>     | (Optional) carrier delay value in seconds       |
| <i>svi_carrier_delay_msec</i>    | (Optional) carrier delay value in milli-seconds |
| <i>svi_arp_type</i>              | (Optional) ARP type                             |
| <i>svi_arp_timeout</i>           | (Optional) ARP timeout value                    |
| <i>svi_time_last_cleared</i>     | (Optional) Time last cleared                    |
| TABLE_secondary_vlan             | (Optional) Secondary vlan                       |
| <i>sec_vlan</i>                  | (Optional) Secondary vlan ID                    |
| <i>sec_vlan_type</i>             | (Optional) Secondary vlan type                  |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec        |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec       |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec       |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec        |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec      |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec      |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary    |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary    |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary   |
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary   |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec        |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec       |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec       |
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec        |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec      |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec      |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary    |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary    |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary   |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary   |

|                                  |   |
|----------------------------------|---|
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec    |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary  |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary  |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary |
| <i>eth_l2_ucastpkts</i>          | (Optional) L2 switched ucast pkts             |
| <i>eth_l2_ucastbytes</i>         | (Optional) L2 switched ucast bytes            |
| <i>eth_l2_mcastpkts</i>          | (Optional) L2 switched mcast pkts             |
| <i>eth_l2_mcastbytes</i>         | (Optional) L2 switched mcast bytes            |
| <i>eth_l2_bcastpkts</i>          | (Optional) L2 switched bcast pkts             |
| <i>eth_l2_bcastbytes</i>         | (Optional) L2 switched bcast bytes            |
| <i>eth_l3in_ucastpkts</i>        | (Optional) IPv4 L3 in switched ucast pkts     |
| <i>eth_l3in_ucastbytes</i>       | (Optional) IPv4 L3 in switched ucast bytes    |
| <i>eth_l3in_mcastpkts</i>        | (Optional) IPv4 L3 in switched mcast pkts     |
| <i>eth_l3in_mcastbytes</i>       | (Optional) IPv4 L3 in switched mcast bytes    |
| <i>eth_l3in_bcastpkts</i>        | (Optional) L3 in switched bcast pkts          |
| <i>eth_l3in_bcastbytes</i>       | (Optional) L3 in switched bcast bytes         |
| <i>eth_l3out_ucastpkts</i>       | (Optional) IPv4 L3 out switched ucast pkts    |
| <i>eth_l3out_ucastbytes</i>      | (Optional) IPv4 L3 out switched ucast bytes   |
| <i>eth_l3out_mcastpkts</i>       | (Optional) IPv4 L3 out switched mcast pkts    |
| <i>eth_l3out_mcastbytes</i>      | (Optional) IPv4 L3 out switched mcast bytes   |
| <i>eth_l3out_bcastpkts</i>       | (Optional) L3 out switched bcast pkts         |
| <i>eth_l3out_bcastbytes</i>      | (Optional) L3 out switched bcast bytes        |
| <i>eth_l3in_routed_pkts</i>      | (Optional) L3 in routed pkts                  |

|                               |  |
|-------------------------------|--|
| <i>eth_l3in_routed_bytes</i>  | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>  | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i> | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>     | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>      | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>    | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>     | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_l3avg2_inbytes</i>     | (Optional) Load interval 2 L3 average in switched bytes  |
| <i>eth_l3avg2_inpkts</i>      | (Optional) Load interval 2 L3 average in switched pkts   |
| <i>eth_l3avg2_outbytes</i>    | (Optional) Load interval 2 L3 average out switched bytes |
| <i>eth_l3avg2_outpkts</i>     | (Optional) Load interval 2 L3 average out switched pkts  |
| <i>eth_l3avg3_inbytes</i>     | (Optional) Load interval 3 L3 average in switched bytes  |
| <i>eth_l3avg3_inpkts</i>      | (Optional) Load interval 3 L3 average in switched pkts   |
| <i>eth_l3avg3_outbytes</i>    | (Optional) Load interval 3 L3 average out switched bytes |
| <i>eth_l3avg3_outpkts</i>     | (Optional) Load interval 3 L3 average out switched pkts  |
| <i>eth_inpkts</i>             | (Optional) Packets input                                 |
| <i>eth_inbytes</i>            | (Optional) Bytes input                                   |
| <i>eth_nobuf</i>              | (Optional) No buffer received                            |
| <i>eth_inbcast</i>            | (Optional) Broadcasts                                    |
| <i>eth_inmcast</i>            | (Optional) Multicasts                                    |
| <i>eth_inucast</i>            | (Optional) Unicasts                                      |
| <i>eth_ingiants</i>           | (Optional) giants  |
| <i>eth_ipmcast</i>            | (Optional) IP multicast                                  |
| <i>eth_inhw_switched</i>      | (Optional) Input H/W Switched                            |
| <i>eth_insw_switched</i>      | (Optional) Input S/W Switched                            |
| <i>eth_runts</i>              | (Optional) runts   |
| <i>eth_storm_supp</i>         | (Optional) storm suppression                             |
| <i>eth_throtles</i>           | (Optional) throttles                                     |
| <i>eth_inerr</i>              | (Optional) input errors                                  |

|                            |   |
|----------------------------|---|
| <i>eth_crc</i>             | (Optional) CRC                                  |
| <i>eth_ecc</i>             | (Optional) ECC                                  |
| <i>eth_frame</i>           | (Optional) frame                                |
| <i>eth_overrun</i>         | (Optional) overrun                              |
| <i>eth_ignored</i>         | (Optional) ignored                              |
| <i>eth_watchdog</i>        | (Optional) watchdog                             |
| <i>eth_outbcast</i>        | (Optional) Broadcasts                           |
| <i>eth_outmcast</i>        | (Optional) Multicasts                           |
| <i>eth_outucast</i>        | (Optional) Unicasts                             |
| <i>eth_outgiants</i>       | (Optional) giants                               |
| <i>eth_inpause</i>         | (Optional) pause input                          |
| <i>eth_dribble</i>         | (Optional) input packets with dribble condition |
| <i>eth_in_ifdown_drops</i> | (Optional) Input if-down drops                  |
| <i>eth_bad_eth</i>         | (Optional) bad ether type drop                  |
| <i>eth_bad_proto</i>       | (Optional) bad protocol drops                   |
| <i>eth_outpkts</i>         | (Optional) packets output                       |
| <i>eth_outbytes</i>        | (Optional) bytes output                         |
| <i>eth_underrun</i>        | (Optional) underruns                            |
| <i>eth_outhw_switched</i>  | (Optional) Out H/W Switched                     |
| <i>eth_outsw_switched</i>  | (Optional) Out S/W Switched                     |
| <i>eth_outerr</i>          | (Optional) output errors                        |
| <i>eth_coll</i>            | (Optional) collisions                           |
| <i>eth_resets</i>          | (Optional) interface resets                     |
| <i>eth_babbles</i>         | (Optional) babbles                              |
| <i>eth_latecoll</i>        | (Optional) late collision                       |
| <i>eth_deferred</i>        | (Optional) deferred                             |
| <i>eth_lostcarrier</i>     | (Optional) lost carrier                         |
| <i>eth_nocarrier</i>       | (Optional) no carrier                           |
| <i>eth_outpause</i>        | (Optional) PAUSE output                         |

|                             |  |
|-----------------------------|--|
| <i>eth_buffail</i>          | (Optional) output buffer failures                  |
| <i>eth_bufswapped</i>       | (Optional) output buffers swapped out              |
| <i>eth_arpdrops</i>         | (Optional) arp drops                               |
| <i>eth_out_ifdown_drops</i> | (Optional) Output if-down drops                    |
| <i>eth_single_coll</i>      | (Optional) single collisions                       |
| <i>eth_multi_coll</i>       | (Optional) multi collisions                        |
| <i>eth_excess_coll</i>      | (Optional) excessive collisions                    |
| <i>eth_jabbers</i>          | (Optional) jabbers                                 |
| <i>eth_shortframe</i>       | (Optional) short frames                            |
| <i>eth_indiscard</i>        | (Optional) discards                                |
| <i>eth_bad_encap</i>        | (Optional) bad encapsulation                       |
| <i>eth_outcrc</i>           | (Optional) Output CRC                              |
| <i>eth_symbol</i>           | (Optional) symbol errors                           |
| <i>eth_out_drops</i>        | (Optional) output drops                            |
| <i>eth_sqetest</i>          | (Optional) SQE test                                |
| <i>eth_inb64</i>            | (Optional) input pkts between 0 and 64 bytes       |
| <i>eth_inb65_127</i>        | (Optional) input pkts between 65 and 127 bytes     |
| <i>eth_inb128_255</i>       | (Optional) input pkts between 128 and 255 bytes    |
| <i>eth_inb256_511</i>       | (Optional) input pkts between 256 and 511 bytes    |
| <i>eth_inb512_1023</i>      | (Optional) input pkts between 512 and 1023 bytes   |
| <i>eth_inb1024_1518</i>     | (Optional) input pkts between 1024 and 1518 bytes  |
| <i>eth_inb1519_1548</i>     | (Optional) input pkts between 1519 and 1548 bytes  |
| <i>eth_intrunk</i>          | (Optional) input trunk pkts                        |
| <i>eth_outb64</i>           | (Optional) output pkts between 0 and 64 bytes      |
| <i>eth_outb65_127</i>       | (Optional) output pkts between 65 and 127 bytes    |
| <i>eth_outb128_255</i>      | (Optional) output pkts between 128 and 255 bytes   |
| <i>eth_outb256_511</i>      | (Optional) output pkts between 256 and 511 bytes   |
| <i>eth_outb512_1023</i>     | (Optional) output pkts between 512 and 1023 bytes  |
| <i>eth_outb1024_1518</i>    | (Optional) output pkts between 1024 and 1518 bytes |

|                                     |  |
|-------------------------------------|--|
| <i>eth_outb1519_1548</i>            | (Optional) output pkts between 1519 and 1548 bytes |
| <i>eth_outtrunk</i>                 | (Optional) output trunk pkts                       |
| <i>eth_bpdu_outlost</i>             | (Optional) BPDU output lost                        |
| <i>eth_cos0_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos1_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos2_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos3_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos4_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos5_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos6_outlost</i>             | (Optional) output pkts                             |
| <i>eth_cos7_outlost</i>             | (Optional) output pkts                             |
| <i>eth_fcoe_in_pkts</i>             | (Optional) fcoe in pkts                            |
| <i>eth_fcoe_in_octets</i>           | (Optional) fcoe in octets                          |
| <i>eth_fcoe_out_pkts</i>            | (Optional) fcoe out pkts                           |
| <i>eth_fcoe_out_octets</i>          | (Optional) fcoe out octets                         |
| <i>eth_nfcoe_in_pkts</i>            | (Optional) nfcoe in pkts                           |
| <i>eth_nfcoe_in_octets</i>          | (Optional) nfcoe in octets                         |
| <i>eth_nfcoe_out_pkts</i>           | (Optional) nfcoe out pkts                          |
| <i>eth_nfcoe_out_octets</i>         | (Optional) nfcoe out octets                        |
| <i>eth_eee_atx_lpi_msec</i>         | (Optional) Tx Lpi usec                             |
| <i>eth_eee_arcv_lpi_msec</i>        | (Optional) Rx Lpi usec                             |
| <i>eth_eee_atx_lpi_transitions</i>  | (Optional) Tx Lpi requests                         |
| <i>eth_eee_arcv_lpi_transitions</i> | (Optional) Rx Lpi indications                      |
| <i>eth_phy_ber_count</i>            | (Optional) Bit error rate counter                  |
| <i>eth_phy_errblks_count</i>        | (Optional) Errored blocks counter                  |
| <i>eth_tx_frm_error</i>             | (Optional) tx frame error                          |
| <i>eth_rx_toolong</i>               | (Optional) rx toolong error                        |
| <i>eth_rx_undersize</i>             | (Optional) rx undersize                            |
| <i>eth_rx_fragment</i>              | (Optional) rx fragment                             |

|                                  |                                  |
|----------------------------------|----------------------------------|
| <i>eth_rx_crcerr_not_stomped</i> | (Optional) rx crcerr not stomped |
| <i>eth_rx_crcerr_stomped</i>     | (Optional) rx crcerr stomped     |
| <i>eth_rx_inrangeerr</i>         | (Optional) rx inrange error      |
| <i>svi_reliability</i>           | (Optional) Reliability           |
| <i>switchport</i>                | (Optional) Switchport enabled    |

**Command Mode**

- /exec

## show interface brief

```
show interface <ifpch_brf> brief [ __readonly__ TABLE_interface <interface> [ <vlan> ] <type> <portmode>
<state> <state_rsn_desc> <speed> <ratemode> [ <proto> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifpch_brf</i>      | Enter interface type and number in module/slot format |
| brief                 | Show brief info of interface                          |
| <i>__readonly__</i>   | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>vlan</i>           | (Optional) Vlan                                       |
| <i>type</i>           | (Optional) Type                                       |
| <i>portmode</i>       | (Optional) Port mode                                  |
| <i>state</i>          | (Optional) Interface state                            |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed            |
| <i>speed</i>          | (Optional) Speed                                      |
| <i>ratemode</i>       | (Optional) Interface port speed                       |
| <i>proto</i>          | (Optional) Port Channel Protocol                      |

### Command Mode

- /exec



## show interface brief

```
show interface brief [ controller | cli ] [ __readonly__ { TABLE_interface [ <interface> ] [ <vlan> ] [ <type> ] [ <portmode> ] [ <state> ] [ <state_rsn> ] [ <state_rsn_desc> ] [ <desc> ] [ <vrf> ] [ <ipv6_addr> ] [ <ip_addr> ] [ <speed> ] [ { <tunnel-ipv4> | <tunnel-ipv6> } ] [ <encap-type> ] [ <mtu> ] [ <ratemode> ] [ <portchan> ] [ <proto> ] [ <interface_vfc> ] [ <vsan_brief> ] [ <admin_mode> ] [ <admin_trunk_mode> ] [ <status> ] [ <fcot_info> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <port_channel> ] [ <ip_addr1> ] [ { brief_san_pc [ <interface_san> ] [ <vsan_brief> ] [ <admin_trunk_mode> ] [ <status> ] [ <port_rate_mode> ] [ <oper_speed> ] [ <ip_addr> ] } ] [ { TABLE_secondary_vlan <sec_vlan> <sec_vlan_type> } ] [ <svi_admin_state> ] [ <svi_rsn_desc> ] } ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information            |
| interface             | Show interface status and information      |
| brief                 | Show brief info of interface               |
| controller            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED  |
| cli                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED  |
| <i>__readonly__</i>   | (Optional) Read Only                       |
| <i>interface</i>      | (Optional) Interface index                 |
| TABLE_interface       | (Optional) show interface                  |
| <i>state</i>          | (Optional) Interface state                 |
| <i>state_rsn</i>      | (Optional) Interface state reason          |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed |
| <i>desc</i>           | (Optional) Interface description           |
| <i>vrf</i>            | (Optional) Vrf membership                  |
| <i>ip_addr</i>        | (Optional) IP address                      |
| <i>tunnel-ipv4</i>    | (Optional) interface IPv4 address          |
| <i>encap-type</i>     | (Optional)                                 |
| <i>mtu</i>            | (Optional) MTU                             |
| <i>speed</i>          | (Optional) Speed                           |
| <i>vlan</i>           | (Optional) Vlan                            |
| <i>type</i>           | (Optional) Type                            |
| <i>portmode</i>       | (Optional) Port mode                       |

|                             |  |
|-----------------------------|--|
| <i>ratemode</i>             | (Optional) Interface port speed            |
| <i>portchan</i>             | (Optional) Port Channel Membership         |
| <i>proto</i>                | (Optional) Port Channel Protocol           |
| <i>interface_vfc</i>        | (Optional) Interface index                 |
| <i>vsan_brief</i>           | (Optional) vsan brief                      |
| <i>admin_mode</i>           | (Optional) admin mode                      |
| <i>admin_trunk_mode</i>     | (Optional) admin trunk mode                |
| <i>status</i>               | (Optional) status                          |
| <i>fcot_info</i>            | (Optional) fcot info                       |
| <i>bind_info</i>            | (Optional) bind interface                  |
| <i>bind_type</i>            | (Optional) bind type                       |
| <i>bind_mac</i>             | (Optional) bind mac address                |
| <i>port_rate_mode</i>       | (Optional) rate mode                       |
| <i>oper_speed</i>           | (Optional) speed                           |
| <i>port_channel</i>         | (Optional) port channel number             |
| <i>ip_addr1</i>             | (Optional) IP address                      |
| <i>brief_san_pc</i>         | (Optional) show interface brief for san-po |
| <i>interface_san</i>        | (Optional) san_po interface                |
| <i>vsan_brief</i>           | (Optional) vsan brief                      |
| <i>admin_trunk_mode</i>     | (Optional) admin trunk mode                |
| <i>status</i>               | (Optional) status                          |
| <i>port_rate_mode</i>       | (Optional) rate mode                       |
| <i>oper_speed</i>           | (Optional) speed                           |
| <i>ip_addr</i>              | (Optional) IP address                      |
| <i>TABLE_secondary_vlan</i> | (Optional) Secondary vlan                  |
| <i>sec_vlan</i>             | (Optional) Secondary vlan ID               |
| <i>sec_vlan_type</i>        | (Optional) Secondary vlan type             |
| <i>svi_admin_state</i>      | (Optional) svi admin state                 |
| <i>svi_rsn_desc</i>         | (Optional) Interface state reason detailed |

### Command Mode

- /exec

# show interface brief

show interface <ifloop\_brf> brief [ \_\_readonly\_\_ TABLE\_interface <interface> <state> [ <desc> ] ]

## Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information                       |
| interface         | Show interface status and information                 |
| <i>ifloop_brf</i> | Enter interface type and number in module/slot format |
| brief             | Show brief info of interface                          |
| __readonly__      | (Optional) Read Only                                  |
| <i>interface</i>  | (Optional) Interface index                            |
| TABLE_interface   | (Optional) show interface                             |
| <i>state</i>      | (Optional) Interface state                            |
| <i>desc</i>       | (Optional) Interface description                      |

## Command Mode

- /exec

## show interface brief

```
show interface <iftunnel_brf> brief [ __readonly__ TABLE_interface <interface> <state> [ <admin-state> ]
[ { <tunnel-ipv4> | <tunnel-ipv6> } ] [ <bandwidth> ] [ <encap-type> ] [ <mtu> ] [ <keepalive-period> ] [
<keepalive-retries> ] [ { <src-ipv4> | <src-ipv6> } ] [ <src-intf> ] [ { <dest-ipv4> | <dest-ipv6> } ] [
<dest-hostname> ] [ <vrf_name> ] [ <tunnel_vrf_name> ] [ <wccp_header> ] [ <ttl_val> ] [
<tunnel_pmtud_age_time> ] [ <tunnel_pmtud_min_mtu> ] [ <tunnel_pmtud> ] [ <tunnel_pgm_mtu> ] [
<tunnel_clear_counter> ] [ <tunnel_tx_pkt_count> ] [ <tunnel_tx_byte_count> ] [ <tunnel_tx_rate> ] [
<tunnel_rx_pkt_count> ] [ <tunnel_rx_byte_count> ] [ <tunnel_rx_rate> ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                       |
| interface                | Show interface status and information                 |
| <i>iftunnel_brf</i>      | Enter interface type and number in module/slot format |
| brief                    | Show brief info of interface                          |
| <i>__readonly__</i>      | (Optional) Read Only                                  |
| <i>interface</i>         | (Optional) Interface index                            |
| TABLE_interface          | (Optional) show interface                             |
| <i>state</i>             | (Optional) Interface state                            |
| <i>admin-state</i>       | (Optional)  |
| <i>tunnel-ipv4</i>       | (Optional) interface IPv4 address                     |
| <i>mtu</i>               | (Optional) interface Maximum Transmission Unit        |
| <i>bandwidth</i>         | (Optional) interface Bandwidth in kilobits            |
| <i>encap-type</i>        | (Optional)  |
| <i>keepalive-period</i>  | (Optional) keealive period                            |
| <i>keepalive-retries</i> | (Optional) number of retries                          |
| <i>src-ipv4</i>          | (Optional) tunnel source IPv4 address                 |
| <i>src-intf</i>          | (Optional) tunnel source interface                    |
| <i>dest-ipv4</i>         | (Optional) tunnel destination IPv4 address            |
| <i>dest-hostname</i>     | (Optional) tunnel destination hostname                |
| <i>vrf_name</i>          | (Optional) transport VRF name                         |
| <i>tunnel_vrf_name</i>   | (Optional) tunnel VRF name                            |
| <i>wccp_header</i>       | (Optional) wccp header                                |

|                              |   |
|------------------------------|---|
| <i>ttl_val</i>               | (Optional) tunnel time to live value                |
| <i>tunnel_pmtud_age_time</i> | (Optional) tunnel path MTU discovery age time       |
| <i>tunnel_pmtud_min_mtu</i>  | (Optional) tunnel path MTU discovery min mtu        |
| <i>tunnel_pmtud</i>          | (Optional) tunnel path MTU discovered               |
| <i>tunnel_pgm_mtu</i>        | (Optional) tunnel actual programmed MTU             |
| <i>tunnel_rx_pkt_count</i>   | (Optional) total number of packets received         |
| <i>tunnel_rx_byte_count</i>  | (Optional) total number of bytes received           |
| <i>tunnel_rx_rate</i>        | (Optional) packets input rate per 5 minutes         |
| <i>tunnel_tx_pkt_count</i>   | (Optional) total number of packets transmitted      |
| <i>tunnel_tx_byte_count</i>  | (Optional) total number of bytes transmitted        |
| <i>tunnel_tx_rate</i>        | (Optional) packets transmitted per 5 minutes        |
| <i>tunnel_clear_counter</i>  | (Optional) Last clearing of show interface counters |

**Command Mode**

- /exec

# show interface brief

```
show interface <ifmgmt_brf> brief [ __readonly__ TABLE_interface <interface> [ <vrf> ] <state> [
<ipv6_addr> ] [ <ip_addr> ] <mtu> <speed> [ <duplex> ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| interface           | Show interface status and information                 |
| <i>ifmgmt_brf</i>   | Enter interface type and number in module/slot format |
| brief               | Show brief info of interface                          |
| <i>__readonly__</i> | (Optional) Read Only                                  |
| <i>interface</i>    | (Optional) Interface index                            |
| TABLE_interface     | (Optional) show interface                             |
| <i>vrf</i>          | (Optional) Vrf membership                             |
| <i>state</i>        | (Optional) Interface state                            |
| <i>ip_addr</i>      | (Optional) IP address                                 |
| <i>mtu</i>          | (Optional) MTU  |
| <i>speed</i>        | (Optional) Speed                                      |
| <i>duplex</i>       | (Optional) Duplex                                     |

## Command Mode

- /exec

## show interface brief

```
show interface <ifeth_brf> brief [ __readonly__ TABLE_interface <interface> [ <vlan> ] <type> <portmode>
<state> <state_rsn_desc> <speed> <ratemode> [ <portchan> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifeth_brf</i>      | Enter interface type and number in module/slot format |
| brief                 | Show brief info of interface                          |
| <i>__readonly__</i>   | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>vlan</i>           | (Optional) Vlan                                       |
| <i>type</i>           | (Optional) Type                                       |
| <i>portmode</i>       | (Optional) Port mode                                  |
| <i>state</i>          | (Optional) Interface state                            |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed            |
| <i>speed</i>          | (Optional) Speed                                      |
| <i>ratemode</i>       | (Optional) Interface port speed                       |
| <i>portchan</i>       | (Optional) Port Channel Membership                    |

### Command Mode

- /exec



## show interface brief

```
show interface <ifrange> brief [ __readonly__ TABLE_interface <interface> <state> [ <state_rsn> ] [
<state_rsn_desc> ] [ <overlay_mtu> ] [ <overlay_bandwidth> ] [ <overlay_vrf> ] [ <overlay_src_addr> ] [
<overlay_dst_addr> ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information            |
| interface                | Show interface status and information      |
| <i>ifrange</i>           | Enter interface type and number            |
| brief                    | Show brief info of interface               |
| <i>__readonly__</i>      | (Optional) Read Only                       |
| <i>interface</i>         | (Optional) Interface index                 |
| TABLE_interface          | (Optional) show interface                  |
| <i>state</i>             | (Optional) Interface state                 |
| <i>state_rsn</i>         | (Optional) Interface state reason          |
| <i>state_rsn_desc</i>    | (Optional) Interface state reason detailed |
| <i>overlay_mtu</i>       | (Optional) MTU                             |
| <i>overlay_bandwidth</i> | (Optional) Bandwidth                       |
| <i>overlay_vrf</i>       | (Optional) VRF                             |
| <i>overlay_src_addr</i>  | (Optional) Source address                  |
| <i>overlay_dst_addr</i>  | (Optional) Destination address             |

### Command Mode

- /exec

## show interface cable-diagnostics-tdr

```
show interface <ifid_tdr> cable-diagnostics-tdr [ __readonly__ TABLE_interface <interface> <speed>
<distance1> <pair1_status> <distance2> <pair2_status> <distance3> <pair3_status> <distance4> <pair4_status>
]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifid_tdr</i>       | Enter interface type and number in module/slot format |
| cable-diagnostics-tdr | Show interface tdr test information                   |
| <i>__readonly__</i>   | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>speed</i>          | (Optional) Speed                                      |
| <i>distance1</i>      | (Optional) Distance to fault for pair 1               |
| <i>distance2</i>      | (Optional) Distance to fault for pair 2               |
| <i>distance3</i>      | (Optional) Distance to fault for pair 3               |
| <i>distance4</i>      | (Optional) Distance to fault for pair 4               |
| <i>pair1_status</i>   | (Optional) Pair1 status                               |
| <i>pair2_status</i>   | (Optional) Pair2 status                               |
| <i>pair3_status</i>   | (Optional) Pair3 status                               |
| <i>pair4_status</i>   | (Optional) Pair4 status                               |

### Command Mode

- /exec

## show interface capabilities

```
show interface capabilities [ __readonly__ TABLE_interface <interface> <model> <type> <speed> <duplex>
<trunk_encap> [ <dce_capable> ] <channel> <bcast_supp> <flo_ctrl> <rate_mode> <port_mode> [ <fast_start>
] <qos_scheduling> <cos_rewrite> <tos_rewrite> [ <inline_power> ] <span> <udld> [ <mdix> ] [ <tdr> ]
<lnk_debounce> <lnk_debounce_time> <fex_fabric> <dot1q_tunnel> [ <pvlan_trunk_mode> ] [ <port_group>
] [ <port_group_members> ] <eee_capable> <pfc_capable> [ <speed_group_capable> ] <buffer_boost_capable>
[ <bkout_capable> ] [ <macsec_capable> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information         |
| interface             | Show interface status and information   |
| capabilities          | Show interface capabilities information |
| <i>__readonly__</i>   | (Optional) Read Only                    |
| <i>interface</i>      | (Optional) Interface index              |
| TABLE_interface       | (Optional) show interface               |
| <i>model</i>          | (Optional) Model                        |
| <i>type</i>           | (Optional) Type                         |
| <i>speed</i>          | (Optional) Speed                        |
| <i>duplex</i>         | (Optional) Duplex                       |
| <i>trunk_encap</i>    | (Optional) Trunk encap. type            |
| <i>dce_capable</i>    | (Optional) DCE mode capable             |
| <i>channel</i>        | (Optional) Channel                      |
| <i>bcast_supp</i>     | (Optional) Broadcast suppression        |
| <i>flo_ctrl</i>       | (Optional) Flowcontrol                  |
| <i>rate_mode</i>      | (Optional) Rate mode                    |
| <i>port_mode</i>      | (Optional) Port mode                    |
| <i>fast_start</i>     | (Optional) Fast start                   |
| <i>qos_scheduling</i> | (Optional) QOS scheduling               |
| <i>cos_rewrite</i>    | (Optional) CoS rewrite                  |
| <i>tos_rewrite</i>    | (Optional) ToS rewrite                  |
| <i>inline_power</i>   | (Optional) Inline power                 |

|                             |                                    |
|-----------------------------|------------------------------------|
| <i>span</i>                 | (Optional) SPAN                    |
| <i>udld</i>                 | (Optional) UDLD                    |
| <i>mdix</i>                 | (Optional) MDIX                    |
| <i>tdr</i>                  | (Optional) TDR                     |
| <i>lnk_debounce</i>         | (Optional) Link debounce           |
| <i>lnk_debounce_time</i>    | (Optional) Link debounce time      |
| <i>fex_fabric</i>           | (Optional) FEX Fabric              |
| <i>dot1q_tunnel</i>         | (Optional) dot1q-tunnel            |
| <i>pvlan_trunk_mode</i>     | (Optional) Private-vlan trunk mode |
| <i>port_group</i>           | (Optional) Port Group              |
| <i>port_group_members</i>   | (Optional) Port Group Members      |
| <i>eee_capable</i>          | (Optional) EEE (efficient-eth)     |
| <i>pfc_capable</i>          | (Optional) PFC Capable:            |
| <i>bkout_capable</i>        | (Optional) Breakout Capable:       |
| <i>buffer_boost_capable</i> | (Optional) Buffer Boost Capable:   |
| <i>speed_group_capable</i>  | (Optional) Speed group capable     |
| <i>macsec_capable</i>       | (Optional) MACSEC capable          |

**Command Mode**

- /exec

## show interface capabilities

```
show interface <ifid_cap> capabilities [ __readonly__ { TABLE_interface_capabilities_if <interface> [
<min_speed> ] [ <max_speed> ] [ <FC-PH_version_high> ] [ <FC-PH_version_low> ] [ <recieve_data_max>
] [ <recieve_data_min> ] [ <transmit_data_max> ] [ <transmit_data_min> ] [ <class_service> ] [ <class_2>
] [ <class_3> ] [ <hold_time_max> ] [ <hold_time_min> ] [ <BB_state_change> ] [ <max_BB_state_change>
] [ <rate_mode_change> ] [ <rate_mode_cap> ] [ <recieve_BB_credit> ] [ <FX_recieve_BB_credit> ] [
<ISL_recieve_BB_credit> ] [ <shared_performance_buf_mod_supp> ] [
<dedicated_performance_buf_mod_supp> ] [ <fx_mode_perf_buf> ] [ <isl_mode_perf_buf> ] [ <out_of_order>
] [ <beacon_mode_config> ] [ <extended_B2B> ] [ <on_demand_port> ] } ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                       |
| interface                       | Show interface status and information                 |
| <i>ifid_cap</i>                 | Enter interface type and number in module/slot format |
| capabilities                    | Show interface capabilities information               |
| <i>__readonly__</i>             | (Optional)  |
| TABLE_interface_capabilities_if | (Optional) interface capabilities if table            |
| <i>interface</i>                | (Optional) fc interface                               |
| <i>min_speed</i>                | (Optional) Min Speed                                  |
| <i>max_speed</i>                | (Optional) Max Speed                                  |
| <i>FC-PH_version_high</i>       | (Optional) FC-PH version high                         |
| <i>FC-PH_version_low</i>        | (Optional) FC-PH version low                          |
| <i>recieve_data_max</i>         | (Optional) Receive data field size max                |
| <i>recieve_data_min</i>         | (Optional) Receive data field size min                |
| <i>transmit_data_max</i>        | (Optional) Transmit data field size max               |
| <i>transmit_data_min</i>        | (Optional) Transmit data field size min               |
| <i>class_service</i>            | (Optional) Classes of Service supported               |
| <i>class_2</i>                  | (Optional) Class 2 sequential delivery                |
| <i>class_3</i>                  | (Optional) Class 3 sequential delivery                |
| <i>hold_time_max</i>            | (Optional) Hold time max                              |
| <i>hold_time_min</i>            | (Optional) Hold time min                              |
| <i>BB_state_change</i>          | (Optional) BB state change notification               |

|   |  |
|---|--|
| <i>max_BB_state_change</i>                | (Optional) Maximum BB state change notifications               |
| <i>rate_mode_change</i>                   | (Optional) Rate Mode change                                    |
| <i>rate_mode_cap</i>                      | (Optional) Rate Mode Capabilities                              |
| <i>recieve_BB_credit</i>                  | (Optional) Receive BB Credit modification supported            |
| <i>FX_recieve_BB_credit</i>               | (Optional) FX mode Receive BB Credit (min/max/default)         |
| <i>ISL_recieve_BB_credit</i>              | (Optional) ISL mode Receive BB Credit (min/max/default)        |
| <i>shared_performance_buf_mod_supp</i>    | (Optional) Performance buffer modification supported shared    |
| <i>dedicated_performance_buf_mod_supp</i> | (Optional) Performance buffer modification supported dedicated |
| <i>fx_mode_perf_buf</i>                   | (Optional) FX mode performance buffers                         |
| <i>isl_mode_perf_buf</i>                  | (Optional) ISL mode performance buffers                        |
| <i>out_of_order</i>                       | (Optional) Out of Service capable                              |
| <i>beacon_mode_config</i>                 | (Optional) Beacon mode configurable                            |
| <i>extended_B2B</i>                       | (Optional) Extended B2B credit capable                         |
| <i>on_demand_port</i>                     | (Optional) On demand port activation license supported         |

**Command Mode**

- /exec

## show interface capabilities

```
show interface <ifid_eth_cap> capabilities [ __readonly__ TABLE_interface <interface> <model> <type>
<speed> <duplex> <trunk_encap> [ <dce_capable> ] <channel> <bcast_supp> <flo_ctrl> <rate_mode>
<port_mode> [ <fast_start> ] <qos_scheduling> <cos_rewrite> <tos_rewrite> [ <inline_power> ] <span>
<udld> [ <mdix> ] [ <tdr> ] <lnk_debounce> <lnk_debounce_time> <fex_fabric> <dot1q_tunnel> [
<pvlan_trunk_mode> ] [ <port_group> ] [ <port_group_members> ] <eee_capable> <pfc_capable> [
<speed_group_capable> ] <buffer_boost_capable> [ <bkout_capable> ] [ <macsec_capable> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifid_eth_cap</i>   | Enter interface type and number in module/slot format |
| capabilities          | Show interface capabilities information               |
| <i>__readonly__</i>   | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>model</i>          | (Optional) Model                                      |
| <i>type</i>           | (Optional) Type                                       |
| <i>speed</i>          | (Optional) Speed                                      |
| <i>duplex</i>         | (Optional) Duplex                                     |
| <i>trunk_encap</i>    | (Optional) Trunk encap. type                          |
| <i>dce_capable</i>    | (Optional) DCE mode capable                           |
| <i>channel</i>        | (Optional) Channel                                    |
| <i>bcast_supp</i>     | (Optional) Broadcast suppression                      |
| <i>flo_ctrl</i>       | (Optional) Flowcontrol                                |
| <i>rate_mode</i>      | (Optional) Rate mode                                  |
| <i>port_mode</i>      | (Optional) Port mode                                  |
| <i>fast_start</i>     | (Optional) Fast start                                 |
| <i>qos_scheduling</i> | (Optional) QOS scheduling                             |
| <i>cos_rewrite</i>    | (Optional) CoS rewrite                                |
| <i>tos_rewrite</i>    | (Optional) ToS rewrite                                |

|                             |                                    |
|-----------------------------|------------------------------------|
| <i>inline_power</i>         | (Optional) Inline power            |
| <i>span</i>                 | (Optional) SPAN                    |
| <i>udld</i>                 | (Optional) UDLD                    |
| <i>mdix</i>                 | (Optional) MDIX                    |
| <i>tdr</i>                  | (Optional) TDR                     |
| <i>lnk_debounce</i>         | (Optional) Link debounce           |
| <i>lnk_debounce_time</i>    | (Optional) Link debounce time      |
| <i>fex_fabric</i>           | (Optional) FEX Fabric              |
| <i>dot1q_tunnel</i>         | (Optional) dot1q-tunnel            |
| <i>pvlan_trunk_mode</i>     | (Optional) Private-vlan trunk mode |
| <i>port_group</i>           | (Optional) Port Group              |
| <i>port_group_members</i>   | (Optional) Port Group Members      |
| <i>eee_capable</i>          | (Optional) EEE (efficient-eth)     |
| <i>pfc_capable</i>          | (Optional) PFC Capable:            |
| <i>bkout_capable</i>        | (Optional) Breakout Capable:       |
| <i>buffer_boost_capable</i> | (Optional) Buffer Boost Capable:   |
| <i>speed_group_capable</i>  | (Optional) Speed group capable     |
| <i>macsec_capable</i>       | (Optional) MACSEC capable          |

**Command Mode**

- /exec



## show interface chassis-info

```
show interface chassis-info [ __readonly__ TABLE_chassis_info <chas_no> <chas_port> <slot_no> <port_no>
<module_side> <chas_vendor> <chas_model> <chas_ser> <mod_vendor> <mod_model> <mod_ser>
<mgmt_inst> <fab_id> <ver> <devtype> <chas_state> <chas_mac> <adapter_mode> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information            |
| interface                 | Show interface status and information      |
| chassis-info              | Show all CHASSIS ports                     |
| <i>__readonly__</i>       | (Optional) Read Only                       |
| <i>TABLE_chassis_info</i> | (Optional) Discovered chassis fabric ports |
| <i>chas_no</i>            | (Optional) Configured chassis number       |
| <i>chas_port</i>          | (Optional) Interface name                  |
| <i>slot_no</i>            | (Optional) Remote slot no                  |
| <i>port_no</i>            | (Optional) Remote port no                  |
| <i>module_side</i>        | (Optional) Remote module side              |
| <i>chas_vendor</i>        | (Optional) Chassis Vendor                  |
| <i>chas_model</i>         | (Optional) Chassis Model                   |
| <i>chas_ser</i>           | (Optional) Chassis serial Number           |
| <i>mod_vendor</i>         | (Optional) Module Vendor                   |
| <i>mod_model</i>          | (Optional) Module Model                    |
| <i>mod_ser</i>            | (Optional) Module serial Number            |
| <i>mgmt_inst</i>          | (Optional) Management instance             |
| <i>fab_id</i>             | (Optional) Fabric ID                       |
| <i>ver</i>                | (Optional) Version                         |
| <i>devtype</i>            | (Optional) Device Type                     |
| <i>chas_state</i>         | (Optional) Chassis port state              |
| <i>chas_mac</i>           | (Optional) Chassis MAC                     |
| <i>adapter_mode</i>       | (Optional) adapter mode                    |

### Command Mode

- /exec

## show interface counters

```
show interface counters [ non-zero ] [ __readonly__ { TABLE_rx_counters <interface_rx> [ <eth_inpkts> ]
[ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_ipv4bytes> ] [
<eth_l3in_ipv4pkts> ] [ <eth_l3in_ipv4ucast_pkts> ] [ <eth_l3in_ipv4mcast_pkts> ] [
<eth_l3in_ipv4bcast_pkts> ] [ <eth_l3in_ipv6bytes> ] [ <eth_l3in_ipv6pkts> ] [ <eth_l3in_ipv6ucast_pkts> ]
] [ <eth_l3in_ipv6mcast_pkts> ] [ <eth_l3in_ipv6bcast_pkts> ] } { TABLE_tx_counters <interface_tx> [
<eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [
<eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] [
<eth_l3out_ipv4bytes> ] [ <eth_l3out_ipv4pkts> ] [ <eth_l3out_ipv4ucast_pkts> ] [
<eth_l3out_ipv4mcast_pkts> ] [ <eth_l3out_ipv4bcast_pkts> ] [ <eth_l3out_ipv6bytes> ] [
<eth_l3out_ipv6pkts> ] [ <eth_l3out_ipv6ucast_pkts> ] [ <eth_l3out_ipv6mcast_pkts> ] [
<eth_l3out_ipv6bcast_pkts> ] } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                        |
| interface           | Show interface status and information                  |
| counters            | Show interface counters                                |
| non-zero            | (Optional) To display only the non-zero counter values |
| __readonly__        | (Optional) Read Only                                   |
| <i>interface_rx</i> | (Optional) Interface index rx                          |
| <i>interface_tx</i> | (Optional) Interface index tx                          |
| TABLE_rx_counters   | (Optional) show Rx counters                            |
| TABLE_tx_counters   | (Optional) show Tx counters                            |
| <i>eth_inpkts</i>   | (Optional) Packets input                               |
| <i>eth_inbytes</i>  | (Optional) Bytes input                                 |
| <i>eth_inucast</i>  | (Optional) Unicasts                                    |
| <i>eth_inmcast</i>  | (Optional) Multicasts                                  |
| <i>eth_inbcast</i>  | (Optional) Broadcasts                                  |
| <i>eth_outpkts</i>  | (Optional) Packets output                              |
| <i>eth_outbytes</i> | (Optional) Bytes output                                |
| <i>eth_outucast</i> | (Optional) Unicasts                                    |
| <i>eth_outmcast</i> | (Optional) Multicasts                                  |
| <i>eth_outbcast</i> | (Optional) Broadcasts                                  |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3in_bytes</i>           | (Optional) L3 Rx bytes           |
| <i>eth_l3in_ucastpkts</i>       | (Optional) L3 Rx Unicast pkts    |
| <i>eth_l3in_mcastpkts</i>       | (Optional) L3 Rx Multicast pkts  |
| <i>eth_l3in_bcastpkts</i>       | (Optional) L3 Rx Broadcast pkts  |
| <i>eth_l3in_ipv4bytes</i>       | (Optional) L3 Rx IPv4 bytes      |
| <i>eth_l3in_ipv4pkts</i>        | (Optional) L3 Rx IPv4 pkts       |
| <i>eth_l3in_ipv4ucast_pkts</i>  | (Optional) L3 Rx IPv4 Ucast pkts |
| <i>eth_l3in_ipv4mcast_pkts</i>  | (Optional) L3 Rx IPv4 Mcast pkts |
| <i>eth_l3in_ipv4bcast_pkts</i>  | (Optional) L3 Rx IPv4 Bcast pkts |
| <i>eth_l3in_ipv6bytes</i>       | (Optional) L3 Rx IPv6 bytes      |
| <i>eth_l3in_ipv6pkts</i>        | (Optional) L3 Rx IPv6 pkts       |
| <i>eth_l3in_ipv6ucast_pkts</i>  | (Optional) L3 Rx IPv6 Ucast pkts |
| <i>eth_l3in_ipv6mcast_pkts</i>  | (Optional) L3 Rx IPv6 Mcast pkts |
| <i>eth_l3in_ipv6bcast_pkts</i>  | (Optional) L3 Rx IPv6 Bcast pkts |
| <i>eth_l3out_bytes</i>          | (Optional) L3 Tx bytes           |
| <i>eth_l3out_ucastpkts</i>      | (Optional) L3 Tx Unicast pkts    |
| <i>eth_l3out_mcastpkts</i>      | (Optional) L3 Tx Multicast pkts  |
| <i>eth_l3out_bcastpkts</i>      | (Optional) L3 Tx Broadcast pkts  |
| <i>eth_l3out_ipv4bytes</i>      | (Optional) L3 Tx IPv4 bytes      |
| <i>eth_l3out_ipv4pkts</i>       | (Optional) L3 Tx IPv4 pkts       |
| <i>eth_l3out_ipv4ucast_pkts</i> | (Optional) L3 Tx IPv4 Ucast pkts |
| <i>eth_l3out_ipv4mcast_pkts</i> | (Optional) L3 Tx IPv4 Mcast pkts |
| <i>eth_l3out_ipv4bcast_pkts</i> | (Optional) L3 Tx IPv4 Bcast pkts |
| <i>eth_l3out_ipv6bytes</i>      | (Optional) L3 Tx IPv6 bytes      |
| <i>eth_l3out_ipv6pkts</i>       | (Optional) L3 Tx IPv6 pkts       |
| <i>eth_l3out_ipv6ucast_pkts</i> | (Optional) L3 Tx IPv6 Ucast pkts |
| <i>eth_l3out_ipv6mcast_pkts</i> | (Optional) L3 Tx IPv6 Mcast pkts |
| <i>eth_l3out_ipv6bcast_pkts</i> | (Optional) L3 Tx IPv6 Bcast pkts |

**Command Mode**

- /exec

## show interface counters

```
show interface <ifid_ctr> counters [ brief ] [ __readonly__ ] { TABLE_counters <sfp> { TABLE_input_rate
<bit_per_sec> <bytes_per_sec> <frames_per_sec> } { TABLE_output_rate <bit_per_sec> <bytes_per_sec>
<frames_per_sec> } { TABLE_input <frames> <bytes> [ <class_2_frames> ] [ <class_2_bytes> ] [
<class_3_frames> ] [ <class_3_bytes> ] [ <class_f_frames> ] [ <class_f_bytes> ] [ <class_2_3_frames> ]
<discards> <errors> <crc_fcs> <unknown_class> <too_long> <too_short> } { TABLE_output <frames>
<bytes> [ <class_2_frames> ] [ <class_2_bytes> ] [ <class_3_frames> ] [ <class_3_bytes> ] [ <class_f_frames>
] [ <class_f_bytes> ] [ <class_2_3_frames> ] [ <discards> ] [ <errors> ] [ <crc_fcs> ] [ <timeout_discards>
] [ <credit_loss> ] [ <input_ols> ] [ <input_lrr> ] [ <input_nos> ] [ <input_loop_inits> ] [ <output_ols> ] [
<output_lrr> ] [ <output_nos> ] [ <output_loop_inits> ] [ <link_faliures> ] [ <sync_loss> ] [ <signal_loss> ]
[ <b2b_transmit> ] [ <b2b_receive> ] [ <txwait> ] [ <tx_credit_unavbl> ] [ <b2b_receive_remain> ] [
<b2b_transmit_remain> ] [ <low_priority_b2b_remain> ] [ <off_seq_err_rcvd> ] [ <broadcast_frames> ] [
<errors> ] [ <queue_drops> ] [ <if_down_drops> ] [ <red_drops> ] [ <bad_ether_type_drops> ] [
<bad_protocol_drops> ] [ <arp_drops> ] [ <reass_frames> ] [ <timestamp_error> ] [ <rx_b2b_perf_buff> ]
[ <rx_b2b_credit> ] [ <tx_b2b_credit> ] [ <tx_b2b_low_pri_cre> ] [ <time_last_cleared> ] } } [ {
TABLE_counters_brief <sfp> <fc_input_rate> <fc_frames_in> <fc_output_rate> <fc_frames_out> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifid_ctr</i>       | Enter interface type and number in module/slot format |
| counters              | Show interface counters                               |
| brief                 | (Optional) Show interface counters in brief           |
| __readonly__          | (Optional) Readonly                                   |
| TABLE_counters        | (Optional) Table counters                             |
| <i>sfp</i>            | (Optional) SFP  |
| TABLE_input_rate      | (Optional) Input rate                                 |
| <i>bit_per_sec</i>    | (Optional) Input rate bits per second                 |
| <i>bytes_per_sec</i>  | (Optional) Input rate bytes per second                |
| <i>frames_per_sec</i> | (Optional) Input rate frames per second               |
| TABLE_output_rate     | (Optional) Output rate                                |
| <i>bit_per_sec</i>    | (Optional) Output rate bits per second                |
| <i>bytes_per_sec</i>  | (Optional) Output rate bytes per second               |
| <i>frames_per_sec</i> | (Optional) Output rate frames per second              |
| TABLE_input           | (Optional) Input values                               |

|                         |                             |
|-------------------------|-----------------------------|
| <i>frames</i>           | (Optional) Frames           |
| <i>bytes</i>            | (Optional) Bytes            |
| <i>class_2_frames</i>   | (Optional) Class 2 frames   |
| <i>class_2_bytes</i>    | (Optional) Class 2 bytes    |
| <i>class_3_frames</i>   | (Optional) Class 3 frames   |
| <i>class_3_bytes</i>    | (Optional) Class 3 bytes    |
| <i>class_f_frames</i>   | (Optional) Class f frames   |
| <i>class_f_bytes</i>    | (Optional) Class f bytes    |
| <i>class_2_3_frames</i> | (Optional) Class 2/3 Frames |
| <i>discards</i>         | (Optional) Discards         |
| <i>errors</i>           | (Optional) Errors           |
| <i>crc_fcs</i>          | (Optional) CRC/FCS          |
| <i>unknown_class</i>    | (Optional) Unknown Class    |
| <i>too_long</i>         | (Optional) Frames too long  |
| <i>too_short</i>        | (Optional) Frames too short |
| TABLE_output            | (Optional) Output Values    |
| <i>frames</i>           | (Optional) Frames           |
| <i>bytes</i>            | (Optional) Bytes            |
| <i>class_2_frames</i>   | (Optional) Class 2 frames   |
| <i>class_2_bytes</i>    | (Optional) Class 2 bytes    |
| <i>class_3_frames</i>   | (Optional) Class 3 frames   |
| <i>class_3_bytes</i>    | (Optional) Class 3 bytes    |
| <i>class_f_frames</i>   | (Optional) Class f frames   |
| <i>class_f_bytes</i>    | (Optional) Class f bytes    |
| <i>class_2_3_frames</i> | (Optional) Class 2/3 frames |
| <i>discards</i>         | (Optional) Discards         |
| <i>errors</i>           | (Optional) Errors           |
| <i>crc_fcs</i>          | (Optional) CRC/FCS          |
| <i>timeout_discards</i> | (Optional) Timeout Discards |

|                                |  |
|--------------------------------|--|
| <i>credit_loss</i>             | (Optional) Credit Loss                       |
| <i>input_ols</i>               | (Optional) input ols                         |
| <i>input_lrr</i>               | (Optional) input LRR                         |
| <i>input_nos</i>               | (Optional) input NOS                         |
| <i>input_loop_inits</i>        | (Optional) input loop inits                  |
| <i>output_ols</i>              | (Optional) output OLS                        |
| <i>output_lrr</i>              | (Optional) output LRR                        |
| <i>output_nos</i>              | (Optional) output NOS                        |
| <i>output_loop_inits</i>       | (Optional) output loop inits                 |
| <i>link_faliures</i>           | (Optional) link faliures                     |
| <i>sync_loss</i>               | (Optional) Sync loss                         |
| <i>signal_loss</i>             | (Optional) Signal loss                       |
| <i>b2b_transmit</i>            | (Optional) B2B transmit                      |
| <i>b2b_receive</i>             | (Optional) B2B receive                       |
| <i>txwait</i>                  | (Optional) TxWait                            |
| <i>tx_credit_unavbl</i>        | (Optional) Tx credit unavliable              |
| <i>b2b_receive_remain</i>      | (Optional) B2B receive remain                |
| <i>b2b_transmit_remain</i>     | (Optional) B2B transmit remain               |
| <i>low_priority_b2b_remain</i> | (Optional) Low priority B2B credit remaining |
| <i>time_last_cleared</i>       | (Optional) Last time cleared                 |
| <i>broadcast_frames</i>        | (Optional) Broadcast frames                  |
| <i>errors</i>                  | (Optional) Errors                            |
| <i>queue_drops</i>             | (Optional) Queue drops                       |
| <i>if_down_drops</i>           | (Optional) If down drops                     |
| <i>red_drops</i>               | (Optional) Red drops                         |
| <i>bad_ether_type_drops</i>    | (Optional) Bad ether type drops              |
| <i>bad_protocol_drops</i>      | (Optional) Bad Protocol Drops                |
| <i>arp_drops</i>               | (Optional) Arp Drops                         |
| <i>timestamp_error</i>         | (Optional) Timestamp Error                   |



|                           |   |
|---------------------------|---|
| <i>reass_frames</i>       | (Optional) Reass Frames                   |
| <i>rx_b2b_perf_buff</i>   | (Optional) RX B2B performance buffer      |
| <i>rx_b2b_credit</i>      | (Optional) RX B2B credit remaining        |
| <i>tx_b2b_credit</i>      | (Optional) TX B2B credit remaining        |
| <i>tx_b2b_low_pri_cre</i> | (Optional) TX B2B low priority Credit     |
| <i>off_seq_err_rcvd</i>   | (Optional) Offset Sequence Error Received |
| TABLE_counters_brief      | (Optional) Table counters brief           |
| <i>sfp</i>                | (Optional) FC id                          |
| <i>fc_input_rate</i>      | (Optional) Input rate                     |
| <i>fc_frames_in</i>       | (Optional) Frames in                      |
| <i>fc_output_rate</i>     | (Optional) Output rate                    |
| <i>fc_frames_out</i>      | (Optional) Frames out                     |

**Command Mode**

- /exec

## show interface counters

```
show interface <ifid_ctr> counters [ snmp ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] } { TABLE_tx_counters
<interface_tx> [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast>
] } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| interface           | Show interface status and information                 |
| <i>ifid_ctr</i>     | Enter interface type and number in module/slot format |
| counters            | Show interface counters                               |
| snmp                | (Optional) Show SNMP MIB values                       |
| __readonly__        | (Optional) Read Only                                  |
| <i>interface_rx</i> | (Optional) Interface index rx                         |
| <i>interface_tx</i> | (Optional) Interface index tx                         |
| TABLE_rx_counters   | (Optional) show Rx counters                           |
| <i>eth_inpkts</i>   | (Optional) Packets input                              |
| <i>eth_inbytes</i>  | (Optional) Bytes input                                |
| <i>eth_inucast</i>  | (Optional) Unicasts                                   |
| <i>eth_inmcast</i>  | (Optional) Multicasts                                 |
| <i>eth_inbcast</i>  | (Optional) Broadcasts                                 |
| TABLE_tx_counters   | (Optional) show Tx counters                           |
| <i>eth_outpkts</i>  | (Optional) Packets output                             |
| <i>eth_outbytes</i> | (Optional) Bytes output                               |
| <i>eth_outucast</i> | (Optional) Unicasts                                   |
| <i>eth_outmcast</i> | (Optional) Multicasts                                 |
| <i>eth_outbcast</i> | (Optional) Broadcasts                                 |

### Command Mode

- /exec

## show interface counters

```
show interface counters [ module <module> ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inpkts> ] [ <fc_inframes> ] [ <eth_inbytes> ] [ <fc_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [
<eth_inbcast> ] [ <eth_l3in_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts>
] [ <eth_l3in_ipv4bytes> ] [ <eth_l3in_ipv4pkts> ] [ <eth_l3in_ipv4ucast_pkts> ] [ <eth_l3in_ipv4mcast_pkts>
] [ <eth_l3in_ipv4bcast_pkts> ] [ <eth_l3in_ipv6bytes> ] [ <eth_l3in_ipv6pkts> ] [ <eth_l3in_ipv6ucast_pkts>
] [ <eth_l3in_ipv6mcast_pkts> ] [ <eth_l3in_ipv6bcast_pkts> ] } { TABLE_tx_counters <interface_tx> [
<eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [
<eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] [
<eth_l3out_ipv4bytes> ] [ <eth_l3out_ipv4pkts> ] [ <eth_l3out_ipv4ucast_pkts> ] [
<eth_l3out_ipv4mcast_pkts> ] [ <eth_l3out_ipv4bcast_pkts> ] [ <eth_l3out_ipv6bytes> ] [
<eth_l3out_ipv6pkts> ] [ <eth_l3out_ipv6ucast_pkts> ] [ <eth_l3out_ipv6mcast_pkts> ] [
<eth_l3out_ipv6bcast_pkts> ] } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| interface           | Show interface status and information            |
| counters            | Show interface counters                          |
| module              | (Optional) Limit display to interfaces on module |
| <i>module</i>       | (Optional) Enter module number                   |
| <u>__readonly__</u> | (Optional) Read Only                             |
| <i>interface_rx</i> | (Optional) Interface index rx                    |
| <i>interface_tx</i> | (Optional) Interface index tx                    |
| TABLE_rx_counters   | (Optional) show Rx counters                      |
| TABLE_tx_counters   | (Optional) show Tx counters                      |
| <i>eth_inpkts</i>   | (Optional) Packets input                         |
| <i>fc_inframes</i>  | (Optional) Frames input fc                       |
| <i>eth_inbytes</i>  | (Optional) Bytes input                           |
| <i>fc_inbytes</i>   | (Optional) Bytes input fc                        |
| <i>eth_inucast</i>  | (Optional) Unicasts                              |
| <i>eth_inmcast</i>  | (Optional) Multicasts                            |
| <i>eth_inbcast</i>  | (Optional) Broadcasts                            |
| <i>eth_outpkts</i>  | (Optional) Packets output                        |
| <i>eth_outbytes</i> | (Optional) Bytes output                          |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_outucast</i>             | (Optional) Unicasts              |
| <i>eth_outmcast</i>             | (Optional) Multicasts            |
| <i>eth_outbcast</i>             | (Optional) Broadcasts            |
| <i>eth_l3in_bytes</i>           | (Optional) L3 Rx bytes           |
| <i>eth_l3in_ucastpkts</i>       | (Optional) L3 Rx Unicast pkts    |
| <i>eth_l3in_mcastpkts</i>       | (Optional) L3 Rx Multicast pkts  |
| <i>eth_l3in_bcastpkts</i>       | (Optional) L3 Rx Broadcast pkts  |
| <i>eth_l3in_ipv4bytes</i>       | (Optional) L3 Rx IPv4 bytes      |
| <i>eth_l3in_ipv4pkts</i>        | (Optional) L3 Rx IPv4 pkts       |
| <i>eth_l3in_ipv4ucast_pkts</i>  | (Optional) L3 Rx IPv4 Ucast pkts |
| <i>eth_l3in_ipv4mcast_pkts</i>  | (Optional) L3 Rx IPv4 Mcast pkts |
| <i>eth_l3in_ipv4bcast_pkts</i>  | (Optional) L3 Rx IPv4 Bcast pkts |
| <i>eth_l3in_ipv6bytes</i>       | (Optional) L3 Rx IPv6 bytes      |
| <i>eth_l3in_ipv6pkts</i>        | (Optional) L3 Rx IPv6 pkts       |
| <i>eth_l3in_ipv6ucast_pkts</i>  | (Optional) L3 Rx IPv6 Ucast pkts |
| <i>eth_l3in_ipv6mcast_pkts</i>  | (Optional) L3 Rx IPv6 Mcast pkts |
| <i>eth_l3in_ipv6bcast_pkts</i>  | (Optional) L3 Rx IPv6 Bcast pkts |
| <i>eth_l3out_bytes</i>          | (Optional) L3 Tx bytes           |
| <i>eth_l3out_ucastpkts</i>      | (Optional) L3 Tx Unicast pkts    |
| <i>eth_l3out_mcastpkts</i>      | (Optional) L3 Tx Multicast pkts  |
| <i>eth_l3out_bcastpkts</i>      | (Optional) L3 Tx Broadcast pkts  |
| <i>eth_l3out_ipv4bytes</i>      | (Optional) L3 Tx IPv4 bytes      |
| <i>eth_l3out_ipv4pkts</i>       | (Optional) L3 Tx IPv4 pkts       |
| <i>eth_l3out_ipv4ucast_pkts</i> | (Optional) L3 Tx IPv4 Ucast pkts |
| <i>eth_l3out_ipv4mcast_pkts</i> | (Optional) L3 Tx IPv4 Mcast pkts |
| <i>eth_l3out_ipv4bcast_pkts</i> | (Optional) L3 Tx IPv4 Bcast pkts |
| <i>eth_l3out_ipv6bytes</i>      | (Optional) L3 Tx IPv6 bytes      |
| <i>eth_l3out_ipv6pkts</i>       | (Optional) L3 Tx IPv6 pkts       |
| <i>eth_l3out_ipv6ucast_pkts</i> | (Optional) L3 Tx IPv6 Ucast pkts |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3out_ipv6mcast_pkts</i> | (Optional) L3 Tx IPv6 Mcast pkts |
| <i>eth_l3out_ipv6bcast_pkts</i> | (Optional) L3 Tx IPv6 Bcast pkts |

**Command Mode**

- /exec

## show interface counters

```
show interface <ifeth_ctr_po> counters [ snmp ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_ipv4bytes> ] [
<eth_l3in_ipv4pkts> ] [ <eth_l3in_ipv4ucast_pkts> ] [ <eth_l3in_ipv4mcast_pkts> ] [
<eth_l3in_ipv4bcast_pkts> ] [ <eth_l3in_ipv6bytes> ] [ <eth_l3in_ipv6pkts> ] [ <eth_l3in_ipv6ucast_pkts>
] [ <eth_l3in_ipv6mcast_pkts> ] [ <eth_l3in_ipv6bcast_pkts> ] } { TABLE_tx_counters <interface_tx> [
<eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes> ] [
<eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_ipv4bytes> ] [
<eth_l3out_ipv4pkts> ] [ <eth_l3out_ipv4ucast_pkts> ] [ <eth_l3out_ipv4mcast_pkts> ] [
<eth_l3out_ipv4bcast_pkts> ] [ <eth_l3out_ipv6bytes> ] [ <eth_l3out_ipv6pkts> ] [ <eth_l3out_ipv6ucast_pkts>
] [ <eth_l3out_ipv6mcast_pkts> ] [ <eth_l3out_ipv6bcast_pkts> ] } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                       |
| interface                      | Show interface status and information                 |
| <i>ifeth_ctr_po</i>            | Enter interface type and number in module/slot format |
| counters                       | Show interface counters                               |
| snmp                           | (Optional) Show SNMP MIB values                       |
| <u>__readonly__</u>            | (Optional) Read Only                                  |
| TABLE_rx_counters              | (Optional) show Rx counters                           |
| <i>interface_rx</i>            | (Optional) Interface index rx                         |
| <i>eth_inbytes</i>             | (Optional) Bytes input                                |
| <i>eth_inucast</i>             | (Optional) Unicasts input                             |
| <i>eth_inmcast</i>             | (Optional) Multicasts input                           |
| <i>eth_inbcast</i>             | (Optional) Broadcasts input                           |
| <i>eth_l3in_bytes</i>          | (Optional) L3 Rx bytes                                |
| <i>eth_l3in_ucastpkts</i>      | (Optional) L3 Rx Unicast pkts                         |
| <i>eth_l3in_mcastpkts</i>      | (Optional) L3 Rx Multicast pkts                       |
| <i>eth_l3in_bcastpkts</i>      | (Optional) L3 Rx Broadcast pkts                       |
| <i>eth_l3in_ipv4bytes</i>      | (Optional) L3 Rx IPv4 bytes                           |
| <i>eth_l3in_ipv4pkts</i>       | (Optional) L3 Rx IPv4 pkts                            |
| <i>eth_l3in_ipv4ucast_pkts</i> | (Optional) L3 Rx IPv4 Ucast pkts                      |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3in_ipv4mcast_pkts</i>  | (Optional) L3 Rx IPv4 Mcast pkts |
| <i>eth_l3in_ipv4bcast_pkts</i>  | (Optional) L3 Rx IPv4 Bcast pkts |
| <i>eth_l3in_ipv6bytes</i>       | (Optional) L3 Rx IPv6 bytes      |
| <i>eth_l3in_ipv6pkts</i>        | (Optional) L3 Rx IPv6 pkts       |
| <i>eth_l3in_ipv6ucast_pkts</i>  | (Optional) L3 Rx IPv6 Ucast pkts |
| <i>eth_l3in_ipv6mcast_pkts</i>  | (Optional) L3 Rx IPv6 Mcast pkts |
| <i>eth_l3in_ipv6bcast_pkts</i>  | (Optional) L3 Rx IPv6 Bcast pkts |
| TABLE_tx_counters               | (Optional) show Tx counters      |
| <i>interface_tx</i>             | (Optional) Interface index tx    |
| <i>eth_outbytes</i>             | (Optional) Bytes output          |
| <i>eth_outucast</i>             | (Optional) Unicasts output       |
| <i>eth_outmcast</i>             | (Optional) Multicasts output     |
| <i>eth_outbcast</i>             | (Optional) Broadcasts output     |
| <i>eth_l3out_bytes</i>          | (Optional) L3 Tx bytes           |
| <i>eth_l3out_ucastpkts</i>      | (Optional) L3 Tx Unicast pkts    |
| <i>eth_l3out_mcastpkts</i>      | (Optional) L3 Tx Multicast pkts  |
| <i>eth_l3out_bcastpkts</i>      | (Optional) L3 Tx Broadcast pkts  |
| <i>eth_l3out_ipv4bytes</i>      | (Optional) L3 Tx IPv4 bytes      |
| <i>eth_l3out_ipv4pkts</i>       | (Optional) L3 Tx IPv4 pkts       |
| <i>eth_l3out_ipv4ucast_pkts</i> | (Optional) L3 Tx IPv4 Ucast pkts |
| <i>eth_l3out_ipv4mcast_pkts</i> | (Optional) L3 Tx IPv4 Mcast pkts |
| <i>eth_l3out_ipv4bcast_pkts</i> | (Optional) L3 Tx IPv4 Bcast pkts |
| <i>eth_l3out_ipv6bytes</i>      | (Optional) L3 Tx IPv6 bytes      |
| <i>eth_l3out_ipv6pkts</i>       | (Optional) L3 Tx IPv6 pkts       |
| <i>eth_l3out_ipv6ucast_pkts</i> | (Optional) L3 Tx IPv6 Ucast pkts |
| <i>eth_l3out_ipv6mcast_pkts</i> | (Optional) L3 Tx IPv6 Mcast pkts |
| <i>eth_l3out_ipv6bcast_pkts</i> | (Optional) L3 Tx IPv6 Bcast pkts |

### Command Mode

- /exec

## show interface counters

```
show interface <ifeth_ctr> counters [ __readonly__ { TABLE_rx_counters <interface_rx> [ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_ipv4bytes> ] [ <eth_l3in_ipv4pkts> ] [ <eth_l3in_ipv4ucast_pkts> ] [ <eth_l3in_ipv4mcast_pkts> ] [ <eth_l3in_ipv4bcast_pkts> ] [ <eth_l3in_ipv6bytes> ] [ <eth_l3in_ipv6pkts> ] [ <eth_l3in_ipv6ucast_pkts> ] [ <eth_l3in_ipv6mcast_pkts> ] [ <eth_l3in_ipv6bcast_pkts> ] } { TABLE_tx_counters <interface_tx> [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_ipv4bytes> ] [ <eth_l3out_ipv4pkts> ] [ <eth_l3out_ipv4ucast_pkts> ] [ <eth_l3out_ipv4mcast_pkts> ] [ <eth_l3out_ipv4bcast_pkts> ] [ <eth_l3out_ipv6bytes> ] [ <eth_l3out_ipv6pkts> ] [ <eth_l3out_ipv6ucast_pkts> ] [ <eth_l3out_ipv6mcast_pkts> ] [ <eth_l3out_ipv6bcast_pkts> ] } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                       |
| interface                      | Show interface status and information                 |
| <i>ifeth_ctr</i>               | Enter interface type and number in module/slot format |
| counters                       | Show interface counters                               |
| <i>__readonly__</i>            | (Optional) Read Only                                  |
| TABLE_rx_counters              | (Optional) show Rx counters                           |
| <i>interface_rx</i>            | (Optional) Interface index rx                         |
| <i>eth_inbytes</i>             | (Optional) Bytes input                                |
| <i>eth_inucast</i>             | (Optional) Unicasts input                             |
| <i>eth_inmcast</i>             | (Optional) Multicasts input                           |
| <i>eth_inbcast</i>             | (Optional) Broadcasts input                           |
| <i>eth_l3in_bytes</i>          | (Optional) L3 Rx bytes                                |
| <i>eth_l3in_ucastpkts</i>      | (Optional) L3 Rx Unicast pkts                         |
| <i>eth_l3in_mcastpkts</i>      | (Optional) L3 Rx Multicast pkts                       |
| <i>eth_l3in_bcastpkts</i>      | (Optional) L3 Rx Broadcast pkts                       |
| <i>eth_l3in_ipv4bytes</i>      | (Optional) L3 Rx IPv4 bytes                           |
| <i>eth_l3in_ipv4pkts</i>       | (Optional) L3 Rx IPv4 pkts                            |
| <i>eth_l3in_ipv4ucast_pkts</i> | (Optional) L3 Rx IPv4 Ucast pkts                      |
| <i>eth_l3in_ipv4mcast_pkts</i> | (Optional) L3 Rx IPv4 Mcast pkts                      |



|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3in_ipv4bcast_pkts</i>  | (Optional) L3 Rx IPv4 Bcast pkts |
| <i>eth_l3in_ipv6bytes</i>       | (Optional) L3 Rx IPv6 bytes      |
| <i>eth_l3in_ipv6pkts</i>        | (Optional) L3 Rx IPv6 pkts       |
| <i>eth_l3in_ipv6ucast_pkts</i>  | (Optional) L3 Rx IPv6 Ucast pkts |
| <i>eth_l3in_ipv6mcast_pkts</i>  | (Optional) L3 Rx IPv6 Mcast pkts |
| <i>eth_l3in_ipv6bcast_pkts</i>  | (Optional) L3 Rx IPv6 Bcast pkts |
| TABLE_tx_counters               | (Optional) show Tx counters      |
| <i>interface_tx</i>             | (Optional) Interface index tx    |
| <i>eth_outbytes</i>             | (Optional) Bytes output          |
| <i>eth_outucast</i>             | (Optional) Unicasts output       |
| <i>eth_outmcast</i>             | (Optional) Multicasts output     |
| <i>eth_outbcast</i>             | (Optional) Broadcasts output     |
| <i>eth_l3out_bytes</i>          | (Optional) L3 Tx bytes           |
| <i>eth_l3out_ucastpkts</i>      | (Optional) L3 Tx Unicast pkts    |
| <i>eth_l3out_mcastpkts</i>      | (Optional) L3 Tx Multicast pkts  |
| <i>eth_l3out_bcastpkts</i>      | (Optional) L3 Tx Broadcast pkts  |
| <i>eth_l3out_ipv4bytes</i>      | (Optional) L3 Tx IPv4 bytes      |
| <i>eth_l3out_ipv4pkts</i>       | (Optional) L3 Tx IPv4 pkts       |
| <i>eth_l3out_ipv4ucast_pkts</i> | (Optional) L3 Tx IPv4 Ucast pkts |
| <i>eth_l3out_ipv4mcast_pkts</i> | (Optional) L3 Tx IPv4 Mcast pkts |
| <i>eth_l3out_ipv4bcast_pkts</i> | (Optional) L3 Tx IPv4 Bcast pkts |
| <i>eth_l3out_ipv6bytes</i>      | (Optional) L3 Tx IPv6 bytes      |
| <i>eth_l3out_ipv6pkts</i>       | (Optional) L3 Tx IPv6 pkts       |
| <i>eth_l3out_ipv6ucast_pkts</i> | (Optional) L3 Tx IPv6 Ucast pkts |
| <i>eth_l3out_ipv6mcast_pkts</i> | (Optional) L3 Tx IPv6 Mcast pkts |
| <i>eth_l3out_ipv6bcast_pkts</i> | (Optional) L3 Tx IPv6 Bcast pkts |

**Command Mode**

- /exec

## show interface counters

```
show interface <ifrange> counters [ __readonly__ TABLE_interface <interface> [ <overlay_load_interval>
] [ <overlay_rx_ucastpkts> ] [ <overlay_rx_ucastbytes> ] [ <overlay_rx_mcastpkts> ] [
<overlay_rx_mcastbytes> ] [ <overlay_rx_pkts> ] [ <overlay_rx_bytes> ] [ <overlay_rx_bcastpkts> ] [
<overlay_rx_bcastbytes> ] [ <overlay_rx_bitrate> ] [ <overlay_rx_pktrate> ] [ <overlay_tx_ucastpkts> ] [
<overlay_tx_ucastbytes> ] [ <overlay_tx_mcastpkts> ] [ <overlay_tx_mcastbytes> ] [ <overlay_tx_bcastpkts>
] [ <overlay_tx_bcastbytes> ] [ <overlay_tx_pkts> ] [ <overlay_tx_bytes> ] [ <overlay_tx_bitrate> ] [
<overlay_tx_pktrate> ] ]
```

### Syntax Description

|                              |                                       |
|------------------------------|---------------------------------------|
| show                         | Show running system information       |
| interface                    | Show interface status and information |
| <i>ifrange</i>               | Enter interface type and number       |
| counters                     | Show interface counters               |
| <i>__readonly__</i>          | (Optional) Read Only                  |
| <i>interface</i>             | (Optional) Interface index            |
| TABLE_interface              | (Optional) show interface             |
| <i>overlay_load_interval</i> | (Optional) Load interval              |
| <i>overlay_rx_ucastpkts</i>  | (Optional) Received ucast pkts        |
| <i>overlay_rx_ucastbytes</i> | (Optional) Received ucast bytes       |
| <i>overlay_rx_mcastpkts</i>  | (Optional) Received mcast pkts        |
| <i>overlay_rx_mcastbytes</i> | (Optional) Received mcast bytes       |
| <i>overlay_rx_bcastpkts</i>  | (Optional) Received bcast pkts        |
| <i>overlay_rx_bcastbytes</i> | (Optional) Received bcast bytes       |
| <i>overlay_rx_pkts</i>       | (Optional) Total received pkts        |
| <i>overlay_rx_bytes</i>      | (Optional) Total received bytes       |
| <i>overlay_rx_bitrate</i>    | (Optional) Receive bit rate           |
| <i>overlay_rx_pktrate</i>    | (Optional) Receive pkt rate           |
| <i>overlay_tx_ucastpkts</i>  | (Optional) Trasnmitted ucast pkts     |
| <i>overlay_tx_ucastbytes</i> | (Optional) Trasnmitted ucast bytes    |
| <i>overlay_tx_mcastpkts</i>  | (Optional) Trasnmitted mcast pkts     |
| <i>overlay_tx_mcastbytes</i> | (Optional) Trasnmitted mcast bytes    |

|                              |                                    |
|------------------------------|------------------------------------|
| <i>overlay_tx_bcastpkts</i>  | (Optional) Trasnmitted beast pkts  |
| <i>overlay_tx_bcastbytes</i> | (Optional) Trasnmitted beast bytes |
| <i>overlay_tx_pkts</i>       | (Optional) Total transmitted pkts  |
| <i>overlay_tx_bytes</i>      | (Optional) Total transmitted bytes |
| <i>overlay_tx_bitrate</i>    | (Optional) Transmit bit rate       |
| <i>overlay_tx_pktrate</i>    | (Optional) Transmit pkt rate       |

**Command Mode**

- /exec

## show interface counters

```
show interface <ifrange> counters [ __readonly__ { TABLE_nve_counters <interface> [ <ucast_inbytes> ]
[ <ucast_inpkts> ] [ <ucast_outbytes> ] [ <ucast_outpkts> ] [ <mcast_inbytes> ] [ <mcast_inpkts> ] [
<mcast_outbytes> ] [ <mcast_outpkts> ] } ]
```

### Syntax Description

|                       |                                       |
|-----------------------|---------------------------------------|
| show                  | Show running system information       |
| interface             | Show interface status and information |
| <i>ifrange</i>        | Enter interface type and number       |
| counters              | Show interface counters               |
| <i>__readonly__</i>   | (Optional) Read Only                  |
| <i>interface</i>      | (Optional) Interface index            |
| TABLE_nve_counters    | (Optional) show interface             |
| <i>ucast_inbytes</i>  | (Optional) ucast bytes input          |
| <i>ucast_inpkts</i>   | (Optional) ucast packets input        |
| <i>ucast_outbytes</i> | (Optional) ucast bytes output         |
| <i>ucast_outpkts</i>  | (Optional) ucast packets output       |
| <i>mcast_inbytes</i>  | (Optional) mcast bytes input          |
| <i>mcast_inpkts</i>   | (Optional) mcast packets input        |
| <i>mcast_outbytes</i> | (Optional) mcast bytes output         |
| <i>mcast_outpkts</i>  | (Optional) mcast packets output       |

### Command Mode

- /exec

## show interface counters brief

```
show interface <ifeth_ctr_brf> counters brief [ <counter_val> ] [ __readonly__ TABLE_interface <interface>
<eth_inrate1> <eth_inframes1> <eth_outrate1> <eth_outframes1> <eth_load_intv1> <eth_inrate2>
<eth_inframes2> <eth_outrate2> <eth_outframes2> <eth_load_intv2> [ <eth_inrate3> <eth_inframes3>
<eth_outrate3> <eth_outframes3> <eth_load_intv3> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                |
| interface             | Show interface status and information                          |
| <i>ifeth_ctr_brf</i>  | Enter interface type and number in module/slot format          |
| counters              | Show interface counters  |
| brief                 | Show interface counters in brief                               |
| <i>counter_val</i>    | (Optional) Specify a single load interval id to show the rates |
| <i>__readonly__</i>   | (Optional) Read Only   |
| TABLE_interface       | (Optional) show interface                                      |
| <i>interface</i>      | (Optional) Interface index                                     |
| <i>eth_inrate1</i>    | (Optional) interval 1 input rate in mbps                       |
| <i>eth_inframes1</i>  | (Optional) interval 1 input rate in frames (pkts)              |
| <i>eth_outrate1</i>   | (Optional) interval 1 output rate in mbps                      |
| <i>eth_outframes1</i> | (Optional) interval 1 output rate in output frames (pkts)      |
| <i>eth_load_intv1</i> | (Optional) interval 1 timer value in sec                       |
| <i>eth_inrate2</i>    | (Optional) interval 2 input rate in mbps                       |
| <i>eth_inframes2</i>  | (Optional) interval 2 input rate in frames (pkts)              |
| <i>eth_outrate2</i>   | (Optional) interval 2 output rate in mbps                      |
| <i>eth_outframes2</i> | (Optional) interval 2 output rate in output frames (pkts)      |
| <i>eth_load_intv2</i> | (Optional) interval 2 timer value in sec                       |
| <i>eth_inrate3</i>    | (Optional) interval 3 input rate in mbps                       |
| <i>eth_inframes3</i>  | (Optional) interval 3 input rate in frames (pkts)              |
| <i>eth_outrate3</i>   | (Optional) interval 3 output rate in mbps                      |
| <i>eth_outframes3</i> | (Optional) interval 3 output rate in output frames (pkts)      |

|                       |  |
|-----------------------|--|
| <i>eth_load_intv3</i> | (Optional) interval 3 timer value in sec |
|-----------------------|--|

**Command Mode**

- /exec

## show interface counters brief

```
show interface counters brief [ <counter_val> ] [ __readonly__ TABLE_interface <interface> [ <eth_inrate1> ] [ <eth_inframes1> ] [ <eth_outrate1> ] [ <eth_outframes1> ] [ <eth_load_intv1> ] [ <eth_inrate2> ] [ <eth_inframes2> ] [ <eth_outrate2> ] [ <eth_outframes2> ] [ <eth_load_intv2> ] [ <eth_inrate3> ] [ <eth_inframes3> ] [ <eth_outrate3> ] [ <eth_outframes3> ] [ <eth_load_intv3> ] [ <fc_input_rate> ] [ <fc_frames_in> ] [ <fc_output_rate> ] [ <fc_frames_out> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                |
| interface             | Show interface status and information                          |
| counters              | Show interface counters  |
| brief                 | Show interface counters in brief                               |
| <i>counter_val</i>    | (Optional) Specify a single load interval id to show the rates |
| <i>__readonly__</i>   | (Optional) Read Only   |
| <i>interface</i>      | (Optional) Interface index                                     |
| TABLE_interface       | (Optional) show interface                                      |
| <i>eth_inrate1</i>    | (Optional) interval 1 input rate in mbps                       |
| <i>eth_inframes1</i>  | (Optional) interval 1 input rate in frames (pkts)              |
| <i>eth_outrate1</i>   | (Optional) interval 1 output rate in mbps                      |
| <i>eth_outframes1</i> | (Optional) interval 1 output rate in output frames (pkts)      |
| <i>eth_load_intv1</i> | (Optional) interval 1 timer value in sec                       |
| <i>eth_inrate2</i>    | (Optional) interval 2 input rate in mbps                       |
| <i>eth_inframes2</i>  | (Optional) interval 2 input rate in frames (pkts)              |
| <i>eth_outrate2</i>   | (Optional) interval 2 output rate in mbps                      |
| <i>eth_outframes2</i> | (Optional) interval 2 output rate in output frames (pkts)      |
| <i>eth_load_intv2</i> | (Optional) interval 2 timer value in sec                       |
| <i>eth_inrate3</i>    | (Optional) interval 3 input rate in mbps                       |
| <i>eth_inframes3</i>  | (Optional) interval 3 input rate in frames (pkts)              |
| <i>eth_outrate3</i>   | (Optional) interval 3 output rate in mbps                      |
| <i>eth_outframes3</i> | (Optional) interval 3 output rate in output frames (pkts)      |
| <i>eth_load_intv3</i> | (Optional) interval 3 timer value in sec                       |

|                       |                        |
|-----------------------|------------------------|
| <i>fc_input_rate</i>  | (Optional) Input rate  |
| <i>fc_frames_in</i>   | (Optional) Frames in   |
| <i>fc_output_rate</i> | (Optional) Output rate |
| <i>fc_frames_out</i>  | (Optional) Frames out  |

**Command Mode**

- /exec



## show interface counters detailed

```
show interface <ifeth_ctr_dtl> counters detailed [ snmp ] [ __readonly__ TABLE_interface <interface> [
<eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [ <eth_load_interval1_tx> ] [
<eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ] [ <eth_inrate1_summary_pkts> ] [
<eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [ <eth_load_interval2_rx> ] [
<eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [ <eth_outrate2_bits> ] [
<eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ] [
<eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_inpkts> ] [ <eth_inucast> ] [
<eth_inmcast> ] [ <eth_inbcast> ] [ <eth_ingiants> ] [ <eth_inbytes> ] [ <eth_storm_supp> ] [ <eth_inb64> ] [
<eth_inb65_127> ] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [
<eth_inb1024_1518> ] [ <eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outpkts> ] [ <eth_outucast> ] [
<eth_outmcast> ] [ <eth_outbcast> ] [ <eth_outgiants> ] [ <eth_outbytes> ] [ <eth_outb64> ] [
<eth_outb65_127> ] [ <eth_outb128_255> ] [ <eth_outb256_511> ] [ <eth_outb512_1023> ] [
<eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [ <eth_outtrunk> ] [ <eth_nobuf> ] [ <eth_runs> ] [
<eth_crc> ] [ <eth_ecc> ] [ <eth_overrun> ] [ <eth_underrun> ] [ <eth_ignored> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_in_ifdown_drops> ] [ <eth_coll> ] [ <eth_latecoll> ] [ <eth_lostcarrier> ] [
<eth_nocarrier> ] [ <eth_babbles> ] [ <eth_watchdog> ] [ <eth_dribble> ] [ <eth_inerr> ] [ <eth_outerr> ] [
<eth_deferred> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_single_coll> ] [ <eth_multi_coll> ] [
<eth_excess_coll> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [ <eth_outcrc> ] [ <eth_symbol> ] [
<eth_out_drops> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost> ] [
<eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_inpause> ] [ <eth_outpause> ] [ <eth_resets> ] [ <eth_sqetest> ] [
<eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes> ] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [
<eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [ <eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [
<eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [
<eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [
<eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [
<eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [
<eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [
<eth_insw_switched> ] [ <eth_throtles> ] [ <eth_frame> ] [ <eth_outhw_switched> ] [ <eth_outsw_switched> ] [
<eth_buffail> ] [ <eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_fcoe_in_pkts> ] [
<eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [ <eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [
<eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [ <eth_nfcoe_out_octets> ] ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                       |
| interface            | Show interface status and information                 |
| <i>ifeth_ctr_dtl</i> | Enter interface type and number in module/slot format |
| counters             | Show interface counters                               |
| detailed             | Show only non-zero counters                           |
| snmp                 | (Optional) Show SNMP MIB values                       |

|  |   |
|--|---|
| <code>__readonly__</code>              | (Optional) Read Only                          |
| <code>interface</code>                 | (Optional) Interface index                    |
| <code>TABLE_interface</code>           | (Optional) show interface                     |
| <code>eth_load_interval1_rx</code>     | (Optional) interval 1 timer value in sec      |
| <code>eth_inrate1_bits</code>          | (Optional) interval 1 input rate bits/sec     |
| <code>eth_inrate1_pkts</code>          | (Optional) interval 1 input rate pkts/sec     |
| <code>eth_load_interval1_tx</code>     | (Optional) interval 1 timer value in sec      |
| <code>eth_outrate1_bits</code>         | (Optional) interval 1 output rate bits/sec    |
| <code>eth_outrate1_pkts</code>         | (Optional) interval 1 output rate pkts/sec    |
| <code>eth_inrate1_summary_bits</code>  | (Optional) interval 1 input rate bit summary  |
| <code>eth_inrate1_summary_pkts</code>  | (Optional) interval 1 input rate pkt summary  |
| <code>eth_outrate1_summary_bits</code> | (Optional) interval 1 output rate bit summary |
| <code>eth_outrate1_summary_pkts</code> | (Optional) interval 1 output rate pkt summary |
| <code>eth_load_interval2_rx</code>     | (Optional) interval 2 timer value in sec      |
| <code>eth_inrate2_bits</code>          | (Optional) interval 2 input rate bits/sec     |
| <code>eth_inrate2_pkts</code>          | (Optional) interval 2 input rate pkts/sec     |
| <code>eth_load_interval2_tx</code>     | (Optional) interval 2 timer value in sec      |
| <code>eth_outrate2_bits</code>         | (Optional) interval 2 output rate bits/sec    |
| <code>eth_outrate2_pkts</code>         | (Optional) interval 2 output rate pkts/sec    |
| <code>eth_inrate2_summary_bits</code>  | (Optional) interval 2 input rate bit summary  |
| <code>eth_inrate2_summary_pkts</code>  | (Optional) interval 2 input rate pkt summary  |
| <code>eth_outrate2_summary_bits</code> | (Optional) interval 2 output rate bit summary |
| <code>eth_outrate2_summary_pkts</code> | (Optional) interval 2 output rate pkt summary |
| <code>eth_load_interval3_rx</code>     | (Optional) interval 3 timer value in sec      |
| <code>eth_inrate3_bits</code>          | (Optional) interval 3 input rate bits/sec     |
| <code>eth_inrate3_pkts</code>          | (Optional) interval 3 input rate pkts/sec     |
| <code>eth_load_interval3_tx</code>     | (Optional) interval 3 timer value in sec      |
| <code>eth_outrate3_bits</code>         | (Optional) interval 3 output rate bits/sec    |
| <code>eth_outrate3_pkts</code>         | (Optional) interval 3 output rate pkts/sec    |

|                                  |   |
|----------------------------------|---|
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary      |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary      |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary     |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary     |
| <i>eth_inpkts</i>                | (Optional) Packets input                          |
| <i>eth_inucast</i>               | (Optional) Unicasts                               |
| <i>eth_inmcast</i>               | (Optional) Multicasts                             |
| <i>eth_inbcast</i>               | (Optional) Broadcasts                             |
| <i>eth_ingiants</i>              | (Optional) giants                                 |
| <i>eth_inbytes</i>               | (Optional) Bytes input                            |
| <i>eth_storm_supp</i>            | (Optional) storm suppression                      |
| <i>eth_inb64</i>                 | (Optional) input pkts between 0 and 64 bytes      |
| <i>eth_inb65_127</i>             | (Optional) input pkts between 65 and 127 bytes    |
| <i>eth_inb128_255</i>            | (Optional) input pkts between 128 and 255 bytes   |
| <i>eth_inb256_511</i>            | (Optional) input pkts between 256 and 511 bytes   |
| <i>eth_inb512_1023</i>           | (Optional) input pkts between 512 and 1023 bytes  |
| <i>eth_inb1024_1518</i>          | (Optional) input pkts between 1024 and 1518 bytes |
| <i>eth_inb1519_1548</i>          | (Optional) input pkts between 1519 and 1548 bytes |
| <i>eth_intrunk</i>               | (Optional) input trunk pkts                       |
| <i>eth_outpkts</i>               | (Optional) packets output                         |
| <i>eth_outucast</i>              | (Optional) Unicasts                               |
| <i>eth_outmcast</i>              | (Optional) Multicasts                             |
| <i>eth_outbcast</i>              | (Optional) Broadcasts                             |
| <i>eth_outgiants</i>             | (Optional) giants                                 |
| <i>eth_outbytes</i>              | (Optional) bytes output                           |
| <i>eth_outb64</i>                | (Optional) output pkts between 0 and 64 bytes     |
| <i>eth_outb65_127</i>            | (Optional) output pkts between 65 and 127 bytes   |
| <i>eth_outb128_255</i>           | (Optional) output pkts between 128 and 255 bytes  |
| <i>eth_outb256_511</i>           | (Optional) output pkts between 256 and 511 bytes  |

|                            |  |
|----------------------------|--|
| <i>eth_outb512_1023</i>    | (Optional) output pkts between 512 and 1023 bytes  |
| <i>eth_outb1024_1518</i>   | (Optional) output pkts between 1024 and 1518 bytes |
| <i>eth_outb1519_1548</i>   | (Optional) output pkts between 1519 and 1548 bytes |
| <i>eth_outtrunk</i>        | (Optional) output trunk pkts                       |
| <i>eth_nobuf</i>           | (Optional) No buffer received                      |
| <i>eth_runts</i>           | (Optional) runts                                   |
| <i>eth_crc</i>             | (Optional) CRC                                     |
| <i>eth_ecc</i>             | (Optional) ECC                                     |
| <i>eth_overrun</i>         | (Optional) overrun                                 |
| <i>eth_underrun</i>        | (Optional) underruns                               |
| <i>eth_ignored</i>         | (Optional) ignored                                 |
| <i>eth_bad_eth</i>         | (Optional) bad ether type drop                     |
| <i>eth_bad_proto</i>       | (Optional) bad protocol drops                      |
| <i>eth_in_ifdown_drops</i> | (Optional) Input if-down drops                     |
| <i>eth_coll</i>            | (Optional) collisions                              |
| <i>eth_latecoll</i>        | (Optional) late collision                          |
| <i>eth_lostcarrier</i>     | (Optional) lost carrier                            |
| <i>eth_nocarrier</i>       | (Optional) no carrier                              |
| <i>eth_babbles</i>         | (Optional) babbles                                 |
| <i>eth_watchdog</i>        | (Optional) watchdog                                |
| <i>eth_dribble</i>         | (Optional) input packets with dribble condition    |
| <i>eth_inerr</i>           | (Optional) input errors                            |
| <i>eth_outerr</i>          | (Optional) output errors                           |
| <i>eth_deferred</i>        | (Optional) deferred                                |
| <i>eth_jabbers</i>         | (Optional) jabbers                                 |
| <i>eth_shortframe</i>      | (Optional) short frames                            |
| <i>eth_single_coll</i>     | (Optional) single collisions                       |
| <i>eth_multi_coll</i>      | (Optional) multi collisions                        |
| <i>eth_excess_coll</i>     | (Optional) excessive collisions                    |

|                            |                                       |
|----------------------------|---------------------------------------|
| <i>eth_indiscard</i>       | (Optional) discards                   |
| <i>eth_bad_encap</i>       | (Optional) bad encapsulation          |
| <i>eth_outcrc</i>          | (Optional) Output CRC                 |
| <i>eth_symbol</i>          | (Optional) symbol errors              |
| <i>eth_out_drops</i>       | (Optional) output drops               |
| <i>eth_bpdu_outlost</i>    | (Optional) BPDU output lost           |
| <i>eth_cos0_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos1_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos2_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos3_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos4_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos5_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos6_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos7_outlost</i>    | (Optional) output pkts                |
| <i>eth_inpause</i>         | (Optional) pause input                |
| <i>eth_outpause</i>        | (Optional) PAUSE output               |
| <i>eth_resets</i>          | (Optional) interface resets           |
| <i>eth_sqetest</i>         | (Optional) SQE test                   |
| <i>eth_l2_ucastpkts</i>    | (Optional) L2 switched ucast pkts     |
| <i>eth_l2_ucastbytes</i>   | (Optional) L2 switched ucast bytes    |
| <i>eth_l2_mcastpkts</i>    | (Optional) L2 switched mcast pkts     |
| <i>eth_l2_mcastbytes</i>   | (Optional) L2 switched mcast bytes    |
| <i>eth_l2_bcastpkts</i>    | (Optional) L2 switched bcast pkts     |
| <i>eth_l2_bcastbytes</i>   | (Optional) L2 switched bcast bytes    |
| <i>eth_l3in_ucastpkts</i>  | (Optional) L3 in switched ucast pkts  |
| <i>eth_l3in_ucastbytes</i> | (Optional) L3 in switched ucast bytes |
| <i>eth_l3in_mcastpkts</i>  | (Optional) L3 in switched mcast pkts  |
| <i>eth_l3in_mcastbytes</i> | (Optional) L3 in switched mcast bytes |
| <i>eth_l3in_bcastpkts</i>  | (Optional) L3 in switched bcast pkts  |

|                               |  |
|-------------------------------|--|
| <i>eth_l3in_bcastbytes</i>    | (Optional) L3 in switched bcast bytes                    |
| <i>eth_l3out_ucastpkts</i>    | (Optional) L3 out switched ucast pkts                    |
| <i>eth_l3out_ucastbytes</i>   | (Optional) L3 out switched ucast bytes                   |
| <i>eth_l3out_mcastpkts</i>    | (Optional) L3 out switched mcast pkts                    |
| <i>eth_l3out_mcastbytes</i>   | (Optional) L3 out switched mcast bytes                   |
| <i>eth_l3out_bcastpkts</i>    | (Optional) L3 out switched bcast pkts                    |
| <i>eth_l3out_bcastbytes</i>   | (Optional) L3 out switched bcast bytes                   |
| <i>eth_l3in_routed_pkts</i>   | (Optional) L3 in routed pkts                             |
| <i>eth_l3in_routed_bytes</i>  | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>  | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i> | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>     | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>      | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>    | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>     | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_ipmcast</i>            | (Optional) IP multicast                                  |
| <i>eth_inhw_switched</i>      | (Optional) Input H/W Switched                            |
| <i>eth_insw_switched</i>      | (Optional) Input S/W Switched                            |
| <i>eth_throtles</i>           | (Optional) throttles                                     |
| <i>eth_frame</i>              | (Optional) frame   |
| <i>eth_outhw_switched</i>     | (Optional) Out H/W Switched                              |
| <i>eth_outsw_switched</i>     | (Optional) Out S/W Switched                              |
| <i>eth_buffail</i>            | (Optional) output buffer failures                        |
| <i>eth_bufswapped</i>         | (Optional) output buffers swapped out                    |
| <i>eth_arpdrops</i>           | (Optional) arp drops                                     |
| <i>eth_out_ifdown_drops</i>   | (Optional) Output if-down drops                          |
| <i>eth_fcoe_in_pkts</i>       | (Optional) fcoe in pkts                                  |
| <i>eth_fcoe_in_octets</i>     | (Optional) fcoe in octets                                |
| <i>eth_fcoe_out_pkts</i>      | (Optional) fcoe out pkts                                 |

|                             |                             |
|-----------------------------|-----------------------------|
| <i>eth_fcoe_out_octets</i>  | (Optional) fcoe out octets  |
| <i>eth_nfcoe_in_pkts</i>    | (Optional) nfcoe in pkts    |
| <i>eth_nfcoe_in_octets</i>  | (Optional) nfcoe in octets  |
| <i>eth_nfcoe_out_pkts</i>   | (Optional) nfcoe out pkts   |
| <i>eth_nfcoe_out_octets</i> | (Optional) nfcoe out octets |

**Command Mode**

- /exec

## show interface counters detailed

```

show interface counters detailed [ snmp ] [ __readonly__ TABLE_interface <interface> [ <vdc_lvl_in_pkts>
] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_ucast> ] [ <vdc_lvl_in_mcast> ] [ <vdc_lvl_in_bcast> ] [
<vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [ <vdc_lvl_in_avg_pkts> ] [ <vdc_lvl_in_avg_bytes> ] [
<vdc_lvl_out_pkts> ] [ <vdc_lvl_out_bytes> ] [ <vdc_lvl_out_ucast> ] [ <vdc_lvl_out_mcast> ] [
<vdc_lvl_out_bcast> ] [ <vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] [ <vdc_lvl_out_avg_pkts> ] [
<vdc_lvl_out_avg_bytes> ] [ <mgmt_in_pkts> ] [ <mgmt_in_bytes> ] [ <mgmt_in_mcast> ] [
<mgmt_in_compressed> ] [ <mgmt_in_errors> ] [ <mgmt_in_frame> ] [ <mgmt_in_overrun> ] [
<mgmt_in_fifo> ] [ <mgmt_out_pkts> ] [ <mgmt_out_bytes> ] [ <mgmt_out_underruns> ] [
<mgmt_out_errors> ] [ <mgmt_out_collisions> ] [ <mgmt_out_fifo> ] [ <mgmt_out_carrier> ] [
<mgmt_align_err> ] [ <mgmt_fcs_err> ] [ <mgmt_xmit_err> ] [ <mgmt_rcv_err> ] [ <mgmt_undersize> ] [
<mgmt_outdisc> ] [ <mgmt_single_col> ] [ <mgmt_multi_col> ] [ <mgmt_late_col> ] [ <mgmt_excess_col>
] [ <mgmt_carri_sen> ] [ <mgmt_runts> ] [ <mgmt_giants> ] [ <mgmt_sqetest_err> ] [ <mgmt_deferred_tx>
] [ <mgmt_inmactx_err> ] [ <mgmt_inmacrx_err> ] [ <mgmt_symbol_err> ] [ <loop_in_pkts> ] [
<loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors> ] [ <loop_in_frame>
] [ <loop_in_overrun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [ <loop_out_underruns>
] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [ <loop_out_carriers> ] [
<eth_load_intervall_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [ <eth_load_interval1_tx> ] [
<eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ] [ <eth_inrate1_summary_pkts>
] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [ <eth_load_interval2_rx> ] [
<eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [ <eth_outrate2_bits> ] [
<eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts> ] [
<eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_inpkts> ] [ <eth_inucast> ] [
<eth_inmcast> ] [ <eth_inbcast> ] [ <eth_ingiants> ] [ <eth_inbytes> ] [ <eth_storm_supp> ] [ <eth_inb64>
] [ <eth_inb65_127> ] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [
<eth_inb1024_1518> ] [ <eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outpkts> ] [ <eth_outucast> ] [
<eth_outmcast> ] [ <eth_outbcast> ] [ <eth_outgiants> ] [ <eth_outbytes> ] [ <eth_outb64> ] [
<eth_outb65_127> ] [ <eth_outb128_255> ] [ <eth_outb256_511> ] [ <eth_outb512_1023> ] [
<eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [ <eth_outtrunk> ] [ <eth_nobuf> ] [ <eth_runts> ] [
<eth_crc> ] [ <eth_ecc> ] [ <eth_overrun> ] [ <eth_underrun> ] [ <eth_ignored> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_in_ifdown_drops> ] [ <eth_coll> ] [ <eth_latecoll> ] [ <eth_lostcarrier> ] [
<eth_nocarrier> ] [ <eth_babbles> ] [ <eth_watchdog> ] [ <eth_dribble> ] [ <eth_inerr> ] [ <eth_outerr> ] [
<eth_deferred> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_single_coll> ] [ <eth_multi_coll> ] [
<eth_excess_coll> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [ <eth_outcrc> ] [ <eth_symbol> ] [
<eth_out_drops> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_inpause> ] [ <eth_outpause> ] [ <eth_resets> ] [ <eth_sqetest> ] [
<eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes> ] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [
<eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [ <eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [
<eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes> ] [ <eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [
<eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [
<eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [
<eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [
<eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [
<eth_insw_switched> ] [ <eth_throtles> ] [ <eth_frame> ] [ <eth_outhw_switched> ] [ <eth_outsw_switched>
] [ <eth_buffail> ] [ <eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_fcoe_in_pkts>

```



```

]] [<eth_fcoe_in_octets> ] [<eth_fcoe_out_pkts> ] [<eth_fcoe_out_octets> ] [<eth_nfcoe_in_pkts> ] [
<eth_nfcoe_in_octets> ] [<eth_nfcoe_out_pkts> ] [<eth_nfcoe_out_octets> ] [<svi_routed_pkts_in> ] [
<svi_routed_bytes_in> ] [<svi_routed_pkts_out> ] [<svi_routed_bytes_out> ] [<svi_ucast_pkts_in> ] [
<svi_ucast_bytes_in> ] [<svi_mcast_pkts_in> ] [<svi_mcast_bytes_in> ] [<svi_ucast_pkts_out> ] [
<svi_ucast_bytes_out> ] [<svi_mcast_pkts_out> ] [<svi_mcast_bytes_out> ] [<svi_ipv4_ucast_pkts_in> ] [
<svi_ipv4_ucast_bytes_in> ] [<svi_ipv4_ucast_pkts_out> ] [<svi_ipv4_ucast_bytes_out> ] [
<svi_ipv4_mcast_pkts_in> ] [<svi_ipv4_mcast_bytes_in> ] [<svi_ipv4_mcast_pkts_out> ] [
<svi_ipv4_mcast_bytes_out> ] [<svi_ipv6_ucast_pkts_in> ] [<svi_ipv6_ucast_bytes_in> ] [
<svi_ipv6_ucast_pkts_out> ] [<svi_ipv6_ucast_bytes_out> ] [<svi_ipv6_mcast_pkts_in> ] [
<svi_ipv6_mcast_bytes_in> ] [<svi_ipv6_mcast_pkts_out> ] [<svi_ipv6_mcast_bytes_out> ] [
<svi_average_input_bits> ] [<svi_average_input_packets> ] [<svi_average_output_bits> ] [
<svi_average_output_packets> ] [<svi_rate_in_mins> ] [<svi_time_last_cleared> ] [<svi_tx_load> ] [
<svi_rx_load> ] [<svi_reliability> ] [<input_rate_bit_per_sec> ] [<input_rate_bytes_per_sec> ] [
<input_rate_frames_per_sec> ] [<output_rate_bit_per_sec> ] [<output_rate_bytes_per_sec> ] [
<output_rate_frames_per_sec> ] [<in_frames> ] [<in_bytes> ] [<class_2_in_frames> ] [<class_2_in_bytes> ] [
<class_3_in_frames> ] [<class_3_in_bytes> ] [<class_f_in_frames> ] [<class_f_in_bytes> ] [
<class_2_3_in_frames> ] [<in_discards> ] [<in_errors> ] [<in_crc_fcs> ] [<in_unknown_class> ] [
<in_too_long> ] [<in_too_short> ] [<out_frames> ] [<out_bytes> ] [<class_2_out_frames> ] [
<class_2_out_bytes> ] [<class_3_out_frames> ] [<class_3_out_bytes> ] [<class_f_out_frames> ] [
<class_f_out_bytes> ] [<class_2_3_out_frames> ] [<out_discards> ] [<out_errors> ] [<out_crc_fcs> ] [
<timeout_discards> ] [<credit_loss> ] [<input_ols> ] [<input_lrr> ] [<input_nos> ] [<input_loop_inits> ] [
<output_ols> ] [<output_lrr> ] [<output_nos> ] [<output_loop_inits> ] [<link_faliures> ] [<sync_loss> ] [
<signal_loss> ] [<b2b_transmit> ] [<b2b_receive> ] [<txwait> ] [<tx_credit_unavbl> ] [
<b2b_receive_remain> ] [<b2b_transmit_remain> ] [<low_priority_b2b_remain> ] [<off_seq_err_rcvd> ] [
<broadcast_frames> ] [<errors> ] [<queue_drops> ] [<if_down_drops> ] [<red_drops> ] [
<bad_ether_type_drops> ] [<bad_protocol_drops> ] [<arp_drops> ] [<reass_frames> ] [<timestamp_error> ] [
<rx_b2b_perf_buff> ] [<rx_b2b_credit> ] [<tx_b2b_credit> ] [<tx_b2b_low_pri_cre> ] [
<time_last_cleared> ] ]

```

### Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information              |
| interface        | Show interface status and information        |
| counters         | Show interface counters                      |
| detailed         | Show only non-zero counters                  |
| snmp             | (Optional) Show SNMP MIB values              |
| __readonly__     | (Optional) Read Only                         |
| TABLE_interface  | (Optional) show interface                    |
| interface        | (Optional) Interface index                   |
| vdc_lvl_in_pkts  | (Optional) VDC level input packets           |
| vdc_lvl_in_bytes | (Optional) VDC level input bytes             |
| vdc_lvl_in_ucast | (Optional) VDC level input unicast packets   |
| vdc_lvl_in_mcast | (Optional) VDC level input multicast packets |

|                              |  |
|------------------------------|--|
| <i>vdc_lvl_in_bcast</i>      | (Optional) VDC level input broadcast packets   |
| <i>vdc_lvl_in_bps</i>        | (Optional) VDC level input bytes per second    |
| <i>vdc_lvl_in_pps</i>        | (Optional) VDC level input packets per second  |
| <i>vdc_lvl_in_avg_pkts</i>   | (Optional) VDC level average input packets     |
| <i>vdc_lvl_in_avg_bytes</i>  | (Optional) VDC level average input bytes       |
| <i>vdc_lvl_out_pkts</i>      | (Optional) VDC level output packets            |
| <i>vdc_lvl_out_bytes</i>     | (Optional) VDC level output bytes              |
| <i>vdc_lvl_out_ucast</i>     | (Optional) VDC level output unicast packets    |
| <i>vdc_lvl_out_mcast</i>     | (Optional) VDC level output multicast packets  |
| <i>vdc_lvl_out_bcast</i>     | (Optional) VDC level output broadcast packets  |
| <i>vdc_lvl_out_bps</i>       | (Optional) VDC level output bytes per second   |
| <i>vdc_lvl_out_pps</i>       | (Optional) VDC level output packets per second |
| <i>vdc_lvl_out_avg_pkts</i>  | (Optional) VDC level average output packets    |
| <i>vdc_lvl_out_avg_bytes</i> | (Optional) VDC level average output bytes      |
| <i>mgmt_in_pkts</i>          | (Optional) Input packets                       |
| <i>mgmt_in_bytes</i>         | (Optional) Input bytes                         |
| <i>mgmt_in_mcast</i>         | (Optional) Input multicast frames              |
| <i>mgmt_in_compressed</i>    | (Optional) Input compressed                    |
| <i>mgmt_in_errors</i>        | (Optional) Input errors                        |
| <i>mgmt_in_frame</i>         | (Optional) Input frame errors                  |
| <i>mgmt_in_overnrun</i>      | (Optional) Input overrun                       |
| <i>mgmt_in_fifo</i>          | (Optional) Input fifo                          |
| <i>mgmt_out_pkts</i>         | (Optional) Output packets                      |
| <i>mgmt_out_bytes</i>        | (Optional) Output bytes                        |
| <i>mgmt_out_underruns</i>    | (Optional) Output overruns                     |
| <i>mgmt_out_errors</i>       | (Optional) Output errors                       |
| <i>mgmt_out_collisions</i>   | (Optional) Output collisions                   |
| <i>mgmt_out_fifo</i>         | (Optional) Output fifo                         |
| <i>mgmt_out_carrier</i>      | (Optional) Output carrier errors               |

|                           |                               |
|---------------------------|-------------------------------|
| <i>mgmt_align_err</i>     | (Optional) Align error        |
| <i>mgmt_fcs_err</i>       | (Optional) FCS error          |
| <i>mgmt_xmit_err</i>      | (Optional) Transmit error     |
| <i>mgmt_rcv_err</i>       | (Optional) Receive error      |
| <i>mgmt_undersize</i>     | (Optional) Undersize          |
| <i>mgmt_outdisc</i>       | (Optional) Out discard        |
| <i>mgmt_single_col</i>    | (Optional) Single collision   |
| <i>mgmt_multi_col</i>     | (Optional) Multiple collision |
| <i>mgmt_late_col</i>      | (Optional) Late collision     |
| <i>mgmt_excess_col</i>    | (Optional) Excess collision   |
| <i>mgmt_carri_sen</i>     | (Optional) Carrier sense      |
| <i>mgmt_runts</i>         | (Optional) Runts              |
| <i>mgmt_giants</i>        | (Optional) Giants             |
| <i>mgmt_sqetest_err</i>   | (Optional) SQETest error      |
| <i>mgmt_deferred_tx</i>   | (Optional) Deferred tx        |
| <i>mgmt_inmactx_err</i>   | (Optional) In MAC tx          |
| <i>mgmt_inmacrx_err</i>   | (Optional) In MAC rx          |
| <i>mgmt_symbol_err</i>    | (Optional) Symbol error       |
| <i>loop_in_pkts</i>       | (Optional) Input packets      |
| <i>loop_in_bytes</i>      | (Optional) Input bytes        |
| <i>loop_in_mcast</i>      | (Optional) Input multicast    |
| <i>loop_in_compressed</i> | (Optional) Input compressed   |
| <i>loop_in_errors</i>     | (Optional) Input errors       |
| <i>loop_in_frame</i>      | (Optional) Input frame errors |
| <i>loop_in_overrun</i>    | (Optional) Input overrun      |
| <i>loop_in_fifo</i>       | (Optional) Input fifo         |
| <i>loop_out_pkts</i>      | (Optional) Output packets     |
| <i>loop_out_bytes</i>     | (Optional) Output bytes       |
| <i>loop_out_underruns</i> | (Optional) Output underruns   |

|                                  |   |
|----------------------------------|---|
| <i>loop_out_errors</i>           | (Optional) Output errors                      |
| <i>loop_out_collisions</i>       | (Optional) Output collisions                  |
| <i>loop_out_fifo</i>             | (Optional) Output fifo                        |
| <i>loop_out_carriers</i>         | (Optional) Output carrier errors              |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec      |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec     |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec     |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec      |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec    |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec    |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary  |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary  |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary |
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec     |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec     |
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec    |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec    |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary  |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary  |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary |
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |

|                                  |   |
|----------------------------------|---|
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec        |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary      |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary      |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary     |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary     |
| <i>eth_inpkts</i>                | (Optional) Packets input                          |
| <i>eth_inucast</i>               | (Optional) Unicasts                               |
| <i>eth_inmcast</i>               | (Optional) Multicasts                             |
| <i>eth_inbcast</i>               | (Optional) Broadcasts                             |
| <i>eth_ingiants</i>              | (Optional) giants                                 |
| <i>eth_inbytes</i>               | (Optional) Bytes input                            |
| <i>eth_storm_supp</i>            | (Optional) storm suppression                      |
| <i>eth_inb64</i>                 | (Optional) input pkts between 0 and 64 bytes      |
| <i>eth_inb65_127</i>             | (Optional) input pkts between 65 and 127 bytes    |
| <i>eth_inb128_255</i>            | (Optional) input pkts between 128 and 255 bytes   |
| <i>eth_inb256_511</i>            | (Optional) input pkts between 256 and 511 bytes   |
| <i>eth_inb512_1023</i>           | (Optional) input pkts between 512 and 1023 bytes  |
| <i>eth_inb1024_1518</i>          | (Optional) input pkts between 1024 and 1518 bytes |
| <i>eth_inb1519_1548</i>          | (Optional) input pkts between 1519 and 1548 bytes |
| <i>eth_intrunk</i>               | (Optional) input trunk pkts                       |
| <i>eth_outpkts</i>               | (Optional) packets output                         |
| <i>eth_outucast</i>              | (Optional) Unicasts                               |
| <i>eth_outmcast</i>              | (Optional) Multicasts                             |
| <i>eth_outbcast</i>              | (Optional) Broadcasts                             |
| <i>eth_outgiants</i>             | (Optional) giants                                 |
| <i>eth_outbytes</i>              | (Optional) bytes output                           |
| <i>eth_outb64</i>                | (Optional) output pkts between 0 and 64 bytes     |
| <i>eth_outb65_127</i>            | (Optional) output pkts between 65 and 127 bytes   |
| <i>eth_outb128_255</i>           | (Optional) output pkts between 128 and 255 bytes  |

|                            |  |
|----------------------------|--|
| <i>eth_outb256_511</i>     | (Optional) output pkts between 256 and 511 bytes   |
| <i>eth_outb512_1023</i>    | (Optional) output pkts between 512 and 1023 bytes  |
| <i>eth_outb1024_1518</i>   | (Optional) output pkts between 1024 and 1518 bytes |
| <i>eth_outb1519_1548</i>   | (Optional) output pkts between 1519 and 1548 bytes |
| <i>eth_outtrunk</i>        | (Optional) output trunk pkts                       |
| <i>eth_nobuf</i>           | (Optional) No buffer received                      |
| <i>eth_runts</i>           | (Optional) runts                                   |
| <i>eth_crc</i>             | (Optional) CRC                                     |
| <i>eth_ecc</i>             | (Optional) ECC                                     |
| <i>eth_overrun</i>         | (Optional) overrun                                 |
| <i>eth_underrun</i>        | (Optional) underruns                               |
| <i>eth_ignored</i>         | (Optional) ignored                                 |
| <i>eth_bad_eth</i>         | (Optional) bad ether type drop                     |
| <i>eth_bad_proto</i>       | (Optional) bad protocol drops                      |
| <i>eth_in_ifdown_drops</i> | (Optional) Input if-down drops                     |
| <i>eth_coll</i>            | (Optional) collisions                              |
| <i>eth_latecoll</i>        | (Optional) late collision                          |
| <i>eth_lostcarrier</i>     | (Optional) lost carrier                            |
| <i>eth_nocarrier</i>       | (Optional) no carrier                              |
| <i>eth_babbles</i>         | (Optional) babbles                                 |
| <i>eth_watchdog</i>        | (Optional) watchdog                                |
| <i>eth_dribble</i>         | (Optional) input packets with dribble condition    |
| <i>eth_inerr</i>           | (Optional) input errors                            |
| <i>eth_outerr</i>          | (Optional) output errors                           |
| <i>eth_deferred</i>        | (Optional) deferred                                |
| <i>eth_jabbers</i>         | (Optional) jabbers                                 |
| <i>eth_shortframe</i>      | (Optional) short frames                            |
| <i>eth_single_coll</i>     | (Optional) single collisions                       |
| <i>eth_multi_coll</i>      | (Optional) multi collisions                        |

|                            |                                       |
|----------------------------|---------------------------------------|
| <i>eth_excess_coll</i>     | (Optional) excessive collisions       |
| <i>eth_indiscard</i>       | (Optional) discards                   |
| <i>eth_bad_encap</i>       | (Optional) bad encapsulation          |
| <i>eth_outcrc</i>          | (Optional) Output CRC                 |
| <i>eth_symbol</i>          | (Optional) symbol errors              |
| <i>eth_out_drops</i>       | (Optional) output drops               |
| <i>eth_bpdu_outlost</i>    | (Optional) BPDU output lost           |
| <i>eth_cos0_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos1_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos2_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos3_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos4_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos5_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos6_outlost</i>    | (Optional) output pkts                |
| <i>eth_cos7_outlost</i>    | (Optional) output pkts                |
| <i>eth_inpause</i>         | (Optional) pause input                |
| <i>eth_outpause</i>        | (Optional) PAUSE output               |
| <i>eth_resets</i>          | (Optional) interface resets           |
| <i>eth_sqetest</i>         | (Optional) SQE test                   |
| <i>eth_l2_ucastpkts</i>    | (Optional) L2 switched ucast pkts     |
| <i>eth_l2_ucastbytes</i>   | (Optional) L2 switched ucast bytes    |
| <i>eth_l2_mcastpkts</i>    | (Optional) L2 switched mcast pkts     |
| <i>eth_l2_mcastbytes</i>   | (Optional) L2 switched mcast bytes    |
| <i>eth_l2_bcastpkts</i>    | (Optional) L2 switched bcast pkts     |
| <i>eth_l2_bcastbytes</i>   | (Optional) L2 switched bcast bytes    |
| <i>eth_l3in_ucastpkts</i>  | (Optional) L3 in switched ucast pkts  |
| <i>eth_l3in_ucastbytes</i> | (Optional) L3 in switched ucast bytes |
| <i>eth_l3in_mcastpkts</i>  | (Optional) L3 in switched mcast pkts  |
| <i>eth_l3in_mcastbytes</i> | (Optional) L3 in switched mcast bytes |

|                               |  |
|-------------------------------|--|
| <i>eth_l3in_bcastpkts</i>     | (Optional) L3 in switched bcast pkts                     |
| <i>eth_l3in_bcastbytes</i>    | (Optional) L3 in switched bcast bytes                    |
| <i>eth_l3out_ucastpkts</i>    | (Optional) L3 out switched ucast pkts                    |
| <i>eth_l3out_ucastbytes</i>   | (Optional) L3 out switched ucast bytes                   |
| <i>eth_l3out_mcastpkts</i>    | (Optional) L3 out switched mcast pkts                    |
| <i>eth_l3out_mcastbytes</i>   | (Optional) L3 out switched mcast bytes                   |
| <i>eth_l3out_bcastpkts</i>    | (Optional) L3 out switched bcast pkts                    |
| <i>eth_l3out_bcastbytes</i>   | (Optional) L3 out switched bcast bytes                   |
| <i>eth_l3in_routed_pkts</i>   | (Optional) L3 in routed pkts                             |
| <i>eth_l3in_routed_bytes</i>  | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>  | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i> | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>     | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>      | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>    | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>     | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_ipmcast</i>            | (Optional) IP multicast                                  |
| <i>eth_inhw_switched</i>      | (Optional) Input H/W Switched                            |
| <i>eth_insw_switched</i>      | (Optional) Input S/W Switched                            |
| <i>eth_throtles</i>           | (Optional) throttles                                     |
| <i>eth_frame</i>              | (Optional) frame   |
| <i>eth_outhw_switched</i>     | (Optional) Out H/W Switched                              |
| <i>eth_outsw_switched</i>     | (Optional) Out S/W Switched                              |
| <i>eth_buffail</i>            | (Optional) output buffer failures                        |
| <i>eth_bufswapped</i>         | (Optional) output buffers swapped out                    |
| <i>eth_arpdrops</i>           | (Optional) arp drops                                     |
| <i>eth_out_ifdown_drops</i>   | (Optional) Output if-down drops                          |
| <i>eth_fcoe_in_pkts</i>       | (Optional) fcoe in pkts                                  |
| <i>eth_fcoe_in_octets</i>     | (Optional) fcoe in octets                                |



|                                   |  |
|-----------------------------------|--|
| <i>eth_fcoe_out_pkts</i>          | (Optional) fcoe out pkts                 |
| <i>eth_fcoe_out_octets</i>        | (Optional) fcoe out octets               |
| <i>eth_nfcoe_in_pkts</i>          | (Optional) nfcoe in pkts                 |
| <i>eth_nfcoe_in_octets</i>        | (Optional) nfcoe in octets               |
| <i>eth_nfcoe_out_pkts</i>         | (Optional) nfcoe out pkts                |
| <i>eth_nfcoe_out_octets</i>       | (Optional) nfcoe out octets              |
| <i>svi_time_last_cleared</i>      | (Optional) Time last cleared             |
| <i>svi_tx_load</i>                | (Optional) Tx Load                       |
| <i>svi_rx_load</i>                | (Optional) Rx Load                       |
| <i>svi_reliability</i>            | (Optional) Reliability                   |
| <i>input_rate_bit_per_sec</i>     | (Optional) Input rate bits per second    |
| <i>input_rate_bytes_per_sec</i>   | (Optional) Input rate bytes per second   |
| <i>input_rate_frames_per_sec</i>  | (Optional) Input rate frames per second  |
| <i>output_rate_bit_per_sec</i>    | (Optional) Output rate bits per second   |
| <i>output_rate_bytes_per_sec</i>  | (Optional) Output rate bytes per second  |
| <i>output_rate_frames_per_sec</i> | (Optional) Output rate frames per second |
| <i>in_frames</i>                  | (Optional) Frames                        |
| <i>in_bytes</i>                   | (Optional) Bytes                         |
| <i>class_2_in_frames</i>          | (Optional) Class 2 frames                |
| <i>class_2_in_bytes</i>           | (Optional) Class 2 bytes                 |
| <i>class_3_in_frames</i>          | (Optional) Class 3 frames                |
| <i>class_3_in_bytes</i>           | (Optional) Class 3 bytes                 |
| <i>class_f_in_frames</i>          | (Optional) Class f frames                |
| <i>class_f_in_bytes</i>           | (Optional) Class f bytes                 |
| <i>class_2_3_in_frames</i>        | (Optional) Class 2/3 Frames              |
| <i>in_discards</i>                | (Optional) Discards                      |
| <i>in_errors</i>                  | (Optional) Errors                        |
| <i>in_crc_fcs</i>                 | (Optional) CRC/FCS                       |
| <i>in_unknown_class</i>           | (Optional) Unknown Class                 |

|                             |                              |
|-----------------------------|------------------------------|
| <i>in_too_long</i>          | (Optional) Frames too long   |
| <i>in_too_short</i>         | (Optional) Frames too short  |
| <i>out_frames</i>           | (Optional) Frames            |
| <i>out_bytes</i>            | (Optional) Bytes             |
| <i>class_2_out_frames</i>   | (Optional) Class 2 frames    |
| <i>class_2_out_bytes</i>    | (Optional) Class 2 bytes     |
| <i>class_3_out_frames</i>   | (Optional) Class 3 frames    |
| <i>class_3_out_bytes</i>    | (Optional) Class 3 bytes     |
| <i>class_f_out_frames</i>   | (Optional) Class f frames    |
| <i>class_f_out_bytes</i>    | (Optional) Class f bytes     |
| <i>class_2_3_out_frames</i> | (Optional) Class 2/3 frames  |
| <i>out_discards</i>         | (Optional) Discards          |
| <i>out_errors</i>           | (Optional) Errors            |
| <i>out_crc_fcs</i>          | (Optional) CRC/FCS           |
| <i>timeout_discards</i>     | (Optional) Timeout Discards  |
| <i>credit_loss</i>          | (Optional) Credit Loss       |
| <i>input_ols</i>            | (Optional) input ols         |
| <i>input_lrr</i>            | (Optional) input LRR         |
| <i>input_nos</i>            | (Optional) input NOS         |
| <i>input_loop_inits</i>     | (Optional) input loop inits  |
| <i>output_ols</i>           | (Optional) output OLS        |
| <i>output_lrr</i>           | (Optional) output LRR        |
| <i>output_nos</i>           | (Optional) output NOS        |
| <i>output_loop_inits</i>    | (Optional) output loop inits |
| <i>link_faliures</i>        | (Optional) link faliures     |
| <i>sync_loss</i>            | (Optional) Sync loss         |
| <i>signal_loss</i>          | (Optional) Signal loss       |
| <i>b2b_transmit</i>         | (Optional) B2B transmit      |
| <i>b2b_receive</i>          | (Optional) B2B receive       |

|                                |  |
|--------------------------------|--|
| <i>txwait</i>                  | (Optional) TxWait                            |
| <i>tx_credit_unavbl</i>        | (Optional) Tx credit unavliable              |
| <i>b2b_receive_remain</i>      | (Optional) B2B receive remain                |
| <i>b2b_transmit_remain</i>     | (Optional) B2B transmit remain               |
| <i>low_priority_b2b_remain</i> | (Optional) Low priority B2B credit remaining |
| <i>off_seq_err_rcvd</i>        | (Optional) Offset Sequence Error Received    |
| <i>broadcast_frames</i>        | (Optional) Broadcast frames                  |
| <i>errors</i>                  | (Optional) Errors                            |
| <i>queue_drops</i>             | (Optional) Queue drops                       |
| <i>if_down_drops</i>           | (Optional) If down drops                     |
| <i>red_drops</i>               | (Optional) Red drops                         |
| <i>bad_ether_type_drops</i>    | (Optional) Bad ether type drops              |
| <i>bad_protocol_drops</i>      | (Optional) Bad Protocol Drops                |
| <i>arp_drops</i>               | (Optional) Arp Drops                         |
| <i>timestamp_error</i>         | (Optional) Timestamp Error                   |
| <i>reass_frames</i>            | (Optional) Reass Frames                      |
| <i>rx_b2b_perf_buff</i>        | (Optional) RX B2B performance buffer         |
| <i>rx_b2b_credit</i>           | (Optional) RX B2B credit remaining           |
| <i>tx_b2b_credit</i>           | (Optional) TX B2B credit remaining           |
| <i>tx_b2b_low_pri_cre</i>      | (Optional) TX B2B low priority Credit        |
| <i>time_last_cleared</i>       | (Optional) Last time cleared                 |

**Command Mode**

- /exec

## show interface counters detailed

```
show interface <ifmgmt_ctr_dtl> counters detailed [ __readonly__ TABLE interface <interface> [
<vdc_lvl_in_pkts> ] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_ucast> ] [ <vdc_lvl_in_mcast> ] [
<vdc_lvl_in_bcast> ] [ <vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [ <vdc_lvl_in_avg_pkts> ] [
<vdc_lvl_in_avg_bytes> ] [ <vdc_lvl_out_pkts> ] [ <vdc_lvl_out_bytes> ] [ <vdc_lvl_out_ucast> ] [
<vdc_lvl_out_mcast> ] [ <vdc_lvl_out_bcast> ] [ <vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] [
<vdc_lvl_out_avg_pkts> ] [ <vdc_lvl_out_avg_bytes> ] [ <mgmt_in_pkts> ] [ <mgmt_in_bytes> ] [
<mgmt_in_mcast> ] [ <mgmt_in_compressed> ] [ <mgmt_in_errors> ] [ <mgmt_in_frame> ] [
<mgmt_in_overrun> ] [ <mgmt_in_fifo> ] [ <mgmt_out_pkts> ] [ <mgmt_out_bytes> ] [
<mgmt_out_underruns> ] [ <mgmt_out_errors> ] [ <mgmt_out_collisions> ] [ <mgmt_out_fifo> ] [
<mgmt_out_carrier> ] [ <mgmt_align_err> ] [ <mgmt_fcs_err> ] [ <mgmt_xmit_err> ] [ <mgmt_rcv_err> ] [
<mgmt_undersize> ] [ <mgmt_outdisc> ] [ <mgmt_single_col> ] [ <mgmt_multi_col> ] [ <mgmt_late_col>
] [ <mgmt_excess_col> ] [ <mgmt_carri_sen> ] [ <mgmt_runs> ] [ <mgmt_giants> ] [ <mgmt_sqetest_err>
] [ <mgmt_deferred_tx> ] [ <mgmt_inmactx_err> ] [ <mgmt_inmacrx_err> ] [ <mgmt_symbol_err> ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                       |
| interface                   | Show interface status and information                 |
| <i>ifmgmt_ctr_dtl</i>       | Enter interface type and number in module/slot format |
| counters                    | Show interface counters                               |
| detailed                    | Show only non-zero counters                           |
| <u>__readonly__</u>         | (Optional) Read Only                                  |
| <i>interface</i>            | (Optional) Interface index                            |
| TABLE_interface             | (Optional) show interface                             |
| <i>vdc_lvl_in_pkts</i>      | (Optional) VDC level input packets                    |
| <i>vdc_lvl_in_bytes</i>     | (Optional) VDC level input bytes                      |
| <i>vdc_lvl_in_ucast</i>     | (Optional) VDC level input unicast packets            |
| <i>vdc_lvl_in_mcast</i>     | (Optional) VDC level input multicast packets          |
| <i>vdc_lvl_in_bcast</i>     | (Optional) VDC level input broadcast packets          |
| <i>vdc_lvl_in_bps</i>       | (Optional) VDC level input bytes per second           |
| <i>vdc_lvl_in_pps</i>       | (Optional) VDC level input packets per second         |
| <i>vdc_lvl_in_avg_pkts</i>  | (Optional) VDC level average input packets            |
| <i>vdc_lvl_in_avg_bytes</i> | (Optional) VDC level average input bytes              |
| <i>vdc_lvl_out_pkts</i>     | (Optional) VDC level output packets                   |

|                              |  |
|------------------------------|--|
| <i>vdc_lvl_out_bytes</i>     | (Optional) VDC level output bytes              |
| <i>vdc_lvl_out_ucast</i>     | (Optional) VDC level output unicast packets    |
| <i>vdc_lvl_out_mcast</i>     | (Optional) VDC level output multicast packets  |
| <i>vdc_lvl_out_bcast</i>     | (Optional) VDC level output broadcast packets  |
| <i>vdc_lvl_out_bps</i>       | (Optional) VDC level output bytes per second   |
| <i>vdc_lvl_out_pps</i>       | (Optional) VDC level output packets per second |
| <i>vdc_lvl_out_avg_pkts</i>  | (Optional) VDC level average output packets    |
| <i>vdc_lvl_out_avg_bytes</i> | (Optional) VDC level average output bytes      |
| <i>mgmt_in_pkts</i>          | (Optional) Input packets                       |
| <i>mgmt_in_bytes</i>         | (Optional) Input bytes                         |
| <i>mgmt_in_mcast</i>         | (Optional) Input multicast frames              |
| <i>mgmt_in_compressed</i>    | (Optional) Input compressed                    |
| <i>mgmt_in_errors</i>        | (Optional) Input errors                        |
| <i>mgmt_in_frame</i>         | (Optional) Input frame errors                  |
| <i>mgmt_in_overrun</i>       | (Optional) Input overrun                       |
| <i>mgmt_in_fifo</i>          | (Optional) Input fifo                          |
| <i>mgmt_out_pkts</i>         | (Optional) Output packets                      |
| <i>mgmt_out_bytes</i>        | (Optional) Output bytes                        |
| <i>mgmt_out_underruns</i>    | (Optional) Output overruns                     |
| <i>mgmt_out_errors</i>       | (Optional) Output errors                       |
| <i>mgmt_out_collisions</i>   | (Optional) Output collisions                   |
| <i>mgmt_out_fifo</i>         | (Optional) Output fifo                         |
| <i>mgmt_out_carrier</i>      | (Optional) Output carrier errors               |
| <i>mgmt_align_err</i>        | (Optional) Align error                         |
| <i>mgmt_fcs_err</i>          | (Optional) FCS error                           |
| <i>mgmt_xmit_err</i>         | (Optional) Transmit error                      |
| <i>mgmt_rcv_err</i>          | (Optional) Receive error                       |
| <i>mgmt_undersize</i>        | (Optional) Undersize                           |
| <i>mgmt_outdisc</i>          | (Optional) Out discard                         |

|                         |                               |
|-------------------------|-------------------------------|
| <i>mgmt_single_col</i>  | (Optional) Single collision   |
| <i>mgmt_multi_col</i>   | (Optional) Multiple collision |
| <i>mgmt_late_col</i>    | (Optional) Late collision     |
| <i>mgmt_excess_col</i>  | (Optional) Excess collision   |
| <i>mgmt_carri_sen</i>   | (Optional) Carrier sense      |
| <i>mgmt_runts</i>       | (Optional) Runts              |
| <i>mgmt_giants</i>      | (Optional) Giants             |
| <i>mgmt_sqetest_err</i> | (Optional) SQETest error      |
| <i>mgmt_deferred_tx</i> | (Optional) Deferred tx        |
| <i>mgmt_inmactx_err</i> | (Optional) In MAC tx          |
| <i>mgmt_inmacrx_err</i> | (Optional) In MAC rx          |
| <i>mgmt_symbol_err</i>  | (Optional) Symbol error       |

**Command Mode**

- /exec

## show interface counters detailed

```
show interface <ifloop_ctr_dtl> counters detailed [ __readonly__ TABLE_interface <interface> [
<loop_in_pkts> ] [ <loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors> ]
[ <loop_in_frame> ] [ <loop_in_overrun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [
<loop_out_underruns> ] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [
<loop_out_carriers> ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                       |
| interface                  | Show interface status and information                 |
| <i>ifloop_ctr_dtl</i>      | Enter interface type and number in module/slot format |
| counters                   | Show interface counters                               |
| detailed                   | Show only non-zero counters                           |
| <u>__readonly__</u>        | (Optional) Read Only                                  |
| <i>interface</i>           | (Optional) Interface index                            |
| TABLE_interface            | (Optional) show interface                             |
| <i>loop_in_pkts</i>        | (Optional) Input packets                              |
| <i>loop_in_bytes</i>       | (Optional) Input bytes                                |
| <i>loop_in_mcast</i>       | (Optional) Input multicast                            |
| <i>loop_in_compressed</i>  | (Optional) Input compressed                           |
| <i>loop_in_errors</i>      | (Optional) Input errors                               |
| <i>loop_in_frame</i>       | (Optional) Input frame errors                         |
| <i>loop_in_overrun</i>     | (Optional) Input overrun                              |
| <i>loop_in_fifo</i>        | (Optional) Input fifo                                 |
| <i>loop_out_pkts</i>       | (Optional) Output packets                             |
| <i>loop_out_bytes</i>      | (Optional) Output bytes                               |
| <i>loop_out_underruns</i>  | (Optional) Output underruns                           |
| <i>loop_out_errors</i>     | (Optional) Output errors                              |
| <i>loop_out_collisions</i> | (Optional) Output collisions                          |
| <i>loop_out_fifo</i>       | (Optional) Output fifo                                |
| <i>loop_out_carriers</i>   | (Optional) Output carrier errors                      |

**Command Mode**

- /exec



## show interface counters detailed all

```
show interface <ifloop_ctr_dtl_all> counters detailed all [ __readonly__ TABLE_interface <interface> [
<rx_total_pkts> ] [ <tx_total_pkts> ] [ <rx_mcast_pkts> ] [ <rx_octets> ] [ <tx_octets> ] [ <loop_in_pkts> ]
[ <loop_in_bytes> ] [ <loop_in_mcast> ] [ <loop_in_compressed> ] [ <loop_in_errors> ] [ <loop_in_frame>
] [ <loop_in_overrun> ] [ <loop_in_fifo> ] [ <loop_out_pkts> ] [ <loop_out_bytes> ] [ <loop_out_underruns>
] [ <loop_out_errors> ] [ <loop_out_collisions> ] [ <loop_out_fifo> ] [ <loop_out_carriers> ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                       |
| interface                 | Show interface status and information                 |
| <i>ifloop_ctr_dtl_all</i> | Enter interface type and number in module/slot format |
| counters                  | Show interface counters                               |
| detailed                  | Show only non-zero counters                           |
| all                       | Show every interface counter                          |
| <u>__readonly__</u>       | (Optional) Read Only                                  |
| <i>interface</i>          | (Optional) Interface index                            |
| TABLE_interface           | (Optional) show interface                             |
| <i>rx_total_pkts</i>      | (Optional) total input packets                        |
| <i>tx_total_pkts</i>      | (Optional) total output packets                       |
| <i>rx_mcast_pkts</i>      | (Optional) input multicasts                           |
| <i>rx_octets</i>          | (Optional) input bytes                                |
| <i>tx_octets</i>          | (Optional) output bytes                               |
| <i>loop_in_pkts</i>       | (Optional) Input packets                              |
| <i>loop_in_bytes</i>      | (Optional) Input bytes                                |
| <i>loop_in_mcast</i>      | (Optional) Input multicast                            |
| <i>loop_in_compressed</i> | (Optional) Input compressed                           |
| <i>loop_in_errors</i>     | (Optional) Input errors                               |
| <i>loop_in_frame</i>      | (Optional) Input frame errors                         |
| <i>loop_in_overrun</i>    | (Optional) Input overrun                              |
| <i>loop_in_fifo</i>       | (Optional) Input fifo                                 |
| <i>loop_out_pkts</i>      | (Optional) Output packets                             |

|                            |                                  |
|----------------------------|----------------------------------|
| <i>loop_out_bytes</i>      | (Optional) Output bytes          |
| <i>loop_out_underruns</i>  | (Optional) Output underruns      |
| <i>loop_out_errors</i>     | (Optional) Output errors         |
| <i>loop_out_collisions</i> | (Optional) Output collisions     |
| <i>loop_out_fifo</i>       | (Optional) Output fifo           |
| <i>loop_out_carriers</i>   | (Optional) Output carrier errors |

**Command Mode**

- /exec

# show interface counters detailed all

```
show interface <ifid_ctr_dtl_all> counters detailed all [ snmp ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                       |
| interface               | Show interface status and information                 |
| <i>ifid_ctr_dtl_all</i> | Enter interface type and number in module/slot format |
| counters                | Show interface counters                               |
| detailed                | Show only non-zero counters                           |
| all                     | Show every interface counter                          |
| snmp                    | (Optional) Show SNMP MIB values                       |

## Command Mode

- /exec

## show interface counters detailed all

```
show interface <ifmgmt_ctr_dtl_all> counters detailed all [ __readonly__ TABLE_interface <interface> [
<vdc_lvl_in_pkts> ] [ <vdc_lvl_in_bytes> ] [ <vdc_lvl_in_ucast> ] [ <vdc_lvl_in_mcast> ] [
<vdc_lvl_in_bcast> ] [ <vdc_lvl_in_bps> ] [ <vdc_lvl_in_pps> ] [ <vdc_lvl_in_avg_pkts> ] [
<vdc_lvl_in_avg_bytes> ] [ <vdc_lvl_out_pkts> ] [ <vdc_lvl_out_bytes> ] [ <vdc_lvl_out_ucast> ] [
<vdc_lvl_out_mcast> ] [ <vdc_lvl_out_bcast> ] [ <vdc_lvl_out_bps> ] [ <vdc_lvl_out_pps> ] [
<vdc_lvl_out_avg_pkts> ] [ <vdc_lvl_out_avg_bytes> ] [ <mgmt_in_pkts> ] [ <mgmt_in_bytes> ] [
<mgmt_in_mcast> ] [ <mgmt_out_pkts> ] [ <mgmt_out_bytes> ] [ <mgmt_in_errors> ] [ <mgmt_out_errors> ]
] [ <mgmt_in_fifo> ] [ <mgmt_out_fifo> ] [ <mgmt_in_compressed> ] [ <mgmt_in_frame> ] [
<mgmt_in_overrun> ] [ <mgmt_out_underruns> ] [ <mgmt_out_collisions> ] [ <mgmt_out_carrier> ] [
<mgmt_align_err> ] [ <mgmt_fcs_err> ] [ <mgmt_xmit_err> ] [ <mgmt_rcv_err> ] [ <mgmt_undersize> ] [
<mgmt_outdisc> ] [ <mgmt_single_col> ] [ <mgmt_multi_col> ] [ <mgmt_late_col> ] [ <mgmt_excess_col> ]
] [ <mgmt_carri_sen> ] [ <mgmt_runts> ] [ <mgmt_giants> ] [ <mgmt_sqetest_err> ] [ <mgmt_deferred_tx> ]
] [ <mgmt_inmactx_err> ] [ <mgmt_inmacrx_err> ] [ <mgmt_symbol_err> ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                       |
| interface                   | Show interface status and information                 |
| <i>ifmgmt_ctr_dtl_all</i>   | Enter interface type and number in module/slot format |
| counters                    | Show interface counters                               |
| detailed                    | Show only non-zero counters                           |
| all                         | Show every interface counter                          |
| <i>__readonly__</i>         | (Optional) Read Only                                  |
| <i>interface</i>            | (Optional) Interface index                            |
| TABLE_interface             | (Optional) show interface                             |
| <i>vdc_lvl_in_pkts</i>      | (Optional) VDC level input packets                    |
| <i>vdc_lvl_in_bytes</i>     | (Optional) VDC level input bytes                      |
| <i>vdc_lvl_in_ucast</i>     | (Optional) VDC level input unicast packets            |
| <i>vdc_lvl_in_mcast</i>     | (Optional) VDC level input multicast packets          |
| <i>vdc_lvl_in_bcast</i>     | (Optional) VDC level input broadcast packets          |
| <i>vdc_lvl_in_bps</i>       | (Optional) VDC level input bytes per second           |
| <i>vdc_lvl_in_pps</i>       | (Optional) VDC level input packets per second         |
| <i>vdc_lvl_in_avg_pkts</i>  | (Optional) VDC level average input packets            |
| <i>vdc_lvl_in_avg_bytes</i> | (Optional) VDC level average input bytes              |

|                              |  |
|------------------------------|--|
| <i>vdc_lvl_out_pkts</i>      | (Optional) VDC level output packets            |
| <i>vdc_lvl_out_bytes</i>     | (Optional) VDC level output bytes              |
| <i>vdc_lvl_out_ucast</i>     | (Optional) VDC level output unicast packets    |
| <i>vdc_lvl_out_mcast</i>     | (Optional) VDC level output multicast packets  |
| <i>vdc_lvl_out_bcast</i>     | (Optional) VDC level output broadcast packets  |
| <i>vdc_lvl_out_bps</i>       | (Optional) VDC level output bytes per second   |
| <i>vdc_lvl_out_pps</i>       | (Optional) VDC level output packets per second |
| <i>vdc_lvl_out_avg_pkts</i>  | (Optional) VDC level average output packets    |
| <i>vdc_lvl_out_avg_bytes</i> | (Optional) VDC level average output bytes      |
| <i>mgmt_in_pkts</i>          | (Optional) Input packets                       |
| <i>mgmt_in_bytes</i>         | (Optional) Input bytes                         |
| <i>mgmt_in_mcast</i>         | (Optional) Input multicast frames              |
| <i>mgmt_out_pkts</i>         | (Optional) Output packets                      |
| <i>mgmt_out_bytes</i>        | (Optional) Output bytes                        |
| <i>mgmt_in_errors</i>        | (Optional) Input errors                        |
| <i>mgmt_out_errors</i>       | (Optional) Output errors                       |
| <i>mgmt_in_fifo</i>          | (Optional) Input fifo                          |
| <i>mgmt_out_fifo</i>         | (Optional) Output fifo                         |
| <i>mgmt_in_compressed</i>    | (Optional) Input compressed                    |
| <i>mgmt_in_frame</i>         | (Optional) Input frame errors                  |
| <i>mgmt_in_overrun</i>       | (Optional) Input overrun                       |
| <i>mgmt_out_underruns</i>    | (Optional) Output overruns                     |
| <i>mgmt_out_collisions</i>   | (Optional) Output collisions                   |
| <i>mgmt_out_carrier</i>      | (Optional) Output carrier errors               |
| <i>mgmt_align_err</i>        | (Optional) Align error                         |
| <i>mgmt_fcs_err</i>          | (Optional) FCS error                           |
| <i>mgmt_xmit_err</i>         | (Optional) Transmit error                      |
| <i>mgmt_rcv_err</i>          | (Optional) Receive error                       |
| <i>mgmt_undersize</i>        | (Optional) Undersize                           |

|                         |                               |
|-------------------------|-------------------------------|
| <i>mgmt_outdisc</i>     | (Optional) Out discard        |
| <i>mgmt_single_col</i>  | (Optional) Single collision   |
| <i>mgmt_multi_col</i>   | (Optional) Multiple collision |
| <i>mgmt_late_col</i>    | (Optional) Late collision     |
| <i>mgmt_excess_col</i>  | (Optional) Excess collision   |
| <i>mgmt_carri_sen</i>   | (Optional) Carrier sense      |
| <i>mgmt_runts</i>       | (Optional) Runts              |
| <i>mgmt_giants</i>      | (Optional) Giants             |
| <i>mgmt_sqetest_err</i> | (Optional) SQETest error      |
| <i>mgmt_deferred_tx</i> | (Optional) Deferred tx        |
| <i>mgmt_inmactx_err</i> | (Optional) In MAC tx          |
| <i>mgmt_inmacrx_err</i> | (Optional) In MAC rx          |
| <i>mgmt_symbol_err</i>  | (Optional) Symbol error       |

**Command Mode**

- /exec

## show interface counters detailed all

```
show interface <ifrange> counters detailed all [ snmp ] [ __readonly__ TABLE_interface <interface> [
<svi_routed_pkts_in> ] [ <svi_routed_bytes_in> ] [ <svi_routed_pkts_out> ] [ <svi_routed_bytes_out> ] [
<svi_ucast_pkts_in> ] [ <svi_ucast_bytes_in> ] [ <svi_mcast_pkts_in> ] [ <svi_mcast_bytes_in> ] [
<svi_ucast_pkts_out> ] [ <svi_ucast_bytes_out> ] [ <svi_mcast_pkts_out> ] [ <svi_mcast_bytes_out> ] [
<svi_ipv4_ucast_pkts_in> ] [ <svi_ipv4_ucast_bytes_in> ] [ <svi_ipv4_ucast_pkts_out> ] [
<svi_ipv4_ucast_bytes_out> ] [ <svi_ipv4_mcast_pkts_in> ] [ <svi_ipv4_mcast_bytes_in> ] [
<svi_ipv4_mcast_pkts_out> ] [ <svi_ipv4_mcast_bytes_out> ] [ <svi_ipv6_ucast_pkts_in> ] [
<svi_ipv6_ucast_bytes_in> ] [ <svi_ipv6_ucast_pkts_out> ] [ <svi_ipv6_ucast_bytes_out> ] [
<svi_ipv6_mcast_pkts_in> ] [ <svi_ipv6_mcast_bytes_in> ] [ <svi_ipv6_mcast_pkts_out> ] [
<svi_ipv6_mcast_bytes_out> ] [ <svi_average_input_bits> ] [ <svi_average_input_packets> ] [
<svi_average_output_bits> ] [ <svi_average_output_packets> ] [ <svi_rate_in_mins> ] [
<svi_time_last_cleared> ] [ <svi_tx_load> ] [ <svi_rx_load> ] [ <svi_reliability> ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                       |
| interface                    | Show interface status and information                 |
| <i>ifrange</i>               | Enter interface type and number in module/slot format |
| counters                     | Show interface counters                               |
| detailed                     | Show only non-zero counters                           |
| all                          | everything  |
| snmp                         | (Optional) Show SNMP MIB values                       |
| __readonly__                 | (Optional) Read Only                                  |
| <i>interface</i>             | (Optional) Interface index                            |
| TABLE_interface              | (Optional) show interface                             |
| <i>svi_time_last_cleared</i> | (Optional) Time last cleared                          |
| <i>svi_tx_load</i>           | (Optional) Tx Load                                    |
| <i>svi_rx_load</i>           | (Optional) Rx Load                                    |
| <i>svi_reliability</i>       | (Optional) Reliability                                |

### Command Mode

- /exec

## show interface counters detailed all

```

show interface <ifeth_ctr_dtl_all> counters detailed all [ snmp ] [ __readonly__ TABLE interface <interface>
[ <rx_total_pkts> ] [ <tx_total_pkts> ] [ <rx_ucast_pkts> ] [ <rx_mcast_pkts> ] [ <rx_bcast_pkts> ] [
<rx_octets> ] [ <tx_ucast_pkts> ] [ <tx_mcast_pkts> ] [ <tx_bcast_pkts> ] [ <tx_octets> ] [
<rxtx_pkts_64octets> ] [ <rxtx_pkts_65_127octets> ] [ <rxtx_pkts_128_255octets> ] [
<rxtx_pkts_256_511octets> ] [ <rxtx_pkts_512_1023octets> ] [ <rxtx_pkts_1024_1518octets> ] [
<rxtx_pkts_1519_1548octets> ] [ <rx_trunk_frames> ] [ <tx_trunk_frames> ] [ <rx_drop_events> ] [
<rxtx_giants> ] [ <eth_load_interval1_rx> ] [ <eth_inrate1_bits> ] [ <eth_inrate1_pkts> ] [
<eth_load_interval1_tx> ] [ <eth_outrate1_bits> ] [ <eth_outrate1_pkts> ] [ <eth_inrate1_summary_bits> ]
[ <eth_inrate1_summary_pkts> ] [ <eth_outrate1_summary_bits> ] [ <eth_outrate1_summary_pkts> ] [
<eth_load_interval2_rx> ] [ <eth_inrate2_bits> ] [ <eth_inrate2_pkts> ] [ <eth_load_interval2_tx> ] [
<eth_outrate2_bits> ] [ <eth_outrate2_pkts> ] [ <eth_inrate2_summary_bits> ] [ <eth_inrate2_summary_pkts>
] [ <eth_outrate2_summary_bits> ] [ <eth_outrate2_summary_pkts> ] [ <eth_load_interval3_rx> ] [
<eth_inrate3_bits> ] [ <eth_inrate3_pkts> ] [ <eth_load_interval3_tx> ] [ <eth_outrate3_bits> ] [
<eth_outrate3_pkts> ] [ <eth_inrate3_summary_bits> ] [ <eth_inrate3_summary_pkts> ] [
<eth_outrate3_summary_bits> ] [ <eth_outrate3_summary_pkts> ] [ <eth_l2_ucastpkts> ] [ <eth_l2_ucastbytes>
] [ <eth_l2_mcastpkts> ] [ <eth_l2_mcastbytes> ] [ <eth_l2_bcastpkts> ] [ <eth_l2_bcastbytes> ] [
<eth_l3in_ucastpkts> ] [ <eth_l3in_ucastbytes> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_mcastbytes> ] [
<eth_l3in_bcastpkts> ] [ <eth_l3in_bcastbytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_ucastbytes> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_mcastbytes> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_bcastbytes> ] [
<eth_l3in_routed_pkts> ] [ <eth_l3in_routed_bytes> ] [ <eth_l3out_routed_pkts> ] [ <eth_l3out_routed_bytes>
] [ <eth_l3avg1_inbytes> ] [ <eth_l3avg1_inpkts> ] [ <eth_l3avg1_outbytes> ] [ <eth_l3avg1_outpkts> ] [
<eth_l3avg2_inbytes> ] [ <eth_l3avg2_inpkts> ] [ <eth_l3avg2_outbytes> ] [ <eth_l3avg2_outpkts> ] [
<eth_l3avg3_inbytes> ] [ <eth_l3avg3_inpkts> ] [ <eth_l3avg3_outbytes> ] [ <eth_l3avg3_outpkts> ] [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_nobuf> ] [ <eth_inbcast> ] [ <eth_inmcast> ] [ <eth_inucast> ] [
<eth_ingiants> ] [ <eth_ipmcast> ] [ <eth_inhw_switched> ] [ <eth_insw_switched> ] [ <eth_runts> ] [
<eth_storm_supp> ] [ <eth_throtles> ] [ <eth_inerr> ] [ <eth_crc> ] [ <eth_ecc> ] [ <eth_frame> ] [
<eth_outrun> ] [ <eth_ignored> ] [ <eth_watchdog> ] [ <eth_outbcast> ] [ <eth_outmcast> ] [ <eth_outucast>
] [ <eth_outgiants> ] [ <eth_inpause> ] [ <eth_dribble> ] [ <eth_in_ifdown_drops> ] [ <eth_bad_eth> ] [
<eth_bad_proto> ] [ <eth_outpkts> ] [ <eth_outbytes> ] [ <eth_underrun> ] [ <eth_outhw_switched> ] [
<eth_outsw_switched> ] [ <eth_outerr> ] [ <eth_coll> ] [ <eth_resets> ] [ <eth_babbles> ] [ <eth_latecoll> ]
[ <eth_deferred> ] [ <eth_lostcarrier> ] [ <eth_nocarrier> ] [ <eth_outpause> ] [ <eth_buffail> ] [
<eth_bufswapped> ] [ <eth_arpdrops> ] [ <eth_out_ifdown_drops> ] [ <eth_single_coll> ] [ <eth_multi_coll>
] [ <eth_excess_coll> ] [ <eth_jabbers> ] [ <eth_shortframe> ] [ <eth_indiscard> ] [ <eth_bad_encap> ] [
<eth_outcrc> ] [ <eth_symbol> ] [ <eth_out_drops> ] [ <eth_sqetest> ] [ <eth_inb64> ] [ <eth_inb65_127>
] [ <eth_inb128_255> ] [ <eth_inb256_511> ] [ <eth_inb512_1023> ] [ <eth_inb1024_1518> ] [
<eth_inb1519_1548> ] [ <eth_intrunk> ] [ <eth_outb64> ] [ <eth_outb65_127> ] [ <eth_outb128_255> ] [
<eth_outb256_511> ] [ <eth_outb512_1023> ] [ <eth_outb1024_1518> ] [ <eth_outb1519_1548> ] [
<eth_outtrunk> ] [ <eth_bpdu_outlost> ] [ <eth_cos0_outlost> ] [ <eth_cos1_outlost> ] [ <eth_cos2_outlost>
] [ <eth_cos3_outlost> ] [ <eth_cos4_outlost> ] [ <eth_cos5_outlost> ] [ <eth_cos6_outlost> ] [
<eth_cos7_outlost> ] [ <eth_fcoe_in_pkts> ] [ <eth_fcoe_in_octets> ] [ <eth_fcoe_out_pkts> ] [
<eth_fcoe_out_octets> ] [ <eth_nfcoe_in_pkts> ] [ <eth_nfcoe_in_octets> ] [ <eth_nfcoe_out_pkts> ] [
<eth_nfcoe_out_octets> ] [ <eth_eee_atx_lpi_msec> ] [ <eth_eee_arcv_lpi_msec> ] [
<eth_eee_atx_lpi_transitions> ] [ <eth_eee_arcv_lpi_transitions> ] [ <eth_phy_ber_count> ] [
<eth_phy_errblks_count> ] [ <eth_tx_frm_error> ] [ <eth_rx_toolong> ] [ <eth_rx_undersize> ] [
<eth_rx_fragment> ] [ <eth_rx_crcerr_not_stomped> ] [ <eth_rx_crcerr_stomped> ] [ <eth_rx_inrangeerr>
] ]

```

### Syntax Description



|                                  |   |
|----------------------------------|---|
| show                             | Show running system information                       |
| interface                        | Show interface status and information                 |
| <i>ifeth_ctr_dtl_all</i>         | Enter interface type and number in module/slot format |
| counters                         | Show interface counters                               |
| detailed                         | Show only non-zero counters                           |
| all                              | everything  |
| snmp                             | (Optional) Show SNMP MIB values                       |
| <u>__readonly__</u>              | (Optional) Read Only                                  |
| <i>interface</i>                 | (Optional) Interface index                            |
| TABLE_interface                  | (Optional) show interface                             |
| <i>rx_total_pkts</i>             | (Optional) total input packets                        |
| <i>tx_total_pkts</i>             | (Optional) total output packets                       |
| <i>rx_ucast_pkts</i>             | (Optional) input unicasts                             |
| <i>rx_mcast_pkts</i>             | (Optional) input multicasts                           |
| <i>rx_bcast_pkts</i>             | (Optional) input broadcasts                           |
| <i>rx_octets</i>                 | (Optional) input bytes                                |
| <i>tx_ucast_pkts</i>             | (Optional) output unicasts                            |
| <i>tx_mcast_pkts</i>             | (Optional) output multicasts                          |
| <i>tx_bcast_pkts</i>             | (Optional) output broadcasts                          |
| <i>tx_octets</i>                 | (Optional) output bytes                               |
| <i>rxtx_pkts_64octets</i>        | (Optional) all pkts between 0 and 64 bytes            |
| <i>rxtx_pkts_65_127octets</i>    | (Optional) all pkts between 65 and 127 bytes          |
| <i>rxtx_pkts_128_255octets</i>   | (Optional) all pkts between 128 and 255 bytes         |
| <i>rxtx_pkts_256_511octets</i>   | (Optional) all pkts between 256 and 511 bytes         |
| <i>rxtx_pkts_512_1023octets</i>  | (Optional) all pkts between 512 and 1023 bytes        |
| <i>rxtx_pkts_1024_1518octets</i> | (Optional) all pkts between 1024 and 1518 bytes       |
| <i>rxtx_pkts_1519_1548octets</i> | (Optional) all pkts between 1519 and 1548 bytes       |
| <i>rx_trunk_frames</i>           | (Optional) input trunk pkts                           |
| <i>tx_trunk_frames</i>           | (Optional) output trunk pkts                          |

## show interface counters detailed all

|                                  |   |
|----------------------------------|---|
| <i>rx_drop_events</i>            | (Optional) dropped pkts                       |
| <i>rxtx_giants</i>               | (Optional) giants                             |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec      |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec     |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec     |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec      |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec    |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec    |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary  |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary  |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary |
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec     |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec     |
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec    |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec    |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary  |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary  |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary |
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec    |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary  |

|                                  |  |
|----------------------------------|--|
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary             |
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary            |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary            |
| <i>eth_l2_ucastpkts</i>          | (Optional) L2 switched ucast pkts                        |
| <i>eth_l2_ucastbytes</i>         | (Optional) L2 switched ucast bytes                       |
| <i>eth_l2_mcastpkts</i>          | (Optional) L2 switched mcast pkts                        |
| <i>eth_l2_mcastbytes</i>         | (Optional) L2 switched mcast bytes                       |
| <i>eth_l2_bcastpkts</i>          | (Optional) L2 switched bcast pkts                        |
| <i>eth_l2_bcastbytes</i>         | (Optional) L2 switched bcast bytes                       |
| <i>eth_l3in_ucastpkts</i>        | (Optional) IPv4 L3 in switched ucast pkts                |
| <i>eth_l3in_ucastbytes</i>       | (Optional) IPv4 L3 in switched ucast bytes               |
| <i>eth_l3in_mcastpkts</i>        | (Optional) IPv4 L3 in switched mcast pkts                |
| <i>eth_l3in_mcastbytes</i>       | (Optional) IPv4 L3 in switched mcast bytes               |
| <i>eth_l3in_bcastpkts</i>        | (Optional) L3 in switched bcast pkts                     |
| <i>eth_l3in_bcastbytes</i>       | (Optional) L3 in switched bcast bytes                    |
| <i>eth_l3out_ucastpkts</i>       | (Optional) IPv4 L3 out switched ucast pkts               |
| <i>eth_l3out_ucastbytes</i>      | (Optional) IPv4 L3 out switched ucast bytes              |
| <i>eth_l3out_mcastpkts</i>       | (Optional) IPv4 L3 out switched mcast pkts               |
| <i>eth_l3out_mcastbytes</i>      | (Optional) IPv4 L3 out switched mcast bytes              |
| <i>eth_l3out_bcastpkts</i>       | (Optional) L3 out switched bcast pkts                    |
| <i>eth_l3out_bcastbytes</i>      | (Optional) L3 out switched bcast bytes                   |
| <i>eth_l3in_routed_pkts</i>      | (Optional) L3 in routed pkts                             |
| <i>eth_l3in_routed_bytes</i>     | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>     | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i>    | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>        | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>         | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>       | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>        | (Optional) Load interval 1 L3 average out switched pkts  |

|                            |  |
|----------------------------|--|
| <i>eth_l3avg2_inbytes</i>  | (Optional) Load interval 2 L3 average in switched bytes  |
| <i>eth_l3avg2_inpkts</i>   | (Optional) Load interval 2 L3 average in switched pkts   |
| <i>eth_l3avg2_outbytes</i> | (Optional) Load interval 2 L3 average out switched bytes |
| <i>eth_l3avg2_outpkts</i>  | (Optional) Load interval 2 L3 average out switched pkts  |
| <i>eth_l3avg3_inbytes</i>  | (Optional) Load interval 3 L3 average in switched bytes  |
| <i>eth_l3avg3_inpkts</i>   | (Optional) Load interval 3 L3 average in switched pkts   |
| <i>eth_l3avg3_outbytes</i> | (Optional) Load interval 3 L3 average out switched bytes |
| <i>eth_l3avg3_outpkts</i>  | (Optional) Load interval 3 L3 average out switched pkts  |
| <i>eth_inpkts</i>          | (Optional) Packets input                                 |
| <i>eth_inbytes</i>         | (Optional) Bytes input                                   |
| <i>eth_nobuf</i>           | (Optional) No buffer received                            |
| <i>eth_inbcast</i>         | (Optional) Broadcasts                                    |
| <i>eth_inmcast</i>         | (Optional) Multicasts                                    |
| <i>eth_inucast</i>         | (Optional) Unicasts                                      |
| <i>eth_ingiants</i>        | (Optional) giants  |
| <i>eth_ipmcast</i>         | (Optional) IP multicast                                  |
| <i>eth_inhw_switched</i>   | (Optional) Input H/W Switched                            |
| <i>eth_insw_switched</i>   | (Optional) Input S/W Switched                            |
| <i>eth_runts</i>           | (Optional) runts   |
| <i>eth_storm_supp</i>      | (Optional) storm suppression                             |
| <i>eth_throtles</i>        | (Optional) throttles                                     |
| <i>eth_inerr</i>           | (Optional) input errors                                  |
| <i>eth_crc</i>             | (Optional) CRC   |
| <i>eth_ecc</i>             | (Optional) ECC   |
| <i>eth_frame</i>           | (Optional) frame   |
| <i>eth_overrun</i>         | (Optional) overrun                                       |
| <i>eth_ignored</i>         | (Optional) ignored                                       |
| <i>eth_watchdog</i>        | (Optional) watchdog                                      |
| <i>eth_outbcast</i>        | (Optional) Broadcasts                                    |

|                             |   |
|-----------------------------|---|
| <i>eth_outmcast</i>         | (Optional) Multicasts                           |
| <i>eth_outucast</i>         | (Optional) Unicasts                             |
| <i>eth_outgiants</i>        | (Optional) giants                               |
| <i>eth_inpause</i>          | (Optional) pause input                          |
| <i>eth_dribble</i>          | (Optional) input packets with dribble condition |
| <i>eth_in_ifdown_drops</i>  | (Optional) Input if-down drops                  |
| <i>eth_bad_eth</i>          | (Optional) bad ether type drop                  |
| <i>eth_bad_proto</i>        | (Optional) bad protocol drops                   |
| <i>eth_outpkts</i>          | (Optional) packets output                       |
| <i>eth_outbytes</i>         | (Optional) bytes output                         |
| <i>eth_underrun</i>         | (Optional) underruns                            |
| <i>eth_outhw_switched</i>   | (Optional) Out H/W Switched                     |
| <i>eth_outsw_switched</i>   | (Optional) Out S/W Switched                     |
| <i>eth_outerr</i>           | (Optional) output errors                        |
| <i>eth_coll</i>             | (Optional) collisions                           |
| <i>eth_resets</i>           | (Optional) interface resets                     |
| <i>eth_babbles</i>          | (Optional) babbles                              |
| <i>eth_latecoll</i>         | (Optional) late collision                       |
| <i>eth_deferred</i>         | (Optional) deferred                             |
| <i>eth_lostcarrier</i>      | (Optional) lost carrier                         |
| <i>eth_nocarrier</i>        | (Optional) no carrier                           |
| <i>eth_outpause</i>         | (Optional) PAUSE output                         |
| <i>eth_buffail</i>          | (Optional) output buffer failures               |
| <i>eth_bufswapped</i>       | (Optional) output buffers swapped out           |
| <i>eth_arpdrops</i>         | (Optional) arp drops                            |
| <i>eth_out_ifdown_drops</i> | (Optional) Output if-down drops                 |
| <i>eth_single_coll</i>      | (Optional) single collisions                    |
| <i>eth_multi_coll</i>       | (Optional) multi collisions                     |
| <i>eth_excess_coll</i>      | (Optional) excessive collisions                 |

|                          |  |
|--------------------------|--|
| <i>eth_jabbers</i>       | (Optional) jabbers                                 |
| <i>eth_shortframe</i>    | (Optional) short frames                            |
| <i>eth_indiscard</i>     | (Optional) discards                                |
| <i>eth_bad_encap</i>     | (Optional) bad encapsulation                       |
| <i>eth_outcrc</i>        | (Optional) Output CRC                              |
| <i>eth_symbol</i>        | (Optional) symbol errors                           |
| <i>eth_out_drops</i>     | (Optional) output drops                            |
| <i>eth_sqetest</i>       | (Optional) SQE test                                |
| <i>eth_inb64</i>         | (Optional) input pkts between 0 and 64 bytes       |
| <i>eth_inb65_127</i>     | (Optional) input pkts between 65 and 127 bytes     |
| <i>eth_inb128_255</i>    | (Optional) input pkts between 128 and 255 bytes    |
| <i>eth_inb256_511</i>    | (Optional) input pkts between 256 and 511 bytes    |
| <i>eth_inb512_1023</i>   | (Optional) input pkts between 512 and 1023 bytes   |
| <i>eth_inb1024_1518</i>  | (Optional) input pkts between 1024 and 1518 bytes  |
| <i>eth_inb1519_1548</i>  | (Optional) input pkts between 1519 and 1548 bytes  |
| <i>eth_intrunk</i>       | (Optional) input trunk pkts                        |
| <i>eth_outb64</i>        | (Optional) output pkts between 0 and 64 bytes      |
| <i>eth_outb65_127</i>    | (Optional) output pkts between 65 and 127 bytes    |
| <i>eth_outb128_255</i>   | (Optional) output pkts between 128 and 255 bytes   |
| <i>eth_outb256_511</i>   | (Optional) output pkts between 256 and 511 bytes   |
| <i>eth_outb512_1023</i>  | (Optional) output pkts between 512 and 1023 bytes  |
| <i>eth_outb1024_1518</i> | (Optional) output pkts between 1024 and 1518 bytes |
| <i>eth_outb1519_1548</i> | (Optional) output pkts between 1519 and 1548 bytes |
| <i>eth_outtrunk</i>      | (Optional) output trunk pkts                       |
| <i>eth_bpdu_outlost</i>  | (Optional) BPDU output lost                        |
| <i>eth_cos0_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos1_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos2_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos3_outlost</i>  | (Optional) output pkts                             |

|                                     |                                   |
|-------------------------------------|-----------------------------------|
| <i>eth_cos4_outlost</i>             | (Optional) output pkts            |
| <i>eth_cos5_outlost</i>             | (Optional) output pkts            |
| <i>eth_cos6_outlost</i>             | (Optional) output pkts            |
| <i>eth_cos7_outlost</i>             | (Optional) output pkts            |
| <i>eth_fcoe_in_pkts</i>             | (Optional) fcoe in pkts           |
| <i>eth_fcoe_in_octets</i>           | (Optional) fcoe in octets         |
| <i>eth_fcoe_out_pkts</i>            | (Optional) fcoe out pkts          |
| <i>eth_fcoe_out_octets</i>          | (Optional) fcoe out octets        |
| <i>eth_nfcoe_in_pkts</i>            | (Optional) nfcoe in pkts          |
| <i>eth_nfcoe_in_octets</i>          | (Optional) nfcoe in octets        |
| <i>eth_nfcoe_out_pkts</i>           | (Optional) nfcoe out pkts         |
| <i>eth_nfcoe_out_octets</i>         | (Optional) nfcoe out octets       |
| <i>eth_eee_atx_lpi_msec</i>         | (Optional) Tx Lpi usec            |
| <i>eth_eee_arcv_lpi_msec</i>        | (Optional) Rx Lpi usec            |
| <i>eth_eee_atx_lpi_transitions</i>  | (Optional) Tx Lpi requests        |
| <i>eth_eee_arcv_lpi_transitions</i> | (Optional) Rx Lpi indications     |
| <i>eth_phy_ber_count</i>            | (Optional) Bit error rate counter |
| <i>eth_phy_errblks_count</i>        | (Optional) Errored blocks counter |
| <i>eth_tx_frm_error</i>             | (Optional) tx frame error         |
| <i>eth_rx_toolong</i>               | (Optional) rx toolong error       |
| <i>eth_rx_undersize</i>             | (Optional) rx undersize           |
| <i>eth_rx_fragment</i>              | (Optional) rx fragment            |
| <i>eth_rx_crcerr_not_stomped</i>    | (Optional) rx crcerr not stomped  |
| <i>eth_rx_crcerr_stomped</i>        | (Optional) rx crcerr stomped      |
| <i>eth_rx_inrangeerr</i>            | (Optional) rx inrange error       |

### Command Mode

- /exec

## show interface counters detailed cached

```

show interface <ifeth_ctr_dtl_all> counters detailed cached [ __readonly__ TABLE_interface <interface> [
<rx_total_pkts> ][ <tx_total_pkts> ][ <rx_ucast_pkts> ][ <rx_mcast_pkts> ][ <rx_bcast_pkts> ][ <rx_octets> ]
][ <tx_ucast_pkts> ][ <tx_mcast_pkts> ][ <tx_bcast_pkts> ][ <tx_octets> ][ <rxtx_pkts_64octets> ][
<rxtx_pkts_65_127octets> ][ <rxtx_pkts_128_255octets> ][ <rxtx_pkts_256_511octets> ][
<rxtx_pkts_512_1023octets> ][ <rxtx_pkts_1024_1518octets> ][ <rxtx_pkts_1519_1548octets> ][
<rx_trunk_frames> ][ <tx_trunk_frames> ][ <rx_drop_events> ][ <rxtx_giants> ][ <eth_load_interval1_rx>
][ <eth_inrate1_bits> ][ <eth_inrate1_pkts> ][ <eth_load_interval1_tx> ][ <eth_outrate1_bits> ][
<eth_outrate1_pkts> ][ <eth_inrate1_summary_bits> ][ <eth_inrate1_summary_pkts> ][
<eth_outrate1_summary_bits> ][ <eth_outrate1_summary_pkts> ][ <eth_load_interval2_rx> ][
<eth_inrate2_bits> ][ <eth_inrate2_pkts> ][ <eth_load_interval2_tx> ][ <eth_outrate2_bits> ][
<eth_outrate2_pkts> ][ <eth_inrate2_summary_bits> ][ <eth_inrate2_summary_pkts> ][
<eth_outrate2_summary_bits> ][ <eth_outrate2_summary_pkts> ][ <eth_load_interval3_rx> ][
<eth_inrate3_bits> ][ <eth_inrate3_pkts> ][ <eth_load_interval3_tx> ][ <eth_outrate3_bits> ][
<eth_outrate3_pkts> ][ <eth_inrate3_summary_bits> ][ <eth_inrate3_summary_pkts> ][
<eth_outrate3_summary_bits> ][ <eth_outrate3_summary_pkts> ][ <eth_l2_ucastpkts> ][ <eth_l2_ucastbytes> ]
][ <eth_l2_mcastpkts> ][ <eth_l2_mcastbytes> ][ <eth_l2_bcastpkts> ][ <eth_l2_bcastbytes> ][
<eth_l3in_ucastpkts> ][ <eth_l3in_ucastbytes> ][ <eth_l3in_mcastpkts> ][ <eth_l3in_mcastbytes> ][
<eth_l3in_bcastpkts> ][ <eth_l3in_bcastbytes> ][ <eth_l3out_ucastpkts> ][ <eth_l3out_ucastbytes> ][
<eth_l3out_mcastpkts> ][ <eth_l3out_mcastbytes> ][ <eth_l3out_bcastpkts> ][ <eth_l3out_bcastbytes> ][
<eth_l3in_routed_pkts> ][ <eth_l3in_routed_bytes> ][ <eth_l3out_routed_pkts> ][ <eth_l3out_routed_bytes> ]
][ <eth_l3avg1_inbytes> ][ <eth_l3avg1_inpkts> ][ <eth_l3avg1_outbytes> ][ <eth_l3avg1_outpkts> ][
<eth_l3avg2_inbytes> ][ <eth_l3avg2_inpkts> ][ <eth_l3avg2_outbytes> ][ <eth_l3avg2_outpkts> ][
<eth_l3avg3_inbytes> ][ <eth_l3avg3_inpkts> ][ <eth_l3avg3_outbytes> ][ <eth_l3avg3_outpkts> ][
<eth_inpkts> ][ <eth_inbytes> ][ <eth_nobuf> ][ <eth_inbcast> ][ <eth_inmcast> ][ <eth_inucast> ][
<eth_ingiants> ][ <eth_ipmcast> ][ <eth_inhw_switched> ][ <eth_insw_switched> ][ <eth_runts> ][
<eth_storm_supp> ][ <eth_throtles> ][ <eth_inerr> ][ <eth_crc> ][ <eth_ecc> ][ <eth_frame> ][
<eth_outrun> ][ <eth_ignored> ][ <eth_watchdog> ][ <eth_outbcast> ][ <eth_outmcast> ][ <eth_outucast> ]
][ <eth_outgiants> ][ <eth_inpause> ][ <eth_dribble> ][ <eth_in_ifdown_drops> ][ <eth_bad_eth> ][
<eth_bad_proto> ][ <eth_outpkts> ][ <eth_outbytes> ][ <eth_underrun> ][ <eth_outhw_switched> ][
<eth_outsw_switched> ][ <eth_outerr> ][ <eth_coll> ][ <eth_resets> ][ <eth_babbles> ][ <eth_latecoll> ]
][ <eth_deferred> ][ <eth_lostcarrier> ][ <eth_nocarrier> ][ <eth_outpause> ][ <eth_buffail> ][
<eth_bufswapped> ][ <eth_arpdrops> ][ <eth_out_ifdown_drops> ][ <eth_single_coll> ][ <eth_multi_coll> ]
][ <eth_excess_coll> ][ <eth_jabbers> ][ <eth_shortframe> ][ <eth_indiscard> ][ <eth_bad_encap> ][
<eth_outcrc> ][ <eth_symbol> ][ <eth_out_drops> ][ <eth_sqetest> ][ <eth_inb64> ][ <eth_inb65_127> ]
][ <eth_inb128_255> ][ <eth_inb256_511> ][ <eth_inb512_1023> ][ <eth_inb1024_1518> ][
<eth_inb1519_1548> ][ <eth_intrunk> ][ <eth_outb64> ][ <eth_outb65_127> ][ <eth_outb128_255> ][
<eth_outb256_511> ][ <eth_outb512_1023> ][ <eth_outb1024_1518> ][ <eth_outb1519_1548> ][
<eth_outtrunk> ][ <eth_bpdu_outlost> ][ <eth_cos0_outlost> ][ <eth_cos1_outlost> ][ <eth_cos2_outlost> ]
][ <eth_cos3_outlost> ][ <eth_cos4_outlost> ][ <eth_cos5_outlost> ][ <eth_cos6_outlost> ][
<eth_cos7_outlost> ][ <eth_fcoe_in_pkts> ][ <eth_fcoe_in_octets> ][ <eth_fcoe_out_pkts> ][
<eth_fcoe_out_octets> ][ <eth_nfcoe_in_pkts> ][ <eth_nfcoe_in_octets> ][ <eth_nfcoe_out_pkts> ][
<eth_nfcoe_out_octets> ][ <eth_eee_atx_lpi_msec> ][ <eth_eee_arcv_lpi_msec> ][
<eth_eee_atx_lpi_transitions> ][ <eth_eee_arcv_lpi_transitions> ][ <eth_phy_ber_count> ][
<eth_phy_errblks_count> ][ <eth_tx_frm_error> ][ <eth_rx_toolong> ][ <eth_rx_undersize> ][
<eth_rx_fragment> ][ <eth_rx_crcerr_not_stomped> ][ <eth_rx_crcerr_stomped> ][ <eth_rx_inrangeerr>
]]

```

### Syntax Description



|                                  |   |
|----------------------------------|---|
| show                             | Show running system information                       |
| interface                        | Show interface status and information                 |
| <i>ifeth_ctr_dtl_all</i>         | Enter interface type and number in module/slot format |
| counters                         | Show interface counters                               |
| detailed                         | Show only non-zero counters                           |
| cached                           | everything cached                                     |
| <i>__readonly__</i>              | (Optional) Read Only                                  |
| <i>interface</i>                 | (Optional) Interface index                            |
| TABLE_interface                  | (Optional) show interface                             |
| <i>rx_total_pkts</i>             | (Optional) total input packets                        |
| <i>tx_total_pkts</i>             | (Optional) total output packets                       |
| <i>rx_ucast_pkts</i>             | (Optional) input unicasts                             |
| <i>rx_mcast_pkts</i>             | (Optional) input multicasts                           |
| <i>rx_bcast_pkts</i>             | (Optional) input broadcasts                           |
| <i>rx_octets</i>                 | (Optional) input bytes                                |
| <i>tx_ucast_pkts</i>             | (Optional) output unicasts                            |
| <i>tx_mcast_pkts</i>             | (Optional) output multicasts                          |
| <i>tx_bcast_pkts</i>             | (Optional) output broadcasts                          |
| <i>tx_octets</i>                 | (Optional) output bytes                               |
| <i>rctx_pkts_64octets</i>        | (Optional) all pkts between 0 and 64 bytes            |
| <i>rctx_pkts_65_127octets</i>    | (Optional) all pkts between 65 and 127 bytes          |
| <i>rctx_pkts_128_255octets</i>   | (Optional) all pkts between 128 and 255 bytes         |
| <i>rctx_pkts_256_511octets</i>   | (Optional) all pkts between 256 and 511 bytes         |
| <i>rctx_pkts_512_1023octets</i>  | (Optional) all pkts between 512 and 1023 bytes        |
| <i>rctx_pkts_1024_1518octets</i> | (Optional) all pkts between 1024 and 1518 bytes       |
| <i>rctx_pkts_1519_1548octets</i> | (Optional) all pkts between 1519 and 1548 bytes       |
| <i>rx_trunk_frames</i>           | (Optional) input trunk pkts                           |
| <i>tx_trunk_frames</i>           | (Optional) output trunk pkts                          |
| <i>rx_drop_events</i>            | (Optional) dropped pkts                               |

|                                  |   |
|----------------------------------|---|
| <i>rxtx_giants</i>               | (Optional) giants                             |
| <i>eth_load_interval1_rx</i>     | (Optional) interval 1 timer value in sec      |
| <i>eth_inrate1_bits</i>          | (Optional) interval 1 input rate bits/sec     |
| <i>eth_inrate1_pkts</i>          | (Optional) interval 1 input rate pkts/sec     |
| <i>eth_load_interval1_tx</i>     | (Optional) interval 1 timer value in sec      |
| <i>eth_outrate1_bits</i>         | (Optional) interval 1 output rate bits/sec    |
| <i>eth_outrate1_pkts</i>         | (Optional) interval 1 output rate pkts/sec    |
| <i>eth_inrate1_summary_bits</i>  | (Optional) interval 1 input rate bit summary  |
| <i>eth_inrate1_summary_pkts</i>  | (Optional) interval 1 input rate pkt summary  |
| <i>eth_outrate1_summary_bits</i> | (Optional) interval 1 output rate bit summary |
| <i>eth_outrate1_summary_pkts</i> | (Optional) interval 1 output rate pkt summary |
| <i>eth_load_interval2_rx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_inrate2_bits</i>          | (Optional) interval 2 input rate bits/sec     |
| <i>eth_inrate2_pkts</i>          | (Optional) interval 2 input rate pkts/sec     |
| <i>eth_load_interval2_tx</i>     | (Optional) interval 2 timer value in sec      |
| <i>eth_outrate2_bits</i>         | (Optional) interval 2 output rate bits/sec    |
| <i>eth_outrate2_pkts</i>         | (Optional) interval 2 output rate pkts/sec    |
| <i>eth_inrate2_summary_bits</i>  | (Optional) interval 2 input rate bit summary  |
| <i>eth_inrate2_summary_pkts</i>  | (Optional) interval 2 input rate pkt summary  |
| <i>eth_outrate2_summary_bits</i> | (Optional) interval 2 output rate bit summary |
| <i>eth_outrate2_summary_pkts</i> | (Optional) interval 2 output rate pkt summary |
| <i>eth_load_interval3_rx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_inrate3_bits</i>          | (Optional) interval 3 input rate bits/sec     |
| <i>eth_inrate3_pkts</i>          | (Optional) interval 3 input rate pkts/sec     |
| <i>eth_load_interval3_tx</i>     | (Optional) interval 3 timer value in sec      |
| <i>eth_outrate3_bits</i>         | (Optional) interval 3 output rate bits/sec    |
| <i>eth_outrate3_pkts</i>         | (Optional) interval 3 output rate pkts/sec    |
| <i>eth_inrate3_summary_bits</i>  | (Optional) interval 3 input rate bit summary  |
| <i>eth_inrate3_summary_pkts</i>  | (Optional) interval 3 input rate pkt summary  |

|                                  |  |
|----------------------------------|--|
| <i>eth_outrate3_summary_bits</i> | (Optional) interval 3 output rate bit summary            |
| <i>eth_outrate3_summary_pkts</i> | (Optional) interval 3 output rate pkt summary            |
| <i>eth_l2_ucastpkts</i>          | (Optional) L2 switched ucast pkts                        |
| <i>eth_l2_ucastbytes</i>         | (Optional) L2 switched ucast bytes                       |
| <i>eth_l2_mcastpkts</i>          | (Optional) L2 switched mcast pkts                        |
| <i>eth_l2_mcastbytes</i>         | (Optional) L2 switched mcast bytes                       |
| <i>eth_l2_bcastpkts</i>          | (Optional) L2 switched bcast pkts                        |
| <i>eth_l2_bcastbytes</i>         | (Optional) L2 switched bcast bytes                       |
| <i>eth_l3in_ucastpkts</i>        | (Optional) IPv4 L3 in switched ucast pkts                |
| <i>eth_l3in_ucastbytes</i>       | (Optional) IPv4 L3 in switched ucast bytes               |
| <i>eth_l3in_mcastpkts</i>        | (Optional) IPv4 L3 in switched mcast pkts                |
| <i>eth_l3in_mcastbytes</i>       | (Optional) IPv4 L3 in switched mcast bytes               |
| <i>eth_l3in_bcastpkts</i>        | (Optional) L3 in switched bcast pkts                     |
| <i>eth_l3in_bcastbytes</i>       | (Optional) L3 in switched bcast bytes                    |
| <i>eth_l3out_ucastpkts</i>       | (Optional) IPv4 L3 out switched ucast pkts               |
| <i>eth_l3out_ucastbytes</i>      | (Optional) IPv4 L3 out switched ucast bytes              |
| <i>eth_l3out_mcastpkts</i>       | (Optional) IPv4 L3 out switched mcast pkts               |
| <i>eth_l3out_mcastbytes</i>      | (Optional) IPv4 L3 out switched mcast bytes              |
| <i>eth_l3out_bcastpkts</i>       | (Optional) L3 out switched bcast pkts                    |
| <i>eth_l3out_bcastbytes</i>      | (Optional) L3 out switched bcast bytes                   |
| <i>eth_l3in_routed_pkts</i>      | (Optional) L3 in routed pkts                             |
| <i>eth_l3in_routed_bytes</i>     | (Optional) L3 in routed bytes                            |
| <i>eth_l3out_routed_pkts</i>     | (Optional) L3 out routed pkts                            |
| <i>eth_l3out_routed_bytes</i>    | (Optional) L3 out routed bytes                           |
| <i>eth_l3avg1_inbytes</i>        | (Optional) Load interval 1 L3 average in switched bytes  |
| <i>eth_l3avg1_inpkts</i>         | (Optional) Load interval 1 L3 average in switched pkts   |
| <i>eth_l3avg1_outbytes</i>       | (Optional) Load interval 1 L3 average out switched bytes |
| <i>eth_l3avg1_outpkts</i>        | (Optional) Load interval 1 L3 average out switched pkts  |
| <i>eth_l3avg2_inbytes</i>        | (Optional) Load interval 2 L3 average in switched bytes  |

## show interface counters detailed cached

|                            |  |
|----------------------------|--|
| <i>eth_l3avg2_inpkts</i>   | (Optional) Load interval 2 L3 average in switched pkts   |
| <i>eth_l3avg2_outbytes</i> | (Optional) Load interval 2 L3 average out switched bytes |
| <i>eth_l3avg2_outpkts</i>  | (Optional) Load interval 2 L3 average out switched pkts  |
| <i>eth_l3avg3_inbytes</i>  | (Optional) Load interval 3 L3 average in switched bytes  |
| <i>eth_l3avg3_inpkts</i>   | (Optional) Load interval 3 L3 average in switched pkts   |
| <i>eth_l3avg3_outbytes</i> | (Optional) Load interval 3 L3 average out switched bytes |
| <i>eth_l3avg3_outpkts</i>  | (Optional) Load interval 3 L3 average out switched pkts  |
| <i>eth_inpkts</i>          | (Optional) Packets input                                 |
| <i>eth_inbytes</i>         | (Optional) Bytes input                                   |
| <i>eth_nobuf</i>           | (Optional) No buffer received                            |
| <i>eth_inbcast</i>         | (Optional) Broadcasts                                    |
| <i>eth_inmcast</i>         | (Optional) Multicasts                                    |
| <i>eth_inucast</i>         | (Optional) Unicasts                                      |
| <i>eth_ingiants</i>        | (Optional) giants  |
| <i>eth_ipmcast</i>         | (Optional) IP multicast                                  |
| <i>eth_inhw_switched</i>   | (Optional) Input H/W Switched                            |
| <i>eth_insw_switched</i>   | (Optional) Input S/W Switched                            |
| <i>eth_runts</i>           | (Optional) runts   |
| <i>eth_storm_supp</i>      | (Optional) storm suppression                             |
| <i>eth_throtles</i>        | (Optional) throttles                                     |
| <i>eth_inerr</i>           | (Optional) input errors                                  |
| <i>eth_crc</i>             | (Optional) CRC   |
| <i>eth_ecc</i>             | (Optional) ECC   |
| <i>eth_frame</i>           | (Optional) frame   |
| <i>eth_overrun</i>         | (Optional) overrun                                       |
| <i>eth_ignored</i>         | (Optional) ignored                                       |
| <i>eth_watchdog</i>        | (Optional) watchdog                                      |
| <i>eth_outbcast</i>        | (Optional) Broadcasts                                    |
| <i>eth_outmcast</i>        | (Optional) Multicasts                                    |

|                             |   |
|-----------------------------|---|
| <i>eth_outucast</i>         | (Optional) Unicasts                             |
| <i>eth_outgiants</i>        | (Optional) giants                               |
| <i>eth_inpause</i>          | (Optional) pause input                          |
| <i>eth_dribble</i>          | (Optional) input packets with dribble condition |
| <i>eth_in_ifdown_drops</i>  | (Optional) Input if-down drops                  |
| <i>eth_bad_eth</i>          | (Optional) bad ether type drop                  |
| <i>eth_bad_proto</i>        | (Optional) bad protocol drops                   |
| <i>eth_outpkts</i>          | (Optional) packets output                       |
| <i>eth_outbytes</i>         | (Optional) bytes output                         |
| <i>eth_underrun</i>         | (Optional) underruns                            |
| <i>eth_outhw_switched</i>   | (Optional) Out H/W Switched                     |
| <i>eth_outsw_switched</i>   | (Optional) Out S/W Switched                     |
| <i>eth_outerr</i>           | (Optional) output errors                        |
| <i>eth_coll</i>             | (Optional) collisions                           |
| <i>eth_resets</i>           | (Optional) interface resets                     |
| <i>eth_babbles</i>          | (Optional) babbles                              |
| <i>eth_latecoll</i>         | (Optional) late collision                       |
| <i>eth_deferred</i>         | (Optional) deferred                             |
| <i>eth_lostcarrier</i>      | (Optional) lost carrier                         |
| <i>eth_nocarrier</i>        | (Optional) no carrier                           |
| <i>eth_outpause</i>         | (Optional) PAUSE output                         |
| <i>eth_buffail</i>          | (Optional) output buffer failures               |
| <i>eth_bufswapped</i>       | (Optional) output buffers swapped out           |
| <i>eth_arpdrops</i>         | (Optional) arp drops                            |
| <i>eth_out_ifdown_drops</i> | (Optional) Output if-down drops                 |
| <i>eth_single_coll</i>      | (Optional) single collisions                    |
| <i>eth_multi_coll</i>       | (Optional) multi collisions                     |
| <i>eth_excess_coll</i>      | (Optional) excessive collisions                 |
| <i>eth_jabbers</i>          | (Optional) jabbers                              |

|                          |  |
|--------------------------|--|
| <i>eth_shortframe</i>    | (Optional) short frames                            |
| <i>eth_indiscard</i>     | (Optional) discards                                |
| <i>eth_bad_encap</i>     | (Optional) bad encapsulation                       |
| <i>eth_outcrc</i>        | (Optional) Output CRC                              |
| <i>eth_symbol</i>        | (Optional) symbol errors                           |
| <i>eth_out_drops</i>     | (Optional) output drops                            |
| <i>eth_sqetest</i>       | (Optional) SQE test                                |
| <i>eth_inb64</i>         | (Optional) input pkts between 0 and 64 bytes       |
| <i>eth_inb65_127</i>     | (Optional) input pkts between 65 and 127 bytes     |
| <i>eth_inb128_255</i>    | (Optional) input pkts between 128 and 255 bytes    |
| <i>eth_inb256_511</i>    | (Optional) input pkts between 256 and 511 bytes    |
| <i>eth_inb512_1023</i>   | (Optional) input pkts between 512 and 1023 bytes   |
| <i>eth_inb1024_1518</i>  | (Optional) input pkts between 1024 and 1518 bytes  |
| <i>eth_inb1519_1548</i>  | (Optional) input pkts between 1519 and 1548 bytes  |
| <i>eth_intrunk</i>       | (Optional) input trunk pkts                        |
| <i>eth_outb64</i>        | (Optional) output pkts between 0 and 64 bytes      |
| <i>eth_outb65_127</i>    | (Optional) output pkts between 65 and 127 bytes    |
| <i>eth_outb128_255</i>   | (Optional) output pkts between 128 and 255 bytes   |
| <i>eth_outb256_511</i>   | (Optional) output pkts between 256 and 511 bytes   |
| <i>eth_outb512_1023</i>  | (Optional) output pkts between 512 and 1023 bytes  |
| <i>eth_outb1024_1518</i> | (Optional) output pkts between 1024 and 1518 bytes |
| <i>eth_outb1519_1548</i> | (Optional) output pkts between 1519 and 1548 bytes |
| <i>eth_outtrunk</i>      | (Optional) output trunk pkts                       |
| <i>eth_bpdu_outlost</i>  | (Optional) BPDU output lost                        |
| <i>eth_cos0_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos1_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos2_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos3_outlost</i>  | (Optional) output pkts                             |
| <i>eth_cos4_outlost</i>  | (Optional) output pkts                             |

|                                     |                                   |
|-------------------------------------|-----------------------------------|
| <i>eth_cos5_outlost</i>             | (Optional) output pkts            |
| <i>eth_cos6_outlost</i>             | (Optional) output pkts            |
| <i>eth_cos7_outlost</i>             | (Optional) output pkts            |
| <i>eth_fcoe_in_pkts</i>             | (Optional) fcoe in pkts           |
| <i>eth_fcoe_in_octets</i>           | (Optional) fcoe in octets         |
| <i>eth_fcoe_out_pkts</i>            | (Optional) fcoe out pkts          |
| <i>eth_fcoe_out_octets</i>          | (Optional) fcoe out octets        |
| <i>eth_nfcoe_in_pkts</i>            | (Optional) nfcoe in pkts          |
| <i>eth_nfcoe_in_octets</i>          | (Optional) nfcoe in octets        |
| <i>eth_nfcoe_out_pkts</i>           | (Optional) nfcoe out pkts         |
| <i>eth_nfcoe_out_octets</i>         | (Optional) nfcoe out octets       |
| <i>eth_eee_atx_lpi_msec</i>         | (Optional) Tx Lpi usec            |
| <i>eth_eee_arcv_lpi_msec</i>        | (Optional) Rx Lpi usec            |
| <i>eth_eee_atx_lpi_transitions</i>  | (Optional) Tx Lpi requests        |
| <i>eth_eee_arcv_lpi_transitions</i> | (Optional) Rx Lpi indications     |
| <i>eth_phy_ber_count</i>            | (Optional) Bit error rate counter |
| <i>eth_phy_errblks_count</i>        | (Optional) Errored blocks counter |
| <i>eth_tx_frm_error</i>             | (Optional) tx frame error         |
| <i>eth_rx_toolong</i>               | (Optional) rx toolong error       |
| <i>eth_rx_undersize</i>             | (Optional) rx undersize           |
| <i>eth_rx_fragment</i>              | (Optional) rx fragment            |
| <i>eth_rx_crcerr_not_stomped</i>    | (Optional) rx crcerr not stomped  |
| <i>eth_rx_crcerr_stomped</i>        | (Optional) rx crcerr stomped      |
| <i>eth_rx_inrangeerr</i>            | (Optional) rx inrange error       |

**Command Mode**

- /exec

## show interface counters details

```
show interface <ifid_ctrs_det2> counters details [ __readonly__ TABLE_ifid_counters [ <sfp> <in_frames>
<in_bytes> <class_2_frames> <class_2_in_bytes> <class_2_in_discards> <class_2_in_f_bsy_frames>
<class_2_in_f_rgt_frames> <class_2_in_port_reject_frames> <class_3_frames> <class_3_bytes_rcvd>
<class_f_frames> <class_f_bytes_rcvd> <class_f_in_discards> <class_f_errors_rcvd> <class_f_out_discards>
<class_f_errors_trans> <out_frames> <out_bytes> <class_2_out_frames> <class_2_bytes_trans>
<class_3_out_frames> <class_3_bytes_trans> <class_3_out_discards> <class_f_out_frames>
<class_f_bytes_trans> <class_f_discards> <muticast_rcvd> <multicast_trans> <broadcast_rcvd>
<broadcast_trans> <unicast_rcvd> <unicast_trans> <timeout_discards> <credit_loss> <link_faliures>
<sync_loss> <signal_loss> <prm_seq_pro_err> <inv_trans_err> <inv_crc> <delim_err> <addr_iden_err>
<link_reset_rcvd> <link_reset_trans> <off_seq_err_rcvd> <off_seq_err_trans> <frames_rcvd_short>
<frames_rcvd_long> [ <txwait> ] <frames_rcvd_greater> <frame_rcvd_short_header> <link_reset_resp_rcvd>
<link_reset_resp_trans> <non_oper_seq_rcvd> <non_oper_seq_trans> <frag_frames_rcvd> <frames_eof_abort>
<unknown_class_frames_rcvd> <8b10b_disparity_err> <frames_discard> <ex_link_param_sw_fab> [
<in_link_ser_req_faliures> ] <b2b_credits_transmit> [ <b2b_credits_receive> ] <eisl_frames> <framing_err>
<f8_lip_seq_err_rcvd> <f8_lip_seq_err_issued> <non_f8_lip_seq_err_rcvd> <non_f8_lip_seq_err_issued>
[ <fec_corrected> ] [ <fec_uncorrected> ] ] ]
```

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information                       |
| interface                            | Show interface status and information                 |
| <i>ifid_ctrs_det2</i>                | Enter interface type and number in module/slot format |
| counters                             | Show interface counters                               |
| details                              | Show interface counters in detail                     |
| <u>__readonly__</u>                  | (Optional)  |
| TABLE_ifid_counters                  | (Optional) show interface counters                    |
| <i>sfp</i>                           | (Optional) SFP  |
| <i>in_frames</i>                     | (Optional) in frames                                  |
| <i>in_bytes</i>                      | (Optional) in bytes                                   |
| <i>class_2_frames</i>                | (Optional) Class 2 frames                             |
| <i>class_2_in_bytes</i>              | (Optional) Class 2 bytes received                     |
| <i>class_2_in_discards</i>           | (Optional) Class 2 discards received                  |
| <i>class_2_in_f_bsy_frames</i>       | (Optional) Class 2 F_BSY frames received              |
| <i>class_2_in_f_rgt_frames</i>       | (Optional) Class 2 F_RGT frames                       |
| <i>class_2_in_port_reject_frames</i> | (Optional) Class 2 port reject frames                 |
| <i>class_3_frames</i>                | (Optional) Class 3 frames                             |



|                             |   |
|-----------------------------|---|
| <i>class_3_bytes_rcv</i>    | (Optional) Class 3 bytes received             |
| <i>class_f_frames</i>       | (Optional) Class f frames                     |
| <i>class_f_bytes_rcv</i>    | (Optional) Class F bytes received             |
| <i>class_f_in_discards</i>  | (Optional) Class F in discards                |
| <i>class_f_errors_rcvd</i>  | (Optional) Class F errors received            |
| <i>class_f_out_discards</i> | (Optional) Class F out discards               |
| <i>class_f_errors_trans</i> | (Optional) Class F errors transmitted         |
| <i>out_frames</i>           | (Optional) Out frames                         |
| <i>out_bytes</i>            | (Optional) Out bytes                          |
| <i>class_2_out_frames</i>   | (Optional) Class 2 frames transmitted         |
| <i>class_2_bytes_trans</i>  | (Optional) Class 2 bytes transmitted          |
| <i>class_3_out_frames</i>   | (Optional) Class 3 frames transmitted         |
| <i>class_3_bytes_trans</i>  | (Optional) Class 3 bytes transmitted          |
| <i>class_3_out_discards</i> | (Optional) Class 3 out discards               |
| <i>class_f_out_frames</i>   | (Optional) Class F out frames                 |
| <i>class_f_bytes_trans</i>  | (Optional) Class F bytes transmitted          |
| <i>class_f_discards</i>     | (Optional) Class F discards                   |
| <i>multicast_rcvd</i>       | (Optional) Multicast received                 |
| <i>multicast_trans</i>      | (Optional) Muticast transmitted               |
| <i>broadcast_rcvd</i>       | (Optional) Broadcast received                 |
| <i>broadcast_trans</i>      | (Optional) Broadcast transmitted              |
| <i>unicast_rcvd</i>         | (Optional) Unicast received                   |
| <i>unicast_trans</i>        | (Optional) Unicast transmitted                |
| <i>timeout_discards</i>     | (Optional) timeout discards                   |
| <i>credit_loss</i>          | (Optional) credit loss                        |
| <i>link_faliures</i>        | (Optional) Link faliures                      |
| <i>sync_loss</i>            | (Optional) Sync Loss                          |
| <i>signal_loss</i>          | (Optional) Signal Loss                        |
| <i>prm_seq_pro_err</i>      | (Optional) primitive sequence protocol errors |

|                                  |   |
|----------------------------------|---|
| <i>inv_trans_err</i>             | (Optional) invalid transmission errors  |
| <i>inv_crc</i>                   | (Optional) Invalid crc  |
| <i>delim_err</i>                 | (Optional) Delimiter Errors   |
| <i>addr_iden_err</i>             | (Optional) Address Identification errors  |
| <i>link_reset_rcvd</i>           | (Optional) link reset received  |
| <i>link_reset_trans</i>          | (Optional) link reset transmitted   |
| <i>off_seq_err_rcvd</i>          | (Optional) Offline sequence error received  |
| <i>off_seq_err_trans</i>         | (Optional) Offline sequence Error transmitted   |
| <i>frames_rcvd_short</i>         | (Optional) frames received that are shorter than the minimum allowable frame length regardless of the CRC/FCS error |
| <i>frames_rcvd_long</i>          | (Optional) frames received that are longer than the minimum allowable frame length regardless of the CRC/FCS error  |
| <i>txwait</i>                    | (Optional) TXwait   |
| <i>frames_rcvd_greater</i>       | (Optional) frames received with length greater than what was agreed to in FLOGI/PLOGI                               |
| <i>frame_rcvd_short_header</i>   | (Optional) frames received with length less than the minimum indicated by the frame header                          |
| <i>link_reset_resp_rcvd</i>      | (Optional) Link reset responses received  |
| <i>link_reset_resp_trans</i>     | (Optional) Link reset responses transmitted   |
| <i>non_oper_seq_rcvd</i>         | (Optional) Non operational sequence received  |
| <i>non_oper_seq_trans</i>        | (Optional) Non operational sequence transmitted   |
| <i>frag_frames_rcvd</i>          | (Optional) fragmented frames received   |
| <i>frames_eof_abort</i>          | (Optional) frames EOF abort   |
| <i>unknown_class_frames_rcvd</i> | (Optional) unknown class frames received  |
| <i>8b10b_disparity_err</i>       | (Optional) 8b10b disparity errors   |
| <i>frames_discard</i>            | (Optional) frames discard   |
| <i>ex_link_param_sw_fab</i>      | (Optional) external link parameters switch fabric   |
| <i>in_link_ser_req_faliures</i>  | (Optional) internal link serial request faliures  |
| <i>b2b_credits_transmit</i>      | (Optional) B2B credits transmit   |
| <i>b2b_credits_receive</i>       | (Optional) B2B credits receive  |

|                                  |   |
|----------------------------------|---|
| <i>eisl_frames</i>               | (Optional) EISL frames                        |
| <i>framing_err</i>               | (Optional) Framing Error                      |
| <i>f8_lip_seq_err_rcvd</i>       | (Optional) f8 LIP sequence error received     |
| <i>f8_lip_seq_err_issued</i>     | (Optional) f8 LIP sequence error issued       |
| <i>non_f8_lip_seq_err_rcvd</i>   | (Optional) non f8 LIP sequence error received |
| <i>non_f8_lip_seq_err_issued</i> | (Optional) non f8 LIP sequence error issued   |
| <i>fec_corrected</i>             | (Optional) fec corrected blocks               |
| <i>fec_uncorrected</i>           | (Optional) fec uncorrected blocks             |

**Command Mode**

- /exec

## show interface counters details

```
show interface <ifid_ctr_det> counters details [ __readonly__ TABLE_interface <interface> [ <fcoe_in_pkts>
] [ <fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifid_ctr_det</i>    | Enter interface type and number in module/slot format |
| counters               | Show interface counters                               |
| details                | Show interface counters in detail                     |
| <u>__readonly__</u>    | (Optional) Read Only                                  |
| <i>interface</i>       | (Optional) Interface index                            |
| TABLE_interface        | (Optional) show interface                             |
| <i>fcoe_in_pkts</i>    | (Optional) fcoe in pkts                               |
| <i>fcoe_in_octets</i>  | (Optional) fcoe in octets                             |
| <i>fcoe_out_pkts</i>   | (Optional) fcoe out pkts                              |
| <i>fcoe_out_octets</i> | (Optional) fcoe out octets                            |

### Command Mode

- /exec

# show interface counters errors

show interface <loop\_ctr\_errs> counters errors

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                       |
| interface            | Show interface status and information                 |
| <i>loop_ctr_errs</i> | Enter interface type and number in module/slot format |
| counters             | Show interface counters                               |
| errors               | Show interface error counters                         |

## Command Mode

- /exec

## show interface counters errors

```
show interface <ifeth_ctr_errs> counters errors [ snmp ] [ __readonly__ TABLE_interface <interface> [
<eth_align_err> ] [ <eth_fcs_err> ] [ <eth_xmit_err> ] [ <eth_rcv_err> ] [ <eth_undersize> ] [ <eth_outdisc>
] [ <eth_single_col> ] [ <eth_multi_col> ] [ <eth_late_col> ] [ <eth_excess_col> ] [ <eth_carri_sen> ] [
<eth_runts> ] [ <eth_giants> ] [ <eth_sqetest_err> ] [ <eth_deferred_tx> ] [ <eth_inmactx_err> ] [
<eth_inmacrx_err> ] [ <eth_symbol_err> ] [ <eth_indisc> ] [ <eth_stomped_crc> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifeth_ctr_errs</i>  | Enter interface type and number in module/slot format |
| counters               | Show interface counters                               |
| errors                 | Show interface error counters                         |
| snmp                   | (Optional) Show SNMP MIB values                       |
| <i>__readonly__</i>    | (Optional) Read Only                                  |
| <i>interface</i>       | (Optional) Interface index                            |
| TABLE_interface        | (Optional) show interface                             |
| <i>eth_align_err</i>   | (Optional) Align error                                |
| <i>eth_fcs_err</i>     | (Optional) FCS error                                  |
| <i>eth_xmit_err</i>    | (Optional) Transmit error                             |
| <i>eth_rcv_err</i>     | (Optional) Receive error                              |
| <i>eth_undersize</i>   | (Optional) Undersize                                  |
| <i>eth_outdisc</i>     | (Optional) Out discard                                |
| <i>eth_single_col</i>  | (Optional) Single collision                           |
| <i>eth_multi_col</i>   | (Optional) Multiple collision                         |
| <i>eth_late_col</i>    | (Optional) Late collision                             |
| <i>eth_excess_col</i>  | (Optional) Excess collision                           |
| <i>eth_carri_sen</i>   | (Optional) Carrier sense                              |
| <i>eth_runts</i>       | (Optional) Runts                                      |
| <i>eth_giants</i>      | (Optional) Giants                                     |
| <i>eth_sqetest_err</i> | (Optional) SQETest error                              |

|                        |                         |
|------------------------|-------------------------|
| <i>eth_deferred_tx</i> | (Optional) Deferred tx  |
| <i>eth_inmactx_err</i> | (Optional) In MAC tx    |
| <i>eth_inmacrx_err</i> | (Optional) In MAC rx    |
| <i>eth_symbol_err</i>  | (Optional) Symbol error |
| <i>eth_indisc</i>      | (Optional) In discards  |
| <i>eth_stomped_crc</i> | (Optional) Stomped CRC  |

**Command Mode**

- /exec

## show interface counters errors

```
show interface counters errors [ module <module> ] [ non-zero ] [ __readonly__ TABLE_interface <interface>
[ <eth_align_err> ] [ <eth_fcs_err> ] [ <eth_xmit_err> ] [ <eth_rcv_err> ] [ <eth_undersize> ] [ <eth_outdisc>
] [ <eth_single_col> ] [ <eth_multi_col> ] [ <eth_late_col> ] [ <eth_excess_col> ] [ <eth_carri_sen> ] [
<eth_runts> ] [ <eth_giants> ] [ <eth_sqetest_err> ] [ <eth_deferred_tx> ] [ <eth_inmactx_err> ] [
<eth_inmacrx_err> ] [ <eth_symbol_err> ] [ <eth_indisc> ] [ <eth_stomped_crc> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| interface             | Show interface status and information             |
| counters              | Show interface counters                           |
| errors                | Show interface error counters                     |
| module                | (Optional) Limit display to interfaces on module  |
| <i>module</i>         | (Optional) Enter module number                    |
| non-zero              | (Optional) Display only the non-zero error values |
| <i>__readonly__</i>   | (Optional) Read Only                              |
| <i>interface</i>      | (Optional) Interface index                        |
| TABLE_interface       | (Optional) show interface                         |
| <i>eth_align_err</i>  | (Optional) Align error                            |
| <i>eth_fcs_err</i>    | (Optional) FCS error                              |
| <i>eth_xmit_err</i>   | (Optional) Transmit error                         |
| <i>eth_rcv_err</i>    | (Optional) Receive error                          |
| <i>eth_undersize</i>  | (Optional) Undersize                              |
| <i>eth_outdisc</i>    | (Optional) Out discard                            |
| <i>eth_single_col</i> | (Optional) Single collision                       |
| <i>eth_multi_col</i>  | (Optional) Multiple collision                     |
| <i>eth_late_col</i>   | (Optional) Late collision                         |
| <i>eth_excess_col</i> | (Optional) Excess collision                       |
| <i>eth_carri_sen</i>  | (Optional) Carrier sense                          |
| <i>eth_runts</i>      | (Optional) Runts                                  |
| <i>eth_giants</i>     | (Optional) Giants                                 |



|                        |                          |
|------------------------|--------------------------|
| <i>eth_sqetest_err</i> | (Optional) SQETest error |
| <i>eth_deferred_tx</i> | (Optional) Deferred tx   |
| <i>eth_inmactx_err</i> | (Optional) In MAC tx     |
| <i>eth_inmacrx_err</i> | (Optional) In MAC rx     |
| <i>eth_symbol_err</i>  | (Optional) Symbol error  |
| <i>eth_indisc</i>      | (Optional) In discards   |
| <i>eth_stomped_crc</i> | (Optional) Stomped CRC   |

**Command Mode**

- /exec



|                         |                             |
|-------------------------|-----------------------------|
| TABLE_input             | (Optional) Input values     |
| <i>frames</i>           | (Optional) Frames           |
| <i>bytes</i>            | (Optional) Bytes            |
| <i>class_2_frames</i>   | (Optional) Class 2 frames   |
| <i>class_2_bytes</i>    | (Optional) Class 2 bytes    |
| <i>class_3_frames</i>   | (Optional) Class 3 frames   |
| <i>class_3_bytes</i>    | (Optional) Class 3 bytes    |
| <i>class_f_frames</i>   | (Optional) Class f frames   |
| <i>class_f_bytes</i>    | (Optional) Class f bytes    |
| <i>class_2_3_frames</i> | (Optional) Class 2/3 Frames |
| <i>discards</i>         | (Optional) Discards         |
| <i>errors</i>           | (Optional) Errors           |
| <i>crc_fcs</i>          | (Optional) CRC/FCS          |
| <i>unknown_class</i>    | (Optional) Unknown Class    |
| <i>too_long</i>         | (Optional) Frames too long  |
| <i>too_short</i>        | (Optional) Frames too short |
| TABLE_output            | (Optional) Output Values    |
| <i>frames</i>           | (Optional) Frames           |
| <i>bytes</i>            | (Optional) Bytes            |
| <i>class_2_frames</i>   | (Optional) Class 2 frames   |
| <i>class_2_bytes</i>    | (Optional) Class 2 bytes    |
| <i>class_3_frames</i>   | (Optional) Class 3 frames   |
| <i>class_3_bytes</i>    | (Optional) Class 3 bytes    |
| <i>class_f_frames</i>   | (Optional) Class f frames   |
| <i>class_f_bytes</i>    | (Optional) Class f bytes    |
| <i>class_2_3_frames</i> | (Optional) Class 2/3 frames |
| <i>discards</i>         | (Optional) Discards         |
| <i>errors</i>           | (Optional) Errors           |
| <i>crc_fcs</i>          | (Optional) CRC/FCS          |

|                                |  |
|--------------------------------|--|
| <i>timeout_discards</i>        | (Optional) Timeout Discards                  |
| <i>credit_loss</i>             | (Optional) Credit Loss                       |
| <i>input_ols</i>               | (Optional) input ols                         |
| <i>input_lrr</i>               | (Optional) input LRR                         |
| <i>input_nos</i>               | (Optional) input NOS                         |
| <i>input_loop_inits</i>        | (Optional) input loop inits                  |
| <i>output_ols</i>              | (Optional) output OLS                        |
| <i>output_lrr</i>              | (Optional) output LRR                        |
| <i>output_nos</i>              | (Optional) output NOS                        |
| <i>output_loop_inits</i>       | (Optional) output loop inits                 |
| <i>link_faliures</i>           | (Optional) link faliures                     |
| <i>sync_loss</i>               | (Optional) Sync loss                         |
| <i>signal_loss</i>             | (Optional) Signal loss                       |
| <i>b2b_transmit</i>            | (Optional) B2B transmit                      |
| <i>b2b_receive</i>             | (Optional) B2B receive                       |
| <i>txwait</i>                  | (Optional) TxWait                            |
| <i>tx_credit_unavbl</i>        | (Optional) Tx credit unavliable              |
| <i>b2b_receive_remain</i>      | (Optional) B2B receive remain                |
| <i>b2b_transmit_remain</i>     | (Optional) B2B transmit remain               |
| <i>low_priority_b2b_remain</i> | (Optional) Low priority B2B credit remaining |
| <i>time_last_cleared</i>       | (Optional) Last time cleared                 |
| <i>broadcast_frames</i>        | (Optional) Broadcast frames                  |
| <i>errors</i>                  | (Optional) Errors                            |
| <i>queue_drops</i>             | (Optional) Queue drops                       |
| <i>if_down_drops</i>           | (Optional) If down drops                     |
| <i>red_drops</i>               | (Optional) Red drops                         |
| <i>bad_ether_type_drops</i>    | (Optional) Bad ether type drops              |
| <i>bad_protocol_drops</i>      | (Optional) Bad Protocol Drops                |
| <i>arp_drops</i>               | (Optional) Arp Drops                         |

|                           |   |
|---------------------------|---|
| <i>timestamp_error</i>    | (Optional) Timestamp Error                |
| <i>reass_frames</i>       | (Optional) Reass Frames                   |
| <i>rx_b2b_perf_buff</i>   | (Optional) RX B2B performance buffer      |
| <i>rx_b2b_credit</i>      | (Optional) RX B2B credit remaining        |
| <i>tx_b2b_credit</i>      | (Optional) TX B2B credit remaining        |
| <i>tx_b2b_low_pri_cre</i> | (Optional) TX B2B low priority Credit     |
| <i>off_seq_err_rcvd</i>   | (Optional) Offset Sequence Error Received |
| TABLE_counters_brief      | (Optional) Table counters brief           |
| <i>sfp</i>                | (Optional) FC id                          |
| <i>fc_input_rate</i>      | (Optional) Input rate                     |
| <i>fc_frames_in</i>       | (Optional) Frames in                      |
| <i>fc_output_rate</i>     | (Optional) Output rate                    |
| <i>fc_frames_out</i>      | (Optional) Frames out                     |
| <i>interface</i>          | (Optional) Interface index                |
| TABLE_interface           | (Optional) interface                      |
| <i>fcoe_in_pkts</i>       | (Optional) fcoe in pkts                   |
| <i>fcoe_in_octets</i>     | (Optional) fcoe in octets                 |
| <i>fcoe_out_pkts</i>      | (Optional) fcoe out pkts                  |
| <i>fcoe_out_octets</i>    | (Optional) fcoe out octets                |

**Command Mode**

- /exec

## show interface counters snmp

```
show interface counters snmp [ module <module> ] [ __readonly__ { TABLE_rx_counters <interface_rx> [
<eth_inpkts> ] [ <eth_inbytes> ] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ]
[ <eth_l3in_ucastpkts> ] [ <eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_ipv4bytes> ] [
<eth_l3in_ipv4pkts> ] [ <eth_l3in_ipv4ucast_pkts> ] [ <eth_l3in_ipv4mcast_pkts> ] [
<eth_l3in_ipv4bcast_pkts> ] [ <eth_l3in_ipv6bytes> ] [ <eth_l3in_ipv6pkts> ] [ <eth_l3in_ipv6ucast_pkts>
] [ <eth_l3in_ipv6mcast_pkts> ] [ <eth_l3in_ipv6bcast_pkts> ] } { TABLE_tx_counters <interface_tx> [
<eth_outpkts> ] [ <eth_outbytes> ] [ <eth_outucast> ] [ <eth_outmcast> ] [ <eth_outbcast> ] [
<eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [ <eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] [
<eth_l3out_ipv4bytes> ] [ <eth_l3out_ipv4pkts> ] [ <eth_l3out_ipv4ucast_pkts> ] [
<eth_l3out_ipv4mcast_pkts> ] [ <eth_l3out_ipv4bcast_pkts> ] [ <eth_l3out_ipv6bytes> ] [
<eth_l3out_ipv6pkts> ] [ <eth_l3out_ipv6ucast_pkts> ] [ <eth_l3out_ipv6mcast_pkts> ] [
<eth_l3out_ipv6bcast_pkts> ] } ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                  |
| interface                 | Show interface status and information            |
| counters                  | Show interface counters                          |
| snmp                      | Show SNMP MIB values                             |
| module                    | (Optional) Limit display to interfaces on module |
| <i>module</i>             | (Optional) Enter module number                   |
| <i>__readonly__</i>       | (Optional) Read Only                             |
| TABLE_rx_counters         | (Optional) show Rx counters                      |
| <i>interface_rx</i>       | (Optional) Interface index                       |
| <i>eth_inpkts</i>         | (Optional) Packets input                         |
| <i>eth_inbytes</i>        | (Optional) Bytes input                           |
| <i>eth_inucast</i>        | (Optional) Unicasts                              |
| <i>eth_inmcast</i>        | (Optional) Multicasts                            |
| <i>eth_inbcast</i>        | (Optional) Broadcasts                            |
| <i>eth_l3in_bytes</i>     | (Optional) L3 Rx bytes                           |
| <i>eth_l3in_ucastpkts</i> | (Optional) L3 Rx Unicast pkts                    |
| <i>eth_l3in_mcastpkts</i> | (Optional) L3 Rx Multicast pkts                  |
| <i>eth_l3in_bcastpkts</i> | (Optional) L3 Rx Broadcast pkts                  |
| <i>eth_l3in_ipv4bytes</i> | (Optional) L3 Rx IPv4 bytes                      |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3in_ipv4pkts</i>        | (Optional) L3 Rx IPv4 pkts       |
| <i>eth_l3in_ipv4ucast_pkts</i>  | (Optional) L3 Rx IPv4 Ucast pkts |
| <i>eth_l3in_ipv4mcast_pkts</i>  | (Optional) L3 Rx IPv4 Mcast pkts |
| <i>eth_l3in_ipv4bcast_pkts</i>  | (Optional) L3 Rx IPv4 Bcast pkts |
| <i>eth_l3in_ipv6bytes</i>       | (Optional) L3 Rx IPv6 bytes      |
| <i>eth_l3in_ipv6pkts</i>        | (Optional) L3 Rx IPv6 pkts       |
| <i>eth_l3in_ipv6ucast_pkts</i>  | (Optional) L3 Rx IPv6 Ucast pkts |
| <i>eth_l3in_ipv6mcast_pkts</i>  | (Optional) L3 Rx IPv6 Mcast pkts |
| <i>eth_l3in_ipv6bcast_pkts</i>  | (Optional) L3 Rx IPv6 Bcast pkts |
| TABLE_tx_counters               | (Optional) show Tx counters      |
| <i>interface_tx</i>             | (Optional) Interface index       |
| <i>eth_outpkts</i>              | (Optional) Packets output        |
| <i>eth_outbytes</i>             | (Optional) Bytes output          |
| <i>eth_outucast</i>             | (Optional) Unicasts              |
| <i>eth_outmcast</i>             | (Optional) Multicasts            |
| <i>eth_outbcast</i>             | (Optional) Broadcasts            |
| <i>eth_l3out_bytes</i>          | (Optional) L3 Tx bytes           |
| <i>eth_l3out_ucastpkts</i>      | (Optional) L3 Tx Unicast pkts    |
| <i>eth_l3out_mcastpkts</i>      | (Optional) L3 Tx Multicast pkts  |
| <i>eth_l3out_bcastpkts</i>      | (Optional) L3 Tx Broadcast pkts  |
| <i>eth_l3out_ipv4bytes</i>      | (Optional) L3 Tx IPv4 bytes      |
| <i>eth_l3out_ipv4pkts</i>       | (Optional) L3 Tx IPv4 pkts       |
| <i>eth_l3out_ipv4ucast_pkts</i> | (Optional) L3 Tx IPv4 Ucast pkts |
| <i>eth_l3out_ipv4mcast_pkts</i> | (Optional) L3 Tx IPv4 Mcast pkts |
| <i>eth_l3out_ipv4bcast_pkts</i> | (Optional) L3 Tx IPv4 Bcast pkts |
| <i>eth_l3out_ipv6bytes</i>      | (Optional) L3 Tx IPv6 bytes      |
| <i>eth_l3out_ipv6pkts</i>       | (Optional) L3 Tx IPv6 pkts       |
| <i>eth_l3out_ipv6ucast_pkts</i> | (Optional) L3 Tx IPv6 Ucast pkts |
| <i>eth_l3out_ipv6mcast_pkts</i> | (Optional) L3 Tx IPv6 Mcast pkts |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3out_ipv6bcast_pkts</i> | (Optional) L3 Tx IPv6 Bcast pkts |
|---------------------------------|----------------------------------|

**Command Mode**

- /exec



## show interface counters snmp

```
show interface <ifeth_ctr> counters snmp [ __readonly__ { TABLE_rx_counters <interface_rx> [ <eth_inbytes>
] [ <eth_inucast> ] [ <eth_inmcast> ] [ <eth_inbcast> ] [ <eth_l3in_bytes> ] [ <eth_l3in_ucastpkts> ] [
<eth_l3in_mcastpkts> ] [ <eth_l3in_bcastpkts> ] [ <eth_l3in_ipv4bytes> ] [ <eth_l3in_ipv4pkts> ] [
<eth_l3in_ipv4ucast_pkts> ] [ <eth_l3in_ipv4mcast_pkts> ] [ <eth_l3in_ipv4bcast_pkts> ] [
<eth_l3in_ipv6bytes> ] [ <eth_l3in_ipv6pkts> ] [ <eth_l3in_ipv6ucast_pkts> ] [ <eth_l3in_ipv6mcast_pkts>
] [ <eth_l3in_ipv6bcast_pkts> ] } { TABLE_tx_counters <interface_tx> [ <eth_outbytes> ] [ <eth_outucast>
] [ <eth_outmcast> ] [ <eth_outbcast> ] [ <eth_l3out_bytes> ] [ <eth_l3out_ucastpkts> ] [
<eth_l3out_mcastpkts> ] [ <eth_l3out_bcastpkts> ] [ <eth_l3out_ipv4bytes> ] [ <eth_l3out_ipv4pkts> ] [
<eth_l3out_ipv4ucast_pkts> ] [ <eth_l3out_ipv4mcast_pkts> ] [ <eth_l3out_ipv4bcast_pkts> ] [
<eth_l3out_ipv6bytes> ] [ <eth_l3out_ipv6pkts> ] [ <eth_l3out_ipv6ucast_pkts> ] [
<eth_l3out_ipv6mcast_pkts> ] [ <eth_l3out_ipv6bcast_pkts> ] } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                       |
| interface                      | Show interface status and information                 |
| <i>ifeth_ctr</i>               | Enter interface type and number in module/slot format |
| counters                       | Show interface counters                               |
| snmp                           | Show SNMP MIB values                                  |
| <u>__readonly__</u>            | (Optional) Read Only                                  |
| TABLE_rx_counters              | (Optional) show Rx counters                           |
| <i>interface_rx</i>            | (Optional) Interface index rx                         |
| <i>eth_inbytes</i>             | (Optional) Bytes input                                |
| <i>eth_inucast</i>             | (Optional) Unicasts input                             |
| <i>eth_inmcast</i>             | (Optional) Multicasts input                           |
| <i>eth_inbcast</i>             | (Optional) Broadcasts input                           |
| <i>eth_l3in_bytes</i>          | (Optional) L3 Rx bytes                                |
| <i>eth_l3in_ucastpkts</i>      | (Optional) L3 Rx Unicast pkts                         |
| <i>eth_l3in_mcastpkts</i>      | (Optional) L3 Rx Multicast pkts                       |
| <i>eth_l3in_bcastpkts</i>      | (Optional) L3 Rx Broadcast pkts                       |
| <i>eth_l3in_ipv4bytes</i>      | (Optional) L3 Rx IPv4 bytes                           |
| <i>eth_l3in_ipv4pkts</i>       | (Optional) L3 Rx IPv4 pkts                            |
| <i>eth_l3in_ipv4ucast_pkts</i> | (Optional) L3 Rx IPv4 Ucast pkts                      |

|                                 |                                  |
|---------------------------------|----------------------------------|
| <i>eth_l3in_ipv4mcast_pkts</i>  | (Optional) L3 Rx IPv4 Mcast pkts |
| <i>eth_l3in_ipv4bcast_pkts</i>  | (Optional) L3 Rx IPv4 Bcast pkts |
| <i>eth_l3in_ipv6bytes</i>       | (Optional) L3 Rx IPv6 bytes      |
| <i>eth_l3in_ipv6pkts</i>        | (Optional) L3 Rx IPv6 pkts       |
| <i>eth_l3in_ipv6ucast_pkts</i>  | (Optional) L3 Rx IPv6 Ucast pkts |
| <i>eth_l3in_ipv6mcast_pkts</i>  | (Optional) L3 Rx IPv6 Mcast pkts |
| <i>eth_l3in_ipv6bcast_pkts</i>  | (Optional) L3 Rx IPv6 Bcast pkts |
| TABLE_tx_counters               | (Optional) show Tx counters      |
| <i>interface_tx</i>             | (Optional) Interface index tx    |
| <i>eth_outbytes</i>             | (Optional) Bytes output          |
| <i>eth_outucast</i>             | (Optional) Unicasts output       |
| <i>eth_outmcast</i>             | (Optional) Multicasts output     |
| <i>eth_outbcast</i>             | (Optional) Broadcasts output     |
| <i>eth_l3out_bytes</i>          | (Optional) L3 Tx bytes           |
| <i>eth_l3out_ucastpkts</i>      | (Optional) L3 Tx Unicast pkts    |
| <i>eth_l3out_mcastpkts</i>      | (Optional) L3 Tx Multicast pkts  |
| <i>eth_l3out_bcastpkts</i>      | (Optional) L3 Tx Broadcast pkts  |
| <i>eth_l3out_ipv4bytes</i>      | (Optional) L3 Tx IPv4 bytes      |
| <i>eth_l3out_ipv4pkts</i>       | (Optional) L3 Tx IPv4 pkts       |
| <i>eth_l3out_ipv4ucast_pkts</i> | (Optional) L3 Tx IPv4 Ucast pkts |
| <i>eth_l3out_ipv4mcast_pkts</i> | (Optional) L3 Tx IPv4 Mcast pkts |
| <i>eth_l3out_ipv4bcast_pkts</i> | (Optional) L3 Tx IPv4 Bcast pkts |
| <i>eth_l3out_ipv6bytes</i>      | (Optional) L3 Tx IPv6 bytes      |
| <i>eth_l3out_ipv6pkts</i>       | (Optional) L3 Tx IPv6 pkts       |
| <i>eth_l3out_ipv6ucast_pkts</i> | (Optional) L3 Tx IPv6 Ucast pkts |
| <i>eth_l3out_ipv6mcast_pkts</i> | (Optional) L3 Tx IPv6 Mcast pkts |
| <i>eth_l3out_ipv6bcast_pkts</i> | (Optional) L3 Tx IPv6 Bcast pkts |

**Command Mode**

- /exec

# show interface counters storm-control

```
show interface <ifeth_ctr_stm_ctrl> counters storm-control [ details ] [ __readonly__ TABLE_interface
<interface> <eth_ucast_supp> <eth_mcast_supp> <eth_bcast_supp> <eth_total_supp> <supp_action>
<eth_type> <eth_pps> <eth_threshold> <eth_supp_ucast> <eth_supp_mcast> <eth_supp_bcast> ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                          |
| interface                 | Show interface status and information                    |
| <i>ifeth_ctr_stm_ctrl</i> | Enter interface type and number in module/slot format    |
| counters                  | Show interface counters                                  |
| storm-control             | Show interface storm-control counters                    |
| details                   | (Optional) Show interface storm-control counters details |
| <i>__readonly__</i>       | (Optional) Read Only                                     |
| <i>interface</i>          | (Optional) Interface index                               |
| TABLE_interface           | (Optional) show interface                                |
| <i>eth_ucast_supp</i>     | (Optional) Unicast suppression percentage                |
| <i>eth_mcast_supp</i>     | (Optional) Multicast suppression percentage              |
| <i>eth_bcast_supp</i>     | (Optional) Broadcast suppression percentage              |
| <i>eth_total_supp</i>     | (Optional) Total discarded due to suppression            |
| <i>supp_action</i>        | (Optional) Action to be taken on suppression             |
| <i>eth_type</i>           | (Optional) cast type                                     |
| <i>eth_pps</i>            | (Optional) PPS enabled                                   |
| <i>eth_threshold</i>      | (Optional) Threshold                                     |
| <i>eth_supp_ucast</i>     | (Optional) Unicast suppression                           |
| <i>eth_supp_mcast</i>     | (Optional) Multicast suppression                         |
| <i>eth_supp_bcast</i>     | (Optional) Broadcast suppression                         |

## Command Mode

- /exec

## show interface counters storm-control

```
show interface counters storm-control [ details | module <module> ] [ __readonly__ TABLE_interface
<interface> <eth_ucast_supp> <eth_mcast_supp> <eth_bcast_supp> <eth_total_supp> <supp_action>
<eth_type> <eth_pps> <eth_threshold> <eth_supp_ucast> <eth_supp_mcast> <eth_supp_bcast> ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                          |
| interface             | Show interface status and information                    |
| counters              | Show interface counters                                  |
| storm-control         | Show interface storm-control counters                    |
| module                | (Optional) Limit display to interfaces on module         |
| details               | (Optional) Show interface storm-control counters details |
| <i>module</i>         | (Optional) Enter module number                           |
| <i>__readonly__</i>   | (Optional) Read Only                                     |
| <i>interface</i>      | (Optional) Interface index                               |
| TABLE_interface       | (Optional) show interface                                |
| <i>eth_ucast_supp</i> | (Optional) Unicast suppression percentage                |
| <i>eth_mcast_supp</i> | (Optional) Multicast suppression percentage              |
| <i>eth_bcast_supp</i> | (Optional) Broadcast suppression percentage              |
| <i>eth_total_supp</i> | (Optional) Total discarded due to suppression            |
| <i>supp_action</i>    | (Optional) Action to be taken on suppression             |
| <i>eth_type</i>       | (Optional) cast type                                     |
| <i>eth_pps</i>        | (Optional) PPS enabled                                   |
| <i>eth_threshold</i>  | (Optional) Threshold                                     |
| <i>eth_supp_ucast</i> | (Optional) Unicast suppression                           |
| <i>eth_supp_mcast</i> | (Optional) Multicast suppression                         |
| <i>eth_supp_bcast</i> | (Optional) Broadcast suppression                         |

### Command Mode

- /exec

## show interface counters storm-control multi-threshold

```
show interface <ifeth_ctr_stm_ctrl> counters storm-control multi-threshold [ unicast | broadcast | multicast ]
[ __readonly__ TABLE_interface <interface> [ <eth_ucast_level1> ] [ <eth_mcast_level1> ] [
<eth_bcast_level1> ] [ <eth_ucast_supp_level1> ] [ <eth_mcast_supp_level1> ] [ <eth_bcast_supp_level1> ] [
<supp_action1> ] [ <eth_ucast_level2> ] [ <eth_mcast_level2> ] [ <eth_bcast_level2> ] [
<eth_ucast_supp_level2> ] [ <eth_mcast_supp_level2> ] [ <eth_bcast_supp_level2> ] [ <supp_action2> ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                       |
| interface                    | Show interface status and information                 |
| <i>ifeth_ctr_stm_ctrl</i>    | Enter interface type and number in module/slot format |
| counters                     | Show interface counters                               |
| storm-control                | Show interface storm-control counters                 |
| multi-threshold              | multi-level storm control                             |
| unicast                      | (Optional) Unicast traffic information                |
| broadcast                    | (Optional) Broadcast traffic information              |
| multicast                    | (Optional) Multicast traffic information              |
| __readonly__                 | (Optional) Read Only                                  |
| <i>interface</i>             | (Optional) Interface index                            |
| TABLE_interface              | (Optional) show interface                             |
| <i>eth_ucast_level1</i>      | (Optional) Unicast suppression percentage level 1     |
| <i>eth_ucast_level2</i>      | (Optional) Unicast suppression percentage level 2     |
| <i>eth_mcast_level1</i>      | (Optional) Multicast suppression percentage level 1   |
| <i>eth_mcast_level2</i>      | (Optional) Multicast suppression percentage level 2   |
| <i>eth_bcast_level1</i>      | (Optional) Broadcast suppression percentage level 1   |
| <i>eth_bcast_level2</i>      | (Optional) Broadcast suppression percentage level 2   |
| <i>supp_action1</i>          | (Optional) Action to be taken on suppression level 1  |
| <i>supp_action2</i>          | (Optional) Action to be taken on suppression level 2  |
| <i>eth_ucast_supp_level1</i> | (Optional) ucast level1 supp                          |
| <i>eth_mcast_supp_level1</i> | (Optional) mcast level1 supp                          |
| <i>eth_bcast_supp_level1</i> | (Optional) bcast level1 supp                          |

|                            |                              |
|----------------------------|------------------------------|
| <i>eth_ucast_supp_lvl2</i> | (Optional) ucast level2 supp |
| <i>eth_mcast_supp_lvl2</i> | (Optional) mcast level2 supp |
| <i>eth_bcast_supp_lvl2</i> | (Optional) bcast level2 supp |

**Command Mode**

- /exec

## show interface counters table

```
show interface counters table [ __readonly__ { TABLE_counters <interface> <desc> <eth_load_intvl>
<eth_inrate_mbps> <eth_inrate_pcmt> <eth_outrate_mbps> <eth_outrate_pcmt> } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information          |
| interface               | Show interface status and information    |
| counters                | Show interface counters                  |
| table                   | format counters in a table               |
| __readonly__            | (Optional) Read Only                     |
| TABLE_counters          | (Optional) Counters table                |
| <i>interface</i>        | (Optional) Interface                     |
| <i>desc</i>             | (Optional) Interface description         |
| <i>eth_load_intvl</i>   | (Optional) interval 1 timer value in sec |
| <i>eth_inrate_mbps</i>  | (Optional) interval 1 input rate mbps    |
| <i>eth_inrate_pcmt</i>  | (Optional) interval 1 input rate in %    |
| <i>eth_outrate_mbps</i> | (Optional) interval 1 output rate mbps   |
| <i>eth_outrate_pcmt</i> | (Optional) interval 1 output rate in %   |

### Command Mode

- /exec

## show interface counters table verbose

```
show interface counters table verbose [ __readonly__ { TABLE_Err_verbose <interface> <overrun> <underrun>
<Etype_Drop> <Proto_Drop> <If_Down_Drop> <RX_discard> <TX_discard> <CRC> <RX_Err> <TX_Err>
} ]
```

### Syntax Description

|                          |                                       |
|--------------------------|---------------------------------------|
| show                     | Show running system information       |
| interface                | Show interface status and information |
| counters                 | Show interface counters               |
| table                    | format counters in a table            |
| verbose                  | show errors counts after counters     |
| <i>__readonly__</i>      | (Optional) Read Only                  |
| <i>TABLE_Err_verbose</i> | (Optional) verbose errors table       |
| <i>interface</i>         | (Optional) Interface                  |
| <i>overrun</i>           | (Optional) overrun                    |
| <i>underrun</i>          | (Optional) underruns                  |
| <i>Etype_Drop</i>        | (Optional) bad ether type drop        |
| <i>Proto_Drop</i>        | (Optional) bad protocol drops         |
| <i>If_Down_Drop</i>      | (Optional) Input if-down drops        |
| <i>RX_discard</i>        | (Optional) discards                   |
| <i>TX_discard</i>        | (Optional) output discard             |
| <i>CRC</i>               | (Optional) CRC                        |
| <i>RX_Err</i>            | (Optional) input errors               |
| <i>TX_Err</i>            | (Optional) output errors              |

### Command Mode

- /exec



## show interface counters trunk

```
show interface <ifeth_ctr_trnk> counters trunk [ __readonly__ TABLE_interface <interface> [
<eth_trunk_frames_tx> ] [ <eth_trunk_frames_rx> ] [ <eth_wrong_encap> ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                       |
| interface                  | Show interface status and information                 |
| <i>ifeth_ctr_trnk</i>      | Enter interface type and number in module/slot format |
| counters                   | Show interface counters                               |
| trunk                      | Show interface trunk counters                         |
| <i>__readonly__</i>        | (Optional) Read Only                                  |
| <i>interface</i>           | (Optional) Interface index                            |
| TABLE_interface            | (Optional) show interface                             |
| <i>eth_trunk_frames_tx</i> | (Optional) Trunk frame transmitted                    |
| <i>eth_trunk_frames_rx</i> | (Optional) Trunk frames received                      |
| <i>eth_wrong_encap</i>     | (Optional) Wrong encapsulation                        |

### Command Mode

- /exec

# show interface dampening

```
show interface dampening [ __readonly__ { [ TABLE_vrf_dampen <vrf> [ TABLE_interface_dampen
<interface> <Flaps> <Penalty> <Supp> <ReuseTm> <HalfL> <ReuseV> <SuppV> <MaxSTm> <MaxP>
<Restart> ] ] } ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                          |
| interface              | Show interface status and information                    |
| dampening              | Show interface dampening info                            |
| __readonly__           | (Optional) Read Only                                     |
| TABLE_vrf_dampen       | (Optional) show interface vrf dampening                  |
| vrf                    | (Optional) Vrf membership                                |
| TABLE_interface_dampen | (Optional) show interface dampening                      |
| interface              | (Optional) Interface index                               |
| Flaps                  | (Optional) Number of times that an interface has flapped |
| Penalty                | (Optional) Accumulated penalty                           |
| Supp                   | (Optional) Indicates if the interface is dampened        |
| ReuseTm                | (Optional) Reuse timer                                   |
| HalfL                  | (Optional) Half-life counter                             |
| ReuseV                 | (Optional) Reuse threshold timer                         |
| SuppV                  | (Optional) Suppress threshold                            |
| MaxSTm                 | (Optional) Maximum suppress                              |
| MaxP                   | (Optional) Maximum penalty                               |
| Restart                | (Optional) Restart timer                                 |

## Command Mode

- /exec

# show interface debounce

```
show interface <ifeth_dbnc> debounce [ __readonly__ TABLE_interface <interface> <debounce>
<debounce_val> ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| interface           | Show interface status and information                 |
| <i>ifeth_dbnc</i>   | Enter interface type and number in module/slot format |
| debounce            | Show interface debounce time information              |
| __readonly__        | (Optional) Read Only                                  |
| <i>interface</i>    | (Optional) Interface index                            |
| TABLE_interface     | (Optional) show interface                             |
| <i>debounce</i>     | (Optional) Debounce time                              |
| <i>debounce_val</i> | (Optional) Value(ms)                                  |

## Command Mode

- /exec

# show interface debounce

show interface debounce [ \_\_readonly\_\_ TABLE\_interface <interface> <debounce> <debounce\_val> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information          |
| interface           | Show interface status and information    |
| debounce            | Show interface debounce time information |
| __readonly__        | (Optional) Read Only                     |
| <i>interface</i>    | (Optional) Interface index               |
| TABLE_interface     | (Optional) show interface                |
| <i>debounce</i>     | (Optional) Debounce time                 |
| <i>debounce_val</i> | (Optional) Value(ms)                     |

## Command Mode

- /exec

# show interface description

```
show interface <ifrange> description [ __readonly__ TABLE_interface <interface> <state> <protocol> <desc> ]
```

## Syntax Description

|                  |                                       |
|------------------|---------------------------------------|
| show             | Show running system information       |
| interface        | Show interface status and information |
| <i>ifrange</i>   | Enter tunnel interface number         |
| description      | Show interface description            |
| __readonly__     | (Optional) Read Only                  |
| <i>interface</i> | (Optional) Interface index            |
| TABLE_interface  | (Optional) show interface             |
| <i>state</i>     | (Optional) Interface state            |
| <i>protocol</i>  | (Optional) Protocol                   |
| <i>desc</i>      | (Optional) Description                |

## Command Mode

- /exec

# show interface description

show interface <ifid\_desc1> description [ \_\_readonly\_\_ TABLE\_interface <interface\_fc> [ <desc\_fc> ] ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| interface           | Show interface status and information                 |
| <i>ifid_desc1</i>   | Enter interface type and number in module/slot format |
| description         | Show interface description                            |
| __readonly__        | (Optional) Read Only                                  |
| <i>interface_fc</i> | (Optional) Interface index                            |
| TABLE_interface     | (Optional) show interface                             |
| <i>desc_fc</i>      | (Optional) Description                                |

## Command Mode

- /exec

# show interface description

```
show interface <ifid> description [ __readonly__ <start> <if_index> <LINE> ]
```

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information                 |
| interface       | Show interface status and information           |
| <i>ifid</i>     | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| description     | Interface specific description                  |
| __readonly__    | (Optional) Read Only                            |
| <i>start</i>    | (Optional) Start                                |
| <i>if_index</i> | (Optional) Interface                            |
| <i>LINE</i>     | (Optional) Description                          |

## Command Mode

- /exec

# show interface description

```
show interface description [ __readonly__ TABLE_interface <interface> [ <state> ] [ <type> ] [ <speed> ] [ <protocol> ] [ <desc> ] ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| interface           | Show interface status and information |
| description         | Show interface description            |
| <i>__readonly__</i> | (Optional) Read Only                  |
| <i>interface</i>    | (Optional) Interface index            |
| TABLE_interface     | (Optional) show interface             |
| <i>state</i>        | (Optional) Interface state            |
| <i>type</i>         | (Optional) Type                       |
| <i>speed</i>        | (Optional) Speed                      |
| <i>protocol</i>     | (Optional) Protocol                   |
| <i>desc</i>         | (Optional) Description                |

## Command Mode

- /exec



# show interface description

```
show interface <ifid_mgmt_loop> description [ __readonly__ TABLE_interface <interface> [ <state> ] [
<protocol> ] [ <desc> ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| <i>ifid_mgmt_loop</i> | Enter interface type and number in module/slot format |
| description           | Show interface description                            |
| __readonly__          | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>state</i>          | (Optional) Interface state                            |
| <i>protocol</i>       | (Optional) Protocol                                   |
| <i>desc</i>           | (Optional) Description                                |

## Command Mode

- /exec

# show interface description

```
show interface <ifid_eth> description [ __readonly__ TABLE_interface <interface> [ <state> ] [ <type> ] [ <speed> ] [ <protocol> ] [ <desc> ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| interface           | Show interface status and information                 |
| <i>ifid_eth</i>     | Enter interface type and number in module/slot format |
| description         | Show interface description                            |
| <i>__readonly__</i> | (Optional) Read Only                                  |
| <i>interface</i>    | (Optional) Interface index                            |
| TABLE_interface     | (Optional) show interface                             |
| <i>state</i>        | (Optional) Interface state                            |
| <i>type</i>         | (Optional) Type                                       |
| <i>speed</i>        | (Optional) Speed                                      |
| <i>protocol</i>     | (Optional) Protocol                                   |
| <i>desc</i>         | (Optional) Description                                |

## Command Mode

- /exec

# show interface description

```
show interface <iftun_desc> description [ __readonly__ TABLE_interface <interface> <state> <protocol>
<desc> ]
```

## Syntax Description

|                   |                                       |
|-------------------|---------------------------------------|
| show              | Show running system information       |
| interface         | Show interface status and information |
| <i>iftun_desc</i> | Enter tunnel interface number         |
| description       | Show interface description            |
| __readonly__      | (Optional) Read Only                  |
| <i>interface</i>  | (Optional) Interface index            |
| TABLE_interface   | (Optional) show interface             |
| <i>state</i>      | (Optional) Interface state            |
| <i>protocol</i>   | (Optional) Protocol                   |
| <i>desc</i>       | (Optional) Description                |

## Command Mode

- /exec

# show interface description

```
show interface <ifrange> description [ __readonly__ TABLE_interface <interface> <state> <protocol> <desc> ]
```

## Syntax Description

|                  |                                       |
|------------------|---------------------------------------|
| show             | Show running system information       |
| interface        | Show interface status and information |
| <i>ifrange</i>   | Enter tunnel interface number         |
| description      | Show interface description            |
| __readonly__     | (Optional) Read Only                  |
| <i>interface</i> | (Optional) Interface index            |
| TABLE_interface  | (Optional) show interface             |
| <i>state</i>     | (Optional) Interface state            |
| <i>protocol</i>  | (Optional) Protocol                   |
| <i>desc</i>      | (Optional) Description                |

## Command Mode

- /exec

## show interface detail-counters

```
show interface detail-counters [ __readonly__ [ { TABLE_counters <sfp> <in_frames> <in_bytes>
<class_2_frames> <class_2_in_bytes> <class_2_in_discards> <class_2_in_f_bsy_frames>
<class_2_in_f_rgt_frames> <class_2_in_port_reject_frames> <class_3_frames> <class_3_bytes_rcvd>
<class_f_frames> <class_f_bytes_rcvd> <class_f_in_discards> <class_f_errors_rcvd> <class_f_out_discards>
<class_f_errors_trans> <out_frames> <out_bytes> <class_2_out_frames> <class_2_bytes_trans>
<class_3_out_frames> <class_3_bytes_trans> <class_3_out_discards> <class_f_out_frames>
<class_f_bytes_trans> <class_f_discards> <muticast_rcvd> <multicast_trans> <broadcast_rcvd>
<broadcast_trans> <unicast_rcvd> <unicast_trans> <timeout_discards> <credit_loss> <link_faliures>
<sync_loss> <signal_loss> <prm_seq_pro_err> <inv_trans_err> <inv_crc> <delim_err> <addr_iden_err>
<link_reset_rcvd> <link_reset_trans> <off_seq_err_rcvd> <off_seq_err_trans> <frames_rcvd_short>
<frames_rcvd_long> [ <txwait> ] <frames_rcvd_greater> <frame_rcvd_short_header> <link_reset_resp_rcvd>
<link_reset_resp_trans> <non_oper_seq_rcvd> <non_oper_seq_trans> <frag_frames_rcvd> <frames_eof_abort>
<unknown_class_frames_rcvd> <8b10b_disparity_err> <frames_discard> <ex_link_param_sw_fab> [
<in_link_ser_req_faliures> ] <b2b_credits_transmit> [ <b2b_credits_receive> ] <eisl_frames> <framing_err>
<f8_lip_seq_err_rcvd> <f8_lip_seq_err_issued> <non_f8_lip_seq_err_rcvd> <non_f8_lip_seq_err_issued>
[ <fec_corrected> ] [ <fec_uncorrected> ] } ] [ { TABLE_interface <interface> [ <fcoe_in_pkts> ] [
<fcoe_in_octets> ] [ <fcoe_out_pkts> ] [ <fcoe_out_octets> ] } ] ] ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information          |
| interface                     | Show interface status and information    |
| detail-counters               | Show interface counters in detail        |
| __readonly__                  | (Optional)                               |
| TABLE_counters                | (Optional) show interface counters       |
| sfp                           | (Optional) SFP                           |
| in_frames                     | (Optional) in frames                     |
| in_bytes                      | (Optional) in bytes                      |
| class_2_frames                | (Optional) Class 2 frames                |
| class_2_in_bytes              | (Optional) Class 2 bytes received        |
| class_2_in_discards           | (Optional) Class 2 discards received     |
| class_2_in_f_bsy_frames       | (Optional) Class 2 F_BSY frames received |
| class_2_in_f_rgt_frames       | (Optional) Class 2 F_RGT frames          |
| class_2_in_port_reject_frames | (Optional) Class 2 port reject frames    |
| class_3_frames                | (Optional) Class 3 frames                |
| class_3_bytes_rcvd            | (Optional) Class 3 bytes received        |

|                             |   |
|-----------------------------|---|
| <i>class_f_frames</i>       | (Optional) Class f frames                     |
| <i>class_f_bytes_rcvd</i>   | (Optional) Class F bytes received             |
| <i>class_f_in_discards</i>  | (Optional) Class F in discards                |
| <i>class_f_errors_rcvd</i>  | (Optional) Class F errors received            |
| <i>class_f_out_discards</i> | (Optional) Class F out discards               |
| <i>class_f_errors_trans</i> | (Optional) Class F errors transmitted         |
| <i>out_frames</i>           | (Optional) Out frames                         |
| <i>out_bytes</i>            | (Optional) Out bytes                          |
| <i>class_2_out_frames</i>   | (Optional) Class 2 frames transmitted         |
| <i>class_2_bytes_trans</i>  | (Optional) Class 2 bytes transmitted          |
| <i>class_3_out_frames</i>   | (Optional) Class 3 frames transmitted         |
| <i>class_3_bytes_trans</i>  | (Optional) Class 3 bytes transmitted          |
| <i>class_3_out_discards</i> | (Optional) Class 3 out discards               |
| <i>class_f_out_frames</i>   | (Optional) Class F out frames                 |
| <i>class_f_bytes_trans</i>  | (Optional) Class F bytes transmitted          |
| <i>class_f_discards</i>     | (Optional) Class F discards                   |
| <i>multicast_rcvd</i>       | (Optional) Multicast received                 |
| <i>multicast_trans</i>      | (Optional) Multicast transmitted              |
| <i>broadcast_rcvd</i>       | (Optional) Broadcast received                 |
| <i>broadcast_trans</i>      | (Optional) Broadcast transmitted              |
| <i>unicast_rcvd</i>         | (Optional) Unicast received                   |
| <i>unicast_trans</i>        | (Optional) Unicast transmitted                |
| <i>timeout_discards</i>     | (Optional) timeout discards                   |
| <i>credit_loss</i>          | (Optional) credit loss                        |
| <i>link_faliures</i>        | (Optional) Link faliures                      |
| <i>sync_loss</i>            | (Optional) Sync Loss                          |
| <i>signal_loss</i>          | (Optional) Signal Loss                        |
| <i>prm_seq_pro_err</i>      | (Optional) primitive sequence protocol errors |
| <i>inv_trans_err</i>        | (Optional) invaid transmission errors         |

|                                  |   |
|----------------------------------|---|
| <i>inv_crc</i>                   | (Optional) Invalid crc  |
| <i>delim_err</i>                 | (Optional) Delimiter Errors   |
| <i>addr_iden_err</i>             | (Optional) Address Identification errors  |
| <i>link_reset_rcvd</i>           | (Optional) link reset received  |
| <i>link_reset_trans</i>          | (Optional) link reset transmitted   |
| <i>off_seq_err_rcvd</i>          | (Optional) Offline sequence error received  |
| <i>off_seq_err_trans</i>         | (Optional) Offline sequence Error transmitted   |
| <i>frames_rcvd_short</i>         | (Optional) frames received that are shorter than the minimum allowable frame length regardless of the CRC/FCS error |
| <i>frames_rcvd_long</i>          | (Optional) frames received that are longer than the minimum allowable frame length regardless of the CRC/FCS error  |
| <i>txwait</i>                    | (Optional) TXwait   |
| <i>frames_rcvd_greater</i>       | (Optional) frames received with length greater than what was agreed to in FLOGI/PLOGI                               |
| <i>frame_rcvd_short_header</i>   | (Optional) frames received with length less than the minimum indicated by the frame header                          |
| <i>link_reset_resp_rcvd</i>      | (Optional) Link reset responses received  |
| <i>link_reset_resp_trans</i>     | (Optional) Link reset responses transmitted   |
| <i>non_oper_seq_rcvd</i>         | (Optional) Non operational sequence received  |
| <i>non_oper_seq_trans</i>        | (Optional) Non operational sequence transmitted   |
| <i>frag_frames_rcvd</i>          | (Optional) fragmented frames received   |
| <i>frames_eof_abort</i>          | (Optional) frames EOF abort   |
| <i>unknown_class_frames_rcvd</i> | (Optional) unknown class frames received  |
| <i>8b10b_disparity_err</i>       | (Optional) 8b10b disparity errors   |
| <i>frames_discard</i>            | (Optional) frames discard   |
| <i>ex_link_param_sw_fab</i>      | (Optional) external link parameters switch fabric   |
| <i>in_link_ser_req_faliures</i>  | (Optional) internal link serial request faliures  |
| <i>b2b_credits_transmit</i>      | (Optional) B2B credits transmit   |
| <i>b2b_credits_receive</i>       | (Optional) B2B credits receive  |
| <i>eisl_frames</i>               | (Optional) EISL frames  |

|                                  |   |
|----------------------------------|---|
| <i>framing_err</i>               | (Optional) Framing Error                      |
| <i>f8_lip_seq_err_rcvd</i>       | (Optional) f8 LIP sequence error received     |
| <i>f8_lip_seq_err_issued</i>     | (Optional) f8 LIP sequence error issued       |
| <i>non_f8_lip_seq_err_rcvd</i>   | (Optional) non f8 LIP sequence error received |
| <i>non_f8_lip_seq_err_issued</i> | (Optional) non f8 LIP sequence error issued   |
| <i>fec_corrected</i>             | (Optional) fec corrected blocks               |
| <i>fec_uncorrected</i>           | (Optional) fec uncorrected blocks             |
| TABLE_interface                  | (Optional) interface                          |
| <i>interface</i>                 | (Optional) interface                          |
| <i>fcoe_in_pkts</i>              | (Optional) fcoe in pkts                       |
| <i>fcoe_in_octets</i>            | (Optional) fcoe in octets                     |
| <i>fcoe_out_pkts</i>             | (Optional) fcoe out pkts                      |
| <i>fcoe_out_octets</i>           | (Optional) fcoe out octets                    |

**Command Mode**

- /exec



## show interface fcoe

```
show interface <ifeth_fcoe> fcoe [ __readonly__ TABLE_interface <interface> [ <state> ] [ <vfc> ] [ <vfc_bound> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifeth_fcoe</i>      | Enter interface type and number in module/slot format |
| fcoe                   | Show interface fcoe information                       |
| <i>__readonly__</i>    | (Optional) Read Only                                  |
| <i>TABLE_interface</i> | (Optional) show interface                             |
| <i>interface</i>       | (Optional) Interface index                            |
| <i>state</i>           | (Optional) State of interface                         |
| <i>vfc</i>             | (Optional) VFC  |
| <i>vfc_bound</i>       | (Optional) Binding information                        |

### Command Mode

- /exec

# show interface fec

```
show interface fec [ __readonly__ TABLE_interface <interface> [ <ifindex-hex> ] [ <admin_port_fec> ] [ <oper_port_fec> ] [ <state> ] [ <speed> ] [ <type> ] ]
```

## Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| <i>show</i>            | Show running system information       |
| <i>interface</i>       | Show interface status and information |
| <i>fec</i>             | Show interface fec list               |
| <i>__readonly__</i>    | (Optional) Read Only                  |
| <i>interface</i>       | (Optional) Interface index            |
| <i>TABLE_interface</i> | (Optional) show interface             |
| <i>ifindex-hex</i>     | (Optional) If Index in Hex            |
| <i>admin_port_fec</i>  | (Optional) Admin port fec state       |
| <i>oper_port_fec</i>   | (Optional) Oper port fec state        |
| <i>state</i>           | (Optional) Interface state            |
| <i>speed</i>           | (Optional) Speed                      |
| <i>type</i>            | (Optional) Type                       |

## Command Mode

- /exec

# show interface flowcontrol

```
show interface <ifeth_fl_ctrl> flowcontrol [ __readonly__ TABLE_interface <interface> <send_admin>
<send_oper> <recv_admin> <recv_oper> <rxpause> <txpause> ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                       |
| interface            | Show interface status and information                 |
| <i>ifeth_fl_ctrl</i> | Enter interface type and number in module/slot format |
| flowcontrol          | Show interface flowcontrol information                |
| <i>__readonly__</i>  | (Optional) Read Only                                  |
| <i>interface</i>     | (Optional) Interface index                            |
| TABLE_interface      | (Optional) show interface                             |
| <i>send_admin</i>    | (Optional) Send flowcontrol admin                     |
| <i>send_oper</i>     | (Optional) Send flowcontrol oper                      |
| <i>recv_admin</i>    | (Optional) Receive flowcontrol admin                  |
| <i>recv_oper</i>     | (Optional) Receive flowcontrol oper                   |
| <i>rxpause</i>       | (Optional) RxPause                                    |
| <i>txpause</i>       | (Optional) TxPause                                    |

## Command Mode

- /exec

## show interface flowcontrol

```
show interface flowcontrol [ module <module> ] [ __readonly__ TABLE_interface <interface> <send_admin>
<send_oper> <recv_admin> <recv_oper> <rxpause> <txpause> ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| interface           | Show interface status and information            |
| flowcontrol         | Show interface flowcontrol information           |
| module              | (Optional) Limit display to interfaces on module |
| <i>module</i>       | (Optional) Enter module number                   |
| <i>__readonly__</i> | (Optional) Read Only                             |
| <i>interface</i>    | (Optional) Interface index                       |
| TABLE_interface     | (Optional) show interface                        |
| <i>send_admin</i>   | (Optional) Send flowcontrol admin                |
| <i>send_oper</i>    | (Optional) Send flowcontrol oper                 |
| <i>recv_admin</i>   | (Optional) Receive flowcontrol admin             |
| <i>recv_oper</i>    | (Optional) Receive flowcontrol oper              |
| <i>rxpause</i>      | (Optional) RxPause                               |
| <i>txpause</i>      | (Optional) TxPause                               |

### Command Mode

- /exec

# show interface hardware-mappings

show interface hardware-mappings [ json ]

## Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information                               |
| interface         | Interface   |
| hardware-mappings | Show hardware port number and unit information for interfaces |
| json              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                     |

## Command Mode

- /exec

## show interface mac-address

```
show interface <ifid_macaddr> mac-address [ __readonly__ TABLE_interface <interface> <address>
<bia_address> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| interface           | Show interface status and information                 |
| <i>ifid_macaddr</i> | Enter interface type and number in module/slot format |
| mac-address         | Show interface MAC address                            |
| __readonly__        | (Optional) Read Only                                  |
| TABLE_interface     | (Optional) show interface                             |
| <i>interface</i>    | (Optional) Interface index                            |
| <i>address</i>      | (Optional) MAC Address                                |
| <i>bia_address</i>  | (Optional) Burn-In MAC Address                        |

### Command Mode

- /exec

# show interface mac-address

```
show interface mac-address [ __readonly__ TABLE_interface <interface> <address> <bia_address> ]
```

## Syntax Description

|                    |                                       |
|--------------------|---------------------------------------|
| show               | Show running system information       |
| interface          | Show interface status and information |
| mac-address        | Show interface MAC address            |
| __readonly__       | (Optional) Read Only                  |
| TABLE_interface    | (Optional) show interface             |
| <i>interface</i>   | (Optional) Interface index            |
| <i>address</i>     | (Optional) MAC Address                |
| <i>bia_address</i> | (Optional) Burn-In MAC Address        |

## Command Mode

- /exec

## show interface priority-flow-control

```
show interface [ <if_list> ] priority-flow-control [ detail ] [ module <module> ] [ __readonly__ [
TABLE_pfc_interface <if_name_str> <admin> <oper> [ <oper_vl_bmap> ] [ <cos-list> ] <rx-stats> <tx-stats>
[ <rx_ppp_cos_0> ] [ <rx_ppp_cos_1> ] [ <rx_ppp_cos_2> ] [ <rx_ppp_cos_3> ] [ <rx_ppp_cos_4> ] [
<rx_ppp_cos_5> ] [ <rx_ppp_cos_6> ] [ <rx_ppp_cos_7> ] [ <tx_ppp_cos_0> ] [ <tx_ppp_cos_1> ] [
<tx_ppp_cos_2> ] [ <tx_ppp_cos_3> ] [ <tx_ppp_cos_4> ] [ <tx_ppp_cos_5> ] [ <tx_ppp_cos_6> ] [
<tx_ppp_cos_7> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | commands to display  |
| interface             | Interface for displaying pfc information                   |
| <i>if_list</i>        | (Optional) List of interfaces                              |
| module                | (Optional) Slot/module                                     |
| <i>module</i>         | (Optional) Slot/module number                              |
| priority-flow-control | Show interface PFC information                             |
| detail                | (Optional) Show detailed per priority Tx/Rx PFC statistics |
| __readonly__          | (Optional)   |
| <i>if_name_str</i>    | (Optional) interface name                                  |
| TABLE_pfc_interface   | (Optional) PFC information of an interface                 |
| <i>admin</i>          | (Optional) PFC admin                                       |
| <i>oper</i>           | (Optional) PFC oper  |
| <i>oper_vl_bmap</i>   | (Optional) vl bitmap value                                 |
| <i>cos-list</i>       | (Optional) List of class-of-service values                 |

### Command Mode

- /exec



## show interface private-vlan mapping

```
show interface [ <if> ] private-vlan mapping [ __readonly__ [ <output-filtered> ] [ { TABLE_interf_mapp
<interface-id> [ <secondary-vlan> + ] [ <pvlan-type> } } ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                     |
| interface              | Show interface status and information               |
| <i>if</i>              | (Optional) Vlan Interface number                    |
| private-vlan           | Show interface private vlan information             |
| mapping                | Show interface private vlan information             |
| <i>__readonly__</i>    | (Optional) Read Only                                |
| <i>output-filtered</i> | (Optional) the output is filtered for specified ifs |
| TABLE_interf_mapp      | (Optional) Pvlan interface mapping table            |
| <i>interface-id</i>    | (Optional) Interface                                |
| <i>secondary-vlan</i>  | (Optional) Secondary Vlan                           |
| <i>pvlan-type</i>      | (Optional) PVLAN Type                               |

### Command Mode

- /exec

## show interface pruning

```
show interface pruning [ __readonly__ <start> { TABLE_interface_pruning1 <if_index1> <rx_join> } {
TABLE_interface_pruning2 <if_index2> <cur_join> } ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                          |
| interface                | Show interface status and information                    |
| pruning                  | Show interface trunk VTP pruning information             |
| __readonly__             | (Optional) Read Only                                     |
| start                    | (Optional) Start   |
| TABLE_interface_pruning1 | (Optional) Interface pruning information in table format |
| if_index1                | (Optional) Trunk   |
| rx_join                  | (Optional) Vlans pruned for lack of request by neighbor  |
| TABLE_interface_pruning2 | (Optional) Interface pruning information in table format |
| if_index2                | (Optional) Trunk   |
| cur_join                 | (Optional) Vlan traffic requested of neighbor            |

### Command Mode

- /exec

# show interface queuing-drop history brief

```
show interface [ <ifindex> ] queuing-drop history brief <type> [ __readonly__
<show-interface-queuing-drop-history-brief-start> <show-hdr> <show-timestamp> <tbl-data> <show-cr>
<show-end> ]
```

## Syntax Description

|  |  |
|--|--|
| show   | Show running system information                                  |
| interface  | Show interface interface   |
| <i>ifindex</i>   | (Optional) Enter interface type and number in module/slot format |
| queuing-drop   | Show interface queuing-drop                                      |
| history  | Show interface queuing-drop history                              |
| brief  | Show interface queuing-drop history brief                        |
| <i>type</i>  | Show interface queuing-drop history detail type                  |
| <i>__readonly__</i>                                    | (Optional) Read Only   |
| <i>show-interface-queuing-drop-history-brief-start</i> | (Optional) show interface queuing-drop hist brief                |
| <i>show-hdr</i>  | (Optional) Show header   |
| <i>show-timestamp</i>                                  | (Optional) Show timestamp  |
| <i>tbl-data</i>  | (Optional) Show table data                                       |
| <i>show-cr</i>   | (Optional) Show carriage return                                  |
| <i>show-end</i>  | (Optional) Show end marker                                       |

## Command Mode

- /exec

## show interface queuing-drop history detail

```
show interface <ifindex> queuing-drop history detail <type> [ __readonly__
<show-interface-queuing-drop-history-detail-start> <show-hdr> <show-timestamp> <show-portnum> <tbl-data>
<show-cr> <show-end> ]
```

### Syntax Description

|   |   |
|---|---|
| show  | Show running system information                       |
| interface   | Show interface interface                              |
| <i>ifindex</i>  | Enter interface type and number in module/slot format |
| queuing-drop  | Show interface queuing-drop                           |
| history   | Show interface queuing-drop history                   |
| detail  | Show interface queuing-drop history detail            |
| <i>type</i>   | Show interface queuing-drop history detail type       |
| <i>__readonly__</i>                                     | (Optional) Read Only                                  |
| <i>show-interface-queuing-drop-history-detail-start</i> | (Optional) show interface queuing-drop hist detail    |
| <i>show-hdr</i>   | (Optional) Show header                                |
| <i>show-timestamp</i>                                   | (Optional) Show timestamp                             |
| <i>show-portnum</i>                                     | (Optional) Show portnum                               |
| <i>tbl-data</i>   | (Optional) Show table data                            |
| <i>show-cr</i>  | (Optional) Show carriage return                       |
| <i>show-end</i>   | (Optional) Show end marker                            |

### Command Mode

- /exec

## show interface server-info interface

```
show interface server-info interface { all | <ifname> } [ __readonly__ TABLE_server_info <server_type>
<port> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| interface           | Show interface status and information     |
| server-info         | Show all SERVER ports                     |
| interface           | interface                                 |
| all                 | all interfaces                            |
| <i>ifname</i>       | Interface name                            |
| <i>__readonly__</i> | (Optional) Read Only                      |
| TABLE_server_info   | (Optional) Discovered server fabric ports |
| <i>server_type</i>  | (Optional) Server Type                    |
| <i>port</i>         | (Optional) Port                           |

### Command Mode

- /exec

# show interface snmp-ifindex

```
show interface snmp-ifindex [ __readonly__ TABLE_interface <interface> <snmp-ifindex> [ <ifindex-hex> ] ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| interface           | Show interface status and information |
| snmp-ifindex        | Show snmp ifindex list                |
| __readonly__        | (Optional) Read Only                  |
| <i>interface</i>    | (Optional) Interface index            |
| TABLE_interface     | (Optional) show interface             |
| <i>ifindex-hex</i>  | (Optional) If Index in Hex            |
| <i>snmp-ifindex</i> | (Optional) If Index in Dec            |

## Command Mode

- /exec

# show interface status

```
show interface <ifid_status> status [ __readonly__ TABLE_interface <interface> [ <name> ] [ <state> ] [ <vlan> ] [ <duplex> ] [ <speed> ] [ <type> ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| <code>show</code>            | Show running system information                       |
| <code>interface</code>       | Show interface status and information                 |
| <i>ifid_status</i>           | Enter interface type and number in module/slot format |
| <code>status</code>          | Show interface line status                            |
| <code>__readonly__</code>    | (Optional) Read Only                                  |
| <i>interface</i>             | (Optional) Interface index                            |
| <code>TABLE_interface</code> | (Optional) show interface                             |
| <i>name</i>                  | (Optional) Name                                       |
| <i>state</i>                 | (Optional) Interface state                            |
| <i>vlan</i>                  | (Optional) Vlan                                       |
| <i>duplex</i>                | (Optional) Duplex                                     |
| <i>speed</i>                 | (Optional) Speed                                      |
| <i>type</i>                  | (Optional) Type                                       |

## Command Mode

- /exec

# show interface status

show interface <ifid> status [ \_\_readonly\_\_ <start> <if\_index> <admin-state> <line-proto> ]

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                 |
| interface          | Show interface status and information           |
| <i>ifid</i>        | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| status             | Interface status                                |
| __readonly__       | (Optional) Read Only                            |
| <i>start</i>       | (Optional) Start                                |
| <i>if_index</i>    | (Optional) Interface                            |
| <i>admin-state</i> | (Optional)                                      |
| <i>line-proto</i>  | (Optional)                                      |

## Command Mode

- /exec



## show interface status

```
show interface status [ down | inactive | module <module> | up | auto-column ] [ __readonly__ TABLE_interface
<interface> [ <name> ] [ <state> ] [ <state_san> ] [ <state_reason> ] [ <vlan> ] [ <duplex> ] [ <speed> ] [
<type> ] [ <admin_mode> ] [ <vsan> ] [ <bind_info> ] [ <bind_type> ] [ <bind_mac> ] [ <oper_speed> ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| interface           | Show interface status and information            |
| status              | Show interface line status                       |
| down                | (Optional) Show interface down state             |
| inactive            | (Optional) Show interface inactive state         |
| auto-column         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED        |
| module              | (Optional) Limit display to interfaces on module |
| <i>module</i>       | (Optional) Enter module number                   |
| up                  | (Optional) Show interface up state               |
| __readonly__        | (Optional) Read Only                             |
| <i>interface</i>    | (Optional) Interface index                       |
| TABLE_interface     | (Optional) show interface                        |
| <i>name</i>         | (Optional) Name                                  |
| <i>state</i>        | (Optional) Interface state                       |
| <i>state_san</i>    | (Optional) SAN Port State                        |
| <i>vlan</i>         | (Optional) Vlan                                  |
| <i>vsan</i>         | (Optional) Vsan                                  |
| <i>duplex</i>       | (Optional) Duplex                                |
| <i>speed</i>        | (Optional) Speed                                 |
| <i>type</i>         | (Optional) Type                                  |
| <i>state_reason</i> | (Optional) Interface state reason                |
| <i>bind_info</i>    | (Optional) bind interface                        |
| <i>bind_type</i>    | (Optional) bind type                             |
| <i>bind_mac</i>     | (Optional) bind mac                              |

|                   |                       |
|-------------------|-----------------------|
| <i>oper_speed</i> | (Optional) speed      |
| <i>admin_mode</i> | (Optional) admin mode |

**Command Mode**

- /exec

# show interface status

```
show interface <ifeth_status> status [ __readonly__ TABLE_interface <interface> [ <name> ] [ <state> ] [
<vlan> ] <duplex> <speed> [ <type> ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| <code>show</code>            | Show running system information                       |
| <code>interface</code>       | Show interface status and information                 |
| <i>ifeth_status</i>          | Enter interface type and number in module/slot format |
| <code>status</code>          | Show interface line status                            |
| <code>__readonly__</code>    | (Optional) Read Only                                  |
| <i>interface</i>             | (Optional) Interface index                            |
| <code>TABLE_interface</code> | (Optional) show interface                             |
| <i>name</i>                  | (Optional) Name                                       |
| <i>state</i>                 | (Optional) Interface state                            |
| <i>vlan</i>                  | (Optional) Vlan                                       |
| <i>duplex</i>                | (Optional) Duplex                                     |
| <i>speed</i>                 | (Optional) Speed                                      |
| <i>type</i>                  | (Optional) Type                                       |

## Command Mode

- /exec

## show interface status

```
show interface <iftun_status> status [ err-disabled ] [ __readonly__ TABLE_interface <interface> <name>
<state> <state_rsn> <state_rsn_desc> ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| interface             | Show interface status and information          |
| <i>iftun_status</i>   | Enter tunnel interface number                  |
| status                | Show interface line status                     |
| err-disabled          | (Optional) Show interface error disabled state |
| __readonly__          | (Optional) Read Only                           |
| <i>interface</i>      | (Optional) Interface index                     |
| TABLE_interface       | (Optional) show interface                      |
| <i>name</i>           | (Optional) Name                                |
| <i>state</i>          | (Optional) Interface state                     |
| <i>state_rsn</i>      | (Optional) Interface state reason              |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed     |

### Command Mode

- /exec

# show interface status

```
show interface <ifrange> status [ err-disabled ] [ __readonly__ TABLE_interface <interface> <name> <state>
[ <state_rsn> ] [ <state_rsn_desc> ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| interface             | Show interface status and information          |
| <i>ifrange</i>        | Enter tunnel interface number                  |
| status                | Show interface line status                     |
| err-disabled          | (Optional) Show interface error disabled state |
| __readonly__          | (Optional) Read Only                           |
| <i>interface</i>      | (Optional) Interface index                     |
| TABLE_interface       | (Optional) show interface                      |
| <i>name</i>           | (Optional) Name                                |
| <i>state</i>          | (Optional) Interface state                     |
| <i>state_rsn</i>      | (Optional) Interface state reason              |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed     |

## Command Mode

- /exec

## show interface status

```
show interface <ifrange> status [ err-disabled ] [ __readonly__ TABLE_interface <interface> <name> <state>
<state_rsn> <state_rsn_desc> <admin_state> ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| interface             | Show interface status and information          |
| <i>ifrange</i>        | Enter tunnel interface number                  |
| status                | Show interface line status                     |
| err-disabled          | (Optional) Show interface error disabled state |
| __readonly__          | (Optional) Read Only                           |
| <i>interface</i>      | (Optional) Interface index                     |
| TABLE_interface       | (Optional) show interface                      |
| <i>name</i>           | (Optional) Name                                |
| <i>state</i>          | (Optional) Interface state                     |
| <i>state_rsn</i>      | (Optional) Interface state reason              |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed     |
| <i>admin_state</i>    | (Optional) admin state                         |

### Command Mode

- /exec

# show interface status err-disabled

```
show interface <ifeth_errdis> status err-disabled [ __readonly__ TABLE_interface <interface> [ <name> ]
<state> [ <state_rsn> ] [ <state_rsn_desc> ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| interface             | Show interface status and information                 |
| status                | Show interface line status                            |
| <i>ifeth_errdis</i>   | Enter interface type and number in module/slot format |
| err-disabled          | Show interface error disabled state                   |
| <i>__readonly__</i>   | (Optional) Read Only                                  |
| <i>interface</i>      | (Optional) Interface index                            |
| TABLE_interface       | (Optional) show interface                             |
| <i>name</i>           | (Optional) Name                                       |
| <i>state</i>          | (Optional) Interface state                            |
| <i>state_rsn</i>      | (Optional) Interface state reason                     |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed            |

## Command Mode

- /exec

## show interface status err-disabled

```
show interface status err-disabled [ __readonly__ TABLE_interface <interface> [ <name> ] <state> [
<state_rsn> ] [ <state_rsn_desc> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information            |
| interface             | Show interface status and information      |
| status                | Show interface line status                 |
| err-disabled          | Show interface error disabled state        |
| <i>__readonly__</i>   | (Optional) Read Only                       |
| <i>interface</i>      | (Optional) Interface index                 |
| TABLE_interface       | (Optional) show interface                  |
| <i>name</i>           | (Optional) Name                            |
| <i>state</i>          | (Optional) Interface state                 |
| <i>state_rsn</i>      | (Optional) Interface state reason          |
| <i>state_rsn_desc</i> | (Optional) Interface state reason detailed |

### Command Mode

- /exec



## show interface status err-vlans

```
show interface <ifeth_errvlans> status err-vlans [ __readonly__ TABLE_interface <interface> [ <name> ] [
{ TABLE_vlan [ <err_vlan> ] [ <err_vlan_status> ] [ <err_vlan_syserr> ] } ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                       |
| interface              | Show interface status and information                 |
| <i>ifeth_errvlans</i>  | Enter interface type and number in module/slot format |
| status                 | Show interface line status                            |
| err-vlans              | Show errored vlans                                    |
| <u>__readonly__</u>    | (Optional) Read Only                                  |
| <i>interface</i>       | (Optional) Interface index                            |
| TABLE_interface        | (Optional) show interface                             |
| <i>name</i>            | (Optional) Name                                       |
| TABLE_vlan             | (Optional) show vlan                                  |
| <i>err_vlan</i>        | (Optional) Errored vlan                               |
| <i>err_vlan_status</i> | (Optional) Errored vlan status                        |
| <i>err_vlan_syserr</i> | (Optional) Errored vlan syserr name                   |

### Command Mode

- /exec

## show interface status err-vlans

```
show interface status err-vlans [ __readonly__ TABLE_interface <interface> [ <name> ] { TABLE_vlan
<err_vlan> <err_vlan_status> <err_vlan_syserr> } ]
```

### Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   | Show running system information       |
| interface              | Show interface status and information |
| status                 | Show interface line status            |
| err-vlans              | Show errored vlans                    |
| <i>__readonly__</i>    | (Optional) Read Only                  |
| <i>interface</i>       | (Optional) Interface index            |
| TABLE_interface        | (Optional) show interface             |
| <i>name</i>            | (Optional) Name                       |
| TABLE_vlan             | (Optional) show vlan                  |
| <i>err_vlan</i>        | (Optional) Errored vlan               |
| <i>err_vlan_status</i> | (Optional) Errored vlan status        |
| <i>err_vlan_syserr</i> | (Optional) Errored vlan syserr name   |

### Command Mode

- /exec

## show interface storm-control multi-threshold

```
show interface storm-control multi-threshold [ __readonly__ TABLE_interface <interface> <eth_ucast_level1>
<eth_ucast_level2> <eth_mcast_level1> <eth_mcast_level2> <eth_bcast_level1> <eth_bcast_level2>
<supp_action1> <supp_action2> ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                      |
| interface               | Show interface status and information                |
| storm-control           | Show interface storm-control counters                |
| multi-threshold         | multi-level storm control                            |
| __readonly__            | (Optional) Read Only                                 |
| <i>interface</i>        | (Optional) Interface index                           |
| TABLE_interface         | (Optional) show interface                            |
| <i>eth_ucast_level1</i> | (Optional) Unicast suppression percentage level 1    |
| <i>eth_ucast_level2</i> | (Optional) Unicast suppression percentage level 2    |
| <i>eth_mcast_level1</i> | (Optional) Multicast suppression percentage level 1  |
| <i>eth_mcast_level2</i> | (Optional) Multicast suppression percentage level 2  |
| <i>eth_bcast_level1</i> | (Optional) Broadcast suppression percentage level 1  |
| <i>eth_bcast_level2</i> | (Optional) Broadcast suppression percentage level 2  |
| <i>supp_action1</i>     | (Optional) Action to be taken on suppression level 1 |
| <i>supp_action2</i>     | (Optional) Action to be taken on suppression level 2 |

### Command Mode

- /exec

## show interface switchport

```
show interface <ifeth_swth> switchport [ __readonly__ TABLE_interface <interface> <switchport> [
<switchport_monitor> ] [ <switchport_isolated> ] [ <switchport_block_multicast> ] [
<switchport_block_unicast> ] [ <oper_mode> ] [ <access_vlan> ] [ <access_vlan_name> ] [ <native_vlan>
] [ <native_vlan_name> ] [ <trunk_vlans> ] [ <fabricpath_topologies> ] [ <pruning_vlans> ] [ <voice_vlan>
] [ <voice_vlan_name> ] [ <extended_trust> ] [ <extended_trust_name> ] [ <admin_pvlan_pri_assoc> ] [
<admin_pvlan_sec_assoc> ] [ <admin_pvlan_pri_mapping> ] [ <admin_pvlan_sec_mapping> ] [
<admin_pvlan_trunk_native> ] [ <admin_pvlan_trunk_encap> ] [ <admin_pvlan_trunk_normal> ] [
<admin_pvlan_trunk_private> ] [ <oper_pvlan> ] [ <autostate_mode> ] [ <encap_vlan> ] [ <provider_vlan>
] ]
```

### Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information                       |
| interface                         | Show interface status and information                 |
| <i>ifeth_swth</i>                 | Enter interface type and number in module/slot format |
| switchport                        | Show interface switchport information                 |
| <u>__readonly__</u>               | (Optional) Read Only                                  |
| <u>TABLE_interface</u>            | (Optional) show interface                             |
| <i>interface</i>                  | (Optional) Interface index                            |
| <i>switchport</i>                 | (Optional) Switchport enabled                         |
| <i>switchport_monitor</i>         | (Optional) Switchport monitor enabled                 |
| <i>switchport_isolated</i>        | (Optional) Switchport isolated enabled                |
| <i>switchport_block_multicast</i> | (Optional) Switchport monitor enabled                 |
| <i>switchport_block_unicast</i>   | (Optional) Switchport monitor enabled                 |
| <i>oper_mode</i>                  | (Optional) Operational mode                           |
| <i>access_vlan</i>                | (Optional) Access mode VLAN                           |
| <i>access_vlan_name</i>           | (Optional) Access mode VLAN name                      |
| <i>native_vlan</i>                | (Optional) Trunking native mode VLAN                  |
| <i>native_vlan_name</i>           | (Optional) Trunking native mode VLAN name             |
| <i>trunk_vlans</i>                | (Optional) Trunking VLANs Allowed                     |
| <i>fabricpath_topologies</i>      | (Optional) FabricPath Topologies Allowed              |
| <i>pruning_vlans</i>              | (Optional) Pruning eligible VLANs                     |

|                                  |   |
|----------------------------------|---|
| <i>voice_vlan</i>                | (Optional) Voice VLAN   |
| <i>voice_vlan_name</i>           | (Optional) Voice VLAN name  |
| <i>extended_trust</i>            | (Optional) Extended Trust   |
| <i>extended_trust_name</i>       | (Optional) Extended Trust name                                    |
| <i>admin_pvlan_pri_assoc</i>     | (Optional) Administrative private-vlan primary host-association   |
| <i>admin_pvlan_sec_assoc</i>     | (Optional) Administrative private-vlan secondary host-association |
| <i>admin_pvlan_pri_mapping</i>   | (Optional) Administrative private-vlan primary mapping            |
| <i>admin_pvlan_sec_mapping</i>   | (Optional) Administrative private-vlan secondary mapping          |
| <i>admin_pvlan_trunk_native</i>  | (Optional) Administrative private-vlan trunk native VLAN          |
| <i>admin_pvlan_trunk_encap</i>   | (Optional) Administrative private-vlan trunk encapsulation        |
| <i>admin_pvlan_trunk_normal</i>  | (Optional) Administrative private-vlan trunk normal VLANs         |
| <i>admin_pvlan_trunk_private</i> | (Optional) Administrative private-vlan trunk private VLANs        |
| <i>oper_pvlan</i>                | (Optional) Operational private-vlan                               |
| <i>autostate_mode</i>            | (Optional) SVI Autostate Exclude Info                             |
| <i>encap_vlan</i>                | (Optional) L2 sub-interface dot1q VLAN                            |
| <i>provider_vlan</i>             | (Optional) L2 sub-interface provider VLAN                         |

**Command Mode**

- /exec

## show interface switchport

```
show interface switchport [ __readonly__ ] TABLE_interface <interface> <switchport> [ <switchport_monitor> ] [ <switchport_isolated> ] [ <switchport_block_multicast> ] [ <switchport_block_unicast> ] [ <mac_learning> ] [ <oper_mode> ] [ <access_vlan> ] [ <access_vlan_name> ] [ <native_vlan> ] [ <native_vlan_name> ] [ <trunk_vlans> ] [ <fabricpath_topologies> ] [ <pruning_vlans> ] [ <voice_vlan> ] [ <voice_vlan_name> ] [ <extended_trust> ] [ <extended_trust_name> ] [ <admin_pvlan_pri_assoc> ] [ <admin_pvlan_sec_assoc> ] [ <admin_pvlan_pri_mapping> ] [ <admin_pvlan_sec_mapping> ] [ <admin_pvlan_trunk_native> ] [ <admin_pvlan_trunk_encap> ] [ <admin_pvlan_trunk_normal> ] [ <admin_pvlan_trunk_private> ] [ <oper_pvlan> ] [ <autostate_mode> ] [ <encap_vlan> ] [ <provider_vlan> ] ]
```

### Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information           |
| interface                         | Show interface status and information     |
| switchport                        | Show interface switchport information     |
| <i>__readonly__</i>               | (Optional) Read Only                      |
| <i>TABLE_interface</i>            | (Optional) show interface                 |
| <i>interface</i>                  | (Optional) Interface index                |
| <i>switchport</i>                 | (Optional) Switchport enabled             |
| <i>switchport_monitor</i>         | (Optional) Switchport monitor enabled     |
| <i>switchport_isolated</i>        | (Optional) Switchport isolated enabled    |
| <i>mac_learning</i>               | (Optional) Mac learning enabled/disabled  |
| <i>switchport_block_multicast</i> | (Optional) Switchport monitor enabled     |
| <i>switchport_block_unicast</i>   | (Optional) Switchport monitor enabled     |
| <i>oper_mode</i>                  | (Optional) Operational mode               |
| <i>access_vlan</i>                | (Optional) Access mode VLAN               |
| <i>access_vlan_name</i>           | (Optional) Access mode VLAN name          |
| <i>native_vlan</i>                | (Optional) Trunking native mode VLAN      |
| <i>native_vlan_name</i>           | (Optional) Trunking native mode VLAN name |
| <i>trunk_vlans</i>                | (Optional) Trunking VLANs Allowed         |
| <i>fabricpath_topologies</i>      | (Optional) FabricPath Topologies Allowed  |
| <i>pruning_vlans</i>              | (Optional) Pruning eligible VLANs         |
| <i>voice_vlan</i>                 | (Optional) Voice VLAN                     |

|                                  |   |
|----------------------------------|---|
| <i>voice_vlan_name</i>           | (Optional) Voice VLAN name  |
| <i>extended_trust</i>            | (Optional) Extended Trust   |
| <i>extended_trust_name</i>       | (Optional) Extended Trust name                                    |
| <i>admin_pvlan_pri_assoc</i>     | (Optional) Administrative private-vlan primary host-association   |
| <i>admin_pvlan_sec_assoc</i>     | (Optional) Administrative private-vlan secondary host-association |
| <i>admin_pvlan_pri_mapping</i>   | (Optional) Administrative private-vlan primary mapping            |
| <i>admin_pvlan_sec_mapping</i>   | (Optional) Administrative private-vlan secondary mapping          |
| <i>admin_pvlan_trunk_native</i>  | (Optional) Administrative private-vlan trunk native VLAN          |
| <i>admin_pvlan_trunk_encap</i>   | (Optional) Administrative private-vlan trunk encapsulation        |
| <i>admin_pvlan_trunk_normal</i>  | (Optional) Administrative private-vlan trunk normal VLANs         |
| <i>admin_pvlan_trunk_private</i> | (Optional) Administrative private-vlan trunk private VLANs        |
| <i>oper_pvlan</i>                | (Optional) Operational private-vlan                               |
| <i>autostate_mode</i>            | (Optional) SVI Autostate Exclude Info                             |
| <i>encap_vlan</i>                | (Optional) L2 sub-interface dot1q VLAN                            |
| <i>provider_vlan</i>             | (Optional) L2 sub-interface provider VLAN                         |

**Command Mode**

- /exec

## show interface switchport backup

```
show interface switchport backup [ detail ][ __readonly__ { TABLE_pair <ai_name> <bi_name> <ai_state>
<bi_state> <ai_prefer> <bi_prefer> <preempt_mode> <delay_value> <delay_default> <delay_scheduled>
<mcast_fast> <ai_bw> <ai_bw_name> <bi_bw> <bi_bw_name> <mmu_primary> } ]
```

### Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                |
| interface       | Show interface status and information          |
| switchport      | Show interface switchport information          |
| backup          | Show interface backup                          |
| detail          | (Optional) Backup interface info in detail     |
| __readonly__    | (Optional) Read Only                           |
| TABLE_pair      | (Optional) Show interface backup               |
| ai_name         | (Optional) Active Interface name               |
| bi_name         | (Optional) Backup Interface name               |
| ai_state        | (Optional) Active Interface state              |
| bi_state        | (Optional) Backup Interface state              |
| ai_prefer       | (Optional) Active Interface prefer VLANs       |
| bi_prefer       | (Optional) Backup Interface prefer VLANs       |
| preempt_mode    | (Optional) Preempt mode                        |
| delay_value     | (Optional) Preempt delay                       |
| delay_default   | (Optional) Preempt delay value is default      |
| delay_scheduled | (Optional) Preemption has been scheduled       |
| mcast_fast      | (Optional) Multicast Fast-Convergence          |
| ai_bw           | (Optional) Active Interface bandwidth          |
| ai_bw_name      | (Optional) Active Interface name for bandwidth |
| bi_bw           | (Optional) Backup Interface bandwidth          |
| bi_bw_name      | (Optional) Backup Interface name for bandwidth |
| mmu_primary     | (Optional) MAC Move Update primary VLAN        |

### Command Mode



- /exec

## show interface transceiver

```
show interface <ifid_trns_fc> transceiver [ calibrations | details ] [ __readonly__ TABLE_interface
<interface_fc> [ <sfp_fc> ] [ <type_fc> ] [ <name_fc> ] [ <partnum_fc> ] [ <rev_fc> ] [ <serialnum_fc> ] [
<cisco_partnum_fc> ] [ <cisco_pid_fc> ] [ <tx_type_fc> ] [ <tx_len_fc> ] [ <tx_medium_fc> ] [ <tx_speeds_fc> ] [
] [ <nom_bitrate_fc> ] [ <len_9_fc> ] [ <len_50_fc> ] [ <len_625_fc> ] [ <len_50_OM3_fc> ] [
<cisco_ext_id_fc> ] [ <txcvr_type_fc> ] [ <connector_type_fc> ] [ <bit_encoding_fc> ] [ <protocol_type_fc> ] [
] [ <10gbe_code_fc> ] [ <fiber_type_byte0_fc> ] [ <fiber_type_byte1_fc> ] [ <tx_range_fc> ] [
<temp_slope_fc> ] [ <temp_offset_fc> ] [ <volt_slope_fc> ] [ <volt_offset_fc> ] [ <curr_slope_fc> ] [
<curr_offset_fc> ] [ <tx_pwr_slope_fc> ] [ <tx_pwr_offset_fc> ] [ <rx_pwr_4_fc> ] [ <rx_pwr_3_fc> ] [
<rx_pwr_2_fc> ] [ <rx_pwr_1_fc> ] [ <rx_pwr_0_fc> ] [ <temperature_fc> ] [ <temp_flag_fc> ] [
<temp_alarm_hi_fc> ] [ <temp_alarm_lo_fc> ] [ <temp_warn_hi_fc> ] [ <temp_warn_lo_fc> ] [ <voltage_fc> ] [
] [ <volt_flag_fc> ] [ <volt_alarm_hi_fc> ] [ <volt_alarm_lo_fc> ] [ <volt_warn_hi_fc> ] [ <volt_warn_lo_fc> ] [
] [ <current_fc> ] [ <current_flag_fc> ] [ <current_alarm_hi_fc> ] [ <current_alarm_lo_fc> ] [
<current_warn_hi_fc> ] [ <current_warn_lo_fc> ] [ <tx_pwr_fc> ] [ <tx_pwr_flag_fc> ] [ <tx_pwr_alarm_hi_fc> ] [
] [ <tx_pwr_alarm_lo_fc> ] [ <tx_pwr_warn_hi_fc> ] [ <tx_pwr_warn_lo_fc> ] [ <rx_pwr_fc> ] [
<rx_pwr_flag_fc> ] [ <rx_pwr_alarm_hi_fc> ] [ <rx_pwr_alarm_lo_fc> ] [ <rx_pwr_warn_hi_fc> ] [
<rx_pwr_warn_lo_fc> ] [ <xmit_faults_fc> ] [ <sfp_calibration> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                               |
| interface               | Show interface status and information                         |
| <i>ifid_trns_fc</i>     | Enter interface type and number in module/slot format         |
| transceiver             | Show interface transceiver information                        |
| calibrations            | (Optional) Show interface transceiver calibration information |
| details                 | (Optional) Show interface transceiver detail information      |
| __readonly__            | (Optional) Read Only  |
| <i>interface_fc</i>     | (Optional) Interface index                                    |
| TABLE_interface         | (Optional) show interface                                     |
| <i>sfp_fc</i>           | (Optional) sfp  |
| <i>type_fc</i>          | (Optional) type   |
| <i>name_fc</i>          | (Optional) Name   |
| <i>partnum_fc</i>       | (Optional) part number  |
| <i>rev_fc</i>           | (Optional) revision   |
| <i>serialnum_fc</i>     | (Optional) serial number                                      |
| <i>cisco_partnum_fc</i> | (Optional) Cisco part number                                  |
| <i>cisco_pid_fc</i>     | (Optional) Cisco PID  |

|                            |  |
|----------------------------|--|
| <i>tx_type_fc</i>          | (Optional) FC Transmitter type                           |
| <i>tx_len_fc</i>           | (Optional) FC Transmitter length                         |
| <i>tx_medium_fc</i>        | (Optional) FC Transmitter medium                         |
| <i>tx_speeds_fc</i>        | (Optional) Transmission speeds                           |
| <i>nom_bitrate_fc</i>      | (Optional) Nominal bit rate in MBits/sec                 |
| <i>len_9_fc</i>            | (Optional) Link length supported for 9/125um fiber       |
| <i>len_50_fc</i>           | (Optional) Link length supported for 50/125um fiber      |
| <i>len_625_fc</i>          | (Optional) Link length supported for 62.5/125um fiber    |
| <i>len_50_OM3_fc</i>       | (Optional) Link length supported for 50/125um fiber in m |
| <i>cisco_ext_id_fc</i>     | (Optional) Cisco extended ID                             |
| <i>txcvr_type_fc</i>       | (Optional) Transceiver type                              |
| <i>connector_type_fc</i>   | (Optional) Connector type                                |
| <i>bit_encoding_fc</i>     | (Optional) Bit encoding                                  |
| <i>protocol_type_fc</i>    | (Optional) Protocol type                                 |
| <i>10gbe_code_fc</i>       | (Optional) 10GbE code byte                               |
| <i>fiber_type_byte0_fc</i> | (Optional) Fiber Type Byte 0                             |
| <i>fiber_type_byte1_fc</i> | (Optional) Fiber Type Byte 1                             |
| <i>tx_range_fc</i>         | (Optional) Transmission Range                            |
| <i>temp_slope_fc</i>       | (Optional) Temperature slope                             |
| <i>temp_offset_fc</i>      | (Optional) Temperature offset                            |
| <i>volt_slope_fc</i>       | (Optional) Voltage slope                                 |
| <i>volt_offset_fc</i>      | (Optional) Voltage offset                                |
| <i>curr_slope_fc</i>       | (Optional) Current slope                                 |
| <i>curr_offset_fc</i>      | (Optional) Current offset                                |
| <i>tx_pwr_slope_fc</i>     | (Optional) Tx power slope                                |
| <i>tx_pwr_offset_fc</i>    | (Optional) Tx power offset                               |
| <i>rx_pwr_4_fc</i>         | (Optional) Rx power 4                                    |
| <i>rx_pwr_3_fc</i>         | (Optional) Rx power 3                                    |
| <i>rx_pwr_2_fc</i>         | (Optional) Rx power 2                                    |

|                            |                                     |
|----------------------------|-------------------------------------|
| <i>rx_pwr_1_fc</i>         | (Optional) Rx power 1               |
| <i>rx_pwr_0_fc</i>         | (Optional) Rx power 0               |
| <i>temperature_fc</i>      | (Optional) Temperature              |
| <i>temp_flag_fc</i>        | (Optional) Temperature Flag         |
| <i>temp_alarm_hi_fc</i>    | (Optional) Temperature Alarm High   |
| <i>temp_alarm_lo_fc</i>    | (Optional) Temperature Alarm Low    |
| <i>temp_warn_hi_fc</i>     | (Optional) Temperature Warning High |
| <i>temp_warn_lo_fc</i>     | (Optional) Temperature Warning Low  |
| <i>voltage_fc</i>          | (Optional) Voltage                  |
| <i>volt_flag_fc</i>        | (Optional) Voltage Flag             |
| <i>volt_alarm_hi_fc</i>    | (Optional) Voltage Alarm High       |
| <i>volt_alarm_lo_fc</i>    | (Optional) Voltage Alarm Low        |
| <i>volt_warn_hi_fc</i>     | (Optional) Voltage Warning High     |
| <i>volt_warn_lo_fc</i>     | (Optional) Voltage Warning Low      |
| <i>current_fc</i>          | (Optional) Current                  |
| <i>current_flag_fc</i>     | (Optional) Current Flag             |
| <i>current_alarm_hi_fc</i> | (Optional) Current Alarm High       |
| <i>current_alarm_lo_fc</i> | (Optional) Current Alarm Low        |
| <i>current_warn_hi_fc</i>  | (Optional) Current Warning High     |
| <i>current_warn_lo_fc</i>  | (Optional) Current Warning Low      |
| <i>tx_pwr_fc</i>           | (Optional) Tx Power                 |
| <i>tx_pwr_flag_fc</i>      | (Optional) Tx Power Flag            |
| <i>tx_pwr_alarm_hi_fc</i>  | (Optional) Tx Power Alarm High      |
| <i>tx_pwr_alarm_lo_fc</i>  | (Optional) Tx Power Alarm Low       |
| <i>tx_pwr_warn_hi_fc</i>   | (Optional) Tx Power Warning High    |
| <i>tx_pwr_warn_lo_fc</i>   | (Optional) Tx Power Warning Low     |
| <i>rx_pwr_fc</i>           | (Optional) Rx Power                 |
| <i>rx_pwr_flag_fc</i>      | (Optional) Rx Power Flag            |
| <i>rx_pwr_alarm_hi_fc</i>  | (Optional) Rx Power Alarm High      |

|                          |  |
|--------------------------|--|
| <i>rx_pwr_alrm_lo_fc</i> | (Optional) Rx Power Alarm Low                            |
| <i>rx_pwr_warn_hi_fc</i> | (Optional) Rx Power Warning High                         |
| <i>rx_pwr_warn_lo_fc</i> | (Optional) Rx Power Warning Low                          |
| <i>xmit_faults_fc</i>    | (Optional) Transmit Fault Count                          |
| <i>sfp_calibration</i>   | (Optional) Checking whether sfp is internally calibrated |

**Command Mode**

- /exec

## show interface transceiver

```
show interface transceiver [ calibrations | details ] [ __readonly__ TABLE_interface <interface> [ <sf> ] [
<qsf> ] [ <type> ] [ <name> ] [ <partnum> ] [ <rev> ] [ <serialnum> ] [ <nom_bitrate> ] [ <len_9>
] [ <len_50> ] [ <len_625> ] [ <len_cu> ] [ <len_50_OM3> ] [ <txcvr_type> ] [ <connector_type> ] [
<bit_encoding> ] [ <protocol_type> ] [ <10gbe_code> ] [ <fiber_type_byte0> ] [ <fiber_type_byte1> ] [
<tx_type> ] [ <tx_len> ] [ <tx_medium> ] [ <tx_speeds> ] [ <tx_range> ] [ <cable_type> ] [ <ciscoid> ] [
<ciscoid_1> ] [ <cisco_part_number> ] [ <cisco_product_id> ] [ <cisco_vendor_id> ] [ <cisco_ext_id> ] [
<info_not_available> ] [ <temp_slope> ] [ <temp_offset> ] [ <volt_slope> ] [ <volt_offset> ] [ <curr_slope>
] [ <curr_offset> ] [ <tx_pwr_slope> ] [ <tx_pwr_offset> ] [ <rx_pwr_4> ] [ <rx_pwr_3> ] [ <rx_pwr_2> ] [
<rx_pwr_1> ] [ <rx_pwr_0> ] [ TABLE_lane [ <lane_number> ] [ <temperature> ] [ <temp_flag> ] [
<temp_alm_hi> ] [ <temp_alm_lo> ] [ <temp_warn_hi> ] [ <temp_warn_lo> ] [ <voltage> ] [ <volt_flag>
] [ <volt_alm_hi> ] [ <volt_alm_lo> ] [ <volt_warn_hi> ] [ <volt_warn_lo> ] [ <current> ] [ <current_flag>
] [ <current_alm_hi> ] [ <current_alm_lo> ] [ <current_warn_hi> ] [ <current_warn_lo> ] [ <tx_pwr> ] [
<tx_pwr_flag> ] [ <tx_pwr_alm_hi> ] [ <tx_pwr_alm_lo> ] [ <tx_pwr_warn_hi> ] [ <tx_pwr_warn_lo> ]
] [ <rx_pwr> ] [ <rx_pwr_flag> ] [ <rx_pwr_alm_hi> ] [ <rx_pwr_alm_lo> ] [ <rx_pwr_warn_hi> ] [
<rx_pwr_warn_lo> ] [ <xmit_faults> ] [ <snr> ] [ <snr_flag> ] [ <snr_alm_hi> ] [ <snr_alm_lo> ] [
<snr_warn_hi> ] [ <snr_warn_lo> ] [ <isi> ] [ <isi_flag> ] [ <isi_alm_hi> ] [ <isi_alm_lo> ] [ <isi_warn_hi>
] [ <isi_warn_lo> ] [ <pam> ] [ <pam_flag> ] [ <pam_alm_hi> ] [ <pam_alm_lo> ] [ <pam_warn_hi> ] [
<pam_warn_lo> ] [ <pre_fec_ber> ] [ <pre_fec_ber_flag> ] [ <pre_fec_ber_alm_hi> ] [ <pre_fec_ber_alm_lo>
] [ <pre_fec_ber_warn_hi> ] [ <pre_fec_ber_warn_lo> ] [ <uncorrect_ber> ] [ <uncorrect_ber_flag> ] [
<uncorrect_ber_alm_hi> ] [ <uncorrect_ber_alm_lo> ] [ <uncorrect_ber_warn_hi> ] [
<uncorrect_ber_warn_lo> ] [ <tec_current> ] [ <tec_current_flag> ] [ <tec_current_alm_hi> ] [
<tec_current_alm_lo> ] [ <tec_current_warn_hi> ] [ <tec_current_warn_lo> ] [ <laser_freq> ] [
<laser_freq_flag> ] [ <laser_freq_alm_hi> ] [ <laser_freq_alm_lo> ] [ <laser_freq_warn_hi> ] [
<laser_freq_warn_lo> ] [ <laser_temp> ] [ <laser_temp_flag> ] [ <laser_temp_alm_hi> ] [
<laser_temp_alm_lo> ] [ <laser_temp_warn_hi> ] [ <laser_temp_warn_lo> ] [ <pre_fec_ber_acc> ] [
<pre_fec_ber_acc_flag> ] [ <pre_fec_ber_acc_alm_hi> ] [ <pre_fec_ber_acc_alm_lo> ] [
<pre_fec_ber_acc_warn_hi> ] [ <pre_fec_ber_acc_warn_lo> ] [ <pre_fec_ber_min> ] [ <pre_fec_ber_min_flag>
] [ <pre_fec_ber_min_alm_hi> ] [ <pre_fec_ber_min_alm_lo> ] [ <pre_fec_ber_min_warn_hi> ] [
<pre_fec_ber_min_warn_lo> ] [ <pre_fec_ber_max> ] [ <pre_fec_ber_max_flag> ] [
<pre_fec_ber_max_alm_hi> ] [ <pre_fec_ber_max_alm_lo> ] [ <pre_fec_ber_max_warn_hi> ] [
<pre_fec_ber_max_warn_lo> ] [ <pre_fec_ber_cur> ] [ <pre_fec_ber_cur_flag> ] [ <pre_fec_ber_cur_alm_hi>
] [ <pre_fec_ber_cur_alm_lo> ] [ <pre_fec_ber_cur_warn_hi> ] [ <pre_fec_ber_cur_warn_lo> ] [
<uncorrect_ber_acc> ] [ <uncorrect_ber_acc_flag> ] [ <uncorrect_ber_acc_alm_hi> ] [
<uncorrect_ber_acc_alm_lo> ] [ <uncorrect_ber_acc_warn_hi> ] [ <uncorrect_ber_acc_warn_lo> ] [
<uncorrect_ber_min> ] [ <uncorrect_ber_min_flag> ] [ <uncorrect_ber_min_alm_hi> ] [
<uncorrect_ber_min_alm_lo> ] [ <uncorrect_ber_min_warn_hi> ] [ <uncorrect_ber_min_warn_lo> ] [
<uncorrect_ber_max> ] [ <uncorrect_ber_max_flag> ] [ <uncorrect_ber_max_alm_hi> ] [
<uncorrect_ber_max_alm_lo> ] [ <uncorrect_ber_max_warn_hi> ] [ <uncorrect_ber_max_warn_lo> ] [
<uncorrect_ber_cur> ] [ <uncorrect_ber_cur_flag> ] [ <uncorrect_ber_cur_alm_hi> ] [
<uncorrect_ber_cur_alm_lo> ] [ <uncorrect_ber_cur_warn_hi> ] [ <uncorrect_ber_cur_warn_lo> ] ] ] ]
```

### Syntax Description

|             |  |
|-------------|--|
| show        | Show running system information        |
| interface   | Show interface status and information  |
| transceiver | Show interface transceiver information |

|                         |   |
|-------------------------|---|
| <i>calibrations</i>     | (Optional) Show interface transceiver calibration information |
| <i>details</i>          | (Optional) Show interface transceiver detail information      |
| <i>__readonly__</i>     | (Optional) Read Only  |
| <i>interface</i>        | (Optional) Interface index                                    |
| TABLE_ <i>interface</i> | (Optional) show interface                                     |
| <i>sfp</i>              | (Optional) sfp  |
| <i>qsfp_or_cfp</i>      | (Optional) qsfp_or_cfp  |
| <i>type</i>             | (Optional) type   |
| <i>name</i>             | (Optional) Name   |
| <i>partnum</i>          | (Optional) part number  |
| <i>rev</i>              | (Optional) revision   |
| <i>serialnum</i>        | (Optional) serial number                                      |
| <i>nom_bitrate</i>      | (Optional) Nominal bit rate in MBits/sec                      |
| <i>len_9</i>            | (Optional) Link length supported for 9/125um fiber            |
| <i>len_50</i>           | (Optional) Link length supported for 50/125um fiber           |
| <i>len_625</i>          | (Optional) Link length supported for 62.5/125um fiber         |
| <i>len_cu</i>           | (Optional) Link length supported for copper                   |
| <i>len_50_OM3</i>       | (Optional) Link length supported for 50/125um fiber in m      |
| <i>txcvr_type</i>       | (Optional)  |
| <i>connector_type</i>   | (Optional)  |
| <i>bit_encoding</i>     | (Optional)  |
| <i>protocol_type</i>    | (Optional)  |
| <i>10gbe_code</i>       | (Optional)  |
| <i>fiber_type_byte0</i> | (Optional)  |
| <i>fiber_type_byte1</i> | (Optional)  |
| <i>tx_type</i>          | (Optional) FC Transmitter type                                |
| <i>tx_len</i>           | (Optional) FC Transmitter length                              |
| <i>tx_medium</i>        | (Optional) FC Transmitter medium                              |
| <i>tx_speeds</i>        | (Optional) Transmission speeds                                |

|                           |   |
|---------------------------|---|
| <i>tx_range</i>           | (Optional) Transmission range                     |
| <i>cable_type</i>         | (Optional)  |
| <i>ciscoid</i>            | (Optional) Cisco extended id                      |
| <i>ciscoid_1</i>          | (Optional) Cisco extended id number               |
| <i>cisco_part_number</i>  | (Optional) Cisco part number                      |
| <i>cisco_product_id</i>   | (Optional) Cisco product identifier               |
| <i>cisco_vendor_id</i>    | (Optional) Cisco vendor identifier                |
| <i>cisco_ext_id</i>       | (Optional) Cisco extended ID                      |
| <i>info_not_available</i> | (Optional) No info available for this transceiver |
| <i>temp_slope</i>         | (Optional) Temperature slope                      |
| <i>temp_offset</i>        | (Optional) Temperature offset                     |
| <i>volt_slope</i>         | (Optional) Voltage slope                          |
| <i>volt_offset</i>        | (Optional) Voltage offset                         |
| <i>curr_slope</i>         | (Optional) Current slope                          |
| <i>curr_offset</i>        | (Optional) Current offset                         |
| <i>tx_pwr_slope</i>       | (Optional) Tx power slope                         |
| <i>tx_pwr_offset</i>      | (Optional) Tx power offset                        |
| <i>rx_pwr_4</i>           | (Optional) Rx power 4                             |
| <i>rx_pwr_3</i>           | (Optional) Rx power 3                             |
| <i>rx_pwr_2</i>           | (Optional) Rx power 2                             |
| <i>rx_pwr_1</i>           | (Optional) Rx power 1                             |
| <i>rx_pwr_0</i>           | (Optional) Rx power 0                             |
| TABLE_lane                | (Optional) show lane                              |
| <i>lane_number</i>        | (Optional) Lane number                            |
| <i>temperature</i>        | (Optional) Temperature                            |
| <i>temp_flag</i>          | (Optional) Temperature Flag                       |
| <i>temp_alarm_hi</i>      | (Optional) Temperature Alarm High                 |
| <i>temp_alarm_lo</i>      | (Optional) Temperature Alarm Low                  |
| <i>temp_warn_hi</i>       | (Optional) Temperature Warning High               |



|                        |   |
|------------------------|---|
| <i>temp_warn_lo</i>    | (Optional) Temperature Warning Low        |
| <i>voltage</i>         | (Optional) Voltage                        |
| <i>volt_flag</i>       | (Optional) Voltage Flag                   |
| <i>volt_alm_hi</i>     | (Optional) Voltage Alarm High             |
| <i>volt_alm_lo</i>     | (Optional) Voltage Alarm Low              |
| <i>volt_warn_hi</i>    | (Optional) Voltage Warning High           |
| <i>volt_warn_lo</i>    | (Optional) Voltage Warning Low            |
| <i>current</i>         | (Optional) Current                        |
| <i>current_flag</i>    | (Optional) Current Flag                   |
| <i>current_alm_hi</i>  | (Optional) Current Alarm High             |
| <i>current_alm_lo</i>  | (Optional) Current Alarm Low              |
| <i>current_warn_hi</i> | (Optional) Current Warning High           |
| <i>current_warn_lo</i> | (Optional) Current Warning Low            |
| <i>tx_pwr</i>          | (Optional) Tx Power                       |
| <i>tx_pwr_flag</i>     | (Optional) Tx Power Flag                  |
| <i>tx_pwr_alm_hi</i>   | (Optional) Tx Power Alarm High            |
| <i>tx_pwr_alm_lo</i>   | (Optional) Tx Power Alarm Low             |
| <i>tx_pwr_warn_hi</i>  | (Optional) Tx Power Warning High          |
| <i>tx_pwr_warn_lo</i>  | (Optional) Tx Power Warning Low           |
| <i>rx_pwr</i>          | (Optional) Rx Power                       |
| <i>rx_pwr_flag</i>     | (Optional) Rx Power Flag                  |
| <i>rx_pwr_alm_hi</i>   | (Optional) Rx Power Alarm High            |
| <i>rx_pwr_alm_lo</i>   | (Optional) Rx Power Alarm Low             |
| <i>rx_pwr_warn_hi</i>  | (Optional) Rx Power Warning High          |
| <i>rx_pwr_warn_lo</i>  | (Optional) Rx Power Warning Low           |
| <i>xmit_faults</i>     | (Optional) Transmit Fault Count           |
| <i>snr</i>             | (Optional) RX Signal-to-Noise Ratio (SNR) |
| <i>snr_flag</i>        | (Optional) SNR Flag                       |
| <i>snr_alm_hi</i>      | (Optional) SNR Alarm High                 |

|                              |   |
|------------------------------|---|
| <i>snr_alm_lo</i>            | (Optional) SNR Alarm Low                |
| <i>snr_warn_hi</i>           | (Optional) SNR Warning High             |
| <i>snr_warn_lo</i>           | (Optional) SNR Warning Low              |
| <i>isi</i>                   | (Optional) Residual-Dispersion(ISI)     |
| <i>isi_flag</i>              | (Optional) ISI Flag                     |
| <i>isi_alm_hi</i>            | (Optional) ISI alarm high               |
| <i>isi_alm_lo</i>            | (Optional) ISI alarm low                |
| <i>isi_warn_hi</i>           | (Optional) ISI warning high             |
| <i>isi_warn_lo</i>           | (Optional) ISI warning low              |
| <i>pam</i>                   | (Optional) PAM Transition               |
| <i>pam_flag</i>              | (Optional) PAM Flag                     |
| <i>pam_alm_hi</i>            | (Optional) PAM alarm high               |
| <i>pam_alm_lo</i>            | (Optional) PAM alarm low                |
| <i>pam_warn_hi</i>           | (Optional) PAM warning high             |
| <i>pam_warn_lo</i>           | (Optional) PAM warning low              |
| <i>pre_fec_ber</i>           | (Optional) Pre-FEC BER                  |
| <i>pre_fec_ber_flag</i>      | (Optional) Pre-FEC BER flag             |
| <i>pre_fec_ber_alm_hi</i>    | (Optional) Pre-FEC BER alarm high       |
| <i>pre_fec_ber_alm_lo</i>    | (Optional) Pre-FEC BER alarm low        |
| <i>pre_fec_ber_warn_hi</i>   | (Optional) Pre-FEC BER warning high     |
| <i>pre_fec_ber_warn_lo</i>   | (Optional) Pre-FEC BER warning low      |
| <i>uncorrect_ber</i>         | (Optional) Uncorrected BER              |
| <i>uncorrect_ber_flag</i>    | (Optional) Uncorrected BER flag         |
| <i>uncorrect_ber_alm_hi</i>  | (Optional) Uncorrected BER alarm high   |
| <i>uncorrect_ber_alm_lo</i>  | (Optional) Uncorrected BER alarm low    |
| <i>uncorrect_ber_warn_hi</i> | (Optional) Uncorrected BER warning high |
| <i>uncorrect_ber_warn_lo</i> | (Optional) Uncorrected BER warning low  |
| <i>tec_current</i>           | (Optional) TEC Current                  |
| <i>tec_current_flag</i>      | (Optional) TEC Current flag             |

|                                |   |
|--------------------------------|---|
| <i>tec_current_alrm_hi</i>     | (Optional) TEC Current Alarm High         |
| <i>tec_current_alrm_lo</i>     | (Optional) TEC Current Alarm Low          |
| <i>tec_current_warn_hi</i>     | (Optional) TEC Current Warning High       |
| <i>tec_current_warn_lo</i>     | (Optional) TEC Current Warning Low        |
| <i>laser_freq</i>              | (Optional) Laser Frequency                |
| <i>laser_freq_flag</i>         | (Optional) Laser Frequency flag           |
| <i>laser_freq_alrm_hi</i>      | (Optional) Laser Frequency Alarm High     |
| <i>laser_freq_alrm_lo</i>      | (Optional) Laser Frequency Alarm Low      |
| <i>laser_freq_warn_hi</i>      | (Optional) Laser Frequency Warning High   |
| <i>laser_freq_warn_lo</i>      | (Optional) Laser Frequency Warning Low    |
| <i>laser_temp</i>              | (Optional) Laser Temperature              |
| <i>laser_temp_flag</i>         | (Optional) Laser Temperature flag         |
| <i>laser_temp_alrm_hi</i>      | (Optional) Laser Temperature Alarm High   |
| <i>laser_temp_alrm_lo</i>      | (Optional) Laser Temperature Alarm Low    |
| <i>laser_temp_warn_hi</i>      | (Optional) Laser Temperature Warning High |
| <i>laser_temp_warn_lo</i>      | (Optional) Laser Temperature Warning Low  |
| <i>pre_fec_ber_acc</i>         | (Optional) Pre-FEC BER Acc                |
| <i>pre_fec_ber_acc_flag</i>    | (Optional) Pre-FEC BER Acc flag           |
| <i>pre_fec_ber_acc_alrm_hi</i> | (Optional) Pre-FEC BER Acc alarm high     |
| <i>pre_fec_ber_acc_alrm_lo</i> | (Optional) Pre-FEC BER Acc alarm low      |
| <i>pre_fec_ber_acc_warn_hi</i> | (Optional) Pre-FEC BER Acc warning high   |
| <i>pre_fec_ber_acc_warn_lo</i> | (Optional) Pre-FEC BER Acc warning low    |
| <i>pre_fec_ber_min</i>         | (Optional) Pre-FEC BER Min                |
| <i>pre_fec_ber_min_flag</i>    | (Optional) Pre-FEC BER Min flag           |
| <i>pre_fec_ber_min_alrm_hi</i> | (Optional) Pre-FEC BER Min alarm high     |
| <i>pre_fec_ber_min_alrm_lo</i> | (Optional) Pre-FEC BER Min alarm low      |
| <i>pre_fec_ber_min_warn_hi</i> | (Optional) Pre-FEC BER Min warning high   |
| <i>pre_fec_ber_min_warn_lo</i> | (Optional) Pre-FEC BER Min warning low    |
| <i>pre_fec_ber_max</i>         | (Optional) Pre-FEC BER Max                |

|                                  |   |
|----------------------------------|---|
| <i>pre_fec_ber_max_flag</i>      | (Optional) Pre-FEC BER Max flag             |
| <i>pre_fec_ber_max_alrm_hi</i>   | (Optional) Pre-FEC BER Max alarm high       |
| <i>pre_fec_ber_max_alrm_lo</i>   | (Optional) Pre-FEC BER Max alarm low        |
| <i>pre_fec_ber_max_warn_hi</i>   | (Optional) Pre-FEC BER Max warning high     |
| <i>pre_fec_ber_max_warn_lo</i>   | (Optional) Pre-FEC BER Max warning low      |
| <i>pre_fec_ber_cur</i>           | (Optional) Pre-FEC BER Cur                  |
| <i>pre_fec_ber_cur_flag</i>      | (Optional) Pre-FEC BER Cur flag             |
| <i>pre_fec_ber_cur_alrm_hi</i>   | (Optional) Pre-FEC BER Cur alarm high       |
| <i>pre_fec_ber_cur_alrm_lo</i>   | (Optional) Pre-FEC BER Cur alarm low        |
| <i>pre_fec_ber_cur_warn_hi</i>   | (Optional) Pre-FEC BER Cur warning high     |
| <i>pre_fec_ber_cur_warn_lo</i>   | (Optional) Pre-FEC BER Cur warning low      |
| <i>uncorrect_ber_acc</i>         | (Optional) Uncorrected BER Acc              |
| <i>uncorrect_ber_acc_flag</i>    | (Optional) Uncorrected BER Acc flag         |
| <i>uncorrect_ber_acc_alrm_hi</i> | (Optional) Uncorrected BER Acc alarm high   |
| <i>uncorrect_ber_acc_alrm_lo</i> | (Optional) Uncorrected BER Acc alarm low    |
| <i>uncorrect_ber_acc_warn_hi</i> | (Optional) Uncorrected BER Acc warning high |
| <i>uncorrect_ber_acc_warn_lo</i> | (Optional) Uncorrected BER Acc warning low  |
| <i>uncorrect_ber_min</i>         | (Optional) Uncorrected BER Min              |
| <i>uncorrect_ber_min_flag</i>    | (Optional) Uncorrected BER Min flag         |
| <i>uncorrect_ber_min_alrm_hi</i> | (Optional) Uncorrected BER Min alarm high   |
| <i>uncorrect_ber_min_alrm_lo</i> | (Optional) Uncorrected BER Min alarm low    |
| <i>uncorrect_ber_min_warn_hi</i> | (Optional) Uncorrected BER Min warning high |
| <i>uncorrect_ber_min_warn_lo</i> | (Optional) Uncorrected BER Min warning low  |
| <i>uncorrect_ber_max</i>         | (Optional) Uncorrected BER Max              |
| <i>uncorrect_ber_max_flag</i>    | (Optional) Uncorrected BER Max flag         |
| <i>uncorrect_ber_max_alrm_hi</i> | (Optional) Uncorrected BER Max alarm high   |
| <i>uncorrect_ber_max_alrm_lo</i> | (Optional) Uncorrected BER Max alarm low    |
| <i>uncorrect_ber_max_warn_hi</i> | (Optional) Uncorrected BER Max warning high |
| <i>uncorrect_ber_max_warn_lo</i> | (Optional) Uncorrected BER Max warning low  |

|                                  |   |
|----------------------------------|---|
| <i>uncorrect_ber_cur</i>         | (Optional) Uncorrected BER Cur              |
| <i>uncorrect_ber_cur_flag</i>    | (Optional) Uncorrected BER Cur flag         |
| <i>uncorrect_ber_cur_alm_hi</i>  | (Optional) Uncorrected BER Cur alarm high   |
| <i>uncorrect_ber_cur_alm_lo</i>  | (Optional) Uncorrected BER Cur alarm low    |
| <i>uncorrect_ber_cur_warn_hi</i> | (Optional) Uncorrected BER Cur warning high |
| <i>uncorrect_ber_cur_warn_lo</i> | (Optional) Uncorrected BER Cur warning low  |

**Command Mode**

- /exec

## show interface transceiver

```

show interface <ifid_transceiver> transceiver [ calibrations | details | sprom ] [ __readonly__ TABLE_interface
<interface> [ <sfp> ] [ <qsfp_or_cfp> ] [ <type> ] [ <name> ] [ <partnum> ] [ <rev> ] [ <serialnum> ] [
<nom_bitrate> ] [ <len_9> ] [ <len_9_2> ] [ <len_50> ] [ <len_625> ] [ <len_cu> ] [ <len_50_OM3> ] [
<txcvr_type> ] [ <connector_type> ] [ <bit_encoding> ] [ <protocol_type> ] [ <10gbe_code> ] [
<fiber_type_byte0> ] [ <fiber_type_byte1> ] [ <tx_range> ] [ <cable_type> ] [ <ciscoid> ] [ <ciscoid_1> ] [
<cisco_part_number> ] [ <cisco_product_id> ] [ <cisco_version_id> ] [ <cisco_vendor_id> ] [
<firmware_version> ] [ <cmis_version> ] [ <identifier> ] [ <ext_identifier> ] [ <connector> ] [
<infiniband_compliance_code> ] [ <sonet_compliance_code> ] [ <gigabit_ethernet_compliance_code> ] [
<fibre_chan_link_length> ] [ <fibre_chan_trans_technology> ] [ <fibre_chan_trans_tech_reserved> ] [
<fibre_chan_transmission_media> ] [ <fibre_chan_speed> ] [ <encoding> ] [ <br_nominal> ] [ <reserved1>
] [ <length_smf> ] [ <length_om5> ] [ <length_om4> ] [ <length_om3> ] [ <length_om2> ] [ <length_om1>
] [ <length_9u_1> ] [ <length_9u_2> ] [ <length_50u> ] [ <length_60u> ] [ <length_copper> ] [ <reserved3>
] [ <wave_length> ] [ <wave_len_tolerance> ] [ <vendor_oui> ] [ <vendor_part_no> ] [ <vendor_revision>
] [ <reserved4> ] [ <check_code_id> ] [ <options> ] [ <br_max> ] [ <br_min> ] [ <vendor_serial_no> ] [
<data_code> ] [ <diagnostic_monitoring_type> ] [ <enhanced_options> ] [ <sff8472compliance> ] [
<check_code_ext> ] [ <vendor_specific_data_id_data> ] [ <date_code> ] [ <clei_code> ] [ <power_class> ]
[ <max_power> ] [ <cable_attenuation> ] [ <near_end_lanes> ] [ <far_end_lanes> ] [ <media_interface> ] [
<adv_code> ] [ <host_elt_intf_code> ] [ <med_intf_adv_code> ] [ <cable_length> ] [ <host_lane_count> ] [
<med_lane_count> ] [ <max_mod_temp> ] [ <min_mod_temp> ] [ <min_op_volt> ] [ <info_not_available>
] [ <temp_slope> ] [ <temp_offset> ] [ <volt_slope> ] [ <volt_offset> ] [ <curr_slope> ] [ <curr_offset> ] [
<tx_pwr_slope> ] [ <tx_pwr_offset> ] [ <rx_pwr_4> ] [ <rx_pwr_3> ] [ <rx_pwr_2> ] [ <rx_pwr_1> ] [
<rx_pwr_0> ] [ TABLE_lane [ <lane_number> ] [ <temperature> ] [ <temp_flag> ] [ <temp_alm_hi> ] [
<temp_alm_lo> ] [ <temp_warn_hi> ] [ <temp_warn_lo> ] [ <voltage> ] [ <volt_flag> ] [ <volt_alm_hi> ] [
<volt_alm_lo> ] [ <volt_warn_hi> ] [ <volt_warn_lo> ] [ <current> ] [ <current_flag> ] [ <current_alm_hi> ] [
<current_alm_lo> ] [ <current_warn_hi> ] [ <current_warn_lo> ] [ <tx_pwr> ] [ <tx_pwr_flag> ] [
<tx_pwr_alm_hi> ] [ <tx_pwr_alm_lo> ] [ <tx_pwr_warn_hi> ] [ <tx_pwr_warn_lo> ] [ <rx_pwr> ] [
<rx_pwr_flag> ] [ <rx_pwr_alm_hi> ] [ <rx_pwr_alm_lo> ] [ <rx_pwr_warn_hi> ] [ <rx_pwr_warn_lo> ]
] [ <xmit_faults> ] [ <snr> ] [ <snr_flag> ] [ <snr_alm_hi> ] [ <snr_alm_lo> ] [ <snr_warn_hi> ] [
<snr_warn_lo> ] [ <isi> ] [ <isi_flag> ] [ <isi_alm_hi> ] [ <isi_alm_lo> ] [ <isi_warn_hi> ] [ <isi_warn_lo>
] [ <pam> ] [ <pam_flag> ] [ <pam_alm_hi> ] [ <pam_alm_lo> ] [ <pam_warn_hi> ] [ <pam_warn_lo> ] [
<pre_fec_ber> ] [ <pre_fec_ber_flag> ] [ <pre_fec_ber_alm_hi> ] [ <pre_fec_ber_alm_lo> ] [
<pre_fec_ber_warn_hi> ] [ <pre_fec_ber_warn_lo> ] [ <uncorrect_ber> ] [ <uncorrect_ber_flag> ] [
<uncorrect_ber_alm_hi> ] [ <uncorrect_ber_alm_lo> ] [ <uncorrect_ber_warn_hi> ] [
<uncorrect_ber_warn_lo> ] [ <tec_current> ] [ <tec_current_flag> ] [ <tec_current_alm_hi> ] [
<tec_current_alm_lo> ] [ <tec_current_warn_hi> ] [ <tec_current_warn_lo> ] [ <laser_freq> ] [
<laser_freq_flag> ] [ <laser_freq_alm_hi> ] [ <laser_freq_alm_lo> ] [ <laser_freq_warn_hi> ] [
<laser_freq_warn_lo> ] [ <laser_temp> ] [ <laser_temp_flag> ] [ <laser_temp_alm_hi> ] [
<laser_temp_alm_lo> ] [ <laser_temp_warn_hi> ] [ <laser_temp_warn_lo> ] [ <pre_fec_ber_acc> ] [
<pre_fec_ber_acc_flag> ] [ <pre_fec_ber_acc_alm_hi> ] [ <pre_fec_ber_acc_alm_lo> ] [
<pre_fec_ber_acc_warn_hi> ] [ <pre_fec_ber_acc_warn_lo> ] [ <pre_fec_ber_min> ] [ <pre_fec_ber_min_flag>
] [ <pre_fec_ber_min_alm_hi> ] [ <pre_fec_ber_min_alm_lo> ] [ <pre_fec_ber_min_warn_hi> ] [
<pre_fec_ber_min_warn_lo> ] [ <pre_fec_ber_max> ] [ <pre_fec_ber_max_flag> ] [
<pre_fec_ber_max_alm_hi> ] [ <pre_fec_ber_max_alm_lo> ] [ <pre_fec_ber_max_warn_hi> ] [
<pre_fec_ber_max_warn_lo> ] [ <pre_fec_ber_cur> ] [ <pre_fec_ber_cur_flag> ] [ <pre_fec_ber_cur_alm_hi>
] [ <pre_fec_ber_cur_alm_lo> ] [ <pre_fec_ber_cur_warn_hi> ] [ <pre_fec_ber_cur_warn_lo> ] [
<uncorrect_ber_acc> ] [ <uncorrect_ber_acc_flag> ] [ <uncorrect_ber_acc_alm_hi> ] [
<uncorrect_ber_acc_alm_lo> ] [ <uncorrect_ber_acc_warn_hi> ] [ <uncorrect_ber_acc_warn_lo> ] [
<uncorrect_ber_min> ] [ <uncorrect_ber_min_flag> ] [ <uncorrect_ber_min_alm_hi> ] [

```

```
<uncorrect_ber_min_alm_lo> ][ <uncorrect_ber_min_warn_hi> ][ <uncorrect_ber_min_warn_lo> ][
<uncorrect_ber_max> ][ <uncorrect_ber_max_flag> ][ <uncorrect_ber_max_alm_hi> ][
<uncorrect_ber_max_alm_lo> ][ <uncorrect_ber_max_warn_hi> ][ <uncorrect_ber_max_warn_lo> ][
<uncorrect_ber_cur> ][ <uncorrect_ber_cur_flag> ][ <uncorrect_ber_cur_alm_hi> ][
<uncorrect_ber_cur_alm_lo> ][ <uncorrect_ber_cur_warn_hi> ][ <uncorrect_ber_cur_warn_lo> ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                               |
| interface               | Show interface status and information                         |
| <i>ifid_transceiver</i> | Enter interface type and number in module/slot format         |
| transceiver             | Show interface transceiver information                        |
| calibrations            | (Optional) Show interface transceiver calibration information |
| details                 | (Optional) Show interface transceiver detail information      |
| sprom                   | (Optional) Show interface transceiver sprom information       |
| <u>__readonly__</u>     | (Optional) Read Only  |
| <i>interface</i>        | (Optional) Interface index                                    |
| TABLE_interface         | (Optional) show interface                                     |
| <i>sfp</i>              | (Optional) sfp  |
| <i>qsfp_or_cfp</i>      | (Optional) qsfp_or_cfp  |
| <i>type</i>             | (Optional) type   |
| <i>name</i>             | (Optional) Name   |
| <i>partnum</i>          | (Optional) part number  |
| <i>rev</i>              | (Optional) revision   |
| <i>serialnum</i>        | (Optional) serial number                                      |
| <i>nom_bitrate</i>      | (Optional) Nominal bit rate in MBits/sec                      |
| <i>len_9</i>            | (Optional) Link length supported for 9/125um fiber in Km      |
| <i>len_9_2</i>          | (Optional) Link length supported for 9/125um fiber in m       |
| <i>len_50</i>           | (Optional) Link length supported for 50/125um fiber in m      |
| <i>len_625</i>          | (Optional) Link length supported for 62.5/125um fiber in m    |
| <i>len_cu</i>           | (Optional) Link length supported for copper sfp in m          |
| <i>len_50_OM3</i>       | (Optional) Link length supported for 50/125um fiber in m      |
| <i>txcvr_type</i>       | (Optional)  |

|   |   |
|---|---|
| <i>connector_type</i>                   | (Optional)                                  |
| <i>bit_encoding</i>                     | (Optional)                                  |
| <i>protocol_type</i>                    | (Optional)                                  |
| <i>10gbe_code</i>                       | (Optional)                                  |
| <i>fiber_type_byte0</i>                 | (Optional)                                  |
| <i>fiber_type_byte1</i>                 | (Optional)                                  |
| <i>tx_range</i>                         | (Optional)                                  |
| <i>cable_type</i>                       | (Optional)                                  |
| <i>ciscoid</i>                          | (Optional) Cisco extended id                |
| <i>ciscoid_1</i>                        | (Optional) Cisco extended id number         |
| <i>cisco_part_number</i>                | (Optional) Cisco part number                |
| <i>cisco_product_id</i>                 | (Optional) Cisco product identifier         |
| <i>cisco_version_id</i>                 | (Optional) Cisco version identifier         |
| <i>cisco_vendor_id</i>                  | (Optional) Cisco vendor identifier          |
| <i>firmware_version</i>                 | (Optional) Firmware version                 |
| <i>cmis_version</i>                     | (Optional) CMIS version                     |
| <i>identifier</i>                       | (Optional) SFP Identifier                   |
| <i>ext_identifier</i>                   | (Optional) SFP Ext Identifier               |
| <i>connector</i>                        | (Optional) SFP connector                    |
| <i>infiniband_compliance_code</i>       | (Optional) SFP Infiniband Compliance Code   |
| <i>sonet_compliance_code</i>            | (Optional) Sonet Compliance Code            |
| <i>gigabit_ethernet_compliance_code</i> | (Optional) Gigabit Ethernet Compliance Code |
| <i>fibre_chan_link_length</i>           | (Optional) Fibre Chan Link Length           |
| <i>fibre_chan_trans_technology</i>      | (Optional) Fibre Chan Trans Technology      |
| <i>fibre_chan_trans_tech_reserved</i>   | (Optional) Fibre Chan Trans Tech Reserved   |
| <i>fibre_chan_transmission_media</i>    | (Optional) Fibre Chan Transmission Media    |
| <i>fibre_chan_speed</i>                 | (Optional) Fibre Chan Speed                 |
| <i>encoding</i>                         | (Optional) Encoding                         |
| <i>br_nominal</i>                       | (Optional) BR Nominal                       |



|                                   |  |
|-----------------------------------|--|
| <i>reserved1</i>                  | (Optional) Reserved1                             |
| <i>length_smf</i>                 | (Optional) Length_SMF                            |
| <i>length_om5</i>                 | (Optional) Length_OM5                            |
| <i>length_om4</i>                 | (Optional) Length_OM4                            |
| <i>length_om3</i>                 | (Optional) Length_OM3                            |
| <i>length_om2</i>                 | (Optional) Length_OM2                            |
| <i>length_om1</i>                 | (Optional) Length_OM1                            |
| <i>length_9u_1</i>                | (Optional) Length 9u 1                           |
| <i>length_9u_2</i>                | (Optional) Length 9u 2                           |
| <i>length_50u</i>                 | (Optional) Length 50u                            |
| <i>length_60u</i>                 | (Optional) Length 60u                            |
| <i>length_copper</i>              | (Optional) Length Copper                         |
| <i>reserved3</i>                  | (Optional) Reserved3                             |
| <i>wave_length</i>                | (Optional) Nominal transmitter output wavelength |
| <i>wave_len_tolerance</i>         | (Optional) Wavelength tolerance                  |
| <i>vendor_oui</i>                 | (Optional) Vendor OUI                            |
| <i>vendor_part_no</i>             | (Optional) Vendor Part No                        |
| <i>vendor_revision</i>            | (Optional) Vendor Revision                       |
| <i>reserved4</i>                  | (Optional) Reserved4                             |
| <i>check_code_id</i>              | (Optional) Check Code ID                         |
| <i>options</i>                    | (Optional) Options                               |
| <i>br_max</i>                     | (Optional) BR max                                |
| <i>br_min</i>                     | (Optional) BR min                                |
| <i>vendor_serial_no</i>           | (Optional) Vendor Serial No                      |
| <i>data_code</i>                  | (Optional) Data code                             |
| <i>diagnostic_monitoring_type</i> | (Optional) Diagnostic Monitoring Type            |
| <i>enhanced_options</i>           | (Optional) Enhanced Options                      |
| <i>sff8472compliance</i>          | (Optional) SFF8472Compliance                     |
| <i>check_code_ext</i>             | (Optional) Check code ext                        |

|                                     |   |
|-------------------------------------|---|
| <i>vendor_specific_data_id_data</i> | (Optional) Vendor Specific Data Id Data           |
| <i>date_code</i>                    | (Optional) date code and lot code                 |
| <i>clei_code</i>                    | (Optional) 10-character CLEI code                 |
| <i>power_class</i>                  | (Optional) power class                            |
| <i>max_power</i>                    | (Optional) maximum power consumption              |
| <i>cable_attenuation</i>            | (Optional) copper cable attenuation               |
| <i>near_end_lanes</i>               | (Optional) near end lane information              |
| <i>far_end_lanes</i>                | (Optional) far end lane information               |
| <i>media_interface</i>              | (Optional) media interface technology             |
| <i>adv_code</i>                     | (Optional) Module Advertising Code                |
| <i>host_elt_intf_code</i>           | (Optional) Module Host Electrical Interfaces Code |
| <i>med_intf_adv_code</i>            | (Optional) Media Interface Advertising Code       |
| <i>cable_length</i>                 | (Optional) Cable Assembly Length                  |
| <i>host_lane_count</i>              | (Optional) Host Lane Count                        |
| <i>med_lane_count</i>               | (Optional) Media Lane Count                       |
| <i>max_mod_temp</i>                 | (Optional) Maximum Module Temperature             |
| <i>min_mod_temp</i>                 | (Optional) Minimum Module Temperature             |
| <i>min_op_volt</i>                  | (Optional) Minimum Operating Voltage              |
| <i>info_not_available</i>           | (Optional) Info not available                     |
| <i>temp_slope</i>                   | (Optional) Temperature slope                      |
| <i>temp_offset</i>                  | (Optional) Temperature offset                     |
| <i>volt_slope</i>                   | (Optional) Voltage slope                          |
| <i>volt_offset</i>                  | (Optional) Voltage offset                         |
| <i>curr_slope</i>                   | (Optional) Current slope                          |
| <i>curr_offset</i>                  | (Optional) Current offset                         |
| <i>tx_pwr_slope</i>                 | (Optional) Tx power slope                         |
| <i>tx_pwr_offset</i>                | (Optional) Tx power offset                        |
| <i>rx_pwr_4</i>                     | (Optional) Rx power 4                             |
| <i>rx_pwr_3</i>                     | (Optional) Rx power 3                             |

|                         |                                     |
|-------------------------|-------------------------------------|
| <i>rx_pwr_2</i>         | (Optional) Rx power 2               |
| <i>rx_pwr_1</i>         | (Optional) Rx power 1               |
| <i>rx_pwr_0</i>         | (Optional) Rx power 0               |
| TABLE_lane              | (Optional) show lane                |
| <i>lane_number</i>      | (Optional) Lane number              |
| <i>temperature</i>      | (Optional) Temperature              |
| <i>temp_flag</i>        | (Optional) Temperature Flag         |
| <i>temp_alarm_hi</i>    | (Optional) Temperature Alarm High   |
| <i>temp_alarm_lo</i>    | (Optional) Temperature Alarm Low    |
| <i>temp_warn_hi</i>     | (Optional) Temperature Warning High |
| <i>temp_warn_lo</i>     | (Optional) Temperature Warning Low  |
| <i>voltage</i>          | (Optional) Voltage                  |
| <i>volt_flag</i>        | (Optional) Voltage Flag             |
| <i>volt_alarm_hi</i>    | (Optional) Voltage Alarm High       |
| <i>volt_alarm_lo</i>    | (Optional) Voltage Alarm Low        |
| <i>volt_warn_hi</i>     | (Optional) Voltage Warning High     |
| <i>volt_warn_lo</i>     | (Optional) Voltage Warning Low      |
| <i>current</i>          | (Optional) Current                  |
| <i>current_flag</i>     | (Optional) Current Flag             |
| <i>current_alarm_hi</i> | (Optional) Current Alarm High       |
| <i>current_alarm_lo</i> | (Optional) Current Alarm Low        |
| <i>current_warn_hi</i>  | (Optional) Current Warning High     |
| <i>current_warn_lo</i>  | (Optional) Current Warning Low      |
| <i>tx_pwr</i>           | (Optional) Tx Power                 |
| <i>tx_pwr_flag</i>      | (Optional) Tx Power Flag            |
| <i>tx_pwr_alarm_hi</i>  | (Optional) Tx Power Alarm High      |
| <i>tx_pwr_alarm_lo</i>  | (Optional) Tx Power Alarm Low       |
| <i>tx_pwr_warn_hi</i>   | (Optional) Tx Power Warning High    |
| <i>tx_pwr_warn_lo</i>   | (Optional) Tx Power Warning Low     |

|                           |   |
|---------------------------|---|
| <i>rx_pwr</i>             | (Optional) Rx Power                       |
| <i>rx_pwr_flag</i>        | (Optional) Rx Power Flag                  |
| <i>rx_pwr_alm_hi</i>      | (Optional) Rx Power Alarm High            |
| <i>rx_pwr_alm_lo</i>      | (Optional) Rx Power Alarm Low             |
| <i>rx_pwr_warn_hi</i>     | (Optional) Rx Power Warning High          |
| <i>rx_pwr_warn_lo</i>     | (Optional) Rx Power Warning Low           |
| <i>xmit_faults</i>        | (Optional) Transmit Fault Count           |
| <i>snr</i>                | (Optional) RX Signal-to-Noise Ratio (SNR) |
| <i>snr_flag</i>           | (Optional) SNR Flag                       |
| <i>snr_alm_hi</i>         | (Optional) SNR Alarm High                 |
| <i>snr_alm_lo</i>         | (Optional) SNR Alarm Low                  |
| <i>snr_warn_hi</i>        | (Optional) SNR Warning High               |
| <i>snr_warn_lo</i>        | (Optional) SNR Warning Low                |
| <i>isi</i>                | (Optional) Residual-Dispersion(ISI)       |
| <i>isi_flag</i>           | (Optional) ISI Flag                       |
| <i>isi_alm_hi</i>         | (Optional) ISI alarm high                 |
| <i>isi_alm_lo</i>         | (Optional) ISI alarm low                  |
| <i>isi_warn_hi</i>        | (Optional) ISI warning high               |
| <i>isi_warn_lo</i>        | (Optional) ISI warning low                |
| <i>pam</i>                | (Optional) PAM Transition                 |
| <i>pam_flag</i>           | (Optional) PAM Flag                       |
| <i>pam_alm_hi</i>         | (Optional) PAM alarm high                 |
| <i>pam_alm_lo</i>         | (Optional) PAM alarm low                  |
| <i>pam_warn_hi</i>        | (Optional) PAM warning high               |
| <i>pam_warn_lo</i>        | (Optional) PAM warning low                |
| <i>pre_fec_ber</i>        | (Optional) Pre-FEC BER                    |
| <i>pre_fec_ber_flag</i>   | (Optional) Pre-FEC BER flag               |
| <i>pre_fec_ber_alm_hi</i> | (Optional) Pre-FEC BER alarm high         |
| <i>pre_fec_ber_alm_lo</i> | (Optional) Pre-FEC BER alarm low          |

|                                |   |
|--------------------------------|---|
| <i>pre_fec_ber_warn_hi</i>     | (Optional) Pre-FEC BER warning high       |
| <i>pre_fec_ber_warn_lo</i>     | (Optional) Pre-FEC BER warning low        |
| <i>uncorrect_ber</i>           | (Optional) Uncorrected BER                |
| <i>uncorrect_ber_flag</i>      | (Optional) Uncorrected BER flag           |
| <i>uncorrect_ber_alrm_hi</i>   | (Optional) Uncorrected BER alarm high     |
| <i>uncorrect_ber_alrm_lo</i>   | (Optional) Uncorrected BER alarm low      |
| <i>uncorrect_ber_warn_hi</i>   | (Optional) Uncorrected BER warning high   |
| <i>uncorrect_ber_warn_lo</i>   | (Optional) Uncorrected BER warning low    |
| <i>tec_current</i>             | (Optional) TEC Current                    |
| <i>tec_current_flag</i>        | (Optional) TEC Current flag               |
| <i>tec_current_alrm_hi</i>     | (Optional) TEC Current Alarm High         |
| <i>tec_current_alrm_lo</i>     | (Optional) TEC Current Alarm Low          |
| <i>tec_current_warn_hi</i>     | (Optional) TEC Current Warning High       |
| <i>tec_current_warn_lo</i>     | (Optional) TEC Current Warning Low        |
| <i>laser_freq</i>              | (Optional) Laser Frequency                |
| <i>laser_freq_flag</i>         | (Optional) Laser Frequency flag           |
| <i>laser_freq_alrm_hi</i>      | (Optional) Laser Frequency Alarm High     |
| <i>laser_freq_alrm_lo</i>      | (Optional) Laser Frequency Alarm Low      |
| <i>laser_freq_warn_hi</i>      | (Optional) Laser Frequency Warning High   |
| <i>laser_freq_warn_lo</i>      | (Optional) Laser Frequency Warning Low    |
| <i>laser_temp</i>              | (Optional) Laser Temperature              |
| <i>laser_temp_flag</i>         | (Optional) Laser Temperature flag         |
| <i>laser_temp_alrm_hi</i>      | (Optional) Laser Temperature Alarm High   |
| <i>laser_temp_alrm_lo</i>      | (Optional) Laser Temperature Alarm Low    |
| <i>laser_temp_warn_hi</i>      | (Optional) Laser Temperature Warning High |
| <i>laser_temp_warn_lo</i>      | (Optional) Laser Temperature Warning Low  |
| <i>pre_fec_ber_acc</i>         | (Optional) Pre-FEC BER Acc                |
| <i>pre_fec_ber_acc_flag</i>    | (Optional) Pre-FEC BER Acc flag           |
| <i>pre_fec_ber_acc_alrm_hi</i> | (Optional) Pre-FEC BER Acc alarm high     |

|                                  |   |
|----------------------------------|---|
| <i>pre_fec_ber_acc_alrm_lo</i>   | (Optional) Pre-FEC BER Acc alarm low        |
| <i>pre_fec_ber_acc_warn_hi</i>   | (Optional) Pre-FEC BER Acc warning high     |
| <i>pre_fec_ber_acc_warn_lo</i>   | (Optional) Pre-FEC BER Acc warning low      |
| <i>pre_fec_ber_min</i>           | (Optional) Pre-FEC BER Min                  |
| <i>pre_fec_ber_min_flag</i>      | (Optional) Pre-FEC BER Min flag             |
| <i>pre_fec_ber_min_alrm_hi</i>   | (Optional) Pre-FEC BER Min alarm high       |
| <i>pre_fec_ber_min_alrm_lo</i>   | (Optional) Pre-FEC BER Min alarm low        |
| <i>pre_fec_ber_min_warn_hi</i>   | (Optional) Pre-FEC BER Min warning high     |
| <i>pre_fec_ber_min_warn_lo</i>   | (Optional) Pre-FEC BER Min warning low      |
| <i>pre_fec_ber_max</i>           | (Optional) Pre-FEC BER Max                  |
| <i>pre_fec_ber_max_flag</i>      | (Optional) Pre-FEC BER Max flag             |
| <i>pre_fec_ber_max_alrm_hi</i>   | (Optional) Pre-FEC BER Max alarm high       |
| <i>pre_fec_ber_max_alrm_lo</i>   | (Optional) Pre-FEC BER Max alarm low        |
| <i>pre_fec_ber_max_warn_hi</i>   | (Optional) Pre-FEC BER Max warning high     |
| <i>pre_fec_ber_max_warn_lo</i>   | (Optional) Pre-FEC BER Max warning low      |
| <i>pre_fec_ber_cur</i>           | (Optional) Pre-FEC BER Cur                  |
| <i>pre_fec_ber_cur_flag</i>      | (Optional) Pre-FEC BER Cur flag             |
| <i>pre_fec_ber_cur_alrm_hi</i>   | (Optional) Pre-FEC BER Cur alarm high       |
| <i>pre_fec_ber_cur_alrm_lo</i>   | (Optional) Pre-FEC BER Cur alarm low        |
| <i>pre_fec_ber_cur_warn_hi</i>   | (Optional) Pre-FEC BER Cur warning high     |
| <i>pre_fec_ber_cur_warn_lo</i>   | (Optional) Pre-FEC BER Cur warning low      |
| <i>uncorrect_ber_acc</i>         | (Optional) Uncorrected BER Acc              |
| <i>uncorrect_ber_acc_flag</i>    | (Optional) Uncorrected BER Acc flag         |
| <i>uncorrect_ber_acc_alrm_hi</i> | (Optional) Uncorrected BER Acc alarm high   |
| <i>uncorrect_ber_acc_alrm_lo</i> | (Optional) Uncorrected BER Acc alarm low    |
| <i>uncorrect_ber_acc_warn_hi</i> | (Optional) Uncorrected BER Acc warning high |
| <i>uncorrect_ber_acc_warn_lo</i> | (Optional) Uncorrected BER Acc warning low  |
| <i>uncorrect_ber_min</i>         | (Optional) Uncorrected BER Min              |
| <i>uncorrect_ber_min_flag</i>    | (Optional) Uncorrected BER Min flag         |

|                                  |   |
|----------------------------------|---|
| <i>uncorrect_ber_min_alm_hi</i>  | (Optional) Uncorrected BER Min alarm high   |
| <i>uncorrect_ber_min_alm_lo</i>  | (Optional) Uncorrected BER Min alarm low    |
| <i>uncorrect_ber_min_warn_hi</i> | (Optional) Uncorrected BER Min warning high |
| <i>uncorrect_ber_min_warn_lo</i> | (Optional) Uncorrected BER Min warning low  |
| <i>uncorrect_ber_max</i>         | (Optional) Uncorrected BER Max              |
| <i>uncorrect_ber_max_flag</i>    | (Optional) Uncorrected BER Max flag         |
| <i>uncorrect_ber_max_alm_hi</i>  | (Optional) Uncorrected BER Max alarm high   |
| <i>uncorrect_ber_max_alm_lo</i>  | (Optional) Uncorrected BER Max alarm low    |
| <i>uncorrect_ber_max_warn_hi</i> | (Optional) Uncorrected BER Max warning high |
| <i>uncorrect_ber_max_warn_lo</i> | (Optional) Uncorrected BER Max warning low  |
| <i>uncorrect_ber_cur</i>         | (Optional) Uncorrected BER Cur              |
| <i>uncorrect_ber_cur_flag</i>    | (Optional) Uncorrected BER Cur flag         |
| <i>uncorrect_ber_cur_alm_hi</i>  | (Optional) Uncorrected BER Cur alarm high   |
| <i>uncorrect_ber_cur_alm_lo</i>  | (Optional) Uncorrected BER Cur alarm low    |
| <i>uncorrect_ber_cur_warn_hi</i> | (Optional) Uncorrected BER Cur warning high |
| <i>uncorrect_ber_cur_warn_lo</i> | (Optional) Uncorrected BER Cur warning low  |

**Command Mode**

- /exec

## show interface transceiver fex-fabric

```
show interface <ifeth_trans> transceiver fex-fabric [ calibrations | details ] [ __readonly__ TABLE_interface
<interface> <sfp> <name> <partnum> <rev> <serialnum> <nom_bitrate> <len_50> <len_625> <ciscoid>
<ciscoid_1> [ <temp_slope> ] [ <temp_offset> ] [ <volt_slope> ] [ <volt_offset> ] [ <curr_slope> ] [
<curr_offset> ] [ <tx_pwr_slope> ] [ <tx_pwr_offset> ] [ <rx_pwr_4> ] [ <rx_pwr_3> ] [ <rx_pwr_2> ] [
<rx_pwr_1> ] [ <rx_pwr_0> ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                               |
| interface           | Show interface status and information                         |
| <i>ifeth_trans</i>  | Enter interface type and number in module/slot format         |
| transceiver         | Show interface transceiver information                        |
| fex-fabric          | Show FEX interface transceiver information                    |
| calibrations        | (Optional) Show interface transceiver calibration information |
| details             | (Optional) Show interface transceiver detail information      |
| <u>__readonly__</u> | (Optional) Read Only  |
| <i>interface</i>    | (Optional) Interface index                                    |
| TABLE_interface     | (Optional) show interface                                     |
| <i>sfp</i>          | (Optional) sfp  |
| <i>name</i>         | (Optional) Name   |
| <i>partnum</i>      | (Optional) part number  |
| <i>rev</i>          | (Optional) revision   |
| <i>serialnum</i>    | (Optional) serial number                                      |
| <i>nom_bitrate</i>  | (Optional) Nominal bit rate in Mbits/sec                      |
| <i>len_50</i>       | (Optional) Link length supported for 50/125mm fiber           |
| <i>len_625</i>      | (Optional) Link length supported for 62.5/125mm fiber         |
| <i>ciscoid</i>      | (Optional) Cisco extended id                                  |
| <i>ciscoid_1</i>    | (Optional) Cisco extended id number                           |
| <i>temp_slope</i>   | (Optional) Temperature slope                                  |
| <i>temp_offset</i>  | (Optional) Temperature offset                                 |
| <i>volt_slope</i>   | (Optional) Voltage slope                                      |



|                      |                            |
|----------------------|----------------------------|
| <i>volt_offset</i>   | (Optional) Voltage offset  |
| <i>curr_slope</i>    | (Optional) Current slope   |
| <i>curr_offset</i>   | (Optional) Current offset  |
| <i>tx_pwr_slope</i>  | (Optional) Tx power slope  |
| <i>tx_pwr_offset</i> | (Optional) Tx power offset |
| <i>rx_pwr_4</i>      | (Optional) Rx power 4      |
| <i>rx_pwr_3</i>      | (Optional) Rx power 3      |
| <i>rx_pwr_2</i>      | (Optional) Rx power 2      |
| <i>rx_pwr_1</i>      | (Optional) Rx power 1      |
| <i>rx_pwr_0</i>      | (Optional) Rx power 0      |

**Command Mode**

- /exec

## show interface transceiver fex-fabric

```
show interface transceiver fex-fabric [ calibrations | details ] [ __readonly__ TABLE_interface <interface> [
<sf> ] [ <type> ] [ <name> ] [ <partnum> ] [ <rev> ] [ <serialnum> ] [ <nom_bitrate> ] [ <len_50> ] [
<len_625> ] [ <len_50_OM3> ] [ <ciscoid> ] [ <ciscoid_1> ] [ <info_not_available> ] [ <temp_slope> ] [
<temp_offset> ] [ <volt_slope> ] [ <volt_offset> ] [ <curr_slope> ] [ <curr_offset> ] [ <tx_pwr_slope> ] [
<tx_pwr_offset> ] [ <rx_pwr_4> ] [ <rx_pwr_3> ] [ <rx_pwr_2> ] [ <rx_pwr_1> ] [ <rx_pwr_0> ] [
TABLE_lane [ <lane_number> ] [ <temperature> ] [ <temp_flag> ] [ <temp_alm_hi> ] [ <temp_alm_lo> ]
[ <temp_warn_hi> ] [ <temp_warn_lo> ] [ <voltage> ] [ <volt_flag> ] [ <volt_alm_hi> ] [ <volt_alm_lo>
] [ <volt_warn_hi> ] [ <volt_warn_lo> ] [ <current> ] [ <current_flag> ] [ <current_alm_hi> ] [
<current_alm_lo> ] [ <current_warn_hi> ] [ <current_warn_lo> ] [ <tx_pwr> ] [ <tx_pwr_flag> ] [
<tx_pwr_alm_hi> ] [ <tx_pwr_alm_lo> ] [ <tx_pwr_warn_hi> ] [ <tx_pwr_warn_lo> ] [ <rx_pwr> ] [
<rx_pwr_flag> ] [ <rx_pwr_alm_hi> ] [ <rx_pwr_alm_lo> ] [ <rx_pwr_warn_hi> ] [ <rx_pwr_warn_lo> ]
[ <xmit_faults> ] [ <snr> ] [ <snr_flag> ] [ <snr_alm_hi> ] [ <snr_alm_lo> ] [ <snr_warn_hi> ] [
<snr_warn_lo> ] [ <isi> ] [ <isi_flag> ] [ <isi_alm_hi> ] [ <isi_alm_lo> ] [ <isi_warn_hi> ] [ <isi_warn_lo>
] [ <pam> ] [ <pam_flag> ] [ <pam_alm_hi> ] [ <pam_alm_lo> ] [ <pam_warn_hi> ] [ <pam_warn_lo> ] [
<pre_fec_ber> ] [ <pre_fec_ber_flag> ] [ <pre_fec_ber_alm_hi> ] [ <pre_fec_ber_alm_lo> ] [
<pre_fec_ber_warn_hi> ] [ <pre_fec_ber_warn_lo> ] [ <uncorrect_ber> ] [ <uncorrect_ber_flag> ] [
<uncorrect_ber_alm_hi> ] [ <uncorrect_ber_alm_lo> ] [ <uncorrect_ber_warn_hi> ] [
<uncorrect_ber_warn_lo> ] [ <tec_current> ] [ <tec_current_flag> ] [ <tec_current_alm_hi> ] [
<tec_current_alm_lo> ] [ <tec_current_warn_hi> ] [ <tec_current_warn_lo> ] [ <laser_freq> ] [
<laser_freq_flag> ] [ <laser_freq_alm_hi> ] [ <laser_freq_alm_lo> ] [ <laser_freq_warn_hi> ] [
<laser_freq_warn_lo> ] [ <laser_temp> ] [ <laser_temp_flag> ] [ <laser_temp_alm_hi> ] [
<laser_temp_alm_lo> ] [ <laser_temp_warn_hi> ] [ <laser_temp_warn_lo> ] [ <pre_fec_ber_acc> ] [
<pre_fec_ber_acc_flag> ] [ <pre_fec_ber_acc_alm_hi> ] [ <pre_fec_ber_acc_alm_lo> ] [
<pre_fec_ber_acc_warn_hi> ] [ <pre_fec_ber_acc_warn_lo> ] [ <pre_fec_ber_min> ] [ <pre_fec_ber_min_flag>
] [ <pre_fec_ber_min_alm_hi> ] [ <pre_fec_ber_min_alm_lo> ] [ <pre_fec_ber_min_warn_hi> ] [
<pre_fec_ber_min_warn_lo> ] [ <pre_fec_ber_max> ] [ <pre_fec_ber_max_flag> ] [
<pre_fec_ber_max_alm_hi> ] [ <pre_fec_ber_max_alm_lo> ] [ <pre_fec_ber_max_warn_hi> ] [
<pre_fec_ber_max_warn_lo> ] [ <pre_fec_ber_cur> ] [ <pre_fec_ber_cur_flag> ] [ <pre_fec_ber_cur_alm_hi>
] [ <pre_fec_ber_cur_alm_lo> ] [ <pre_fec_ber_cur_warn_hi> ] [ <pre_fec_ber_cur_warn_lo> ] [
<uncorrect_ber_acc> ] [ <uncorrect_ber_acc_flag> ] [ <uncorrect_ber_acc_alm_hi> ] [
<uncorrect_ber_acc_alm_lo> ] [ <uncorrect_ber_acc_warn_hi> ] [ <uncorrect_ber_acc_warn_lo> ] [
<uncorrect_ber_min> ] [ <uncorrect_ber_min_flag> ] [ <uncorrect_ber_min_alm_hi> ] [
<uncorrect_ber_min_alm_lo> ] [ <uncorrect_ber_min_warn_hi> ] [ <uncorrect_ber_min_warn_lo> ] [
<uncorrect_ber_max> ] [ <uncorrect_ber_max_flag> ] [ <uncorrect_ber_max_alm_hi> ] [
<uncorrect_ber_max_alm_lo> ] [ <uncorrect_ber_max_warn_hi> ] [ <uncorrect_ber_max_warn_lo> ] [
<uncorrect_ber_cur> ] [ <uncorrect_ber_cur_flag> ] [ <uncorrect_ber_cur_alm_hi> ] [
<uncorrect_ber_cur_alm_lo> ] [ <uncorrect_ber_cur_warn_hi> ] [ <uncorrect_ber_cur_warn_lo> ] ] ]
```

### Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                               |
| interface    | Show interface status and information                         |
| transceiver  | Show interface transceiver information                        |
| fex-fabric   | Show FEX interface transceiver information                    |
| calibrations | (Optional) Show interface transceiver calibration information |

|                           |  |
|---------------------------|--|
| <i>details</i>            | (Optional) Show interface transceiver detail information |
| <i>__readonly__</i>       | (Optional) Read Only                                     |
| <i>interface</i>          | (Optional) Interface index                               |
| TABLE_ <i>interface</i>   | (Optional) show interface                                |
| <i>sfp</i>                | (Optional) sfp   |
| <i>type</i>               | (Optional) type  |
| <i>name</i>               | (Optional) Name  |
| <i>partnum</i>            | (Optional) part number                                   |
| <i>rev</i>                | (Optional) revision                                      |
| <i>serialnum</i>          | (Optional) serial number                                 |
| <i>nom_bitrate</i>        | (Optional) Nominal bit rate in MBits/sec                 |
| <i>len_50</i>             | (Optional) Link length supported for 50/125mm fiber      |
| <i>len_625</i>            | (Optional) Link length supported for 62.5/125mm fiber    |
| <i>len_50_OM3</i>         | (Optional) Link length supported for 50/125um fiber in m |
| <i>ciscoid</i>            | (Optional) Cisco extended id                             |
| <i>ciscoid_1</i>          | (Optional) Cisco extended id number                      |
| <i>info_not_available</i> | (Optional) Error case if sfp info not available          |
| <i>temp_slope</i>         | (Optional) Temperature slope                             |
| <i>temp_offset</i>        | (Optional) Temperature offset                            |
| <i>volt_slope</i>         | (Optional) Voltage slope                                 |
| <i>volt_offset</i>        | (Optional) Voltage offset                                |
| <i>curr_slope</i>         | (Optional) Current slope                                 |
| <i>curr_offset</i>        | (Optional) Current offset                                |
| <i>tx_pwr_slope</i>       | (Optional) Tx power slope                                |
| <i>tx_pwr_offset</i>      | (Optional) Tx power offset                               |
| <i>rx_pwr_4</i>           | (Optional) Rx power 4                                    |
| <i>rx_pwr_3</i>           | (Optional) Rx power 3                                    |
| <i>rx_pwr_2</i>           | (Optional) Rx power 2                                    |
| <i>rx_pwr_1</i>           | (Optional) Rx power 1                                    |

|                         |                                     |
|-------------------------|-------------------------------------|
| <i>rx_pwr_0</i>         | (Optional) Rx power 0               |
| TABLE_lane              | (Optional) show lane                |
| <i>lane_number</i>      | (Optional) Lane number              |
| <i>temperature</i>      | (Optional) Temperature              |
| <i>temp_flag</i>        | (Optional) Temperature Flag         |
| <i>temp_alarm_hi</i>    | (Optional) Temperature Alarm High   |
| <i>temp_alarm_lo</i>    | (Optional) Temperature Alarm Low    |
| <i>temp_warn_hi</i>     | (Optional) Temperature Warning High |
| <i>temp_warn_lo</i>     | (Optional) Temperature Warning Low  |
| <i>voltage</i>          | (Optional) Voltage                  |
| <i>volt_flag</i>        | (Optional) Voltage Flag             |
| <i>volt_alarm_hi</i>    | (Optional) Voltage Alarm High       |
| <i>volt_alarm_lo</i>    | (Optional) Voltage Alarm Low        |
| <i>volt_warn_hi</i>     | (Optional) Voltage Warning High     |
| <i>volt_warn_lo</i>     | (Optional) Voltage Warning Low      |
| <i>current</i>          | (Optional) Current                  |
| <i>current_flag</i>     | (Optional) Current Flag             |
| <i>current_alarm_hi</i> | (Optional) Current Alarm High       |
| <i>current_alarm_lo</i> | (Optional) Current Alarm Low        |
| <i>current_warn_hi</i>  | (Optional) Current Warning High     |
| <i>current_warn_lo</i>  | (Optional) Current Warning Low      |
| <i>tx_pwr</i>           | (Optional) Tx Power                 |
| <i>tx_pwr_flag</i>      | (Optional) Tx Power Flag            |
| <i>tx_pwr_alarm_hi</i>  | (Optional) Tx Power Alarm High      |
| <i>tx_pwr_alarm_lo</i>  | (Optional) Tx Power Alarm Low       |
| <i>tx_pwr_warn_hi</i>   | (Optional) Tx Power Warning High    |
| <i>tx_pwr_warn_lo</i>   | (Optional) Tx Power Warning Low     |
| <i>rx_pwr</i>           | (Optional) Rx Power                 |
| <i>rx_pwr_flag</i>      | (Optional) Rx Power Flag            |

|                            |   |
|----------------------------|---|
| <i>rx_pwr_alrm_hi</i>      | (Optional) Rx Power Alarm High            |
| <i>rx_pwr_alrm_lo</i>      | (Optional) Rx Power Alarm Low             |
| <i>rx_pwr_warn_hi</i>      | (Optional) Rx Power Warning High          |
| <i>rx_pwr_warn_lo</i>      | (Optional) Rx Power Warning Low           |
| <i>xmit_faults</i>         | (Optional) Transmit Fault Count           |
| <i>snr</i>                 | (Optional) RX Signal-to-Noise Ratio (SNR) |
| <i>snr_flag</i>            | (Optional) SNR Flag                       |
| <i>snr_alrm_hi</i>         | (Optional) SNR Alarm High                 |
| <i>snr_alrm_lo</i>         | (Optional) SNR Alarm Low                  |
| <i>snr_warn_hi</i>         | (Optional) SNR Warning High               |
| <i>snr_warn_lo</i>         | (Optional) SNR Warning Low                |
| <i>isi</i>                 | (Optional) Residual-Dispersion(ISI)       |
| <i>isi_flag</i>            | (Optional) ISI Flag                       |
| <i>isi_alrm_hi</i>         | (Optional) ISI alarm high                 |
| <i>isi_alrm_lo</i>         | (Optional) ISI alarm low                  |
| <i>isi_warn_hi</i>         | (Optional) ISI warning high               |
| <i>isi_warn_lo</i>         | (Optional) ISI warning low                |
| <i>pam</i>                 | (Optional) PAM Transition                 |
| <i>pam_flag</i>            | (Optional) PAM Flag                       |
| <i>pam_alrm_hi</i>         | (Optional) PAM alarm high                 |
| <i>pam_alrm_lo</i>         | (Optional) PAM alarm low                  |
| <i>pam_warn_hi</i>         | (Optional) PAM warning high               |
| <i>pam_warn_lo</i>         | (Optional) PAM warning low                |
| <i>pre_fec_ber</i>         | (Optional) Pre-FEC BER                    |
| <i>pre_fec_ber_flag</i>    | (Optional) Pre-FEC BER flag               |
| <i>pre_fec_ber_alrm_hi</i> | (Optional) Pre-FEC BER alarm high         |
| <i>pre_fec_ber_alrm_lo</i> | (Optional) Pre-FEC BER alarm low          |
| <i>pre_fec_ber_warn_hi</i> | (Optional) Pre-FEC BER warning high       |
| <i>pre_fec_ber_warn_lo</i> | (Optional) Pre-FEC BER warning low        |

|                                |   |
|--------------------------------|---|
| <i>uncorrect_ber</i>           | (Optional) Uncorrected BER                |
| <i>uncorrect_ber_flag</i>      | (Optional) Uncorrected BER flag           |
| <i>uncorrect_ber_alm_hi</i>    | (Optional) Uncorrected BER alarm high     |
| <i>uncorrect_ber_alm_lo</i>    | (Optional) Uncorrected BER alarm low      |
| <i>uncorrect_ber_warn_hi</i>   | (Optional) Uncorrected BER warning high   |
| <i>uncorrect_ber_warn_lo</i>   | (Optional) Uncorrected BER warning low    |
| <i>tec_current</i>             | (Optional) TEC Current                    |
| <i>tec_current_flag</i>        | (Optional) TEC Current flag               |
| <i>tec_current_alm_hi</i>      | (Optional) TEC Current Alarm High         |
| <i>tec_current_alm_lo</i>      | (Optional) TEC Current Alarm Low          |
| <i>tec_current_warn_hi</i>     | (Optional) TEC Current Warning High       |
| <i>tec_current_warn_lo</i>     | (Optional) TEC Current Warning Low        |
| <i>laser_freq</i>              | (Optional) Laser Frequency                |
| <i>laser_freq_flag</i>         | (Optional) Laser Frequency flag           |
| <i>laser_freq_alm_hi</i>       | (Optional) Laser Frequency Alarm High     |
| <i>laser_freq_alm_lo</i>       | (Optional) Laser Frequency Alarm Low      |
| <i>laser_freq_warn_hi</i>      | (Optional) Laser Frequency Warning High   |
| <i>laser_freq_warn_lo</i>      | (Optional) Laser Frequency Warning Low    |
| <i>laser_temp</i>              | (Optional) Laser Temperature              |
| <i>laser_temp_flag</i>         | (Optional) Laser Temperature flag         |
| <i>laser_temp_alm_hi</i>       | (Optional) Laser Temperature Alarm High   |
| <i>laser_temp_alm_lo</i>       | (Optional) Laser Temperature Alarm Low    |
| <i>laser_temp_warn_hi</i>      | (Optional) Laser Temperature Warning High |
| <i>laser_temp_warn_lo</i>      | (Optional) Laser Temperature Warning Low  |
| <i>pre_fec_ber_acc</i>         | (Optional) Pre-FEC BER Acc                |
| <i>pre_fec_ber_acc_flag</i>    | (Optional) Pre-FEC BER Acc flag           |
| <i>pre_fec_ber_acc_alm_hi</i>  | (Optional) Pre-FEC BER Acc alarm high     |
| <i>pre_fec_ber_acc_alm_lo</i>  | (Optional) Pre-FEC BER Acc alarm low      |
| <i>pre_fec_ber_acc_warn_hi</i> | (Optional) Pre-FEC BER Acc warning high   |

|                                  |   |
|----------------------------------|---|
| <i>pre_fec_ber_acc_warn_lo</i>   | (Optional) Pre-FEC BER Acc warning low      |
| <i>pre_fec_ber_min</i>           | (Optional) Pre-FEC BER Min                  |
| <i>pre_fec_ber_min_flag</i>      | (Optional) Pre-FEC BER Min flag             |
| <i>pre_fec_ber_min_alm_hi</i>    | (Optional) Pre-FEC BER Min alarm high       |
| <i>pre_fec_ber_min_alm_lo</i>    | (Optional) Pre-FEC BER Min alarm low        |
| <i>pre_fec_ber_min_warn_hi</i>   | (Optional) Pre-FEC BER Min warning high     |
| <i>pre_fec_ber_min_warn_lo</i>   | (Optional) Pre-FEC BER Min warning low      |
| <i>pre_fec_ber_max</i>           | (Optional) Pre-FEC BER Max                  |
| <i>pre_fec_ber_max_flag</i>      | (Optional) Pre-FEC BER Max flag             |
| <i>pre_fec_ber_max_alm_hi</i>    | (Optional) Pre-FEC BER Max alarm high       |
| <i>pre_fec_ber_max_alm_lo</i>    | (Optional) Pre-FEC BER Max alarm low        |
| <i>pre_fec_ber_max_warn_hi</i>   | (Optional) Pre-FEC BER Max warning high     |
| <i>pre_fec_ber_max_warn_lo</i>   | (Optional) Pre-FEC BER Max warning low      |
| <i>pre_fec_ber_cur</i>           | (Optional) Pre-FEC BER Cur                  |
| <i>pre_fec_ber_cur_flag</i>      | (Optional) Pre-FEC BER Cur flag             |
| <i>pre_fec_ber_cur_alm_hi</i>    | (Optional) Pre-FEC BER Cur alarm high       |
| <i>pre_fec_ber_cur_alm_lo</i>    | (Optional) Pre-FEC BER Cur alarm low        |
| <i>pre_fec_ber_cur_warn_hi</i>   | (Optional) Pre-FEC BER Cur warning high     |
| <i>pre_fec_ber_cur_warn_lo</i>   | (Optional) Pre-FEC BER Cur warning low      |
| <i>uncorrect_ber_acc</i>         | (Optional) Uncorrected BER Acc              |
| <i>uncorrect_ber_acc_flag</i>    | (Optional) Uncorrected BER Acc flag         |
| <i>uncorrect_ber_acc_alm_hi</i>  | (Optional) Uncorrected BER Acc alarm high   |
| <i>uncorrect_ber_acc_alm_lo</i>  | (Optional) Uncorrected BER Acc alarm low    |
| <i>uncorrect_ber_acc_warn_hi</i> | (Optional) Uncorrected BER Acc warning high |
| <i>uncorrect_ber_acc_warn_lo</i> | (Optional) Uncorrected BER Acc warning low  |
| <i>uncorrect_ber_min</i>         | (Optional) Uncorrected BER Min              |
| <i>uncorrect_ber_min_flag</i>    | (Optional) Uncorrected BER Min flag         |
| <i>uncorrect_ber_min_alm_hi</i>  | (Optional) Uncorrected BER Min alarm high   |
| <i>uncorrect_ber_min_alm_lo</i>  | (Optional) Uncorrected BER Min alarm low    |

|                                  |   |
|----------------------------------|---|
| <i>uncorrect_ber_min_warn_hi</i> | (Optional) Uncorrected BER Min warning high |
| <i>uncorrect_ber_min_warn_lo</i> | (Optional) Uncorrected BER Min warning low  |
| <i>uncorrect_ber_max</i>         | (Optional) Uncorrected BER Max              |
| <i>uncorrect_ber_max_flag</i>    | (Optional) Uncorrected BER Max flag         |
| <i>uncorrect_ber_max_alm_hi</i>  | (Optional) Uncorrected BER Max alarm high   |
| <i>uncorrect_ber_max_alm_lo</i>  | (Optional) Uncorrected BER Max alarm low    |
| <i>uncorrect_ber_max_warn_hi</i> | (Optional) Uncorrected BER Max warning high |
| <i>uncorrect_ber_max_warn_lo</i> | (Optional) Uncorrected BER Max warning low  |
| <i>uncorrect_ber_cur</i>         | (Optional) Uncorrected BER Cur              |
| <i>uncorrect_ber_cur_flag</i>    | (Optional) Uncorrected BER Cur flag         |
| <i>uncorrect_ber_cur_alm_hi</i>  | (Optional) Uncorrected BER Cur alarm high   |
| <i>uncorrect_ber_cur_alm_lo</i>  | (Optional) Uncorrected BER Cur alarm low    |
| <i>uncorrect_ber_cur_warn_hi</i> | (Optional) Uncorrected BER Cur warning high |
| <i>uncorrect_ber_cur_warn_lo</i> | (Optional) Uncorrected BER Cur warning low  |

**Command Mode**

- /exec



# show interface trunk

```
show interface <ifeth_trnk> trunk [ __readonly__ { TABLE_interface <interface> [ <native> ] <status>
<portchannel> } { TABLE_allowed_vlans <interface> <allowedvlans> } { TABLE_errored_vlans <interface>
<erroredvlans> } { TABLE_stp_forward <interface> <stpfwd_vlans> } [ { TABLE_fabricpath_vlans
<interface> <fabricpath_vlans> } ] { TABLE_vtp_pruning <interface> <vtppruning_vlans> } ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                          |
| interface               | Show interface status and information                    |
| <i>ifeth_trnk</i>       | Enter interface type and number in module/slot format    |
| trunk                   | Show interface trunk information                         |
| __readonly__            | (Optional) Read Only                                     |
| TABLE_interface         | (Optional) show interface                                |
| <i>interface</i>        | (Optional) Interface index                               |
| <i>native</i>           | (Optional) Native VLAN                                   |
| <i>status</i>           | (Optional) Status  |
| <i>portchannel</i>      | (Optional) Port Channel                                  |
| TABLE_allowed_vlans     | (Optional) show allowed vlans                            |
| <i>interface</i>        | (Optional) Interface index                               |
| <i>allowedvlans</i>     | (Optional) VLANs allowed and active in management domain |
| TABLE_errored_vlans     | (Optional) show errored vlans                            |
| <i>interface</i>        | (Optional) Interface index                               |
| <i>erroredvlans</i>     | (Optional) Errored VLANs                                 |
| TABLE_stp_forward       | (Optional) show STP forwarding VLANs                     |
| <i>interface</i>        | (Optional) Interface index                               |
| <i>stpfwd_vlans</i>     | (Optional) STP Forwarding VLANs                          |
| TABLE_fabricpath_vlans  | (Optional) show fabricpath VLANs                         |
| <i>interface</i>        | (Optional) Interface index                               |
| <i>fabricpath_vlans</i> | (Optional) FabricPath VLANs                              |
| TABLE_vtp_pruning       | (Optional) show VTP pruning VLANs                        |

|                         |                              |
|-------------------------|------------------------------|
| <i>interface</i>        | (Optional) Interface index   |
| <i>vtppruning_vlans</i> | (Optional) VTP Pruning VLANs |

**Command Mode**

- /exec

# show interface trunk

```
show interface trunk [ module <module> | vlan <vlan_id> | fex <fex_num> ] [ __readonly__ [ {
TABLE_interface <interface> [ <native> ] <status> <portchannel> } ] [ { TABLE_allowed_vlans <interface>
<allowedvlans> } ] [ { TABLE_errored_vlans <interface> <erroredvlans> } ] [ { TABLE_stp_forward
<interface> <stpfwd_vlans> } ] [ { TABLE_fabricpath_vlans <interface> <fabricpath_vlans> } ] [ {
TABLE_vtp_pruning <interface> <vtppruning_vlans> } ] ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                          |
| interface           | Show interface status and information                    |
| trunk               | Show interface trunk information                         |
| module              | (Optional) Limit display to interfaces on module         |
| <i>module</i>       | (Optional) Enter module number                           |
| fex                 | (Optional) Limit display to interfaces on a FEX          |
| <i>fex_num</i>      | (Optional) Enter FEX number                              |
| vlan                | (Optional) Show per vlan information for trunk           |
| <i>vlan_id</i>      | (Optional) Enter vlan range                              |
| <i>interface</i>    | (Optional) Interface index                               |
| <i>__readonly__</i> | (Optional) Read Only                                     |
| TABLE_interface     | (Optional) show interface                                |
| <i>interface</i>    | (Optional) Interface index                               |
| <i>native</i>       | (Optional) Native VLAN                                   |
| <i>status</i>       | (Optional) Status  |
| <i>portchannel</i>  | (Optional) Port Channel                                  |
| TABLE_allowed_vlans | (Optional) show allowed vlans                            |
| <i>interface</i>    | (Optional) Interface index                               |
| <i>allowedvlans</i> | (Optional) VLANs allowed and active in management domain |
| TABLE_errored_vlans | (Optional) show errored vlans                            |
| <i>interface</i>    | (Optional) Interface index                               |
| <i>erroredvlans</i> | (Optional) Errored VLANs                                 |
| TABLE_stp_forward   | (Optional) show STP forwarding VLANs                     |

|                          |                                   |
|--------------------------|-----------------------------------|
| <i>interface</i>         | (Optional) Interface index        |
| <i>stp fwd_vlans</i>     | (Optional) STP Forwarding VLANs   |
| TABLE_fabricpath_vlans   | (Optional) show fabricpath VLANs  |
| <i>interface</i>         | (Optional) Interface index        |
| <i>fabricpath_vlans</i>  | (Optional) FabricPath VLANs       |
| TABLE_vtp_pruning        | (Optional) show VTP pruning VLANs |
| <i>vtp pruning_vlans</i> | (Optional) VTP Pruning VLANs      |

**Command Mode**

- /exec

## show interface trunk vsan

```
show interface <ifid_trnk> trunk vsan [ <vsan_id> ] [ __readonly__ { TABLE_interface_trunk [ <interface>
] [ <oper_state> ] [ <oper_state_reason> ] [ <bundle_str> ] [ TABLE_vsan_info { [ <vsan_num> ] [
<vsan_state> ] [ <vsan_state_reason> ] [ <fcid> ] } } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                       |
| interface                | Show interface status and information                 |
| <i>ifid_trnk</i>         | Enter interface type and number in module/slot format |
| trunk                    | Show interface trunk information                      |
| vsan                     | Show per vsan information for trunk                   |
| <i>vsan_id</i>           | (Optional) Enter vsan range                           |
| <i>__readonly__</i>      | (Optional) Read Only                                  |
| TABLE_interface_trunk    | (Optional) interface trunk table                      |
| <i>interface</i>         | (Optional) fc interface                               |
| <i>oper_state</i>        | (Optional) the status of trunking                     |
| <i>oper_state_reason</i> | (Optional) reason for operation state                 |
| <i>bundle_str</i>        | (Optional) bundle string                              |
| TABLE_vsan_info          | (Optional) vsan information                           |
| <i>vsan_num</i>          | (Optional) the vsan ID                                |
| <i>vsan_state</i>        | (Optional) the ststus of vsan                         |
| <i>vsan_state_reason</i> | (Optional) reason for vsan state                      |
| <i>fcid</i>              | (Optional) FCID                                       |

### Command Mode

- /exec

## show interface trunk vsan

```
show interface trunk vsan [ <vsan_id> ] [ __readonly__ { TABLE_interface_trunk [ <interface> ] [ <oper_state> ] [ <oper_state_reason> ] [ <bundle_str> ] [ TABLE_vsan_info { [ <vsan_num> ] [ <vsan_state> ] [ <vsan_state_reason> ] [ <fcid> ] } } ] ]
```

### Syntax Description

|                          |                                       |
|--------------------------|---------------------------------------|
| show                     | Show running system information       |
| interface                | Show interface status and information |
| trunk                    | Show interface trunk information      |
| vsan                     | Show per vsan information for trunk   |
| <i>vsan_id</i>           | (Optional) Enter vsan range           |
| <i>__readonly__</i>      | (Optional)                            |
| TABLE_interface_trunk    | (Optional) interface trunk table      |
| <i>interface</i>         | (Optional) fc interface               |
| <i>oper_state</i>        | (Optional) the status of trunking     |
| <i>oper_state_reason</i> | (Optional) reason for operation state |
| <i>bundle_str</i>        | (Optional) bundle string              |
| TABLE_vsan_info          | (Optional) vsan information           |
| <i>vsan_num</i>          | (Optional) the vsan ID                |
| <i>vsan_state</i>        | (Optional) the status of vsan         |
| <i>vsan_state_reason</i> | (Optional) reason for vsan state      |
| <i>fcid</i>              | (Optional) FCID                       |

### Command Mode

- /exec

## show interface untagged-cos

```
show interface untagged-cos [ module <mod_num> ] [ __readonly__ TABLE_interface <interface>
<ucos-value> [ <portmode> ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| interface           | Show interface status and information            |
| untagged-cos        | Show interface untagged CoS information          |
| module              | (Optional) Limit display to interfaces on module |
| <i>mod_num</i>      | (Optional) Enter module number                   |
| <i>__readonly__</i> | (Optional)                                       |
| <i>interface</i>    | (Optional) Interface index                       |
| TABLE_interface     | (Optional) show interface                        |
| <i>ucos-value</i>   | (Optional) COS value                             |
| <i>portmode</i>     | (Optional) Port mode                             |

### Command Mode

- /exec

## show interface vlan mapping

```
show interface <ifindex> vlan mapping [ __readonly__ <if-index-id> { TABLE_vlan_xlt <orig-vlan-id> [
<inner-vlan-id> ] <xlt-vlan-id> } <show-end> [ <true-end> ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                       |
| interface            | Show interface status and information                 |
| <i>ifindex</i>       | Enter interface type and number in module/slot format |
| vlan                 | Show VLAN information                                 |
| mapping              | VLAN translation mapping                              |
| <i>__readonly__</i>  | (Optional) Read Only                                  |
| TABLE_vlan_xlt       | (Optional) Vlan translation table                     |
| <i>if-index-id</i>   | (Optional) Interface index id                         |
| <i>orig-vlan-id</i>  | (Optional) Original Vlan Id                           |
| <i>inner-vlan-id</i> | (Optional) Inner Vlan Id                              |
| <i>xlt-vlan-id</i>   | (Optional) Translated Vlan Id                         |
| <i>show-end</i>      | (Optional) Show vlan end marker                       |
| <i>true-end</i>      | (Optional) Show vlan end marker                       |

### Command Mode

- /exec



# show inventory

```
show inventory [ chassis | fans | power_supply | module [ <module> ] | <s0> [ <santa-cruz-range> ] | all ] [
__readonly__ TABLE_inv <name> <desc> <productid> <vendorid> <serialnum> ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                         |
| inventory               | system inventory information                            |
| chassis                 | (Optional) system inventory chassis information         |
| fans                    | (Optional) system inventory fan information             |
| power_supply            | (Optional) system inventory power supply information    |
| module                  | (Optional) system inventory module information          |
| <i>module</i>           | (Optional) please enter the module number               |
| <i>s0</i>               | (Optional) please enter the module number               |
| <i>santa-cruz-range</i> | (Optional) please enter the xbar number                 |
| all                     | (Optional) system and transceiver inventory information |
| <u>__readonly__</u>     | (Optional)  |
| TABLE_inv               | (Optional) Inventory table                              |
| <i>name</i>             | (Optional) Name of inventory                            |
| <i>desc</i>             | (Optional) Description of inventory                     |
| <i>productid</i>        | (Optional) Product ID                                   |
| <i>vendorid</i>         | (Optional) Vendor ID                                    |
| <i>serialnum</i>        | (Optional) Serial Number                                |

## Command Mode

- /exec

# show ip adjacency

```
show ip adjacency [ <interface> [ summary ] | <ip-addr> [ non-best | detail ] | detail | summary | non-best |
throttle ] statistics ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ <invalid_pkt_cnt> ] [
<invalid_byte_cnt> ] [ <global_drop_pkt_cnt> ] [ <global_drop_byte_cnt> ] [ <global_punt_pkt_cnt> ] [
<global_punt_byte_cnt> ] [ <global_glean_pkt_cnt> ] [ <global_glean_byte_cnt> ] [ <glean_pkt_cnt> ] [
<glean_byte_cnt> ] [ <normal_pkt_cnt> ] [ <normal_byte_cnt> ] [ <last_updated> ] [ <count-static> ] [
<count-dynamic> ] [ <count-others> ] [ <count-throttle> ] [ <count-total> ] [ TABLE_vrf <vrf-name-out> ]
TABLE_afi <afi> <count> [ TABLE_adj [ <intf-out> ] [ <ip-addr-out> ] [ <phy-intf> ] [ <mac> ] [ <pref> ]
[ <owner> ] [ <pkt-count> ] [ <byte-count> ] [ <mobility> ] [ <is-best> ] [ <is-thrtld> ] ] ] ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                         |
| ip                   | Display IP information                                  |
| adjacency            | Display adjacency table                                 |
| interface            | (Optional) Display specific interface adjacencies only  |
| ip-addr              | (Optional) IPV4 source address                          |
| detail               | (Optional) Show detail information of adjacency entries |
| summary              | (Optional) Show adjacency summary                       |
| non-best             | (Optional) Show both best/non-best entries              |
| throttle             | (Optional) Throttle                                     |
| statistics           | (Optional) Show adjacency statistics                    |
| vrf                  | (Optional) Display per-VRF information                  |
| vrf-name             | (Optional) VRF name                                     |
| vrf-known-name       | (Optional) Known VRF name                               |
| all                  | (Optional) Show adjacency entries for all vrfs          |
| __readonly__         | (Optional)  |
| TABLE_vrf            | (Optional) VRF table                                    |
| vrf-name-out         | (Optional) VRF name                                     |
| invalid_pkt_cnt      | (Optional) Invalid packet count                         |
| invalid_byte_cnt     | (Optional) Invalid byte count                           |
| global_drop_pkt_cnt  | (Optional) Global drop packet count                     |
| global_drop_byte_cnt | (Optional) Global drop byte count                       |

|                              |                                      |
|------------------------------|--------------------------------------|
| <i>global_punt_pkt_cnt</i>   | (Optional) Global packet punt count  |
| <i>global_punt_byte_cnt</i>  | (Optional) Global byte punt count    |
| <i>global_glean_pkt_cnt</i>  | (Optional) Global glean packet count |
| <i>global_glean_byte_cnt</i> | (Optional) Global glean byte count   |
| <i>glean_pkt_cnt</i>         | (Optional) Glean packet count        |
| <i>glean_byte_cnt</i>        | (Optional) Glean byte count          |
| <i>normal_pkt_cnt</i>        | (Optional) Packet count              |
| <i>normal_byte_cnt</i>       | (Optional) Byte count                |
| <i>last_updated</i>          | (Optional) Last updated              |
| <i>count-static</i>          | (Optional) Count static              |
| <i>count-dynamic</i>         | (Optional) Count dynamic             |
| <i>count-others</i>          | (Optional) Count others              |
| <i>count-throttle</i>        | (Optional) Count throttle            |
| <i>count-total</i>           | (Optional) Count total               |
| TABLE_afi                    | (Optional) TABLR afi                 |
| <i>afi</i>                   | (Optional) afi                       |
| <i>count</i>                 | (Optional) count                     |
| TABLE_adj                    | (Optional) Adjacency table           |
| <i>intf-out</i>              | (Optional) Interface                 |
| <i>phy-intf</i>              | (Optional) Physical interface        |
| <i>ip-addr-out</i>           | (Optional) IP address                |
| <i>mac</i>                   | (Optional) MAC address               |
| <i>pref</i>                  | (Optional) Preference                |
| <i>owner</i>                 | (Optional) Owner                     |
| <i>pkt-count</i>             | (Optional) Packet count              |
| <i>byte-count</i>            | (Optional) Byte count                |
| <i>mobility</i>              | (Optional) Mobility                  |
| <i>is-best</i>               | (Optional) Best                      |
| <i>is-thrtld</i>             | (Optional) Throttled                 |

**Command Mode**

- /exec

# show ip amt relay

```
show { ip | ipv6 } amt relay [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ TABLE_vrf <vrf>
<tut> <ra> <nds> <ldn> <nts> <lrn> <lra> <lq> <uc> <rc4> <rc6> ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| ip                    | Display IP information                         |
| ipv6                  | Display IPv6 information                       |
| vrf                   | (Optional) Display information for VRF         |
| <i>vrf-name</i>       | (Optional) VRF name                            |
| <i>vrf-known-name</i> | (Optional) Known VRF name                      |
| amt                   | AMT show commands                              |
| relay                 | Display status information about the AMT Relay |
| __readonly__          | (Optional)                                     |
| TABLE_vrf             | (Optional)                                     |
| <i>tut</i>            | (Optional)                                     |
| <i>ra</i>             | (Optional)                                     |
| <i>vrf</i>            | (Optional)                                     |
| <i>nds</i>            | (Optional)                                     |
| <i>ldn</i>            | (Optional)                                     |
| <i>nts</i>            | (Optional)                                     |
| <i>lrn</i>            | (Optional)                                     |
| <i>lra</i>            | (Optional)                                     |
| <i>lq</i>             | (Optional)                                     |
| <i>uc</i>             | (Optional)                                     |
| <i>rc4</i>            | (Optional)                                     |
| <i>rc6</i>            | (Optional)                                     |

## Command Mode

- /exec

## show ip amt route

```
show { ip | ipv6 } amt route [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ TABLE_vrf <vrf>
<rc4> <rc6> { TABLE_route <addrs> <if> <nbr> <gwa> <gw_exp> } ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information          |
| ip                    | Display IP information                   |
| ipv6                  | Display IPv6 information                 |
| vrf                   | (Optional) Display information for VRF   |
| <i>vrf-name</i>       | (Optional) VRF name                      |
| <i>vrf-known-name</i> | (Optional) Known VRF name                |
| amt                   | AMT show commands                        |
| route                 | Display multicast routes learned via AMT |
| __readonly__          | (Optional)                               |
| TABLE_vrf             | (Optional)                               |
| <i>vrf</i>            | (Optional)                               |
| <i>rc4</i>            | (Optional)                               |
| <i>rc6</i>            | (Optional)                               |
| TABLE_route           | (Optional)                               |
| <i>addrs</i>          | (Optional)                               |
| <i>if</i>             | (Optional)                               |
| <i>nbr</i>            | (Optional)                               |
| <i>gwa</i>            | (Optional)                               |
| <i>gw_exp</i>         | (Optional)                               |

### Command Mode

- /exec

# show ip amt tunnel

```
show ip amt tunnel [ <address4> <port> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__
TABLE_vrf <vrf> <tc4> { TABLE_tunnel <gwa> <gwp> <ut> <ld> <lr> <rc> <exp> { TABLE_route
<source> <group> <rexp> } } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| amt                   | AMT show commands                                   |
| ip                    | Display IP information                              |
| tunnel                | Display tunnel information                          |
| vrf                   | (Optional) Display information for VRF              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| <i>address4</i>       | (Optional) IP address of tunnel endpoint            |
| <i>port</i>           | (Optional) UDP port number of gateway               |
| detail                | (Optional) Display routes joined by tunnel endpoint |
| <u>__readonly__</u>   | (Optional)  |
| TABLE_vrf             | (Optional)  |
| <i>vrf</i>            | (Optional)  |
| <i>tc4</i>            | (Optional)  |
| TABLE_tunnel          | (Optional)  |
| <i>gwa</i>            | (Optional)  |
| <i>gwp</i>            | (Optional)  |
| <i>ut</i>             | (Optional)  |
| <i>ld</i>             | (Optional)  |
| <i>lr</i>             | (Optional)  |
| <i>rc</i>             | (Optional)  |
| <i>exp</i>            | (Optional)  |
| TABLE_route           | (Optional)  |
| <i>source</i>         | (Optional)  |

|              |            |
|--------------|------------|
| <i>group</i> | (Optional) |
| <i>rexp</i>  | (Optional) |

**Command Mode**

- /exec



# show ip arp

```
show ip arp [ [ [ <ip-address> | [ sync-entries | fhrp-non-active-learn ] [ detail ] | static | summary ] [ summary ] <interface> ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ] [ __readonly__ TABLE_vrf <vrf-name-out> [ <cnt-resolved> ] [ <cnt-incomplete> ] [ <cnt-thrtld-incomplete> ] [ <cnt-unknown> ] [ <cnt-total> ] [ TABLE_adj <intf-out> <ip-addr-out> [ <time-stamp> ] { <mac> | <unknown> | <incomplete> } ] [ <phy-intf> ] [ <flags> ] [ <adj-vrf-name> ] ] ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information   |
| ip                           | Display IP information  |
| arp                          | Display ARP table and statistics  |
| summary                      | (Optional) Display ARP adjacency summary  |
| detail                       | (Optional) Display detailed information   |
| sync-entries                 | (Optional) Display ARP table learnt only due to arp table sync                      |
| fhrp-non-active-learn        | (Optional) Display ARP table learnt only due to request for non-active FHRP address |
| <i>interface</i>             | (Optional) ARP interface  |
| <i>ip-address</i>            | (Optional) IP address   |
| vrf                          | (Optional) Display per-VRF information  |
| <i>vrf-name</i>              | (Optional) VRF name   |
| <i>vrf-known-name</i>        | (Optional) Known VRF name   |
| all                          | (Optional) Display ARP entries for all vrfs   |
| static                       | (Optional) Display Static ARP entries   |
| <i>__readonly__</i>          | (Optional)  |
| TABLE_vrf                    | (Optional) Show VRF table   |
| <i>vrf-name-out</i>          | (Optional) Show VRF name  |
| <i>cnt-resolved</i>          | (Optional) Show total resolved ARP entries  |
| <i>cnt-incomplete</i>        | (Optional) Show total incomplete ARP entreis  |
| <i>cnt-thrtld-incomplete</i> | (Optional) Show total incomplete throttled entries                                  |
| <i>cnt-unknown</i>           | (Optional) Show total unknow entris   |
| <i>cnt-total</i>             | (Optional) Show total   |

|                     |                                    |
|---------------------|------------------------------------|
| <i>TABLE_adj</i>    | (Optional) Show IP ARP             |
| <i>intf-out</i>     | (Optional) Show interface          |
| <i>ip-addr-out</i>  | (Optional) Show ip address         |
| <i>time-stamp</i>   | (Optional) Show age of adjacency   |
| <i>mac</i>          | (Optional) Show mac                |
| <i>unknown</i>      | (Optional) Show unknown entry      |
| <i>incomplete</i>   | (Optional) Show incomplete entry   |
| <i>phy-intf</i>     | (Optional) Show physical interface |
| <i>flags</i>        | (Optional) Show flags              |
| <i>adj-vrf-name</i> | (Optional) Show VRF name           |

**Command Mode**

- /exec

## show ip arp anycast topo-info

```
show ip arp anycast topo-info [ <topo-id> ] [ __readonly__ { TABLE_ip_arp_anycast_topo_info [
<ip_arp_anycat_topo_id> ] [ <ip_arp_anycast_feature> ] [ <ip_arp_anycast_mode> ] } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information           |
| ip                             | Configure IP features                     |
| arp                            | Configure ARP parameters                  |
| anycast                        | anycast feature info                      |
| topo-info                      | Per topology specific information         |
| <i>topo-id</i>                 | (Optional) Topology ID (VLAN-ID or BD-ID) |
| <i>__readonly__</i>            | (Optional)                                |
| TABLE_ip_arp_anycast_topo_info | (Optional) Show ip arp anycast topo-info  |
| <i>ip_arp_anycat_topo_id</i>   | (Optional) Show ARP anycast topo-id       |
| <i>ip_arp_anycast_feature</i>  | (Optional) Show ARP anycast feature       |
| <i>ip_arp_anycast_mode</i>     | (Optional) Show ARP anycast mode          |

### Command Mode

- /exec

# show ip arp client

```
show ip arp client [ __readonly__ { <arp-clients> } [ TABLE_arp_client_list { <arp-cli-uuid> <l2-client-type>
<client-flg> <mts-addr-sap> <cli-msg-cnt> [ <l2-cli-func-name> ] [ <l2-cli-dbg-func> ] [
<l2-cli-dbg-un-init-func> ] } ] ]
```

## Syntax Description

|                                |                                   |
|--------------------------------|-----------------------------------|
| show                           | Show running system information   |
| ip                             | Display IP information            |
| arp                            | Display ARP table and statistics  |
| client                         | Display ARP Client table          |
| <i>__readonly__</i>            | (Optional)                        |
| <i>arp-clients</i>             | (Optional) Number of ARP Clients  |
| <i>TABLE_arp_client_list</i>   | (Optional) Show ip arp client     |
| <i>arp-cli-uuid</i>            | (Optional) Protocol uuid          |
| <i>l2-client-type</i>          | (Optional) Client type            |
| <i>client-flg</i>              | (Optional) Flags                  |
| <i>mts-addr-sap</i>            | (Optional) SAP                    |
| <i>cli-msg-cnt</i>             | (Optional) Client message count   |
| <i>l2-cli-func-name</i>        | (Optional) Received function      |
| <i>l2-cli-dbg-func</i>         | (Optional) Debug init function    |
| <i>l2-cli-dbg-un-init-func</i> | (Optional) Debug Un-init function |

## Command Mode

- /exec

## show ip arp controller-statistics

```
show ip arp controller-statistics [ __readonly__ { TABLE_ip_arp_controller_statistics [
<arp_adj_controller_add_count> ] [ <arp_adj_controller_del_count> ] [ <arp_adj_controller_add_err_count>
] [ <arp_adj_controller_del_err> ] } ]
```

### Syntax Description

|   |                                       |
|---|---------------------------------------|
| show                                    | Show running system information       |
| ip                                      | Display IP information                |
| arp                                     | Display ARP table and statistics      |
| controller-statistics                   | Controller statistics                 |
| __readonly__                            | (Optional)                            |
| TABLE_ip_arp_controller_statistics      | (Optional) Show controller-statistics |
| <i>arp_adj_controller_add_count</i>     | (Optional)                            |
| <i>arp_adj_controller_del_count</i>     | (Optional)                            |
| <i>arp_adj_controller_add_err_count</i> | (Optional)                            |
| <i>arp_adj_controller_del_err</i>       | (Optional)                            |

### Command Mode

- /exec

# show ip arp esi

```
show ip arp esi [ __readonly__ { TABLE_ip_arp_esi [ <ip_arp_esi_interface> ] [ <ip_arp_esi_value> ] } ]
```

## Syntax Description

|                             |                                 |
|-----------------------------|---------------------------------|
| show                        | Show running system information |
| ip                          | Configure IP features           |
| arp                         | Configure ARP parameters        |
| esi                         | ESI information                 |
| __readonly__                | (Optional)                      |
| TABLE_ip_arp_esi            | (Optional) Show ip arp esi      |
| <i>ip_arp_esi_interface</i> | (Optional) Interface            |
| <i>ip_arp_esi_value</i>     | (Optional) Values               |

## Command Mode

- /exec

# show ip arp inspection

```
show ip arp inspection [ __readonly__ <src_mac_valid> <dest_mac_valid> <ip_addr_valid> TABLE_entry
<active_vlan_id> <is_insp_enabled> <oper_state> [ <acl_name> ] [ [ <acl_logging> ] <dhcp_logging> ] [
<req_fwded> <res_fwded> <req_dropped> <res_dropped> <dhcp_drops> [ <acl_drops> ] <dhcp_permits>
[ <acl_permits> ] <req_smac_fails> <res_smac_fails> <res_dmac_fails> <req_ip_fails> <res_ip_fails> ] ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information   |
| ip                     | Show the IP features of the system  |
| arp                    | IP ARP table  |
| inspection             | Status of ARP Inspection  |
| <i>__readonly__</i>    | (Optional) read only  |
| <i>src_mac_valid</i>   | (Optional) source ethernet address in header must be same as sender mac address in arp payload      |
| <i>dest_mac_valid</i>  | (Optional) destination ethernet address in header must be same as target mac address in arp payload |
| <i>ip_addr_valid</i>   | (Optional) validate the target ip address to filter broadcast/multicast address in arp payload      |
| TABLE_entry            | (Optional)  |
| <i>active_vlan_id</i>  | (Optional) active vlan id   |
| <i>is_insp_enabled</i> | (Optional)  |
| <i>oper_state</i>      | (Optional)  |
| <i>acl_name</i>        | (Optional)  |
| <i>acl_logging</i>     | (Optional)  |
| <i>dhcp_logging</i>    | (Optional)  |

## Command Mode

- /exec

## show ip arp inspection interfaces

```
show ip arp inspection interfaces [ <intf1> ] [ __readonly__ <intf_header> [ TABLE_intf <intf2> <trust_state> ] ]
```

### Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| ip                  | Show the IP features of the system |
| arp                 | IP ARP table                       |
| inspection          | Status of ARP Inspection           |
| interfaces          | Trust status of all interfaces     |
| <i>intf1</i>        | (Optional) interface               |
| <i>__readonly__</i> | (Optional)                         |
| TABLE_intf          | (Optional)                         |
| <i>intf_header</i>  | (Optional)                         |
| <i>intf2</i>        | (Optional)                         |
| <i>trust_state</i>  | (Optional)                         |

### Command Mode

- /exec



# show ip arp inspection log

```
show ip arp inspection log [ __readonly__ <log_buff_size> <log_rate_entries> <log_rate_interval> [
<log_frame> ] ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                          |
| ip                       | Show the IP features of the system                       |
| arp                      | IP ARP table   |
| inspection               | Status of ARP Inspection                                 |
| log                      | Log Buffer   |
| <i>__readonly__</i>      | (Optional)   |
| <i>log_buff_size</i>     | (Optional) number of entries per log buffer              |
| <i>log_rate_entries</i>  | (Optional) number of entries into log buffer per sec     |
| <i>log_rate_interval</i> | (Optional) time after which log buffer is updated in sec |
| <i>log_frame</i>         | (Optional) log frames in buffer                          |

## Command Mode

- /exec

## show ip arp inspection statistics

```
show ip arp inspection statistics [ vlan <vlan-range> ] [ __readonly__ TABLE_stats <vlanid> <req_fwded>
<res_fwded> <req_dropped> <res_dropped> <dhcp_drops> [ <acl_drops> ] <dhcp_permits> [ <acl_permits>
] <req_smac_fails> <res_smac_fails> <res_dmac_fails> <req_ip_fails> <res_ip_fails> ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                            |
| ip                  | Show the IP features of the system                         |
| arp                 | IP ARP table   |
| inspection          | Status of ARP Inspection                                   |
| statistics          | Status of ARP Inspection                                   |
| vlan                | (Optional) Selected vlan range                             |
| <i>vlan-range</i>   | (Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| <i>__readonly__</i> | (Optional)   |
| TABLE_stats         | (Optional)   |
| <i>vlanid</i>       | (Optional) ip arp inspection vlan id                       |

### Command Mode

- /exec

## show ip arp inspection vlan

```
show ip arp inspection { vlan <vlan-range> } [ __readonly__ <src_vlan_mac_valid> <dest_vlan_mac_valid>
<ip_vlan_addr_valid> TABLE_vlan <active_vlan_id> <is_insp_enabled> <oper_state> [ <dhcp_logging> ]
[ <acl_name> ] [ <acl_logging> ] ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information  |
| ip                         | Show the IP features of the system   |
| arp                        | IP ARP table   |
| inspection                 | Status of ARP Inspection   |
| vlan                       | Selected vlan range  |
| <i>vlan-range</i>          | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19  |
| <i>__readonly__</i>        | (Optional)   |
| <i>src_vlan_mac_valid</i>  | (Optional) validates header source mac address with sender mac address in arp payload      |
| <i>dest_vlan_mac_valid</i> | (Optional) validates header destination mac address with target mac address in arp payload |
| <i>ip_vlan_addr_valid</i>  | (Optional) filters invalid ip addresses like multicast/broadcast in arp requests/responses |
| TABLE_vlan                 | (Optional)   |
| <i>active_vlan_id</i>      | (Optional) active vlan id  |
| <i>is_insp_enabled</i>     | (Optional) ip arp inspection on vlan   |
| <i>oper_state</i>          | (Optional) operational on vlan   |
| <i>acl_name</i>            | (Optional) arp inspection access list name   |
| <i>acl_logging</i>         | (Optional) acl logging options   |
| <i>dhcp_logging</i>        | (Optional) ip arp inspection dhcp-binding logging options                                  |

### Command Mode

- /exec

## show ip arp l2 statistics interface

```
show ip arp l2 statistics interface { <interface> | all } [ __readonly__ { TABLE_ip_arp_l2_statistics
<arp-l2-port-ifname> <arp-l2-port-stats-rx-total> } ]
```

### Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information          |
| ip                                | Display IP information                   |
| arp                               | Display ARP table and statistics         |
| l2                                | Display ARP L2 port level info           |
| statistics                        | Display ARP statistics                   |
| interface                         | ARP interface                            |
| <i>interface</i>                  | ARP interface                            |
| all                               | Display ARP statistics for all interface |
| __readonly__                      | (Optional)                               |
| TABLE_ip_arp_l2_statistics        | (Optional) Show ip arp l2 stats          |
| <i>arp-l2-port-ifname</i>         | (Optional) Interface name                |
| <i>arp-l2-port-stats-rx-total</i> | (Optional) L2 port stats rx toal         |

### Command Mode

- /exec

## show ip arp multihoming-statistics

```
show ip arp multihoming-statistics [ <interface> ] [ interface-all ] [ vrf { <vrf-name> | <vrf-known-name> |
all } ] [ __readonly__ TABLE_vrf <vrf-name-out2> TABLE_stat <ps-recv-add-l2rib> <ps-proc-add-l2rib>
<ps-recv-del-l2rib> <ps-proc-del-l2rib> <ps-recv-pc-shut-l2rib> <ps-proc-pc-shut-l2rib>
<ps-recv-remote-upd-l2rib> <ps-proc-remote-upd-l2rib> <ps-add-err-invalid-flags> <ps-del-err-invalid-flags>
<ps-add-err-invalid-curr-state> <ps-del-err-invalid-curr-state> <ps-del-err-mac-mismatch> <ps-del-err-sec-del>
<ps-del-err-tl-route> <tl-del-err-psro-route> ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                                 |
| ip                              | Display IP information  |
| arp                             | Display ARP table and statistics                                |
| multihoming-statistics          | Display ARP Multihoming stats                                   |
| vrf                             | (Optional) Display per-VRF information                          |
| <i>vrf-name</i>                 | (Optional) VRF name   |
| <i>vrf-known-name</i>           | (Optional) Known VRF name                                       |
| all                             | (Optional) Display ARP Multihoming statistics for all vrfs      |
| interface-all                   | (Optional) Display ARP Multihoming statistics for all interface |
| <i>interface</i>                | (Optional) ARP interface  |
| <i>__readonly__</i>             | (Optional)  |
| TABLE_vrf                       | (Optional) VRF table  |
| <i>vrf-name-out2</i>            | (Optional) VRF name   |
| TABLE_stat                      | (Optional) Show ip arp multihoming statistics                   |
| <i>ps-recv-add-l2rib</i>        | (Optional) Received ADD from L2RIB                              |
| <i>ps-recv-del-l2rib</i>        | (Optional) Received DEL from L2RIB                              |
| <i>ps-recv-remote-upd-l2rib</i> | (Optional) Received remote UPD from L2RIB                       |
| <i>ps-recv-pc-shut-l2rib</i>    | (Optional) Received PC shut from L2RIB                          |
| <i>ps-proc-add-l2rib</i>        | (Optional) Processed ADD from L2RIB                             |
| <i>ps-proc-del-l2rib</i>        | (Optional) Processed DEL from L2RIB                             |
| <i>ps-proc-remote-upd-l2rib</i> | (Optional) Processed remote UPD from L2RIB                      |
| <i>ps-proc-pc-shut-l2rib</i>    | (Optional) Processed PC shut from L2RIB                         |

|                                      |  |
|--------------------------------------|--|
| <i>ps-add-err-invalid-flags</i>      | (Optional) Multihoming ADD error invalid flag          |
| <i>ps-del-err-invalid-flags</i>      | (Optional) Multihoming DEL error invalid flag          |
| <i>ps-add-err-invalid-curr-state</i> | (Optional) Multihoming ADD error invalid current state |
| <i>ps-del-err-invalid-curr-state</i> | (Optional) Multihoming DEL error invalid current state |
| <i>ps-del-err-mac-mismatch</i>       | (Optional) Peer sync DEL error MAC mismatch            |
| <i>ps-del-err-tl-route</i>           | (Optional) Peer sync DEL error second delete           |
| <i>tl-del-err-psro-route</i>         | (Optional) True local DEL error deleteing PS RO route  |
| <i>ps-del-err-sec-del</i>            | (Optional) Peer sync DEL error second delete           |

**Command Mode**

- /exec

## show ip arp off-list

```
show ip arp off-list [ { vlan | bdi } <vlan-id> ] [ __readonly__ [ <offlist-vlan-id> <vlan-adj-cnt> ] [
<arp-sync-adj-cnt> ] { TABLE_arp_vlan_list <adj-vlan-id> <off-adj-ip-addr> <time-stamp> <arp-mac-addr>
<off-adj-flags> } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                  |
| ip                      | Display IP information                           |
| arp                     | Display ARP table and statistics                 |
| off-list                | Show adjacencies in off-list arp database        |
| vlan                    | (Optional) Vlan id                               |
| bdi                     | (Optional) Bridge Domain Name/Id                 |
| <i>vlan-id</i>          | (Optional) Show information for specified vlan   |
| <i>__readonly__</i>     | (Optional)                                       |
| <i>offlist-vlan-id</i>  | (Optional) Show ip arp offlist vlan-id           |
| <i>vlan-adj-cnt</i>     | (Optional) Show ip arp vlan adjacency count      |
| <i>arp-sync-adj-cnt</i> | (Optional) Show arp sync adjacency count         |
| TABLE_arp_vlan_list     | (Optional) Show ip arp vlan list                 |
| <i>adj-vlan-id</i>      | (Optional) Show ip arp adjacency vlan id         |
| <i>off-adj-ip-addr</i>  | (Optional) Show arp offlist adjacency ip address |
| <i>time-stamp</i>       | (Optional) Show duration                         |
| <i>arp-mac-addr</i>     | (Optional) Show mac address                      |
| <i>off-adj-flags</i>    | (Optional) show offlist adjacency flgs           |

### Command Mode

- /exec

## show ip arp open-flow error-statistics

```
show ip arp open-flow error-statistics [ __readonly__ <arp_ofa_total_err_cnt> <arp_ofa_dp_adj_err_on_del>
<arp_ofa_cp_mac_mismatch_err_on_del> <arp_ofa_cp_null_mac_err_on_del>
<arp_ofa_cp_no_adj_err_on_del_flag> <arp_ofa_cp_cp_nh_mismatch_err_on_del>
<arp_ofa_cp_adj_del_failure_err> <arp_ofa_cp_null_mac_err_on_add>
<arp_ofa_cp_dp_mac_mismatch_err_on_add> <arp_ofa_cp_cp_mac_mismatch_err_on_add>
<arp_ofa_cp_added_first_err> <arp_ofa_dp_overwrite_cp_err> <arp_ofa_dp_cp_nh_mismatch_err_on_add>
<arp_ofa_cp_cp_nh_mismatch_err_on_add> <arp_ofa_cp_dp_nh_mismatch_err_on_add>
<arp_ofa_cp_adj_add_failure_err> <arp_ofa_peer_ip_lookup_rec_phy_iod_err>
<arp_ofa_peer_ip_ipv6_rec_phy_iod_err> <arp_ofa_peer_ip_lookup_adj_phy_iod_err>
<arp_ofa_peer_ip_ipv6_adj_phy_iod_err> <arp_ofa_barrier_response_err> ]
```

### Syntax Description

|  |   |
|--|---|
| show   | Show running system information                           |
| ip   | Configure IP features                                     |
| arp  | Configure ARP parameters                                  |
| open-flow                                    | open flow   |
| error-statistics                             | IR mode specific adjacency statistics                     |
| <i>__readonly__</i>                          | (Optional)  |
| <i>arp_ofa_total_err_cnt</i>                 | (Optional) OFA total error count                          |
| <i>arp_ofa_dp_adj_err_on_del</i>             | (Optional) Controller Deleting DP adjacency error         |
| <i>arp_ofa_cp_mac_mismatch_err_on_del</i>    | (Optional) CP adjacency MAC mismatch error while delete   |
| <i>arp_ofa_cp_null_mac_err_on_del</i>        | (Optional) CP adjacency NULL mac error while delete       |
| <i>arp_ofa_cp_no_adj_err_on_del_flag</i>     | (Optional) No adjacency found while delete                |
| <i>arp_ofa_cp_cp_nh_mismatch_err_on_del</i>  | (Optional) CP adjacency NH mismatch error while delete    |
| <i>arp_ofa_cp_adj_del_failure_err</i>        | (Optional) Other errors while deleting                    |
| <i>arp_ofa_cp_null_mac_err_on_add</i>        | (Optional) CP adjacency NULL mac error while Adding       |
| <i>arp_ofa_cp_dp_mac_mismatch_err_on_add</i> | (Optional) DP adjacency present with different mac        |
| <i>arp_ofa_cp_cp_mac_mismatch_err_on_add</i> | (Optional) CP adjacency present with different mac        |
| <i>arp_ofa_cp_added_first_err</i>            | (Optional) CP adjacency added first                       |
| <i>arp_ofa_dp_overwrite_cp_err</i>           | (Optional) Overwriting CP adjacency with DP               |
| <i>arp_ofa_dp_cp_nh_mismatch_err_on_add</i>  | (Optional) DP adjacency already present with different NH |
| <i>arp_ofa_cp_cp_nh_mismatch_err_on_add</i>  | (Optional) CP adjacency already present with different NH |



|   |   |
|---|---|
| <i>arp_ofa_cp_dp_nh_mismatch_err_on_add</i>   | (Optional) Overwriting CP adj with DP with different NH |
| <i>arp_ofa_cp_adj_add_failure_err</i>         | (Optional) Other errors while adding                    |
| <i>arp_ofa_peer_ip_lookup_rec_phy_iod_err</i> | (Optional) Peer IP lookup for received physical iod     |
| <i>arp_ofa_peer_ip_ipv6_rec_phy_iod_err</i>   | (Optional) Peer is IPv6 for received physical iod       |
| <i>arp_ofa_peer_ip_lookup_adj_phy_iod_err</i> | (Optional) Peer IP lookup for adjacency physical iod    |
| <i>arp_ofa_peer_ip_ipv6_adj_phy_iod_err</i>   | (Optional) Peer is IPv6 for adjacecny physical iod      |
| <i>arp_ofa_barrier_response_err</i>           | (Optional) Barrier responses                            |

**Command Mode**

- /exec

## show ip arp statistics

```
show ip arp statistics [ <interface> ] [ interface-all ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_vrf <vrf-name-out1> [ TABLE_stat <tx-total> <tx-req> <tx-reply> <tx-req-l2>
<tx-reply-l2> <tx-grat> <tx-tunnel> <tx-drop> [ <tx-srvrport> ] [ <tx-fbrport> ] [ <tx-fixup-core> ] [
<tx-fixup-server> ] [ <tx-fixup-rarp> ] [ <tx-anycast-glean> ] <tx-mbuf-fail> <tx-ctxt-not-crtd> <tx-bad-ctxt-id>
<tx-invalid-ifindex> <tx-invalid-sip> <tx-invalid-dip> <tx-own-ip> <tx-unattached-ip> <tx-adj-create-fail>
<tx-null-sip> <tx-null-smac> <tx-client-enq-fail> <tx-dest-unreachable-proxy-arp>
<tx-dest-unreachable-enhanced-proxy> <tx-dest-l2port-track> <tx-invalid-local-proxy> <tx-invalid-proxy>
<tx-vip-not-active> <tx-skip-refresh-over-core-and-flood-to-server> <rx-total> <rx-req> <rx-reply> <rx-req-l2>
<rx-reply-l2> <rx-proxy> <rx-local-proxy> <rx-enhanced-proxy> <rx-enhanced-proxy-anycast>
<rx-enhanced-proxy-l2port-track> <rx-tunnel> <rx-fastpath> <rx-snoop> <rx-drop> <rx-srvrport> <bad-if>
<bad-len> <invalid-opcode> <invalid-prot> <invalid-hrd-type> <invalid-ctxt> <ctxt-not-crtd> <invalid-l2>
<invalid-l3> <invalid-sip> <our-sip> <arp-if-no-mem> <subnet-mismatch> <dir-bcast> <invalid-dip>
<non-local-dst> <non-active-fhrp> <invalid-smac> <our-smac> <not-init> <l2-prxy-en> <l2-port-untrusted>
<stdby-fhrp-vip> <grat-prxy-en> <arp-req-ignore> <l2-intf> <l2fm-query-fail> <tunnel_fail> [
<hsrp-active-vmac> ] [ <rx-intf-down> ] <recv-glean-count> <refresh-req-from-clients> <l2rib-signals>
<skip-dyn-add> <adds> <dels> <timeouts> <del-dyn-stat-add> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| ip                    | Display IP information                              |
| arp                   | Display ARP table and statistics                    |
| statistics            | Display ARP statistics                              |
| vrf                   | (Optional) Display per-VRF information              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| all                   | (Optional) Display ARP statistics for all vrfs      |
| interface-all         | (Optional) Display ARP statistics for all interface |
| <i>interface</i>      | (Optional) ARP interface                            |
| <u>__readonly__</u>   | (Optional)  |
| TABLE_vrf             | (Optional) Table Vrf                                |
| <i>vrf-name-out1</i>  | (Optional) Show VRF name                            |
| TABLE_stat            | (Optional) Show IP ARP statistics                   |
| <i>tx-total</i>       | (Optional) Sent: total                              |
| <i>tx-req</i>         | (Optional) Sent: request                            |
| <i>tx-reply</i>       | (Optional) Sent: reply                              |

|   |  |
|---|--|
| <i>tx-req-l2</i>                          | (Optional) Sent: request on L2                       |
| <i>tx-reply-l2</i>                        | (Optional) Sent: replay on L2                        |
| <i>tx-grat</i>                            | (Optional) Sent: gratuitous                          |
| <i>tx-tunnel</i>                          | (Optional) Sent: tunnel packet                       |
| <i>tx-drop</i>                            | (Optional) Sent:Dropped packet                       |
| <i>tx-svrport</i>                         | (Optional) Sent from Server Port                     |
| <i>tx-fbrport</i>                         | (Optional) Sent from Fabric Port                     |
| <i>tx-fixup-core</i>                      | (Optional) Sent: fixup core                          |
| <i>tx-fixup-server</i>                    | (Optional) Sent: fixup server                        |
| <i>tx-fixup-rarp</i>                      | (Optional) Sent: fixup rarp                          |
| <i>tx-anycast-glean</i>                   | (Optional) Sent: modified anycast glean              |
| <i>tx-mbuf-fail</i>                       | (Optional) Sent:MBUF operation failed                |
| <i>tx-ctxt-not-crtd</i>                   | (Optional) Sent:Context not yet created              |
| <i>tx-bad-ctxt-id</i>                     | (Optional) Sent:Invalid context                      |
| <i>tx-invalid-ifindex</i>                 | (Optional) Sent:Invalid ifindex                      |
| <i>tx-invalid-sip</i>                     | (Optional) Sent:Invalid SRC IP                       |
| <i>tx-invalid-dip</i>                     | (Optional) Sent:Invalid DEST IP                      |
| <i>tx-own-ip</i>                          | (Optional) Sent:Destination is our own IP            |
| <i>tx-unattached-ip</i>                   | (Optional) Sent:Unattached IP                        |
| <i>tx-adj-create-fail</i>                 | (Optional) Sent:Adjacency Couldn't be added          |
| <i>tx-null-sip</i>                        | (Optional) Sent:Null Source IP                       |
| <i>tx-null-smac</i>                       | (Optional) Sent: Null Source MAC                     |
| <i>tx-client-enq-fail</i>                 | (Optional) Sent: Client Enqueue Failed               |
| <i>tx-dest-unreachable-proxy-arp</i>      | (Optional) Sent: Dest. not reachable for proxy arp   |
| <i>tx-dest-unreachable-enhanced-proxy</i> | (Optional) Sent:Dest. unreachable for enhanced proxy |
| <i>tx-dest-l2port-track</i>               | (Optional) Sent:Dest. on L2 port being tracked       |
| <i>tx-invalid-local-proxy</i>             | (Optional) Sent:Invalid Local proxy arp              |
| <i>tx-invalid-proxy</i>                   | (Optional) Sent:Invalid proxy arp                    |
| <i>tx-vip-not-active</i>                  | (Optional) Sent:VIP is not active                    |

|  |  |
|--|--|
| <i>tx-skip-refresh-over-core-and-flood-to-server</i> | (Optional) ARP refresh skipped over core and sent on server side |
| <i>rx-total</i>                                      | (Optional) Received: total                                       |
| <i>rx-req</i>  | (Optional) Received: Requests                                    |
| <i>rx-reply</i>                                      | (Optional) Received: Replies                                     |
| <i>rx-req-l2</i>                                     | (Optional) Received: Requests on L2                              |
| <i>rx-reply-l2</i>                                   | (Optional) Received: Replies on L2                               |
| <i>rx-proxy</i>                                      | (Optional) Received: Proxy arp                                   |
| <i>rx-local-proxy</i>                                | (Optional) Received: Local-Proxy arp                             |
| <i>rx-enhanced-proxy</i>                             | (Optional) Received: Enhanced Proxy arp                          |
| <i>rx-enhanced-proxy-anycast</i>                     | (Optional) Received: Anycast proxy Proxy arp                     |
| <i>rx-enhanced-proxy-l2port-track</i>                | (Optional) Received: L2 Port-track Proxy arp                     |
| <i>rx-tunnel</i>                                     | (Optional) Received: Tunneled                                    |
| <i>rx-fastpath</i>                                   | (Optional) Received: Fastpath                                    |
| <i>rx-snoop</i>                                      | (Optional) Received: Snooped                                     |
| <i>rx-drop</i>                                       | (Optional) Received: Dropped                                     |
| <i>rx-srvrport</i>                                   | (Optional) Received: on Server Port                              |
| <i>bad-if</i>  | (Optional) Appeared on a wrong interface                         |
| <i>bad-len</i>                                       | (Optional) Incorrect length                                      |
| <i>invalid-opcode</i>                                | (Optional) Invalid OPCODE packet                                 |
| <i>invalid-prot</i>                                  | (Optional) Invalid protocol packet                               |
| <i>invalid-hrd-type</i>                              | (Optional) Invalid Hardware type                                 |
| <i>invalid-ctxt</i>                                  | (Optional) Invalid context                                       |
| <i>ctxt-not-crtd</i>                                 | (Optional) Context not yet created                               |
| <i>invalid-l2</i>                                    | (Optional) Invalid layer 2 address length                        |
| <i>invalid-l3</i>                                    | (Optional) Invalid layer 3 address length                        |
| <i>invalid-sip</i>                                   | (Optional) Invalid source IP address                             |
| <i>our-sip</i>                                       | (Optional) Source IP address is our own                          |
| <i>arp-if-no-mem</i>                                 | (Optional) No mem to create per intf structure                   |
| <i>subnet-mismatch</i>                               | (Optional) Source address mismatch with subnet                   |

|                                 |  |
|---------------------------------|--|
| <i>dir-bcast</i>                | (Optional) Directed broadcast source                               |
| <i>invalid-dip</i>              | (Optional) Invalid destination IP address                          |
| <i>non-local-dst</i>            | (Optional) Non-local destination IP address                        |
| <i>non-active-fhrp</i>          | (Optional) Non-active FHRP dest IP address. Learn and drop         |
| <i>invalid-smac</i>             | (Optional) Invalid source MAC address                              |
| <i>our-smac</i>                 | (Optional) Source MAC address is our own                           |
| <i>not-init</i>                 | (Optional) Received before arp initialization                      |
| <i>l2-prxy-en</i>               | (Optional) L2 packet on proxy-arp-enabled interface                |
| <i>l2-port-untrusted</i>        | (Optional) L2 packet on untrusted L2 port                          |
| <i>stdby-fhrp-vip</i>           | (Optional) Packet with VIP on standby FHRP                         |
| <i>grat-prxy-en</i>             | (Optional) Grat arp received on proxy-arp-enabled interface        |
| <i>arp-req-ignore</i>           | (Optional) Requests came for existing entries                      |
| <i>l2-intf</i>                  | (Optional) Requests came on a L2 interface                         |
| <i>l2fm-query-fail</i>          | (Optional) L2FM query failed for a L2 Address                      |
| <i>tunnel_fail</i>              | (Optional) Dropping due to tunneling failures                      |
| <i>hsrp-active-vmac</i>         | (Optional) Dropping due to HSRP standby receiving HSRP active vmac |
| <i>rx-intf-down</i>             | (Optional) Received Interface Down                                 |
| <i>rcv-glean-count</i>          | (Optional) Glean requests rcv count                                |
| <i>refresh-req-from-clients</i> | (Optional) Refresh requests received from clients                  |
| <i>l2rib-signals</i>            | (Optional) Signals received from L2rib                             |
| <i>skip-dyn-add</i>             | (Optional) Skip Dynamic Adj Learning                               |
| <i>adds</i>                     | (Optional) Adds  |
| <i>dels</i>                     | (Optional) Deletes   |
| <i>timeouts</i>                 | (Optional) Timeouts  |
| <i>del-dyn-stat-add</i>         | (Optional) Delete Dynamic Adj on Static Add                        |

**Command Mode**

- /exec

## show ip arp suppression-cache

```
show ip arp suppression-cache { detail [ vlan <vlan_id> ] | summary | statistics | vlan <vlan_id> | local [ vlan
<vlan_id> ] | remote [ vlan <vlan_id> ] } [ __readonly__ TABLE_arp-suppression [ TABLE_entries <ip-addr>
<age> <mac> <vlan> <physical-iod> <flag> [ <remote-vtep-addr> | <remote-vtep-v6addr> ] ] [
TABLE_summary <remote-count> <local-count> <total-count> ] [ TABLE_stats TABLE_suppressed <total>
<requests> <requests-on-l2> <gratuitous> <gratuitous-on-l2> TABLE_forwarded <total-sent> <requests-sent>
<replies-sent> <requests-on-core-sent> <replies-on-core-sent> <arp-probe-flood> <dropped-sent>
<requests-on-l2-sent> <replies-on-l2-sent> <requests-on-core-l2-sent> <replies-on-core-l2-sent>
<arp-probe-flood-l2> <dropped-l2-sent> TABLE_received <total-recv> <requests-recv> <replies-recv>
<local-requests-recv> <local-replies-recv> <gratuitous-recv> <dropped-recv> <requests-on-l2-recv>
<replies-on-l2-recv> <gratuitous-l2-recv> <dropped-l2-recv> TABLE_entrystats <adds> <dels> ] ]
```

### Syntax Description

|                       |                                       |
|-----------------------|---------------------------------------|
| show                  | Show running system information       |
| ip                    | Display IP information                |
| arp                   | Display ARP table and statistics      |
| suppression-cache     | arp-suppression-cache                 |
| detail                | show details                          |
| summary               | show summary                          |
| statistics            | show statistics                       |
| local                 | show local entries                    |
| remote                | show remote entries                   |
| vlan                  | (Optional) L2vlan                     |
| <i>vlan_id</i>        | (Optional) Vlan                       |
| <u>__readonly__</u>   | (Optional)                            |
| TABLE_arp-suppression | (Optional) IP ARP suppression-cache   |
| TABLE_entries         | (Optional) IP ARP suppression entries |
| <i>ip-addr</i>        | (Optional) IP address                 |
| <i>age</i>            | (Optional) Age                        |
| <i>mac</i>            | (Optional) MAC address                |
| <i>vlan</i>           | (Optional) vlan id                    |
| <i>physical-iod</i>   | (Optional) Physical iod               |
| <i>flag</i>           | (Optional) Flags                      |

|                                 |   |
|---------------------------------|---|
| <i>remote-vtep-addr</i>         | (Optional) Remote Vtep Address                |
| TABLE_summary                   | (Optional) IP ARP suppression-cache Summary   |
| <i>remote-count</i>             | (Optional) Remote count                       |
| <i>local-count</i>              | (Optional) Local count                        |
| <i>total-count</i>              | (Optional) Total count                        |
| TABLE_stats                     | (Optional) Show IP ARP suppression statistics |
| TABLE_suppressed                | (Optional) Suppressed table                   |
| <i>total</i>                    | (Optional) total                              |
| <i>requests</i>                 | (Optional) request                            |
| <i>requests-on-l2</i>           | (Optional) requests-on-l2                     |
| <i>gratuitous</i>               | (Optional) gratuitous                         |
| <i>gratuitous-on-l2</i>         | (Optional) gratuitous-on-l2                   |
| TABLE_forwarded                 | (Optional) Forwarded table                    |
| <i>total-sent</i>               | (Optional) total                              |
| <i>requests-sent</i>            | (Optional) Requests sent on L3                |
| <i>replies-sent</i>             | (Optional) Replies sent on L3                 |
| <i>requests-on-core-sent</i>    | (Optional) Request on core port               |
| <i>replies-on-core-sent</i>     | (Optional) Reply on core port                 |
| <i>arp-probe-flood</i>          | (Optional) Flood ARP Probe                    |
| <i>dropped-sent</i>             | (Optional) Dropped                            |
| <i>requests-on-l2-sent</i>      | (Optional) Requests on L2                     |
| <i>replies-on-l2-sent</i>       | (Optional) Replies on L2                      |
| <i>requests-on-core-l2-sent</i> | (Optional) Request on core port L2            |
| <i>replies-on-core-l2-sent</i>  | (Optional) Reply on core port L2              |
| <i>arp-probe-flood-l2</i>       | (Optional) Flood ARP Probe L2                 |
| <i>dropped-l2-sent</i>          | (Optional) Dropped on L2                      |
| TABLE_received                  | (Optional) Received                           |
| <i>total-recv</i>               | (Optional) Total                              |
| <i>requests-recv</i>            | (Optional) Requests on L3 mode                |

|                            |   |
|----------------------------|---|
| <i>replies-recv</i>        | (Optional) Replies on L3 mode                           |
| <i>local-requests-recv</i> | (Optional) Local Request                                |
| <i>local-replies-recv</i>  | (Optional) Local Responses                              |
| <i>gratuitous-recv</i>     | (Optional) Gratuitous on L3 mode                        |
| <i>dropped-recv</i>        | (Optional) Dropped on L3 mode                           |
| <i>requests-on-l2-recv</i> | (Optional) Requests on L2 mode                          |
| <i>replies-on-l2-recv</i>  | (Optional) Replies on L2 mode                           |
| <i>gratuitous-l2-recv</i>  | (Optional) Gratuitous on L2 mode                        |
| <i>dropped-l2-recv</i>     | (Optional) Dropped on L2 mode                           |
| TABLE_entrystats           | (Optional) ARP suppression-cache Local entry statistics |
| <i>adds</i>                | (Optional) Adds   |
| <i>dels</i>                | (Optional) Deletes                                      |

**Command Mode**

- /exec



## show ip arp suppression topo-info

```
show ip arp suppression topo-info [ <topo-id> ] [ __readonly__ { TABLE_ip_arp_suppression_topo_info [
<ip_arp_suppression_topo_id> ] [ <ip_arp_suppression_mode> ] [ <ip_arp_suppression_hmm_mode> ] } ]
```

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                |
| ip                                 | Configure IP features                          |
| arp                                | Configure ARP parameters                       |
| suppression                        | ARP-suppression based event                    |
| topo-info                          | E-VPN identifier                               |
| <i>topo-id</i>                     | (Optional) E-VPN identifier (VLAN-ID or BD-ID) |
| <i>__readonly__</i>                | (Optional)                                     |
| TABLE_ip_arp_suppression_topo_info | (Optional) Show suppression topo-info          |
| <i>ip_arp_suppression_topo_id</i>  | (Optional) Show ARP suppression topo_id        |
| <i>ip_arp_suppression_mode</i>     | (Optional) Show ARP suppression mode           |
| <i>ip_arp_suppression_hmm_mode</i> | (Optional) Show ARP suppression hmm mode       |

### Command Mode

- /exec

## show ip arp tunnel-statistics

```
show ip arp tunnel-statistics [ __readonly__ { TABLE_ip_arp_tunnel_stat [ <arp-tun-pkt-rcv-cnt> ] [
<arp-tun-pkt-rcv-ing-vpc> ] [ <arp-tun-pkt-rcv-ing-gpc> ] [ <arp-tun-pkt-rcv-ing-orp-vpc> ] [
<arp-tun-pkt-rcv-ing-orp-vpc-pl> ] [ <arp-tun-pkt-snd-cnt> ] [ <arp-tun-pkt-snd-snoop-cnt> ] [
<arp-tun-pkt-snd-non-local-vip-cnt> ] [ <arp-tun-pkt-snd-peer-gate-cnt> ] [ <arp-tun-pkt-snd-ing-vpc> ] [
<arp-tun-pkt-snd-ing-gpc> ] [ <arp-tun-pkt-snd-ing-orp-vpc> ] [ <arp-tun-pkt-snd-ing-orp-vpc-pl> ] [
<arp-tun-pkt-rcv-drp-cnt> ] [ <arp-tun-pkt-snd-drp-cnt> ] [ <arp-tun-pkt-snd-drp-snd-fail-cnt> ] [
<arp-tun-pkt-rcv-drp-ver-cnt> ] [ <arp-tun-pkt-rcv-drp-pl-cnt> ] [ <arp-tun-pkt-rcv-drp-ing-non-mct> ] [
<arp-tun-pkt-rcv-drp-inv-ing-intf> ] [ <arp-tun-pkt-snd-drp-inv-ing-intf> ] [
<arp-tun-pkt-rcvdrp-inv-gpc-core-sw> ] [ <arp-tun-pkt-rcvdrp-inv-gpc-peer-sw> ] [ <arp-tun-pkt-drp-inv-mceec>
] [ <arp-tun-pkt-im-api-fail> ] [ <arp-tun-pkt-drp-ctxt-inv> ] [ <arp-tun-pkt-drp-mct-dwn> ] [
<arp-tun-pkt-rcv-drp-mbuf-op-fail> ] [ <arp-tun-pkt-snd-drp-mbuf-op-fail> ] [ <arp-tun-pkt-snd-drp-tunnel>
] [ <arp-tun-pkt-snd-drp-ce> ] [ <arp-tun-pkt-snd-drp-inv-gpc> ] [ <arp-tun-pkt-rcv-drp-inv-gpc> ] [
<arp-tun-pkt-sys-mceecm-key-not-found> ] } ]
```

### Syntax Description

|  |  |
|--|--|
| show                                     | Show running system information                        |
| ip                                       | Display IP information                                 |
| arp                                      | Display ARP table and statistics                       |
| tunnel-statistics                        | Display ARP statistics for tunneled packets            |
| __readonly__                             | (Optional)   |
| TABLE_ip_arp_tunnel_stat                 | (Optional) ARP Tunnel statistics                       |
| <i>arp-tun-pkt-rcv-cnt</i>               | (Optional) Total tunneled packets received             |
| <i>arp-tun-pkt-rcv-ing-vpc</i>           | (Optional) Tunneled packets rx for ingress vPC         |
| <i>arp-tun-pkt-rcv-ing-gpc</i>           | (Optional) Tunneled packets rx for ingress GPC         |
| <i>arp-tun-pkt-rcv-ing-orp-vpc</i>       | (Optional) Tunneled Packets rx for ingress orphan vPC  |
| <i>arp-tun-pkt-rcv-ing-orp-vpc-pl</i>    | (Optional) Tunneled Packets rx for ingress orphan vPC+ |
| <i>arp-tun-pkt-snd-cnt</i>               | (Optional) Total tunneled packets sent                 |
| <i>arp-tun-pkt-snd-snoop-cnt</i>         | (Optional) Tunneled packets Sent for ARP Snoop         |
| <i>arp-tun-pkt-snd-non-local-vip-cnt</i> | (Optional) Tunneled packets sent for Non-Local VIP     |
| <i>arp-tun-pkt-snd-peer-gate-cnt</i>     | (Optional) Tunneled Packets sent for Peer Gateway      |
| <i>arp-tun-pkt-snd-ing-vpc</i>           | (Optional) Tunneled packets tx for ingress vPC         |
| <i>arp-tun-pkt-snd-ing-gpc</i>           | (Optional) Tunneled packets tx for ingress GPC         |
| <i>arp-tun-pkt-snd-ing-orp-vpc</i>       | (Optional) Tunneled Packets tx for ingress orphan vPC  |

|  |  |
|--|--|
| <i>arp-tun-pkt-snd-ing-orp-vpc-pl</i>      | (Optional) Tunneled Packets tx for ingress orphan vPC+ |
| <i>arp-tun-pkt-rcv-drp-cnt</i>             | (Optional) Total tunnel packets rcv dropped            |
| <i>arp-tun-pkt-snd-drp-cnt</i>             | (Optional) Total tunnel packets send dropped           |
| <i>arp-tun-pkt-snd-drp-snd-fail-cnt</i>    | (Optional) Drops due to send failed                    |
| <i>arp-tun-pkt-rcv-drp-ver-cnt</i>         | (Optional) Received packet with invalid version        |
| <i>arp-tun-pkt-rcv-drp-pl-cnt</i>          | (Optional) Received packet with invalid payload type   |
| <i>arp-tun-pkt-rcv-drp-ing-non-mct</i>     | (Optional) Received packet on non mct interface        |
| <i>arp-tun-pkt-rcv-drp-inv-ing-intf</i>    | (Optional) Received packet with invalid ingress port   |
| <i>arp-tun-pkt-snd-drp-inv-ing-intf</i>    | (Optional) Drop send packets for invalid ingress port  |
| <i>arp-tun-pkt-rcvdrp-inv-gpc-core-sw</i>  | (Optional) Drop rcv pkt, invalid GPC of core switch    |
| <i>arp-tun-pkt-rcvdrp-inv-gpc-peer-sw</i>  | (Optional) Drop rcv pkt, invalid GPC of peer switch    |
| <i>arp-tun-pkt-drp-inv-mcec</i>            | (Optional) Failed to retrieve vPC ID while processing  |
| <i>arp-tun-pkt-im-api-fail</i>             | (Optional) IM api failed while processing              |
| <i>arp-tun-pkt-drp-ctxt-inv</i>            | (Optional) Drop tunnel packet as context is invalid    |
| <i>arp-tun-pkt-drp-mct-dwn</i>             | (Optional) Drop tunnel packet as mct is down           |
| <i>arp-tun-pkt-rcv-drp-mbuf-op-fail</i>    | (Optional) Drop rcv packets as mbuf operation failed   |
| <i>arp-tun-pkt-snd-drp-mbuf-op-fail</i>    | (Optional) Drop send packets as mbuf operation failed  |
| <i>arp-tun-pkt-snd-drp-tunnel</i>          | (Optional) Cannot tunnel a incoming tunneled packet    |
| <i>arp-tun-pkt-snd-drp-ce</i>              | (Optional) Cannot tunnel in a CE network               |
| <i>arp-tun-pkt-snd-drp-inv-gpc</i>         | (Optional) Drop send pkt, failed in retrieving the GPC |
| <i>arp-tun-pkt-rcv-drp-inv-gpc</i>         | (Optional) Drop rcv pkt, failed in retrieving the GPC  |
| <i>arp-tun-pkt-sys-mcecm-key-not-found</i> | (Optional) MCEC_ID to PHY_IF_INDEX not found in DB     |

### Command Mode

- /exec

## show ip arp vpc-statistics

```
show ip arp vpc-statistics [ __readonly__ { TABLE_arp_vpc_stats [ <arp-pro-drp-pull-disable> ] [
<arp-pro-drp-push-msg-disable> ] [ <arp-pro-ign-snd-pull-disabe> ] [ <arp-ign-snd-push-disable> ] [
<arp-drp-im-fail> ] [ <arp-drp-mcecm-fail> ] [ <arp-drp-invalid-pc-iod> ] [ <arp-drp-pt-lookup-fail> ] [
<arp-drp-resp-fail-no-mct> ] [ <arp-drp-resp-fail> ] [ <arp-mcecm-ifidx-vpc-fail> ] [
<arp-mcecm-vpc-ifidx-fail> ] [ <arp-periodic-mcecm-ifidx-vpc-fail> ] [ <arp-resp-sent> ] [ <arp-resp-recvd>
] [ <arp-resp-recv-err> ] [ <arp-rcvd-msg> ] [ <arp-send-fail> ] [ <arp-cfs-rel-dlvry-fail> ] [
<arp-cfs-rel-dnvry-suc> ] [ <arp-pkt-vmct-drop-count> ] [ <arp-drp-pt-add-fail> ] [ <arp-drp-no-mem> ] [
<arp-drp-tmr-cre-fail> ] [ <arp-drp-add-adj-fail> ] [ <arp-off-drp-pt-lookup-fail> ] [ <arp-dont-drp-vlan-mismat>
] [ <arp-drp-svi-invalid> ] [ <arp-dont-drop-sv-down> ] [ <arp-drp-mct-down> ] [ <arp-drp-ctxt-invalid> ] [
<arp-drp-vrf-invalid> ] [ <arp-drp-l3addr-invalid> ] [ <arp-drp-l3addr-sanity-fail> ] [ <arp-drp-mac-sanity-fail>
] [ <arp-own-rtr-mac> ] [ <arp-drp-own-ipaddr> ] [ <arp-drp-own-vipadd> ] [ <arp-drp-adj-fail> ] [
<arp-drp-subnet-mismatch> ] [ <arp-drp-adj-exist> ] [ <arp-dont-drp-ip-not-enable> ] [ <arp-drp-total-cnt>
] [ <arp-dont-drop-total-cnt> ] [ <arp-drp-inval-phy-iod> ] [ <arp-add-adj> ] [ <arp-del-adj> ] [
<arp-adj-already-exist> ] [ <arp-sync-recv-op-add-adj> ] [ <arp-sync-recv-op-del-adj> ] [
<arp-sync-push-msg-adj-cnt> ] [ <arp-sync-send-op-add-adj> ] [ <arp-sync-send-op-del-adj> ] [
<arp-sync-adj-cnt> ] [ <arp-sync-addadj-fail> ] [ <arp-sync-drp-svi-inv> ] [ <arp-sync-drp-svi-dwn> ] [
<arp-sync-drp-ctxt-inv> ] [ <arp-sync-null-adj> ] [ <arp-sync-invalid-ip> ] [ <arp-periodic-sync-adj-l2-supp-cnt>
] [ <arp-periodic-sync-stop-bcast-pkt-sync-count> ] [ <arp-periodic-sync-vmct-stop-orphan-sync-count> ] ]
]
```

### Syntax Description

|  |  |
|--|--|
| show                                     | Show running system information                                      |
| ip                                       | Display IP information   |
| arp                                      | Display ARP table and statistics                                     |
| vpc-statistics                           | Show vPC global statistics   |
| <i>__readonly__</i>                      | (Optional)   |
| <i>TABLE_arp_vpc_stats</i>               | (Optional) Arp Vpc statistics  |
| <i>arp-mcecm-ifidx-vpc-fail</i>          | (Optional) Unable to retrieve VPC id from ifidx                      |
| <i>arp-mcecm-vpc-ifidx-fail</i>          | (Optional) Unable to retrieve ifidx from VPC id                      |
| <i>arp-periodic-mcecm-ifidx-vpc-fail</i> | (Optional) Unable to retrieve ifidx from VPC id during periodic sync |
| <i>arp-sync-recv-op-add-adj</i>          | (Optional) Total adjacencies recieved from peer to add               |
| <i>arp-sync-recv-op-del-adj</i>          | (Optional) Total adjacencies received from peer to delete            |
| <i>arp-sync-push-msg-adj-cnt</i>         | (Optional) Total gross adjacencies sent periodically                 |
| <i>arp-sync-send-op-add-adj</i>          | (Optional) Total adjacencies sent to peer to add                     |
| <i>arp-sync-send-op-del-adj</i>          | (Optional) Total adjacencies sent to peer to delete                  |
| <i>arp-sync-adj-cnt</i>                  | (Optional) Total periodic sync adjacencies                           |

|  |   |
|--|---|
| <i>arp-sync-addadj-fail</i>                        | (Optional) Failure in adding adjacencies while periodic sync send       |
| <i>arp-sync-drp-svi-inv</i>                        | (Optional) Total drops during periodic sync because of invalid svi      |
| <i>arp-sync-drp-svi-dwn</i>                        | (Optional) Total drops during periodic sync because of svi down         |
| <i>arp-sync-drp-ctxt-inv</i>                       | (Optional) Total drops during periodic sync because of invalid context  |
| <i>arp-sync-null-adj</i>                           | (Optional) Total drops while processing syne of NULL Adjacencies        |
| <i>arp-sync-invalid-ip</i>                         | (Optional) Total drops while processing sync because of NULL IP         |
| <i>arp-periodic-sync-adj-l2-supp-cnt</i>           | (Optional) Total periodic sync adjacenciesadded for L2 suppression case |
| <i>arp-periodic-sync-stop-bcast-pkt-sync-count</i> | (Optional) Total Bcast packets that was stopped sync to peer            |
| <i>arp-pro-drp-pull-disable</i>                    | (Optional) Drop the received CFS pull request                           |
| <i>arp-pro-drp-push-msg-disable</i>                | (Optional) Drop the received CFS push message                           |
| <i>arp-pro-ign-snd-pull-disabe</i>                 | (Optional) Ignore to send pull request using CFSoE                      |
| <i>arp-ign-snd-push-disable</i>                    | (Optional) Ignore to send push message using CFSoE                      |
| <i>arp-drp-im-fail</i>                             | (Optional) IM api failed while processing CFS payload                   |
| <i>arp-drp-mcecm-fail</i>                          | (Optional) MCECM api failed while processing CFS payload                |
| <i>arp-drp-invalid-pc-iod</i>                      | (Optional) Invalid MCT port-channel iod                                 |
| <i>arp-drp-pt-lookup-fail</i>                      | (Optional) PT lookup failed while processing CFS payload                |
| <i>arp-drp-resp-fail-no-mct</i>                    | (Optional) Sending CFS response failed due to invalid MCT iod           |
| <i>arp-drp-resp-fail</i>                           | (Optional) Sending CFS response failed                                  |
| <i>arp-resp-sent</i>                               | (Optional) Response sent via CFSoE                                      |
| <i>arp-resp-recvd</i>                              | (Optional) Response received via CFSoE                                  |
| <i>arp-resp-recv-err</i>                           | (Optional) Response received via CFSoE with errors                      |
| <i>arp-rcvd-msg</i>                                | (Optional) Received message via CFSoE                                   |
| <i>arp-send-fail</i>                               | (Optional) Send message failed via CFSoE                                |
| <i>arp-cfs-rel-dlvry-fail</i>                      | (Optional) MCECM send api failed via CFSoE                              |
| <i>arp-cfs-rel-dnvry-suc</i>                       | (Optional) Send message succeeded via CFSoE                             |
| <i>arp-drp-pt-add-fail</i>                         | (Optional) PT add failed while processing offlist                       |
| <i>arp-drp-no-mem</i>                              | (Optional) Memory alloc failed while processing offlist databse         |
| <i>arp-drp-tmr-cre-fail</i>                        | (Optional) Timer create failed while processing offlist database        |

|  |  |
|--|--|
| <i>arp-drp-add-adj-fail</i>                          | (Optional) Adjacency addition failed while processing offlist database     |
| <i>arp-off-drp-pt-lookup-fail</i>                    | (Optional) PT lookup failed while processing offlist database              |
| <i>arp-dont-drp-vlan-mismat</i>                      | (Optional) VLAN mismatch while processing offlist database                 |
| <i>arp-drp-svi-invalid</i>                           | (Optional) SVI is invalid while processing offlist database                |
| <i>arp-dont-drop-sv-down</i>                         | (Optional) SVI is down while processing offlist database                   |
| <i>arp-drp-mct-down</i>                              | (Optional) MCT is down while processing offlist database                   |
| <i>arp-drp-ctxt-invalid</i>                          | (Optional) Ctxt_type is invalid while processing offlist database          |
| <i>arp-drp-vrf-invalid</i>                           | (Optional) VRF is invalid while processing offlist database                |
| <i>arp-drp-l3addr-invalid</i>                        | (Optional) VRF is invalid while processing offlist database                |
| <i>arp-drp-l3addr-sanity-fail</i>                    | (Optional) IP address sanity failed  |
| <i>arp-drp-mac-sanity-fail</i>                       | (Optional) MAC address sanity failed                                       |
| <i>arp-own-rtr-mac</i>                               | (Optional) Our own router mac  |
| <i>arp-drp-own-ipaddr</i>                            | (Optional) Our own ip address  |
| <i>arp-drp-own-vipaddr</i>                           | (Optional) Our own virtual ip address                                      |
| <i>arp-drp-adj-fail</i>                              | (Optional) Create adjacency failed   |
| <i>arp-drp-subnet-mismatch</i>                       | (Optional) Subnet mismatch   |
| <i>arp-drp-adj-exist</i>                             | (Optional) Entry exists  |
| <i>arp-dont-drp-ip-not-enable</i>                    | (Optional) IP not enabled on interface                                     |
| <i>arp-drp-inval-phy-iod</i>                         | (Optional) Physical interface invalid                                      |
| <i>arp-drp-total-cnt</i>                             | (Optional) Total drop count  |
| <i>arp-dont-drop-total-cnt</i>                       | (Optional) Total don't drop count  |
| <i>arp-add-adj</i>                                   | (Optional) Total adjacency additions                                       |
| <i>arp-del-adj</i>                                   | (Optional) Total adjacency deletions                                       |
| <i>arp-adj-already-exist</i>                         | (Optional) Total adjacencies ignored as already exist                      |
| <i>arp-pkt-vmct-drop-count</i>                       | (Optional) Total virtual-mct packets dropped                               |
| <i>arp-periodic-sync-vmct-stop-orphan-sync-count</i> | (Optional) Total virtual-mct orphan hosts that was stopped syncing to peer |

**Command Mode**

- /exec

# show ip as-path-access-list

```
show ip as-path-access-list [ <aspl-name> | <aspl-cfg-name> ] [ __readonly__ TABLE_aspl <name> <seq>
<action> <rule> ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information           |
| ip                   | Display IP information                    |
| as-path-access-list  | List AS path access lists                 |
| <i>aspl-name</i>     | (Optional) AS path access list name       |
| <i>aspl-cfg-name</i> | (Optional) Known as-path access-list name |
| <i>__readonly__</i>  | (Optional)                                |
| TABLE_aspl           | (Optional)                                |
| <i>name</i>          | (Optional)                                |
| <i>seq</i>           | (Optional)                                |
| <i>action</i>        | (Optional)                                |
| <i>rule</i>          | (Optional)                                |

## Command Mode

- /exec





# show ip community-list

```
show ip community-list [ <cl_name> ] [ __readonly__ TABLE_cl <name> <seq> <action> <rule> ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| ip                  | Display IP information                              |
| community-list      | List community-list                                 |
| <i>cl_name</i>      | (Optional) Standard or expanded community-list name |
| <i>__readonly__</i> | (Optional)  |
| <i>TABLE_cl</i>     | (Optional)  |
| <i>name</i>         | (Optional)  |
| <i>seq</i>          | (Optional)  |
| <i>action</i>       | (Optional)  |
| <i>rule</i>         | (Optional)  |

## Command Mode

- /exec

## show ip dhcp global statistics

```
show ip dhcp global statistics [ __readonly__ <pkts_processed> <pkts_rcvd_through_cfsoe> <pkts_fwded>
<pkts_cfsoe_fwded> <pkts_dropped> <pkts_dropped_from_untrusted_ports>
<pkts_dropped_src_mac_chk_fail> <pkts_dropped_opt82_ins_fail> <pkts_dropped_unknown_op_intf>
<pkts_dropped_unknown_pkt> <pkts_dropped_no_trust_inf> <pkts_dropped_relay_disable>
<pkts_dropped_no_binding_entry> <pkts_dropped_interface_error> <pkts_dropped_max_hops_exceeded>
<pkts_dropped_queue_full> ]
```

### Syntax Description

|  |  |
|--|--|
| show                                     | Show running system information                                |
| ip                                       | Show the IP features of the system                             |
| dhcp                                     | Show information about DHCP                                    |
| global                                   | DHCP global stats  |
| statistics                               | Statistics related to DHCP                                     |
| <i>__readonly__</i>                      | (Optional) Read only   |
| <i>pkts_processed</i>                    | (Optional) Packets processed                                   |
| <i>pkts_rcvd_through_cfsoe</i>           | (Optional) Packets received through cfsoe                      |
| <i>pkts_fwded</i>                        | (Optional) Packets forwarded                                   |
| <i>pkts_cfsoe_fwded</i>                  | (Optional) Packets forwarded on cfsoe                          |
| <i>pkts_dropped</i>                      | (Optional) Total packets dropped                               |
| <i>pkts_dropped_from_untrusted_ports</i> | (Optional) Packets dropped from untrusted ports                |
| <i>pkts_dropped_src_mac_chk_fail</i>     | (Optional) Packets dropped due to MAC address check failure    |
| <i>pkts_dropped_opt82_ins_fail</i>       | (Optional) Packets dropped due to Option 82 insertion failure  |
| <i>pkts_dropped_unknown_op_intf</i>      | (Optional) Packets dropped due to o/p intf unknown             |
| <i>pkts_dropped_unknown_pkt</i>          | (Optional) Packets dropped which were unknown                  |
| <i>pkts_dropped_no_trust_inf</i>         | (Optional) Packets dropped due to no trusted ports             |
| <i>pkts_dropped_relay_disable</i>        | (Optional) Packets dropped due to dhcp relay not enabled       |
| <i>pkts_dropped_no_binding_entry</i>     | (Optional) Packets dropped due to no binding entry             |
| <i>pkts_dropped_interface_error</i>      | (Optional) Packets dropped due to interface error/no interface |
| <i>pkts_dropped_max_hops_exceeded</i>    | (Optional) Packets dropped due to max hops exceeded            |
| <i>pkts_dropped_queue_full</i>           | (Optional) Packets dropped due to queue full                   |

**Command Mode**

- /exec

## show ip dhcp option82 suboption info interface

```
show ip dhcp option82 suboption info interface [ <intf> ][ __readonly__ <intf_header> { TABLE_intf_option82
<intf_name> <option82_status> [ <suboption_string> ] [ <tx_count> ] } ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                       |
| ip                      | Show the IP features of the system                    |
| dhcp                    | Show items in DHCP                                    |
| option82                | DHCP option82   |
| suboption               | DHCP option82 suboption                               |
| info                    | DHCP option82 suboption information                   |
| interface               | DHCP option82 suboption information of all interfaces |
| <i>intf</i>             | (Optional) interface                                  |
| <i>__readonly__</i>     | (Optional) Read only                                  |
| <i>intf_header</i>      | (Optional)  |
| TABLE_intf_option82     | (Optional)  |
| <i>intf_name</i>        | (Optional)  |
| <i>option82_status</i>  | (Optional)  |
| <i>suboption_string</i> | (Optional)  |
| <i>tx_count</i>         | (Optional)  |

### Command Mode

- /exec

## show ip dhcp relay

```
show ip dhcp relay [ __readonly__ <relay_service_enable> <relay_opt82_enable> <relay_opt82_customize>
<relay_subopt_VPN_enable> <relay_subopt_type_cisco_enable> <global_smart-relay_enable>
<global_relay_trusted_enable> <relay_trusted_port_enable> <global_src_addr_hsrp_enable>
<smart_relay_intfs_hdr> <server_id_override> [ TABLE_intf <smart_relay_enabled_intfs> ]
<subnet_bcast_intfs_hdr> [ TABLE_intf <subnet_bcast_enabled_intfs> ] <trusted_port_intfs_hdr> [
TABLE_intf <trusted_port_enabled_intfs> ] <relay_src_addr_hsrp_hdr> [ TABLE_intf
<src_addr_hsrp_enabled_intfs> ] <relay_address_hdr> [ TABLE_intf <intf> <relay_address> <vrf_name> ]
]
```

### Syntax Description

|                                       |  |
|---------------------------------------|--|
| show                                  | Show running system information                              |
| ip                                    | Show the IP features of the system                           |
| dhcp                                  | Show items in DHCP   |
| relay                                 | DHCP relay   |
| <i>__readonly__</i>                   | (Optional) Read only   |
| <i>relay_service_enable</i>           | (Optional)   |
| <i>relay_opt82_enable</i>             | (Optional)   |
| <i>relay_opt82_customize</i>          | (Optional)   |
| <i>relay_subopt_VPN_enable</i>        | (Optional)   |
| <i>relay_subopt_type_cisco_enable</i> | (Optional)   |
| <i>global_smart-relay_enable</i>      | (Optional)   |
| <i>global_relay_trusted_enable</i>    | (Optional)   |
| <i>relay_trusted_port_enable</i>      | (Optional)   |
| <i>global_src_addr_hsrp_enable</i>    | (Optional) V4 Relay src-addr hsrp is globally enabled or not |
| <i>server_id_override</i>             | (Optional)   |
| <i>smart_relay_intfs_hdr</i>          | (Optional) Smart relay interfaces header                     |
| TABLE_intf                            | (Optional)   |
| <i>smart_relay_enabled_intfs</i>      | (Optional) smart-relay enabled interfaces                    |
| <i>subnet_bcast_intfs_hdr</i>         | (Optional) Subnet broadcast interfaces header                |
| TABLE_intf                            | (Optional)   |
| <i>subnet_bcast_enabled_intfs</i>     | (Optional) subnet_bcast enabled interfaces                   |

|                                   |  |
|-----------------------------------|--|
| <i>trusted_port_intf_hdr</i>      | (Optional) Trusted port interfaces header                  |
| TABLE_intf                        | (Optional)   |
| <i>trusted_port_enabled_intf</i>  | (Optional) trusted_port enabled interfaces                 |
| <i>relay_src_addr_hsrp_hdr</i>    | (Optional) Header for V4 Relay src-addr enabled interfaces |
| TABLE_intf                        | (Optional)   |
| <i>src_addr_hsrp_enabled_intf</i> | (Optional) source-address hsrp enabled interfaces          |
| <i>relay_address_hdr</i>          | (Optional) relay address header                            |
| TABLE_intf                        | (Optional) Table for list of interfaces                    |
| <i>intf</i>                       | (Optional) interface name                                  |
| <i>relay_address</i>              | (Optional) helper address                                  |
| <i>vrf_name</i>                   | (Optional) vrf name  |

**Command Mode**

- /exec

# show ip dhcp relay address

```
show ip dhcp relay address [ interface <intf-range> ] [ __readonly__ <intf_header> [ TABLE_intf <intf2>
<relay_address> <vrf_name> ] ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                |
| ip                   | Show the IP features of the system             |
| dhcp                 | Show DHCP                                      |
| relay                | relay address of the interface                 |
| address              | DHCP relay address                             |
| interface            | (Optional) DHCP relay address of the interface |
| <i>intf-range</i>    | (Optional) interface                           |
| <i>__readonly__</i>  | (Optional) Read only                           |
| <i>intf_header</i>   | (Optional) interface header                    |
| TABLE_intf           | (Optional)                                     |
| <i>intf2</i>         | (Optional) interface name                      |
| <i>relay_address</i> | (Optional) helper address                      |
| <i>vrf_name</i>      | (Optional) VRF name                            |

## Command Mode

- /exec

# show ip dhcp relay information trusted-sources

show ip dhcp relay information trusted-sources [ \_\_readonly\_\_ <header> [ TABLE\_intf <intf> ] ]

## Syntax Description

|                 |                                    |
|-----------------|------------------------------------|
| show            | Show running system information    |
| ip              | Show the IP features of the system |
| dhcp            | Show DHCP                          |
| relay           | DHCP Relay                         |
| information     | Relay information                  |
| trusted-sources | Relay Trusted Sources              |
| __readonly__    | (Optional) Read only               |
| TABLE_intf      | (Optional) trusted interface table |
| <i>header</i>   | (Optional) interface header        |
| <i>intf</i>     | (Optional) interface name          |

## Command Mode

- /exec



## show ip dhcp relay statistics

```
show ip dhcp relay statistics [ interface <intf> | { interface <intf> serverip <ip-addr-val> [ use-vrf <vrf-name>
] } ] [ __readonly__ [ <msg_stats_hdr> <msg_type_str> <rx_pkts> <tx_pkts> <drops> <msg_type_str_offer>
<offer_rx_pkts> <offer_tx_pkts> <offer_drops> <msg_type_str_request> <request_rx_pkts> <request_tx_pkts>
<request_drops> <msg_type_str_ack> <ack_rx_pkts> <ack_tx_pkts> <ack_drops> <msg_type_str_release>
<release_rx_pkts> <release_tx_pkts> <release_drops> <msg_type_str_decline> <decline_rx_pkts>
<decline_tx_pkts> <decline_drops> <msg_type_str_inform> <inform_rx_pkts> <inform_tx_pkts>
<inform_drops> <msg_type_str_nack> <nack_rx_pkts> <nack_tx_pkts> <nack_drops> <line>
<msg_type_str_total> <total_rx_pkts> <total_tx_pkts> <total_drops> <line_x> ] [ <server_consolidated_hdr>
[ TABLE_server_info <server_helper_addr> <server_vrf> <server_total_request> <server_total_response>
] <line_y> ] [ <l3_fwd_hdr> <l3_fwd_rx_pkts> <l3_fwd_tx_pkts> <l3_fwd_drops> <non_dhcp_hdr>
<non_dhcp_rx_pkts> <non_dhcp_tx_pkts> <non_dhcp_drops> <drop_hdr> <drop_validation_fail>
<drop_relay_disable> <drop_invalid_msg_type> <drop_intf_err> <drop_tx_sock_err>
<drop_tx_fail_client_intf> <drop_unknown_op_intf> <drop_l3_unknown_op_intf> <drop_max_hops>
<drop_opt82_insert_fail> <drop_malformed> <drop_mct_drop> <drop_untrusted_relay_intf> ] [
<server_discover> <server_request> <server_decline> <server_release> <server_inform> <server_ack>
<server_nack> <server_offer> <server_resp_hdr> <drop_unknown> <server_req_hdr> ] <footer> ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information           |
| ip                   | Show the IP features of the system        |
| dhcp                 | Show information about DHCP               |
| relay                | DHCP Relay                                |
| statistics           | Statistics related to DHCP                |
| interface            | (Optional) input interface                |
| <i>intf</i>          | (Optional) interface                      |
| serverip             | (Optional) Helper address                 |
| <i>ip-addr-val</i>   | (Optional) IP address                     |
| use-vrf              | (Optional) helper address VRF membership  |
| <i>vrf-name</i>      | (Optional) VRF name                       |
| <i>__readonly__</i>  | (Optional) Read only                      |
| <i>msg_stats_hdr</i> | (Optional) dhcp message statistics header |
| <i>msg_type_str</i>  | (Optional) dhcp message type              |
| <i>rx_pkts</i>       | (Optional) received dhcp packets          |
| <i>tx_pkts</i>       | (Optional) forwarded dhcp packets         |
| <i>drops</i>         | (Optional) dhcp packet drops              |

|                             |                                   |
|-----------------------------|-----------------------------------|
| <i>msg_type_str_offer</i>   | (Optional) dhcp message type      |
| <i>offer_rx_pkts</i>        | (Optional) received dhcp packets  |
| <i>offer_tx_pkts</i>        | (Optional) forwarded dhcp packets |
| <i>offer_drops</i>          | (Optional) dhcp packet drops      |
| <i>msg_type_str_request</i> | (Optional) dhcp message type      |
| <i>request_rx_pkts</i>      | (Optional) received dhcp packets  |
| <i>request_tx_pkts</i>      | (Optional) forwarded dhcp packets |
| <i>request_drops</i>        | (Optional) dhcp packet drops      |
| <i>msg_type_str_ack</i>     | (Optional) dhcp message type      |
| <i>ack_rx_pkts</i>          | (Optional) received dhcp packets  |
| <i>ack_tx_pkts</i>          | (Optional) forwarded dhcp packets |
| <i>ack_drops</i>            | (Optional) dhcp packet drops      |
| <i>msg_type_str_release</i> | (Optional) dhcp message type      |
| <i>release_rx_pkts</i>      | (Optional) received dhcp packets  |
| <i>release_tx_pkts</i>      | (Optional) forwarded dhcp packets |
| <i>release_drops</i>        | (Optional) dhcp packet drops      |
| <i>msg_type_str_decline</i> | (Optional) dhcp message type      |
| <i>decline_rx_pkts</i>      | (Optional) received dhcp packets  |
| <i>decline_tx_pkts</i>      | (Optional) forwarded dhcp packets |
| <i>decline_drops</i>        | (Optional) dhcp packet drops      |
| <i>msg_type_str_inform</i>  | (Optional) dhcp message type      |
| <i>inform_rx_pkts</i>       | (Optional) received dhcp packets  |
| <i>inform_tx_pkts</i>       | (Optional) forwarded dhcp packets |
| <i>inform_drops</i>         | (Optional) dhcp packet drops      |
| <i>msg_type_str_nack</i>    | (Optional) dhcp message type      |
| <i>nack_rx_pkts</i>         | (Optional) received dhcp packets  |
| <i>nack_tx_pkts</i>         | (Optional) forwarded dhcp packets |
| <i>nack_drops</i>           | (Optional) dhcp packet drops      |
| <i>line</i>                 | (Optional)                        |

|                                 |   |
|---------------------------------|---|
| <i>msg_type_str_total</i>       | (Optional) total dhcp packets of all message types  |
| <i>total_rx_pkts</i>            | (Optional) total forwarded dhcp packets             |
| <i>total_tx_pkts</i>            | (Optional) total forwarded dhcp packets             |
| <i>total_drops</i>              | (Optional) total dhcp drops                         |
| <i>line_x</i>                   | (Optional)  |
| <i>server_consolidated_hdr</i>  | (Optional) DHCP server stats                        |
| TABLE_server_info               | (Optional)  |
| <i>server_helper_addr</i>       | (Optional) dhcp server address                      |
| <i>server_vrf</i>               | (Optional) dhcp server vrf                          |
| <i>server_total_request</i>     | (Optional) total dhcp requests to server            |
| <i>server_total_response</i>    | (Optional) total dhcp responses from server         |
| <i>line_y</i>                   | (Optional)  |
| <i>l3_fwd_hdr</i>               | (Optional) DHCP l3 forward header                   |
| <i>l3_fwd_rx_pkts</i>           | (Optional) DHCP l3 received packets                 |
| <i>l3_fwd_tx_pkts</i>           | (Optional) DHCP l3 forwarded packets                |
| <i>l3_fwd_drops</i>             | (Optional) DHCP l3 forward drops                    |
| <i>non_dhcp_hdr</i>             | (Optional) non dhcp packets header                  |
| <i>non_dhcp_rx_pkts</i>         | (Optional) total non dhcp packets received          |
| <i>non_dhcp_tx_pkts</i>         | (Optional) total non dhcp packets forwarded         |
| <i>non_dhcp_drops</i>           | (Optional) total non dhcp drops                     |
| <i>drop_hdr</i>                 | (Optional) total dhcp drops in various scenarios    |
| <i>drop_validation_fail</i>     | (Optional) drops due to option 82 validation failed |
| <i>drop_relay_disable</i>       | (Optional) drops due to dhcp relay not enabled      |
| <i>drop_invalid_msg_type</i>    | (Optional) drops due to invalid message type        |
| <i>drop_intf_err</i>            | (Optional) drops due to interface error             |
| <i>drop_tx_sock_err</i>         | (Optional) tx failure towards server                |
| <i>drop_tx_fail_client_intf</i> | (Optional) drops due to Tx failure towards client   |
| <i>drop_unknown_op_intf</i>     | (Optional) Unknown output interface                 |
| <i>drop_l3_unknown_op_intf</i>  | (Optional) unknown vrf interface for server         |

|                                  |   |
|----------------------------------|---|
| <i>drop_max_hops</i>             | (Optional) drops due to max hop exceeded            |
| <i>drop_opt82_insert_fail</i>    | (Optional) Insertion of option 82 failed            |
| <i>drop_malformed</i>            | (Optional) drops due to packet malformed            |
| <i>drop_mct_drop</i>             | (Optional) drops through mct                        |
| <i>drop_untrusted_relay_intf</i> | (Optional) drops due to untrusted relay interface   |
| <i>server_discover</i>           | (Optional) DHCP discover messages relayed to server |
| <i>server_request</i>            | (Optional) DHCP request messages relayed to server  |
| <i>server_decline</i>            | (Optional) DHCP decline messages relayed to server  |
| <i>server_release</i>            | (Optional) DHCP release messages relayed to server  |
| <i>server_inform</i>             | (Optional) DHCP inform messages relayed to server   |
| <i>server_ack</i>                | (Optional) DHCP ack messages relayed from server    |
| <i>server_nack</i>               | (Optional) DHCP nack messages relayed from server   |
| <i>server_offer</i>              | (Optional) DHCP offer messages relayed from server  |
| <i>server_resp_hdr</i>           | (Optional) DHCP server response header              |
| <i>drop_unknown</i>              | (Optional) drops due to Unknown Failure             |
| <i>server_req_hdr</i>            | (Optional) DHCP server request header               |
| <i>footer</i>                    | (Optional) footer line                              |

**Command Mode**

- /exec

# show ip dhcp snooping

```
show ip dhcp snooping [ __readonly__ [ <snoop_service_enable> ] <snoop_gbl_enable> [ <snoop_vlan_enable>
] [ <snoop_oper_vlan_enable> ] <snoop_opt82_enable> <snoop_hwaddr_verify_enable> <snoop_hdr> [ {
TABLE_intf_entry <intf_entry_if_index> <intf_entry_trust_dhcp> <intf_entry_pkt_limit> } ] ]
```

## Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information                               |
| ip                                | Show the IP features of the system                            |
| dhcp                              | Show items in DHCP  |
| snooping                          | DHCP snooping   |
| <i>__readonly__</i>               | (Optional) Read only  |
| <i>snoop_service_enable</i>       | (Optional)  |
| <i>snoop_gbl_enable</i>           | (Optional)  |
| <i>snoop_vlan_enable</i>          | (Optional)  |
| <i>snoop_oper_vlan_enable</i>     | (Optional)  |
| <i>snoop_opt82_enable</i>         | (Optional)  |
| <i>snoop_hwaddr_verify_enable</i> | (Optional)  |
| <i>snoop_hdr</i>                  | (Optional)  |
| TABLE_intf_entry                  | (Optional)  |
| <i>intf_entry_if_index</i>        | (Optional)  |
| <i>intf_entry_trust_dhcp</i>      | (Optional) is DHCP snooping trusted on the interface          |
| <i>intf_entry_pkt_limit</i>       | (Optional) limit for DHCP packets per second on the interface |

## Command Mode

- /exec

# show ip dhcp snooping binding

show ip dhcp snooping binding [ <ip> | <mac> | vlan <vlan-range> |

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                            |
| ip                | Show the IP features of the system                         |
| dhcp              | Show items in DHCP   |
| snooping          | DHCP snooping  |
| binding           | DHCP snooping bindings                                     |
| <i>ip</i>         | (Optional) Binding entry IP address                        |
| <i>mac</i>        | (Optional) Binding entry MAC address                       |
| vlan              | (Optional) Binding entry VLAN                              |
| <i>vlan-range</i> | (Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |

## Command Mode

- /exec

# show ip dhcp snooping statistics

```
show ip dhcp snooping statistics [ { vlan <vlan-id> interface <intf> } |
```

## Syntax Description

|                |                                    |
|----------------|------------------------------------|
| <i>vlan-id</i> | (Optional) ]                       |
| show           | Show running system information    |
| ip             | Show the IP features of the system |
| dhcp           | Show information about DHCP        |
| snooping       | DHCP snooping                      |
| statistics     | Statistics related to DHCP         |
| vlan           | (Optional) VLAN                    |
| interface      | (Optional) input interface         |
| <i>intf</i>    | (Optional) interface               |

## Command Mode

- /exec

# show ip dhcp status

show ip dhcp status [ *\_\_readonly\_\_* [ *<current\_cli\_op>* ] [ *<last\_cli\_op>* *<last\_cli\_stat>* ] ]

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                              |
| ip                    | Show the IP features of the system                           |
| dhcp                  | Show information about DHCP                                  |
| status                | Current CLI command and execution status of the last command |
| <i>__readonly__</i>   | (Optional) Read only   |
| <i>current_cli_op</i> | (Optional) current cli operation                             |
| <i>last_cli_op</i>    | (Optional) last cli operation                                |
| <i>last_cli_stat</i>  | (Optional) last cli status                                   |

## Command Mode

- /exec



# show ip dns source-interface

```
show ip dns source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipdnsvrf
<vrfname> <ifname> } ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information              |
| ip                    | Display IP information                       |
| dns                   | Display domain-lookup information            |
| source-interface      | Display source interface information         |
| vrf                   | (Optional) Display per-VRF information       |
| <i>vrf-name</i>       | (Optional) VRF name                          |
| <i>vrf-known-name</i> | (Optional) Known VRF name                    |
| <i>__readonly__</i>   | (Optional)                                   |
| TABLE_ipdnsvrf        | (Optional) source interface of dns given vrf |
| <i>vrfname</i>        | (Optional) vrfname                           |
| <i>ifname</i>         | (Optional) ifname                            |

## Command Mode

- /exec

# show ip dns source-interface vrf all

```
show ip dns source-interface vrf all [ __readonly__ [ { TABLE_ipdns <vrfname> <ifname> } ] ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | Display IP information               |
| dns              | Display domain-lookup information    |
| source-interface | Display source interface information |
| vrf              | Display per-VRF information          |
| all              | Display entries for all vrfs         |
| __readonly__     | (Optional)                           |
| TABLE_ipdns      | (Optional) source interface of dns   |
| <i>vrfname</i>   | (Optional) vrfname                   |
| <i>ifname</i>    | (Optional) ifname                    |

## Command Mode

- /exec

## show ip eigrp

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_asn <asn> <router_id> TABLE_vrf <vrf> <eigrp_ptag> <instance_num> <state> <authen_md5>
<authen_keychain> <metric_weight_k1> <metric_weight_k2> <metric_weight_k3> <metric_weight_k4>
<metric_weight_k5> [ <metric_weight_k6> <metric_ribscale> ] <metric_version> <eigrp_proto> {
<multicast_group> | <multicast_groupv6> } <int_distance> <ext_distance> <max_paths> <active_interval>
<num_interfaces> <num_lo_interfaces> <num_pass_interfaces> <num_peers> [ { TABLE_redist
<redist_srcproto> <redist_routemap> } ] <tmap_route_map> [ <tmap_filter_configured> ]
<default_info_originate> [ <default_info_route_map> <default_info_originate_always> ] <graceful_restart>
<stub_configured> [ <stub_option_connected> <stub_option_summary> <stub_option_redist>
<stub_option_leak_map> <stub_option_receive_only> ] <isolate> <nsf_converge_time>
<nsf_converge_expiries> <nsf_route_hold_time> <nsf_route_hold_expiries> <nsf_signal_time>
<nsf_signal_expiries> <redist_max_prefix> [ <redist_max_prefix_mode> <redist_prefix_count>
<redist_prefix_max> <redist_limit_threshold> <redist_limit_retry_count> <redist_limit_retry_max>
<redist_limit_timer_left> <redist_limit_timeout> ] <bfd_enabled> <eigrp_mmode> [ { TABLE_command_q
<addr> <mask> } ] <await_redist_proto_converge> <suppress_fib_pending> <nsf_in_progress> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ipv6                  | Display IPv6 information                    |
| eigrp                 | Display EIGRP status and configuration      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>eigrp-ptag</i>     | (Optional) Process tag                      |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_asn             | (Optional) AS Number table                  |
| <i>asn</i>            | (Optional) AS number                        |
| <i>router_id</i>      | (Optional) Router-ID                        |
| TABLE_vrf             | (Optional) VRF table                        |
| <i>vrf</i>            | (Optional) VRF name                         |
| <i>eigrp_ptag</i>     | (Optional) Process-tag for EIGRP            |
| <i>instance_num</i>   | (Optional) EIGRP Instance Number            |

|                               |   |
|-------------------------------|---|
| <i>state</i>                  | (Optional) EIGRP Process Status   |
| <i>authen_md5</i>             | (Optional) Authentication Mode  |
| <i>authen_keychain</i>        | (Optional) Authentication Key-Chain                                     |
| <i>metric_weight_k1</i>       | (Optional) DUAL metric k1   |
| <i>metric_weight_k2</i>       | (Optional) DUAL metric k2   |
| <i>metric_weight_k3</i>       | (Optional) DUAL metric k3   |
| <i>metric_weight_k4</i>       | (Optional) DUAL metric k4   |
| <i>metric_weight_k5</i>       | (Optional) DUAL metric k5   |
| <i>metric_weight_k6</i>       | (Optional) DUAL metric k6   |
| <i>metric_rib_scale</i>       | (Optional) RIB Scale  |
| <i>metric_version</i>         | (Optional) Metric version   |
| <i>eigrp_proto</i>            | (Optional) IP Protocol number   |
| <i>multicast_group</i>        | (Optional) Multicast Group Address                                      |
| <i>int_distance</i>           | (Optional) Internal Administrative Distance                             |
| <i>ext_distance</i>           | (Optional) External Administrative Distance                             |
| <i>max_paths</i>              | (Optional) Maximum paths allowed for a dndb                             |
| <i>active_interval</i>        | (Optional) Active Interval in minutes                                   |
| <i>num_interfaces</i>         | (Optional) Number of EIGRP interfaces configured under this AS          |
| <i>num_lo_interfaces</i>      | (Optional) Number of EIGRP loopback interfaces configured under this AS |
| <i>num_pass_interfaces</i>    | (Optional) Number of EIGRP Passive interfaces configured under this AS  |
| <i>num_peers</i>              | (Optional) Number of EIGRP peers  |
| TABLE_redist                  | (Optional) Redistribution Table   |
| <i>redist_srcproto</i>        | (Optional) Source protocol of the redistributed route                   |
| <i>redist_routemap</i>        | (Optional) Route-map used in this redistribution                        |
| <i>tmap_route_map</i>         | (Optional) Tablemap Policy name   |
| <i>tmap_filter_configured</i> | (Optional) Tablemap filter configured?                                  |
| <i>default_info_originate</i> | (Optional) Default-info Policy Originate?                               |

|                                      |   |
|--------------------------------------|---|
| <i>default_info_route_map</i>        | (Optional) Default-info Policy name                   |
| <i>default_info_originate_always</i> | (Optional) Default-info Originate always?             |
| <i>graceful_restart</i>              | (Optional) Graceful restart configured?               |
| <i>stub_configured</i>               | (Optional) Stub-Routing configured?                   |
| <i>stub_option_connected</i>         | (Optional) Advertise connected routes?                |
| <i>stub_option_summary</i>           | (Optional) Advertise summary routes?                  |
| <i>stub_option_redist</i>            | (Optional) Advertise redistributed routes?            |
| <i>stub_option_leak_map</i>          | (Optional) Allow routes permitted by leak-map?        |
| <i>stub_option_receive_only</i>      | (Optional) Configured as receive only?                |
| <i>isolate</i>                       | (Optional) Isolate is enabled                         |
| <i>nsf_converge_time</i>             | (Optional) NSF converge time limit                    |
| <i>nsf_converge_expires</i>          | (Optional) NSF converge time expires                  |
| <i>nsf_route_hold_time</i>           | (Optional) NSF route-hold time limit                  |
| <i>nsf_route_hold_expires</i>        | (Optional) NSF route-hold time expires                |
| <i>nsf_signal_time</i>               | (Optional) NSF signal time limit                      |
| <i>nsf_signal_expires</i>            | (Optional) NSF signal time expires                    |
| <i>redist_max_prefix</i>             | (Optional) Redistributed max-prefix enabled?          |
| <i>redist_max_prefix_mode</i>        | (Optional) Redistributed max-prefix mode              |
| <i>redist_prefix_count</i>           | (Optional) Redistributed prefix count                 |
| <i>redist_prefix_max</i>             | (Optional) Redistributed prefix max                   |
| <i>redist_limit_threshold</i>        | (Optional) Redistributed max-prefix warning threshold |
| <i>redist_limit_retry_count</i>      | (Optional) Redistributed max-prefix retries attempted |
| <i>redist_limit_retry_max</i>        | (Optional) Redistributed max-prefix retries allowed   |
| <i>redist_limit_timer_left</i>       | (Optional) Redistributed max-prefix timer left        |
| <i>redist_limit_timeout</i>          | (Optional) Redistributed max-prefix timeout           |
| <i>bfd_enabled</i>                   | (Optional) Is BFD enabled?                            |
| <i>eigrp_mmode</i>                   | (Optional) EIGRP MMODE initialized?                   |
| TABLE_command_q                      | (Optional) Network commands table                     |
| <i>addr</i>                          | (Optional) IP address                                 |

|                                    |   |
|------------------------------------|---|
| <i>mask</i>                        | (Optional) Mask length                                |
| <i>await_redist_proto_converge</i> | (Optional) Await-Redist-proto-convergence configured? |
| <i>suppress_fib_pending</i>        | (Optional) Suppress-FIB-Pending configured?           |
| <i>nsf_in_progress</i>             | (Optional) NSF in progress?                           |

**Command Mode**

- /exec

# show ip eigrp accounting

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] accounting [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_asn <asn> <router_id> TABLE_vrf <vrf> <total_prefix> <redist_state> <redist_count>
<restart_count> <acct_timer> [ TABLE_peer { <p_ipaddr> | <p_ipv6addr> } <p_state> <p_ifname>
<p_prefix_count> <p_restart_count> <p_acct_timer> ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| ip                    | Display IP information                              |
| ipv6                  | Display IPv6 information                            |
| eigrp                 | Display EIGRP status and configuration              |
| vrf                   | (Optional) Display per-VRF information              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| all                   | (Optional) Display information for all VRFs         |
| <i>eigrp-ptag</i>     | (Optional) Process tag                              |
| accounting            | IP-EIGRP Accounting                                 |
| <i>__readonly__</i>   | (Optional)  |
| TABLE_asn             | (Optional) AS number table                          |
| <i>asn</i>            | (Optional) AS number                                |
| <i>router_id</i>      | (Optional) Router-ID                                |
| TABLE_vrf             | (Optional) VRF table                                |
| <i>vrf</i>            | (Optional) VRF name                                 |
| <i>total_prefix</i>   | (Optional) Total prefix count (Aggregate)           |
| <i>redist_state</i>   | (Optional) State of redistributed prefixes          |
| <i>redist_count</i>   | (Optional) Number of redistributed prefixes         |
| <i>restart_count</i>  | (Optional) Number of times the prefix was suspended |
| <i>acct_timer</i>     | (Optional) Accounting timer                         |
| TABLE_peer            | (Optional) Peer (Prefix) table                      |
| <i>p_ipaddr</i>       | (Optional) Peer IP addr                             |

|                        |   |
|------------------------|---|
| <i>p_state</i>         | (Optional) Peer state                               |
| <i>p_ifname</i>        | (Optional) Peering interface                        |
| <i>p_prefix_count</i>  | (Optional) Number of Prefixes learnt from the peer  |
| <i>p_restart_count</i> | (Optional) Number of times the prefix was suspended |
| <i>p_acct_timer</i>    | (Optional) Peer accounting timer                    |

**Command Mode**

- /exec



# show ip eigrp interfaces

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] interfaces [ detail ] [ <interface> ] [ brief ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_asn <asn> TABLE_vrf <vrf> [ TABLE_if <ifname>
<peer_count> <xmitq_unrel> <xmitq_rel> <mean_srtt> <send_intvl_unrel> <send_intvl_rel>
<mcast_flow_delay> <pending_routes> [ <hello_intvl> <holdtime_intvl> <next_xmit_serno>
<packetize_pending> <mcasts_sent_unrel> <mcasts_sent_rel> <ucasts_sent_unrel> <ucasts_sent_rel>
<mcast_exceptions> <cr_packets> <acks_suppressed> <retrans_sent> <out_of_seq_rcvd> <stub_interface>
<nexthop_self> <auth_mode_md5> <auth_key_chain> <use_multicast> <classic_metric_peers>
<wide_metric_peers> <bfd_enabled> ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ipv6                  | Display IPv6 information                    |
| eigrp                 | Display EIGRP status and configuration      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>eigrp-ptag</i>     | (Optional) Process tag                      |
| interfaces            | IP-EIGRP interfaces                         |
| detail                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>interface</i>      | (Optional) Interface                        |
| brief                 | (Optional) Show summary information only    |
| __readonly__          | (Optional)                                  |
| TABLE_asn             | (Optional) AS number table                  |
| <i>asn</i>            | (Optional) AS number                        |
| TABLE_vrf             | (Optional) VRF table                        |
| <i>vrf</i>            | (Optional) VRF name                         |
| TABLE_if              | (Optional) Interface table                  |
| <i>ifname</i>         | (Optional) Interface name                   |
| <i>peer_count</i>     | (Optional) Number of Peer on this interface |

|                             |  |
|-----------------------------|--|
| <i>xmitq_unrel</i>          | (Optional) Xmit Q (unreliable) count                                   |
| <i>xmitq_rel</i>            | (Optional) Xmit Q (reliable) count                                     |
| <i>mean_srtt</i>            | (Optional) Mean of all peer SRTTs                                      |
| <i>send_intvl_unrel</i>     | (Optional) Base packet gap, per queue (unreliable)                     |
| <i>send_intvl_rel</i>       | (Optional) Base packet gap, per queue (reliable)                       |
| <i>mcast_flow_delay</i>     | (Optional) Last delay for Multicast flow control timer                 |
| <i>pending_routes</i>       | (Optional) Pending routes on the interface                             |
| <i>hello_intvl</i>          | (Optional) Configured hello interval for interface                     |
| <i>holdtime_intvl</i>       | (Optional) Configured holdtime interval for interface                  |
| <i>next_xmit_serno</i>      | (Optional) Next xmit serial number                                     |
| <i>packetize_pending</i>    | (Optional) Packetization pending?                                      |
| <i>mcasts_sent_unrel</i>    | (Optional) Number of Multicasts sent (unreliable)                      |
| <i>mcasts_sent_rel</i>      | (Optional) Number of Multicasts sent (reliable)                        |
| <i>ucasts_sent_unrel</i>    | (Optional) Number of Unicasts sent (unreliable)                        |
| <i>ucasts_sent_rel</i>      | (Optional) Number of Unicasts sent (reliable)                          |
| <i>mcast_exceptions</i>     | (Optional) Multicast exceptions (Count of multicasts sent as unicasts) |
| <i>cr_packets</i>           | (Optional) Count of Multicasts sent with CR                            |
| <i>acks_suppressed</i>      | (Optional) Count of suppressed ACK packets                             |
| <i>retrans_sent</i>         | (Optional) Count of Retransmissions sent                               |
| <i>out_of_seq_rcvd</i>      | (Optional) Count of packets received Out-of-Sequence                   |
| <i>stub_interface</i>       | (Optional) All Peers are stubbed?                                      |
| <i>nexthop_self</i>         | (Optional) should retain next-hop?                                     |
| <i>auth_mode_md5</i>        | (Optional) MD5 Authentication enabled?                                 |
| <i>auth_key_chain</i>       | (Optional) Authentication key-chain                                    |
| <i>use_multicast</i>        | (Optional) Use Multicast?  |
| <i>classic_metric_peers</i> | (Optional) Classical metric peers                                      |
| <i>wide_metric_peers</i>    | (Optional) Wide metric peers   |
| <i>bfd_enabled</i>          | (Optional) BFD enabled   |

**Command Mode**

- /exec

## show ip eigrp traffic

```
show { ip | ipv6 } eigrp [ <eigrp-ptag> ] traffic [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_asn <asn> TABLE_vrf <vrf> <hellos_sent> <hellos_rcvd> <updates_sent> <updates_rcvd>
<queries_sent> <queries_rcvd> <replies_sent> <replies_rcvd> <acks_sent> <acks_rcvd> <max_inqueue_depth>
<inqueue_drops> <sia_queries_sent> <sia_queries_rcvd> <sia_replies_sent> <sia_replies_rcvd> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ipv6                  | Display IPv6 information                    |
| eigrp                 | Display EIGRP status and configuration      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>eigrp-ptag</i>     | (Optional) Process tag                      |
| traffic               | IP-EIGRP Traffic Statistics                 |
| __readonly__          | (Optional)                                  |
| TABLE_asn             | (Optional) AS number table                  |
| <i>asn</i>            | (Optional) AS number                        |
| TABLE_vrf             | (Optional) VRF table                        |
| <i>vrf</i>            | (Optional) VRF name                         |
| <i>hellos_sent</i>    | (Optional) Number of Hellos sent            |
| <i>hellos_rcvd</i>    | (Optional) Number of Hellos received        |
| <i>updates_sent</i>   | (Optional) Number of Updates sent           |
| <i>updates_rcvd</i>   | (Optional) Number of Updates received       |
| <i>queries_sent</i>   | (Optional) Number of Queries sent           |
| <i>queries_rcvd</i>   | (Optional) Number of Queries received       |
| <i>replies_sent</i>   | (Optional) Number of Replies sent           |
| <i>replies_rcvd</i>   | (Optional) Number of Replies received       |

|                          |   |
|--------------------------|---|
| <i>acks_sent</i>         | (Optional) Number of ACKs sent            |
| <i>acks_rcvd</i>         | (Optional) Number of ACKs received        |
| <i>max_inqueue_depth</i> | (Optional) Input queue high water mark    |
| <i>inqueue_drops</i>     | (Optional) Input queue drops              |
| <i>sia_queries_sent</i>  | (Optional) Number of SIA queries sent     |
| <i>sia_queries_rcvd</i>  | (Optional) Number of SIA queries received |
| <i>sia_replies_sent</i>  | (Optional) Number of SIA replies sent     |
| <i>sia_replies_rcvd</i>  | (Optional) Number of SIA replies received |

**Command Mode**

- /exec

## show ip extcommunity-list

show ip extcommunity-list [ <extcl\_name> ] [ \_\_readonly\_\_ TABLE\_extcl <name> <action> <rule> ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| ip                  | Display IP information                              |
| extcommunity-list   | List extcommunity-list                              |
| <i>extcl_name</i>   | (Optional) Standard or expanded community-list name |
| <i>__readonly__</i> | (Optional)  |
| TABLE_extcl         | (Optional)  |
| <i>name</i>         | (Optional)  |
| <i>action</i>       | (Optional)  |
| <i>rule</i>         | (Optional)  |

### Command Mode

- /exec

# show ip fib distribution

show ip fib distribution [ pauz | rezum ]

## Syntax Description

|              |   |
|--------------|---|
| show         |   |
| ip           | ipv4                                      |
| fib          | forwarding information                    |
| distribution | fib distribution information              |
| pauz         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| rezum        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

## Command Mode

- /exec

# show ip fib distribution clients

show ip fib distribution clients [ \_\_readonly\_\_ <id><pid><name><shms><shme><shmn> ]

## Syntax Description

|              |                            |
|--------------|----------------------------|
| show         |                            |
| ip           | ipv4                       |
| fib          | forwarding information     |
| distribution | fib distribution info      |
| clients      | unicast client information |
| __readonly__ | (Optional)                 |

## Command Mode

- /exec



## show ip fib distribution mroute

```
show ip fib distribution mroute [ { <group> | <gprefix> } [ <source> ] ] [ table <id> ] [ __readonly__
TABLE_vrf [ <vrf-name> ] [ <table-name> ] [ <table-id> ] [ <table-wildcard> ] [ <total-num-groups> ] [
TABLE_route_summary [ <vrf-name> ] [ <total-num-routes> ] [ <num-star-g-route> ] [ <num-sg-route> ] [
<num-star-g-prfx> ] [ <num-group-count> ] ] [ TABLE_one_route [ <source-addr> ] [ <source-len> ] [
<group-addr> ] [ <group-len> ] [ <df-ordinal> ] [ <rpf-intf> ] [ <flags> ] [ <stats-pkts> ] [ <stats-bytes> ] [
<oif-count> ] [ <oiflist-index> ] [ TABLE_oif [ <oif-name> ] [ <mti-src-intf> ] [ <mti-grp-ip> ] [ <mti-src-ip>
] [ <next-hop> ] ] ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    |   |
| ip                      | IP information                                |
| fib                     | Forwarding Information                        |
| distribution            | FIB distribution information                  |
| mroute                  | MFDM IP multicast routing table               |
| <i>group</i>            | (Optional) IPv4 Multicast Group Address       |
| <i>gprefix</i>          | (Optional) IPv4 Multicast Group Prefix        |
| <i>source</i>           | (Optional) IPv4 Source Address                |
| table                   | (Optional) Specify Multicast Routing Table    |
| <i>id</i>               | (Optional) Multicast Routing Table Identifier |
| <i>__readonly__</i>     | (Optional)                                    |
| TABLE_vrf               | (Optional)                                    |
| <i>vrf-name</i>         | (Optional)                                    |
| <i>table-name</i>       | (Optional)                                    |
| <i>table-id</i>         | (Optional)                                    |
| <i>table-wildcard</i>   | (Optional)                                    |
| <i>total-num-groups</i> | (Optional)                                    |
| TABLE_route_summary     | (Optional)                                    |
| <i>total-num-routes</i> | (Optional)                                    |
| <i>num-star-g-route</i> | (Optional)                                    |
| <i>num-sg-route</i>     | (Optional)                                    |
| <i>num-star-g-prfx</i>  | (Optional)                                    |

|                        |            |
|------------------------|------------|
| <i>num-group-count</i> | (Optional) |
| TABLE_one_route        | (Optional) |
| <i>source-addr</i>     | (Optional) |
| <i>source-len</i>      | (Optional) |
| <i>group-addr</i>      | (Optional) |
| <i>group-len</i>       | (Optional) |
| <i>df-ordinal</i>      | (Optional) |
| <i>rpf-intf</i>        | (Optional) |
| <i>flags</i>           | (Optional) |
| <i>stats-pkts</i>      | (Optional) |
| <i>stats-bytes</i>     | (Optional) |
| <i>oif-count</i>       | (Optional) |
| <i>oiflist-index</i>   | (Optional) |
| TABLE_oif              | (Optional) |
| <i>oif-name</i>        | (Optional) |
| <i>mti-src-intf</i>    | (Optional) |
| <i>mti-grp-ip</i>      | (Optional) |
| <i>mti-src-ip</i>      | (Optional) |
| <i>next-hop</i>        | (Optional) |

**Command Mode**

- /exec

# show ip fib distribution multicast

```
show ip fib distribution multicast [ messages ] [ __readonly__ <fibstate> <slot> <accepting_routes>
<num_accepting_routes> ]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| show                        |  |
| ip                          | IP information                                       |
| fib                         | Forwarding Information                               |
| distribution                | FIB distribution information                         |
| multicast                   | Multicast FIB distribution information               |
| messages                    | (Optional) Outstanding Message Information           |
| <i>__readonly__</i>         | (Optional)   |
| <i>fibstate</i>             | (Optional) IP Multicast FIB process state            |
| <i>slot</i>                 | (Optional) Slot                                      |
| <i>accepting_routes</i>     | (Optional) Indicates whether FIB is accepting routes |
| <i>num_accepting_routes</i> | (Optional) Number of fibs accepting routes           |

## Command Mode

- /exec

# show ip fib distribution state

```
show ip fib distribution state [ __readonly__ <slot> <state><ttc><tprc><tv4ac><tv6ac> { TABLE_fib_state
<tid><tafi><prc><pc><tname> } ]
```

## Syntax Description

|                 |                            |
|-----------------|----------------------------|
| show            |                            |
| ip              | ipv4                       |
| fib             | forwarding information     |
| distribution    | fib distribution info      |
| state           | unicast fib state info     |
| __readonly__    | (Optional)                 |
| <i>slot</i>     | (Optional) slot number     |
| TABLE_fib_state | (Optional) fib-state table |

## Command Mode

- /exec

# show ip fib mroute

```
show ip fib mroute [ { <group> | <gprefix> } [ <source> ] ] [ table <table-id> ] [ module <module> ] [
__readonly__ <table_type> <num_groups> <num_sources> <src_len> <grp_len> <df_ordinal> <rpfif>
<rpf_ifindex> <flag> <flag_value> <route_pkts> <route_bytes> <oiflist_id> <platform_id> <oif_count>
<refcount> <oifname> <oifindex> <oif_pkts> <oif_bytes> ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                |   |
| ip                  | Display IP information                                    |
| fib                 | Forwarding information                                    |
| mroute              | Multicast IPv4 routes                                     |
| <i>group</i>        | (Optional) Multicast IPv4 Group Address                   |
| <i>gprefix</i>      | (Optional) Multicast IPv4 Group Prefix                    |
| <i>source</i>       | (Optional) Multicast IPv4 Source Address                  |
| table               | (Optional) display info per vpn-id                        |
| <i>table-id</i>     | (Optional) table-id                                       |
| module              | (Optional) slot   |
| <i>module</i>       | (Optional) slot number                                    |
| <i>__readonly__</i> | (Optional)  |
| <i>table_type</i>   | (Optional) Table Type                                     |
| <i>num_groups</i>   | (Optional) Number of group entries in the table           |
| <i>num_sources</i>  | (Optional) Number of (S, G) entries for the group address |
| <i>src_len</i>      | (Optional) Source Address Mask                            |
| <i>grp_len</i>      | (Optional) Group address Mask                             |
| <i>df_ordinal</i>   | (Optional) DF ordinal                                     |
| <i>rpfif</i>        | (Optional) RPF interface                                  |
| <i>rpf_ifindex</i>  | (Optional) RPF Interface ifIndex                          |
| <i>flag</i>         | (Optional) Route type flag                                |
| <i>flag_value</i>   | (Optional) hex value of route flag                        |
| <i>route_pkts</i>   | (Optional) Route packet count                             |

|                    |                                     |
|--------------------|-------------------------------------|
| <i>route_bytes</i> | (Optional) Route bytes              |
| <i>oiflist_id</i>  | (Optional) OIF list Identifier      |
| <i>platform_id</i> | (Optional) Platform-index           |
| <i>oif_count</i>   | (Optional) Number of OIFs           |
| <i>refcount</i>    | (Optional) OIF list Reference Count |
| <i>oifname</i>     | (Optional) OIF Interface name       |
| <i>oifindex</i>    | (Optional) OIF Interface ifIndex    |
| <i>oif_pkts</i>    | (Optional) OIF packets              |
| <i>oif_bytes</i>   | (Optional) OIF bytes                |

**Command Mode**

- /exec

# show ip fib route

```
show ip fib route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ summary | <prefix>
[ longer-prefixes ] | <address> | interface <interface> | next-hop <nh> | attached | unresolved | adjacency {
<aif> <anh> | drop | glean | punt } ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all>
} ] + [ __readonly__ <header> <vrfname> <tableid> <prefix-count> <pfx> { <nexthop> | <special> } <intf>
<route-count> <path-count> <mask-length> <routes-per-mask> ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  |   |
| ip                    | Display IP information                              |
| fib                   | Forwarding information                              |
| route                 | display IP routing table                            |
| vrf                   | (Optional) display info per VRF                     |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| vrf-all               | (Optional) Display information for all VRFs         |
| table                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED           |
| <i>table_id</i>       | (Optional) table number                             |
| summary               | (Optional) display route counts                     |
| <i>prefix</i>         | (Optional) display single exact match route         |
| longer-prefixes       | (Optional) display longer prefixes                  |
| <i>address</i>        | (Optional) display single longest match route       |
| interface             | (Optional) display routes with this output i/f only |
| <i>interface</i>      | (Optional) output interface                         |
| next-hop              | (Optional) display routes with this next-hop only   |
| <i>nh</i>             | (Optional) next hop address                         |
| attached              | (Optional) display directly connected routes        |
| unresolved            | (Optional) display unresolved routes                |
| adjacency             | (Optional) display adjacency information            |
| <i>aif</i>            | (Optional) adjacency output interface               |
| <i>anh</i>            | (Optional) adjacency next-hop address               |

|                        |   |
|------------------------|---|
| drop                   | (Optional) display routes via drop adjacency  |
| glean                  | (Optional) display routes via glean adjacency |
| punt                   | (Optional) display routes via punt adjacency  |
| module                 | (Optional) slot                               |
| <i>module</i>          | (Optional) slot number                        |
| <i>__readonly__</i>    | (Optional)                                    |
| <i>header</i>          | (Optional) header string                      |
| <i>vrfname</i>         | (Optional) VRF name                           |
| <i>tableid</i>         | (Optional) table identifier                   |
| <i>prefix-count</i>    | (Optional) total number of prefix in VRF      |
| <i>px</i>              | (Optional) ipv4 prefix                        |
| <i>nexthop</i>         | (Optional) next hop address                   |
| <i>special</i>         | (Optional) special adjacencies                |
| <i>intf</i>            | (Optional) output interface                   |
| <i>route-count</i>     | (Optional) total number of routes in VRF      |
| <i>path-count</i>      | (Optional) total number of paths in VRF       |
| <i>mask-length</i>     | (Optional) length of mask                     |
| <i>routes-per-mask</i> | (Optional)                                    |

### Command Mode

- /exec



# show ip ftp source-interface

```
show ip ftp source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipftpvrf
<vrfname> <ifname> } ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information              |
| ip                    | Display IP information                       |
| ftp                   | Display FTP client information               |
| source-interface      | Display source interface information         |
| vrf                   | (Optional) Display per-VRF information       |
| <i>vrf-name</i>       | (Optional) VRF name                          |
| <i>vrf-known-name</i> | (Optional) Known VRF name                    |
| <i>__readonly__</i>   | (Optional)                                   |
| TABLE_ipftpvrf        | (Optional) source interface of ftp given vrf |
| <i>vrfname</i>        | (Optional) vrfname                           |
| <i>ifname</i>         | (Optional) ifname                            |

## Command Mode

- /exec

## show ip ftp source-interface vrf all

```
show ip ftp source-interface vrf all [ __readonly__ [ { TABLE_ipftp <vrfname> <ifname> } ] ]
```

### Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | Display IP information               |
| ftp              | Display FTP client information       |
| source-interface | Display source interface information |
| vrf              | Display per-VRF information          |
| all              | Display entries for all vrfs         |
| __readonly__     | (Optional)                           |
| TABLE_ipftp      | (Optional) source interface of ftp   |
| <i>vrfname</i>   | (Optional) vrfname                   |
| <i>ifname</i>    | (Optional) ifname                    |

### Command Mode

- /exec

## show ip http source-interface

```
show ip http source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_iphttpvrf
<vrfname> <ifname> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| ip                    | Display IP information                        |
| http                  | Display HTTP client information               |
| source-interface      | Display source interface information          |
| vrf                   | (Optional) Display per-VRF information        |
| <i>vrf-name</i>       | (Optional) VRF name                           |
| <i>vrf-known-name</i> | (Optional) Known VRF name                     |
| <i>__readonly__</i>   | (Optional)                                    |
| TABLE_iphttpvrf       | (Optional) source interface of http given vrf |
| <i>vrfname</i>        | (Optional) vrfname                            |
| <i>ifname</i>         | (Optional) ifname                             |

### Command Mode

- /exec

# show ip http source-interface vrf all

```
show ip http source-interface vrf all [ __readonly__ [ { TABLE_iphttp <vrfname> <ifname> } ] ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | Display IP information               |
| http             | Display HTTP client information      |
| source-interface | Display source interface information |
| vrf              | Display per-VRF information          |
| all              | Display entries for all vrfs         |
| __readonly__     | (Optional)                           |
| TABLE_iphttp     | (Optional) source interface of http  |
| <i>vrfname</i>   | (Optional) vrfname                   |
| <i>ifname</i>    | (Optional) ifname                    |

## Command Mode

- /exec

## show ip igmp groups

```
show ip igmp { groups | route } [ <source> [ <group> ] | <group> [ <source> ] ] [ <interface> ] [ summary ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ summary-old ] [ serialize ] [ __readonly__ [ TABLE_vrf [
<if-name> ] [ <vrfname> ] [ <entry-count> ] [ <group-addr> ] [ <sourceaddress> ] [ TABLE_group [
<group-addr> ] [ <group-type> ] [ <if-name> ] [ <uptime> ] [ <expires> ] [ <reporter> ] [ TABLE_source [
<source-addr> ] [ <group-type> ] [ <translate> ] [ <if-name> ] [ <uptime> ] [ <expires> ] [ <reporter> ] ] ] [
<vrf-cntxt> ] [ <g-count> ] [ <sg-count> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                              |
| ip                    | Display IP information                                       |
| igmp                  | Display IGMP status and configuration                        |
| groups                | Display IGMP attached group membership information           |
| route                 | Display IGMP attached group membership information           |
| <i>group</i>          | (Optional) Multicast IP address of single group to display   |
| <i>source</i>         | (Optional) Source IP address                                 |
| vrf                   | (Optional) Display per-VRF information                       |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                    |
| all                   | (Optional) Display information for all VRFs                  |
| <i>interface</i>      | (Optional) Display group membership on single interface name |
| summary               | (Optional) Display group summary                             |
| summary-old           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| serialize             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrfname</i>        | (Optional)   |
| <i>if-name</i>        | (Optional)   |
| <i>group-addr</i>     | (Optional)   |
| <i>entry-count</i>    | (Optional)   |
| <i>sourceaddress</i>  | (Optional)   |

|                    |            |
|--------------------|------------|
| TABLE_group        | (Optional) |
| <i>group-addr</i>  | (Optional) |
| <i>group-type</i>  | (Optional) |
| <i>if-name</i>     | (Optional) |
| <i>uptime</i>      | (Optional) |
| <i>expires</i>     | (Optional) |
| <i>reporter</i>    | (Optional) |
| TABLE_source       | (Optional) |
| <i>source-addr</i> | (Optional) |
| <i>group-type</i>  | (Optional) |
| <i>translate</i>   | (Optional) |
| <i>if-name</i>     | (Optional) |
| <i>uptime</i>      | (Optional) |
| <i>expires</i>     | (Optional) |
| <i>reporter</i>    | (Optional) |
| <i>vrf-cntxt</i>   | (Optional) |
| <i>g-count</i>     | (Optional) |
| <i>sg-count</i>    | (Optional) |

**Command Mode**

- /exec

## show ip igmp interface

```
show ip igmp interface [ <interface> ] [ brief ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
serialize ] [ __readonly__ TABLE_vrf <vrf> [ <entry-count> ] [ [ TABLE_brief [ <if-name> ] [ <addr> ] [
<querier> ] [ <mc> ] [ <ver> ] ] [ TABLE_if <if-name> [ <if-status> ] [ <ip-sum> ] [ <addr> ] [ <querier> ]
[ <q-ver> ] [ <next-query> ] [ <expires> ] [ <mc> ] [ <ver> ] [ <host-ver> ] [ <qi> ] [ <cqi> ] [ <mrt> ] [
<cmrt> ] [ <sqi> ] [ <csqi> ] [ <sqc> ] [ <lmmt> ] [ <lmqc> ] [ <gt> ] [ <cgt> ] [ <qt> ] [ <cqt> ] [ <uri> ] [
<rv> ] [ <crv> ] [ <rl> ] [ <rc> ] [ <il> ] [ <report-policy> ] [ <join-group-map> ] [ <static-group-map> ] [
<host-proxy> ] [ <host-proxy-group-map> ] [ <un-solicited> ] [ <unsoint> ] [ <v1rr> ] [ <v2qs> ] [ <v2qr> ]
[ <v2rs> ] [ <v2rr> ] [ <v2ls> ] [ <v2lr> ] [ <v3qs> ] [ <v3qr> ] [ <v3rs> ] [ <v3rr> ] [ <v2gqdest> ] [
<v3gqdest> ] [ <cse> ] [ <ple> ] [ <lsip> ] [ <scf> ] [ <qnq> ] [ <rvm> ] [ <qvm> ] [ <uit> ] [ <v1gdam> ] [
<v2gdam> ] [ <v3dai> ] [ <ra> ] ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                          |
| ip                    | Display IP information                                   |
| igmp                  | Display IGMP status and configuration                    |
| interface             | Display IGMP interface related information               |
| <i>interface</i>      | (Optional) Interface name of single interface to display |
| brief                 | (Optional) Display one line status per interface         |
| vrf                   | (Optional) Display per-VRF information                   |
| <i>vrf-name</i>       | (Optional) VRF name                                      |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                |
| all                   | (Optional) Display information for all VRFs              |
| detail                | (Optional) Display detailed information                  |
| serialize             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                |
| <i>__readonly__</i>   | (Optional)   |
| <i>TABLE_vrf</i>      | (Optional)   |
| <i>vrf</i>            | (Optional)   |
| <i>entry-count</i>    | (Optional)   |
| <i>TABLE_brief</i>    | (Optional)   |
| <i>if-name</i>        | (Optional)   |
| <i>addr</i>           | (Optional)   |
| <i>querier</i>        | (Optional)   |

|                   |            |
|-------------------|------------|
| <i>mc</i>         | (Optional) |
| <i>ver</i>        | (Optional) |
| TABLE_if          | (Optional) |
| <i>if-name</i>    | (Optional) |
| <i>if-status</i>  | (Optional) |
| <i>ip-sum</i>     | (Optional) |
| <i>addr</i>       | (Optional) |
| <i>querier</i>    | (Optional) |
| <i>q-ver</i>      | (Optional) |
| <i>next-query</i> | (Optional) |
| <i>expires</i>    | (Optional) |
| <i>mc</i>         | (Optional) |
| <i>ver</i>        | (Optional) |
| <i>host-ver</i>   | (Optional) |
| <i>qi</i>         | (Optional) |
| <i>cqi</i>        | (Optional) |
| <i>mrt</i>        | (Optional) |
| <i>cmrt</i>       | (Optional) |
| <i>sqi</i>        | (Optional) |
| <i>csqi</i>       | (Optional) |
| <i>sqc</i>        | (Optional) |
| <i>lmmrt</i>      | (Optional) |
| <i>lmqc</i>       | (Optional) |
| <i>gt</i>         | (Optional) |
| <i>cgt</i>        | (Optional) |
| <i>qt</i>         | (Optional) |
| <i>cqt</i>        | (Optional) |
| <i>uri</i>        | (Optional) |
| <i>rv</i>         | (Optional) |



|                         |            |
|-------------------------|------------|
| <i>crv</i>              | (Optional) |
| <i>rll</i>              | (Optional) |
| <i>rc</i>               | (Optional) |
| <i>v1rr</i>             | (Optional) |
| <i>v2qs</i>             | (Optional) |
| <i>v2qr</i>             | (Optional) |
| <i>v2rs</i>             | (Optional) |
| <i>v2rr</i>             | (Optional) |
| <i>v2ls</i>             | (Optional) |
| <i>v2lr</i>             | (Optional) |
| <i>v3qs</i>             | (Optional) |
| <i>v3qr</i>             | (Optional) |
| <i>v3rs</i>             | (Optional) |
| <i>v3rr</i>             | (Optional) |
| <i>v2ggdest</i>         | (Optional) |
| <i>v3ggdest</i>         | (Optional) |
| <i>cse</i>              | (Optional) |
| <i>ple</i>              | (Optional) |
| <i>lsip</i>             | (Optional) |
| <i>scf</i>              | (Optional) |
| <i>qnq</i>              | (Optional) |
| <i>rvm</i>              | (Optional) |
| <i>qvm</i>              | (Optional) |
| <i>uit</i>              | (Optional) |
| <i>v1gdam</i>           | (Optional) |
| <i>v2gdam</i>           | (Optional) |
| <i>v3dai</i>            | (Optional) |
| <i>ra</i>               | (Optional) |
| <i>static-group-map</i> | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>join-group-map</i>       | (Optional) |
| <i>host-proxy-group-map</i> | (Optional) |
| <i>il</i>                   | (Optional) |
| <i>report-policy</i>        | (Optional) |
| <i>host-proxy</i>           | (Optional) |
| <i>un-solicited</i>         | (Optional) |
| <i>unsoint</i>              | (Optional) |

**Command Mode**

- /exec

## show ip igmp local-groups

```
show ip igmp local-groups [ <interface> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf [ <vrf-name> ] [ TABLE_if [ <if-name> ] [ TABLE_grp [ <group-addr> ] [ TABLE_src [
<source-addr> ] [ <last-reported> ] [ <local-group> ] [ <static-oif> ] [ <report-only> ] [ <host-proxy> ] ] ] ]
]]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                              |
| ip                    | Display IP information                                       |
| igmp                  | Display IGMP status and configuration                        |
| local-groups          | Display IGMP local group membership information              |
| <i>interface</i>      | (Optional) Display group membership on single interface name |
| vrf                   | (Optional) Display per-VRF information                       |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                    |
| all                   | (Optional) Display information for all VRFs                  |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrf-name</i>       | (Optional)   |
| TABLE_if              | (Optional)   |
| <i>if-name</i>        | (Optional)   |
| TABLE_grp             | (Optional)   |
| <i>group-addr</i>     | (Optional)   |
| TABLE_src             | (Optional)   |
| <i>source-addr</i>    | (Optional)   |
| <i>last-reported</i>  | (Optional)   |
| <i>local-group</i>    | (Optional)   |
| <i>static-oif</i>     | (Optional)   |
| <i>report-only</i>    | (Optional)   |
| <i>host-proxy</i>     | (Optional)   |

**Command Mode**

- /exec

## show ip igmp policy statistics reports

```
show ip igmp policy statistics reports [ <interface> ] [ __readonly__ [ TABLE_interface [ <if> ] [
TABLE_routemap [ <name> ] [ <action> ] [ <seq_num> ] [ TABLE_cmd [ <command> ] [ <compare_count>
] [ <match_count> ] ] ] [ <total_accept_count> ] [ <total_reject_count> ] ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                |
| ip                        | Display IP information                         |
| igmp                      | Show IGMP related information                  |
| policy                    | Policy related information                     |
| statistics                | Policy statistics                              |
| reports                   | IGMP reports                                   |
| <i>interface</i>          | (Optional) Interface to display statistics for |
| <i>__readonly__</i>       | (Optional)                                     |
| TABLE_interface           | (Optional)                                     |
| <i>if</i>                 | (Optional)                                     |
| TABLE_routemap            | (Optional)                                     |
| <i>name</i>               | (Optional)                                     |
| <i>action</i>             | (Optional)                                     |
| <i>seq_num</i>            | (Optional)                                     |
| TABLE_cmd                 | (Optional)                                     |
| <i>command</i>            | (Optional)                                     |
| <i>compare_count</i>      | (Optional)                                     |
| <i>match_count</i>        | (Optional)                                     |
| <i>total_accept_count</i> | (Optional)                                     |
| <i>total_reject_count</i> | (Optional)                                     |

### Command Mode

- /exec

## show ip igmp snooping

```
show ip igmp snooping [ { vlan <vlan> | bridge-domain <bidid> } ] [ serialize ] [ __readonly__ [ <vdc> ] [
<enabled> ] [ <omf> ] [ <grepsup> ] [ <gv3repsup> ] [ <glinklocalgrpsup> ] { TABLE_vlan <vlan-id> [
<description> ] [ <snoop-on> ] [ <qa> ] [ <qv> ] [ <qi> ] [ <qlmqi> ] [ <rv> ] [ <sq> ] [ <sqr> ] [ <eht> ] [
<fl> ] [ <repsup> ] [ <v3repsup> ] [ <vlinklocalgrpsup> ] [ <rpc> ] [ <gc> ] [ TABLE_active_ports [ <actvports>
] ] [ <lkupmode> ] [ <omf_enabled> ] [ <reportfloodenable> ] [ <reportfloodall> ] [ TABLE_intf <if-name>
] [ <leavegroupaddress> ] } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                              |
| ip                      | Display IP information                                       |
| igmp                    | Display IGMP status and configuration                        |
| snooping                | IGMP Snooping information                                    |
| vlan                    | (Optional) Display VLAN IGMP snooping membership information |
| <i>vlan</i>             | (Optional) Specify VLAN                                      |
| bridge-domain           | (Optional) Display BD IGMP snooping membership information   |
| <i>bidid</i>            | (Optional) Specify BD  |
| serialize               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| __readonly__            | (Optional)   |
| <i>vdc</i>              | (Optional)   |
| <i>enabled</i>          | (Optional)   |
| <i>omf</i>              | (Optional)   |
| <i>grepsup</i>          | (Optional)   |
| <i>gv3repsup</i>        | (Optional)   |
| <i>glinklocalgrpsup</i> | (Optional)   |
| TABLE_vlan              | (Optional)   |
| <i>vlan-id</i>          | (Optional)   |
| <i>description</i>      | (Optional) description, if any                               |
| <i>snoop-on</i>         | (Optional)   |
| <i>qa</i>               | (Optional)   |
| <i>qv</i>               | (Optional)   |

|                          |            |
|--------------------------|------------|
| <i>qi</i>                | (Optional) |
| <i>qlmqi</i>             | (Optional) |
| <i>rv</i>                | (Optional) |
| <i>sq</i>                | (Optional) |
| <i>sqr</i>               | (Optional) |
| <i>eht</i>               | (Optional) |
| <i>fl</i>                | (Optional) |
| <i>repsup</i>            | (Optional) |
| <i>v3repsup</i>          | (Optional) |
| <i>vlinklocalgrpsup</i>  | (Optional) |
| <i>rpc</i>               | (Optional) |
| <i>gc</i>                | (Optional) |
| TABLE_active_ports       | (Optional) |
| <i>actvports</i>         | (Optional) |
| <i>lkupmode</i>          | (Optional) |
| <i>omf_enabled</i>       | (Optional) |
| <i>reportfloodenable</i> | (Optional) |
| <i>reportfloodall</i>    | (Optional) |
| TABLE_intf               | (Optional) |
| <i>if-name</i>           | (Optional) |
| <i>leavegroupaddress</i> | (Optional) |

**Command Mode**

- /exec





|                           |            |
|---------------------------|------------|
| <i>expires</i>            | (Optional) |
| <i>version</i>            | (Optional) |
| <i>num_of_reports</i>     | (Optional) |
| <i>cfs-flag</i>           | (Optional) |
| <i>native-flag</i>        | (Optional) |
| <i>delete-pending</i>     | (Optional) |
| <i>cfs-update-pending</i> | (Optional) |

**Command Mode**

- /exec

## show ip igmp snooping filter details

```
show ip igmp snooping filter [ vlan <vlan_id> ] details [ __readonly__ { TABLE_vlanid <vlan-id>
<access-group> <group-channels-limit> <igmp-min-ver> } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information        |
| ip                          | Display IP information                 |
| igmp                        | Display IGMP status and configuration  |
| snooping                    | IGMP Snooping information              |
| filter                      | Shows filter policy configuration      |
| vlan                        | (Optional) Only for the specified VLAN |
| <i>vlan_id</i>              | (Optional) VLAN ID                     |
| details                     | Shows different Filter configurations  |
| <i>__readonly__</i>         | (Optional)                             |
| <i>TABLE_vlanid</i>         | (Optional)                             |
| <i>vlan-id</i>              | (Optional)                             |
| <i>access-group</i>         | (Optional)                             |
| <i>group-channels-limit</i> | (Optional)                             |
| <i>igmp-min-ver</i>         | (Optional)                             |

### Command Mode

- /exec

## show ip igmp snooping groups

```
show ip igmp snooping [ otv | remote ] groups [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ vlan
<vlan> | bridge-domain <bdid> ] [ detail ] [ summary ] [ serialize ] [ __readonly__ ] [ TABLE_vlan [ <vlan-id>
] [ <rports> ] [ <rtrPortFlag> ] [ TABLE_port <if-name> ] [ TABLE_rtrports <rport-if-name> ] [ <raddr> ]
[ TABLE_source <source> ] [ TABLE_group <addr> [ <g-mfdm> ] [ <ver> ] [ <old-host> ] [ <raddr> ] [
<static> ] [ <dynamic> ] [ TABLE_static_ports <static-if-name> ] [ TABLE_v2_ports <v2-if-name> [ <uptime>
] [ <expires> ] [ <gq-missed> ] ] [ TABLE_star_g_ports <star-g-if-name> [ <uptime> ] [ <expires> ] ] [
<g-vpc> ] [ <rsf> ] [ <js> ] [ TABLE_source <source> [ <srsf> ] [ <s-mfdm> ] [ <src-static> ] [ <src-dynamic>
] [ TABLE_src_static_ports <src-static-if-name> ] [ TABLE_src_dynamic [ <oifs> ] <dyn-if-name> [
<src-uptime> ] [ <src-expires> ] ] [ <s-vp> ] ] ] [ <snoop-enabled> ] [ <omf-enabled> ] [ <group-count> ] [
<s-g-count> ] [ <total_star_g_count> ] [ <total_sg_count> ] ] ]
```

### Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                              |
| ip             | Display IP information                                       |
| igmp           | Display IGMP status and configuration                        |
| snooping       | IGMP Snooping information                                    |
| otv            | (Optional) IGMP Snooping OTV information                     |
| remote         | (Optional) IGMP Snooping remote information                  |
| groups         | Display snooping information for group address               |
| summary        | (Optional) Display snooping group summary                    |
| <i>group</i>   | (Optional) Multicast IP address of single group to display   |
| <i>source</i>  | (Optional) Source IP address                                 |
| vlan           | (Optional) Display VLAN IGMP snooping membership information |
| <i>vlan</i>    | (Optional) Specify VLAN                                      |
| bridge-domain  | (Optional) Display BD IGMP snooping membership information   |
| <i>bdid</i>    | (Optional) Specify BD  |
| detail         | (Optional) Display detailed information for the group        |
| serialize      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                    |
| __readonly__   | (Optional)   |
| TABLE_vlan     | (Optional)   |
| <i>vlan-id</i> | (Optional)   |
| <i>rports</i>  | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>rtrPortFlag</i>        | (Optional) |
| <i>snoop-enabled</i>      | (Optional) |
| <i>omf-enabled</i>        | (Optional) |
| <i>group-count</i>        | (Optional) |
| <i>s-g-count</i>          | (Optional) |
| <i>total_star_g_count</i> | (Optional) |
| <i>total_sg_count</i>     | (Optional) |
| TABLE_port                | (Optional) |
| <i>if-name</i>            | (Optional) |
| TABLE_rtrports            | (Optional) |
| <i>rport-if-name</i>      | (Optional) |
| <i>raddr</i>              | (Optional) |
| TABLE_group               | (Optional) |
| <i>addr</i>               | (Optional) |
| <i>ver</i>                | (Optional) |
| <i>raddr</i>              | (Optional) |
| TABLE_source              | (Optional) |
| <i>source</i>             | (Optional) |
| <i>rsf</i>                | (Optional) |
| <i>js</i>                 | (Optional) |
| <i>g-mfdm</i>             | (Optional) |
| <i>old-host</i>           | (Optional) |
| <i>g-vpc</i>              | (Optional) |
| <i>static</i>             | (Optional) |
| <i>dynamic</i>            | (Optional) |
| TABLE_static_ports        | (Optional) |
| <i>static-if-name</i>     | (Optional) |
| TABLE_v2_ports            | (Optional) |
| <i>v2-if-name</i>         | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>uptime</i>             | (Optional) |
| <i>expires</i>            | (Optional) |
| <i>gq-missed</i>          | (Optional) |
| TABLE_star_g_ports        | (Optional) |
| <i>star-g-if-name</i>     | (Optional) |
| <i>uptime</i>             | (Optional) |
| <i>expires</i>            | (Optional) |
| TABLE_source              | (Optional) |
| <i>source</i>             | (Optional) |
| <i>srsf</i>               | (Optional) |
| <i>s-mfdm</i>             | (Optional) |
| <i>s-vpc</i>              | (Optional) |
| <i>src-static</i>         | (Optional) |
| <i>src-dynamic</i>        | (Optional) |
| TABLE_src_static_ports    | (Optional) |
| <i>src-static-if-name</i> | (Optional) |
| TABLE_src_dynamic         | (Optional) |
| <i>oifs</i>               | (Optional) |
| <i>dyn-if-name</i>        | (Optional) |
| <i>src-uptime</i>         | (Optional) |
| <i>src-expires</i>        | (Optional) |

**Command Mode**

- /exec

# show ip igmp snooping lookup-mode

```
show ip igmp snooping lookup-mode [ vlan <vlan> | bridge-domain <bidid> ] [ __readonly__ [ <configured> ] [ <operational> ] [ TABLE_vlan [ <vlan-id> ] [ <lookup> ] ] ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| ip                  | Display IP information                |
| igmp                | Display IGMP status and configuration |
| snooping            | IGMP Snooping information             |
| lookup-mode         | IGMP Snooping lkup mode information   |
| vlan                | (Optional) Display VLAN information   |
| <i>vlan</i>         | (Optional) Specify VLAN               |
| bridge-domain       | (Optional) Display BD information     |
| <i>bidid</i>        | (Optional) Specify BD                 |
| <i>__readonly__</i> | (Optional)                            |
| <i>configured</i>   | (Optional)                            |
| <i>operational</i>  | (Optional)                            |
| TABLE_vlan          | (Optional)                            |
| <i>vlan-id</i>      | (Optional)                            |
| <i>lookup</i>       | (Optional)                            |

## Command Mode

- /exec

## show ip igmp snooping mac-oif

```
show ip igmp snooping mac-oif [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ __readonly__ [ <totaloif> ] ] [ TABLE_vlan [ <vlan-id> ] [ <count> ] ] [ TABLE_mac [ <mac-addr> ] [ TABLE_oif [ <oifs> ] ] ] ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| ip                  | Display IP information                           |
| igmp                | Display IGMP status and configuration            |
| snooping            | IGMP Snooping information                        |
| mac-oif             | IGMP Snooping static mac oif information         |
| vlan                | (Optional) Display VLAN information              |
| <i>vlan</i>         | (Optional) Specify VLAN                          |
| bridge-domain       | (Optional) Display BD information                |
| <i>bdid</i>         | (Optional) Specify BD                            |
| detail              | (Optional) static mac oif detail, M2RIB oif info |
| <i>__readonly__</i> | (Optional)                                       |
| <i>totaloif</i>     | (Optional)                                       |
| TABLE_vlan          | (Optional)                                       |
| <i>vlan-id</i>      | (Optional)                                       |
| <i>count</i>        | (Optional)                                       |
| TABLE_mac           | (Optional)                                       |
| <i>mac-addr</i>     | (Optional)                                       |
| TABLE_oif           | (Optional)                                       |
| <i>oifs</i>         | (Optional)                                       |

### Command Mode

- /exec

## show ip igmp snooping mrouter

```
show ip igmp snooping mrouter [ otv ] [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ serialize ] [
__readonly__ TABLE_vlan <vlan-id> TABLE_intf <if-name> <static> <dynamic> <vpc>
<fabricpath-core-port> <co-learned> <user-configured> <learnt-by-peer> <uptime> <expires> <internal> ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                      |
| ip                          | Display IP information                               |
| igmp                        | Display IGMP status and configuration                |
| snooping                    | IGMP Snooping information                            |
| mrouter                     | Display multicast routers detected                   |
| otv                         | (Optional) IGMP Snooping OTV information             |
| vlan                        | (Optional) Display VLAN multicast router information |
| <i>vlan</i>                 | (Optional) Specify VLAN                              |
| bridge-domain               | (Optional) Display BD multicast router information   |
| <i>bdid</i>                 | (Optional) Specify BD                                |
| detail                      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| serialize                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| <i>__readonly__</i>         | (Optional)   |
| TABLE_vlan                  | (Optional)   |
| <i>vlan-id</i>              | (Optional)   |
| TABLE_intf                  | (Optional)   |
| <i>if-name</i>              | (Optional)   |
| <i>uptime</i>               | (Optional)   |
| <i>expires</i>              | (Optional)   |
| <i>static</i>               | (Optional)   |
| <i>dynamic</i>              | (Optional)   |
| <i>internal</i>             | (Optional)   |
| <i>vpc</i>                  | (Optional)   |
| <i>fabricpath-core-port</i> | (Optional)   |



|                        |            |
|------------------------|------------|
| <i>co-learned</i>      | (Optional) |
| <i>user-configured</i> | (Optional) |
| <i>learnt-by-peer</i>  | (Optional) |

**Command Mode**

- /exec

# show ip igmp snooping otv vlan brief

show ip igmp snooping otv vlan brief [ \_\_readonly\_\_ <vlan-id> ]

## Syntax Description

|                |                                       |
|----------------|---------------------------------------|
| show           | Show running system information       |
| ip             | Display IP information                |
| igmp           | Display IGMP status and configuration |
| snooping       | IGMP Snooping information             |
| otv            | IGMP Snooping OTV information         |
| vlan           | Display VLAN/BD information           |
| brief          | Brief output                          |
| __readonly__   | (Optional)                            |
| <i>vlan-id</i> | (Optional)                            |

## Command Mode

- /exec

# show ip igmp snooping pw vlan brief

```
show ip igmp snooping pw vlan brief [ __readonly__ <vlan-id> ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| ip                  | Display IP information                |
| igmp                | Display IGMP status and configuration |
| snooping            | IGMP Snooping information             |
| pw                  | IGMP Snooping PW information          |
| vlan                | Display VLAN/BD information           |
| brief               | Brief output                          |
| <i>__readonly__</i> | (Optional)                            |
| <i>vlan-id</i>      | (Optional)                            |

## Command Mode

- /exec

## show ip igmp snooping querier

```
show ip igmp snooping querier [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ __readonly__ [ TABLE_vlan
<vlan-id> <qa> <qv> [ <expires> ] <qiod> <qname> <int> [ <last_member_query_count> ] [
<config_last_member_query_count> ] [ <snooping_version> ] [ <config_qv> ] [ <robust> ] [ <config_robust>
] [ <startup_query_count> ] [ <config_startup_query_count> ] [ <startup_query_interval> ] [
<config_startup_query_interval> ] [ <mbr_query_interval> ] [ <config_mbr_query_interval> ] [
<snooping_query_intvl> ] [ <config_snooping_query_intvl> ] [ <gquery_response_time> ] [
<config_gquery_response_time> ] [ <querier_timeout> ] [ <querier_timeout_flag> ] ] ]
```

### Syntax Description

|                                       |   |
|---------------------------------------|---|
| show                                  | Show running system information                           |
| ip                                    | Display IP information                                    |
| igmp                                  | Display IGMP status and configuration                     |
| snooping                              | IGMP Snooping information                                 |
| querier                               | Display snooping querier information                      |
| vlan                                  | (Optional) Display VLAN IGMP snooping querier information |
| <i>vlan</i>                           | (Optional) Specify VLAN                                   |
| bridge-domain                         | (Optional) Display BD IGMP snooping querier information   |
| <i>bdid</i>                           | (Optional) Specify BD                                     |
| detail                                | (Optional) Display detailed information                   |
| <i>__readonly__</i>                   | (Optional)  |
| TABLE_vlan                            | (Optional)  |
| <i>vlan-id</i>                        | (Optional)  |
| <i>qa</i>                             | (Optional)  |
| <i>expires</i>                        | (Optional)  |
| <i>qv</i>                             | (Optional)  |
| <i>qiod</i>                           | (Optional)  |
| <i>qname</i>                          | (Optional)  |
| <i>int</i>                            | (Optional)  |
| <i>last_member_query_count</i>        | (Optional)  |
| <i>config_last_member_query_count</i> | (Optional)  |
| <i>snooping_version</i>               | (Optional)  |

|                                      |            |
|--------------------------------------|------------|
| <i>config_qv</i>                     | (Optional) |
| <i>robust</i>                        | (Optional) |
| <i>config_robust</i>                 | (Optional) |
| <i>startup_query_count</i>           | (Optional) |
| <i>config_startup_query_count</i>    | (Optional) |
| <i>startup_query_interval</i>        | (Optional) |
| <i>config_startup_query_interval</i> | (Optional) |
| <i>mbr_query_interval</i>            | (Optional) |
| <i>config_mbr_query_interval</i>     | (Optional) |
| <i>snooping_query_intvl</i>          | (Optional) |
| <i>config_snooping_query_intvl</i>   | (Optional) |
| <i>gquery_response_time</i>          | (Optional) |
| <i>config_gquery_response_time</i>   | (Optional) |
| <i>querier_timeout</i>               | (Optional) |
| <i>querier_timeout_flag</i>          | (Optional) |

### Command Mode

- /exec

## show ip igmp snooping report statistics

```
show ip igmp snooping { report-policy | access-group } statistics [ vlan <vlan> ] [ __readonly__ [
TABLE_vlanid { <vlan-id> <rpm-type> <policy-name> } ] [ TABLE_filtervlanid { <filter-vlan-id>
<filter-policy-name> } ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                                     |
| ip                        | Display IP information  |
| igmp                      | Display IGMP status and configuration                               |
| snooping                  | IGMP Snooping information   |
| report-policy             | IGMP Report Policy  |
| access-group              | IGMP access-group   |
| statistics                | Policy statistics   |
| vlan                      | (Optional) Display VLAN IGMP snooping policy statistics information |
| <i>vlan</i>               | (Optional) Specify VLAN   |
| <i>__readonly__</i>       | (Optional)  |
| TABLE_vlanid              | (Optional)  |
| <i>vlan-id</i>            | (Optional)  |
| <i>rpm-type</i>           | (Optional)  |
| <i>policy-name</i>        | (Optional)  |
| TABLE_filtervlanid        | (Optional)  |
| <i>filter-vlan-id</i>     | (Optional)  |
| <i>filter-policy-name</i> | (Optional)  |

### Command Mode

- /exec

# show ip igmp snooping statistics

```
show ip igmp snooping statistics [ global | vlan <vlan> | bridge-domain <bdid> ] [ serialize ] [ __readonly__
[ <pr> ] [ <inv_pkt> ] [ <inv_pkt_bd> ] [ <inv_pkt_no_fd_vxlan> ] [ <pnv> ] [ <loopbkpkt> ] [ <mrdloopbk>
] [ <pf> ] [ <vpcdrqs> ] [ <vpcdrqr> ] [ <vpcdrqf> ] [ <vpcdrus> ] [ <vpcdrur> ] [ <vpcdruf> ] [ <vpccfsf>
] [ <vpccfsrs> ] [ <vpccfsrr> ] [ <vpccfsrf> ] [ <vpccfsrfp> ] [ <vpccfsurls> ] [ <vpccfsurlr> ] [ <vpccfsurlf>
] [ <vpccfsrls> ] [ <vpccfsrlr> ] [ <vpccfsrlf> ] [ <stptcnr> ] [ <imapif> ] [ <mfreqr> ] [ <mfcmps> ] [ <inv_iod>
] [ <mfdgcmps> ] [ <bufsnt> ] [ <bufackr> ] [ <vpemismatch> ] [ { TABLE_vlan [ <vlan-id> ] [ <ut> ] [
<vpr> ] [ <v1rr> ] [ <v2rr> ] [ <v3rr> ] [ <v1qr> ] [ <v2qr> ] [ <v3qr> ] [ <v2lr> ] [ <phr> ] [ <irr> ] [ <iqr>
] [ <v1rs> ] [ <v2rs> ] [ <v2ls> ] [ <v2lsv1> ] [ <v3gs> ] [ <qo> ] [ <v2ro> ] [ <v2lo> ] [ <v3ro> ] [ <vpsr>
] [ <str> ] [ <vmr> ] [ <upr> ] [ <cps> ] [ <cpr> ] [ <cpe> ] [ <mps> ] [ <mpr> ] [ <mpe> ] [ <repflooded> ]
[ <repfwded> ] [ <agd> ] [ <egd> ] [ <lvd> ] [ <qd> ] [ <pmd> } } ] ]
```

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information           |
| ip                         | Display IP information                    |
| igmp                       | Display IGMP status and configuration     |
| snooping                   | IGMP Snooping information                 |
| statistics                 | Display packet/error counter statistics   |
| global                     | (Optional) Display global statistics      |
| vlan                       | (Optional) Display VLAN statistics        |
| <i>vlan</i>                | (Optional) Specify VLAN                   |
| bridge-domain              | (Optional) Display BD statistics          |
| <i>bdid</i>                | (Optional) Specify BD                     |
| serialize                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__               | (Optional)                                |
| <i>pr</i>                  | (Optional)                                |
| <i>inv_pkt</i>             | (Optional)                                |
| <i>inv_pkt_bd</i>          | (Optional)                                |
| <i>inv_pkt_no_fd_vxlan</i> | (Optional)                                |
| <i>pnv</i>                 | (Optional)                                |
| <i>loopbkpkt</i>           | (Optional)                                |
| <i>mrdloopbk</i>           | (Optional)                                |
| <i>pf</i>                  | (Optional)                                |

|                    |            |
|--------------------|------------|
| <i>vpcdrqs</i>     | (Optional) |
| <i>vpcdrqr</i>     | (Optional) |
| <i>vpcdrqf</i>     | (Optional) |
| <i>vpcdrus</i>     | (Optional) |
| <i>vpcdrur</i>     | (Optional) |
| <i>vpcdruf</i>     | (Optional) |
| <i>vpccfssf</i>    | (Optional) |
| <i>vpccfsrs</i>    | (Optional) |
| <i>vpccfsrr</i>    | (Optional) |
| <i>vpccfsrf</i>    | (Optional) |
| <i>vpccfsrfp</i>   | (Optional) |
| <i>vpccfsurls</i>  | (Optional) |
| <i>vpccfsurlr</i>  | (Optional) |
| <i>vpccfsurlf</i>  | (Optional) |
| <i>vpccfsrls</i>   | (Optional) |
| <i>vpccfsrlr</i>   | (Optional) |
| <i>vpccfsrlf</i>   | (Optional) |
| <i>stptcnr</i>     | (Optional) |
| <i>imapif</i>      | (Optional) |
| <i>mfreqr</i>      | (Optional) |
| <i>mfcmps</i>      | (Optional) |
| <i>inv_iod</i>     | (Optional) |
| <i>mfdgcmps</i>    | (Optional) |
| <i>bufsnt</i>      | (Optional) |
| <i>bufackr</i>     | (Optional) |
| <i>vpcmismatch</i> | (Optional) |
| TABLE_vlan         | (Optional) |
| <i>vlan-id</i>     | (Optional) |
| <i>ut</i>          | (Optional) |



|               |            |
|---------------|------------|
| <i>vpr</i>    | (Optional) |
| <i>v1rr</i>   | (Optional) |
| <i>v2rr</i>   | (Optional) |
| <i>v3rr</i>   | (Optional) |
| <i>v1qr</i>   | (Optional) |
| <i>v2qr</i>   | (Optional) |
| <i>v3qr</i>   | (Optional) |
| <i>v2lr</i>   | (Optional) |
| <i>phr</i>    | (Optional) |
| <i>irr</i>    | (Optional) |
| <i>iqr</i>    | (Optional) |
| <i>v1rs</i>   | (Optional) |
| <i>v2rs</i>   | (Optional) |
| <i>v2ls</i>   | (Optional) |
| <i>v2lsv1</i> | (Optional) |
| <i>v3gs</i>   | (Optional) |
| <i>vmr</i>    | (Optional) |
| <i>upr</i>    | (Optional) |
| <i>qo</i>     | (Optional) |
| <i>v2ro</i>   | (Optional) |
| <i>v2lo</i>   | (Optional) |
| <i>v3ro</i>   | (Optional) |
| <i>vpsr</i>   | (Optional) |
| <i>str</i>    | (Optional) |
| <i>cps</i>    | (Optional) |
| <i>cpr</i>    | (Optional) |
| <i>cpe</i>    | (Optional) |
| <i>mps</i>    | (Optional) |
| <i>mpr</i>    | (Optional) |

|                   |            |
|-------------------|------------|
| <i>mpe</i>        | (Optional) |
| <i>repflooded</i> | (Optional) |
| <i>repfwded</i>   | (Optional) |
| <i>agd</i>        | (Optional) |
| <i>egd</i>        | (Optional) |
| <i>lvd</i>        | (Optional) |
| <i>qd</i>         | (Optional) |
| <i>pmd</i>        | (Optional) |

**Command Mode**

- /exec

## show ip igmp vrf all

```
show ip igmp vrf all [ __readonly__ { TABLE_vrfname <vrf-name> <vrf-id> <instance> <work-in-txlist> [
<global-mcast-bndry> ] } { TABLE_vrfid <vrf-name-i> <vrf-id-i> <instance-i> <work-in-txlist-i> } ]
```

### Syntax Description

|                           |                                       |
|---------------------------|---------------------------------------|
| show                      | Show running system information       |
| ip                        | Display IP information                |
| igmp                      | Display IGMP status and configuration |
| vrf                       | Display per-VRF information           |
| all                       | Display information for all VRFs      |
| <i>__readonly__</i>       | (Optional)                            |
| TABLE_vrfname             | (Optional)                            |
| <i>vrf-name</i>           | (Optional)                            |
| <i>vrf-id</i>             | (Optional)                            |
| <i>instance</i>           | (Optional)                            |
| <i>work-in-txlist</i>     | (Optional)                            |
| <i>global-mcast-bndry</i> | (Optional)                            |
| TABLE_vrfid               | (Optional)                            |
| <i>vrf-name-i</i>         | (Optional)                            |
| <i>vrf-id-i</i>           | (Optional)                            |
| <i>instance-i</i>         | (Optional)                            |
| <i>work-in-txlist-i</i>   | (Optional)                            |

### Command Mode

- /exec

## show ip interface

```
show ip interface { { { brief [ include-secondary ] } | [ <interface> ] | [ <ip-addr> ] } [ operational ] [ vaddr ]
[ vrf { <vrf-name> | <vrf-known-name> | all } } [ __readonly__ [ TABLE_intf [ <vrf-name-out> ] [
<intf-name> ] [ <proto-state> ] [ <link-state> ] [ <admin-state> ] [ <iod> ] [ <first_unnum_iod> ] [
TABLE_unnuminf<unnum-child-inf> ] [ <prefix> ] [ <subnet> ] [ <masklen> ] [ TABLE_secondary_address
<prefix1> <subnet1> <masklen1> ] [ <num-addr> ] [ <vaddr-client> ] [ <vaddr-prefix> ] [ <vaddr-subnet>
] [ <vaddr-masklen> ] [ <num-vaddr> ] [ <unnum-intf> ] [ <ip-disabled> ] [ <bcast-addr> ] [ <maddr> ] + [
<num-maddr> ] [ <mtu> ] [ <pref> ] [ <tag> ] [ <proxy-arp> ] [ <lcl-proxy-arp> ] [ <mrouting> ] [
<icmp-redirect> ] [ <dir-bcast> ] [ <ip-forwarding> ] [ <ip-unreach> ] [ <port-unreach> ] [ <urpf-mode> ] [
<ip-ls-type> ] [ <urpf-acl> ] [ <pbr-in> ] [ <pbr-out> ] [ <acl-in> ] [ <acl-out> ] [ <stats-last-reset> ] [
<upkt-sent> ] [ <upkt-recv> ] [ <upkt-fwd> ] [ <upkt-orig> ] [ <upkt-consumed> ] [ <ubyte-sent> ] [
<ubyte-recv> ] [ <ubyte-fwd> ] [ <ubyte-orig> ] [ <ubyte-consumed> ] [ <mpkt-sent> ] [ <mpkt-recv> ] [
<mpkt-fwd> ] [ <mpkt-orig> ] [ <mpkt-consumed> ] [ <mbyte-sent> ] [ <mbyte-recv> ] [ <mbyte-fwd> ] [
<mbyte-orig> ] [ <mbyte-consumed> ] [ <bpkt-sent> ] [ <bpkt-recv> ] [ <bpkt-fwd> ] [ <bpkt-orig> ] [
<bpkt-consumed> ] [ <bbyte-sent> ] [ <bbyte-recv> ] [ <bbyte-fwd> ] [ <bbyte-orig> ] [ <bbyte-consumed>
] [ <lpkt-sent> ] [ <lpkt-recv> ] [ <lpkt-fwd> ] [ <lpkt-orig> ] [ <lpkt-consumed> ] [ <lbyte-sent> ] [
<lbyte-recv> ] [ <lbyte-fwd> ] [ <lbyte-orig> ] [ <lbyte-consumed> ] [ <wccp-outbound> ] [ <wccp-inbound>
] [ <wccp-exclude> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                      |
| ip                    | Display IP information   |
| interface             | Display IP related interface information                             |
| brief                 | Display summary of IP interface status and configuration             |
| include-secondary     | (Optional) Display summary of all IP addresses                       |
| operational           | (Optional) Display only interfaces that are administratively enabled |
| <i>interface</i>      | (Optional) Interface name to display                                 |
| <i>ip-addr</i>        | (Optional) Display interface for local IP address                    |
| vrf                   | (Optional) Display per-VRF information                               |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name  |
| all                   | (Optional) Display all VRFs  |
| vaddr                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                            |
| __readonly__          | (Optional)   |
| <i>vrf-name-out</i>   | (Optional)   |
| TABLE_intf            | (Optional)   |

|                         |            |
|-------------------------|------------|
| <i>intf-name</i>        | (Optional) |
| <i>iod</i>              | (Optional) |
| <i>first_unnum_iod</i>  | (Optional) |
| <i>prefix</i>           | (Optional) |
| <i>proto-state</i>      | (Optional) |
| <i>link-state</i>       | (Optional) |
| <i>admin-state</i>      | (Optional) |
| <i>subnet</i>           | (Optional) |
| <i>masklen</i>          | (Optional) |
| TABLE_unnuminf          | (Optional) |
| <i>unnum-child-inf</i>  | (Optional) |
| TABLE_secondary_address | (Optional) |
| <i>prefix1</i>          | (Optional) |
| <i>subnet1</i>          | (Optional) |
| <i>masklen1</i>         | (Optional) |
| <i>num-addr</i>         | (Optional) |
| <i>vaddr-client</i>     | (Optional) |
| <i>vaddr-prefix</i>     | (Optional) |
| <i>vaddr-subnet</i>     | (Optional) |
| <i>vaddr-masklen</i>    | (Optional) |
| <i>num-vaddr</i>        | (Optional) |
| <i>unnum-intf</i>       | (Optional) |
| <i>ip-disabled</i>      | (Optional) |
| <i>bcast-addr</i>       | (Optional) |
| <i>maddr</i>            | (Optional) |
| <i>num-maddr</i>        | (Optional) |
| <i>mtu</i>              | (Optional) |
| <i>pref</i>             | (Optional) |
| <i>tag</i>              | (Optional) |

|                         |            |
|-------------------------|------------|
| <i>proxy-arp</i>        | (Optional) |
| <i>lcl-proxy-arp</i>    | (Optional) |
| <i>mrouting</i>         | (Optional) |
| <i>icmp-redirect</i>    | (Optional) |
| <i>dir-bcast</i>        | (Optional) |
| <i>ip-forwarding</i>    | (Optional) |
| <i>ip-unreach</i>       | (Optional) |
| <i>port-unreach</i>     | (Optional) |
| <i>urpf-mode</i>        | (Optional) |
| <i>ip-ls-type</i>       | (Optional) |
| <i>urpf-acl</i>         | (Optional) |
| <i>pbr-in</i>           | (Optional) |
| <i>pbr-out</i>          | (Optional) |
| <i>acl-in</i>           | (Optional) |
| <i>acl-out</i>          | (Optional) |
| <i>stats-last-reset</i> | (Optional) |
| <i>upkt-sent</i>        | (Optional) |
| <i>upkt-recv</i>        | (Optional) |
| <i>upkt-fwd</i>         | (Optional) |
| <i>upkt-orig</i>        | (Optional) |
| <i>upkt-consumed</i>    | (Optional) |
| <i>ubyte-sent</i>       | (Optional) |
| <i>ubyte-recv</i>       | (Optional) |
| <i>ubyte-fwd</i>        | (Optional) |
| <i>ubyte-orig</i>       | (Optional) |
| <i>ubyte-consumed</i>   | (Optional) |
| <i>mpkt-sent</i>        | (Optional) |
| <i>mpkt-recv</i>        | (Optional) |
| <i>mpkt-fwd</i>         | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>mpkt-orig</i>      | (Optional) |
| <i>mpkt-consumed</i>  | (Optional) |
| <i>mbyte-sent</i>     | (Optional) |
| <i>mbyte-recv</i>     | (Optional) |
| <i>mbyte-fwd</i>      | (Optional) |
| <i>mbyte-orig</i>     | (Optional) |
| <i>mbyte-consumed</i> | (Optional) |
| <i>bpkt-sent</i>      | (Optional) |
| <i>bpkt-recv</i>      | (Optional) |
| <i>bpkt-fwd</i>       | (Optional) |
| <i>bpkt-orig</i>      | (Optional) |
| <i>bpkt-consumed</i>  | (Optional) |
| <i>bbyte-sent</i>     | (Optional) |
| <i>bbyte-recv</i>     | (Optional) |
| <i>bbyte-fwd</i>      | (Optional) |
| <i>bbyte-orig</i>     | (Optional) |
| <i>bbyte-consumed</i> | (Optional) |
| <i>lpkt-sent</i>      | (Optional) |
| <i>lpkt-recv</i>      | (Optional) |
| <i>lpkt-fwd</i>       | (Optional) |
| <i>lpkt-orig</i>      | (Optional) |
| <i>lpkt-consumed</i>  | (Optional) |
| <i>lbyte-sent</i>     | (Optional) |
| <i>lbyte-recv</i>     | (Optional) |
| <i>lbyte-fwd</i>      | (Optional) |
| <i>lbyte-orig</i>     | (Optional) |
| <i>lbyte-consumed</i> | (Optional) |
| <i>wccp-outbound</i>  | (Optional) |
| <i>wccp-inbound</i>   | (Optional) |

|                     |            |
|---------------------|------------|
| <i>wccp-exclude</i> | (Optional) |
|---------------------|------------|

**Command Mode**

- /exec



# show ip lisp

```
show { ip | ipv6 } lisp [ database ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                  |
| ip                    | Display IP information                           |
| ipv6                  | Display IPv6 information                         |
| lisp                  | LISP show commands                               |
| database              | (Optional) Show EID-prefixes configured for site |
| vrf                   | (Optional) Display information for vrf           |
| <i>vrf-name</i>       | (Optional) VRF name                              |
| <i>vrf-known-name</i> | (Optional) Known VRF name                        |

## Command Mode

- /exec

# show ip lisp data-cache

```
show ip lisp data-cache [ <eid> ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| ip                    | Display IP information                             |
| lisp                  | LISP show commands                                 |
| data-cache            | Display EID-to-RLOC data cache mapping in this ITR |
| <i>eid</i>            | (Optional) Display mapping for IP destination EID  |
| vrf                   | (Optional) Display per-VRF information             |
| <i>vrf-name</i>       | (Optional) VRF name                                |
| <i>vrf-known-name</i> | (Optional) Known VRF name                          |

## Command Mode

- /exec

## show ip lisp locator-hash

```
{ { show ip lisp locator-hash { <eid-prefix> | { <source-eid> <dest-eid> } } [ vrf { <vrf-name> |
<vrf-known-name> } ] } | { show ipv6 lisp locator-hash { <eid-prefix6> | { <source-eid6> <dest-eid6> } } [
vrf { <vrf-name> | <vrf-known-name> } ] } }
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| ip                    | Display IP information                        |
| ipv6                  | Display IPv6 information                      |
| lisp                  | LISP show commands                            |
| locator-hash          | Display source and dest locators for EID pair |
| <i>source-eid</i>     | Source IPv4 endpoint identifier (EID)         |
| <i>dest-eid</i>       | Destination IPv4 endpoint identifier (EID)    |
| <i>eid-prefix</i>     | Display exact match for IP EID-prefix entry   |
| vrf                   | (Optional) Display information for vrf        |
| <i>vrf-name</i>       | (Optional) VRF name                           |
| <i>vrf-known-name</i> | (Optional) Known VRF name                     |

### Command Mode

- /exec

# show ip lisp map-cache

```
{ { show ip lisp map-cache [ <eid> | <eid-prefix> | detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] } } | {
show ipv6 lisp map-cache [ <eid6> | <eid-prefix6> | detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] } }
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| ip                    | Display IP information                                 |
| ipv6                  | Display IPv6 information                               |
| lisp                  | LISP show commands                                     |
| map-cache             | Display EID-to-RLOC cache mapping in this ITR          |
| vrf                   | (Optional) Display information for vrf                 |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| <i>eid</i>            | (Optional) Display mapping for IP destination EID      |
| <i>eid-prefix</i>     | (Optional) Display exact match for IP EID-prefix entry |
| detail                | (Optional) Display entire map-cache in long format     |

## Command Mode

- /exec

# show ip lisp statistics

```
show { ip | ipv6 } lisp statistics [ vrf { <vrf-name> | <vrf-known-name> } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| ip                    | Display IP information                            |
| ipv6                  | Display IPv6 information                          |
| lisp                  | LISP show commands                                |
| statistics            | Display global LISP statistics                    |
| vrf                   | (Optional) Display statistics information for vrf |
| <i>vrf-name</i>       | (Optional) VRF name                               |
| <i>vrf-known-name</i> | (Optional) Known VRF name                         |

## Command Mode

- /exec

# show ip lisp translate-cache

```
{ show ip lisp translate-cache [ <nrEID> ] } | { show ipv6 lisp translate-cache [ <nrEID6> ] }
```

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                    |
| ip              | Display IP information                             |
| ipv6            | Display IPv6 information                           |
| lisp            | LISP show commands                                 |
| translate-cache | Display configured translation cache               |
| <i>nrEID</i>    | (Optional) IPv4 address of inside non-routable EID |
| <i>nrEID6</i>   | (Optional) IPv6 address of inside non-routable EID |

## Command Mode

- /exec

# show ip load-sharing

```
show ip load-sharing [ __readonly__ { <univer-id-ran-seed> [ <l3-msg-load> ] [ <l34-msg-load> ] [
<dest-addr-load> ] [ <src-dst-ip-gre> ] [ <bad-load> ] [ <gre-outer-hash> ] [ <concatenation> ] [ <rotate> ] [
<src-dst-ip-gtpu> ] [ <src-dst-ip-ipv6-flowlabel> ] [ <src-dst-ip-ttl> ] [ { <src-dst-ip-udf> [ <offset> ] } ] [
<src-dst-ip-inner-all-infra> ] [ <src-dst-ip-inner-all> ] } ]
```

## Syntax Description

|                                   |                                 |
|-----------------------------------|---------------------------------|
| show                              | Show running system information |
| ip                                | Configure IP features           |
| load-sharing                      | Display global loadbalance info |
| <i>__readonly__</i>               | (Optional)                      |
| <i>univer-id-ran-seed</i>         | (Optional)                      |
| <i>l3-msg-load</i>                | (Optional)                      |
| <i>l34-msg-load</i>               | (Optional)                      |
| <i>dest-addr-load</i>             | (Optional)                      |
| <i>src-dst-ip-gre</i>             | (Optional)                      |
| <i>bad-load</i>                   | (Optional)                      |
| <i>gre-outer-hash</i>             | (Optional)                      |
| <i>concatenation</i>              | (Optional)                      |
| <i>rotate</i>                     | (Optional)                      |
| <i>src-dst-ip-gtpu</i>            | (Optional)                      |
| <i>src-dst-ip-ipv6-flowlabel</i>  | (Optional)                      |
| <i>src-dst-ip-ttl</i>             | (Optional)                      |
| <i>src-dst-ip-udf</i>             | (Optional)                      |
| <i>src-dst-ip-inner-all-infra</i> | (Optional)                      |
| <i>src-dst-ip-inner-all</i>       | (Optional)                      |
| <i>offset</i>                     | (Optional)                      |

## Command Mode

- /exec

# show ip local policy

```
show ip local policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_pbr [ <interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| local                 | IP local options                            |
| policy                | Policy routing                              |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| __readonly__          | (Optional)                                  |
| TABLE_pbr             | (Optional)                                  |
| <i>interface</i>      | (Optional)                                  |
| <i>rmap</i>           | (Optional)                                  |
| <i>status</i>         | (Optional)                                  |
| <i>vrf_name</i>       | (Optional)                                  |

## Command Mode

- /exec



# show ip logging

```
show ip logging [ hash ] [ __readonly__ ]
```

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information           |
| ip           | Display IP information                    |
| logging      | Display IP policy logging table           |
| hash         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__ | (Optional)                                |

## Command Mode

- /exec

## show ip mbgp

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } { route-map { <rmap-name> | <rmap-name> } | filter-list { <fltrlist-name> | <test_pol_name> } | {
community-list { <commlist-name> | <test_pol_name> } | extcommunity-list { <extcommlist-name> |
<test_pol_name> } } [ exact-match ] } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                                 |
| ip                      | Display IP information  |
| bgp                     | Display BGP status and configuration                            |
| mbgp                    | Display MBGP status and configuration                           |
| vrf                     | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>         | (Optional) VRF name   |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                                       |
| route-map               | Display routes matching the route-map                           |
| <i>rmap-name</i>        | Route-map name  |
| <i>rmap-name</i>        | Known route-map name  |
| filter-list             | Display routes matching the filter-list                         |
| <i>fltrlist-name</i>    | Name of filter-list   |
| community-list          | Display routes matching the community-list                      |
| extcommunity-list       | Display routes matching the extcommunity-list                   |
| <i>commlist-name</i>    | Name of community-list  |
| <i>extcommlist-name</i> | Name of extcommunity-list                                       |
| <i>test_pol_name</i>    | An existing test-list policy                                    |
| ipv4                    | (Optional) Display BGP information for IPv4 address family      |
| unicast                 | (Optional) Display BGP information for unicast address family   |
| multicast               | (Optional) Display BGP information for multicast address family |
| all                     | (Optional) Display BGP information for all address families     |
| exact-match             | (Optional) Exact match of the communities                       |

**Command Mode**

- /exec

# show ip mbgp

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast | mdt } |
all } ] } } [ <ip-addr> [ <ip-mask> [ longer-prefixes ] ] | <ip-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name>
| <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                    |
| ip                    | Display IP information   |
| bgp                   | Display BGP status and configuration                               |
| mbgp                  | Display MBGP status and configuration                              |
| vrf                   | (Optional) Virtual Router Context                                  |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name  |
| <i>ip-addr</i>        | (Optional) Display one particular network from the BRIB in detail  |
| <i>ip-mask</i>        | (Optional) Mask for one particular prefix in the BRIB              |
| <i>ip-prefix</i>      | (Optional) Display one particular prefix from the BRIB in detail   |
| longer-prefixes       | (Optional) Display route and more specific routes                  |
| ipv4                  | (Optional) Display BGP information for IPv4 address family         |
| unicast               | (Optional) Display BGP information for unicast address family      |
| multicast             | (Optional) Display BGP information for multicast address family    |
| mdt                   | (Optional) Display BGP information for multicast distribution tree |
| all                   | (Optional) Display BGP information for all address families        |

## Command Mode

- /exec

# show ip mbgp community

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] ] } community { <regexp-str> | { { <comm-id> | <wellknown-id> } + [ exact-match ] } } [ vrf { <vrf-name>
| <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| all                   | (Optional) Display BGP information for all address families     |
| community             | Display routes matching the BGP communities                     |
| <i>regexp-str</i>     | Regular expression to match the communities                     |
| <i>comm-id</i>        | BGP community value   |
| <i>wellknown-id</i>   | BGP wellknown community   |
| exact-match           | (Optional) Exact match of the communities                       |

## Command Mode

- /exec

## show ip mbgp dampening

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } dampening { dampened-paths [ regexp <regexp-str> ] | flap-statistics | parameters | history-paths [ regexp
<regexp-str> ] } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                   |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                              |
| mbgp                  | Display MBGP status and configuration                             |
| vrf                   | (Optional) Virtual Router Context                                 |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| dampening             | Display dampening info  |
| dampened-paths        | Display all dampened paths  |
| flap-statistics       | Display flap statistics for routes                                |
| parameters            | Display dampening parameters                                      |
| history-paths         | Display all history paths   |
| ipv4                  | (Optional) Display BGP information for IPv4 address family        |
| unicast               | (Optional) Display BGP information for unicast address family     |
| multicast             | (Optional) Display BGP information for multicast address family   |
| all                   | (Optional) Display BGP information for all address families       |
| regexp                | (Optional) Display routes matching the AS path regular expression |
| <i>regexp-str</i>     | (Optional) Regular expression to match the AS paths               |

### Command Mode

- /exec

## show ip mbgp extcommunity

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } extcommunity { <regexp-str> | { { 4byteas-generic { transitive <ext-comm-gen-trans> | non-transitive
<ext-comm-gen-nontrans> } } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                                 |
| ip                           | Display IP information  |
| bgp                          | Display BGP status and configuration                            |
| mbgp                         | Display MBGP status and configuration                           |
| ipv4                         | (Optional) Display BGP information for IPv4 address family      |
| unicast                      | (Optional) Display BGP information for unicast address family   |
| multicast                    | (Optional) Display BGP information for multicast address family |
| vrf                          | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>              | (Optional) VRF name   |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                                       |
| all                          | (Optional) Display BGP information for all address families     |
| extcommunity                 | Display routes matching the BGP extcommunities                  |
| 4byteas-generic              | Generic extended community                                      |
| transitive                   | Transitive extcommunity   |
| non-transitive               | Non-Transitive extcommunity                                     |
| <i>regexp-str</i>            | Regular expression to match the extcommunities                  |
| <i>ext-comm-gen-trans</i>    | Extcommunity number aa4:nn format                               |
| <i>ext-comm-gen-nontrans</i> | Extcommunity number aa4:nn format                               |
| exact-match                  | (Optional) Exact match of the extcommunities                    |

### Command Mode

- /exec

## show ip mbgp flap-statistics

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } flap-statistics [ <ip-prefix> | <ip-addr> [ <ip-mask> ] ] [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| flap-statistics       | Display route flap statistics                                   |
| <i>ip-prefix</i>      | (Optional) Display flap statistics for one prefix               |
| <i>ip-addr</i>        | (Optional) Display flap statistics for one network              |
| <i>ip-mask</i>        | (Optional) Network mask   |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |
| all                   | (Optional) Display BGP information for all address families     |

### Command Mode

- /exec



# show ip mbgp neighbors

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] ] } neighbors { [ { <neighbor-id> | <ipv6-neighbor-id> } [ routes [ advertised | received | dampened ] |
advertised-routes | received-routes | paths | flap-statistics ] ] | <neighbor-prefix-id> | <ipv6-neighbor-prefix-id>
| <neighbor-interface> } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                                       |
| ip                        | Display IP information  |
| bgp                       | Display BGP status and configuration                                  |
| mbgp                      | Display MBGP status and configuration                                 |
| vrf                       | (Optional) Virtual Router Context                                     |
| <i>vrf-name</i>           | (Optional) VRF name   |
| <i>vrf-known-name</i>     | (Optional) Known VRF name   |
| neighbors                 | Display all configured BGP neighbors                                  |
| <i>neighbor-id</i>        | (Optional) Display one particular BGP neighbor                        |
| <i>neighbor-prefix-id</i> | Display details for a prefix peering                                  |
| <i>neighbor-interface</i> | Display details for BGP interface peering                             |
| ipv4                      | (Optional) Display BGP information for IPv4 address family            |
| unicast                   | (Optional) Display BGP information for unicast address family         |
| multicast                 | (Optional) Display BGP information for multicast address family       |
| all                       | (Optional) Display BGP information for all address families           |
| routes                    | (Optional) Display all routes advertised/received to/from peer        |
| advertised                | (Optional) Display all routes advertised to this peer                 |
| received                  | (Optional) Display all routes received from this peer                 |
| dampened                  | (Optional) Display all dampened routes received from this peer        |
| advertised-routes         | (Optional) Display all the routes advertised to this peer             |
| received-routes           | (Optional) Display all the routes received from this peer             |
| flap-statistics           | (Optional) Display flap statistics for routes received from this peer |
| paths                     | (Optional) Display AS paths learned from this peer                    |

**Command Mode**

- /exec

## show ip mbgp nexthop-database

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } nexthop-database [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| nexthop-database      | Display nexthop database  |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |
| all                   | (Optional) Display BGP information for all address families     |

### Command Mode

- /exec

## show ip mbgp nexthop

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 { unicast | multicast } ] } nexthop
<ipnexthop> [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| nexthop               | Display routes matching the nexthop                             |
| <i>ipnexthop</i>      | Nexthop address   |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |

### Command Mode

- /exec

## show ip mbgp prefix-list

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 { unicast | multicast } ] } }
prefix-list { <prfxlist-name> | <test_pol_name> } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| prefix-list           | Display routes matching the prefix-list                         |
| <i>prfxlist-name</i>  | Name of prefix-list   |
| <i>test_pol_name</i>  | An existing test-list policy                                    |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |

### Command Mode

- /exec

## show ip mbgp received-paths

```
show ip { mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | { bgp [ vrf {
<vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ { ipv4 { unicast | multicast } | all }
] } } received-paths [ private ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| received-paths        | Display paths stored for soft-reconfig                          |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |
| all                   | (Optional) Display BGP information for all address families     |
| private               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |

### Command Mode

- /exec



|                             |   |
|-----------------------------|---|
| <i>mofrr</i>                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>group</i>                | (Optional) Display multicast group/source address for route |
| <i>source</i>               | (Optional) Display multicast group/source address for route |
| <i>gprefix</i>              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>count</i>                | (Optional) Display route counts only                        |
| <i>bitfield</i>             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>detail</i>               | (Optional) Display detailed route attributes                |
| <i>flags</i>                | (Optional) Display detailed route attributes                |
| <i>exact</i>                | (Optional) Exactly match the given mask length              |
| <i>__readonly__</i>         | (Optional)  |
| <i>TABLE_vrf</i>            | (Optional)  |
| <i>vrf-name</i>             | (Optional)  |
| <i>expry_timer</i>          | (Optional)  |
| <i>route_count</i>          | (Optional)  |
| <i>star_g_cnt</i>           | (Optional)  |
| <i>sg_cnt</i>               | (Optional)  |
| <i>star_g_prfx_cnt</i>      | (Optional)  |
| <i>TABLE_summary_source</i> | (Optional)  |
| <i>group_addr</i>           | (Optional)  |
| <i>group_mask_len</i>       | (Optional)  |
| <i>source_count</i>         | (Optional)  |
| <i>TABLE_one_sg</i>         | (Optional)  |
| <i>sgroup_addr</i>          | (Optional)  |
| <i>source_addr</i>          | (Optional)  |
| <i>packets</i>              | (Optional)  |
| <i>bytes</i>                | (Optional)  |
| <i>aps</i>                  | (Optional)  |
| <i>pps</i>                  | (Optional)  |
| <i>rate_buf</i>             | (Optional)  |



|                         |            |
|-------------------------|------------|
| <i>oifs</i>             | (Optional) |
| <i>sr_type</i>          | (Optional) |
| <i>software_fwd</i>     | (Optional) |
| <i>rpf-failed-pkts</i>  | (Optional) |
| <i>rpf-failed-bytes</i> | (Optional) |
| TABLE_one_route         | (Optional) |
| <i>mcast-addr</i>       | (Optional) |
| <i>source_addr</i>      | (Optional) |
| <i>group_addr</i>       | (Optional) |
| <i>bidir</i>            | (Optional) |
| <i>pending</i>          | (Optional) |
| <i>mofrr</i>            | (Optional) |
| <i>uptime</i>           | (Optional) |
| <i>uptime_detailed</i>  | (Optional) |
| TABLE_mpib              | (Optional) |
| <i>mpib-name</i>        | (Optional) |
| <i>oif-count</i>        | (Optional) |
| <i>stale-route</i>      | (Optional) |
| <i>mdt-encap</i>        | (Optional) |
| <i>mdt-decap</i>        | (Optional) |
| <i>mdt-last-hop</i>     | (Optional) |
| <i>mdt-encap-index</i>  | (Optional) |
| <i>stats-pkts</i>       | (Optional) |
| <i>stats-bytes</i>      | (Optional) |
| <i>stats-rate-buf</i>   | (Optional) |
| <i>lisp-src-rloc</i>    | (Optional) |
| <i>nat-mode</i>         | (Optional) |
| <i>nat-route-type</i>   | (Optional) |
| <i>route-iif</i>        | (Optional) |

|                            |            |
|----------------------------|------------|
| <i>rpf-nbr</i>             | (Optional) |
| <i>mofrr-iif</i>           | (Optional) |
| <i>mofrr-nbr</i>           | (Optional) |
| <i>internal</i>            | (Optional) |
| <i>oif-count</i>           | (Optional) |
| <i>fabric-oif</i>          | (Optional) |
| <i>fabric-loser</i>        | (Optional) |
| <i>num-vpc-svi-oifs</i>    | (Optional) |
| TABLE_oif                  | (Optional) |
| <i>oif-name</i>            | (Optional) |
| <i>oif-uptime</i>          | (Optional) |
| <i>oif-uptime-detailed</i> | (Optional) |
| TABLE_oif_mpib             | (Optional) |
| <i>oif-mpib-name</i>       | (Optional) |
| <i>stale-oif</i>           | (Optional) |
| <i>omd-vpc-svi</i>         | (Optional) |
| <i>core-interest</i>       | (Optional) |
| <i>fabric-interest</i>     | (Optional) |
| <i>rpf</i>                 | (Optional) |
| <i>route-mdt-iod</i>       | (Optional) |
| <i>oif-list-bitfield</i>   | (Optional) |
| TABLE_route_summary        | (Optional) |
| <i>total-num-routes</i>    | (Optional) |
| <i>star-g-route</i>        | (Optional) |
| <i>sg-route</i>            | (Optional) |
| <i>star-g-prfx</i>         | (Optional) |
| <i>group-count</i>         | (Optional) |
| <i>avg</i>                 | (Optional) |
| <i>rem</i>                 | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>stats-pndg</i>           | (Optional) |
| <i>sr-routes</i>            | (Optional) |
| <i>pre-routes</i>           | (Optional) |
| <i>post-routes</i>          | (Optional) |
| <i>ingress-routes</i>       | (Optional) |
| <i>egress-routes</i>        | (Optional) |
| <i>sr-count</i>             | (Optional) |
| TABLE_sr                    | (Optional) |
| <i>translated-route-src</i> | (Optional) |
| <i>translated-route-grp</i> | (Optional) |
| <i>udp-src-port</i>         | (Optional) |
| <i>udp-dst-port</i>         | (Optional) |
| <i>sr-oif</i>               | (Optional) |
| TABLE_extranet              | (Optional) |
| <i>extranet_vrf_name</i>    | (Optional) |
| <i>extranet_addr</i>        | (Optional) |
| <i>extranet_oif_count</i>   | (Optional) |

**Command Mode**

- /exec

# show ip msdp count

```
show ip msdp count [ <asn> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf
[ <out-vrf> ] [ <total-cnt> ] [ TABLE_asn [ <out-asn> ] [ <src-cnt> ] [ <grp-cnt> ] ] ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| msdp                  | Display MSDP status and configuration       |
| count                 | Display SA cache counters                   |
| <i>asn</i>            | (Optional) AS number                        |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| __readonly__          | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out-vrf</i>        | (Optional)                                  |
| <i>total-cnt</i>      | (Optional)                                  |
| TABLE_asn             | (Optional)                                  |
| <i>out-asn</i>        | (Optional)                                  |
| <i>src-cnt</i>        | (Optional)                                  |
| <i>grp-cnt</i>        | (Optional)                                  |

## Command Mode

- /exec

## show ip msdp mesh-group

```
show ip msdp mesh-group [ <mesh-group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
[ TABLE_vrf [ <out-vrf> ] [ TABLE_meshgroup [ <meshgroup-name> ] [ TABLE_peer [ <peer-ipaddr> ] [
<peer-asn> ] [ <peer-description> ] ] ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| ip                      | Display IP information                      |
| msdp                    | Display MSDP status and configuration       |
| mesh-group              | Display members of mesh-group               |
| <i>mesh-group</i>       | (Optional) Display single mesh-group        |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| __readonly__            | (Optional)                                  |
| TABLE_vrf               | (Optional)                                  |
| <i>out-vrf</i>          | (Optional)                                  |
| TABLE_meshgroup         | (Optional)                                  |
| <i>meshgroup-name</i>   | (Optional)                                  |
| TABLE_peer              | (Optional)                                  |
| <i>peer-ipaddr</i>      | (Optional)                                  |
| <i>peer-asn</i>         | (Optional)                                  |
| <i>peer-description</i> | (Optional)                                  |

### Command Mode

- /exec

## show ip msdp peer

```
show ip msdp peer [ <peer-address> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_peer [ <peer-ipaddr> ] [ <out-vrf> ] [ <peer-asn> ] [ <local-ipaddr> ] [ <local-iface> ] [
<fully-configured> ] [ <peer-description> ] [ <connection-status> ] [ <peer-listening> ] [ <state-duration> ]
[ <peer-uptime> ] [ <peer-rr> ] [ <peer-password> ] [ <peer-ki> ] [ <peer-kt> ] [ <peer-ri> ] [ <sa-in-policy>
] [ <sa-out-policy> ] [ <sa-limit> ] [ <mesh-name> ] [ <last-rcvd> ] [ <sa-rcvd> ] [ <sa-sent> ] [ <sa-req-rcvd>
] [ <sa-req-sent> ] [ <sa-resp-rcvd> ] [ <sa-resp-sent> ] [ <in-ctrl-msgs> ] [ <out-ctrl-msgs> ] [ <in-data-msgs>
] [ <out-data-msgs> ] [ <sa-ka-rcvd> ] [ <sa-ka-sent> ] [ <sa-notif-rcvd> ] [ <sa-notif-sent> ] [ <rem-port> ]
[ <local-port> ] [ <rfp-failures> ] [ <cache-lifetime> ] [ <estb-transitions> ] [ <conn-attempts> ] [ <discont-time>
] ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information             |
| ip                       | Display IP information                      |
| msdp                     | Display MSDP status and configuration       |
| vrf                      | (Optional) Display per-VRF information      |
| <i>vrf-name</i>          | (Optional) VRF name                         |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                   |
| all                      | (Optional) Display information for all VRFs |
| peer                     | Display MSDP peer information               |
| <i>peer-address</i>      | (Optional) IP address of MSDP peer          |
| <i>__readonly__</i>      | (Optional)                                  |
| <i>TABLE_peer</i>        | (Optional)                                  |
| <i>peer-ipaddr</i>       | (Optional)                                  |
| <i>out-vrf</i>           | (Optional)                                  |
| <i>peer-asn</i>          | (Optional)                                  |
| <i>local-ipaddr</i>      | (Optional)                                  |
| <i>local-iface</i>       | (Optional)                                  |
| <i>fully-configured</i>  | (Optional)                                  |
| <i>peer-description</i>  | (Optional)                                  |
| <i>connection-status</i> | (Optional)                                  |
| <i>state-duration</i>    | (Optional)                                  |

|                       |            |
|-----------------------|------------|
| <i>peer-listening</i> | (Optional) |
| <i>peer-uptime</i>    | (Optional) |
| <i>peer-password</i>  | (Optional) |
| <i>peer-ki</i>        | (Optional) |
| <i>peer-kt</i>        | (Optional) |
| <i>peer-ri</i>        | (Optional) |
| <i>peer-rr</i>        | (Optional) |
| <i>sa-in-policy</i>   | (Optional) |
| <i>sa-out-policy</i>  | (Optional) |
| <i>sa-limit</i>       | (Optional) |
| <i>mesh-name</i>      | (Optional) |
| <i>last-rcvd</i>      | (Optional) |
| <i>sa-rcvd</i>        | (Optional) |
| <i>sa-sent</i>        | (Optional) |
| <i>sa-req-rcvd</i>    | (Optional) |
| <i>sa-req-sent</i>    | (Optional) |
| <i>sa-resp-rcvd</i>   | (Optional) |
| <i>sa-resp-sent</i>   | (Optional) |
| <i>out-ctrl-msgs</i>  | (Optional) |
| <i>in-ctrl-msgs</i>   | (Optional) |
| <i>out-data-msgs</i>  | (Optional) |
| <i>in-data-msgs</i>   | (Optional) |
| <i>sa-ka-rcvd</i>     | (Optional) |
| <i>sa-ka-sent</i>     | (Optional) |
| <i>sa-notif-rcvd</i>  | (Optional) |
| <i>sa-notif-sent</i>  | (Optional) |
| <i>rem-port</i>       | (Optional) |
| <i>local-port</i>     | (Optional) |
| <i>rpf-failures</i>   | (Optional) |

|                         |            |
|-------------------------|------------|
| <i>cache-lifetime</i>   | (Optional) |
| <i>estb-transitions</i> | (Optional) |
| <i>conn-attempts</i>    | (Optional) |
| <i>discont-time</i>     | (Optional) |

**Command Mode**

- /exec



## show ip msdp policy statistics sa-policy in

```
show ip msdp policy statistics sa-policy <peer-address> { in | out } [ vrf { <vrf-name> | <vrf-known-name>
} ] [ __readonly__ [ TABLE_routemap [ <name> ] [ <action> ] [ <seq_num> ] [ TABLE_cmd [ <command>
] [ <compare_count> ] [ <match_count> ] ] ] [ <total_accept_count> ] [ <total_reject_count> ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information        |
| ip                        | Display IP information                 |
| msdp                      | MSDP global configuration commands     |
| policy                    | Policy information                     |
| statistics                | Policy statistics                      |
| sa-policy                 | Configured SA policy for MSDP peer     |
| <i>peer-address</i>       | IP address of MSDP peer for SA policy  |
| in                        | Input policy                           |
| out                       | Output policy                          |
| vrf                       | (Optional) Display per-VRF information |
| <i>vrf-name</i>           | (Optional) VRF name                    |
| <i>vrf-known-name</i>     | (Optional) Known VRF name              |
| <i>__readonly__</i>       | (Optional)                             |
| TABLE_routemap            | (Optional)                             |
| <i>name</i>               | (Optional)                             |
| <i>action</i>             | (Optional)                             |
| <i>seq_num</i>            | (Optional)                             |
| TABLE_cmd                 | (Optional)                             |
| <i>command</i>            | (Optional)                             |
| <i>compare_count</i>      | (Optional)                             |
| <i>match_count</i>        | (Optional)                             |
| <i>total_accept_count</i> | (Optional)                             |
| <i>total_reject_count</i> | (Optional)                             |

### Command Mode

- /exec

## show ip msdp rpf

```
show ip msdp rpf <rp-address> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_rp
[ <out-rp-address> ] [ <out-vrf> ] [ TABLE_mesh [ <peer-addr> ] [ <mesh-name> ] ] [ <is-peer-cnt-one> ] [
<is-rp-peer> ] [ <is-bgp-alive> ] [ <bgp-peer-addr> ] [ <peer-asn> ] [ <origin-asn> ] [ <is-mbgp> ] ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information             |
| ip                     | Display IP information                      |
| msdp                   | Display MSDP status and configuration       |
| rpf                    | Display RPF-peer for RP address             |
| <i>rp-address</i>      | IP address of RP                            |
| vrf                    | (Optional) Display per-VRF information      |
| <i>vrf-name</i>        | (Optional) VRF name                         |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                   |
| all                    | (Optional) Display information for all VRFs |
| __readonly__           | (Optional)                                  |
| TABLE_rp               | (Optional)                                  |
| <i>out-rp-address</i>  | (Optional)                                  |
| <i>out-vrf</i>         | (Optional)                                  |
| TABLE_mesh             | (Optional)                                  |
| <i>peer-addr</i>       | (Optional)                                  |
| <i>mesh-name</i>       | (Optional)                                  |
| <i>is-peer-cnt-one</i> | (Optional)                                  |
| <i>is-rp-peer</i>      | (Optional)                                  |
| <i>is-bgp-alive</i>    | (Optional)                                  |
| <i>bgp-peer-addr</i>   | (Optional)                                  |
| <i>peer-asn</i>        | (Optional)                                  |
| <i>origin-asn</i>      | (Optional)                                  |
| <i>is-mbgp</i>         | (Optional)                                  |

### Command Mode

- /exec

## show ip msdp sa

```
show ip msdp { sa-cache | route } [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ <asn> ] [ peer
<peer> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf [ <out-vrf>
] ] [ <total-sa-count> ] [ TABLE_sa [ <src-addr> ] [ <grp-addr> ] [ <rp-addr> ] [ <out-asn> ] [ <uptime> ] [
<in-mrib> ] [ <peer-addr> ] [ <expire> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| ip                    | Display IP information                               |
| msdp                  | Display MSDP status and configuration                |
| vrf                   | (Optional) Display per-VRF information               |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| all                   | (Optional) Display information for all VRFs          |
| route                 | Display MSDP SA route cache                          |
| sa-cache              | Display MSDP SA route cache                          |
| <i>source</i>         | (Optional) Display group/source address for SA       |
| <i>group</i>          | (Optional) Display group/source address for SA       |
| <i>asn</i>            | (Optional) AS number                                 |
| detail                | (Optional) Display detailed information              |
| peer                  | (Optional) Display MSDP SA received from single peer |
| <i>peer</i>           | (Optional) IP address of peer for SA                 |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>out-vrf</i>        | (Optional)   |
| <i>total-sa-count</i> | (Optional)   |
| TABLE_sa              | (Optional)   |
| <i>src-addr</i>       | (Optional)   |
| <i>grp-addr</i>       | (Optional)   |
| <i>rp-addr</i>        | (Optional)   |

|                  |            |
|------------------|------------|
| <i>in-mrib</i>   | (Optional) |
| <i>peer-addr</i> | (Optional) |
| <i>out-asn</i>   | (Optional) |
| <i>uptime</i>    | (Optional) |
| <i>expire</i>    | (Optional) |

**Command Mode**

- /exec

# show ip msdp sources

```
show ip msdp sources [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_VRF [
<out-vrf> ] [ TABLE_source [ <source-addr> ] [ <count> ] [ <is-count-ge-limit> ] [ <is-limit-valid> ] [ <limit>
] [ <source-prefix> ] [ <violates> ] ] ] ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                            |
| ip                       | Display IP information                                     |
| msdp                     | Display MSDP status and configuration                      |
| sources                  | Display learned sources with their group counts and limits |
| vrf                      | (Optional) Display per-VRF information                     |
| <i>vrf-name</i>          | (Optional) VRF name  |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                                  |
| all                      | (Optional) Display information for all VRFs                |
| <i>__readonly__</i>      | (Optional)   |
| TABLE_VRF                | (Optional)   |
| <i>out-vrf</i>           | (Optional)   |
| TABLE_source             | (Optional)   |
| <i>source-addr</i>       | (Optional)   |
| <i>is-count-ge-limit</i> | (Optional)   |
| <i>count</i>             | (Optional)   |
| <i>is-limit-valid</i>    | (Optional)   |
| <i>limit</i>             | (Optional)   |
| <i>source-prefix</i>     | (Optional)   |
| <i>violates</i>          | (Optional)   |

## Command Mode

- /exec

## show ip msdp statistics

```
show ip msdp statistics [ <peer-address> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf [ <out-vrf> ] [ <select-err> ] [ <recv-sel-err> ] [ TABLE_peer [ <peer-address> ] [ <buffer-full>
] [ <recv-buf-full> ] [ <fatal-err> ] [ <recv-fat-err> ] [ <would-block> ] [ <recv-would-block> ] [ <sock-exp>
] [ <invalid-type> ] [ <invalid-len> ] ] ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| ip                      | Display IP information                      |
| msdp                    | Display MSDP status and configuration       |
| statistics              | Display internal statistics                 |
| <i>peer-address</i>     | (Optional) IP address of MSDP peer          |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| __readonly__            | (Optional)                                  |
| TABLE_vrf               | (Optional)                                  |
| <i>out-vrf</i>          | (Optional)                                  |
| <i>select-err</i>       | (Optional)                                  |
| <i>recv-sel-err</i>     | (Optional)                                  |
| TABLE_peer              | (Optional)                                  |
| <i>peer-address</i>     | (Optional)                                  |
| <i>buffer-full</i>      | (Optional)                                  |
| <i>recv-buf-full</i>    | (Optional)                                  |
| <i>fatal-err</i>        | (Optional)                                  |
| <i>recv-fat-err</i>     | (Optional)                                  |
| <i>would-block</i>      | (Optional)                                  |
| <i>recv-would-block</i> | (Optional)                                  |
| <i>sock-exp</i>         | (Optional)                                  |



|                     |            |
|---------------------|------------|
| <i>invalid-type</i> | (Optional) |
| <i>invalid-len</i>  | (Optional) |

**Command Mode**

- /exec



|                      |            |
|----------------------|------------|
| <i>peer-sa-rcvd</i>  | (Optional) |
| <i>peer-sa-limit</i> | (Optional) |

**Command Mode**

- /exec

## show ip multicast vrf

```
show ip multicast vrf [ <vrf-name> | <vrf-known-name> | all ] [ detail ] [ __readonly__ <vrf-count> [ {
TABLE_vrf <vrf-name> <cid> <tid> <rc> <gc> <sc> <star_gc> <state> [ <multipath-configuration> ] [
<mrrib-cc-timer-left> ] [ <mrrib-stats-timer-left> ] [ <mrrib-mfdm-timer-left> ] [ <mrrib-lisp-timer-left> ] [
<sr-interface> ] [ <resilient> ] [ TABLE_RPF_SELECT <rpf-ip> <rpf-ip-mask> <rpf-vrf> ] [
<global-mcast-bndry> ] } ] ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information             |
| ip                             | Display IP information                      |
| multicast                      | Display multicast routing info              |
| vrf                            | Display information for particular VRF      |
| <i>vrf-name</i>                | (Optional) VRF name                         |
| <i>vrf-known-name</i>          | (Optional) Known VRF name                   |
| all                            | (Optional) Display information for all VRFs |
| detail                         | (Optional) Display detailed information     |
| <i>__readonly__</i>            | (Optional)                                  |
| <i>vrf-count</i>               | (Optional)                                  |
| TABLE_vrf                      | (Optional)                                  |
| <i>vrf-name</i>                | (Optional)                                  |
| <i>cid</i>                     | (Optional)                                  |
| <i>tid</i>                     | (Optional)                                  |
| <i>rc</i>                      | (Optional)                                  |
| <i>gc</i>                      | (Optional)                                  |
| <i>sc</i>                      | (Optional)                                  |
| <i>star_gc</i>                 | (Optional)                                  |
| <i>state</i>                   | (Optional)                                  |
| <i>multipath-configuration</i> | (Optional)                                  |
| <i>mrrib-cc-timer-left</i>     | (Optional)                                  |
| <i>mrrib-stats-timer-left</i>  | (Optional)                                  |
| <i>mrrib-mfdm-timer-left</i>   | (Optional)                                  |

|                             |            |
|-----------------------------|------------|
| <i>mrib-lisp-timer-left</i> | (Optional) |
| <i>sr-interface</i>         | (Optional) |
| <i>resilient</i>            | (Optional) |
| TABLE_RPF_SELECT            | (Optional) |
| <i>rpf-ip</i>               | (Optional) |
| <i>rpf-ip-mask</i>          | (Optional) |
| <i>rpf-vrf</i>              | (Optional) |
| <i>global-mcast-bndry</i>   | (Optional) |

**Command Mode**

- /exec

# show ip nat-alias

```
show ip nat-alias [ __readonly__ [ TABLE_nat_alias_vrf [ { <nat-alias-vrf-name> [ TABLE_each_vrf_alias
{ <nat-alias-addr> <nat-alias-intr> } ] } ] ] ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information          |
| ip                        | Display IP information                   |
| nat-alias                 | Display aliases registered by NAT module |
| __readonly__              | (Optional)                               |
| TABLE_nat_alias_vrf       | (Optional)                               |
| <i>nat-alias-vrf-name</i> | (Optional)                               |
| TABLE_each_vrf_alias      | (Optional)                               |
| <i>nat-alias-addr</i>     | (Optional)                               |
| <i>nat-alias-intr</i>     | (Optional)                               |

## Command Mode

- /exec

# show ip nat max

```
show ip nat max [ __readonly__ <max_dyn_translations> <max_all_host> <static_translations>
<dynamic_translations> <icmp_translations> ]
```

## Syntax Description

|                             |                                     |
|-----------------------------|-------------------------------------|
| show                        | Show running system information     |
| ip                          | Show the IP features of the system  |
| nat                         | IP NAT information                  |
| max                         | IP NAT max values                   |
| <i>__readonly__</i>         | (Optional)                          |
| <i>max_dyn_translations</i> | (Optional) Max Dynamic Translations |
| <i>max_all_host</i>         | (Optional) Max All Hosts            |
| <i>static_translations</i>  | (Optional) No. Static Translations  |
| <i>dynamic_translations</i> | (Optional) No. Dynamic Translations |
| <i>icmp_translations</i>    | (Optional) No. ICMP Translations    |

## Command Mode

- /exec





|                                     |   |
|-------------------------------------|---|
| <i>oi_hits</i>                      | (Optional) Out-In Hits                                |
| <i>oi_misses</i>                    | (Optional) Out-In Misses                              |
| <i>total_sw_translated</i>          | (Optional) Total SW Translated Packets                |
| <i>io_sw_translated</i>             | (Optional) In-Out SW Translated Packets               |
| <i>oi_sw_translated</i>             | (Optional) Out-In SW Translated Packets               |
| <i>total_sw_dropped</i>             | (Optional) Total SW Dropped Packets                   |
| <i>io_sw_dropped</i>                | (Optional) In-Out SW Dropped Packets                  |
| <i>oi_sw_dropped</i>                | (Optional) Out-In SW Dropped Packets                  |
| <i>addr_alloc_fail_drop</i>         | (Optional) Address alloc. failure dropped Packets     |
| <i>port_alloc_fail_drop</i>         | (Optional) Port alloc. failure dropped Packets        |
| <i>dyn_trans_maxlimit_drop</i>      | (Optional) Dyn. Translation max limit dropped Packets |
| <i>icmp_maxlimit_drop</i>           | (Optional) ICMP max limit dropped Packets             |
| <i>allhost_maxlimit_drop</i>        | (Optional) Allhost max limit dropped Packets          |
| <i>total_tcp_session_created</i>    | (Optional) Total tcp session created                  |
| <i>total_tcp_session_closed</i>     | (Optional) Total tcp session closed                   |
| <i>Total_NAT_inside_interfaces</i>  | (Optional) Number of NAT inside interfaces            |
| TABLE_NAT_inside_interfaces         | (Optional) NAT inside interfaces                      |
| <i>nat_inside_interfaces</i>        | (Optional) NAT Inside Interfaces                      |
| <i>Total_NAT_outside_interfaces</i> | (Optional) Number of NAT outside interfaces           |
| TABLE_NAT_outside_interfaces        | (Optional) NAT outside interfaces                     |
| <i>nat_outside_interfaces</i>       | (Optional) NAT Outside Interfaces                     |
| TABLE_NAT_inside_source_list        | (Optional) NAT Inside source list                     |
| TABLE_NAT_outside_source_list       | (Optional) NAT Outside source list                    |
| <i>nat_in_acl_name</i>              | (Optional) NAT inside access list name                |
| <i>nat_out_acl_name</i>             | (Optional) NAT outside access list name               |
| <i>nat_in_acl_refcount</i>          | (Optional) NAT inside access list ref. count          |
| <i>nat_out_acl_refcount</i>         | (Optional) NAT outside access list ref. count         |
| <i>nat_in_pool_name</i>             | (Optional) NAT inside Pool name                       |
| <i>nat_out_pool_name</i>            | (Optional) NAT outside Pool name                      |

|                                      |   |
|--------------------------------------|---|
| <i>nat_pool_overload</i>             | (Optional) NAT Pool overload                                      |
| <i>in_pool_total_address</i>         | (Optional) Total address in the inside pool                       |
| <i>out_pool_total_address</i>        | (Optional) Total address in the outside pool                      |
| <i>in_pool_allocated</i>             | (Optional) Total address allocated in the inside pool             |
| <i>in_pool_allocated_percentage</i>  | (Optional) Total address allocated in the inside pool percentage  |
| <i>out_pool_allocated</i>            | (Optional) Total address allocated in the outside pool            |
| <i>out_pool_allocated_percentage</i> | (Optional) Total address allocated in the outside pool percentage |
| <i>in_pool_missed</i>                | (Optional) Total failed address allocation in the inside pool     |
| <i>out_pool_missed</i>               | (Optional) Total failed address allocation in the outside pool    |
| <i>interface_name</i>                | (Optional) NAT source list interface name                         |
| <i>interface_status</i>              | (Optional) NAT source list interface status                       |
| <i>interface_ip_addr</i>             | (Optional) NAT source list interface addr                         |

**Command Mode**

- /exec

## show ip nat timeout

```
show ip nat timeout [ __readonly__ <tcp_timeout> <udp_timeout> [ <icmp_timeout> ] <dynamic_timeout>
[ <sampling_timeout> ] [ <syn_timeout> ] [ <finrst_timeout> ] ]
```

### Syntax Description

|                         |                                    |
|-------------------------|------------------------------------|
| show                    | Show running system information    |
| ip                      | Show the IP features of the system |
| nat                     | IP NAT information                 |
| timeout                 | IP NAT timeout values              |
| <i>__readonly__</i>     | (Optional)                         |
| <i>tcp_timeout</i>      | (Optional) TCP Timeout             |
| <i>udp_timeout</i>      | (Optional) UDP Timeout             |
| <i>icmp_timeout</i>     | (Optional) ICMP Timeout            |
| <i>dynamic_timeout</i>  | (Optional) Dynamic Timeout         |
| <i>sampling_timeout</i> | (Optional) Sampling Timeout        |
| <i>syn_timeout</i>      | (Optional) SYN Timeout             |
| <i>finrst_timeout</i>   | (Optional) FINRST Timeout          |

### Command Mode

- /exec

# show ip nat translations

```
show ip nat translations [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ verbose ] [ internal-detail ] [
__readonly__ { TABLE_nat_translation [ <Protocol> ] [ <Inside_global_IP_V4_Address> ] [
<Inside_global_port> ] [ <Inside_local_IP_V4_Address> ] [ <Inside_local_port> ] [
<Outside_local_IP_V4_Address> ] [ <Outside_local_port> ] [ <Outside_global_IP_V4_Address> ] [
<Outside_global_port> ] [ <VRF> ] [ <In_stats_count> ] [ <Out_stats_count> ] [ <Group_id> ] [ <Time_left>
] [ <Syn> ] [ <Fin_rst> ] [ <Flags> ] [ <Entry_id> ] [ <State> } } ]
```

## Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information        |
| ip                                  | Show the IP features of the system     |
| nat                                 | IP NAT information                     |
| translations                        | Translation entries                    |
| verbose                             | (Optional) Show extra information      |
| vrf                                 | (Optional) Display per-VRF information |
| <i>vrf-name</i>                     | (Optional) VRF name                    |
| <i>vrf-known-name</i>               | (Optional) Known VRF name              |
| all                                 | (Optional) Display all vrfs            |
| internal-detail                     | (Optional) Display internal debugs     |
| <i>__readonly__</i>                 | (Optional) Readonly                    |
| TABLE_nat_translation               | (Optional) NAT Translation Table       |
| <i>Protocol</i>                     | (Optional) Protocol                    |
| <i>Inside_global_IP_V4_Address</i>  | (Optional) Inside global address       |
| <i>Inside_global_port</i>           | (Optional) Inside global port          |
| <i>Inside_local_IP_V4_Address</i>   | (Optional) Inside local address        |
| <i>Inside_local_port</i>            | (Optional) Inside local port           |
| <i>Outside_local_IP_V4_Address</i>  | (Optional) Outside local address       |
| <i>Outside_local_port</i>           | (Optional) Outside local port          |
| <i>Outside_global_IP_V4_Address</i> | (Optional) Outside global address      |
| <i>Outside_global_port</i>          | (Optional) Outside global port         |
| <i>Flags</i>                        | (Optional) Flags                       |

|                        |                                 |
|------------------------|---------------------------------|
| <i>In_stats_count</i>  | (Optional) In stats count       |
| <i>Out_stats_count</i> | (Optional) Out stats count      |
| <i>Entry_id</i>        | (Optional) Entry ID             |
| <i>State</i>           | (Optional) State                |
| <i>Group_id</i>        | (Optional) Group ID             |
| <i>VRF</i>             | (Optional) VRF                  |
| <i>Time_left</i>       | (Optional) Time Left (HH:MM:SS) |
| <i>Syn</i>             | (Optional) Syn                  |
| <i>Fin_rst</i>         | (Optional) FIN RESET            |

**Command Mode**

- /exec



|  |            |
|--|------------|
| <i>rid</i>                                 | (Optional) |
| <i>domain_id_type</i>                      | (Optional) |
| <i>domain_id_value</i>                     | (Optional) |
| <i>domain_tag</i>                          | (Optional) |
| <i>dn_bit_ignore</i>                       | (Optional) |
| <i>stateful_ha</i>                         | (Optional) |
| <i>gr_ha</i>                               | (Optional) |
| <i>gr_planned_only</i>                     | (Optional) |
| <i>gr_grace_period</i>                     | (Optional) |
| <i>gr_state</i>                            | (Optional) |
| <i>gr_last_status</i>                      | (Optional) |
| <i>gr_helper_mode</i>                      | (Optional) |
| <i>support_tos0_only</i>                   | (Optional) |
| <i>support_opaque_lsa</i>                  | (Optional) |
| <i>low_mem_cond</i>                        | (Optional) |
| <i>is_abr</i>                              | (Optional) |
| <i>is_asbr</i>                             | (Optional) |
| <i>max_lsa_non_self_number</i>             | (Optional) |
| <i>max_lsa_state</i>                       | (Optional) |
| <i>max_lsa_warning_only</i>                | (Optional) |
| <i>max_lsa_current_non_self_lsa_number</i> | (Optional) |
| <i>max_lsa_threshold_pct</i>               | (Optional) |
| <i>max_lsa_ignore_time</i>                 | (Optional) |
| <i>max_lsa_reset_time</i>                  | (Optional) |
| <i>max_lsa_ignore_count</i>                | (Optional) |
| <i>max_lsa_current_ignore_count</i>        | (Optional) |
| <i>max_lsa_ignore_time_left</i>            | (Optional) |
| <i>max_lsa_reset_time_left</i>             | (Optional) |
| <i>max_lsa_permanent_ignore</i>            | (Optional) |

|                             |            |
|-----------------------------|------------|
| TABLE_redist                | (Optional) |
| <i>proto</i>                | (Optional) |
| <i>max_lsas</i>             | (Optional) |
| <i>warning</i>              | (Optional) |
| <i>threshold</i>            | (Optional) |
| <i>current_count</i>        | (Optional) |
| <i>admin_dist</i>           | (Optional) |
| <i>ref_bw</i>               | (Optional) |
| <i>spf_start_time</i>       | (Optional) |
| <i>spf_hold_time</i>        | (Optional) |
| <i>spf_max_time</i>         | (Optional) |
| <i>lsa_start_time</i>       | (Optional) |
| <i>lsa_hold_time</i>        | (Optional) |
| <i>lsa_max_time</i>         | (Optional) |
| <i>min_lsa_arr_time</i>     | (Optional) |
| <i>lsa_aging_pace</i>       | (Optional) |
| <i>spf_max_paths</i>        | (Optional) |
| <i>max_metric_adver</i>     | (Optional) |
| <i>max_metric_time_left</i> | (Optional) |
| <i>max_metric_wait_bgp</i>  | (Optional) |
| <i>max_metric_timeout</i>   | (Optional) |
| <i>max_metric_always</i>    | (Optional) |
| <i>max_metric_sum_lsa</i>   | (Optional) |
| <i>max_metric_ext_lsa</i>   | (Optional) |
| <i>asext_lsa_cnt</i>        | (Optional) |
| <i>asext_lsa_crc</i>        | (Optional) |
| <i>asopaque_lsa_cnt</i>     | (Optional) |
| <i>asopaque_lsa_crc</i>     | (Optional) |
| <i>area_total</i>           | (Optional) |



|                          |            |
|--------------------------|------------|
| <i>area_normal</i>       | (Optional) |
| <i>area_stub</i>         | (Optional) |
| <i>area_nssa</i>         | (Optional) |
| <i>act_area_total</i>    | (Optional) |
| <i>act_area_normal</i>   | (Optional) |
| <i>act_area_stub</i>     | (Optional) |
| <i>act_area_nssa</i>     | (Optional) |
| <i>name_lookup</i>       | (Optional) |
| <i>no_discard_rt_ext</i> | (Optional) |
| <i>no_discard_rt_int</i> | (Optional) |
| <i>passive_dflt</i>      | (Optional) |
| <i>bfd_enabled</i>       | (Optional) |
| <i>segrt_configured</i>  | (Optional) |
| <i>segrt_enabled</i>     | (Optional) |
| <i>srgb_min_label</i>    | (Optional) |
| <i>srgb_max_label</i>    | (Optional) |
| TABLE_area               | (Optional) |
| <i>aname</i>             | (Optional) |
| <i>backbone_active</i>   | (Optional) |
| <i>active</i>            | (Optional) |
| <i>age</i>               | (Optional) |
| <i>total_intf</i>        | (Optional) |
| <i>act_intf</i>          | (Optional) |
| <i>passive_intf</i>      | (Optional) |
| <i>loopback_intf</i>     | (Optional) |
| <i>gr_nbr_cnt</i>        | (Optional) |
| <i>stub</i>              | (Optional) |
| <i>stub_def_cost</i>     | (Optional) |
| <i>nssa</i>              | (Optional) |

|                                      |            |
|--------------------------------------|------------|
| <i>no_redist</i>                     | (Optional) |
| <i>nssa_trans</i>                    | (Optional) |
| <i>no_summary</i>                    | (Optional) |
| <i>auth_type</i>                     | (Optional) |
| <i>area_segrt_configured</i>         | (Optional) |
| <i>area_segrt_disabled_by_config</i> | (Optional) |
| <i>area_segrt_enabled</i>            | (Optional) |
| <i>spf_runs</i>                      | (Optional) |
| <i>last_spf_run_time</i>             | (Optional) |
| TABLE_range                          | (Optional) |
| <i>addr</i>                          | (Optional) |
| <i>masklen</i>                       | (Optional) |
| <i>state</i>                         | (Optional) |
| <i>nets</i>                          | (Optional) |
| <i>advertise</i>                     | (Optional) |
| <i>cost</i>                          | (Optional) |
| <i>filter_in</i>                     | (Optional) |
| <i>filter_out</i>                    | (Optional) |
| <i>lsa_cnt</i>                       | (Optional) |
| <i>lsa_crc</i>                       | (Optional) |
| <i>num_new_lsa_tx</i>                | (Optional) |
| <i>num_new_lsa_rx</i>                | (Optional) |

### Command Mode

- /exec

## show ip ospf border-routers

```
show ip ospf [ <tag> ] border-routers [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> [ TABLE_br <type> <addr> <cost> <asbr> <abr> <area> <spf_inst> [
<vlink_unresolved> ] [ TABLE_br_ubest_nh [ <ubest_nh_addr> ] [ <ubest_nh_intf> ] ] [ TABLE_br_mbset_nh
[ <mbest_nh_addr> ] [ <mbest_nh_intf> ] ] ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| ip                      | Display IP information                      |
| ospf                    | Display OSPF status and configuration       |
| <i>tag</i>              | (Optional) Process tag                      |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| border-routers          | Border routers                              |
| __readonly__            | (Optional)                                  |
| TABLE_ctx               | (Optional)                                  |
| <i>ptag</i>             | (Optional)                                  |
| <i>cname</i>            | (Optional)                                  |
| TABLE_br                | (Optional)                                  |
| <i>type</i>             | (Optional)                                  |
| <i>addr</i>             | (Optional)                                  |
| <i>cost</i>             | (Optional)                                  |
| <i>asbr</i>             | (Optional)                                  |
| <i>abr</i>              | (Optional)                                  |
| <i>area</i>             | (Optional)                                  |
| <i>spf_inst</i>         | (Optional)                                  |
| <i>vlink_unresolved</i> | (Optional)                                  |
| TABLE_br_ubest_nh       | (Optional)                                  |

|                      |            |
|----------------------|------------|
| <i>ubest_nh_addr</i> | (Optional) |
| <i>ubest_nh_intf</i> | (Optional) |
| TABLE_br_mbest_nh    | (Optional) |
| <i>mbest_nh_addr</i> | (Optional) |
| <i>mbest_nh_intf</i> | (Optional) |

**Command Mode**

- /exec

# show ip ospf database

```
show ip ospf [ <tag> ] database [ [ [ network | asbr-summary | summary | router | opaque-link | opaque-area
[ type { router-information | ext-prefix | ext-link } ] | nssa-external ] [ area <area-id-ip> ] ] | external [ ext_tag
<tag_val> ] | opaque-as ] [ <lsid> ] [ self-originated | adv-router <advid> | adv-router-name <adv-name> ] ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [
TABLE_db2_lsa <name> [ <area> ] <id> <advtr> <age> <seqno> <cksum> [ <opaque_id> ] [ <prefix> ] [
<prefix_mask> ] [ <srgb_base> ] [ <srgb_range> ] [ <corrupt> ] [ <rtr_num_links> ] [ <tag> ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| ip                    | Display IP information                            |
| ospf                  | Display OSPF status and configuration             |
| <i>tag</i>            | (Optional) Process tag                            |
| vrf                   | (Optional) Display per-VRF information            |
| <i>vrf-name</i>       | (Optional) VRF name                               |
| <i>vrf-known-name</i> | (Optional) Known VRF name                         |
| all                   | (Optional) Display information for all VRFs       |
| database              | Link-state Database Summary                       |
| network               | (Optional) Display network LSAs                   |
| asbr-summary          | (Optional) Display type 4 (asbr-summary) LSAs     |
| external              | (Optional) Display type 5 (external) LSAs         |
| router                | (Optional) Display router LSAs                    |
| nssa-external         | (Optional) Display type 7 (NSSA external) LSAs    |
| opaque-link           | (Optional) Display Opaque Link-Local LSAs         |
| opaque-area           | (Optional) Display Opaque Area LSAs               |
| opaque-as             | (Optional) Display Opaque AS LSAs                 |
| summary               | (Optional) Display type 3 (network-summary) LSAs  |
| self-originated       | (Optional) Display only self-originated LSAs      |
| <i>lsid</i>           | (Optional) Restrict display by link state ID      |
| adv-router            | (Optional) Restrict display by Advertising router |
| <i>advid</i>          | (Optional) Advertising router ID                  |

|                     |  |
|---------------------|--|
| adv-router-name     | (Optional) Restrict display by Advertising router name |
| <i>adv-name</i>     | (Optional) DNS Name of the Advertising router          |
| area                | (Optional) Display only LSA's in this area             |
| <i>area-id-ip</i>   | (Optional) Area Id as an integer or ip address         |
| ext_tag             | (Optional) Restrict display by tag                     |
| <i>tag_val</i>      | (Optional) 32-bit tag value                            |
| type                | (Optional) Opaque type                                 |
| router-information  | (Optional) Router Information (RI) Opaque LSA          |
| ext-prefix          | (Optional) Extended Prefix Opaque LSA                  |
| ext-link            | (Optional) Extended Link Opaque LSA                    |
| <i>tag</i>          | (Optional)   |
| <i>__readonly__</i> | (Optional)   |
| TABLE_ctx           | (Optional)   |
| <i>rid</i>          | (Optional)   |
| <i>ptag</i>         | (Optional)   |
| <i>cname</i>        | (Optional)   |
| TABLE_db2_lsa       | (Optional)   |
| <i>name</i>         | (Optional)   |
| <i>area</i>         | (Optional)   |
| <i>id</i>           | (Optional)   |
| <i>advrtr</i>       | (Optional)   |
| <i>age</i>          | (Optional)   |
| <i>seqno</i>        | (Optional)   |
| <i>cksum</i>        | (Optional)   |
| <i>opaque_id</i>    | (Optional)   |
| <i>prefix</i>       | (Optional)   |
| <i>prefix_mask</i>  | (Optional)   |
| <i>srgb_base</i>    | (Optional)   |
| <i>srgb_range</i>   | (Optional)   |

|                      |            |
|----------------------|------------|
| <i>corrupt</i>       | (Optional) |
| <i>rtr_num_links</i> | (Optional) |

**Command Mode**

- /exec

## show ip ospf database database-summary

```
show ip ospf [ <tag> ] database database-summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_ctx <rid> <ptag> <cname> [ TABLE_dbsum [ TABLE_dbsum_area <area> [
TABLE_dbsum_area_lsa <area_lsa_name> <area_lsa_count> ] <area_lsa_total> ] [ TABLE_dbsum_all [
TABLE_dbsum_lsa_all <lsa_name> <lsa_count> ] <non_self_lsa_total> <lsa_total> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| database              | Link-state Database Summary                 |
| database-summary      | Summary of database                         |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>rid</i>            | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| TABLE_dbsum           | (Optional)                                  |
| TABLE_dbsum_area      | (Optional)                                  |
| <i>area</i>           | (Optional)                                  |
| TABLE_dbsum_area_lsa  | (Optional)                                  |
| <i>area_lsa_name</i>  | (Optional)                                  |
| <i>area_lsa_count</i> | (Optional)                                  |
| <i>area_lsa_total</i> | (Optional)                                  |
| TABLE_dbsum_all       | (Optional)                                  |



|                           |            |
|---------------------------|------------|
| TABLE_dbsum_lsa_all       | (Optional) |
| <i>lsa_name</i>           | (Optional) |
| <i>lsa_count</i>          | (Optional) |
| <i>non_self_lsa_total</i> | (Optional) |
| <i>lsa_total</i>          | (Optional) |

**Command Mode**

- /exec



|                       |  |
|-----------------------|--|
| opaque-link           | (Optional) Display Opaque Link-Local LSAs              |
| opaque-area           | (Optional) Display Opaque Area LSAs                    |
| opaque-as             | (Optional) Display Opaque AS LSAs                      |
| summary               | (Optional) Display type 3 (network-summary) LSAs       |
| self-originated       | (Optional) Display only self-originated LSAs           |
| <i>lsid</i>           | (Optional) Restrict display by link state ID           |
| adv-router            | (Optional) Restrict display by Advertising router      |
| <i>advid</i>          | (Optional) Advertising router ID                       |
| adv-router-name       | (Optional) Restrict display by Advertising router name |
| <i>adv-name</i>       | (Optional) DNS Name of the Advertising router          |
| area                  | (Optional) Display only LSA's in this area             |
| <i>area-id-ip</i>     | (Optional) Area Id as an integer or ip address         |
| ext_tag               | (Optional) Restrict display by tag                     |
| <i>tag_val</i>        | (Optional) 32-bit tag value                            |
| type                  | (Optional) Opaque type                                 |
| router-information    | (Optional) Router Information (RI) Opaque LSA          |
| ext-prefix            | (Optional) Extended Prefix Opaque LSA                  |
| ext-link              | (Optional) Extended Link Opaque LSA                    |
| detail                | Display LSA in detail                                  |
| private               | (Optional) Developer-only statistics                   |
| __readonly__          | (Optional)   |
| TABLE_ctx             | (Optional)   |
| <i>rid</i>            | (Optional)   |
| <i>ptag</i>           | (Optional)   |
| <i>cname</i>          | (Optional)   |
| TABLE_db2_lsa         | (Optional)   |
| <i>name</i>           | (Optional)   |
| <i>area</i>           | (Optional)   |
| <i>rtr_max_metric</i> | (Optional)   |

|                           |            |
|---------------------------|------------|
| TABLE_lsdb                | (Optional) |
| <i>age</i>                | (Optional) |
| <i>maxage</i>             | (Optional) |
| <i>options</i>            | (Optional) |
| <i>options_str</i>        | (Optional) |
| <i>wrapping</i>           | (Optional) |
| <i>dummy</i>              | (Optional) |
| <i>flush_pending</i>      | (Optional) |
| <i>type</i>               | (Optional) |
| <i>id</i>                 | (Optional) |
| <i>id_str</i>             | (Optional) |
| <i>opaque_type</i>        | (Optional) |
| <i>opaque_type_str</i>    | (Optional) |
| <i>opaque_id</i>          | (Optional) |
| <i>prefix</i>             | (Optional) |
| <i>prefix_mask</i>        | (Optional) |
| <i>srgb_base</i>          | (Optional) |
| <i>srgb_range</i>         | (Optional) |
| <i>advrtr</i>             | (Optional) |
| <i>seqno</i>              | (Optional) |
| <i>cksum</i>              | (Optional) |
| <i>len</i>                | (Optional) |
| <i>corrupt</i>            | (Optional) |
| <i>rtr_abr</i>            | (Optional) |
| <i>rtr_asbr</i>           | (Optional) |
| <i>rtr_translate</i>      | (Optional) |
| <i>rtr_vlink_end</i>      | (Optional) |
| <i>rtr_num_links</i>      | (Optional) |
| <i>rtr_links_mismatch</i> | (Optional) |

|                              |            |
|------------------------------|------------|
| TABLE_rlsa                   | (Optional) |
| <i>rtr_link_type</i>         | (Optional) |
| <i>rtr_link_id_str</i>       | (Optional) |
| <i>rtr_link_id</i>           | (Optional) |
| <i>rtr_link_data_str</i>     | (Optional) |
| <i>rtr_link_data</i>         | (Optional) |
| <i>rtr_link_num_tos</i>      | (Optional) |
| <i>rtr_link_metric</i>       | (Optional) |
| TABLE_rlinktos               | (Optional) |
| <i>rtr_link_tos_id</i>       | (Optional) |
| <i>rtr_link_tos_metric</i>   | (Optional) |
| <i>net_mask</i>              | (Optional) |
| TABLE_netlsa                 | (Optional) |
| <i>net_rtr</i>               | (Optional) |
| <i>sum_mask</i>              | (Optional) |
| <i>sum_metric</i>            | (Optional) |
| TABLE_sumlsa                 | (Optional) |
| <i>sum_tos_id</i>            | (Optional) |
| <i>sum_tos_metric</i>        | (Optional) |
| <i>nssa_mask</i>             | (Optional) |
| <i>nssa_metric_type2</i>     | (Optional) |
| <i>nssa_metric</i>           | (Optional) |
| <i>nssa_fwd_addr</i>         | (Optional) |
| <i>nssa_tag</i>              | (Optional) |
| TABLE_nssa                   | (Optional) |
| <i>nssa_tos_metric_type2</i> | (Optional) |
| <i>nssa_tos_id</i>           | (Optional) |
| <i>nssa_tos_metric</i>       | (Optional) |
| <i>nssa_tos_fwd_addr</i>     | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>nssa_tos_tag</i>           | (Optional) |
| <i>asext_mask</i>             | (Optional) |
| <i>asext_metric_type2</i>     | (Optional) |
| <i>asext_metric</i>           | (Optional) |
| <i>asext_fwd_addr</i>         | (Optional) |
| <i>asext_tag</i>              | (Optional) |
| TABLE_asext                   | (Optional) |
| <i>asext_tos_metric_type2</i> | (Optional) |
| <i>asext_tos_id</i>           | (Optional) |
| <i>asext_tos_metric</i>       | (Optional) |
| <i>asext_tos_fwd_addr</i>     | (Optional) |
| <i>asext_tos_tag</i>          | (Optional) |
| <i>opaque_link_intf</i>       | (Optional) |
| <i>opaque_unknown</i>         | (Optional) |
| <i>opaque_data_len</i>        | (Optional) |
| <i>opaque_data</i>            | (Optional) |
| <i>opaque_corrupt</i>         | (Optional) |
| <i>tlv_type</i>               | (Optional) |
| <i>tlv_len</i>                | (Optional) |
| <i>tlv_data</i>               | (Optional) |
| <i>tlv_unknown</i>            | (Optional) |
| <i>gr_interval</i>            | (Optional) |
| <i>gr_reason</i>              | (Optional) |
| <i>gr_addr</i>                | (Optional) |
| <i>te_frag_id</i>             | (Optional) |
| <i>te_rtr_id</i>              | (Optional) |
| <i>te_link_type</i>           | (Optional) |
| <i>te_link_id</i>             | (Optional) |
| <i>te_link_metric</i>         | (Optional) |

|                         |            |
|-------------------------|------------|
| <i>te_link_max_bw</i>   | (Optional) |
| <i>te_link_rsv_bw</i>   | (Optional) |
| <i>te_link_unrsv_bw</i> | (Optional) |
| <i>te_link_admin</i>    | (Optional) |
| <i>te_num_links</i>     | (Optional) |

**Command Mode**

- /exec

## show ip ospf interface

```
show ip ospf [ <tag> ] interface [ <interface> | vrf { <vrf-name> | <vrf-known-name> | all } ] [ private ] [
__readonly__ TABLE_ctx <ptag> <cname> [ TABLE_intf <ifname> <admin_status> <proto_status> [
<unnumbered> ] <addr> [ <masklen> ] [ <parent_intf> ] <area> [ <if_cfg> ] <state_str> <type_str> <cost>
[ <bfd_enabled> ] [ <ldp_sync> ] [ <dc_enabled> ] [ <sid_index> ] [ <sid_n_flag_clear> ] [ <sid_exp_null>
] <index> [ <passive> ] [ <mpls> ] [ <transmit_delay> ] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid>
] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [ <nbr_adj> ] [ <gr_nbr> ] [ <hello_interval> ] [
<dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [ <hello_timer> ] [ <wait_timer> ] [ <lsu_timer> ]
[ <lsack_timer> ] [ <auth_type> ] [ <keychain_name> ] [ <keychain_ready> ] [ <auth_md5_keyid> ] [
<auth_keyid> ] [ <auth_algo> ] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] [ <multi_area_cnt> ] [ <multi_area_adj>
] [ <state_chg_cnt> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| interface             | OSPF enabled interface                      |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| private               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| TABLE_intf            | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>admin_status</i>   | (Optional)                                  |
| <i>proto_status</i>   | (Optional)                                  |
| <i>unnumbered</i>     | (Optional)                                  |



|                         |            |
|-------------------------|------------|
| <i>addr</i>             | (Optional) |
| <i>masklen</i>          | (Optional) |
| <i>parent_intf</i>      | (Optional) |
| <i>area</i>             | (Optional) |
| <i>if_cfg</i>           | (Optional) |
| <i>state_str</i>        | (Optional) |
| <i>type_str</i>         | (Optional) |
| <i>cost</i>             | (Optional) |
| <i>bfd_enabled</i>      | (Optional) |
| <i>ldp_sync</i>         | (Optional) |
| <i>dc_enabled</i>       | (Optional) |
| <i>sid_index</i>        | (Optional) |
| <i>sid_n_flag_clear</i> | (Optional) |
| <i>sid_exp_null</i>     | (Optional) |
| <i>index</i>            | (Optional) |
| <i>passive</i>          | (Optional) |
| <i>mpls</i>             | (Optional) |
| <i>transmit_delay</i>   | (Optional) |
| <i>if_priority</i>      | (Optional) |
| <i>dr_rid</i>           | (Optional) |
| <i>dr_addr</i>          | (Optional) |
| <i>bdr_rid</i>          | (Optional) |
| <i>bdr_addr</i>         | (Optional) |
| <i>nbr_total</i>        | (Optional) |
| <i>nbr_flood</i>        | (Optional) |
| <i>nbr_adj</i>          | (Optional) |
| <i>gr_nbr</i>           | (Optional) |
| <i>hello_interval</i>   | (Optional) |
| <i>dead_interval</i>    | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>wait_interval</i>  | (Optional) |
| <i>rxmt_interval</i>  | (Optional) |
| <i>hello_timer</i>    | (Optional) |
| <i>wait_timer</i>     | (Optional) |
| <i>lsu_timer</i>      | (Optional) |
| <i>lsack_timer</i>    | (Optional) |
| <i>auth_type</i>      | (Optional) |
| <i>keychain_name</i>  | (Optional) |
| <i>keychain_ready</i> | (Optional) |
| <i>auth_md5_keyid</i> | (Optional) |
| <i>auth_keyid</i>     | (Optional) |
| <i>auth_algo</i>      | (Optional) |
| <i>link_lsa_cnt</i>   | (Optional) |
| <i>link_lsa_crc</i>   | (Optional) |
| <i>multi_area_cnt</i> | (Optional) |
| <i>multi_area_adj</i> | (Optional) |
| <i>state_chg_cnt</i>  | (Optional) |

**Command Mode**

- /exec

# show ip ospf interface brief

```
show ip ospf [ <tag> ] interface brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> <intf_count> TABLE_intf <ifname> <index> <area> <cost> <state_str>
<nbr_total> <admin_status> ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| interface             | OSPF enabled interface                      |
| brief                 | Display summary of OSPF interfaces          |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>intf_count</i>     | (Optional)                                  |
| TABLE_intf            | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>index</i>          | (Optional)                                  |
| <i>area</i>           | (Optional)                                  |
| <i>cost</i>           | (Optional)                                  |
| <i>state_str</i>      | (Optional)                                  |
| <i>nbr_total</i>      | (Optional)                                  |
| <i>admin_status</i>   | (Optional)                                  |

## Command Mode

- /exec



- /exec

# show ip ospf neighbors

```
show ip ospf [ <tag> ] neighbors [ { { <interface> [ <neighbor> | <neighbor-name> ] } | { [ <neighbor> | <neighbor-name> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] } } ] [ __readonly__ TABLE_ctx <ptag> <cname> <nbrcount> [ TABLE_nbr <rid> <priority> <state> <drstate> <uptime> <addr> <intf> [ <multiarea> ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| neighbors             | Neighbor list                               |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| <i>neighbor</i>       | (Optional) Router ID of neighbor            |
| <i>neighbor-name</i>  | (Optional) DNS Name of the neighbor         |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>nbrcount</i>       | (Optional)                                  |
| TABLE_nbr             | (Optional)                                  |
| <i>rid</i>            | (Optional)                                  |
| <i>priority</i>       | (Optional)                                  |
| <i>state</i>          | (Optional)                                  |
| <i>drstate</i>        | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |

|                  |            |
|------------------|------------|
| <i>addr</i>      | (Optional) |
| <i>intf</i>      | (Optional) |
| <i>multiarea</i> | (Optional) |

**Command Mode**

- /exec



## show ip ospf neighbors detail

```
show ip ospf [ <tag> ] neighbors [ <interface> ] [ <neighbor> | <neighbor-name> ] detail [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ private ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_nbr <rid>
<addr> <area> <intf> <state> <transition> <lastchange> [ <bfd_state> ] [ <priority> ] [ <ifid> ] [ <dr> ] [
<dc> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [ <dbdallsent> ] [ <dbdallacked> ] [
<lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] <hellooptions> <dbdoptions> <lastnonhello> [ <deadtimer>
] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [ <lsutimer> ] [ <rerxmtimer> ] [ <fastrerxmtimer>
] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [ <helpercand> ] [ <helperterm> ] [ <senddbd> ] [ <sendlsreq>
] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack> ] [ <sendlsreqreply> ] [ <sradsid> ] [ <sradjflags> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| neighbors             | Neighbor list                               |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| <i>neighbor</i>       | (Optional) Router ID of neighbor            |
| <i>neighbor-name</i>  | (Optional) DNS Name of the neighbor         |
| detail                | Show detailed neighbor display              |
| private               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| __readonly__          | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| TABLE_nbr             | (Optional)                                  |
| <i>rid</i>            | (Optional)                                  |
| <i>addr</i>           | (Optional)                                  |

|                        |            |
|------------------------|------------|
| <i>area</i>            | (Optional) |
| <i>intf</i>            | (Optional) |
| <i>state</i>           | (Optional) |
| <i>transition</i>      | (Optional) |
| <i>lastchange</i>      | (Optional) |
| <i>bfd_state</i>       | (Optional) |
| <i>priority</i>        | (Optional) |
| <i>ifid</i>            | (Optional) |
| <i>dr</i>              | (Optional) |
| <i>bdr</i>             | (Optional) |
| <i>master</i>          | (Optional) |
| <i>seqno</i>           | (Optional) |
| <i>dbdallsentacked</i> | (Optional) |
| <i>dbdallsent</i>      | (Optional) |
| <i>dbdallacked</i>     | (Optional) |
| <i>lsaonreqlist</i>    | (Optional) |
| <i>lsafromlastreq</i>  | (Optional) |
| <i>lsreqrxmts</i>      | (Optional) |
| <i>helloptions</i>     | (Optional) |
| <i>dbdoptions</i>      | (Optional) |
| <i>lastnonhello</i>    | (Optional) |
| <i>deadtimer</i>       | (Optional) |
| <i>paddingtimer</i>    | (Optional) |
| <i>bdbrxmtimer</i>     | (Optional) |
| <i>reqrxmtimer</i>     | (Optional) |
| <i>lsutimer</i>        | (Optional) |
| <i>rerxmtimer</i>      | (Optional) |
| <i>fastrerxmtimer</i>  | (Optional) |
| <i>lsacktimer</i>      | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>grtimer</i>        | (Optional) |
| <i>helpermode</i>     | (Optional) |
| <i>helpercand</i>     | (Optional) |
| <i>helperterm</i>     | (Optional) |
| <i>senddbd</i>        | (Optional) |
| <i>sendlsreq</i>      | (Optional) |
| <i>sendlsu</i>        | (Optional) |
| <i>sendlsurxmt</i>    | (Optional) |
| <i>sendlsack</i>      | (Optional) |
| <i>sendlsreqreply</i> | (Optional) |
| <i>dc</i>             | (Optional) |
| <i>sradjsid</i>       | (Optional) |
| <i>sradjflags</i>     | (Optional) |

**Command Mode**

- /exec

# show ip ospf neighbors summary

```
show ip ospf [ <tag> ] neighbors [ <interface> ] summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ TABLE_ctx <ptag> <cname> TABLE_intf { <ifname> | <total> } <down> <attempt> <init>
<twoway> <exstart> <exchange> <loading> <full> <if_total> ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| neighbors             | Neighbor list                               |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| summary               | Summary of neighbors                        |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| TABLE_intf            | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>total</i>          | (Optional)                                  |
| <i>down</i>           | (Optional)                                  |
| <i>attempt</i>        | (Optional)                                  |
| <i>init</i>           | (Optional)                                  |
| <i>twoway</i>         | (Optional)                                  |
| <i>exstart</i>        | (Optional)                                  |
| <i>exchange</i>       | (Optional)                                  |

|                 |            |
|-----------------|------------|
| <i>loading</i>  | (Optional) |
| <i>full</i>     | (Optional) |
| <i>if_total</i> | (Optional) |

**Command Mode**

- /exec

# show ip ospf request-list

```
show ip ospf [ <tag> ] request-list { <ip-addr> | <neighbor-name> } <interface> [ __readonly__ [ TABLE_ctx  
<ptag> <cname> [ TABLE_lsreq <nbr_rid> <intf> <nbr_addr> <total> [ TABLE_lsa [ <type> ] [ <lsid> ] [ <advrtr> ] [ <seqno> ] [ <cksum> ] [ <age> ] ] ] ] ] ] ] ]
```

## Syntax Description

|                      |                                       |
|----------------------|---------------------------------------|
| show                 | Show running system information       |
| ip                   | Display IP information                |
| ospf                 | Display OSPF status and configuration |
| <i>tag</i>           | (Optional) Process tag                |
| request-list         | Link state request list               |
| <i>interface</i>     | OSPF enabled interface                |
| <i>ip-addr</i>       | Neighbor router ID                    |
| <i>neighbor-name</i> | DNS Name of the neighbor              |
| <i>__readonly__</i>  | (Optional)                            |
| TABLE_ctx            | (Optional)                            |
| <i>ptag</i>          | (Optional)                            |
| <i>cname</i>         | (Optional)                            |
| TABLE_lsreq          | (Optional)                            |
| <i>nbr_rid</i>       | (Optional)                            |
| <i>intf</i>          | (Optional)                            |
| <i>nbr_addr</i>      | (Optional)                            |
| <i>total</i>         | (Optional)                            |
| TABLE_lsa            | (Optional)                            |
| <i>type</i>          | (Optional)                            |
| <i>lsid</i>          | (Optional)                            |
| <i>advrtr</i>        | (Optional)                            |
| <i>seqno</i>         | (Optional)                            |
| <i>cksum</i>         | (Optional)                            |
| <i>age</i>           | (Optional)                            |

**Command Mode**

- /exec





|            |            |
|------------|------------|
| <i>age</i> | (Optional) |
|------------|------------|

**Command Mode**

- /exec



|                           |            |
|---------------------------|------------|
| <i>masklen</i>            | (Optional) |
| <i>type</i>               | (Optional) |
| <i>in_ulib</i>            | (Optional) |
| <i>in_rib</i>             | (Optional) |
| <i>direct</i>             | (Optional) |
| <i>area</i>               | (Optional) |
| <i>sid</i>                | (Optional) |
| <i>in_label</i>           | (Optional) |
| <i>vlink_unresolved</i>   | (Optional) |
| TABLE_route_ubest_nh      | (Optional) |
| <i>ubest_nh_addr</i>      | (Optional) |
| <i>ubest_nh_intf</i>      | (Optional) |
| <i>ubest_cost</i>         | (Optional) |
| <i>distance</i>           | (Optional) |
| <i>ubest_nh_direct</i>    | (Optional) |
| <i>ubest_nh_sham_link</i> | (Optional) |
| <i>ubest_nh_te_tun</i>    | (Optional) |
| <i>ubest_nh_in_rib</i>    | (Optional) |
| <i>out_label</i>          | (Optional) |
| TABLE_route_mbest_nh      | (Optional) |
| <i>mbest_nh_addr</i>      | (Optional) |
| <i>mbest_nh_intf</i>      | (Optional) |
| <i>mbest_cost</i>         | (Optional) |
| <i>mbest_nh_direct</i>    | (Optional) |
| <i>mbest_nh_in_rib</i>    | (Optional) |

### Command Mode

- /exec

## show ip ospf route summary

```
show ip ospf [ <tag> ] route [ <ip-prefix> [ longer-prefixes ] ] summary [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_route <total_routes> <total_paths> [
TABLE_route_type <path_type> <path_routes> <path_paths> ] [ TABLE_route_masklen <masklen>
<masklen_routes> <masklen_paths> ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| ip                    | Display IP information                               |
| ospf                  | Display OSPF status and configuration                |
| <i>tag</i>            | (Optional) Process tag                               |
| vrf                   | (Optional) Display per-VRF information               |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| all                   | (Optional) Display information for all VRFs          |
| route                 | Internal OSPF routes                                 |
| <i>ip-prefix</i>      | (Optional) Show single exact match OSPF route        |
| longer-prefixes       | (Optional) Show exact match and more specific routes |
| summary               | Show route counts                                    |
| <i>__readonly__</i>   | (Optional)   |
| TABLE_ctx             | (Optional)   |
| <i>ptag</i>           | (Optional)   |
| <i>cname</i>          | (Optional)   |
| TABLE_route           | (Optional)   |
| <i>total_routes</i>   | (Optional)   |
| <i>total_paths</i>    | (Optional)   |
| TABLE_route_type      | (Optional)   |
| <i>path_type</i>      | (Optional)   |
| <i>path_routes</i>    | (Optional)   |
| <i>path_paths</i>     | (Optional)   |

|                       |            |
|-----------------------|------------|
| TABLE_route_masklen   | (Optional) |
| <i>masklen</i>        | (Optional) |
| <i>masklen_routes</i> | (Optional) |
| <i>masklen_paths</i>  | (Optional) |

**Command Mode**

- /exec

## show ip ospf segment-routing adj-sid-database

```
show ip ospf [ <tag> ] segment-routing adj-sid-database [ detail ] [ __readonly__ TABLE_ctx <rid> <ptag>
<cname> [ { TABLE_segrt_adj_sid_db <sid_val> <nbr_id> <nbr_addr> <intf> [ <flags> ] [ <lsa> } ] ] ]
```

### Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   | Show running system information       |
| ip                     | Display IP information                |
| ospf                   | Display OSPF status and configuration |
| <i>tag</i>             | (Optional) Process tag                |
| segment-routing        | Segment-Routing information           |
| adj-sid-database       | Adjacency SID Database                |
| detail                 | (Optional) Detailed Information       |
| <i>__readonly__</i>    | (Optional)                            |
| TABLE_ctx              | (Optional)                            |
| <i>rid</i>             | (Optional)                            |
| <i>ptag</i>            | (Optional)                            |
| <i>cname</i>           | (Optional)                            |
| TABLE_segrt_adj_sid_db | (Optional)                            |
| <i>sid_val</i>         | (Optional)                            |
| <i>nbr_id</i>          | (Optional)                            |
| <i>nbr_addr</i>        | (Optional)                            |
| <i>intf</i>            | (Optional)                            |
| <i>flags</i>           | (Optional)                            |
| <i>lsa</i>             | (Optional)                            |

### Command Mode

- /exec

# show ip ospf segment-routing global-block

```
show ip ospf [ <tag> ] segment-routing global-block [ <adv-rtr> ] [ detail ] [ __readonly__ TABLE_ctx <rid>
<ptag> <cname> [ { TABLE_segrt_global_block <area> <adv_router_id> <SR_capable> <SR_algo>
<SRGB_base> <SRGB_range> [ <ril_area> ] [ <lsa> } ] ] ]
```

## Syntax Description

|                          |                                       |
|--------------------------|---------------------------------------|
| show                     | Show running system information       |
| ip                       | Display IP information                |
| ospf                     | Display OSPF status and configuration |
| <i>tag</i>               | (Optional) Process tag                |
| segment-routing          | Segment-Routing information           |
| global-block             | Global Block                          |
| <i>adv-rtr</i>           | (Optional) Advertising Router ID      |
| detail                   | (Optional) Detailed Information       |
| <i>__readonly__</i>      | (Optional)                            |
| TABLE_ctx                | (Optional)                            |
| <i>rid</i>               | (Optional)                            |
| <i>ptag</i>              | (Optional)                            |
| <i>cname</i>             | (Optional)                            |
| TABLE_segrt_global_block | (Optional)                            |
| <i>adv_router_id</i>     | (Optional)                            |
| <i>SR_capable</i>        | (Optional)                            |
| <i>SR_algo</i>           | (Optional)                            |
| <i>SRGB_base</i>         | (Optional)                            |
| <i>SRGB_range</i>        | (Optional)                            |
| <i>area</i>              | (Optional)                            |
| <i>ril_area</i>          | (Optional)                            |
| <i>lsa</i>               | (Optional)                            |

## Command Mode

- /exec

## show ip ospf segment-routing sid-database

```
show ip ospf [ <tag> ] segment-routing sid-database [ <sid-id> ] [ detail ] [ __readonly__ TABLE_ctx <rid>
<ptag> <cname> [ { TABLE_segrt_sid_db <sid_val> <prefix> <prefix_mask> <own_prefix> [
<adv_rtr_vtx_reachable> ] [ <sid_conflict> ] [ <area> ] [ <route_type> ] [ <pfx_flags> ] [ <sid_flags> ] [
<lsa> ] [ <lsa_ref_count> } ] ] ]
```

### Syntax Description

|                              |                                       |
|------------------------------|---------------------------------------|
| show                         | Show running system information       |
| ip                           | Display IP information                |
| ospf                         | Display OSPF status and configuration |
| <i>tag</i>                   | (Optional) Process tag                |
| segment-routing              | Segment-Routing information           |
| sid-database                 | SID Database                          |
| <i>sid-id</i>                | (Optional) SID value                  |
| detail                       | (Optional) Detailed Information       |
| <i>__readonly__</i>          | (Optional)                            |
| TABLE_ctx                    | (Optional)                            |
| <i>rid</i>                   | (Optional)                            |
| <i>ptag</i>                  | (Optional)                            |
| <i>cname</i>                 | (Optional)                            |
| TABLE_segrt_sid_db           | (Optional)                            |
| <i>sid_val</i>               | (Optional)                            |
| <i>prefix</i>                | (Optional)                            |
| <i>prefix_mask</i>           | (Optional)                            |
| <i>own_prefix</i>            | (Optional)                            |
| <i>adv_rtr_vtx_reachable</i> | (Optional)                            |
| <i>sid_conflict</i>          | (Optional)                            |
| <i>area</i>                  | (Optional)                            |
| <i>route_type</i>            | (Optional)                            |
| <i>pfx_flags</i>             | (Optional)                            |



|                      |            |
|----------------------|------------|
| <i>sid_flags</i>     | (Optional) |
| <i>lsa</i>           | (Optional) |
| <i>lsa_ref_count</i> | (Optional) |

**Command Mode**

- /exec



|                         |            |
|-------------------------|------------|
| <i>masklen</i>          | (Optional) |
| <i>parent_intf</i>      | (Optional) |
| <i>area</i>             | (Optional) |
| <i>if_cfg</i>           | (Optional) |
| <i>state_str</i>        | (Optional) |
| <i>type_str</i>         | (Optional) |
| <i>cost</i>             | (Optional) |
| <i>bfd_enabled</i>      | (Optional) |
| <i>ldp_sync</i>         | (Optional) |
| <i>dc_enabled</i>       | (Optional) |
| <i>sid_index</i>        | (Optional) |
| <i>sid_n_flag_clear</i> | (Optional) |
| <i>sid_exp_null</i>     | (Optional) |
| <i>index</i>            | (Optional) |
| <i>passive</i>          | (Optional) |
| <i>mpls</i>             | (Optional) |
| <i>transmit_delay</i>   | (Optional) |
| <i>if_priority</i>      | (Optional) |
| <i>dr_rid</i>           | (Optional) |
| <i>dr_addr</i>          | (Optional) |
| <i>bdr_rid</i>          | (Optional) |
| <i>bdr_addr</i>         | (Optional) |
| <i>nbr_total</i>        | (Optional) |
| <i>nbr_flood</i>        | (Optional) |
| <i>nbr_adj</i>          | (Optional) |
| <i>gr_nbr</i>           | (Optional) |
| <i>hello_interval</i>   | (Optional) |
| <i>dead_interval</i>    | (Optional) |
| <i>wait_interval</i>    | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>rxmt_interval</i>  | (Optional) |
| <i>hello_timer</i>    | (Optional) |
| <i>wait_timer</i>     | (Optional) |
| <i>lsu_timer</i>      | (Optional) |
| <i>lsack_timer</i>    | (Optional) |
| <i>auth_type</i>      | (Optional) |
| <i>keychain_name</i>  | (Optional) |
| <i>keychain_ready</i> | (Optional) |
| <i>auth_md5_keyid</i> | (Optional) |
| <i>auth_keyid</i>     | (Optional) |
| <i>auth_algo</i>      | (Optional) |
| <i>link_lsa_cnt</i>   | (Optional) |
| <i>link_lsa_crc</i>   | (Optional) |
| <i>dest_ip</i>        | (Optional) |
| TABLE_nbr             | (Optional) |
| <i>rid</i>            | (Optional) |
| <i>addr</i>           | (Optional) |
| <i>area</i>           | (Optional) |
| <i>intf</i>           | (Optional) |
| <i>state</i>          | (Optional) |
| <i>transition</i>     | (Optional) |
| <i>lastchange</i>     | (Optional) |
| <i>bfd_state</i>      | (Optional) |
| <i>priority</i>       | (Optional) |
| <i>ifid</i>           | (Optional) |
| <i>dr</i>             | (Optional) |
| <i>bdr</i>            | (Optional) |
| <i>master</i>         | (Optional) |
| <i>seqno</i>          | (Optional) |

|                        |            |
|------------------------|------------|
| <i>dbdallsentacked</i> | (Optional) |
| <i>dbdallsent</i>      | (Optional) |
| <i>dbdallacked</i>     | (Optional) |
| <i>lsaonreqlist</i>    | (Optional) |
| <i>lsafromlastreq</i>  | (Optional) |
| <i>lsreqrxmts</i>      | (Optional) |
| <i>helloptions</i>     | (Optional) |
| <i>dbdoptions</i>      | (Optional) |
| <i>lastnonhello</i>    | (Optional) |
| <i>deadtimer</i>       | (Optional) |
| <i>pacingtimer</i>     | (Optional) |
| <i>dbdrxmtimer</i>     | (Optional) |
| <i>reqrxmtimer</i>     | (Optional) |
| <i>lsutimer</i>        | (Optional) |
| <i>rerxmtimer</i>      | (Optional) |
| <i>fastrerxmtimer</i>  | (Optional) |
| <i>lsacktimer</i>      | (Optional) |
| <i>grtimer</i>         | (Optional) |
| <i>helpermode</i>      | (Optional) |
| <i>helpercand</i>      | (Optional) |
| <i>helperterm</i>      | (Optional) |
| <i>senddbd</i>         | (Optional) |
| <i>sendlsreq</i>       | (Optional) |
| <i>sendlsu</i>         | (Optional) |
| <i>sendlsurxmt</i>     | (Optional) |
| <i>sendlsack</i>       | (Optional) |
| <i>sendlsreqreply</i>  | (Optional) |

**Command Mode**

- /exec

## show ip ospf sham-links brief

```
show ip ospf [ <tag> ] sham-links brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> <count> [ TABLE_slink <src_ip> <dest_ip> <ifnum> <area> <cost> <if_state>
]]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| sham-links            | Sham link information                       |
| brief                 | Display summary of OSPF sham links          |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>count</i>          | (Optional)                                  |
| TABLE_slink           | (Optional)                                  |
| <i>src_ip</i>         | (Optional)                                  |
| <i>dest_ip</i>        | (Optional)                                  |
| <i>ifnum</i>          | (Optional)                                  |
| <i>area</i>           | (Optional)                                  |
| <i>cost</i>           | (Optional)                                  |
| <i>if_state</i>       | (Optional)                                  |

### Command Mode

- /exec

## show ip ospf statistics

```
show ip ospf [ <tag> ] statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_stats
<ptag> <cname> <last_clear> <rid_change> <dr_elections> <older_lsa_recv> <nbr_state_change>
<nbr_dead_postpone> <nbr_dead_expire> <nbr_bad_lsreq> <nbr_seqno_mismatch> <spf_full>
<spf_summary> <spf_external> <spf_extsummary> <rtr_generate> <rtr_refresh> <rtr_flush> <rtr_other_flush>
<net_generate> <net_refresh> <net_flush> <net_other_flush> <sum_generate> <sum_refresh> <sum_flush>
<sum_other_flush> <asbr_generate> <asbr_refresh> <asbr_flush> <asbr_other_flush> <asext_generate>
<asext_refresh> <asext_flush> <asext_other_flush> <opaque_link_generate> <opaque_link_refresh>
<opaque_link_flush> <opaque_link_other_flush> <opaque_area_generate> <opaque_area_refresh>
<opaque_area_flush> <opaque_area_other_flush> <opaque_as_generate> <opaque_as_refresh>
<opaque_as_flush> <opaque_as_other_flush> <limbo_lsa_count> <limbo_lsa_hwm> <limbo_lsa_deleted>
<limbo_lsa_revived> <limbo_runs> <limbo_lsa_last_time_hwm> [ <limbo_timer> ] <helloq_size>
<helloq_max_size> <helloq_hwm> <helloq_drops> <helloq_last_hwm_time> <floodq_size>
<floodq_max_size> <floodq_hwm> <floodq_drops> <floodq_last_hwm_time> <lsdb_add_fail> [
TABLE_buffer_detail [ <buf_size> ] [ <buf_size_huge> ] <buf_in_use> <buf_hwm> <buf_perm> <buf_alloc>
<buf_free> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| statistics            | Event counters                              |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_stats           | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>last_clear</i>     | (Optional)                                  |
| <i>rid_change</i>     | (Optional)                                  |
| <i>dr_elections</i>   | (Optional)                                  |
| <i>older_lsa_recv</i> | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>nbr_state_change</i>   | (Optional) |
| <i>nbr_dead_postpone</i>  | (Optional) |
| <i>nbr_dead_expire</i>    | (Optional) |
| <i>nbr_bad_lsreq</i>      | (Optional) |
| <i>nbr_seqno_mismatch</i> | (Optional) |
| <i>spf_full</i>           | (Optional) |
| <i>spf_summary</i>        | (Optional) |
| <i>spf_external</i>       | (Optional) |
| <i>spf_extsummary</i>     | (Optional) |
| <i>rtr_generate</i>       | (Optional) |
| <i>rtr_refresh</i>        | (Optional) |
| <i>rtr_flush</i>          | (Optional) |
| <i>rtr_other_flush</i>    | (Optional) |
| <i>net_generate</i>       | (Optional) |
| <i>net_refresh</i>        | (Optional) |
| <i>net_flush</i>          | (Optional) |
| <i>net_other_flush</i>    | (Optional) |
| <i>sum_generate</i>       | (Optional) |
| <i>sum_refresh</i>        | (Optional) |
| <i>sum_flush</i>          | (Optional) |
| <i>sum_other_flush</i>    | (Optional) |
| <i>asbr_generate</i>      | (Optional) |
| <i>asbr_refresh</i>       | (Optional) |
| <i>asbr_flush</i>         | (Optional) |
| <i>asbr_other_flush</i>   | (Optional) |
| <i>asext_generate</i>     | (Optional) |
| <i>asext_refresh</i>      | (Optional) |
| <i>asext_flush</i>        | (Optional) |
| <i>asext_other_flush</i>  | (Optional) |



|                                |            |
|--------------------------------|------------|
| <i>opaque_link_generate</i>    | (Optional) |
| <i>opaque_link_refresh</i>     | (Optional) |
| <i>opaque_link_flush</i>       | (Optional) |
| <i>opaque_link_other_flush</i> | (Optional) |
| <i>opaque_area_generate</i>    | (Optional) |
| <i>opaque_area_refresh</i>     | (Optional) |
| <i>opaque_area_flush</i>       | (Optional) |
| <i>opaque_area_other_flush</i> | (Optional) |
| <i>opaque_as_generate</i>      | (Optional) |
| <i>opaque_as_refresh</i>       | (Optional) |
| <i>opaque_as_flush</i>         | (Optional) |
| <i>opaque_as_other_flush</i>   | (Optional) |
| <i>limbo_lsa_count</i>         | (Optional) |
| <i>limbo_lsa_hwm</i>           | (Optional) |
| <i>limbo_lsa_deleted</i>       | (Optional) |
| <i>limbo_lsa_revived</i>       | (Optional) |
| <i>limbo_runs</i>              | (Optional) |
| <i>limbo_lsa_last_time_hwm</i> | (Optional) |
| <i>limbo_timer</i>             | (Optional) |
| <i>helloq_size</i>             | (Optional) |
| <i>helloq_max_size</i>         | (Optional) |
| <i>helloq_hwm</i>              | (Optional) |
| <i>helloq_drops</i>            | (Optional) |
| <i>helloq_last_hwm_time</i>    | (Optional) |
| <i>floodq_size</i>             | (Optional) |
| <i>floodq_max_size</i>         | (Optional) |
| <i>floodq_hwm</i>              | (Optional) |
| <i>floodq_drops</i>            | (Optional) |
| <i>floodq_last_hwm_time</i>    | (Optional) |

|                      |            |
|----------------------|------------|
| <i>lsdb_add_fail</i> | (Optional) |
| TABLE_buffer_detail  | (Optional) |
| <i>buf_size</i>      | (Optional) |
| <i>buf_size_huge</i> | (Optional) |
| <i>buf_in_use</i>    | (Optional) |
| <i>buf_hwm</i>       | (Optional) |
| <i>buf_perm</i>      | (Optional) |
| <i>buf_alloc</i>     | (Optional) |
| <i>buf_free</i>      | (Optional) |

**Command Mode**

- /exec



## show ip ospf traffic

```
show ip ospf [ <tag> ] traffic [ <interface> [ detail ] | [ detail ] | [ detail ] vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_traf <ptag> <cname> <last_clear> [ <ifname> ] <pkt_in> <pkt_out>
<lsu_first_trans> <lsu_retrans> <lsu_for_lsreq> <lsu_nbr_trans> <throttle_out> <throttle_out_token>
<throttle_out_ip> <lsa_ignored> <lsa_dropped_spf> <lsa_dropped_gr> <pkt_drops_in> <pkt_drops_out>
<pkt_errors_in> <pkt_errors_out> <hello_errors_in> <dbds_errors_in> <lsreqs_errors_in> <lsus_errors_in>
<lsacks_errors_in> <pkt_unknown_in> <pkt_unknown_out> <pkt_no_ospf_intf> <bad_version> <bad_crc>
<dup_rtr_id> <dup_src_addr> <invalid_src_addr> <invalid_dst_addr> <non_existing_nbr> <pkt_passive_intf>
<wrong_area> <invalid_pkt_len> <nbr_changed_routerid_ipaddr> <nbr_changed_interfaceid> <bad_auth>
[ <pkt_no_vrf> ] [ <bad_reserved> ] <hellos_in> <dbds_in> <lsreqs_in> <lsus_in> <lsacks_in> <hellos_out>
<dbds_out> <lsreqs_out> <lsus_out> <lsacks_out> [ <hellos_in_hq> <dbds_in_hq> <lsreqs_in_flq>
<lsus_in_flq> <lsacks_in_flq> <lsas_in_dbds_in> <lsas_in_lsreqs_in> <lsas_in_lsus_in> <lsas_in_lsacks_in>
<lsas_in_dbds_out> <lsas_in_lsreqs_out> <lsas_in_lsus_out> <lsas_in_lsacks_out> <lsas_in_rxmt_lsus_out>
] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| detail                | (Optional) Display detailed information     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| traffic               | Packet counters                             |
| <i>__readonly__</i>   | (Optional)                                  |
| <i>TABLE_traf</i>     | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>last_clear</i>     | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>pkt_in</i>         | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>pkt_out</i>            | (Optional) |
| <i>lsu_first_trans</i>    | (Optional) |
| <i>lsu_retrans</i>        | (Optional) |
| <i>lsu_for_lsreq</i>      | (Optional) |
| <i>lsu_nbr_trans</i>      | (Optional) |
| <i>throttle_out</i>       | (Optional) |
| <i>throttle_out_token</i> | (Optional) |
| <i>throttle_out_ip</i>    | (Optional) |
| <i>lsa_ignored</i>        | (Optional) |
| <i>lsa_dropped_spf</i>    | (Optional) |
| <i>lsa_dropped_gr</i>     | (Optional) |
| <i>pkt_drops_in</i>       | (Optional) |
| <i>pkt_drops_out</i>      | (Optional) |
| <i>pkt_errors_in</i>      | (Optional) |
| <i>pkt_errors_out</i>     | (Optional) |
| <i>hello_errors_in</i>    | (Optional) |
| <i>dbds_errors_in</i>     | (Optional) |
| <i>lsreqs_errors_in</i>   | (Optional) |
| <i>lsus_errors_in</i>     | (Optional) |
| <i>lsacks_errors_in</i>   | (Optional) |
| <i>pkt_unknown_in</i>     | (Optional) |
| <i>pkt_unknown_out</i>    | (Optional) |
| <i>pkt_no_ospf_intf</i>   | (Optional) |
| <i>bad_version</i>        | (Optional) |
| <i>bad_crc</i>            | (Optional) |
| <i>dup_rtr_id</i>         | (Optional) |
| <i>dup_src_addr</i>       | (Optional) |
| <i>invalid_src_addr</i>   | (Optional) |
| <i>invalid_dst_addr</i>   | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>non_existing_nbr</i>            | (Optional) |
| <i>pkt_passive_intf</i>            | (Optional) |
| <i>wrong_area</i>                  | (Optional) |
| <i>invalid_pkt_len</i>             | (Optional) |
| <i>nbr_changed_routerid_ipaddr</i> | (Optional) |
| <i>nbr_changed_interfaceid</i>     | (Optional) |
| <i>bad_auth</i>                    | (Optional) |
| <i>bad_reserved</i>                | (Optional) |
| <i>pkt_no_vrf</i>                  | (Optional) |
| <i>hellos_in</i>                   | (Optional) |
| <i>dbds_in</i>                     | (Optional) |
| <i>lsreqs_in</i>                   | (Optional) |
| <i>lsus_in</i>                     | (Optional) |
| <i>lsacks_in</i>                   | (Optional) |
| <i>hellos_out</i>                  | (Optional) |
| <i>dbds_out</i>                    | (Optional) |
| <i>lsreqs_out</i>                  | (Optional) |
| <i>lsus_out</i>                    | (Optional) |
| <i>lsacks_out</i>                  | (Optional) |
| <i>hellos_in_hq</i>                | (Optional) |
| <i>dbds_in_hq</i>                  | (Optional) |
| <i>lsreqs_in_flq</i>               | (Optional) |
| <i>lsus_in_flq</i>                 | (Optional) |
| <i>lsacks_in_flq</i>               | (Optional) |
| <i>lsas_in_dbds_in</i>             | (Optional) |
| <i>lsas_in_lsreqs_in</i>           | (Optional) |
| <i>lsas_in_lsus_in</i>             | (Optional) |
| <i>lsas_in_lsacks_in</i>           | (Optional) |
| <i>lsas_in_dbds_out</i>            | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>lsas_in_lsreqs_out</i>    | (Optional) |
| <i>lsas_in_lsus_out</i>      | (Optional) |
| <i>lsas_in_lsacks_out</i>    | (Optional) |
| <i>lsas_in_rxmt_lsus_out</i> | (Optional) |

**Command Mode**

- /exec

## show ip ospf virtual-links

```
show ip ospf [ <tag> ] virtual-links [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ TABLE_vlink <name> <nbr_rid> <if_state> <transit_area> <nh_intf> <nbr_addr> [
<transit_area_stub> ] [ <transit_area_nssa> ] <addr> [ <masklen> ] <area> [ <if_cfg> ] <state_str> <type_str>
<cost> <index> [ <passive> ] [ <mpls> ] [ <transmit_delay> ] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [
<bdr_rid> ] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [ <nbr_adj> ] [ <gr_nbr> ] [ <hello_interval> ] [
<dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [ <hello_timer> ] [ <wait_timer> ] [ <pacing_timer>
] [ <lsu_timer> ] [ <lsack_timer> ] [ <netlsa_throt_timer> ] [ <auth_type> ] [ <keychain_name> ] [
<keychain_ready> ] [ <auth_md5_keyid> ] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] [ <dc_enabled> ] [ <state>
] [ <transition> ] [ <lastchange> ] [ <priority> ] [ <ifid> ] [ <dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [
<dbdallsentacked> ] [ <dbdallsent> ] [ <dbdallacked> ] [ <lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts>
] [ <helloptions> ] [ <dbdoptions> ] [ <lastnonhello> ] [ <deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ]
[ <reqrxmtimer> ] [ <lsutimer> ] [ <rerxmtimer> ] [ <fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [
<helpermode> ] [ <helpercand> ] [ <helperterm> ] [ <senddbd> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt>
] [ <sendlsack> ] [ <sendlsreply> ] ] ] ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information             |
| ip             | Display IP information                      |
| ospf           | Display OSPF status and configuration       |
| tag            | (Optional) Process tag                      |
| vrf            | (Optional) Display per-VRF information      |
| vrf-name       | (Optional) VRF name                         |
| vrf-known-name | (Optional) Known VRF name                   |
| all            | (Optional) Display information for all VRFs |
| virtual-links  | Virtual link information                    |
| __readonly__   | (Optional)                                  |
| TABLE_ctx      | (Optional)                                  |
| ptag           | (Optional)                                  |
| cname          | (Optional)                                  |
| TABLE_vlink    | (Optional)                                  |
| name           | (Optional)                                  |
| nbr_rid        | (Optional)                                  |
| if_state       | (Optional)                                  |
| transit_area   | (Optional)                                  |



|                          |            |
|--------------------------|------------|
| <i>nh_intf</i>           | (Optional) |
| <i>dc_enabled</i>        | (Optional) |
| <i>nbr_addr</i>          | (Optional) |
| <i>transit_area_stub</i> | (Optional) |
| <i>transit_area_nssa</i> | (Optional) |
| <i>addr</i>              | (Optional) |
| <i>masklen</i>           | (Optional) |
| <i>area</i>              | (Optional) |
| <i>if_cfg</i>            | (Optional) |
| <i>state_str</i>         | (Optional) |
| <i>type_str</i>          | (Optional) |
| <i>cost</i>              | (Optional) |
| <i>index</i>             | (Optional) |
| <i>passive</i>           | (Optional) |
| <i>mpls</i>              | (Optional) |
| <i>transmit_delay</i>    | (Optional) |
| <i>if_priority</i>       | (Optional) |
| <i>dr_rid</i>            | (Optional) |
| <i>dr_addr</i>           | (Optional) |
| <i>bdr_rid</i>           | (Optional) |
| <i>bdr_addr</i>          | (Optional) |
| <i>nbr_total</i>         | (Optional) |
| <i>nbr_flood</i>         | (Optional) |
| <i>nbr_adj</i>           | (Optional) |
| <i>gr_nbr</i>            | (Optional) |
| <i>hello_interval</i>    | (Optional) |
| <i>dead_interval</i>     | (Optional) |
| <i>wait_interval</i>     | (Optional) |
| <i>rxmt_interval</i>     | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>hello_timer</i>        | (Optional) |
| <i>wait_timer</i>         | (Optional) |
| <i>pacing_timer</i>       | (Optional) |
| <i>lsu_timer</i>          | (Optional) |
| <i>lsack_timer</i>        | (Optional) |
| <i>netlsa_throt_timer</i> | (Optional) |
| <i>auth_type</i>          | (Optional) |
| <i>keychain_name</i>      | (Optional) |
| <i>keychain_ready</i>     | (Optional) |
| <i>auth_md5_keyid</i>     | (Optional) |
| <i>link_lsa_cnt</i>       | (Optional) |
| <i>link_lsa_crc</i>       | (Optional) |
| <i>state</i>              | (Optional) |
| <i>transition</i>         | (Optional) |
| <i>lastchange</i>         | (Optional) |
| <i>priority</i>           | (Optional) |
| <i>ifid</i>               | (Optional) |
| <i>dr</i>                 | (Optional) |
| <i>bdr</i>                | (Optional) |
| <i>master</i>             | (Optional) |
| <i>seqno</i>              | (Optional) |
| <i>dbdallsentacked</i>    | (Optional) |
| <i>dbdallsent</i>         | (Optional) |
| <i>dbdallacked</i>        | (Optional) |
| <i>lsaonreqlist</i>       | (Optional) |
| <i>lsafromlastreq</i>     | (Optional) |
| <i>lsreqrxmts</i>         | (Optional) |
| <i>helloptions</i>        | (Optional) |
| <i>dbdoptions</i>         | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>lastmonhello</i>   | (Optional) |
| <i>deadtimer</i>      | (Optional) |
| <i>paddingtimer</i>   | (Optional) |
| <i>dbdrxmtimer</i>    | (Optional) |
| <i>reqrxmtimer</i>    | (Optional) |
| <i>lsutimer</i>       | (Optional) |
| <i>rerxmtimer</i>     | (Optional) |
| <i>fastrerxmtimer</i> | (Optional) |
| <i>lsacktimer</i>     | (Optional) |
| <i>grtimer</i>        | (Optional) |
| <i>helpermode</i>     | (Optional) |
| <i>helpercand</i>     | (Optional) |
| <i>helperterm</i>     | (Optional) |
| <i>senddbd</i>        | (Optional) |
| <i>sendlsreq</i>      | (Optional) |
| <i>sendlsu</i>        | (Optional) |
| <i>sendlsurxmt</i>    | (Optional) |
| <i>sendlsack</i>      | (Optional) |
| <i>sendlsreqreply</i> | (Optional) |

**Command Mode**

- /exec

## show ip ospf virtual-links brief

```
show ip ospf [ <tag> ] virtual-links brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_ctx <ptag> <cname> <vlink_count> [ TABLE_vlink <nbr_rid> <vlink_num> <transit_area> <cost>
<if_state> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| ospf                  | Display OSPF status and configuration       |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| virtual-links         | Virtual link information                    |
| brief                 | Display summary of OSPF virtual links       |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>vlink_count</i>    | (Optional)                                  |
| TABLE_vlink           | (Optional)                                  |
| <i>nbr_rid</i>        | (Optional)                                  |
| <i>vlink_num</i>      | (Optional)                                  |
| <i>transit_area</i>   | (Optional)                                  |
| <i>cost</i>           | (Optional)                                  |
| <i>if_state</i>       | (Optional)                                  |

### Command Mode

- /exec

## show ip pim config-sanity

```
show ip pim config-sanity [ __readonly__ [ TABLE_vrf [ <out-context> ] [ TABLE_RP [ <rp-addr> ] [
<rperr-count> ] [ <rp-interface> ] [ <rp-error> ] [ <rp-sec-addr-err> ] ] [ TABLE_ANYCAST [ <arperr-count>
] [ <anycast-rp-addr> ] [ <arp-interface> ] [ <arp-error> ] [ <configure-as-RP> ] [ TABLE_MEMBER [
<memerr-count> ] [ <mem-interface> ] [ <mem-error> ] ] [ <found> ] ] [ TABLE_BSR [ <rp-cand-count> ]
[ <rp-cand-interface> ] [ <rp-cand-error> ] [ <bsr-cand-count> ] [ <bsr-cand-interface> ] [ <bsr-cand-error>
] ] [ TABLE_AUTORP [ <rp-cand-count> ] [ <rp-cand-interface> ] [ <rp-cand-error> ] [ <auto-cand-count>
] [ <auto-cand-interface> ] [ <auto-cand-error> ] ] ] ] ]
```

### Syntax Description

|                        |                                      |
|------------------------|--------------------------------------|
| show                   | Show running system information      |
| ip                     | Display IP information               |
| pim                    | Display PIM status and configuration |
| config-sanity          | Configuration Sanity check           |
| __readonly__           | (Optional)                           |
| TABLE_vrf              | (Optional)                           |
| <i>out-context</i>     | (Optional)                           |
| TABLE_RP               | (Optional)                           |
| <i>rp-addr</i>         | (Optional)                           |
| <i>rperr-count</i>     | (Optional)                           |
| <i>rp-interface</i>    | (Optional)                           |
| <i>rp-error</i>        | (Optional)                           |
| <i>rp-sec-addr-err</i> | (Optional)                           |
| TABLE_ANYCAST          | (Optional)                           |
| <i>configure-as-RP</i> | (Optional)                           |
| <i>arperr-count</i>    | (Optional)                           |
| <i>anycast-rp-addr</i> | (Optional)                           |
| <i>arp-interface</i>   | (Optional)                           |
| <i>arp-error</i>       | (Optional)                           |
| TABLE_MEMBER           | (Optional)                           |
| <i>memerr-count</i>    | (Optional)                           |
| <i>mem-interface</i>   | (Optional)                           |

|                            |            |
|----------------------------|------------|
| <i>mem-error</i>           | (Optional) |
| <i>found</i>               | (Optional) |
| TABLE_BSR                  | (Optional) |
| <i>rp-cand-count</i>       | (Optional) |
| <i>rp-cand-interface</i>   | (Optional) |
| <i>rp-cand-error</i>       | (Optional) |
| <i>bsr-cand-count</i>      | (Optional) |
| <i>bsr-cand-interface</i>  | (Optional) |
| <i>bsr-cand-error</i>      | (Optional) |
| TABLE_AUTORP               | (Optional) |
| <i>rp-cand-count</i>       | (Optional) |
| <i>rp-cand-interface</i>   | (Optional) |
| <i>rp-cand-error</i>       | (Optional) |
| <i>auto-cand-count</i>     | (Optional) |
| <i>auto-cand-interface</i> | (Optional) |
| <i>auto-cand-error</i>     | (Optional) |

**Command Mode**

- /exec



|                           |            |
|---------------------------|------------|
| TABLE_iod                 | (Optional) |
| <i>if-name</i>            | (Optional) |
| <i>df-winner</i>          | (Optional) |
| <i>df-state</i>           | (Optional) |
| <i>winner-metric-pref</i> | (Optional) |
| <i>winner-metric</i>      | (Optional) |
| <i>uptime</i>             | (Optional) |
| <i>is-rpf</i>             | (Optional) |

**Command Mode**

- /exec



# show ip pim fabric info

```
show ip pim fabric info [ __readonly__ <switch_role> <fabric_ctrl_addr> <peer_fabric_ctrl_infra>
<vpc_domain_id> <peer_fabric_ctrl_addr> ]
```

## Syntax Description

|                               |                                      |
|-------------------------------|--------------------------------------|
| show                          | Show running system information      |
| ip                            | Display IP information               |
| pim                           | Display PIM status and configuration |
| fabric                        | Fabric functionality                 |
| info                          | show the fabric info                 |
| <i>__readonly__</i>           | (Optional)                           |
| <i>switch_role</i>            | (Optional)                           |
| <i>fabric_ctrl_addr</i>       | (Optional)                           |
| <i>peer_fabric_ctrl_infra</i> | (Optional)                           |
| <i>vpc_domain_id</i>          | (Optional)                           |
| <i>peer_fabric_ctrl_addr</i>  | (Optional)                           |

## Command Mode

- /exec

## show ip pim fabric legacy-vlans

show ip pim fabric legacy-vlans [ *\_\_readonly\_\_* *TABLE\_legacy\_vlan* <*vlan\_id*> ]

### Syntax Description

|                          |                                      |
|--------------------------|--------------------------------------|
| show                     | Show running system information      |
| ip                       | Display IP information               |
| pim                      | Display PIM status and configuration |
| fabric                   | Fabric functionality                 |
| legacy-vlans             | Show legacy VLANs on this switch     |
| <i>__readonly__</i>      | (Optional)                           |
| <i>TABLE_legacy_vlan</i> | (Optional)                           |
| <i>vlan_id</i>           | (Optional)                           |

### Command Mode

- /exec

# show ip pim group-range

```
show ip pim group-range [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf <out-context> [ { TABLE_group <grp-addr> [ <invalid-grp> ] [ <action> ] [ <mode> ] [ <rp-addr>
] [ <sh-tree-only-range> ] [ <origin> } ] ] ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information             |
| ip                        | Display IP information                      |
| pim                       | Display PIM status and configuration        |
| group-range               | Display the various group-ranges            |
| <i>group</i>              | (Optional) IP address of group to display   |
| vrf                       | (Optional) Display per-VRF information      |
| <i>vrf-name</i>           | (Optional) VRF name                         |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                   |
| all                       | (Optional) Display information for all VRFs |
| __readonly__              | (Optional)                                  |
| TABLE_vrf                 | (Optional)                                  |
| <i>out-context</i>        | (Optional)                                  |
| TABLE_group               | (Optional)                                  |
| <i>invalid-grp</i>        | (Optional)                                  |
| <i>grp-addr</i>           | (Optional)                                  |
| <i>mode</i>               | (Optional)                                  |
| <i>rp-addr</i>            | (Optional)                                  |
| <i>sh-tree-only-range</i> | (Optional)                                  |
| <i>action</i>             | (Optional)                                  |
| <i>origin</i>             | (Optional)                                  |

## Command Mode

- /exec

# show ip pim host-proxy

show ip pim host-proxy [ \_\_readonly\_\_ TABLE\_intf <intf-name> ]

## Syntax Description

|                  |                                   |
|------------------|-----------------------------------|
| show             | Show running system information   |
| ip               | Display IP information            |
| pim              | PIM global configuration commands |
| host-proxy       | host-proxy                        |
| __readonly__     | (Optional)                        |
| TABLE_intf       | (Optional)                        |
| <i>intf-name</i> | (Optional)                        |

## Command Mode

- /exec

## show ip pim interface

```
show ip pim interface [ <interface> ] [ brief ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [
serialize ] [ __readonly__ [ <is-pim-enabled> ] [ TABLE_vrf [ <out-context> ] [ TABLE_brief [ <if-name>
] [ <if-addr> ] [ <if-dr> ] [ <if-nbr-count> ] [ <if-is-border> ] ] [ TABLE_iod [ <if-name> ] [ <if-status> ] [
<cached_if_status> ] [ <if-addr-summary> ] [ <pim-dr-address> ] [ <dr-priority> ] [ <no-dr-priority> ] [
<nbr-cnt> ] [ <hello-interval-sec> ] [ <hello-interval-msec> ] [ <hello-timer> ] [ <holdtime-msec> ] [
<holdtime-sec> ] [ <if-conf-dr-priority> ] [ <if-conf-delay> ] [ <is-border> ] [ <genid> ] [ <isauth-config> ]
[ <nbr-policy-name> ] [ <jp-in-policy-name> ] [ <jp-out-policy-name> ] [ <jp-interval> ] [ <jp-next-send> ]
[ <pim-bfd-enabled> ] [ <is-passive> ] [ <is-pim-vpc-svi> ] [ <is-auto-enabled> ] [ <vpc-peer-nbr> ] [
<last-cleared> ] [ <hello-sent> ] [ <hello-rcvd> ] [ <hello-early-sent> ] [ <jp-sent> ] [ <jp-rcvd> ] [ <assert-sent>
] [ <assert-rcvd> ] [ <graft-sent> ] [ <graft-rcvd> ] [ <graft-ack-sent> ] [ <graft-ack-rcvd> ] [ <df-offer-sent>
] [ <df-offer-rcvd> ] [ <df-winner-sent> ] [ <df-winner-rcvd> ] [ <df-backoff-sent> ] [ <df-backoff-rcvd> ] [
<pass-sent> ] [ <pass-rcvd> ] [ <cksum-errors> ] [ <invalid-errors> ] [ <invalid-df-errors> ] [ <auth-failed>
] [ <pak-len-errors> ] [ <ver-errors> ] [ <pkts-self> ] [ <pkts-non-nbr> ] [ <pkts-on-passive> ] [ <jp-rcvd-on-rpf>
] [ <jp-rcvd-no-rp> ] [ <jp-rcvd-wrong-rp> ] [ <jp-rcvd-for-ssm> ] [ <jp-rcvd-for-bidir> ] [ <jp-in-policy-filter>
] [ <jp-out-policy-filter> ] [ <ecmp-redirect-sent> ] [ <ecmp-redirect-rcv> ] [ <is-border-router> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                          |
| ip                    | Display IP information                                   |
| pim                   | Display PIM status and configuration                     |
| interface             | Display PIM interface related information                |
| <i>interface</i>      | (Optional) Interface name of single interface to display |
| brief                 | (Optional) Display one line status per interface         |
| vrf                   | (Optional) Display per-VRF information                   |
| <i>vrf-name</i>       | (Optional) VRF name                                      |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                |
| all                   | (Optional) Display information for all VRFs              |
| internal              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                |
| serialize             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                |
| <i>__readonly__</i>   | (Optional)   |
| <i>is-pim-enabled</i> | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>out-context</i>    | (Optional)   |
| TABLE_brief           | (Optional)   |

|                            |            |
|----------------------------|------------|
| <i>if-name</i>             | (Optional) |
| <i>if-addr</i>             | (Optional) |
| <i>if-dr</i>               | (Optional) |
| <i>if-nbr-count</i>        | (Optional) |
| <i>if-is-border</i>        | (Optional) |
| TABLE_iod                  | (Optional) |
| <i>if-name</i>             | (Optional) |
| <i>if-status</i>           | (Optional) |
| <i>cached_if_status</i>    | (Optional) |
| <i>if-addr-summary</i>     | (Optional) |
| <i>pim-dr-address</i>      | (Optional) |
| <i>dr-priority</i>         | (Optional) |
| <i>no-dr-priority</i>      | (Optional) |
| <i>nbr-cnt</i>             | (Optional) |
| <i>hello-interval-sec</i>  | (Optional) |
| <i>hello-interval-msec</i> | (Optional) |
| <i>hello-timer</i>         | (Optional) |
| <i>holdtime-msec</i>       | (Optional) |
| <i>holdtime-sec</i>        | (Optional) |
| <i>if-conf-dr-priority</i> | (Optional) |
| <i>if-conf-delay</i>       | (Optional) |
| <i>is-border</i>           | (Optional) |
| <i>genid</i>               | (Optional) |
| <i>isauth-config</i>       | (Optional) |
| <i>nbr-policy-name</i>     | (Optional) |
| <i>jp-in-policy-name</i>   | (Optional) |
| <i>jp-out-policy-name</i>  | (Optional) |
| <i>jp-interval</i>         | (Optional) |
| <i>jp-next-send</i>        | (Optional) |

|                          |            |
|--------------------------|------------|
| <i>pim-bfd-enabled</i>   | (Optional) |
| <i>is-passive</i>        | (Optional) |
| <i>is-pim-vpc-svi</i>    | (Optional) |
| <i>is-auto-enabled</i>   | (Optional) |
| <i>vpc-peer-nbr</i>      | (Optional) |
| <i>last-cleared</i>      | (Optional) |
| <i>hello-sent</i>        | (Optional) |
| <i>hello-rcvd</i>        | (Optional) |
| <i>hello-early-sent</i>  | (Optional) |
| <i>jp-sent</i>           | (Optional) |
| <i>jp-rcvd</i>           | (Optional) |
| <i>assert-sent</i>       | (Optional) |
| <i>assert-rcvd</i>       | (Optional) |
| <i>graft-sent</i>        | (Optional) |
| <i>graft-rcvd</i>        | (Optional) |
| <i>graft-ack-sent</i>    | (Optional) |
| <i>graft-ack-rcvd</i>    | (Optional) |
| <i>df-offer-sent</i>     | (Optional) |
| <i>df-offer-rcvd</i>     | (Optional) |
| <i>df-winner-sent</i>    | (Optional) |
| <i>df-winner-rcvd</i>    | (Optional) |
| <i>df-backoff-sent</i>   | (Optional) |
| <i>df-backoff-rcvd</i>   | (Optional) |
| <i>pass-sent</i>         | (Optional) |
| <i>pass-rcvd</i>         | (Optional) |
| <i>cksum-errors</i>      | (Optional) |
| <i>invalid-errors</i>    | (Optional) |
| <i>invalid-df-errors</i> | (Optional) |
| <i>auth-failed</i>       | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>pak-len-errors</i>       | (Optional) |
| <i>ver-errors</i>           | (Optional) |
| <i>pkts-self</i>            | (Optional) |
| <i>pkts-non-nbr</i>         | (Optional) |
| <i>pkts-on-passive</i>      | (Optional) |
| <i>jp-rcvd-on-rpf</i>       | (Optional) |
| <i>jp-rcvd-no-rp</i>        | (Optional) |
| <i>jp-rcvd-wrong-rp</i>     | (Optional) |
| <i>jp-rcvd-for-ssm</i>      | (Optional) |
| <i>jp-rcvd-for-bidir</i>    | (Optional) |
| <i>jp-in-policy-filter</i>  | (Optional) |
| <i>jp-out-policy-filter</i> | (Optional) |
| <i>ecmp-redirect-sent</i>   | (Optional) |
| <i>ecmp-redirect-recv</i>   | (Optional) |
| <i>is-border-router</i>     | (Optional) |

**Command Mode**

- /exec



## show ip pim mdt

```
show ip pim mdt [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <out_context>
<mti> <mti_status> <default_mdt_grp> <grp_mode> <asm_shared_tree> <mti_config_mtu> <mti_active_mtu>
<cfg_tunnel_src_if> <bgp_update_src_if> <hello_interval> <jp_interval> <data_mdt_join_interval>
<data_switchover_interval> <data_holddown_interval> <data_timeout_interval> <mdt_src> <mdt_src_if>
<bgp_rd> <bgp_rd_set> <send_join_count> <rcvd_join_count> [ { TABLE_data_mdt <grange_prefix>
<grange_mask_len> <data_grp_mode> <threshold> [ <policy_name> } ] ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information             |
| ip                       | Display IP information                      |
| pim                      | Display PIM status and configuration        |
| mdt                      | Display MDT information                     |
| vrf                      | (Optional) Display per-VRF information      |
| <i>vrf-name</i>          | (Optional) VRF name                         |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                   |
| all                      | (Optional) Display information for all VRFs |
| <i>__readonly__</i>      | (Optional)                                  |
| TABLE_vrf                | (Optional)                                  |
| <i>out_context</i>       | (Optional)                                  |
| <i>mti</i>               | (Optional)                                  |
| <i>mti_status</i>        | (Optional)                                  |
| <i>default_mdt_grp</i>   | (Optional)                                  |
| <i>grp_mode</i>          | (Optional)                                  |
| <i>asm_shared_tree</i>   | (Optional)                                  |
| <i>mti_config_mtu</i>    | (Optional)                                  |
| <i>mti_active_mtu</i>    | (Optional)                                  |
| <i>cfg_tunnel_src_if</i> | (Optional)                                  |
| <i>bgp_update_src_if</i> | (Optional)                                  |
| <i>hello_interval</i>    | (Optional)                                  |
| <i>jp_interval</i>       | (Optional)                                  |

|                                 |            |
|---------------------------------|------------|
| <i>data_mdt_join_interval</i>   | (Optional) |
| <i>data_switchover_interval</i> | (Optional) |
| <i>data_holddown_interval</i>   | (Optional) |
| <i>data_timeout_interval</i>    | (Optional) |
| <i>mdt_src</i>                  | (Optional) |
| <i>mdt_src_if</i>               | (Optional) |
| <i>bgp_rd</i>                   | (Optional) |
| <i>bgp_rd_set</i>               | (Optional) |
| <i>send_join_count</i>          | (Optional) |
| <i>rcvd_join_count</i>          | (Optional) |
| TABLE_data_mdt                  | (Optional) |
| <i>grange_prefix</i>            | (Optional) |
| <i>grange_mask_len</i>          | (Optional) |
| <i>data_grp_mode</i>            | (Optional) |
| <i>threshold</i>                | (Optional) |
| <i>policy_name</i>              | (Optional) |

### Command Mode

- /exec

# show ip pim mdt bgp

```
show ip pim mdt bgp [ mdt-source <src-addr> ] [ __readonly__ { TABLE_entry <bgp_rd> <mdt_src>
<mdt_grp> <local> } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| ip                  | Display IP information                     |
| pim                 | Display PIM status and configuration       |
| mdt                 | Display MDT information                    |
| bgp                 | Display BGP related information            |
| mdt-source          | (Optional) Source address of MVPN neighbor |
| <i>src-addr</i>     | (Optional) Source Address                  |
| <i>__readonly__</i> | (Optional)                                 |
| TABLE_entry         | (Optional)                                 |
| <i>bgp_rd</i>       | (Optional)                                 |
| <i>mdt_src</i>      | (Optional)                                 |
| <i>mdt_grp</i>      | (Optional)                                 |
| <i>local</i>        | (Optional)                                 |

## Command Mode

- /exec

## show ip pim mdt history interval

```
show ip pim mdt history interval <min> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_vrf <out_context> [ { TABLE_entry <csrc> <cgrp> <psrc> <pgrp> <uptime> <send_count> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| pim                   | Display PIM status and configuration        |
| mdt                   | Display MDT information                     |
| history               | Display MDT Data Join Send Histoy           |
| interval              | Display in specified interval               |
| <i>min</i>            | Minutes                                     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| __readonly__          | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_entry           | (Optional)                                  |
| <i>csrc</i>           | (Optional)                                  |
| <i>cgrp</i>           | (Optional)                                  |
| <i>psrc</i>           | (Optional)                                  |
| <i>pgrp</i>           | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| <i>send_count</i>     | (Optional)                                  |

### Command Mode

- /exec

# show ip pim mdt receive

```
show ip pim mdt receive [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
[ <out_context> ] [ TABLE_entry [ <csrc> ] [ <cgrp> ] [ <psrc> ] [ <pgrp> ] [ <uptime> ] [ <expires> ] [
<rcv_count> ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| pim                   | Display PIM status and configuration        |
| mdt                   | Display MDT information                     |
| receive               | Display Received Data Joins Information     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| detail                | (Optional) Display detailed information     |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_entry           | (Optional)                                  |
| <i>csrc</i>           | (Optional)                                  |
| <i>cgrp</i>           | (Optional)                                  |
| <i>psrc</i>           | (Optional)                                  |
| <i>pgrp</i>           | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| <i>expires</i>        | (Optional)                                  |
| <i>rcv_count</i>      | (Optional)                                  |

## Command Mode

- /exec

# show ip pim mdt send

```
show ip pim mdt send [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<out_context> [ { TABLE_entry <csrc> <cgrp> <psrc> <pgrp> <uptime> <send_count> } ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| pim                   | Display PIM status and configuration        |
| mdt                   | Display MDT information                     |
| send                  | Display MDT Data Join Send Information      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| detail                | (Optional) Display detailed information     |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_entry           | (Optional)                                  |
| <i>csrc</i>           | (Optional)                                  |
| <i>cgrp</i>           | (Optional)                                  |
| <i>psrc</i>           | (Optional)                                  |
| <i>pgrp</i>           | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| <i>send_count</i>     | (Optional)                                  |

## Command Mode

- /exec

# show ip pim neighbor

```
show ip pim neighbor { [ <interface> ] | [ <address> ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
detail | internal ] [ serialize ] [ __readonly__ [ TABLE_vrf <out-context> [ TABLE_neighbor
<nbr-addr><if-name><uptime><expires> [ <dr-priority> ] <bidir-capable><bfd-state> [
<longest-hello-intvl><non-hello-pkts> ] [ <ecmp-redirect-capable> ] ] ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                       |
| ip                           | Display IP information                                |
| pim                          | Display PIM status and configuration                  |
| neighbor                     | Display PIM neighbor related information              |
| <i>interface</i>             | (Optional) Display neighbors on single interface name |
| <i>address</i>               | (Optional) IP address of single neighbor to display   |
| vrf                          | (Optional) Display per-VRF information                |
| <i>vrf-name</i>              | (Optional) VRF name                                   |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                             |
| all                          | (Optional) Display information for all VRFs           |
| detail                       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| internal                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| serialize                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>__readonly__</i>          | (Optional)  |
| TABLE_vrf                    | (Optional)  |
| <i>out-context</i>           | (Optional)  |
| TABLE_neighbor               | (Optional)  |
| <i>dr-priority</i>           | (Optional)  |
| <i>ecmp-redirect-capable</i> | (Optional)  |

## Command Mode

- /exec





|                                     |            |
|-------------------------------------|------------|
| TABLE_timeoutlist                   | (Optional) |
| <i>timeoutoif-name</i>              | (Optional) |
| <i>immediate-list-count</i>         | (Optional) |
| TABLE_immediatelist                 | (Optional) |
| <i>immediateoif-name</i>            | (Optional) |
| <i>immediate-timeout-list-count</i> | (Optional) |
| TABLE_immediatettimeoutlist         | (Optional) |
| <i>immediatettimeoutoif-name</i>    | (Optional) |
| <i>sgr-prune-list-count</i>         | (Optional) |
| TABLE_sgrprunelist                  | (Optional) |
| <i>sgrprunelisoif-name</i>          | (Optional) |

**Command Mode**

- /exec

## show ip pim policy statistics

```
show ip pim policy statistics { register-policy | bsr { bsr-policy | rp-candidate-policy } | auto-rp {
rp-candidate-policy | mapping-agent-policy } } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
[ TABLE_vrf [ <vrf_name_stats> ] [ TABLE_routemap [ <name> ] [ <action> ] [ <seq_num> ] [ TABLE_cmd
[ <command> ] [ <compare_count> ] [ <match_count> ] ] ] [ <total_accept_count> ] [ <total_reject_count>
] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| ip                    | Display IP information                         |
| pim                   | PIM global configuration commands              |
| policy                | Policy related information                     |
| statistics            | Policy statistics                              |
| register-policy       | Statistics for Register policy                 |
| bsr                   | Bootstrap protocol RP-distribution policy      |
| bsr-policy            | Statistics for filtered BSR messages           |
| rp-candidate-policy   | Statistics for filtered RP candidate messages  |
| auto-rp               | Statistics for auto-rp messages                |
| rp-candidate-policy   | Statistics for filtered RP candidate messages  |
| mapping-agent-policy  | Statistics for filtered mapping agent messages |
| vrf                   | (Optional) Display per-VRF information         |
| <i>vrf-name</i>       | (Optional) VRF name                            |
| <i>vrf-known-name</i> | (Optional) Known VRF name                      |
| all                   | (Optional) Display information for all VRFs    |
| __readonly__          | (Optional)                                     |
| TABLE_vrf             | (Optional)                                     |
| <i>vrf_name_stats</i> | (Optional)                                     |
| TABLE_routemap        | (Optional)                                     |
| <i>name</i>           | (Optional)                                     |
| <i>action</i>         | (Optional)                                     |
| <i>seq_num</i>        | (Optional)                                     |

|                           |            |
|---------------------------|------------|
| TABLE_cmd                 | (Optional) |
| <i>command</i>            | (Optional) |
| <i>compare_count</i>      | (Optional) |
| <i>match_count</i>        | (Optional) |
| <i>total_accept_count</i> | (Optional) |
| <i>total_reject_count</i> | (Optional) |

**Command Mode**

- /exec

## show ip pim policy statistics jp

```
show ip pim policy statistics { jp-policy | neighbor-policy } <interface> [ __readonly__ { TABLE_routemap
<name> <action> <seq_num> [ { TABLE_cmd <command> <compare_count> <match_count> } ] }
<total_accept_count> <total_reject_count> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information            |
| ip                        | Display IP information                     |
| pim                       | PIM global configuration commands          |
| policy                    | Policy related information                 |
| statistics                | Policy statistics                          |
| jp-policy                 | Statistics for jp-policy                   |
| neighbor-policy           | Statistics for neighbor-policy             |
| <i>interface</i>          | Interface to display policy statistics for |
| <i>__readonly__</i>       | (Optional)                                 |
| TABLE_routemap            | (Optional)                                 |
| <i>name</i>               | (Optional)                                 |
| <i>action</i>             | (Optional)                                 |
| <i>seq_num</i>            | (Optional)                                 |
| TABLE_cmd                 | (Optional)                                 |
| <i>command</i>            | (Optional)                                 |
| <i>compare_count</i>      | (Optional)                                 |
| <i>match_count</i>        | (Optional)                                 |
| <i>total_accept_count</i> | (Optional)                                 |
| <i>total_reject_count</i> | (Optional)                                 |

### Command Mode

- /exec

## show ip pim route

```
show ip pim route [ [ <source> [ <group> ] ] | [ <group> [ <source> ] ] ] [ bitfield ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ serialize ] [ __readonly__ [ TABLE_vrf [ <context-name> ] [ <route-count> ] [
TABLE_one_route [ <mcast-addr> ] [ <rp-addr> ] [ <rp-local> ] [ <bidir> ] [ <sgexpire> ] [ <sgexpire> ]
[ <timeleft> ] [ <rp-bit> ] [ <register> ] [ <intf-name> ] [ <rpf-nbr-1> ] [ <rpf-nbr-addr> ] [ <oif-count> ] [
<oif-bf-str> ] [ <timeout-count> ] [ <timeout-bf-str> ] [ <immediate-count> ] [ <immediate-bf-str> ] [
<immediate-timeout-count> ] [ <immediate-timeout-bf-str> ] [ <sgr-prune-list-count> ] [ <sgr-prune-list-bf-str>
] [ <timeout-interval> ] [ <jp-holdtime-rndup> ] [ <mdt-encap-index> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| pim                   | Display PIM status and configuration        |
| route                 | Display PIM specific route information      |
| <i>group</i>          | (Optional) Group address to display         |
| <i>source</i>         | (Optional) Source address to display        |
| bitfield              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| serialize             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>context-name</i>   | (Optional)                                  |
| <i>route-count</i>    | (Optional)                                  |
| TABLE_one_route       | (Optional)                                  |
| <i>mcast-addr</i>     | (Optional)                                  |
| <i>rp-addr</i>        | (Optional)                                  |
| <i>rp-local</i>       | (Optional)                                  |
| <i>bidir</i>          | (Optional)                                  |
| <i>sgexpire</i>       | (Optional)                                  |

|                                 |            |
|---------------------------------|------------|
| <i>sgrexpire</i>                | (Optional) |
| <i>timeleft</i>                 | (Optional) |
| <i>rp-bit</i>                   | (Optional) |
| <i>register</i>                 | (Optional) |
| <i>intf-name</i>                | (Optional) |
| <i>rpf-nbr-l</i>                | (Optional) |
| <i>rpf-nbr-addr</i>             | (Optional) |
| <i>oif-count</i>                | (Optional) |
| <i>oif-bf-str</i>               | (Optional) |
| <i>timeout-count</i>            | (Optional) |
| <i>timeout-bf-str</i>           | (Optional) |
| <i>immediate-count</i>          | (Optional) |
| <i>immediate-bf-str</i>         | (Optional) |
| <i>immediate-timeout-count</i>  | (Optional) |
| <i>immediate-timeout-bf-str</i> | (Optional) |
| <i>sgr-prune-list-count</i>     | (Optional) |
| <i>sgr-prune-list-bf-str</i>    | (Optional) |
| <i>timeout-interval</i>         | (Optional) |
| <i>jp-holdtime-rndup</i>        | (Optional) |
| <i>mdt-encap-index</i>          | (Optional) |

**Command Mode**

- /exec

# show ip pim rp-hash

```
show ip pim rp-hash <group> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ <out-context>
[ <rp-found> ] [ <is-rp-bsr-learned> ] [ <out-group1> <rp-addr1> ] [ <out-group> <hash-length> <out-bsr> ]
[ { TABLE_rp <rp-addr> <hash> <isbest_hash> } ] ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information             |
| ip                       | Display IP information                      |
| pim                      | Display PIM status and configuration        |
| rp-hash                  | Display RP hash value for group             |
| <i>group</i>             | Group address for RP lookup                 |
| vrf                      | (Optional) Display per-VRF information      |
| <i>vrf-name</i>          | (Optional) VRF name                         |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                   |
| all                      | (Optional) Display information for all VRFs |
| __readonly__             | (Optional)                                  |
| <i>out-context</i>       | (Optional)                                  |
| <i>rp-found</i>          | (Optional)                                  |
| <i>is-rp-bsr-learned</i> | (Optional)                                  |
| <i>out-group1</i>        | (Optional)                                  |
| <i>rp-addr1</i>          | (Optional)                                  |
| <i>out-group</i>         | (Optional)                                  |
| <i>hash-length</i>       | (Optional)                                  |
| <i>out-bsr</i>           | (Optional)                                  |
| TABLE_rp                 | (Optional)                                  |
| <i>rp-addr</i>           | (Optional)                                  |
| <i>hash</i>              | (Optional)                                  |
| <i>isbest_hash</i>       | (Optional)                                  |

## Command Mode

- /exec

## show ip pim rp

```
show ip pim rp [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [ serialize ] [
__readonly__ ] [ TABLE_vrf <out-context> [ <is-bsr-enabled> ] [ <is-bsr-listen-only> ] [ <is-bsr-forward-only>
] [ <bsr-address> ] [ <is-bsr-local> ] [ <bsr-is-local> ] [ <bs-timer> ] [ <bsr-uptime> ] [ <bsr-expires> ] [
<bsr-priority> ] [ <bsr-hash-masklen> ] [ <is-autorp-enabled> ] [ <is-autorp-listen-only> ] [
<is-autorp-forward-only> ] [ <auto-rp-addr> ] [ <is-autorp-local> ] [ <autorp-dis-timer> ] [
<autorp-cand-address> ] [ <autorp-up-time> ] [ <autorp-expire-time> ] [ <rp-cand-policy-name> ] [
<bsr-policy-name> ] [ <rp-announce-policy-name> ] [ <rp-discovery-policy-name> ] [ TABLE_anycast_rp
<anycast-rp-addr> ] [ TABLE_arp_rp <arp-rp-addr> <is-rpaddr-local> ] [ TABLE_rp [ <rp-addr> ] [
<is-rp-local> ] [ <df-ordinal> ] [ <rp-uptime> ] [ <rp-priority> ] [ <is_autorp_source> ] [ <is_bsr_source> ]
[ <is_static_source> ] [ <rp-source> ] [ <static-rp-group-map> ] [ TABLE_grange [ <grange-grp> ] [
<grange-masklen> ] [ <grange-is-deny> ] [ <is-bidir-grp> ] [ <autorp-expires> ] [ <bsr-rp-expires> ] [
<rp-owner-flags> ] ] [ <bidir-ordinal> ] [ <df-bits-recovered> ] [ <rpf-nbr-address> ] [ <metric> ] [
<metric-preference> ] ] ] ] ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                      |
| ip                         | Display IP information                               |
| pim                        | Display PIM status and configuration                 |
| rp                         | Display PIM RP, Auto-RP, and BSR related information |
| <i>group</i>               | (Optional) Display RP for group address              |
| internal                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| vrf                        | (Optional) Display per-VRF information               |
| <i>vrf-name</i>            | (Optional) VRF name                                  |
| <i>vrf-known-name</i>      | (Optional) Known VRF name                            |
| all                        | (Optional) Display information for all VRFs          |
| serialize                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| <i>__readonly__</i>        | (Optional)   |
| TABLE_vrf                  | (Optional)   |
| <i>out-context</i>         | (Optional)   |
| <i>is-bsr-enabled</i>      | (Optional)   |
| <i>is-bsr-listen-only</i>  | (Optional)   |
| <i>is-bsr-forward-only</i> | (Optional)   |
| <i>bsr-address</i>         | (Optional)   |



|                                 |            |
|---------------------------------|------------|
| <i>is-bsr-local</i>             | (Optional) |
| <i>bsr-is-local</i>             | (Optional) |
| <i>bsr-priority</i>             | (Optional) |
| <i>bsr-hash-masklen</i>         | (Optional) |
| <i>bs-timer</i>                 | (Optional) |
| <i>bsr-uptime</i>               | (Optional) |
| <i>bsr-expires</i>              | (Optional) |
| <i>is-autorp-enabled</i>        | (Optional) |
| <i>is-autorp-listen-only</i>    | (Optional) |
| <i>is-autorp-forward-only</i>   | (Optional) |
| <i>auto-rp-addr</i>             | (Optional) |
| <i>autorp-cand-address</i>      | (Optional) |
| <i>is-autorp-local</i>          | (Optional) |
| <i>autorp-dis-timer</i>         | (Optional) |
| <i>autorp-up-time</i>           | (Optional) |
| <i>autorp-expire-time</i>       | (Optional) |
| <i>rp-cand-policy-name</i>      | (Optional) |
| <i>bsr-policy-name</i>          | (Optional) |
| <i>rp-announce-policy-name</i>  | (Optional) |
| <i>rp-discovery-policy-name</i> | (Optional) |
| TABLE_anycast_rp                | (Optional) |
| <i>anycast-rp-addr</i>          | (Optional) |
| TABLE_arp_rp                    | (Optional) |
| <i>arp-rp-addr</i>              | (Optional) |
| <i>is-rpaddr-local</i>          | (Optional) |
| TABLE_rp                        | (Optional) |
| <i>rp-addr</i>                  | (Optional) |
| <i>is-rp-local</i>              | (Optional) |
| <i>df-ordinal</i>               | (Optional) |

|                            |            |
|----------------------------|------------|
| <i>rp-uptime</i>           | (Optional) |
| <i>rp-priority</i>         | (Optional) |
| <i>is_atorp_source</i>     | (Optional) |
| <i>is_bsr_source</i>       | (Optional) |
| <i>is_static_source</i>    | (Optional) |
| <i>rp-source</i>           | (Optional) |
| <i>static-rp-group-map</i> | (Optional) |
| TABLE_grange               | (Optional) |
| <i>grange-grp</i>          | (Optional) |
| <i>grange-masklen</i>      | (Optional) |
| <i>grange-is-deny</i>      | (Optional) |
| <i>is-bidir-grp</i>        | (Optional) |
| <i>atorp-expires</i>       | (Optional) |
| <i>bsr-rp-expires</i>      | (Optional) |
| <i>rp-owner-flags</i>      | (Optional) |
| <i>bidir-ordinal</i>       | (Optional) |
| <i>df-bits-recovered</i>   | (Optional) |
| <i>rpf-nbr-address</i>     | (Optional) |
| <i>metric</i>              | (Optional) |
| <i>metric-preference</i>   | (Optional) |

### Command Mode

- /exec

## show ip pim statistics

```
show ip pim statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ serialize ] [ __readonly__ TABLE_vrf
<vrf-name> [ <uptime> <reg-sent> <reg-rcvd> <null-reg-sent> <null-reg-rcvd> <reg-stop-sent> <reg-stop-rcvd>
<reg-rcvd-not-rp> <reg-rcvd-for-ssm> <reg-rcvd-for-bidir> <bootstrap-sent> <bootstrap-rcvd> <cand-rp-sent>
<cand-rp-rcvd> <bs-no-nbr> <bs-border-deny> <bs-len-errors> <bs-rpf-failed> <bs-no-listen>
<candrp-border-deny> <candrp-no-listen> <autorp-announce-sent> <autorp-announce-rcvd>
<autorp-discovery-sent> <autorp-discovery-rcvd> <autorp-rpf-failed> <autorp-border-deny>
<autorp-invalid-type> <autorp-ttl-expired> <autorp-no-listen> <ctrl-no-route> <data-no-route> <no-state>
<create-state> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| ip                      | Display IP information                      |
| pim                     | Display PIM status and configuration        |
| statistics              | Packet counter statistics                   |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| serialize               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| __readonly__            | (Optional)                                  |
| TABLE_vrf               | (Optional)                                  |
| <i>vrf-name</i>         | (Optional)                                  |
| <i>uptime</i>           | (Optional)                                  |
| <i>reg-sent</i>         | (Optional)                                  |
| <i>reg-rcvd</i>         | (Optional)                                  |
| <i>null-reg-sent</i>    | (Optional)                                  |
| <i>null-reg-rcvd</i>    | (Optional)                                  |
| <i>reg-stop-sent</i>    | (Optional)                                  |
| <i>reg-stop-rcvd</i>    | (Optional)                                  |
| <i>reg-rcvd-not-rp</i>  | (Optional)                                  |
| <i>reg-rcvd-for-ssm</i> | (Optional)                                  |

|                              |            |
|------------------------------|------------|
| <i>reg-rcvd-for-bidir</i>    | (Optional) |
| <i>bootstrap-sent</i>        | (Optional) |
| <i>bootstrap-rcvd</i>        | (Optional) |
| <i>cand-rp-sent</i>          | (Optional) |
| <i>cand-rp-rcvd</i>          | (Optional) |
| <i>bs-no-nbr</i>             | (Optional) |
| <i>bs-border-deny</i>        | (Optional) |
| <i>bs-len-errors</i>         | (Optional) |
| <i>bs-rpf-failed</i>         | (Optional) |
| <i>bs-no-listen</i>          | (Optional) |
| <i>candrp-border-deny</i>    | (Optional) |
| <i>candrp-no-listen</i>      | (Optional) |
| <i>autorp-announce-sent</i>  | (Optional) |
| <i>autorp-announce-rcvd</i>  | (Optional) |
| <i>autorp-discovery-sent</i> | (Optional) |
| <i>autorp-discovery-rcvd</i> | (Optional) |
| <i>autorp-rpf-failed</i>     | (Optional) |
| <i>autorp-border-deny</i>    | (Optional) |
| <i>autorp-invalid-type</i>   | (Optional) |
| <i>autorp-ttl-expired</i>    | (Optional) |
| <i>autorp-no-listen</i>      | (Optional) |
| <i>ctrl-no-route</i>         | (Optional) |
| <i>data-no-route</i>         | (Optional) |
| <i>no-state</i>              | (Optional) |
| <i>create-state</i>          | (Optional) |

**Command Mode**

- /exec

# show ip pim vrf

```
show ip pim vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ detail | internal ] [ __readonly__ {
TABLE_context <out-context> <context-id> <count> <table-id> <bfd> <mvpn> [ <strict_rfc_compliant> ]
[ <global-mcast-bndry> ] } ]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                   |
| ip                          | Display IP information                            |
| pim                         | Display PIM status and configuration              |
| vrf                         | Display per-VRF information                       |
| <i>vrf-name</i>             | (Optional) VRF name                               |
| <i>vrf-known-name</i>       | (Optional) Known VRF name                         |
| all                         | (Optional) Display all VRFs PIM is configured for |
| detail                      | (Optional) Display detailed information           |
| internal                    | (Optional) VRF related internal information       |
| __readonly__                | (Optional)  |
| TABLE_context               | (Optional)  |
| <i>out-context</i>          | (Optional)  |
| <i>context-id</i>           | (Optional)  |
| <i>table-id</i>             | (Optional)  |
| <i>count</i>                | (Optional)  |
| <i>bfd</i>                  | (Optional)  |
| <i>mvpn</i>                 | (Optional)  |
| <i>strict_rfc_compliant</i> | (Optional)  |
| <i>global-mcast-bndry</i>   | (Optional)  |

## Command Mode

- /exec

# show ip ping source-interface

```
show ip ping source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ippingvrf
<vrfname> <ifname> } ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information        |
| ip                    | Display IP information                 |
| ping                  | Display ping client information        |
| source-interface      | Display source interface information   |
| vrf                   | (Optional) Display per-VRF information |
| <i>vrf-name</i>       | (Optional) VRF name                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name              |
| <i>__readonly__</i>   | (Optional)                             |
| TABLE_ippingvrf       | (Optional) source interface of ping    |
| <i>vrfname</i>        | (Optional) vrfname                     |
| <i>ifname</i>         | (Optional) ifname                      |

## Command Mode

- /exec

# show ip ping source-interface vrf all

```
show ip ping source-interface vrf all [ __readonly__ [ { TABLE_ipping <vrfname> <ifname> } ] ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | Display IP information               |
| ping             | Display ping client information      |
| source-interface | Display source interface information |
| vrf              | Display per-VRF information          |
| all              | Display entries for all vrfs         |
| __readonly__     | (Optional)                           |
| TABLE_ipping     | (Optional) source interface of ping  |
| <i>vrfname</i>   | (Optional) vrfname                   |
| <i>ifname</i>    | (Optional) ifname                    |

## Command Mode

- /exec

# show ip policy

```
show ip policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ detail ] [ __readonly__ { TABLE_pbr [
<interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ip                    | Display IP information                      |
| policy                | Policy routing                              |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| detail                | (Optional) Detailed information             |
| __readonly__          | (Optional)                                  |
| TABLE_pbr             | (Optional)                                  |
| <i>interface</i>      | (Optional)                                  |
| <i>rmap</i>           | (Optional)                                  |
| <i>status</i>         | (Optional)                                  |
| <i>vrf_name</i>       | (Optional)                                  |

## Command Mode

- /exec



# show ip prefix-list

```
show ip prefix-list { [ detail | summary ] [ <ipv4-pfl-name> | <ipv4-pfl-cfg-name> ] } | { { <ipv4-pfl-name>
| <ipv4-pfl-cfg-name> } seq <seq-no> } | { { <ipv4-pfl-name> | <ipv4-pfl-cfg-name> } <prefix> [ first-match
| longer ] } } [ __readonly__ TABLE_ip_pfl <name> <seq> <action> <rule> ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information            |
| ip                       | Display IP information                     |
| detail                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED  |
| summary                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED  |
| prefix-list              | List IP prefix lists                       |
| <i>ipv4-pfl-name</i>     | (Optional) Name of prefix-list             |
| <i>ipv4-pfl-cfg-name</i> | (Optional) Known prefix-list name          |
| seq                      | Sequence number                            |
| <i>seq-no</i>            | Sequence number                            |
| <i>prefix</i>            | IP prefix network/length, e.g., 35.0.0.0/8 |
| first-match              | (Optional) Find the first match            |
| longer                   | (Optional) Find the more specific entries  |
| <i>__readonly__</i>      | (Optional)                                 |
| TABLE_ip_pfl             | (Optional)                                 |
| <i>name</i>              | (Optional)                                 |
| <i>seq</i>               | (Optional)                                 |
| <i>action</i>            | (Optional)                                 |
| <i>rule</i>              | (Optional)                                 |

## Command Mode

- /exec

## show ip process

```
show ip process [ api ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_ip_pro_vrf
[ { <pro-cntxt-name> <pro-cntxt-id> <pro-base-tid> <pro-auto-disc> <pro-atuo-add> <pro-null-bcast>
<auto-punt-bcast> <static-disc> <static-def-route> <ip-unreach> } ] [ TABLE_pro_api [ <api-vrf>
<api-cntxt-id> <api-base-tid> <api-ip-addr> <api-rtr-id-iod> ] ] [ TABLE_iod [ { <entry-iod> } ] ] [
TABLE_local_addr [ { <local-addr> } ] ] ] [ TABLE_ip_pro_all { <all-pro-cntxt-name> <all-pro-cntxt-id>
} ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information           |
| ip                      | Display IP information                    |
| process                 | Display IP global information             |
| api                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| vrf                     | (Optional) Display per-VRF information    |
| all                     | (Optional) Display all VRFs               |
| <i>vrf-name</i>         | (Optional) VRF name                       |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                 |
| <i>__readonly__</i>     | (Optional)                                |
| TABLE_ip_pro_vrf        | (Optional)                                |
| <i>pro-cntxt-name</i>   | (Optional)                                |
| <i>pro-cntxt-id</i>     | (Optional)                                |
| <i>pro-base-tid</i>     | (Optional)                                |
| <i>pro-auto-disc</i>    | (Optional)                                |
| <i>pro-atuo-add</i>     | (Optional)                                |
| <i>pro-null-bcast</i>   | (Optional)                                |
| <i>auto-punt-bcast</i>  | (Optional)                                |
| <i>static-disc</i>      | (Optional)                                |
| <i>static-def-route</i> | (Optional)                                |
| <i>ip-unreach</i>       | (Optional)                                |
| TABLE_pro_api           | (Optional)                                |
| <i>api-vrf</i>          | (Optional)                                |

|                           |            |
|---------------------------|------------|
| <i>api-cntxt-id</i>       | (Optional) |
| <i>api-base-tid</i>       | (Optional) |
| <i>api-ip-addr</i>        | (Optional) |
| <i>api-rtr-id-iod</i>     | (Optional) |
| TABLE_iod                 | (Optional) |
| <i>entry-iod</i>          | (Optional) |
| TABLE_local_addr          | (Optional) |
| <i>local-addr</i>         | (Optional) |
| TABLE_ip_pro_all          | (Optional) |
| <i>all-pro-cntxt-name</i> | (Optional) |
| <i>all-pro-cntxt-id</i>   | (Optional) |

**Command Mode**

- /exec

## show ip rip

```
show { ipv6 | ip } rip [ instance <inst> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_mode <isolate-mode> <mmode> [ TABLE_inst <inst-name> TABLE_vrf [ <vrf> ]
<rip-shut-globally-in-this-vrf> <port> <mcast-grp> <admin-dist> <update-tmr> <expire-tmr> <garbage-tmr>
<def-metric> <max-paths> <def-rt-distrib> <def-distrib-always> <process-disabled> <out-of-mem> TABLE_afi
<af> [ TABLE_interface <if-name> ] TABLE_redistrib <redistributing> [ TABLE_clients <pibname> <policy>
] ] ]
```

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information             |
| ipv6                                 | Display IPv6 information                    |
| ip                                   | Display IP information                      |
| rip                                  | Display RIP routing protocol status         |
| instance                             | (Optional) Process ID                       |
| <i>inst</i>                          | (Optional) Process ID                       |
| vrf                                  | (Optional) Display per-VRF information      |
| <i>vrf-name</i>                      | (Optional) VRF name                         |
| <i>vrf-known-name</i>                | (Optional) Known VRF name                   |
| all                                  | (Optional) Display information for all VRFs |
| __readonly__                         | (Optional)                                  |
| TABLE_mode                           | (Optional)                                  |
| <i>isolate-mode</i>                  | (Optional)                                  |
| <i>mmode</i>                         | (Optional)                                  |
| TABLE_inst                           | (Optional)                                  |
| <i>inst-name</i>                     | (Optional)                                  |
| TABLE_vrf                            | (Optional)                                  |
| <i>vrf</i>                           | (Optional)                                  |
| <i>rip-shut-globally-in-this-vrf</i> | (Optional)                                  |
| <i>port</i>                          | (Optional)                                  |
| <i>mcast-grp</i>                     | (Optional)                                  |
| <i>admin-dist</i>                    | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>update-tmr</i>         | (Optional) |
| <i>expire-tmr</i>         | (Optional) |
| <i>garbage-tmr</i>        | (Optional) |
| <i>def-metric</i>         | (Optional) |
| <i>max-paths</i>          | (Optional) |
| <i>def-rt-distrib</i>     | (Optional) |
| <i>def-distrib-always</i> | (Optional) |
| <i>process-disabled</i>   | (Optional) |
| <i>out-of-mem</i>         | (Optional) |
| TABLE_afi                 | (Optional) |
| <i>af</i>                 | (Optional) |
| TABLE_interface           | (Optional) |
| <i>if-name</i>            | (Optional) |
| TABLE_redistrib           | (Optional) |
| <i>redistributing</i>     | (Optional) |
| TABLE_clients             | (Optional) |
| <i>pidname</i>            | (Optional) |
| <i>policy</i>             | (Optional) |

**Command Mode**

- /exec



|                          |            |
|--------------------------|------------|
| <i>local-only</i>        | (Optional) |
| <i>no-addr-conf</i>      | (Optional) |
| <i>if-addr</i>           | (Optional) |
| <i>if-mask</i>           | (Optional) |
| <i>if-metric</i>         | (Optional) |
| <i>poison-reverse</i>    | (Optional) |
| <i>if-passive</i>        | (Optional) |
| <i>route-dist-filter</i> | (Optional) |
| <i>in-policy</i>         | (Optional) |
| <i>out-policy</i>        | (Optional) |
| TABLE_auth               | (Optional) |
| <i>auth-ena</i>          | (Optional) |
| <i>auth-type</i>         | (Optional) |
| <i>auth-keychain</i>     | (Optional) |
| TABLE_detail             | (Optional) |
| <i>import-routes</i>     | (Optional) |
| <i>periodic-updates</i>  | (Optional) |
| <i>trigger-updates</i>   | (Optional) |
| <i>out-mcast-request</i> | (Optional) |
| <i>out-ucast-update</i>  | (Optional) |
| <i>out-ucast-request</i> | (Optional) |
| <i>in-mcast-update</i>   | (Optional) |
| <i>in-mcast-request</i>  | (Optional) |
| <i>in-ucast-update</i>   | (Optional) |
| <i>in-ucast-request</i>  | (Optional) |
| <i>bad-pkt</i>           | (Optional) |
| <i>bad-route</i>         | (Optional) |

### Command Mode

- /exec

## show ip rip neighbor

```
show { ipv6 | ip } rip [ instance <inst> ] neighbor [ <interface> ] [ vrf { <vrf-name> | <vrf-known-name> |
all } ] [ __readonly__ [ TABLE_inst <inst-name> TABLE_vrf [ <vrf> ] <numberof-adj> <dead-timer-seconds>
[ TABLE_adj <adj-addr> <if-name> [ <last-response-sent-state> ] [ <last-response-sent> ] [
<last-response-rcvd-state> ] [ <last-response-rcvd> ] [ <last-request-sent-state> ] [ <last-request-sent> ] [
<last-request-rcvd-state> ] [ <last-request-rcvd> ] <in-bad-packets> <in-bad-routes> ] ] ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information             |
| ipv6                            | Display IPv6 information                    |
| ip                              | Display IP information                      |
| rip                             | Display RIP status and configuration        |
| instance                        | (Optional) Process ID                       |
| <i>inst</i>                     | (Optional) Process ID                       |
| neighbor                        | RIP neighbor                                |
| <i>interface</i>                | (Optional) RIP interface                    |
| vrf                             | (Optional) Display per-VRF information      |
| <i>vrf-name</i>                 | (Optional) VRF name                         |
| <i>vrf-known-name</i>           | (Optional) Known VRF name                   |
| all                             | (Optional) Display information for all VRFs |
| <i>__readonly__</i>             | (Optional)                                  |
| TABLE_inst                      | (Optional)                                  |
| <i>inst-name</i>                | (Optional)                                  |
| TABLE_vrf                       | (Optional)                                  |
| <i>vrf</i>                      | (Optional)                                  |
| <i>numberof-adj</i>             | (Optional)                                  |
| <i>dead-timer-seconds</i>       | (Optional)                                  |
| TABLE_adj                       | (Optional)                                  |
| <i>adj-addr</i>                 | (Optional)                                  |
| <i>if-name</i>                  | (Optional)                                  |
| <i>last-response-sent-state</i> | (Optional)                                  |



|                                 |            |
|---------------------------------|------------|
| <i>last-response-sent</i>       | (Optional) |
| <i>last-response-rcvd-state</i> | (Optional) |
| <i>last-response-rcvd</i>       | (Optional) |
| <i>last-request-sent-state</i>  | (Optional) |
| <i>last-request-sent</i>        | (Optional) |
| <i>last-request-rcvd-state</i>  | (Optional) |
| <i>last-request-rcvd</i>        | (Optional) |
| <i>in-bad-packets</i>           | (Optional) |
| <i>in-bad-routes</i>            | (Optional) |

**Command Mode**

- /exec

## show ip rip policy statistics redistribute

```
show ip rip [ instance <inst> ] policy statistics redistribute { bgp <asn> | { eigrp | isis | <src-rip> | ospf } <tag>
| direct | static } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_asn <asn> TABLE_vrf
<vrf> [ TABLE_rmap [ <name> <action> <seq_num> ] [ TABLE_cmd <command> [ <compare_count> ]
<match_count> ] ] <total_accept_count> <total_reject_count> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| ip                    | Display IP information                              |
| rip                   | Display RIP routing protocol status                 |
| instance              | (Optional) Process ID                               |
| <i>inst</i>           | (Optional) Process ID                               |
| policy                | Policy related information                          |
| statistics            | Policy statistics                                   |
| redistribute          | RIP redistribute routes from other routing protocol |
| bgp                   | Border Gateway Protocol (BGP)                       |
| eigrp                 | Enhanced Interior Gateway Routing Protocol (EIGRP)  |
| <i>as</i>             | Autonomous system number                            |
| isis                  | Intermediate-to-intermediate (ISIS)                 |
| src-rip               | Routing Information Protocol (RIP)                  |
| ospf                  | Open Shortest Path First (OSPFv2)                   |
| <i>tag</i>            | Process tag   |
| direct                | Directly connected routes                           |
| static                | Static routes                                       |
| vrf                   | (Optional) Display per-VRF information              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| all                   | (Optional) Display information for all VRFs         |
| __readonly__          | (Optional)  |
| TABLE_asn             | (Optional) AS number table                          |

|                           |   |
|---------------------------|---|
| <i>asn</i>                | (Optional) AS number                                      |
| TABLE_vrf                 | (Optional) VRF table                                      |
| <i>vrf</i>                | (Optional) VRF name                                       |
| TABLE_rmap                | (Optional) Routemap table                                 |
| <i>name</i>               | (Optional) Route-map Name                                 |
| <i>action</i>             | (Optional) Route-map action                               |
| <i>seq_num</i>            | (Optional) Sequence number of the rule in route-map       |
| TABLE_cmd                 | (Optional) Route-map command table                        |
| <i>command</i>            | (Optional) Route-map command                              |
| <i>compare_count</i>      | (Optional) Number of comparisons                          |
| <i>match_count</i>        | (Optional) Number of matches                              |
| <i>total_accept_count</i> | (Optional) Total number of packets accepted by the policy |
| <i>total_reject_count</i> | (Optional) Total number of packets rejected by the policy |

**Command Mode**

- /exec

## show ip rip route

```
show { ipv6 | ip } rip [ instance <inst> ] route [ { <ipv6-prefix> | <ip-prefix> } [ { longer-prefixes |
shorter-prefixes } ] ] [ summary ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_inst
<inst-name> TABLE_vrf [ <vrf> ] TABLE_issummary <is-summary> [ TABLE_route <rt-prefix> <rt-mask>
<rt-numnh> <best-route> [ TABLE_nexthop [ <nh-addr> ] [ <nh-interface> ] [ <nh-metric> ] [ <nh-tag> ] [
<nh-direct> ] [ <nh-redistrib> ] [ <nh-state> ] [ <nh-state-timer> ] ] ] [ TABLE_summary <total-num-rts>
<total-best-rts> <total-paths> [ TABLE_rtspermask <mask-length> <rts-per-mask> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| ipv6                  | Display IPv6 information                        |
| ip                    | Display IP information                          |
| rip                   | Display RIP routing protocol status             |
| instance              | (Optional) Process ID                           |
| <i>inst</i>           | (Optional) Process ID                           |
| route                 | RIP routes                                      |
| summary               | (Optional) route counts                         |
| <i>ip-prefix</i>      | (Optional) Exact prefix                         |
| longer-prefixes       | (Optional) exact match and more specific routes |
| shorter-prefixes      | (Optional) exact match and less specific routes |
| vrf                   | (Optional) Display per-VRF information          |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| all                   | (Optional) Display information for all VRFs     |
| <u>__readonly__</u>   | (Optional)                                      |
| TABLE_inst            | (Optional)                                      |
| <i>inst-name</i>      | (Optional)                                      |
| TABLE_vrf             | (Optional)                                      |
| <i>vrf</i>            | (Optional)                                      |
| TABLE_issummary       | (Optional)                                      |
| <i>is-summary</i>     | (Optional)                                      |

|                       |            |
|-----------------------|------------|
| TABLE_route           | (Optional) |
| <i>rt-prefix</i>      | (Optional) |
| <i>rt-mask</i>        | (Optional) |
| <i>rt-nummh</i>       | (Optional) |
| <i>best-route</i>     | (Optional) |
| TABLE_nexthop         | (Optional) |
| <i>nh-addr</i>        | (Optional) |
| <i>nh-interface</i>   | (Optional) |
| <i>nh-metric</i>      | (Optional) |
| <i>nh-tag</i>         | (Optional) |
| <i>nh-direct</i>      | (Optional) |
| <i>nh-redistrib</i>   | (Optional) |
| <i>nh-state</i>       | (Optional) |
| <i>nh-state-timer</i> | (Optional) |
| TABLE_summary         | (Optional) |
| <i>total-num-rts</i>  | (Optional) |
| <i>total-best-rts</i> | (Optional) |
| <i>total-paths</i>    | (Optional) |
| TABLE_rtspermask      | (Optional) |
| <i>mask-length</i>    | (Optional) |
| <i>rts-per-mask</i>   | (Optional) |

### Command Mode

- /exec

## show ip rip statistics

```
show { ipv6 | ip } rip [ instance <inst> ] statistics [ * | <interface> ] [ __readonly__ [ TABLE_inst <inst-name>
TABLE_interface <if-name> [ <periodic-updates> <trigger-updates> <out-mcast-request> <out-ucast-update>
<out-ucast-request> <in-mcast-update> <in-mcast-request> <in-ucast-update> <in-ucast-request> <bad-pkt>
<bad-route> ] ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information              |
| ipv6                     | Display IPv6 information                     |
| ip                       | Display IP information                       |
| rip                      | Display RIP status and configuration         |
| instance                 | (Optional) Process ID                        |
| <i>inst</i>              | (Optional) Process ID                        |
| statistics               | RIP statistics                               |
| <i>interface</i>         | (Optional) RIP interface                     |
| *                        | (Optional) RIP statistics for all interfaces |
| __readonly__             | (Optional)                                   |
| TABLE_inst               | (Optional)                                   |
| <i>inst-name</i>         | (Optional)                                   |
| TABLE_interface          | (Optional)                                   |
| <i>if-name</i>           | (Optional)                                   |
| <i>periodic-updates</i>  | (Optional)                                   |
| <i>trigger-updates</i>   | (Optional)                                   |
| <i>out-mcast-request</i> | (Optional)                                   |
| <i>out-ucast-update</i>  | (Optional)                                   |
| <i>out-ucast-request</i> | (Optional)                                   |
| <i>in-mcast-update</i>   | (Optional)                                   |
| <i>in-mcast-request</i>  | (Optional)                                   |
| <i>in-ucast-update</i>   | (Optional)                                   |
| <i>in-ucast-request</i>  | (Optional)                                   |

|                  |            |
|------------------|------------|
| <i>bad-pkt</i>   | (Optional) |
| <i>bad-route</i> | (Optional) |

**Command Mode**

- /exec

## show ip route

```

show ip route [ ip | ipv4 ] [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ip-addr> | {
<ip-prefix> [ { longer-prefixes | shorter-prefixes } ] } ] [ { <protocol> [ all ] } | { bind-label <bind-lbl> |
next-hop <next-hop> | next-hop-v6 <next-hop-v6> } | { interface <interface> } | { updated { [ since <stime>
] [ until <utime> ] } } ] + [ summary [ cached ] | detail | summary-counter-consistency-check ] [ vrf {
<vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf
<addrf> [ TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> <attached> TABLE_path [ <ipnexthop>
] [ <ipv6nexthop> ] [ <nexthop-vrf-name> ] [ <ifname> ] [ <bindlbl> ] [ <uptime> ] [ <pref> ] [ <metric> ] [ <clientname>
] [ <type> ] [ <tag> ] [ <stale> ] [ <unres> ] [ <hidden> ] [ <stale-label> ] [ <bgpbackuppath> ] [ <type2> ] [
<remote-sid> ] [ <src-ip> ] [ <sid-ct> ] [ <bsid> ] [ <ubest> ] [ <mbest> ] ] [ TABLE_summary <routes>
<paths> [ <multicast_paths> ] [ TABLE_unicast [ <clientnameuni> ] [ <best-paths> ] [ <backup-paths> ] ] [
TABLE_multicast [ <clientnamemulti> ] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_route_count [
<mask_len> ] [ <count> ] ] ] ] ] ]

```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                    |
| ip                    | Display IP information   |
| route                 | Display routing information  |
| vrf                   | (Optional) Display per-VRF information                             |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name  |
| vrf-all               | (Optional) Display information for all VRFs                        |
| ipv4                  | (Optional) Display IP information                                  |
| unicast               | (Optional) Display unicast information                             |
| topology              | (Optional) Display per-topology information                        |
| <i>topology-name</i>  | (Optional) topology name   |
| l3vm-info             | (Optional) Display corresponding L3VM information                  |
| rpf                   | (Optional) Display RPF information for multicast source            |
| <i>ip-addr</i>        | (Optional) Display single route longest match lookup               |
| <i>ip-prefix</i>      | (Optional) Display single exact match route                        |
| longer-prefixes       | (Optional) Display matching routes with mask-lengths $\geq$ prefix |
| shorter-prefixes      | (Optional) Display matching routes with mask-lengths $\leq$ prefix |
| <i>protocol</i>       | (Optional) Display routes for protocol (or route type)             |
| all                   | (Optional) Display routes for protocol for backup next-hops too    |



|                                   |   |
|-----------------------------------|---|
| bind-label                        | (Optional) Display routes with this bind-label only         |
| <i>bind-lbl</i>                   | (Optional) Binding label                                    |
| next-hop                          | (Optional) Display routes with this next-hop only           |
| <i>next-hop</i>                   | (Optional) Next hop address                                 |
| next-hop-v6                       | (Optional) Display routes with this V6 next-hop only        |
| interface                         | (Optional) Display routes with this output interface only   |
| <i>interface</i>                  | (Optional) Interface Name                                   |
| updated                           | (Optional) Display routes filtered by last updated time     |
| since                             | (Optional) Display those routes updated since this time     |
| <i>stime</i>                      | (Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| until                             | (Optional) Display those routes updated until this time     |
| <i>utime</i>                      | (Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| summary                           | (Optional) Display route counts                             |
| detail                            | (Optional) Display routes in full detail                    |
| cached                            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| summary-counter-consistency-check | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <u>__readonly__</u>               | (Optional)  |
| TABLE_vrf                         | (Optional)  |
| <i>vrf-name-out</i>               | (Optional)  |
| TABLE_addrf                       | (Optional)  |
| <i>addrf</i>                      | (Optional)  |
| TABLE_prefix                      | (Optional)  |
| <i>ipprefix</i>                   | (Optional)  |
| <i>ucast-nhops</i>                | (Optional)  |
| <i>mcast-nhops</i>                | (Optional)  |
| <i>attached</i>                   | (Optional)  |
| TABLE_path                        | (Optional)  |
| <i>ipnexthop</i>                  | (Optional)  |
| <i>nexthop-vrf-name</i>           | (Optional)  |

|                        |            |
|------------------------|------------|
| <i>ifname</i>          | (Optional) |
| <i>bindlbl</i>         | (Optional) |
| <i>uptime</i>          | (Optional) |
| <i>pref</i>            | (Optional) |
| <i>metric</i>          | (Optional) |
| <i>clientname</i>      | (Optional) |
| <i>type</i>            | (Optional) |
| <i>tag</i>             | (Optional) |
| <i>stale</i>           | (Optional) |
| <i>unres</i>           | (Optional) |
| <i>hidden</i>          | (Optional) |
| <i>stale-label</i>     | (Optional) |
| <i>bgpbackuppath</i>   | (Optional) |
| <i>type2</i>           | (Optional) |
| <i>remote-sid</i>      | (Optional) |
| <i>sid-fct</i>         | (Optional) |
| <i>ubest</i>           | (Optional) |
| <i>mbest</i>           | (Optional) |
| TABLE_summary          | (Optional) |
| <i>routes</i>          | (Optional) |
| <i>paths</i>           | (Optional) |
| <i>multicast_paths</i> | (Optional) |
| TABLE_unicast          | (Optional) |
| <i>clientnameuni</i>   | (Optional) |
| <i>best-paths</i>      | (Optional) |
| <i>backup-paths</i>    | (Optional) |
| TABLE_multicast        | (Optional) |
| <i>clientnamemulti</i> | (Optional) |
| <i>best-paths</i>      | (Optional) |

|                     |            |
|---------------------|------------|
| <i>backup-paths</i> | (Optional) |
| TABLE_route_count   | (Optional) |
| <i>mask_len</i>     | (Optional) |
| <i>count</i>        | (Optional) |

**Command Mode**

- /exec

# show ip sla application

```
show ip sla application [ __readonly__ <version> [ <line-length> ] <type-name> <feature-name>
<lowmemorymark> <max-entries> <probe-cap> <entries-config> <entries-active> <entries-pending>
<entries-inactive> <last-change-time> <rttMonApplReset> [ <rttMonApplTimeOfLastSet> ] ]
```

## Syntax Description

|                                |                               |
|--------------------------------|-------------------------------|
| show                           |                               |
| ip                             |                               |
| sla                            | Service Level Agreement (SLA) |
| application                    | IP SLAs Application           |
| <i>__readonly__</i>            | (Optional)                    |
| <i>version</i>                 | (Optional)                    |
| <i>line-length</i>             | (Optional)                    |
| <i>type-name</i>               | (Optional)                    |
| <i>feature-name</i>            | (Optional)                    |
| <i>lowmemorymark</i>           | (Optional)                    |
| <i>max-entries</i>             | (Optional)                    |
| <i>probe-cap</i>               | (Optional)                    |
| <i>entries-config</i>          | (Optional)                    |
| <i>entries-active</i>          | (Optional)                    |
| <i>entries-pending</i>         | (Optional)                    |
| <i>entries-inactive</i>        | (Optional)                    |
| <i>last-change-time</i>        | (Optional)                    |
| <i>rttMonApplReset</i>         | (Optional) Appl Reset         |
| <i>rttMonApplTimeOfLastSet</i> | (Optional)                    |

## Command Mode

- /exec

# show ip sla configuration

```
show ip sla configuration [ <entry-num> ] [ dynamic ] [ __readonly__ { TABLE_configuration [ <index> ]
[ <owner> ] [ <tag> ] [ <timeout> ] [ <oper-type> ] [ <dest-ip> ] [ <source-int> ] [ <source-ip> ] [ <dest-port> ]
[ <source-port> ] [ <dns-source-port> ] [ <traffic-class> ] [ <tos> ] [ <dns-name-server> ] [ <flow-label> ]
[ <switch-id> ] [ <profile-id> ] [ <interface> ] [ <packet-size> ] [ <packet-interval> ] [ <num-packets> ] [
<codec-type> ] [ <codec-num-packets> ] [ <codec-packet-size> ] [ <codec-packet-interval> ] [
<codec-adv-factor> ] [ <verify-data> ] [ <data-pattern> ] [ <precision> ] [ <packet-priority> ] [
<ntp-sync-tolerance> ] [ <ntp-sync-to-type> ] [ <vrf-name> ] [ <control-enabled> ] [ <http-oper> ] [
<http-version> ] [ <url> ] [ <proxy> ] [ <raw-strings> ] [ <cache-control> ] [ <http-vrf-name> ] [ <http-owner> ]
] [ <http-tag> ] [ <http-timeout> ] [ <frequency> ] [ <frequency-in-ms> ] [ <secondary-freq-timeout> ] [
<secondary-freq-loss> ] [ <next-start-time> ] [ <group-scheduled> ] [ <randomly-scheduled> ] [
<low-frequency> ] [ <high-frequency> ] [ <life> ] [ <ageout> ] [ <recurring> ] [ <status-of-entry> ] [
<threshold> ] [ <hours> ] [ <buckets> ] [ <interval> ] [ <einterval> ] [ <ebuckets> ] [ <lives> ] [ <hsbuckets> ]
] [ <filter> ] } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                |  |
| ip                  |  |
| sla                 | Service Level Agreement (SLA)                    |
| configuration       | IP SLA configuration                             |
| <i>entry-num</i>    | (Optional) Entry Number                          |
| dynamic             | (Optional) Entries programmed by clients         |
| <i>__readonly__</i> | (Optional)                                       |
| TABLE_configuration | (Optional) show ip sla configuration information |
| <i>index</i>        | (Optional)                                       |
| <i>owner</i>        | (Optional)                                       |
| <i>tag</i>          | (Optional)                                       |
| <i>timeout</i>      | (Optional)                                       |
| <i>oper-type</i>    | (Optional)                                       |
| <i>dest-ip</i>      | (Optional)                                       |
| <i>source-int</i>   | (Optional)                                       |
| <i>source-ip</i>    | (Optional)                                       |
| <i>dest-port</i>    | (Optional)                                       |
| <i>source-port</i>  | (Optional)                                       |

|                              |            |
|------------------------------|------------|
| <i>dns-source-port</i>       | (Optional) |
| <i>traffic-class</i>         | (Optional) |
| <i>tos</i>                   | (Optional) |
| <i>dns-name-server</i>       | (Optional) |
| <i>flow-label</i>            | (Optional) |
| <i>profile-id</i>            | (Optional) |
| <i>switch-id</i>             | (Optional) |
| <i>interface</i>             | (Optional) |
| <i>packet-size</i>           | (Optional) |
| <i>packet-interval</i>       | (Optional) |
| <i>num-packets</i>           | (Optional) |
| <i>codec-type</i>            | (Optional) |
| <i>codec-num-packets</i>     | (Optional) |
| <i>codec-packet-size</i>     | (Optional) |
| <i>codec-packet-interval</i> | (Optional) |
| <i>codec-adv-factor</i>      | (Optional) |
| <i>verify-data</i>           | (Optional) |
| <i>data-pattern</i>          | (Optional) |
| <i>precision</i>             | (Optional) |
| <i>packet-priority</i>       | (Optional) |
| <i>ntp-sync-tolerance</i>    | (Optional) |
| <i>ntp-sync-toctype</i>      | (Optional) |
| <i>vrf-name</i>              | (Optional) |
| <i>control-enabled</i>       | (Optional) |
| <i>http-oper</i>             | (Optional) |
| <i>http-version</i>          | (Optional) |
| <i>url</i>                   | (Optional) |
| <i>proxy</i>                 | (Optional) |
| <i>raw-strings</i>           | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>cache-control</i>          | (Optional) |
| <i>http-vrf-name</i>          | (Optional) |
| <i>http-owner</i>             | (Optional) |
| <i>http-tag</i>               | (Optional) |
| <i>http-timeout</i>           | (Optional) |
| <i>frequency</i>              | (Optional) |
| <i>frequency-in-ms</i>        | (Optional) |
| <i>secondary-freq-timeout</i> | (Optional) |
| <i>secondary-freq-loss</i>    | (Optional) |
| <i>next-start-time</i>        | (Optional) |
| <i>group-scheduled</i>        | (Optional) |
| <i>randomly-scheduled</i>     | (Optional) |
| <i>low-frequency</i>          | (Optional) |
| <i>high-frequency</i>         | (Optional) |
| <i>life</i>                   | (Optional) |
| <i>ageout</i>                 | (Optional) |
| <i>recurring</i>              | (Optional) |
| <i>status-of-entry</i>        | (Optional) |
| <i>threshold</i>              | (Optional) |
| <i>hours</i>                  | (Optional) |
| <i>buckets</i>                | (Optional) |
| <i>interval</i>               | (Optional) |
| <i>einterval</i>              | (Optional) |
| <i>ebuckets</i>               | (Optional) |
| <i>lives</i>                  | (Optional) |
| <i>hsbuckets</i>              | (Optional) |
| <i>filter</i>                 | (Optional) |

**Command Mode**

- /exec

## show ip sla enhanced-history collection-statistics

```
show ip sla enhanced-history collection-statistics [ <operation-number> [ interval <interval-in-secs> ] ] [
__readonly__ [ { TABLE_generic [ <entry-num> ] [ <aggregate-interval> ] [ { TABLE_bkt [ <bkt-index> ]
[ <agg-sti> ] [ <tgt-addr> ] [ <oper-type> ] [ <nofod> ] [ <nofot> ] [ <nofob> ] [ <nofonc> ] [ <nofoie> ] [
<nofose> ] [ <nofove> ] [ <ntp-state> ] [ <icpif> ] [ <mos-score> ] [ <rtt-values> ] [ <num-rtt> ] [ <rtt-avg>
] [ <rtt-min> ] [ <rtt-max> ] [ <rtt-sum> ] [ <rtt-sum2> ] [ <num-out-sync-rtt> ] [ <plsd> ] [ <plds> ] [ <pos>
] [ <pl-mia> ] [ <pla> ] [ <int-err> ] [ <busies> ] [ <pkt-skipped> ] [ <jitter-value-precision> ] [ <min-pos-sd>
] [ <max-pos-sd> ] [ <num-pos-sd> ] [ <sum-pos-sd> ] [ <sum2-pos-sd> ] [ <min-neg-sd> ] [ <max-neg-sd>
] [ <num-neg-sd> ] [ <sum-neg-sd> ] [ <sum2-neg-sd> ] [ <min-pos-ds> ] [ <max-pos-ds> ] [ <num-pos-ds>
] [ <sum-pos-ds> ] [ <sum2-pos-ds> ] [ <min-neg-ds> ] [ <max-neg-ds> ] [ <num-neg-ds> ] [ <sum-neg-ds>
] [ <sum2-neg-ds> ] [ <jitter-avg> ] [ <jitter-sd-avg> ] [ <jitter-ds-avg> ] [ <inter-jit-out> ] [ <inter-jit-in> ]
[ <ow-precision> ] [ <num-ow> ] [ <ow-min-sd> ] [ <ow-max-sd> ] [ <ow-sum-sd> ] [ <ow-sum2-sd> ] [
<ow-min-ds> ] [ <ow-max-ds> ] [ <ow-sum-ds> ] [ <ow-sum2-ds> ] [ <avg-ow-sd> ] [ <avg-ow-ds> ] } ] [
<outstring> ] } ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      |  |
| ip                        |  |
| sla                       | Service Level Agreement (SLA)              |
| enhanced-history          | IP SLAs Enhanced History                   |
| collection-statistics     | IP SLAs Collection Statistics              |
| <i>operation-number</i>   | (Optional) Entry Number                    |
| interval                  | (Optional) Aggregation Interval            |
| <i>interval-in-secs</i>   | (Optional) Interval in seconds             |
| <i>__readonly__</i>       | (Optional)                                 |
| TABLE_generic             | (Optional) Show History Information        |
| <i>entry-num</i>          | (Optional)                                 |
| <i>aggregate-interval</i> | (Optional)                                 |
| TABLE_bkt                 | (Optional) Show bucket History Information |
| <i>bkt-index</i>          | (Optional)                                 |
| <i>agg-sti</i>            | (Optional)                                 |
| <i>tgt-addr</i>           | (Optional)                                 |
| <i>oper-type</i>          | (Optional)                                 |
| <i>nofod</i>              | (Optional)                                 |



|                               |            |
|-------------------------------|------------|
| <i>nofot</i>                  | (Optional) |
| <i>nofob</i>                  | (Optional) |
| <i>nofonc</i>                 | (Optional) |
| <i>nofoie</i>                 | (Optional) |
| <i>nofose</i>                 | (Optional) |
| <i>nofove</i>                 | (Optional) |
| <i>ntp-state</i>              | (Optional) |
| <i>icpif</i>                  | (Optional) |
| <i>mos-score</i>              | (Optional) |
| <i>rtt-values</i>             | (Optional) |
| <i>num-rtt</i>                | (Optional) |
| <i>rtt-avg</i>                | (Optional) |
| <i>rtt-min</i>                | (Optional) |
| <i>rtt-max</i>                | (Optional) |
| <i>rtt-sum</i>                | (Optional) |
| <i>rtt-sum2</i>               | (Optional) |
| <i>num-out-sync-rtt</i>       | (Optional) |
| <i>plsd</i>                   | (Optional) |
| <i>plds</i>                   | (Optional) |
| <i>pos</i>                    | (Optional) |
| <i>pl-mia</i>                 | (Optional) |
| <i>pla</i>                    | (Optional) |
| <i>int-err</i>                | (Optional) |
| <i>busies</i>                 | (Optional) |
| <i>pkt-skipped</i>            | (Optional) |
| <i>jitter-value-precision</i> | (Optional) |
| <i>min-pos-sd</i>             | (Optional) |
| <i>max-pos-sd</i>             | (Optional) |
| <i>num-pos-sd</i>             | (Optional) |

|                      |            |
|----------------------|------------|
| <i>sum-pos-sd</i>    | (Optional) |
| <i>sum2-pos-sd</i>   | (Optional) |
| <i>min-neg-sd</i>    | (Optional) |
| <i>max-neg-sd</i>    | (Optional) |
| <i>num-neg-sd</i>    | (Optional) |
| <i>sum-neg-sd</i>    | (Optional) |
| <i>sum2-neg-sd</i>   | (Optional) |
| <i>min-pos-ds</i>    | (Optional) |
| <i>max-pos-ds</i>    | (Optional) |
| <i>num-pos-ds</i>    | (Optional) |
| <i>sum-pos-ds</i>    | (Optional) |
| <i>sum2-pos-ds</i>   | (Optional) |
| <i>min-neg-ds</i>    | (Optional) |
| <i>max-neg-ds</i>    | (Optional) |
| <i>num-neg-ds</i>    | (Optional) |
| <i>sum-neg-ds</i>    | (Optional) |
| <i>sum2-neg-ds</i>   | (Optional) |
| <i>jitter-avg</i>    | (Optional) |
| <i>jitter-sd-avg</i> | (Optional) |
| <i>jitter-ds-avg</i> | (Optional) |
| <i>inter-jit-out</i> | (Optional) |
| <i>inter-jit-in</i>  | (Optional) |
| <i>ow-precision</i>  | (Optional) |
| <i>num-ow</i>        | (Optional) |
| <i>ow-min-sd</i>     | (Optional) |
| <i>ow-max-sd</i>     | (Optional) |
| <i>ow-sum-sd</i>     | (Optional) |
| <i>ow-sum2-sd</i>    | (Optional) |
| <i>ow-min-ds</i>     | (Optional) |

|                   |            |
|-------------------|------------|
| <i>ow-max-ds</i>  | (Optional) |
| <i>ow-sum-ds</i>  | (Optional) |
| <i>ow-sum2-ds</i> | (Optional) |
| <i>avg-ow-sd</i>  | (Optional) |
| <i>avg-ow-ds</i>  | (Optional) |
| <i>oustring</i>   | (Optional) |

**Command Mode**

- /exec

## show ip sla enhanced-history distribution-statistics

```
show ip sla enhanced-history distribution-statistics [ <operation-number> [ interval <interval-in-secs> ] ] [
__readonly__ [ <hdr> ] [ { TABLE_generic [ <col1> ] [ <col2> ] [ <col3> ] } ] ]
```

### Syntax Description

|                         |                                     |
|-------------------------|-------------------------------------|
| show                    |                                     |
| ip                      |                                     |
| sla                     | Service Level Agreement (SLA)       |
| enhanced-history        | IP SLAs Enhanced History            |
| distribution-statistics | IP SLAs Distribution Statistics     |
| <i>operation-number</i> | (Optional) Entry Number             |
| interval                | (Optional) Aggregation Interval     |
| <i>interval-in-secs</i> | (Optional) Interval in seconds      |
| <i>__readonly__</i>     | (Optional)                          |
| <i>hdr</i>              | (Optional)                          |
| TABLE_generic           | (Optional) Show History Information |
| <i>col1</i>             | (Optional)                          |
| <i>col2</i>             | (Optional)                          |
| <i>col3</i>             | (Optional)                          |

### Command Mode

- /exec

# show ip sla group schedule

```
show ip sla group schedule [ <group-operation-number> ] [ __readonly__ [ <entry-number> ] [ <probe-list>
] [ <num-probes> ] [ <sched-period> ] [ <mode> ] [ <low-freq> ] [ <high-freq> ] [ <freq> ] [ <snmp-status>
] [ <next-start-time> ] [ <life> ] [ <ageout> ] ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          |  |
| ip                            |  |
| sla                           | Service Level Agreement (SLA)          |
| group                         | IP SLAs Group Scheduling/Configuration |
| schedule                      | Group Scheduling                       |
| <i>group-operation-number</i> | (Optional) Group Schedule Entry Number |
| <i>__readonly__</i>           | (Optional)                             |
| <i>entry-number</i>           | (Optional)                             |
| <i>probe-list</i>             | (Optional)                             |
| <i>num-probes</i>             | (Optional)                             |
| <i>sched-period</i>           | (Optional)                             |
| <i>mode</i>                   | (Optional)                             |
| <i>low-freq</i>               | (Optional)                             |
| <i>high-freq</i>              | (Optional)                             |
| <i>freq</i>                   | (Optional)                             |
| <i>snmp-status</i>            | (Optional)                             |
| <i>next-start-time</i>        | (Optional)                             |
| <i>life</i>                   | (Optional)                             |
| <i>ageout</i>                 | (Optional)                             |

## Command Mode

- /exec

# show ip sla history

```
show ip sla history [ <operation-number> ] [ tabular | full | interval-statistics ] [ __readonly__ [ <outstring> ] ] [ { TABLE_generic [ <index> ] [ <life-index> ] [ <bucket-index> ] [ <col1> ] [ <addr> ] [ <dest-id> ] [ <nsr> ] [ <st> ] [ <latest-rtt> ] [ <latest-ret-code> ] [ <col2> } } ] [ <error> ] ]
```

## Syntax Description

|                         |                                       |
|-------------------------|---------------------------------------|
| show                    |                                       |
| ip                      |                                       |
| sla                     | Service Level Agreement (SLA)         |
| history                 | IP SLAs History                       |
| <i>operation-number</i> | (Optional) Entry Number               |
| tabular                 | (Optional) Compact Output             |
| full                    | (Optional) Listed Output              |
| interval-statistics     | (Optional) Interval statistics output |
| <i>__readonly__</i>     | (Optional)                            |
| <i>outstring</i>        | (Optional)                            |
| TABLE_generic           | (Optional) Show History Information   |
| <i>index</i>            | (Optional)                            |
| <i>life-index</i>       | (Optional)                            |
| <i>bucket-index</i>     | (Optional)                            |
| <i>col1</i>             | (Optional)                            |
| <i>addr</i>             | (Optional)                            |
| <i>dest-id</i>          | (Optional)                            |
| <i>nsr</i>              | (Optional)                            |
| <i>st</i>               | (Optional)                            |
| <i>latest-rtt</i>       | (Optional)                            |
| <i>latest-ret-code</i>  | (Optional)                            |
| <i>col2</i>             | (Optional)                            |
| <i>error</i>            | (Optional)                            |

## Command Mode

- /exec

## show ip sla reaction-configuration

```
show ip sla reaction-configuration [ <entry-num> ] [ __readonly__ { TABLE_reaction [ <entry-number> ] [
<index> ] [ <reaction> ] [ <threshold-type> ] [ <rising-value> ] [ <falling-value> ] [ <threshold-countX> ] [
<threshold-countY> ] [ <action-type> ] [ <unconfigured> ] } ]
```

### Syntax Description

|                         |                                |
|-------------------------|--------------------------------|
| show                    |                                |
| ip                      |                                |
| sla                     | Service Level Agreement (SLA)  |
| reaction-configuration  | IP SLAs Reaction Configuration |
| <i>entry-num</i>        | (Optional) Entry Number        |
| <i>__readonly__</i>     | (Optional)                     |
| TABLE_reaction          | (Optional)                     |
| <i>entry-number</i>     | (Optional)                     |
| <i>index</i>            | (Optional)                     |
| <i>reaction</i>         | (Optional)                     |
| <i>threshold-type</i>   | (Optional)                     |
| <i>rising-value</i>     | (Optional)                     |
| <i>falling-value</i>    | (Optional)                     |
| <i>threshold-countX</i> | (Optional)                     |
| <i>threshold-countY</i> | (Optional)                     |
| <i>action-type</i>      | (Optional)                     |
| <i>unconfigured</i>     | (Optional)                     |

### Command Mode

- /exec



# show ip sla reaction-trigger

```
show ip sla reaction-trigger [ <entry-num> ] [ __readonly__ { TABLE_trigger [ <entry-number> ] [ <index> ] [ <target-entry> ] [ <snmp-status> ] [ <operational-state> ] [ <unconfigured> ] } ]
```

## Syntax Description

|                          |                               |
|--------------------------|-------------------------------|
| show                     |                               |
| ip                       |                               |
| sla                      | Service Level Agreement (SLA) |
| reaction-trigger         | IP SLAs Reaction Trigger      |
| <i>entry-num</i>         | (Optional) Entry Number       |
| <i>__readonly__</i>      | (Optional)                    |
| <i>TABLE_trigger</i>     | (Optional)                    |
| <i>entry-number</i>      | (Optional)                    |
| <i>index</i>             | (Optional)                    |
| <i>target-entry</i>      | (Optional)                    |
| <i>snmp-status</i>       | (Optional)                    |
| <i>operational-state</i> | (Optional)                    |
| <i>unconfigured</i>      | (Optional)                    |

## Command Mode

- /exec

## show ip sla responder

```
show ip sla responder [ __readonly__ <rttMonApplResponder> <gen-enabled> [ <ctrl-msg-count> ] [ <errors>
] [ <print-recent-hdr> ] [ { TABLE_recent [ <recent-addr> ] [ <recent-time> ] } ] [ <print-recent-err-hdr> ] [
{ TABLE_recent_error [ <recent-error> ] } ] <perm-enabled> [ { TABLE_permanent_udp [ <print-udp-hdr>
] [ <address> ] [ <port> ] } ] [ { TABLE_permanent_tcp [ <print-tcp-hdr> ] [ <address> ] [ <port> ] } ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        |  |
| ip                          |  |
| sla                         | Service Level Agreement (SLA)                          |
| responder                   | IP SLAs Responder Information                          |
| <i>__readonly__</i>         | (Optional)   |
| <i>rttMonApplResponder</i>  | (Optional) rttMonApplResponder                         |
| <i>gen-enabled</i>          | (Optional)   |
| <i>ctrl-msg-count</i>       | (Optional)   |
| <i>errors</i>               | (Optional)   |
| <i>print-recent-hdr</i>     | (Optional)   |
| TABLE_recent                | (Optional) Show recent control message information     |
| <i>recent-addr</i>          | (Optional)   |
| <i>recent-time</i>          | (Optional)   |
| <i>print-recent-err-hdr</i> | (Optional)   |
| TABLE_recent_error          | (Optional) Show recent control error information       |
| <i>recent-error</i>         | (Optional)   |
| <i>perm-enabled</i>         | (Optional)   |
| TABLE_permanent_udp         | (Optional) Show UDP permanent port/address information |
| <i>print-udp-hdr</i>        | (Optional)   |
| <i>address</i>              | (Optional)   |
| <i>port</i>                 | (Optional)   |
| TABLE_permanent_tcp         | (Optional) Show TCP permanent port/address information |
| <i>print-tcp-hdr</i>        | (Optional)   |

|                |            |
|----------------|------------|
| <i>address</i> | (Optional) |
| <i>port</i>    | (Optional) |

**Command Mode**

- /exec



|                           |  |
|---------------------------|--|
| <i>top</i>                | (Optional)   |
| TABLE_detail              | (Optional) Show ip sla statistics detail information |
| <i>sti</i>                | (Optional)   |
| <i>operation-type</i>     | (Optional)   |
| <i>MINICPIF</i>           | (Optional)   |
| <i>MAXICPIF</i>           | (Optional)   |
| <i>MINMOS</i>             | (Optional)   |
| <i>MAXMOS</i>             | (Optional)   |
| <i>update-count</i>       | (Optional)   |
| <i>micro-accuracy</i>     | (Optional)   |
| <i>nano-accuracy</i>      | (Optional)   |
| <i>latest-RTT</i>         | (Optional)   |
| <i>latest-return-code</i> | (Optional)   |
| <i>latest-start-time</i>  | (Optional)   |
| <i>http-dns-rtt</i>       | (Optional)   |
| <i>http-tcp-rtt</i>       | (Optional)   |
| <i>http-ttfb</i>          | (Optional)   |
| <i>http-rtt</i>           | (Optional)   |
| <i>http-status</i>        | (Optional)   |
| <i>http-recvlen</i>       | (Optional)   |
| <i>http-bodysize</i>      | (Optional)   |
| <i>http-dns-timeout</i>   | (Optional)   |
| <i>http-tcp-timeout</i>   | (Optional)   |
| <i>http-t-timeout</i>     | (Optional)   |
| <i>http-dns-error</i>     | (Optional)   |
| <i>http-tcp-error</i>     | (Optional)   |
| <i>http-t-error</i>       | (Optional)   |
| <i>ntp-sync-state</i>     | (Optional)   |
| <i>rtt-count</i>          | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>rtt-min</i>            | (Optional) |
| <i>rtt-avg</i>            | (Optional) |
| <i>rtt-max</i>            | (Optional) |
| <i>lat-ow-samples</i>     | (Optional) |
| <i>sd-lat-ow-min</i>      | (Optional) |
| <i>sd-lat-ow-avg</i>      | (Optional) |
| <i>sd-lat-ow-max</i>      | (Optional) |
| <i>ds-lat-ow-min</i>      | (Optional) |
| <i>ds-lat-ow-avg</i>      | (Optional) |
| <i>ds-lat-ow-max</i>      | (Optional) |
| <i>sd-lat-sum</i>         | (Optional) |
| <i>sd-lat-sum2</i>        | (Optional) |
| <i>ds-lat-sum</i>         | (Optional) |
| <i>ds-lat-sum2</i>        | (Optional) |
| <i>sd-jitter-count</i>    | (Optional) |
| <i>ds-jitter-count</i>    | (Optional) |
| <i>sd-jitter-min</i>      | (Optional) |
| <i>sd-jitter-avg</i>      | (Optional) |
| <i>sd-jitter-max</i>      | (Optional) |
| <i>ds-jitter-min</i>      | (Optional) |
| <i>ds-jitter-avg</i>      | (Optional) |
| <i>ds-jitter-max</i>      | (Optional) |
| <i>sd-pos-jitter-min</i>  | (Optional) |
| <i>sd-pos-jitter-avg</i>  | (Optional) |
| <i>sd-pos-jitter-max</i>  | (Optional) |
| <i>sd-pos-jitter-num</i>  | (Optional) |
| <i>sd-pos-jitter-sum</i>  | (Optional) |
| <i>sd-pos-jitter-sum2</i> | (Optional) |
| <i>sd-neg-jitter-min</i>  | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>sd-neg-jitter-avg</i>  | (Optional) |
| <i>sd-neg-jitter-max</i>  | (Optional) |
| <i>sd-neg-jitter-num</i>  | (Optional) |
| <i>sd-neg-jitter-sum</i>  | (Optional) |
| <i>sd-neg-jitter-sum2</i> | (Optional) |
| <i>ds-pos-jitter-min</i>  | (Optional) |
| <i>ds-pos-jitter-avg</i>  | (Optional) |
| <i>ds-pos-jitter-max</i>  | (Optional) |
| <i>ds-pos-jitter-num</i>  | (Optional) |
| <i>ds-pos-jitter-sum</i>  | (Optional) |
| <i>ds-pos-jitter-sum2</i> | (Optional) |
| <i>ds-neg-jitter-min</i>  | (Optional) |
| <i>ds-neg-jitter-avg</i>  | (Optional) |
| <i>ds-neg-jitter-max</i>  | (Optional) |
| <i>ds-neg-jitter-num</i>  | (Optional) |
| <i>ds-neg-jitter-sum</i>  | (Optional) |
| <i>ds-neg-jitter-sum2</i> | (Optional) |
| <i>pkt-unprocessed</i>    | (Optional) |
| <i>pkt-loss</i>           | (Optional) |
| <i>pkt-loss-per</i>       | (Optional) |
| <i>pkt-loss-min</i>       | (Optional) |
| <i>pkt-loss-max</i>       | (Optional) |
| <i>pkt-loss-inter-min</i> | (Optional) |
| <i>pkt-loss-inter-max</i> | (Optional) |
| <i>inter-jitter-out</i>   | (Optional) |
| <i>inter-jitter-in</i>    | (Optional) |
| <i>jitter-avg</i>         | (Optional) |
| <i>pkt-loss-sd</i>        | (Optional) |
| <i>pkt-loss-sd-per</i>    | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>pkt-loss-sd-min</i>       | (Optional) |
| <i>pkt-loss-sd-max</i>       | (Optional) |
| <i>pkt-loss-sd-inter-min</i> | (Optional) |
| <i>pkt-loss-sd-inter-max</i> | (Optional) |
| <i>pkt-loss-ds</i>           | (Optional) |
| <i>pkt-loss-ds-per</i>       | (Optional) |
| <i>pkt-loss-ds-min</i>       | (Optional) |
| <i>pkt-loss-ds-max</i>       | (Optional) |
| <i>pkt-loss-ds-inter-min</i> | (Optional) |
| <i>pkt-loss-ds-inter-max</i> | (Optional) |
| <i>pkt-oos</i>               | (Optional) |
| <i>pkt-oos-sd</i>            | (Optional) |
| <i>pkt-oos-ds</i>            | (Optional) |
| <i>pkt-oos-both</i>          | (Optional) |
| <i>pkt-mia</i>               | (Optional) |
| <i>pkt-late</i>              | (Optional) |
| <i>pkt-skipped</i>           | (Optional) |
| <i>voice-icpif</i>           | (Optional) |
| <i>voice-mos</i>             | (Optional) |
| <i>dnobs</i>                 | (Optional) |
| <i>dmam</i>                  | (Optional) |
| <i>dtoo</i>                  | (Optional) |
| <i>dmin</i>                  | (Optional) |
| <i>dmax</i>                  | (Optional) |
| <i>pnobs</i>                 | (Optional) |
| <i>pmam</i>                  | (Optional) |
| <i>ptoo</i>                  | (Optional) |
| <i>pmin</i>                  | (Optional) |
| <i>pmax</i>                  | (Optional) |



|                        |                                   |
|------------------------|-----------------------------------|
| <i>nnobs</i>           | (Optional)                        |
| <i>nmam</i>            | (Optional)                        |
| <i>ntoo</i>            | (Optional)                        |
| <i>nmin</i>            | (Optional)                        |
| <i>nmax</i>            | (Optional)                        |
| <i>outstring1</i>      | (Optional)                        |
| <i>outstring2</i>      | (Optional)                        |
| <i>nos</i>             | (Optional)                        |
| <i>nof</i>             | (Optional)                        |
| <i>noot</i>            | (Optional)                        |
| <i>nofo1</i>           | (Optional)                        |
| <i>nofo2</i>           | (Optional)                        |
| TABLE_br               | (Optional) Bin range related info |
| <i>br</i>              | (Optional)                        |
| <i>avg-lat</i>         | (Optional)                        |
| <i>potc</i>            | (Optional)                        |
| <i>noc-by-lat</i>      | (Optional)                        |
| <i>sorthigh-by-low</i> | (Optional)                        |
| <i>operot</i>          | (Optional)                        |
| <i>life-left</i>       | (Optional)                        |
| <i>oper-state</i>      | (Optional)                        |
| <i>reset-time</i>      | (Optional)                        |
| <i>nob</i>             | (Optional)                        |
| <i>bbh</i>             | (Optional)                        |
| <i>bbv</i>             | (Optional)                        |

**Command Mode**

- /exec

## show ip sla twamp connection detail

```
show ip sla twamp connection detail [ __readonly__ [ { TABLE_twamp-connection-detail <Connection-Id>
<Client-Addr> <Client-Port> <Client-VRF> <Mode> <Connection-state> <Control-state>
<Number-Of-Test-requests> } ] ]
```

### Syntax Description

|                                      |                                    |
|--------------------------------------|------------------------------------|
| show                                 |                                    |
| ip                                   |                                    |
| sla                                  |                                    |
| twamp                                |                                    |
| connection                           |                                    |
| detail                               |                                    |
| <i>__readonly__</i>                  | (Optional)                         |
| <i>TABLE_twamp-connection-detail</i> | (Optional) connection related info |
| <i>Connection-Id</i>                 | (Optional)                         |
| <i>Client-Addr</i>                   | (Optional)                         |
| <i>Client-Port</i>                   | (Optional)                         |
| <i>Client-VRF</i>                    | (Optional)                         |
| <i>Mode</i>                          | (Optional)                         |
| <i>Connection-state</i>              | (Optional)                         |
| <i>Control-state</i>                 | (Optional)                         |
| <i>Number-Of-Test-requests</i>       | (Optional)                         |

### Command Mode

- /exec

# show ip sla twamp connection requests

```
show ip sla twamp connection requests [ __readonly__ [ { TABLE_twamp-connection-request <Connection-Id>
<Client-Addr> <Client-Port> <Client-VRF> } ] [ <Total-Connections> ] ]
```

## Syntax Description

|                                       |   |
|---------------------------------------|---|
| show                                  |   |
| ip                                    |   |
| sla                                   |   |
| twamp                                 |   |
| connection                            |   |
| requests                              |   |
| <i>__readonly__</i>                   | (Optional)                                  |
| <i>TABLE_twamp-connection-request</i> | (Optional) connection requests related info |
| <i>Connection-Id</i>                  | (Optional)                                  |
| <i>Client-Addr</i>                    | (Optional)                                  |
| <i>Client-Port</i>                    | (Optional)                                  |
| <i>Client-VRF</i>                     | (Optional)                                  |
| <i>Total-Connections</i>              | (Optional)                                  |

## Command Mode

- /exec

## show ip sla twamp session

```
show ip sla twamp session [ __readonly__ <twamp-resp-status> [ { TABLE_twamp-session [ <recv-addr> ]
[ <recv-port> ] [ <send-addr> ] [ <send-port> ] [ <send-vrf> ] [ <sess-id> ] [ <conn-id> ] } ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     |  |
| ip                       |  |
| sla                      | Service Level Agreement (SLA)          |
| twamp                    | IP SLAs Twamp Information              |
| session                  | Display TWAMP Sessions                 |
| <i>__readonly__</i>      | (Optional)                             |
| <i>twamp-resp-status</i> | (Optional)                             |
| TABLE_twamp-session      | (Optional) session related information |
| <i>recv-addr</i>         | (Optional)                             |
| <i>recv-port</i>         | (Optional)                             |
| <i>send-addr</i>         | (Optional)                             |
| <i>send-port</i>         | (Optional)                             |
| <i>send-vrf</i>          | (Optional)                             |
| <i>sess-id</i>           | (Optional)                             |
| <i>conn-id</i>           | (Optional)                             |

### Command Mode

- /exec

# show ip sla twamp standards

```
show ip sla twamp standards [ __readonly__ [ { TABLE_twamp-standards <twamp-standard-feature>
<twamp-standard-org> <twamp-standard> } ] ]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| show                          |   |
| ip                            |   |
| sla                           |   |
| twamp                         |   |
| standards                     |   |
| <i>__readonly__</i>           | (Optional)  |
| TABLE_twamp-standards         | (Optional) twamp standards for each supported feature |
| <i>twamp-standard-feature</i> | (Optional)  |
| <i>twamp-standard-org</i>     | (Optional)  |
| <i>twamp-standard</i>         | (Optional)  |

## Command Mode

- /exec

## show ip ssh source-interface

```
show ip ssh source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_ipsshvrf
<vrfname> <ifname> } ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information              |
| ip                    | Display IP information                       |
| ssh                   | Display SSH client information               |
| source-interface      | Display source interface information         |
| vrf                   | (Optional) Display per-VRF information       |
| <i>vrf-name</i>       | (Optional) VRF name                          |
| <i>vrf-known-name</i> | (Optional) Known VRF name                    |
| <i>__readonly__</i>   | (Optional)                                   |
| TABLE_ipsshvrf        | (Optional) source interface of ssh given vrf |
| <i>vrfname</i>        | (Optional) vrfname                           |
| <i>ifname</i>         | (Optional) ifname                            |

### Command Mode

- /exec

# show ip ssh source-interface vrf all

```
show ip ssh source-interface vrf all [ __readonly__ [ { TABLE_ipssh <vrfname> <ifname> } ] ]
```

## Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | Display IP information               |
| ssh              | Display SSH client information       |
| source-interface | Display source interface information |
| vrf              | Display per-VRF information          |
| all              | Display entries for all vrfs         |
| __readonly__     | (Optional)                           |
| TABLE_ipssh      | (Optional) source interface of ssh   |
| <i>vrfname</i>   | (Optional) vrfname                   |
| <i>ifname</i>    | (Optional) ifname                    |

## Command Mode

- /exec

## show ip static-route

```
show ip static-route [ multicast ] [ internal ] [ track-table ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ [ <count> <unres-count> ] [ TABLE_vrf_all { <cntxt_name> <cntxt_id> [ TABLE_each_vrf
{ <prefix_addr_msk> <nhop_addr_msk> <nhop_vrf_info> <nhop_intr_info> <urib_stat> [ <seg_id> ] [
<tunnel_id> <urib_encap_type> ] [ <nhop_urib_stat> ] [ <track_obj_num> <track_obj_state> ] } ] ] [
TABLE_multicast <multicast> ] [ TABLE_track-table ] [ TABLE_route <prefix> <masklen> <nhop>
<nhop-masklen> <intf> <real-nhop> <iod> <pref> <tag> <unres> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                                       |
| ip                     | Display IP information  |
| static-route           | Display configured static routes                                      |
| multicast              | (Optional) Display only multicast routes                              |
| internal               | (Optional) Display internal data structure info                       |
| track-table            | (Optional) Display track object details associated with static routes |
| vrf                    | (Optional) Display per-VRF information                                |
| all                    | (Optional) Display all VRFs   |
| <i>vrf-name</i>        | (Optional) VRF name   |
| <i>vrf-known-name</i>  | (Optional) Known VRF name   |
| <i>__readonly__</i>    | (Optional)  |
| TABLE_vrf_all          | (Optional)  |
| <i>cntxt_name</i>      | (Optional)  |
| <i>cntxt_id</i>        | (Optional)  |
| TABLE_each_vrf         | (Optional)  |
| <i>prefix_addr_msk</i> | (Optional)  |
| <i>nhop_addr_msk</i>   | (Optional)  |
| <i>nhop_vrf_info</i>   | (Optional)  |
| <i>nhop_intr_info</i>  | (Optional)  |
| <i>urib_stat</i>       | (Optional)  |
| <i>seg_id</i>          | (Optional)  |
| <i>tunnel_id</i>       | (Optional)  |



|                        |            |
|------------------------|------------|
| <i>urib_encap_type</i> | (Optional) |
| <i>nhop_urib_stat</i>  | (Optional) |
| <i>track_obj_num</i>   | (Optional) |
| <i>track_obj_state</i> | (Optional) |
| TABLE_multicast        | (Optional) |
| <i>multicast</i>       | (Optional) |
| TABLE_track-table      | (Optional) |
| TABLE_route            | (Optional) |
| <i>prefix</i>          | (Optional) |
| <i>masklen</i>         | (Optional) |
| <i>nhop</i>            | (Optional) |
| <i>nhop-masklen</i>    | (Optional) |
| <i>intf</i>            | (Optional) |
| <i>real-nhop</i>       | (Optional) |
| <i>iod</i>             | (Optional) |
| <i>pref</i>            | (Optional) |
| <i>tag</i>             | (Optional) |
| <i>unres</i>           | (Optional) |
| <i>count</i>           | (Optional) |
| <i>unres-count</i>     | (Optional) |

### Command Mode

- /exec

# show ip tcp mss

```
show ip tcp mss [ __readonly__ { <tcp-mss-value> } ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                   |
| ip                   | Configure IP features                             |
| tcp                  | Global TCP parameters                             |
| mss                  | Maximum segment size for TCP connections in bytes |
| __readonly__         | (Optional)  |
| <i>tcp-mss-value</i> | (Optional) TCP Maximum Segment Size Value         |

## Command Mode

- /exec

# show ip telnet source-interface

```
show ip telnet source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ {
TABLE_iptelnetvrf <vrfname> <ifname> } ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| ip                    | Display IP information                          |
| telnet                | Display telnet information                      |
| source-interface      | Display source interface information            |
| vrf                   | (Optional) Display per-VRF information          |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| <i>__readonly__</i>   | (Optional)                                      |
| TABLE_iptelnetvrf     | (Optional) source interface of telnet given vrf |
| <i>vrfname</i>        | (Optional) vrfname                              |
| <i>ifname</i>         | (Optional) ifname                               |

## Command Mode

- /exec

# show ip telnet source-interface vrf all

```
show ip telnet source-interface vrf all [ __readonly__ [ { TABLE_ip telnet <vrfname> <ifname> } ] ]
```

## Syntax Description

|                  |                                       |
|------------------|---------------------------------------|
| show             | Show running system information       |
| ip               | Display IP information                |
| telnet           | Display telnet information            |
| source-interface | Display source interface information  |
| vrf              | Display per-VRF information           |
| all              | Display entries for all vrfs          |
| __readonly__     | (Optional)                            |
| TABLE_ip telnet  | (Optional) source interface of telnet |
| <i>vrfname</i>   | (Optional) vrfname                    |
| <i>ifname</i>    | (Optional) ifname                     |

## Command Mode

- /exec

# show ip tftp source-interface

```
show ip tftp source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ { TABLE_iptftpvrf
<vrfname> <ifname> } ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| ip                    | Display IP information                        |
| tftp                  | Display TFTP client information               |
| source-interface      | Display source interface information          |
| vrf                   | (Optional) Display per-VRF information        |
| <i>vrf-name</i>       | (Optional) VRF name                           |
| <i>vrf-known-name</i> | (Optional) Known VRF name                     |
| <i>__readonly__</i>   | (Optional)                                    |
| TABLE_iptftpvrf       | (Optional) source interface of tftp given vrf |
| <i>vrfname</i>        | (Optional) vrfname                            |
| <i>ifname</i>         | (Optional) ifname                             |

## Command Mode

- /exec

## show ip tftp source-interface vrf all

```
show ip tftp source-interface vrf all [ __readonly__ [ { TABLE_iptftp <vrfname> <ifname> } ] ]
```

### Syntax Description

|                  |                                      |
|------------------|--------------------------------------|
| show             | Show running system information      |
| ip               | Display IP information               |
| tftp             | Display TFTP client information      |
| source-interface | Display source interface information |
| vrf              | Display per-VRF information          |
| all              | Display entries for all vrfs         |
| __readonly__     | (Optional)                           |
| TABLE_iptftp     | (Optional) source interface of tftp  |
| <i>vrfname</i>   | (Optional) vrfname                   |
| <i>ifname</i>    | (Optional) ifname                    |

### Command Mode

- /exec

## show ip traceroute source-interface

```
show ip traceroute source-interface [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ {
TABLE_iptraceroutevrf <vrfname> <ifname> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information           |
| ip                    | Display IP information                    |
| traceroute            | Display traceroute client information     |
| source-interface      | Display source interface information      |
| vrf                   | (Optional) Display per-VRF information    |
| <i>vrf-name</i>       | (Optional) VRF name                       |
| <i>vrf-known-name</i> | (Optional) Known VRF name                 |
| <i>__readonly__</i>   | (Optional)                                |
| TABLE_iptraceroutevrf | (Optional) source interface of traceroute |
| <i>vrfname</i>        | (Optional) vrfname                        |
| <i>ifname</i>         | (Optional) ifname                         |

### Command Mode

- /exec

# show ip traceroute source-interface vrf all

```
show ip traceroute source-interface vrf all [ __readonly__ [ { TABLE_iptraceroute <vrfname> <ifname> } ] ]
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information           |
| ip                 | Display IP information                    |
| traceroute         | Display traceroute client information     |
| source-interface   | Display source interface information      |
| vrf                | Display per-VRF information               |
| all                | Display entries for all vrfs              |
| __readonly__       | (Optional)                                |
| TABLE_iptraceroute | (Optional) source interface of traceroute |
| <i>vrfname</i>     | (Optional) vrfname                        |
| <i>ifname</i>      | (Optional) ifname                         |

## Command Mode

- /exec





|                                 |            |
|---------------------------------|------------|
| TABLE_ip_soft_processed_traffic | (Optional) |
| TABLE_trans_and_reception       | (Optional) |
| <i>rcvd</i>                     | (Optional) |
| <i>sent</i>                     | (Optional) |
| <i>consumed</i>                 | (Optional) |
| <i>fwd-ucast</i>                | (Optional) |
| <i>fwd-mcast</i>                | (Optional) |
| <i>fwd-label</i>                | (Optional) |
| <i>ingress-mcecfwd</i>          | (Optional) |
| TABLE_opts                      | (Optional) |
| <i>opts-end</i>                 | (Optional) |
| <i>opts-nop</i>                 | (Optional) |
| <i>opts-bsec</i>                | (Optional) |
| <i>opts-loosesrc-route</i>      | (Optional) |
| <i>opts-timestamp</i>           | (Optional) |
| <i>opts-esec</i>                | (Optional) |
| <i>opts-record-route</i>        | (Optional) |
| <i>opts-ump</i>                 | (Optional) |
| <i>opts-stid</i>                | (Optional) |
| <i>opts-strsrc-route</i>        | (Optional) |
| <i>opts-alert</i>               | (Optional) |
| <i>opts-cipso</i>               | (Optional) |
| <i>opts-other</i>               | (Optional) |
| TABLE_errors                    | (Optional) |
| <i>bad-csum</i>                 | (Optional) |
| <i>too-small</i>                | (Optional) |
| <i>bad-ver</i>                  | (Optional) |
| <i>bad-hlen</i>                 | (Optional) |
| <i>bad-len</i>                  | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>bad-dest</i>             | (Optional) |
| <i>bad-ttl</i>              | (Optional) |
| <i>cant-fwd</i>             | (Optional) |
| <i>out-drop</i>             | (Optional) |
| <i>bad-encap</i>            | (Optional) |
| <i>no-route</i>             | (Optional) |
| <i>no-proto</i>             | (Optional) |
| <i>bad-options</i>          | (Optional) |
| <i>vinci</i>                | (Optional) |
| <i>snoop</i>                | (Optional) |
| <i>svi</i>                  | (Optional) |
| <i>restart-recovery</i>     | (Optional) |
| <i>mbuf-fail</i>            | (Optional) |
| <i>bad-context</i>          | (Optional) |
| <i>rpf-drops</i>            | (Optional) |
| <i>bad-gw-mac</i>           | (Optional) |
| <i>ing-ips-option-fail</i>  | (Optional) |
| <i>nat-in-drop</i>          | (Optional) |
| <i>nat-out-drop</i>         | (Optional) |
| <i>ing-option-proc-fail</i> | (Optional) |
| <i>ing-mfrwd-fail</i>       | (Optional) |
| <i>ing-lisp-drop</i>        | (Optional) |
| <i>ing-lisp-decap-drop</i>  | (Optional) |
| <i>ing-lisp-encap-drop</i>  | (Optional) |
| <i>ing-lisp-encap</i>       | (Optional) |
| <i>ing-mfwd-copy-drop</i>   | (Optional) |
| <i>ing-ra-reass-drop</i>    | (Optional) |
| <i>ing-icmp-redirect</i>    | (Optional) |
| <i>ing-drop-ifmgr-init</i>  | (Optional) |

|                                  |            |
|----------------------------------|------------|
| <i>ing-drop-invld-filter</i>     | (Optional) |
| <i>ing-drop-invld-l2-msg</i>     | (Optional) |
| <i>ingress</i>                   | (Optional) |
| <i>egrees</i>                    | (Optional) |
| <i>directed_bdcst</i>            | (Optional) |
| TABLE_fragment                   | (Optional) |
| <i>frag</i>                      | (Optional) |
| <i>fragmented</i>                | (Optional) |
| <i>out-frag</i>                  | (Optional) |
| <i>frag-drop</i>                 | (Optional) |
| <i>cant-frag</i>                 | (Optional) |
| <i>reasm</i>                     | (Optional) |
| <i>frag-to</i>                   | (Optional) |
| TABLE_icmp_software_proc_traffic | (Optional) |
| TABLE_transmission               | (Optional) |
| <i>tx-redirect</i>               | (Optional) |
| <i>tx-unreach</i>                | (Optional) |
| <i>tx-echo-req</i>               | (Optional) |
| <i>tx-echo-reply</i>             | (Optional) |
| <i>tx-mask-req</i>               | (Optional) |
| <i>tx-mask-rep</i>               | (Optional) |
| <i>tx-info-req</i>               | (Optional) |
| <i>tx-info-reply</i>             | (Optional) |
| <i>tx-param-prob</i>             | (Optional) |
| <i>tx-source-quench</i>          | (Optional) |
| <i>tx-tstamp-req</i>             | (Optional) |
| <i>tx-tstamp-reply</i>           | (Optional) |
| <i>tx-time-exceeded</i>          | (Optional) |
| <i>tx-router-solicit</i>         | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>tx-router-advert</i>       | (Optional) |
| <i>out-drop-badlen</i>        | (Optional) |
| <i>encap-fail</i>             | (Optional) |
| <i>xmit-fail</i>              | (Optional) |
| <i>icmp-originate</i>         | (Optional) |
| <i>redirect-originate-req</i> | (Optional) |
| <i>originate-deny</i>         | (Optional) |
| <i>short-ip</i>               | (Optional) |
| <i>old-icmp</i>               | (Optional) |
| <i>error-drop</i>             | (Optional) |
| TABLE_reception               | (Optional) |
| <i>rx-redir</i>               | (Optional) |
| <i>rx-unreach</i>             | (Optional) |
| <i>rx-echo-req</i>            | (Optional) |
| <i>rx-echo-reply</i>          | (Optional) |
| <i>rx-mask-req</i>            | (Optional) |
| <i>rx-mask-rep</i>            | (Optional) |
| <i>rx-info-req</i>            | (Optional) |
| <i>rx-info-reply</i>          | (Optional) |
| <i>rx-param-prob</i>          | (Optional) |
| <i>rx-source-quench</i>       | (Optional) |
| <i>rx-tstamp-req</i>          | (Optional) |
| <i>rx-tstamp-reply</i>        | (Optional) |
| <i>rx-time-exceeded</i>       | (Optional) |
| <i>rx-router-solicit</i>      | (Optional) |
| <i>rx-router-advert</i>       | (Optional) |
| <i>rx-format-errors</i>       | (Optional) |
| <i>rx-csum-errors</i>         | (Optional) |
| <i>lisp-processed</i>         | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>lisp-noclient</i>               | (Optional) |
| <i>lisp-consumed</i>               | (Optional) |
| <i>icmp-replies</i>                | (Optional) |
| <i>icmp-reply-drop</i>             | (Optional) |
| <i>icmp-inactive-addr</i>          | (Optional) |
| TABLE_stat_last_never              | (Optional) |
| <i>stat-last-never</i>             | (Optional) |
| TABLE_rfc4293_ip_soft_proc_traffic | (Optional) |
| TABLE_rfc_reception                | (Optional) |
| <i>inrcv</i>                       | (Optional) |
| <i>inoctet</i>                     | (Optional) |
| <i>inhdrrr</i>                     | (Optional) |
| <i>innoroutes</i>                  | (Optional) |
| <i>inaddrerr</i>                   | (Optional) |
| <i>innoproto</i>                   | (Optional) |
| <i>intruncated</i>                 | (Optional) |
| <i>inforw</i>                      | (Optional) |
| <i>reasmreqds</i>                  | (Optional) |
| <i>reasmoks</i>                    | (Optional) |
| <i>reasmfails</i>                  | (Optional) |
| <i>indiscards</i>                  | (Optional) |
| <i>indelivers</i>                  | (Optional) |
| <i>inmcastpkts</i>                 | (Optional) |
| <i>inmcastbytes</i>                | (Optional) |
| <i>inbaspkts</i>                   | (Optional) |
| TABLE_rfc_transmission             | (Optional) |
| <i>out-req</i>                     | (Optional) |
| <i>out-no-route</i>                | (Optional) |
| <i>out-forwdgrams</i>              | (Optional) |

|                        |            |
|------------------------|------------|
| <i>out-discards</i>    | (Optional) |
| <i>out-frag-req</i>    | (Optional) |
| <i>out-frag-oks</i>    | (Optional) |
| <i>out-frag-fails</i>  | (Optional) |
| <i>out-frag-create</i> | (Optional) |
| <i>out-transmits</i>   | (Optional) |
| <i>byte-sent</i>       | (Optional) |
| <i>out-mcast-pkts</i>  | (Optional) |
| <i>out-mcast-bytes</i> | (Optional) |
| <i>out-bcast-pkts</i>  | (Optional) |
| <i>out-bcast-bytes</i> | (Optional) |

**Command Mode**

- /exec

# show ip traffic pps

```
show ip traffic pps [ __readonly__ [ { TABLE_ip_pps [ <ip_pps_type> ] <ip_pps_threshold_size>
<ip_pps_threshold_log_interval> } ] ]
```

## Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information                         |
| ip                                   | Display IP information                                  |
| traffic                              | Display IP software processed traffic statistics        |
| pps                                  | Display packets per second threshold config information |
| <i>__readonly__</i>                  | (Optional)  |
| <i>TABLE_ip_pps</i>                  | (Optional) Show ip traffic pps type                     |
| <i>ip_pps_type</i>                   | (Optional) IP PPS type                                  |
| <i>ip_pps_threshold_size</i>         | (Optional) Show IP PPS limit                            |
| <i>ip_pps_threshold_log_interval</i> | (Optional) Show IP PPS log interval                     |

## Command Mode

- /exec



# show ip udp relay

```
show ip udp relay [ __readonly__ <udp_relay_service_enable> <udp_relay_hdr> [ { TABLE_default_ports
<port_name> <udp_relay_port_enable> } ] <udp_ports_hdr> [ TABLE_ports <udp_port_num> ]
<udp_intf_hdr> [ TABLE_intf <udp_intf_idx> <udp_sub_bcast> <udp_objgrp> ] ]
```

## Syntax Description

|                                 |                                    |
|---------------------------------|------------------------------------|
| show                            | Show running system information    |
| ip                              | Show the IP features of the system |
| udp                             | Show items in UDP relay            |
| relay                           | UDP relay                          |
| <i>__readonly__</i>             | (Optional) Read only               |
| <i>udp_relay_service_enable</i> | (Optional)                         |
| <i>udp_relay_hdr</i>            | (Optional)                         |
| TABLE_default_ports             | (Optional)                         |
| <i>port_name</i>                | (Optional) UDP Port Name           |
| <i>udp_relay_port_enable</i>    | (Optional)                         |
| <i>udp_ports_hdr</i>            | (Optional)                         |
| TABLE_ports                     | (Optional)                         |
| <i>udp_port_num</i>             | (Optional)                         |
| <i>udp_intf_hdr</i>             | (Optional)                         |
| TABLE_intf                      | (Optional)                         |
| <i>udp_intf_idx</i>             | (Optional) UDP relay interfaces    |
| <i>udp_sub_bcast</i>            | (Optional)                         |
| <i>udp_objgrp</i>               | (Optional) Object-group            |

## Command Mode

- /exec

# show ip udp relay interface

```
show ip udp relay interface [ <intf_range> ] [ __readonly__ <udp_intf_hdr> [ TABLE_intf <udp_intf_idx>
<udp_sub_bcast> <udp_objgrp> ] ]
```

## Syntax Description

|                      |                                    |
|----------------------|------------------------------------|
| show                 | Show running system information    |
| ip                   | Show the IP features of the system |
| udp                  | Show items in UDP relay            |
| relay                | UDP relay                          |
| interface            | Interface ID                       |
| <i>intf_range</i>    | (Optional) interface               |
| <i>__readonly__</i>  | (Optional) Read only               |
| <i>udp_intf_hdr</i>  | (Optional)                         |
| TABLE_intf           | (Optional)                         |
| <i>udp_intf_idx</i>  | (Optional) UDP relay interfaces    |
| <i>udp_sub_bcast</i> | (Optional)                         |
| <i>udp_objgrp</i>    | (Optional) Object-group            |

## Command Mode

- /exec

## show ip udp relay object-group

```
show ip udp relay object-group [ <obj-grp-name> ] [ __readonly__ [ TABLE_objgrp_list [ <udp_objgrp> ]
[ TABLE_objgrp [ <host_addr> ] [ <net_addr> <net_mask> ] [ <prefix_addr> <prefix_len> ] ] <udp_intf_hdr>
[ TABLE_intf <udp_intf_idx> ] ] ]
```

### Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| ip                  | Show the IP features of the system |
| udp                 | Show items in UDP relay            |
| relay               | UDP relay                          |
| object-group        | Object-group                       |
| <i>obj-grp-name</i> | (Optional) object-group name       |
| <i>__readonly__</i> | (Optional) Read only               |
| TABLE_objgrp_list   | (Optional)                         |
| <i>udp_objgrp</i>   | (Optional) Object-group            |
| TABLE_objgrp        | (Optional)                         |
| <i>host_addr</i>    | (Optional) Host Address            |
| <i>net_addr</i>     | (Optional) Network Address         |
| <i>net_mask</i>     | (Optional) Network Mask            |
| <i>prefix_addr</i>  | (Optional) Network Address         |
| <i>prefix_len</i>   | (Optional) IP Prefix Length        |
| <i>udp_intf_hdr</i> | (Optional)                         |
| TABLE_intf          | (Optional)                         |
| <i>udp_intf_idx</i> | (Optional) UDP relay interfaces    |

### Command Mode

- /exec

## show ip verify source

```
show ip verify source [ interface <intf6> ] [ __readonly__ [ <verify_ipsg_exclude_vlans> ] [
<verify_intf_ipsg_val> | <verify_ipsg_enable_intf> ] [ TABLE_verified_intf<verified_ipsg_enable_intf>
] [ <verify_hdr> ] [ { TABLE_verify_entry <verify_intf> [ <verify_intf_ipsg_val> ] [ {
TABLE_verify_entry_intf<verify_ipsg_enable_intf> } ] <verify_filter_mode> [ <verify_ip_addr> ] [
<verify_mac_addr> ] [ <verify_vlan> ] } ] ] ]
```

### Syntax Description

|                                  |   |
|----------------------------------|---|
| show                             | Show running system information                       |
| ip                               | Show the IP features of the system                    |
| verify                           | Verify IPSG information                               |
| source                           | IPSG source   |
| interface                        | (Optional) Interface                                  |
| <i>intf6</i>                     | (Optional) interface                                  |
| <i>__readonly__</i>              | (Optional) Read only                                  |
| <i>verify_ipsg_exclude_vlans</i> | (Optional)  |
| <i>verify_hdr</i>                | (Optional) IP source guard operational entries        |
| <i>verify_intf_ipsg_val</i>      | (Optional) IP source guard value (enabled or disable) |
| <i>verify_ipsg_enable_intf</i>   | (Optional) IP source guard enabled interfaces names   |
| TABLE_verified_intf              | (Optional)  |
| <i>verified_ipsg_enable_intf</i> | (Optional)  |
| TABLE_verify_entry               | (Optional)  |
| <i>verify_filter_mode</i>        | (Optional)  |
| <i>verify_intf</i>               | (Optional)  |
| TABLE_verify_entry_intf          | (Optional)  |
| <i>verify_ip_addr</i>            | (Optional) verify ip address                          |
| <i>verify_mac_addr</i>           | (Optional) verify mac address                         |
| <i>verify_vlan</i>               | (Optional) vlan for interface                         |

### Command Mode

- /exec

## show ipt details

```
show ipt details [ __readonly__ <probe_marker> [ { TABLE_source_monitor <source_monitor> [
<source_monitor_properties> ] } ] [ { TABLE_sink_monitor <sink_monitor> [ <sink_monitor_properties>
] } ] [ { TABLE_source_record <source_record> [ <source_record_properties> + ] } ] [ { TABLE_sink_record
<sink_record> [ <sink_record_properties> + ] } ] [ { TABLE_sink_collector <sink_collector> [
<collector_properties> + ] } ] ] ]
```

### Syntax Description

|                                  |  |
|----------------------------------|--|
| ipt                              | Display IPT information                        |
| details                          | Show IPT details                               |
| <i>__readonly__</i>              | (Optional)                                     |
| <i>probe_marker</i>              | (Optional) Probe Marker applied                |
| TABLE_source_monitor             | (Optional) Source Monitor Table                |
| <i>source_monitor</i>            | (Optional) Source Monitor Information          |
| <i>source_monitor_properties</i> | (Optional) Attributes under the source monitor |
| TABLE_sink_monitor               | (Optional) Sink Monitor Table                  |
| <i>sink_monitor</i>              | (Optional) Sink Monitor Information            |
| <i>sink_monitor_properties</i>   | (Optional) Attributes under the source monitor |
| TABLE_source_record              | (Optional) Source Monitor Table                |
| <i>source_record</i>             | (Optional) Source Monitor Information          |
| <i>source_record_properties</i>  | (Optional) Attributes under the source record  |
| TABLE_sink_record                | (Optional) Sink Monitor Table                  |
| <i>sink_record</i>               | (Optional) Sink Monitor Information            |
| <i>sink_record_properties</i>    | (Optional) Attributes under the source record  |
| TABLE_sink_collector             | (Optional) Sink Collector Table                |
| <i>sink_collector</i>            | (Optional) Sink Collector Information          |
| <i>collector_properties</i>      | (Optional) Attributes under the sink collector |

### Command Mode

- /exec



|                              |                                      |
|------------------------------|--------------------------------------|
| <i>global_punt_pkt_cnt</i>   | (Optional) Global punt packet count  |
| <i>global_punt_byte_cnt</i>  | (Optional) Global punt byte count    |
| <i>global_glean_pkt_cnt</i>  | (Optional) Global glean packet count |
| <i>global_glean_byte_cnt</i> | (Optional) Global glean byte count   |
| <i>glean_pkt_cnt</i>         | (Optional) Glean packet count        |
| <i>glean_byte_cnt</i>        | (Optional) Glean byte count          |
| <i>normal_pkt_cnt</i>        | (Optional) Packet count              |
| <i>normal_byte_cnt</i>       | (Optional) Byte count                |
| <i>last_updated</i>          | (Optional) Lat updated               |
| <i>count-static</i>          | (Optional) Static count              |
| <i>count-dynamic</i>         | (Optional) Dynamic count             |
| <i>count-others</i>          | (Optional) Others count              |
| <i>count-throttle</i>        | (Optional) Throttled count           |
| <i>count-total</i>           | (Optional) Total count               |
| TABLE_afi                    | (Optional) AFI table                 |
| <i>afi</i>                   | (Optional) AFI                       |
| <i>count</i>                 | (Optional) Count                     |
| TABLE_adj                    | (Optional) Adjacency table for IPV6  |
| <i>intf-out</i>              | (Optional) Interface                 |
| <i>phy-intf</i>              | (Optional) Physical interface        |
| <i>time-stamp</i>            | (Optional) Age                       |
| <i>mac</i>                   | (Optional) MAC address               |
| <i>pref</i>                  | (Optional) Preference                |
| <i>owner</i>                 | (Optional) Owner                     |
| <i>pkt-count</i>             | (Optional) Packet count              |
| <i>byte-count</i>            | (Optional) Byte count                |
| <i>mobility</i>              | (Optional) Mobility                  |
| <i>is-best</i>               | (Optional) Best                      |
| <i>is-thrtld</i>             | (Optional) Throttled                 |

**Command Mode**

- /exec



## show ipv6 adjacency aggregate-prefix

```
show ipv6 adjacency aggregate-prefix [ [ vlan <vlan-id> ] [ summary ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] ] [ __readonly__ [ TABLE_vlan <vlan-id> { <ipv6-agg-prefix-vlan-count> | <ipv6-agg-prefix>
<ref-count> } ] <ipv6-agg-prefix-total-count> ]
```

### Syntax Description

|                                    |   |
|------------------------------------|---|
| show                               | Show running system information               |
| ipv6                               | Display IPv6 information                      |
| adjacency                          | Display adjacency table                       |
| aggregate-prefix                   | aggregate-prefix PT info                      |
| vlan                               | (Optional) Vlan id                            |
| <i>vlan-id</i>                     | (Optional) Vlan                               |
| summary                            | (Optional) Show aggregate-prefix summary      |
| vrf                                | (Optional) Display per-VRF information        |
| <i>vrf-name</i>                    | (Optional) VRF name                           |
| <i>vrf-known-name</i>              | (Optional) Known VRF name                     |
| all                                | (Optional) Display ARP entries for all vrfs   |
| __readonly__                       | (Optional)                                    |
| <i>ipv6-agg-prefix-total-count</i> | (Optional) ipv6 aggregate-prefix total count  |
| TABLE_vlan                         | (Optional) TABLR vlan                         |
| <i>vlan-id</i>                     | (Optional) vlan id                            |
| <i>ipv6-agg-prefix-vlan-count</i>  | (Optional) show ipv6 aggregate-prefix summary |
| <i>ipv6-agg-prefix</i>             | (Optional) Ipv6 aggregate prefix              |
| <i>ref-count</i>                   | (Optional) reference-hop count                |

### Command Mode

- /exec

## show ipv6 adjacency subnet-prefix

```
show ipv6 adjacency subnet-prefix [ [ vlan <vlan-id> ] [ summary ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] ] [ __readonly__ [ TABLE_vlan <vlan-id> { <ipv6-subnet-prefix-vlan-count> | <ipv6-subnet-prefix>
<agg-len> <nh-count> } ] <ipv6-subnet-prefix-total-count> ]
```

### Syntax Description

|                                       |   |
|---------------------------------------|---|
| show                                  | Show running system information             |
| ipv6                                  | Display IPv6 information                    |
| adjacency                             | Display adjacency table                     |
| subnet-prefix                         | subnet-prefix PT info                       |
| vlan                                  | (Optional) Vlan id                          |
| <i>vlan-id</i>                        | (Optional) Vlan                             |
| summary                               | (Optional) Show subnet-prefix summary       |
| vrf                                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>                       | (Optional) VRF name                         |
| <i>vrf-known-name</i>                 | (Optional) Known VRF name                   |
| all                                   | (Optional) Display ARP entries for all vrfs |
| <i>__readonly__</i>                   | (Optional)                                  |
| <i>ipv6-subnet-prefix-total-count</i> | (Optional) ipv6 subnet-prefix total count   |
| TABLE_vlan                            | (Optional) TABLE vlan                       |
| <i>vlan-id</i>                        | (Optional) vlan id                          |
| <i>ipv6-subnet-prefix-vlan-count</i>  | (Optional) show ipv6 subnet-prefix summary  |
| <i>ipv6-subnet-prefix</i>             | (Optional) Ipv6 subnet prefix               |
| <i>agg-len</i>                        | (Optional) aggregate-length                 |
| <i>nh-count</i>                       | (Optional) next-hop count                   |

### Command Mode

- /exec

# show ipv6 amt tunnel

```
show ipv6 amt tunnel [ <address6> <port> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__
TABLE_vrf <vrf> <tc6> { TABLE_tunnel <gwa> <gwp> <ut> <ld> <lr> <rc> <exp> { TABLE_route
<source> <group> <rexp> } } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| amt                   | AMT show commands                                   |
| ipv6                  | Display IPv6 information                            |
| tunnel                | Display tunnel information                          |
| vrf                   | (Optional) Display information for VRF              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| <i>port</i>           | (Optional) UDP port number of gateway               |
| detail                | (Optional) Display routes joined by tunnel endpoint |
| __readonly__          | (Optional)  |
| TABLE_vrf             | (Optional)  |
| <i>vrf</i>            | (Optional)  |
| <i>tc6</i>            | (Optional)  |
| TABLE_tunnel          | (Optional)  |
| <i>gwa</i>            | (Optional)  |
| <i>gwp</i>            | (Optional)  |
| <i>ut</i>             | (Optional)  |
| <i>ld</i>             | (Optional)  |
| <i>lr</i>             | (Optional)  |
| <i>rc</i>             | (Optional)  |
| <i>exp</i>            | (Optional)  |
| TABLE_route           | (Optional)  |
| <i>source</i>         | (Optional)  |
| <i>group</i>          | (Optional)  |

|             |            |
|-------------|------------|
| <i>rexp</i> | (Optional) |
|-------------|------------|

**Command Mode**

- /exec

## show ipv6 bgp

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [
<ipv6-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234
} ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| ipv6                  | Display BGP information for IPv6 address family   |
| bgp                   | Display BGP status and configuration              |
| mbgp                  | Display MBGP status and configuration             |
| vrf                   | (Optional) Virtual Router Context                 |
| <i>vrf-name</i>       | (Optional) VRF name                               |
| <i>vrf-known-name</i> | (Optional) Known VRF name                         |
| longer-prefixes       | (Optional) Display route and more specific routes |

### Command Mode

- /exec

## show ipv6 bgp

```
show ipv6 { bgp | mbgp } { route-map { <rmap-name> | <rmap-name> } | prefix-list { <prfxlist-name> |
<test_pol_name> } | filter-list { <fltrlist-name> | <test_pol_name> } | community-list { <commlist-name> |
<test_pol_name> } | extcommunity-list { <extcommlist-name> | <test_pol_name> } [ exact-match ] }
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                 |
| ipv6                    | Display BGP information for IPv6 address family |
| bgp                     | Display BGP status and configuration            |
| mbgp                    | Display MBGP status and configuration           |
| route-map               | Display routes matching the route-map           |
| <i>rmap-name</i>        | Route-map name                                  |
| <i>rmap-name</i>        | Known route-map name                            |
| prefix-list             | Display routes matching the prefix-list         |
| <i>prfxlist-name</i>    | Name of prefix-list                             |
| filter-list             | Display routes matching the filter-list         |
| <i>fltrlist-name</i>    | Name of filter-list                             |
| community-list          | Display routes matching the community-list      |
| <i>commlist-name</i>    | Name of community-list                          |
| extcommunity-list       | Display routes matching the extcommunity-list   |
| <i>extcommlist-name</i> | Name of extcommunity-list                       |
| <i>test_pol_name</i>    | An existing test-list policy                    |
| exact-match             | (Optional) Exact match of the communities       |

### Command Mode

- /exec

## show ipv6 bgp community

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
community { <regex-str> | { { <comm-id> | <wellknown-id> } + [ exact-match ] } } [ vrf { <vrf-name> |
<vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| bgp                   | Display BGP status and configuration            |
| mbgp                  | Display MBGP status and configuration           |
| ipv6                  | Display BGP information for IPv6 address family |
| vrf                   | (Optional) Virtual Router Context               |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| community             | Display routes matching the BGP communities     |
| <i>regex-str</i>      | Regular expression to match the communities     |
| <i>comm-id</i>        | BGP community value                             |
| <i>wellknown-id</i>   | BGP wellknown community                         |
| exact-match           | (Optional) Exact match of the communities       |

### Command Mode

- /exec

## show ipv6 bgp dampening

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
dampening { dampened-paths [ regexp <regexp-str> ] | history-paths [ regexp <regexp-str> ] | parameters |
flap-statistics } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                   |
| bgp                   | Display BGP status and configuration                              |
| mbgp                  | Display MBGP status and configuration                             |
| vrf                   | (Optional) Virtual Router Context                                 |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| dampening             | Display dampening info  |
| parameters            | Display dampening parameters                                      |
| dampened-paths        | Display all dampened paths  |
| history-paths         | Display all history paths   |
| flap-statistics       | Display flap statistics for routes                                |
| ipv6                  | Display BGP information for IPv6 address family                   |
| regexp                | (Optional) Display routes matching the AS path regular expression |
| <i>regexp-str</i>     | (Optional) Regular expression to match the AS paths               |

### Command Mode

- /exec



## show ipv6 bgp extcommunity

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
extcommunity { <regex-str> | { { 4byteas-generic { transitive <ext-comm-gen-trans> | non-transitive
<ext-comm-gen-nontrans> } } + [ exact-match ] } } [ vrf { <vrf-name> | <vrf-known-name> |
ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                 |
| ipv6                         | Display BGP information for IPv6 address family |
| bgp                          | Display BGP status and configuration            |
| mbgp                         | Display MBGP status and configuration           |
| vrf                          | (Optional) Virtual Router Context               |
| <i>vrf-name</i>              | (Optional) VRF name                             |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                       |
| extcommunity                 | Display routes matching the BGP extcommunities  |
| 4byteas-generic              | Generic extended community                      |
| transitive                   | Transitive extcommunity                         |
| non-transitive               | Non-Transitive extcommunity                     |
| <i>regex-str</i>             | Regular expression to match the extcommunities  |
| <i>ext-comm-gen-trans</i>    | Extcommunity number aa4:nn format               |
| <i>ext-comm-gen-nontrans</i> | Extcommunity number aa4:nn format               |
| exact-match                  | (Optional) Exact match of the extcommunities    |

### Command Mode

- /exec

## show ipv6 bgp flap-statistics

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
flap-statistics [ <ipv6-prefix> ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| bgp                   | Display BGP status and configuration            |
| mbgp                  | Display MBGP status and configuration           |
| vrf                   | (Optional) Virtual Router Context               |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| flap-statistics       | Display route flap statistics                   |
| ipv6                  | Display BGP information for IPv6 address family |

### Command Mode

- /exec

# show ipv6 bgp neighbors

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
neighbors { [ { <neighbor-id> | <ipv6-neighbor-id> } [ routes [ advertised | received | dampened ] |
advertised-routes | paths | received-routes | flap-statistics ] ] | <neighbor-prefix-id> | <ipv6-neighbor-prefix-id>
} [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                                       |
| bgp                       | Display BGP status and configuration                                  |
| mbgp                      | Display MBGP status and configuration                                 |
| neighbors                 | Display all configured BGP neighbors                                  |
| vrf                       | (Optional) Virtual Router Context                                     |
| <i>vrf-name</i>           | (Optional) VRF name   |
| <i>vrf-known-name</i>     | (Optional) Known VRF name   |
| <i>neighbor-id</i>        | (Optional) Display one particular BGP neighbor                        |
| <i>neighbor-prefix-id</i> | Display details for a prefix peering                                  |
| ipv6                      | Display BGP information for IPv6 address family                       |
| routes                    | (Optional) Display all routes advertised/received to/from peer        |
| advertised                | (Optional) Display all routes advertised to this peer                 |
| received                  | (Optional) Display all routes received from this peer                 |
| dampened                  | (Optional) Display all dampened routes received from this peer        |
| advertised-routes         | (Optional) Display all the routes advertised to this peer             |
| received-routes           | (Optional) Display all the routes received from this peer             |
| flap-statistics           | (Optional) Display flap statistics for routes received from this peer |
| paths                     | (Optional) Display AS paths learned from this peer                    |

## Command Mode

- /exec

## show ipv6 bgp nexthop-database

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
nexthop-database [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| bgp                   | Display BGP status and configuration            |
| mbgp                  | Display MBGP status and configuration           |
| vrf                   | (Optional) Virtual Router Context               |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| nexthop-database      | Display nexthop database                        |
| ipv6                  | Display BGP information for IPv6 address family |

### Command Mode

- /exec

# show ipv6 bgp nexthop

```
show ipv6 { bgp | mbgp } nexthop <ipv6nexthop>
```

## Syntax Description

|         |   |
|---------|---|
| show    | Show running system information                 |
| ipv6    | Display BGP information for IPv6 address family |
| bgp     | Display BGP status and configuration            |
| mbgp    | Display MBGP status and configuration           |
| nexthop | Display routes matching the nexthop             |

## Command Mode

- /exec

## show ipv6 bgp received-paths

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
received-paths [ private ] [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| ipv6                  | Display BGP information for IPv6 address family |
| bgp                   | Display BGP status and configuration            |
| mbgp                  | Display MBGP status and configuration           |
| vrf                   | (Optional) Virtual Router Context               |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| received-paths        | Display paths stored for soft-reconfig          |
| private               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED       |

### Command Mode

- /exec

# show ipv6 bgp regexp

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] regexp  
<regexp-str> [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| bgp                   | Display BGP status and configuration                   |
| mbgp                  | Display MBGP status and configuration                  |
| vrf                   | (Optional) Virtual Router Context                      |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| ipv6                  | Display BGP information for IPv6 address family        |
| regexp                | Display routes matching the AS path regular expression |
| <i>regexp-str</i>     | Regular expression to match the AS paths               |

## Command Mode

- /exec

# show ipv6 bgp summary

```
show ipv6 { bgp | mbgp } [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
summary [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| bgp                   | Display BGP status and configuration            |
| mbgp                  | Display MBGP status and configuration           |
| vrf                   | (Optional) Virtual Router Context               |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| summary               | Display summarized information of BGP state     |
| ipv6                  | Display BGP information for IPv6 address family |

## Command Mode

- /exec



# show ipv6 client

```
show ipv6 client [ <client-name> ] [ __readonly__ { TABLE_ipv6_client { <cli-name> <cli-stat> <cli-pid>
<cli-ext-pid> [ <protocol> ] <pib-index> <cli-uuid> <rou-vrf> <rou-flg> <ctrl-sap> <data-sap> <ipc-ctrl-mq>
<ipc-ctrl-fail> <ipc-data-mq> <ipc-data-fail> [ <if-ext-ind> ] [ <recv-fn> <recv-hex> ] } } ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                         |
| ipv6                 | Display IPv6 information                                |
| client               | Display clients registered with the IPv6 process        |
| <i>client-name</i>   | (Optional) Display information for a single IPv6 client |
| <i>__readonly__</i>  | (Optional)  |
| TABLE_ipv6_client    | (Optional) IPV6 client table                            |
| <i>cli-name</i>      | (Optional) client name                                  |
| <i>cli-stat</i>      | (Optional) client state                                 |
| <i>cli-pid</i>       | (Optional) client pid                                   |
| <i>cli-ext-pid</i>   | (Optional) client ext-pid                               |
| <i>protocol</i>      | (Optional) ipv6 client protocol                         |
| <i>pib-index</i>     | (Optional) client pib-index                             |
| <i>cli-uuid</i>      | (Optional) client uuid                                  |
| <i>rou-vrf</i>       | (Optional) client route vrf                             |
| <i>rou-flg</i>       | (Optional) client route flag                            |
| <i>ctrl-sap</i>      | (Optional) client control sap                           |
| <i>data-sap</i>      | (Optional) client data sap                              |
| <i>ipc-ctrl-mq</i>   | (Optional) client ipc control message queue             |
| <i>ipc-ctrl-fail</i> | (Optional) client ipc control fail                      |
| <i>ipc-data-mq</i>   | (Optional) client ipc data message queue                |
| <i>ipc-data-fail</i> | (Optional) client ipc data fail                         |
| <i>if-ext-ind</i>    | (Optional) client if ext indes                          |
| <i>recv-fn</i>       | (Optional) client receive fn name                       |
| <i>recv-hex</i>      | (Optional) receive-hexadecimal address                  |

**Command Mode**

- /exec

## show ipv6 dhcp guard policy

```
show ipv6 dhcp guard policy [ <pname> ] [ __readonly__ { TABLE_dhcp_guard_policy <name> <role> [ <target> ] [ <max_pref> ] [ <min_pref> ] [ <match_src_list> ] [ <match_prefix_list> ] } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information               |
| ipv6                     | Show the IPv6 features of the system          |
| <i>pname</i>             | (Optional) Policy name for dhcp guard feature |
| <i>__readonly__</i>      | (Optional)                                    |
| TABLE_dhcp_guard_policy  | (Optional) IPv6 DHCP guard policy             |
| <i>name</i>              | (Optional) Policy Name                        |
| <i>role</i>              | (Optional) Role                               |
| <i>target</i>            | (Optional) Target                             |
| <i>max_pref</i>          | (Optional) Max preference                     |
| <i>min_pref</i>          | (Optional) Min preference                     |
| <i>match_src_list</i>    | (Optional) Source Address Match Access List   |
| <i>match_prefix_list</i> | (Optional) Prefix List Match Prefix List      |

### Command Mode

- /exec

## show ipv6 dhcp relay

```
show ipv6 dhcp relay [ interface <intf-range> ] [ __readonly__ [ <relay_service_enable>
<v6_global_smart-relay_enable> [ <gbl_src_intf> ] <relay_vpn_enable> <relay_option79_state>
<relay_cisco_option_enable> ] [ TABLE_intf <interface-name> [ <intf_src_intf> ] <intf_header> [
TABLE_addr <relay_address> <dst_intf> <vrf_name> ] ] <v6_smart_relay_intfs_hdr> [ TABLE_intf
<v6_smart_relay_enabled_intfs> ] ]
```

### Syntax Description

|                                     |   |
|-------------------------------------|---|
| show                                | Show running system information                                 |
| ipv6                                | Show the IPv6 features of the system                            |
| dhcp                                | Show DHCPv6   |
| relay                               | DHCPv6 relay address of the interface                           |
| interface                           | (Optional) DHCPv6 relay address of the interface                |
| <i>intf-range</i>                   | (Optional) interface  |
| <i>__readonly__</i>                 | (Optional) Read only  |
| <i>relay_service_enable</i>         | (Optional) is dhcpv6 relay service enabled                      |
| <i>v6_global_smart-relay_enable</i> | (Optional)  |
| <i>gbl_src_intf</i>                 | (Optional) interface name                                       |
| <i>relay_vpn_enable</i>             | (Optional) is dhcpv6 relay insertion of vpn sub options enabled |
| <i>relay_option79_state</i>         | (Optional) is dhcp relay option79 state                         |
| <i>relay_cisco_option_enable</i>    | (Optional) is dhcpv6 relay cisco option enabled                 |
| TABLE_intf                          | (Optional)  |
| <i>interface-name</i>               | (Optional) interface name                                       |
| <i>intf_src_intf</i>                | (Optional) interface name                                       |
| <i>intf_header</i>                  | (Optional) interface header                                     |
| TABLE_addr                          | (Optional)  |
| <i>dst_intf</i>                     | (Optional) interface name                                       |
| <i>vrf_name</i>                     | (Optional) VRF name   |
| <i>v6_smart_relay_intfs_hdr</i>     | (Optional) Smart relay interfaces header                        |
| TABLE_intf                          | (Optional)  |
| <i>v6_smart_relay_enabled_intfs</i> | (Optional) smart-relay enabled interfaces                       |

**Command Mode**

- /exec

## show ipv6 dhcp relay statistics

```
show ipv6 dhcp relay statistics [ interface <intf> [ [ server-ip <ip-addr-val> [ use-vrf <vrf-name> ] [ interface
<dest-interface> ] ] ] [ server-ip <ip-addr-val> [ interface <dest-interface> ] [ use-vrf <vrf-name> ] ] ] [
__readonly__ [ <msg_stats_hdr> <msg_type_str> <rx_pkts> <tx_pkts> <drops> <msg_type_str_advertise>
<rx_pkts_advertise> <tx_pkts_advertise> <drops_advertise> <msg_type_str_request> <rx_pkts_request>
<tx_pkts_request> <drops_request> <msg_type_str_confirm> <rx_pkts_confirm> <tx_pkts_confirm>
<drops_confirm> <msg_type_str_renew> <rx_pkts_renew> <tx_pkts_renew> <drops_renew>
<msg_type_str_rebind> <rx_pkts_rebind> <tx_pkts_rebind> <drops_rebind> <msg_type_str_reply>
<rx_pkts_reply> <tx_pkts_reply> <drops_reply> <msg_type_str_release> <rx_pkts_release> <tx_pkts_release>
<drops_release> <msg_type_str_decline> <rx_pkts_decline> <tx_pkts_decline> <drops_decline>
<msg_type_str_reconfigure> <rx_pkts_reconfigure> <tx_pkts_reconfigure> <drops_reconfigure>
<msg_type_str_inforeq> <rx_pkts_inforeq> <tx_pkts_inforeq> <drops_inforeq> <msg_type_str_relay_fwd>
<rx_pkts_relay_fwd> <tx_pkts_relay_fwd> <drops_relay_fwd> <msg_type_str_relay_reply>
<rx_pkts_relay_reply> <tx_pkts_relay_reply> <drops_relay_reply> <msg_type_str_unknown>
<rx_pkts_unknown> <tx_pkts_unknown> <drops_unknown> <msg_type_str_total> <rx_pkts_total>
<tx_pkts_total> <drops_total> ] [ <server_stats_hdr> [ TABLE_server <server_helper_addr> <server_vrf>
<server_intf> <server_requests> <server_responses> ] ] [ <drop_hdr> <drop_relay_disable> <drop_max_hops>
<drop_validation_fails> <drop_unknown_op_intf> <drop_bad_context> <drop_opt_insert_fail>
<drop_server_direct_reply> <drop_no_ipv6_addr> <drop_intf_error> <drop_vpn_disabled>
<drop_ipv6_extn_hdrs_presence> <drop_mct_drop> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                         |
| ipv6                  | Show the IPv6 features of the system                    |
| dhcp                  | Show information about DHCPv6                           |
| relay                 | DHCPv6 Relay  |
| statistics            | Statistics related to DHCPv6                            |
| interface             | (Optional) input interface                              |
| <i>intf</i>           | (Optional) interface                                    |
| server-ip             | (Optional) Server address                               |
| use-vrf               | (Optional) server address VRF membership                |
| <i>vrf-name</i>       | (Optional) VRF name                                     |
| interface             | (Optional) Destination interface for the server address |
| <i>dest-interface</i> | (Optional) Destination interface                        |
| <i>__readonly__</i>   | (Optional) Read only                                    |
| <i>msg_stats_hdr</i>  | (Optional) dhcpv6 message statistics header             |
| <i>msg_type_str</i>   | (Optional) dhcpv6 message type                          |

|                               |                                     |
|-------------------------------|-------------------------------------|
| <i>rx_pkts</i>                | (Optional) dhcpv6 received packets  |
| <i>tx_pkts</i>                | (Optional) dhcpv6 forwarded packets |
| <i>drops</i>                  | (Optional) dhcpv6 packet drops      |
| <i>msg_type_str_advertise</i> | (Optional)                          |
| <i>rx_pkts_advertise</i>      | (Optional)                          |
| <i>tx_pkts_advertise</i>      | (Optional)                          |
| <i>drops_advertise</i>        | (Optional)                          |
| <i>msg_type_str_request</i>   | (Optional)                          |
| <i>rx_pkts_request</i>        | (Optional)                          |
| <i>tx_pkts_request</i>        | (Optional)                          |
| <i>drops_request</i>          | (Optional)                          |
| <i>msg_type_str_confirm</i>   | (Optional)                          |
| <i>rx_pkts_confirm</i>        | (Optional)                          |
| <i>tx_pkts_confirm</i>        | (Optional)                          |
| <i>drops_confirm</i>          | (Optional)                          |
| <i>msg_type_str_renew</i>     | (Optional)                          |
| <i>rx_pkts_renew</i>          | (Optional)                          |
| <i>tx_pkts_renew</i>          | (Optional)                          |
| <i>drops_renew</i>            | (Optional)                          |
| <i>msg_type_str_rebind</i>    | (Optional)                          |
| <i>rx_pkts_rebind</i>         | (Optional)                          |
| <i>tx_pkts_rebind</i>         | (Optional)                          |
| <i>drops_rebind</i>           | (Optional)                          |
| <i>msg_type_str_reply</i>     | (Optional)                          |
| <i>rx_pkts_reply</i>          | (Optional)                          |
| <i>tx_pkts_reply</i>          | (Optional)                          |
| <i>drops_reply</i>            | (Optional)                          |
| <i>msg_type_str_release</i>   | (Optional)                          |
| <i>rx_pkts_release</i>        | (Optional)                          |

|                                 |  |
|---------------------------------|--|
| <i>tx_pkts_release</i>          | (Optional)                                   |
| <i>drops_release</i>            | (Optional)                                   |
| <i>msg_type_str_decline</i>     | (Optional)                                   |
| <i>rx_pkts_decline</i>          | (Optional)                                   |
| <i>tx_pkts_decline</i>          | (Optional)                                   |
| <i>drops_decline</i>            | (Optional)                                   |
| <i>msg_type_str_reconfigure</i> | (Optional)                                   |
| <i>rx_pkts_reconfigure</i>      | (Optional)                                   |
| <i>tx_pkts_reconfigure</i>      | (Optional)                                   |
| <i>drops_reconfigure</i>        | (Optional)                                   |
| <i>msg_type_str_inforeq</i>     | (Optional)                                   |
| <i>rx_pkts_inforeq</i>          | (Optional)                                   |
| <i>tx_pkts_inforeq</i>          | (Optional)                                   |
| <i>drops_inforeq</i>            | (Optional)                                   |
| <i>msg_type_str_relay_fwd</i>   | (Optional)                                   |
| <i>rx_pkts_relay_fwd</i>        | (Optional)                                   |
| <i>tx_pkts_relay_fwd</i>        | (Optional)                                   |
| <i>drops_relay_fwd</i>          | (Optional)                                   |
| <i>msg_type_str_relay_reply</i> | (Optional)                                   |
| <i>rx_pkts_relay_reply</i>      | (Optional)                                   |
| <i>tx_pkts_relay_reply</i>      | (Optional)                                   |
| <i>drops_relay_reply</i>        | (Optional)                                   |
| <i>msg_type_str_unknown</i>     | (Optional)                                   |
| <i>rx_pkts_unknown</i>          | (Optional)                                   |
| <i>tx_pkts_unknown</i>          | (Optional)                                   |
| <i>drops_unknown</i>            | (Optional)                                   |
| <i>msg_type_str_total</i>       | (Optional) total of all dhcpv6 message types |
| <i>rx_pkts_total</i>            | (Optional)                                   |
| <i>tx_pkts_total</i>            | (Optional)                                   |



|                                     |   |
|-------------------------------------|---|
| <i>drops_total</i>                  | (Optional)                              |
| <i>server_stats_hdr</i>             | (Optional) per-server statistics header |
| TABLE_server                        | (Optional)                              |
| <i>server_vrf</i>                   | (Optional) dhcpv6 server vrf            |
| <i>server_intf</i>                  | (Optional) interface name               |
| <i>server_requests</i>              | (Optional)                              |
| <i>server_responses</i>             | (Optional)                              |
| <i>drop_hdr</i>                     | (Optional)                              |
| <i>drop_relay_disable</i>           | (Optional)                              |
| <i>drop_max_hops</i>                | (Optional)                              |
| <i>drop_validation_fails</i>        | (Optional)                              |
| <i>drop_unknown_op_intf</i>         | (Optional)                              |
| <i>drop_bad_context</i>             | (Optional)                              |
| <i>drop_opt_insert_fail</i>         | (Optional)                              |
| <i>drop_server_direct_reply</i>     | (Optional)                              |
| <i>drop_no_ipv6_addr</i>            | (Optional)                              |
| <i>drop_intf_error</i>              | (Optional)                              |
| <i>drop_vpn_disabled</i>            | (Optional)                              |
| <i>drop_ipv6_extn_hdrs_presence</i> | (Optional)                              |
| <i>drop_mct_drop</i>                | (Optional) drops through mct            |

### Command Mode

- /exec

# show ipv6 fragments

```
show ipv6 fragments [ <source-addr> ] [ __readonly__ [ TABLE_ipv6_frag [ TABLE_ipv6_each_q {
<ipv6-src> <ipv6-dest> <frag-id> <frag-off> <m-flag> <nxt-header> <pay-load> <expires> } ] ] ]
```

## Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information           |
| ipv6              | Display IPv6 information                  |
| fragments         | Display queued fragments                  |
| __readonly__      | (Optional)                                |
| TABLE_ipv6_frag   | (Optional) IPV6 fragment table            |
| TABLE_ipv6_each_q | (Optional) IPV6 each fragment queue table |
| <i>frag-id</i>    | (Optional) fragment id                    |
| <i>frag-off</i>   | (Optional) fragment offset                |
| <i>m-flag</i>     | (Optional) m flag                         |
| <i>nxt-header</i> | (Optional) next header                    |
| <i>pay-load</i>   | (Optional) fargment payload               |
| <i>expires</i>    | (Optional) expiry time                    |

## Command Mode

- /exec

# show ipv6 icmp

```
show ipv6 icmp { adjacency | neighbor | sync-entries } [ <interface> ] [ detail ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ { <icmpv6-vrftype> <icmpv6-cxt-name> } [ TABLE_icmpv6_all_int
{ TABLE_icmpv6_one_int { <icmpv6-ipv6-addr> <time-stamp-icmpv6> <icmpv6-mac> <icmpv6-state>
<icmpv6-short-name> [ <phy-int-short-name> ] } } ] ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information               |
| ipv6                      | Display IPv6 information                      |
| icmp                      | Display ICMPv6 information                    |
| adjacency                 | Show IPv6 dynamic learnt adjacency entry      |
| neighbor                  | Show IPv6 dynamic learnt neighbor entry       |
| sync-entries              | Show IPv6 table learnt only due to table sync |
| <i>interface</i>          | (Optional) Interface name to display          |
| detail                    | (Optional) Display detailed information       |
| vrf                       | (Optional) Display per-VRF information        |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                     |
| all                       | (Optional) Display information for all VRFs   |
| <i>__readonly__</i>       | (Optional)                                    |
| <i>icmpv6-vrftype</i>     | (Optional)                                    |
| <i>icmpv6-cxt-name</i>    | (Optional)                                    |
| TABLE_icmpv6_all_int      | (Optional)                                    |
| TABLE_icmpv6_one_int      | (Optional)                                    |
| <i>time-stamp-icmpv6</i>  | (Optional)                                    |
| <i>icmpv6-mac</i>         | (Optional)                                    |
| <i>icmpv6-state</i>       | (Optional)                                    |
| <i>icmpv6-short-name</i>  | (Optional)                                    |
| <i>phy-int-short-name</i> | (Optional)                                    |

## Command Mode

- /exec

## show ipv6 icmp global traffic

```
show ipv6 { icmp | nd } global traffic [ __readonly__ [ { TABLE_icmpv6_global_stat [ <st-total> ] [ <rv-total> ] [ <st-err> ] [ <rv-err> ] [ <st-int-drp-cnt> ] [ <rv-int-drp-cnt> ] [ <st-adj-nt-recov-am-ha> ] [ <rv-adj-nt-recov-am-ha> ] [ <st-pkt-allow-inv-ttl-vpc> ] [ <rv-pkt-allow-inv-ttl-vpc> ] [ <st-drp-src-mac-own> ] [ <rv-drp-src-mac-own> ] [ <st-drp-tgt-ip-not-own> ] [ <rv-drp-tgt-ip-not-own> ] [ <st-drp-src-ip-not-own> ] [ <rv-drp-src-ip-not-own> ] [ <st-dest-unreach> ] [ <rv-dest-unreach> ] [ <st-admin-prohibit> ] [ <rv-admin-prohibit> ] [ <st-time-exceed> ] [ <rv-time-exceed> ] [ <st-para-pbms> ] [ <rv-para-pbms> ] [ <st-echo-req> ] [ <rv-echo-req> ] [ <st-echo-reply> ] [ <rv-echo-reply> ] [ <st-redirect> ] [ <rv-redirect> ] [ <st-pkt-too-big> ] [ <rv-pkt-too-big> ] [ <st-rtr-adver> ] [ <rv-rtr-adver> ] [ <st-rtr-solicit> ] [ <rv-rtr-solicit> ] [ <st-nei-adver> ] [ <rv-nei-adver> ] [ <st-nei-solicit> ] [ <rv-nei-solicit> ] [ <fast-path-pkts> ] [ <fastpath-disable> ] [ <ign-fastpath-pkts> ] [ <dup-rtr-ra-recvd> ] [ <rv-dup-rtr-ra-recvd> ] } ] ] ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                           |
| ipv6                            | Display IPv6 information                                  |
| icmp                            | Display ICMPv6 information                                |
| nd                              | ICMPv6 Neighbor Discovery commands                        |
| global                          | Show ICMPv6/ND global variables                           |
| traffic                         | Display ICMPv6 software processed traffic statistics      |
| __readonly__                    | (Optional)  |
| TABLE_icmpv6_global_stat        | (Optional) ICMPV6 global statistics                       |
| <i>st-total</i>                 | (Optional) total sent messages                            |
| <i>rv-total</i>                 | (Optional) total receive messages                         |
| <i>st-err</i>                   | (Optional) total sent error message                       |
| <i>rv-err</i>                   | (Optional) total receive error message                    |
| <i>st-int-drp-cnt</i>           | (Optional) sent interface down drop count                 |
| <i>rv-int-drp-cnt</i>           | (Optional) receive interface down drop count              |
| <i>st-adj-nt-recov-am-ha</i>    | (Optional) sent Adjacency not recovered from AM aft HA    |
| <i>rv-adj-nt-recov-am-ha</i>    | (Optional) receive Adjacency not recovered from AM aft HA |
| <i>st-pkt-allow-inv-ttl-vpc</i> | (Optional) sent Pkts allowed due to inv ttl on vPC-MCT    |
| <i>rv-pkt-allow-inv-ttl-vpc</i> | (Optional) receive Pkts allowed due to inv ttl on vPC-MCT |
| <i>st-drp-src-mac-own</i>       | (Optional) sent packet drop source mac address own        |
| <i>rv-drp-src-mac-own</i>       | (Optional) receive packet drop source mac address own     |

|                              |  |
|------------------------------|--|
| <i>st-drp-tgt-ip-not-own</i> | (Optional) sent drop tgt ip address not own    |
| <i>rv-drp-tgt-ip-not-own</i> | (Optional) receive drop tgt ip address not own |
| <i>st-drp-src-ip-not-own</i> | (Optional) sent dropped source ip address      |
| <i>rv-drp-src-ip-not-own</i> | (Optional) receive dropped source ip address   |
| <i>st-dest-unreach</i>       | (Optional) sent destination unreachable        |
| <i>rv-dest-unreach</i>       | (Optional) receive destination unreachable     |
| <i>st-admin-prohibit</i>     | (Optional) sent Administratively Prohibited    |
| <i>rv-admin-prohibit</i>     | (Optional) receive Administratively Prohibited |
| <i>st-time-exceed</i>        | (Optional) sent time exceeded                  |
| <i>rv-time-exceed</i>        | (Optional) receive time exceeded               |
| <i>st-para-pbms</i>          | (Optional) sent parameter problems             |
| <i>rv-para-pbms</i>          | (Optional) receive parameter problems          |
| <i>st-echo-req</i>           | (Optional) sent echo request                   |
| <i>rv-echo-req</i>           | (Optional) receive echo request                |
| <i>st-echo-reply</i>         | (Optional) sent echo replies                   |
| <i>rv-echo-reply</i>         | (Optional) receive echo replies                |
| <i>st-redirect</i>           | (Optional) sent redirects                      |
| <i>rv-redirect</i>           | (Optional) receive redirects                   |
| <i>st-pkt-too-big</i>        | (Optional) sent packet too big                 |
| <i>rv-pkt-too-big</i>        | (Optional) receive packet too big              |
| <i>st-rtr-adver</i>          | (Optional) sent router advertisements          |
| <i>rv-rtr-adver</i>          | (Optional) receive router advertisements       |
| <i>st-rtr-solicit</i>        | (Optional) sent router solicitations           |
| <i>rv-rtr-solicit</i>        | (Optional) receive router solicitations        |
| <i>st-nei-adver</i>          | (Optional) sent neighbor advertisements        |
| <i>rv-nei-adver</i>          | (Optional) receive neighbor advertisements     |
| <i>st-nei-solicit</i>        | (Optional) sent neighbor solicitations         |
| <i>rv-nei-solicit</i>        | (Optional) receive neighbor solicitations      |
| <i>fast-path-pkts</i>        | (Optional) fastpath packets                    |

|                            |  |
|----------------------------|--|
| <i>fastpath-disable</i>    | (Optional) [fastpath disabled / others]      |
| <i>ign-fastpath-pkts</i>   | (Optional) Packets drop request ignore count |
| <i>dup-rtr-ra-recvd</i>    | (Optional) Duplicate router RA sent          |
| <i>rv-dup-rtr-ra-recvd</i> | (Optional) Duplicate router RA received      |

**Command Mode**

- /exec

## show ipv6 icmp interface

```
{ show ipv6 { icmp | nd } interface [ <interface> ] { [ prefix [ full ] ] [ route ] [ detail ] } [ vrf { <vrf-name>
| <vrf-known-name> | all } ] } [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_intf <intf-name>
<proto-state> <link-state> <admin-state> [ TABLE_addr <addr> ] <subnet> <link-local-addr>
<icmpv6-disabled> <last-ns-sent> <last-na-sent> <last-ra-sent> <next-na-sent> <ra-min-interval> <ra-interval>
<set-m-flag> <set-o-flag> <current-hop-limit> <mtu> <router-lifetime> <reachable-time> <retrans-timer>
<ns-interval> <send-redirect> <send-unreachables> <ra-sent> <ra-rec> <rs-sent> <rs-rec> <na-sent> <na-rec>
<ns-sent> <ns-rec> <ns-drop-tent-state> <redirect-sent> <redirect-rec> <msg-sent> <msg-rec> <errors-sent>
<erros-rec> <ifdown-sent> <ifdown-rec> <am-ha-not-ready> <allow-mct-ttl> <our-own-mac> <tgt-not-us>
<dest-unreachs-sent> <dest-unreachs-rec> <admin-prohibs-sent> <admin-prohibs-rec> <time-excds-sent>
<time-excds-rec> <parm-problems-sent> <parm-problems-rec> <echos-sent> <echos-rec> <echo-replies-sent>
<echo-replies-rec> <pkt-toobigs-sent> <pkt-toobigs-rec> <fastpath-pkt-recv> <fastpath-disable-pkt-recv>
<fastpath-ignore-pkt-recv> <uptime> <mld-config-il> [ TABLE_one_int <grp-id> <protocol-one-int>
<client-uuid> <client-state-act> <client-in-use> TABLE_vip_list <virt-ipv6> <virt-mac> <context_name>
<context_id> <last-solocit-st> <last-nei-ad-st> <last-rtr-adv-st> <nxt-rtr-ad-st> ] <max-dad-attempts>
<current-dad-attempts> [ TABLE_route <route> <preference> <lifetime> <info-option>
<reachability-verify-enabled> <adv-route-info> <route-zero-lifetime> ] [ TABLE_prefix <prefix> <enabled>
<vlaidlife-time> <preferredlife-time> <on-link> <off-link> <autonomous> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                   |
| ipv6                  | Display IPv6 information  |
| icmp                  | Display ICMPv6 information  |
| vrf                   | (Optional) Display per-VRF information                            |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| all                   | (Optional) Display information for all VRFs                       |
| nd                    | ICMPv6 Neighbor Discovery commands                                |
| interface             | Display ICMPv6 related interface information                      |
| prefix                | (Optional) Display List of ICMPv6 RA prefix                       |
| route                 | (Optional) Display List of ICMPv6 RA routes                       |
| full                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                         |
| detail                | (Optional) Display ICMPv6 related interface information in detail |
| <i>interface</i>      | (Optional) Interface name to show                                 |
| <i>__readonly__</i>   | (Optional)  |
| TABLE_vrf             | (Optional)  |



|                          |            |
|--------------------------|------------|
| <i>vrf-name-out</i>      | (Optional) |
| TABLE_intf               | (Optional) |
| <i>intf-name</i>         | (Optional) |
| <i>proto-state</i>       | (Optional) |
| <i>link-state</i>        | (Optional) |
| <i>admin-state</i>       | (Optional) |
| TABLE_addr               | (Optional) |
| <i>icmpv6-disabled</i>   | (Optional) |
| <i>last-ns-sent</i>      | (Optional) |
| <i>last-na-sent</i>      | (Optional) |
| <i>last-ra-sent</i>      | (Optional) |
| <i>next-na-sent</i>      | (Optional) |
| <i>ra-min-interval</i>   | (Optional) |
| <i>ra-interval</i>       | (Optional) |
| <i>set-m-flag</i>        | (Optional) |
| <i>set-o-flag</i>        | (Optional) |
| <i>current-hop-limit</i> | (Optional) |
| <i>mtu</i>               | (Optional) |
| <i>router-lifetime</i>   | (Optional) |
| <i>reachable-time</i>    | (Optional) |
| <i>retrans-timer</i>     | (Optional) |
| <i>ns-interval</i>       | (Optional) |
| <i>send-redirect</i>     | (Optional) |
| <i>send-unreachables</i> | (Optional) |
| <i>ra-sent</i>           | (Optional) |
| <i>ra-rec</i>            | (Optional) |
| <i>rs-sent</i>           | (Optional) |
| <i>rs-rec</i>            | (Optional) |
| <i>na-sent</i>           | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>na-rec</i>             | (Optional) |
| <i>ns-sent</i>            | (Optional) |
| <i>ns-rec</i>             | (Optional) |
| <i>ns-drop-tent-state</i> | (Optional) |
| <i>redirect-sent</i>      | (Optional) |
| <i>redirect-rec</i>       | (Optional) |
| <i>msg-sent</i>           | (Optional) |
| <i>msg-rec</i>            | (Optional) |
| <i>errors-sent</i>        | (Optional) |
| <i>erros-rec</i>          | (Optional) |
| <i>ifdown-sent</i>        | (Optional) |
| <i>ifdown-rec</i>         | (Optional) |
| <i>am-ha-not-ready</i>    | (Optional) |
| <i>allow-mct-ttl</i>      | (Optional) |
| <i>our-own-mac</i>        | (Optional) |
| <i>tgt-not-us</i>         | (Optional) |
| <i>dest-unreachs-sent</i> | (Optional) |
| <i>dest-unreachs-rec</i>  | (Optional) |
| <i>admin-prohibs-sent</i> | (Optional) |
| <i>admin-prohibs-rec</i>  | (Optional) |
| <i>time-excds-sent</i>    | (Optional) |
| <i>time-excds-rec</i>     | (Optional) |
| <i>parm-problems-sent</i> | (Optional) |
| <i>parm-problems-rec</i>  | (Optional) |
| <i>echos-sent</i>         | (Optional) |
| <i>echos-rec</i>          | (Optional) |
| <i>echo-replies-sent</i>  | (Optional) |
| <i>echo-replies-rec</i>   | (Optional) |
| <i>pkt-toobigs-sent</i>   | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>pkt-toobigs-rec</i>             | (Optional) |
| <i>fastpath-pkt-recv</i>           | (Optional) |
| <i>fastpath-disable-pkt-recv</i>   | (Optional) |
| <i>fastpath-ignore-pkt-recv</i>    | (Optional) |
| <i>uptime</i>                      | (Optional) |
| <i>mld-config-il</i>               | (Optional) |
| TABLE_one_int                      | (Optional) |
| <i>grp-id</i>                      | (Optional) |
| <i>protocol-one-int</i>            | (Optional) |
| <i>client-uuid</i>                 | (Optional) |
| <i>client-state-act</i>            | (Optional) |
| <i>client-in-use</i>               | (Optional) |
| TABLE_vip_list                     | (Optional) |
| <i>virt-mac</i>                    | (Optional) |
| <i>context_name</i>                | (Optional) |
| <i>context_id</i>                  | (Optional) |
| <i>last-solicit-st</i>             | (Optional) |
| <i>last-nei-ad-st</i>              | (Optional) |
| <i>last-rtr-adv-st</i>             | (Optional) |
| <i>nxt-rtr-ad-st</i>               | (Optional) |
| <i>max-dad-attempts</i>            | (Optional) |
| <i>current-dad-attempts</i>        | (Optional) |
| TABLE_route                        | (Optional) |
| <i>preference</i>                  | (Optional) |
| <i>lifetime</i>                    | (Optional) |
| <i>info-option</i>                 | (Optional) |
| <i>reachability-verify-enabled</i> | (Optional) |
| <i>adv-route-info</i>              | (Optional) |
| <i>route-zero-lifetime</i>         | (Optional) |

|                          |            |
|--------------------------|------------|
| TABLE_prefix             | (Optional) |
| <i>enabled</i>           | (Optional) |
| <i>vlaidlif-time</i>     | (Optional) |
| <i>preferredlif-time</i> | (Optional) |
| <i>on-link</i>           | (Optional) |
| <i>off-link</i>          | (Optional) |
| <i>autonomous</i>        | (Optional) |

**Command Mode**

- /exec

## show ipv6 icmp l2 statistics

```
show ipv6 { icmp | nd } l2 statistics [ interface <interface> ] [ __readonly__ [ TABLE_intf { <intf_name>
<l2_stats> } ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| ipv6                | Display IPv6 information                            |
| icmp                | Display ICMPv6 information                          |
| nd                  | ICMPv6 Neighbor Discovery commands                  |
| interface           | (Optional) Interface for which l2 stats to be shown |
| l2                  | Display ND info for layer-2 interface               |
| statistics          | Display ND statistics for layer 2 interface         |
| <i>interface</i>    | (Optional) interface                                |
| <i>__readonly__</i> | (Optional)  |
| TABLE_intf          | (Optional) Layer 2 Interface name                   |
| <i>intf_name</i>    | (Optional) Interface name                           |
| <i>l2_stats</i>     | (Optional) layer 2 ND stats on given interface      |

### Command Mode

- /exec

## show ipv6 icmp nd local-proxy stats

```
show ipv6 icmp nd local-proxy stats { <vlan-interface> [ <interface> ] } [ __readonly__ [ TABLE_vlan {
<vlan-name> [ TABLE_intf { <intf-name> <current-count> [ TABLE_hourly_stats { <hrs> <hrs-str> <stats>
} ] } ] } ] }
```

### Syntax Description

|                       |                                    |
|-----------------------|------------------------------------|
| show                  | Show running system information    |
| ipv6                  | Display IPv6 information           |
| icmp                  | Display ICMPv6 information         |
| nd                    | ICMPv6 Neighbor Discovery commands |
| local-proxy           | show nd local proxy stats          |
| stats                 | statistics                         |
| <i>vlan-interface</i> | vlan interface                     |
| <i>interface</i>      | (Optional) interface               |
| <i>__readonly__</i>   | (Optional)                         |
| TABLE_vlan            | (Optional)                         |
| <i>vlan-name</i>      | (Optional)                         |
| TABLE_intf            | (Optional)                         |
| <i>intf-name</i>      | (Optional)                         |
| <i>current-count</i>  | (Optional)                         |
| TABLE_hourly_stats    | (Optional)                         |
| <i>hrs</i>            | (Optional)                         |
| <i>hrs-str</i>        | (Optional)                         |
| <i>stats</i>          | (Optional)                         |

### Command Mode

- /exec

## show ipv6 icmp off-list

```
show ipv6 icmp off-list [ vlan <vlan-id> ] [ __readonly__ [ <vlan-adj-cnt> ] [ <icmpv6-sync-adj-cnt> ] {
TABLE_ icmpv6_vlan_list <adj-vlan-id> <off-adj-ip-addr> <icmpv6-time-stamp> <icmpv6-mac-addr>
<off-adj-flags> } ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                |
| ipv6                       | Display IPv6 information                       |
| icmp                       | Display ICMPv6 information                     |
| off-list                   | Show adjacencies in off-list icmpv6 database   |
| vlan                       | (Optional) Vlan id                             |
| <i>vlan-id</i>             | (Optional) Show information for specified vlan |
| <i>__readonly__</i>        | (Optional)                                     |
| <i>vlan-adj-cnt</i>        | (Optional) vlan adjacency count                |
| <i>icmpv6-sync-adj-cnt</i> | (Optional) icmpv6 sync adjacency count         |
| TABLE_ icmpv6_vlan_list    | (Optional) icmpv6 vlan list table              |
| <i>adj-vlan-id</i>         | (Optional) adjacency vlan id                   |
| <i>icmpv6-time-stamp</i>   | (Optional) icmpv6 time stamp                   |
| <i>icmpv6-mac-addr</i>     | (Optional) icmpv6 mac address                  |
| <i>off-adj-flags</i>       | (Optional) offlist adjacency flags             |

### Command Mode

- /exec

## show ipv6 icmp vaddr

```
show ipv6 icmp vaddr { link-local [ detail ] | global | pt-tree } [ vrf { <vrf-name> | <vrf-known-name> | all }
] [ __readonly__ [ TABLE_pt_tree { <v-ipv6-addr> <v-mac-addr> <v-interface> <v-client-state> } ] [
TABLE_vrf_all [ TABLE_glo_vrf { <group-id> <protocol-vrf> <cli-uuid> <vaddr-action> <vrf-interface>
<v-ipv6-addr-one> <vaddr-mac> <cxt-name> <cxt-id> } ] [ TABLE_one_int [ <lcache-inter> <cxt-name-int>
<cxt_id-int> ] TABLE_one_group { <grp-id> <protocol-one-int> <client-uuid> <client-state-act>
<client-in-use> <client-state> TABLE_vip_list { <virt-ipv6> <virt-mac> <cxt_name> <cxt_id> [
<last-solicit-st> <last-nei-ad-st> <last-rtr-adv-st> <nxt-rtr-ad-st> <icmpv6-addr> <vmac-addr> <st-total>
<rv-total> <st-err> <rv-err> <st-int-dwn-drp> <rv-int-dwn-drp> <st-adj-nt-recov-am> <rv-adj-nt-recov-am>
<st-pkt-allow-inv-ttl> <rv-pkt-allow-inv-ttl> <st-pkt-drp-src-mac-own> <rv-pkt-drp-src-mac-own>
<st-pkt-drp-tgt-not-own> <rv-pkt-drp-tgt-not-own> <st-pkt-drp-src-not-own> <rv-pkt-drp-src-not-own>
<st-dest-unreach> <rv-dest-unreach> <st-admin-prohi> <rv-admin-prohi> <st-time-exceed> <rv-time-exceed>
<st-patr-pbm> <rv-patr-pbm> <st-echo-req> <rv-echo-req> <st-echo-reply> <rv-echo-reply> <st-dup-ra>
<rv-dup-ra> <st-redirect> <rv-redirect> <st-pkt-too-big> <rv-pkt-too-big> <st-rtr-adver> <rv-rtr-adver>
<st-rtr-solicit> <rv-rtr-solicit> <st-nei-adver> <rv-nei-adver> <st-nei-solicit> <rv-nei-solicit> } } ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                               |
| ipv6                  | Display IPv6 information                                      |
| icmp                  | Display ICMPv6 information                                    |
| vaddr                 | Show all virtual addresses configured                         |
| link-local            | Display link-local virtual ipv6 addresses                     |
| detail                | (Optional) Display detailed information                       |
| global                | Display global virtual ipv6 addresses                         |
| pt-tree               | Display link-local virtual ipv6 addresses pt-tree information |
| vrf                   | (Optional) Display per-VRF information                        |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                     |
| all                   | (Optional) Display information for all VRFs                   |
| <i>__readonly__</i>   | (Optional)  |
| TABLE_pt_tree         | (Optional)  |
| <i>v-mac-addr</i>     | (Optional)  |
| <i>v-interface</i>    | (Optional)  |
| <i>v-client-state</i> | (Optional)  |
| TABLE_vrf_all         | (Optional)  |



|                         |            |
|-------------------------|------------|
| TABLE_glo_vrf           | (Optional) |
| <i>group-id</i>         | (Optional) |
| <i>protocol-vrf</i>     | (Optional) |
| <i>cli-uuid</i>         | (Optional) |
| <i>vaddr-action</i>     | (Optional) |
| <i>vrf-interface</i>    | (Optional) |
| <i>vaddr-mac</i>        | (Optional) |
| <i>cxt-name</i>         | (Optional) |
| <i>cxt-id</i>           | (Optional) |
| TABLE_one_int           | (Optional) |
| <i>lcache-inter</i>     | (Optional) |
| <i>cxt-name-int</i>     | (Optional) |
| <i>cxt_id-int</i>       | (Optional) |
| <i>grp-id</i>           | (Optional) |
| <i>protocol-one-int</i> | (Optional) |
| <i>client-uuid</i>      | (Optional) |
| <i>client-state-act</i> | (Optional) |
| <i>client-in-use</i>    | (Optional) |
| <i>client-state</i>     | (Optional) |
| TABLE_one_group         | (Optional) |
| TABLE_vip_list          | (Optional) |
| <i>virt-mac</i>         | (Optional) |
| <i>cxt_name</i>         | (Optional) |
| <i>cxt_id</i>           | (Optional) |
| <i>last-solocit-st</i>  | (Optional) |
| <i>last-nei-ad-st</i>   | (Optional) |
| <i>last-rtr-adv-st</i>  | (Optional) |
| <i>nxt-rtr-ad-st</i>    | (Optional) |
| <i>vmac-addr</i>        | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>st-total</i>               | (Optional) |
| <i>rv-total</i>               | (Optional) |
| <i>st-err</i>                 | (Optional) |
| <i>rv-err</i>                 | (Optional) |
| <i>st-int-dwn-drp</i>         | (Optional) |
| <i>rv-int-dwn-drp</i>         | (Optional) |
| <i>st-adj-nt-recov-am</i>     | (Optional) |
| <i>rv-adj-nt-recov-am</i>     | (Optional) |
| <i>st-pkt-allow-inv-ttl</i>   | (Optional) |
| <i>rv-pkt-allow-inv-ttl</i>   | (Optional) |
| <i>st-pkt-drp-src-mac-own</i> | (Optional) |
| <i>rv-pkt-drp-src-mac-own</i> | (Optional) |
| <i>st-pkt-drp-tgt-not-own</i> | (Optional) |
| <i>rv-pkt-drp-tgt-not-own</i> | (Optional) |
| <i>st-pkt-drp-src-not-own</i> | (Optional) |
| <i>rv-pkt-drp-src-not-own</i> | (Optional) |
| <i>st-dest-unreach</i>        | (Optional) |
| <i>rv-dest-unreach</i>        | (Optional) |
| <i>st-admin-prohi</i>         | (Optional) |
| <i>rv-admin-prohi</i>         | (Optional) |
| <i>st-time-exceed</i>         | (Optional) |
| <i>rv-time-exceed</i>         | (Optional) |
| <i>st-patr-pbm</i>            | (Optional) |
| <i>rv-patr-pbm</i>            | (Optional) |
| <i>st-echo-req</i>            | (Optional) |
| <i>rv-echo-req</i>            | (Optional) |
| <i>st-echo-reply</i>          | (Optional) |
| <i>rv-echo-reply</i>          | (Optional) |
| <i>st-dup-ra</i>              | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>rv-dup-ra</i>      | (Optional) |
| <i>st-redirect</i>    | (Optional) |
| <i>rv-redirect</i>    | (Optional) |
| <i>st-pkt-too-big</i> | (Optional) |
| <i>rv-pkt-too-big</i> | (Optional) |
| <i>st-rtr-adver</i>   | (Optional) |
| <i>rv-rtr-adver</i>   | (Optional) |
| <i>st-rtr-solicit</i> | (Optional) |
| <i>rv-rtr-solicit</i> | (Optional) |
| <i>st-nei-adver</i>   | (Optional) |
| <i>rv-nei-adver</i>   | (Optional) |
| <i>st-nei-solicit</i> | (Optional) |
| <i>rv-nei-solicit</i> | (Optional) |

**Command Mode**

- /exec

## show ipv6 icmp vpc-statistics

```
show ipv6 icmp vpc-statistics [ __readonly__ [ { TABLE_icmpv6_vpc_stats [ <icmpv6-pro-drp-pull-disable>
] [ <icmpv6-pro-drp-push-msg-disable> ] [ <icmpv6-pro-ign-snd-pull-disabe> ] [
<icmpv6-ign-snd-push-disable> ] [ <icmpv6-drp-im-fail> ] [ <icmpv6-drp-mcecm-fail> ] [
<icmpv6-drp-invalid-pc-iod> ] [ <icmpv6-drp-pt-lookup-fail> ] [ <icmpv6-drp-resp-fail-no-mct> ] [
<icmpv6-drp-resp-fail> ] [ <icmpv6-vpc-id-ifindx-sending-pushmsg> ] [ <icmpv6-vpc-id-proc-cfs-payload>
] [ <icmpv6-resp-sent> ] [ <icmpv6-resp-recvd> ] [ <icmpv6-resp-recv-err> ] [ <icmpv6-rcvd-msg> ] [
<icmpv6-send-fail> ] [ <icmpv6-cfs-rel-dlvry-fail> ] [ <icmpv6-cfs-rel-dnvry-suc> ] [ <icmpv6-drp-pt-add-fail>
] [ <icmpv6-drp-no-mem> ] [ <icmpv6-drp-tmr-cre-fail> ] [ <icmpv6-drp-add-adj-fail> ] [
<icmpv6-off-drp-pt-lookup-fail> ] [ <icmpv6-dont-drp-vlan-mismat> ] [ <icmpv6-drp-svi-invalid> ] [
<icmpv6-dont-drop-sv-down> ] [ <icmpv6-drp-mct-down> ] [ <icmpv6-drp-ctxt-invalid> ] [
<icmpv6-drp-vrf-invalid> ] [ <icmpv6-drp-l3addr-invalid> ] [ <icmpv6-drp-l3addr-sanity-fail> ] [
<icmpv6-drp-mac-sanity-fail> ] [ <icmpv6-own-rtr-mac> ] [ <icmpv6-drp-own-ipv6addr> ] [
<icmpv6-drp-own-vipv6add> ] [ <icmpv6-drp-adj-fail> ] [ <icmpv6-drp-subnet-mismatch> ] [
<icmpv6-drp-adj-exist> ] [ <icmpv6-dont-drp-ip-not-enable> ] [ <icmpv6-drp-total-cnt> ] [
<icmpv6-dont-drop-total-cnt> ] [ <icmpv6-add-adj> ] [ <icmpv6-del-adj> ] [ <icmpv6-adj-already-exist> ] [
<icmpv6-vpc-id-periodic-sync> ] [ <icmpv6-vpc-id-cfs-payload-periodic-sync> ] } ] ]
```

### Syntax Description

|   |   |
|---|---|
| show  | Show running system information   |
| ipv6  | Display IPv6 information  |
| icmp  | Display ICMPv6 information  |
| vpc-statistics                              | Show vPC global statistics  |
| __readonly__                                | (Optional)  |
| TABLE_icmpv6_vpc_stats                      | (Optional) icmpv6 Vpc statistics  |
| <i>icmpv6-pro-drp-pull-disable</i>          | (Optional) icmpv6 protocol drop pull disable                            |
| <i>icmpv6-pro-drp-push-msg-disable</i>      | (Optional) icmpv6 protocol drop push message disable                    |
| <i>icmpv6-pro-ign-snd-pull-disabe</i>       | (Optional) icmpv6 protocol ignore send pull disable                     |
| <i>icmpv6-ign-snd-push-disable</i>          | (Optional) icmpv6 ignore send push disable                              |
| <i>icmpv6-drp-im-fail</i>                   | (Optional) icmpv6 drop im fail  |
| <i>icmpv6-drp-mcecm-fail</i>                | (Optional) MCECM api failed while processing CFS payload                |
| <i>icmpv6-drp-invalid-pc-iod</i>            | (Optional) Invalid MCT port-channel iod while processing CFS payload    |
| <i>icmpv6-drp-pt-lookup-fail</i>            | (Optional) PT lookup failed while processing CFS payload                |
| <i>icmpv6-drp-resp-fail-no-mct</i>          | (Optional) invalid MCT iod while processing CFS payload                 |
| <i>icmpv6-drp-resp-fail</i>                 | (Optional) response failed while processing CFS payload                 |
| <i>icmpv6-vpc-id-ifindx-sending-pushmsg</i> | (Optional) Unable to retrieve VPC id ifindex while sending push message |

|  |  |
|--|--|
| <i>icmpv6-vpc-id-proc-cfs-payload</i>          | (Optional) Unable to retrieve ifindex from vpc id  |
| <i>icmpv6-vpc-id-periodic-sync</i>             | (Optional) unable to retrieve vpc id ifindex for periodic sync                                   |
| <i>icmpv6-vpc-id-cfs-payload-periodic-sync</i> | (Optional) unable to retrieve ifindex from vpc id while processing cfs payload for periodic sync |
| <i>icmpv6-resp-sent</i>                        | (Optional) Response sent via CFSOE   |
| <i>icmpv6-resp-rcvd</i>                        | (Optional) Response received via CFSOE   |
| <i>icmpv6-resp-rcv-err</i>                     | (Optional) Response received via CFSOE with errors   |
| <i>icmpv6-rcvd-msg</i>                         | (Optional) Received message via CFSOE  |
| <i>icmpv6-send-fail</i>                        | (Optional) Send message failed via CFSOE   |
| <i>icmpv6-cfs-rel-dlvry-fail</i>               | (Optional) MCECM send api failed via CFSOE   |
| <i>icmpv6-cfs-rel-dmrvy-suc</i>                | (Optional) Send message succeeded via CFSOE  |
| <i>icmpv6-drp-pt-add-fail</i>                  | (Optional) PT add failed while processing offlist database                                       |
| <i>icmpv6-drp-no-mem</i>                       | (Optional) Memory alloc failed while processing offlist database                                 |
| <i>icmpv6-drp-tmr-cre-fail</i>                 | (Optional) Timer create failed while processing offlist database                                 |
| <i>icmpv6-drp-add-adj-fail</i>                 | (Optional) Adjacency addition failed while processing offlist database                           |
| <i>icmpv6-off-drp-pt-lookup-fail</i>           | (Optional) PT lookup failed while processing offlist database                                    |
| <i>icmpv6-dont-drp-vlan-mismat</i>             | (Optional) VLAN mismatch while processing offlist database                                       |
| <i>icmpv6-drp-svi-invalid</i>                  | (Optional) SVI is invalid while processing offlist database                                      |
| <i>icmpv6-dont-drop-sv-down</i>                | (Optional) SVI is down while processing offlist database   |
| <i>icmpv6-drp-mct-down</i>                     | (Optional) MCT is down while processing offlist database   |
| <i>icmpv6-drp-ctxt-invalid</i>                 | (Optional) Ctxt_type is invalid while processing offlist database                                |
| <i>icmpv6-drp-vrf-invalid</i>                  | (Optional) VRF is invalid while processing offlist database                                      |
| <i>icmpv6-drp-l3addr-invalid</i>               | (Optional) IP address is invalid while processing offlist database                               |
| <i>icmpv6-drp-l3addr-sanity-fail</i>           | (Optional) IP address sanity failed while processing offlist database                            |
| <i>icmpv6-drp-mac-sanity-fail</i>              | (Optional) MAC address sanity failed while processing offlist database                           |
| <i>icmpv6-own-rtr-mac</i>                      | (Optional) Our own router mac while processing offlist database                                  |
| <i>icmpv6-drp-own-ipv6addr</i>                 | (Optional) Our own ip address while processing offlist database                                  |
| <i>icmpv6-drp-own-vipv6add</i>                 | (Optional) Our own virtual ip address while processing offlist database                          |
| <i>icmpv6-drp-adj-fail</i>                     | (Optional) Create adjacency failed while processing offlist database                             |

|                                      |   |
|--------------------------------------|---|
| <i>icmpv6-drp-subnet-mismatch</i>    | (Optional) Subnet mismatch while processing offlist database                    |
| <i>icmpv6-drp-adj-exist</i>          | (Optional) Entry exists while processing offlist database                       |
| <i>icmpv6-dont-drp-ip-not-enable</i> | (Optional) IPv6 not enabled on interface while processing offlist database      |
| <i>icmpv6-drp-total-cnt</i>          | (Optional) Total drop count while processing offlist database                   |
| <i>icmpv6-dont-drop-total-cnt</i>    | (Optional) Total don't drop count while processing offlist database             |
| <i>icmpv6-add-adj</i>                | (Optional) Total adjacency additions in offlist database                        |
| <i>icmpv6-del-adj</i>                | (Optional) Total adjacency deletions in offlist database                        |
| <i>icmpv6-adj-already-exist</i>      | (Optional) Total adjacencies ignored as they already exists in offlist database |

**Command Mode**

- /exec

## show ipv6 interface

```
show ipv6 interface { [ brief [ include-secondary ] ] [ <interface> | <ipv6-addr> ] [ detail ] } [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ [ TABLE_intf <vrf-name-out> <intf-name> [ <iod> ] [
<proto-state> ] [ <link-state> ] [ <admin-state> ] [ TABLE_addr <addr> ] [ <prefix> ] [ { TABLE_sec_addr
[ <sec-prefix> } ] ] [ <linklocal-addr> ] [ <linklocal-configured> ] [ { TABLE_vaddr [ <v-addr> } ] ] [
<ipv6-disabled> ] [ <mrouting-enabled> ] [ <report-linklocal-enabled> ] [ <forwarding-enabled> ] [
<mgroup-locally-joined> ] [ { TABLE_maddr <m-addr> [ <m-addr-refcnt> } ] ] [ <mcast-sgentries-joined>
] [ { TABLE_sg [ <sg-saddr> ] [ <sg-maddr> ] [ <sg-refcnt> } ] ] [ <mtu> ] [ <global-in-pcl-configured> ] [
<global-in-pcl-name> ] [ <global-in-pcl-pending> ] [ <global-out-pcl-configured> ] [ <global-out-pcl-name>
] [ <global-out-pcl-pending> ] [ <in-pcl-configured> ] [ <in-pcl-name> ] [ <in-pcl-pending> ] [
<out-pcl-configured> ] [ <out-pcl-name> ] [ <out-pcl-pending> ] [ <urpf-mode> ] [ <ipv6-lstype> ] [
<stats-last-reset> ] [ <acl-in> ] [ <acl-out> ] [ <upkt-fwd> ] [ <upkt-orig> ] [ <upkt-consumed> ] [ <ubyte-fwd>
] [ <ubyte-orig> ] [ <ubyte-consumed> ] [ <mpkt-fwd> ] [ <mpkt-orig> ] [ <mpkt-consumed> ] [ <mbyte-fwd>
] [ <mbyte-orig> ] [ <mbyte-consumed> ] [ <upkt-in-acc> ] [ <upkt-in-rej> ] [ <ubyte-in-acc> ] [ <ubyte-in-rej>
] [ <mpkt-in-acc> ] [ <mpkt-in-rej> ] [ <mbyte-in-acc> ] [ <mbyte-in-rej> ] [ <upkt-out-acc> ] [ <upkt-out-rej>
] [ <ubyte-out-acc> ] [ <ubyte-out-rej> ] [ <mpkt-out-acc> ] [ <mpkt-out-rej> ] [ <mbyte-out-acc> ] [
<mbyte-out-rej> ] [ <hw-upkt-sent> ] [ <hw-upkt-recv> ] [ <hw-ubyte-sent> ] [ <hw-ubyte-recv> ] [
<hw-mpkt-sent> ] [ <hw-mpkt-recv> ] [ <hw-mbyte-sent> ] [ <hw-mbyte-recv> ] [ <hw-upkt-drop> ] [
<hw-ubyte-drop> ] [ <hw-mpkt-drop> ] [ <hw-mbyte-drop> ] [ <hw-mpkt-rpdrop> ] [ <hw-mbyte-rpdrop>
] [ <hw-mpkt-dfdrop> ] [ <hw-mbyte-dfdrop> ] [ <unspecified-src> ] [ <total-pkt-recv-tent-addr> ] [
<total-pkts-recv-invalid-addr-state> ] [ <total-pkt-recv-dup-state> ] [ <anycast-pkt-arrived-tcp> ] [
<deliver-intf-down> ] [ <nd-frag-drop> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                             |
| ipv6                  | Display IPv6 information                                    |
| interface             | Display IPv6 related interface information                  |
| brief                 | (Optional) Display summary of IPv6 status and configuration |
| include-secondary     | (Optional) Display summary of all IPv6 addresses            |
| <i>interface</i>      | (Optional) Interface name to display                        |
| detail                | (Optional) Display detailed IPv6 interface information      |
| vrf                   | (Optional) Display per-VRF information                      |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                   |
| all                   | (Optional) Display all VRFs                                 |
| __readonly__          | (Optional)  |
| TABLE_addr            | (Optional)  |
| <i>vrf-name-out</i>   | (Optional)  |

|                                  |            |
|----------------------------------|------------|
| TABLE_intf                       | (Optional) |
| <i>intf-name</i>                 | (Optional) |
| <i>proto-state</i>               | (Optional) |
| <i>link-state</i>                | (Optional) |
| <i>admin-state</i>               | (Optional) |
| <i>iod</i>                       | (Optional) |
| <i>addr</i>                      | (Optional) |
| <i>prefix</i>                    | (Optional) |
| TABLE_sec_addr                   | (Optional) |
| <i>sec-prefix</i>                | (Optional) |
| <i>linklocal-configured</i>      | (Optional) |
| TABLE_vaddr                      | (Optional) |
| <i>ipv6-disabled</i>             | (Optional) |
| <i>mrouting-enabled</i>          | (Optional) |
| <i>report-linklocal-enabled</i>  | (Optional) |
| <i>forwarding-enabled</i>        | (Optional) |
| <i>mgroup-locally-joined</i>     | (Optional) |
| TABLE_maddr                      | (Optional) |
| <i>m-addr-refcnt</i>             | (Optional) |
| <i>mcast-sgentries-joined</i>    | (Optional) |
| TABLE_sg                         | (Optional) |
| <i>sg-refcnt</i>                 | (Optional) |
| <i>mtu</i>                       | (Optional) |
| <i>global-in-pcl-configured</i>  | (Optional) |
| <i>global-in-pcl-name</i>        | (Optional) |
| <i>global-in-pcl-pending</i>     | (Optional) |
| <i>global-out-pcl-configured</i> | (Optional) |
| <i>global-out-pcl-name</i>       | (Optional) |
| <i>global-out-pcl-pending</i>    | (Optional) |



|                           |            |
|---------------------------|------------|
| <i>in-pcl-configured</i>  | (Optional) |
| <i>in-pcl-name</i>        | (Optional) |
| <i>in-pcl-pending</i>     | (Optional) |
| <i>out-pcl-configured</i> | (Optional) |
| <i>out-pcl-name</i>       | (Optional) |
| <i>out-pcl-pending</i>    | (Optional) |
| <i>urpf-mode</i>          | (Optional) |
| <i>ipv6-lstype</i>        | (Optional) |
| <i>stats-last-reset</i>   | (Optional) |
| <i>acl-in</i>             | (Optional) |
| <i>acl-out</i>            | (Optional) |
| <i>upkt-fwd</i>           | (Optional) |
| <i>upkt-orig</i>          | (Optional) |
| <i>upkt-consumed</i>      | (Optional) |
| <i>ubyte-fwd</i>          | (Optional) |
| <i>ubyte-orig</i>         | (Optional) |
| <i>ubyte-consumed</i>     | (Optional) |
| <i>mpkt-fwd</i>           | (Optional) |
| <i>mpkt-orig</i>          | (Optional) |
| <i>mpkt-consumed</i>      | (Optional) |
| <i>mbyte-fwd</i>          | (Optional) |
| <i>mbyte-orig</i>         | (Optional) |
| <i>mbyte-consumed</i>     | (Optional) |
| <i>upkt-in-acc</i>        | (Optional) |
| <i>upkt-in-rej</i>        | (Optional) |
| <i>ubyte-in-acc</i>       | (Optional) |
| <i>ubyte-in-rej</i>       | (Optional) |
| <i>mpkt-in-acc</i>        | (Optional) |
| <i>mpkt-in-rej</i>        | (Optional) |

|   |            |
|---|------------|
| <i>mbyte-in-acc</i>                       | (Optional) |
| <i>mbyte-in-rej</i>                       | (Optional) |
| <i>upkt-out-acc</i>                       | (Optional) |
| <i>upkt-out-rej</i>                       | (Optional) |
| <i>ubyte-out-acc</i>                      | (Optional) |
| <i>ubyte-out-rej</i>                      | (Optional) |
| <i>mpkt-out-acc</i>                       | (Optional) |
| <i>mpkt-out-rej</i>                       | (Optional) |
| <i>mbyte-out-acc</i>                      | (Optional) |
| <i>mbyte-out-rej</i>                      | (Optional) |
| <i>hw-upkt-sent</i>                       | (Optional) |
| <i>hw-upkt-recv</i>                       | (Optional) |
| <i>hw-ubyte-sent</i>                      | (Optional) |
| <i>hw-ubyte-recv</i>                      | (Optional) |
| <i>hw-mpkt-sent</i>                       | (Optional) |
| <i>hw-mpkt-recv</i>                       | (Optional) |
| <i>hw-mbyte-sent</i>                      | (Optional) |
| <i>hw-mbyte-recv</i>                      | (Optional) |
| <i>hw-upkt-drop</i>                       | (Optional) |
| <i>hw-ubyte-drop</i>                      | (Optional) |
| <i>hw-mpkt-drop</i>                       | (Optional) |
| <i>hw-mbyte-drop</i>                      | (Optional) |
| <i>hw-mpkt-rpdrop</i>                     | (Optional) |
| <i>hw-mbyte-rpdrop</i>                    | (Optional) |
| <i>hw-mpkt-dfdrop</i>                     | (Optional) |
| <i>hw-mbyte-dfdrop</i>                    | (Optional) |
| <i>unspecified-src</i>                    | (Optional) |
| <i>total-pkt-recv-tent-addr</i>           | (Optional) |
| <i>total-pkts-recv-invalid-addr-state</i> | (Optional) |

|                                 |            |
|---------------------------------|------------|
| <i>total-pkt-recv-dup-state</i> | (Optional) |
| <i>anycast-pkt-arrived-tcp</i>  | (Optional) |
| <i>deliver-intf-down</i>        | (Optional) |
| <i>nd-frag-drop</i>             | (Optional) |

**Command Mode**

- /exec

## show ipv6 lisp data-cache

show ipv6 lisp data-cache [ <eid> ] [ vrf { <vrf-name> | <vrf-known-name> } ]

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| ipv6                  | Display IPv6 information                            |
| lisp                  | LISP show commands                                  |
| data-cache            | Display EID-to-RLOC data cache mapping in this ITR  |
| <i>eid</i>            | (Optional) Display mapping for IPv6 destination EID |
| vrf                   | (Optional) Display per-VRF information              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |

### Command Mode

- /exec

# show ipv6 local policy

```
show ipv6 local policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_pbr [
<interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| local                 | IPv6 local options                          |
| policy                | Policy routing                              |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_pbr             | (Optional)                                  |
| <i>interface</i>      | (Optional)                                  |
| <i>rmap</i>           | (Optional)                                  |
| <i>status</i>         | (Optional)                                  |
| <i>vrf_name</i>       | (Optional)                                  |

## Command Mode

- /exec

## show ipv6 mld global traffic

```
show ipv6 [ icmp ] mld global traffic [ __readonly__ [ { TABLE_icmpv6_mld_stat <st-v1-queries>
<rv-v1-queries> <st-v2-queries> <rv-v2-queries> <st-v1-reports> <rv-v1-reports> <st-v2-reports>
<rv-v2-reports> <st-v1-leaves> <rv-v1-leaves> } ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| ipv6                  | Display IPv6 information                             |
| icmp                  | (Optional) Display ICMPv6 information                |
| mld                   | Display Multicast Listener Discovery information     |
| global                | Show ICMPv6 global variables                         |
| traffic               | Display ICMPv6 software processed traffic statistics |
| __readonly__          | (Optional)   |
| TABLE_icmpv6_mld_stat | (Optional) ICMPv6 MLD Statistics                     |
| <i>st-v1-queries</i>  | (Optional) V1 Queries sent                           |
| <i>rv-v1-queries</i>  | (Optional) V1 Queries received                       |
| <i>st-v2-queries</i>  | (Optional) V2 Queries sent                           |
| <i>rv-v2-queries</i>  | (Optional) V2 Queries received                       |
| <i>st-v1-reports</i>  | (Optional) V1 Reports sent                           |
| <i>rv-v1-reports</i>  | (Optional) V1 Reports received                       |
| <i>st-v2-reports</i>  | (Optional) V2 Reports sent                           |
| <i>rv-v2-reports</i>  | (Optional) V2 Reports received                       |
| <i>st-v1-leaves</i>   | (Optional) V1 Leaves sent                            |
| <i>rv-v1-leaves</i>   | (Optional) V1 Leaves received                        |

### Command Mode

- /exec

## show ipv6 mld groups

```
show ipv6 [ icmp ] mld groups [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ <interface> ] [
summary ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf [ <if-name> ] [
<vrfname> ] [ <entry-count> ] [ <group-addr> ] [ <sourceaddress> ] [ TABLE_group [ <group-addr> ] [
<group-type> ] [ <if-name> ] [ <uptime> ] [ <expires> ] [ <reporter> ] [ TABLE_source [ <source-addr> ] [
<group-type> ] [ <translate> ] [ <if-name> ] [ <uptime> ] [ <expires> ] [ <reporter> ] ] ] [ <vrf-entxt> ] [
<g-count> ] [ <sg-count> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| ipv6                  | Display IPv6 information                              |
| icmp                  | (Optional) Display ICMPv6 information                 |
| mld                   | Display Multicast Listener Discovery information      |
| groups                | Display MLD attached group membership information     |
| vrf                   | (Optional) Display per-VRF information                |
| <i>vrf-name</i>       | (Optional) VRF name                                   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                             |
| all                   | (Optional) Display information for all VRFs           |
| <i>interface</i>      | (Optional) Display group membership on interface name |
| summary               | (Optional) Display group summary                      |
| __readonly__          | (Optional)  |
| TABLE_vrf             | (Optional)  |
| <i>vrfname</i>        | (Optional)  |
| <i>if-name</i>        | (Optional)  |
| <i>group-addr</i>     | (Optional)  |
| <i>entry-count</i>    | (Optional)  |
| <i>sourceaddress</i>  | (Optional)  |
| TABLE_group           | (Optional)  |
| <i>group-addr</i>     | (Optional)  |
| <i>group-type</i>     | (Optional)  |
| <i>if-name</i>        | (Optional)  |

|                    |            |
|--------------------|------------|
| <i>uptime</i>      | (Optional) |
| <i>expires</i>     | (Optional) |
| <i>reporter</i>    | (Optional) |
| TABLE_source       | (Optional) |
| <i>source-addr</i> | (Optional) |
| <i>group-type</i>  | (Optional) |
| <i>translate</i>   | (Optional) |
| <i>if-name</i>     | (Optional) |
| <i>uptime</i>      | (Optional) |
| <i>expires</i>     | (Optional) |
| <i>reporter</i>    | (Optional) |
| <i>vrf-cntxt</i>   | (Optional) |
| <i>g-count</i>     | (Optional) |
| <i>sg-count</i>    | (Optional) |

**Command Mode**

- /exec



# show ipv6 mld interface

```
show ipv6 [ icmp ] mld interface [ <interface> ] [ brief ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> |
all } ] [ __readonly__ TABLE_vrf <vrf> [ <entry-count> ] [ [ TABLE_brief [ <if-name> ] [ <addr> ] [
<querier> ] [ <mc> ] [ <ver> ] ] [ TABLE_if <if-name> [ <if-status> ] [ <ip-sum> ] [ <querier> ] [ <q-ver>
] [ <next-query> ] [ <expires> ] [ <mc> ] [ <ver> ] [ <host-ver> ] [ <qf> ] [ <cqi> ] [ <mrt> ] [ <cmrt> ] [
<sqi> ] [ <csqi> ] [ <sqc> ] [ <lmrt> ] [ <lmqc> ] [ <gt> ] [ <cgt> ] [ <qt> ] [ <cqt> ] [ <uri> ] [ <rv> ] [
<crv> ] [ <rll> ] [ <rc> ] [ <il> ] [ <report-policy> ] [ <join-group-map> ] [ <static-group-map> ] [ <v2qs> ]
[ <v2qr> ] [ <v2rs> ] [ <v2rr> ] [ <v2ls> ] [ <v2lr> ] [ <v3qs> ] [ <v3qr> ] [ <v3rs> ] [ <v3rr> ] [ <v2gqdest>
] [ <v3gqdest> ] [ <cse> ] [ <ple> ] [ <lsip> ] [ <scf> ] [ <qnq> ] [ <rvm> ] [ <qvm> ] [ <uit> ] [ <v2gdam>
] [ <v3dai> ] [ <ra> ] ] ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                   |
| ipv6                  | Display IPv6 information  |
| icmp                  | (Optional) Display ICMPv6 information                             |
| mld                   | Display Multicast Listener Discovery information                  |
| interface             | Display ICMPv6 related interface information                      |
| detail                | (Optional) Display ICMPv6 related interface information in detail |
| brief                 | (Optional) Display ICMPv6 related interface information in brief  |
| vrf                   | (Optional) Display per-VRF information                            |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| all                   | (Optional) Display information for all VRFs                       |
| <i>interface</i>      | (Optional) Interface name to show                                 |
| <i>__readonly__</i>   | (Optional)  |
| TABLE_vrf             | (Optional)  |
| <i>vrf</i>            | (Optional)  |
| <i>entry-count</i>    | (Optional)  |
| TABLE_brief           | (Optional)  |
| <i>if-name</i>        | (Optional)  |
| <i>querier</i>        | (Optional)  |
| <i>mc</i>             | (Optional)  |

|                   |            |
|-------------------|------------|
| <i>ver</i>        | (Optional) |
| TABLE_if          | (Optional) |
| <i>if-name</i>    | (Optional) |
| <i>if-status</i>  | (Optional) |
| <i>ip-sum</i>     | (Optional) |
| <i>addr</i>       | (Optional) |
| <i>querier</i>    | (Optional) |
| <i>q-ver</i>      | (Optional) |
| <i>next-query</i> | (Optional) |
| <i>expires</i>    | (Optional) |
| <i>mc</i>         | (Optional) |
| <i>ver</i>        | (Optional) |
| <i>host-ver</i>   | (Optional) |
| <i>qi</i>         | (Optional) |
| <i>cqi</i>        | (Optional) |
| <i>mrt</i>        | (Optional) |
| <i>cmrt</i>       | (Optional) |
| <i>sqi</i>        | (Optional) |
| <i>csqi</i>       | (Optional) |
| <i>sqc</i>        | (Optional) |
| <i>lmmrt</i>      | (Optional) |
| <i>lmqc</i>       | (Optional) |
| <i>gt</i>         | (Optional) |
| <i>cgt</i>        | (Optional) |
| <i>qt</i>         | (Optional) |
| <i>cqt</i>        | (Optional) |
| <i>uri</i>        | (Optional) |
| <i>rv</i>         | (Optional) |
| <i>crv</i>        | (Optional) |

|                         |            |
|-------------------------|------------|
| <i>rll</i>              | (Optional) |
| <i>rc</i>               | (Optional) |
| <i>il</i>               | (Optional) |
| <i>report-policy</i>    | (Optional) |
| <i>v2qs</i>             | (Optional) |
| <i>v2qr</i>             | (Optional) |
| <i>v2rs</i>             | (Optional) |
| <i>v2rr</i>             | (Optional) |
| <i>v2ls</i>             | (Optional) |
| <i>v2lr</i>             | (Optional) |
| <i>v3qs</i>             | (Optional) |
| <i>v3qr</i>             | (Optional) |
| <i>v3rs</i>             | (Optional) |
| <i>v3rr</i>             | (Optional) |
| <i>v2ggdest</i>         | (Optional) |
| <i>v3ggdest</i>         | (Optional) |
| <i>cse</i>              | (Optional) |
| <i>ple</i>              | (Optional) |
| <i>lsip</i>             | (Optional) |
| <i>scf</i>              | (Optional) |
| <i>qnq</i>              | (Optional) |
| <i>rvm</i>              | (Optional) |
| <i>qvm</i>              | (Optional) |
| <i>uit</i>              | (Optional) |
| <i>v2gdam</i>           | (Optional) |
| <i>v3dai</i>            | (Optional) |
| <i>ra</i>               | (Optional) |
| <i>static-group-map</i> | (Optional) |
| <i>join-group-map</i>   | (Optional) |

**Command Mode**

- /exec



|                   |            |
|-------------------|------------|
| <i>host-proxy</i> | (Optional) |
|-------------------|------------|

**Command Mode**

- /exec

## show ipv6 mld snooping

```
show ipv6 mld snooping [ { vlan <vlan> | bridge-domain <bdid> } ] [ __readonly__ [ <vdc> ] [ <enabled> ]
[ <omf> ] [ <grepsup> ] [ <gv2repsup> ] [ <glinklocalgrpsup> ] { TABLE_vlan <vlan-id> [ <description> ]
[ <snoop-on> ] [ <qv> ] [ <qv> ] [ <qi> ] [ <qlmqi> ] [ <rv> ] [ <sq> ] [ <sqr> ] [ <eht> ] [ <fl> ] [ <repsup>
] [ <v2repsup> ] [ <vlinklocalgrpsup> ] [ <rpc> ] [ <gc> ] [ TABLE_active_ports [ <actvports> ] ] [ <lkupmode>
] [ <omf_enabled> ] [ <reportfloodenable> ] [ <reportfloodall> ] [ TABLE_intf <if-name> ] [
<leavegroupaddress> ] } ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                             |
| ipv6                    | Display IPv6 information                                    |
| mld                     | Display Multicast Listener Discovery information            |
| snooping                | MLD Snooping information                                    |
| vlan                    | (Optional) Display VLAN MLD snooping membership information |
| <i>vlan</i>             | (Optional) Specify VLAN                                     |
| bridge-domain           | (Optional) Display BD MLD snooping membership information   |
| <i>bdid</i>             | (Optional) Specify BD                                       |
| <i>__readonly__</i>     | (Optional)  |
| <i>vdc</i>              | (Optional)  |
| <i>enabled</i>          | (Optional)  |
| <i>omf</i>              | (Optional)  |
| <i>grepsup</i>          | (Optional)  |
| <i>gv2repsup</i>        | (Optional)  |
| <i>glinklocalgrpsup</i> | (Optional)  |
| TABLE_vlan              | (Optional)  |
| <i>vlan-id</i>          | (Optional)  |
| <i>description</i>      | (Optional) description, if any                              |
| <i>snoop-on</i>         | (Optional)  |
| <i>qv</i>               | (Optional)  |
| <i>qi</i>               | (Optional)  |
| <i>qlmqi</i>            | (Optional)  |

|                          |            |
|--------------------------|------------|
| <i>rv</i>                | (Optional) |
| <i>sq</i>                | (Optional) |
| <i>sqr</i>               | (Optional) |
| <i>eht</i>               | (Optional) |
| <i>fl</i>                | (Optional) |
| <i>repsup</i>            | (Optional) |
| <i>v2repsup</i>          | (Optional) |
| <i>vlinklocalgrpsup</i>  | (Optional) |
| <i>rpc</i>               | (Optional) |
| <i>gc</i>                | (Optional) |
| TABLE_active_ports       | (Optional) |
| <i>actvports</i>         | (Optional) |
| <i>lkupmode</i>          | (Optional) |
| <i>omf_enabled</i>       | (Optional) |
| <i>reportfloodenable</i> | (Optional) |
| <i>reportfloodall</i>    | (Optional) |
| TABLE_intf               | (Optional) |
| <i>if-name</i>           | (Optional) |
| <i>leavegroupaddress</i> | (Optional) |

**Command Mode**

- /exec





|                           |            |
|---------------------------|------------|
| <i>expires</i>            | (Optional) |
| <i>version</i>            | (Optional) |
| <i>num_of_reports</i>     | (Optional) |
| <i>cfs-flag</i>           | (Optional) |
| <i>native-flag</i>        | (Optional) |
| <i>delete-pending</i>     | (Optional) |
| <i>cfs-update-pending</i> | (Optional) |

**Command Mode**

- /exec

## show ipv6 mld snooping filter details

```
show ipv6 mld snooping filter [ vlan <vlan_id> ] details [ __readonly__ { TABLE_vlanid <vlan-id>
<access-group> <group-channels-limit> <mld-min-ver> } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                  |
| ipv6                        | Display IPv6 information                         |
| mld                         | Display Multicast Listener Discovery information |
| snooping                    | MLD Snooping information                         |
| filter                      | Shows filter policy configuration                |
| vlan                        | (Optional) Only for the specified VLAN           |
| <i>vlan_id</i>              | (Optional) VLAN ID                               |
| details                     | Shows different Filter configurations            |
| <i>__readonly__</i>         | (Optional)                                       |
| TABLE_vlanid                | (Optional)                                       |
| <i>vlan-id</i>              | (Optional)                                       |
| <i>access-group</i>         | (Optional)                                       |
| <i>group-channels-limit</i> | (Optional)                                       |
| <i>mld-min-ver</i>          | (Optional)                                       |

### Command Mode

- /exec

## show ipv6 mld snooping groups

```
show ipv6 mld snooping [ otv | remote ] groups [ { <source> [ <group> ] } | { <group> [ <source> ] } ] [ vlan
<vlan> | bridge-domain <bdid> ] [ detail ] [ summary ] [ __readonly__ [ TABLE_vlan [ <vlan-id> ] [ <rports>
] [ <rtrPortFlag> ] [ TABLE_port <if-name> ] [ TABLE_rtrports <rport-if-name> ] [ <raddr> ] [ TABLE_source
<source> ] [ TABLE_group <addr> [ <g-mfdm> ] [ <ver> ] [ <old-host> ] [ <raddr> ] [ <static> ] [ <dynamic>
] [ TABLE_static_ports <static-if-name> ] [ TABLE_v2_ports <v2-if-name> [ <uptime> ] [ <expires> ] [
<gq-missed> ] ] [ TABLE_star_g_ports <star-g-if-name> [ <uptime> ] [ <expires> ] ] [ <g-vpc> ] [ <rsf> ] [
<js> ] [ TABLE_source <source> [ <srsf> ] [ <s-mfdm> ] [ <src-static> ] [ <src-dynamic> ] [
TABLE_src_static_ports <src-static-if-name> ] [ TABLE_src_dynamic [ <oifs> ] <dyn-if-name> [ <src-uptime>
] [ <src-expires> ] ] [ <s-vpc> ] ] ] [ <snoop-enabled> ] [ <omf-enabled> ] [ <group-count> ] [ <s-g-count>
] [ <total_star_g_count> ] [ <total_sg_count> ] ] ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                             |
| ipv6                 | Display IPv6 information                                    |
| mld                  | Display Multicast Listener Discovery information            |
| snooping             | MLD Snooping information                                    |
| otv                  | (Optional) MLD Snooping OTV information                     |
| remote               | (Optional) MLD Snooping remote information                  |
| groups               | Display snooping information for group address              |
| summary              | (Optional) Display snooping group summary                   |
| vlan                 | (Optional) Display VLAN MLD snooping membership information |
| <i>vlan</i>          | (Optional) Specify VLAN                                     |
| bridge-domain        | (Optional) Display BD MLD snooping membership information   |
| <i>bdid</i>          | (Optional) Specify BD                                       |
| detail               | (Optional) Display detailed information for the group       |
| __readonly__         | (Optional)  |
| TABLE_vlan           | (Optional)  |
| <i>vlan-id</i>       | (Optional)  |
| <i>rports</i>        | (Optional)  |
| <i>rtrPortFlag</i>   | (Optional)  |
| <i>snoop-enabled</i> | (Optional)  |
| <i>omf-enabled</i>   | (Optional)  |

|                           |            |
|---------------------------|------------|
| <i>group-count</i>        | (Optional) |
| <i>s-g-count</i>          | (Optional) |
| <i>total_star_g_count</i> | (Optional) |
| <i>total_sg_count</i>     | (Optional) |
| TABLE_port                | (Optional) |
| <i>if-name</i>            | (Optional) |
| TABLE_rtrports            | (Optional) |
| <i>rport-if-name</i>      | (Optional) |
| <i>raddr</i>              | (Optional) |
| TABLE_group               | (Optional) |
| <i>addr</i>               | (Optional) |
| <i>ver</i>                | (Optional) |
| <i>raddr</i>              | (Optional) |
| TABLE_source              | (Optional) |
| <i>source</i>             | (Optional) |
| <i>rsf</i>                | (Optional) |
| <i>js</i>                 | (Optional) |
| <i>g-mfdm</i>             | (Optional) |
| <i>old-host</i>           | (Optional) |
| <i>g-vpc</i>              | (Optional) |
| <i>static</i>             | (Optional) |
| <i>dynamic</i>            | (Optional) |
| TABLE_static_ports        | (Optional) |
| <i>static-if-name</i>     | (Optional) |
| TABLE_v2_ports            | (Optional) |
| <i>v2-if-name</i>         | (Optional) |
| <i>uptime</i>             | (Optional) |
| <i>expires</i>            | (Optional) |
| <i>gq-missed</i>          | (Optional) |

|                           |            |
|---------------------------|------------|
| TABLE_star_g_ports        | (Optional) |
| <i>star-g-if-name</i>     | (Optional) |
| <i>uptime</i>             | (Optional) |
| <i>expires</i>            | (Optional) |
| TABLE_source              | (Optional) |
| <i>source</i>             | (Optional) |
| <i>srsf</i>               | (Optional) |
| <i>s-mfdm</i>             | (Optional) |
| <i>s-vpc</i>              | (Optional) |
| <i>src-static</i>         | (Optional) |
| <i>src-dynamic</i>        | (Optional) |
| TABLE_src_static_ports    | (Optional) |
| <i>src-static-if-name</i> | (Optional) |
| TABLE_src_dynamic         | (Optional) |
| <i>oifs</i>               | (Optional) |
| <i>dyn-if-name</i>        | (Optional) |
| <i>src-uptime</i>         | (Optional) |
| <i>src-expires</i>        | (Optional) |

**Command Mode**

- /exec

## show ipv6 mld snooping lookup-mode

```
show ipv6 mld snooping lookup-mode [ vlan <vlan> | bridge-domain <bdid> ] [ __readonly__ [ <configured> ] [ <operational> ] [ TABLE_vlan [ <vlan-id> ] [ <lookup> ] ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| ipv6                | Display IPv6 information                         |
| mld                 | Display Multicast Listener Discovery information |
| snooping            | MLD Snooping information                         |
| lookup-mode         | MLD Snooping lkup mode information               |
| vlan                | (Optional) Display VLAN information              |
| <i>vlan</i>         | (Optional) Specify VLAN                          |
| bridge-domain       | (Optional) Display BD information                |
| <i>bdid</i>         | (Optional) Specify BD                            |
| <i>__readonly__</i> | (Optional)                                       |
| <i>configured</i>   | (Optional)                                       |
| <i>operational</i>  | (Optional)                                       |
| TABLE_vlan          | (Optional)                                       |
| <i>vlan-id</i>      | (Optional)                                       |
| <i>lookup</i>       | (Optional)                                       |

### Command Mode

- /exec

## show ipv6 mld snooping mrouter

```
show ipv6 mld snooping mrouter [ otv ] [ vlan <vlan> | bridge-domain <bdid> ] [ detail ] [ __readonly__
TABLE_vlan <vlan-id> TABLE_intf <if-name> <static> <dynamic> <vpc> <fabricpath-core-port>
<co-learned> <user-configured> <learnt-by-peer> <uptime> <expires> <internal> ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                      |
| ipv6                        | Display IPv6 information                             |
| mld                         | Display Multicast Listener Discovery information     |
| snooping                    | MLD Snooping information                             |
| mrouter                     | Display multicast routers detected                   |
| otv                         | (Optional) MLD Snooping OTV information              |
| vlan                        | (Optional) Display VLAN multicast router information |
| <i>vlan</i>                 | (Optional) Specify VLAN                              |
| bridge-domain               | (Optional) Display BD multicast router information   |
| <i>bdid</i>                 | (Optional) Specify BD                                |
| detail                      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| <i>__readonly__</i>         | (Optional)   |
| TABLE_vlan                  | (Optional)   |
| <i>vlan-id</i>              | (Optional)   |
| TABLE_intf                  | (Optional)   |
| <i>if-name</i>              | (Optional)   |
| <i>uptime</i>               | (Optional)   |
| <i>expires</i>              | (Optional)   |
| <i>static</i>               | (Optional)   |
| <i>dynamic</i>              | (Optional)   |
| <i>internal</i>             | (Optional)   |
| <i>vpc</i>                  | (Optional)   |
| <i>fabricpath-core-port</i> | (Optional)   |
| <i>co-learned</i>           | (Optional)   |



|                        |            |
|------------------------|------------|
| <i>user-configured</i> | (Optional) |
| <i>learnt-by-peer</i>  | (Optional) |

**Command Mode**

- /exec

# show ipv6 mld snooping otv vlan brief

show ipv6 mld snooping otv vlan brief [ \_\_readonly\_\_ <vlan-id> ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                  |
| ipv6           | Display IPv6 information                         |
| mld            | Display Multicast Listener Discovery information |
| snooping       | MLD Snooping information                         |
| otv            | MLD Snooping OTV information                     |
| vlan           | Display VLAN/BD information                      |
| brief          | Brief output                                     |
| __readonly__   | (Optional)                                       |
| <i>vlan-id</i> | (Optional)                                       |

## Command Mode

- /exec

# show ipv6 mld snooping pw vlan brief

show ipv6 mld snooping pw vlan brief [ \_\_readonly\_\_ <vlan-id> ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                  |
| ipv6           | Display IPv6 information                         |
| mld            | Display Multicast Listener Discovery information |
| snooping       | MLD Snooping information                         |
| pw             | MLD Snooping PW information                      |
| vlan           | Display VLAN/BD information                      |
| brief          | Brief output                                     |
| __readonly__   | (Optional)                                       |
| <i>vlan-id</i> | (Optional)                                       |

## Command Mode

- /exec

## show ipv6 mld snooping querier

```
show ipv6 mld snooping querier [ vlan <vlan> | bridge-domain <bidid> ] [ detail ] [ __readonly__ [ TABLE_vlan
<vlan-id> <qa> <qv> [ <expires> ] <qiod> <qname> <int> [ <last_member_query_count> ] [
<config_last_member_query_count> ] [ <snooping_version> ] [ <config_qv> ] [ <robust> ] [ <config_robust>
] [ <startup_query_count> ] [ <config_startup_query_count> ] [ <startup_query_interval> ] [
<config_startup_query_interval> ] [ <mbr_query_interval> ] [ <config_mbr_query_interval> ] [
<snooping_query_intvl> ] [ <config_snooping_query_intvl> ] [ <gquery_response_time> ] [
<config_gquery_response_time> ] [ <querier_timeout> ] [ <querier_timeout_flag> ] ] ]
```

### Syntax Description

|                                       |  |
|---------------------------------------|--|
| show                                  | Show running system information                          |
| ipv6                                  | Display IPv6 information                                 |
| mld                                   | Display Multicast Listener Discovery information         |
| snooping                              | MLD Snooping information                                 |
| querier                               | Display snooping querier information                     |
| vlan                                  | (Optional) Display VLAN MLD snooping querier information |
| <i>vlan</i>                           | (Optional) Specify VLAN                                  |
| bridge-domain                         | (Optional) Display BD MLD snooping querier information   |
| <i>bidid</i>                          | (Optional) Specify BD                                    |
| detail                                | (Optional) Display detailed information                  |
| <i>__readonly__</i>                   | (Optional)   |
| TABLE_vlan                            | (Optional)   |
| <i>vlan-id</i>                        | (Optional)   |
| <i>expires</i>                        | (Optional)   |
| <i>qv</i>                             | (Optional)   |
| <i>qiod</i>                           | (Optional)   |
| <i>qname</i>                          | (Optional)   |
| <i>int</i>                            | (Optional)   |
| <i>last_member_query_count</i>        | (Optional)   |
| <i>config_last_member_query_count</i> | (Optional)   |
| <i>snooping_version</i>               | (Optional)   |
| <i>config_qv</i>                      | (Optional)   |

|                                      |            |
|--------------------------------------|------------|
| <i>robust</i>                        | (Optional) |
| <i>config_robust</i>                 | (Optional) |
| <i>startup_query_count</i>           | (Optional) |
| <i>config_startup_query_count</i>    | (Optional) |
| <i>startup_query_interval</i>        | (Optional) |
| <i>config_startup_query_interval</i> | (Optional) |
| <i>mbr_query_interval</i>            | (Optional) |
| <i>config_mbr_query_interval</i>     | (Optional) |
| <i>snooping_query_intvl</i>          | (Optional) |
| <i>config_snooping_query_intvl</i>   | (Optional) |
| <i>gquery_response_time</i>          | (Optional) |
| <i>config_gquery_response_time</i>   | (Optional) |
| <i>querier_timeout</i>               | (Optional) |
| <i>querier_timeout_flag</i>          | (Optional) |

### Command Mode

- /exec

## show ipv6 mld snooping report statistics

```
show ipv6 mld snooping { report-policy | access-group } statistics [ vlan <vlan> ] [ __readonly__ [
TABLE_vlanid { <vlan-id> <rpm-type> <policy-name> } ] [ TABLE_filtervlanid { <filter-vlan-id>
<filter-policy-name> } ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                                    |
| ipv6                      | Display IPv6 information   |
| mld                       | Display Multicast Listener Discovery information                   |
| snooping                  | MLD Snooping information   |
| report-policy             | MLD report policy  |
| access-group              | MLD access-group   |
| statistics                | Policy statistics  |
| vlan                      | (Optional) Display VLAN MLD snooping policy statistics information |
| <i>vlan</i>               | (Optional) Specify VLAN  |
| <i>__readonly__</i>       | (Optional)   |
| TABLE_vlanid              | (Optional)   |
| <i>vlan-id</i>            | (Optional)   |
| <i>rpm-type</i>           | (Optional)   |
| <i>policy-name</i>        | (Optional)   |
| TABLE_filtervlanid        | (Optional)   |
| <i>filter-vlan-id</i>     | (Optional)   |
| <i>filter-policy-name</i> | (Optional)   |

### Command Mode

- /exec

## show ipv6 mld snooping statistics

```
show ipv6 mld snooping statistics [ global | vlan <vlan> | bridge-domain <bdid> ] [ __readonly__ [ <pr> ] [
<inv_pkt> ] [ <inv_pkt_bd> ] [ <inv_pkt_no_fd_vxlan> ] [ <pnv> ] [ <loopbkpkt> ] [ <mrdloopbk> ] [ <pf>
] [ <vpcdrqs> ] [ <vpcdrqr> ] [ <vpcdrqf> ] [ <vpcdrus> ] [ <vpcdrur> ] [ <vpcdruf> ] [ <vpccfsf> ] [
<vpccfsrs> ] [ <vpccfsrr> ] [ <vpccfsrf> ] [ <vpccfsrpf> ] [ <vpccfsurls> ] [ <vpccfsurlr> ] [ <vpccfsurlf> ]
] [ <vpccfsrls> ] [ <vpccfsrlr> ] [ <vpccfsrlf> ] [ <stptcnr> ] [ <imapif> ] [ <mfreqr> ] [ <mfcmps> ] [ <inv_iod>
] [ <mfgcdmps> ] [ <bufsnt> ] [ <bufackr> ] [ <vpemismatch> ] [ { TABLE_vlan [ <vlan-id> ] [ <ut> ] [
<vpr> ] [ <v1rr> ] [ <v2rr> ] [ <v1qr> ] [ <v2qr> ] [ <v2lr> ] [ <phr> ] [ <irr> ] [ <iqr> ] [ <v1rs> ] [ <v2rs>
] [ <v2ls> ] [ <v2lsv1> ] [ <v3gs> ] [ <qo> ] [ <v2ro> ] [ <v2lo> ] [ <v3ro> ] [ <vpsr> ] [ <str> ] [ <vmr> ] [
<upr> ] [ <cps> ] [ <cpr> ] [ <cpe> ] [ <mps> ] [ <mpr> ] [ <mpe> ] [ <repflooded> ] [ <repfwded> ] [ <agd>
] [ <egd> ] [ <lvd> ] [ <qd> ] [ <pmd> ] } ] ] ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                  |
| ipv6                       | Display IPv6 information                         |
| mld                        | Display Multicast Listener Discovery information |
| snooping                   | MLD Snooping information                         |
| statistics                 | Display packet/error counter statistics          |
| global                     | (Optional) Display global statistics             |
| vlan                       | (Optional) Display VLAN statistics               |
| <i>vlan</i>                | (Optional) Specify VLAN                          |
| bridge-domain              | (Optional) Display BD statistics                 |
| <i>bdid</i>                | (Optional) Specify BD                            |
| <u>__readonly__</u>        | (Optional)                                       |
| <i>pr</i>                  | (Optional)                                       |
| <i>inv_pkt</i>             | (Optional)                                       |
| <i>inv_pkt_bd</i>          | (Optional)                                       |
| <i>inv_pkt_no_fd_vxlan</i> | (Optional)                                       |
| <i>pnv</i>                 | (Optional)                                       |
| <i>loopbkpkt</i>           | (Optional)                                       |
| <i>mrdloopbk</i>           | (Optional)                                       |
| <i>pf</i>                  | (Optional)                                       |
| <i>vpcdrqs</i>             | (Optional)                                       |

|                    |            |
|--------------------|------------|
| <i>vpcdrqr</i>     | (Optional) |
| <i>vpcdrqf</i>     | (Optional) |
| <i>vpcdrus</i>     | (Optional) |
| <i>vpcdrur</i>     | (Optional) |
| <i>vpcdruf</i>     | (Optional) |
| <i>vpccfssf</i>    | (Optional) |
| <i>vpccfsrs</i>    | (Optional) |
| <i>vpccfsrr</i>    | (Optional) |
| <i>vpccfsrf</i>    | (Optional) |
| <i>vpccfsrfp</i>   | (Optional) |
| <i>vpccfsurls</i>  | (Optional) |
| <i>vpccfsurlr</i>  | (Optional) |
| <i>vpccfsurlf</i>  | (Optional) |
| <i>vpccfsrls</i>   | (Optional) |
| <i>vpccfsrlr</i>   | (Optional) |
| <i>vpccfsrlf</i>   | (Optional) |
| <i>stptcnr</i>     | (Optional) |
| <i>imapif</i>      | (Optional) |
| <i>mfreqr</i>      | (Optional) |
| <i>mfcmps</i>      | (Optional) |
| <i>inv_iod</i>     | (Optional) |
| <i>mfdgcmps</i>    | (Optional) |
| <i>bufsnt</i>      | (Optional) |
| <i>bufackr</i>     | (Optional) |
| <i>vpcmismatch</i> | (Optional) |
| TABLE_vlan         | (Optional) |
| <i>vlan-id</i>     | (Optional) |
| <i>ut</i>          | (Optional) |
| <i>vpr</i>         | (Optional) |



|                   |            |
|-------------------|------------|
| <i>v1rr</i>       | (Optional) |
| <i>v2rr</i>       | (Optional) |
| <i>v1qr</i>       | (Optional) |
| <i>v2qr</i>       | (Optional) |
| <i>v2lr</i>       | (Optional) |
| <i>phr</i>        | (Optional) |
| <i>irr</i>        | (Optional) |
| <i>iqr</i>        | (Optional) |
| <i>v1rs</i>       | (Optional) |
| <i>v2rs</i>       | (Optional) |
| <i>v2ls</i>       | (Optional) |
| <i>v2lsv1</i>     | (Optional) |
| <i>v3gs</i>       | (Optional) |
| <i>vmr</i>        | (Optional) |
| <i>upr</i>        | (Optional) |
| <i>qo</i>         | (Optional) |
| <i>v2ro</i>       | (Optional) |
| <i>v2lo</i>       | (Optional) |
| <i>v3ro</i>       | (Optional) |
| <i>vpsr</i>       | (Optional) |
| <i>str</i>        | (Optional) |
| <i>cps</i>        | (Optional) |
| <i>cpr</i>        | (Optional) |
| <i>cpe</i>        | (Optional) |
| <i>mps</i>        | (Optional) |
| <i>mpr</i>        | (Optional) |
| <i>mpe</i>        | (Optional) |
| <i>repflooded</i> | (Optional) |
| <i>repfwded</i>   | (Optional) |

|            |            |
|------------|------------|
| <i>agd</i> | (Optional) |
| <i>egd</i> | (Optional) |
| <i>lvd</i> | (Optional) |
| <i>qd</i>  | (Optional) |
| <i>pmd</i> | (Optional) |

**Command Mode**

- /exec

## show ipv6 mroute

```
show ipv6 mroute [[ [ bitfield ] [ detail ] ] | sr | rp | [ summary [ count | software-forwarded | rpf-failed ] ] | {
  [[ <source> <group> ] | [ <group> [ <source> ] ] ] [ shared-tree | source-tree | mofrr ] [ [ flags ] | [ detail ] | [
  bitfield ] | [ summary [ software-forwarded | rpf-failed ] ] } ] [ vrf { <vrf-name> | <vrf-known-name> | all
  } ] [ __readonly__ TABLE_vrf <vrf-name> [ <expyr_timer> ] [ <route_count> ] [ <star_g_cnt> ] [ <sg_cnt>
  ] [ <star_g_prfx_cnt> ] [ TABLE_route_summary [ <total-num-routes> ] [ <star-g-route> ] [ <sg-route> ] [
  <star-g-prfx> ] [ <group-count> ] [ <avg> ] [ <rem> ] [ <stats-pndg> ] ] [ TABLE_summary_source [
  <group_addr> ] [ <group_mask_len> ] [ <source_count> ] [ TABLE_one_sg [ <source_addr> ] [ <packets>
  ] [ <bytes> ] [ <aps> ] [ <pps> ] [ <rate_buf> ] [ <oifs> ] [ <software_fwd> ] [ <rpf-failed-pkts> ] [
  <rpf-failed-bytes> ] ] ] [ TABLE_one_route <mcast-addrs> [ <source_addrs> <group_addrs> ] [ <pending>
  ] [ <bidir> ] [ <uptime> ] [ <uptime_detailed> ] [ <mofrr> ] [ TABLE_mpib [ <mpib-name> ] [ <oif-count>
  ] [ <stale-route> ] ] [ <mdt-encap-index> ] [ <stats-pkts> ] [ <stats-bytes> ] [ <stats-rate-buf> ] [ <lisp-src-rloc>
  ] [ <nat-mode> ] [ <nat-route-type> ] [ <route-iif> ] [ <rpf-nbr> ] [ <mofrr-iif> ] [ <mofrr-nbr> ] [ <internal>
  ] [ <oif-count> ] [ <fabric-oif> ] [ <fabric-loser> ] [ <num-vpc-svi-oifs> ] [ TABLE_oif [ <oif-name> ] [
  <oif-uptime> ] [ <oif-uptime-detailed> ] [ TABLE_oif_mpib [ <oif-mpib-name> ] [ <stale-oif> ] [
  <omd-vpc-svi> ] [ <core-interest> ] [ <fabric-interest> ] ] [ <rpf> ] ] [ <route-mdt-iod> ] [ <oif-list-bitfield>
  ] [ <sr-count> ] [ TABLE_sr [ <translated-route-src> ] [ <translated-route-grp> ] [ <udp-src-port> ] [
  <udp-dst-port> ] [ <sr-oif> ] ] ] [ TABLE_extranet [ <extranet_vrf_name> ] [ <extranet_addr> ] [
  <extranet_oif_count> ] ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| ipv6                  | Display IPv6 information                               |
| vrf                   | (Optional) Display per-VRF information                 |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| all                   | (Optional) Display information for all VRFs            |
| mroute                | Display IP multicast routing table                     |
| summary               | (Optional) Display route counts and packet rates       |
| shared-tree           | (Optional) Display route for *,G entries               |
| source-tree           | (Optional) Display route for S,G entries               |
| software-forwarded    | (Optional) Display software switched route counts only |
| rpf-failed            | (Optional) Display RPF failure statistics              |
| rp                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |
| sr                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |
| mofrr                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED              |

|                      |  |
|----------------------|--|
| count                | (Optional) Display route counts only         |
| bitfield             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED    |
| detail               | (Optional) Display detailed route attributes |
| flags                | (Optional) Display detailed route attributes |
| __readonly__         | (Optional)                                   |
| TABLE_vrf            | (Optional)                                   |
| vrf-name             | (Optional)                                   |
| expry_timer          | (Optional)                                   |
| route_count          | (Optional)                                   |
| star_g_cnt           | (Optional)                                   |
| sg_cnt               | (Optional)                                   |
| star_g_prfx_cnt      | (Optional)                                   |
| TABLE_summary_source | (Optional)                                   |
| group_addr           | (Optional)                                   |
| group_mask_len       | (Optional)                                   |
| source_count         | (Optional)                                   |
| TABLE_one_sg         | (Optional)                                   |
| source_addr          | (Optional)                                   |
| packets              | (Optional)                                   |
| bytes                | (Optional)                                   |
| aps                  | (Optional)                                   |
| pps                  | (Optional)                                   |
| rate_buf             | (Optional)                                   |
| oifs                 | (Optional)                                   |
| software_fwd         | (Optional)                                   |
| rpf-failed-pkts      | (Optional)                                   |
| rpf-failed-bytes     | (Optional)                                   |
| TABLE_one_route      | (Optional)                                   |
| mcast-addrs          | (Optional)                                   |

|                         |            |
|-------------------------|------------|
| <i>source_addrs</i>     | (Optional) |
| <i>group_addrs</i>      | (Optional) |
| <i>bidir</i>            | (Optional) |
| <i>pending</i>          | (Optional) |
| <i>mofrr</i>            | (Optional) |
| <i>uptime</i>           | (Optional) |
| <i>uptime_detailed</i>  | (Optional) |
| TABLE_mpib              | (Optional) |
| <i>mpib-name</i>        | (Optional) |
| <i>oif-count</i>        | (Optional) |
| <i>stale-route</i>      | (Optional) |
| <i>mdt-encap-index</i>  | (Optional) |
| <i>stats-pkts</i>       | (Optional) |
| <i>stats-bytes</i>      | (Optional) |
| <i>stats-rate-buf</i>   | (Optional) |
| <i>lisp-src-rloc</i>    | (Optional) |
| <i>nat-mode</i>         | (Optional) |
| <i>nat-route-type</i>   | (Optional) |
| <i>route-iif</i>        | (Optional) |
| <i>rpf-nbr</i>          | (Optional) |
| <i>mofrr-iif</i>        | (Optional) |
| <i>mofrr-nbr</i>        | (Optional) |
| <i>internal</i>         | (Optional) |
| <i>oif-count</i>        | (Optional) |
| <i>fabric-oif</i>       | (Optional) |
| <i>fabric-loser</i>     | (Optional) |
| <i>num-vpc-svi-oifs</i> | (Optional) |
| TABLE_oif               | (Optional) |
| <i>oif-name</i>         | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>oif-uptime</i>           | (Optional) |
| <i>oif-uptime-detailed</i>  | (Optional) |
| TABLE_oif_mpib              | (Optional) |
| <i>oif-mpib-name</i>        | (Optional) |
| <i>stale-oif</i>            | (Optional) |
| <i>omd-vpc-svi</i>          | (Optional) |
| <i>core-interest</i>        | (Optional) |
| <i>fabric-interest</i>      | (Optional) |
| <i>rpf</i>                  | (Optional) |
| <i>route-mdt-iod</i>        | (Optional) |
| <i>oif-list-bitfield</i>    | (Optional) |
| TABLE_route_summary         | (Optional) |
| <i>total-num-routes</i>     | (Optional) |
| <i>star-g-route</i>         | (Optional) |
| <i>sg-route</i>             | (Optional) |
| <i>star-g-prfx</i>          | (Optional) |
| <i>group-count</i>          | (Optional) |
| <i>avg</i>                  | (Optional) |
| <i>rem</i>                  | (Optional) |
| <i>stats-pndg</i>           | (Optional) |
| <i>sr-count</i>             | (Optional) |
| TABLE_sr                    | (Optional) |
| <i>translated-route-src</i> | (Optional) |
| <i>translated-route-grp</i> | (Optional) |
| <i>udp-src-port</i>         | (Optional) |
| <i>udp-dst-port</i>         | (Optional) |
| <i>sr-oif</i>               | (Optional) |
| TABLE_extranet              | (Optional) |
| <i>extranet_vrf_name</i>    | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>extranet_addr</i>      | (Optional) |
| <i>extranet_oif_count</i> | (Optional) |

**Command Mode**

- /exec

## show ipv6 mtu

```
show ipv6 mtu [ statistics | vrf { <vrf-name> | <vrf-known-name> | all [ detail ] } ] [ __readonly__ [
TABLE_mtu_stat <out-ent> <exp-ent> <purge-ent> <int-err> <pkt-too-big> <cache-miss> <cache-upd>
<mtu-small> <cache-no-upd> ] [ TABLE_mtu_vrf [ <tot-ipv6-mtu> ] [ TABLE_one_mtu [ <pmtu-entxt> ]
[ { <mtu-ipv6> <mtu-cache> <up-time> <iod-lcache> } ] ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| ipv6                  | Display IPv6 information                        |
| mtu                   | Display IPV6 Path MTU Cache                     |
| statistics            | (Optional) Display non-TCP Path MTU Statistics  |
| vrf                   | (Optional) Clear information for particular VRF |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| all                   | (Optional) Display information for all VRFs     |
| detail                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED       |
| __readonly__          | (Optional)                                      |
| TABLE_mtu_stat        | (Optional) mtu statistic table                  |
| <i>out-ent</i>        | (Optional) outstanding entries                  |
| <i>exp-ent</i>        | (Optional) expired entries                      |
| <i>purge-ent</i>      | (Optional) purge entries                        |
| <i>int-err</i>        | (Optional) internal entries                     |
| <i>pkt-too-big</i>    | (Optional) packets too big meassages received   |
| <i>cache-miss</i>     | (Optional) cache misses                         |
| <i>cache-upd</i>      | (Optional) cache updates                        |
| <i>mtu-small</i>      | (Optional) too small mtu advertised             |
| <i>cache-no-upd</i>   | (Optional) cache no update                      |
| TABLE_mtu_vrf         | (Optional) MTU vrf table                        |
| <i>tot-ipv6-mtu</i>   | (Optional) total ipv6 mtu messages              |
| TABLE_one_mtu         | (Optional) MTU table                            |



|                   |                         |
|-------------------|-------------------------|
| <i>pmtu-cntxt</i> | (Optional) pmtu context |
| <i>mtu-cache</i>  | (Optional) mtu cache    |
| <i>up-time</i>    | (Optional) up time      |
| <i>iod-lcache</i> | (Optional) iod lcache   |

**Command Mode**

- /exec

## show ipv6 multicast vrf

```
show ipv6 multicast vrf [ <vrf-name> | <vrf-known-name> | all ] [ detail ] [ __readonly__ <vrf-count> [ {
TABLE_vrf <vrf-name> <cid> <tid> <rc> <gc> <sc> <star_gc> <state> [ <multipath-configuration> ] [
<mrrib-cc-timer-left> ] [ <mrrib-stats-timer-left> ] [ <mrrib-mfdm-timer-left> ] [ <mrrib-lisp-timer-left> ] [
<sr-interface> ] [ <resilient> ] [ TABLE_RPF_SELECT <rpf-ip> <rpf-ip-mask> <rpf-vrf> ] [
<global-mcast-bndry> ] } ] ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information             |
| ipv6                           | Display IPv6 information                    |
| multicast                      | Display multicast routing info              |
| vrf                            | Display information for particular VRF      |
| <i>vrf-name</i>                | (Optional) VRF name                         |
| <i>vrf-known-name</i>          | (Optional) Known VRF name                   |
| all                            | (Optional) Display information for all VRFs |
| detail                         | (Optional) Display detailed information     |
| <i>__readonly__</i>            | (Optional)                                  |
| <i>vrf-count</i>               | (Optional)                                  |
| TABLE_vrf                      | (Optional)                                  |
| <i>vrf-name</i>                | (Optional)                                  |
| <i>cid</i>                     | (Optional)                                  |
| <i>tid</i>                     | (Optional)                                  |
| <i>rc</i>                      | (Optional)                                  |
| <i>gc</i>                      | (Optional)                                  |
| <i>sc</i>                      | (Optional)                                  |
| <i>star_gc</i>                 | (Optional)                                  |
| <i>state</i>                   | (Optional)                                  |
| <i>multipath-configuration</i> | (Optional)                                  |
| <i>mrrib-cc-timer-left</i>     | (Optional)                                  |
| <i>mrrib-stats-timer-left</i>  | (Optional)                                  |
| <i>mrrib-mfdm-timer-left</i>   | (Optional)                                  |

|                             |            |
|-----------------------------|------------|
| <i>mrib-lisp-timer-left</i> | (Optional) |
| <i>sr-interface</i>         | (Optional) |
| <i>resilient</i>            | (Optional) |
| TABLE_RPF_SELECT            | (Optional) |
| <i>rpf-ip</i>               | (Optional) |
| <i>rpf-ip-mask</i>          | (Optional) |
| <i>rpf-vrf</i>              | (Optional) |
| <i>global-mcast-bndry</i>   | (Optional) |

**Command Mode**

- /exec

## show ipv6 nd ra dns search-list

```
show ipv6 nd ra dns search-list [ interface <interface> ] [ __readonly__ { TABLE_intf <intf_name>
<dns_supress_server_list> [ { TABLE_list <list_no> <list_name> [ { <finite> | <infinite> } ] <seq_no> } ]
} ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                             |
| ipv6                           | Display IPv6 information                                    |
| nd                             | ICMPv6 Neighbor Discovery commands                          |
| ra                             | Router Advertisement  |
| dns                            | Domain Name System  |
| search-list                    | DNS Search List   |
| interface                      | (Optional) Display DNS Search List information on interface |
| <i>interface</i>               | (Optional) Interface name to display                        |
| <i>__readonly__</i>            | (Optional)  |
| TABLE_intf                     | (Optional) IPV6 Interface name                              |
| <i>intf_name</i>               | (Optional) Interface name                                   |
| <i>dns_supress_server_list</i> | (Optional) DNS Supress server list                          |
| TABLE_list                     | (Optional) Search list                                      |
| <i>list_no</i>                 | (Optional) Search list number                               |
| <i>list_name</i>               | (Optional) Search list name                                 |
| <i>finite</i>                  | (Optional) Search list life time                            |
| <i>infinite</i>                | (Optional) Search list infinte time                         |
| <i>seq_no</i>                  | (Optional) Search list sequence number                      |

### Command Mode

- /exec

## show ipv6 nd ra dns server

```
show ipv6 nd ra dns server [ interface <interface> ] [ __readonly__ [ { TABLE_intf_name [ <inf-name> ] } ] ] [ { TABLE_intf [ <dns-recursion-server-list> ] [ <dns-suppression-server-list> ] [ { TABLE_dns_server [ <dns-server-index> ] [ <dns-server-list> ] [ <lifetime> ] [ <second-seqno> ] } ] ] [ { TABLE_dns_seq [ <dns-server> ] [ <dns-addr> ] [ <infinite-seq-no> ] } ] ] ] ]
```

### Syntax Description

|                                    |   |
|------------------------------------|---|
| show                               | Show running system information                                       |
| ipv6                               | Display IPv6 information  |
| nd                                 | ICMPv6 Neighbor Discovery commands                                    |
| ra                                 | Router Advertisement  |
| dns                                | Domain Name System  |
| server                             | Domain Name System Server   |
| interface                          | (Optional) Display Recursive DNS Server List information on interface |
| <i>interface</i>                   | (Optional) Interface name to display                                  |
| <i>__readonly__</i>                | (Optional)  |
| TABLE_intf_name                    | (Optional) interface table  |
| <i>inf-name</i>                    | (Optional) interface name   |
| TABLE_intf                         | (Optional)  |
| <i>dns-recursion-server-list</i>   | (Optional) DNS recursion server list                                  |
| <i>dns-suppression-server-list</i> | (Optional) DNS suppression server list                                |
| TABLE_dns_server                   | (Optional) DNS server table   |
| <i>dns-server-index</i>            | (Optional) dns server index   |
| <i>dns-server-list</i>             | (Optional) dns server list  |
| <i>lifetime</i>                    | (Optional) server lifetime  |
| <i>second-seqno</i>                | (Optional) second sequence number                                     |
| TABLE_dns_seq                      | (Optional) DNS sequence table   |
| <i>dns-server</i>                  | (Optional) dns server   |
| <i>dns-addr</i>                    | (Optional) dns address  |
| <i>infinite-seq-no</i>             | (Optional) infinite sequence number                                   |

**Command Mode**

- /exec

## show ipv6 nd raguard policy

```
show ipv6 nd raguard policy [ <name> ] [ __readonly__ { TABLE_raguard_policy <policy> [ <port_type>
] <device_role> [ <min_hop_limit> ] [ <max_hop_limit> ] [ <mgd_conf_flag> ] [ <other_conf_flag> ] [
<rtr_pref_max> ] [ <ra_prefix_list> ] [ <ipv6_acl> ] [ { TABLE_raguard_targets <target> <target_type>
<target_policy> <feature> <target_range> } ] } ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| <i>name</i>            | (Optional) Policy name for feature RA guard |
| <i>__readonly__</i>    | (Optional)                                  |
| TABLE_raguard_policy   | (Optional) IPv6 RA guard policy             |
| <i>policy</i>          | (Optional) Policy Name                      |
| <i>port_type</i>       | (Optional) Port type                        |
| <i>device_role</i>     | (Optional) Device role                      |
| <i>min_hop_limit</i>   | (Optional) Minimum hop limit                |
| <i>max_hop_limit</i>   | (Optional) Minimum hop limit                |
| <i>mgd_conf_flag</i>   | (Optional) Check managed config flag        |
| <i>other_conf_flag</i> | (Optional) Check other config flag          |
| <i>rtr_pref_max</i>    | (Optional) Router-preference maximum        |
| <i>ra_prefix_list</i>  | (Optional) Match RA prefix list             |
| <i>ipv6_acl</i>        | (Optional) Match IPv6 access list           |
| TABLE_raguard_targets  | (Optional) RA Guard Targets table           |
| <i>target</i>          | (Optional) Target Name                      |
| <i>target_type</i>     | (Optional) Target Type                      |
| <i>target_policy</i>   | (Optional) Policy Name                      |
| <i>feature</i>         | (Optional) Feature                          |
| <i>target_range</i>    | (Optional) Target Range                     |

### Command Mode

- /exec

# show ipv6 neighbor binding

```
show ipv6 neighbor binding [ { { vlan <vlanid> [ details ] } | { { address { <ipv6-addr> | all } } { interface <intfid> vlan <vlanid> [ details ] } }
```

## Syntax Description

|               |                                      |
|---------------|--------------------------------------|
| <i>intfid</i> | (Optional) [details]                 |
| show          | Show running system information      |
| ipv6          | Show the IPv6 features of the system |
| <i>vlanid</i> | (Optional) Vlan number               |

## Command Mode

- /exec



# show ipv6 neighbor binding mac

```
show ipv6 neighbor binding mac <macaddr> { interface <intfid> vlan <vlanid> [ details ] |
```

## Syntax Description

|                |                                      |
|----------------|--------------------------------------|
| <i>intfid</i>  | [details]                            |
| show           | Show running system information      |
| ipv6           | Show the IPv6 features of the system |
| <i>macaddr</i> | 48-bit hardware address              |
| <i>vlanid</i>  | Vlan number                          |

## Command Mode

- /exec

## show ipv6 neighbor static

```
show ipv6 neighbor static [ interface <interface> ] [ __readonly__ [ TABLE_i6_nei { <nei-ipv6> <nei-mac>
<nei-iod> <nei-if-iod> } ] [ <tot-nei-ent> ] [ TABLE_nei_cnt { <nei-ipv6-tot> <nei-mac-tot> <nei-iod-tot>
<nei-if-iod-tot> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                       |
| ipv6                  | Display IPv6 information                              |
| neighbor              | Show IPv6 neighbor entry                              |
| static                | Displays only static neighbors                        |
| interface             | (Optional) Display IPv6 related interface information |
| <i>interface</i>      | (Optional) Interface name to display                  |
| <i>__readonly__</i>   | (Optional)  |
| TABLE_i6_nei          | (Optional) ipv6 neighbor table                        |
| <i>nei-mac</i>        | (Optional) neighbor mac address                       |
| <i>nei-iod</i>        | (Optional) neighbor iod                               |
| <i>nei-if-iod</i>     | (Optional) neighbor interface iod                     |
| <i>tot-nei-ent</i>    | (Optional) total neighbor entries                     |
| TABLE_nei_cnt         | (Optional) neighbor count table                       |
| <i>nei-mac-tot</i>    | (Optional) neighbor mac address                       |
| <i>nei-iod-tot</i>    | (Optional) neighbor iod                               |
| <i>nei-if-iod-tot</i> | (Optional) neighbor physical interface iod            |

### Command Mode

- /exec

## show ipv6 pim df

```
show ipv6 pim df [ <rp-or-group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [ __readonly__
[ TABLE_ctx [ <out-context> ] [ TABLE_rp [ <rp-addr> ] [ <df-ordinal> ] [ <df-bits> ] [ <df-bits-count> ]
[ <metric-pref> ] [ <metric> ] [ TABLE_grange [ <grange-grp> ] [ <grange-masklen> ] ] [ TABLE_iod [
<if-name> ] [ <df-winner> ] [ <df-state> ] [ <winner-metric-pref> ] [ <winner-metric> ] [ <uptime> ] [ <is-rpf>
] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| pim                   | Display PIM6 status and configuration       |
| df                    | Display Bidir Designated Forwarders         |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| internal              | (Optional) Commands for internal use        |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>out-context</i>    | (Optional)                                  |
| TABLE_rp              | (Optional)                                  |
| <i>df-ordinal</i>     | (Optional)                                  |
| <i>df-bits</i>        | (Optional)                                  |
| <i>df-bits-count</i>  | (Optional)                                  |
| <i>metric-pref</i>    | (Optional)                                  |
| <i>metric</i>         | (Optional)                                  |
| TABLE_grange          | (Optional)                                  |
| <i>grange-masklen</i> | (Optional)                                  |
| TABLE_iod             | (Optional)                                  |
| <i>if-name</i>        | (Optional)                                  |
| <i>df-state</i>       | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>winner-metric-pref</i> | (Optional) |
| <i>winner-metric</i>      | (Optional) |
| <i>uptime</i>             | (Optional) |
| <i>is-rpf</i>             | (Optional) |

**Command Mode**

- /exec

## show ipv6 pim fabric info

```
show ipv6 pim fabric info [ __readonly__ <switch_role> <fabric_ctrl_addr> <peer_fabric_ctrl_infra>
<vpc_domain_id> <peer_fabric_ctrl_addr> ]
```

### Syntax Description

|                               |                                       |
|-------------------------------|---------------------------------------|
| show                          | Show running system information       |
| ipv6                          | Display IPv6 information              |
| pim                           | Display PIM6 status and configuration |
| fabric                        | Fabric functionality                  |
| info                          | show the fabric info                  |
| <i>__readonly__</i>           | (Optional)                            |
| <i>switch_role</i>            | (Optional)                            |
| <i>fabric_ctrl_addr</i>       | (Optional)                            |
| <i>peer_fabric_ctrl_infra</i> | (Optional)                            |
| <i>vpc_domain_id</i>          | (Optional)                            |
| <i>peer_fabric_ctrl_addr</i>  | (Optional)                            |

### Command Mode

- /exec

# show ipv6 pim fabric legacy-vlans

show ipv6 pim fabric legacy-vlans [ *\_\_readonly\_\_* *TABLE\_legacy\_vlan* *<vlan\_id>* ]

## Syntax Description

|                          |                                       |
|--------------------------|---------------------------------------|
| show                     | Show running system information       |
| ipv6                     | Display IPv6 information              |
| pim                      | Display PIM6 status and configuration |
| fabric                   | Fabric functionality                  |
| legacy-vlans             | Show legacy VLANs on this switch      |
| <i>__readonly__</i>      | (Optional)                            |
| <i>TABLE_legacy_vlan</i> | (Optional)                            |
| <i>vlan_id</i>           | (Optional)                            |

## Command Mode

- /exec

## show ipv6 pim group-range

```
show ipv6 pim group-range [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf <out-context> [ { TABLE_group [ <grp-addr> ] [ <invalid-grp> ] [ <action> ] [ <mode> ] [
<rp-addr> ] [ <sh-tree-only-range> ] [ <origin> } } ] ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information             |
| ipv6                      | Display IPv6 information                    |
| pim                       | Display PIM6 status and configuration       |
| group-range               | Display the various group-ranges            |
| vrf                       | (Optional) Display per-VRF information      |
| <i>vrf-name</i>           | (Optional) VRF name                         |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                   |
| all                       | (Optional) Display information for all VRFs |
| __readonly__              | (Optional)                                  |
| TABLE_vrf                 | (Optional)                                  |
| <i>out-context</i>        | (Optional)                                  |
| TABLE_group               | (Optional)                                  |
| <i>invalid-grp</i>        | (Optional)                                  |
| <i>grp-addr</i>           | (Optional)                                  |
| <i>mode</i>               | (Optional)                                  |
| <i>rp-addr</i>            | (Optional)                                  |
| <i>sh-tree-only-range</i> | (Optional)                                  |
| <i>action</i>             | (Optional)                                  |
| <i>origin</i>             | (Optional)                                  |

### Command Mode

- /exec

## show ipv6 pim interface

```
show ipv6 pim interface [ <interface> ] [ brief ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ]
[ __readonly__ [ <is-pim-enabled> ] [ TABLE_vrf [ <out-context> ] [ TABLE_brief [ <if-name> ] [ <if-addr>
] [ <if-dr> ] [ <if-nbr-count> ] [ <if-is-border> ] ] [ TABLE_iod [ <if-name> ] [ <if-status> ] [
<cached_if_status> ] [ <if-addr-summary> ] [ <pim-dr-address> ] [ <dr-priority> ] [ <no-dr-priority> ] [
<nbr-cnt> ] [ <hello-interval-sec> ] [ <hello-interval-msec> ] [ <hello-timer> ] [ <holdtime-msec> ] [
<holdtime-sec> ] [ <if-conf-dr-priority> ] [ <if-conf-delay> ] [ <is-border> ] [ <genid> ] [ <isauth-config> ]
[ <nbr-policy-name> ] [ <jp-in-policy-name> ] [ <jp-out-policy-name> ] [ <jp-interval> ] [ <jp-next-send> ]
[ <pim-bfd-enabled> ] [ <is-passive> ] [ <is-pim-vpc-svi> ] [ <is-auto-enabled> ] [ <vpc-peer-nbr> ] [
<last-cleared> ] [ <hello-sent> ] [ <hello-rcvd> ] [ <hello-early-sent> ] [ <jp-sent> ] [ <jp-rcvd> ] [ <assert-sent>
] [ <assert-rcvd> ] [ <graft-sent> ] [ <graft-rcvd> ] [ <graft-ack-sent> ] [ <graft-ack-rcvd> ] [ <df-offer-sent>
] [ <df-offer-rcvd> ] [ <df-winner-sent> ] [ <df-winner-rcvd> ] [ <df-backoff-sent> ] [ <df-backoff-rcvd> ] [
<pass-sent> ] [ <pass-rcvd> ] [ <cksum-errors> ] [ <invalid-errors> ] [ <invalid-df-errors> ] [ <auth-failed>
] [ <pak-len-errors> ] [ <ver-errors> ] [ <pkts-self> ] [ <pkts-non-nbr> ] [ <pkts-on-passive> ] [ <jp-rcvd-on-rpf>
] [ <jp-rcvd-no-rp> ] [ <jp-rcvd-wrong-rp> ] [ <jp-rcvd-for-ssm> ] [ <jp-rcvd-for-bidir> ] [ <jp-in-policy-filter>
] [ <jp-out-policy-filter> ] [ <ecmp-redirect-sent> ] [ <ecmp-redirect-rcv> ] [ <is-border-router> ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                          |
| ipv6                  | Display IPv6 information                                 |
| pim                   | Display PIM6 status and configuration                    |
| interface             | Display PIM6 interface related information               |
| <i>interface</i>      | (Optional) Interface name of single interface to display |
| brief                 | (Optional) Display one line status per interface         |
| vrf                   | (Optional) Display per-VRF information                   |
| <i>vrf-name</i>       | (Optional) VRF name                                      |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                |
| all                   | (Optional) Display information for all VRFs              |
| internal              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                |
| <i>__readonly__</i>   | (Optional)   |
| <i>is-pim-enabled</i> | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>out-context</i>    | (Optional)   |
| TABLE_brief           | (Optional)   |
| <i>if-name</i>        | (Optional)   |



|                            |            |
|----------------------------|------------|
| <i>if-addr</i>             | (Optional) |
| <i>if-dr</i>               | (Optional) |
| <i>if-nbr-count</i>        | (Optional) |
| <i>if-is-border</i>        | (Optional) |
| TABLE_iod                  | (Optional) |
| <i>if-name</i>             | (Optional) |
| <i>if-status</i>           | (Optional) |
| <i>cached_if_status</i>    | (Optional) |
| <i>if-addr-summary</i>     | (Optional) |
| <i>pim-dr-address</i>      | (Optional) |
| <i>dr-priority</i>         | (Optional) |
| <i>no-dr-priority</i>      | (Optional) |
| <i>nbr-cnt</i>             | (Optional) |
| <i>hello-interval-sec</i>  | (Optional) |
| <i>hello-interval-msec</i> | (Optional) |
| <i>hello-timer</i>         | (Optional) |
| <i>holdtime-msec</i>       | (Optional) |
| <i>holdtime-sec</i>        | (Optional) |
| <i>if-conf-dr-priority</i> | (Optional) |
| <i>if-conf-delay</i>       | (Optional) |
| <i>is-border</i>           | (Optional) |
| <i>genid</i>               | (Optional) |
| <i>isauth-config</i>       | (Optional) |
| <i>nbr-policy-name</i>     | (Optional) |
| <i>jp-in-policy-name</i>   | (Optional) |
| <i>jp-out-policy-name</i>  | (Optional) |
| <i>jp-interval</i>         | (Optional) |
| <i>jp-next-send</i>        | (Optional) |
| <i>pim-bfd-enabled</i>     | (Optional) |

|                          |            |
|--------------------------|------------|
| <i>is-passive</i>        | (Optional) |
| <i>is-pim-vpc-svi</i>    | (Optional) |
| <i>is-auto-enabled</i>   | (Optional) |
| <i>vpc-peer-nbr</i>      | (Optional) |
| <i>last-cleared</i>      | (Optional) |
| <i>hello-sent</i>        | (Optional) |
| <i>hello-rcvd</i>        | (Optional) |
| <i>hello-early-sent</i>  | (Optional) |
| <i>jp-sent</i>           | (Optional) |
| <i>jp-rcvd</i>           | (Optional) |
| <i>assert-sent</i>       | (Optional) |
| <i>assert-rcvd</i>       | (Optional) |
| <i>graft-sent</i>        | (Optional) |
| <i>graft-rcvd</i>        | (Optional) |
| <i>graft-ack-sent</i>    | (Optional) |
| <i>graft-ack-rcvd</i>    | (Optional) |
| <i>df-offer-sent</i>     | (Optional) |
| <i>df-offer-rcvd</i>     | (Optional) |
| <i>df-winner-sent</i>    | (Optional) |
| <i>df-winner-rcvd</i>    | (Optional) |
| <i>df-backoff-sent</i>   | (Optional) |
| <i>df-backoff-rcvd</i>   | (Optional) |
| <i>pass-sent</i>         | (Optional) |
| <i>pass-rcvd</i>         | (Optional) |
| <i>cksum-errors</i>      | (Optional) |
| <i>invalid-errors</i>    | (Optional) |
| <i>invalid-df-errors</i> | (Optional) |
| <i>auth-failed</i>       | (Optional) |
| <i>pak-len-errors</i>    | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>ver-errors</i>           | (Optional) |
| <i>pkts-self</i>            | (Optional) |
| <i>pkts-non-nbr</i>         | (Optional) |
| <i>pkts-on-passive</i>      | (Optional) |
| <i>jp-rcvd-on-rpf</i>       | (Optional) |
| <i>jp-rcvd-no-rp</i>        | (Optional) |
| <i>jp-rcvd-wrong-rp</i>     | (Optional) |
| <i>jp-rcvd-for-ssm</i>      | (Optional) |
| <i>jp-rcvd-for-bidir</i>    | (Optional) |
| <i>jp-in-policy-filter</i>  | (Optional) |
| <i>jp-out-policy-filter</i> | (Optional) |
| <i>ecmp-redirect-sent</i>   | (Optional) |
| <i>ecmp-redirect-rcv</i>    | (Optional) |
| <i>is-border-router</i>     | (Optional) |

**Command Mode**

- /exec

## show ipv6 pim mdt

```
show ipv6 pim mdt [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <out_context>
<mti> <mti_status> <default_mdt_grp> <grp_mode> <asm_shared_tree> <mti_config_mtu> <mti_active_mtu>
<cfg_tunnel_src_if> <bgp_update_src_if> <hello_interval> <jp_interval> <data_mdt_join_interval>
<data_switchover_interval> <data_holddown_interval> <data_timeout_interval> <mdt_src> <mdt_src_if>
<bgp_rd> <bgp_rd_set> <send_join_count> <rcvd_join_count> { TABLE_data_mdt <grange_prefix>
<grange_mask_len> <threshold> [ <policy_name> ] } ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information             |
| ipv6                          | Display IPv6 information                    |
| pim                           | Display PIM6 status and configuration       |
| mdt                           | Display MDT information                     |
| vrf                           | (Optional) Display per-VRF information      |
| <i>vrf-name</i>               | (Optional) VRF name                         |
| <i>vrf-known-name</i>         | (Optional) Known VRF name                   |
| all                           | (Optional) Display information for all VRFs |
| <i>__readonly__</i>           | (Optional)                                  |
| TABLE_vrf                     | (Optional)                                  |
| <i>out_context</i>            | (Optional)                                  |
| <i>mti</i>                    | (Optional)                                  |
| <i>mti_status</i>             | (Optional)                                  |
| <i>grp_mode</i>               | (Optional)                                  |
| <i>asm_shared_tree</i>        | (Optional)                                  |
| <i>mti_config_mtu</i>         | (Optional)                                  |
| <i>mti_active_mtu</i>         | (Optional)                                  |
| <i>cfg_tunnel_src_if</i>      | (Optional)                                  |
| <i>bgp_update_src_if</i>      | (Optional)                                  |
| <i>hello_interval</i>         | (Optional)                                  |
| <i>jp_interval</i>            | (Optional)                                  |
| <i>data_mdt_join_interval</i> | (Optional)                                  |

|                                 |            |
|---------------------------------|------------|
| <i>data_switchover_interval</i> | (Optional) |
| <i>data_holddown_interval</i>   | (Optional) |
| <i>data_timeout_interval</i>    | (Optional) |
| <i>mdt_src_if</i>               | (Optional) |
| <i>bgp_rd</i>                   | (Optional) |
| <i>bgp_rd_set</i>               | (Optional) |
| <i>send_join_count</i>          | (Optional) |
| <i>rcvd_join_count</i>          | (Optional) |
| TABLE_data_mdt                  | (Optional) |
| <i>grange_mask_len</i>          | (Optional) |
| <i>threshold</i>                | (Optional) |
| <i>policy_name</i>              | (Optional) |

**Command Mode**

- /exec

# show ipv6 pim mdt bgp

```
show ipv6 pim mdt bgp [ mdt-source <src-addr> ] [ __readonly__ { TABLE_entry <bgp_rd> <mdt_src>
<mdt_grp> <local> } ]
```

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information            |
| ipv6          | Display IPv6 information                   |
| pim           | Display PIM6 status and configuration      |
| mdt           | Display MDT information                    |
| bgp           | Display BGP related information            |
| mdt-source    | (Optional) Source address of MVPN neighbor |
| __readonly__  | (Optional)                                 |
| TABLE_entry   | (Optional)                                 |
| <i>bgp_rd</i> | (Optional)                                 |
| <i>local</i>  | (Optional)                                 |

## Command Mode

- /exec

## show ipv6 pim mdt history interval

```
show ipv6 pim mdt history interval <min> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
TABLE_vrf <out_context> [ { TABLE_entry <csrc> <cgrp> <psrc> <pgrp> <uptime> <send_count> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| pim                   | Display PIM6 status and configuration       |
| mdt                   | Display MDT information                     |
| history               | Display MDT Data Join Send Histoy           |
| interval              | Display in specified interval               |
| <i>min</i>            | Minutes                                     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| __readonly__          | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_entry           | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| <i>send_count</i>     | (Optional)                                  |

### Command Mode

- /exec

## show ipv6 pim mdt receive

```
show ipv6 pim mdt receive [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
[ <out_context> ] [ TABLE_entry [ <csrc> ] [ <cgrp> ] [ <psrc> ] [ <pgrp> ] [ <uptime> ] [ <expires> ] [
<rcv_count> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| pim                   | Display PIM6 status and configuration       |
| mdt                   | Display MDT information                     |
| receive               | Display Received Data Joins Information     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| detail                | (Optional) Display detailed information     |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_entry           | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| <i>expires</i>        | (Optional)                                  |
| <i>rcv_count</i>      | (Optional)                                  |

### Command Mode

- /exec



## show ipv6 pim mdt send

```
show ipv6 pim mdt send [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<out_context> [ { TABLE_entry <csrc> <cgrp> <psrc> <pgrp> <uptime> <send_count> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| pim                   | Display PIM6 status and configuration       |
| mdt                   | Display MDT information                     |
| send                  | Display MDT Data Join Send Information      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| detail                | (Optional) Display detailed information     |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_entry           | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| <i>send_count</i>     | (Optional)                                  |

### Command Mode

- /exec

## show ipv6 pim neighbor

```
show ipv6 pim neighbor { [ <interface> ] | [ <address> ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
detail | internal ] [ __readonly__ [ TABLE_vrf <out-context> [ TABLE_neighbor
<nbr-addr><if-name><uptime><expires> [ <dr-priority> ] <bidir-capable><bfd-state> [
<longest-hello-intvl><non-hello-pkts> ] [ <ecmp-redirect-capable> ] [ TABLE_secondary <sec-addr> ] ] ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                       |
| ipv6                         | Display IPv6 information                              |
| pim                          | Display PIM6 status and configuration                 |
| neighbor                     | Display PIM6 neighbor related information             |
| <i>interface</i>             | (Optional) Display neighbors on single interface name |
| vrf                          | (Optional) Display per-VRF information                |
| <i>vrf-name</i>              | (Optional) VRF name                                   |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                             |
| all                          | (Optional) Display information for all VRFs           |
| detail                       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| internal                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>__readonly__</i>          | (Optional)  |
| TABLE_vrf                    | (Optional)  |
| <i>out-context</i>           | (Optional)  |
| TABLE_neighbor               | (Optional)  |
| <i>dr-priority</i>           | (Optional)  |
| <i>ecmp-redirect-capable</i> | (Optional)  |
| TABLE_secondary              | (Optional)  |

### Command Mode

- /exec



|                                     |            |
|-------------------------------------|------------|
| TABLE_immediatelist                 | (Optional) |
| <i>immediateoif-name</i>            | (Optional) |
| <i>immediate-timeout-list-count</i> | (Optional) |
| TABLE_immediatettimeoutlist         | (Optional) |
| <i>immediatettimeoutoif-name</i>    | (Optional) |
| <i>sgr-prune-list-count</i>         | (Optional) |
| TABLE_sgrprunelist                  | (Optional) |
| <i>sgrprunelisoif-name</i>          | (Optional) |

**Command Mode**

- /exec

## show ipv6 pim policy statistics jp

```
show ipv6 pim policy statistics { jp-policy | neighbor-policy } <interface> [ __readonly__ { TABLE_routemap
<name> <action> <seq_num> [ { TABLE_cmd <command> <compare_count> <match_count> } ] }
<total_accept_count> <total_reject_count> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information            |
| ipv6                      | Display IPv6 information                   |
| pim                       | PIM6 global configuration commands         |
| policy                    | Policy related information                 |
| statistics                | Policy statistics                          |
| jp-policy                 | Statistics for jp-policy                   |
| neighbor-policy           | Statistics for neighbor-policy             |
| <i>interface</i>          | Interface to display policy statistics for |
| <i>__readonly__</i>       | (Optional)                                 |
| TABLE_routemap            | (Optional)                                 |
| <i>name</i>               | (Optional)                                 |
| <i>action</i>             | (Optional)                                 |
| <i>seq_num</i>            | (Optional)                                 |
| TABLE_cmd                 | (Optional)                                 |
| <i>command</i>            | (Optional)                                 |
| <i>compare_count</i>      | (Optional)                                 |
| <i>match_count</i>        | (Optional)                                 |
| <i>total_accept_count</i> | (Optional)                                 |
| <i>total_reject_count</i> | (Optional)                                 |

### Command Mode

- /exec

## show ipv6 pim route

```
show ipv6 pim route [ [ <source> [ <group> ] ] | [ <group> [ <source> ] ] ] [ bitfield ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf [ <context-name> ] [ <route-count> ] [
TABLE_one_route [ <mcast-addr> ] [ <rp-addr> ] [ <rp-local> ] [ <bidir> ] [ <sgexpire> ] [ <sgexpire> ]
[ <timeleft> ] [ <rp-bit> ] [ <register> ] [ <intf-name> ] [ <rpf-nbr-1> ] [ <rpf-nbr-addr> ] [ <oif-count> ] [
<oif-bf-str> ] [ <timeout-count> ] [ <timeout-bf-str> ] [ <immediate-count> ] [ <immediate-bf-str> ] [
<immediate-timeout-count> ] [ <immediate-timeout-bf-str> ] [ <sgr-prune-list-count> ] [ <sgr-prune-list-bf-str> ]
] [ <timeout-interval> ] [ <jp-holdtime-rndup> ] [ <mdt-encap-index> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| pim                   | Display PIM6 status and configuration       |
| route                 | Display PIM6 specific route information     |
| bitfield              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| __readonly__          | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>context-name</i>   | (Optional)                                  |
| <i>route-count</i>    | (Optional)                                  |
| TABLE_one_route       | (Optional)                                  |
| <i>mcast-addr</i>     | (Optional)                                  |
| <i>rp-addr</i>        | (Optional)                                  |
| <i>rp-local</i>       | (Optional)                                  |
| <i>bidir</i>          | (Optional)                                  |
| <i>sgexpire</i>       | (Optional)                                  |
| <i>sgexpire</i>       | (Optional)                                  |
| <i>timeleft</i>       | (Optional)                                  |
| <i>rp-bit</i>         | (Optional)                                  |

|                                 |            |
|---------------------------------|------------|
| <i>register</i>                 | (Optional) |
| <i>intf-name</i>                | (Optional) |
| <i>rpf-nbr-1</i>                | (Optional) |
| <i>rpf-nbr-addr</i>             | (Optional) |
| <i>oif-count</i>                | (Optional) |
| <i>oif-bf-str</i>               | (Optional) |
| <i>timeout-count</i>            | (Optional) |
| <i>timeout-bf-str</i>           | (Optional) |
| <i>immediate-count</i>          | (Optional) |
| <i>immediate-bf-str</i>         | (Optional) |
| <i>immediate-timeout-count</i>  | (Optional) |
| <i>immediate-timeout-bf-str</i> | (Optional) |
| <i>sgr-prune-list-count</i>     | (Optional) |
| <i>sgr-prune-list-bf-str</i>    | (Optional) |
| <i>timeout-interval</i>         | (Optional) |
| <i>jp-holdtime-rndup</i>        | (Optional) |
| <i>mdt-encap-index</i>          | (Optional) |

**Command Mode**

- /exec

## show ipv6 pim rp-hash

```
show ipv6 pim rp-hash <group> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ <out-context>
[ <rp-found> ] [ <is-rp-bsr-learnt> ] [ <out-group1> <rp-addr1> ] [ <out-group> <hash-length> <out-bsr> ]
[ { TABLE_rp <rp-addr> <hash> <isbest_hash> } ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| ipv6                    | Display IPv6 information                    |
| pim                     | Display PIM6 status and configuration       |
| rp-hash                 | Display RP hash value for group             |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| <i>__readonly__</i>     | (Optional)                                  |
| <i>out-context</i>      | (Optional)                                  |
| <i>rp-found</i>         | (Optional)                                  |
| <i>is-rp-bsr-learnt</i> | (Optional)                                  |
| <i>hash-length</i>      | (Optional)                                  |
| TABLE_rp                | (Optional)                                  |
| <i>hash</i>             | (Optional)                                  |
| <i>isbest_hash</i>      | (Optional)                                  |

### Command Mode

- /exec



## show ipv6 pim rp

```
show ipv6 pim rp [ <group> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ internal ] [ __readonly__ [
TABLE_vrf <out-context> [ <is-bsr-enabled> ] [ <is-bsr-listen-only> ] [ <is-bsr-forward-only> ] [ <bsr-address>
] [ <is-bsr-local> ] [ <bsr-is-local> ] [ <bs-timer> ] [ <bsr-uptime> ] [ <bsr-expires> ] [ <bsr-priority> ] [
<bsr-hash-masklen> ] [ <rp-cand-policy-name> ] [ <bsr-policy-name> ] [ TABLE_anycast_rp <anycast-rp-addr>
] [ TABLE_arp_rp <arp-rp-addr> <is-rpaddr-local> ] ] [ TABLE_rp [ <rp-addr> ] [ <is-rp-local> ] [ <df-ordinal>
] [ <rp-uptime> ] [ <rp-priority> ] [ <is_autorp_source> ] [ <is_bsr_source> ] [ <is_static_source> ] [
<rp-source> ] [ <static-rp-group-map> ] [ TABLE_grange [ <grange-grp> ] [ <grange-masklen> ] [
<grange-is-deny> ] [ <is-bidir-grp> ] [ <autorp-expires> ] [ <bsr-rp-expires> ] [ <rp-owner-flags> ] ] [ [
<bidir-ordinal> ] [ <df-bits-recovered> ] [ <rpf-nbr-address> ] [ <metric> ] [ <metric-preference> ] ] ] ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information             |
| ipv6                       | Display IPv6 information                    |
| pim                        | Display PIM6 status and configuration       |
| rp                         | Display PIM6 RP and BSR related information |
| internal                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| vrf                        | (Optional) Display per-VRF information      |
| <i>vrf-name</i>            | (Optional) VRF name                         |
| <i>vrf-known-name</i>      | (Optional) Known VRF name                   |
| all                        | (Optional) Display information for all VRFs |
| __readonly__               | (Optional)                                  |
| TABLE_vrf                  | (Optional)                                  |
| <i>out-context</i>         | (Optional)                                  |
| <i>is-bsr-enabled</i>      | (Optional)                                  |
| <i>is-bsr-listen-only</i>  | (Optional)                                  |
| <i>is-bsr-forward-only</i> | (Optional)                                  |
| <i>is-bsr-local</i>        | (Optional)                                  |
| <i>bsr-is-local</i>        | (Optional)                                  |
| <i>bsr-priority</i>        | (Optional)                                  |
| <i>bsr-hash-masklen</i>    | (Optional)                                  |
| <i>bs-timer</i>            | (Optional)                                  |

|                            |            |
|----------------------------|------------|
| <i>bsr-uptime</i>          | (Optional) |
| <i>bsr-expires</i>         | (Optional) |
| <i>rp-cand-policy-name</i> | (Optional) |
| <i>bsr-policy-name</i>     | (Optional) |
| TABLE_anycast_rp           | (Optional) |
| <i>anycast-rp-addr</i>     | (Optional) |
| TABLE_arp_rp               | (Optional) |
| <i>arp-rp-addr</i>         | (Optional) |
| <i>is-rpaddr-local</i>     | (Optional) |
| TABLE_rp                   | (Optional) |
| <i>rp-addr</i>             | (Optional) |
| <i>is-rp-local</i>         | (Optional) |
| <i>df-ordinal</i>          | (Optional) |
| <i>rp-uptime</i>           | (Optional) |
| <i>rp-priority</i>         | (Optional) |
| <i>is_atorp_source</i>     | (Optional) |
| <i>is_bsr_source</i>       | (Optional) |
| <i>is_static_source</i>    | (Optional) |
| <i>rp-source</i>           | (Optional) |
| <i>static-rp-group-map</i> | (Optional) |
| TABLE_grange               | (Optional) |
| <i>grange-grp</i>          | (Optional) |
| <i>grange-masklen</i>      | (Optional) |
| <i>grange-is-deny</i>      | (Optional) |
| <i>is-bidir-grp</i>        | (Optional) |
| <i>atorp-expires</i>       | (Optional) |
| <i>bsr-rp-expires</i>      | (Optional) |
| <i>rp-owner-flags</i>      | (Optional) |
| <i>bidir-ordinal</i>       | (Optional) |

|                          |            |
|--------------------------|------------|
| <i>df-bits-recovered</i> | (Optional) |
| <i>rpf-nbr-address</i>   | (Optional) |
| <i>metric</i>            | (Optional) |
| <i>metric-preference</i> | (Optional) |

**Command Mode**

- /exec

## show ipv6 pim statistics

```
show ipv6 pim statistics [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<vrf-name> [ <uptime> <reg-sent> <reg-rcvd> <null-reg-sent> <null-reg-rcvd> <reg-stop-sent> <reg-stop-rcvd>
<reg-rcvd-not-rp> <reg-rcvd-for-ssm> <reg-rcvd-for-bidir> <bootstrap-sent> <bootstrap-rcvd> <cand-rp-sent>
<cand-rp-rcvd> <bs-no-nbr> <bs-border-deny> <bs-len-errors> <bs-rpf-failed> <bs-no-listen>
<candrp-border-deny> <candrp-no-listen> <ctrl-no-route> <data-no-route> <no-state> <create-state> ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information             |
| ipv6                      | Display IPv6 information                    |
| pim                       | Display PIM6 status and configuration       |
| statistics                | Packet counter statistics                   |
| vrf                       | (Optional) Display per-VRF information      |
| <i>vrf-name</i>           | (Optional) VRF name                         |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                   |
| all                       | (Optional) Display information for all VRFs |
| __readonly__              | (Optional)                                  |
| TABLE_vrf                 | (Optional)                                  |
| <i>vrf-name</i>           | (Optional)                                  |
| <i>uptime</i>             | (Optional)                                  |
| <i>reg-sent</i>           | (Optional)                                  |
| <i>reg-rcvd</i>           | (Optional)                                  |
| <i>null-reg-sent</i>      | (Optional)                                  |
| <i>null-reg-rcvd</i>      | (Optional)                                  |
| <i>reg-stop-sent</i>      | (Optional)                                  |
| <i>reg-stop-rcvd</i>      | (Optional)                                  |
| <i>reg-rcvd-not-rp</i>    | (Optional)                                  |
| <i>reg-rcvd-for-ssm</i>   | (Optional)                                  |
| <i>reg-rcvd-for-bidir</i> | (Optional)                                  |
| <i>bootstrap-sent</i>     | (Optional)                                  |
| <i>bootstrap-rcvd</i>     | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>cand-rp-sent</i>       | (Optional) |
| <i>cand-rp-rcvd</i>       | (Optional) |
| <i>bs-no-nbr</i>          | (Optional) |
| <i>bs-border-deny</i>     | (Optional) |
| <i>bs-len-errors</i>      | (Optional) |
| <i>bs-rpf-failed</i>      | (Optional) |
| <i>bs-no-listen</i>       | (Optional) |
| <i>candrp-border-deny</i> | (Optional) |
| <i>candrp-no-listen</i>   | (Optional) |
| <i>ctrl-no-route</i>      | (Optional) |
| <i>data-no-route</i>      | (Optional) |
| <i>no-state</i>           | (Optional) |
| <i>create-state</i>       | (Optional) |

**Command Mode**

- /exec

## show ipv6 pim vrf

```
show ipv6 pim vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ detail | internal ] [ __readonly__ {
TABLE_context <out-context> <context-id> <count> <table-id> <bfd> <mvpn> [ <strict_rfc_compliant> ]
[ <global-mcast-bndry> ] } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                    |
| ipv6                        | Display IPv6 information                           |
| pim                         | Display PIM6 status and configuration              |
| vrf                         | Display per-VRF information                        |
| <i>vrf-name</i>             | (Optional) VRF name                                |
| <i>vrf-known-name</i>       | (Optional) Known VRF name                          |
| all                         | (Optional) Display all VRFs PIM6 is configured for |
| detail                      | (Optional) Display detailed information            |
| internal                    | (Optional) VRF related internal information        |
| __readonly__                | (Optional)   |
| TABLE_context               | (Optional)   |
| <i>out-context</i>          | (Optional)   |
| <i>context-id</i>           | (Optional)   |
| <i>table-id</i>             | (Optional)   |
| <i>count</i>                | (Optional)   |
| <i>bfd</i>                  | (Optional)   |
| <i>mvpn</i>                 | (Optional)   |
| <i>strict_rfc_compliant</i> | (Optional)   |
| <i>global-mcast-bndry</i>   | (Optional)   |

### Command Mode

- /exec

# show ipv6 policy

```
show ipv6 policy [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_pbr [ <interface> ] [ <rmap> ] [ <status> ] [ <vrf_name> ] } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | Display IPv6 information                    |
| policy                | Policy routing                              |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| __readonly__          | (Optional)                                  |
| TABLE_pbr             | (Optional)                                  |
| <i>interface</i>      | (Optional)                                  |
| <i>rmap</i>           | (Optional)                                  |
| <i>status</i>         | (Optional)                                  |
| <i>vrf_name</i>       | (Optional)                                  |

## Command Mode

- /exec

## show ipv6 prefix-list

```
show ipv6 prefix-list { [ detail | summary ] [ <ipv6-pfl-name> | <ipv6-pfl-cfg-name> ] } | { { <ipv6-pfl-name>
| <ipv6-pfl-cfg-name> } seq <seq-no> } | { { <ipv6-pfl-name> | <ipv6-pfl-cfg-name> } <prefix> [ first-match
| longer ] } } [ __readonly__ TABLE_ipv6_pfl <name> <seq> <action> <rule> ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information           |
| ipv6                     | Display IPv6 information                  |
| detail                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| summary                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| prefix-list              | List IPv6 prefix lists                    |
| <i>ipv6-pfl-name</i>     | (Optional) Name of prefix-list            |
| <i>ipv6-pfl-cfg-name</i> | (Optional) Known prefix-list name         |
| seq                      | Sequence number                           |
| <i>seq-no</i>            | Sequence number                           |
| first-match              | (Optional) Find the first match           |
| longer                   | (Optional) Find the more specific entries |
| <i>__readonly__</i>      | (Optional)                                |
| TABLE_ipv6_pfl           | (Optional)                                |
| <i>name</i>              | (Optional)                                |
| <i>seq</i>               | (Optional)                                |
| <i>action</i>            | (Optional)                                |
| <i>rule</i>              | (Optional)                                |

### Command Mode

- /exec



## show ipv6 process

```
show ipv6 process [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_ipv6_all {
<cnxt-name> <cnxt-id> } ] [ TABLE_ipv6 { <ipv6-vrf> <ipv6-vrf-id> <auto-disc> <auto-add> <sta-disc>
<sta-def> [ <ipv6-unreach> } ] [ TABLE_iod { <iod-val> <iod-ifind> } ] [ TABLE_ipv6_nxt { <ipv6-nxt>
} ] ] ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information        |
| ipv6                  | Display IPv6 information               |
| process               | Display IPv6 global information        |
| vrf                   | (Optional) Display per-VRF information |
| <i>vrf-name</i>       | (Optional) VRF name                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name              |
| all                   | (Optional) Display all VRFs            |
| <i>__readonly__</i>   | (Optional)                             |
| TABLE_ipv6_all        | (Optional) IPV6 process table          |
| <i>cnxt-name</i>      | (Optional) context name                |
| <i>cnxt-id</i>        | (Optional) context name                |
| TABLE_ipv6            | (Optional) ipv6 table                  |
| <i>ipv6-vrf</i>       | (Optional) vrf name                    |
| <i>ipv6-vrf-id</i>    | (Optional) vrf id                      |
| <i>auto-disc</i>      | (Optional) auto discard                |
| <i>auto-add</i>       | (Optional) auto add                    |
| <i>sta-disc</i>       | (Optional) static discard              |
| <i>sta-def</i>        | (Optional) static def                  |
| <i>ipv6-unreach</i>   | (Optional) ipv6 unreachable            |
| TABLE_iod             | (Optional) IOD table                   |
| <i>iod-val</i>        | (Optional) iod value                   |
| <i>iod-ifind</i>      | (Optional) iod if index                |
| TABLE_ipv6_nxt        | (Optional) ipv6 next hop table         |

**Command Mode**

- /exec

# show ipv6 raguard statistics

```
show ipv6 raguard statistics [ interface <intf-range> ] [ __readonly__ <msg_stats_hdr> [ <intf2> ] [ <rx_pkts> ] [ <drop_count> ] ]
```

## Syntax Description

|                      |                                       |
|----------------------|---------------------------------------|
| show                 | Show running system information       |
| ipv6                 | Show the IPv6 features of the system  |
| raguard              | IPV6 raguard                          |
| statistics           | RA packet drop count                  |
| interface            | (Optional) Raguard enabled interfaces |
| <i>intf-range</i>    | (Optional) interface                  |
| <i>__readonly__</i>  | (Optional) Read only                  |
| <i>msg_stats_hdr</i> | (Optional)                            |
| <i>intf2</i>         | (Optional) interface name             |
| <i>rx_pkts</i>       | (Optional)                            |
| <i>drop_count</i>    | (Optional)                            |

## Command Mode

- /exec

## show ipv6 rip policy statistics redistribute

```
show ipv6 rip [ instance <inst> ] policy statistics redistribute { bgp <as> | { eigrp | isis | <src-rip> | ospfv3 |
lisp } <tag> | direct | static } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_asn
<asn> TABLE_vrf <vrf> [ TABLE_rmap [ <name> <action> <seq_num> ] [ TABLE_cmd <command> [
<compare_count> ] <match_count> ] ] <total_accept_count> <total_reject_count> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| ipv6                  | Display IPv6 information                            |
| rip                   | Display RIP routing protocol status                 |
| instance              | (Optional) Process ID                               |
| <i>inst</i>           | (Optional) Process ID                               |
| policy                | Policy related information                          |
| statistics            | Policy statistics                                   |
| redistribute          | RIP redistribute routes from other routing protocol |
| bgp                   | Border Gateway Protocol (BGP)                       |
| <i>as</i>             | Autonomous system number                            |
| eigrp                 | Enhanced Interior Gateway Routing Protocol (EIGRP)  |
| isis                  | Intermediate-to-intermediate (ISIS)                 |
| src-rip               | Routing Information Protocol (RIP)                  |
| ospfv3                | Open Shortest Path First (OSPFv3)                   |
| lisp                  | LISP EID-prefixes                                   |
| <i>tag</i>            | Process tag   |
| direct                | Directly connected routes                           |
| static                | Static routes                                       |
| vrf                   | (Optional) Display per-VRF information              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| all                   | (Optional) Display information for all VRFs         |
| __readonly__          | (Optional)  |

|                           |   |
|---------------------------|---|
| TABLE_asn                 | (Optional) AS number table                                |
| <i>asn</i>                | (Optional) AS number                                      |
| TABLE_vrf                 | (Optional) VRF table                                      |
| <i>vrf</i>                | (Optional) VRF name                                       |
| TABLE_rmap                | (Optional) Routemap table                                 |
| <i>name</i>               | (Optional) Route-map Name                                 |
| <i>action</i>             | (Optional) Route-map action                               |
| <i>seq_num</i>            | (Optional) Sequence number of the rule in route-map       |
| TABLE_cmd                 | (Optional) Route-map command table                        |
| <i>command</i>            | (Optional) Route-map command                              |
| <i>compare_count</i>      | (Optional) Number of comparisons                          |
| <i>match_count</i>        | (Optional) Number of matches                              |
| <i>total_accept_count</i> | (Optional) Total number of packets accepted by the policy |
| <i>total_reject_count</i> | (Optional) Total number of packets rejected by the policy |

**Command Mode**

- /exec

## show ipv6 route

```
show ipv6 route [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ipv6-addr> | { <ipv6-prefix>
[ { longer-prefixes | shorter-prefixes } ] } ] [ { <ipv6-protocol> [ all ] } | { bind-label <bind-lbl> | next-hop
<next-hop> } | { interface <interface> } | { updated { [ since <stime> ] [ until <utime> ] } } ] + [ summary [
cached ] | summary-counter-consistency-check | { [ detail ] [ deleted ] } ] [ vrf { <vrf-name> |
<vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [
TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> [ <attached> ] TABLE_path [ <ubest> ] [ <mbest>
] [ <ipnexthop> ] [ <nexthop-vrf-name> ] [ <ifname> ] [ <bindlbl> ] [ <srv6-funct> ] <uptime> <pref> <metric>
<clientname> [ <type> ] [ <tag> ] [ <stale> ] [ <stalelbl> ] [ <hidden> ] [ <remote-sid> ] [ <src-ip> ] [ <sid-ct>
] [ <bsid> ] ] [ TABLE_summary <routes> <paths> [ <multicast_paths> ] [ TABLE_unicast [ <clientnameuni>
] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_multicast [ <clientnamemulti> ] [ <best-paths> ] [
<backup-paths> ] ] [ TABLE_route_count [ <mask_len> ] [ <count> ] ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ipv6                  | Display IPv6 information  |
| route                 | Display IPv6 routing table                                      |
| vrf                   | (Optional) Display per-VRF information                          |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| vrf-all               | (Optional) Display information for all VRFs                     |
| unicast               | (Optional) Display unicast information                          |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| <i>topology-name</i>  | (Optional) topology name  |
| l3vm-info             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| rpf                   | (Optional) Display RPF information for multicast source         |
| longer-prefixes       | (Optional) Display matching routes with mask-lengths >= prefix  |
| shorter-prefixes      | (Optional) Display matching routes with mask-lengths <= prefix  |
| <i>ipv6-protocol</i>  | (Optional) Display routes for protocol (or route type)          |
| all                   | (Optional) Display routes for protocol for backup next-hops too |
| bind-label            | (Optional) Display routes with this bind-label only             |
| <i>bind-lbl</i>       | (Optional) Binding label  |
| next-hop              | (Optional) Display routes with this next-hop only               |

|  |   |
|--|---|
| <i>interface</i>                         | (Optional) Display routes with this output interface only   |
| <i>interface</i>                         | (Optional) Interface Name                                   |
| <i>updated</i>                           | (Optional) Display routes filtered by last updated time     |
| <i>since</i>                             | (Optional) Display those routes updated since this time     |
| <i>stime</i>                             | (Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| <i>until</i>                             | (Optional) Display those routes updated until this time     |
| <i>utime</i>                             | (Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| <i>summary</i>                           | (Optional) Display route counts                             |
| <i>cached</i>                            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>summary-counter-consistency-check</i> | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>deleted</i>                           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>detail</i>                            | (Optional) Display routes in full detail                    |
| <i>__readonly__</i>                      | (Optional)  |
| <i>TABLE_vrf</i>                         | (Optional)  |
| <i>vrf-name-out</i>                      | (Optional)  |
| <i>TABLE_addrf</i>                       | (Optional)  |
| <i>addrf</i>                             | (Optional)  |
| <i>TABLE_prefix</i>                      | (Optional)  |
| <i>ucast-nhops</i>                       | (Optional)  |
| <i>mcast-nhops</i>                       | (Optional)  |
| <i>attached</i>                          | (Optional)  |
| <i>TABLE_path</i>                        | (Optional)  |
| <i>ubest</i>                             | (Optional)  |
| <i>mbest</i>                             | (Optional)  |
| <i>nexthop-vrf-name</i>                  | (Optional)  |
| <i>ifname</i>                            | (Optional)  |
| <i>bindlbl</i>                           | (Optional)  |
| <i>srv6-funct</i>                        | (Optional) Srv6 function                                    |
| <i>pref</i>                              | (Optional)  |

|                        |            |
|------------------------|------------|
| <i>tag</i>             | (Optional) |
| <i>metric</i>          | (Optional) |
| <i>uptime</i>          | (Optional) |
| <i>clientname</i>      | (Optional) |
| <i>type</i>            | (Optional) |
| <i>stale</i>           | (Optional) |
| <i>stalelbl</i>        | (Optional) |
| <i>hidden</i>          | (Optional) |
| <i>remote-sid</i>      | (Optional) |
| <i>sid-fct</i>         | (Optional) |
| TABLE_summary          | (Optional) |
| <i>routes</i>          | (Optional) |
| <i>paths</i>           | (Optional) |
| <i>multicast_paths</i> | (Optional) |
| TABLE_unicast          | (Optional) |
| <i>clientnameuni</i>   | (Optional) |
| <i>best-paths</i>      | (Optional) |
| <i>backup-paths</i>    | (Optional) |
| TABLE_multicast        | (Optional) |
| <i>clientnamemulti</i> | (Optional) |
| <i>best-paths</i>      | (Optional) |
| <i>backup-paths</i>    | (Optional) |
| TABLE_route_count      | (Optional) |
| <i>mask_len</i>        | (Optional) |
| <i>count</i>           | (Optional) |

### Command Mode

- /exec



## show ipv6 routers

```
show ipv6 routers [ all-routers ] [ [ interface <interface> ] | [ vrf { <vrf-name> | <vrf-known-name> | all } ] ] [ __readonly__ { TABLE_ipv6_routers [ TABLE_interface_ipv6 { <rtr-ipv6> <ipv6-int-addr> <rtr-flo-time> <curr-hop-lmt> <life-time> <addr-flag> <other-flg> <mtu-rtr> <hm-agent-flg> <preference> <reach-time> <retrans-time> [ TABLE_prefix_ipv6 { <ipv6-prefix> <buf-ipv6> <buf-autono> <valid-life-time> <prefer-life> } ] } ] } ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                             |
| ipv6                  | Display IPv6 information                                    |
| routers               | Display neighbor router information                         |
| all-routers           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| interface             | (Optional) Display neighbor router information on interface |
| <i>interface</i>      | (Optional) Interface name to display                        |
| vrf                   | (Optional) Display per-VRF information                      |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                   |
| all                   | (Optional) Display information for all VRFs                 |
| <u>__readonly__</u>   | (Optional)  |
| TABLE_ipv6_routers    | (Optional) ipv6 router table                                |
| TABLE_interface_ipv6  | (Optional) ipv6 interface table                             |
| <i>ipv6-int-addr</i>  | (Optional) ipv6 interface address                           |
| <i>rtr-flo-time</i>   | (Optional) last updated time                                |
| <i>curr-hop-lmt</i>   | (Optional) current hop limit                                |
| <i>life-time</i>      | (Optional) life time  |
| <i>addr-flag</i>      | (Optional) address flag                                     |
| <i>other-flg</i>      | (Optional) other flag                                       |
| <i>mtu-rtr</i>        | (Optional) router MTU                                       |
| <i>hm-agent-flg</i>   | (Optional) home agent flag                                  |
| <i>preference</i>     | (Optional) preference                                       |
| <i>reach-time</i>     | (Optional) reachable time                                   |

|                        |  |
|------------------------|--|
| <i>retrans-time</i>    | (Optional) retransmission time         |
| TABLE_prefix_ipv6      | (Optional) ipv6 prefix table           |
| <i>ipv6-prefix</i>     | (Optional) ipv6 prefix                 |
| <i>buf-ipv6</i>        | (Optional) ipv6 buffer                 |
| <i>buf-autono</i>      | (Optional) ipv6 buffer autonomous flag |
| <i>valid-life-time</i> | (Optional) ipv6 valid life time        |
| <i>prefer-life</i>     | (Optional) ipv6 preferred life time    |

**Command Mode**

- /exec

# show ipv6 snooping capture-policy

```
show ipv6 snooping capture-policy [ vlan <vlanid> ] [ interface <intf> ] [ __readonly__ <cmdout> ]
```

## Syntax Description

|                     |                                      |
|---------------------|--------------------------------------|
| show                | Show running system information      |
| ipv6                | Show the IPv6 features of the system |
| <i>vlanid</i>       | (Optional) VLAN ID                   |
| <i>intf</i>         | (Optional) interface                 |
| <i>__readonly__</i> | (Optional)                           |
| <i>cmdout</i>       | (Optional)                           |

## Command Mode

- /exec

## show ipv6 snooping counters vlan

```
show ipv6 snooping counters { { vlan <vlanid> } | { interface <intf> } } [ __readonly__ [ {
TABLE_target_counters <target> [ { TABLE_protocol_msgs <protocol_name> [ { TABLE_sub_protocol_msgs
[ <subfield_name> ] [ <msg_count> ] } ] } ] [ { TABLE_bridged_msgs <protocol_name> [ {
TABLE_sub_protocol_msgs [ <subfield_name> ] [ <msg_count> ] } ] } ] [ { TABLE_dropped_msgs
<feature_name> <protocol_name> [ { TABLE_sub_protocol_msgs [ <subfield_name> ] [ <msg_count> ] [
<drop_reason> ] } ] } ] } ] }
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information        |
| ipv6                    | Show the IPv6 features of the system   |
| <i>vlanid</i>           | VLAN ID                                |
| <i>intf</i>             | interface                              |
| <i>__readonly__</i>     | (Optional)                             |
| TABLE_target_counters   | (Optional) Policy counters per target  |
| <i>target</i>           | (Optional) Target Name                 |
| TABLE_protocol_msgs     | (Optional) Protocol messages table     |
| <i>protocol_name</i>    | (Optional) Protocol name               |
| TABLE_sub_protocol_msgs | (Optional) Protocol sub-messages table |
| <i>subfield_name</i>    | (Optional) Sub-field name              |
| <i>msg_count</i>        | (Optional) Message count               |
| TABLE_bridged_msgs      | (Optional) Bridged messages table      |
| <i>protocol_name</i>    | (Optional) Protocol name               |
| TABLE_sub_protocol_msgs | (Optional) Protocol sub-messages table |
| <i>subfield_name</i>    | (Optional) Sub-field name              |
| <i>msg_count</i>        | (Optional) Message count               |
| TABLE_dropped_msgs      | (Optional) Bridged messages table      |
| <i>feature_name</i>     | (Optional) Feature name                |
| <i>protocol_name</i>    | (Optional) Protocol name               |
| TABLE_sub_protocol_msgs | (Optional) Protocol sub-messages table |
| <i>subfield_name</i>    | (Optional) Sub-field name              |

|                    |                          |
|--------------------|--------------------------|
| <i>msg_count</i>   | (Optional) Message count |
| <i>drop_reason</i> | (Optional) Drop reason   |

**Command Mode**

- /exec

# show ipv6 snooping events

show ipv6 snooping events [ \_\_readonly\_\_ <cmdout> ]

## Syntax Description

|               |                                      |
|---------------|--------------------------------------|
| show          | Show running system information      |
| ipv6          | Show the IPv6 features of the system |
| __readonly__  | (Optional)                           |
| <i>cmdout</i> | (Optional)                           |

## Command Mode

- /exec

# show ipv6 snooping features

```
show ipv6 snooping features [ __readonly__ { TABLE_features <name> <priority> <state> } ]
```

## Syntax Description

|                 |                                      |
|-----------------|--------------------------------------|
| show            | Show running system information      |
| ipv6            | Show the IPv6 features of the system |
| __readonly__    | (Optional)                           |
| TABLE_features  | (Optional) IPv6 Snooping Features    |
| <i>name</i>     | (Optional) Name                      |
| <i>priority</i> | (Optional) Priority                  |
| <i>state</i>    | (Optional) State                     |

## Command Mode

- /exec

# show ipv6 snooping messages

show ipv6 snooping messages [ detailed <count> ] [ \_\_readonly\_\_ <cmdout> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information          |
| ipv6                | Show the IPv6 features of the system     |
| <i>count</i>        | (Optional) Number of messages to display |
| <i>__readonly__</i> | (Optional)                               |
| <i>cmdout</i>       | (Optional)                               |

## Command Mode

- /exec



# show ipv6 snooping policies

```
show ipv6 snooping policies { [ vlan <vlanid> ] | [ interface <intf> ] } [ __readonly__ { TABLE_policies
<target> <target_type> <policy> <feature> <target_range> } ]
```

## Syntax Description

|                     |                                      |
|---------------------|--------------------------------------|
| show                | Show running system information      |
| ipv6                | Show the IPv6 features of the system |
| <i>vlanid</i>       | (Optional) VLAN ID                   |
| <i>intf</i>         | (Optional) interface                 |
| <i>__readonly__</i> | (Optional)                           |
| TABLE_policies      | (Optional) IPv6 Snooping Policies    |
| <i>target</i>       | (Optional) Target Name               |
| <i>target_type</i>  | (Optional) Target Type               |
| <i>policy</i>       | (Optional) Policy Name               |
| <i>feature</i>      | (Optional) Feature                   |
| <i>target_range</i> | (Optional) Target Range              |

## Command Mode

- /exec

## show ipv6 snooping policy

```
show ipv6 snooping policy [ <policy_name> ] [ __readonly__ { [ TABLE_glean_policy <policy> [ <port_type>
] <sec_lvl> <device_role> [ <data_glean> ] [ <dest_glean> ] [ <glean_type> ] [ <reachable_lifetime> ] [
<stale_lifetime> ] } { [ TABLE_non_glean_protocols | TABLE_glean_protocols # 395
../feature/sisf/core/nxos/src/sisf_glean_dme.cmd <protocol> [ <prefix_list> ] ] } [ <limit_address_cnt> ] [
<limit_address_cnt_v4_per_mac> ] [ <limit_address_cnt_v6_per_mac> ] [ <limit_address_cnt_v4_per_target>
] [ <tracking> ] { { [ TABLE_targets <target> <target_type> <target_policy> <feature> <target_range> ] } }
]
```

### Syntax Description

|  |  |
|--|--|
| show                                   | Show running system information              |
| ipv6                                   | Show the IPv6 features of the system         |
| <i>policy_name</i>                     | (Optional) Policy name for feature snooping  |
| <i>__readonly__</i>                    | (Optional)                                   |
| TABLE_glean_policy                     | (Optional) IPv6 DHCP guard policy            |
| <i>policy</i>                          | (Optional) Policy Name                       |
| <i>port_type</i>                       | (Optional) Port type                         |
| <i>sec_lvl</i>                         | (Optional) Security level                    |
| <i>device_role</i>                     | (Optional) Device role                       |
| <i>data_glean</i>                      | (Optional) Data glean                        |
| <i>dest_glean</i>                      | (Optional) Destination glean                 |
| <i>glean_type</i>                      | (Optional) Glean type                        |
| <i>reachable_lifetime</i>              | (Optional) Reachable lifetime                |
| <i>stale_lifetime</i>                  | (Optional) Stale lifetime                    |
| TABLE_non_glean_protocols              | (Optional) Non Glean protocols               |
| <i>protocol</i>                        | (Optional) Protocol                          |
| TABLE_glean_protocols                  | (Optional) Glean protocols                   |
| <i>prefix_list</i>                     | (Optional) Prefix list                       |
| <i>limit_address_cnt</i>               | (Optional) Limit address count               |
| <i>limit_address_cnt_v4_per_mac</i>    | (Optional) Limit address count v4 per mac    |
| <i>limit_address_cnt_v6_per_mac</i>    | (Optional) Limit address count v6 per mac    |
| <i>limit_address_cnt_v4_per_target</i> | (Optional) Limit address count v4 per target |

|                      |                          |
|----------------------|--------------------------|
| <i>tracking</i>      | (Optional) Tracking      |
| TABLE_targets        | (Optional) Targets table |
| <i>target</i>        | (Optional) Target Name   |
| <i>target_type</i>   | (Optional) Target Type   |
| <i>target_policy</i> | (Optional) Policy Name   |
| <i>feature</i>       | (Optional) Feature       |
| <i>target_range</i>  | (Optional) Target Range  |

**Command Mode**

- /exec

# show ipv6 snooping pss database

show ipv6 snooping pss database [ \_\_readonly\_\_ <cmdout> ]

## Syntax Description

|               |                                      |
|---------------|--------------------------------------|
| show          | Show running system information      |
| ipv6          | Show the IPv6 features of the system |
| __readonly__  | (Optional)                           |
| <i>cmdout</i> | (Optional)                           |

## Command Mode

- /exec

## show ipv6 static-route

```
show ipv6 static-route [ <prefix> ] [ multicast ] [ track-table ] [ vrf { <vrf-name> | <vrf-known-name> | all }
] [ __readonly__ [ TABLE_vrf <vrf-name-out> ] [ TABLE_route [ <prefix-out> ] [ <next-hop> ] [ <intf-name>
] [ <pref> ] [ <next-hop-vrf> ] [ <reslv-tid> ] [ <real-nh> ] [ <has-real-intf> ] [ <real-intf-name> ] [ <track-id>
] [ <track-status> ] [ <rnh-status> ] [ <bfd-status> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                       |
| ipv6                  | Display IPv6 information  |
| static-route          | Display configured static routes                                      |
| track-table           | (Optional) Display track object details associated with static routes |
| multicast             | (Optional) Display configured static mroutes                          |
| all                   | (Optional) Display all VRFs   |
| vrf                   | (Optional) Display per-VRF information                                |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| <i>__readonly__</i>   | (Optional)  |
| TABLE_vrf             | (Optional) VRF table  |
| <i>vrf-name-out</i>   | (Optional) vrf name   |
| TABLE_route           | (Optional) Route table  |
| <i>intf-name</i>      | (Optional) interface name   |
| <i>pref</i>           | (Optional) interface prefix   |
| <i>next-hop-vrf</i>   | (Optional) next hop vrf   |
| <i>reslv-tid</i>      | (Optional) reslv tid  |
| <i>has-real-intf</i>  | (Optional) has real interface   |
| <i>real-intf-name</i> | (Optional) real interface name  |
| <i>track-id</i>       | (Optional) interface track id   |
| <i>track-status</i>   | (Optional) interface track status                                     |
| <i>rnh-status</i>     | (Optional) interface rn timer status                                  |
| <i>bfd-status</i>     | (Optional) interface bfd status                                       |

**Command Mode**

- /exec

# show ipv6 traffic

```
show ipv6 traffic [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] [ __readonly__ [ TABLE_vrf
<vrf-name-out> ] TABLE_ipv6_traffic <uptime> <upkt-fwd> <mpkt-fwd> <ubyte-fwd> <mbyte-fwd>
<upkt-orig> <mpkt-orig> <ubyte-orig> <mbyte-orig> <upkt-consumed> <mpkt-consumed> <ubyte-consumed>
<mbyte-consumed> <ufrag-orig> <mfra-orig> <ufrag-consumed> <mfrag-consumed> <bad-version>
<rt-lookup-fail> <hoplimit-excd> <opt-header-error> <pld-length-too-small> <pm-failed> <mbuf-error>
<could-not-enc> <dest-if-down> <rx-pkts-recv> <rx-bytes-recv> <rx-inhdrrerrors> <rx-innoroutes>
<rx-inaddrrerrors> <rx-inunknownprotos> <rx-intruncatedpkts> <rx-inforwdgrams> <rx-reasmreqds>
<rx-reasmoks> <rx-reasmfails> <rx-indiscards> <rx-indelivers> <rx-inmcastpkts> <rx-inmcastbytes>
<tx-pkts-sent> <tx-bytes-sent> <tx-outrequests> <tx-outnoroutes> <tx-outforwdgrams> <tx-outdiscards>
<tx-outfragreqds> <tx-outfragoks> <tx-outfragfails> <tx-outfragcreates> <tx-outtransmits> <tx-outmcastpkts>
<tx-outmcastbytes> ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| ipv6                  | Display IPv6 information                        |
| traffic               | Display IPv6 traffic statistics                 |
| detail                | (Optional) Display per protocol IPv6 statistics |
| vrf                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED       |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| <i>__readonly__</i>   | (Optional)                                      |
| TABLE_vrf             | (Optional) VRF table                            |
| <i>vrf-name-out</i>   | (Optional) vrf name                             |
| TABLE_ipv6_traffic    | (Optional) ipv6 traffic table                   |
| <i>uptime</i>         | (Optional) up time                              |
| <i>upkt-fwd</i>       | (Optional) unicast packets forward              |
| <i>mpkt-fwd</i>       | (Optional) multicast packets forward            |
| <i>ubyte-fwd</i>      | (Optional) unicast byte forward                 |
| <i>mbyte-fwd</i>      | (Optional) multicast byte forward               |
| <i>upkt-orig</i>      | (Optional) unicast packet origin                |
| <i>mpkt-orig</i>      | (Optional) multicast packet origin              |
| <i>ubyte-orig</i>     | (Optional) unicast byte origin                  |

|                             |  |
|-----------------------------|--|
| <i>mbyte-orig</i>           | (Optional) multicast byte origin       |
| <i>upkt-consumed</i>        | (Optional) unicast packet consumed     |
| <i>mpkt-consumed</i>        | (Optional) multicast packet consumed   |
| <i>ubyte-consumed</i>       | (Optional) unicast byte consumed       |
| <i>mbyte-consumed</i>       | (Optional) multicast byte consumed     |
| <i>ufrag-orig</i>           | (Optional) unicast fragment origin     |
| <i>mfra-orig</i>            | (Optional) multicast fragment origin   |
| <i>ufrag-consumed</i>       | (Optional) unicast fragment consumed   |
| <i>mfrag-consumed</i>       | (Optional) multicast fragment consumed |
| <i>bad-version</i>          | (Optional) bad version                 |
| <i>rt-lookup-fail</i>       | (Optional) route lookup fail           |
| <i>hoplimit-excd</i>        | (Optional) hoplimit exceeded           |
| <i>opt-header-error</i>     | (Optional) opt header error            |
| <i>pld-length-too-small</i> | (Optional) pld length too small        |
| <i>pm-failed</i>            | (Optional) packet manager failed       |
| <i>mbuf-error</i>           | (Optional) m-buffer error              |
| <i>could-not-enc</i>        | (Optional) could not encode            |
| <i>dest-if-down</i>         | (Optional) destination if down         |
| <i>rx-pkts-recv</i>         | (Optional) packets received            |
| <i>rx-bytes-recv</i>        | (Optional) bytes received              |
| <i>rx-inhdrrerrors</i>      | (Optional) inhdr error                 |
| <i>rx-innoroutes</i>        | (Optional) in-no routes                |
| <i>rx-inaddrerrors</i>      | (Optional) in-address error            |
| <i>rx-inunknownprotos</i>   | (Optional) in-unknown protocol         |
| <i>rx-intruncatedpkts</i>   | (Optional) in-truncated packets        |
| <i>rx-inforwdgrams</i>      | (Optional) in-forward                  |
| <i>rx-reasmreqds</i>        | (Optional) reasm request               |
| <i>rx-reasmoks</i>          | (Optional) reasm ok                    |
| <i>rx-reasmfails</i>        | (Optional) reasm fail                  |



|                          |                                  |
|--------------------------|----------------------------------|
| <i>rx-indiscards</i>     | (Optional) in-discards           |
| <i>rx-indelivers</i>     | (Optional) in-delivers           |
| <i>rx-inmcastpkts</i>    | (Optional) in multicast packets  |
| <i>rx-inmcastbytes</i>   | (Optional) in multicast bytes    |
| <i>tx-pkts-sent</i>      | (Optional) packets sent          |
| <i>tx-bytes-sent</i>     | (Optional) bytes sent            |
| <i>tx-outrequests</i>    | (Optional) out request           |
| <i>tx-outnoroutes</i>    | (Optional) out no routes         |
| <i>tx-outforwdgrams</i>  | (Optional) out forwardgrams      |
| <i>tx-outdiscards</i>    | (Optional) out discards          |
| <i>tx-outfragreqds</i>   | (Optional) out fragment request  |
| <i>tx-outfragoks</i>     | (Optional) out fragment oks      |
| <i>tx-outfragfails</i>   | (Optional) out fragment fails    |
| <i>tx-outfragcreates</i> | (Optional) out fragment creates  |
| <i>tx-outtransmits</i>   | (Optional) out transmits         |
| <i>tx-outmcastpkts</i>   | (Optional) out multicast packets |
| <i>tx-outmcastbytes</i>  | (Optional) out multicast bytes   |

**Command Mode**

- /exec

## show isis

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ process | protocol ] [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <instance_num> <uuid>
<process-id> <vrf-name-out> <system-id-out> <is-type-out> <sap-out> <qh-out> <mtu-out> [ <gr-status-out>
] [ <gr-state-active-out> ] [ <gr-state-inactive-out> ] [ <last-gr-status-fail-out> ] [ <last-gr-status-success-out>
] [ <last-gr-status-none-out> ] [ <gr-status-disable-out> ] [ TABLE_afi_safi <af-ix> <af-bfd-config>
<af-pib-tag> ] <metric-style> <accept-metric> [ <net-set-none> ] [ TABLE_area_addr <area-addr-nsap> ] [
<proc-state-not-config> ] [ <proc-state-admin-down> ] [ <proc-state-l3vm-down> ] [
<proc-state-unknown-down> ] [ <proc-state-not-specified> ] [ <proc-state-no-net> ] [ <proc-state-no-vrf-id>
] [ <proc-state-out-memory> ] [ <proc-state-restart> ] [ <proc-state-running> ] <vrf-id-out> [ TABLE_te
<te-lvl-out> <te-lvl-active> ] [ <te-ted-out> ] [ <mpls-te-out> ] [ TABLE_mpls_te [ <mpls-te-lvl-out> ] [
<mpls-te-rtrid-intf-out> ] [ <mpls-te-fa-lvl-out> ] [ TABLE_te_fa <te-fa-sysid-out> <te-fa-intf-out> ] [
<te-stat-sys-id-out> ] [ <te-stat-rtr-id-out> ] [ TABLE_te_stat_lvl <te-stat-lvl-out> <te-stat-up-out>
<te-stat-down-out> ] [ <srte-registered-out> ] [ TABLE_segment_routing <af-out> <ptag-out> <cfg-out>
<enable-out> [ <exp-null-cfg> ] ] [ <srv6-enabled> ] [ TABLE_iib_list yeild <intf-name-out> ] [ TABLE_auth
<auth-lvl-out> [ <auth-type-no-type> ] [ <auth-type-clear-text> ] [ <auth-type-md5> ] [ <auth-type-key-chain>
] [ <auth-type-none> ] [ <auth-check> ] [ <auth-no-check> ] ] [ TABLE_spf <spf-lvl-out> [ <spf-timer> ] ]
[ TABLE_distribute_ls <distribute-linkst-lvl> ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information              |
| isis                   | Display IS-IS status and configuration       |
| <i>isis-tag</i>        | (Optional) Routing process tag               |
| vrf                    | (Optional) Display per-VRF information       |
| <i>vrf-name</i>        | (Optional) VRF name                          |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                    |
| all                    | (Optional) Display information for all VRFs  |
| process                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED    |
| protocol               | (Optional) Display IS-IS process information |
| __readonly__           | (Optional)                                   |
| TABLE_process_tag      | (Optional)                                   |
| <i>process-tag-out</i> | (Optional)                                   |
| <i>instance_num</i>    | (Optional)                                   |
| <i>uuid</i>            | (Optional)                                   |
| <i>process-id</i>      | (Optional)                                   |
| <i>vrf-name-out</i>    | (Optional)                                   |

|                                   |            |
|-----------------------------------|------------|
| <i>system-id-out</i>              | (Optional) |
| <i>is-type-out</i>                | (Optional) |
| <i>sap-out</i>                    | (Optional) |
| <i>qh-out</i>                     | (Optional) |
| <i>mtu-out</i>                    | (Optional) |
| <i>gr-status-out</i>              | (Optional) |
| <i>gr-state-active-out</i>        | (Optional) |
| <i>gr-state-inactive-out</i>      | (Optional) |
| <i>last-gr-status-fail-out</i>    | (Optional) |
| <i>last-gr-status-success-out</i> | (Optional) |
| <i>last-gr-status-none-out</i>    | (Optional) |
| <i>gr-status-disable-out</i>      | (Optional) |
| TABLE_afi_safi                    | (Optional) |
| <i>af-ix</i>                      | (Optional) |
| <i>af-bfd-config</i>              | (Optional) |
| <i>af-pib-tag</i>                 | (Optional) |
| <i>metric-style</i>               | (Optional) |
| <i>accept-metric</i>              | (Optional) |
| <i>net-set-none</i>               | (Optional) |
| TABLE_area_addr                   | (Optional) |
| <i>area-addr-nsap</i>             | (Optional) |
| <i>proc-state-not-config</i>      | (Optional) |
| <i>proc-state-admin-down</i>      | (Optional) |
| <i>proc-state-l3vm-down</i>       | (Optional) |
| <i>proc-state-unknown-down</i>    | (Optional) |
| <i>proc-state-not-specified</i>   | (Optional) |
| <i>proc-state-no-net</i>          | (Optional) |
| <i>proc-state-no-vrf-id</i>       | (Optional) |
| <i>proc-state-out-memory</i>      | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>proc-state-restart</i>     | (Optional) |
| <i>proc-state-running</i>     | (Optional) |
| <i>vrf-id-out</i>             | (Optional) |
| TABLE_te                      | (Optional) |
| <i>te-lvl-out</i>             | (Optional) |
| <i>te-lvl-active</i>          | (Optional) |
| <i>te-ted-out</i>             | (Optional) |
| <i>mpls-te-out</i>            | (Optional) |
| TABLE_mpls_te                 | (Optional) |
| <i>mpls-te-lvl-out</i>        | (Optional) |
| <i>mpls-te-rtrid-intf-out</i> | (Optional) |
| <i>mpls-te-fa-lvl-out</i>     | (Optional) |
| TABLE_te_fa                   | (Optional) |
| <i>te-fa-sysid-out</i>        | (Optional) |
| <i>te-fa-intf-out</i>         | (Optional) |
| <i>te-stat-sys-id-out</i>     | (Optional) |
| <i>te-stat-rtr-id-out</i>     | (Optional) |
| TABLE_te_stat_lvl             | (Optional) |
| <i>te-stat-lvl-out</i>        | (Optional) |
| <i>te-stat-up-out</i>         | (Optional) |
| <i>te-stat-down-out</i>       | (Optional) |
| <i>srte-registered-out</i>    | (Optional) |
| TABLE_segment_routing         | (Optional) |
| <i>af-out</i>                 | (Optional) |
| <i>ptag-out</i>               | (Optional) |
| <i>cfg-out</i>                | (Optional) |
| <i>enable-out</i>             | (Optional) |
| <i>exp-null-cfg</i>           | (Optional) |
| <i>srv6-enabled</i>           | (Optional) |

|                              |            |
|------------------------------|------------|
| TABLE_iib_list_yeild         | (Optional) |
| <i>intf-name-out</i>         | (Optional) |
| TABLE_auth                   | (Optional) |
| <i>auth-lvl-out</i>          | (Optional) |
| <i>auth-type-no-type</i>     | (Optional) |
| <i>auth-type-cleartext</i>   | (Optional) |
| <i>auth-type-md5</i>         | (Optional) |
| <i>auth-type-key-chain</i>   | (Optional) |
| <i>auth-type-none</i>        | (Optional) |
| <i>auth-check</i>            | (Optional) |
| <i>auth-no-check</i>         | (Optional) |
| TABLE_spf                    | (Optional) |
| <i>spf-lvl-out</i>           | (Optional) |
| <i>spf-timer</i>             | (Optional) |
| TABLE_distribute_ls          | (Optional) |
| <i>distribute-linkst-lvl</i> | (Optional) |

**Command Mode**

- /exec

## show isis adjacency

```
show isis [<isis-tag>] [ vrf { <vrf-name> | <vrf-known-name> | all } ] adjacency [ <interface> [ p2p-level-1-2 ] ] [ { system-id <sid> } ] [ detail ] [ summary ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <adj-summary-out> <adj-interface-out> [ <adj-interface-name-out> ] [ { TABLE_process_adj <adj-sys-name-out> <adj-sys-id-out> [ <adj-usage-out> ] [ <adj-level-out> ] <adj-state-out> <adj-hold-time-out> <adj-intf-name-out> <adj-detail-set-out> [ [ { TABLE_area_address <adj-area-addr-out> } ] <adj-transitions-out> <adj-flap-out> [ <adj-flap-time-out> ] <adj-ckt-type-out> <adj-ipv4-addr-out> <adj-ipv6-addr-out> <adj-bcast-out> [ { <adj-ckt-id-out> <adj-lan-prio-out> } ] <adj-bfd-ipv4-establish-out> <adj-bfd-ipv6-establish-out> <adj-resurrect-out> [ { <adj-resurrect-count-out> <adj-resurrect-hwm-out> } ] <adj-restart-capable-out> <adj-restart-ack-out> [ { <adj-restart-mode-out> <adj-restart-adj-seen-ra-out> <adj-restart-adj-seen-csnp-out> <adj-restart-adj-seen-l1-csnp-out> <adj-restart-adj-seen-l2-csnp-out> <adj-restart-suppress-adj-out> } ] [ { TABLE_adj_sid <adj-sid-value> <adj-sid-f-flag> <adj-sid-b-flag> <adj-sid-v-flag> <adj-sid-l-flag> <adj-sid-s-flag> <adj-sid-p-flag> <adj-sid-weight> } ] } ] [ { TABLE_p2p_adj_sum <adj-summ-p2p-level-out> <adj-summ-p2p-state-out> <adj-summ-p2p-count-out> } ] [ { TABLE_lan_adj_sum <adj-summ-lan-level-out> <adj-summ-lan-state-out> <adj-summ-lan-count-out> } ] } ] }
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                  |
| isis                   | Display IS-IS status and configuration                           |
| <i>isis-tag</i>        | (Optional) Routing process tag                                   |
| vrf                    | (Optional) Display per-VRF information                           |
| <i>vrf-name</i>        | (Optional) VRF name  |
| <i>vrf-known-name</i>  | (Optional) Known VRF name  |
| all                    | (Optional) Display information for all VRFs                      |
| adjacency              | Display IS-IS adjacency information                              |
| <i>interface</i>       | (Optional) IS-IS interface                                       |
| system-id              | (Optional) Hostname or System ID                                 |
| <i>sid</i>             | (Optional) Hostname or System ID (in the form of XXXX.XXXX.XXXX) |
| detail                 | (Optional) Display IS-IS adjacency detail information            |
| p2p-level-1-2          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                        |
| summary                | (Optional) Display IS-IS adjacency summary information           |
| __readonly__           | (Optional)   |
| TABLE_process_tag      | (Optional)   |
| <i>process-tag-out</i> | (Optional)   |

|                                   |            |
|-----------------------------------|------------|
| TABLE_vrf                         | (Optional) |
| <i>vrf-name-out</i>               | (Optional) |
| <i>adj-summary-out</i>            | (Optional) |
| <i>adj-interface-out</i>          | (Optional) |
| <i>adj-interface-name-out</i>     | (Optional) |
| TABLE_process_adj                 | (Optional) |
| <i>adj-sys-name-out</i>           | (Optional) |
| <i>adj-sys-id-out</i>             | (Optional) |
| <i>adj-usage-out</i>              | (Optional) |
| <i>adj-level-out</i>              | (Optional) |
| <i>adj-state-out</i>              | (Optional) |
| <i>adj-hold-time-out</i>          | (Optional) |
| <i>adj-intf-name-out</i>          | (Optional) |
| <i>adj-detail-set-out</i>         | (Optional) |
| TABLE_area_address                | (Optional) |
| <i>adj-area-addr-out</i>          | (Optional) |
| <i>adj-transitions-out</i>        | (Optional) |
| <i>adj-flap-out</i>               | (Optional) |
| <i>adj-flap-time-out</i>          | (Optional) |
| <i>adj-ckt-type-out</i>           | (Optional) |
| <i>adj-ipv4-addr-out</i>          | (Optional) |
| <i>adj-ipv6-addr-out</i>          | (Optional) |
| <i>adj-bcast-out</i>              | (Optional) |
| <i>adj-ckt-id-out</i>             | (Optional) |
| <i>adj-lan-prio-out</i>           | (Optional) |
| <i>adj-bfd-ipv4-establish-out</i> | (Optional) |
| <i>adj-bfd-ipv6-establish-out</i> | (Optional) |
| <i>adj-resurrect-out</i>          | (Optional) |
| <i>adj-resurrect-count-out</i>    | (Optional) |

|   |            |
|---|------------|
| <i>adj-resurrect-hwm-out</i>            | (Optional) |
| <i>adj-restart-capable-out</i>          | (Optional) |
| <i>adj-restart-ack-out</i>              | (Optional) |
| <i>adj-restart-mode-out</i>             | (Optional) |
| <i>adj-restart-adj-seen-ra-out</i>      | (Optional) |
| <i>adj-restart-adj-seen-csnp-out</i>    | (Optional) |
| <i>adj-restart-adj-seen-l1-csnp-out</i> | (Optional) |
| <i>adj-restart-adj-seen-l2-csnp-out</i> | (Optional) |
| <i>adj-restart-suppress-adj-out</i>     | (Optional) |
| TABLE_adj_sid                           | (Optional) |
| <i>adj-sid-value</i>                    | (Optional) |
| <i>adj-sid-f-flag</i>                   | (Optional) |
| <i>adj-sid-b-flag</i>                   | (Optional) |
| <i>adj-sid-v-flag</i>                   | (Optional) |
| <i>adj-sid-l-flag</i>                   | (Optional) |
| <i>adj-sid-s-flag</i>                   | (Optional) |
| <i>adj-sid-p-flag</i>                   | (Optional) |
| <i>adj-sid-weight</i>                   | (Optional) |
| TABLE_p2p_adj_sum                       | (Optional) |
| <i>adj-summ-p2p-level-out</i>           | (Optional) |
| <i>adj-summ-p2p-state-out</i>           | (Optional) |
| <i>adj-summ-p2p-count-out</i>           | (Optional) |
| TABLE_lan_adj_sum                       | (Optional) |
| <i>adj-summ-lan-level-out</i>           | (Optional) |
| <i>adj-summ-lan-state-out</i>           | (Optional) |
| <i>adj-summ-lan-count-out</i>           | (Optional) |

**Command Mode**

- /exec



## show isis csnp

```
show isis [ <isis-tag> ] csnp [ detail ] [ __readonly__ TABLE_process_tag <process-tag-out> [ {
TABLE_CSNPLEVEL <csnp-level> <csnp-cache-valid> <csnp-cache-hit> <cscnp-cache-miss> <csnp-hit-rate>
[ { TABLE_CSNPLSPS <csnp-start-lsp-id> <csnp-end-lsp-id> <csnp-entry-valid> <csnp-pdu-lengh> [ {
TABLE_CSNPONELSP <csnp-lsp-id> <csnp-lsp-seq-num> <csnp-lsp-chk-sum> <csnp-lsp-life-time> } ] }
] } ] }
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information               |
| isis                     | Display IS-IS status and configuration        |
| <i>isis-tag</i>          | (Optional) Routing process tag                |
| csnp                     | Display IS-IS CSNP cache contents             |
| detail                   | (Optional) Display detailed IS-IS information |
| <i>__readonly__</i>      | (Optional)                                    |
| TABLE_process_tag        | (Optional)                                    |
| <i>process-tag-out</i>   | (Optional)                                    |
| TABLE_CSNPLEVEL          | (Optional)                                    |
| <i>csnp-level</i>        | (Optional)                                    |
| <i>csnp-cache-valid</i>  | (Optional)                                    |
| <i>csnp-cache-hit</i>    | (Optional)                                    |
| <i>cscnp-cache-miss</i>  | (Optional)                                    |
| <i>csnp-hit-rate</i>     | (Optional)                                    |
| TABLE_CSNPLSPS           | (Optional)                                    |
| <i>csnp-start-lsp-id</i> | (Optional)                                    |
| <i>csnp-end-lsp-id</i>   | (Optional)                                    |
| <i>csnp-entry-valid</i>  | (Optional)                                    |
| <i>csnp-pdu-lengh</i>    | (Optional)                                    |
| TABLE_CSNPONELSP         | (Optional)                                    |
| <i>csnp-lsp-id</i>       | (Optional)                                    |
| <i>csnp-lsp-seq-num</i>  | (Optional)                                    |
| <i>csnp-lsp-chk-sum</i>  | (Optional)                                    |

|                           |            |
|---------------------------|------------|
| <i>csnp-lsp-life-time</i> | (Optional) |
|---------------------------|------------|

**Command Mode**

- /exec

## show isis database

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database [ <level> ] [ detail | advertise
| summary ] [ <lid> ] { [ zero-sequence ] | [ ip prefix <ip-prefix> ] | [ ipv6 prefix <ipv6-prefix> ] | [ router-id
<rid> ] | [ adjacency <adj-id> ] } [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ {
TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> [ <dbase-hname-absent-out> ] [ {
TABLE_process_lvl <dbase-level-out> [ { TABLE_process_lsp <dbase-lsp-name-out> <dbase-lsp-status-out>
<dbase-lsp-absent-out> [ { <dbase-lsp-seqnum-out> <dbase-lsp-cksum-out> [ <dbase-lsp-lifetime-str-out> ]
[ <dbase-lsp-lifetime-out> ] <dbase-att-out> <dbase-partition-out> <dbase-overload-out> <dbase-istype-out>
} ] [ { <dbase-lsp-instance-out> [ { TABLE_process_tlv <dbase-lsp-tlv-name-out> [ <dbase-lsp-area-addr-out>
] [ <dbase-lsp-is-nbr-name-out> ] [ <dbase-lsp-is-nbr-metric-out> ] [ <dbase-lsp-is-nbr-ext-metric-out> ] [
<dbase-lsp-es-nbr-name-out> ] [ <dbase-lsp-es-nbr-metric-out> ] [ <dbase-lsp-es-nbr-ext-metric-out> ] [
<dbase-lsp-auth-type-out> ] [ <dbase-lsp-auth-len-out> ] [ { TABLE_process_extis [
<dbase-lsp-ext-is-name-out> ] [ <dbase-lsp-ext-is-metric-out> ] } ] [ <dbase-lsp-ip-ri-addr-out> ] [
<dbase-lsp-ip-ri-mask-out> ] [ <dbase-lsp-ip-ri-metric-out> ] [ <dbase-lsp-ip-ri-ext-metric-out> ] [
<dbase-lsp-ip-ri-up-down-out> ] [ <dbase-lsp-cap-rtrid> ] [ <dbase-lsp-cap-flags> ] [ { TABLE_process_nlpid
<dbase-lsp-prot-support-out> } ] [ <dbase-lsp-ip-addr-out> ] [ <dbase-lsp-ipv6-addr-out> ] [ {
TABLE_process_extip <dbase-lsp-extip-addr-out> <dbase-lsp-extip-prefix-len-out>
<dbase-lsp-extip-metric-out> <dbase-lsp-extip-up-down-out> [ <dbase-lsp-extip-pfxsid> ] [
<dbase-lsp-extip-pfxsid-algo> ] [ <dbase-lsp-extip-pfxsid-flags> ] [ <dbase-lsp-extip-unknown-out> ] } ] [
<dbase-lsp-hname-out> ] [ <dbase-lsp-hname-len-out> ] [ { TABLE_process_extipv6
<dbase-lsp-extipv6-addr-out> <dbase-lsp-extipv6-prefix-len-out> <dbase-lsp-extipv6-metric-out>
<dbase-lsp-extipv6-up-down-out> <dbase-lsp-extipv6-ext-origin-out> [ <dbase-lsp-extipv6-pfxsid> ] [
<dbase-lsp-extipv6-pfxsid-algo> ] [ <dbase-lsp-extipv6-pfxsid-flags> ] [ <dbase-lsp-extipv6-unknown-out>
] } ] [ { TABLE_process_subtlv <dbase-lsp-subtlv-name-out> [ <dbase-lsp-extis-admin-group-out> ] [
<dbase-lsp-subtlv-ip-addr-out> ] [ <dbase-lsp-extis-bw-out> ] [ <dbase-lsp-extis-pri1-out> ] [
<dbase-lsp-extis-pri1-val-out> ] [ <dbase-lsp-extis-pri2-out> ] [ <dbase-lsp-extis-pri2-val-out> ] [
<dbase-lsp-extis-te-metric-out> ] [ <dbase-lsp-extis-p2p-adsid-out> ] [ <dbase-lsp-extis-p2p-adsid-flags> ]
[ <dbase-lsp-extis-p2p-adsid-weight> ] [ <dbase-lsp-extis-lan-adsid-out> ] [ <dbase-lsp-extis-lan-adsid-sysid>
] [ <dbase-lsp-extis-lan-adsid-flags> ] [ <dbase-lsp-extis-lan-adsid-weight> ] [
<dbase-lsp-cap-subtlv-sr-start-sid> ] [ <dbase-lsp-cap-subtlv-sr-end-sid> ] [ <dbase-lsp-cap-subtlv-sr-range>
] [ <dbase-lsp-cap-subtlv-sr-flags> ] [ <dbase-lsp-subtlv-len-out> ] [ <dbase-lsp-subtlv-unknown-out> ] } ]
[ <dbase-lsp-tlv-len-out> ] [ <dbase-lsp-tlv-unknown-out> ] } ] <dbase-lsp-digest-out> } } ] [ {
<dbase-lsp-total-out> [ { <dbase-lsp-empty-out> <dbase-lsp-zeroseq-out> } } ] } ] }
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| isis                  | Display IS-IS status and configuration      |
| <i>isis-tag</i>       | (Optional) Routing process tag              |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| database              | Display IS-IS database information          |

|                                   |   |
|-----------------------------------|---|
| <i>level</i>                      | (Optional) IS-IS level                                |
| <i>lid</i>                        | (Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX |
| detail                            | (Optional) Display detailed IS-IS information         |
| advertise                         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| summary                           | (Optional) Display summary IS-IS information          |
| zero-sequence                     | (Optional) LSP with zero sequence number              |
| ip                                | (Optional) IP attribute filter                        |
| ipv6                              | (Optional) IPv6 attribute filter                      |
| prefix                            | (Optional) Prefix filter                              |
| <i>ip-prefix</i>                  | (Optional) Single exact match IP prefix filter        |
| adjacency                         | (Optional) Adjacency filter                           |
| <i>adj-id</i>                     | (Optional) Single exact match adjacency filter        |
| router-id                         | (Optional) Router-id filter                           |
| <i>rid</i>                        | (Optional) single exact match router-id filter        |
| <i>__readonly__</i>               | (Optional)  |
| TABLE_process_tag                 | (Optional)  |
| <i>process-tag-out</i>            | (Optional)  |
| TABLE_vrf                         | (Optional)  |
| <i>vrf-name-out</i>               | (Optional)  |
| <i>dbase-hname-absent-out</i>     | (Optional)  |
| TABLE_process_lvl                 | (Optional)  |
| <i>dbase-level-out</i>            | (Optional)  |
| TABLE_process_lsp                 | (Optional)  |
| <i>dbase-lsp-name-out</i>         | (Optional)  |
| <i>dbase-lsp-status-out</i>       | (Optional)  |
| <i>dbase-lsp-absent-out</i>       | (Optional)  |
| <i>dbase-lsp-seqnum-out</i>       | (Optional)  |
| <i>dbase-lsp-cksum-out</i>        | (Optional)  |
| <i>dbase-lsp-lifetime-str-out</i> | (Optional)  |

|  |            |
|--|------------|
| <i>dbase-lsp-lifetime-out</i>          | (Optional) |
| <i>dbase-att-out</i>                   | (Optional) |
| <i>dbase-partition-out</i>             | (Optional) |
| <i>dbase-overload-out</i>              | (Optional) |
| <i>dbase-istype-out</i>                | (Optional) |
| <i>dbase-lsp-instance-out</i>          | (Optional) |
| TABLE_process_tlv                      | (Optional) |
| <i>dbase-lsp-tlv-name-out</i>          | (Optional) |
| <i>dbase-lsp-area-addr-out</i>         | (Optional) |
| <i>dbase-lsp-is-nbr-name-out</i>       | (Optional) |
| <i>dbase-lsp-is-nbr-metric-out</i>     | (Optional) |
| <i>dbase-lsp-is-nbr-ext-metric-out</i> | (Optional) |
| <i>dbase-lsp-es-nbr-name-out</i>       | (Optional) |
| <i>dbase-lsp-es-nbr-metric-out</i>     | (Optional) |
| <i>dbase-lsp-es-nbr-ext-metric-out</i> | (Optional) |
| <i>dbase-lsp-auth-type-out</i>         | (Optional) |
| <i>dbase-lsp-auth-len-out</i>          | (Optional) |
| TABLE_process_extis                    | (Optional) |
| <i>dbase-lsp-ext-is-name-out</i>       | (Optional) |
| <i>dbase-lsp-ext-is-metric-out</i>     | (Optional) |
| <i>dbase-lsp-ip-ri-addr-out</i>        | (Optional) |
| <i>dbase-lsp-ip-ri-mask-out</i>        | (Optional) |
| <i>dbase-lsp-ip-ri-metric-out</i>      | (Optional) |
| <i>dbase-lsp-ip-ri-ext-metric-out</i>  | (Optional) |
| <i>dbase-lsp-ip-ri-up-down-out</i>     | (Optional) |
| TABLE_process_nlpid                    | (Optional) |
| <i>dbase-lsp-prot-support-out</i>      | (Optional) |
| <i>dbase-lsp-ip-addr-out</i>           | (Optional) |
| <i>dbase-lsp-ipv6-addr-out</i>         | (Optional) |

|   |            |
|---|------------|
| TABLE_process_extip                     | (Optional) |
| <i>dbase-lsp-extip-addr-out</i>         | (Optional) |
| <i>dbase-lsp-extip-prefix-len-out</i>   | (Optional) |
| <i>dbase-lsp-extip-metric-out</i>       | (Optional) |
| <i>dbase-lsp-extip-up-down-out</i>      | (Optional) |
| <i>dbase-lsp-extip-pfxsid</i>           | (Optional) |
| <i>dbase-lsp-extip-pfxsid-algo</i>      | (Optional) |
| <i>dbase-lsp-extip-pfxsid-flags</i>     | (Optional) |
| <i>dbase-lsp-extip-unknown-out</i>      | (Optional) |
| <i>dbase-lsp-hname-out</i>              | (Optional) |
| <i>dbase-lsp-hname-len-out</i>          | (Optional) |
| TABLE_process_extipv6                   | (Optional) |
| <i>dbase-lsp-extipv6-addr-out</i>       | (Optional) |
| <i>dbase-lsp-extipv6-prefix-len-out</i> | (Optional) |
| <i>dbase-lsp-extipv6-metric-out</i>     | (Optional) |
| <i>dbase-lsp-extipv6-up-down-out</i>    | (Optional) |
| <i>dbase-lsp-extipv6-ext-origin-out</i> | (Optional) |
| <i>dbase-lsp-extipv6-pfxsid</i>         | (Optional) |
| <i>dbase-lsp-extipv6-pfxsid-algo</i>    | (Optional) |
| <i>dbase-lsp-extipv6-pfxsid-flags</i>   | (Optional) |
| <i>dbase-lsp-extipv6-unknown-out</i>    | (Optional) |
| <i>dbase-lsp-tlv-len-out</i>            | (Optional) |
| <i>dbase-lsp-tlv-unknown-out</i>        | (Optional) |
| TABLE_process_subtlv                    | (Optional) |
| <i>dbase-lsp-subtlv-name-out</i>        | (Optional) |
| <i>dbase-lsp-extis-admin-group-out</i>  | (Optional) |
| <i>dbase-lsp-subtlv-ip-addr-out</i>     | (Optional) |
| <i>dbase-lsp-extis-bw-out</i>           | (Optional) |
| <i>dbase-lsp-extis-pri1-out</i>         | (Optional) |

|  |            |
|--|------------|
| <i>dbase-lsp-extis-pri1-val-out</i>      | (Optional) |
| <i>dbase-lsp-extis-pri2-out</i>          | (Optional) |
| <i>dbase-lsp-extis-pri2-val-out</i>      | (Optional) |
| <i>dbase-lsp-extis-te-metric-out</i>     | (Optional) |
| <i>dbase-lsp-extis-p2p-adjsid-out</i>    | (Optional) |
| <i>dbase-lsp-extis-p2p-adjsid-flags</i>  | (Optional) |
| <i>dbase-lsp-extis-p2p-adjsid-weight</i> | (Optional) |
| <i>dbase-lsp-extis-lan-adjsid-out</i>    | (Optional) |
| <i>dbase-lsp-extis-lan-adjsid-sysid</i>  | (Optional) |
| <i>dbase-lsp-extis-lan-adjsid-flags</i>  | (Optional) |
| <i>dbase-lsp-extis-lan-adjsid-weight</i> | (Optional) |
| <i>dbase-lsp-subtlv-len-out</i>          | (Optional) |
| <i>dbase-lsp-subtlv-unknown-out</i>      | (Optional) |
| <i>dbase-lsp-digest-out</i>              | (Optional) |
| <i>dbase-lsp-total-out</i>               | (Optional) |
| <i>dbase-lsp-empty-out</i>               | (Optional) |
| <i>dbase-lsp-zeroseq-out</i>             | (Optional) |
| <i>dbase-lsp-cap-rtrid</i>               | (Optional) |
| <i>dbase-lsp-cap-flags</i>               | (Optional) |
| <i>dbase-lsp-cap-subtlv-sr-start-sid</i> | (Optional) |
| <i>dbase-lsp-cap-subtlv-sr-end-sid</i>   | (Optional) |
| <i>dbase-lsp-cap-subtlv-sr-range</i>     | (Optional) |
| <i>dbase-lsp-cap-subtlv-sr-flags</i>     | (Optional) |

### Command Mode

- /exec

## show isis distribute-ls

```
show isis [ <isis-tag> ] distribute-ls { [ system-id <sid> ] [ lsp-id <lid> ] } [ brief ] [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <vrf-name-out>
<vrf-id-out> <lslib-connection-out> <client-type-out> <protocol-instance-out> <nxos-instance-out>
<ha-recovery-out> [ <queue-all-out> ] <update-timer-sec-out> <update-timer-msec-out>
<update-timer-running-out> [ <update-timer-due-in> ] [ { TABLE_process_lvl <level-out>
<level-distributing-out> [ { TABLE_ls_node [ <node-id-out> ] [ <node-name-out> ] [ { TABLE_ls_lsp
<lsp-id-out> <lsp-name-out> <lsp-purged-out> [ <node-grpid-out> ] [ <prefix-grpid-out> ] [ <link-grpid-out>
] [ <node-attr-bitfield-out> ] [ <node-flags-out> ] [ <attached-bit-out> ] [ <overloaded-bit-out> ] [ <area-id-out>
] [ <area-length-out> ] [ <name-out> ] [ <ipv4-id-out> ] [ { TABLE_srgb <number-out> <start-out> <size-out>
} ] [ <sr-algo-count-out> ] [ { TABLE_sr_algo <algo-out> } ] [ { TABLE_ls_link <nbr-node-out>
<local-ip-out> <remote-ip-out> [ <link-attr-bitfield-out> ] [ <metric-out> ] [ <local-ip-attr-out> ] [
<remote-ip-attr-out> ] [ <admin-group-out> ] [ <max-link-bw-out> ] [ <max-resv-bw-out> ] [ {
TABLE_unresv_bw <number-out> <bw-out> } ] [ <metric-te-out> ] [ { TABLE_adj_sid <asid-out> <flag-out>
<weight-out> } ] } ] [ { TABLE_ls_prefix <prefix-out> <prefix-len-out> [ <prefix-attr-bitfield-out> ] [
<metric-out> ] [ { TABLE_sid <sid-out> <algo-out> <flags-out> } ] } ] } ] }
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                  |
| isis                   | Display IS-IS status and configuration                           |
| <i>isis-tag</i>        | (Optional) Routing process tag                                   |
| distribute-ls          | Link-state distribution database                                 |
| system-id              | (Optional) Hostname or System ID                                 |
| <i>sid</i>             | (Optional) Hostname or System ID (in the form of XXXX.XXXX.XXXX) |
| lsp-id                 | (Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX            |
| <i>lid</i>             | (Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX            |
| brief                  | (Optional) Short output  |
| vrf                    | (Optional) Display per-VRF information                           |
| <i>vrf-name</i>        | (Optional) VRF name  |
| <i>vrf-known-name</i>  | (Optional) Known VRF name  |
| all                    | (Optional) Display information for all VRFs                      |
| __readonly__           | (Optional)   |
| TABLE_process_tag      | (Optional)   |
| <i>process-tag-out</i> | (Optional)   |
| <i>vrf-name-out</i>    | (Optional)   |



|                                 |            |
|---------------------------------|------------|
| <i>vrf-id-out</i>               | (Optional) |
| <i>lslib-connection-out</i>     | (Optional) |
| <i>client-type-out</i>          | (Optional) |
| <i>protocol-instance-out</i>    | (Optional) |
| <i>nxos-instance-out</i>        | (Optional) |
| <i>ha-recovery-out</i>          | (Optional) |
| <i>queue-all-out</i>            | (Optional) |
| <i>update-timer-sec-out</i>     | (Optional) |
| <i>update-timer-msec-out</i>    | (Optional) |
| <i>update-timer-running-out</i> | (Optional) |
| <i>update-timer-due-in</i>      | (Optional) |
| TABLE_process_lvl               | (Optional) |
| <i>level-out</i>                | (Optional) |
| <i>level-distributing-out</i>   | (Optional) |
| TABLE_ls_node                   | (Optional) |
| <i>node-id-out</i>              | (Optional) |
| <i>node-name-out</i>            | (Optional) |
| TABLE_ls_lsp                    | (Optional) |
| <i>lsp-id-out</i>               | (Optional) |
| <i>lsp-name-out</i>             | (Optional) |
| <i>lsp-purged-out</i>           | (Optional) |
| <i>node-grpid-out</i>           | (Optional) |
| <i>prefix-grpid-out</i>         | (Optional) |
| <i>link-grpid-out</i>           | (Optional) |
| <i>node-attr-bitfield-out</i>   | (Optional) |
| <i>node-flags-out</i>           | (Optional) |
| <i>attached-bit-out</i>         | (Optional) |
| <i>overloaded-bit-out</i>       | (Optional) |
| <i>area-id-out</i>              | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>area-length-out</i>        | (Optional) |
| <i>name-out</i>               | (Optional) |
| <i>ipv4-id-out</i>            | (Optional) |
| TABLE_srgb                    | (Optional) |
| <i>number-out</i>             | (Optional) |
| <i>start-out</i>              | (Optional) |
| <i>size-out</i>               | (Optional) |
| <i>sr-algo-count-out</i>      | (Optional) |
| TABLE_sr_algo                 | (Optional) |
| <i>algo-out</i>               | (Optional) |
| TABLE_ls_link                 | (Optional) |
| <i>nbr-node-out</i>           | (Optional) |
| <i>local-ip-out</i>           | (Optional) |
| <i>remote-ip-out</i>          | (Optional) |
| <i>link-attr-bitfield-out</i> | (Optional) |
| <i>metric-out</i>             | (Optional) |
| <i>local-ip-attr-out</i>      | (Optional) |
| <i>remote-ip-attr-out</i>     | (Optional) |
| <i>admin-group-out</i>        | (Optional) |
| <i>max-link-bw-out</i>        | (Optional) |
| <i>max-resv-bw-out</i>        | (Optional) |
| TABLE_unresv_bw               | (Optional) |
| <i>number-out</i>             | (Optional) |
| <i>bw-out</i>                 | (Optional) |
| <i>metric-te-out</i>          | (Optional) |
| TABLE_adj_sid                 | (Optional) |
| <i>asid-out</i>               | (Optional) |
| <i>flag-out</i>               | (Optional) |
| <i>weight-out</i>             | (Optional) |

|                                 |            |
|---------------------------------|------------|
| TABLE_ls_prefix                 | (Optional) |
| <i>prefix-out</i>               | (Optional) |
| <i>prefix-len-out</i>           | (Optional) |
| <i>prefix-attr-bitfield-out</i> | (Optional) |
| <i>metric-out</i>               | (Optional) |
| TABLE_sid                       | (Optional) |
| <i>sid-out</i>                  | (Optional) |
| <i>algo-out</i>                 | (Optional) |
| <i>flags-out</i>                | (Optional) |

**Command Mode**

- /exec

# show isis dynamic-flooding

```

show isis [ <isis-tag> ] dynamic-flooding [ tree-1 | tree-2 ] [ detail ] [ __readonly__ [ <df-process-tag-out> ]
[ <df-vrf-name-out> ] [ { TABLE_df_level [ <df-level-out> ] [ <df-level-config-out> ] [ <df-area-leader-cap-out>
] [ <df-area-leader-level-out> ] [ <df-algo-name-out> ] [ <df-algorithm-out> ] [ <df-priority-out> ] [
<df-primary-leader-level-out> ] [ <df-primary-leader-algo-name> ] [ <df-primary-leader-algo-out> ] [
<df-primary-leader-priority-out> ] [ <df-primary-leader-sysid-out> ] [ <df-secondary-leader-level-out> ] [
<df-secondary-leader-algo-name-out> ] [ <df-secondary-leader-algo-out> ] [ <df-secondary-leader-priority-out>
] [ <df-secondary-leader-sysid-out> ] [ <df-reach-matrix-level-out> ] [ { TABLE_source_info [
<df-reach-source-id-info> ] [ { TABLE_neighbor_info [ <df-reach-neighbor-id-out> ] [
<df-neighbor-overall-out> ] [ <df-neighbor-tree1-out> ] [ <df-neighbor-tree2-out> ] [
<df-neighbor-interface-id-out> ] [ <df-neighbor-name-out> ] } } ] [ { TABLE_FT_interface_info [
<df-ft-interface-name-out> ] } ] [ { TABLE_Temp_interface_info [ <df-temp-ft-interface-name-out> ] } ] [
{ TABLE_broadcast_interfaceinfo [ <df-interface-name-out> ] } } ] ] ]
  
```

## Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                            |
| isis                               | IS-IS events   |
| <i>isis-tag</i>                    | (Optional) Routing process tag                             |
| dynamic-flooding                   | Display IS-IS information for Dynamic Flooding             |
| tree-1                             | (Optional) Display dynamic-flooding information for tree-1 |
| tree-2                             | (Optional) Display dynamic-flooding information for tree-2 |
| detail                             | (Optional) Detail to show the Dynamic Flooding area leader |
| <i>__readonly__</i>                | (Optional)   |
| <i>df-process-tag-out</i>          | (Optional)   |
| <i>df-vrf-name-out</i>             | (Optional)   |
| TABLE_df_level                     | (Optional)   |
| <i>df-level-out</i>                | (Optional)   |
| <i>df-level-config-out</i>         | (Optional)   |
| <i>df-area-leader-cap-out</i>      | (Optional)   |
| <i>df-area-leader-level-out</i>    | (Optional)   |
| <i>df-algo-name-out</i>            | (Optional)   |
| <i>df-algorithm-out</i>            | (Optional)   |
| <i>df-priority-out</i>             | (Optional)   |
| <i>df-primary-leader-level-out</i> | (Optional)   |

|  |            |
|--|------------|
| <i>df-primary-leader-algo-name</i>       | (Optional) |
| <i>df-primary-leader-algo-out</i>        | (Optional) |
| <i>df-primary-leader-priority-out</i>    | (Optional) |
| <i>df-primary-leader-sysid-out</i>       | (Optional) |
| <i>df-secondary-leader-level-out</i>     | (Optional) |
| <i>df-secondary-leader-algo-name-out</i> | (Optional) |
| <i>df-secondary-leader-algo-out</i>      | (Optional) |
| <i>df-secondary-leader-priority-out</i>  | (Optional) |
| <i>df-secondary-leader-sysid-out</i>     | (Optional) |
| <i>df-reach-matrix-level-out</i>         | (Optional) |
| TABLE_source_info                        | (Optional) |
| <i>df-reach-source-id-info</i>           | (Optional) |
| TABLE_neighbor_info                      | (Optional) |
| <i>df-reach-neighbor-id-out</i>          | (Optional) |
| <i>df-neighbor-overall-out</i>           | (Optional) |
| <i>df-neighbor-tree1-out</i>             | (Optional) |
| <i>df-neighbor-tree2-out</i>             | (Optional) |
| <i>df-neighbor-interface-id-out</i>      | (Optional) |
| <i>df-neighbor-name-out</i>              | (Optional) |
| TABLE_FT_interface_info                  | (Optional) |
| <i>df-ft-interface-name-out</i>          | (Optional) |
| TABLE_Temp_interface_info                | (Optional) |
| <i>df-temp-ft-interface-name-out</i>     | (Optional) |
| TABLE_broadcast_interfaceinfo            | (Optional) |
| <i>df-interface-name-out</i>             | (Optional) |

**Command Mode**

- /exec

## show isis interface

```
show isis [<isis-tag>] [vrf {<vrf-name> | <vrf-known-name> | all}] interface [brief | <interface>] [level-1
| level-2] [vrf {<vrf-name> | <vrf-known-name> | all}] [__readonly__ {TABLE_process_tag
<process-tag-out> {TABLE_vrf <vrf-name-out> [ {TABLE_interface [ {<intfb-name-out> <intfb-type-out>
<intfb-ix-out> <intfb-state-out> <intfb-ready-state-out> <intfb-cid-out> <intfb-ckt-type-out> <intfb-mtu-out>
[ {<intf-p2p-metric-lvl-1-out> <intf-p2p-metric-lvl-2-out> <intf-p2p-prio-lvl-1-out> <intf-p2p-prio-lvl-2-out>
<intf-p2p-adj-count-lvl-1-out> <intf-p2p-adj-up-count-lvl-1-out> <intf-p2p-adj-count-lvl-2-out>
<intf-p2p-adj-up-count-lvl-2-out> } ] [ {<intf-loopback-metric-lvl-1-out> <intf-loopback-metric-lvl-2-out>
<intf-loopback-prio-lvl-1-out> <intf-loopback-prio-lvl-2-out> <intf-loopback-adj-count-lvl-1-out>
<intf-loopback-adj-up-count-lvl-1-out> <intf-loopback-adj-count-lvl-2-out>
<intf-loopback-adj-up-count-lvl-2-out> } ] [ {<intf-bcast-metric-lvl-1-out> <intf-bcast-metric-lvl-2-out>
<intf-bcast-prio-lvl-1-out> <intf-bcast-prio-lvl-2-out> <intf-bcast-adj-count-lvl-1-out>
<intf-bcast-adj-up-count-lvl-1-out> <intf-bcast-adj-count-lvl-2-out> <intf-bcast-adj-up-count-lvl-2-out> } ]
} ] [ {<intf-name-out> <intf-status-out> } ] [ {<intf-state-out> <intf-internal-state-out> [
<intf-cib-disabled-out> ] [ <intf-cid-invalid-out> } ] [ <intf-admin-group-out> <intf-admin-group-stale-out>
] [ {TABLE_auth [ {<intf-auth-info-out> [ <intf-auth-kchain-out> ] <intf-auth-chk-info-out> } ] } ] [ {
<intf-ix-out> <intf-cid-out> <intf-ckt-type-out> } ] [ {<prefix-suppression-state-out> <suppressed-ix-out>
} ] [ {TABLE_advertise_passive_lvl [ {<advertise-passive-level-out> <advertise-passive-ipv4-state-out>
<advertise-passive-ipv6-state-out> } ] } ] [ {TABLE_bfd [ <intf-bfd-ipv4-state-out> ] [
<intf-bfd-ipv6-state-out> } ] [ <intf-passive-mask-out> ] [ <intf-passive-mask-lvl-out> ] [ <intf-mgrp-set-out>
] [ <intf-mgrp-state-out> ] [ <intf-mgrp-id-out> ] [ <intf-p2p-type-out> ] [ { <intf-p2p-ext-local-cid-out>
<intf-p2p-cid-out> <intf-retx-intv-out> <intf-retx-throttle-out> } ] [ <intf-loopback-type-out> ] [ {
<intf-lsp-intv-out> <intf-mtu-out> [ <intf-hpad-state-out> } ] ] [ { [ <intf-p2p-pad-ts-out> ]
<intf-p2p-adj-count-out> <intf-p2p-adj-up-count-out> <intf-p2p-prio-out> <intf-p2p-hello-intv-out>
<intf-p2p-hello-multi-out> <intf-p2p-hello-next-out> [ {TABLE_p2p <intf-p2p-lvl-out> <intf-p2p-adj-lvl-out>
<intf-p2p-adj-up-lvl-out> <intf-p2p-metric-lvl-out> <intf-p2p-csnp-lvl-out> <intf-p2p-csnp-nxt-lvl-out>
<intf-p2p-lspid-last-lvl-out> } ] } ] [ {<intf-bcast-type-out> [ {TABLE_bcast_pad [ {<intf-bcast-lvl-out>
<intf-bcast-pad-ts-out> } ] } ] [ {TABLE_bcast_dis [ {<intf-bcast-lvl-dis-out> <intf-bcast-dis-ts-out> } ] } ]
] [ {TABLE_bcast_pkt <intf-bcast-lvl-info-out> <intf-bcast-lvl-metric-0-out> <intf-bcast-lvl-metric-2-out>
<intf-bcast-lvl-csnp-intv-out> <intf-bcast-lvl-csnp-next-out> <intf-bcast-lvl-iih-intv-out>
<intf-bcast-lvl-iih-multi-out> <intf-bcast-lvl-iih-next-out> } ] [ {TABLE_bcast_adj <intf-bcast-lvl-value-out>
<intf-bcast-lvl-adj-out> <intf-bcast-lvl-adj-up-out> <intf-bcast-lvl-prio-out> <intf-bcast-lvl-ctid-out>
<intf-bcast-lvl-ctid-ts-out> } ] } ] [ {TABLE_loopback <intf-loopback-lvl-out> <intf-loopback-lvl-metric-out>
} ] [ <intf-unknown-out> } ] } ] }
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| isis                  | Display IS-IS status and configuration      |
| <i>isis-tag</i>       | (Optional) Routing process tag              |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |

|                                     |  |
|-------------------------------------|--|
| brief                               | (Optional) Brief display of IS-IS interfaces |
| interface                           | Display IS-IS interface information          |
| level-1                             | (Optional) Display Level-1 interfaces        |
| level-2                             | (Optional) Display level-2 interfaces        |
| <i>interface</i>                    | (Optional) IS-IS interface                   |
| <i>__readonly__</i>                 | (Optional)                                   |
| TABLE_process_tag                   | (Optional)                                   |
| <i>process-tag-out</i>              | (Optional)                                   |
| TABLE_vrf                           | (Optional)                                   |
| <i>vrf-name-out</i>                 | (Optional)                                   |
| TABLE_interface                     | (Optional)                                   |
| <i>intf-status-out</i>              | (Optional)                                   |
| <i>intf-name-out</i>                | (Optional)                                   |
| <i>intf-ix-out</i>                  | (Optional)                                   |
| <i>intf-state-out</i>               | (Optional)                                   |
| <i>intf-cid-out</i>                 | (Optional)                                   |
| <i>intf-ckt-type-out</i>            | (Optional)                                   |
| <i>intfb-name-out</i>               | (Optional)                                   |
| <i>intfb-type-out</i>               | (Optional)                                   |
| <i>intfb-ix-out</i>                 | (Optional)                                   |
| <i>intfb-state-out</i>              | (Optional)                                   |
| <i>intfb-ready-state-out</i>        | (Optional)                                   |
| <i>intfb-cid-out</i>                | (Optional)                                   |
| <i>intfb-ckt-type-out</i>           | (Optional)                                   |
| <i>intf-p2p-metric-lvl-1-out</i>    | (Optional)                                   |
| <i>intf-p2p-metric-lvl-2-out</i>    | (Optional)                                   |
| <i>intf-p2p-prio-lvl-1-out</i>      | (Optional)                                   |
| <i>intf-p2p-prio-lvl-2-out</i>      | (Optional)                                   |
| <i>intf-p2p-adj-count-lvl-1-out</i> | (Optional)                                   |

|   |            |
|---|------------|
| <i>intf-p2p-adj-count-lvl-2-out</i>         | (Optional) |
| <i>intf-p2p-adj-up-count-lvl-1-out</i>      | (Optional) |
| <i>intf-p2p-adj-up-count-lvl-2-out</i>      | (Optional) |
| <i>intf-loopback-metric-lvl-1-out</i>       | (Optional) |
| <i>intf-loopback-metric-lvl-2-out</i>       | (Optional) |
| <i>intf-loopback-prio-lvl-1-out</i>         | (Optional) |
| <i>intf-loopback-prio-lvl-2-out</i>         | (Optional) |
| <i>intf-loopback-adj-count-lvl-1-out</i>    | (Optional) |
| <i>intf-loopback-adj-count-lvl-2-out</i>    | (Optional) |
| <i>intf-loopback-adj-up-count-lvl-1-out</i> | (Optional) |
| <i>intf-loopback-adj-up-count-lvl-2-out</i> | (Optional) |
| <i>intf-bcast-metric-lvl-1-out</i>          | (Optional) |
| <i>intf-bcast-metric-lvl-2-out</i>          | (Optional) |
| <i>intf-bcast-prio-lvl-1-out</i>            | (Optional) |
| <i>intf-bcast-prio-lvl-2-out</i>            | (Optional) |
| <i>intf-bcast-adj-count-lvl-1-out</i>       | (Optional) |
| <i>intf-bcast-adj-count-lvl-2-out</i>       | (Optional) |
| <i>intf-bcast-adj-up-count-lvl-1-out</i>    | (Optional) |
| <i>intf-bcast-adj-up-count-lvl-2-out</i>    | (Optional) |
| <i>intf-internal-state-out</i>              | (Optional) |
| <i>intf-cib-disabled-out</i>                | (Optional) |
| <i>intf-cid-invalid-out</i>                 | (Optional) |
| <i>intf-admin-group-out</i>                 | (Optional) |
| <i>intf-admin-group-stale-out</i>           | (Optional) |
| TABLE_auth                                  | (Optional) |
| <i>intf-auth-info-out</i>                   | (Optional) |
| <i>intf-auth-kchain-out</i>                 | (Optional) |
| <i>intf-auth-chk-info-out</i>               | (Optional) |
| <i>prefix-suppression-state-out</i>         | (Optional) |



|   |            |
|---|------------|
| <i>suppressed-ix-out</i>                | (Optional) |
| TABLE_advertise_passive_lvl             | (Optional) |
| <i>advertise-passive-level-out</i>      | (Optional) |
| <i>advertise-passive-ipv4-state-out</i> | (Optional) |
| <i>advertise-passive-ipv6-state-out</i> | (Optional) |
| TABLE_bfd                               | (Optional) |
| <i>intf-bfd-ipv4-state-out</i>          | (Optional) |
| <i>intf-bfd-ipv6-state-out</i>          | (Optional) |
| <i>intf-passive-mask-out</i>            | (Optional) |
| <i>intf-passive-mask-lvl-out</i>        | (Optional) |
| <i>intf-mgrp-set-out</i>                | (Optional) |
| <i>intf-mgrp-state-out</i>              | (Optional) |
| <i>intf-mgrp-id-out</i>                 | (Optional) |
| <i>intf-p2p-type-out</i>                | (Optional) |
| <i>intf-p2p-ext-local-cid-out</i>       | (Optional) |
| <i>intf-p2p-cid-out</i>                 | (Optional) |
| <i>intf-retx-intv-out</i>               | (Optional) |
| <i>intf-retx-throttle-out</i>           | (Optional) |
| <i>intf-loopback-type-out</i>           | (Optional) |
| <i>intf-lsp-intv-out</i>                | (Optional) |
| <i>intf-mtu-out</i>                     | (Optional) |
| <i>intfb-mtu-out</i>                    | (Optional) |
| <i>intf-hpad-state-out</i>              | (Optional) |
| <i>intf-p2p-pad-ts-out</i>              | (Optional) |
| <i>intf-p2p-adj-count-out</i>           | (Optional) |
| <i>intf-p2p-adj-up-count-out</i>        | (Optional) |
| <i>intf-p2p-prio-out</i>                | (Optional) |
| <i>intf-p2p-hello-intv-out</i>          | (Optional) |
| <i>intf-p2p-hello-multi-out</i>         | (Optional) |

|                                     |            |
|-------------------------------------|------------|
| <i>intf-p2p-hello-next-out</i>      | (Optional) |
| TABLE_p2p                           | (Optional) |
| <i>intf-p2p-lvl-out</i>             | (Optional) |
| <i>intf-p2p-adj-lvl-out</i>         | (Optional) |
| <i>intf-p2p-adj-up-lvl-out</i>      | (Optional) |
| <i>intf-p2p-metric-lvl-out</i>      | (Optional) |
| <i>intf-p2p-csnp-lvl-out</i>        | (Optional) |
| <i>intf-p2p-csnp-nxt-lvl-out</i>    | (Optional) |
| <i>intf-p2p-lspid-last-lvl-out</i>  | (Optional) |
| <i>intf-bcast-type-out</i>          | (Optional) |
| TABLE_bcast_pad                     | (Optional) |
| <i>intf-bcast-lvl-out</i>           | (Optional) |
| <i>intf-bcast-pad-ts-out</i>        | (Optional) |
| TABLE_bcast_dis                     | (Optional) |
| <i>intf-bcast-lvl-dis-out</i>       | (Optional) |
| <i>intf-bcast-dis-ts-out</i>        | (Optional) |
| TABLE_bcast_pkt                     | (Optional) |
| <i>intf-bcast-lvl-info-out</i>      | (Optional) |
| <i>intf-bcast-lvl-metric-0-out</i>  | (Optional) |
| <i>intf-bcast-lvl-metric-2-out</i>  | (Optional) |
| <i>intf-bcast-lvl-csnp-intv-out</i> | (Optional) |
| <i>intf-bcast-lvl-csnp-next-out</i> | (Optional) |
| <i>intf-bcast-lvl-iih-intv-out</i>  | (Optional) |
| <i>intf-bcast-lvl-iih-multi-out</i> | (Optional) |
| <i>intf-bcast-lvl-iih-next-out</i>  | (Optional) |
| TABLE_bcast_adj                     | (Optional) |
| <i>intf-bcast-lvl-value-out</i>     | (Optional) |
| <i>intf-bcast-lvl-adj-out</i>       | (Optional) |
| <i>intf-bcast-lvl-adj-up-out</i>    | (Optional) |

|                                     |            |
|-------------------------------------|------------|
| <i>intf-bcast-lvl-prio-out</i>      | (Optional) |
| <i>intf-bcast-lvl-ctid-out</i>      | (Optional) |
| <i>intf-bcast-lvl-ctid-ts-out</i>   | (Optional) |
| TABLE_loopback                      | (Optional) |
| <i>intf-loopback-lvl-out</i>        | (Optional) |
| <i>intf-loopback-lvl-metric-out</i> | (Optional) |
| <i>intf-unknown-out</i>             | (Optional) |

**Command Mode**

- /exec

## show isis ipv6 redistribute route

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ipv6 redistribute route [ topology { [
base ] | mt-ipv6 } ] [ summary | <ipv6-addr> | <ipv6-prefix> [ longer-prefixes [ summary ] ] ] [ direct-mask
] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out>
<redist-route-ipv6-vrf> [ <redist-route-ipv6-topo-id> ] [ <redist-route-ipv6-af-ix> ] [ { TABLE_one_route
<redist-route-ipv6-prefix> [ <redist-route-ipv6-mask-len> ] [ <redist-route-ipv6-stale> ] [
<redist-route-ipv6-pib-name> ] [ <redist-route-ipv6-direct-mask> ] [ <redist-route-ipv6-route-type> ] [ {
TABLE_redist <redist-route-ipv6-status> <redist-route-ipv6-level> [ <redist-route-ipv6-metric> ] [
<redist-route-ipv6-sum-addr-prefix> ] [ <redist-route-ipv6-sum-addr-mask-len> ] } ] [
<redist-route-ipv6-summary-addr-prefix> ] [ <redist-route-ipv6-summary-addr-mask-len> ] [
<redist-route-ipv6-summary-route-total> ] [ { TABLE_protocol <redist-route-ipv6-summary-pib-name> [
<redist-route-ipv6-summary-prot-route-total> ] } ] [ <redist-route-ipv6-summary-pending-total> ] [ {
TABLE_mask_len <redist-route-ipv6-summary-mask-len-ix> [ <redist-route-ipv6-summary-mask-len> ] }
] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                         |
| isis                  | Display IS-IS status and configuration                  |
| <i>isis-tag</i>       | (Optional) Routing process tag                          |
| vrf                   | (Optional) Display per-VRF information                  |
| <i>vrf-name</i>       | (Optional) VRF name                                     |
| <i>vrf-known-name</i> | (Optional) Known VRF name                               |
| all                   | (Optional) Display information for all VRFs             |
| redistribute          | Display IS-IS redistribute information                  |
| route                 | Display ISIS redistribute route                         |
| ipv6                  | Display IS-IS IPv6 information                          |
| topology              | (Optional) Display routes for a topology                |
| base                  | (Optional) Display routes for BASE topology             |
| mt-ipv6               | (Optional) Display routes for MT-IPV6-UNICAST topology  |
| longer-prefixes       | (Optional) Display exact match and more specific routes |
| summary               | (Optional) Display route counts                         |
| direct-mask           | (Optional) Display routes with direct-mask set          |
| __readonly__          | (Optional)  |
| TABLE_process_tag     | (Optional)  |

|   |            |
|---|------------|
| <i>process-tag-out</i>                            | (Optional) |
| <i>redist-route-ipv6-vrf</i>                      | (Optional) |
| <i>redist-route-ipv6-topo-id</i>                  | (Optional) |
| <i>redist-route-ipv6-af-ix</i>                    | (Optional) |
| TABLE_one_route                                   | (Optional) |
| <i>redist-route-ipv6-prefix</i>                   | (Optional) |
| <i>redist-route-ipv6-mask-len</i>                 | (Optional) |
| <i>redist-route-ipv6-stale</i>                    | (Optional) |
| <i>redist-route-ipv6-pib-name</i>                 | (Optional) |
| <i>redist-route-ipv6-direct-mask</i>              | (Optional) |
| <i>redist-route-ipv6-route-type</i>               | (Optional) |
| TABLE_redist                                      | (Optional) |
| <i>redist-route-ipv6-status</i>                   | (Optional) |
| <i>redist-route-ipv6-level</i>                    | (Optional) |
| <i>redist-route-ipv6-metric</i>                   | (Optional) |
| <i>redist-route-ipv6-sum-addr-prefix</i>          | (Optional) |
| <i>redist-route-ipv6-sum-addr-mask-len</i>        | (Optional) |
| <i>redist-route-ipv6-summary-addr-prefix</i>      | (Optional) |
| <i>redist-route-ipv6-summary-addr-mask-len</i>    | (Optional) |
| <i>redist-route-ipv6-summary-route-total</i>      | (Optional) |
| TABLE_protocol                                    | (Optional) |
| <i>redist-route-ipv6-summary-pib-name</i>         | (Optional) |
| <i>redist-route-ipv6-summary-prot-route-total</i> | (Optional) |
| <i>redist-route-ipv6-summary-pending-total</i>    | (Optional) |
| TABLE_mask_len                                    | (Optional) |
| <i>redist-route-ipv6-summary-mask-len-ix</i>      | (Optional) |
| <i>redist-route-ipv6-summary-mask-len</i>         | (Optional) |

**Command Mode**

- /exec

## show isis ipv6 route

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ipv6 route [ topology { [ base ] |
mt-ipv6 } ] [ summary | detail | private | <ipv6-addr> [ detail | private ] | <ipv6-prefix> [ detail | private |
longer-prefixes [ summary | detail | private ] ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
{ TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> [ <topo-id-out> ] <afi-safi-out> [
TABLE_prefix [ <route-prefix-out> <route-mask-len-out> <route-level-out> ] [ <route-summ-discard-addr-out>
<route-summ-discard-mask-len-out> ] [ <route-discard-addr-out> <route-discard-mask-len-out> ] [
<route-addr-print-out> <route-mask-len-print-out> <route-direct-print-out> ] [ TABLE_direct_path [
<route-direct-out> <route-direct-via-out> <route-direct-if-name-out> <route-direct-metric-out>
<route-direct-level-out> ] [ <route-direct-instance-out> ] ] [ TABLE_best_path [ <route-no-def-prefix-out>
] [ <route-def-prefix-out> ] <route-addr-valid-out> <route-marker-out> <route-ifname-out> <route-metric-out>
<route-pref-out> [ <route-instance-out> ] ] [ <route-discard-mask-out> ] [ [ <route-sum-prefix-out>
<route-sum-prefix-len-out> ] <route-total-out> <route-paths-total-out> <route-paths-best-out>
<route-paths-backup-out> [ TABLE_sum_best_route <route-sum-lvl-out> <route-sum-total-out> [
<route-sum-direct-out> ] [ <route-sum-normal-out> ] [ <route-sum-missing-out> ] ] [
<route-best-pend-num-out> ] <route-bestpaths-out> [ TABLE_sum_best_path <route-path-sum-lvl-out>
<route-path-sum-total-out> [ <route-path-sum-direct-out> ] [ <route-path-sum-normal-out> ] ]
<route-backuppaths-out> [ TABLE_sum_backup_path <backup-path-sum-lvl-out> <backup-path-sum-total-out>
[ <backup-path-sum-direct-out> ] [ <backup-path-sum-normal-out> ] ] <route-bestroutes-per-mask-out> [
TABLE_best_mask <route-best-mask-val-out> <route-best-mask-count-out> ] [ <route-pend-q-count-out> ]
] ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                         |
| isis                  | Display IS-IS status and configuration                  |
| <i>isis-tag</i>       | (Optional) Routing process tag                          |
| vrf                   | (Optional) Display per-VRF information                  |
| <i>vrf-name</i>       | (Optional) VRF name                                     |
| <i>vrf-known-name</i> | (Optional) Known VRF name                               |
| all                   | (Optional) Display information for all VRFs             |
| ipv6                  | Display IS-IS IPv6 information                          |
| route                 | Display IS-IS route information                         |
| topology              | (Optional) Display routes for a topology                |
| base                  | (Optional) Display routes for BASE topology             |
| mt-ipv6               | (Optional) Display routes for MT-IPV6-UNICAST topology  |
| longer-prefixes       | (Optional) Display exact match and more specific routes |
| summary               | (Optional) Display route counts                         |

|  |   |
|--|---|
| detail                                 | (Optional) Display detail route information |
| private                                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <u>__readonly__</u>                    | (Optional)                                  |
| TABLE_process_tag                      | (Optional)                                  |
| <i>process-tag-out</i>                 | (Optional)                                  |
| TABLE_vrf                              | (Optional)                                  |
| <i>vrf-name-out</i>                    | (Optional)                                  |
| <i>topo-id-out</i>                     | (Optional)                                  |
| <i>afi-safi-out</i>                    | (Optional)                                  |
| TABLE_prefix                           | (Optional)                                  |
| <i>route-prefix-out</i>                | (Optional)                                  |
| <i>route-mask-len-out</i>              | (Optional)                                  |
| <i>route-level-out</i>                 | (Optional)                                  |
| <i>route-summ-discard-addr-out</i>     | (Optional)                                  |
| <i>route-summ-discard-mask-len-out</i> | (Optional)                                  |
| <i>route-discard-addr-out</i>          | (Optional)                                  |
| <i>route-discard-mask-len-out</i>      | (Optional)                                  |
| <i>route-addr-print-out</i>            | (Optional)                                  |
| <i>route-mask-len-print-out</i>        | (Optional)                                  |
| <i>route-direct-print-out</i>          | (Optional)                                  |
| TABLE_direct_path                      | (Optional)                                  |
| <i>route-direct-out</i>                | (Optional)                                  |
| <i>route-direct-via-out</i>            | (Optional)                                  |
| <i>route-direct-if-name-out</i>        | (Optional)                                  |
| <i>route-direct-metric-out</i>         | (Optional)                                  |
| <i>route-direct-level-out</i>          | (Optional)                                  |
| <i>route-direct-instance-out</i>       | (Optional)                                  |
| TABLE_best_path                        | (Optional)                                  |
| <i>route-no-def-prefix-out</i>         | (Optional)                                  |

|                                  |            |
|----------------------------------|------------|
| <i>route-def-prefix-out</i>      | (Optional) |
| <i>route-addr-valid-out</i>      | (Optional) |
| <i>route-marker-out</i>          | (Optional) |
| <i>route-ifname-out</i>          | (Optional) |
| <i>route-metric-out</i>          | (Optional) |
| <i>route-pref-out</i>            | (Optional) |
| <i>route-instance-out</i>        | (Optional) |
| <i>route-discard-mask-out</i>    | (Optional) |
| <i>route-sum-prefix-out</i>      | (Optional) |
| <i>route-sum-prefix-len-out</i>  | (Optional) |
| <i>route-total-out</i>           | (Optional) |
| <i>route-paths-total-out</i>     | (Optional) |
| <i>route-paths-best-out</i>      | (Optional) |
| <i>route-paths-backup-out</i>    | (Optional) |
| TABLE_sum_best_route             | (Optional) |
| <i>route-sum-lvl-out</i>         | (Optional) |
| <i>route-sum-total-out</i>       | (Optional) |
| <i>route-sum-direct-out</i>      | (Optional) |
| <i>route-sum-normal-out</i>      | (Optional) |
| <i>route-sum-missing-out</i>     | (Optional) |
| <i>route-best-pend-num-out</i>   | (Optional) |
| <i>route-bestpaths-out</i>       | (Optional) |
| TABLE_sum_best_path              | (Optional) |
| <i>route-path-sum-lvl-out</i>    | (Optional) |
| <i>route-path-sum-total-out</i>  | (Optional) |
| <i>route-path-sum-direct-out</i> | (Optional) |
| <i>route-path-sum-normal-out</i> | (Optional) |
| <i>route-backuppaths-out</i>     | (Optional) |
| TABLE_sum_backup_path            | (Optional) |



|                                      |            |
|--------------------------------------|------------|
| <i>backup-path-sum-lvl-out</i>       | (Optional) |
| <i>backup-path-sum-total-out</i>     | (Optional) |
| <i>backup-path-sum-direct-out</i>    | (Optional) |
| <i>backup-path-sum-normal-out</i>    | (Optional) |
| <i>route-bestroutes-per-mask-out</i> | (Optional) |
| TABLE_best_mask                      | (Optional) |
| <i>route-best-mask-val-out</i>       | (Optional) |
| <i>route-best-mask-count-out</i>     | (Optional) |
| <i>route-pend-q-count-out</i>        | (Optional) |

**Command Mode**

- /exec

## show isis ipv6 summary-address

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ipv6 summary-address [ <ipv6-addr>
| <ipv6-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<vrf-name-out> <tag-out> <afi-safi-out> [ <addr-absent-out> ] [ { TABLE_addr <sum-prefix-out>
<mask-len-out> <level-out> [ { TABLE_lvl <addr-lvl-out> <addr-num-out> [ <addr-metric-absent-out> ] [
<addr-metric-out> ] [ <addr-route-count-out> } } ] ] ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                                  |
| isis                      | Display IS-IS status and configuration                           |
| <i>isis-tag</i>           | (Optional) Routing process tag                                   |
| vrf                       | (Optional) Display per-VRF information                           |
| <i>vrf-name</i>           | (Optional) VRF name  |
| <i>vrf-known-name</i>     | (Optional) Known VRF name  |
| all                       | (Optional) Display information for all VRFs                      |
| ipv6                      | Display IS-IS IPv6 information                                   |
| summary-address           | Display IS-IS summary address                                    |
| longer-prefixes           | (Optional) Display exact match and more specific summary address |
| <code>__readonly__</code> | (Optional)   |
| TABLE_vrf                 | (Optional)   |
| <i>vrf-name-out</i>       | (Optional)   |
| <i>tag-out</i>            | (Optional)   |
| <i>afi-safi-out</i>       | (Optional)   |
| <i>addr-absent-out</i>    | (Optional)   |
| TABLE_addr                | (Optional)   |
| <i>sum-prefix-out</i>     | (Optional)   |
| <i>mask-len-out</i>       | (Optional)   |
| <i>level-out</i>          | (Optional)   |
| TABLE_lvl                 | (Optional)   |
| <i>addr-lvl-out</i>       | (Optional)   |
| <i>addr-num-out</i>       | (Optional)   |

|                               |            |
|-------------------------------|------------|
| <i>addr-metric-absent-out</i> | (Optional) |
| <i>addr-metric-out</i>        | (Optional) |
| <i>addr-route-count-out</i>   | (Optional) |

**Command Mode**

- /exec

# show isis lslib

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] lslib [ cache [ nodes | links | prefixes
| node <s0> | link <s1> | prefix <s2> | links-of-node <s3> | prefixes-of-node <s4> ] [ detail ] ] [ vrf { <vrf-name>
| <vrf-known-name> | all } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| isis                  | Display IS-IS status and configuration        |
| <i>isis-tag</i>       | (Optional) Routing process tag                |
| lslib                 | LSLIB client information                      |
| cache                 | (Optional) Link-state cache in LSLIB          |
| nodes                 | (Optional) All Node objects                   |
| links                 | (Optional) All Link objects                   |
| prefixes              | (Optional) All Prefix objects                 |
| node                  | (Optional) One node object information        |
| <i>s0</i>             | (Optional) Node information                   |
| link                  | (Optional) One link object information        |
| <i>s1</i>             | (Optional) Link information                   |
| prefix                | (Optional) One prefix object information      |
| <i>s2</i>             | (Optional) Prefix information                 |
| links-of-node         | (Optional) All links information of a node    |
| <i>s3</i>             | (Optional) Node information                   |
| prefixes-of-node      | (Optional) All prefixes information of a node |
| <i>s4</i>             | (Optional) Node information                   |
| detail                | (Optional) Detailed info                      |
| vrf                   | (Optional) Display per-VRF information        |
| <i>vrf-name</i>       | (Optional) VRF name                           |
| <i>vrf-known-name</i> | (Optional) Known VRF name                     |
| all                   | (Optional) Display information for all VRFs   |

## Command Mode

- /exec

## show isis mesh-group

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] mesh-group [ <mesh-id> ] [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf <vrf-name-out> <tag-out> [
<mesh-id-set-out> ] [ <mesh-id-invalid-out> ] [ <mesh-id-none-out> ] [ { TABLE_meshid <mesh-set-id-out>
[ { TABLE_if <mesh-id-intf-name-out> } } ] ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information             |
| isis                         | Display IS-IS status and configuration      |
| <i>isis-tag</i>              | (Optional) Routing process tag              |
| vrf                          | (Optional) Display per-VRF information      |
| <i>vrf-name</i>              | (Optional) VRF name                         |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                   |
| all                          | (Optional) Display information for all VRFs |
| mesh-group                   | Display IS-IS mesh-groups                   |
| <i>mesh-id</i>               | (Optional) Display a single mesh-group      |
| __readonly__                 | (Optional)                                  |
| TABLE_vrf                    | (Optional)                                  |
| <i>vrf-name-out</i>          | (Optional)                                  |
| <i>tag-out</i>               | (Optional)                                  |
| <i>mesh-id-set-out</i>       | (Optional)                                  |
| <i>mesh-id-invalid-out</i>   | (Optional)                                  |
| <i>mesh-id-none-out</i>      | (Optional)                                  |
| TABLE_meshid                 | (Optional)                                  |
| <i>mesh-set-id-out</i>       | (Optional)                                  |
| TABLE_if                     | (Optional)                                  |
| <i>mesh-id-intf-name-out</i> | (Optional)                                  |

### Command Mode

- /exec

## show isis redistribute route

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ ip ] redistribute route [ summary |
<ip-addr> | <ip-prefix> [ longer-prefixes [ summary ] ] ] [ direct-mask ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <redist-route-vrf> [ <redist-route-af-ix> ] [
{ TABLE_one_route <redist-route-prefix> [ <redist-route-mask-len> ] [ <redist-route-stale> ] [
<redist-route-pib-name> ] [ <redist-route-direct-mask> ] [ <redist-route-route-type> ] [ { TABLE_redist
<redist-route-status> <redist-route-level> [ <redist-route-metric> ] [ <redist-route-sum-addr-prefix> ] [
<redist-route-sum-addr-mask-len> ] } } ] [ <redist-route-summary-addr-prefix> ] [
<redist-route-summary-addr-mask-len> ] [ <redist-route-summary-route-total> ] [ { TABLE_protocol
<redist-route-summary-pib-name> [ <redist-route-summary-prot-route-total> } } ] [
<redist-route-summary-pending-total> ] [ { TABLE_mask_len <redist-route-summary-mask-len-ix> [
<redist-route-summary-mask-len> ] } } ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                             |
| isis                    | Display IS-IS status and configuration                      |
| <i>isis-tag</i>         | (Optional) Routing process tag                              |
| vrf                     | (Optional) Display per-VRF information                      |
| <i>vrf-name</i>         | (Optional) VRF name   |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                                   |
| all                     | (Optional) Display information for all VRFs                 |
| redistribute            | Display IS-IS redistribute information                      |
| route                   | Display ISIS redistribute route                             |
| ip                      | (Optional) Display IS-IS IPv4 information                   |
| <i>ip-addr</i>          | (Optional) Display single IP redistribute route             |
| <i>ip-prefix</i>        | (Optional) Display single exact match IP redistribute route |
| longer-prefixes         | (Optional) Display exact match and more specific routes     |
| summary                 | (Optional) Display route counts                             |
| direct-mask             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <u>__readonly__</u>     | (Optional)  |
| TABLE_process_tag       | (Optional)  |
| <i>process-tag-out</i>  | (Optional)  |
| <i>redist-route-vrf</i> | (Optional)  |

|  |            |
|--|------------|
| <i>redist-route-af-ix</i>                    | (Optional) |
| TABLE_one_route                              | (Optional) |
| <i>redist-route-prefix</i>                   | (Optional) |
| <i>redist-route-mask-len</i>                 | (Optional) |
| <i>redist-route-stale</i>                    | (Optional) |
| <i>redist-route-pib-name</i>                 | (Optional) |
| <i>redist-route-direct-mask</i>              | (Optional) |
| <i>redist-route-route-type</i>               | (Optional) |
| TABLE_redist                                 | (Optional) |
| <i>redist-route-status</i>                   | (Optional) |
| <i>redist-route-level</i>                    | (Optional) |
| <i>redist-route-metric</i>                   | (Optional) |
| <i>redist-route-sum-addr-prefix</i>          | (Optional) |
| <i>redist-route-sum-addr-mask-len</i>        | (Optional) |
| <i>redist-route-summary-addr-prefix</i>      | (Optional) |
| <i>redist-route-summary-addr-mask-len</i>    | (Optional) |
| <i>redist-route-summary-route-total</i>      | (Optional) |
| TABLE_protocol                               | (Optional) |
| <i>redist-route-summary-pib-name</i>         | (Optional) |
| <i>redist-route-summary-prot-route-total</i> | (Optional) |
| <i>redist-route-summary-pending-total</i>    | (Optional) |
| TABLE_mask_len                               | (Optional) |
| <i>redist-route-summary-mask-len-ix</i>      | (Optional) |
| <i>redist-route-summary-mask-len</i>         | (Optional) |

**Command Mode**

- /exec





|  |            |
|--|------------|
| <code>__readonly__</code>                    | (Optional) |
| <code>TABLE_process_tag</code>               | (Optional) |
| <code>process-tag-out</code>                 | (Optional) |
| <code>TABLE_vrf</code>                       | (Optional) |
| <code>vrf-name-out</code>                    | (Optional) |
| <code>afi-safi-out</code>                    | (Optional) |
| <code>TABLE_prefix</code>                    | (Optional) |
| <code>route-prefix-out</code>                | (Optional) |
| <code>route-mask-len-out</code>              | (Optional) |
| <code>route-level-out</code>                 | (Optional) |
| <code>route-summ-discard-addr-out</code>     | (Optional) |
| <code>route-summ-discard-mask-len-out</code> | (Optional) |
| <code>route-discard-addr-out</code>          | (Optional) |
| <code>route-discard-mask-len-out</code>      | (Optional) |
| <code>route-addr-print-out</code>            | (Optional) |
| <code>route-mask-len-print-out</code>        | (Optional) |
| <code>route-direct-print-out</code>          | (Optional) |
| <code>TABLE_direct_path</code>               | (Optional) |
| <code>route-direct-out</code>                | (Optional) |
| <code>route-direct-via-out</code>            | (Optional) |
| <code>route-direct-if-name-out</code>        | (Optional) |
| <code>route-direct-metric-out</code>         | (Optional) |
| <code>route-direct-level-out</code>          | (Optional) |
| <code>route-direct-instance-out</code>       | (Optional) |
| <code>TABLE_best_path</code>                 | (Optional) |
| <code>route-no-def-prefix-out</code>         | (Optional) |
| <code>route-def-prefix-out</code>            | (Optional) |
| <code>route-addr-valid-out</code>            | (Optional) |
| <code>route-marker-out</code>                | (Optional) |

|                                   |            |
|-----------------------------------|------------|
| <i>route-ifname-out</i>           | (Optional) |
| <i>route-metric-out</i>           | (Optional) |
| <i>route-pref-out</i>             | (Optional) |
| <i>route-instance-out</i>         | (Optional) |
| <i>route-discard-mask-out</i>     | (Optional) |
| <i>route-sum-prefix-out</i>       | (Optional) |
| <i>route-sum-prefix-len-out</i>   | (Optional) |
| <i>route-total-out</i>            | (Optional) |
| <i>route-paths-total-out</i>      | (Optional) |
| <i>route-paths-best-out</i>       | (Optional) |
| <i>route-paths-backup-out</i>     | (Optional) |
| TABLE_sum_best_route              | (Optional) |
| <i>route-sum-lvl-out</i>          | (Optional) |
| <i>route-sum-total-out</i>        | (Optional) |
| <i>route-sum-direct-out</i>       | (Optional) |
| <i>route-sum-normal-out</i>       | (Optional) |
| <i>route-sum-missing-out</i>      | (Optional) |
| <i>route-best-pend-num-out</i>    | (Optional) |
| <i>route-bestpaths-out</i>        | (Optional) |
| TABLE_sum_best_path               | (Optional) |
| <i>route-path-sum-lvl-out</i>     | (Optional) |
| <i>route-path-sum-total-out</i>   | (Optional) |
| <i>route-path-sum-direct-out</i>  | (Optional) |
| <i>route-path-sum-normal-out</i>  | (Optional) |
| <i>route-backuppaths-out</i>      | (Optional) |
| TABLE_sum_backup_path             | (Optional) |
| <i>backup-path-sum-lvl-out</i>    | (Optional) |
| <i>backup-path-sum-total-out</i>  | (Optional) |
| <i>backup-path-sum-direct-out</i> | (Optional) |

|                                      |            |
|--------------------------------------|------------|
| <i>backup-path-sum-normal-out</i>    | (Optional) |
| <i>route-bestroutes-per-mask-out</i> | (Optional) |
| TABLE_best_mask                      | (Optional) |
| <i>route-best-mask-val-out</i>       | (Optional) |
| <i>route-best-mask-count-out</i>     | (Optional) |
| <i>route-pend-q-count-out</i>        | (Optional) |

**Command Mode**

- /exec

## show isis rrm

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] rrm <interface> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <rrm-if-name> [ { TABLE_rrm <rrm-level> <rrm-retx-interval> <rrm-retx-throttle-interval> <rrm-retx-queue-length> <rrm-next-retx> <rrm-retx-queue-hwm> <rrm-retx-queue-limit> <rrm-retx-queue-exceed> <rrm-dbase-hdr> [ <rrm-timestamp> ] [ <rrm-lsp-retx-instance> ] [ <rrm-lsp-db-instance> ] [ <rrm-rrm-set> ] [ <rrm-srm-set> ] } ] } ] }
```

### Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                      |
| isis                              | Display IS-IS status and configuration               |
| <i>isis-tag</i>                   | (Optional) Routing process tag                       |
| vrf                               | (Optional) Display per-VRF information               |
| <i>vrf-name</i>                   | (Optional) VRF name                                  |
| <i>vrf-known-name</i>             | (Optional) Known VRF name                            |
| all                               | (Optional) Display information for all VRFs          |
| rrm                               | Display IS-IS Retransmit-Routing-Message information |
| <i>interface</i>                  | IS-IS interface                                      |
| __readonly__                      | (Optional)   |
| TABLE_process_tag                 | (Optional)   |
| <i>process-tag-out</i>            | (Optional)   |
| <i>rrm-if-name</i>                | (Optional)   |
| TABLE_rrm                         | (Optional)   |
| <i>rrm-level</i>                  | (Optional)   |
| <i>rrm-retx-interval</i>          | (Optional)   |
| <i>rrm-retx-throttle-interval</i> | (Optional)   |
| <i>rrm-retx-queue-length</i>      | (Optional)   |
| <i>rrm-next-retx</i>              | (Optional)   |
| <i>rrm-retx-queue-hwm</i>         | (Optional)   |
| <i>rrm-retx-queue-limit</i>       | (Optional)   |
| <i>rrm-retx-queue-exceed</i>      | (Optional)   |

|                              |            |
|------------------------------|------------|
| <i>rrm-dbase-hdr</i>         | (Optional) |
| <i>rrm-timestamp</i>         | (Optional) |
| <i>rrm-lsp-retx-instance</i> | (Optional) |
| <i>rrm-lsp-db-instance</i>   | (Optional) |
| <i>rrm-rrm-set</i>           | (Optional) |
| <i>rrm-srm-set</i>           | (Optional) |

**Command Mode**

- /exec

## show isis segment-routing mapcache

```
show isis [ <isis-tag> ] segment-routing mapcache [ level-1 | level-2 ] [ <ipv4-prefix> ] [ sid <sr-sid> ] [ vrf
{ <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> {
TABLE_vrf <vrf-name-out> <srmap-v4-state> <srmap-v6-state> [ { TABLE_srmap_level <srmap-level> [
{ TABLE_srmap_pfxsid <srmap-pfxsid> <srmap-lsp-id> <srmap-pfxsid-valid> <srmap-pfxsid-flags>
<srmap-prefix> } ] } ] } ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                   |
| isis                   | Display IS-IS status and configuration            |
| <i>isis-tag</i>        | (Optional) Routing process tag                    |
| segment-routing        | show segment-routing information                  |
| mapcache               | prefix-sid mappings                               |
| level-1                | (Optional) show information for level 1 only      |
| level-2                | (Optional) show information for level 2 only      |
| <i>ipv4-prefix</i>     | (Optional) Display single exact match IP route    |
| sid                    | (Optional) show information for this SR SID value |
| <i>sr-sid</i>          | (Optional) SR SID value                           |
| vrf                    | (Optional) Display per-VRF information            |
| <i>vrf-name</i>        | (Optional) VRF name                               |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                         |
| all                    | (Optional) Display information for all VRFs       |
| __readonly__           | (Optional)  |
| TABLE_process_tag      | (Optional)  |
| <i>process-tag-out</i> | (Optional)  |
| TABLE_vrf              | (Optional)  |
| <i>vrf-name-out</i>    | (Optional)  |
| <i>srmap-v4-state</i>  | (Optional)  |
| <i>srmap-v6-state</i>  | (Optional)  |
| TABLE_srmap_level      | (Optional)  |
| <i>srmap-level</i>     | (Optional)  |

|                           |            |
|---------------------------|------------|
| TABLE_srmap_pfxsid        | (Optional) |
| <i>srmap-pfxsid</i>       | (Optional) |
| <i>srmap-lsp-id</i>       | (Optional) |
| <i>srmap-pfxsid-valid</i> | (Optional) |
| <i>srmap-pfxsid-flags</i> | (Optional) |
| <i>srmap-prefix</i>       | (Optional) |

**Command Mode**

- /exec



## show isis segment-routing remote-srgb

```
show isis [ <isis-tag> ] segment-routing remote-srgb [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ { TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <sr-v4-state>
<sr-v6-state> [ { TABLE_srgb_lsp <srgb-level> <srgb-lspid> <srgb-num-entries> <srgb-flags> [ {
TABLE_srgb_label <srgb-start-label> <srgb-range> } ] } ] } ] }
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| isis                    | Display IS-IS status and configuration      |
| <i>isis-tag</i>         | (Optional) Routing process tag              |
| segment-routing         | show segment-routing information            |
| remote-srgb             | remote SR ranges                            |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| <i>__readonly__</i>     | (Optional)                                  |
| TABLE_process_tag       | (Optional)                                  |
| <i>process-tag-out</i>  | (Optional)                                  |
| TABLE_vrf               | (Optional)                                  |
| <i>vrf-name-out</i>     | (Optional)                                  |
| <i>sr-v4-state</i>      | (Optional)                                  |
| <i>sr-v6-state</i>      | (Optional)                                  |
| TABLE_srgb_lsp          | (Optional)                                  |
| <i>srgb-level</i>       | (Optional)                                  |
| <i>srgb-lspid</i>       | (Optional)                                  |
| <i>srgb-num-entries</i> | (Optional)                                  |
| <i>srgb-flags</i>       | (Optional)                                  |
| TABLE_srgb_label        | (Optional)                                  |
| <i>srgb-start-label</i> | (Optional)                                  |

|                   |            |
|-------------------|------------|
| <i>srgb-range</i> | (Optional) |
|-------------------|------------|

**Command Mode**

- /exec

## show isis segment-routing sids

```
show isis [ <isis-tag> ] segment-routing sids [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
{ TABLE_process_tag <process-tag-out> <vrf-name-out> [ { TABLE_sr_sids <sr-sid> [ <sr-prefix> ] [
<sr-local-flag> ] [ <sr-conflict-flag> ] } } ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| isis                    | Display IS-IS status and configuration      |
| <i>isis-tag</i>         | (Optional) Routing process tag              |
| segment-routing         | show segment-routing information            |
| sids                    | sid database                                |
| vrf                     | (Optional) Display per-VRF information      |
| <i>vrf-name</i>         | (Optional) VRF name                         |
| <i>vrf-known-name</i>   | (Optional) Known VRF name                   |
| all                     | (Optional) Display information for all VRFs |
| __readonly__            | (Optional)                                  |
| TABLE_process_tag       | (Optional)                                  |
| <i>process-tag-out</i>  | (Optional)                                  |
| <i>vrf-name-out</i>     | (Optional)                                  |
| TABLE_sr_sids           | (Optional)                                  |
| <i>sr-sid</i>           | (Optional)                                  |
| <i>sr-prefix</i>        | (Optional)                                  |
| <i>sr-local-flag</i>    | (Optional)                                  |
| <i>sr-conflict-flag</i> | (Optional)                                  |

### Command Mode

- /exec

# show isis segment-routing srv6

```
show isis [ <isis-tag> ] segment-routing srv6 [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__
{ TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <vrf-id-out> <srv6-enabled-out>
<sidmgr-registered-out> } } ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information             |
| isis                         | Display IS-IS status and configuration      |
| <i>isis-tag</i>              | (Optional) Routing process tag              |
| segment-routing              | Segment-routing properties                  |
| srv6                         | Segment-routing for IPv6                    |
| vrf                          | (Optional) Display per-VRF information      |
| <i>vrf-name</i>              | (Optional) VRF name                         |
| <i>vrf-known-name</i>        | (Optional) Known VRF name                   |
| all                          | (Optional) Display information for all VRFs |
| __readonly__                 | (Optional)                                  |
| TABLE_process_tag            | (Optional)                                  |
| <i>process-tag-out</i>       | (Optional)                                  |
| TABLE_vrf                    | (Optional)                                  |
| <i>vrf-name-out</i>          | (Optional)                                  |
| <i>vrf-id-out</i>            | (Optional)                                  |
| <i>srv6-enabled-out</i>      | (Optional)                                  |
| <i>sidmgr-registered-out</i> | (Optional)                                  |

## Command Mode

- /exec

## show isis segment-routing srv6 locators

```
show isis [ <isis-tag> ] segment-routing srv6 locators [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ { TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <vrf-id-out>
<srv6-enabled-out> [ { TABLE_locators <name-out> <active-out> [ <ipv6-prefix-out> ] [ <mask-len-out> ]
<sidmgr-cfg-complete-out> <isis-cfg-complete-out> <stale-locator-out> [ { TABLE_level <level-out>
<advertised> [ <lsp-id-out> ] } ] } ] } ] }
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information             |
| isis                           | Display IS-IS status and configuration      |
| <i>isis-tag</i>                | (Optional) Routing process tag              |
| segment-routing                | Segment-routing properties                  |
| srv6                           | Segment-routing for IPv6                    |
| locators                       | IS-IS SRv6 Locator Table                    |
| vrf                            | (Optional) Display per-VRF information      |
| <i>vrf-name</i>                | (Optional) VRF name                         |
| <i>vrf-known-name</i>          | (Optional) Known VRF name                   |
| all                            | (Optional) Display information for all VRFs |
| <i>__readonly__</i>            | (Optional)                                  |
| TABLE_process_tag              | (Optional)                                  |
| <i>process-tag-out</i>         | (Optional)                                  |
| TABLE_vrf                      | (Optional)                                  |
| <i>vrf-name-out</i>            | (Optional)                                  |
| <i>vrf-id-out</i>              | (Optional)                                  |
| <i>srv6-enabled-out</i>        | (Optional)                                  |
| TABLE_locators                 | (Optional)                                  |
| <i>name-out</i>                | (Optional)                                  |
| <i>active-out</i>              | (Optional)                                  |
| <i>ipv6-prefix-out</i>         | (Optional)                                  |
| <i>mask-len-out</i>            | (Optional)                                  |
| <i>sidmgr-cfg-complete-out</i> | (Optional)                                  |

|                              |            |
|------------------------------|------------|
| <i>isis-cfg-complete-out</i> | (Optional) |
| <i>stale-locator-out</i>     | (Optional) |
| TABLE_level                  | (Optional) |
| <i>level-out</i>             | (Optional) |
| <i>advertised</i>            | (Optional) |
| <i>lsp-id-out</i>            | (Optional) |

**Command Mode**

- /exec

## show isis spf-log

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] spf-log [ detail ] [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ [ { TABLE_process_tag [ <process-tag-out> ] [ <vrf-name-out>
] [ { TABLE_topo [ <topo-id-out> ] [ <spflog-calc-out> ] [ <spflog-size-out> ] [ <spflog-maxsize-out> ] [ {
TABLE_log_detail [ <num-out> ] [ <ts-out> ] [ <date-out> ] [ { TABLE_lvl_detail [ <lvlid-out> ] [
<instance-out> ] [ <init-ts-out> ] [ <ts-lvl-out> ] } ] [ <ts-is-out> ] [ <ts-urib-out> ] [ <ts-elapsed-out> ] [ {
TABLE_lvl_second [ <lvls-out> ] [ <spf-node-out> ] [ <spf-cnt-out> ] [ <changed-cnt-out> ] [ <spf-reason-out>
] } ] } ] [ { TABLE_log_brief [ <ago-time-out> ] [ { TABLE_lvl [ <lvl-out> ] [ <reason-out> ] [ <count-out>
] } ] [ <elapsed-ts-out> ] } ] } ] }
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                |
| isis                      | Display IS-IS status and configuration         |
| <i>isis-tag</i>           | (Optional) Routing process tag                 |
| vrf                       | (Optional) Display per-VRF information         |
| <i>vrf-name</i>           | (Optional) VRF name                            |
| <i>vrf-known-name</i>     | (Optional) Known VRF name                      |
| all                       | (Optional) Display information for all VRFs    |
| spf-log                   | Display IS-IS SPF information                  |
| detail                    | (Optional) Display detail ISIS SPF information |
| __readonly__              | (Optional)                                     |
| TABLE_process_tag         | (Optional)                                     |
| <i>process-tag-out</i>    | (Optional)                                     |
| <i>vrf-name-out</i>       | (Optional)                                     |
| TABLE_topo                | (Optional)                                     |
| <i>topo-id-out</i>        | (Optional)                                     |
| <i>spflog-calc-out</i>    | (Optional)                                     |
| <i>spflog-size-out</i>    | (Optional)                                     |
| <i>spflog-maxsize-out</i> | (Optional)                                     |
| TABLE_log_detail          | (Optional)                                     |
| <i>num-out</i>            | (Optional)                                     |
| <i>ts-out</i>             | (Optional)                                     |

|                        |            |
|------------------------|------------|
| <i>date-out</i>        | (Optional) |
| TABLE_lvl_detail       | (Optional) |
| <i>lvld-out</i>        | (Optional) |
| <i>instance-out</i>    | (Optional) |
| <i>init-ts-out</i>     | (Optional) |
| <i>ts-lvl-out</i>      | (Optional) |
| <i>ts-is-out</i>       | (Optional) |
| <i>ts-urib-out</i>     | (Optional) |
| <i>ts-elapsed-out</i>  | (Optional) |
| TABLE_lvl_second       | (Optional) |
| <i>lvls-out</i>        | (Optional) |
| <i>spf-node-out</i>    | (Optional) |
| <i>spf-cnt-out</i>     | (Optional) |
| <i>changed-cnt-out</i> | (Optional) |
| <i>spf-reason-out</i>  | (Optional) |
| TABLE_log_brief        | (Optional) |
| <i>ago-time-out</i>    | (Optional) |
| TABLE_lvl              | (Optional) |
| <i>lvl-out</i>         | (Optional) |
| <i>reason-out</i>      | (Optional) |
| <i>count-out</i>       | (Optional) |
| <i>elapsed-ts-out</i>  | (Optional) |

**Command Mode**

- /exec



## show isis srm

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] srm <interface> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <srm-if-name> [ { TABLE_srm <srm-level> <srm-if-eligible> <srm-if-not-on-srm-list> <srm-lsp-interval> <srm-next-lsp> <srm-dbase-hdr> } ] } ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                |
| isis                          | Display IS-IS status and configuration         |
| <i>isis-tag</i>               | (Optional) Routing process tag                 |
| vrf                           | (Optional) Display per-VRF information         |
| <i>vrf-name</i>               | (Optional) VRF name                            |
| <i>vrf-known-name</i>         | (Optional) Known VRF name                      |
| all                           | (Optional) Display information for all VRFs    |
| srm                           | Display IS-IS Send-Routing-Message information |
| <i>interface</i>              | IS-IS interface                                |
| __readonly__                  | (Optional)                                     |
| TABLE_process_tag             | (Optional)                                     |
| <i>process-tag-out</i>        | (Optional)                                     |
| <i>srm-if-name</i>            | (Optional)                                     |
| TABLE_srm                     | (Optional)                                     |
| <i>srm-level</i>              | (Optional)                                     |
| <i>srm-if-eligible</i>        | (Optional)                                     |
| <i>srm-if-not-on-srm-list</i> | (Optional)                                     |
| <i>srm-lsp-interval</i>       | (Optional)                                     |
| <i>srm-next-lsp</i>           | (Optional)                                     |
| <i>srm-dbase-hdr</i>          | (Optional)                                     |

### Command Mode

- /exec

## show isis ssn

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] ssn <interface> [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> <snn-if-name> [ { TABLE_ssn <snn-level> <snn-psnp-eligible> <snn-next-psnp> <snn-dbase_hdr> } ] } ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                |
| isis                     | Display IS-IS status and configuration         |
| <i>isis-tag</i>          | (Optional) Routing process tag                 |
| vrf                      | (Optional) Display per-VRF information         |
| <i>vrf-name</i>          | (Optional) VRF name                            |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                      |
| all                      | (Optional) Display information for all VRFs    |
| ssn                      | Display IS-IS Send-Sequence-Number information |
| <i>interface</i>         | IS-IS interface                                |
| __readonly__             | (Optional)                                     |
| TABLE_process_tag        | (Optional)                                     |
| <i>process-tag-out</i>   | (Optional)                                     |
| <i>snn-if-name</i>       | (Optional)                                     |
| TABLE_ssn                | (Optional)                                     |
| <i>snn-level</i>         | (Optional)                                     |
| <i>snn-psnp-eligible</i> | (Optional)                                     |
| <i>snn-next-psnp</i>     | (Optional)                                     |
| <i>snn-dbase_hdr</i>     | (Optional)                                     |

### Command Mode

- /exec

## show isis statistics

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] statistics [ <interface> ] [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ { TABLE_interface_set [ <stat-if-out> ] [
<process-tag-out> ] [ <vrf-name-out> ] [ <stat-if-name-out> ] [ <stat-spf-calc-out> ] [ <stat-lsp-sourced-out>
] [ <stat-lsp-refresh-out> ] [ <stat-lsp-purge-out> ] [ <stat-dis-elections-out> } ] ] ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information             |
| isis                          | Display IS-IS status and configuration      |
| <i>isis-tag</i>               | (Optional) Routing process tag              |
| vrf                           | (Optional) Display per-VRF information      |
| <i>vrf-name</i>               | (Optional) VRF name                         |
| <i>vrf-known-name</i>         | (Optional) Known VRF name                   |
| all                           | (Optional) Display information for all VRFs |
| statistics                    | Display IS-IS protocol statistics           |
| <i>interface</i>              | (Optional) IS-IS interface                  |
| <i>__readonly__</i>           | (Optional)                                  |
| TABLE_interface_set           | (Optional)                                  |
| <i>stat-if-out</i>            | (Optional)                                  |
| <i>process-tag-out</i>        | (Optional)                                  |
| <i>vrf-name-out</i>           | (Optional)                                  |
| <i>stat-if-name-out</i>       | (Optional)                                  |
| <i>stat-spf-calc-out</i>      | (Optional)                                  |
| <i>stat-lsp-sourced-out</i>   | (Optional)                                  |
| <i>stat-lsp-refresh-out</i>   | (Optional)                                  |
| <i>stat-lsp-purge-out</i>     | (Optional)                                  |
| <i>stat-dis-elections-out</i> | (Optional)                                  |

### Command Mode

- /exec

## show isis summary-address

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ ip ] summary-address [ <ip-addr> |
<ip-prefix> [ longer-prefixes ] ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<vrf-name-out> <tag-out> <afi-safi-out> [ <addr-absent-out> ] [ { TABLE_addr <sum-prefix-out>
<mask-len-out> <level-out> [ { TABLE_lvl <addr-lvl-out> <addr-num-out> [ <addr-metric-absent-out> ] [
<addr-metric-out> ] [ <addr-route-count-out> } ] } ] ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                  |
| isis                   | Display IS-IS status and configuration                           |
| <i>isis-tag</i>        | (Optional) Routing process tag                                   |
| vrf                    | (Optional) Display per-VRF information                           |
| <i>vrf-name</i>        | (Optional) VRF name  |
| <i>vrf-known-name</i>  | (Optional) Known VRF name  |
| all                    | (Optional) Display information for all VRFs                      |
| ip                     | (Optional) Display IS-IS IPv4 information                        |
| summary-address        | Display IS-IS summary address                                    |
| <i>ip-addr</i>         | (Optional) Display single IP summary address                     |
| <i>ip-prefix</i>       | (Optional) Display single exact match IP summary address         |
| longer-prefixes        | (Optional) Display exact match and more specific summary address |
| __readonly__           | (Optional)   |
| TABLE_vrf              | (Optional)   |
| <i>vrf-name-out</i>    | (Optional)   |
| <i>tag-out</i>         | (Optional)   |
| <i>afi-safi-out</i>    | (Optional)   |
| <i>addr-absent-out</i> | (Optional)   |
| TABLE_addr             | (Optional)   |
| <i>sum-prefix-out</i>  | (Optional)   |
| <i>mask-len-out</i>    | (Optional)   |
| <i>level-out</i>       | (Optional)   |
| TABLE_lvl              | (Optional)   |

|                               |            |
|-------------------------------|------------|
| <i>addr-lvl-out</i>           | (Optional) |
| <i>addr-num-out</i>           | (Optional) |
| <i>addr-metric-absent-out</i> | (Optional) |
| <i>addr-metric-out</i>        | (Optional) |
| <i>addr-route-count-out</i>   | (Optional) |

**Command Mode**

- /exec



|   |            |
|---|------------|
| <i>topology-one-route-on-path</i>           | (Optional) |
| <i>topology-one-route-mt-id</i>             | (Optional) |
| TABLE_ONE_ROUTE_NH                          | (Optional) |
| <i>topology-one-route-nh-system-name</i>    | (Optional) |
| <i>topology-one-route-nh-if-name</i>        | (Optional) |
| <i>topology-one-route-nh-metric</i>         | (Optional) |
| TABLE_ONE_ROUTE_MBEST                       | (Optional) |
| <i>topology-one-route-mbest-system-name</i> | (Optional) |
| <i>topology-one-route-mbest-if-name</i>     | (Optional) |
| <i>topology-one-route-mbest-metric</i>      | (Optional) |
| <i>topology-default-spf-instance</i>        | (Optional) |
| TABLE_NH                                    | (Optional) |
| <i>topology-nh-system-name</i>              | (Optional) |
| <i>topology-nh-if-name</i>                  | (Optional) |
| <i>topology-nh-metric</i>                   | (Optional) |
| TABLE_MBEST                                 | (Optional) |
| <i>topology-mbest-system-name</i>           | (Optional) |
| <i>topology-mbest-if-name</i>               | (Optional) |
| <i>topology-mbest-metric</i>                | (Optional) |

**Command Mode**

- /exec

## show isis traffic

```
show isis [ <isis-tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] traffic [ <interface> ] [ interfaces ] [
mbuf-priority ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ { TABLE_process_tag
<process-tag-out> [ { TABLE_vrf [ <vrf-name-out> ] [ { TABLE_interface [ <traffic-if-name-out> ] [
<traffic-lan-iih-out> ] [ <traffic-lan-iih-rcv-out> ] [ <traffic-lan-iih-xmit-out> ] [
<traffic-lan-iih-rcv-auth-err-out> ] [ <traffic-lan-iih-rcv-err-out> ] [ <traffic-p2p-iih-out> ] [
<traffic-p2p-iih-rcv-out> ] [ <traffic-p2p-iih-xmit-out> ] [ <traffic-p2p-iih-rcv-auth-err-out> ] [
<traffic-p2p-iih-rcv-err-out> ] [ <traffic-csnp-out> ] [ <traffic-csnp-rcv-out> ] [ <traffic-csnp-xmit-out> ] [
<traffic-csnp-rcv-auth-err-out> ] [ <traffic-csnp-rcv-err-out> ] [ <traffic-psnp-out> ] [ <traffic-psnp-rcv-out>
] [ <traffic-psnp-xmit-out> ] [ <traffic-psnp-rcv-auth-err-out> ] [ <traffic-psnp-rcv-err-out> ] [ <traffic-lsp-out>
] [ <traffic-lsp-rcv-out> ] [ <traffic-lsp-flood-out> ] [ <traffic-lsp-rcv-auth-err-out> ] [ <traffic-lsp-rcv-err-out>
] [ <traffic-lsp-rexmit-out> ] [ <traffic-xmit-err-out> ] [ <traffic-unknown-pdu-rcv-out> ] } ] [
<traffic-lan-iih-out> ] [ <traffic-lan-iih-rcv-out> ] [ <traffic-lan-iih-xmit-out> ] [
<traffic-lan-iih-rcv-auth-err-out> ] [ <traffic-lan-iih-rcv-err-out> ] [ <traffic-p2p-iih-out> ] [
<traffic-p2p-iih-rcv-out> ] [ <traffic-p2p-iih-xmit-out> ] [ <traffic-p2p-iih-rcv-auth-err-out> ] [
<traffic-p2p-iih-rcv-err-out> ] [ <traffic-csnp-out> ] [ <traffic-csnp-rcv-out> ] [ <traffic-csnp-xmit-out> ] [
<traffic-csnp-rcv-auth-err-out> ] [ <traffic-csnp-rcv-err-out> ] [ <traffic-psnp-out> ] [ <traffic-psnp-rcv-out>
] [ <traffic-psnp-xmit-out> ] [ <traffic-psnp-rcv-auth-err-out> ] [ <traffic-psnp-rcv-err-out> ] [ <traffic-lsp-out>
] [ <traffic-lsp-rcv-out> ] [ <traffic-lsp-flood-out> ] [ <traffic-lsp-rcv-auth-err-out> ] [ <traffic-lsp-rcv-err-out>
] [ <traffic-lsp-rexmit-out> ] [ <traffic-xmit-err-out> ] [ <traffic-unknown-pdu-rcv-out> ] } } ] }
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                                 |
| isis                   | Display IS-IS status and configuration                          |
| <i>isis-tag</i>        | (Optional) Routing process tag                                  |
| vrf                    | (Optional) Display per-VRF information                          |
| <i>vrf-name</i>        | (Optional) VRF name   |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                                       |
| all                    | (Optional) Display information for all VRFs                     |
| traffic                | Display IS-IS traffic information                               |
| <i>interface</i>       | (Optional) IS-IS interface                                      |
| interfaces             | (Optional) Display IS-IS traffic information for all interfaces |
| mbuf-priority          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| <i>__readonly__</i>    | (Optional)  |
| TABLE_process_tag      | (Optional)  |
| <i>process-tag-out</i> | (Optional)  |
| TABLE_interface        | (Optional)  |



|   |            |
|---|------------|
| <i>traffic-if-name-out</i>              | (Optional) |
| <i>traffic-lan-iih-out</i>              | (Optional) |
| <i>traffic-lan-iih-rcv-out</i>          | (Optional) |
| <i>traffic-lan-iih-xmit-out</i>         | (Optional) |
| <i>traffic-lan-iih-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-lan-iih-rcv-err-out</i>      | (Optional) |
| <i>traffic-p2p-iih-out</i>              | (Optional) |
| <i>traffic-p2p-iih-rcv-out</i>          | (Optional) |
| <i>traffic-p2p-iih-xmit-out</i>         | (Optional) |
| <i>traffic-p2p-iih-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-p2p-iih-rcv-err-out</i>      | (Optional) |
| <i>traffic-csnp-out</i>                 | (Optional) |
| <i>traffic-csnp-rcv-out</i>             | (Optional) |
| <i>traffic-csnp-xmit-out</i>            | (Optional) |
| <i>traffic-csnp-rcv-auth-err-out</i>    | (Optional) |
| <i>traffic-csnp-rcv-err-out</i>         | (Optional) |
| <i>traffic-psnp-out</i>                 | (Optional) |
| <i>traffic-psnp-rcv-out</i>             | (Optional) |
| <i>traffic-psnp-xmit-out</i>            | (Optional) |
| <i>traffic-psnp-rcv-auth-err-out</i>    | (Optional) |
| <i>traffic-psnp-rcv-err-out</i>         | (Optional) |
| <i>traffic-lsp-out</i>                  | (Optional) |
| <i>traffic-lsp-rcv-out</i>              | (Optional) |
| <i>traffic-lsp-flood-out</i>            | (Optional) |
| <i>traffic-lsp-rcv-auth-err-out</i>     | (Optional) |
| <i>traffic-lsp-rcv-err-out</i>          | (Optional) |
| <i>traffic-lsp-rexmit-out</i>           | (Optional) |
| <i>traffic-xmit-err-out</i>             | (Optional) |
| <i>traffic-unknown-pdu-rcv-out</i>      | (Optional) |

|   |            |
|---|------------|
| TABLE_vrf                               | (Optional) |
| <i>vrf-name-out</i>                     | (Optional) |
| <i>traffic-lan-iih-out</i>              | (Optional) |
| <i>traffic-lan-iih-rcv-out</i>          | (Optional) |
| <i>traffic-lan-iih-xmit-out</i>         | (Optional) |
| <i>traffic-lan-iih-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-lan-iih-rcv-err-out</i>      | (Optional) |
| <i>traffic-p2p-iih-out</i>              | (Optional) |
| <i>traffic-p2p-iih-rcv-out</i>          | (Optional) |
| <i>traffic-p2p-iih-xmit-out</i>         | (Optional) |
| <i>traffic-p2p-iih-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-p2p-iih-rcv-err-out</i>      | (Optional) |
| <i>traffic-csnp-out</i>                 | (Optional) |
| <i>traffic-csnp-rcv-out</i>             | (Optional) |
| <i>traffic-csnp-xmit-out</i>            | (Optional) |
| <i>traffic-csnp-rcv-auth-err-out</i>    | (Optional) |
| <i>traffic-csnp-rcv-err-out</i>         | (Optional) |
| <i>traffic-psnp-out</i>                 | (Optional) |
| <i>traffic-psnp-rcv-out</i>             | (Optional) |
| <i>traffic-psnp-xmit-out</i>            | (Optional) |
| <i>traffic-psnp-rcv-auth-err-out</i>    | (Optional) |
| <i>traffic-psnp-rcv-err-out</i>         | (Optional) |
| <i>traffic-lsp-out</i>                  | (Optional) |
| <i>traffic-lsp-rcv-out</i>              | (Optional) |
| <i>traffic-lsp-flood-out</i>            | (Optional) |
| <i>traffic-lsp-rcv-auth-err-out</i>     | (Optional) |
| <i>traffic-lsp-rcv-err-out</i>          | (Optional) |
| <i>traffic-lsp-rexmit-out</i>           | (Optional) |
| <i>traffic-xmit-err-out</i>             | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>traffic-unknown-pdu-rcv-out</i> | (Optional) |
|------------------------------------|------------|

**Command Mode**

- /exec

## show itd

```
show itd [ <svc-name> ] [ brief ] [ __readonly__ ] [ TABLE_summary <is_detail> <is_active> <service_name>
<is_include_acl> <probe> <lb_scheme> <state> <buckets> [ <interface_num> ] [ <interface> ] [
TABLE_interface <interface_grp> ] [ <reason> ] [ <src_interface> ] [ <source_vlan> ] [ <vrf_name> ] [
<excludeACL> ] [ <peer_status> ] <is_l2> [ TABLE_device <device_grp> [ <dg_probe> ] [ <dg_probe_port>
] [ <dg_vrf_name> ] ] [ <is_firstentry_routemap> ] [ TABLE_route_map [ <route_map> ] [
TABLE_rmap_interface [ <r_interface> ] [ <r_status> ] [ <int_track_id> ] ] ] [ TABLE_vip [ <vip_flags> ]
[ <vip_acl_key> ] [ <vip_probe> ] [ <vip_port> ] [ <ace_buckets> ] [ <vip_dgname> ] [ <vip_dg_vrf_name>
] [ <is_firstentry_vip_node> ] [ TABLE_vip_node <is_vip_node_ipv6> <vip_node> [ <vip_node_cluster> ]
<vip_config> <vip_weight> <vip_node_port> <vip_node_probe> <vip_node_probe_port>
<vip_node_probe_ip> <vip_status> <vip_track_id> <vip_ip_sla_id> [ <is_firstentry_standby> ] [
TABLE_vip_standby <is_standby_vip_node_ipv6> <vip_standby_ip> <vip_standby_config>
<vip_standby_weight> <vip_standby_probe> <vip_standby_probe_port> <vip_standby_probe_ip>
<vip_standby_status> <vip_standby_track_id> <vip_standby_sla_id> ] [ <is_firstentry_acl> ] [ TABLE_vip_acl
[ <vip_access_list> ] ] ] [ <is_firstentry> ] [ TABLE_node [ <is_node_ipv6> ] <node> [ <node_cluster> ]
[ <config> ] [ <weight> ] [ <port> ] [ <node_probe> ] [ <node_probe_port> ] [ <node_probe_ip> ] [ <status>
] [ <track_id> ] [ <ip_sla_id> ] [ <is_first_def_stdby> ] [ TABLE_standby <is_standby_node_ipv6>
<standby_ip> <standby_config> <standby_weight> <standby_probe> <standby_probe_port>
<standby_probe_ip> <standby_status> <standby_track_id> <standby_sla_id> ] [ <is_first_defdg_acl> ] [
TABLE_acl [ <access_list> ] ] ] ] [ <is_lastentry> ] ]
```

### Syntax Description

|                               |                                     |
|-------------------------------|-------------------------------------|
| show                          | Show running system information     |
| itd                           | ITD service                         |
| <i>svc-name</i>               | (Optional) ITD service name         |
| brief                         | (Optional) brief                    |
| <i>__readonly__</i>           | (Optional) Read Only                |
| <i>is_firstentry</i>          | (Optional) First entry              |
| <i>is_firstentry_vip_node</i> | (Optional) First VIP node entry     |
| <i>is_detail</i>              | (Optional) In detail                |
| <i>is_active</i>              | (Optional) Is active                |
| <i>is_firstentry_routemap</i> | (Optional) Is first route-map entry |
| <i>is_firstentry_acl</i>      | (Optional) Is first acl entry       |
| <i>is_firstentry_standby</i>  | (Optional) Is first standby entry   |
| <i>is_include_acl</i>         | (Optional) Is include acl           |
| <i>is_first_defdg_acl</i>     | (Optional) Is first default dg acl  |
| <i>is_l2</i>                  | (Optional) Is L2 service            |

|                      |   |
|----------------------|---|
| TABLE_summary        | (Optional)                              |
| <i>service_name</i>  | (Optional) service_name                 |
| <i>probe</i>         | (Optional) probe                        |
| <i>lb_scheme</i>     | (Optional) lb scheme                    |
| <i>interface_num</i> | (Optional) Number of ingress interfaces |
| <i>interface</i>     | (Optional) interface                    |
| TABLE_interface      | (Optional)                              |
| <i>interface_grp</i> | (Optional) interface_grp                |
| <i>src_interface</i> | (Optional) source interface for probe   |
| <i>state</i>         | (Optional) state                        |
| <i>buckets</i>       | (Optional) buckets                      |
| <i>reason</i>        | (Optional) inactive reason              |
| <i>vrf_name</i>      | (Optional) VRF-Name                     |
| <i>excludeACL</i>    | (Optional) exclude access-list          |
| <i>peer_status</i>   | (Optional) peer status                  |
| TABLE_device         | (Optional)                              |
| <i>device_grp</i>    | (Optional) service device group         |
| <i>dg_probe</i>      | (Optional) probe type                   |
| <i>dg_probe_port</i> | (Optional) probe port                   |
| <i>dg_vrf_name</i>   | (Optional) VRF name for device-group    |
| TABLE_route_map      | (Optional)                              |
| <i>route_map</i>     | (Optional) service route map            |
| TABLE_rmap_interface | (Optional)                              |
| <i>r_interface</i>   | (Optional) interface                    |
| <i>r_status</i>      | (Optional) route map status             |
| <i>int_track_id</i>  | (Optional) interface track id           |
| TABLE_vip            | (Optional)                              |
| <i>vip_flags</i>     | (Optional) VIP encoded flags            |
| <i>vip_acl_key</i>   | (Optional) vip ip or acl name           |

|                                 |  |
|---------------------------------|--|
| <i>vip_probe</i>                | (Optional) vip protocol                  |
| <i>vip_port</i>                 | (Optional) vip port                      |
| <i>vip_dgname</i>               | (Optional) vip device group              |
| <i>vip_dg_vrf_name</i>          | (Optional) VRF name for VIP device-group |
| <i>ace_buckets</i>              | (Optional) ace active buckets            |
| TABLE_vip_node                  | (Optional)                               |
| <i>is_vip_node_ipv6</i>         | (Optional) is node ipv6                  |
| <i>vip_node</i>                 | (Optional) service node ip               |
| <i>vip_node_cluster</i>         | (Optional) cluster id                    |
| <i>vip_config</i>               | (Optional) node config                   |
| <i>vip_weight</i>               | (Optional) node weight                   |
| <i>vip_node_port</i>            | (Optional) node port                     |
| <i>vip_status</i>               | (Optional) node status                   |
| <i>vip_node_probe</i>           | (Optional) node probe type               |
| <i>vip_node_probe_port</i>      | (Optional) node probe port               |
| <i>vip_node_probe_ip</i>        | (Optional) node probe ip                 |
| <i>vip_track_id</i>             | (Optional) node track id                 |
| <i>vip_ip_sla_id</i>            | (Optional) node ip sla id                |
| TABLE_vip_standby               | (Optional)                               |
| <i>is_standby_vip_node_ipv6</i> | (Optional) is standby node ipv6          |
| <i>vip_standby_ip</i>           | (Optional) standby node ip               |
| <i>vip_standby_config</i>       | (Optional) standby node config           |
| <i>vip_standby_weight</i>       | (Optional) standby node weight           |
| <i>vip_standby_status</i>       | (Optional) standby node status           |
| <i>vip_standby_probe</i>        | (Optional) standby node probe type       |
| <i>vip_standby_probe_port</i>   | (Optional) standby node probe port       |
| <i>vip_standby_probe_ip</i>     | (Optional) standby node probe ip         |
| <i>vip_standby_track_id</i>     | (Optional) standby node track id         |
| <i>vip_standby_sla_id</i>       | (Optional) standby node sla id           |

|                             |                                     |
|-----------------------------|-------------------------------------|
| TABLE_vip_acl               | (Optional)                          |
| <i>vip_access_list</i>      | (Optional) access list              |
| TABLE_node                  | (Optional)                          |
| <i>is_node_ipv6</i>         | (Optional) is node ipv6             |
| <i>node</i>                 | (Optional) service node ip          |
| <i>node_cluster</i>         | (Optional) cluster id               |
| <i>config</i>               | (Optional) node config              |
| <i>weight</i>               | (Optional) node weight              |
| <i>port</i>                 | (Optional) node port                |
| <i>status</i>               | (Optional) node status              |
| <i>node_probe</i>           | (Optional) node probe type          |
| <i>node_probe_port</i>      | (Optional) node probe port          |
| <i>node_probe_ip</i>        | (Optional) node probe ip            |
| <i>track_id</i>             | (Optional) node track id            |
| <i>ip_sla_id</i>            | (Optional) node ip sla id           |
| <i>is_first_def_stdbby</i>  | (Optional) first default dg standby |
| TABLE_standby               | (Optional)                          |
| <i>is_standby_node_ipv6</i> | (Optional) is standby node ipv6     |
| <i>standby_ip</i>           | (Optional) standby node ip          |
| <i>standby_config</i>       | (Optional) standby node config      |
| <i>standby_weight</i>       | (Optional) standby node weight      |
| <i>standby_status</i>       | (Optional) standby node status      |
| <i>standby_probe</i>        | (Optional) standby node probe type  |
| <i>standby_probe_port</i>   | (Optional) standby node probe port  |
| <i>standby_probe_ip</i>     | (Optional) standby node probe ip    |
| <i>standby_track_id</i>     | (Optional) standby node track id    |
| <i>standby_sla_id</i>       | (Optional) standby node sla id      |
| TABLE_acl                   | (Optional)                          |
| <i>access_list</i>          | (Optional) access list              |

|                     |                                       |
|---------------------|---------------------------------------|
| <i>is_lastentry</i> | (Optional) last entry                 |
| <i>source_vlan</i>  | (Optional) source vlan for L2 service |

**Command Mode**

- /exec



## show itd session device-group

```
show itd session device-group [ <name> ] [ __readonly__ [ TABLE_dg <dg_name> <first_entry> [ TABLE_svc
<node> [ <utrackid> ] [ <clusterid> ] [ <weight> ] ] ] ]
```

### Syntax Description

|                     |                                     |
|---------------------|-------------------------------------|
| show                | Show running system information     |
| itd                 | ITD service                         |
| session             | ITD service session                 |
| device-group        | ITD service session device-group    |
| <i>name</i>         | (Optional) ITD Service session name |
| <i>__readonly__</i> | (Optional) Read Only                |
| TABLE_dg            | (Optional)                          |
| <i>dg_name</i>      | (Optional) Device-group name        |
| <i>first_entry</i>  | (Optional)                          |
| TABLE_svc           | (Optional)                          |
| <i>node</i>         | (Optional) node                     |
| <i>utrackid</i>     | (Optional) track for node           |
| <i>clusterid</i>    | (Optional) cluster id for node      |
| <i>weight</i>       | (Optional) weight for node          |

### Command Mode

- /exec

## show itd statistics

```
show itd { <svc-name> | all } [ { src { <src-ip> | <src-IPv6> } } | { dst { <dst-ip> | <dst-IPv6> } } ] statistics
[ brief ] [ __readonly__ [ TABLE_nice [ <is_for_ace> ] <service_name> <dev_grp> [ <vip> ] [ <ace_seq> ]
[ <ace_ip> ] <vip_pkt> <percentage> [ TABLE_node <node_num> [ TABLE_bucket <bucket_acl> <node>
<mode> <orig_node> <acl_pkt> <bucket_per> ] ] [ TABLE_return_pkt <return_node_num> <return_node>
<return_node_pkt> <return_node_percentage> ] [ <return_pkt> ] [ <return_percentage> ] ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                   |
| __readonly__             | (Optional) Read Only                              |
| itd                      | ITD service                                       |
| statistics               | ITD statistics                                    |
| brief                    | (Optional) brief                                  |
| <i>svc-name</i>          | ITD service name                                  |
| all                      | All ITD services                                  |
| src                      | (Optional) Statistics for src ip                  |
| <i>src-ip</i>            | (Optional) Provide statistics for src ip          |
| dst                      | (Optional) Statistics for dst ip                  |
| <i>dst-ip</i>            | (Optional) Provide statistics for dst ip          |
| TABLE_nice               | (Optional)  |
| <i>is_for_ace</i>        | (Optional) ACE/VIP based services                 |
| <i>service_name</i>      | (Optional) ITD service name                       |
| <i>dev_grp</i>           | (Optional) device group                           |
| <i>vip</i>               | (Optional) service virtual ip                     |
| <i>ace_seq</i>           | (Optional) service ACE name and sequence number   |
| <i>ace_ip</i>            | (Optional) service ACE ip/mask/prefix             |
| <i>vip_pkt</i>           | (Optional) virtual ip pkt_count                   |
| <i>percentage</i>        | (Optional) Packet percentage                      |
| <i>return_pkt</i>        | (Optional) total return traffic packet count      |
| <i>return_percentage</i> | (Optional) total return traffic packet percentage |
| TABLE_node               | (Optional)  |

|                               |   |
|-------------------------------|---|
| <i>node_num</i>               | (Optional) Node number                      |
| TABLE_bucket                  | (Optional)                                  |
| <i>bucket_acl</i>             | (Optional) access list                      |
| <i>node</i>                   | (Optional) service node ip                  |
| <i>mode</i>                   | (Optional) Redirect mode                    |
| <i>orig_node</i>              | (Optional) original node ip                 |
| <i>acl_pkt</i>                | (Optional) acl pkt count                    |
| <i>bucket_per</i>             | (Optional) Packet percentage                |
| TABLE_return_pkt              | (Optional)                                  |
| <i>return_node_num</i>        | (Optional) Node number                      |
| <i>return_node</i>            | (Optional) return traffic node ip           |
| <i>return_node_pkt</i>        | (Optional) return traffic packet count      |
| <i>return_node_percentage</i> | (Optional) return traffic packet percentage |

**Command Mode**

- /exec

# show itd vrf

```
show itd vrf [ <name> ] [ __readonly__ <first_entry> [ TABLE_svc <service_name> <vrf_name> <vrf_id> ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| itd                 | ITD service                     |
| vrf                 | ITD service vrf                 |
| <i>name</i>         | (Optional) ITD Service VRF name |
| <i>__readonly__</i> | (Optional) Read Only            |
| <i>first_entry</i>  | (Optional)                      |
| TABLE_svc           | (Optional)                      |
| <i>service_name</i> | (Optional) itd service name     |
| <i>vrf_name</i>     | (Optional) vrf name             |
| <i>vrf_id</i>       | (Optional) vrf id               |

## Command Mode

- /exec

# show itu channel

show itu channel { <itu\_val> | all } [ \_\_readonly\_\_ TABLE\_itu <ituchannel> <frequency> <wavelength> ]

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| itu                 | Show itu channel mapping        |
| channel             | Show itu channel mapping        |
| <i>itu_val</i>      | Enter itu channel               |
| all                 | Show all itu channel mapping    |
| <u>__readonly__</u> | (Optional) Read Only            |
| TABLE_itu           | (Optional) show itu channel     |
| <i>ituchannel</i>   | (Optional) itu channel          |
| <i>frequency</i>    | (Optional) frequency in THz     |
| <i>wavelength</i>   | (Optional) wavelength in nm     |

## Command Mode

- /exec





## K Show Commands

---

- [show key chain, on page 1754](#)
- [show key chain mode decrypt, on page 1755](#)
- [show keystore, on page 1756](#)
- [show kim inconsistency, on page 1757](#)
- [show kubernetes containers, on page 1758](#)

# show key chain

```
{ show key chain [ <keychain> ] } [ __readonly__ TABLE_keychain <chain_name> { TABLE_key [ <key_id> ] [ <key_string> ] [ <crypto_algo> ] [ <accept_utc_zone> ] [ <accept_start> ] [ <accept_end> ] [ <accept_valid> ] [ <send_utc_zone> ] [ <send_start> ] [ <send_end> ] [ <send_valid> ] } }
```

## Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| key                    | Display Key Information         |
| chain                  | Display Keychain Information    |
| <i>keychain</i>        | (Optional) Keychain name        |
| <i>__readonly__</i>    | (Optional)                      |
| TABLE_keychain         | (Optional)                      |
| TABLE_key              | (Optional)                      |
| <i>chain_name</i>      | (Optional)                      |
| <i>key_id</i>          | (Optional)                      |
| <i>key_string</i>      | (Optional)                      |
| <i>crypto_algo</i>     | (Optional)                      |
| <i>accept_utc_zone</i> | (Optional)                      |
| <i>accept_start</i>    | (Optional)                      |
| <i>accept_end</i>      | (Optional)                      |
| <i>accept_valid</i>    | (Optional)                      |
| <i>send_utc_zone</i>   | (Optional)                      |
| <i>send_start</i>      | (Optional)                      |
| <i>send_end</i>        | (Optional)                      |
| <i>send_valid</i>      | (Optional)                      |

## Command Mode

- /exec



# show key chain mode decrypt

```
{ show key chain [ <keychain> ] mode decrypt } [ __readonly__ TABLE_keychain_decrypt <chain_name>
{ TABLE_key [ <key_id> ] [ <key_string> ] [ <crypto_algo> ] [ <accept_utc_zone> ] [ <accept_start> ] [
<accept_end> ] [ <accept_valid> ] [ <send_utc_zone> ] [ <send_start> ] [ <send_end> ] [ <send_valid> ] } }
```

## Syntax Description

|                               |                                 |
|-------------------------------|---------------------------------|
| show                          | Show running system information |
| key                           | Display Key Information         |
| chain                         | Display Keychain Information    |
| <i>keychain</i>               | (Optional) Keychain name        |
| mode                          | Mode of display                 |
| decrypt                       | Display Decrypted Keystings     |
| <i>__readonly__</i>           | (Optional)                      |
| <i>TABLE_keychain_decrypt</i> | (Optional)                      |
| <i>TABLE_key</i>              | (Optional)                      |
| <i>chain_name</i>             | (Optional)                      |
| <i>key_id</i>                 | (Optional)                      |
| <i>key_string</i>             | (Optional)                      |
| <i>crypto_algo</i>            | (Optional)                      |
| <i>accept_utc_zone</i>        | (Optional)                      |
| <i>accept_start</i>           | (Optional)                      |
| <i>accept_end</i>             | (Optional)                      |
| <i>accept_valid</i>           | (Optional)                      |
| <i>send_utc_zone</i>          | (Optional)                      |
| <i>send_start</i>             | (Optional)                      |
| <i>send_end</i>               | (Optional)                      |
| <i>send_valid</i>             | (Optional)                      |

## Command Mode

- /exec

# show keystore

```
show keystore [ __readonly__ { TABLE_sksd_state_entries <index> <handle> } <keystore_type>
<keystore_ver> <fw_panic> <fw_resets> <rx_fifo_underruns> <rx_timeouts> <rx_bad_checksums>
<rx_bad_fragment_lengths> <keystore_corruption> ]
```

## Syntax Description

|                                |  |
|--------------------------------|--|
| keystore                       | keystore stats                                 |
| <i>__readonly__</i>            | (Optional)                                     |
| TABLE_sksd_state_entries       | (Optional) Displays handles of the keys stored |
| <i>index</i>                   | (Optional) Index value                         |
| <i>handle</i>                  | (Optional) Handle Name                         |
| <i>keystore_type</i>           | (Optional) Type of storage h/w or s/w          |
| <i>keystore_ver</i>            | (Optional) Version                             |
| <i>fw_panic</i>                | (Optional) Number of panics                    |
| <i>fw_resets</i>               | (Optional) Number of Resets                    |
| <i>rx_fifo_underruns</i>       | (Optional) Rx FIFO Underruns                   |
| <i>rx_timeouts</i>             | (Optional) Number of Rx timeouts               |
| <i>rx_bad_checksums</i>        | (Optional) Number of Bad Checksums             |
| <i>rx_bad_fragment_lengths</i> | (Optional) Bad fragment lengths received       |
| <i>keystore_corruption</i>     | (Optional) Number of corruptions detected      |

## Command Mode

- /exec

# show kim inconsistency

show kim inconsistency

## Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| kim           | Display KIM information         |
| inconsistency | KIM inconsistency               |

## Command Mode

- /exec

# show kubernetes containers

show kubernetes containers [ brief | interface <if\_name> | mgmt0 ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| kubernetes     | Show kubernetes                           |
| containers     | containers                                |
| brief          | (Optional) Show brief information         |
| interface      | (Optional) Interface name                 |
| <i>if_name</i> | (Optional) Physical interface             |
| mgmt0          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

## Command Mode

- /exec



## L Show Commands

---

- [show l2 mroute](#), on page 1766
- [show l2 multicast ftag](#), on page 1768
- [show l2 multicast trees](#), on page 1769
- [show l2 route](#), on page 1771
- [show l2rib clients](#), on page 1773
- [show l2rib producers](#), on page 1774
- [show l2rib registrations](#), on page 1776
- [show l2route cmcast topology](#), on page 1778
- [show l2route evpn ead all](#), on page 1779
- [show l2route evpn ethernet-segment esi](#), on page 1780
- [show l2route evpn fl all](#), on page 1781
- [show l2route evpn fl evi](#), on page 1782
- [show l2route evpn imet all](#), on page 1783
- [show l2route evpn imet evi](#), on page 1784
- [show l2route evpn mac-ip all](#), on page 1785
- [show l2route evpn mac-ip evi](#), on page 1787
- [show l2route evpn mac all](#), on page 1789
- [show l2route evpn mac evi](#), on page 1791
- [show l2route evpn path-list all](#), on page 1793
- [show l2route evpn startup-route all](#), on page 1794
- [show l2route evpn startup-route evi](#), on page 1795
- [show l2route evpn topo-child-attr all](#), on page 1796
- [show l2route evpn topo-child-attr evi](#), on page 1797
- [show l2route fl topology](#), on page 1798
- [show l2route peerid](#), on page 1799
- [show l2route summary](#), on page 1800
- [show l2route topology](#), on page 1801
- [show l2route topology](#), on page 1803
- [show l2route topology](#), on page 1805
- [show lacp counters](#), on page 1807
- [show lacp interface](#), on page 1808
- [show lacp issu-impact](#), on page 1811
- [show lacp neighbor](#), on page 1812

- [show lacp port-channel](#), on page 1813
- [show lacp system-identifier](#), on page 1814
- [show lcnd dot1x address](#), on page 1815
- [show lcnd dot1x port](#), on page 1816
- [show lcnd stats interface](#), on page 1817
- [show ldap-search-map](#), on page 1818
- [show ldap-server](#), on page 1819
- [show ldap-server groups](#), on page 1821
- [show ldap-server statistics](#), on page 1823
- [show license](#), on page 1825
- [show license all](#), on page 1826
- [show license certs](#), on page 1829
- [show license data conversion](#), on page 1830
- [show license eventlog](#), on page 1831
- [show license history message](#), on page 1832
- [show license host-id](#), on page 1833
- [show license status](#), on page 1834
- [show license summary](#), on page 1837
- [show license tech support](#), on page 1838
- [show license tech support](#), on page 1839
- [show license udi](#), on page 1840
- [show license usage](#), on page 1841
- [show license version](#), on page 1843
- [show line](#), on page 1844
- [show line console](#), on page 1845
- [show line console connected](#), on page 1846
- [show line console user-input-string](#), on page 1847
- [show lisp ddt](#), on page 1848
- [show lisp ddt queue](#), on page 1849
- [show lisp ddt referral-cache](#), on page 1850
- [show lisp dynamic-eid](#), on page 1851
- [show lisp elp](#), on page 1852
- [show lisp negative-prefix](#), on page 1853
- [show lisp proxy-itr](#), on page 1854
- [show lisp site](#), on page 1855
- [show lisp site instance-id](#), on page 1856
- [show lldp all](#), on page 1857
- [show lldp debx interface](#), on page 1858
- [show lldp entry](#), on page 1860
- [show lldp interface](#), on page 1862
- [show lldp neighbors](#), on page 1864
- [show lldp neighbors detail](#), on page 1866
- [show lldp neighbors system-detail](#), on page 1868
- [show lldp poe interface](#), on page 1869
- [show lldp portid-subtype](#), on page 1870
- [show lldp timers](#), on page 1871

- [show lldp tlv-select](#), on page 1872
- [show lldp traffic](#), on page 1873
- [show lldp traffic interface](#), on page 1874
- [show lldp traffic interface all](#), on page 1875
- [show locator-led status](#), on page 1876
- [show logging](#), on page 1877
- [show logging console](#), on page 1878
- [show logging dropcount](#), on page 1879
- [show logging history](#), on page 1880
- [show logging info](#), on page 1881
- [show logging ip access-list cache](#), on page 1883
- [show logging ip access-list status](#), on page 1885
- [show logging last](#), on page 1886
- [show logging level](#), on page 1887
- [show logging level](#), on page 1889
- [show logging level aaa](#), on page 1890
- [show logging level acl](#), on page 1891
- [show logging level aclog](#), on page 1892
- [show logging level aclmgr](#), on page 1893
- [show logging level adbm](#), on page 1894
- [show logging level adjmgr](#), on page 1895
- [show logging level amt](#), on page 1896
- [show logging level arp](#), on page 1897
- [show logging level ascii-cfg](#), on page 1898
- [show logging level assoc\\_mgr](#), on page 1899
- [show logging level backup](#), on page 1900
- [show logging level bfd](#), on page 1901
- [show logging level bgp](#), on page 1902
- [show logging level bloggerd](#), on page 1903
- [show logging level bootvar](#), on page 1904
- [show logging level callhome](#), on page 1905
- [show logging level capability](#), on page 1906
- [show logging level cdp](#), on page 1907
- [show logging level cert\\_enroll](#), on page 1908
- [show logging level cfs](#), on page 1909
- [show logging level clis](#), on page 1910
- [show logging level clk\\_mgr](#), on page 1911
- [show logging level confcheck](#), on page 1912
- [show logging level copp](#), on page 1913
- [show logging level core-dmon](#), on page 1914
- [show logging level cts](#), on page 1915
- [show logging level device-alias](#), on page 1916
- [show logging level dhclient](#), on page 1917
- [show logging level dhcp\\_snoop](#), on page 1918
- [show logging level diagnostic diag\\_port\\_lb](#), on page 1919
- [show logging level diagnostic diagclient](#), on page 1920

- [show logging level diagnostic diagmgr](#), on page 1921
- [show logging level dot1x](#), on page 1922
- [show logging level dpvm](#), on page 1923
- [show logging level ecp](#), on page 1924
- [show logging level eigrp](#), on page 1925
- [show logging level eltm](#), on page 1926
- [show logging level epbr](#), on page 1927
- [show logging level epp](#), on page 1928
- [show logging level ethdstats](#), on page 1929
- [show logging level ethpm](#), on page 1930
- [show logging level evb](#), on page 1931
- [show logging level evmc](#), on page 1932
- [show logging level evmed](#), on page 1933
- [show logging level evms](#), on page 1934
- [show logging level fabric forwarding](#), on page 1935
- [show logging level fabricpath isis](#), on page 1936
- [show logging level fabricpath switch-id](#), on page 1937
- [show logging level fc2d](#), on page 1938
- [show logging level fcdomain](#), on page 1939
- [show logging level fcns](#), on page 1940
- [show logging level fcoe\\_mgr](#), on page 1941
- [show logging level fcs](#), on page 1942
- [show logging level fdmi](#), on page 1943
- [show logging level feature-mgr](#), on page 1944
- [show logging level flogi](#), on page 1945
- [show logging level fs-daemon](#), on page 1946
- [show logging level fspf](#), on page 1947
- [show logging level fsync\\_mgr](#), on page 1948
- [show logging level gpixm](#), on page 1949
- [show logging level hardware-telemetry](#), on page 1950
- [show logging level hsrp](#), on page 1951
- [show logging level icam](#), on page 1952
- [show logging level igmp](#), on page 1953
- [show logging level im](#), on page 1954
- [show logging level imp](#), on page 1955
- [show logging level interface-vlan](#), on page 1956
- [show logging level ip sla responder](#), on page 1957
- [show logging level ip sla sender](#), on page 1958
- [show logging level ip sla twamp-server](#), on page 1959
- [show logging level ipconf](#), on page 1960
- [show logging level ipfib](#), on page 1961
- [show logging level ipqos](#), on page 1962
- [show logging level ipv6 icmp](#), on page 1963
- [show logging level ipv6 mfwd](#), on page 1964
- [show logging level ipv6 pim](#), on page 1965
- [show logging level iscm](#), on page 1966



- [show logging level iscm, on page 1967](#)
- [show logging level isis, on page 1968](#)
- [show logging level l2fm, on page 1969](#)
- [show logging level l3vm, on page 1970](#)
- [show logging level lacp, on page 1971](#)
- [show logging level ldap, on page 1972](#)
- [show logging level lim, on page 1973](#)
- [show logging level lisp, on page 1974](#)
- [show logging level lldp, on page 1975](#)
- [show logging level m2rib, on page 1976](#)
- [show logging level mfdm, on page 1977](#)
- [show logging level mfwd, on page 1978](#)
- [show logging level mld, on page 1979](#)
- [show logging level mmode, on page 1980](#)
- [show logging level module, on page 1981](#)
- [show logging level monitor, on page 1982](#)
- [show logging level mpls manager, on page 1983](#)
- [show logging level mpls switching, on page 1984](#)
- [show logging level msdp, on page 1985](#)
- [show logging level mvsh, on page 1986](#)
- [show logging level nat, on page 1987](#)
- [show logging level nbm, on page 1988](#)
- [show logging level netstack, on page 1989](#)
- [show logging level nfm, on page 1990](#)
- [show logging level nfm, on page 1991](#)
- [show logging level ngmvpn, on page 1992](#)
- [show logging level ngoam, on page 1993](#)
- [show logging level npv, on page 1994](#)
- [show logging level ntp, on page 1995](#)
- [show logging level nve, on page 1996](#)
- [show logging level nxsdk, on page 1997](#)
- [show logging level ofm, on page 1998](#)
- [show logging level openflow, on page 1999](#)
- [show logging level ospf, on page 2000](#)
- [show logging level ospfv3, on page 2001](#)
- [show logging level otv isis, on page 2002](#)
- [show logging level pfstat, on page 2003](#)
- [show logging level pie, on page 2004](#)
- [show logging level pim, on page 2005](#)
- [show logging level pixm, on page 2006](#)
- [show logging level pktmgr, on page 2007](#)
- [show logging level platform, on page 2008](#)
- [show logging level plcmgr, on page 2009](#)
- [show logging level pltfm\\_config, on page 2010](#)
- [show logging level plugin, on page 2011](#)
- [show logging level poed, on page 2012](#)

- [show logging level port-channel](#), on page 2013
- [show logging level port-profile](#), on page 2014
- [show logging level port-resources](#), on page 2015
- [show logging level port-security](#), on page 2016
- [show logging level port](#), on page 2017
- [show logging level private-vlan](#), on page 2018
- [show logging level ptp](#), on page 2019
- [show logging level radius](#), on page 2020
- [show logging level rdl](#), on page 2021
- [show logging level res\\_mgr](#), on page 2022
- [show logging level rib](#), on page 2023
- [show logging level rip](#), on page 2024
- [show logging level routing ipv6 multicast](#), on page 2025
- [show logging level routing multicast](#), on page 2026
- [show logging level rpm](#), on page 2027
- [show logging level rscn](#), on page 2028
- [show logging level sal](#), on page 2029
- [show logging level san-port-channel](#), on page 2030
- [show logging level san-port-channel](#), on page 2031
- [show logging level scheduler](#), on page 2032
- [show logging level scsi-target](#), on page 2033
- [show logging level security](#), on page 2034
- [show logging level segment-routing](#), on page 2035
- [show logging level session-mgr](#), on page 2036
- [show logging level sflow](#), on page 2037
- [show logging level smm](#), on page 2038
- [show logging level snmpd](#), on page 2039
- [show logging level snmpmib\\_proc](#), on page 2040
- [show logging level spanning-tree](#), on page 2041
- [show logging level spm](#), on page 2042
- [show logging level stripcl](#), on page 2043
- [show logging level sync](#), on page 2044
- [show logging level sysmgr](#), on page 2045
- [show logging level tacacs](#), on page 2046
- [show logging level telemetry](#), on page 2047
- [show logging level template\\_manager](#), on page 2048
- [show logging level track](#), on page 2049
- [show logging level tunnel-encryption](#), on page 2050
- [show logging level tunnel](#), on page 2051
- [show logging level u2rib](#), on page 2052
- [show logging level u6rib](#), on page 2053
- [show logging level udd](#), on page 2054
- [show logging level ufdm](#), on page 2055
- [show logging level urib](#), on page 2056
- [show logging level vdc\\_mgr](#), on page 2057
- [show logging level virtual-service](#), on page 2058

- [show logging level vlan\\_mgr](#), on page 2059
- [show logging level vmm](#), on page 2060
- [show logging level vmtracker](#), on page 2061
- [show logging level vpc](#), on page 2062
- [show logging level vrrp-cfg](#), on page 2063
- [show logging level vrrp-eng](#), on page 2064
- [show logging level vrrpv3](#), on page 2065
- [show logging level vsan](#), on page 2066
- [show logging level vshd](#), on page 2067
- [show logging level vtp](#), on page 2068
- [show logging level wwn](#), on page 2069
- [show logging level xbar](#), on page 2070
- [show logging level zone](#), on page 2071
- [show logging logfile](#), on page 2072
- [show logging logfile duration](#), on page 2073
- [show logging logfile last-index](#), on page 2074
- [show logging logfile start-seqn](#), on page 2075
- [show logging logfile start-time](#), on page 2076
- [show logging loopback](#), on page 2077
- [show logging module](#), on page 2078
- [show logging monitor](#), on page 2079
- [show logging nvram](#), on page 2080
- [show logging onboard](#), on page 2081
- [show logging onboard](#), on page 2084
- [show logging onboard kernel-trace](#), on page 2085
- [show logging origin-id](#), on page 2086
- [show logging pending-diff](#), on page 2087
- [show logging pending](#), on page 2088
- [show logging rate-limit](#), on page 2089
- [show logging rfc-strict](#), on page 2090
- [show logging server](#), on page 2091
- [show logging session status](#), on page 2092
- [show logging source-interface](#), on page 2093
- [show logging status](#), on page 2094
- [show logging timestamp](#), on page 2095
- [show login on-failure log](#), on page 2096
- [show login on-successful log](#), on page 2097

## show l2 mroute

```
show { l2 | fabricpath } mroute { [ vdc-omf ] { [ resolved ] } | [ vlan <vlanid> ] { { [ omf ] | [ flood ] } | [ source
{ <srcaddr> | <v6srcaddr> | <macsrcaddr> } ] [ group { <groupaddr> | <v6groupaddr> | <macgroupaddr> }
] } [ resolved ] [ ftag <ftag-id> ] [ hex ] } } [ __readonly__ [ <hex2> ] { TABLE_gr [ <ftag> ] <vlan_id> [ {
<v4src> <v4grp> <macgrp> | <v6src> <v6grp> <macsrc> } ] [ <omf> | <flood> ] <rt-uptime> <owners>
<num_nh> TABLE_nh { <nh_if> | <nh_sw> } [ <stale> ] [ <exclude> ] [ <svi> ] <flags> <nh-uptime>
<owner> <rt_type> | <done> | <start> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                                     |
| l2                  | Layer2 information  |
| fabricpath          | fabricpath information  |
| mroute              | Show multicast route database                                       |
| vdc-omf             | (Optional) Display vdc omf route                                    |
| vlan                | (Optional) Show information for a vlan                              |
| omf                 | (Optional) Show catch-all entry consisting of mroute ports          |
| flood               | (Optional) Display vlan flood route                                 |
| ftag                | (Optional) Show ftag number   |
| source              | (Optional) Show (s, g) source IP address                            |
| group               | (Optional) Show group address                                       |
| hex                 | (Optional) Display switch-ids in hex                                |
| <i>vlanid</i>       | (Optional) Vlan value   |
| <i>ftag-id</i>      | (Optional) ftag id  |
| <i>groupaddr</i>    | (Optional) Group address  |
| <i>macgroupaddr</i> | (Optional) MAC Group address  |
| <i>srcaddr</i>      | (Optional) Source address   |
| <i>macsrcaddr</i>   | (Optional) MAC source address                                       |
| resolved            | (Optional) Resolve switchid nexthops into the underlying interfaces |
| __readonly__        | (Optional) Read Only  |
| <i>hex2</i>         | (Optional)  |
| TABLE_gr            | (Optional)  |

|                  |  |
|------------------|--|
| <i>vlan_id</i>   | (Optional) VLAN                                  |
| <i>rt-uptime</i> | (Optional) Time route was created                |
| <i>num_nh</i>    | (Optional) Number of next-hops                   |
| <i>owners</i>    | (Optional) Owners                                |
| <i>v4src</i>     | (Optional) IPv4 Multicast traffic source         |
| <i>v4grp</i>     | (Optional) IPv4 Multicast Group address          |
| <i>macsrc</i>    | (Optional) MAC Multicast traffic source          |
| <i>macgrp</i>    | (Optional) MAC Multicast Group address           |
| <i>ftag</i>      | (Optional) ftag id                               |
| <i>omf</i>       | (Optional) Is OMF route                          |
| <i>flood</i>     | (Optional) Is flood to vlan route                |
| TABLE_nh         | (Optional)                                       |
| <i>nh_if</i>     | (Optional) The next hop interface                |
| <i>nh_sw</i>     | (Optional) The next hop switch id                |
| <i>owner</i>     | (Optional) Owner                                 |
| <i>flags</i>     | (Optional) flags                                 |
| <i>nh-uptime</i> | (Optional) Time nexthop was created              |
| <i>rt_type</i>   | (Optional) Route type                            |
| <i>stale</i>     | (Optional) Is stale                              |
| <i>exclude</i>   | (Optional) exclude from post routing replication |
| <i>svi</i>       | (Optional) SVI interface                         |
| <i>done</i>      | (Optional) Done displaying route data            |
| <i>start</i>     | (Optional) Print header                          |

**Command Mode**

- /exec

## show l2 multicast ftag

```
show { l2 | fabricpath } multicast ftag [ <ftag-id> ] [ __readonly__ TABLE_topo <id> <topo_config>
TABLE_ftag <ftag> <topo_id> <config> ]
```

### Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| l2                  | Layer2 information                 |
| fabricpath          | fabricpath information             |
| multicast           | Multicast information              |
| ftag                | ftag number                        |
| <i>ftag-id</i>      | (Optional) ftag id                 |
| <i>__readonly__</i> | (Optional) Read Only               |
| TABLE_topo          | (Optional)                         |
| <i>id</i>           | (Optional) topo id                 |
| <i>topo_config</i>  | (Optional) program ftag star route |
| TABLE_ftag          | (Optional)                         |
| <i>ftag</i>         | (Optional) ftag                    |
| <i>topo_id</i>      | (Optional) topo id                 |
| <i>config</i>       | (Optional) ftag config             |

### Command Mode

- /exec

## show l2 multicast trees

```
show { l2 | fabricpath } multicast trees [ topo <topo-id> ] [ ftag <ftag-id> ] [ hex ] [ __readonly__ [ <hex2>
] ] { TABLE_swid <ftag> <topo_id> <sw_id> <rt-uptime> <owners> <num_nh> TABLE_nh [ <preferred> ]
{ <nh_if> | <nh_sw> } [ <stale> ] <distance> <nh-uptime> <owner> <flags> <rt_type> | <start> | <done> }
]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| l2                  | Layer2 information                         |
| fabricpath          | fabricpath information                     |
| multicast           | Multicast information                      |
| trees               | Show the broadcast/multicast tree database |
| topo                | (Optional) Show topo instance              |
| ftag                | (Optional) Show ftag number                |
| hex                 | (Optional) Display switch-ids in hex       |
| <i>topo-id</i>      | (Optional) topo id                         |
| <i>ftag-id</i>      | (Optional) ftag id                         |
| <i>__readonly__</i> | (Optional) Read Only                       |
| <i>hex2</i>         | (Optional)                                 |
| TABLE_swid          | (Optional)                                 |
| <i>sw_id</i>        | (Optional) switch id                       |
| <i>topo_id</i>      | (Optional) topo id                         |
| <i>ftag</i>         | (Optional) ftag id                         |
| <i>rt-uptime</i>    | (Optional) Time route was created          |
| <i>num_nh</i>       | (Optional) Number of next-hops             |
| <i>owners</i>       | (Optional) Owners                          |
| TABLE_nh            | (Optional)                                 |
| <i>preferred</i>    | (Optional) Is preferred interface          |
| <i>nh_if</i>        | (Optional) The next hop interface          |
| <i>nh_sw</i>        | (Optional) The next hop switch id          |

|                  |                                     |
|------------------|-------------------------------------|
| <i>owner</i>     | (Optional) Owner                    |
| <i>flags</i>     | (Optional) flags                    |
| <i>rt_type</i>   | (Optional) Route type               |
| <i>nh-uptime</i> | (Optional) Time nexthop was created |
| <i>distance</i>  | (Optional) admin distance           |
| <i>stale</i>     | (Optional) Is stale                 |
| <i>start</i>     | (Optional)                          |
| <i>done</i>      | (Optional)                          |

**Command Mode**

- /exec



## show l2 route

```
show { l2 | fabricpath } route [ topology { <topo_val> [ switchid <switchid> ] | all } | switchid <switchid> ]
[ detail | hex ] + [ __readonly__ <line_marker> <is_hex> { TABLE_route <topo_id> <ftag_value> <swid>
<sswid> <num_paths> { TABLE_path <path_str> <admin_distance> <metric> <time> <time_detail> <uuid>
} } ]
```

### Syntax Description

|                       |                                   |
|-----------------------|-----------------------------------|
| show                  | Show running system information   |
| l2                    | Layer2 information                |
| fabricpath            | fabricpath information            |
| route                 | Show FabricPath route information |
| topology              | (Optional) topology               |
| <i>topo_val</i>       | (Optional) topology value         |
| switchid              | (Optional) switchid               |
| <i>switchid</i>       | (Optional) switchid value         |
| all                   | (Optional) all topologies         |
| detail                | (Optional) detail                 |
| hex                   | (Optional) display in hex         |
| <i>__readonly__</i>   | (Optional) Read Only              |
| <i>line_marker</i>    | (Optional) line marker            |
| <i>is_hex</i>         | (Optional) print in hex           |
| TABLE_route           | (Optional) Route delimiter        |
| <i>topo_id</i>        | (Optional) topo-id value          |
| <i>ftag_value</i>     | (Optional) ftag value             |
| <i>swid</i>           | (Optional) switch-id              |
| <i>sswid</i>          | (Optional) sub-switch id          |
| <i>num_paths</i>      | (Optional) num of paths           |
| TABLE_path            | (Optional) Path delimiter         |
| <i>path_str</i>       | (Optional) paths                  |
| <i>admin_distance</i> | (Optional) admin distance         |

|                    |                        |
|--------------------|------------------------|
| <i>metric</i>      | (Optional) metric      |
| <i>time</i>        | (Optional) time        |
| <i>time_detail</i> | (Optional) time_detail |
| <i>uuid</i>        | (Optional) uuid        |

**Command Mode**

- /exec

## show l2rib clients

```
show l2rib clients [ <client_id> ] [ __readonly__ TABLE_l2rib_clients <client-id> <uuid> <process-suffix> ]
```

### Syntax Description

|                            |                                  |
|----------------------------|----------------------------------|
| show                       | Show running system information  |
| l2rib                      | Layer 2 routing information base |
| clients                    | L2RIB Clients                    |
| <i>client_id</i>           | (Optional) Enter Client ID       |
| <i>__readonly__</i>        | (Optional)                       |
| <i>TABLE_l2rib_clients</i> | (Optional) L2RIB Clients Table   |
| <i>client-id</i>           | (Optional) Client ID             |
| <i>uuid</i>                | (Optional) Process ID            |
| <i>process-suffix</i>      | (Optional) Process Name Suffix   |

### Command Mode

- /exec

## show l2rib producers

```
show l2rib producers [ { topology | mac | mac-ip | ead | pl | imet | flood-list | startup-route | peerid | es |
topo-child-attr } [ static | local | bgp | vxlan | hmm | arp | ofa | lisp ] ] [ detail ] [ __readonly__
TABLE_l2rib_producers <prod-name> <prod-id> <client-id> <obj-type> <admin-dist> <purge-time> <state>
[ <prod-flags> ] ]
```

### Syntax Description

|                 |                                      |
|-----------------|--------------------------------------|
| show            | Show running system information      |
| l2rib           | Layer 2 routing information base     |
| producers       | L2RIB Producers                      |
| detail          | (Optional) Detailed information      |
| topology        | (Optional) Filter on Topology        |
| mac             | (Optional) Filter on MAC             |
| mac-ip          | (Optional) Filter on MAC-IP          |
| ead             | (Optional) Filter on Ethernet-AD     |
| pl              | (Optional) Filter on Path List       |
| imet            | (Optional) Filter on IMET Route      |
| flood-list      | (Optional) Filter on Flood List      |
| startup-route   | (Optional) Filter on Startup Route   |
| peerid          | (Optional) Filter on Peerid          |
| es              | (Optional) Filter on ES              |
| static          | (Optional) Static                    |
| local           | (Optional) Local                     |
| bgp             | (Optional) BGP                       |
| vxlan           | (Optional) VXLAN                     |
| hmm             | (Optional) HMM                       |
| arp             | (Optional) ARP                       |
| ofa             | (Optional) OFA                       |
| lisp            | (Optional) lisp                      |
| topo-child-attr | (Optional) Filter on Topo child attr |

|                       |                                  |
|-----------------------|----------------------------------|
| <i>__readonly__</i>   | (Optional)                       |
| TABLE_l2rib_producers | (Optional) L2RIB Producers Table |
| <i>prod-name</i>      | (Optional) Producer Name         |
| <i>prod-id</i>        | (Optional) Producer ID           |
| <i>client-id</i>      | (Optional) Client ID             |
| <i>obj-type</i>       | (Optional) Object Type           |
| <i>admin-dist</i>     | (Optional) Admin Distance        |
| <i>purge-time</i>     | (Optional) Purge Time            |
| <i>state</i>          | (Optional) State                 |
| <i>prod-flags</i>     | (Optional) Global Producer Flags |

**Command Mode**

- /exec

## show l2rib registrations

```
show l2rib registrations [ client <client_id> [ <topo_id> { mac | mac-ip | ead | pl | imet | flood-list | arp-signal
| startup-route | topo | es | topo-child-attr } ] ] [ __readonly__ TABLE_l2rib_registrations <client-id> <topo-id>
<obj-type> <prod> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information          |
| l2rib                     | Layer 2 routing information base         |
| registrations             | L2RIB Registrations                      |
| client                    | (Optional) Global Registraion Entries    |
| <i>client_id</i>          | (Optional) Enter Client ID               |
| <i>topo_id</i>            | (Optional) Enter Topology ID             |
| mac                       | (Optional) Filter on MAC                 |
| mac-ip                    | (Optional) Filter on MAC-IP              |
| ead                       | (Optional) Filter on Ethernet-AD         |
| pl                        | (Optional) Filter on Path List           |
| imet                      | (Optional) Filter on IMET Route          |
| es                        | (Optional) Filter on Ethernet Segment ID |
| flood-list                | (Optional) Filter on Flood List          |
| startup-route             | (Optional) Filter on Startup Route       |
| arp-signal                | (Optional) Filter on ARP Signal          |
| topo                      | (Optional) Filter on Topo Subtype        |
| topo-child-attr           | (Optional) Filter on Topo Chil Attr      |
| __readonly__              | (Optional)                               |
| TABLE_l2rib_registrations | (Optional) L2RIB Registrations Table     |
| <i>client-id</i>          | (Optional) Client ID                     |
| <i>topo-id</i>            | (Optional) Topology ID                   |
| <i>obj-type</i>           | (Optional) Object Type                   |
| <i>prod</i>               | (Optional) Producer                      |

### Command Mode

- /exec

## show l2route cmcast topology

```
show l2route cmcast { topology <topo-id> | all } [ detail ] [ __readonly__ TABLE_l2route_cmcast <topo-id>
<src-ip-addr> <grp-ip-addr> <peer-ip-addr> [ <peer-type> ] [ <prod-type> ] [ <peer-id> ] [ <vrf-id> ] [
<l3vni-id> ] ]
```

### Syntax Description

|                      |                                      |
|----------------------|--------------------------------------|
| show                 | Show running system information      |
| l2route              | Layer 2 routing information base     |
| cmcast               | CMCAST Route                         |
| topology             | Filter on topology ID                |
| <i>topo-id</i>       | topology ID                          |
| all                  | Display all routes without filtering |
| detail               | (Optional) Detailed information      |
| __readonly__         | (Optional)                           |
| TABLE_l2route_cmcast | (Optional) L2RIB CMCAST Table        |
| <i>topo-id</i>       | (Optional) Topology ID               |
| <i>src-ip-addr</i>   | (Optional) SRC IP Address            |
| <i>grp-ip-addr</i>   | (Optional) GRP IP Address            |
| <i>peer-ip-addr</i>  | (Optional) PEER IP Address           |
| <i>peer-type</i>     | (Optional) Peer Type                 |
| <i>prod-type</i>     | (Optional) Producer Type             |
| <i>peer-id</i>       | (Optional) Peer ID                   |
| <i>vrf-id</i>        | (Optional) VRF ID                    |
| <i>l3vni-id</i>      | (Optional) L3VNI ID                  |

### Command Mode

- /exec



# show l2route evpn ead all

```
show l2route evpn ead all [ detail ] [ __readonly__ TABLE_l2route_evpn_ead_all <topo-id> <prod> <esi>
<client-nfn> <flags> <num_pls> [ { <next-hop> } ] + ]
```

## Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| l2route                    | Layer 2 routing information base      |
| evpn                       | EVPN                                  |
| ead                        | EAD                                   |
| all                        | Display all routes without filtering  |
| detail                     | (Optional) Detailed information       |
| __readonly__               | (Optional)                            |
| TABLE_l2route_evpn_ead_all | (Optional) L2RIB EVPN EAD All Table   |
| <i>topo-id</i>             | (Optional) Topology ID                |
| <i>prod</i>                | (Optional) Producer                   |
| <i>esi</i>                 | (Optional) ESI                        |
| <i>client-nfn</i>          | (Optional) Client Notification Bitmap |
| <i>num_pls</i>             | (Optional) Number of Path lists       |
| <i>flags</i>               | (Optional) Flags                      |
| <i>next-hop</i>            | (Optional) Next Hop                   |

## Command Mode

- /exec

## show l2route evpn ethernet-segment esi

```
show l2route evpn ethernet-segment { esi <esi-id> | all } [ bgp | vxlan ] [ detail ] [ __readonly__
TABLE_l2route_es <ethernet-segment> <originating-rtr> <prod-name> <int-ifhdl> <client-nfn> ]
```

### Syntax Description

|                         |                                       |
|-------------------------|---------------------------------------|
| show                    | Show running system information       |
| l2route                 | Layer 2 routing information base      |
| evpn                    | EVPN                                  |
| ethernet-segment        | Ethernet Segment ID                   |
| esi                     | ESI Value                             |
| <i>esi-id</i>           | ESI ID                                |
| all                     | Display all entries without filtering |
| bgp                     | (Optional) Filter on BGP producer     |
| vxlan                   | (Optional) Filter on VXLAN producer   |
| detail                  | (Optional) Detailed information       |
| <i>__readonly__</i>     | (Optional)                            |
| TABLE_l2route_es        | (Optional) L2RIB ES Table             |
| <i>ethernet-segment</i> | (Optional) ESI                        |
| <i>originating-rtr</i>  | (Optional) Originating Router         |
| <i>prod-name</i>        | (Optional) Producer Name              |
| <i>int-ifhdl</i>        | (Optional) Interface Handle           |
| <i>client-nfn</i>       | (Optional) Client Notification Bitmap |

### Command Mode

- /exec

# show l2route evpn fl all

```
show l2route evpn fl all [ detail ] [ __readonly__ TABLE_l2route_fl_all <topo-id> <peer-id> <flood-list>
<egress-vni> <is-service-node> [ <client-nfn> ] ]
```

## Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   | Show running system information       |
| l2route                | Layer 2 routing information base      |
| evpn                   | EVPN                                  |
| fl                     | Flood List                            |
| all                    | Display all routes without filtering  |
| detail                 | (Optional) Detailed information       |
| __readonly__           | (Optional)                            |
| TABLE_l2route_fl_all   | (Optional) L2RIB Flood List All Table |
| <i>topo-id</i>         | (Optional) Topology ID                |
| <i>peer-id</i>         | (Optional) Peer-ID                    |
| <i>flood-list</i>      | (Optional) Flood List                 |
| <i>egress-vni</i>      | (Optional) Egress VNI                 |
| <i>is-service-node</i> | (Optional) Is Service Node            |
| <i>client-nfn</i>      | (Optional) Client Notification Bitmap |

## Command Mode

- /exec

## show l2route evpn fl evi

```
show l2route evpn fl evi <vpn-id> [ detail ] [ __readonly__ TABLE_l2route_fl <peer-id> <flood-list>
<egress-vni> <is-service-node> [ <client-nfn> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information               |
| l2route                 | Layer 2 routing information base              |
| evpn                    | EVPN  |
| fl                      | Flood List                                    |
| evi                     | Filter on E-VPN identifier (VLAN-ID or BD-ID) |
| <i>vpn-id</i>           | E-VPN identifier (VLAN-ID or BD-ID)           |
| detail                  | (Optional) Detailed information               |
| <i>__readonly__</i>     | (Optional)                                    |
| <i>TABLE_l2route_fl</i> | (Optional) L2RIB Flood List Table             |
| <i>peer-id</i>          | (Optional) Peer-ID                            |
| <i>flood-list</i>       | (Optional) Flood List                         |
| <i>egress-vni</i>       | (Optional) Egress VNI                         |
| <i>is-service-node</i>  | (Optional) Is Service Node                    |
| <i>client-nfn</i>       | (Optional) Client Notification Bitmap         |

### Command Mode

- /exec

# show l2route evpn imet all

```
show l2route evpn imet all [ detail ] [ __readonly__ TABLE_l2route_imet_all <topo-id> <vni> <prod-type>
<ip-addr> [ <eth-tag-id> ] [ <pmsi-flags> ] [ <flags> ] [ <type> ] [ <vni-label> ] [ <tunnel-id> ] [ <client-nfn>
]
```

## Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   | Show running system information       |
| l2route                | Layer 2 routing information base      |
| evpn                   | EVPN                                  |
| imet                   | IMET Route                            |
| all                    | Display all routes without filtering  |
| detail                 | (Optional) Detailed information       |
| __readonly__           | (Optional)                            |
| TABLE_l2route_imet_all | (Optional) L2RIB IMET All Table       |
| <i>topo-id</i>         | (Optional) Topology ID                |
| <i>vni</i>             | (Optional) VNI                        |
| <i>prod-type</i>       | (Optional) Producer Type              |
| <i>ip-addr</i>         | (Optional) IP Address                 |
| <i>eth-tag-id</i>      | (Optional) Ethernet Tag ID            |
| <i>pmsi-flags</i>      | (Optional) PMSI Flags                 |
| <i>flags</i>           | (Optional) Flags                      |
| <i>type</i>            | (Optional) Type                       |
| <i>vni-label</i>       | (Optional) VNI Label                  |
| <i>tunnel-id</i>       | (Optional) Tunnel ID                  |
| <i>client-nfn</i>      | (Optional) Client Notification Bitmap |

## Command Mode

- /exec

## show l2route evpn imet evi

```
show l2route evpn imet evi <vpn-id> [ bgp | vxlan ] [ detail ] [ __readonly__ TABLE_l2route_imet <vni>
<prod-type> <ip-addr> [ <eth-tag-id> ] [ <pmsi-flags> ] [ <flags> ] [ <type> ] [ <vni-label> ] [ <tunnel-id>
] [ <client-nfn> ] ]
```

### Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                         |
| l2route            | Layer 2 routing information base                        |
| evpn               | EVPN  |
| imet               | IMET Route  |
| evi                | Filter on E-VPN identifier (VLAN-ID or BD-ID)           |
| <i>vpn-id</i>      | E-VPN identifier (VLAN-ID or BD-ID)                     |
| bgp                | (Optional) Filter on BGP producer (remote imet routes)  |
| vxlan              | (Optional) Filter on VXLAN producer (local imet routes) |
| detail             | (Optional) Detailed information                         |
| __readonly__       | (Optional)  |
| TABLE_l2route_imet | (Optional) L2RIB IMET Table                             |
| <i>vni</i>         | (Optional) VNI  |
| <i>prod-type</i>   | (Optional) Producer Type                                |
| <i>ip-addr</i>     | (Optional) IP Address                                   |
| <i>eth-tag-id</i>  | (Optional) Ethernet Tag ID                              |
| <i>pmsi-flags</i>  | (Optional) PMSI Flags                                   |
| <i>flags</i>       | (Optional) Flags  |
| <i>type</i>        | (Optional) Type   |
| <i>vni-label</i>   | (Optional) VNI Label                                    |
| <i>tunnel-id</i>   | (Optional) Tunnel ID                                    |
| <i>client-nfn</i>  | (Optional) Client Notification Bitmap                   |

### Command Mode

- /exec

## show l2route evpn mac-ip all

```
show l2route evpn mac-ip all [ detail ] [ __readonly__ TABLE_l2route_mac_ip_all <topo-id> <mac-addr>
<host-ip> <prod-type> <flags> <seq-num> <next-hop1> [ <next-hop2> ] [ <l3-info> ] [ <fwd-state> ] [
<rte-res> ] [ <sent-to> ] [ <peerid> ] [ <peer-ifindex> ] [ <esi-id> ] [ <soo> ] [ <pcinfo> ] [ <vrf-id> ] [
<encap-type> ] ]
```

### Syntax Description

|                          |                                      |
|--------------------------|--------------------------------------|
| show                     | Show running system information      |
| l2route                  | Layer 2 routing information base     |
| evpn                     | EVPN                                 |
| mac-ip                   | MAC-IP Route                         |
| all                      | Display all routes without filtering |
| detail                   | (Optional) Detailed information      |
| __readonly__             | (Optional)                           |
| TABLE_l2route_mac_ip_all | (Optional) L2RIB Mac-IP All Table    |
| <i>topo-id</i>           | (Optional) Topology ID               |
| <i>mac-addr</i>          | (Optional) Mac Address               |
| <i>host-ip</i>           | (Optional) Host IP                   |
| <i>prod-type</i>         | (Optional) Producer Type             |
| <i>flags</i>             | (Optional) Flags                     |
| <i>seq-num</i>           | (Optional) Sequence Number           |
| <i>next-hop1</i>         | (Optional) Next Hop 1                |
| <i>next-hop2</i>         | (Optional) Next Hop 2                |
| <i>l3-info</i>           | (Optional) L3 Information            |
| <i>fwd-state</i>         | (Optional) Forwarding State          |
| <i>rte-res</i>           | (Optional) Route Resolution          |
| <i>sent-to</i>           | (Optional) Active Clients            |
| <i>peerid</i>            | (Optional) Peer ID                   |
| <i>peer-ifindex</i>      | (Optional) Peer Interface Index      |
| <i>esi-id</i>            | (Optional) ESI ID                    |

|                   |   |
|-------------------|---|
| <i>soo</i>        | (Optional) SOO                          |
| <i>pcinfo</i>     | (Optional) Port-Channel Info            |
| <i>vrf-id</i>     | (Optional) vrf id associated with route |
| <i>encap-type</i> | (Optional) Overlay encap type           |

**Command Mode**

- /exec



## show l2route evpn mac-ip evi

```
show l2route evpn mac-ip evi <vpn-id> [ arp | bgp | hmm ] [ mac <mac_addr> ] [ host-ip { <ipv4_host> | <ipv6_host> } ] [ next-hop { <ipv4_addr> | <ipv6_addr> | <if-hdl> } ] [ detail ] [ __readonly__ ]
TABLE_l2route_mac_ip_evi <topo-id> <mac-addr> <host-ip> <prod-type> <flags> <seq-num> <next-hop1>
[ <next-hop2> ] [ <l3-info> ] [ <fwd-state> ] [ <rte-res> ] [ <sent-to> ] [ <peerid> ] [ <peer-ifindex> ] [ <esi-id> ]
[ <soo> ] [ <pcinfo> ] [ <vrf-id> ] [ <encap-type> ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                    |
| l2route                  | Layer 2 routing information base                   |
| evpn                     | EVPN   |
| mac-ip                   | MAC-IP Route                                       |
| evi                      | Filter on E-VPN identifier (VLAN-ID or BD-ID)      |
| <i>vpn-id</i>            | E-VPN identifier (VLAN-ID or BD-ID)                |
| arp                      | (Optional) Filter on ARP producer                  |
| bgp                      | (Optional) Filter on BGP producer                  |
| hmm                      | (Optional) Filter on HMM producer                  |
| mac                      | (Optional) Filter on MAC address                   |
| <i>mac_addr</i>          | (Optional) 48-bit MAC address value                |
| host-ip                  | (Optional) Filter on Host IP address               |
| <i>ipv4_host</i>         | (Optional) IPv4 address                            |
| next-hop                 | (Optional) Filter on Next-Hop IP or Interface Name |
| <i>ipv4_addr</i>         | (Optional) IPv4 address of Next Hop                |
| <i>if-hdl</i>            | (Optional) Interface index of Next Hop             |
| detail                   | (Optional) Detailed information                    |
| <i>__readonly__</i>      | (Optional)   |
| TABLE_l2route_mac_ip_evi | (Optional) L2RIB Mac-IP Table                      |
| <i>topo-id</i>           | (Optional) Topology ID                             |
| <i>mac-addr</i>          | (Optional) Mac Address                             |
| <i>host-ip</i>           | (Optional) Host IP                                 |
| <i>prod-type</i>         | (Optional) Producer Type                           |

|                     |   |
|---------------------|---|
| <i>flags</i>        | (Optional) Flags                        |
| <i>seq-num</i>      | (Optional) Sequence Number              |
| <i>next-hop1</i>    | (Optional) Next Hop 1                   |
| <i>next-hop2</i>    | (Optional) Next Hop 2                   |
| <i>l3-info</i>      | (Optional) L3 Information               |
| <i>fwd-state</i>    | (Optional) Forwarding State             |
| <i>rte-res</i>      | (Optional) Route Resolution             |
| <i>sent-to</i>      | (Optional) Active Clients               |
| <i>peerid</i>       | (Optional) Peer ID                      |
| <i>peer-ifindex</i> | (Optional) Peer Interface Index         |
| <i>esi-id</i>       | (Optional) ESI ID                       |
| <i>soo</i>          | (Optional) SOO                          |
| <i>pcinfo</i>       | (Optional) Port-Channel Info            |
| <i>vrf-id</i>       | (Optional) vrf-id associated with route |
| <i>encap-type</i>   | (Optional) Overlay encap type           |

**Command Mode**

- /exec

# show l2route evpn mac all

```
show l2route evpn mac all [ detail ] [ __readonly__ TABLE_l2route_mac_all <topo-id> <mac-addr>
<prod-type> <flags> <seq-num> <next-hop1> [ <next-hop2> ] [ <rte-res> ] [ <fwd-state> ] [ <res-pl-next-hop1>
] [ <res-pl-next-hop2> ] [ <sent-to> ] [ <esi-id> ] [ <soo> ] [ <pcinfo> ] [ <encap-type> ] ]
```

## Syntax Description

|                         |                                      |
|-------------------------|--------------------------------------|
| show                    | Show running system information      |
| l2route                 | Layer 2 routing information base     |
| evpn                    | EVPN                                 |
| mac                     | MAC Route                            |
| all                     | Display all routes without filtering |
| detail                  | (Optional) Detailed information      |
| __readonly__            | (Optional)                           |
| TABLE_l2route_mac_all   | (Optional) L2RIB Mac All Table       |
| <i>topo-id</i>          | (Optional) Topology ID               |
| <i>mac-addr</i>         | (Optional) Mac Address               |
| <i>prod-type</i>        | (Optional) Producer Type             |
| <i>flags</i>            | (Optional) Flags                     |
| <i>seq-num</i>          | (Optional) Sequence Number           |
| <i>fwd-state</i>        | (Optional) Forwarding State          |
| <i>res-pl-next-hop1</i> | (Optional) Resultant PL Next hop 1   |
| <i>res-pl-next-hop2</i> | (Optional) Resultant PL Next hop 2   |
| <i>rte-res</i>          | (Optional) Route Resolution          |
| <i>sent-to</i>          | (Optional) Active Clients            |
| <i>esi-id</i>           | (Optional) ESI ID                    |
| <i>soo</i>              | (Optional) SOO                       |
| <i>pcinfo</i>           | (Optional) Port-Channel Info         |
| <i>encap-type</i>       | (Optional) Overlay encap type        |
| <i>next-hop1</i>        | (Optional) Next Hop 1                |
| <i>next-hop2</i>        | (Optional) Next Hop 2                |

**Command Mode**

- /exec

## show l2route evpn mac evi

```
show l2route evpn mac evi <vpn-id> [ static | local | bgp | vxlan | lisp ] [ mac <mac_addr> ] [ next-hop {
<ipv4_addr> | <ipv6_addr> | <if-hdl> } ] [ esi <esi-id> ] [ detail ] [ __readonly__ TABLE_l2route_mac_evi
<topo-id> <mac-addr> <prod-type> <flags> <seq-num> <next-hop1> [ <next-hop2> ] [ <rte-res> ] [ <fwd-state>
] [ <res-pl-next-hop1> ] [ <res-pl-next-hop2> ] [ <sent-to> ] [ <esi-id> ] [ <soo> ] [ <pcinfo> ] [ <encap-type>
]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| l2route               | Layer 2 routing information base                   |
| evpn                  | EVPN   |
| mac                   | MAC Route  |
| evi                   | Filter on E-VPN identifier (VLAN-ID or BD-ID)      |
| <i>vpn-id</i>         | E-VPN identifier (VLAN-ID or BD-ID)                |
| static                | (Optional) Filter on Static producer               |
| local                 | (Optional) Filter on Local producer                |
| bgp                   | (Optional) Filter on BGP producer                  |
| vxlan                 | (Optional) Filter on VXLAN producer                |
| lisp                  | (Optional) Filter on LISP producer                 |
| mac                   | (Optional) Filter on MAC address                   |
| esi                   | (Optional) Filter on ESI value                     |
| <i>mac_addr</i>       | (Optional) Enter 48-bit MAC address value          |
| next-hop              | (Optional) Filter on Next-Hop IP or Interface Name |
| <i>ipv4_addr</i>      | (Optional) IPv4 address of Next Hop                |
| <i>if-hdl</i>         | (Optional) Interface index of Next Hop             |
| detail                | (Optional) Detailed information                    |
| __readonly__          | (Optional)   |
| TABLE_l2route_mac_evi | (Optional) L2RIB Mac EVI Table                     |
| <i>topo-id</i>        | (Optional) Topology ID                             |
| <i>mac-addr</i>       | (Optional) Mac Address                             |
| <i>prod-type</i>      | (Optional) Producer Type                           |

|                         |                                    |
|-------------------------|------------------------------------|
| <i>flags</i>            | (Optional) Flags                   |
| <i>seq-num</i>          | (Optional) Sequence Number         |
| <i>next-hop1</i>        | (Optional) Next Hop 1              |
| <i>next-hop2</i>        | (Optional) Next Hop 2              |
| <i>fwd-state</i>        | (Optional) Forwarding State        |
| <i>res-pl-next-hop1</i> | (Optional) Resultant PL Next hop 1 |
| <i>res-pl-next-hop2</i> | (Optional) Resultant PL Next hop 2 |
| <i>rte-res</i>          | (Optional) Route Resolution        |
| <i>sent-to</i>          | (Optional) Active Clients          |
| <i>esi-id</i>           | (Optional) ESI ID                  |
| <i>soo</i>              | (Optional) SOO                     |
| <i>pcinfo</i>           | (Optional) Port-Channel Info       |
| <i>encap-type</i>       | (Optional) Overlay encap-type      |

**Command Mode**

- /exec

## show l2route evpn path-list all

```
show l2route evpn path-list { all | esi <esi-id> } [ detail ] [ __readonly__ TABLE_l2route_evpn_pathlist_all
<topo-id> <prod> <esi> [ <ecmp_label> ] [ <evpn-flags> ] [ <client_ctx> ] <mac-cnt> <client-nfn> [ {
<cp-next-hop> } ] [ { <res-next-hop> } ] ]
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information          |
| l2route                         | Layer 2 routing information base         |
| evpn                            | EVPN                                     |
| path-list                       | Path-List                                |
| all                             | Display all routes without filtering     |
| esi                             | ESI Value                                |
| <i>esi-id</i>                   | ESI ID                                   |
| detail                          | (Optional) Detailed information          |
| <i>__readonly__</i>             | (Optional)                               |
| TABLE_l2route_evpn_pathlist_all | (Optional) L2RIB EVPN Pathlist all Table |
| <i>topo-id</i>                  | (Optional) Topology ID                   |
| <i>prod</i>                     | (Optional) Producer                      |
| <i>esi</i>                      | (Optional) ESI                           |
| <i>ecmp_label</i>               | (Optional) ECMP label                    |
| <i>evpn-flags</i>               | (Optional) Flags                         |
| <i>client_ctx</i>               | (Optional) Client context                |
| <i>mac-cnt</i>                  | (Optional) Mac count                     |
| <i>client-nfn</i>               | (Optional) Client Notification Bitmap    |
| <i>cp-next-hop</i>              | (Optional) Control plane Next hops       |
| <i>res-next-hop</i>             | (Optional) Resultant Next hops           |

### Command Mode

- /exec

## show l2route evpn startup-route all

```
show l2route evpn startup-route all [ detail ] [ __readonly__ TABLE_l2route_startup_route_all <topo-id>
<src-group> <del-src-group> [ <src-lpbk-ifhdl> ] [ <nve-ifhdl> ] [ <evpn-flags> ] [ <client-nfn> ] ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information             |
| l2route                         | Layer 2 routing information base            |
| evpn                            | EVPN  |
| startup-route                   | Startup Route                               |
| all                             | Display all routes without filtering        |
| detail                          | (Optional) Detailed information             |
| __readonly__                    | (Optional)                                  |
| TABLE_l2route_startup_route_all | (Optional) L2RIB Startup-Route All Table    |
| <i>topo-id</i>                  | (Optional) Topology ID                      |
| <i>src-group</i>                | (Optional) Source Group                     |
| <i>del-src-group</i>            | (Optional) Delivery Source Group            |
| <i>src-lpbk-ifhdl</i>           | (Optional) Source Loopback Interface Handle |
| <i>nve-ifhdl</i>                | (Optional) NVE Interface Handle             |
| <i>evpn-flags</i>               | (Optional) Flags                            |
| <i>client-nfn</i>               | (Optional) Client Notification Bitmap       |

### Command Mode

- /exec



## show l2route evpn startup-route evi

```
show l2route evpn startup-route evi <vpn-id> [ detail ] [ __readonly__ TABLE_l2route_startup_route
<src-group> <del-src-group> [ <src-lpbk-afhdl> ] [ <nve-afhdl> ] [ <evpn-flags> ] [ <client-nfn> ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information               |
| l2route                     | Layer 2 routing information base              |
| evpn                        | EVPN  |
| startup-route               | Startup Route                                 |
| evi                         | Filter on E-VPN identifier (VLAN-ID or BD-ID) |
| <i>vpn-id</i>               | E-VPN identifier (VLAN-ID or BD-ID)           |
| detail                      | (Optional) Detailed information               |
| <i>__readonly__</i>         | (Optional)                                    |
| TABLE_l2route_startup_route | (Optional) L2RIB Startup-Route Table          |
| <i>src-group</i>            | (Optional) Source Group                       |
| <i>del-src-group</i>        | (Optional) Delivery Source Group              |
| <i>src-lpbk-afhdl</i>       | (Optional) Source Loopback Interface Handle   |
| <i>nve-afhdl</i>            | (Optional) NVE Interface Handle               |
| <i>evpn-flags</i>           | (Optional) Flags                              |
| <i>client-nfn</i>           | (Optional) Client Notification Bitmap         |

### Command Mode

- /exec

## show l2route evpn topo-child-attr all

```
show l2route evpn topo-child-attr all [ detail ] [ __readonly__ TABLE_l2route_topo_child_attr <topo-id> [
<flags> ] [ <type> ] [ <l3vni> ] [ <vrf-id> ] ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information        |
| l2route                       | Layer 2 routing information base       |
| evpn                          | EVPN                                   |
| topo-child-attr               | Topo Child Attr                        |
| all                           | Display all topo-child-attr entries    |
| detail                        | (Optional) Detailed information        |
| __readonly__                  | (Optional)                             |
| TABLE_l2route_topo_child_attr | (Optional) L2RIB Topo Child Attr Table |
| <i>topo-id</i>                | (Optional) Topology ID                 |
| <i>flags</i>                  | (Optional) Flags                       |
| <i>type</i>                   | (Optional) Type                        |
| <i>l3vni</i>                  | (Optional) L3VNI                       |
| <i>vrf-id</i>                 | (Optional) VRFID                       |

### Command Mode

- /exec

## show l2route evpn topo-child-attr evi

```
show l2route evpn topo-child-attr evi <vpn-id> [ detail ] [ __readonly__ TABLE_l2route_topo_child_attr
<topo-id> [ <flags> ] [ <type> ] [ <l3vni> ] [ <vrf-id> ] ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information               |
| l2route                       | Layer 2 routing information base              |
| evpn                          | EVPN  |
| topo-child-attr               | Topo Child Attr                               |
| evi                           | Filter on E-VPN identifier (VLAN-ID or BD-ID) |
| <i>vpn-id</i>                 | E-VPN identifier (VLAN-ID or BD-ID)           |
| detail                        | (Optional) Detailed information               |
| <i>__readonly__</i>           | (Optional)                                    |
| TABLE_l2route_topo_child_attr | (Optional) L2RIB Topo Child Attr Table        |
| <i>topo-id</i>                | (Optional) Topology ID                        |
| <i>flags</i>                  | (Optional) Flags                              |
| <i>type</i>                   | (Optional) Type                               |
| <i>l3vni</i>                  | (Optional) L3VNI                              |
| <i>vrf-id</i>                 | (Optional) VRFID                              |

### Command Mode

- /exec

# show l2route fl topology

```
show l2route fl { topology <topo-id> | all } [ detail ] [ __readonly__ TABLE_l2route_fl [ <topo-id> ] <peer-id>
<flood-list> <egress-vni> <is-service-node> [ <client-nfn> ] ]
```

## Syntax Description

|                        |                                       |
|------------------------|---------------------------------------|
| show                   | Show running system information       |
| l2route                | Layer 2 routing information base      |
| fl                     | Flood List                            |
| all                    | Display all routes without filtering  |
| topology               | Filter on topology ID                 |
| <i>topo-id</i>         | topology ID                           |
| detail                 | (Optional) Detailed information       |
| <i>__readonly__</i>    | (Optional)                            |
| TABLE_l2route_fl       | (Optional) L2RIB Flood List Table     |
| <i>topo-id</i>         | (Optional) Topology ID                |
| <i>peer-id</i>         | (Optional) Peer-ID                    |
| <i>flood-list</i>      | (Optional) Flood List                 |
| <i>egress-vni</i>      | (Optional) Egress VNI                 |
| <i>is-service-node</i> | (Optional) Is Service Node            |
| <i>client-nfn</i>      | (Optional) Client Notification Bitmap |

## Command Mode

- /exec

# show l2route peerid

show l2route peerid [ \_\_readonly\_\_ TABLE\_l2route\_peerid <if-hdl> <ip-addr> <peer-id> <if-idx> <num-macs> <num-nhs> ]

## Syntax Description

|                      |                                  |
|----------------------|----------------------------------|
| show                 | Show running system information  |
| l2route              | Layer 2 routing information base |
| peerid               | Display Peer ID DB               |
| __readonly__         | (Optional)                       |
| TABLE_l2route_peerid | (Optional) L2RIB Peer-ID Table   |
| <i>if-hdl</i>        | (Optional) Interface Handle      |
| <i>ip-addr</i>       | (Optional) IP Address            |
| <i>if-idx</i>        | (Optional) Peer Interface Index  |
| <i>peer-id</i>       | (Optional) Peer-ID               |
| <i>num-macs</i>      | (Optional) Number of Macs        |
| <i>num-nhs</i>       | (Optional) Number of NHs         |

## Command Mode

- /exec

# show l2route summary

```
show l2route summary [ __readonly__ { <total_memory> <numof_converged_tables> [ {
TABLE_l2route_summary <table_name> { TABLE_producer <producer_name> <id> <objects> <memory>
} <total><total_obj><total_mem> } ] } ]
```

## Syntax Description

|                               |                                       |
|-------------------------------|---------------------------------------|
| show                          | Show running system information       |
| l2route                       | Layer 2 routing information base      |
| summary                       | Summary                               |
| <i>__readonly__</i>           | (Optional) Read only                  |
| <i>total_memory</i>           | (Optional) Total memory               |
| <i>numof_converged_tables</i> | (Optional) Number of converged tables |
| TABLE_l2route_summary         | (Optional) L2route summary table      |
| <i>table_name</i>             | (Optional) Table name                 |
| TABLE_producer                | (Optional) Producer table             |
| <i>producer_name</i>          | (Optional) Producer name              |
| <i>id</i>                     | (Optional) id                         |
| <i>objects</i>                | (Optional) objects                    |
| <i>memory</i>                 | (Optional) Memory                     |

## Command Mode

- /exec

## show l2route topology

```
show l2route { mac | openflow mac | dataplane mac [ local | remote ] } { topology <topo-id> | all } [ detail ]
[ __readonly__ TABLE_l2route_mac <topo-id> <mac-addr> <prod-type> <flags> <seq-num> <next-hop1>
[ <next-hop2> ] [ <rte-res> ] [ <fwd-state> ] [ <res-pl-next-hop1> ] [ <res-pl-next-hop2> ] [ <sent-to> ] [
<esi-id> ] [ <soo> ] [ <pcinfo> ] [ <encap-type> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information           |
| l2route                 | Layer 2 routing information base          |
| dataplane               | dataplane                                 |
| openflow                | openflow                                  |
| mac                     | MAC Route                                 |
| all                     | Display all routes without filtering      |
| local                   | (Optional) dataplane learnt local routes  |
| remote                  | (Optional) dataplane learnt remote routes |
| topology                | Filter on topology ID                     |
| <i>topo-id</i>          | topology ID                               |
| detail                  | (Optional) Detailed information           |
| <i>__readonly__</i>     | (Optional)                                |
| TABLE_l2route_mac       | (Optional) L2RIB Mac All Table            |
| <i>topo-id</i>          | (Optional) Topology ID                    |
| <i>mac-addr</i>         | (Optional) Mac Address                    |
| <i>prod-type</i>        | (Optional) Producer Type                  |
| <i>flags</i>            | (Optional) Flags                          |
| <i>seq-num</i>          | (Optional) Sequence Number                |
| <i>next-hop1</i>        | (Optional) Next Hop 1                     |
| <i>next-hop2</i>        | (Optional) Next Hop 2                     |
| <i>fwd-state</i>        | (Optional) Forwarding State               |
| <i>res-pl-next-hop1</i> | (Optional) Resultant PL Next hop1         |
| <i>res-pl-next-hop2</i> | (Optional) Resultant PL Next hop2         |

|                   |                               |
|-------------------|-------------------------------|
| <i>rte-res</i>    | (Optional) Route Resolution   |
| <i>sent-to</i>    | (Optional) Active Clients     |
| <i>esi-id</i>     | (Optional) ESI ID             |
| <i>soo</i>        | (Optional) SOO                |
| <i>pcinfo</i>     | (Optional) Port-Channel Info  |
| <i>encap-type</i> | (Optional) Overlay encap type |

**Command Mode**

- /exec



# show l2route topology

```
show l2route topology [ <topo_id> ] [ detail ] [ __readonly__ ] TABLE_l2route_topology <topo-id> <topo-name>
<topo-type> [ <vni> ] [ <evi> ] [ <encap-type> ] [ <iod> ] [ <if-hdl> ] [ <vtep-ip> ] [ <emulated-ip> ] [
<emulated-ro-ip> ] [ <tx-id> ] [ <rcvd-flag> ] [ <rmac> ] [ <vrf-id> ] [ <vmac> ] [ <vmac-ro> ] [ <flags> ] [
<sub-flags> ] [ <prev-flags> ] ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information            |
| l2route                | Layer 2 routing information base           |
| topology               | Display topology IDs                       |
| <i>topo_id</i>         | (Optional) Enter Topology ID               |
| detail                 | (Optional) Detailed information            |
| <i>__readonly__</i>    | (Optional)                                 |
| TABLE_l2route_topology | (Optional) L2RIB Topology Table            |
| <i>topo-id</i>         | (Optional) Topology ID                     |
| <i>topo-name</i>       | (Optional) Topology Name                   |
| <i>topo-type</i>       | (Optional) Topology Type                   |
| <i>vni</i>             | (Optional) VNI                             |
| <i>evi</i>             | (Optional) EVI                             |
| <i>encap-type</i>      | (Optional) Encap Type                      |
| <i>iod</i>             | (Optional) IOD                             |
| <i>if-hdl</i>          | (Optional) Interface Handle                |
| <i>vtep-ip</i>         | (Optional) VTEP IP Address                 |
| <i>emulated-ip</i>     | (Optional) Emulated VTEP IP Address        |
| <i>emulated-ro-ip</i>  | (Optional) Emulated RO VTEP IP Address     |
| <i>tx-id</i>           | (Optional) Transaction ID for Topology Ack |
| <i>rcvd-flag</i>       | (Optional) Flag to Indicate Topology Ack   |
| <i>rmac</i>            | (Optional) Local Router MAC (For L3 VNIs)  |
| <i>vrf-id</i>          | (Optional) VRF ID (For L3 VNIs)            |
| <i>vmac</i>            | (Optional) Local Virtual MAC (For L3 VNIs) |

|                   |  |
|-------------------|--|
| <i>vmac-ro</i>    | (Optional) Local Virtual MAC Re-Orig(For Multi-site) |
| <i>flags</i>      | (Optional) Flags                                     |
| <i>sub-flags</i>  | (Optional) Sub Flags                                 |
| <i>prev-flags</i> | (Optional) Previous Flags                            |

**Command Mode**

- /exec

## show l2route topology

```
show l2route { mac-ip | openflow mac-ip } { topology <topo-id> | all } [ detail ] [ __readonly__
TABLE_l2route_mac_ip <topo-id> <mac-addr> <host-ip> <prod-type> <flags> <seq-num> <next-hop1> [
<next-hop2> ] [ <l3-info> ] [ <fwd-state> ] [ <rte-res> ] [ <sent-to> ] [ <peerid> ] [ <peer-ifindex> ] [ <esi-id>
] [ <soo> ] [ <pcinfo> ] [ <vrf-id> ] [ <encap-type> ] ]
```

### Syntax Description

|                      |                                      |
|----------------------|--------------------------------------|
| show                 | Show running system information      |
| l2route              | Layer 2 routing information base     |
| mac-ip               | MAC-IP Route                         |
| all                  | Display all routes without filtering |
| openflow             | openflow                             |
| topology             | Filter on topology ID                |
| <i>topo-id</i>       | topology ID                          |
| detail               | (Optional) Detailed information      |
| __readonly__         | (Optional)                           |
| TABLE_l2route_mac_ip | (Optional) L2RIB Mac-IP Table        |
| <i>topo-id</i>       | (Optional) Topology ID               |
| <i>mac-addr</i>      | (Optional) Mac Address               |
| <i>host-ip</i>       | (Optional) Host IP                   |
| <i>prod-type</i>     | (Optional) Producer Type             |
| <i>flags</i>         | (Optional) Flags                     |
| <i>seq-num</i>       | (Optional) Sequence Number           |
| <i>next-hop1</i>     | (Optional) Next Hop 1                |
| <i>next-hop2</i>     | (Optional) Next Hop 2                |
| <i>l3-info</i>       | (Optional) L3 Information            |
| <i>fwd-state</i>     | (Optional) Forwarding State          |
| <i>rte-res</i>       | (Optional) Route Resolution          |
| <i>sent-to</i>       | (Optional) Active Clients            |
| <i>peerid</i>        | (Optional) Peer ID                   |

|                     |   |
|---------------------|---|
| <i>peer-ifindex</i> | (Optional) Peer Interface Index         |
| <i>esi-id</i>       | (Optional) ESI ID                       |
| <i>soo</i>          | (Optional) SOO                          |
| <i>pcinfo</i>       | (Optional) Port-Channel Info            |
| <i>vrf-id</i>       | (Optional) vrf-id associated with route |
| <i>encap-type</i>   | (Optional) Ovaerlay encap type          |

**Command Mode**

- /exec

## show lacp counters

```
show lacp counters [ interface <if0> ] [ detail ] [ __readonly__ TABLE_interface <interface> TABLE_member
<port> <pdu-sent> <pdu-rcvd> <marker-rcvd> <marker-resp-sent> [ <marker-sent> ] [ <marker-resp-rcvd>
] [ <pkt-errors> ] [ <pdu-timeout-count> ] [ <flap-count> ] [ <illegal-rcvd> ] [ <unknown-rcvd> ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                    |
| lacp                     | LACP protocol                                      |
| counters                 | LACP counters                                      |
| interface                | (Optional) Specify a port-channel                  |
| detail                   | (Optional) For more counters                       |
| <i>if0</i>               | (Optional)   |
| <i>__readonly__</i>      | (Optional)   |
| TABLE_interface          | (Optional) Port channel table                      |
| <i>interface</i>         | (Optional) Port channel                            |
| TABLE_member             | (Optional) Member port info                        |
| <i>port</i>              | (Optional) Member port                             |
| <i>pdu-sent</i>          | (Optional) Number of PDUs sent                     |
| <i>pdu-rcvd</i>          | (Optional) Number of PDUs received                 |
| <i>marker-sent</i>       | (Optional) Number of Marker PDUs sent              |
| <i>marker-rcvd</i>       | (Optional) Number of Marker PDUs received          |
| <i>marker-resp-sent</i>  | (Optional) Number of Marker response PDUs sent     |
| <i>marker-resp-rcvd</i>  | (Optional) Number of Marker response PDUs received |
| <i>pkt-errors</i>        | (Optional) Number of packet errors                 |
| <i>illegal-rcvd</i>      | (Optional) Number of illegal packets received      |
| <i>unknown-rcvd</i>      | (Optional) Number of unknown packets received      |
| <i>pdu-timeout-count</i> | (Optional) Number of PDU timeouts                  |
| <i>flap-count</i>        | (Optional) Number of flaps                         |

### Command Mode

- /exec

## show lacp interface

```
show lacp interface [ <if0> ] [ __readonly__ { TABLE_lacp_intf <interface> <operational-state>
<channel-group> <port-channel> <pbus-sent> <pbus-rcvd> <marker-sent> <marker-rcvd> <marker-resp-sent>
<marker-resp-rcvd> <unknown-rcvd> <illegal-rcvd> <lag-id> <active-time> { localport <local-interface>
<local-mac-address> <local-system-priority> <local-port-priority> <local-port-num> <local-op-key>
<local-activity> <local-timeout> <local-sync> <local-collecting> <local-distributing> <partner-info-timeout>
<local-admin-state> <local-oper-state> } { partnerport <partner-interface> <partner-mac-address>
<partner-system-priority> <partner-port-priority> <partner-port-num> <partner-op-key> <partner-activity>
<partner-timeout> <partner-sync> <partner-collecting> <partner-distributing> <partner-admin-state>
<partner-oper-state> } <agg-or-indiv> } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information         |
| lacp                     | LACP protocol                           |
| interface                | Specify a interface                     |
| <i>if0</i>               | (Optional)                              |
| <i>__readonly__</i>      | (Optional)                              |
| TABLE_lacp_intf          | (Optional) Table of LACP interfaces     |
| <i>interface</i>         | (Optional) Interface ID                 |
| <i>channel-group</i>     | (Optional) Channel Group                |
| <i>port-channel</i>      | (Optional) Port Channel                 |
| <i>lag-id</i>            | (Optional) LAG Id                       |
| <i>active-time</i>       | (Optional) active-time                  |
| <i>operational-state</i> | (Optional) Operational State            |
| <i>agg-or-indiv</i>      | (Optional) Aggregate or individual port |
| <i>pbus-rcvd</i>         | (Optional) PDUs received                |
| <i>pbus-sent</i>         | (Optional) PDUs sent                    |
| <i>marker-rcvd</i>       | (Optional) Markers received             |
| <i>marker-sent</i>       | (Optional) Markers sent                 |
| <i>marker-resp-rcvd</i>  | (Optional) Marker response received     |
| <i>marker-resp-sent</i>  | (Optional) Marker response sent         |
| <i>unknown-rcvd</i>      | (Optional) Unknown pdus received        |

|                                |  |
|--------------------------------|--|
| <i>illegal-rcvd</i>            | (Optional) Illegal pdus received               |
| <i>localport</i>               | (Optional) Local port information              |
| <i>local-interface</i>         | (Optional) Interface                           |
| <i>local-mac-address</i>       | (Optional) MAC Address                         |
| <i>local-system-priority</i>   | (Optional) System Priority                     |
| <i>local-port-priority</i>     | (Optional) Port Priority                       |
| <i>local-port-num</i>          | (Optional) Port Number                         |
| <i>local-op-key</i>            | (Optional) Operational Key                     |
| <i>local-admin-state</i>       | (Optional) Local Admin State                   |
| <i>local-oper-state</i>        | (Optional) Local Oper State                    |
| <i>local-activity</i>          | (Optional) Mode                                |
| <i>local-timeout</i>           | (Optional) Timeout                             |
| <i>local-sync</i>              | (Optional) Synchronization                     |
| <i>local-distributing</i>      | (Optional) Distributing                        |
| <i>local-collecting</i>        | (Optional) Collecting                          |
| <i>partner-info-timeout</i>    | (Optional) Partner information refresh timeout |
| <i>partnerport</i>             | (Optional) Partner port information            |
| <i>partner-interface</i>       | (Optional) Partner Interface                   |
| <i>partner-mac-address</i>     | (Optional) Partner MAC Address                 |
| <i>partner-system-priority</i> | (Optional) Partner System Priority             |
| <i>partner-port-priority</i>   | (Optional) Partner Port Priority               |
| <i>partner-port-num</i>        | (Optional) Partner Port Number                 |
| <i>partner-op-key</i>          | (Optional) Operational Key                     |
| <i>partner-admin-state</i>     | (Optional) Partner Admin State                 |
| <i>partner-oper-state</i>      | (Optional) Partner Oper State                  |
| <i>partner-activity</i>        | (Optional) Mode                                |
| <i>partner-timeout</i>         | (Optional) Timeout                             |
| <i>partner-sync</i>            | (Optional) Synchronization                     |
| <i>partner-distributing</i>    | (Optional) Distributing                        |

|                           |                       |
|---------------------------|-----------------------|
| <i>partner-collecting</i> | (Optional) Collecting |
|---------------------------|-----------------------|

**Command Mode**

- /exec



# show lacp issu-impact

```
show lacp issu-impact [ __readonly__ TABLE_interface <interface> [ <failed_interface> ] [ <intf_issu_ready> ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                 |
| lacp                    | Show LACP information                           |
| issu-impact             | Check for ISSU readiness                        |
| __readonly__            | (Optional)                                      |
| TABLE_interface         | (Optional) Port-channel issu-impact member list |
| <i>interface</i>        | (Optional) Port-channel Member                  |
| <i>failed_interface</i> | (Optional) ISSU failed interface                |
| <i>intf_issu_ready</i>  | (Optional) interfaces ready for issu            |

## Command Mode

- /exec

## show lacp neighbor

```
show lacp neighbor [ interface <if0> ] [ __readonly__ TABLE_interface <interface> TABLE_member <port>
<partner-system-id> <partner-port-num> <partner-age> <partner-flags> <partner-port-priority>
<partner-oper-key> <partner-port-state> ]
```

### Syntax Description

|                              |                                   |
|------------------------------|-----------------------------------|
| show                         | Show running system information   |
| lacp                         | LACP protocol                     |
| neighbor                     | LACP interface neighbor           |
| interface                    | (Optional) Specify a port-channel |
| <i>if0</i>                   | (Optional)                        |
| <i>__readonly__</i>          | (Optional)                        |
| TABLE_interface              | (Optional) Port channel table     |
| <i>interface</i>             | (Optional) Port channel           |
| TABLE_member                 | (Optional) Member port info       |
| <i>port</i>                  | (Optional) Member port            |
| <i>partner-system-id</i>     | (Optional) Partner System ID      |
| <i>partner-port-num</i>      | (Optional) Partner Port Number    |
| <i>partner-age</i>           | (Optional) Partner age            |
| <i>partner-flags</i>         | (Optional) Partner flags          |
| <i>partner-port-priority</i> | (Optional) Partner Port Priority  |
| <i>partner-oper-key</i>      | (Optional) Partner oper key       |
| <i>partner-port-state</i>    | (Optional) Partner port state     |

### Command Mode

- /exec

# show lacp port-channel

```
show lacp port-channel [ interface <if0> ] [ __readonly__ TABLE _interface <interface> <aggr-mac-address>
<local-system-priority> <local-system-id> <local-admin-key> <local-oper-key> <partner-system-priority>
<partner-system-id> <partner-oper-key> <max-delay> <agg-or-indiv> { <port-list> } + ]
```

## Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | Show running system information                            |
| lacp                           | LACP protocol  |
| port-channel                   | LACP port-channels   |
| interface                      | (Optional) Specify a port-channel                          |
| <i>if0</i>                     | (Optional)   |
| <i>__readonly__</i>            | (Optional)   |
| <i>TABLE _interface</i>        | (Optional) Port channel table                              |
| <i>interface</i>               | (Optional) Port channel                                    |
| <i>aggr-mac-address</i>        | (Optional) Mac Address of aggregator                       |
| <i>local-system-priority</i>   | (Optional) Local System Priority                           |
| <i>local-system-id</i>         | (Optional) Local System-Id                                 |
| <i>local-admin-key</i>         | (Optional) Local admin key                                 |
| <i>local-oper-key</i>          | (Optional) Local oper key                                  |
| <i>partner-system-priority</i> | (Optional) Partner System Priority                         |
| <i>partner-system-id</i>       | (Optional) Partner System-Id                               |
| <i>partner-oper-key</i>        | (Optional) Partner oper key                                |
| <i>max-delay</i>               | (Optional) Maximum delay between aggregator and mac-client |
| <i>agg-or-indiv</i>            | (Optional) Aggregate or individual port                    |
| <i>port-list</i>               | (Optional) List of port names for member ports             |

## Command Mode

- /exec

# show lacp system-identifier

show lacp system-identifier [ \_\_readonly\_\_ <system-priority> <system-mac> ]

## Syntax Description

|                        |                                    |
|------------------------|------------------------------------|
| show                   | Show running system information    |
| lacp                   | LACP protocol                      |
| system-identifier      | Show system-identifier information |
| __readonly__           | (Optional)                         |
| <i>system-priority</i> | (Optional) System priority         |
| <i>system-mac</i>      | (Optional) System mac address      |

## Command Mode

- /exec

# show lcnd dot1x address

show lcnd dot1x address { <macaddr> | all }

## Syntax Description

|                |                                       |
|----------------|---------------------------------------|
| show           | Show running system information       |
| lcnd           | LCND information                      |
| dot1x          | Dot1x information                     |
| address        | Address in lcnd auth_db               |
| <i>macaddr</i> | MAC address                           |
| all            | Display all addresses in lcnd auth_db |

## Command Mode

- /exec

# show lcmd dot1x port

show lcmd dot1x port <portnum>

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| lcmd           | LCND information                |
| dot1x          | Dot1x information               |
| port           | Port number                     |
| <i>portnum</i> | Port number                     |

## Command Mode

- /exec

# show lcmd stats interface

show lcmd stats interface <interface>

## Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information           |
| lcmd             | lcmd                                      |
| stats            | statistics                                |
| interface        | get interface related stats at lcmd level |
| <i>interface</i> | Interface name to display                 |

## Command Mode

- /exec

# show ldap-search-map

```
show ldap-search-map [ __readonly__ { number_of_search_maps <search_map_count> } [
TABLE_ldap_searchmaps [ <map_name> <map_baseDN> <map_attr> <map_filter> ] ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| <i>__readonly__</i>          | (Optional)  |
| <i>number_of_search_maps</i> | (Optional) Total number of search maps configured |
| <i>search_map_count</i>      | (Optional) Ldap Search map count                  |
| TABLE_ldap_searchmaps        | (Optional) Ldap search map configuration          |
| <i>map_name</i>              | (Optional) Search map name                        |
| <i>map_baseDN</i>            | (Optional) Ldap base DN                           |
| <i>map_attr</i>              | (Optional) Search map attribute                   |
| <i>map_filter</i>            | (Optional) Ldap Search filter                     |
| show                         | Show running system information                   |
| ldap-search-map              | Show LDAP configuration information               |

## Command Mode

- /exec



## show ldap-server

```
show ldap-server [ __readonly__ { global_timeout <g_timeout> } { global_port <g_port> } { global_deadtime
<g_deadtime> } { total_number_of_server <g_servers_count> } { TABLE_ldap_hosts <ldap_host>
<h_idletime> <h_test_user> <h_test_passwd> [ <h_test_dn> ] <h_timeout> <h_port> <h_rootDN>
<h_ssl_enable> <h_referral_disable> } ]
```

### Syntax Description

|                                     |  |
|-------------------------------------|--|
| <code>__readonly__</code>           | (Optional)                                       |
| <code>TABLE_ldap_hosts</code>       | (Optional) Ldap host configuration               |
| <code>global_timeout</code>         | (Optional) Ldap host global timeout              |
| <code>global_port</code>            | (Optional) Ldap host global port                 |
| <code>global_deadtime</code>        | (Optional) Ldap host global deadtime             |
| <code>total_number_of_server</code> | (Optional) Total number of ldap hosts configured |
| <code>g_servers_count</code>        | (Optional) Total number of ldap hosts configured |
| <code>g_timeout</code>              | (Optional) global timeout value                  |
| <code>g_port</code>                 | (Optional) Global ldap port                      |
| <code>g_deadtime</code>             | (Optional) Global deadtime value                 |
| <code>ldap_host</code>              | (Optional) Ldap host                             |
| <code>h_idletime</code>             | (Optional) Ldap host idletime                    |
| <code>h_test_user</code>            | (Optional) Ldap host testuser                    |
| <code>h_test_passwd</code>          | (Optional) Ldap host password                    |
| <code>h_test_dn</code>              | (Optional) Ldap testuser dn                      |
| <code>h_timeout</code>              | (Optional) Ldap host timeout                     |
| <code>h_port</code>                 | (Optional) Ldap host port                        |
| <code>h_rootDN</code>               | (Optional) Ldap host RootDN                      |
| <code>h_ssl_enable</code>           | (Optional) Ldap host ssl configuration           |
| <code>h_referral_disable</code>     | (Optional) Ldap host referral chasing disable    |
| <code>show</code>                   | Show running system information                  |
| <code>ldap-server</code>            | Show LDAP configuration information              |

### Command Mode

- /exec

## show ldap-server groups

```
show ldap-server groups [ __readonly__ { total_number_of_groups <total_groups_count> } { TABLE_groups
<g_name> <g_vrf> <g_mode> <is_bind_and_search> <g_append_with_baseDN> <g_compare_or_bind>
<g_cmp_passwd_attr> [ <user-server-group> ] [ <Cert-DN-match> ] <auth_mechanism> [ TABLE_g_servers
<g_server> <g_port> <g_timeout> ] [ <g_search_map> ] } ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information                       |
| ldap-server                   | Show LDAP configuration information                   |
| groups                        | Show LDAP server group configuration information      |
| <i>__readonly__</i>           | (Optional)  |
| <i>total_number_of_groups</i> | (Optional) Total number of Ldap groups configured     |
| <i>total_groups_count</i>     | (Optional) Ldap group count                           |
| TABLE_groups                  | (Optional) LDAP Group information                     |
| <i>g_name</i>                 | (Optional) Ldap group name                            |
| <i>g_vrf</i>                  | (Optional) LDAP group vrf                             |
| <i>g_mode</i>                 | (Optional) LDAP group mode                            |
| <i>is_bind_and_search</i>     | (Optional) Ldap Authentication bind or search         |
| <i>g_append_with_baseDN</i>   | (Optional) LDAP baseDN append information             |
| <i>g_compare_or_bind</i>      | (Optional) LDAP bind or compare                       |
| <i>g_cmp_passwd_attr</i>      | (Optional) LDAP compare password attribute            |
| <i>user-server-group</i>      | (Optional) Ldap server group validation               |
| <i>Cert-DN-match</i>          | (Optional) Ldap group CERT-DN match                   |
| <i>auth_mechanism</i>         | (Optional) Ldap server group authentication mechanism |
| TABLE_g_servers               | (Optional) LDAP group server information              |
| <i>g_server</i>               | (Optional) LDAP group host                            |
| <i>g_port</i>                 | (Optional) LDAP group host port                       |
| <i>g_timeout</i>              | (Optional) LDAP griup host timeout                    |
| <i>g_search_map</i>           | (Optional) LDAP group search map                      |

### Command Mode

- /exec

## show ldap-server statistics

```
show ldap-server statistics <host0> [ __readonly__ { <server_state> [ <clock_time> { monitoring_statistics
<time_in_pstate> <ndead> <tt_in_dstate> } ] } { { auth_statistics <auth_failed_transactions>
<auth_succ_transactions> <auth_req_sent> <auth_req_timedout> <auth_resp_no_match>
<auth_resp_not_processed> <auth_resp_error> } [ acct_statistics <acct_failed_transactions>
<acct_succ_transactions> <acct_req_sent> <acct_req_timedout> <acct_resp_no_match>
<acct_resp_not_processed> <acct_resp_error> ] } ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                                   |
| ldap-server                     | Show LDAP configuration information                               |
| statistics                      | Show LDAP statistics  |
| <i>host0</i>                    | DNS name or IP address  |
| <i>__readonly__</i>             | (Optional)  |
| <i>server_state</i>             | (Optional) Show state of server                                   |
| <i>clock_time</i>               | (Optional) Show clock time in terms of hours, minutes and seconds |
| <i>monitoring_statistics</i>    | (Optional) Monitoring Statistics                                  |
| <i>time_in_pstate</i>           | (Optional) Time in previous state                                 |
| <i>ndead</i>                    | (Optional) Number of times dead                                   |
| <i>tt_in_dstate</i>             | (Optional) Total time in dead state                               |
| <i>auth_statistics</i>          | (Optional) Authentication Statistics                              |
| <i>acct_statistics</i>          | (Optional) Accounting Statistics                                  |
| <i>auth_failed_transactions</i> | (Optional) Authentication: Failed transactions                    |
| <i>auth_succ_transactions</i>   | (Optional) Authentication: Successful transactions                |
| <i>auth_req_sent</i>            | (Optional) Authentication: Requests sent                          |
| <i>auth_req_timedout</i>        | (Optional) Authentication: Requests timedout                      |
| <i>auth_resp_no_match</i>       | (Optional) Authentication: Responses with no matching requests    |
| <i>auth_resp_not_processed</i>  | (Optional) Authentication: Responses not processed                |
| <i>auth_resp_error</i>          | (Optional) Authentication: Responses containing errors            |
| <i>acct_failed_transactions</i> | (Optional) Accounting: Failed transactions                        |
| <i>acct_succ_transactions</i>   | (Optional) Accounting: Successful transactions                    |

|                                |  |
|--------------------------------|--|
| <i>acct_req_sent</i>           | (Optional) Accounting: Requests sent                       |
| <i>acct_req_timeout</i>        | (Optional) Accounting: Requests timeout                    |
| <i>acct_resp_no_match</i>      | (Optional) Accounting: Responses with no matching requests |
| <i>acct_resp_not_processed</i> | (Optional) Accounting: Responses not processed             |
| <i>acct_resp_error</i>         | (Optional) Accounting: Responses containing errors         |

**Command Mode**

- /exec

# show license

```
show license [ __readonly__ { [ <lic_file_name> <lic_file_contents> ] + } ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information            |
| license                  | show the contents of all the license files |
| <i>__readonly__</i>      | (Optional) Read only                       |
| <i>lic_file_name</i>     | (Optional) Name of the license file        |
| <i>lic_file_contents</i> | (Optional) License file contents           |

## Command Mode

- /exec

## show license all

```
show license all [ __readonly__ { utility_info <utility_status> } { smart_status_info <smart_status> } {
data_privacy_info <sending_hostname> <callhome_hostname> <license_hostname> <version_privacy> } {
smart_transport_info <transport_type> [ { transport_info [ <transport_url> ] [ <cslu_address> ] } ] [ proxy_info
[ <proxy_address> ] [ <proxy_port> ] [ <proxy_status> ] ] } { miscellaneous <custom_id> } { policy_info [
<policy_in_use> ] [ <policy_install_time> ] [ <policy_install_name> <reporting_ack_req> {
TABLE_policy_attr_info <policy_attr_name> <first_report_req> <first_report_req_type>
<ongoing_reporting_req> <ongoing_reporting_req_type> <on_change_reporting>
<on_change_reporting_req_type> } } { usage_reporting_info <last_ack_received> <next_ack_deadline>
<reporting_push_interval> <next_ack_push_check> <next_report_push> <last_report_push>
<last_report_file_write> } } { trust_code_info <trust_code_installed_time> [ TABLE_ha_trust_code_info
<ha_role_name> <ha_udi_pid> <ha_udi_sn> <ha_trust_code_installed_time> ] } [ TABLE_smart_feat_info
{ <feature_name> <description> <count> <version> <status> <enforcement_type> <license_type> } ] {
local_udi [ <local_pid> ] <local_sn> } [ TABLE_udiList <role> <pid> <sn> ] { smart_version <version> }
]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information            |
| license                     | Show the contents of all the license files |
| all                         | All Smart license agent information        |
| <i>__readonly__</i>         | (Optional) Read only                       |
| <i>utility_info</i>         | (Optional)                                 |
| <i>utility_status</i>       | (Optional) Utility status                  |
| <i>smart_status_info</i>    | (Optional)                                 |
| <i>smart_status</i>         | (Optional) Smart status                    |
| <i>data_privacy_info</i>    | (Optional)                                 |
| <i>sending_hostname</i>     | (Optional) Sending hostname                |
| <i>callhome_hostname</i>    | (Optional) Callhome hostname privacy       |
| <i>license_hostname</i>     | (Optional) License hostname privacy        |
| <i>version_privacy</i>      | (Optional) Version privacy                 |
| <i>smart_transport_info</i> | (Optional)                                 |
| <i>transport_type</i>       | (Optional) Transport type                  |
| <i>transport_info</i>       | (Optional)                                 |
| <i>transport_url</i>        | (Optional) Transport URL                   |
| <i>cslu_address</i>         | (Optional) CSLU Address                    |



|                                     |  |
|-------------------------------------|--|
| <i>proxy_info</i>                   | (Optional)                                     |
| <i>proxy_address</i>                | (Optional) Proxy address                       |
| <i>proxy_port</i>                   | (Optional) Proxy port                          |
| <i>proxy_status</i>                 | (Optional) Proxy status                        |
| <i>miscellaneous</i>                | (Optional)                                     |
| <i>custom_id</i>                    | (Optional) Custom id                           |
| <i>policy_info</i>                  | (Optional)                                     |
| <i>policy_in_use</i>                | (Optional) Policy in use Installed case        |
| <i>policy_install_time</i>          | (Optional) Policy install time                 |
| <i>policy_install_name</i>          | (Optional) Policy installed name               |
| <i>reporting_ack_req</i>            | (Optional) Reporting ACK required              |
| TABLE_policy_attr_info              | (Optional) Policy attribute info               |
| <i>policy_attr_name</i>             | (Optional) Policy attribute name               |
| <i>first_report_req</i>             | (Optional) First report requirement in days    |
| <i>first_report_req_type</i>        | (Optional) First report req type               |
| <i>ongoing_reporting_req</i>        | (Optional) Ongoing reporting frequency in days |
| <i>ongoing_reporting_req_type</i>   | (Optional) Ongoing reporting req type          |
| <i>on_change_reporting</i>          | (Optional) On change reporting in days         |
| <i>on_change_reporting_req_type</i> | (Optional) On change reporting req type        |
| <i>usage_reporting_info</i>         | (Optional)                                     |
| <i>last_ack_received</i>            | (Optional) Last ACK received                   |
| <i>next_ack_deadline</i>            | (Optional) Next ACK deadline                   |
| <i>reporting_push_interval</i>      | (Optional) Reporting push interval             |
| <i>next_ack_push_check</i>          | (Optional) Next ACK push check                 |
| <i>next_report_push</i>             | (Optional) Next report push                    |
| <i>last_report_push</i>             | (Optional) Last report push                    |
| <i>last_report_file_write</i>       | (Optional) Last report file write              |
| <i>trust_code_info</i>              | (Optional)                                     |
| <i>trust_code_installed_time</i>    | (Optional) Trust code installed time           |

|                                     |   |
|-------------------------------------|---|
| TABLE_ha_trust_code_info            | (Optional) Trust code info              |
| <i>ha_role_name</i>                 | (Optional) HA role name                 |
| <i>ha_udi_pid</i>                   | (Optional) HA UDI PID                   |
| <i>ha_udi_sn</i>                    | (Optional) HA UDI SN                    |
| <i>ha_trust_code_installed_time</i> | (Optional) HA trust code installed time |
| TABLE_smart_feat_info               | (Optional)                              |
| <i>feature_name</i>                 | (Optional)                              |
| <i>description</i>                  | (Optional)                              |
| <i>version</i>                      | (Optional)                              |
| <i>count</i>                        | (Optional)                              |
| <i>status</i>                       | (Optional)                              |
| <i>enforcement_type</i>             | (Optional) Enforcement type             |
| <i>license_type</i>                 | (Optional) license type                 |
| local_udi                           | (Optional) Local device information     |
| <i>local_pid</i>                    | (Optional) Local product identifier     |
| <i>local_sn</i>                     | (Optional) Device serial number         |
| TABLE_udiList                       | (Optional) All device identifiers       |
| <i>role</i>                         | (Optional) Device role                  |
| <i>pid</i>                          | (Optional) Device product identifier    |
| <i>sn</i>                           | (Optional) Device serial number         |
| smart_version                       | (Optional) smart version                |
| <i>version</i>                      | (Optional) smart version                |

### Command Mode

- /exec

## show license certs

```
show license certs [ __readonly__ { <production_cert> } [ <piid> ] [ TABLE_smart_cert_info { <cert_name>
<start_date> <expiry_date> <version_num> <serial_num> <common_name> } ] [ <sudi_list> ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information            |
| license                | Show the contents of all the license files |
| certs                  | Smart License certificates                 |
| <i>__readonly__</i>    | (Optional) Read only                       |
| <i>production_cert</i> | (Optional) Production cert value           |
| <i>piid</i>            | (Optional) Certificate piid                |
| TABLE_smart_cert_info  | (Optional)                                 |
| <i>cert_name</i>       | (Optional) Certificate name                |
| <i>start_date</i>      | (Optional) Certificate start date          |
| <i>expiry_date</i>     | (Optional) Certificate expiry date         |
| <i>version_num</i>     | (Optional) Certificate version number      |
| <i>serial_num</i>      | (Optional) Certificate serial number       |
| <i>common_name</i>     | (Optional) Certificate common name         |
| <i>sudi_list</i>       | (Optional) Sudi llist info                 |

### Command Mode

- /exec

# show license data conversion

show license data conversion

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information            |
| license    | Show the contents of all the license files |
| data       | Show data for device led conversions       |
| conversion | Smart license conversion related commands  |

## Command Mode

- /exec

# show license eventlog

show license eventlog

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information            |
| license  | Show the contents of all the license files |
| eventlog | Event log                                  |

## Command Mode

- /exec

# show license history message

show license history message

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information            |
| license | Show the contents of all the license files |
| history | Show license history information           |
| message | Show license messaging history information |

## Command Mode

- /exec

# show license host-id

```
show license host-id [ __readonly__ { <host_id> } ]
```

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                  |
| license        | Show the contents of all the license files       |
| host-id        | Show unique id for this host for licensing       |
| __readonly__   | (Optional) Read only                             |
| <i>host_id</i> | (Optional) unique id for this host for licensing |

## Command Mode

- /exec

## show license status

```
show license status [ __readonly__ { utility_info <utility_status> } { smart_status_info <smart_status> } {
data_privacy_info <sending_hostname> <callhome_hostname> <license_hostname> <version_privacy> } {
smart_transport_info <transport_type> [ { transport_info [ <transport_url> ] [ <cslu_address> ] } ] [ proxy_info
[ <proxy_address> ] [ <proxy_port> ] [ <proxy_status> ] ] } { policy_info [ <policy_in_use> ] [
<policy_install_time> ] <policy_install_name> <reporting_ack_req> { TABLE_policy_attr_info
<policy_attr_name> <first_report_req> <first_report_req_type> <ongoing_reporting_req>
<ongoing_reporting_req_type> <on_change_reporting> <on_change_reporting_req_type> } } { miscellaneous
<custom_id> } { usage_reporting_info <last_ack_received> <next_ack_deadline> <reporting_push_interval>
<next_ack_push_check> <next_report_push> <last_report_push> <last_report_file_write> } { trust_code_info
<trust_code_installed_time> [ TABLE_ha_trust_code_info <ha_role_name> <ha_udi_pid> <ha_udi_sn>
<ha_trust_code_installed_time> ] } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information            |
| license                     | Show the contents of all the license files |
| status                      | Smart license agent status                 |
| <i>__readonly__</i>         | (Optional) Read only                       |
| <i>utility_info</i>         | (Optional)                                 |
| <i>utility_status</i>       | (Optional) Utility status                  |
| <i>smart_status_info</i>    | (Optional)                                 |
| <i>smart_status</i>         | (Optional) Smart_status                    |
| <i>data_privacy_info</i>    | (Optional)                                 |
| <i>sending_hostname</i>     | (Optional) Sending hostname                |
| <i>callhome_hostname</i>    | (Optional) Callhome hostname privacy       |
| <i>license_hostname</i>     | (Optional) License hostname privacy        |
| <i>version_privacy</i>      | (Optional) Version privacy                 |
| <i>smart_transport_info</i> | (Optional)                                 |
| <i>transport_type</i>       | (Optional) Transport type                  |
| <i>transport_info</i>       | (Optional)                                 |
| <i>transport_url</i>        | (Optional) Transport URL                   |
| <i>cslu_address</i>         | (Optional) CSLU Address                    |
| <i>proxy_info</i>           | (Optional)                                 |



|                                     |  |
|-------------------------------------|--|
| <i>proxy_address</i>                | (Optional) Proxy address                       |
| <i>proxy_port</i>                   | (Optional) Proxy port                          |
| <i>proxy_status</i>                 | (Optional) Proxy status                        |
| <i>policy_info</i>                  | (Optional)                                     |
| <i>policy_in_use</i>                | (Optional) Policy in use Installed case        |
| <i>policy_install_time</i>          | (Optional) Policy install time                 |
| <i>policy_install_name</i>          | (Optional) Policy installed name               |
| <i>reporting_ack_req</i>            | (Optional) Reporting ACK required              |
| TABLE_policy_attr_info              | (Optional) Policy attribute info               |
| <i>policy_attr_name</i>             | (Optional) Policy attribute name               |
| <i>first_report_req</i>             | (Optional) First report requirement in days    |
| <i>first_report_req_type</i>        | (Optional) First report req type               |
| <i>ongoing_reporting_req</i>        | (Optional) Ongoing reporting frequency in days |
| <i>ongoing_reporting_req_type</i>   | (Optional) Ongoing reporting req type          |
| <i>on_change_reporting</i>          | (Optional) On change reporting in days         |
| <i>on_change_reporting_req_type</i> | (Optional) On change reporting req type        |
| miscellaneous                       | (Optional)                                     |
| <i>custom_id</i>                    | (Optional) Custom id                           |
| usage_reporting_info                | (Optional)                                     |
| <i>last_ack_received</i>            | (Optional) Last ACK received                   |
| <i>next_ack_deadline</i>            | (Optional) Next ACK deadline                   |
| <i>reporting_push_interval</i>      | (Optional) Reporting push interval             |
| <i>next_ack_push_check</i>          | (Optional) Next ACK push check                 |
| <i>next_report_push</i>             | (Optional) Next report push                    |
| <i>last_report_push</i>             | (Optional) Last report push                    |
| <i>last_report_file_write</i>       | (Optional) Last report file write              |
| trust_code_info                     | (Optional)                                     |
| <i>trust_code_installed_time</i>    | (Optional) Trust code installed time           |
| TABLE_ha_trust_code_info            | (Optional) Trust code info                     |

|                                     |   |
|-------------------------------------|---|
| <i>ha_role_name</i>                 | (Optional) HA role name                 |
| <i>ha_udi_pid</i>                   | (Optional) HA UDI PID                   |
| <i>ha_udi_sn</i>                    | (Optional) HA UDI SN                    |
| <i>ha_trust_code_installed_time</i> | (Optional) HA trust code installed time |

**Command Mode**

- /exec

# show license summary

```
show license summary [ __readonly__ [ TABLE_smart_feat_info { <license_name> <feature_name> <count> <status> } ] ]
```

## Syntax Description

|                                    |  |
|------------------------------------|--|
| <code>show</code>                  | Show running system information            |
| <code>license</code>               | Show the contents of all the license files |
| <code>summary</code>               | Smart license agent summary                |
| <code>__readonly__</code>          | (Optional) Read only                       |
| <code>TABLE_smart_feat_info</code> | (Optional)                                 |
| <code>license_name</code>          | (Optional) License name                    |
| <code>feature_name</code>          | (Optional) Feature name                    |
| <code>count</code>                 | (Optional) Feature usage count             |
| <code>status</code>                | (Optional) Feature status                  |

## Command Mode

- /exec

# show license tech support

show license tech support

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information            |
| license | Show the contents of all the license files |
| tech    | Gather information for troubleshooting     |
| support | Gather information for troubleshooting     |

## Command Mode

- /exec

# show license tech support

show license tech support

## Syntax Description

|         |  |
|---------|--|
| show    | show commands                          |
| license | Display licensing information          |
| tech    | Gather information for troubleshooting |
| support | Gather information for troubleshooting |

## Command Mode

- /exec

## show license udi

```
show license udi [ __readonly__ { local_udi [ <local_pid> ] <local_sn> } [ TABLE_udiList <role> <pid>
<sn> ] ]
```

### Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information            |
| license          | Show the contents of all the license files |
| udi              | device udi                                 |
| __readonly__     | (Optional) Read only                       |
| local_udi        | (Optional) Local device information        |
| <i>local_pid</i> | (Optional) Local product identifier        |
| <i>local_sn</i>  | (Optional) Device serial number            |
| TABLE_udiList    | (Optional) All device identifiers          |
| <i>role</i>      | (Optional) Device role                     |
| <i>pid</i>       | (Optional) Device product identifier       |
| <i>sn</i>        | (Optional) Device serial number            |

### Command Mode

- /exec

## show license usage

```
show license usage [ { detail | <license-feature> } ] [ __readonly__ { [ [ TABLE_show_lic_usage {
<feature_name> <lic_installed> <count> <status> <expiry_date> <comments> } ] { [ <application_name> ]
+ } ] ] [ <auth_status> [ TABLE_show_smart_lic_usage { <smart_feature_name> <smart_description>
<smart_count> <smart_version> <smart_status> <enforcement_type> <license_type> } ] ] ] ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                      |
| license                    | show the contents of all the license files           |
| usage                      | Show license usage table                             |
| detail                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| <i>license-feature</i>     | (Optional) Show usage of this license package        |
| <i>__readonly__</i>        | (Optional) Read only                                 |
| TABLE_show_lic_usage       | (Optional) License usage                             |
| <i>feature_name</i>        | (Optional) Name of the feature                       |
| <i>lic_installed</i>       | (Optional) Is the license installed?                 |
| <i>count</i>               | (Optional) License count                             |
| <i>status</i>              | (Optional) License status                            |
| <i>expiry_date</i>         | (Optional) Expiry date of the license                |
| <i>comments</i>            | (Optional) License comments                          |
| <i>application_name</i>    | (Optional) Name of the application using the license |
| <i>auth_status</i>         | (Optional) Brief about smart license usage           |
| TABLE_show_smart_lic_usage | (Optional) Smart License usage                       |
| <i>smart_feature_name</i>  | (Optional) Name of the feature                       |
| <i>smart_description</i>   | (Optional) Description of the entitlement            |
| <i>smart_count</i>         | (Optional) License count                             |
| <i>smart_version</i>       | (Optional) License version                           |
| <i>smart_status</i>        | (Optional) License status                            |
| <i>enforcement_type</i>    | (Optional) Enforcement type                          |
| <i>license_type</i>        | (Optional) License type                              |

**Command Mode**

- /exec



# show license version

show license version [ *\_\_readonly\_\_* { <version> } ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| license             | Show the contents of all the license files |
| version             | Smart License version                      |
| <i>__readonly__</i> | (Optional) Read only                       |
| <i>version</i>      | (Optional) smart agent version info        |

## Command Mode

- /exec

# show line

```
show line [ __readonly__ <speed> <databits> <stopbits> <parity> <modem_in> <modem_init_str> <stat> [
TABLE_ps_output <ps> ] [ <speed_aux> <databits_aux> <stopbits_aux> <parity_aux> <modem_in_aux>
<modem_init_str_aux> <hw_fc_aux> <stat_aux> [ TABLE_ps_output_aux <ps_aux> ] ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information           |
| line                      | Show the line configuration               |
| __readonly__              | (Optional)                                |
| TABLE_ps_output           | (Optional) Process info for console login |
| TABLE_ps_output_aux       | (Optional) Process info for com1 login    |
| <i>speed</i>              | (Optional) Port speed(baud)               |
| <i>databits</i>           | (Optional) Bits per byte                  |
| <i>stopbits</i>           | (Optional) Bits                           |
| <i>parity</i>             | (Optional) Parity                         |
| <i>modem_in</i>           | (Optional) Modem In                       |
| <i>modem_init_str</i>     | (Optional) Modem Init-String              |
| <i>stat</i>               | (Optional) Statistics                     |
| <i>ps</i>                 | (Optional) Login process                  |
| <i>speed_aux</i>          | (Optional) Port speed(baud)               |
| <i>databits_aux</i>       | (Optional) Bits per byte                  |
| <i>stopbits_aux</i>       | (Optional) Bits                           |
| <i>parity_aux</i>         | (Optional) Parity                         |
| <i>modem_in_aux</i>       | (Optional) Modem In                       |
| <i>modem_init_str_aux</i> | (Optional) Modem Init-String              |
| <i>hw_fc_aux</i>          | (Optional) Hardware Flowcontrol           |
| <i>stat_aux</i>           | (Optional) Statistics                     |
| <i>ps_aux</i>             | (Optional) Login process                  |

## Command Mode

- /exec

# show line console

```
show line console [ __readonly__ <speed> <databits> <stopbits> <parity> <modem_in> <modem_init_str>
<stat> [ TABLE_ps_output <ps> ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information           |
| line                  | Show the line configuration               |
| console               | Show console line configurations          |
| __readonly__          | (Optional)                                |
| TABLE_ps_output       | (Optional) Process info for console login |
| <i>speed</i>          | (Optional) Port speed(baud)               |
| <i>databits</i>       | (Optional) Bits per byte                  |
| <i>stopbits</i>       | (Optional) Bits                           |
| <i>parity</i>         | (Optional) Parity                         |
| <i>modem_in</i>       | (Optional) Modem In                       |
| <i>modem_init_str</i> | (Optional) Modem Init-String              |
| <i>stat</i>           | (Optional) Statistics                     |
| <i>ps</i>             | (Optional) Login process                  |

## Command Mode

- /exec

# show line console connected

show line console connected [ \_\_readonly\_\_ <output> ]

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information                         |
| line          | Show the line configuration                             |
| console       | Show console line configurations                        |
| connected     | Show whether the line is currently connected physically |
| __readonly__  | (Optional)  |
| <i>output</i> | (Optional) output string                                |

## Command Mode

- /exec

# show line console user-input-string

```
show line console user-input-string [ __readonly__ <input> ]
```

## Syntax Description

|                   |                                  |
|-------------------|----------------------------------|
| show              | Show running system information  |
| line              | Show the line configuration      |
| console           | Show console line configurations |
| user-input-string | Show user-input init string      |
| __readonly__      | (Optional)                       |
| <i>input</i>      | (Optional) user input string     |

## Command Mode

- /exec

# show lisp ddt

```
show lisp ddt [ vrf { <vrf-name> | <vrf-known-name> } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information         |
| lisp                  | LISP show commands                      |
| ddt                   | LISP Delegated Database Tree (LISP-DDT) |
| vrf                   | (Optional) Display information for vrf  |
| <i>vrf-name</i>       | (Optional) VRF name                     |
| <i>vrf-known-name</i> | (Optional) Known VRF name               |

## Command Mode

- /exec

## show lisp ddt queue

```
show lisp ddt queue [ [ instance-id <iid> ] { <eid> | <eid6> } ] [ vrf { <vrf-name> | <vrf-known-name> } ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| lisp                  | LISP show commands                                 |
| ddt                   | LISP Delegated Database Tree (LISP-DDT)            |
| queue                 | Display LISP-DDT Map-Request queue in Map-Resolver |
| instance-id           | (Optional) Show instance-ID summary display        |
| <i>iid</i>            | (Optional) Instance-ID for EID-prefix              |
| <i>eid</i>            | (Optional) IPv4 EID address                        |
| vrf                   | (Optional) Display information for vrf             |
| <i>vrf-name</i>       | (Optional) VRF name                                |
| <i>vrf-known-name</i> | (Optional) Known VRF name                          |

### Command Mode

- /exec

## show lisp ddt referral-cache

```
{ show lisp ddt referral-cache [ [ instance-id <iid> ] { <eid> | <eid6> } ] [ vrf { <vrf-name> | <vrf-known-name> } ] ] | { show lisp ddt referral-cache { ms-ack | ms-referral | node-referral | ms-not-registered | delegation-hole | not-authoritative } [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| lisp                  | LISP show commands                                |
| ddt                   | LISP Delegated Database Tree (LISP-DDT)           |
| referral-cache        | Display LISP-DDT referral cache                   |
| instance-id           | (Optional) Show instance-ID summary display       |
| <i>iid</i>            | (Optional) Instance-ID for EID-prefix             |
| <i>eid</i>            | (Optional) IPv4 EID address                       |
| ms-ack                | Referral cache entries to map-servers             |
| ms-referral           | Referral cache entries from parent of map-servers |
| node-referral         | Referral cache entries from parent of DDT-nodes   |
| ms-not-registered     | Referral cache entries from map-servers           |
| delegation-hole       | Referral cache entries from any DDT-node          |
| not-authoritative     | Referral cache entries from any DDT-node          |
| vrf                   | (Optional) Display information for vrf            |
| <i>vrf-name</i>       | (Optional) VRF name                               |
| <i>vrf-known-name</i> | (Optional) Known VRF name                         |

### Command Mode

- /exec



# show lisp dynamic-eid

```
{ show lisp dynamic-eid { summary | { [ <dyn-eid-name> ] [ detail ] } } [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                     |
| lisp                  | LISP show commands                                  |
| dynamic-eid           | Display dynamic-EIDs configured and discovered      |
| summary               | One-line summary display of discovered dynamic-EIDs |
| <i>dyn-eid-name</i>   | (Optional) Display a single dynamic-EID             |
| vrf                   | (Optional) Display information for vrf              |
| <i>vrf-name</i>       | (Optional) VRF name                                 |
| <i>vrf-known-name</i> | (Optional) Known VRF name                           |
| detail                | (Optional) Display discovered dynamic-EIDs          |

## Command Mode

- /exec

# show lisp elp

```
show lisp elp [ vrf { <vrf-name> | <vrf-known-name> } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                |
| lisp                  | LISP show commands                             |
| elp                   | Display LISP Explicit Locator Paths configured |
| vrf                   | (Optional) Display information for vrf         |
| <i>vrf-name</i>       | (Optional) VRF name                            |
| <i>vrf-known-name</i> | (Optional) Known VRF name                      |

## Command Mode

- /exec

## show lisp negative-prefix

```
show lisp negative-prefix { <eid> | <eid6> } [ vrf { <vrf-name> | <vrf-known-name> } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information               |
| lisp                  | LISP show commands                            |
| negative-prefix       | Compute negative-prefix for hole in EID space |
| <i>eid</i>            | IPv4 EID address                              |
| vrf                   | (Optional) Display information for vrf        |
| <i>vrf-name</i>       | (Optional) VRF name                           |
| <i>vrf-known-name</i> | (Optional) Known VRF name                     |

### Command Mode

- /exec

## show lisp proxy-itr

```
show lisp proxy-itr [ vrf { <vrf-name> | <vrf-known-name> } ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information        |
| lisp                  | LISP show commands                     |
| proxy-itr             | Display discovered proxy-ITRs (PITRs)  |
| vrf                   | (Optional) Display information for vrf |
| <i>vrf-name</i>       | (Optional) VRF name                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name              |

### Command Mode

- /exec

# show lisp site

```
{ show lisp site [ { { <eid> | <eid6> } [ instance-id <iid> ] } | { { <eid-prefix> | <eid-prefix6> } [ instance-id <iid> ] } | <site-name> ] [ detail ] [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| lisp                  | LISP show commands                                     |
| site                  | Display Map-Server site EID-prefixes configured        |
| vrf                   | (Optional) Display information for vrf                 |
| <i>vrf-name</i>       | (Optional) VRF name                                    |
| <i>vrf-known-name</i> | (Optional) Known VRF name                              |
| <i>eid</i>            | (Optional) Display mapping for IP destination EID      |
| <i>eid-prefix</i>     | (Optional) Display exact match for IP EID-prefix entry |
| instance-id           | (Optional) Instance EID-prefix registered in           |
| <i>iid</i>            | (Optional) Instance-ID value                           |
| <i>site-name</i>      | (Optional) Display a single site                       |
| detail                | (Optional) Display allowed registered locator sources  |

## Command Mode

- /exec

# show lisp site instance-id

```
{ show lisp site instance-id [ <iid> ] [ vrf { <vrf-name> | <vrf-known-name> } ] }
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                            |
| lisp                  | LISP show commands   |
| site                  | Display Map-Server site EID-prefixes configured            |
| instance-id           | Show instance-ID summary display                           |
| <i>iid</i>            | (Optional) Show detail for entries of a single Instance-ID |
| vrf                   | (Optional) Display information for vrf                     |
| <i>vrf-name</i>       | (Optional) VRF name  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                  |

## Command Mode

- /exec

# show lldp all

show lldp all [ *\_\_readonly\_\_* *TABLE\_lldp\_all* <*intf\_desc*> <*lldp\_tx*> <*lldp\_rx*> <*lldp\_dcbx*> ]

## Syntax Description

|                       |                                      |
|-----------------------|--------------------------------------|
| show                  | Show running system information      |
| lldp                  | Show lldp Protocol information       |
| all                   | Show all interfaces in lldp database |
| <i>__readonly__</i>   | (Optional) Read only                 |
| <i>TABLE_lldp_all</i> | (Optional) output of show lldp all   |
| <i>intf_desc</i>      | (Optional) Interface desc            |
| <i>lldp_tx</i>        | (Optional) lldp tx status            |
| <i>lldp_rx</i>        | (Optional) lldp rx status            |
| <i>lldp_dcbx</i>      | (Optional) lldp dcbx status          |

## Command Mode

- /exec

## show lldp dcbx interface

```
show lldp dcbx interface <if_in> [ __readonly__ <if_out> <cfg_proto> <det_proto> [ <l_op_ver> <l_max_ver>
<l_seq_no> <l_ack_no> ] [ <l_feature> <l_feat_len> <l_cfg> ] + [ <p_op_ver> <p_max_ver> <p_seq_no>
<p_ack_no> ] [ <p_tlv_type> <p_tlv_ctrl> <p_tlv_len> <p_tlv_value> ] + ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| lldp                | Show information about lldp                     |
| dcbx                | Show dcbx information                           |
| interface           | Show lldp interface information                 |
| <i>if_in</i>        | Enter interface                                 |
| <i>__readonly__</i> | (Optional)                                      |
| <i>if_out</i>       | (Optional) Interface ID                         |
| <i>cfg_proto</i>    | (Optional) Configured DCBX Protocol             |
| <i>det_proto</i>    | (Optional) DCBX Protocol detected               |
| <i>l_op_ver</i>     | (Optional) local dcbx control operation version |
| <i>l_max_ver</i>    | (Optional) local dcbx control maximum version   |
| <i>l_seq_no</i>     | (Optional) local dcbx control seq no            |
| <i>l_ack_no</i>     | (Optional) local dcbx control ack no            |
| <i>l_feature</i>    | (Optional) local feature                        |
| <i>l_feat_len</i>   | (Optional) Local Feature Length                 |
| <i>l_cfg</i>        | (Optional) local feature config                 |
| <i>p_op_ver</i>     | (Optional) peer dcbx control operation version  |
| <i>p_max_ver</i>    | (Optional) peer dcbx control maximum version    |
| <i>p_seq_no</i>     | (Optional) peer dcbx control seq no             |
| <i>p_ack_no</i>     | (Optional) peer dcbx control ack no             |
| <i>p_tlv_type</i>   | (Optional) peer TLV type field                  |
| <i>p_tlv_ctrl</i>   | (Optional) peer TLV control info                |
| <i>p_tlv_len</i>    | (Optional) Peer TLV Length                      |
| <i>p_tlv_value</i>  | (Optional) peer TLV value field                 |



**Command Mode**

- /exec

# show lldp entry

```
show lldp entry [ <sys-name> ] [ __readonly__ { <neigh_hdr> } { TABLE_entry <chassis_type> <chassis_id>
<port_type> <port_id> <l_port_id> <port_desc> <sys_name> <sys_desc> <ttl> <capability>
<mgmt_addr_type> <mgmt_addr> <mgmt_addr_ipv6_type> <mgmt_addr_ipv6> <vlan_id> } { <neigh_count>
} ]
```

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information         |
| lldp                       | Show information about lldp             |
| entry                      | Show lldp entry information             |
| <i>sys-name</i>            | (Optional) WORD Peer's System name      |
| <i>__readonly__</i>        | (Optional)                              |
| <i>neigh_hdr</i>           | (Optional)                              |
| TABLE_entry                | (Optional) Table Entry                  |
| <i>chassis_type</i>        | (Optional) Chassis ID type              |
| <i>chassis_id</i>          | (Optional) Chassis ID                   |
| <i>port_type</i>           | (Optional) Port ID type                 |
| <i>port_id</i>             | (Optional) Port ID                      |
| <i>l_port_id</i>           | (Optional) Port ID                      |
| <i>port_desc</i>           | (Optional) Port description             |
| <i>sys_name</i>            | (Optional) System name                  |
| <i>sys_desc</i>            | (Optional) System description           |
| <i>ttl</i>                 | (Optional) Time to live                 |
| <i>capability</i>          | (Optional) Capability                   |
| <i>mgmt_addr_type</i>      | (Optional) Management Address type      |
| <i>mgmt_addr</i>           | (Optional) Management Address           |
| <i>mgmt_addr_ipv6_type</i> | (Optional) IPV6 Management Address type |
| <i>mgmt_addr_ipv6</i>      | (Optional) IPV6 Management Address      |
| <i>vlan_id</i>             | (Optional) Vlan ID                      |
| <i>neigh_count</i>         | (Optional)                              |

**Command Mode**

- /exec

## show lldp interface

```
show lldp interface <if0> [ __readonly__ <interface> <tx_en> <rx_en> <dcbx_en> <port_mac> [ <tlv_type>
<tlv_len> [ <tlv_value> ] ] + [ <l_op_ver> <l_max_ver> <l_seq_no> <l_ack_no> [ <l_feature> <l_cfg_len>
<l_cfg> ] + ] [ <p_op_ver> <p_max_ver> <p_seq_no> <p_ack_no> [ <p_tlv_type> <p_tlv_len> <p_tlv_value>
] + ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| lldp                | Show information about lldp                      |
| interface           | Show lldp interface information                  |
| <i>if0</i>          | Enter interface                                  |
| <i>__readonly__</i> | (Optional)                                       |
| <i>interface</i>    | (Optional) Interface ID                          |
| <i>tx_en</i>        | (Optional) tx enable                             |
| <i>rx_en</i>        | (Optional) rx enable                             |
| <i>dcbx_en</i>      | (Optional) dcbox enable                          |
| <i>port_mac</i>     | (Optional) Port mac address                      |
| <i>tlv_type</i>     | (Optional) TLV type field                        |
| <i>tlv_len</i>      | (Optional) TLV len field                         |
| <i>tlv_value</i>    | (Optional) TLV value field                       |
| <i>l_op_ver</i>     | (Optional) local dcbox control operation version |
| <i>l_max_ver</i>    | (Optional) local dcbox control maximum version   |
| <i>l_seq_no</i>     | (Optional) local dcbox control seq no            |
| <i>l_ack_no</i>     | (Optional) local dcbox control ack no            |
| <i>l_feature</i>    | (Optional) local feature                         |
| <i>l_cfg_len</i>    | (Optional) local feature config length           |
| <i>l_cfg</i>        | (Optional) local feature config                  |
| <i>p_op_ver</i>     | (Optional) peer dcbox control operation version  |
| <i>p_max_ver</i>    | (Optional) peer dcbox control maximum version    |
| <i>p_seq_no</i>     | (Optional) peer dcbox control seq no             |

|                    |                                     |
|--------------------|-------------------------------------|
| <i>p_ack_no</i>    | (Optional) peer dcbx control ack no |
| <i>p_tlv_type</i>  | (Optional) peer TLV type field      |
| <i>p_tlv_len</i>   | (Optional) peer TLV len field       |
| <i>p_tlv_value</i> | (Optional) peer TLV value field     |

**Command Mode**

- /exec

## show lldp neighbors

```
show lldp neighbors [ interface <if> ] [ __readonly__ { <neigh_hdr> } { TABLE_nbor <chassis_type>
<chassis_id> <l_port_id> <hold_time> [ <capability> ] <system_capability> <enabled_capability> <port_type>
<port_id> <mgmt_addr_type> <mgmt_addr> <mgmt_addr_ipv6_type> <mgmt_addr_ipv6> } { <neigh_count>
} ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                           |
| lldp                       | Show information about lldp                               |
| neighbors                  | Show lldp neighbor information                            |
| interface                  | (Optional) Show lldp neighbor information on an interface |
| <i>if</i>                  | (Optional) Enter interface                                |
| <i>__readonly__</i>        | (Optional)  |
| <i>neigh_hdr</i>           | (Optional)  |
| TABLE_nbor                 | (Optional) Neighbor Table                                 |
| <i>chassis_type</i>        | (Optional) Chassis ID type                                |
| <i>chassis_id</i>          | (Optional) Chassis ID                                     |
| <i>l_port_id</i>           | (Optional) Local port ID                                  |
| <i>hold_time</i>           | (Optional) Hold time                                      |
| <i>capability</i>          | (Optional) Capability                                     |
| <i>system_capability</i>   | (Optional) System Capability                              |
| <i>enabled_capability</i>  | (Optional) Enabled Capability                             |
| <i>port_type</i>           | (Optional) Port ID type                                   |
| <i>port_id</i>             | (Optional) Port ID  |
| <i>mgmt_addr_type</i>      | (Optional) Management Address type                        |
| <i>mgmt_addr</i>           | (Optional) Management Address                             |
| <i>mgmt_addr_ipv6_type</i> | (Optional) IPV6 Management Address type                   |
| <i>mgmt_addr_ipv6</i>      | (Optional) IPV6 Management Address                        |
| <i>neigh_count</i>         | (Optional)  |

### Command Mode

- /exec

## show lldp neighbors detail

```
show lldp neighbors [ interface <if> ] detail [ __readonly__ { <neigh_hdr> } { TABLE_nbor_detail
<chassis_type> <chassis_id> <port_type> <port_id> <l_port_id> <port_desc> <sys_name> <sys_desc> <ttl>
[ <capability> ] <system_capability> <enabled_capability> <mgmt_addr_type> <mgmt_addr>
<mgmt_addr_ipv6_type> <mgmt_addr_ipv6> <vlan_id> } { <neigh_count> } ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                           |
| lldp                      | Show information about lldp                               |
| neighbors                 | Show lldp neighbor information                            |
| interface                 | (Optional) Show lldp neighbor information on an interface |
| <i>if</i>                 | (Optional) Enter interface                                |
| detail                    | Show lldp neighbor detail information                     |
| <i>__readonly__</i>       | (Optional)  |
| <i>neigh_hdr</i>          | (Optional)  |
| TABLE_nbor_detail         | (Optional) Neighbor detail Table                          |
| <i>chassis_type</i>       | (Optional) Chassis ID type                                |
| <i>chassis_id</i>         | (Optional) Chassis ID                                     |
| <i>port_type</i>          | (Optional) Port ID type                                   |
| <i>port_id</i>            | (Optional) Port ID  |
| <i>l_port_id</i>          | (Optional) Port ID  |
| <i>port_desc</i>          | (Optional) Port description                               |
| <i>sys_name</i>           | (Optional) System name                                    |
| <i>sys_desc</i>           | (Optional) System description                             |
| <i>ttl</i>                | (Optional) Time to live                                   |
| <i>capability</i>         | (Optional) Capability                                     |
| <i>system_capability</i>  | (Optional) System Capability                              |
| <i>enabled_capability</i> | (Optional) Enabled Capability                             |
| <i>mgmt_addr_type</i>     | (Optional) Management Address type                        |
| <i>mgmt_addr</i>          | (Optional) Management Address                             |



|                            |   |
|----------------------------|---|
| <i>mgmt_addr_ipv6_type</i> | (Optional) IPV6 Management Address type |
| <i>mgmt_addr_ipv6</i>      | (Optional) IPV6 Management Address      |
| <i>vlan_id</i>             | (Optional) Vlan ID                      |
| <i>neigh_count</i>         | (Optional)                              |

**Command Mode**

- /exec

## show lldp neighbors system-detail

```
show lldp neighbors [ interface <if> ] system-detail [ __readonly__ { <neigh_hdr> } { TABLE_nbor_sys_detail
<sys_type> <sys_name> <l_port_id> <chassis_type> <chassis_id> <port_type> <port_id> <ttl> <capability>
<mgmt_addr_type> <mgmt_addr> } { <neigh_count> } ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                           |
| lldp                  | Show information about lldp                               |
| neighbors             | Show lldp neighbor information                            |
| interface             | (Optional) Show lldp neighbor information on an interface |
| <i>if</i>             | (Optional) Enter interface                                |
| system-detail         | Show lldp neighbor system detail information              |
| <i>__readonly__</i>   | (Optional)  |
| <i>neigh_hdr</i>      | (Optional)  |
| TABLE_nbor_sys_detail | (Optional) Neighbor sys-detail Table                      |
| <i>sys_type</i>       | (Optional) System Type                                    |
| <i>sys_name</i>       | (Optional) System Name                                    |
| <i>l_port_id</i>      | (Optional) Local port ID                                  |
| <i>chassis_type</i>   | (Optional) Chassis ID type                                |
| <i>chassis_id</i>     | (Optional) Chassis ID                                     |
| <i>port_type</i>      | (Optional) Port ID type                                   |
| <i>port_id</i>        | (Optional) Port ID  |
| <i>ttl</i>            | (Optional) Time to live                                   |
| <i>capability</i>     | (Optional) Capability                                     |
| <i>mgmt_addr_type</i> | (Optional) Management Address type                        |
| <i>mgmt_addr</i>      | (Optional) Management Address                             |
| <i>neigh_count</i>    | (Optional)  |

### Command Mode

- /exec

# show lldp poe interface

```
show lldp poe { interface <if0> } [ __readonly__ <power-type> <power-source> <power-priority>
<power-requested> <power-allocated> ]
```

## Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| lldp                   | Show lldp protocol information  |
| poe                    | Power over Ethernet             |
| interface              | Show lldp interface information |
| <i>if0</i>             | Interface name                  |
| <i>__readonly__</i>    | (Optional)                      |
| <i>power-type</i>      | (Optional) Power Type           |
| <i>power-source</i>    | (Optional) Power Source         |
| <i>power-priority</i>  | (Optional) Power Priority       |
| <i>power-requested</i> | (Optional) Requested Power      |
| <i>power-allocated</i> | (Optional) Allocated Power      |

## Command Mode

- /exec

## show lldp portid-subtype

```
show lldp portid-subtype [ __readonly__ <portid_subtype> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| lldp                  | Show information about lldp                     |
| portid-subtype        | Show lldp portid-subtype                        |
| __readonly__          | (Optional)                                      |
| <i>portid_subtype</i> | (Optional) portid-subtype for LLDP TLV and MIBs |

### Command Mode

- /exec

## show lldp timers

```
show lldp timers [ __readonly__ <ttl> <reinit> <tx_interval> <tx_delay> <hold_mplier> <notification_interval> ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                         |
| lldp                         | Show information about lldp                             |
| timers                       | Show lldp timers  |
| <i>__readonly__</i>          | (Optional)  |
| <i>ttl</i>                   | (Optional) Time to Live for lldp info                   |
| <i>reinit</i>                | (Optional) Interface reinit timer                       |
| <i>tx_interval</i>           | (Optional) Wait interval between successive transmit    |
| <i>tx_delay</i>              | (Optional) Delay between successive frame transmissions |
| <i>hold_mplier</i>           | (Optional) Hold multiplier for ttl                      |
| <i>notification_interval</i> | (Optional) Notification interval for SNMP trap          |

### Command Mode

- /exec

## show lldp tlv-select

```
show lldp tlv-select [ __readonly__ <management-address-v4> <management-address-v6> <port-description>
<port-vlan> <power-management> <four-wire-power-management> <system-capabilities>
<system-description> <system-name> <dcbxp-cin-cee> [ <dcbxp-cn> ] [ <dcbxp-ets-cfg> ] [ <dcbxp-ets-reco>
] [ <dcbxp-pfc-cfg> ] [ <dcbxp-app-pri> ] [ <dcbxp-app-vlan> ] ]
```

### Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information             |
| lldp                              | Show information about lldp                 |
| tlv-select                        | Show lldp tlv-select                        |
| <i>__readonly__</i>               | (Optional)                                  |
| <i>management-address-v4</i>      | (Optional) Management address v4            |
| <i>management-address-v6</i>      | (Optional) Management address v6            |
| <i>port-description</i>           | (Optional) Port description                 |
| <i>port-vlan</i>                  | (Optional) Port vlan                        |
| <i>power-management</i>           | (Optional) IEEE 802.3 DTE Power via MDI TLV |
| <i>four-wire-power-management</i> | (Optional) Cisco 4-Wire Power via MDI TLV   |
| <i>system-capabilities</i>        | (Optional) System capabilities              |
| <i>system-description</i>         | (Optional) System description               |
| <i>system-name</i>                | (Optional) System name                      |
| <i>dcbxp-cin-cee</i>              | (Optional) DCBXP CIN or CEE                 |
| <i>dcbxp-cn</i>                   | (Optional) DCBXP Congestion Notification    |
| <i>dcbxp-ets-cfg</i>              | (Optional) DCBXP ETS Configuration          |
| <i>dcbxp-ets-reco</i>             | (Optional) DCBXP ETS Recommendation         |
| <i>dcbxp-pfc-cfg</i>              | (Optional) DCBXP PFC Configuration          |
| <i>dcbxp-app-pri</i>              | (Optional) DCBXP Application Priorities     |
| <i>dcbxp-app-vlan</i>             | (Optional) DCBXP Application VLAN's         |

### Command Mode

- /exec

# show lldp traffic

```
show lldp traffic [ __readonly__ <tx_cnt> <aged_cnt> <rx_cnt> <rx_err> <disc_cnt> <unrecognized_tlv>
<flap_cnt> ]
```

## Syntax Description

|                         |                                   |
|-------------------------|-----------------------------------|
| show                    | Show running system information   |
| lldp                    | Show information about lldp       |
| traffic                 | Show lldp counters                |
| <i>__readonly__</i>     | (Optional)                        |
| <i>tx_cnt</i>           | (Optional) Transmit count         |
| <i>aged_cnt</i>         | (Optional) Aged out count         |
| <i>rx_cnt</i>           | (Optional) Received count         |
| <i>rx_err</i>           | (Optional) Received error count   |
| <i>disc_cnt</i>         | (Optional) Disconnect count       |
| <i>unrecognized_tlv</i> | (Optional) Unrecognized TLV count |
| <i>flap_cnt</i>         | (Optional) flap count             |

## Command Mode

- /exec

# show lldp traffic interface

```
show lldp traffic interface <if> [ __readonly__ <interface> <tx_cnt> <aged_cnt> <rx_cnt> <rx_err> <disc_cnt>
<unrecognized_tlv> <flap_cnt> ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information            |
| lldp                    | Show information about lldp                |
| traffic                 | Show lldp counters                         |
| interface               | Show lldp traffic counters on an interface |
| <i>if</i>               | Enter interface                            |
| <i>__readonly__</i>     | (Optional)                                 |
| <i>interface</i>        | (Optional) Interface ID                    |
| <i>tx_cnt</i>           | (Optional) Transmit count                  |
| <i>aged_cnt</i>         | (Optional) Aged out count                  |
| <i>rx_cnt</i>           | (Optional) Received count                  |
| <i>rx_err</i>           | (Optional) Received error count            |
| <i>disc_cnt</i>         | (Optional) Disconnect count                |
| <i>unrecognized_tlv</i> | (Optional) Unrecognized TLV count          |
| <i>flap_cnt</i>         | (Optional) flap count                      |

## Command Mode

- /exec



## show lldp traffic interface all

```
show lldp traffic interface all [ __readonly__ TABLE_lldp_traffic_interface <interface> <tx_cnt> <aged_cnt>
<rx_cnt> <rx_err> <disc_cnt> <unrecognized_tlv> <flap_cnt> ]
```

### Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information            |
| lldp                                | Show information about lldp                |
| traffic                             | Show lldp counters                         |
| interface                           | Show lldp traffic counters on an interface |
| all                                 | Get status for all interfaces              |
| <i>__readonly__</i>                 | (Optional)                                 |
| <i>TABLE_lldp_traffic_interface</i> | (Optional) LLDP traffic interface table    |
| <i>interface</i>                    | (Optional) Interface ID                    |
| <i>tx_cnt</i>                       | (Optional) Transmit count                  |
| <i>aged_cnt</i>                     | (Optional) Aged out count                  |
| <i>rx_cnt</i>                       | (Optional) Received count                  |
| <i>rx_err</i>                       | (Optional) Received error count            |
| <i>disc_cnt</i>                     | (Optional) Disconnect count                |
| <i>unrecognized_tlv</i>             | (Optional) Unrecognized TLV count          |
| <i>flap_cnt</i>                     | (Optional) flap count                      |

### Command Mode

- /exec

# show locator-led status

```
show locator-led status [ __readonly__ { TABLE_loc_led_stat <component> <status> } ]
```

## Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| locator-led        | blink locator led on device     |
| status             | status                          |
| __readonly__       | (Optional)                      |
| TABLE_loc_led_stat | (Optional)                      |
| <i>component</i>   | (Optional)                      |
| <i>status</i>      | (Optional)                      |

## Command Mode

- /exec

# show logging

show logging

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |

## Command Mode

- /exec

# show logging console

show logging console

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| console | Show console logging configuration                 |

## Command Mode

- /exec

# show logging dropcount

show logging dropcount

## Syntax Description

|           |                                    |
|-----------|------------------------------------|
| show      | logging dropcount                  |
| logging   | Show logging drop count of syslogs |
| dropcount | Show logging dropcount             |

## Command Mode

- /exec

# show logging history

show logging history

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| history | Show logging history configuration                 |

## Command Mode

- /exec

## show logging info

```
show logging info [ __readonly__ { <console_status> [ <console_severity> ] } { <monitor_status> [
<monitor_severity> ] } { <linecard_status> [ <linecard_severity> ] } { <log_timestamp> } [ {
<source_interface_status> } [ <source_interface_intf> | <source_interface_intf_index> <source_interface_error>
] ] { <server_status> [ { TABLE_logserver <server> <forwarding> <severity> <facility> <vrf> <port> [
<transport> ] } ] } { <origin_id_status> } [ <origin_id> ] ] [ [ <logflash_status> ] [ <logflash_severity> ] [
<logflash_threshold> ] ] { <logfile_status> [ <logfile_name> <logfile_severity> <logfile_size> ] } { {
TABLE_facility <fac_name> <def_level> <cur_level> } { <fac_info> } } ]
```

### Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | Show running system information                    |
| logging                        | Show logging configuration and contents of logfile |
| info                           | Show logging configuration                         |
| <i>__readonly__</i>            | (Optional)   |
| <i>console_status</i>          | (Optional) console logging status                  |
| <i>console_severity</i>        | (Optional) console logging level                   |
| <i>monitor_status</i>          | (Optional) monitor logging status                  |
| <i>monitor_severity</i>        | (Optional) monitor logging level                   |
| <i>linecard_status</i>         | (Optional) linecard logging status                 |
| <i>linecard_severity</i>       | (Optional) linecard logging level                  |
| <i>log_timestamp</i>           | (Optional) timestamp unit                          |
| <i>source_interface_status</i> | (Optional) source-interface logging status         |
| <i>source_interface_intf</i>   | (Optional) source-interface interface              |
| <i>server_status</i>           | (Optional) logging server status                   |
| TABLE_logserver                | (Optional) output of show logging server           |
| <i>transport</i>               | (Optional) remote server transport                 |
| <i>origin_id_status</i>        | (Optional) origin-id status                        |
| <i>origin_id</i>               | (Optional) origin-id                               |
| <i>logflash_status</i>         | (Optional) logflash status                         |
| <i>logflash_severity</i>       | (Optional) logflash level                          |
| <i>logflash_threshold</i>      | (Optional) logflash threshold percentage           |
| <i>logfile_status</i>          | (Optional) logfile status                          |

|                |   |
|----------------|---|
| TABLE_facility | (Optional) output of show logging level(facility) |
| fac_info       | (Optional) level info                             |

**Command Mode**

- /exec



## show logging ip access-list cache

```
show logging ip access-list cache [ detail ] [ __readonly__ <disp_flags> <sgt> <src_ip> <dst_ip> <src_port>
<dst_port> <if_index> <proto> <hit_cnt> <acl_name> <acl_num> <acl_permit> <acl_ingress> <acl_type>
<acl_appl_if_index> <acl_fltr_hit_cnt> ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                           |
| logging                  | logging information                                       |
| ip                       | IP configuration  |
| access-list              | Access-list   |
| cache                    | logging   |
| detail                   | (Optional) Show additional details about entries in cache |
| <i>__readonly__</i>      | (Optional)  |
| <i>disp_flags</i>        | (Optional) Display flags                                  |
| <i>sgt</i>               | (Optional) SGT  |
| <i>src_ip</i>            | (Optional) Source IP                                      |
| <i>dst_ip</i>            | (Optional) Dest IP  |
| <i>src_port</i>          | (Optional) Source port                                    |
| <i>dst_port</i>          | (Optional) Dest port                                      |
| <i>if_index</i>          | (Optional) Interface                                      |
| <i>proto</i>             | (Optional) Protocol                                       |
| <i>hit_cnt</i>           | (Optional) Hits   |
| <i>acl_name</i>          | (Optional) ACL Name                                       |
| <i>acl_num</i>           | (Optional) ACL Number                                     |
| <i>acl_permit</i>        | (Optional) ACL Permit                                     |
| <i>acl_ingress</i>       | (Optional) ACL Ingress                                    |
| <i>acl_type</i>          | (Optional) ACL Filter Type                                |
| <i>acl_appl_if_index</i> | (Optional) ACL Applied Interface                          |
| <i>acl_fltr_hit_cnt</i>  | (Optional) ACL Filter Count                               |

### Command Mode

- /exec

# show logging ip access-list status

show logging ip access-list status [ *\_\_readonly\_\_* <num\_entries> <seconds> <num\_packets> ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| logging             | logging information                       |
| ip                  | IP configuration                          |
| access-list         | Access-list                               |
| status              | ACLLOG status                             |
| <i>__readonly__</i> | (Optional)                                |
| <i>num_entries</i>  | (Optional) Max flows                      |
| <i>seconds</i>      | (Optional) Log-update interval in seconds |
| <i>num_packets</i>  | (Optional) threshold                      |

## Command Mode

- /exec

# show logging last

show logging last <i0>

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| last      | Show last few lines of logfile                     |
| <i>i0</i> | Enter number of lines to display                   |

## Command Mode

- /exec

# show logging level

```
show logging level [ { auth | authpriv | cron | daemon | ftp | kernel | local0 | local1 | local2 | local3 | local4 |
local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp } ] [ __readonly__ { TABLE_facility <fac_name>
<def_level> <cur_level> } ]
```

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                |
| logging      | Show logging configuration and contents of logfile             |
| level        | Show facility logging configuration                            |
| auth         | (Optional) Show Authorization System logging configuration     |
| authpriv     | (Optional) Show Authorization (Private) logging configuration  |
| cron         | (Optional) Show Cron/at facility logging configuration         |
| daemon       | (Optional) Show System daemons logging configuration           |
| ftp          | (Optional) Show File Transfer System logging configuration     |
| kernel       | (Optional) Show kernel logging configuration                   |
| local0       | (Optional) Show Local use daemons logging configuration        |
| local1       | (Optional) Show Local use daemons logging configuration        |
| local2       | (Optional) Show Local use daemons logging configuration        |
| local3       | (Optional) Show Local use daemons logging configuration        |
| local4       | (Optional) Show Local use daemons logging configuration        |
| local5       | (Optional) Show Local use daemons logging configuration        |
| local6       | (Optional) Show Local use daemons logging configuration        |
| local7       | (Optional) Show Local use daemons logging configuration        |
| lpr          | (Optional) Show Line Printer System logging configuration      |
| mail         | (Optional) Show Mail System logging configuration              |
| news         | (Optional) Show USENET news logging configuration              |
| syslog       | (Optional) Show Internal Syslog Messages logging configuration |
| user         | (Optional) Show user process logging configuration             |
| uucp         | (Optional) Show Unix-to-Unix copy system logging configuration |
| __readonly__ | (Optional)   |

|                  |                             |
|------------------|-----------------------------|
| <i>fac_name</i>  | (Optional) facility names   |
| TABLE_facility   | (Optional)                  |
| <i>def_level</i> | (Optional) default severity |
| <i>cur_level</i> | (Optional) current severity |

**Command Mode**

- /exec

# show logging level

show logging level

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level aaa

show logging level aaa

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| aaa     | Show aaa logging configuration                     |

## Command Mode

- /exec



# show logging level acl

show logging level acl

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| acl     | Show acl logging configuration                     |

## Command Mode

- /exec

# show logging level aclog

show logging level aclog

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| aclog   | Show aclog logging configuration                   |

## Command Mode

- /exec

# show logging level aclmgr

show logging level aclmgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| aclmgr  | Show aclmgr logging configuration                  |

## Command Mode

- /exec

# show logging level adbm

show logging level adbm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| adbm    | Show adbm logging configuration                    |

## Command Mode

- /exec

# show logging level adjmgr

show logging level adjmgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| adjmgr  | Show adjmgr logging configuration                  |

## Command Mode

- /exec

# show logging level amt

show logging level amt

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| amt     | Show amt logging configuration                     |

## Command Mode

- /exec

# show logging level arp

show logging level arp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| arp     | Show arp logging configuration                     |

## Command Mode

- /exec

# show logging level ascii-cfg

show logging level ascii-cfg

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| ascii-cfg | Show ascii-cfg logging configuration               |

## Command Mode

- /exec



# show logging level assoc\_mgr

show logging level assoc\_mgr

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| assoc_mgr | Show Association Manager Logging Configuration     |

## Command Mode

- /exec

# show logging level backup

show logging level { backup | flexlink }

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| backup   | Show Switchport Backup logging level               |
| flexlink | Show Switchport Backup logging level               |

## Command Mode

- /exec

# show logging level bfd

show logging level bfd

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| bfd     | Show bfd logging configuration                     |

## Command Mode

- /exec

# show logging level bgp

show logging level bgp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| bgp     | Show BGP logging configuration                     |

## Command Mode

- /exec

# show logging level bloggerd

show logging level bloggerd

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| bloggerd | Show BloggerD logging configuration                |

## Command Mode

- /exec

# show logging level bootvar

show logging level bootvar

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| bootvar | Show bootvar logging configuration                 |

## Command Mode

- /exec

# show logging level callhome

show logging level callhome

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| callhome | Show callhome logging configuration                |

## Command Mode

- /exec

# show logging level capability

show logging level capability

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| level      | Show facility logging configuration                |
| capability | Show capability logging configuration              |

## Command Mode

- /exec



# show logging level cdp

show logging level cdp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| cdp     | Show CDP logging configuration                     |

## Command Mode

- /exec

# show logging level cert\_enroll

show logging level cert\_enroll

## Syntax Description

|             |  |
|-------------|--|
| show        | Show running system information                    |
| logging     | Show logging configuration and contents of logfile |
| level       | Show facility logging configuration                |
| cert_enroll | Show Cert-enroll logging configuration             |

## Command Mode

- /exec

# show logging level cfs

show logging level cfs

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level clis

show logging level clis

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| clis    | Show CLIS logging configuration                    |

## Command Mode

- /exec

# show logging level clk\_mgr

show logging level clk\_mgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| clk_mgr | Show clock manager logging configuration           |

## Command Mode

- /exec

# show logging level confcheck

show logging level confcheck

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| confcheck | Show confcheck logging configuration               |

## Command Mode

- /exec

# show logging level copp

show logging level copp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| copp    | Show copp logging configuration                    |

## Command Mode

- /exec

# show logging level core-dmon

show logging level core-dmon

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| core-dmon | Show core daemon logging configuration             |

## Command Mode

- /exec



# show logging level cts

show logging level cts

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| cts     | Show cts logging configuration                     |

## Command Mode

- /exec

# show logging level device-alias

show logging level device-alias

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| device-alias | Show device-alias logging configuration            |

## Command Mode

- /exec

# show logging level dhclient

show logging level dhclient

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| dhclient | Show syslog level for dhcp client                  |

## Command Mode

- /exec

# show logging level dhcp\_snoop

show logging level dhcp\_snoop

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| level      | Show facility logging configuration                |
| dhcp_snoop | Show DHCP snoop logging configuration              |

## Command Mode

- /exec

# show logging level diagnostic diag\_port\_lb

show logging level diagnostic diag\_port\_lb

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| diagnostic   | Diagnostic commands                                |
| diag_port_lb | Show diagmgr logging configuration                 |

## Command Mode

- /exec

# show logging level diagnostic diagclient

show logging level diagnostic diagclient

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| level      | Show facility logging configuration                |
| diagnostic | Diagnostic commands                                |
| diagclient | Show diagclient logging configuration              |

## Command Mode

- /exec

# show logging level diagnostic diagmgr

show logging level diagnostic diagmgr

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| level      | Show facility logging configuration                |
| diagnostic | Diagnostic commands                                |
| diagmgr    | Show diagmgr logging configuration                 |

## Command Mode

- /exec

# show logging level dot1x

show logging level dot1x

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| dot1x   | Show dot1x logging configuration                   |

## Command Mode

- /exec



# show logging level dpvm

show logging level dpvm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level ecp

show logging level ecp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information        |
| logging | Modify message logging facilities      |
| level   | Facility parameter for syslog messages |
| ecp     | Set syslog filter level for ECP        |

## Command Mode

- /exec

# show logging level eigrp

show logging level eigrp [ <eigrp-ptag> ]

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                    |
| logging           | Show logging configuration and contents of logfile |
| level             | Show facility logging configuration                |
| eigrp             | Show EIGRP logging configuration                   |
| <i>eigrp-ptag</i> | (Optional) Process tag                             |

## Command Mode

- /exec

# show logging level eltm

show logging level eltm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| eltm    | Show eltm logging configuration                    |

## Command Mode

- /exec

# show logging level epbr

show logging level epbr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| epbr    | Show epbr logging configuration                    |

## Command Mode

- /exec

# show logging level epp

show logging level epp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| epp     | Show epp logging configuration                     |

## Command Mode

- /exec

# show logging level ethdstats

show logging level ethdstats

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| ethdstats | Show delta statistics logging configuration        |

## Command Mode

- /exec

# show logging level ethpm

show logging level ethpm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ethpm   | Show ethpm logging configuration                   |

## Command Mode

- /exec



# show logging level evb

show logging level evb

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information        |
| logging | Modify message logging facilities      |
| level   | Facility parameter for syslog messages |
| evb     | Set syslog filter level for EVB        |

## Command Mode

- /exec

# show logging level evmc

show logging level evmc

## Syntax Description

|         |                                     |
|---------|-------------------------------------|
| show    | Show running system information     |
| logging | Show message logging facilities     |
| level   | Show facility logging configuration |
| evmc    | Show level for evmc syslog messages |

## Command Mode

- /exec

# show logging level evmed

show logging level evmed

## Syntax Description

|         |                                      |
|---------|--------------------------------------|
| show    | Show running system information      |
| logging | Show message logging facilities      |
| level   | Show facility logging configuration  |
| evmed   | Show level for evmed syslog messages |

## Command Mode

- /exec

# show logging level evms

show logging level evms

## Syntax Description

|         |                                     |
|---------|-------------------------------------|
| show    | Show running system information     |
| logging | Show message logging facilities     |
| level   | Show facility logging configuration |
| evms    | Show level for evms syslog messages |

## Command Mode

- /exec

# show logging level fabric forwarding

show logging level fabric forwarding

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                         |
| logging    | Modify message logging facilities                       |
| level      | Facility parameter for syslog messages                  |
| fabric     | Fabric  |
| forwarding | Fabric Forwarding Protocol: Host Mobility Manager (HMM) |

## Command Mode

- /exec

# show logging level fabricpath isis

show logging level fabricpath isis

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| level      | Show facility logging configuration                |
| fabricpath | Show fabricpath logging configuration              |
| isis       | Show ISIS logging configuration                    |

## Command Mode

- /exec

# show logging level fabricpath switch-id

show logging level fabricpath switch-id

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| level      | Show facility logging configuration                |
| fabricpath | fabricpath information                             |
| switch-id  | show fabricpath switch-id logging configuration    |

## Command Mode

- /exec

# show logging level fc2d

show logging level fc2d

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec



# show logging level fcdomain

show logging level fcdomain

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| fcdomain | Show fcdomain logging configuration                |

## Command Mode

- /exec

# show logging level fcns

show logging level fcns

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| fcns    | Show fcns logging configuration                    |

## Command Mode

- /exec

# show logging level fcoe\_mgr

show logging level fcoe\_mgr

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| fcoe_mgr | Show fcoe_mgr logging configuration                |

## Command Mode

- /exec

# show logging level fcs

show logging level fcs

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level fdmi

show logging level fdmi

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| fdmi    | Show fdmi logging configuration                    |

## Command Mode

- /exec

# show logging level feature-mgr

show logging level feature-mgr

## Syntax Description

|             |  |
|-------------|--|
| show        | Show running system information                    |
| logging     | Show logging configuration and contents of logfile |
| level       | Show facility logging configuration                |
| feature-mgr | Show feature manager logging configuration         |

## Command Mode

- /exec

# show logging level flogi

show logging level flogi

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| flogi   | Show flogi logging configuration                   |

## Command Mode

- /exec

# show logging level fs-daemon

show logging level fs-daemon

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| fs-daemon | Show fs-daemon logging configuration               |

## Command Mode

- /exec



# show logging level fspf

show logging level fspf

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level fsync\_mgr

show logging level fsync\_mgr

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| fsync_mgr | Frequency Synchronization Manager                  |

## Command Mode

- /exec

# show logging level gpixm

show logging level gpixm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| gpixm   | Show global-pixm logging configuration             |

## Command Mode

- /exec

# show logging level hardware-telemetry

show logging level hardware-telemetry

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                    |
| logging            | Show logging configuration and contents of logfile |
| level              | Show facility logging configuration                |
| hardware-telemetry | Show hardware-telemetry logging configuration      |

## Command Mode

- /exec

# show logging level hsrp

show logging level hsrp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| hsrp    | Show HSRP logging configuration                    |

## Command Mode

- /exec

# show logging level icam

show logging level icam

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| icam    | Show icam logging configuration                    |

## Command Mode

- /exec

# show logging level igmp

show logging level [ ip ] igmp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ip      | (Optional) Display IP information                  |
| igmp    | Show igmp logging configuration                    |

## Command Mode

- /exec

# show logging level im

show logging level im

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| im      | Show im logging configuration                      |

## Command Mode

- /exec



# show logging level imp

show logging level imp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| imp     | Show imp logging configuration                     |

## Command Mode

- /exec

# show logging level interface-vlan

show logging level interface-vlan

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                    |
| logging        | Show logging configuration and contents of logfile |
| level          | Show facility logging configuration                |
| interface-vlan | Show interface-vlan logging configuration          |

## Command Mode

- /exec

# show logging level ip sla responder

show logging level ip sla responder

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| ip        |  |
| sla       | Service Level Agreement (SLA)                      |
| responder | Show sla-responder logging configuration           |

## Command Mode

- /exec

# show logging level ip sla sender

show logging level ip sla sender

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ip      |  |
| sla     | Service Level Agreement (SLA)                      |
| sender  | Show sla-sender logging configuration              |

## Command Mode

- /exec

# show logging level ip sla twamp-server

show logging level ip sla twamp-server

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| ip           |  |
| sla          | Service Level Agreement (SLA)                      |
| twamp-server | Show sla-twamp-server logging configuration        |

## Command Mode

- /exec

# show logging level ipconf

show logging level ipconf [ ipv6 ]

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ipconf  | Show ipconf logging configuration                  |
| ipv6    | (Optional) Show ipv6 Conf logging configuration    |

## Command Mode

- /exec

# show logging level ipfib

show logging level ipfib

## Syntax Description

|         |         |
|---------|---------|
| show    | show    |
| logging | logging |
| level   | level   |
| ipfib   | ipfib   |

## Command Mode

- /exec

# show logging level ipqos

show logging level ipqos

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec



# show logging level ipv6 icmp

show logging level ipv6 icmp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ipv6    | Configure IPv6 features                            |
| icmp    | Show icmpv6 logging configuration                  |

## Command Mode

- /exec

# show logging level ipv6 mfwd

show logging level ipv6 mfwd

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ipv6    | Display IPv6 information                           |
| mfwd    | Show MCASTFWD v6 logging configuration             |

## Command Mode

- /exec

# show logging level ipv6 pim

show logging level ipv6 pim

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ipv6    | Display IPv6 information                           |
| pim     | Show pim6 logging configuration                    |

## Command Mode

- /exec

# show logging level iscm

show logging level iscm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| iscm    | Show iscm logging configuration                    |

## Command Mode

- /exec

# show logging level iscm

show logging level iscm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| iscm    | Show iscm logging configuration                    |

## Command Mode

- /exec

# show logging level isis

show logging level isis

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| isis    | Show ISIS logging configuration                    |

## Command Mode

- /exec

# show logging level l2fm

show logging level l2fm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| l2fm    | Show l2fm logging configuration                    |

## Command Mode

- /exec

# show logging level l3vm

show logging level l3vm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| l3vm    | Show L3VM logging configuration                    |

## Command Mode

- /exec



# show logging level lacp

show logging level lacp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| lacp    | Show lacp logging configuration                    |

## Command Mode

- /exec

# show logging level ldap

show logging level ldap

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ldap    | Show ldap logging configuration                    |

## Command Mode

- /exec

# show logging level lim

show logging level lim

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| lim     | Show lim logging configuration                     |

## Command Mode

- /exec

# show logging level lisp

show logging level lisp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| lisp    | Show lisp logging configuration                    |

## Command Mode

- /exec

# show logging level lldp

show logging level lldp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| lldp    | Show LLDP logging configuration                    |

## Command Mode

- /exec

# show logging level m2rib

show logging level m2rib

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| m2rib   | Show M2RIB logging configuration                   |

## Command Mode

- /exec

# show logging level mfdm

show logging level mfdm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| mfdm    | Show mfdm logging configuration                    |

## Command Mode

- /exec

# show logging level mfwd

show logging level { mfwd | mcastfwd }

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| mfwd     | Show MCASTFWD logging configuration                |
| mcastfwd | Show MCASTFWD logging configuration                |

## Command Mode

- /exec



# show logging level mld

show logging level [ ipv6 ] mld

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ipv6    | (Optional) Display IPv6 information                |
| mld     | Show MLD logging configuration                     |

## Command Mode

- /exec

# show logging level mmode

show logging level mmode

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| mmode   | Show maintenance mode logging configuration        |

## Command Mode

- /exec

# show logging level module

show logging level module

## Syntax Description

|         |   |
|---------|---|
| show    | Show running system information                     |
| logging | Show logging configuration and contents of logfile  |
| level   | Show facility logging configuration                 |
| module  | Show module(linecard) manager logging configuration |

## Command Mode

- /exec

# show logging level monitor

show logging level monitor

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| monitor | Show monitor logging configuration                 |

## Command Mode

- /exec

# show logging level mpls manager

show logging level mpls manager

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| mpls    | Show MPLS logging configuration                    |
| manager | Show MPLS manager logging configuration            |

## Command Mode

- /exec

# show logging level mpls switching

show logging level mpls switching

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| mpls      | Show MPLS logging configuration                    |
| switching | Show mpls switching logging configuration          |

## Command Mode

- /exec

# show logging level msdp

show logging level [ ip ] msdp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ip      | (Optional) Display IP information                  |
| msdp    | Show msdp logging configuration                    |

## Command Mode

- /exec

# show logging level mvsh

show logging level mvsh

## Syntax Description

|         |                                     |
|---------|-------------------------------------|
| show    | Show commands                       |
| logging | Show message logging facilities     |
| level   | Show message logging facilities     |
| mvsh    | Show level for mvsh syslog messages |

## Command Mode

- /exec



# show logging level nat

show logging level nat

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| nat     | Show NAT logging configurarion                     |

## Command Mode

- /exec

# show logging level nbm

show logging level nbm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| nbm     | Show Non Blocking Multicast logging configuration  |

## Command Mode

- /exec

# show logging level netstack

show logging level netstack

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| netstack | Show netstack logging configuration                |

## Command Mode

- /exec

# show logging level nfm

show logging level nfm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| nfm     | Show NFM logging configuration                     |

## Command Mode

- /exec

# show logging level nfm

show logging level nfm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| nfm     | Show NFM logging configuration                     |

## Command Mode

- /exec

# show logging level ngmvpn

show logging level ngmvpn

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ngmvpn  | Show ngmvpn logging configuration                  |

## Command Mode

- /exec

# show logging level ngoam

show logging level ngoam

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ngoam   | Show ngoam logging level                           |

## Command Mode

- /exec

# show logging level npv

show logging level npv

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| npv     | Show npv logging configuration                     |

## Command Mode

- /exec



# show logging level ntp

show logging level ntp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ntp     | Show NTP logging settings.                         |

## Command Mode

- /exec

# show logging level nve

show logging level nve

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| nve     | Show NVE logging configuration                     |

## Command Mode

- /exec

# show logging level nxsdk

show logging level nxsdk

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information        |
| logging | Modify message logging facilities      |
| level   | Facility parameter for syslog messages |
| nxsdk   | NXOS SDK                               |

## Command Mode

- /exec

# show logging level ofm

show logging level ofm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information        |
| logging | Modify message logging facilities      |
| level   | Facility parameter for syslog messages |
| ofm     | Show ofm logging settings              |

## Command Mode

- /exec

# show logging level openflow

show logging level openflow

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| openflow | Show OpenFlow agent logging configuration          |

## Command Mode

- /exec

# show logging level ospf

show logging level ospf

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ospf    | Show OSPF logging configuration                    |

## Command Mode

- /exec

# show logging level ospfv3

show logging level ospfv3

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ospfv3  | Display OSPFv3 status and configuration            |

## Command Mode

- /exec

# show logging level otv isis

show logging level otv isis

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| otv     | Show OTV ISIS logging configuration                |
| isis    | Show OTV ISIS logging configuration                |

## Command Mode

- /exec



# show logging level pfstat

show logging level pfstat

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| pfstat  | Show pfstat logging configuration                  |

## Command Mode

- /exec

# show logging level pie

show logging level pie

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| pie     | Show pie logging configuration                     |

## Command Mode

- /exec

# show logging level pim

show logging level [ ip ] pim

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ip      | (Optional) Display IP information                  |
| pim     | Show pim logging configuration                     |

## Command Mode

- /exec

# show logging level pixm

show logging level pixm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| pixm    | Show vdc-local-pixm logging configuration          |

## Command Mode

- /exec

# show logging level pktmgr

show logging level pktmgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| pktmgr  | Show pktmgr logging configuration                  |

## Command Mode

- /exec

# show logging level platform

show logging level platform

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| platform | Show platform logging configuration                |

## Command Mode

- /exec

# show logging level plcmgr

show logging level plcmgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level pltfm\_config

show logging level pltfm\_config

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| pltfm_config | Show pltfm_config logging configuration            |

## Command Mode

- /exec



# show logging level plugin

show logging level plugin

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| plugin  | Show plugin logging configuration                  |

## Command Mode

- /exec

# show logging level poed

show logging level poed

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| poed    | Show PoE Daemon Logging Configuration              |

## Command Mode

- /exec

# show logging level port-channel

show logging level port-channel

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| port-channel | Show port-channel logging configuration            |

## Command Mode

- /exec

# show logging level port-profile

show logging level port-profile

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| port-profile | Show syslog level for port-profile                 |

## Command Mode

- /exec

# show logging level port-resources

show logging level port-resources

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                    |
| logging        | Show logging configuration and contents of logfile |
| level          | Show facility logging configuration                |
| port-resources | Show port-resources logging configuration          |

## Command Mode

- /exec

# show logging level port-security

show logging level port-security

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information                    |
| logging       | Show logging configuration and contents of logfile |
| level         | Show facility logging configuration                |
| port-security | Show port-security logging configuration           |

## Command Mode

- /exec

# show logging level port

show logging level port

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| port    | Show port logging configuration                    |

## Command Mode

- /exec

# show logging level private-vlan

show logging level private-vlan

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| private-vlan | Show interface-vlan logging configuration          |

## Command Mode

- /exec



# show logging level ptp

show logging level ptp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ptp     | Show ptp logging configuration                     |

## Command Mode

- /exec

# show logging level radius

show logging level radius

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| radius  | Show radius logging configuration                  |

## Command Mode

- /exec

# show logging level rdl

show logging level rdl

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level res\_mgr

show logging level res\_mgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| res_mgr | Show res_mgr logging configuration                 |

## Command Mode

- /exec

# show logging level rib

show logging level rib

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| rib     | Show rib logging configuration                     |

## Command Mode

- /exec

# show logging level rip

show logging level rip

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| rip     | Show RIP logging configuration                     |

## Command Mode

- /exec

# show logging level routing ipv6 multicast

show logging level routing ipv6 multicast

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| routing   | Display routing information                        |
| ipv6      | Display IPv6 information                           |
| multicast | Display multicast information                      |

## Command Mode

- /exec

# show logging level routing multicast

show logging level routing [ ip | ipv4 ] multicast

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| routing   | Display routing information                        |
| ip        | (Optional) Display IP information                  |
| ipv4      | (Optional) Display IP information                  |
| multicast | Display multicast information                      |

## Command Mode

- /exec



# show logging level rpm

show logging level rpm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| rpm     | Show RPM logging configuration                     |

## Command Mode

- /exec

# show logging level rscn

show logging level rscn

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| rscn    | Show RSCN logging configuration                    |

## Command Mode

- /exec

# show logging level sal

show logging level sal

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| sal     | Show SAL logging configuration                     |

## Command Mode

- /exec

# show logging level san-port-channel

show logging level san-port-channel

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                    |
| logging          | Show logging configuration and contents of logfile |
| level            | Show facility logging configuration                |
| san-port-channel | Show san-port-channel logging configuration        |

## Command Mode

- /exec

# show logging level san-port-channel

show logging level san-port-channel

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                    |
| logging          | Show logging configuration and contents of logfile |
| level            | Show facility logging configuration                |
| san-port-channel | Show san-port-channel logging configuration        |

## Command Mode

- /exec

# show logging level scheduler

show logging level scheduler

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| scheduler | Show scheduler logging configuration               |

## Command Mode

- /exec

# show logging level scsi-target

show logging level scsi-target

## Syntax Description

|             |  |
|-------------|--|
| show        | Show running system information                    |
| logging     | Show logging configuration and contents of logfile |
| level       | Show facility logging configuration                |
| scsi-target | Show scsi-target logging configuration             |

## Command Mode

- /exec

# show logging level security

show logging level security

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| security | Show security logging configuration                |

## Command Mode

- /exec



# show logging level segment-routing

show logging level segment-routing

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                    |
| logging         | Show logging configuration and contents of logfile |
| level           | Show facility logging configuration                |
| segment-routing | Show SR logging configuration                      |

## Command Mode

- /exec

# show logging level session-mgr

show logging level session-mgr

## Syntax Description

|             |  |
|-------------|--|
| show        | Show running system information                    |
| logging     | Show logging configuration and contents of logfile |
| level       | Show facility logging configuration                |
| session-mgr | Show session-mgr logging configurarion             |

## Command Mode

- /exec

# show logging level sflow

show logging level sflow

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| sflow   | Show sFlow logging configuration                   |

## Command Mode

- /exec

# show logging level smm

show logging level smm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| smm     | Show Shared Memory Manager logging configuration   |

## Command Mode

- /exec

# show logging level snmpd

show logging level snmpd

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| snmpd   | Show SNMP logging configuration                    |

## Command Mode

- /exec

# show logging level snmpmib\_proc

show logging level snmpmib\_proc

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| level        | Show facility logging configuration                |
| snmpmib_proc | Show snmpmib_proc logging configuration            |

## Command Mode

- /exec

# show logging level spanning-tree

show logging level spanning-tree

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information                    |
| logging       | Show logging configuration and contents of logfile |
| level         | Show facility logging configuration                |
| spanning-tree | Show spanning-tree logging configuration           |

## Command Mode

- /exec

# show logging level spm

show logging level spm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| spm     | Show spm logging configuration                     |

## Command Mode

- /exec



# show logging level stripcl

show logging level stripcl

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| stripcl | Show stripcl logging configuration                 |

## Command Mode

- /exec

# show logging level sync

show logging level sync

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| sync    | Show sync logging configuration                    |

## Command Mode

- /exec

# show logging level sysmgr

show logging level sysmgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| sysmgr  | Show sysmgr logging configuration                  |

## Command Mode

- /exec

# show logging level tacacs

show logging level tacacs

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| tacacs  | Show tacacs+ logging configuration                 |

## Command Mode

- /exec

# show logging level telemetry

show logging level telemetry

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| telemetry | Show telemetry logging level                       |

## Command Mode

- /exec

# show logging level template\_manager

show logging level template\_manager

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                    |
| logging          | Show logging configuration and contents of logfile |
| level            | Show facility logging configuration                |
| template_manager | Show template manager logging configuration        |

## Command Mode

- /exec

# show logging level track

show logging level track

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| track   | Show track logging configuration                   |

## Command Mode

- /exec

# show logging level tunnel-encryption

show logging level tunnel-encryption

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                      |
| logging           | Show logging configuration and contents of logfile   |
| level             | Show facility logging configuration                  |
| tunnel-encryption | Show tunnel encryption manager logging configuration |

## Command Mode

- /exec



# show logging level tunnel

show logging level tunnel

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| tunnel  | Show tunnel logging settings                       |

## Command Mode

- /exec

# show logging level u2rib

show logging level u2rib

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| u2rib   | Show U2RIB logging configuration                   |

## Command Mode

- /exec

# show logging level u6rib

show logging level u6rib

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| u6rib   | Show U6RIB logging configuration                   |

## Command Mode

- /exec

# show logging level udd

show logging level udd

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| udd     | Show udd logging configuration                     |

## Command Mode

- /exec

# show logging level ufdm

show logging level ufdm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| ufdm    | Show ufdm logging configuration                    |

## Command Mode

- /exec

# show logging level urib

show logging level urib

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| urib    | Show URIB logging configuration                    |

## Command Mode

- /exec

# show logging level vdc\_mgr

show logging level vdc\_mgr

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| vdc_mgr | Show vdc manager logging configuration             |

## Command Mode

- /exec

# show logging level virtual-service

show logging level virtual-service

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                    |
| logging         | Show logging configuration and contents of logfile |
| level           | Show facility logging configuration                |
| virtual-service | Show virtualization manager logging configuration  |

## Command Mode

- /exec



# show logging level vlan\_mgr

show logging level vlan\_mgr

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| vlan_mgr | Show vlan manager logging configuration            |

## Command Mode

- /exec

# show logging level vmm

show logging level vmm

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| vmm     | Show vmm logging configuration                     |

## Command Mode

- /exec

# show logging level vmtracker

show logging level vmtracker

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| level     | Show facility logging configuration                |
| vmtracker | Show vmtracker logging configuration               |

## Command Mode

- /exec

# show logging level vpc

show logging level vpc

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| vpc     | Show vPC logging configuration                     |

## Command Mode

- /exec

# show logging level vrrp-cfg

show logging level vrrp-cfg

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| vrrp-cfg | Show vrrp-cfg logging configuration                |

## Command Mode

- /exec

# show logging level vrrp-eng

show logging level vrrp-eng

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| level    | Show facility logging configuration                |
| vrrp-eng | Show vrrp-eng logging configuration                |

## Command Mode

- /exec

# show logging level vrrpv3

show logging level vrrpv3

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| vrrpv3  | level for vrrpv3 configuration                     |

## Command Mode

- /exec

# show logging level vsan

show logging level vsan

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| vsan    | Show vsan logging configuration                    |

## Command Mode

- /exec



# show logging level vshd

show logging level vshd

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level vtp

show logging level vtp

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| vtp     | Show vtp logging configuration                     |

## Command Mode

- /exec

# show logging level wwn

show logging level wwn

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |
| wwn     | Show wwn logging configuration                     |

## Command Mode

- /exec

# show logging level xbar

show logging level xbar

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging level zone

show logging level zone

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| level   | Show facility logging configuration                |

## Command Mode

- /exec

# show logging logfile

show logging logfile

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| logfile | Show contents of logfile                           |

## Command Mode

- /exec

# show logging logfile duration

show logging logfile duration <s1>

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                      |
| logging   | Show logging configuration and contents of logfile   |
| logfile   | Show contents of logfile                             |
| duration  | show messages from logfile of last given duration    |
| <i>s1</i> | Enter hour, minutes, seconds of duration as HH:MM:SS |

## Command Mode

- /exec

# show logging logfile last-index

show logging logfile last-index

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                         |
| logging    | Show logging configuration and contents of logfile      |
| logfile    | Show contents of logfile                                |
| last-index | Show the sequence-number of the last message in logfile |

## Command Mode

- /exec



# show logging logfile start-seqn

show logging logfile start-seqn <i0> [ end-seqn <i1> ]

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information  |
| logging    | Show logging configuration and contents of logfile                     |
| logfile    | Show contents of logfile   |
| start-seqn | Show messages from logfile from a given start-sequence-number          |
| <i>i0</i>  | Enter starting sequence number   |
| end-seqn   | (Optional) Show messages from logfile from a given end-sequence-number |
| <i>i1</i>  | (Optional) Enter ending sequence number                                |

## Command Mode

- /exec

## show logging logfile start-time

show logging logfile start-time <i0> <s0> <i1> <s1> [ end-time <i2> <s2> <i3> <s3> ]

### Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                                |
| logging    | Show logging configuration and contents of logfile             |
| logfile    | Show contents of logfile                                       |
| start-time | Show messages from logfile from a given start-time             |
| <i>i0</i>  | Enter year in YYYY format                                      |
| <i>s0</i>  | Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec            |
| <i>i1</i>  | Enter day of month in dd format                                |
| <i>s1</i>  | Enter hour, minutes, seconds as HH:MM:SS                       |
| end-time   | (Optional) Show messages from logfile up to a given end-time   |
| <i>i2</i>  | (Optional) Enter year in YYYY format                           |
| <i>s2</i>  | (Optional) Enter Month as Jan, Feb, Mar, ..., Oct, Nov, or Dec |
| <i>i3</i>  | (Optional) Enter day of month in dd format                     |
| <i>s3</i>  | (Optional) Enter hour, minutes, seconds as HH:MM:SS            |

### Command Mode

- /exec

# show logging loopback

show logging loopback

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information                    |
| logging  | Show logging configuration and contents of logfile |
| loopback | Show logging loopback configuration                |

## Command Mode

- /exec

# show logging module

show logging module

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| module  | Show module(linecard) logging configuration        |

## Command Mode

- /exec

# show logging monitor

show logging monitor

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| monitor | Show monitor logging configuration                 |

## Command Mode

- /exec

# show logging nvram

```
show logging nvram [ [ { last <i0> } ] [ __readonly__ [ <error> ] [ { TABLE_nvram <log> } ] ] ]
```

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| nvram        | Show NVRAM log                                     |
| last         | (Optional) Show last few lines of nvram log        |
| <i>i0</i>    | (Optional) Enter number of lines to display        |
| __readonly__ | (Optional)   |
| <i>error</i> | (Optional) error message                           |
| TABLE_nvram  | (Optional) nvram log prints                        |
| <i>log</i>   | (Optional) single log line                         |

## Command Mode

- /exec

## show logging onboard

```
show logging onboard [ card-first-power-on | card-boot-history | <common_options> | endtime <s0> [ {
<common_options> | error-stats [ port <i0> ] } ] | error-stats [ port1 <i1> ] | module <module> [
<common_options> | endtime1 <s1> [ { <common_options> | error-stats [ port3 <i3> ] } ] | error-stats [ port4
<i4> ] | starttime <s2> [ { <common_options> | endtime2 <s3> [ { <common_options> | error-stats [ port6
<i6> ] } ] | error-stats [ port7 <i7> ] } ] | card-first-power-on | card-boot-history ] | obfl-logs | starttime1 <s4>
[ { <common_options> | endtime3 <s5> [ { <common_options> | error-stats [ port8 <i8> ] } ] | error-stats [
port9 <i9> ] } ] | credit-loss [ module <module> [ last <last_no> { minutes | hours | days } ] | last <last_no>
{ minutes | hours | days } ] | flow-control { pause-count [ module <module> [ last <last_no> { minutes | hours
| days } ] | last <last_no> { minutes | hours | days } ] | pause-events [ module <module> [ last <last_no> {
minutes | hours | days } ] | last <last_no> { minutes | hours | days } ] | request-timeout [ module <module> ]
| timeout-drops [ module <module> [ port10 <i10> [ last <last_no> { minutes | hours | days } ] | last <last_no>
{ minutes | hours | days } ] | last <last_no> { minutes | hours | days } } ] }
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                           |
| logging               | Show logging configuration and contents of logfile        |
| onboard               | Show OBFL information                                     |
| card-first-power-on   | (Optional) show card first power on information           |
| card-boot-history     | (Optional) show card boot history                         |
| endtime               | (Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS |
| <i>s0</i>             | (Optional) End time format - mm/dd/yy-HH:MM:SS            |
| error-stats           | (Optional) Show OBFL error statistics                     |
| port                  | (Optional) Show OBFL error statistics for a port          |
| <i>i0</i>             | (Optional)  |
| <i>common_options</i> | (Optional) give the options                               |
| port1                 | (Optional) Show OBFL error statistics for a port          |
| <i>i1</i>             | (Optional)  |
| module                | (Optional) Show OBFL information for Module               |
| <i>module</i>         | (Optional) Enter module number                            |
| endtime1              | (Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS |
| <i>s1</i>             | (Optional) End time format - mm/dd/yy-HH:MM:SS            |
| port3                 | (Optional) Show OBFL error statistics for a port          |
| <i>i3</i>             | (Optional)  |

|                 |   |
|-----------------|---|
| port4           | (Optional) Show OBFL error statistics for a port            |
| <i>i4</i>       | (Optional)  |
| starttime       | (Optional) Show OBFL logs from start time mm/dd/yy-HH:MM:SS |
| <i>s2</i>       | (Optional) Start time format - mm/dd/yy-HH:MM:SS            |
| endtime2        | (Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS   |
| <i>s3</i>       | (Optional) End time format - mm/dd/yy-HH:MM:SS              |
| port6           | (Optional) Show OBFL error statistics for a port            |
| <i>i6</i>       | (Optional)  |
| port7           | (Optional) Show OBFL error statistics for a port            |
| <i>i7</i>       | (Optional)  |
| starttime1      | (Optional) Show OBFL logs from start time mm/dd/yy-HH:MM:SS |
| <i>s4</i>       | (Optional) Start time format - mm/dd/yy-HH:MM:SS            |
| endtime3        | (Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS   |
| <i>s5</i>       | (Optional) End time format - mm/dd/yy-HH:MM:SS              |
| port8           | (Optional) Show OBFL error statistics for a port            |
| <i>i8</i>       | (Optional)  |
| port9           | (Optional) Show OBFL error statistics for a port            |
| <i>i9</i>       | (Optional)  |
| obfl-logs       | (Optional) Show OBFL Tech Support Log.                      |
| timeout-drops   | (Optional) Show OBFL Timeout Drops logs                     |
| port10          | (Optional) Show OBFL statistics per port basis              |
| <i>i10</i>      | (Optional)  |
| credit-loss     | (Optional) Show OBFL Credit Loss logs                       |
| last            | (Optional) Show last min/hour/day logs                      |
| <i>last_no</i>  | (Optional) Duration in min/hrs/day                          |
| minutes         | (Optional) entry in minutes                                 |
| hours           | (Optional) entry in hours                                   |
| days            | (Optional) entry in days                                    |
| request-timeout | (Optional) Show OBFL request timeout log                    |



|              |   |
|--------------|---|
| flow-control | (Optional) Show OBFL Flow Control log         |
| pause-count  | (Optional) Show Flow Control Pause Count Logs |
| pause-events | (Optional) Show Flow Control Pause Event Logs |

**Command Mode**

- /exec

# show logging onboard

```
show logging onboard { counter-stats | endtime <s0> [ { counter-stats | internal { <dc3_options> } } ] | internal
{ <dc3_options> } | module <module> { counter-stats | endtime1 <s1> [ { counter-stats | internal {
<dc3_options> } } ] | internal { <dc3_options> } | starttime <s2> [ { counter-stats | endtime2 <s3> [ {
counter-stats | internal { <dc3_options> } } ] | internal { <dc3_options> } } ] | starttime1 <s4> [ { counter-stats
| endtime3 <s5> [ { counter-stats | internal { <dc3_options> } } ] | internal { <dc3_options> } } ] }
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                           |
| logging            | Show logging configuration and contents of logfile        |
| onboard            | Show OBFL information                                     |
| counter-stats      | Show OBFL counter statistics                              |
| endtime            | Show OBFL logs till end time mm/dd/yy-HH:MM:SS            |
| <i>s0</i>          | End time format - mm/dd/yy-HH:MM:SS                       |
| internal           | (Optional) Show Logging Onboard Internal                  |
| module             | Show OBFL information for Module                          |
| <i>module</i>      | Enter module number                                       |
| endtime1           | Show OBFL logs till end time mm/dd/yy-HH:MM:SS            |
| <i>s1</i>          | End time format - mm/dd/yy-HH:MM:SS                       |
| starttime          | Show OBFL logs from start time mm/dd/yy-HH:MM:SS          |
| <i>s2</i>          | Start time format - mm/dd/yy-HH:MM:SS                     |
| endtime2           | (Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS |
| <i>s3</i>          | (Optional) End time format - mm/dd/yy-HH:MM:SS            |
| starttime1         | Show OBFL logs from start time mm/dd/yy-HH:MM:SS          |
| <i>s4</i>          | Start time format - mm/dd/yy-HH:MM:SS                     |
| endtime3           | (Optional) Show OBFL logs till end time mm/dd/yy-HH:MM:SS |
| <i>s5</i>          | (Optional) End time format - mm/dd/yy-HH:MM:SS            |
| <i>dc3_options</i> | (Optional) dc3 options                                    |

## Command Mode

- /exec

# show logging onboard kernel-trace

show logging onboard kernel-trace

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| onboard      | Show OBFL information                              |
| kernel-trace | Show OBFL Kernel Trace                             |

## Command Mode

- /exec

# show logging origin-id

show logging origin-id

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| origin-id | Show logging origin id configuration               |

## Command Mode

- /exec

# show logging pending-diff

show logging pending-diff

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| logging      | Show logging configuration and contents of logfile |
| pending-diff | server address pending configuration diff          |

## Command Mode

- /exec

# show logging pending

show logging pending

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| pending | server address pending configuration               |

## Command Mode

- /exec

# show logging rate-limit

show logging rate-limit

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| rate-limit | Show rate limit configuration                      |

## Command Mode

- /exec

# show logging rfc-strict

show logging rfc-strict

## Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                    |
| logging    | Show logging configuration and contents of logfile |
| rfc-strict | Show RFC to which messages are compliant           |

## Command Mode

- /exec



# show logging server

```
show logging server [ __readonly__ [ <server_status> ] [ { TABLE_logserv <server> <forwarding> <severity>
<facility> <vrf> <port> [ <transport> ] } ] ]
```

## Syntax Description

|                            |  |
|----------------------------|--|
| <code>show</code>          | Show running system information                    |
| <code>logging</code>       | Show logging configuration and contents of logfile |
| <code>server</code>        | Show server logging configuration                  |
| <code>__readonly__</code>  | (Optional)   |
| <code>server_status</code> | (Optional) logging server configured               |
| <code>TABLE_logserv</code> | (Optional) output of show logging server           |
| <code>server</code>        | (Optional) remote server address                   |
| <code>forwarding</code>    | (Optional) remote server forwarding                |
| <code>severity</code>      | (Optional) remote server severity                  |
| <code>facility</code>      | (Optional) remote server facility                  |
| <code>vrf</code>           | (Optional) remote server vrf                       |
| <code>port</code>          | (Optional) remote server port                      |
| <code>transport</code>     | (Optional) remote server transport                 |

## Command Mode

- /exec

# show logging session status

show logging session status

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| session | Show logging session status                        |
| status  | Show logging session status                        |

## Command Mode

- /exec

# show logging source-interface

show logging source-interface

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                    |
| logging          | Show logging configuration and contents of logfile |
| source-interface | Show logging source-interface configuration        |

## Command Mode

- /exec

# show logging status

show logging status

## Syntax Description

|         |  |
|---------|--|
| show    | Show running system information                    |
| logging | Show logging configuration and contents of logfile |
| status  | Show logging status                                |

## Command Mode

- /exec

# show logging timestamp

show logging timestamp

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                    |
| logging   | Show logging configuration and contents of logfile |
| timestamp | Show logging timestamp configuration               |

## Command Mode

- /exec

# show login on-failure log

show login on-failure log [ \_\_readonly\_\_ [ <status> ] ]

## Syntax Description

|               |   |
|---------------|---|
| show          | show  |
| login         | login   |
| on-failure    | authentication failure                              |
| log           | Log   |
| __readonly__  | (Optional)  |
| <i>status</i> | (Optional) login on failure log enabled or disabled |

## Command Mode

- /exec

# show login on-successful log

show login on-successful log [ \_\_readonly\_\_ [ <status> ] ]

## Syntax Description

|               |  |
|---------------|--|
| show          | show   |
| login         | login  |
| on-successful | authentication successful                              |
| log           | Log  |
| __readonly__  | (Optional)   |
| <i>status</i> | (Optional) login on successful log enabled or disabled |

## Command Mode

- /exec

**show login on-successful log**





## M Show Commands

---

- [show mac-list](#), on page 2101
- [show mac address-table](#), on page 2102
- [show mac address-table](#), on page 2104
- [show mac address-table aging-time](#), on page 2106
- [show mac address-table count](#), on page 2107
- [show mac address-table count es](#), on page 2109
- [show mac address-table limit](#), on page 2110
- [show mac address-table limit user-defined](#), on page 2111
- [show mac address-table loop-detect](#), on page 2112
- [show mac address-table multicast](#), on page 2113
- [show mac address-table notification mac-move](#), on page 2114
- [show macsec mka](#), on page 2115
- [show macsec mka session](#), on page 2116
- [show macsec mka statistics](#), on page 2119
- [show macsec policy](#), on page 2124
- [show macsec secy statistics](#), on page 2125
- [show maintenance maint-delay](#), on page 2129
- [show maintenance on-reload reset-reasons](#), on page 2130
- [show maintenance profile](#), on page 2131
- [show maintenance snapshot-delay](#), on page 2132
- [show maintenance timeout](#), on page 2133
- [show mcast](#), on page 2134
- [show module](#), on page 2135
- [show module bandwidth-fairness](#), on page 2138
- [show module port type](#), on page 2139
- [show module uptime](#), on page 2140
- [show monitor](#), on page 2141
- [show monitor session](#), on page 2142
- [show mpls extended-ecmp](#), on page 2145
- [show mpls forwarding statistics](#), on page 2146
- [show mpls interfaces](#), on page 2148
- [show mpls interfaces detail](#), on page 2149
- [show mpls interfaces statistics](#), on page 2150

- [show mpls ip bindings](#), on page 2151
- [show mpls ip bindings summary](#), on page 2154
- [show mpls ip ttl](#), on page 2155
- [show mpls label range](#), on page 2156
- [show mpls load-sharing](#), on page 2157
- [show mpls oam echo statistics](#), on page 2158
- [show mpls static binding](#), on page 2160
- [show mpls strip labels](#), on page 2162
- [show mpls switching](#), on page 2163
- [show mpls switching clients](#), on page 2167
- [show mvpn bgp mdt](#), on page 2169
- [show mvpn bgp mdt](#), on page 2170
- [show mvpn mdt encap](#), on page 2171
- [show mvpn mdt encap](#), on page 2172
- [show mvpn mdt route](#), on page 2173
- [show mvpn mdt route](#), on page 2174
- [show mvr](#), on page 2175
- [show mvr groups](#), on page 2176
- [show mvr interface](#), on page 2177
- [show mvr members](#), on page 2178
- [show mvr members count](#), on page 2179
- [show mvr members vlan](#), on page 2180
- [show mvr receiver-ports](#), on page 2181
- [show mvr source-ports](#), on page 2182

## show mac-list

```
show mac-list { [ { <maclist-name> | <maclist-cfg-name> } [ { seq <seq_no> | { <mac_addr> [ <mac_mask> ] } } ] ] } [ __readonly__ TABLE_mac_list <name> <seq> <action> <rule> ]
```

### Syntax Description

|                         |                                 |
|-------------------------|---------------------------------|
| show                    | Show running system information |
| mac-list                | Show mac-lists                  |
| <i>maclist-name</i>     | (Optional) Name of mac-list     |
| <i>maclist-cfg-name</i> | (Optional) Known mac-list name  |
| seq                     | (Optional) Sequence number      |
| <i>seq_no</i>           | (Optional) Sequence number      |
| <i>mac_addr</i>         | (Optional) MAC address          |
| <i>mac_mask</i>         | (Optional) MAC mask             |
| <i>__readonly__</i>     | (Optional)                      |
| TABLE_mac_list          | (Optional)                      |
| <i>name</i>             | (Optional)                      |
| <i>seq</i>              | (Optional)                      |
| <i>action</i>           | (Optional)                      |
| <i>rule</i>             | (Optional)                      |

### Command Mode

- /exec

## show mac address-table

```
show mac address-table <module> [ count ] [ static | dynamic | secure ] [ { [ address1 <mac-addr> | { switch-id
<swid> [ sub-switch-id <sswid> ] } | vlan1 <id> | [ vdc1 <vdc> | <e-vdc> ] | fe1 <feid> ] + } | { [ address
<mac-addr> | interface <interface-name> | vlan <id> | [ vdc <vdc> | <e-vdc> ] | fe <feid> ] + } } [ hex ] [
__readonly__ <entrycount> <l2entry> <header> <pi_e> <age> <rm> <ifname> <sec> <ntfy> <type> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | show                                      |
| mac                   | MAC configuration commands                |
| address-table         | MAC Address Table                         |
| <i>module</i>         | Module Number                             |
| count                 | (Optional) Number of entries              |
| static                | (Optional) Display Static Entries         |
| dynamic               | (Optional) Display Dynamic Entries        |
| secure                | (Optional) Display Secure Entries         |
| address               | (Optional) address                        |
| address1              | (Optional) address                        |
| <i>mac-addr</i>       | (Optional) MAC Address                    |
| switch-id             | (Optional) Remote Switch ID               |
| <i>swid</i>           | (Optional) Switch ID                      |
| sub-switch-id         | (Optional) Remote Sub Switch ID           |
| <i>sswid</i>          | (Optional) Sub Switch ID                  |
| interface             | (Optional) Interface                      |
| <i>interface-name</i> | (Optional) Interface name                 |
| vlan                  | (Optional) VLAN                           |
| vlan1                 | (Optional) VLAN                           |
| <i>id</i>             | (Optional) VLAN ID                        |
| vdc                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| vdc1                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>vdc</i>            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

|                     |   |
|---------------------|---|
| <i>e-vdc</i>        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>fe</i>           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>fel</i>          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>feid</i>         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>hex</i>          | (Optional) display swid/sswid/lid in hex  |
| <i>__readonly__</i> | (Optional)                                |
| <i>header</i>       | (Optional) Header                         |
| <i>pi_e</i>         | (Optional) Primary Interface of EARL      |
| <i>age</i>          | (Optional) Last seen age in seconds       |
| <i>rm</i>           | (Optional) RM                             |
| <i>ifname</i>       | (Optional) interface name as string       |
| <i>sec</i>          | (Optional) secure                         |
| <i>ntfy</i>         | (Optional) notify                         |
| <i>entrycount</i>   | (Optional) Number of L2 entries           |
| <i>l2entry</i>      | (Optional) L2 Entry String                |
| <i>type</i>         | (Optional) MAC type - Static or Dynamic   |

**Command Mode**

- /exec

## show mac address-table

```
show mac address-table [ static | dynamic | secure ] [ local ] [ { [ address1 <mac-addr> | { switch-id <swid>
[ sub-switch-id <sswid> ] } | vlan1 <id> ] + } | { [ address <mac-addr> | interface <interface-name> | vlan
<id> ] + } | { [ address2 <mac-addr> | interface1 <interface-name> | vni <vni-id> | [ peer-ip <peer-ipv4> |
peer-ipv6 <peer-ipv6> ] ] + } | { [ address3 <mac-addr> | interface2 <interface-name> | vni1 <vni-id> | es {
<esid-opt1> | <esid-opt2> | all } ] + } ] [ __readonly__ [ { TABLE_mac_address
<disp_mac_addr><disp_type><disp_vlan> [ <disp_is_static> ]
<disp_age><disp_is_secure><disp_is_ntfy><disp_port> } ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | show  |
| mac                   | MAC configuration commands  |
| address-table         | MAC Address Table   |
| static                | (Optional) Display Static Entries   |
| dynamic               | (Optional) Display Dynamic Entries  |
| secure                | (Optional) Display Secure Entries   |
| local                 | (Optional) Display MAC Entries Learned Locally and Not on the Overlay/VXLAN |
| address               | (Optional) address  |
| address1              | (Optional) address  |
| address2              | (Optional) address  |
| address3              | (Optional) address  |
| <i>mac-addr</i>       | (Optional) MAC Address  |
| switch-id             | (Optional) Remote Switch ID   |
| <i>swid</i>           | (Optional) Switch ID  |
| sub-switch-id         | (Optional) Remote Sub Switch ID   |
| <i>sswid</i>          | (Optional) Sub Switch ID  |
| interface             | (Optional) Interface  |
| interface1            | (Optional) Interface  |
| <i>interface-name</i> | (Optional) Interface name   |
| interface2            | (Optional) Interface  |
| <i>interface-name</i> | (Optional) Interface name   |

|                   |  |
|-------------------|--|
| vlan              | (Optional) VLAN  |
| vlan1             | (Optional) VLAN  |
| id                | (Optional) VLAN ID                                     |
| vni               | (Optional) VXLAN Network Identifier                    |
| vni1              | (Optional) VXLAN Network Identifier                    |
| vni-id            | (Optional) VXLAN Network Identifier                    |
| peer-ip           | (Optional) VXLAN Peer IP Address                       |
| peer-ipv4         | (Optional) VXLAN Peer IP Address                       |
| peer-ipv6         | (Optional) VXLAN Peer IPv6 Address                     |
| es                | (Optional) EVPN Remote ESID                            |
| esid-opt1         | (Optional) EE:EE:EE:EE:EE:EE:EE:EE:EE:EE ESID Option 1 |
| esid-opt2         | (Optional) EEEE.EEEE.EEEE.EEEE.EEEE ESID Option 2      |
| all               | (Optional) all ESIs                                    |
| __readonly__      | (Optional)   |
| TABLE_mac_address | (Optional) Mac address table                           |
| disp_is_static    | (Optional) Static/Dynamic                              |

**Command Mode**

- /exec

## show mac address-table aging-time

show mac address-table aging-time [ *\_\_readonly\_\_* <age\_str> <age> ]

### Syntax Description

|                     |                            |
|---------------------|----------------------------|
| show                | show                       |
| mac                 | MAC configuration commands |
| address-table       | MAC Address Table          |
| aging-time          | Configured/default age     |
| <i>__readonly__</i> | (Optional)                 |
| <i>age_str</i>      | (Optional) Age info        |
| <i>age</i>          | (Optional) Age time        |

### Command Mode

- /exec



## show mac address-table count

```
show mac address-table count [ static | dynamic | secure ] [ local ] [ { [ interface <interface-name> | switch-id
<swid> [ sub-switch-id <sswid> ] } | vlan <id> ] + } | { [ interface1 <interface-name> | vni <vni-id> | [ peer-ip
<peer-ipv4> | peer-ipv6 <peer-ipv6> ] ] + } ] [ __readonly__ TABLE-macaddtblcount [ <id-out> ] [ <count_str>
] [ <dyn_cnt> ] [ <otv_cnt> ] [ <rvtep_static_cnt> ] [ <static_cnt> ] [ <secure_cnt> ] [ <total_cnt> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | show  |
| mac                   | MAC configuration commands  |
| address-table         | MAC Address Table   |
| count                 | Number of MAC entries   |
| static                | (Optional) Display Static Entries   |
| dynamic               | (Optional) Display Dynamic Entries  |
| secure                | (Optional) Display Secure Entries   |
| local                 | (Optional) Display MAC Entries Learned Locally and Not on the Overlay/VXLAN |
| vlan                  | (Optional) VLAN   |
| <i>id</i>             | (Optional) VLAN ID  |
| interface             | (Optional) Interface  |
| interface1            | (Optional) Interface  |
| <i>interface-name</i> | (Optional) Interface name   |
| switch-id             | (Optional) Remote Switch ID   |
| <i>swid</i>           | (Optional) Switch ID  |
| sub-switch-id         | (Optional) Remote Sub Switch ID   |
| <i>sswid</i>          | (Optional) Sub Switch ID  |
| vni                   | (Optional) VXLAN Network Identifier   |
| <i>vni-id</i>         | (Optional) VXLAN Network Identifier   |
| peer-ip               | (Optional) VXLAN Peer IP Address  |
| <i>peer-ipv4</i>      | (Optional) VXLAN Peer IP Address  |
| peer-ipv6             | (Optional) VXLAN Peer IPv6 Address  |
| <i>__readonly__</i>   | (Optional)  |

|                         |  |
|-------------------------|--|
| TABLE-macaddtblcount    | (Optional) MAC Address Dynamic Count Table |
| <i>id-out</i>           | (Optional) MAC Address Table VLAN ID       |
| <i>count_str</i>        | (Optional) Count info                      |
| <i>total_cnt</i>        | (Optional) Total count                     |
| <i>dyn_cnt</i>          | (Optional) Dynamic count                   |
| <i>otv_cnt</i>          | (Optional) OTV count                       |
| <i>static_cnt</i>       | (Optional) Static count                    |
| <i>rvtep_static_cnt</i> | (Optional) RVTEP Static count              |
| <i>secure_cnt</i>       | (Optional) Secure count                    |

**Command Mode**

- /exec

## show mac address-table count es

```
show mac address-table count es { <es-id> | <es-id2> | all } [ __readonly__ { [ <es-id> ] [ <count> ] [
TABLE_macaddtblcount <es-idx> <es-count> ] } ]
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | show   |
| mac                  | MAC configuration commands                             |
| address-table        | MAC Address Table                                      |
| count                | Number of MAC entries                                  |
| es                   | EVPN Remote ESID                                       |
| <i>es-id</i>         | EE:EE:EE:EE:EE:EE:EE:EE:EE:EE ESID                     |
| <i>es-id2</i>        | EEEE.EEEE.EEEE.EEEE.EEEE ESID                          |
| all                  | all ESIs   |
| __readonly__         | (Optional)   |
| <i>es-id</i>         | (Optional) Specific ESID                               |
| <i>count</i>         | (Optional) Number of entries for specific ESID         |
| TABLE_macaddtblcount | (Optional) Display all ESID and its count in mac table |
| <i>es-idx</i>        | (Optional) ESID  |
| <i>es-count</i>      | (Optional) Number of entries                           |

### Command Mode

- /exec

## show mac address-table limit

show mac address-table limit { all | system | vlan | interface } [ \_\_readonly\_\_ <limit\_str> <limit> ]

### Syntax Description

|                  |                              |
|------------------|------------------------------|
| show             | show                         |
| mac              | MAC configuration commands   |
| address-table    | MAC Address Table            |
| limit            | Configured/default mac limit |
| __readonly__     | (Optional)                   |
| <i>limit_str</i> | (Optional) Limit info        |
| <i>limit</i>     | (Optional) Mac limit         |
| all              | Display Mac Limit All        |
| system           | System-wide                  |
| vlan             | VLAN                         |
| interface        | Interface                    |

### Command Mode

- /exec

## show mac address-table limit user-defined

show mac address-table limit user-defined [ *\_\_readonly\_\_* <*user\_cnt*> <*fhrp\_cnt*> ]

### Syntax Description

|                     |   |
|---------------------|---|
| show                | show  |
| mac                 | MAC configuration commands  |
| address-table       | MAC Address Table   |
| limit               | mac limit   |
| user-defined        | limit the number of unique mac addresses used on any type of L3 interface |
| <i>__readonly__</i> | (Optional)  |
| <i>user_cnt</i>     | (Optional) user defined mac limit   |
| <i>fhrp_cnt</i>     | (Optional) fhrp limit   |

### Command Mode

- /exec

# show mac address-table loop-detect

show mac address-table loop-detect [ \_\_readonly\_\_ <port\_loop\_detect> ]

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | show   |
| mac                     | MAC configuration commands   |
| address-table           | MAC  |
| loop-detect             | Display Action for Mac Loop Detection                                      |
| __readonly__            | (Optional)   |
| <i>port_loop_detect</i> | (Optional) Display Port Down Action Mac Loop Detect is enabled or disabled |

## Command Mode

- /exec

## show mac address-table multicast

```
show mac address-table multicast [ vlan <vlan> | bridge-domain <bdid> ] [ __readonly__ [ TABLE_mac [
<vlan-id> ] [ <mac-addr> ] [ <type> ] [ <age> ] [ TABLE_oif [ <oifs> ] ] ] ] ]
```

### Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| mac                 | MAC configuration commands      |
| address-table       | MAC Address Table               |
| multicast           | mcast mac OIF Static Entry      |
| vlan                | (Optional) VLAN                 |
| <i>vlan</i>         | (Optional) VLAN                 |
| bridge-domain       | (Optional) BD                   |
| <i>bdid</i>         | (Optional) BD                   |
| <i>__readonly__</i> | (Optional)                      |
| TABLE_mac           | (Optional)                      |
| <i>vlan-id</i>      | (Optional)                      |
| <i>mac-addr</i>     | (Optional)                      |
| <i>type</i>         | (Optional)                      |
| <i>age</i>          | (Optional)                      |
| TABLE_oif           | (Optional)                      |
| <i>oifs</i>         | (Optional)                      |

### Command Mode

- /exec

## show mac address-table notification mac-move

```
show mac address-table notification mac-move [ __readonly__ TABLE_mac_notif <disp_mm_status>
<disp_mm_triggers> <disp_macs_added> <disp_macs_moved> <disp_macs_moved_border>
<disp_macs_removed> ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | show   |
| mac                           | MAC configuration commands                                   |
| address-table                 | MAC Address Table  |
| notification                  | Display Notification Information                             |
| mac-move                      | Mac Move Notification  |
| <i>__readonly__</i>           | (Optional) Read Only   |
| <i>TABLE_mac_notif</i>        | (Optional) Mac address notification table                    |
| <i>disp_mm_status</i>         | (Optional) Mac Move Status                                   |
| <i>disp_mm_triggers</i>       | (Optional) # of triggers                                     |
| <i>disp_macs_added</i>        | (Optional) Number of MACs added since system bring up        |
| <i>disp_macs_removed</i>      | (Optional) Number of MACs removed since system bring up      |
| <i>disp_macs_moved</i>        | (Optional) Number of MACs moved since system bring up        |
| <i>disp_macs_moved_border</i> | (Optional) Number of MACs moved border since system bring up |

### Command Mode

- /exec



## show macsec mka

```
show macsec mka [ summary ] [ __readonly__ [ <macsec_status> ] [ TABLE_mka_summary <ifname>
<status> <cipher> <keyserver> <policy> <keychain> <fallback_keychain> ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                   |
| macsec                   | Show MACSEC information                           |
| mka                      | Show MKA information                              |
| summary                  | (Optional) Show MKA summary information           |
| __readonly__             | (Optional)  |
| <i>macsec_status</i>     | (Optional) Macsec status                          |
| TABLE_mka_summary        | (Optional)  |
| <i>ifname</i>            | (Optional) Interface                              |
| <i>status</i>            | (Optional) MACSEC Session status                  |
| <i>cipher</i>            | (Optional) Operational MACSEC Cipher-suite        |
| <i>keyserver</i>         | (Optional) Is this acting as interface key-server |
| <i>policy</i>            | (Optional) MACSEC Policy applied to interface     |
| <i>keychain</i>          | (Optional) Keychain associated with interface     |
| <i>fallback_keychain</i> | (Optional) Keychain associated with interface     |

### Command Mode

- /exec



|                                |   |
|--------------------------------|---|
| <i>status</i>                  | (Optional) Session Status                     |
| <i>sci</i>                     | (Optional) Interface local TxSCI              |
| <i>ssci</i>                    | (Optional) Interface local TxSSCI             |
| <i>port_id</i>                 | (Optional) MKA Port Identifier                |
| <i>ckn</i>                     | (Optional) CAK Name                           |
| <i>mi</i>                      | (Optional) Member Identifier                  |
| <i>mn</i>                      | (Optional) Message Number                     |
| <i>policy</i>                  | (Optional) MACSEC Policy                      |
| <i>ks_prio</i>                 | (Optional) Key-server Priority                |
| <i>cipher</i>                  | (Optional) MKA Cipher Suite                   |
| <i>cipher_operational</i>      | (Optional) MKA Cipher Suite Operational       |
| <i>window</i>                  | (Optional) Replay Window Size                 |
| <i>conf_offset</i>             | (Optional) Confidentiality Offset             |
| <i>conf_offset_operational</i> | (Optional) Confidentiality Offset Operational |
| <i>sak_status</i>              | (Optional) SAK Status                         |
| <i>sak_an</i>                  | (Optional) SAK AN                             |
| <i>sak_ki</i>                  | (Optional) SAK KI                             |
| <i>sak_kn</i>                  | (Optional) SAK KN                             |
| <i>last_sak_rekey_time</i>     | (Optional) Last SAK rekey                     |
| <i>peer_count</i>              | (Optional) Peer Count                         |
| <i>mac_addr</i>                | (Optional) Eapol Dest mac                     |
| <i>ether_type</i>              | (Optional) Eapol ether type                   |
| TABLE_mka_peer_status          | (Optional)                                    |
| <i>peer_mi</i>                 | (Optional) Peer MI                            |
| <i>rxsci</i>                   | (Optional) RxSCI                              |
| <i>icv_status</i>              | (Optional) Peer CAK                           |
| <i>last_rx_time</i>            | (Optional) Latest Rx MKPDU                    |
| TABLE_mka_fallback             | (Optional)                                    |
| <i>fallback_ckn</i>            | (Optional) Fallback CAK Name                  |

|                              |                                       |
|------------------------------|---------------------------------------|
| <i>fallback_mi</i>           | (Optional) Fallback Member Identifier |
| <i>fallback_mn</i>           | (Optional) Fallback Message Number    |
| TABLE_mka_fallback_peer      | (Optional)                            |
| <i>fallback_peer_mi</i>      | (Optional) Peer MI                    |
| <i>fallback_rxsci</i>        | (Optional) RxSCI                      |
| <i>fallback_icv_status</i>   | (Optional) Peer CAK                   |
| <i>fallback_last_rx_time</i> | (Optional) Latest Rx MKPDU            |
| <i>sessions</i>              | (Optional) Total number of Sessions   |
| <i>active_sessions</i>       | (Optional) Count of Active Sessions   |
| <i>pending_sessions</i>      | (Optional) Count of Pending Sessions  |

**Command Mode**

- /exec

# show macsec mka statistics

```
show macsec mka statistics [ interface <ifname> ] [ __readonly__ [ <macsec_status> ] [ TABLE_mka_intf_stats
[ [ <ifname2> ] [ TABLE_ca_stats [ [ <ca_stat_ckn> ] [ <ca_stat_pairwise_cak_rekey> ] [
<sa_stat_sak_generated> ] [ <sa_stat_sak_rekey> ] [ <sa_stat_sak_received> ] [ <sa_stat_sak_response_rx>
] [ <mkpdu_stat_mkpdu_tx> ] [ <mkpdu_stat_mkpdu_tx_distsak> ] [ <mkpdu_stat_mkpdu_rx> ] [
<mkpdu_stat_mkpdu_rx_distsak> ] ] ] ] [ TABLE_idb_stats [ [ <ca_stat_pairwise_cak_rekey> ] [
<sa_stat_sak_generated> ] [ <sa_stat_sak_rekey> ] [ <sa_stat_sak_received> ] [ <sa_stat_sak_response_rx>
] [ <mkpdu_stat_mkpdu_tx> ] [ <mkpdu_stat_mkpdu_tx_distsak> ] [ <mkpdu_stat_mkpdu_rx> ] [
<mkpdu_stat_mkpdu_rx_distsak> ] [ <idb_stat_mkpdu_tx_success> ] [ <idb_stat_mkpdu_tx_fail> ] [
<idb_stat_mkpdu_tx_pkt_build_fail> ] [ <idb_stat_mkpdu_no_tx_on_intf_down> ] [
<idb_stat_mkpdu_no_rx_on_intf_down> ] [ <idb_stat_mkpdu_rx_ca_notfound> ] [ <idb_stat_mkpdu_rx_error>
] [ <idb_stat_mkpdu_rx_success> ] [ <idb_stat_mkpdu_failure_rx_integrity_check_error> ] [
<idb_stat_mkpdu_failure_invalid_peer_mn_error> ] [ <idb_stat_mkpdu_failure_nonrecent_peerlist_mn_error>
] [ <idb_stat_mkpdu_failure_sakuse_kn_mismatch_error> ] [
<idb_stat_mkpdu_failure_sakuse_rx_not_set_error> ] [
<idb_stat_mkpdu_failure_sakuse_key_mi_mismatch_error> ] [
<idb_stat_mkpdu_failure_sakuse_an_not_in_use_error> ] [
<idb_stat_mkpdu_failure_sakuse_ks_rx_tx_not_set_error> ] [
<idb_stat_mkpdu_failure_sakuse_eapol_ethertype_mismatch_error> ] [
<idb_stat_mkpdu_failure_sakuse_eapol_destmac_mismatch_error> ] [
<idb_stat_sak_failure_sak_generate_error> ] [ <idb_stat_sak_failure_hash_generate_error> ] [
<idb_stat_sak_failure_sak_encryption_error> ] [ <idb_stat_sak_failure_sak_decryption_error> ] [
<idb_stat_sak_failure_ick_derivation_error> ] [ <idb_stat_sak_failure_kek_derivation_error> ] [
<idb_stat_sak_failure_invalid_macsec_capability_error> ] [ <idb_stat_macsec_failure_rx_sa_create_error>
] [ <idb_stat_macsec_failure_tx_sa_create_error> ] ] ] ] [ TABLE_mka_gbl_stats [ [ <session_secured> ] [
<session_deleted> ] [ <session_keeplive_timeout> ] [ <ca_stat_pairwise_cak_rekey> ] [
<sa_stat_sak_generated> ] [ <sa_stat_sak_rekey> ] [ <sa_stat_sak_received> ] [ <sa_stat_sak_response_rx>
] [ <mkpdu_stat_mkpdu_rx> ] [ <mkpdu_stat_mkpdu_rx_distsak> ] [ <mkpdu_stat_mkpdu_tx> ] [
<mkpdu_stat_mkpdu_tx_distsak> ] [ <mka_error_session_failure_bring_up_error> ] [
<mka_error_sak_failure_sak_generate_error> ] [ <mka_error_sak_failure_hash_generate_error> ] [
<mka_error_sak_failure_sak_encryption_error> ] [ <mka_error_sak_failure_sak_decryption_error> ] [
<mka_error_sak_failure_sak_cipher_mismatch_error> ] [ <mka_error_ca_failure_ick_derivation_error> ] [
<mka_error_ca_failure_kek_derivation_error> ] [ <mka_error_ca_failure_invalid_macsec_capability_error>
] [ <mka_error_macsec_failure_rx_sa_create_error> ] [ <mka_error_macsec_failure_tx_sa_create_error> ] [
<mka_error_mkpdu_failure_mkpdu_tx_error> ] [
<mka_error_mkpdu_failure_mkpdu_rx_integrity_check_error> ] [
<mka_error_mkpdu_failure_mkpdu_invalid_peer_mn_error> ] [
<mka_error_mkpdu_failure_mkpdu_nonrecent_peerlist_mn_error> ] [
<mka_error_mkpdu_failure_sakuse_kn_mismatch_error> ] [
<mka_error_mkpdu_failure_sakuse_rx_not_set_error> ] [
<mka_error_mkpdu_failure_sakuse_key_mi_mismatch_error> ] [
<mka_error_mkpdu_failure_sakuse_an_not_in_use_error> ] [
<mka_error_mkpdu_failure_sakuse_ks_rx_tx_not_set_error> ] [ <global_stats_mkpdu_rx_invalid_ckn> ] [
<global_stats_mkpdu_tx_pkt_build_fail> ] ] ] ] ]
```

### Syntax Description

|        |                                 |
|--------|---------------------------------|
| show   | Show running system information |
| macsec | Show MACSEC information         |

|                                    |  |
|------------------------------------|--|
| mka                                | Show MKA information                                 |
| statistics                         | Show MKA statistics                                  |
| interface                          | (Optional) Specify interface                         |
| <i>ifname</i>                      | (Optional) Interface list                            |
| <i>__readonly__</i>                | (Optional)   |
| <i>macsec_status</i>               | (Optional) Macsec status                             |
| TABLE_mka_intf_stats               | (Optional) MKA Interface statistics                  |
| TABLE_ca_stats                     | (Optional) CA Statistics                             |
| <i>ca_stat_ckn</i>                 | (Optional) CA Statistics CKN                         |
| <i>ca_stat_pairwise_cak_rekey</i>  | (Optional) CA Statistics Pairwise CAK Rekey          |
| <i>sa_stat_sak_generated</i>       | (Optional) SA Statistics SAK generated               |
| <i>sa_stat_sak_rekey</i>           | (Optional) SA Statistics SAK rekey                   |
| <i>sa_stat_sak_received</i>        | (Optional) SA Statistics SAK received                |
| <i>sa_stat_sak_response_rx</i>     | (Optional) SA Statistics SAK response received       |
| <i>mkpdu_stat_mkpdu_tx</i>         | (Optional) MKPDU Statistics MKPDU Tx                 |
| <i>mkpdu_stat_mkpdu_tx_distsak</i> | (Optional) MKPDU Statistics MKPDU Tx distributed SAK |
| <i>mkpdu_stat_mkpdu_rx</i>         | (Optional) MKPDU Statistics MKPDU Rx                 |
| <i>mkpdu_stat_mkpdu_rx_distsak</i> | (Optional) MKPDU Statistics MKPDU Rx distributed SAK |
| TABLE_idb_stats                    | (Optional) IDB Statistics                            |
| <i>ca_stat_pairwise_cak_rekey</i>  | (Optional) CA Statistics pairwise CAK rekey          |
| <i>sa_stat_sak_generated</i>       | (Optional) SA Statistics SAK generated               |
| <i>sa_stat_sak_rekey</i>           | (Optional) SA Statistics SAK rekey                   |
| <i>sa_stat_sak_received</i>        | (Optional) SA Statistics SAK received                |
| <i>sa_stat_sak_response_rx</i>     | (Optional) SA Statistics SAK response received       |
| <i>mkpdu_stat_mkpdu_tx</i>         | (Optional) MKPDU Statistics MKPDU Tx                 |
| <i>mkpdu_stat_mkpdu_tx_distsak</i> | (Optional) MKPDU Statistics MKPDU Tx distributed SAK |
| <i>mkpdu_stat_mkpdu_rx</i>         | (Optional) MKPDU Statistics MKPDU Rx                 |
| <i>mkpdu_stat_mkpdu_rx_distsak</i> | (Optional) MKPDU Statistics MKPDU Rx distributed SAK |
| <i>idb_stat_mkpdu_tx_success</i>   | (Optional) IDB Statistics MKPDU Tx success           |

|  |   |
|--|---|
| <i>idb_stat_mkpdu_tx_fail</i>                                      | (Optional) IDB Statistics MKPDU Tx fail   |
| <i>idb_stat_mkpdu_tx_pkt_build_fail</i>                            | (Optional) IDB Statistics MKPDU Tx packet build fail                              |
| <i>idb_stat_mkpdu_no_tx_on_intf_down</i>                           | (Optional) IDB Statistics MKPDU no Tx on interface down                           |
| <i>idb_stat_mkpdu_no_rx_on_intf_down</i>                           | (Optional) IDB Statistics MKPDU no Rx on interface down                           |
| <i>idb_stat_mkpdu_rx_ca_notfound</i>                               | (Optional) IDB Statistics MKPDU Rx CA not found                                   |
| <i>idb_stat_mkpdu_rx_error</i>                                     | (Optional) IDB Statistics MKPDU Rx error  |
| <i>idb_stat_mkpdu_rx_success</i>                                   | (Optional) IDB Statistics MKPDU Rx success  |
| <i>iclb_stat_mkpdu_failure_rx_integrity_check_error</i>            | (Optional) IDB Statistics - MKPDU failure - Rx integrity check error              |
| <i>iclb_stat_mkpdu_failure_invalid_peer_mn_error</i>               | (Optional) IDB Statistics - MKPDU failure - invalid peer MN error                 |
| <i>iclb_stat_mkpdu_failure_nonrecent_peerlist_mn_error</i>         | (Optional) IDB Statistics - MKPDU failure - non recent peerlist MN error          |
| <i>iclb_stat_mkpdu_failure_sakuse_kn_mismatch_error</i>            | (Optional) IDB Statistics - MKPDU failure - SAKuse KN mismatch error              |
| <i>iclb_stat_mkpdu_failure_sakuse_rx_not_set_error</i>             | (Optional) IDB Statistics - MKPDU failure - SAKuse Rx not set error               |
| <i>iclb_stat_mkpdu_failure_sakuse_key_mi_mismatch_error</i>        | (Optional) IDB Statistics - MKPDU failure - SAKuse key MI mismatch error          |
| <i>iclb_stat_mkpdu_failure_sakuse_an_not_in_use_error</i>          | (Optional) IDB Statistics - MKPDU failure - SAKuse AN not in use error            |
| <i>iclb_stat_mkpdu_failure_sakuse_ks_rx_tx_not_set_error</i>       | (Optional) IDB Statistics - MKPDU failure - SAKuse KS Rx Tx not set error         |
| <i>iclb_stat_mkpdu_failure_sakuse_eapol_etype_mismatch_error</i>   | (Optional) IDB Statistics - MKPDU failure - SAKuse EAPOL ethertype mismatch error |
| <i>iclb_stat_mkpdu_failure_sakuse_eapol_destmac_mismatch_error</i> | (Optional) IDB Statistics - MKPDU failure - SAKuse EAPOL destMAC mismatch error   |
| <i>idb_stat_sak_failure_sak_generate_error</i>                     | (Optional) IDB Statistics - SAK failure - SAK generate error                      |
| <i>idb_stat_sak_failure_hash_generate_error</i>                    | (Optional) IDB Statistics - SAK failure - Hash generate error                     |
| <i>idb_stat_sak_failure_sak_encryption_error</i>                   | (Optional) IDB Statistics - SAK failure - SAK encryption error                    |
| <i>idb_stat_sak_failure_sak_decryption_error</i>                   | (Optional) IDB Statistics - SAK failure - SAK decryption error                    |
| <i>idb_stat_sak_failure_ick_derivation_error</i>                   | (Optional) IDB Statistics - SAK failure - ICK derivation error                    |
| <i>idb_stat_sak_failure_kek_derivation_error</i>                   | (Optional) IDB Statistics - SAK failure - KEK derivation error                    |
| <i>idb_stat_sak_failure_invalid_macsec_capability_error</i>        | (Optional) IDB Statistics - SAK failure - invalid MACsec capability error         |

|   |   |
|---|---|
| <i>idb_stat_macsec_failure_rx_sa_create_error</i>             | (Optional) IDB Statistics - SAK failure - Rx SA create error          |
| <i>idb_stat_macsec_failure_tx_sa_create_error</i>             | (Optional) IDB Statistics - SAK failure - Tx SA create error          |
| TABLE_mka_gbl_stats   | (Optional) MKA Global Statistics                                      |
| <i>session_secured</i>  | (Optional) Session secured Events                                     |
| <i>session_deleted</i>  | (Optional) Session deleted Events                                     |
| <i>session_keepalive_timeout</i>                              | (Optional) Session keepalive timeout Events                           |
| <i>ca_stat_pairwise_cak_rekey</i>                             | (Optional) CA Statistics pairwise CAK rekey                           |
| <i>sa_stat_sak_generated</i>                                  | (Optional) SA Statistics SAK generated                                |
| <i>sa_stat_sak_rekey</i>                                      | (Optional) SA Statistics SAK rekey                                    |
| <i>sa_stat_sak_received</i>                                   | (Optional) SA Statistics SAK received                                 |
| <i>sa_stat_sak_response_rx</i>                                | (Optional) SA Statistics SAK response received                        |
| <i>mkpdu_stat_mkpdu_rx</i>                                    | (Optional) MKPDU Statistics MKPDU received                            |
| <i>mkpdu_stat_mkpdu_rx_distsak</i>                            | (Optional) MKPDU Statistics MKPDU received distributed SAK            |
| <i>mkpdu_stat_mkpdu_tx</i>                                    | (Optional) MKPDU Statistics MKPDU transmitted                         |
| <i>mkpdu_stat_mkpdu_tx_distsak</i>                            | (Optional) MKPDU Statistics MKPDU transmitted distributed SAK         |
| <i>mka_error_session_failure_bring_up_error</i>               | (Optional) MKA Error - Session failure - Bring up error               |
| <i>mka_error_sak_failure_sak_generate_error</i>               | (Optional) MKA Error - SAK failure - SAK generate error               |
| <i>mka_error_sak_failure_hash_generate_error</i>              | (Optional) MKA Error - SAK failure - Hash generate error              |
| <i>mka_error_sak_failure_sak_encryption_error</i>             | (Optional) MKA Error - SAK failure - SAK encryption error             |
| <i>mka_error_sak_failure_sak_decryption_error</i>             | (Optional) MKA Error - SAK failure - SAK decryption error             |
| <i>mka_error_sak_failure_sak_cipher_mismatch_error</i>        | (Optional) MKA Error - SAK failure - SAK Cipher mismatch error        |
| <i>mka_error_ca_failure_ick_derivation_error</i>              | (Optional) MKA Error - CA failure - ICK derivation error              |
| <i>mka_error_ca_failure_kek_derivation_error</i>              | (Optional) MKA Error - CA failure - KEK derivation error              |
| <i>mka_error_ca_failure_invalid_macsec_capability_error</i>   | (Optional) MKA Error - CA failure - Invalid MACsec capability error   |
| <i>mka_error_macsec_failure_rx_sa_create_error</i>            | (Optional) MKA Error - MACsec failure - Rx SA create error            |
| <i>mka_error_macsec_failure_tx_sa_create_error</i>            | (Optional) MKA Error - MACsec failure - Tx SA create error            |
| <i>mka_error_mkpdu_failure_mkpdu_tx_error</i>                 | (Optional) MKA Error - MKPDU failure - MKPDU Tx error                 |
| <i>mka_error_mkpdu_failure_mkpdu_rx_integrity_check_error</i> | (Optional) MKA Error - MKPDU failure - MKPDU Rx integrity check error |



|  |  |
|--|--|
| <i>mka_enor_mkpdu_failure_mkpdu_invalid_peer_mn_enor</i>       | (Optional) MKA Error - MKPDU failure - invalid peer MN error         |
| <i>mka_enor_mkpdu_failure_mkpdu_nonrecent_peerlist_mn_enor</i> | (Optional) MKA Error - MKPDU failure - non recent peerlist MN error  |
| <i>mka_enor_mkpdu_failure_sakuse_kn_mismatch_enor</i>          | (Optional) MKA Error - MKPDU failure - SAKuse KN mismatch error      |
| <i>mka_enor_mkpdu_failure_sakuse_rx_not_set_enor</i>           | (Optional) MKA Error - MKPDU failure - SAKuse Rx not set error       |
| <i>mka_enor_mkpdu_failure_sakuse_key_mi_mismatch_enor</i>      | (Optional) MKA Error - MKPDU failure - SAKuse key MI mismatch error  |
| <i>mka_enor_mkpdu_failure_sakuse_an_not_in_use_enor</i>        | (Optional) MKA Error - MKPDU failure - SAKuse AN not in use error    |
| <i>mka_enor_mkpdu_failure_sakuse_ks_rx_tx_not_set_enor</i>     | (Optional) MKA Error - MKPDU failure - SAKuse KS Rx Tx not set error |
| <i>global_stats_mkpdu_rx_invalid_ckn</i>                       | (Optional) Global Statistics MKPDU received invalid CKN              |
| <i>global_stats_mkpdu_tx_pkt_build_fail</i>                    | (Optional) Global Statistics Transmit Pkt build fail                 |
| <i>ifname2</i>   | (Optional) MACSEC Interface Name                                     |

**Command Mode**

- /exec

## show macsec policy

```
show macsec policy [ <policy_name> ] [ __readonly__ { TABLE_macsec_policy <name> <cipher_suite>
<keyserver_priority> <window_size> <conf_offset> <security_policy> <sak-expiry-time>
<include_icv_indicator> <include_sci> } ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information            |
| macsec                       | Show MACSEC policy information             |
| policy                       | Show MACSEC policy information             |
| <i>policy_name</i>           | (Optional) Name of MACSEC Policy           |
| <i>__readonly__</i>          | (Optional)                                 |
| TABLE_macsec_policy          | (Optional)                                 |
| <i>name</i>                  | (Optional) MACSEC Policy Name              |
| <i>cipher_suite</i>          | (Optional) Cipher Suite                    |
| <i>keyserver_priority</i>    | (Optional) KeyServer Priority              |
| <i>window_size</i>           | (Optional) Window Size                     |
| <i>conf_offset</i>           | (Optional) Confidentiality Offset          |
| <i>security_policy</i>       | (Optional) Security Policy                 |
| <i>sak-expiry-time</i>       | (Optional) SAK expiry on time interval     |
| <i>include_icv_indicator</i> | (Optional) Include ICV indicator in MKPDUs |
| <i>include_sci</i>           | (Optional) Include SCI in secTag           |

### Command Mode

- /exec



|  |  |
|--|--|
| <i>in_pkts_unicast_controlled</i>      | (Optional) In Pkts Unicast Controlled      |
| <i>in_pkts_multicast_controlled</i>    | (Optional) In Pkts Multicast Controlled    |
| <i>in_pkts_broadcast_controlled</i>    | (Optional) In Pkts Broadcast Controlled    |
| <i>in_pkts_controlled</i>              | (Optional) In Pkts Controlled              |
| <i>in_rx_drop_pkts_controlled</i>      | (Optional) In Rx Drop Pkts Controlled      |
| <i>in_rx_err_pkts_controlled</i>       | (Optional) In Rx Err Pkts Controlled       |
| <i>in_octets_uncontrolled</i>          | (Optional) In Octets Uncontrolled          |
| <i>in_octets_controlled</i>            | (Optional) In Octets Controlled            |
| <i>input_rate_uncontrolled_bps</i>     | (Optional) Input Rate Uncontrolled BPS     |
| <i>input_rate_uncontrolled_pps</i>     | (Optional) Input Rate Uncontrolled PPS     |
| <i>input_rate_controlled_bps</i>       | (Optional) Input Rate Controlled BPS       |
| <i>input_rate_controlled_pps</i>       | (Optional) Input Rate Controlled PPS       |
| <i>out_pkts_unicast_uncontrolled</i>   | (Optional) Out Pkts Unicast Uncontrolled   |
| <i>out_pkts_multicast_uncontrolled</i> | (Optional) Out Pkts Multicast Uncontrolled |
| <i>out_pkts_broadcast_uncontrolled</i> | (Optional) Out Pkts Broadcast Uncontrolled |
| <i>out_rx_drop_pkts_uncontrolled</i>   | (Optional) Out Rx Drop Pkts Uncontrolled   |
| <i>out_rx_err_pkts_uncontrolled</i>    | (Optional) Out Rx Err Pkts Uncontrolled    |
| <i>out_pkts_unicast_controlled</i>     | (Optional) Out Pkts Unicast Controlled     |
| <i>out_pkts_multicast_controlled</i>   | (Optional) Out Pkts Multicast Controlled   |
| <i>out_pkts_broadcast_controlled</i>   | (Optional) Out Pkts Broadcast Controlled   |
| <i>out_pkts_controlled</i>             | (Optional) Out Pkts Controlled             |
| <i>out_rx_drop_pkts_controlled</i>     | (Optional) Out Rx Drop Pkts Controlled     |
| <i>out_rx_err_pkts_controlled</i>      | (Optional) Out Rx Err Pkts Controlled      |
| <i>out_octets_uncontrolled</i>         | (Optional) Out Octets Uncontrolled         |
| <i>out_octets_controlled</i>           | (Optional) Out Octets Controlled           |
| <i>out_octets_common</i>               | (Optional) Out Octets Common               |
| <i>output_rate_uncontrolled_bps</i>    | (Optional) Output Rate Uncontrolled BPS    |
| <i>output_rate_uncontrolled_pps</i>    | (Optional) Output Rate Uncontrolled PPS    |
| <i>output_rate_controlled_bps</i>      | (Optional) Output Rate Controlled BPS      |

|                                     |  |
|-------------------------------------|--|
| <i>output_rate_controlled_pps</i>   | (Optional) Output Rate Controlled PPS      |
| <i>in_pkts_transform_error</i>      | (Optional) In Pkts Transform Error         |
| <i>in_pkts_control</i>              | (Optional) In Pkts Control                 |
| <i>in_pkts_untagged</i>             | (Optional) In Pkts Untagged                |
| <i>in_pkts_no_tag</i>               | (Optional) In Pkts No Tag                  |
| <i>in_pkts_badtag</i>               | (Optional) In Pkts Bad Tag                 |
| <i>in_pkts_no_sci</i>               | (Optional) In Pkts No SCI                  |
| <i>in_pkts_unknown_sci</i>          | (Optional) In Pkts Unknown SCI             |
| <i>in_pkts_tagged_ctrl</i>          | (Optional) In Pkts Tagged Control          |
| <i>out_pkts_transform_error</i>     | (Optional) Out Pkts Transform Error        |
| <i>out_pkts_control</i>             | (Optional) Out Pkts Control                |
| <i>out_pkts_untagged</i>            | (Optional) Out Pkts Untagged               |
| TABLE_rx_sa_an                      | (Optional) MACsec secy rx_sa_an statistics |
| <i>rx_sa_an</i>                     | (Optional) Rx SA AN                        |
| <i>in_pkts_unchecked</i>            | (Optional) In Pkts Unchecked               |
| <i>in_pkts_delayed</i>              | (Optional) In Pkts Delayed                 |
| <i>in_pkts_late</i>                 | (Optional) In Pkts Late                    |
| <i>in_pkts_ok</i>                   | (Optional) In Pkts OK                      |
| <i>in_pkts_invalid</i>              | (Optional) In Pkts Invalid                 |
| <i>in_pkts_not_valid</i>            | (Optional) In Pkts not Valid               |
| <i>in_pkts_not_using_sa</i>         | (Optional) In Pkts not using SA            |
| <i>in_pkts_unused_sa</i>            | (Optional) In Pkts Unused SA               |
| <i>in_octets_decrypted</i>          | (Optional) In Octets Decrypted             |
| <i>in_octets_validated</i>          | (Optional) In Octets Validated             |
| TABLE_tx_sa_an                      | (Optional) MACsec secy tx_sa_an statistics |
| <i>tx_sa_an</i>                     | (Optional) Tx SA AN                        |
| <i>out_pkts_encrypted_protected</i> | (Optional) Out Pkts Encrypted Protected    |
| <i>out_pkts_too_long</i>            | (Optional) Out Pkts too Long               |
| <i>out_pkts_sa_not_inuse</i>        | (Optional) Out Pkts SA not in use          |

|                                       |   |
|---------------------------------------|---|
| <i>out_octets_encrypted_protected</i> | (Optional) Out octets Encrypted Protected |
| <i>ifname2</i>                        | (Optional) MACSEC Interface Name          |

**Command Mode**

- /exec

# show maintenance maint-delay

```
show maintenance maint-delay [ __readonly__ <delay> ]
```

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information          |
| maintenance  | maintenance                              |
| maint-delay  | maintenance mode CLI release delay value |
| __readonly__ | (Optional)                               |
| <i>delay</i> | (Optional) delay value in seconds        |

## Command Mode

- /exec

## show maintenance on-reload reset-reasons

```
show maintenance on-reload reset-reasons [ __readonly__ [ TABLE_reset_reason <reset_reason> ] <rr_bitmap> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information          |
| maintenance               | maintenance                              |
| on-reload                 | on reload maintenance mode configuration |
| reset-reasons             | system reset reasons                     |
| <i>__readonly__</i>       | (Optional)                               |
| <i>TABLE_reset_reason</i> | (Optional)                               |
| <i>rr_bitmap</i>          | (Optional) reset reason bitmap           |
| <i>reset_reason</i>       | (Optional) system reset reason           |

### Command Mode

- /exec



# show maintenance profile

```
show maintenance profile [ <mode> ] [ __readonly__ TABLE_profile <name> [ TABLE_cfg <cfg> ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| maintenance         | maintenance                     |
| profile             | maintenance profile             |
| <i>mode</i>         | (Optional)                      |
| <i>__readonly__</i> | (Optional)                      |
| TABLE_profile       | (Optional)                      |
| <i>name</i>         | (Optional) profile name         |
| TABLE_cfg           | (Optional)                      |
| <i>cfg</i>          | (Optional) profile config       |

## Command Mode

- /exec

# show maintenance snapshot-delay

```
show maintenance snapshot-delay [ __readonly__ <delay> ]
```

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information        |
| maintenance    | maintenance                            |
| snapshot-delay | after_maintenance snapshot delay value |
| __readonly__   | (Optional)                             |
| <i>delay</i>   | (Optional) delay value in seconds      |

## Command Mode

- /exec

# show maintenance timeout

show maintenance timeout [ \_\_readonly\_\_ <timeout> ]

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| maintenance    | maintenance                     |
| timeout        | timeout value                   |
| __readonly__   | (Optional)                      |
| <i>timeout</i> | (Optional) timeout value        |

## Command Mode

- /exec

# show mcast

show mcast [ vsan <i0> ]

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| vsan      | (Optional) Enter VSAN           |
| <i>i0</i> | (Optional) VSAN id              |

## Command Mode

- /exec

# show module

```
show module [ { <module> } | { <s0> [ <santa-cruz-range> ] } | { fabric [ <module> ] } ] [ __readonly__ {
TABLE_modinfo <modinf> <ports> <modtype> <model> <status> } [ { TABLE_modpwrinfo <modpwr>
<pwrstat> <reason> } ] { TABLE_modwwninfo <modwwn> <sw> <hw> <slottype> } [ { TABLE_modapplinfo
<modappl> <desc> <applver> } ] { TABLE_modmacinfo <modmac> <mac> <serialnum> } {
TABLE_moddiaginfo <mod> <diagstatus> } [ { TABLE_modinfo <modinf> <ports> <modtype> <model>
<status> } [ { TABLE_modpwrinfo <modpwr> <pwrstat> <reason> } ] { TABLE_modwwninfo <modwwn>
<sw> <hw> <slottype> } [ { TABLE_modapplinfo <modappl> <desc> <applver> } ] { TABLE_modmacinfo
<modmac> <mac> <serialnum> } { TABLE_moddiaginfo <mod> <diagstatus> } ] [ { TABLE_xbarinfo
<xbarinf> <xbarports> <xbartype> <xbarmodel> <xbarstatus> } ] [ { TABLE_xbarpwrinfo <xbarpwr>
<xbarpwrstat> <xbarreason> } ] [ { TABLE_xbarwwninfo <xbarwwn> <xbarsw> <xbarhw> <xbarwwnstr>
} ] [ { TABLE_xbarmacinfo <xbarmac> <xbarmacaddr> <xbarserialnum> } ] ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information         |
| module                  | Show module information                 |
| <i>module</i>           | (Optional) Enter module number          |
| <i>s0</i>               | (Optional) Show xbar information        |
| <i>santa-cruz-range</i> | (Optional) please enter the xbar number |
| fabric                  | (Optional) Show fabric information      |
| __readonly__            | (Optional)                              |
| TABLE_modinfo           | (Optional) Show Module info             |
| <i>modinf</i>           | (Optional) Module                       |
| <i>ports</i>            | (Optional) Num Ports                    |
| <i>modtype</i>          | (Optional) Module Type                  |
| <i>model</i>            | (Optional) Model                        |
| <i>status</i>           | (Optional) Status                       |
| TABLE_modpwrinfo        | (Optional) Mod Pwr Info                 |
| <i>modpwr</i>           | (Optional) Module                       |
| <i>pwrstat</i>          | (Optional) Power Status                 |
| <i>reason</i>           | (Optional) Reason                       |
| TABLE_modwwninfo        | (Optional) Mod WWN Info                 |
| <i>modwwn</i>           | (Optional) Module                       |

|                    |                                |
|--------------------|--------------------------------|
| <i>sw</i>          | (Optional) SW Ver              |
| <i>hw</i>          | (Optional) HW Ver              |
| <i>slottype</i>    | (Optional) Slot                |
| TABLE_modapplinfo  | (Optional) Mod Appl image info |
| <i>modappl</i>     | (Optional) Module              |
| <i>desc</i>        | (Optional) Image desc          |
| <i>applver</i>     | (Optional) Version             |
| TABLE_modmacinfo   | (Optional) Mod MAC Info        |
| <i>modmac</i>      | (Optional) Module              |
| <i>mac</i>         | (Optional) MAC                 |
| <i>serialnum</i>   | (Optional) Serial Num          |
| TABLE_moddiaginfo  | (Optional) Mod diag info       |
| <i>mod</i>         | (Optional) Module              |
| <i>diagstatus</i>  | (Optional) Diag status         |
| TABLE_xbarinfo     | (Optional) Show xbar info      |
| <i>xbarinf</i>     | (Optional) Module              |
| <i>xbarports</i>   | (Optional) Num Ports           |
| <i>xbartype</i>    | (Optional) Module Type         |
| <i>xbarmodel</i>   | (Optional) Model               |
| <i>xbarstatus</i>  | (Optional) Status              |
| TABLE_xbarpwrinfo  | (Optional) Xbar Pwr Info       |
| <i>xbarpwr</i>     | (Optional) Module              |
| <i>xbarpwrstat</i> | (Optional) Power Status        |
| <i>xbarreason</i>  | (Optional) Reason              |
| TABLE_xbarwwninfo  | (Optional) Xbar WWN Info       |
| <i>xbarwwn</i>     | (Optional) Module              |
| <i>xbarsw</i>      | (Optional) SW Ver              |
| <i>xbarhw</i>      | (Optional) HW Ver              |
| <i>xbarwwnstr</i>  | (Optional) WWN                 |

|                      |                          |
|----------------------|--------------------------|
| TABLE_xbarmacinfo    | (Optional) Xbar MAC Info |
| <i>xbarmac</i>       | (Optional) Module        |
| <i>xbarmacaddr</i>   | (Optional) MAC           |
| <i>xbarserialnum</i> | (Optional) Serial Num    |

**Command Mode**

- /exec

# show module bandwidth-fairness

show module <module> bandwidth-fairness [ \_\_readonly\_\_ { TABLE\_fairness <statement> } ]

## Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| module             | Show module information         |
| <i>module</i>      | Enter module number             |
| bandwidth-fairness | Show bandwidth fairness status  |
| __readonly__       | (Optional)                      |
| TABLE_fairness     | (Optional)                      |
| <i>statement</i>   | (Optional)                      |

## Command Mode

- /exec



# show module port type

```
show module <module1> port type [ __readonly__ { TABLE_porttype <slot1> <port1> <opertype>
<admintype> } ]
```

## Syntax Description

|                     |                                      |
|---------------------|--------------------------------------|
| show                | Show running system information      |
| module              | Show module information              |
| <i>module1</i>      | Enter module number                  |
| port                | Show port type                       |
| type                | Show port type                       |
| <i>__readonly__</i> | (Optional)                           |
| TABLE_porttype      | (Optional) Module port type          |
| <i>slot1</i>        | (Optional) Module number             |
| <i>port1</i>        | (Optional) Port number               |
| <i>opertype</i>     | (Optional) Operational type for port |
| <i>admintype</i>    | (Optional) Admin type for port       |

## Command Mode

- /exec

# show module uptime

```
show module uptime [ __readonly__ { TABLE_uptimeinf <slot> <starttime> <daysup> <hoursup> <minutesup>
<secondsup> } ]
```

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                  |
| module           | Show module information                          |
| uptime           | Show how long the module has been up and running |
| __readonly__     | (Optional)                                       |
| TABLE_uptimeinf  | (Optional) Show uptime info                      |
| <i>slot</i>      | (Optional) Slot                                  |
| <i>starttime</i> | (Optional) Start Time                            |
| <i>daysup</i>    | (Optional) Days Up                               |
| <i>hoursup</i>   | (Optional) Hours Up                              |
| <i>minutesup</i> | (Optional) Minutes Up                            |
| <i>secondsup</i> | (Optional) Seconds Up                            |

## Command Mode

- /exec

# show monitor

show monitor [ *\_\_readonly\_\_* *TABLE\_session* <session\_number> <state> <state\_reason> <description> ]

## Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| <i>show</i>           | Show running system information |
| <i>monitor</i>        | Show Ethernet SPAN information  |
| <i>__readonly__</i>   | (Optional) Read only            |
| <i>TABLE_session</i>  | (Optional) show monitor         |
| <i>session_number</i> | (Optional) session id           |
| <i>state</i>          | (Optional) State                |
| <i>state_reason</i>   | (Optional) State reason         |
| <i>description</i>    | (Optional) Session Description  |

## Command Mode

- /exec

## show monitor session

```
show monitor session { all | <session_number> | warp | range <session_range> } [ { drops | brief } ] [
__readonly__ [ TABLE_session <session_number> [ <description> ] [ <type> ] [ <version> ] [ <state> ] [
<state_reason> ] [ <err_desc> ] [ <flow_id> ] [ <switch_id> ] [ <erspan_granularity> ] [ <vrf_name> ] [
<acl_name> ] [ <erspan_ttl> ] [ <erspan_dscp> ] [ <header_type> ] [ <span_mtu> ] [ <span_sampling> ] [
<ip_filter> ] + [ <dst_ip> ] [ <dst_ipv6> ] [ <origin_ip> ] [ <origin_ipv6> ] [ <src_ip> ] [ <src_ipv6> ] [
<control_pkt_filter> ] [ TABLE_sources_rx [ <sources_rx> ] ] [ TABLE_sources_tx [ <sources_tx> ] ] [
TABLE_sources_both [ <sources_both> ] ] [ <source_vlans_rx> ] [ <source_vlans_tx> ] [ <source_vlans_both>
] [ <source_vsans_rx> ] [ <tree-id> <switchid> ] + [ <filter_vlans> ] [ <destinations> ] + [ <acl_destinations>
] + [ <rate_limit_cap> ] + [ <mtu_capability> ] + [ <sampling_capability> ] + [ <mcbe> ] + [ <l3_egress_span>
] + [ <erspan_acl> ] + [ <erspan_v3_cap> ] + [ <erspan_v2_cap> ] + [ <erspan_gran_cap> ] + [
<fex_ingress_intf> ] + [ <sources_rx_2> ] + [ <marker_time_intv> ] [ <marker_pkt_count> ] [
<marker_pkt_fail> ] [ <erspan_egress_if> ] [ <drops> ] [ <inactive> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information         |
| monitor               | Show Ethernet SPAN information          |
| session               | Show session info                       |
| all                   | All sessions                            |
| <i>session_number</i> |   |
| warp                  | warp session                            |
| range                 | Specify a range                         |
| <i>session_range</i>  |   |
| brief                 | (Optional) Brief information            |
| drops                 | (Optional) show drop count              |
| <u>__readonly__</u>   | (Optional) Read only                    |
| TABLE_session         | (Optional) show monitor                 |
| <i>session_number</i> | (Optional) session number               |
| <i>description</i>    | (Optional) Session Description          |
| <i>type</i>           | (Optional) Session type                 |
| <i>version</i>        | (Optional) Erspan source version: v2/v3 |
| <i>state</i>          | (Optional) State                        |
| <i>state_reason</i>   | (Optional) State reason                 |
| <i>err_desc</i>       | (Optional) Error Description            |

|                           |  |
|---------------------------|--|
| <i>flow_id</i>            | (Optional) erspan-id                           |
| <i>switch_id</i>          | (Optional) erspan_switch-id                    |
| <i>erspan_granularity</i> | (Optional) ERSPAN Type III Granularity         |
| <i>vrf_name</i>           | (Optional) ERSPAN session VRF                  |
| <i>acl_name</i>           | (Optional) ERSPAN session ACL                  |
| <i>erspan_ttl</i>         | (Optional) ERSPAN TTL Value                    |
| <i>erspan_dscp</i>        | (Optional) ERSPAN DSCP Value                   |
| <i>header_type</i>        | (Optional) ERSPAN Header Type                  |
| <i>span_mtu</i>           | (Optional) SPAN MTU value                      |
| <i>span_sampling</i>      | (Optional) SPAN sampling range                 |
| <i>ip_filter</i>          | (Optional) IP filter value                     |
| <i>dst_ip</i>             | (Optional) ERSPAN destination IP               |
| <i>dst_ipv6</i>           | (Optional) ERSPAN destination IPv6             |
| <i>origin_ip</i>          | (Optional) ERSPAN origin IP at source router   |
| <i>origin_ipv6</i>        | (Optional) ERSPAN origin IPv6 at source router |
| <i>src_ip</i>             | (Optional) ERSPAN source IP                    |
| <i>src_ipv6</i>           | (Optional) ERSPAN source IPv6                  |
| <i>control_pkt_filter</i> | (Optional) Control packet filter value         |
| TABLE_sources_rx          | (Optional) ingress intf table                  |
| <i>sources_rx</i>         | (Optional) List of ingress sources             |
| TABLE_sources_tx          | (Optional) egress intf table                   |
| <i>sources_tx</i>         | (Optional) List of egress sources              |
| TABLE_sources_both        | (Optional) bi-direction intf table             |
| <i>sources_both</i>       | (Optional) List of sources in both directions  |
| <i>source_vlans_rx</i>    | (Optional) Source ingress vlan                 |
| <i>source_vsans_rx</i>    | (Optional) Source ingress vsan                 |
| <i>source_vlans_tx</i>    | (Optional) Source egress vlan                  |
| <i>source_vlans_both</i>  | (Optional) Source vlans in both directions     |
| <i>tree-id</i>            | (Optional) proxy layer2 gateway source tree-id |

|                            |   |
|----------------------------|---|
| <i>switchid</i>            | (Optional) proxy layer2 gateway source switchid                   |
| <i>filter_vlans</i>        | (Optional) Filter vlans   |
| <i>destinations</i>        | (Optional) List of destinations                                   |
| <i>acl_destinations</i>    | (Optional) List of interfaces that wont work for acl capture      |
| <i>rate_limit_cap</i>      | (Optional) List of modules that support Rate Limit                |
| <i>mtu_capability</i>      | (Optional) List of modules that support MTU                       |
| <i>sampling_capability</i> | (Optional) List of modules that support Sampling                  |
| <i>mcbe</i>                | (Optional) List all modules that support multicast best effort    |
| <i>l3_egress_span</i>      | (Optional) List of modules that support L3 Multicast Egress SPAN  |
| <i>erspan_acl</i>          | (Optional) List of modules that support ERSPAN ACL filtering      |
| <i>erspan_v3_cap</i>       | (Optional) List of modules that support erspan version3           |
| <i>erspan_v2_cap</i>       | (Optional) List of modules that support erspan version2           |
| <i>erspan_gran_cap</i>     | (Optional) List of modules that support the granularity set       |
| <i>fex_ingress_intf</i>    | (Optional) List of fex interfaces that wont work for ingress span |
| <i>erspan_egress_if</i>    | (Optional) Egress interface for ERSPAN SRC session                |
| <i>sources_rx_2</i>        | (Optional) List of ingress sources                                |
| <i>marker_time_intv</i>    | (Optional) Marker packet interval                                 |
| <i>marker_pkt_count</i>    | (Optional) Marker packet count                                    |
| <i>marker_pkt_fail</i>     | (Optional) Marker packet fail count                               |
| <i>drops</i>               | (Optional) Drop count   |
| <i>inactive</i>            | (Optional) Session is inactive                                    |

**Command Mode**

- /exec

# show mpls extended-ecmp

show mpls extended-ecmp

## Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| mpls          | MPLS routing ECMP mode          |
| extended-ecmp | extended-ecmp mode (default)    |

## Command Mode

- /exec

## show mpls forwarding statistics

```
show mpls forwarding statistics [ interface { <interface> | all } ] [ __readonly__ { TABLE_mpls_stats [
<intf_name> ] <mpls_packets_sent> <mpls_bytes_sent> <mpls_packets_received> <mpls_bytes_received>
<mpls_packets_forwarded> <mpls_bytes_forwarded> <mpls_packets_originated> <mpls_bytes_originated>
<mpls_packets_consumed> <mpls_bytes_consumed> <mpls_packets_input_dropped>
<mpls_bytes_input_dropped> <mpls_packets_output_dropped> <mpls_bytes_output_dropped> } ]
```

### Syntax Description

|                                    |   |
|------------------------------------|---|
| show                               | Show running system information                   |
| mpls                               | MPLS information                                  |
| forwarding                         | Display MPLS software forwarded                   |
| statistics                         | Traffic statistics                                |
| interface                          | (Optional) Interface specific information         |
| <i>interface</i>                   | (Optional) Interface chosen to display statistics |
| all                                | (Optional) All interfaces                         |
| <i>__readonly__</i>                | (Optional)  |
| TABLE_mpls_stats                   | (Optional) MPLS forwarding statistics             |
| <i>intf_name</i>                   | (Optional) Interface name                         |
| <i>mpls_packets_sent</i>           | (Optional) mpls packet sent                       |
| <i>mpls_bytes_sent</i>             | (Optional) mpls bytes sent                        |
| <i>mpls_packets_received</i>       | (Optional) mpls packet received                   |
| <i>mpls_bytes_received</i>         | (Optional) mpls bytes received                    |
| <i>mpls_packets_forwarded</i>      | (Optional) mpls packet forwarded                  |
| <i>mpls_bytes_forwarded</i>        | (Optional) mpls bytes forwarded                   |
| <i>mpls_packets_originated</i>     | (Optional) mpls packet originated                 |
| <i>mpls_bytes_originated</i>       | (Optional) mpls bytes originated                  |
| <i>mpls_packets_consumed</i>       | (Optional) mpls packet consumed                   |
| <i>mpls_bytes_consumed</i>         | (Optional) mpls bytes consumed                    |
| <i>mpls_packets_input_dropped</i>  | (Optional) mpls packet input dropped              |
| <i>mpls_bytes_input_dropped</i>    | (Optional) mpls bytes input dropped               |
| <i>mpls_packets_output_dropped</i> | (Optional) mpls packet output dropped             |



|                                  |                                      |
|----------------------------------|--------------------------------------|
| <i>mpls_bytes_output_dropped</i> | (Optional) mpls bytes output dropped |
|----------------------------------|--------------------------------------|

**Command Mode**

- /exec

# show mpls interfaces

show mpls interfaces [ *\_\_readonly\_\_* *TABLE\_mpls\_interface* <intf> <oper> ]

## Syntax Description

|                             |                                       |
|-----------------------------|---------------------------------------|
| show                        | Show running system information       |
| mpls                        | Display MPLS status and configuration |
| interfaces                  | Display MPLS Interfaces               |
| <i>__readonly__</i>         | (Optional)                            |
| <i>TABLE_mpls_interface</i> | (Optional)                            |
| <i>intf</i>                 | (Optional)                            |
| <i>oper</i>                 | (Optional)                            |

## Command Mode

- /exec

# show mpls interfaces detail

show mpls interfaces detail [ *\_\_readonly\_\_* *TABLE\_mpls\_interface\_det* <intf> { <client\_name> + } <oper\_str> <ls\_id> <mpls\_sublayer\_name> <mpls\_sublayer\_id> ]

## Syntax Description

|                                 |                                       |
|---------------------------------|---------------------------------------|
| show                            | Show running system information       |
| mpls                            | Display MPLS status and configuration |
| interfaces                      | Interfaces                            |
| detail                          | Detail                                |
| <i>__readonly__</i>             | (Optional)                            |
| <i>TABLE_mpls_interface_det</i> | (Optional)                            |
| <i>intf</i>                     | (Optional)                            |
| <i>client_name</i>              | (Optional)                            |
| <i>oper_str</i>                 | (Optional)                            |
| <i>ls_id</i>                    | (Optional)                            |
| <i>mpls_sublayer_name</i>       | (Optional)                            |
| <i>mpls_sublayer_id</i>         | (Optional)                            |

## Command Mode

- /exec

# show mpls interfaces statistics

```
show mpls interfaces <ifname> statistics [ __readonly__ TABLE_mpls_interface_stats <intf> <enabled> [
<pkts_in> ] [ <bytes_in> ] [ <pkts_out> ] [ <bytes_out> ] ]
```

## Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| mpls                       | Display MPLS status and configuration |
| interfaces                 | Interfaces                            |
| <i>ifname</i>              | Interface Name                        |
| statistics                 | statistics                            |
| <i>__readonly__</i>        | (Optional)                            |
| TABLE_mpls_interface_stats | (Optional)                            |
| <i>intf</i>                | (Optional)                            |
| <i>enabled</i>             | (Optional)                            |
| <i>pkts_in</i>             | (Optional)                            |
| <i>bytes_in</i>            | (Optional)                            |
| <i>pkts_out</i>            | (Optional)                            |
| <i>bytes_out</i>           | (Optional)                            |

## Command Mode

- /exec

## show mpls ip bindings

```
show mpls ip bindings [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ generic ] [ { <prefix> { <mask> |
<mask-length> } | <prefix-mask> } [ longer-prefix ] ] [ neighbor <addr> | local ] [ [ local-label <local-label>
[ local-to <local-label-max> ] ] | [ remote-label <remote-label> [ remote-to <remote-label-max> ] ] ] [
advertisement-prefix-list | detail ] [ __readonly__ { TABLE_bnd [ <ldp_ctx> ] [ <laf> ] [ {
TABLE_bnd_acl_list <oldstyle> <prefix_acl> <peer_acl> } ] [ { TABLE_bnd_rec <lib_addr> <lib_mask>
[ <lcl_bnd_rev> ] [ <no_route> ] [ <chkpt> ] [ <local_label> ] [ <withdraw> ] [ { TABLE_bnd_peer_list
<peer_ident> } ] [ { TABLE_bnd_remote [ <remote_lsr> ] [ <remote_label> ] [ <rem_lbl_in_use> ] [ <stale_gr>
] } ] [ <advert_acl_pending> ] [ <peer_acl> ] [ <prefix_acl> } ] } ] }
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                        |
| mpls                   | Display MPLS status and configuration                  |
| ip                     | MPLS IP information                                    |
| bindings               | Show the MPLS IP Label Information Base (LIB)          |
| vrf                    | (Optional) VRF Routing/Forwarding instance information |
| <i>vrf-name</i>        | (Optional) VPN Routing/Forwarding instance name        |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                              |
| all                    | (Optional) Display LIB information in all VRFs         |
| generic                | (Optional) Display generic labels                      |
| <i>prefix</i>          | (Optional) Destination prefix                          |
| <i>mask</i>            | (Optional) Destination prefix mask                     |
| <i>mask-length</i>     | (Optional) Mask length                                 |
| <i>prefix-mask</i>     | (Optional) Destination prefix/mask                     |
| longer-prefix          | (Optional) Include longer matches                      |
| neighbor               | (Optional) Display labels from LDP neighbor            |
| <i>addr</i>            | (Optional) IP adjacency address                        |
| local                  | (Optional) Display only locally assigned labels        |
| local-label            | (Optional) Match locally assigned label values         |
| <i>local-label</i>     | (Optional) Locally assigned label value                |
| local-to               | (Optional) Label range                                 |
| <i>local-label-max</i> | (Optional) Locally assigned label value                |

|                           |  |
|---------------------------|--|
| remote-label              | (Optional) Match remotely assigned label values                |
| <i>remote-label</i>       | (Optional) Remotely assigned label value                       |
| remote-to                 | (Optional) Label range   |
| <i>remote-label-max</i>   | (Optional) Remotely assigned label value                       |
| advertisement-prefix-list | (Optional) Show advertisement prefix lists                     |
| detail                    | (Optional) Show detailed information                           |
| __readonly__              | (Optional) Read Only   |
| TABLE_bnd                 | (Optional) Show bindings or tib summary for a vrf              |
| <i>ldp_ctx</i>            | (Optional) LDP context   |
| <i>llaf</i>               | (Optional) Local label filtering spec                          |
| TABLE_bnd_acl_list        | (Optional) Show advertisement access lists for default vrf     |
| <i>oldstyle</i>           | (Optional) Oldstyle assignment of prefix acls to entries       |
| <i>prefix_acl</i>         | (Optional) Prefix acl  |
| <i>peer_acl</i>           | (Optional) Peer acl  |
| TABLE_bnd_rec             | (Optional) Show bindings in a vrf                              |
| <i>lib_addr</i>           | (Optional) LIB entry IP address                                |
| <i>lib_mask</i>           | (Optional) LIB entry mask                                      |
| <i>lcl_bnd_rev</i>        | (Optional) Local binding revision for lib entry                |
| <i>no_route</i>           | (Optional) Displays if no route present for lib entry          |
| <i>chkpt</i>              | (Optional) Checkpoint state for lib entry                      |
| <i>local_label</i>        | (Optional) Local label   |
| <i>withdraw</i>           | (Optional) Displays if label withdrawn or label withdraw sent  |
| TABLE_bnd_remote          | (Optional) Remote bindings                                     |
| <i>remote_lsr</i>         | (Optional) Remote binding label switched route for lib entry   |
| <i>remote_label</i>       | (Optional) Remote label for lib entry                          |
| <i>rem_lbl_in_use</i>     | (Optional) Displays if out label is in use                     |
| <i>stale_gr</i>           | (Optional) Displays if stale GR binding for lib entry          |
| <i>advert_acl_pending</i> | (Optional) Displays if advert acl action pending for lib entry |
| <i>peer_acl</i>           | (Optional) Advertisement acl: Peer acl name for lib entry      |

|                     |  |
|---------------------|--|
| <i>prefix_acl</i>   | (Optional) Advertisement acl: Prefix acl name for lib entry            |
| TABLE_bnd_peer_list | (Optional) Show list of peers to which local label has been advertised |
| <i>peer_ident</i>   | (Optional) Peer to which local label has been advertised               |

**Command Mode**

- /exec

## show mpls ip bindings summary

```
show mpls ip bindings summary [ __readonly__ { TABLE_bnd [ <total_prefixes> ] [ <assigned_bindings>
] [ <local_bindings> ] [ <rem_bindings> ] [ <total_rt_info> ] [ <current_prev_lbl_entries> ] [
<total_prev_lbl_entries> ] [ <current_prev_lbl_queues> ] [ <total_prev_lbl_queues> ] } ]
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information  |
| mpls                            | Display MPLS status and configuration                                    |
| ip                              | MPLS IP information  |
| bindings                        | Show the MPLS IP Label Information Base (LIB)                            |
| summary                         | Show summary information   |
| <i>__readonly__</i>             | (Optional) Read Only   |
| <i>TABLE_bnd</i>                | (Optional) Show bindings or tib summary for a vrf                        |
| <i>total_prefixes</i>           | (Optional) Total number of prefixes                                      |
| <i>assigned_bindings</i>        | (Optional) Total number of assigned bindings                             |
| <i>total_rt_info</i>            | (Optional) Total tib route info allocated                                |
| <i>local_bindings</i>           | (Optional) Total number of locally assigned bindings                     |
| <i>rem_bindings</i>             | (Optional) Total number of remote bindings                               |
| <i>current_prev_lbl_entries</i> | (Optional) Current number of previous tib remote label entries allocated |
| <i>total_prev_lbl_entries</i>   | (Optional) Total number of previous tib remote label entries allocated   |
| <i>current_prev_lbl_queues</i>  | (Optional) Current number of previous tib remote label queues allocated  |
| <i>total_prev_lbl_queues</i>    | (Optional) Total number of previous tib remote label queues allocated    |

### Command Mode

- /exec



# show mpls ip ttl

```
show mpls ip ttl [ __readonly__ TABLE_mpls_ip_ttl <prop_or_exp> [ <forwarded> ] [ <local> ] [ <exp_count> ] ]
```

## Syntax Description

|                          |                                       |
|--------------------------|---------------------------------------|
| show                     | Show running system information       |
| mpls                     | Display MPLS status and configuration |
| ip                       | Display IP information                |
| ttl                      | TTL related information               |
| <i>__readonly__</i>      | (Optional)                            |
| <i>TABLE_mpls_ip_ttl</i> | (Optional)                            |
| <i>prop_or_exp</i>       | (Optional)                            |
| <i>forwarded</i>         | (Optional)                            |
| <i>local</i>             | (Optional)                            |
| <i>exp_count</i>         | (Optional)                            |

## Command Mode

- /exec

# show mpls label range

```
show mpls label range [ __readonly__ <dynamic-min> <dynamic-max> [ <static-min> <static-max> ] [
<srgb-min> <srgb-max> ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| mpls                | MPLS configuration commands     |
| label               | Label properties                |
| range               | Label range                     |
| <i>__readonly__</i> | (Optional)                      |
| <i>dynamic-min</i>  | (Optional)                      |
| <i>dynamic-max</i>  | (Optional)                      |
| <i>static-min</i>   | (Optional)                      |
| <i>static-max</i>   | (Optional)                      |
| <i>srgb-min</i>     | (Optional)                      |
| <i>srgb-max</i>     | (Optional)                      |

## Command Mode

- /exec

# show mpls load-sharing

```
show mpls load-sharing [ __readonly__ TABLE_mpls_load_sharing [ <label-ip> ] [ <label-only> ] ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information        |
| mpls                    | MPLS information                       |
| load-sharing            | Show mpls load sharing options         |
| __readonly__            | (Optional)                             |
| TABLE_mpls_load_sharing | (Optional) Table for MPLS Load Sharing |
| <i>label-ip</i>         | (Optional) Label IP load sharing       |
| <i>label-only</i>       | (Optional) Label only load sharing     |

## Command Mode

- /exec

## show mpls oam echo statistics

```
show mpls oam echo statistics [ summary ] [ __readonly__ <rq_sent> <rq_timeout> <rq_unsent> <rq_rcvd>
<rx_sent> <rx_unsent> <rx_rcvd> <rc_zero> <rc_one> <rc_two> <rc_three> <rc_four> <rc_five> <rc_six>
<rc_seven> <rc_eight> <rc_nine> <rc_ten> <rc_eleven> <rc_twelve> <rc_thirteen> <rc_fourteen>
<summary_flag> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| mpls                | Display MPLS status and configuration     |
| oam                 | Display OAM information                   |
| echo                | Echo request information                  |
| statistics          | Detailed Echo packet statistics           |
| summary             | (Optional) Echo packet statistics summary |
| <i>__readonly__</i> | (Optional)                                |
| <i>rq_sent</i>      | (Optional) Requests sent                  |
| <i>rq_timeout</i>   | (Optional) Requests timeout               |
| <i>rq_unsent</i>    | (Optional) Requests unsent                |
| <i>rq_rcvd</i>      | (Optional) Requests received              |
| <i>rx_sent</i>      | (Optional) Replies sent                   |
| <i>rx_unsent</i>    | (Optional) Replies unsent                 |
| <i>rx_rcvd</i>      | (Optional) Replies received               |
| <i>rc_zero</i>      | (Optional) Return code zero               |
| <i>rc_one</i>       | (Optional) Return code one                |
| <i>rc_two</i>       | (Optional) Return code two                |
| <i>rc_three</i>     | (Optional) Return code three              |
| <i>rc_four</i>      | (Optional) Return code four               |
| <i>rc_five</i>      | (Optional) Return code five               |
| <i>rc_six</i>       | (Optional) Return code six                |
| <i>rc_seven</i>     | (Optional) Return code seven              |
| <i>rc_eight</i>     | (Optional) Return code eight              |

|                     |                                 |
|---------------------|---------------------------------|
| <i>rc_nine</i>      | (Optional) Return code nine     |
| <i>rc_ten</i>       | (Optional) Return code ten      |
| <i>rc_eleven</i>    | (Optional) Return code eleven   |
| <i>rc_twelve</i>    | (Optional) Return code twelve   |
| <i>rc_thirteen</i>  | (Optional) Return code thirteen |
| <i>rc_fourteen</i>  | (Optional) Return code fourteen |
| <i>summary_flag</i> | (Optional) Summary flag         |

**Command Mode**

- /exec

## show mpls static binding

```
show mpls static binding [ vrf { <vrf-name> | <vrf-known-name> } ] { { ipv4 [ <prefix> { <mask> |
<mask-length> } | <prefix-mask> ] [ local | remote ] [ nexthop <addr> ] [ inconsistency ] [ lsp <slb_name> ]
} | { ipv6 [ <ipv6-prefix> ] [ local | remote ] [ ipv6-nexthop <ipv6-addr> ] [ inconsistency ] } | all [ inconsistency
] } [ __readonly__ [ TABLE_slb [ <slb_name> ] [ <slb_prefix> ] [ <slb_mask> ] <slb_vrf> <slb_inlabel> [
<slb_type> ] [ TABLE_slb_outlbl_list [ <slb_nh_path_num> ] <slb_nhops> <slb_outlabel> ] [
<inconsistency_reason> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information           |
| mpls                  | Display MPLS status and configuration     |
| static                | Show MPLS static information              |
| binding               | Show static label bindings                |
| ipv4                  | Show ipv4 static label bindings           |
| ipv6                  | Show ipv6 static label bindings           |
| all                   | Show all static label bindings            |
| vrf                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>vrf-name</i>       | (Optional) VRF name                       |
| <i>vrf-known-name</i> | (Optional) Known VRF name                 |
| local                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| remote                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| inconsistency         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>prefix</i>         | (Optional) Destination ipv4 prefix        |
| <i>mask</i>           | (Optional) Destination ipv4 prefix mask   |
| <i>mask-length</i>    | (Optional) Ipv4 mask length               |
| <i>prefix-mask</i>    | (Optional) Destination prefix/mask        |
| nexthop               | (Optional) Ipv4 next hop address          |
| <i>addr</i>           | (Optional) Ipv4 Next hop address          |
| ipv6-nexthop          | (Optional) Ipv6 next hop address          |
| lsp                   | (Optional) LSP Name                       |
| __readonly__          | (Optional) Read Only                      |

|                             |  |
|-----------------------------|--|
| TABLE_slb                   | (Optional) Show static label bindings for a given prefix |
| <i>slb_name</i>             | (Optional) Name  |
| <i>slb_prefix</i>           | (Optional) Prefix  |
| <i>slb_type</i>             | (Optional) SLB Type                                      |
| <i>slb_mask</i>             | (Optional) Mask bits                                     |
| <i>slb_vrf</i>              | (Optional) VRF name for prefix                           |
| <i>slb_inlabel</i>          | (Optional) Incoming label for prefix                     |
| TABLE_slb_outlbl_list       | (Optional) Show static outgoing labels for prefix        |
| <i>slb_nhop</i>             | (Optional) Next-hop address                              |
| <i>slb_nh_path_num</i>      | (Optional) Identifier for outgoing nexthop               |
| <i>slb_outlabel</i>         | (Optional) Outgoing label for next-hop address           |
| <i>inconsistency_reason</i> | (Optional) Reason for inconsistency                      |

**Command Mode**

- /exec

## show mpls strip labels

show mpls strip labels [ all | static | dynamic | <label\_val> ] [ \_\_readonly\_\_ <disp\_summary> [ TABLE\_labels <disp\_label> <disp\_age> <disp\_interface> <disp\_pkt\_cnt> <disp\_stats> <disp\_static> ] ]

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information        |
| mpls                  | MPLS information                       |
| strip                 | Stripping of MPLS headers              |
| labels                | labels added in the system             |
| all                   | (Optional) all labels [default]        |
| static                | (Optional) labels programmed using cli |
| dynamic               | (Optional) dynamically learned         |
| <i>label_val</i>      | (Optional) Label to show               |
| <i>__readonly__</i>   | (Optional) Read Only                   |
| <i>disp_summary</i>   | (Optional) Summary                     |
| TABLE_labels          | (Optional) MPLS Strip Labels Tables    |
| <i>disp_label</i>     | (Optional) Label                       |
| <i>disp_age</i>       | (Optional) Age                         |
| <i>disp_interface</i> | (Optional) Interface                   |
| <i>disp_pkt_cnt</i>   | (Optional) Packet Count                |
| <i>disp_stats</i>     | (Optional) Statistics                  |
| <i>disp_static</i>    | (Optional) Static                      |

### Command Mode

- /exec



## show mpls switching

```
show mpls switching [ labels <label> [ <max-label> ] | interface <intf> | { <ip-addr> | <ipv4-prefix> } [ vrf
{ <vrf-name> | <vrf-known-name> | all } ] | <ipv6-prefix> [ vrf { <vrf-name> | <vrf-known-name> | all } ] |
traffic-eng srpath [ <srte-path-id> ] | aggregate [ ipv4 | ipv6 ] [ vrf { <vrf-name> | <vrf-known-name> | all }
] | { fec { ipv4_prefix [ vrf { <vrf-name> | <vrf-known-name> | all } ] | ipv6_prefix [ vrf { <vrf-name> |
<vrf-known-name> | all } ] | deagg [ vrf { <vrf-name> | <vrf-known-name> | all | ias_vpnv4 | ias_vpnv6 } ]
| per-bd <per-bd-vlan-id> } } | { summary } ] [ detail ] [ private ] [ vrf { <vrf-name> | <vrf-known-name> |
all } ] [ _readonly_ [ [ TABLE_vrf [ <vrf_name> ] [ [ TABLE_inlabel <in_label> [ [ { <out_label_stack>
+ } ] [ { <srte_path_id> | <ipv4_prefix> | <ipv6_prefix> } ] [ <out_interface> ] { <ipv4_next_hop> |
<ipv6_next_hop> } [ <weight> ] ] [ <deagg_vrf> [ <deagg_af> ] ] [ { <tunnel_v4_mid_source> |
<tunnel_v6_mid_source> } <tunnel_id> { <ext_v4_tunnel_id> | <ext_v6_tunnel_id> } <tunnel_instance>
<tunnel_head> ] [ <nhlfe_p2p_flag> ] [ <nhlfe_fr_status> ] [ <nhlfe_stale_flag> ] [ <in_packets> <in_bytes>
] [ [ <out_label> + ] <out_packets> + <out_bytes> + ] [ { <tunnel_v4_mid_dest> | <tunnel_v6_mid_dest> }
{ <ipv4_next_hop> | <ipv6_next_hop> } ] [ <per_ce_table> <per_ce_nh_set_id> ] [ { <ias_v4_prefix> |
<ias_v6_prefix> } <ias_rd> ] [ <fec_none_label> ] [ <per_bd_vlan_id> ] [ <table_name> ] ] [
TABLE_adj_sid_inlabel <adj_sid_in_label> <out_label> { <ipv4_addr> | <ipv6_addr> } <out_interface> {
<adj_sid_ipv4_next_hop> | <adj_sid_ipv6_next_hop> } [ <in_packets> <in_bytes> ] [ [ <out_label> + ]
<out_packets> + <out_bytes> + ] ] ] [ TABLE_block <blockid> <lbl_range> ] ] ] ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                                  |
| mpls               | Display MPLS status and configuration                            |
| switching          | Display the MPLS label switching database                        |
| traffic-eng        | (Optional) Show traffic-engineering related entries              |
| srpath             | (Optional) Show traffic-engineering segment-routing path entries |
| <i>ip-addr</i>     | (Optional) Match destination address                             |
| <i>ipv4-prefix</i> | (Optional) Specify an IP prefix/mask                             |
| fec                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                        |
| private            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                        |
| labels             | (Optional) Show a specific label-related information             |
| <i>label</i>       | (Optional) Low label value                                       |
| <i>max-label</i>   | (Optional) High label value                                      |
| interface          | (Optional) Match outgoing interface                              |
| aggregate          | (Optional) Show aggregate-related information                    |
| <i>intf</i>        | (Optional) Specify outgoing interface                            |
| summary            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                        |

|                             |  |
|-----------------------------|--|
| detail                      | (Optional) Detailed information                        |
| ipv4_prefix                 | (Optional) IPv4 prefix                                 |
| ipv6_prefix                 | (Optional) IPv6 prefix                                 |
| ipv4                        | (Optional) Display IPv4 information                    |
| ipv6                        | (Optional) Display IPv6 information                    |
| deagg                       | (Optional) De-aggregation                              |
| per-bd                      | (Optional) BD FEC                                      |
| ias_vpnv4                   | (Optional) Display Inter-AS V4 information             |
| ias_vpnv6                   | (Optional) Display Inter-AS V6 information             |
| <i>srtc-path-id</i>         | (Optional) Traffic-engineering segment-routing path id |
| <i>per-bd-vlan-id</i>       | (Optional) Per BD id                                   |
| vrf                         | (Optional) Display per-VRF information                 |
| <i>vrf-name</i>             | (Optional) VRF name                                    |
| <i>vrf-known-name</i>       | (Optional) Known VRF name                              |
| all                         | (Optional) Display information for all VRFs            |
| __readonly__                | (Optional)   |
| TABLE_vrf                   | (Optional)   |
| <i>vrf_name</i>             | (Optional)   |
| TABLE_inlabel               | (Optional)   |
| <i>in_label</i>             | (Optional)   |
| <i>out_label_stack</i>      | (Optional)   |
| <i>ipv4_prefix</i>          | (Optional)   |
| <i>tunnel_v4_mid_source</i> | (Optional)   |
| <i>tunnel_v4_mid_dest</i>   | (Optional)   |
| <i>tunnel_id</i>            | (Optional)   |
| <i>ext_v4_tunnel_id</i>     | (Optional)   |
| <i>tunnel_instance</i>      | (Optional)   |
| <i>tunnel_head</i>          | (Optional)   |
| <i>deagg_vrf</i>            | (Optional)   |

|                              |            |
|------------------------------|------------|
| <i>deagg_af</i>              | (Optional) |
| <i>out_interface</i>         | (Optional) |
| <i>ipv4_next_hop</i>         | (Optional) |
| <i>ipv6_next_hop</i>         | (Optional) |
| <i>weight</i>                | (Optional) |
| <i>nhlfe_frr_status</i>      | (Optional) |
| <i>nhlfe_stale_flag</i>      | (Optional) |
| <i>nhlfe_p2p_flag</i>        | (Optional) |
| <i>table_name</i>            | (Optional) |
| <i>in_packets</i>            | (Optional) |
| <i>in_bytes</i>              | (Optional) |
| <i>out_label</i>             | (Optional) |
| <i>out_packets</i>           | (Optional) |
| <i>out_bytes</i>             | (Optional) |
| <i>per_ce_table</i>          | (Optional) |
| <i>per_ce_nh_set_id</i>      | (Optional) |
| <i>fec_none_label</i>        | (Optional) |
| <i>ias_v4_prefix</i>         | (Optional) |
| <i>ias_v6_prefix</i>         | (Optional) |
| <i>ias_rd</i>                | (Optional) |
| <i>srte_path_id</i>          | (Optional) |
| <i>per_bd_vlan_id</i>        | (Optional) |
| TABLE_adj_sid_inlabel        | (Optional) |
| <i>adj_sid_in_label</i>      | (Optional) |
| <i>out_label</i>             | (Optional) |
| <i>ipv4_addr</i>             | (Optional) |
| <i>out_interface</i>         | (Optional) |
| <i>adj_sid_ipv4_next_hop</i> | (Optional) |
| <i>adj_sid_ipv6_next_hop</i> | (Optional) |

|                    |            |
|--------------------|------------|
| <i>in_packets</i>  | (Optional) |
| <i>in_bytes</i>    | (Optional) |
| <i>out_packets</i> | (Optional) |
| <i>out_bytes</i>   | (Optional) |
| TABLE_block        | (Optional) |
| <i>blockid</i>     | (Optional) |
| <i>lbl_range</i>   | (Optional) |

**Command Mode**

- /exec

# show mpls switching clients

```
show mpls switching clients [ __readonly__ [ TABLE_client <pib-name> <pib-index> <pib-uuid> <pib-sap>
<stale-time> <pib-flag> [ <stale-due> ] <reg-msg> <conv-msg> [ <inv-conv> ] <fec-msg> <fec-add> <ile-add>
<fec-del> <ile-del> <last-xid> <fec-ack> ] ]
```

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                  |
| mpls              | Display MPLS status and configuration            |
| switching         | Display the MPLS label switching database        |
| clients           | Display ULIB client components                   |
| __readonly__      | (Optional)                                       |
| TABLE_client      | (Optional)                                       |
| <i>pib-name</i>   | (Optional) Name of the client(pib)               |
| <i>pib-index</i>  | (Optional) PIB Index                             |
| <i>pib-uuid</i>   | (Optional) PIB UUID                              |
| <i>pib-sap</i>    | (Optional) MTS SAP for the pib                   |
| <i>stale-time</i> | (Optional) Stale time                            |
| <i>pib-flag</i>   | (Optional) Flags set by the pib                  |
| <i>stale-due</i>  | (Optional) Stale timer due in                    |
| <i>reg-msg</i>    | (Optional) Number of Registration Message        |
| <i>conv-msg</i>   | (Optional) Number of Converge Message            |
| <i>inv-conv</i>   | (Optional) Number of Invalid Convergence message |
| <i>fec-msg</i>    | (Optional) Number of FEC messages                |
| <i>fec-add</i>    | (Optional) Number of FEC Add messages            |
| <i>ile-add</i>    | (Optional) Number of ILE Add messages            |
| <i>fec-del</i>    | (Optional) Number of FEC delete messages         |
| <i>ile-del</i>    | (Optional) Number of ILE delete messages         |
| <i>last-xid</i>   | (Optional) Last XID                              |
| <i>fec-ack</i>    | (Optional) Number of FEC Ack messages sent       |

## Command Mode

- /exec

## show mvpn bgp mdt

```
show mvpn bgp { mdt-safi | auto-discovery } [ mdt-source <src-addr> ] [ __readonly__ { TABLE_entry
<bgp_rd> <mdt_src> <mdt_grp> <local> } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information               |
| mvpn                | Display Multicast VPN information             |
| bgp                 | Display BGP related information               |
| mdt-safi            | Display Auto-discovered BGP MDT-SAFI database |
| auto-discovery      | Display Auto-discovered BGP MDT-SAFI database |
| mdt-source          | (Optional) Source address of MVPN neighbor    |
| <i>src-addr</i>     | (Optional) Source Address                     |
| <i>__readonly__</i> | (Optional)                                    |
| TABLE_entry         | (Optional)                                    |
| <i>bgp_rd</i>       | (Optional)                                    |
| <i>mdt_src</i>      | (Optional)                                    |
| <i>mdt_grp</i>      | (Optional)                                    |
| <i>local</i>        | (Optional)                                    |

### Command Mode

- /exec

## show mvpn bgp mdt

```
show mvpn bgp { mdt-safi | auto-discovery } [ mdt-source <src-addr> ] [ __readonly__ { TABLE_entry
<bgp_rd> <mdt_src> <mdt_grp> <local> } ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information               |
| mvpn           | Display Multicast VPN information             |
| bgp            | Display BGP related information               |
| mdt-safi       | Display Auto-discovered BGP MDT-SAFI database |
| auto-discovery | Display Auto-discovered BGP MDT-SAFI database |
| mdt-source     | (Optional) Source address of MVPN neighbor    |
| __readonly__   | (Optional)                                    |
| TABLE_entry    | (Optional)                                    |
| <i>bgp_rd</i>  | (Optional)                                    |
| <i>local</i>   | (Optional)                                    |

### Command Mode

- /exec



# show mvpn mdt encap

```
show mvpn mdt encap [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<out_context> { TABLE_encap <encap_index> <mdt_grp> <mdt_src> <mdt_src_if> } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| mvpn                  | Display Multicast VPN information           |
| mdt                   | Display MDT information                     |
| encap                 | Display MDT Encap table                     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>__readonly__</i>   | (Optional)                                  |
| <i>TABLE_vrf</i>      | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| <i>TABLE_encap</i>    | (Optional)                                  |
| <i>encap_index</i>    | (Optional)                                  |
| <i>mdt_src_if</i>     | (Optional)                                  |

## Command Mode

- /exec

# show mvpn mdt encap

```
show mvpn mdt encap [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<out_context> { TABLE_encap <encap_index> <mdt_grp> <mdt_src> <mdt_src_if> } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| mvpn                  | Display Multicast VPN information           |
| mdt                   | Display MDT information                     |
| encap                 | Display MDT Encap table                     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>out_context</i>    | (Optional)                                  |
| TABLE_encap           | (Optional)                                  |
| <i>encap_index</i>    | (Optional)                                  |
| <i>mdt_grp</i>        | (Optional)                                  |
| <i>mdt_src</i>        | (Optional)                                  |
| <i>mdt_src_if</i>     | (Optional)                                  |

## Command Mode

- /exec

# show mvpn mdt route

```
show mvpn mdt route [ detail ] [ __readonly__ TABLE_vrf <out_context> [ TABLE_mroute <src_addr>
<grp_addr> <uptime> <ref_count> ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information         |
| mvpn                | Display Multicast VPN information       |
| mdt                 | Display MDT information                 |
| route               | Display MDT route information           |
| detail              | (Optional) Display detailed information |
| <i>__readonly__</i> | (Optional)                              |
| TABLE_vrf           | (Optional)                              |
| <i>out_context</i>  | (Optional)                              |
| TABLE_mroute        | (Optional)                              |
| <i>src_addr</i>     | (Optional)                              |
| <i>grp_addr</i>     | (Optional)                              |
| <i>uptime</i>       | (Optional)                              |
| <i>ref_count</i>    | (Optional)                              |

## Command Mode

- /exec

## show mvpn mdt route

```
show mvpn mdt route [ detail ] [ __readonly__ TABLE_vrf <out_context> [ TABLE_mroute <src_addr>
<grp_addr> <uptime> <ref_count> [ <route_type> ] [ <group_mode> ] [ <route_flags> ] ] ]
```

### Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information         |
| mvpn               | Display Multicast VPN information       |
| mdt                | Display MDT information                 |
| route              | Display MDT route information           |
| detail             | (Optional) Display detailed information |
| __readonly__       | (Optional)                              |
| TABLE_vrf          | (Optional)                              |
| <i>out_context</i> | (Optional)                              |
| TABLE_mroute       | (Optional)                              |
| <i>src_addr</i>    | (Optional)                              |
| <i>grp_addr</i>    | (Optional)                              |
| <i>uptime</i>      | (Optional)                              |
| <i>ref_count</i>   | (Optional)                              |
| <i>route_type</i>  | (Optional)                              |
| <i>group_mode</i>  | (Optional)                              |
| <i>route_flags</i> | (Optional)                              |

### Command Mode

- /exec

# show mvr

```
show mvr [ verbose ] [ __readonly__ <mvr-status> <mvr-default-vlan> <number-of-mvr-vlans> [
<mvr-group-list> <cfg-nodes> <interface-cfg-nodes> ] ]
```

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information           |
| mvr                        | show mvr info                             |
| verbose                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__               | (Optional)                                |
| <i>mvr-status</i>          | (Optional)                                |
| <i>mvr-default-vlan</i>    | (Optional)                                |
| <i>number-of-mvr-vlans</i> | (Optional)                                |
| <i>mvr-group-list</i>      | (Optional)                                |
| <i>cfg-nodes</i>           | (Optional)                                |
| <i>interface-cfg-nodes</i> | (Optional)                                |

## Command Mode

- /exec

## show mvr groups

```
show mvr groups [ __readonly__ [ TABLE_group_list <ip-address> <ip-max-addr> <rn-count-char> <rn-count>
<mvr-vlan-string> <if-name> ] [ [ <interface-name> ] [ <mvr-vlan> ] [ TABLE_mvr_vlan <global-mvr-vlan>
] <mvr-groups> <mvr-receiver-type> <mvr-source-type> ] ]
```

### Syntax Description

|                          |                                 |
|--------------------------|---------------------------------|
| show                     | Show running system information |
| mvr                      | show mvr info                   |
| groups                   | show mvr groups config          |
| <i>__readonly__</i>      | (Optional)                      |
| <i>TABLE_group_list</i>  | (Optional)                      |
| <i>ip-address</i>        | (Optional)                      |
| <i>ip-max-addr</i>       | (Optional)                      |
| <i>rn-count-char</i>     | (Optional)                      |
| <i>rn-count</i>          | (Optional)                      |
| <i>mvr-vlan-string</i>   | (Optional)                      |
| <i>if-name</i>           | (Optional)                      |
| <i>interface-name</i>    | (Optional)                      |
| <i>mvr-vlan</i>          | (Optional)                      |
| <i>TABLE_mvr_vlan</i>    | (Optional)                      |
| <i>global-mvr-vlan</i>   | (Optional)                      |
| <i>mvr-groups</i>        | (Optional)                      |
| <i>mvr-receiver-type</i> | (Optional)                      |
| <i>mvr-source-type</i>   | (Optional)                      |

### Command Mode

- /exec

# show mvr interface

```
show mvr interface [ <if0> ] [ __readonly__ [ TABLE_if_name <interface-name> <access-vlan> <src-rcvr>
<igmp-mvr-port-status> <mvr-vlan-str> ] ]
```

## Syntax Description

|                             |                                 |
|-----------------------------|---------------------------------|
| show                        | Show running system information |
| mvr                         | show mvr info                   |
| interface                   | show mvr interfaces             |
| <i>if0</i>                  | (Optional) Interface name       |
| <i>__readonly__</i>         | (Optional)                      |
| <i>TABLE_if_name</i>        | (Optional)                      |
| <i>interface-name</i>       | (Optional)                      |
| <i>access-vlan</i>          | (Optional)                      |
| <i>src-rcvr</i>             | (Optional)                      |
| <i>igmp-mvr-port-status</i> | (Optional)                      |
| <i>mvr-vlan-str</i>         | (Optional)                      |

## Command Mode

- /exec

## show mvr members

```
show mvr members [ interface <if0> ] [ __readonly__ [ TABLE_mvr_vlan <mvr-vlan> <group> <status> [
TABLE_members_if <if-name> ] ] [ <vlan> <mvr-group> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                       |
| mvr                     | show mvr info   |
| members                 | show active mvr groups                                |
| interface               | (Optional) show active mvr groups config on interface |
| <i>if0</i>              | (Optional) Interface name                             |
| <i>__readonly__</i>     | (Optional)  |
| <i>TABLE_mvr_vlan</i>   | (Optional)  |
| <i>mvr-vlan</i>         | (Optional)  |
| <i>group</i>            | (Optional)  |
| <i>status</i>           | (Optional)  |
| <i>TABLE_members_if</i> | (Optional)  |
| <i>if-name</i>          | (Optional)  |
| <i>vlan</i>             | (Optional)  |
| <i>mvr-group</i>        | (Optional)  |

### Command Mode

- /exec



# show mvr members count

```
show mvr members count [ __readonly__ [ TABLE_mvr_vlan <mvr-vlan> <mvr-members-count> ] ]
```

## Syntax Description

|                          |                                    |
|--------------------------|------------------------------------|
| show                     | Show running system information    |
| mvr                      | show mvr info                      |
| members                  | show active mvr groups             |
| count                    | Active mvr groups on each mvr-vlan |
| <i>__readonly__</i>      | (Optional)                         |
| <i>TABLE_mvr_vlan</i>    | (Optional)                         |
| <i>mvr-vlan</i>          | (Optional)                         |
| <i>mvr-members-count</i> | (Optional)                         |

## Command Mode

- /exec

## show mvr members vlan

```
show mvr members { vlan <vlan-id> } [ __readonly__ [ TABLE_mvr_vlan <mvr-vlan> <grp> <stat> [
TABLE_interface_vlan <interface-name> ] ] ]
```

### Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| mvr                   | show mvr info                   |
| members               | show active mvr groups          |
| vlan                  | vlan                            |
| <i>vlan-id</i>        | Enter MVR Vlan                  |
| <i>__readonly__</i>   | (Optional)                      |
| TABLE_mvr_vlan        | (Optional)                      |
| <i>mvr-vlan</i>       | (Optional)                      |
| <i>grp</i>            | (Optional)                      |
| <i>stat</i>           | (Optional)                      |
| TABLE_interface_vlan  | (Optional)                      |
| <i>interface-name</i> | (Optional)                      |

### Command Mode

- /exec

## show mvr receiver-ports

```
show mvr receiver-ports [ <if0> ] [ __readonly__ [ TABLE_mvr_if_name <mvr-if-name> <mvr-vlan-str>
<igmp-port-status> <rx_reports> <rx_leaves> ] ]
```

### Syntax Description

|                          |                                 |
|--------------------------|---------------------------------|
| show                     | Show running system information |
| mvr                      | show mvr info                   |
| receiver-ports           | List MVR receiver ports         |
| <i>if0</i>               | (Optional) Interface name       |
| <i>__readonly__</i>      | (Optional)                      |
| <i>TABLE_mvr_if_name</i> | (Optional)                      |
| <i>mvr-if-name</i>       | (Optional)                      |
| <i>mvr-vlan-str</i>      | (Optional)                      |
| <i>igmp-port-status</i>  | (Optional)                      |
| <i>rx_reports</i>        | (Optional)                      |
| <i>rx_leaves</i>         | (Optional)                      |

### Command Mode

- /exec

# show mvr source-ports

```
show mvr source-ports [ <if0> ] [ __readonly__ [ TABLE_mvr_if_name <mvr-if-name> <interface-name>
<igmp-port-status> ] ]
```

## Syntax Description

|                          |                                 |
|--------------------------|---------------------------------|
| show                     | Show running system information |
| mvr                      | show mvr info                   |
| source-ports             | List MVR source ports           |
| <i>if0</i>               | (Optional) Interface name       |
| <i>__readonly__</i>      | (Optional)                      |
| <i>TABLE_mvr_if_name</i> | (Optional)                      |
| <i>mvr-if-name</i>       | (Optional)                      |
| <i>interface-name</i>    | (Optional)                      |
| <i>igmp-port-status</i>  | (Optional)                      |

## Command Mode

- /exec



## N Show Commands

---

- [show nat itd](#), on page 2185
- [show nbm defaults](#), on page 2186
- [show nbm flow-policy](#), on page 2188
- [show nbm flows](#), on page 2190
- [show nbm flows pending-stitch](#), on page 2194
- [show nbm flows static](#), on page 2195
- [show nbm flows statistics](#), on page 2197
- [show nbm flows summary](#), on page 2199
- [show nbm host-policy all](#), on page 2200
- [show nbm host-policy applied receiver](#), on page 2202
- [show nbm host-policy applied sender](#), on page 2204
- [show nbm interface bandwidth](#), on page 2206
- [show ngoam interface statistics](#), on page 2208
- [show ngoam loop-detection status](#), on page 2209
- [show ngoam loop-detection summary](#), on page 2210
- [show ngoam loopback](#), on page 2211
- [show ngoam pathtrace](#), on page 2213
- [show ngoam probe](#), on page 2217
- [show ngoam traceroute statistics](#), on page 2219
- [show ngoam xconnect session](#), on page 2221
- [show npiv status](#), on page 2223
- [show npv external-interface-usage](#), on page 2224
- [show npv flogi-table](#), on page 2225
- [show npv status](#), on page 2226
- [show npv traffic-map](#), on page 2228
- [show ntp access-groups](#), on page 2229
- [show ntp authentication-keys](#), on page 2230
- [show ntp authentication-status](#), on page 2231
- [show ntp information](#), on page 2232
- [show ntp logging-status](#), on page 2233
- [show ntp peer-status](#), on page 2234
- [show ntp peers](#), on page 2235
- [show ntp rts-update](#), on page 2236

- [show ntp session status](#), on page 2237
- [show ntp source-interface](#), on page 2238
- [show ntp source](#), on page 2239
- [show ntp statistics](#), on page 2240
- [show ntp status](#), on page 2243
- [show ntp trusted-keys](#), on page 2244
- [show nve adjacency mpls](#), on page 2245
- [show nve bfd neighbors](#), on page 2246
- [show nve core-links](#), on page 2247
- [show nve ethernet-segment](#), on page 2248
- [show nve evi](#), on page 2250
- [show nve interface](#), on page 2251
- [show nve mpls](#), on page 2253
- [show nve multisite dci-links](#), on page 2254
- [show nve multisite fabric-links](#), on page 2255
- [show nve peers](#), on page 2256
- [show nve peers interface counters](#), on page 2258
- [show nve peers mpls](#), on page 2259
- [show nve peers vni interface counters](#), on page 2260
- [show nve replication-servers](#), on page 2261
- [show nve vni](#), on page 2262
- [show nve vni counters](#), on page 2264
- [show nve vni ingress-replication](#), on page 2265
- [show nve vni peer-vtep](#), on page 2266
- [show nve vrf](#), on page 2267
- [show nve vxlan-params](#), on page 2268
- [show nxapi-server logs](#), on page 2269
- [show nxapi](#), on page 2270

## show nat itd

```
show nat itd [ __readonly__ [ { TABLE_NAT_ITD_configurations [ <nat_itd_acl_name> ] [ <nat_itd_globalip> ] [ <nat_itd_globalport> ] [ <nat_itd_localip> ] [ <nat_itd_localport> ] [ <nat_itd_proto> ] } ] ]
```

### Syntax Description

|                              |                                      |
|------------------------------|--------------------------------------|
| show                         | Show running system information      |
| nat                          | IP NAT information                   |
| itd                          | IP NAT ITD                           |
| __readonly__                 | (Optional)                           |
| TABLE_NAT_ITD_configurations | (Optional) NAT ITD Configurations    |
| <i>nat_itd_acl_name</i>      | (Optional) NAT ITD ACL name          |
| <i>nat_itd_globalip</i>      | (Optional) NAT ITD Global Ip address |
| <i>nat_itd_globalport</i>    | (Optional) NAT ITD Global port       |
| <i>nat_itd_localip</i>       | (Optional) NAT ITD Local Ip address  |
| <i>nat_itd_localport</i>     | (Optional) NAT ITD Local port        |
| <i>nat_itd_proto</i>         | (Optional) NAT ITD protocol          |

### Command Mode

- /exec

## show nbm defaults

```
show nbm defaults [ vrf { <vrf-name> | <nbm-vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<vrfName> { <contextId> <bandwidthInKbps> <dscp> <qid> <policer> <operModeCache> <operMode>
<unicastFabricBandwidth> <ResBwRxOnly> <numAsmGroup> } [ TABLE_ASM <groupId> { <groupPrefix>
<groupMaskLen> } ] { <senderPolicy> <localReceiverPolicy> <externalReceiverPolicy> } ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information            |
| nbm                           | Non Blocking Multicast                     |
| defaults                      | Default config                             |
| vrf                           | (Optional) Display per-VRF information     |
| all                           | (Optional) Display all VRFs                |
| <i>vrf-name</i>               | (Optional) VRF name                        |
| <i>nbm-vrf-known-name</i>     | (Optional) NBM VRF Name                    |
| <i>__readonly__</i>           | (Optional)                                 |
| TABLE_vrf                     | (Optional) VRF table                       |
| <i>vrfName</i>                | (Optional) VRF name                        |
| <i>contextId</i>              | (Optional) Context ID                      |
| <i>bandwidthInKbps</i>        | (Optional) Bandwidth in Kbps               |
| <i>dscp</i>                   | (Optional) DSCP                            |
| <i>qid</i>                    | (Optional) Queue ID                        |
| <i>policer</i>                | (Optional) Policer                         |
| <i>operModeCache</i>          | (Optional) Operation Mode Cache            |
| <i>operMode</i>               | (Optional) Operation Mode                  |
| <i>unicastFabricBandwidth</i> | (Optional) Unicast fabric bandwidth        |
| <i>ResBwRxOnly</i>            | (Optional) Reserve Bandwidth Receiver Only |
| <i>numAsmGroup</i>            | (Optional) Number of ASM Groups            |
| TABLE_ASM                     | (Optional) ASM Group Table                 |
| <i>groupId</i>                | (Optional) Group number                    |
| <i>groupPrefix</i>            | (Optional) Group Prefix                    |



|                               |   |
|-------------------------------|---|
| <i>groupMaskLen</i>           | (Optional) Group Mask Length              |
| <i>senderPolicy</i>           | (Optional) Sender Policy                  |
| <i>localReceiverPolicy</i>    | (Optional) Local Receiver Policy          |
| <i>externalReceiverPolicy</i> | (Optional) External Receiver Policy (PIM) |

**Command Mode**

- /exec

## show nbm flow-policy

```
show nbm flow-policy [ name { <policy-name> } ] [ vrf { <vrf-name> | <nbm-vrf-known-name> | all } ] [
__readonly__ TABLE_vrf { <vrfName> [ <policyName> ] [ { <defaultBandwidthKbps> <defaultDscp>
<defaultQos> <defaultPolicer> } ] [ { TABLE_flow_policy <groupRange> <bandwidthKbps> <dscp> <qos>
<policer> <priority> <policyName> } ] <numGroupRanges> <numPolicies> } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information        |
| nbm                         | Non Blocking Multicast                 |
| flow-policy                 | Flow policy show command               |
| name                        | (Optional) Policy name                 |
| <i>policy-name</i>          | (Optional) Policy name value           |
| vrf                         | (Optional) Display per-VRF information |
| all                         | (Optional) Display all VRFs            |
| <i>vrf-name</i>             | (Optional) VRF name                    |
| <i>nbm-vrf-known-name</i>   | (Optional) NBM VRF Name                |
| <i>__readonly__</i>         | (Optional)                             |
| TABLE_vrf                   | (Optional) VRF table                   |
| <i>vrfName</i>              | (Optional) VRF name                    |
| <i>policyName</i>           | (Optional) Policy name                 |
| <i>defaultBandwidthKbps</i> | (Optional) Default Bandwidth in Kbps   |
| <i>defaultDscp</i>          | (Optional) Default DSCP                |
| <i>defaultQos</i>           | (Optional) Default QOS                 |
| <i>defaultPolicer</i>       | (Optional) Default Policer             |
| TABLE_flow_policy           | (Optional) Flow policies in VRF        |
| <i>groupRange</i>           | (Optional) Group range                 |
| <i>bandwidthKbps</i>        | (Optional) Bandwidth in Kbps           |
| <i>dscp</i>                 | (Optional) DSCP                        |
| <i>qos</i>                  | (Optional) QOS                         |
| <i>policer</i>              | (Optional) Policer                     |

|                       |   |
|-----------------------|---|
| <i>priority</i>       | (Optional) Priority                       |
| <i>policyName</i>     | (Optional) Policy Name                    |
| <i>numGroupRanges</i> | (Optional) Number of group or group-range |
| <i>numPolicies</i>    | (Optional) Number of flow policies        |

**Command Mode**

- /exec

## show nbm flows

```
show nbm flows [ group-based [ group <group-ip> ] | { flow-policy { <cfg-pol-name> | <unknown-pol-name> } } | source <source-ip> [ group <group-ip> ] | group <group-ip> [ source <source-ip> ] | interface <if-name> | priority { low | critical } | logical-id { none | any | <lid-val> } | profile-id <prof-id> ] [ all | active | inactive | no-receiver ] [ detail ] [ vrf { <vrf-name> | <nbm-vrf-known-name> | all } ] [ _readonly_ [ TABLE_vrf <vrf-name> [ TABLE_flows { <mcast_grp> <src_ip> [ <start_time> ] <uptime> <src_intf> <src_nbr_device> [ <lid> <profile> <status> ] <num_rx> <bw_mbps> [ <cfg_mbps> ] <src_slot> <src_unit> <src_slice> } [ { <act_slot> <act_unit> <stdby_slot> <stdby_unit> } ] } { <dscp> <qos> [ <owner_type> ] <policed> [ <is_fhr> ] <priority> <pol_name> } [ <flag> ] [ TABLE_num_int_links { <n_link> <num_links> } ] [ TABLE_int_links { <iiod> <ilink> <i_ifidx> <fab_iiod> <fab_oiod> <fab_ifidx> <oiod> <olink> <i_ieth_port> <fab_ieth_port> } ] [ TABLE_oifs { [ <oif_num> ] <oif_slot> <oif_unit> <oif_slot_unit_num_rx> <oif_if_idx> <oif_ioid> <oif_name> <oif_nbr_device> } ] [ { <end_timestr> <flow_rate_bps> <packets> <bytes> } ] ] ] ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                                |
| nbm                     | Non Blocking Multicast   |
| flows                   | NBM flows (default will be active flows)                       |
| active                  | (Optional) Active flows (default)                              |
| inactive                | (Optional) Inactive flows                                      |
| no-receiver             | (Optional) Flows without any receiver                          |
| all                     | (Optional) Both active and inactive flows                      |
| group-based             | (Optional) Multicast group based (*,G) flows to IGMP receivers |
| flow-policy             | (Optional) Flow policy   |
| <i>cfg-pol-name</i>     | (Optional) Policy name   |
| <i>unknown-pol-name</i> | (Optional) Policy name   |
| source                  | (Optional) Source IP address                                   |
| <i>source-ip</i>        | (Optional) Source IP address                                   |
| group                   | (Optional) Multicast group                                     |
| <i>group-ip</i>         | (Optional) Multicast group address                             |
| interface               | (Optional) Ingress interface                                   |
| priority                | (Optional) Flow Priority                                       |
| low                     | (Optional) low   |
| critical                | (Optional) critical  |

|                       |   |
|-----------------------|---|
| logical-id            | (Optional) Logical ID (LID)             |
| <i>lid-val</i>        | (Optional) Logical ID (LID) value       |
| any                   | (Optional) Any Logical ID (LID)         |
| none                  | (Optional) Without any Logical ID (LID) |
| profile-id            | (Optional) Profile ID                   |
| <i>prof-id</i>        | (Optional) Profile ID value             |
| detail                | (Optional) Detailed output              |
| <i>if-name</i>        | (Optional) Interface name               |
| __readonly__          | (Optional)                              |
| TABLE_vrf             | (Optional) VRF table                    |
| <i>vrf-name</i>       | (Optional) VRF name                     |
| TABLE_flows           | (Optional) Flow table                   |
| <i>mcast_grp</i>      | (Optional) Multicast group IP           |
| <i>src_ip</i>         | (Optional) Source IP                    |
| <i>start_time</i>     | (Optional) Start time for the flow      |
| <i>uptime</i>         | (Optional) Uptime for the flow          |
| <i>src_intf</i>       | (Optional) Ingress source interface     |
| <i>src_nbr_device</i> | (Optional) Ingress neighbor device name |
| <i>lid</i>            | (Optional) Logical internal flow ID     |
| <i>profile</i>        | (Optional) Profile ID                   |
| <i>status</i>         | (Optional) Flow status                  |
| <i>num_rx</i>         | (Optional) Number of receivers (OIFs)   |
| <i>bw_mbps</i>        | (Optional) Set bandwidth                |
| <i>cfg_mbps</i>       | (Optional) Configured bandwidth         |
| <i>src_slot</i>       | (Optional) Source (RPF) slot            |
| <i>src_unit</i>       | (Optional) Source (RPF) unit            |
| <i>src_slice</i>      | (Optional) Source (RPF) slice           |
| <i>dscp</i>           | (Optional) Flow DSCP                    |
| <i>qos</i>            | (Optional) Flow QOS group               |

|                           |   |
|---------------------------|---|
| <i>owner_type</i>         | (Optional) Flow Owner type                                  |
| <i>policed</i>            | (Optional) Flow is policed or not                           |
| <i>is_fhr</i>             | (Optional) This node is FHR (First-Hop Router) for the Flow |
| <i>priority</i>           | (Optional) Priority   |
| <i>pol_name</i>           | (Optional) Flow Policy name                                 |
| vrf                       | (Optional) Display per-VRF information                      |
| all                       | (Optional) Display all VRFs                                 |
| <i>vrf-name</i>           | (Optional) VRF name   |
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name                                     |
| <i>act_slot</i>           | (Optional) Active FM Slot                                   |
| <i>act_unit</i>           | (Optional) Active FM Unit                                   |
| <i>stdby_slot</i>         | (Optional) Standby FM Slot                                  |
| <i>stdby_unit</i>         | (Optional) Standby FM Unit                                  |
| <i>flag</i>               | (Optional) Flow not guarantee flag                          |
| TABLE_num_int_links       | (Optional) Internal link number table                       |
| <i>n_link</i>             | (Optional) N Link   |
| <i>num_links</i>          | (Optional) Number of Links                                  |
| TABLE_int_links           | (Optional) Internal link table                              |
| <i>iiod</i>               | (Optional) IIOD   |
| <i>ilink</i>              | (Optional) Ilink  |
| <i>i_ifidx</i>            | (Optional) Internal IF IDX                                  |
| <i>fab_iiod</i>           | (Optional) Fabric IIOD                                      |
| <i>fab_oiod</i>           | (Optional) Fabric OIOD                                      |
| <i>fab_ifidx</i>          | (Optional) Fabric IFIDX                                     |
| <i>oiod</i>               | (Optional) OIOD   |
| <i>olink</i>              | (Optional) OLink  |
| <i>i_ieth_port</i>        | (Optional) Internal IEth Link                               |
| <i>fab_ieth_port</i>      | (Optional) Fabric IEth Port                                 |
| TABLE_oifs                | (Optional) OIF table  |

|                             |  |
|-----------------------------|--|
| <i>oif_num</i>              | (Optional) Receiver serial number            |
| <i>oif_slot</i>             | (Optional) Slot                              |
| <i>oif_unit</i>             | (Optional) Unit                              |
| <i>oif_slot_unit_num_rx</i> | (Optional) Number of Receivers for slot/unit |
| <i>oif_if_idx</i>           | (Optional) Receiver interface index          |
| <i>oif_iod</i>              | (Optional) Outgoing IOD                      |
| <i>oif_name</i>             | (Optional) Outgoing interface name           |
| <i>oif_nbr_device</i>       | (Optional) Outgoing neighbor device name     |
| <i>end_timestr</i>          | (Optional) Deleted flow end time             |
| <i>flow_rate_bps</i>        | (Optional) Deleted flow flow rate in bps     |
| <i>packets</i>              | (Optional) Deleted flow packets              |
| <i>bytes</i>                | (Optional) Deleted flow bytes                |

**Command Mode**

- /exec

## show nbm flows pending-stitch

```
show nbm flows pending-stitch [ vrf { <vrf-name> | <nbm-vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf<vrf-name> [ TABLE_pending_stitch_flows { <src_ip> <grp> <ctx_name> <mrrib_del> <star_g>
<pending_type> <pending_type_str> } ] <num_entries> ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information         |
| nbm                        | Non Blocking Multicast                  |
| flows                      | NBM flows                               |
| pending-stitch             | All pending stitch flows                |
| __readonly__               | (Optional)                              |
| TABLE_vrf                  | (Optional) VRF TABLE                    |
| <i>vrf-name</i>            | (Optional) VRF name                     |
| vrf                        | (Optional) Display per-VRF information  |
| all                        | (Optional) Display all VRFs             |
| <i>vrf-name</i>            | (Optional) VRF name                     |
| <i>nbm-vrf-known-name</i>  | (Optional) NBM VRF Name                 |
| TABLE_pending_stitch_flows | (Optional) Pending stitch flows         |
| <i>src_ip</i>              | (Optional) Source IP                    |
| <i>grp</i>                 | (Optional) Group IP                     |
| <i>ctx_name</i>            | (Optional) Context name                 |
| <i>mrrib_del</i>           | (Optional) Deleted from MRIB            |
| <i>star_g</i>              | (Optional) Star g flow                  |
| <i>pending_type</i>        | (Optional) pending type for flow        |
| <i>pending_type_str</i>    | (Optional) pending type for flow string |
| <i>num_entries</i>         | (Optional) Number of entries            |

### Command Mode

- /exec



## show nbm flows static

```
show nbm flows static [ group <grp> ] [ source <src> ] [ stitched | unstitched ] [ vrf { <vrf-name> |
<nbm-vrf-known-name> | all } ] [ __readonly__ { [ TABLE_vrf <vrf-name> [ TABLE_stitched { <stitchedSrc>
<stitchedGrp> [ TABLE_stitchedEgress { <stitchedEgressIntf> } ] [ TABLE_stitchedHost { <stitchedHostIp>
} ] } ] [ TABLE_unstitched { <unstitchedSrc> <unstitchedGrp> [ TABLE_unstitchedEgress {
<unstitchedEgressIntf> } ] [ TABLE_unstitchedHost { <unstitchedHostIp> } ] } ] [
TABLE_Provisioned_Static_Flows { [ <staticApiSrc> ] [ <staticApiGrp> ] } [ <iifName> ] [ <bwkbps> ] [
<policer> ] [ <iifProgStatus> ] [ TABLE_OIF { [ <isLhr> ] [ <oifName> ] [ <oifProgStatus> ] } ] ] ] ] }
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                   |
| nbm                       | Non Blocking Multicast                            |
| flows                     | NBM flows (default will be active flows)          |
| static                    | Static NBM Flows                                  |
| group                     | (Optional) Multicast group                        |
| <i>grp</i>                | (Optional) Multicast group address                |
| source                    | (Optional) Source ip of sender                    |
| <i>src</i>                | (Optional) Source address                         |
| stitched                  | (Optional) Show only successfully provisioned oif |
| unstitched                | (Optional) Show only failed to provision oif      |
| vrf                       | (Optional) Display per-VRF information            |
| all                       | (Optional) Display all VRFs                       |
| <i>vrf-name</i>           | (Optional) VRF name                               |
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name                           |
| <i>__readonly__</i>       | (Optional)  |
| TABLE_vrf                 | (Optional) VRF table                              |
| <i>vrf-name</i>           | (Optional) VRF name                               |
| TABLE_stitched            | (Optional) Static Flows stitched table            |
| <i>stitchedSrc</i>        | (Optional) Source IP address stitched             |
| <i>stitchedGrp</i>        | (Optional) Multicast Group address stitched       |
| TABLE_stitchedEgress      | (Optional) Egress Intferace table stitched flows  |
| <i>stitchedEgressIntf</i> | (Optional) Egress Interface for stitched flows    |

|                                |   |
|--------------------------------|---|
| TABLE_stitchedHost             | (Optional) Host IP table for stitched flows             |
| <i>stitchedHostIp</i>          | (Optional) Host IP address for stitched flows           |
| TABLE_unstitched               | (Optional) Static Flows unstitched                      |
| <i>unstitchedSrc</i>           | (Optional) Source IP address unstitched                 |
| <i>unstitchedGrp</i>           | (Optional) Multicast Group address unstitched           |
| TABLE_unstitchedEgress         | (Optional) Egress Interface table unstitched flows      |
| <i>unstitchedEgressIntf</i>    | (Optional) Egress Interface for unstitched flows        |
| TABLE_unstitchedHost           | (Optional) Host IP table for unstitched flows           |
| <i>unstitchedHostIp</i>        | (Optional) Host IP address for unstitched flows         |
| TABLE_Provisioned_Static_Flows | (Optional) Provisioned Static Flows                     |
| <i>staticApiSrc</i>            | (Optional) Source IP address for Pim Passive            |
| <i>staticApiGrp</i>            | (Optional) Multicast Group address for Pim Passive      |
| <i>iifName</i>                 | (Optional) Ingress Interface name                       |
| <i>bwkbps</i>                  | (Optional) BW in Kbps                                   |
| <i>policer</i>                 | (Optional) Policer                                      |
| <i>iifProgStatus</i>           | (Optional) Ingress Interface Prog Status                |
| TABLE_OIF                      | (Optional) Egress Interface table for Pim Passive flows |
| <i>isLhr</i>                   | (Optional) Is LHR                                       |
| <i>oifName</i>                 | (Optional) Egress Interface Name                        |
| <i>oifProgStatus</i>           | (Optional) OIF Interface Prog Status                    |

**Command Mode**

- /exec

## show nbm flows statistics

```
show nbm flows statistics [ group-based [ group <group-ip> ] | source <source-ip> [ group <group-ip> ] |
group <group-ip> [ source <source-ip> ] | { flow-policy { <cfg-pol-name> | <unknown-pol-name> } } |
interface <if-name> | logical-id { none | any | <lid-val> } | profile-id <prof-id> ] [ vrf { <vrf-name> |
<nbm-vrf-known-name> | all } ] [ __readonly__ { [ TABLE_vrf <vrf-name> [ TABLE_stats { <mcast_grp>
<src_ip> [ <start_time> ] <uptime> <src_intf> <packets> <bytes> <allow_bytes> <drop_bytes> } ] } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                                |
| nbm                     | Non Blocking Multicast   |
| flows                   | NBM flows  |
| statistics              | Flow statistics  |
| group-based             | (Optional) Multicast group based (*,G) flows to IGMP receivers |
| source                  | (Optional) Source IP address                                   |
| <i>source-ip</i>        | (Optional) Source IP address value                             |
| group                   | (Optional) Multicast group                                     |
| <i>group-ip</i>         | (Optional) Multicast group address value                       |
| flow-policy             | (Optional) Flow policy   |
| <i>cfg-pol-name</i>     | (Optional) Policy name   |
| <i>unknown-pol-name</i> | (Optional) Policy name   |
| interface               | (Optional) Ingress interface                                   |
| <i>if-name</i>          | (Optional) Interface interface name                            |
| logical-id              | (Optional) Logical ID (LID)                                    |
| <i>lid-val</i>          | (Optional) Logical ID (LID) value                              |
| any                     | (Optional) Any Logical ID (LID)                                |
| none                    | (Optional) Without any Logical ID (LID)                        |
| profile-id              | (Optional) Profile ID  |
| <i>prof-id</i>          | (Optional) Profile ID value                                    |
| vrf                     | (Optional) Display per-VRF information                         |
| all                     | (Optional) Display all VRFs                                    |
| <i>vrf-name</i>         | (Optional) VRF name  |

|                           |                                     |
|---------------------------|-------------------------------------|
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name             |
| <i>__readonly__</i>       | (Optional)                          |
| <i>TABLE_vrf</i>          | (Optional) VRF table                |
| <i>vrf-name</i>           | (Optional) VRF name                 |
| <i>TABLE_stats</i>        | (Optional) Flow stats table         |
| <i>mcast_grp</i>          | (Optional) Multicast group IP       |
| <i>src_ip</i>             | (Optional) Source IP                |
| <i>start_time</i>         | (Optional) Start time for the flow  |
| <i>uptime</i>             | (Optional) Uptime for the flow      |
| <i>src_intf</i>           | (Optional) Ingress source interface |
| <i>packets</i>            | (Optional) Packets                  |
| <i>bytes</i>              | (Optional) Bytes                    |
| <i>allow_bytes</i>        | (Optional) Allowed bytes            |
| <i>drop_bytes</i>         | (Optional) Dropped bytes            |

**Command Mode**

- /exec

# show nbm flows summary

```
show nbm flows summary [ vrf { <vrf-name> | <nbm-vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf
<vrf-name> [ TABLE_flows_summary <flow_type> <starg> <sg> <total> ] [ TABLE_flows_summary_per_rpf
<if-name> <starg> <sg> <total> ] ] ]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information        |
| nbm                         | Non Blocking Multicast                 |
| flows                       | NBM Flows                              |
| summary                     | NBM Flow Summary                       |
| vrf                         | (Optional) Display per-VRF information |
| all                         | (Optional) Display all VRFs            |
| <i>vrf-name</i>             | (Optional) VRF name                    |
| <i>nbm-vrf-known-name</i>   | (Optional) NBM VRF Name                |
| __readonly__                | (Optional)                             |
| TABLE_vrf                   | (Optional) VRF table                   |
| <i>vrf-name</i>             | (Optional) VRF name                    |
| TABLE_flows_summary         | (Optional) Flow summary table          |
| <i>flow_type</i>            | (Optional) Type of Flow Summary        |
| <i>sg</i>                   | (Optional) (S,G) number of flows       |
| <i>starg</i>                | (Optional) (*,G) number of flows       |
| <i>total</i>                | (Optional) Total Flows                 |
| TABLE_flows_summary_per_rpf | (Optional) Flow summary table per RPF  |
| <i>if-name</i>              | (Optional) RPF Interface name          |
| <i>sg</i>                   | (Optional) (S,G) number of flows       |
| <i>starg</i>                | (Optional) (*,G) number of flows       |
| <i>total</i>                | (Optional) Total Flows                 |

## Command Mode

- /exec

## show nbm host-policy all

```
show nbm host-policy all { sender | { receiver { local | external } } } [ vrf { <vrf-name> |
<nbm-vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf <vrf-name> <policyType> <defaultHostPolicy>
[ TABLE_host_policies <seqNum> <source> <group> <groupMask> [ <host> ] <permission> ] <numPolicies>
] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information               |
| nbm                       | Non Blocking Multicast                        |
| host-policy               | Host policy                                   |
| all                       | All policies on switch                        |
| sender                    | Sender Policy                                 |
| receiver                  | Receiver Policy                               |
| local                     | Local receiver policy                         |
| external                  | External receiver policy                      |
| vrf                       | (Optional) Display per-VRF information        |
| all                       | (Optional) Display all VRFs                   |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name                       |
| <i>__readonly__</i>       | (Optional)                                    |
| TABLE_vrf                 | (Optional) VRF table                          |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>policyType</i>         | (Optional) Type of Policy                     |
| <i>defaultHostPolicy</i>  | (Optional) Default Permission for Host Policy |
| TABLE_host_policies       | (Optional) Host policy table                  |
| <i>seqNum</i>             | (Optional) Sequence number                    |
| <i>source</i>             | (Optional) Source IP                          |
| <i>group</i>              | (Optional) Multicast group IP                 |
| <i>groupMask</i>          | (Optional) Group mask length                  |
| <i>host</i>               | (Optional) Reporter or Host IP                |

|                    |                                       |
|--------------------|---------------------------------------|
| <i>permission</i>  | (Optional) Permission for this Policy |
| <i>numPolicies</i> | (Optional) Number of Policies         |

**Command Mode**

- /exec

## show nbm host-policy applied receiver

```
show nbm host-policy applied receiver { { { local { all | wildcard } | external } [ vrf { <vrf-name> |
<nbm-vrf-known-name> | all } ] } | { local interface <if-name> } } [ __readonly__ [ TABLE_vrf <vrf-name>
<policyType> <defaultHostPolicy> [ TABLE_interface <ifName> [ TABLE_host_policies <seqNum>
<source> <group> <groupMask> <permission> <denyCounter> ] ] [ TABLE_wildcard_policies
<seqNumWildcard> <sourceWildcard> <groupWildcard> <groupMaskWildcard> <permissionWildcard>
<denyCounterWildcard> ] <numPolicies> ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information               |
| nbm                       | Non Blocking Multicast                        |
| host-policy               | Host policy                                   |
| applied                   | Applied policies only                         |
| receiver                  | Receiver Policy                               |
| local                     | Local receiver policy                         |
| all                       | All policies on switch                        |
| wildcard                  | All wildcard policies                         |
| external                  | External receiver policy                      |
| vrf                       | (Optional) Display per-VRF information        |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name                       |
| all                       | (Optional) Display all VRFs                   |
| interface                 | Interface                                     |
| <i>if-name</i>            | Interface name                                |
| __readonly__              | (Optional)                                    |
| TABLE_vrf                 | (Optional) VRF table                          |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>policyType</i>         | (Optional) Type of Policy                     |
| <i>defaultHostPolicy</i>  | (Optional) Default Permission for Host Policy |
| TABLE_interface           | (Optional) Interface table                    |
| <i>ifName</i>             | (Optional) Interface name                     |



|                            |                                       |
|----------------------------|---------------------------------------|
| TABLE_host_policies        | (Optional) Host policy table          |
| <i>seqNum</i>              | (Optional) Sequence number            |
| <i>source</i>              | (Optional) Source IP                  |
| <i>group</i>               | (Optional) Multicast group IP         |
| <i>groupMask</i>           | (Optional) Group mask length          |
| <i>permission</i>          | (Optional) Permission for this Policy |
| <i>denyCounter</i>         | (Optional) Deny Counter               |
| TABLE_wildcard_policies    | (Optional) Wildcard policy table      |
| <i>seqNumWildcard</i>      | (Optional) Sequence number            |
| <i>sourceWildcard</i>      | (Optional) Source IP                  |
| <i>groupWildcard</i>       | (Optional) Multicast group IP         |
| <i>groupMaskWildcard</i>   | (Optional) Group mask length          |
| <i>permissionWildcard</i>  | (Optional) Permission for this Policy |
| <i>denyCounterWildcard</i> | (Optional) Deny Counter               |
| <i>numPolicies</i>         | (Optional) Number of Policies         |

**Command Mode**

- /exec

## show nbm host-policy applied sender

```
show nbm host-policy applied sender { { { all | wildcard } [ vrf { <vrf-name> | <nbm-vrf-known-name> | all
} ] } | { interface <if-name> } } [ __readonly__ [ TABLE_vrf <vrf-name> <policyType> <defaultHostPolicy>
[ TABLE_interface <ifName> [ TABLE_host_policies <seqNum> <source> <group> <groupMask>
<permission> ] ] [ TABLE_wildcard_policies <seqNumWildcard> <sourceWildcard> <groupWildcard>
<groupMaskWildcard> <permissionWildcard> ] <numPolicies> ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information               |
| nbm                       | Non Blocking Multicast                        |
| host-policy               | Host policy                                   |
| applied                   | Applied policies only                         |
| sender                    | Sender Policy                                 |
| all                       | All policies on switch                        |
| wildcard                  | Wildcard host policy                          |
| vrf                       | (Optional) Display per-VRF information        |
| all                       | (Optional) Display all VRFs                   |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name                       |
| interface                 | Interface                                     |
| <i>if-name</i>            | Interface name                                |
| __readonly__              | (Optional)                                    |
| TABLE_vrf                 | (Optional) VRF table                          |
| <i>vrf-name</i>           | (Optional) VRF name                           |
| <i>policyType</i>         | (Optional) Type of Policy                     |
| <i>defaultHostPolicy</i>  | (Optional) Default Permission for Host Policy |
| TABLE_interface           | (Optional) Interface table                    |
| <i>ifName</i>             | (Optional) Interface name                     |
| TABLE_host_policies       | (Optional) Host policy table                  |
| <i>seqNum</i>             | (Optional) Sequence number                    |
| <i>source</i>             | (Optional) Source IP                          |

|                           |                                       |
|---------------------------|---------------------------------------|
| <i>group</i>              | (Optional) Multicast group IP         |
| <i>groupMask</i>          | (Optional) Group mask length          |
| <i>permission</i>         | (Optional) Permission for this Policy |
| TABLE_wildcard_policies   | (Optional) Wildcard policy table      |
| <i>seqNumWildcard</i>     | (Optional) Sequence number            |
| <i>sourceWildcard</i>     | (Optional) Source IP                  |
| <i>groupWildcard</i>      | (Optional) Multicast group IP         |
| <i>groupMaskWildcard</i>  | (Optional) Group mask length          |
| <i>permissionWildcard</i> | (Optional) Permission for this Policy |
| <i>numPolicies</i>        | (Optional) Number of Policies         |

**Command Mode**

- /exec

## show nbm interface bandwidth

```
show nbm interface { bandwidth | bandwidth-utilized } [ interface <if-name> ] [ vrf { <vrf-name> |
<nbm-vrf-known-name> | all } ] [ __readonly__ [ TABLE_bw { <index> <ifname> <iod> <slot> <unit>
<slice> <configured_unicast_percentage> <ingr_fl_bw_available> <ingr_fl_bw_usable> <ingr_fl_bw_capacity>
<applied_ingr_unicast_mbps> <applied_ingr_unicast_rsvd_percent> <egr_fl_bw_available>
<egr_fl_bw_usable> <egr_fl_bw_capacity> <applied_egr_unicast_mbps> <applied_egr_unicast_rsvd_percent>
<nbr_dev_id> <nbr_dev_name> <external> } ] ]
```

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information               |
| nbm                                  | Non Blocking Multicast                        |
| interface                            | interface                                     |
| bandwidth                            | Bandwidth interface table                     |
| bandwidth-utilized                   | Utilized Bandwidth interface table            |
| vrf                                  | (Optional) Display per-VRF information        |
| all                                  | (Optional) Display all VRFs                   |
| interface                            | (Optional) Interface                          |
| <i>if-name</i>                       | (Optional) Physical or Logical interface      |
| <i>vrf-name</i>                      | (Optional) VRF name                           |
| <i>nbm-vrf-known-name</i>            | (Optional) NBM VRF Name                       |
| <i>__readonly__</i>                  | (Optional)                                    |
| TABLE_bw                             | (Optional) TABLE Bandwidth                    |
| <i>index</i>                         | (Optional) Index                              |
| <i>ifname</i>                        | (Optional) Interface                          |
| <i>iod</i>                           | (Optional) IOD                                |
| <i>slot</i>                          | (Optional) SLOT                               |
| <i>unit</i>                          | (Optional) UNIT                               |
| <i>slice</i>                         | (Optional) SLICE                              |
| <i>configured_unicast_percentage</i> | (Optional) Link Configured Unicast Percentage |
| <i>ingr_fl_bw_available</i>          | (Optional) Ingress Link BW available in MBPS  |
| <i>ingr_fl_bw_usable</i>             | (Optional) Ingress Link BW usable in MBPS     |

|  |   |
|--|---|
| <i>ingr_fl_bw_capacity</i>               | (Optional) Ingress Link BW capacity in MBPS                   |
| <i>applied_ingr_unicast_mbps</i>         | (Optional) Applied ingress Unicast bandwidth allotted in MBPS |
| <i>applied_ingr_unicast_rsvd_percent</i> | (Optional) Applied ingress Unicast bandwidth reserved percent |
| <i>egr_fl_bw_available</i>               | (Optional) Egress Link BW available in MBPS                   |
| <i>egr_fl_bw_usable</i>                  | (Optional) Egress Link BW usable in MBPS                      |
| <i>egr_fl_bw_capacity</i>                | (Optional) Egress Link BW capacity in MBPS                    |
| <i>applied_egr_unicast_mbps</i>          | (Optional) Applied egress Unicast bandwidth allotted in MBPS  |
| <i>applied_egr_unicast_rsvd_percent</i>  | (Optional) Applied egress Unicast bandwidth reserved percent  |
| <i>nbr_dev_id</i>                        | (Optional) Neighbor device ID                                 |
| <i>nbr_dev_name</i>                      | (Optional) Neighbor device name                               |
| <i>external</i>                          | (Optional) External   |

**Command Mode**

- /exec

# show ngoam interface statistics

```
show ngoam interface statistics [ __readonly__ [ TABLE_stats { <interface-name> <tx> <rx> } <statistics-end> ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| TABLE_stats           | (Optional) interface statistics table            |
| <i>interface-name</i> | (Optional) interface namestring                  |
| <i>tx</i>             | (Optional) ngoam probe transmit on the interface |
| <i>rx</i>             | (Optional) ngoam probe receive on the interface  |
| show                  | Show running system information                  |
| ngoam                 | ngoam  |
| interface             | probe packet interface                           |
| statistics            | ngoam probe interface statistics                 |
| __readonly__          | (Optional) Read Only                             |
| <i>statistics-end</i> | (Optional) statistics table end marker           |

## Command Mode

- /exec

## show ngoam loop-detection status

```
show ngoam loop-detection status [ vlan <vlan-range> [ port <port-range> ] ] [ history ] [ __readonly__
<top-line> [ TABLE_loopdetection_status { <vlanId> <portId> <state> <numLoops> <loopDetectedTime>
<loopClearedTime> } ] ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                                    |
| ngoam                      | Configure ngoam  |
| loop-detection             | Configure sld  |
| status                     | show blocked/recovering state loops                                |
| vlan                       | (Optional) ngoam loop-detection vlan                               |
| port                       | (Optional) ngoam loop-detection port                               |
| history                    | (Optional) show history of loops detected                          |
| <i>vlan-range</i>          | (Optional) vlan range max span 1024, Example: 2000-3000,400,500    |
| <i>port-range</i>          | (Optional) Interface for loop detection                            |
| <i>__readonly__</i>        | (Optional) Read Only   |
| TABLE_loopdetection_status | (Optional) Loop detection status table                             |
| <i>vlanId</i>              | (Optional) Vlan id of loop detected                                |
| <i>portId</i>              | (Optional) Port name of loop detected                              |
| <i>state</i>               | (Optional) Port status   |
| <i>loopDetectedTime</i>    | (Optional) Loop detection time stamp                               |
| <i>loopClearedTime</i>     | (Optional) Loop Cleared time stamp                                 |
| <i>numLoops</i>            | (Optional) Number of times loop detected for given vlanid and port |
| <i>top-line</i>            | (Optional) Placeholder for printing the status header              |

### Command Mode

- /exec

## show ngoam loop-detection summary

```
show ngoam loop-detection summary [ __readonly__ [ TABLE_loopdetection_summary { <enable>
<periodic_probe_interval> <port_recovery_interval> <numVlans> <numPorts> <numLoops>
<numPortsBlocked> <numVlansDisabled> <numPortsDisabled> <totalProbesSent> <totalProbesReceived>
<nextProbeTime> <nextRecoveryTime> } ] ]
```

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                                |
| ngoam                              | Configure ngoam  |
| loop-detection                     | Show loop detection  |
| summary                            | ngoam loop detection summary                                   |
| <i>__readonly__</i>                | (Optional) Read Only   |
| <i>TABLE_loopdetection_summary</i> | (Optional) Loop detection summary table                        |
| <i>enable</i>                      | (Optional) Loop detection enable                               |
| <i>periodic_probe_interval</i>     | (Optional) Loop detection probe interval                       |
| <i>port_recovery_interval</i>      | (Optional) Loop detection port recovery time                   |
| <i>numVlans</i>                    | (Optional) Number of vlan Loop detection is active monitoring  |
| <i>numPorts</i>                    | (Optional) Number of ports Loop detection is active monitoring |
| <i>numLoops</i>                    | (Optional) Number of loops detected                            |
| <i>numPortsBlocked</i>             | (Optional) Number of ports blocked by the loop detection       |
| <i>numVlansDisabled</i>            | (Optional) Number of VLANs,loop detection has disabled         |
| <i>numPortsDisabled</i>            | (Optional) Number of ports,loop detection has disabled         |
| <i>totalProbesSent</i>             | (Optional) Total number of probes sent                         |
| <i>totalProbesReceived</i>         | (Optional) Total number of probes received                     |
| <i>nextProbeTime</i>               | (Optional) Next probe window start time                        |
| <i>nextRecoveryTime</i>            | (Optional) Next recovery window start time                     |

### Command Mode

- /exec



# show ngoam loopback

```
show ngoam loopback { { statistics { session { <handle> | all } | summary } } | { status { session { <handle> | all } } } } [ _readonly_ [ TABLE_statistics { <sender-handle> [ <connect-check-id> ] <last-clear-stats> TABLE_stats_attr { <stat-attr> <stat-value> } } ] [ TABLE_status { <st-sender-handle> <type> <state> } ] [ TABLE_statistics_summary { <last-clear-summary-stats> <tx> <rx> <timeout> <unsent> <req-sw-fwd> <req-drop> <resp-tx> <resp-rx> <resp-unsent> <resp-dup> <resp-sw-fwd> <resp-drop> } ] ]
```

## Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                   |
| ngoam                           | ngoam   |
| loopback                        | ngoam loopback                                    |
| statistics                      | ngoam loopback statistics                         |
| summary                         | ngoam loopback statistics summary                 |
| status                          | ngoam loopback status                             |
| session                         | ngoam loopback session                            |
| session                         | ngoam loopback session                            |
| <i>handle</i>                   | ngoam loopback session handle                     |
| <i>handle</i>                   | ngoam loopback session handle                     |
| all                             | Display results for all ping/loopback sessions    |
| all                             | Display results for all ping/loopback sessions    |
| TABLE_statistics                | (Optional) statistics table                       |
| <i>sender-handle</i>            | (Optional) sender handle                          |
| <i>connect-check-id</i>         | (Optional) connect check id                       |
| <i>last-clear-stats</i>         | (Optional) last clear time for statistics         |
| TABLE_stats_attr                | (Optional) Stats attributes table                 |
| <i>stat-attr</i>                | (Optional) stats type                             |
| <i>stat-value</i>               | (Optional) stats value                            |
| TABLE_statistics_summary        | (Optional) statistics summary table               |
| <i>last-clear-summary-stats</i> | (Optional) last clear time for summary statistics |
| <i>tx</i>                       | (Optional) summary request sent                   |
| <i>rx</i>                       | (Optional) summary reply received                 |

|                         |   |
|-------------------------|---|
| <i>timeout</i>          | (Optional) summary timeout              |
| <i>unsent</i>           | (Optional) summary unsent               |
| <i>resp-tx</i>          | (Optional) summary resp tx              |
| <i>resp-rx</i>          | (Optional) summary resp rx              |
| <i>resp-unsent</i>      | (Optional) summary resp unsent          |
| <i>resp-dup</i>         | (Optional) Duplicate responses received |
| <i>req-sw-fwd</i>       | (Optional) Request pkts sw fwded        |
| <i>resp-sw-fwd</i>      | (Optional) Response pkts sw fwded       |
| <i>req-drop</i>         | (Optional) Requests dropped             |
| <i>resp-drop</i>        | (Optional) Responses dropped            |
| TABLE_status            | (Optional) database status table        |
| <i>st-sender-handle</i> | (Optional) sender handle                |
| <i>type</i>             | (Optional) ngoam ping type              |
| <i>state</i>            | (Optional) ngoam ping state             |
| __readonly__            | (Optional) Read Only                    |

### Command Mode

- /exec

## show ngoam pathtrace

```
show ngoam pathtrace { { statistics { summary | { session { <handle> | all } } } } | { database session {
<handle> | all } [ detail ] } } [ __readonly__ [ { TABLE_stats <sender-handle> <last-clear-stats> [
TABLE_stats_fields { <stat-attr> <stat-value> } ] ] ] [ { TABLE_summary <last-clear-summary-stats> <tx>
<rx> <timeout> <unsent> <req-sw-fwd> <req-drop> <resp-tx> <resp-rx> <resp-unsent> <resp-dup>
<resp-sw-fwd> <resp-drop> } ] [ { TABLE_database <db-sender-handle> <db-start-time> <db-end-time>
<db-last-clear-stats> <db-tx> <db-rx> <db-timeout> <db-unsent> <db-req-sw-fwd> <db-req-drop> <db-resp-tx>
<db-resp-rx> <db-resp-unsent> <db-resp-dup> <db-resp-sw-fwd> <db-resp-drop> { TABLE_db_reply
<seq-number> <cli-status> [ <reply-ip> ] [ <ingress-if> ] [ <ingress-if-state> ] [ <egress-if> ] [ <egress-if-state>
] ] [ { TABLE_ifstats <if-name> <rx-len> <rx-bytes> <rx-pkt-rate> <rx-byte-rate> <rx-load> <rx-ucast>
<rx-mcast> <rx-bcast> <rx-discards> <rx-errors> <rx-unknown> <rx-bandwidth> <tx-len> <tx-bytes>
<tx-pkt-rate> <tx-byte-rate> <tx-load> <tx-ucast> <tx-mcast> <tx-bcast> <tx-discards> <tx-errors>
<tx-bandwidth> } ] [ <end-row> ] + } } ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information            |
| ngoam                   | ngoam                                      |
| pathtrace               | ngoam pathtrace                            |
| statistics              | ngoam pathtrace statistics                 |
| summary                 | ngoam pathtrace statistics summary         |
| session                 | ngoam pathtrace session                    |
| <i>handle</i>           | ngoam pathtrace session handle             |
| all                     | Display results for all pathtrace sessions |
| database                | ngoam pathtrace results from the database  |
| session                 | ngoam pathtrace session                    |
| all                     | Display results for all pathtrace sessions |
| <i>handle</i>           | ngoam pathtrace session handle             |
| detail                  | (Optional) Show detailed stats if present  |
| __readonly__            | (Optional) Read Only                       |
| TABLE_stats             | (Optional) statistics table                |
| <i>sender-handle</i>    | (Optional) sender handle                   |
| <i>last-clear-stats</i> | (Optional) last clear time for statistics  |
| TABLE_stats_fields      | (Optional) statistics entries              |
| <i>stat-attr</i>        | (Optional) stats type                      |

|                                 |   |
|---------------------------------|---|
| <i>stat-value</i>               | (Optional) stats value                            |
| TABLE_summary                   | (Optional) statistics summary table               |
| <i>last-clear-summary-stats</i> | (Optional) last clear time for summary statistics |
| <i>tx</i>                       | (Optional) summary request sent                   |
| <i>rx</i>                       | (Optional) summary reply received                 |
| <i>timeout</i>                  | (Optional) summary timeout                        |
| <i>unsent</i>                   | (Optional) summary unsent                         |
| <i>req-sw-fwd</i>               | (Optional) Request pkts sw fwded                  |
| <i>req-drop</i>                 | (Optional) Requests dropped                       |
| <i>resp-tx</i>                  | (Optional) summary resp tx                        |
| <i>resp-rx</i>                  | (Optional) summary resp rx                        |
| <i>resp-unsent</i>              | (Optional) summary resp unsent                    |
| <i>resp-dup</i>                 | (Optional) Duplicate responses received           |
| <i>resp-sw-fwd</i>              | (Optional) Response pkts sw fwded                 |
| <i>resp-drop</i>                | (Optional) Responses dropped                      |
| TABLE_database                  | (Optional) pathtrace database                     |
| <i>db-sender-handle</i>         | (Optional) Sender handle                          |
| <i>db-start-time</i>            | (Optional) Start time                             |
| <i>db-end-time</i>              | (Optional) End time                               |
| <i>db-last-clear-stats</i>      | (Optional) Last clear stats                       |
| <i>db-tx</i>                    | (Optional) Tx packets                             |
| <i>db-rx</i>                    | (Optional) Rx packets                             |
| <i>db-timeout</i>               | (Optional) Timeout                                |
| <i>db-unsent</i>                | (Optional) Unsent                                 |
| <i>db-req-sw-fwd</i>            | (Optional) Request pkts sw fwded                  |
| <i>db-req-drop</i>              | (Optional) Requests dropped                       |
| <i>db-resp-tx</i>               | (Optional) Response tx                            |
| <i>db-resp-rx</i>               | (Optional) Response Rx                            |
| <i>db-resp-unsent</i>           | (Optional) Response unsent                        |

|                         |                                     |
|-------------------------|-------------------------------------|
| <i>db-resp-dup</i>      | (Optional) Duplicate response recvd |
| <i>db-resp-sw-fwd</i>   | (Optional) Response pkts sw fwded   |
| <i>db-resp-drop</i>     | (Optional) Responses dropped        |
| TABLE_db_reply          | (Optional) Replies                  |
| <i>seq-number</i>       | (Optional) Sequence number          |
| <i>cli-status</i>       | (Optional) ngoam pathtrace status   |
| <i>reply-ip</i>         | (Optional) ngoam pathtrace reply ip |
| <i>ingress-if</i>       | (Optional) Ingress interface        |
| <i>ingress-if-state</i> | (Optional) Ingress interface state  |
| <i>egress-if</i>        | (Optional) Egress interface         |
| <i>egress-if-state</i>  | (Optional) Egress interface state   |
| <i>end-row</i>          | (Optional) Row end                  |
| TABLE_ifstats           | (Optional) Interface statistics     |
| <i>if-name</i>          | (Optional) Interface name           |
| <i>rx-len</i>           | (Optional) Rx Length                |
| <i>rx-bytes</i>         | (Optional) Rx Bytes                 |
| <i>rx-pkt-rate</i>      | (Optional) Rx packet rate           |
| <i>rx-byte-rate</i>     | (Optional) Rx byte rate             |
| <i>rx-load</i>          | (Optional) Rx load                  |
| <i>rx-ucast</i>         | (Optional) Rx unicast pkts          |
| <i>rx-mcast</i>         | (Optional) Rx mcast pkts            |
| <i>rx-bcast</i>         | (Optional) Rx bcast pkts            |
| <i>rx-discards</i>      | (Optional) Rx discards              |
| <i>rx-errors</i>        | (Optional) Rx errors                |
| <i>rx-unknown</i>       | (Optional) Rx unknown               |
| <i>rx-bandwidth</i>     | (Optional) Rx bandwidth             |
| <i>tx-len</i>           | (Optional) Tx Length                |
| <i>tx-bytes</i>         | (Optional) Tx Bytes                 |
| <i>tx-pkt-rate</i>      | (Optional) Tx packet rate           |

|                     |                            |
|---------------------|----------------------------|
| <i>tx-byte-rate</i> | (Optional) Tx byte rate    |
| <i>tx-load</i>      | (Optional) Tx load         |
| <i>tx-ucast</i>     | (Optional) Tx unicast pkts |
| <i>tx-mcast</i>     | (Optional) Tx mcast pkts   |
| <i>tx-bcast</i>     | (Optional) Tx bcast pkts   |
| <i>tx-discards</i>  | (Optional) Tx discards     |
| <i>tx-errors</i>    | (Optional) Tx unknown      |
| <i>tx-bandwidth</i> | (Optional) Tx bandwidth    |

**Command Mode**

- /exec

# show ngoam probe

```
show ngoam probe { { statistics { summary | { session { <handle> | all } } } } [ __readonly__ [ TABLE_stats
{ <sender-handle> <transaction-id> <dst-vip> <vni> <oam-type> <flow-str> <last-clear-stats> <req-sent>
<req-not-sent> } <statistics-end> ] [ TABLE_summary { <last-clear-summary-stats> <tx> <rx> <timeout>
<unsent> <resp-tx> <resp-rx> <resp-unsent> } ] ]
```

## Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                   |
| ngoam                           | ngoam   |
| probe                           | ngoam probe                                       |
| statistics                      | ngoam probe statistics                            |
| summary                         | ngoam probe statistics summary                    |
| session                         | ngoam probe session                               |
| <i>handle</i>                   | ngoam probe session handle                        |
| all                             | Display results for all probe sessions            |
| TABLE_stats                     | (Optional) statistics table                       |
| <i>sender-handle</i>            | (Optional) sender handle                          |
| <i>transaction-id</i>           | (Optional) Transaction Identifier                 |
| <i>dst-vip</i>                  | (Optional) Destination Vtep ip address            |
| <i>vni</i>                      | (Optional) vxlan header vni                       |
| <i>oam-type</i>                 | (Optional) draft pang oam type                    |
| <i>flow-str</i>                 | (Optional) 128 byte flow string.                  |
| <i>last-clear-stats</i>         | (Optional) last clear time for statistics         |
| <i>req-sent</i>                 | (Optional) request sent                           |
| <i>req-not-sent</i>             | (Optional) request not sent or failed             |
| <i>statistics-end</i>           | (Optional) statistics table end marker            |
| TABLE_summary                   | (Optional) statistics summary table               |
| <i>last-clear-summary-stats</i> | (Optional) last clear time for summary statistics |
| <i>tx</i>                       | (Optional) summary request sent                   |
| <i>rx</i>                       | (Optional) summary reply received                 |

|                     |                                |
|---------------------|--------------------------------|
| <i>timeout</i>      | (Optional) summary timeout     |
| <i>unsent</i>       | (Optional) summary unsent      |
| <i>resp-tx</i>      | (Optional) summary resp tx     |
| <i>resp-rx</i>      | (Optional) summary resp rx     |
| <i>resp-unsent</i>  | (Optional) summary resp unsent |
| <i>__readonly__</i> | (Optional) Read Only           |

**Command Mode**

- /exec



## show ngoam traceroute statistics

```
show ngoam traceroute statistics { summary | { session { <handle> | all } } } [ __readonly__ [ TABLE_stats
{ <sender-handle> <last-clear-stats> TABLE_stats_attr { <stat-attr> <stat-value> } } ] [ TABLE_summary
{ <last-clear-summary-stats> <tx> <rx> <timeout> <unsent> <resp-tx> <resp-rx> <resp-unsent> <resp-dup>
} ] ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                   |
| ngoam                           | ngoam   |
| traceroute                      | ngoam traceroute                                  |
| statistics                      | ngoam traceroute statistics                       |
| summary                         | ngoam traceroute statistics summary               |
| session                         | ngoam traceroute session                          |
| <i>handle</i>                   | ngoam traceroute session handle                   |
| all                             | Display results for all traceroute sessions       |
| TABLE_stats                     | (Optional) statistics table                       |
| <i>sender-handle</i>            | (Optional) sender handle                          |
| <i>last-clear-stats</i>         | (Optional) last clear time for statistics         |
| TABLE_stats_attr                | (Optional) Stats attributes table                 |
| <i>stat-attr</i>                | (Optional) stats type                             |
| <i>stat-value</i>               | (Optional) stats value                            |
| TABLE_summary                   | (Optional) statistics summary table               |
| <i>last-clear-summary-stats</i> | (Optional) last clear time for summary statistics |
| <i>tx</i>                       | (Optional) summary request sent                   |
| <i>rx</i>                       | (Optional) summary reply received                 |
| <i>timeout</i>                  | (Optional) summary timeout                        |
| <i>unsent</i>                   | (Optional) summary unsent                         |
| <i>resp-tx</i>                  | (Optional) summary resp tx                        |
| <i>resp-rx</i>                  | (Optional) summary resp rx                        |
| <i>resp-unsent</i>              | (Optional) summary resp unsent                    |

|                     |   |
|---------------------|---|
| <i>resp-dup</i>     | (Optional) Duplicate responses received |
| <i>__readonly__</i> | (Optional) Read Only                    |

**Command Mode**

- /exec

## show ngoam xconnect session

```
show ngoam xconnect session { <id> [ iodb ] | all [ dbdump ] } [ __readonly__ [ TABLE_xc_db_summary
{ [ <legend> ] <vlan-id> <peer-ip> <vni> <db-state> <local-if> <local-if-state> <remote-if> <remote-if-state>
[ <end-row> ] + } + ] [ ENTRY_xc_db_detail { <detail> <d-vlan-id> <d-peer-ip> [ <peer-name> ] <d-vni>
<d-db-state> <last-state-change-ts> <d-local-if> <d-local-if-state> <vpc-if> <vpc-if-state> <remote-if-detail>
<remote-if-detail-state> <remote-vpc-if> <remote-vpc-if-state> [ <d-end-row> ] + } ] ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information           |
| ngoam                         | ngoam information                         |
| xconnect                      | crossconnect info                         |
| session                       | xc session id                             |
| <i>id</i>                     | Vlan-id of the xc                         |
| iodb                          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| all                           | show summary info for all sessions        |
| <i>__readonly__</i>           | (Optional) Read Only                      |
| TABLE_xc_db_summary           | (Optional) XC Db table                    |
| ENTRY_xc_db_detail            | (Optional) XC Db detail                   |
| <i>detail</i>                 | (Optional) Detail or not                  |
| <i>vlan-id</i>                | (Optional) Vlan id                        |
| <i>d-vlan-id</i>              | (Optional) Vlan id                        |
| <i>vni</i>                    | (Optional) vni                            |
| <i>d-vni</i>                  | (Optional) vni                            |
| <i>local-if</i>               | (Optional) Interface                      |
| <i>d-local-if</i>             | (Optional) Interface                      |
| <i>local-if-state</i>         | (Optional) Interface state                |
| <i>d-local-if-state</i>       | (Optional) Interface state                |
| <i>remote-if</i>              | (Optional) Remote interface               |
| <i>remote-if-state</i>        | (Optional) Remote interface state         |
| <i>remote-if-detail</i>       | (Optional) Remote interface               |
| <i>remote-if-detail-state</i> | (Optional) Remote interface state         |

|                             |   |
|-----------------------------|---|
| <i>vpc-if</i>               | (Optional) Interface                      |
| <i>vpc-if-state</i>         | (Optional) Interface state                |
| <i>remote-vpc-if</i>        | (Optional) Remote vpc interface           |
| <i>remote-vpc-if-state</i>  | (Optional) Remote vpc interface state     |
| <i>db-state</i>             | (Optional) XC state                       |
| <i>d-db-state</i>           | (Optional) XC state                       |
| <i>last-state-change-ts</i> | (Optional) Last state change timestamp    |
| <i>peer-ip</i>              | (Optional) Peer ip                        |
| <i>d-peer-ip</i>            | (Optional) Peer ip                        |
| <i>peer-name</i>            | (Optional) Peer name                      |
| <i>end-row</i>              | (Optional) end row                        |
| <i>d-end-row</i>            | (Optional) end row                        |
| <i>legend</i>               | (Optional) legend                         |
| dbdump                      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

**Command Mode**

- /exec

# show npiv status

show npiv status

## Syntax Description

|        |   |
|--------|---|
| show   | Show running system information         |
| npiv   | Show information about the npiv feature |
| status | Show the status of the npiv feature     |

## Command Mode

- /exec

## show npv external-interface-usage

```
show npv external-interface-usage [ server-interface <if0> ] [ __readonly__ { TABLE_intf_usage <svr_intf>
<ext_intf> } ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                                |
| npv                      | Show information about NPV                                     |
| external-interface-usage | Show external interface usage by server interfaces             |
| server-interface         | (Optional) Show external interface usage by a server interface |
| <i>if0</i>               | (Optional)   |
| __readonly__             | (Optional) Read Only   |
| TABLE_intf_usage         | (Optional) External Interfaces Usage Table                     |
| <i>svr_intf</i>          | (Optional) Server Interface                                    |
| <i>ext_intf</i>          | (Optional) External Interface                                  |

### Command Mode

- /exec

# show npv flogi-table

```
show npv flogi-table [ { interface <iif0> | vsan <iid> } ] [ __readonly__ [ [ TABLE_flogi <svr_intf> <vsan_id>
<fcid> <pwwn> <ext_intf> <nwwn> ] [ <flogi_count> ] ] ]
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information   |
| npv                | Show information about NPV  |
| flogi-table        | Show information about FLOGI sessions                                   |
| interface          | (Optional) Show information about FLOGI sessions for a server interface |
| <i>if0</i>         | (Optional)  |
| vsan               | (Optional) Show information about FLOGI sessions for a VSAN             |
| <i>id</i>          | (Optional)  |
| __readonly__       | (Optional) Read Only  |
| TABLE_flogi        | (Optional) FLOGI Table  |
| <i>svr_intf</i>    | (Optional) Server Interface   |
| <i>vsan_id</i>     | (Optional) VSAN ID  |
| <i>fcid</i>        | (Optional) FLOGI FCID   |
| <i>pwwn</i>        | (Optional) The PWWN   |
| <i>ext_intf</i>    | (Optional) External Interface   |
| <i>nwwn</i>        | (Optional) The NWWN   |
| <i>flogi_count</i> | (Optional) Total FLOGI Count  |

## Command Mode

- /exec

## show npv status

```
show npv status [ vsan <i0> ] [ __readonly__ [ [ <npiv_status> ] [ <load_balance> ] [ { TABLE_extintf
<ext_intf> [ <ext_vsan> ] [ <ext_fcid> ] <ext_state> [ { TABLE_vsan <vsan_vsan> <vsan_state> [ <vsan_fcid>
] } ] ] ] <ext_intf_count> [ { TABLE_svrntf <svr_intf> <svr_vsan> <svr_state> } ] <svr_intf_count> ] ]
```

### Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                |
| npv            | Show information about NPV                     |
| status         | Show NPV status                                |
| vsan           | (Optional) Show NPV status for a specific VSAN |
| i0             | (Optional)                                     |
| __readonly__   | (Optional) Read Only                           |
| npiv_status    | (Optional) NPIV enable/disable status          |
| load_balance   | (Optional) disruptive load balance status      |
| TABLE_extintf  | (Optional) External Interfaces Table           |
| ext_intf       | (Optional) External Interface                  |
| ext_vsan       | (Optional) External Interface VSAN             |
| ext_fcid       | (Optional) External Interface FCID             |
| ext_state      | (Optional) External Interface State            |
| TABLE_vsan     | (Optional) External Interfaces VSAN Table      |
| vsan_vsan      | (Optional) External Interface VSAN             |
| vsan_state     | (Optional) VSAN State                          |
| vsan_fcid      | (Optional) VSAN FCID                           |
| ext_intf_count | (Optional) External Interface count            |
| TABLE_svrntf   | (Optional) Server Interfaces Table             |
| svr_intf       | (Optional) Server Interface                    |
| svr_vsan       | (Optional) Server Interface VSAN               |
| svr_state      | (Optional) Server Interface State              |
| svr_intf_count | (Optional) Server Interface count              |

### Command Mode



- /exec

# show npv traffic-map

```
show npv traffic-map [ server-interface <if0> ] [ __readonly__ [ { TABLE_traffic_map <svr_intf> <ext_intf>
} ] ]
```

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                                      |
| npv               | Show information about NPV   |
| traffic-map       | Show information about Traffic Map                                   |
| server-interface  | (Optional) Show information about Traffic map for a server interface |
| <i>if0</i>        | (Optional)   |
| __readonly__      | (Optional) Read Only   |
| TABLE_traffic_map | (Optional) Traffic Map Table   |
| <i>svr_intf</i>   | (Optional) Server Interface  |
| <i>ext_intf</i>   | (Optional) External Interface  |

## Command Mode

- /exec

## show ntp access-groups

```
show ntp access-groups [ __readonly__ [ <matchall> ] [ { TABLE_accessgroups <accesslist> [ <type> } ] ]
```

### Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| ntp                | Show NTP information            |
| access-groups      | Display NTP access groups       |
| __readonly__       | (Optional)                      |
| <i>matchall</i>    | (Optional) matchall             |
| TABLE_accessgroups | (Optional) accessgroups         |
| <i>accesslist</i>  | (Optional) accesslist           |
| <i>type</i>        | (Optional) type                 |

### Command Mode

- /exec

# show ntp authentication-keys

```
show ntp authentication-keys [ __readonly__ [ { TABLE_authkeys <Authkey> [ <MD5String> ] } ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| ntp                 | Show NTP information            |
| authentication-keys | Display authentication keys     |
| __readonly__        | (Optional)                      |
| TABLE_authkeys      | (Optional) authentication keys  |
| <i>Authkey</i>      | (Optional) authentication key   |
| <i>MD5String</i>    | (Optional) password             |

## Command Mode

- /exec

# show ntp authentication-status

show ntp authentication-status [ \_\_readonly\_\_ [ <authentication> ] ]

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information            |
| ntp                   | Show NTP information                       |
| authentication-status | NTP Authentication Status                  |
| __readonly__          | (Optional)                                 |
| <i>authentication</i> | (Optional) authentication enabled/disabled |

## Command Mode

- /exec

# show ntp information

show ntp information [ *\_\_readonly\_\_* [ *<system\_type>* ] [ *<software\_version>* ] ]

## Syntax Description

|                         |                                 |
|-------------------------|---------------------------------|
| show                    | Show running system information |
| ntp                     | Show NTP information            |
| information             | Show ntp information            |
| <i>__readonly__</i>     | (Optional)                      |
| <i>system_type</i>      | (Optional) Ntp System Type      |
| <i>software_version</i> | (Optional) Ntp Software Version |

## Command Mode

- /exec

# show ntp logging-status

show ntp logging-status [ \_\_readonly\_\_ [ <loggingstatus> ] ]

## Syntax Description

|                      |                                     |
|----------------------|-------------------------------------|
| show                 | Show running system information     |
| ntp                  | Show NTP information                |
| logging-status       | Display NTP logging status          |
| __readonly__         | (Optional)                          |
| <i>loggingstatus</i> | (Optional) logging enabled/disabled |

## Command Mode

- /exec

## show ntp peer-status

```
show ntp peer-status [ __readonly__ [ <totalpeers> ] [ { TABLE_peersstatus <syncmode> <remote> <local>
<st> <poll> <reach> <delay> [ <vrf> ] } ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information          |
| ntp                 | Show NTP information                     |
| peer-status         | Show the status for all the server/peers |
| <i>__readonly__</i> | (Optional)                               |
| <i>totalpeers</i>   | (Optional) totalpeers                    |
| TABLE_peersstatus   | (Optional) peersstatus                   |
| <i>syncmode</i>     | (Optional) peermode                      |
| <i>remote</i>       | (Optional) remote addr                   |
| <i>local</i>        | (Optional) local addr                    |
| <i>st</i>           | (Optional) stratum                       |
| <i>poll</i>         | (Optional) ntp poll                      |
| <i>reach</i>        | (Optional) reach                         |
| <i>delay</i>        | (Optional) delay                         |
| <i>vrf</i>          | (Optional) vrf name                      |

### Command Mode

- /exec



# show ntp peers

```
show ntp peers [ __readonly__ [ { TABLE_peers <PeerIPAddress> <serv_peer> <conf_flag> } ] ]
```

## Syntax Description

|                      |                                  |
|----------------------|----------------------------------|
| show                 | Show running system information  |
| ntp                  | Show NTP information             |
| peers                | Show all the peers.              |
| __readonly__         | (Optional)                       |
| TABLE_peers          | (Optional) peers                 |
| <i>PeerIPAddress</i> | (Optional) peer Ip addr          |
| <i>serv_peer</i>     | (Optional) server or peer        |
| <i>conf_flag</i>     | (Optional) configured or dynamic |

## Command Mode

- /exec

# show ntp rts-update

show ntp rts-update [ \_\_readonly\_\_ [ <rtsupdate> ] ]

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information        |
| ntp              | Show NTP information                   |
| rts-update       | Show if the RTS update is enabled      |
| __readonly__     | (Optional)                             |
| <i>rtsupdate</i> | (Optional) rts update enabled/disabled |

## Command Mode

- /exec

# show ntp session status

```
show ntp session status [ __readonly__ [ <session_status> ] ]
```

## Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| ntp                   | Show NTP information            |
| session               | Show the session information    |
| status                | Show the session status         |
| <i>__readonly__</i>   | (Optional)                      |
| <i>session_status</i> | (Optional) last session status  |

## Command Mode

- /exec

# show ntp source-interface

show ntp source-interface [ \_\_readonly\_\_ [ <sourceinterface> ] ]

## Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| ntp                    | Show NTP information            |
| source-interface       | Source interface configured     |
| __readonly__           | (Optional)                      |
| <i>sourceinterface</i> | (Optional) source interface     |

## Command Mode

- /exec

# show ntp source

```
show ntp source [ __readonly__ [ { TABLE_sourceip <sourceip> } ] ]
```

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| ntp             | Show NTP information            |
| source          | Source IP address configured    |
| __readonly__    | (Optional)                      |
| TABLE_sourceip  | (Optional) source ip table      |
| <i>sourceip</i> | (Optional) source ip addr       |

## Command Mode

- /exec

## show ntp statistics

```
show ntp statistics [ { io } | [ local ] | [ memory ] | peer { ipaddr { <ipv4_0> | <ipv6_1> } | name <s0> } } [
__readonly__ [ { <iotimesincereset> <ioreceivebuffers> <iofreereceivebuffers> <iousedreceivebuffers>
<iolowwaterrefills> <iodroppedpackets> <ioignoredpackets> <ioreceivedpackets> <iopacketsent>
<iopacketsnotsent> <iointerruptshandled> <ioreceivedbyint> } ] [ { <localsystemuptime> <localtimesincereset>
<localoldversionpackets> <localnewversionpackets> <localunknownversionnumber> <localbadpacketformat>
<localpacketsprocessed> <localbadauthentication> [ <localpacketsrejected> } ] [ { <memtimesincereset>
<memtotalpeermemory> <memfreepeermemory> <memcallstofindpeer> <memnewpeerallocations>
<mempeerdemobilizations> <memhashtablecounts> } ] [ { <peeripremotehost> <peeriplocalinterface>
<peeriptimelastreceived> <peeriptimeuntilnextsend> <peeripreachabilitychange> <peerippacketsent>
<peerippacketsreceived> <peeripbadauthentication> <peeripbogusorigin> <peeripduplicate>
<peeripbaddispersion> <peeripbadreferencetime> <peeripcandidateorder> } ] [ { <peernameremotehost>
<peernamelocalinterface> <peernametimelastreceived> <peernametimeuntilnextsend>
<peernamereachabilitychange> <peernamepacketsent> <peernamepacketsreceived>
<peernamebadauthentication> <peernamebogusorigin> <peernameduplicate> <peernameduplicate>
<peernamebaddispersion> <peernamebadreferencetime> <peernamecandidateorder> } ] ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information                                 |
| ntp                         | Show NTP information  |
| statistics                  | Show the NTP statistics   |
| io                          | (Optional) Show the input-output statistics.                    |
| local                       | (Optional) Show the counters maintained by the local NTP.       |
| memory                      | (Optional) Show the statistics counters related to memory code. |
| peer                        | Show the per-peer statistics counter of a peer.                 |
| ipaddr                      | Peer's IP address   |
| <i>ipv4_0</i>               |   |
| name                        | Peer's Name   |
| <i>s0</i>                   |   |
| <i>__readonly__</i>         | (Optional)  |
| <i>iotimesincereset</i>     | (Optional) time since reset                                     |
| <i>ioreceivebuffers</i>     | (Optional) receive buffers                                      |
| <i>iofreereceivebuffers</i> | (Optional) free receive buffers                                 |
| <i>iousedreceivebuffers</i> | (Optional) used receive buffers                                 |
| <i>iolowwaterrefills</i>    | (Optional) low water refills                                    |

|                                  |                                     |
|----------------------------------|-------------------------------------|
| <i>iodroppedpackets</i>          | (Optional) dropped packets          |
| <i>ioignoredpackets</i>          | (Optional) ignored packets          |
| <i>ioreceivedpackets</i>         | (Optional) received packets         |
| <i>iopacketsent</i>              | (Optional) packets sent             |
| <i>iopacketsnotsent</i>          | (Optional) packets not sent         |
| <i>iointerruptshandled</i>       | (Optional) interrupts handled       |
| <i>ioreceivedbyint</i>           | (Optional) received by int          |
| <i>localsystemuptime</i>         | (Optional) system up time           |
| <i>localtimesincereset</i>       | (Optional) time since reset         |
| <i>localoldversionpackets</i>    | (Optional) old version packets      |
| <i>localnewversionpackets</i>    | (Optional) new version packets      |
| <i>localunknownversionnumber</i> | (Optional) unknown version number   |
| <i>localbadpacketformat</i>      | (Optional) bad packet format        |
| <i>localpacketsprocessed</i>     | (Optional) packets processed        |
| <i>localbadauthentication</i>    | (Optional) bad authentication       |
| <i>localpacketsrejected</i>      | (Optional) packets rejected         |
| <i>memtimesincereset</i>         | (Optional) time since reset         |
| <i>memtotalpeermemory</i>        | (Optional) total peer memory        |
| <i>memfreepeermemory</i>         | (Optional) free peer memory         |
| <i>memcallstofindpeer</i>        | (Optional) calls to find peer       |
| <i>memnewpeerallocations</i>     | (Optional) new peer allocations     |
| <i>mempeerdemobilizations</i>    | (Optional) peer demobilizations     |
| <i>memhashtablecounts</i>        | (Optional) hash table counts        |
| <i>peeripremotehost</i>          | (Optional) peeripremotehost         |
| <i>peeriplocalinterface</i>      | (Optional) peeriplocalinterface     |
| <i>peeriptimelastreceived</i>    | (Optional) peeriptimelastreceived   |
| <i>peeriptimeuntilnextsend</i>   | (Optional) peeriptimeuntilnextsend  |
| <i>peeripreachabilitychange</i>  | (Optional) peeripreachabilitychange |
| <i>peerippacketsent</i>          | (Optional) peerippacketsent         |

|                                    |  |
|------------------------------------|--|
| <i>peerippacketsreceived</i>       | (Optional) peerippacketsreceived       |
| <i>peeripbadauthentication</i>     | (Optional) peeripbadauthentication     |
| <i>peeripbogusorigin</i>           | (Optional) peeripbogusorigin           |
| <i>peeripduplicate</i>             | (Optional) peeripduplicate             |
| <i>peeripbaddispersion</i>         | (Optional) peeripbaddispersion         |
| <i>peeripbadreferencetime</i>      | (Optional) peeripbadreferencetime      |
| <i>peeripcandidateorder</i>        | (Optional) peeripcandidateorder        |
| <i>peername remotehost</i>         | (Optional) peername remotehost         |
| <i>peername localinterface</i>     | (Optional) peername localinterface     |
| <i>peername timelastreceived</i>   | (Optional) peername timelastreceived   |
| <i>peername timeuntilnextsend</i>  | (Optional) peername timeuntilnextsend  |
| <i>peername reachabilitychange</i> | (Optional) peername reachabilitychange |
| <i>peername packetsent</i>         | (Optional) peername packetsent         |
| <i>peername packetsreceived</i>    | (Optional) peername packetsreceived    |
| <i>peername badauthentication</i>  | (Optional) peername badauthentication  |
| <i>peername bogusorigin</i>        | (Optional) peername bogusorigin        |
| <i>peername duplicate</i>          | (Optional) peername duplicate          |
| <i>peername baddispersion</i>      | (Optional) peername baddispersion      |
| <i>peername badreferencetime</i>   | (Optional) peername badreferencetime   |
| <i>peername candidateorder</i>     | (Optional) peername candidateorder     |

### Command Mode

- /exec



# show ntp status

```
show ntp status [ __readonly__ [ <distribution> ] [ <operational_state> ] ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information          |
| ntp                      | Show NTP information                     |
| status                   | Show the NTP distribution status         |
| <i>__readonly__</i>      | (Optional)                               |
| <i>distribution</i>      | (Optional) distribution enabled/disabled |
| <i>operational_state</i> | (Optional) last operation status         |

## Command Mode

- /exec

# show ntp trusted-keys

```
show ntp trusted-keys [ __readonly__ [ { TABLE_trustkeys <key> } ] ]
```

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| ntp             | Show NTP information            |
| trusted-keys    | Display trusted keys            |
| __readonly__    | (Optional)                      |
| TABLE_trustkeys | (Optional) trusted keys         |
| <i>key</i>      | (Optional) trusted key          |

## Command Mode

- /exec

## show nve adjacency mpls

```
show nve adjacency mpls [ __readonly__ TABLE_nve_mpls_adj [ { <peer-ip> | <peer-ipv6> } <evi> <label-sr>
<learn-mask> <pending-state> <adj-state> ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Display NVE information                     |
| nve                       | Configure NVE information                   |
| adjacency                 | Downstream Adjacencies                      |
| mpls                      | Segment routing                             |
| <i>__readonly__</i>       | (Optional)                                  |
| <i>TABLE_nve_mpls_adj</i> | (Optional) xml schema for sr nve parameters |
| <i>peer-ip</i>            | (Optional) Peer IP address v4               |
| <i>evi</i>                | (Optional) EVI value                        |
| <i>label-sr</i>           | (Optional) SR Label                         |
| <i>learn-mask</i>         | (Optional) Learn mask for the peer          |
| <i>pending-state</i>      | (Optional) Peer adjacency pending state     |
| <i>adj-state</i>          | (Optional) Peer adjacency state             |

### Command Mode

- /exec

## show nve bfd neighbors

```
show nve bfd neighbors [ __readonly__ [ TABLE_nve_bfd_neighbors <if-name> [ { <neighbor-vtep-ip>
<neighbor-inner-ip> <neighbor-inner-mac> <neighbor-cc-state> } ] ] ]
```

### Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | Display NVE information                            |
| nve                            | Configure NVE information                          |
| bfd                            | BFD  |
| neighbors                      | neighbors  |
| <i>__readonly__</i>            | (Optional)   |
| <i>TABLE_nve_bfd_neighbors</i> | (Optional) BFD neighbors schema                    |
| <i>if-name</i>                 | (Optional) if-name                                 |
| <i>neighbor-vtep-ip</i>        | (Optional) Remote VTEP IP address                  |
| <i>neighbor-inner-ip</i>       | (Optional) Remote VTEP Inner IP address            |
| <i>neighbor-inner-mac</i>      | (Optional) Remote VTEP Inner MAC address           |
| <i>neighbor-cc-state</i>       | (Optional) Remote VTEP vPC consistency check state |

### Command Mode

- /exec

## show nve core-links

```
show nve core-links [ __readonly__ [ TABLE_core_link <if-name> [ { <if-state> } ] ] ]
```

### Syntax Description

|                 |   |
|-----------------|---|
| show            | Display NVE information                       |
| nve             | Configure NVE information                     |
| core-links      | Core-links                                    |
| __readonly__    | (Optional)                                    |
| TABLE_core_link | (Optional) xml schema for show nve core-links |
| <i>if-name</i>  | (Optional) core-link interface name           |
| <i>if-state</i> | (Optional) core-link interface oper state     |

### Command Mode

- /exec



|                             |  |
|-----------------------------|--|
| <i>config-status</i>        | (Optional) config state                          |
| <i>df-list</i>              | (Optional) List of router-ips in DF list         |
| <i>es-rt-added</i>          | (Optional) ES route added to L2RIB               |
| <i>ead-rt-added</i>         | (Optional) EAD routes added to L2RIB             |
| <i>ead-evi-rt-timer-age</i> | (Optional) EAD/EVI route advertisement timer age |
| <i>sh-esi</i>               | (Optional) Split-horizon ESI                     |

**Command Mode**

- /exec

# show nve evi

show nve evi [ *\_\_readonly\_\_* *TABLE\_nve\_evi* [ *<evi>* *<sw-bd>* *<label-sr>* *<oper-state>* *<evi-state>* ] ]

## Syntax Description

|                      |                                    |
|----------------------|------------------------------------|
| show                 | Display NVE information            |
| nve                  | Configure NVE information          |
| evi                  | Ethernet Virtual Identifier        |
| <i>__readonly__</i>  | (Optional)                         |
| <i>TABLE_nve_evi</i> | (Optional) xml schema for nve evis |
| <i>evi</i>           | (Optional) EVI value               |
| <i>sw-bd</i>         | (Optional) VLAN information        |
| <i>label-sr</i>      | (Optional) SR Label                |
| <i>oper-state</i>    | (Optional) EVI up or down          |
| <i>evi-state</i>     | (Optional) EVI state               |

## Command Mode

- /exec





|  |  |
|--|--|
| <i>adv-vmac</i>                                | (Optional) advertise virtual rmac              |
| <i>nve-flags</i>                               | (Optional) nve-flags                           |
| <i>nve-if-handle</i>                           | (Optional) interface handle                    |
| <i>src-if-holddown-tm</i>                      | (Optional) hold down time                      |
| <i>src-if-holdup-tm</i>                        | (Optional) hold up time                        |
| <i>src-if-holddown-left</i>                    | (Optional) hold down time left                 |
| <i>vpc-compat-check</i>                        | (Optional) vpc-compat-check                    |
| <i>vip-rmac</i>                                | (Optional) Generated VIP MAC                   |
| <i>vip-rmac-ro</i>                             | (Optional) Generated VIP MAC Re-origination    |
| <i>sm-state</i>                                | (Optional) sm state                            |
| <i>es-delay-restore-time</i>                   | (Optional) es delay restore time               |
| <i>es-delay-restore-time-left</i>              | (Optional) es delay restore time left          |
| <i>multisite-convergence-time</i>              | (Optional) multisite convergence time          |
| <i>multisite-convergence-time-left</i>         | (Optional) multisite convergence time left     |
| <i>multisite-bgw-if</i>                        | (Optional) multisite border gateway interface  |
| <i>multisite-bgw-if-ip</i>                     | (Optional) multisite if ip                     |
| <i>multisite-bgw-if-admin-state</i>            | (Optional) multisite if admin state            |
| <i>multisite-bgw-if-oper-state</i>             | (Optional) multisite if oper state             |
| <i>multisite-bgw-if-oper-state-down-reason</i> | (Optional) multisite if oper state down reason |
| <i>dci-advertise-pip</i>                       | (Optional) dci-advertise-pip                   |

**Command Mode**

- /exec

# show nve mpls

```
show nve mpls [ __readonly__ [ TABLE_nve_mpls { <source-if> { <primary-ip> | <primary-ipv6> } {
<secondary-ip> | <secondary-ipv6> } <sm-state> [ <down-reason> ] } ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Display NVE information                     |
| nve                 | Configure NVE information                   |
| mpls                | Segment routing                             |
| __readonly__        | (Optional)                                  |
| TABLE_nve_mpls      | (Optional) xml schema for sr nve parameters |
| <i>source-if</i>    | (Optional) source-interface                 |
| <i>primary-ip</i>   | (Optional) primary-ip                       |
| <i>secondary-ip</i> | (Optional) secondary-ip                     |
| <i>sm-state</i>     | (Optional) sm state                         |
| <i>down-reason</i>  | (Optional) down reason                      |

## Command Mode

- /exec

## show nve multisite dci-links

```
show nve multisite dci-links [ __readonly__ [ TABLE_multisite_dci_link <if-name> [ { <if-state> } ] ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Display NVE information                                |
| nve                      | Configure NVE information                              |
| multisite                | multisite  |
| dci-links                | dci-links  |
| __readonly__             | (Optional)   |
| TABLE_multisite_dci_link | (Optional) xml schema for show nve multisite dci-links |
| <i>if-name</i>           | (Optional) dci-link interface name                     |
| <i>if-state</i>          | (Optional) dci-link interface oper state               |

### Command Mode

- /exec

# show nve multisite fabric-links

```
show nve multisite fabric-links [ __readonly__ [ TABLE_multisite_fabric_link <if-name> [ { <if-state> } ] ] ]
```

## Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Display NVE information                                   |
| nve                         | Configure NVE information                                 |
| multisite                   | multisite   |
| fabric-links                | fabric-links  |
| __readonly__                | (Optional)  |
| TABLE_multisite_fabric_link | (Optional) xml schema for show nve multisite fabric-links |
| <i>if-name</i>              | (Optional) fabric-link interface name                     |
| <i>if-state</i>             | (Optional) fabric-link interface oper state               |

## Command Mode

- /exec

## show nve peers

```
show nve peers [ [ interface <nve-if> | peer-ip { <user-peer-ip> | <user-peer-ipv6> } | control-plane | data-plane ] [ detail ] ] [ control-plane-vni [ vni <vni-id> | peer-ip { <user-peer-ip> | <user-peer-ipv6> } ] ] [ controller ] [ __readonly__ TABLE_nve_peers [ [ <detail> ] [ <control-plane-vni> ] [ <if-name> ] { <peer-ip> | <peer-ipv6> } [ <peer-state> ] [ <learn-type> ] [ <uptime> ] [ <router-mac> ] [ { <first-vni> <create-ts> <config-vnis> <provision-state> <cp-vni> <vni-assignment-mode> <dci-fabric-location> [ <stale-timer> ] } ] [ { <vni> <learn-src> <learn-src-mask> <vni-gw-mac> <peer-type> <egress-vni> <sw-bd> <irb> <state> } ] ] ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Display NVE information                         |
| nve                      | Configure NVE information                       |
| peers                    | Show peers                                      |
| interface                | (Optional) Interface                            |
| <i>nve-if</i>            | (Optional) NVE interface                        |
| detail                   | (Optional) Detailed information                 |
| peer-ip                  | (Optional) Show a specific peer                 |
| <i>user-peer-ip</i>      | (Optional) Remote Peer IP address               |
| control-plane            | (Optional) Show peers learned via control plane |
| data-plane               | (Optional) Show peers learned via data plane    |
| control-plane-vni        | (Optional) Show details of control plane vnis   |
| vni                      | (Optional) VNI ID                               |
| <i>vni-id</i>            | (Optional) Virtual Network Identifier           |
| controller               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED       |
| <i>__readonly__</i>      | (Optional)                                      |
| <i>detail</i>            | (Optional) detail                               |
| <i>control-plane-vni</i> | (Optional) control-plane-vni                    |
| TABLE_nve_peers          | (Optional) schema peer                          |
| <i>if-name</i>           | (Optional) if-name                              |
| <i>peer-ip</i>           | (Optional) peer-ip                              |
| <i>peer-state</i>        | (Optional) peer-state                           |
| <i>learn-type</i>        | (Optional) learn-type                           |

|                            |                                     |
|----------------------------|-------------------------------------|
| <i>uptime</i>              | (Optional) uptime                   |
| <i>router-mac</i>          | (Optional) router-mac               |
| <i>first-vni</i>           | (Optional) first-vni                |
| <i>create-ts</i>           | (Optional) create-timestamp         |
| <i>config-vnis</i>         | (Optional) config-vnis              |
| <i>provision-state</i>     | (Optional) provision-state          |
| <i>cp-vni</i>              | (Optional) cp-vni                   |
| <i>vni-assignment-mode</i> | (Optional) vni assignment mode      |
| <i>dci-fabric-location</i> | (Optional) dci-fabric-location      |
| <i>stale-timer</i>         | (Optional) stale-timer              |
| <i>vni</i>                 | (Optional) vni value                |
| <i>learn-src</i>           | (Optional) learn source             |
| <i>learn-src-mask</i>      | (Optional) learn source mask        |
| <i>vni-gw-mac</i>          | (Optional) vni gateway mac          |
| <i>peer-type</i>           | (Optional) peer location wan/fabric |
| <i>egress-vni</i>          | (Optional) egress-vni value         |
| <i>sw-bd</i>               | (Optional) SW BD value              |
| <i>irb</i>                 | (Optional) IRB state                |
| <i>state</i>               | (Optional) State machine state      |

**Command Mode**

- /exec

## show nve peers interface counters

```
show nve peers { <addr> | <addr-v6> } interface <nve-if> counters [ __readonly__ { <peer-ip> | <peer-ipv6>
} <tx_ucastpkts> <tx_ucastbytes> <tx_mcastpkts> <tx_mcastbytes> <rx_ucastpkts> <rx_ucastbytes>
<rx_mcastpkts> <rx_mcastbytes> ]
```

### Syntax Description

|                      |                           |
|----------------------|---------------------------|
| show                 | Display NVE information   |
| nve                  | Configure NVE information |
| peers                | NVE Peer                  |
| <i>addr</i>          | Remote Peer IP Address    |
| counters             | Counters                  |
| interface            | Interface                 |
| <i>nve-if</i>        | NVE interface             |
| <i>__readonly__</i>  | (Optional)                |
| <i>peer-ip</i>       | (Optional)                |
| <i>tx_ucastpkts</i>  | (Optional)                |
| <i>tx_ucastbytes</i> | (Optional)                |
| <i>tx_mcastpkts</i>  | (Optional)                |
| <i>tx_mcastbytes</i> | (Optional)                |
| <i>rx_ucastpkts</i>  | (Optional)                |
| <i>rx_ucastbytes</i> | (Optional)                |
| <i>rx_mcastpkts</i>  | (Optional)                |
| <i>rx_mcastbytes</i> | (Optional)                |

### Command Mode

- /exec



## show nve peers mpls

```
show nve peers mpls [ peer-ip { <user-peer-ip> | <user-peer-ipv6> } ] [ detail ] [ __readonly__
TABLE_nve_mpls_peers [ [ <detail> ] { <peer-ip> | <peer-ipv6> } [ <peer-state> ] [ <uptime> ] [ <create-ts>
] [ <provision-state> ] ] ]
```

### Syntax Description

|                        |                                   |
|------------------------|-----------------------------------|
| show                   | Display NVE information           |
| nve                    | Configure NVE information         |
| peers                  | Show peers                        |
| mpls                   | Segment routing peers             |
| detail                 | (Optional) Detailed information   |
| peer-ip                | (Optional) Show a specific peer   |
| <i>user-peer-ip</i>    | (Optional) Remote Peer IP address |
| <i>__readonly__</i>    | (Optional)                        |
| <i>detail</i>          | (Optional) detail                 |
| TABLE_nve_mpls_peers   | (Optional) schema peer            |
| <i>peer-ip</i>         | (Optional) peer-ip                |
| <i>peer-state</i>      | (Optional) peer-state             |
| <i>uptime</i>          | (Optional) uptime                 |
| <i>create-ts</i>       | (Optional) create-timestamp       |
| <i>provision-state</i> | (Optional) provision-state        |

### Command Mode

- /exec

## show nve peers vni interface counters

```
show nve peers { { <addr> | <addr-v6> } | all } vni { <vni-id> | all } interface <nve-if> counters [ __readonly__
TABLE_nve_peer_vni_counters { <peer-ip> | <peer-ipv6> } <vni> <tx_ucastpkts> <tx_ucastbytes>
<tx_mcastpkts> <tx_mcastbytes> <rx_ucastpkts> <rx_ucastbytes> <rx_mcastpkts> <rx_mcastbytes> ]
```

### Syntax Description

|                             |                                  |
|-----------------------------|----------------------------------|
| show                        | Display NVE information          |
| nve                         | Configure NVE information        |
| peers                       | NVE Peer                         |
| <i>addr</i>                 | Remote Peer IP Address           |
| all                         | Show counters for all peers/VNIs |
| vni                         | Virtual Network Identifier       |
| <i>vni-id</i>               | Virtual Network Identifier       |
| counters                    | Counters                         |
| interface                   | Interface                        |
| <i>nve-if</i>               | NVE interface                    |
| __readonly__                | (Optional)                       |
| TABLE_nve_peer_vni_counters | (Optional)                       |
| <i>peer-ip</i>              | (Optional)                       |
| <i>vni</i>                  | (Optional)                       |
| <i>tx_ucastpkts</i>         | (Optional)                       |
| <i>tx_ucastbytes</i>        | (Optional)                       |
| <i>tx_mcastpkts</i>         | (Optional)                       |
| <i>tx_mcastbytes</i>        | (Optional)                       |
| <i>rx_ucastpkts</i>         | (Optional)                       |
| <i>rx_ucastbytes</i>        | (Optional)                       |
| <i>rx_mcastpkts</i>         | (Optional)                       |
| <i>rx_mcastbytes</i>        | (Optional)                       |

### Command Mode

- /exec

## show nve replication-servers

```
show nve replication-servers [ __readonly__ [ TABLE_nve_replication_servers <if-name> [ { <server-ip>
<server-state> <server-ready> } ] ] ]
```

### Syntax Description

|                               |                                      |
|-------------------------------|--------------------------------------|
| show                          | Display NVE information              |
| nve                           | Configure NVE information            |
| replication-servers           | replication-servers                  |
| __readonly__                  | (Optional)                           |
| TABLE_nve_replication_servers | (Optional) replcation servers schema |
| <i>if-name</i>                | (Optional) if-name                   |
| <i>server-ip</i>              | (Optional) Server IP address         |
| <i>server-state</i>           | (Optional) Server reachability state |
| <i>server-ready</i>           | (Optional) Server ready state        |

### Command Mode

- /exec

## show nve vni

```
show nve vni [ { { interface <nve-if> | <vni-id> | all } [ detail ] } | control-plane | data-plane | summary |
controller ] [ __readonly__ [ TABLE_nve_vni [ [ <detail> ] [ <if-name> <vni> <mcast> <vni-state> <mode>
<type> <flags> [ { <prvsn-state> <vlan-bd> <svi-state> <vpc-compat-check> } ] ] [ [ <summary> ]
<cp-vni-count> <cp-vni-up> <cp-vni-down> <dp-vni-count> <dp-vni-up> <dp-vni-down> ] ] ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Display NVE information                    |
| nve                | Configure NVE information                  |
| vni                | Virtual Network Identifier                 |
| <i>vni-id</i>      | (Optional) Virtual Network Identifier      |
| interface          | (Optional) Interface                       |
| <i>nve-if</i>      | (Optional) NVE interface                   |
| all                | (Optional) Display all VNIs                |
| detail             | (Optional) Detailed information            |
| control-plane      | (Optional) show vni learned via BGP        |
| data-plane         | (Optional) show vni learned via data plane |
| summary            | (Optional) show vni summary                |
| controller         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED  |
| __readonly__       | (Optional)                                 |
| TABLE_nve_vni      | (Optional) vni schema                      |
| <i>detail</i>      | (Optional) detail                          |
| <i>if-name</i>     | (Optional) if-name                         |
| <i>vni</i>         | (Optional) vni                             |
| <i>mcast</i>       | (Optional) mcast                           |
| <i>vni-state</i>   | (Optional) vni-state                       |
| <i>mode</i>        | (Optional) vni-mode                        |
| <i>type</i>        | (Optional) vni-type                        |
| <i>flags</i>       | (Optional) vni-flags                       |
| <i>prvsn-state</i> | (Optional) provision-state                 |

|                         |                              |
|-------------------------|------------------------------|
| <i>vlan-bd</i>          | (Optional) vlan-bd           |
| <i>svi-state</i>        | (Optional) svi-state         |
| <i>vpc-compat-check</i> | (Optional) vpc-compat-check  |
| <i>summary</i>          | (Optional) summary           |
| <i>cp-vni-count</i>     | (Optional) CP vni count      |
| <i>cp-vni-up</i>        | (Optional) CP vni up count   |
| <i>cp-vni-down</i>      | (Optional) CP vni down count |
| <i>dp-vni-count</i>     | (Optional) DP vni count      |
| <i>dp-vni-up</i>        | (Optional) DP vni up count   |
| <i>dp-vni-down</i>      | (Optional) DP vni down count |

**Command Mode**

- /exec

## show nve vni counters

```
show nve vni { <vni-id> | all } counters [ __readonly__ <vni> <tx_ucastpkts> <tx_ucastbytes> <tx_mcastpkts>
<tx_mcastbytes> <rx_ucastpkts> <rx_ucastbytes> <rx_mcastpkts> <rx_mcastbytes> ]
```

### Syntax Description

|                      |                            |
|----------------------|----------------------------|
| show                 | Display NVE information    |
| nve                  | Configure NVE information  |
| vni                  | Virtual Network Identifier |
| <i>vni-id</i>        | Virtual Network Identifier |
| all                  | Show counters for all vnis |
| counters             | Counters                   |
| <i>__readonly__</i>  | (Optional)                 |
| <i>vni</i>           | (Optional)                 |
| <i>tx_ucastpkts</i>  | (Optional)                 |
| <i>tx_ucastbytes</i> | (Optional)                 |
| <i>tx_mcastpkts</i>  | (Optional)                 |
| <i>tx_mcastbytes</i> | (Optional)                 |
| <i>rx_ucastpkts</i>  | (Optional)                 |
| <i>rx_ucastbytes</i> | (Optional)                 |
| <i>rx_mcastpkts</i>  | (Optional)                 |
| <i>rx_mcastbytes</i> | (Optional)                 |

### Command Mode

- /exec

# show nve vni ingress-replication

```
show nve vni ingress-replication [ { interface <nve-if> | <vni-id> } ] [ __readonly__ [
TABLE_nve_vni_ingr_repl <if-name> <vni> [ { { <repl-ip> | <repl-ipv6> } <source> <up-time> } ] + ] ]
```

## Syntax Description

|                         |                                       |
|-------------------------|---------------------------------------|
| show                    | Display NVE information               |
| nve                     | Configure NVE information             |
| vni                     | Virtual Network Identifier            |
| ingress-replication     | ingress-replication                   |
| <i>vni-id</i>           | (Optional) Virtual Network Identifier |
| interface               | (Optional) Interface                  |
| <i>nve-if</i>           | (Optional) NVE interface              |
| <i>__readonly__</i>     | (Optional)                            |
| TABLE_nve_vni_ingr_repl | (Optional) vni ingress repl schema    |
| <i>if-name</i>          | (Optional) if-name                    |
| <i>vni</i>              | (Optional) vni                        |
| <i>repl-ip</i>          | (Optional) Replication List           |
| <i>source</i>           | (Optional) Source                     |
| <i>up-time</i>          | (Optional) Up Time                    |

## Command Mode

- /exec

## show nve vni peer-vtep

```
show nve vni peer-vtep [ { interface <nve-if> | <vni-id> } ] [ __readonly__ [ TABLE_nve_vni_peer_vtep
<if-name> <vni> [ { <vtep-ip> <source> <up-time> } ] ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Display NVE information                  |
| nve                     | Configure NVE information                |
| vni                     | Virtual Network Identifier               |
| peer-vtep               | Show static peer-vtep configured per vni |
| <i>vni-id</i>           | (Optional) Virtual Network Identifier    |
| interface               | (Optional) Interface                     |
| <i>nve-if</i>           | (Optional) NVE interface                 |
| <i>__readonly__</i>     | (Optional)                               |
| TABLE_nve_vni_peer_vtep | (Optional) vni peer vtep schema          |
| <i>if-name</i>          | (Optional) if-name                       |
| <i>vni</i>              | (Optional) vni                           |
| <i>vtep-ip</i>          | (Optional) VTEP List                     |
| <i>source</i>           | (Optional) Source                        |
| <i>up-time</i>          | (Optional) Up Time                       |

### Command Mode

- /exec



# show nve vrf

```
show nve vrf [ vrf-name ] [ __readonly__ [ TABLE_nve_vrf <vrf-name> <vni> <if-name> <gateway-mac>
[ { <ipv4-tblid> <ipv6-tblid> <vni-sw-bd> <flags> } ] ] ]
```

## Syntax Description

|                     |                           |
|---------------------|---------------------------|
| show                | Display NVE information   |
| nve                 | Configure NVE information |
| vrf                 | VRF name                  |
| <i>vrf-name</i>     | (Optional) vrf name       |
| <i>__readonly__</i> | (Optional)                |
| TABLE_nve_vrf       | (Optional) vrf schema     |
| <i>vrf-name</i>     | (Optional) vrf-name       |
| <i>vni</i>          | (Optional) vni            |
| <i>if-name</i>      | (Optional) if-name        |
| <i>gateway-mac</i>  | (Optional) gateway-mac    |
| <i>ipv4-tblid</i>   | (Optional) ipv4-table-id  |
| <i>ipv6-tblid</i>   | (Optional) ipv6-table-id  |
| <i>vni-sw-bd</i>    | (Optional) vni-sw-bd      |
| <i>flags</i>        | (Optional) flags          |

## Command Mode

- /exec

# show nve vxlan-params

show nve vxlan-params [ \_\_readonly\_\_ <vxlan-port> ]

## Syntax Description

|                   |                           |
|-------------------|---------------------------|
| show              | Display NVE information   |
| nve               | Configure NVE information |
| vxlan-params      | VxLAN Parameters          |
| __readonly__      | (Optional)                |
| <i>vxlan-port</i> | (Optional) vxlan-params   |

## Command Mode

- /exec

# show nxapi-server logs

show nxapi-server logs

## Syntax Description

|              |                                 |
|--------------|---------------------------------|
| show         | Show running system information |
| nxapi-server | Show NX-API Server              |
| logs         | Show NX-API Server logs         |

## Command Mode

- /exec

# show nxapi

```
show nxapi [ __readonly__ <nxapi_status> <timeout> [ configuration_error <c_error> ] [ <http_port> ] [ <https_port> <ssl_issuer> <ssl_enddate> ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| nxapi               | Show nxapi status                                     |
| __readonly__        | (Optional)  |
| <i>nxapi_status</i> | (Optional) NX-API enabled status                      |
| <i>timeout</i>      | (Optional) Time in minutes until session expires      |
| configuration_error | (Optional) config syntax error                        |
| <i>c_error</i>      | (Optional) config syntax error                        |
| <i>http_port</i>    | (Optional) Configured HTTP port                       |
| <i>https_port</i>   | (Optional) Configured HTTPS port                      |
| <i>ssl_issuer</i>   | (Optional) Issuer information for current certificate |
| <i>ssl_enddate</i>  | (Optional) Expiration date of current certificate     |

## Command Mode

- /exec



## O Show Commands

---

- [show object-group](#), on page 2273
- [show openflow hardware capabilities](#), on page 2274
- [show openflow switch](#), on page 2275
- [show openflow switch flows](#), on page 2276
- [show ospfv3](#), on page 2277
- [show ospfv3 border-routers](#), on page 2282
- [show ospfv3 database](#), on page 2284
- [show ospfv3 database database-summary](#), on page 2287
- [show ospfv3 database detail](#), on page 2289
- [show ospfv3 interface](#), on page 2294
- [show ospfv3 interface brief](#), on page 2297
- [show ospfv3 neighbors](#), on page 2299
- [show ospfv3 neighbors detail](#), on page 2301
- [show ospfv3 neighbors summary](#), on page 2304
- [show ospfv3 request-list](#), on page 2306
- [show ospfv3 retransmission-list](#), on page 2308
- [show ospfv3 route](#), on page 2310
- [show ospfv3 route summary](#), on page 2312
- [show ospfv3 statistics](#), on page 2314
- [show ospfv3 summary-address](#), on page 2318
- [show ospfv3 traffic](#), on page 2319
- [show ospfv3 virtual-links](#), on page 2323
- [show ospfv3 virtual-links brief](#), on page 2327
- [show otv isis](#), on page 2328
- [show otv isis active-source](#), on page 2331
- [show otv isis adjacency](#), on page 2333
- [show otv isis aed-svr-req local](#), on page 2335
- [show otv isis database](#), on page 2337
- [show otv isis ed-summary local](#), on page 2342
- [show otv isis ed-summary remote](#), on page 2343
- [show otv isis fast-flood](#), on page 2345
- [show otv isis hostname](#), on page 2346
- [show otv isis interface](#), on page 2347

- [show otv isis ip mroute](#), on page 2352
- [show otv isis ip redistribute mroute](#), on page 2354
- [show otv isis redistribute route](#), on page 2356
- [show otv isis route-map statistics](#), on page 2357
- [show otv isis route](#), on page 2358
- [show otv isis rrm](#), on page 2361
- [show otv isis site-index](#), on page 2363
- [show otv isis site](#), on page 2364
- [show otv isis spf-log](#), on page 2367
- [show otv isis srm](#), on page 2369
- [show otv isis ssn](#), on page 2371
- [show otv isis statistics](#), on page 2373
- [show otv isis track-adjacency-nexthop](#), on page 2374
- [show otv isis traffic](#), on page 2375
- [show otv isis vlan-status local](#), on page 2377

# show object-group

```
show object-group [ <name> ] [ __readonly__ TABLE_ogroup <group_type> <group_name> [ TABLE_seqno
<seqno> { <_port_op> <port0_num> | <_port_range> <port1_num> <port2_num> | <hostaddr> | <net_ip> |
<mask_ip_addr> <mask_ip_mask> | <hostip6> | <net_ipv6> | <mask_ipv6_addr> <mask_ipv6_mask> } ]
]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                           |
| object-group        | Show configured ACL object groups                         |
| <i>name</i>         | (Optional) object-group name                              |
| <i>__readonly__</i> | (Optional)  |
| <i>group_type</i>   | (Optional) Object group type                              |
| <i>group_name</i>   | (Optional) Object group name                              |
| <i>seqno</i>        | (Optional) Sequence number                                |
| TABLE_ogroup        | (Optional)  |
| TABLE_seqno         | (Optional)  |
| <i>_port_op</i>     | (Optional) Port operator                                  |
| <i>_port_range</i>  | (Optional) Port range                                     |
| <i>port0_num</i>    | (Optional) Port number                                    |
| <i>port1_num</i>    | (Optional) Port number                                    |
| <i>port2_num</i>    | (Optional) Port number                                    |
| <i>net_ip</i>       | (Optional) A.B.C.D Network address of object-group member |
| <i>hostaddr</i>     | (Optional) A.B.C.D Host address                           |
| <i>mask_ip_addr</i> | (Optional) A.B.C.D IP address                             |
| <i>mask_ip_mask</i> | (Optional) A.B.C.D IP address mask                        |

## Command Mode

- /exec

# show openflow hardware capabilities

show openflow hardware capabilities [ pipeline <pipeline-id> ]

## Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| openflow           | Show OpenFlow information       |
| hardware           | Hardware                        |
| capabilities       | Capabilities                    |
| pipeline           | (Optional) Pipeline id          |
| <i>pipeline-id</i> | (Optional) Pipeline id          |

## Command Mode

- /exec



# show openflow switch

```
show openflow switch <switch-id> [ { controllers [ stats | { role { master | slave | equal } } ] | ports } ] [
__readonly__ <cli_output> <ctrlv4> <ctrlport> ]
```

## Syntax Description

|                   |                                 |
|-------------------|---------------------------------|
| show              | Show running system information |
| openflow          | Show OpenFlow information       |
| switch            | Logical switch id               |
| <i>switch-id</i>  | Logical switch-id to enter      |
| controllers       | (Optional) Controllers          |
| stats             | (Optional) Stats                |
| ports             | (Optional) Ports                |
| role              | (Optional) Controller role      |
| master            | (Optional) Master               |
| slave             | (Optional) Slave                |
| equal             | (Optional) Equal                |
| __readonly__      | (Optional)                      |
| <i>cli_output</i> | (Optional)                      |
| <i>ctrlv4</i>     | (Optional)                      |
| <i>ctrlport</i>   | (Optional)                      |

## Command Mode

- /exec

# show openflow switch flows

```
show openflow switch <switch-id> flows [ [ table-id <table-id> ] [ [ pending | pending-del | controller |
configured | default | fixed ] [ brief | list | summary ] ] | stats | compare statistics { snapshot | report [ brief |
list ] } ]
```

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                                    |
| openflow         | Show OpenFlow information  |
| switch           | Logical switch id  |
| <i>switch-id</i> | Logical switch-id to enter   |
| flows            | Flows  |
| brief            | (Optional) Brief   |
| summary          | (Optional) Summary   |
| pending          | (Optional) Pending   |
| pending-del      | (Optional) Pending delete  |
| controller       | (Optional) Controller  |
| configured       | (Optional) Configured  |
| default          | (Optional) Default   |
| fixed            | (Optional) Fixed   |
| stats            | (Optional) Stats   |
| compare          | (Optional) Compare Flow Statistics                                 |
| statistics       | (Optional) Flow Statistics   |
| snapshot         | (Optional) Create a reference point to compare flow stats counters |
| report           | (Optional) Dump difference of flow stats counters from snapshot    |
| table-id         | (Optional) Table-id for the pipeline                               |
| list             | (Optional) List  |
| <i>table-id</i>  | (Optional) Table ID  |

## Command Mode

- /exec

# show ospfv3

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <instance_number> <cname> <rid> <stateful_ha> <gr_ha> [ [ <gr_planned_only> ] [ <gr_grace_period>
] [ <gr_state> ] [ <gr_last_status> ] ] [ <gr_helper_mode> ] <support_tos0_only> <support_opaque_lsa> [
<low_mem_cond> ] <is_abr> <is_asbr> [ <max_lsa_non_self_number> ] [ <max_lsa_state> ] [
<max_lsa_warning_only> ] [ <max_lsa_current_non_self_lsa_number> ] [ <max_lsa_threshold_pct> ] [
<max_lsa_ignore_time> ] [ <max_lsa_reset_time> ] [ <max_lsa_ignore_count> ] [
<max_lsa_current_ignore_count> ] [ <max_lsa_ignore_time_left> ] [ <max_lsa_reset_time_left> ] [
<max_lsa_permanent_ignore> ] [ <ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] [
<ipsec_esp_sa_type> ] [ <ipsec_esp_sa_encr_algorithm> ] [ <ipsec_esp_sa_auth_algorithm> ] [
<ipsec_esp_sa_spi> ] [ { TABLE_redist <proto> [ <max_lsas> ] [ <warning> ] [ <threshold> ] [
<current_count> ] } ] <admin_dist> <ref_bw> <spf_start_time> <spf_hold_time> <spf_max_time>
<lsa_start_time> <lsa_hold_time> <lsa_max_time> <min_lsa_arr_time> <lsa_aging_pace> <spf_max_paths>
<max_metric_adver> [ [ <max_metric_time_left> ] [ <max_metric_wait_bgp> ] [ <max_metric_timeout> ]
[ <max_metric_always> ] [ <max_metric_sum_lsa> ] [ <max_metric_ext_lsa> ] ] <asext_lsa_cnt>
<asext_lsa_crc> <area_total> <area_normal> <area_stub> <area_nssa> <act_area_total> <act_area_normal>
<act_area_stub> <act_area_nssa> [ <name_lookup> ] <no_discard_rt_ext> <no_discard_rt_int> [ <passive_dflt>
] [ <bfd_enabled> ] [ <num_new_lsa_tx> ] [ <num_new_lsa_rx> ] [ { TABLE_area <aname> [
<backbone_active> ] [ <active> ] <age> <total_intf> <act_intf> <passive_intf> <loopback_intf> [ <gr_nbr_cnt>
] <stub> [ <stub_def_cost> ] <nssa> [ <no_redist> ] [ <nssa_trans> ] <no_summary> <spf_runs>
<last_spf_run_time> [ <ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] [ <ipsec_esp_sa_type>
] [ <ipsec_esp_sa_encr_algorithm> ] [ <ipsec_esp_sa_auth_algorithm> ] [ <ipsec_esp_sa_spi> ] [ TABLE_range
<addr> <masklen> <state> <nets> <advertise> [ <cost> ] ] [ <filter_in> ] [ <filter_out> ] <lsa_cnt> <lsa_crc>
} ] ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information             |
| ipv6                   | (Optional) Display IPv6 information         |
| ospfv3                 | Display OSPFv3 status and configuration     |
| <i>tag</i>             | (Optional) Process tag                      |
| vrf                    | (Optional) Display per-VRF information      |
| <i>vrf-name</i>        | (Optional) VRF name                         |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                   |
| all                    | (Optional) Display information for all VRFs |
| __readonly__           | (Optional)                                  |
| TABLE_ctx              | (Optional)                                  |
| <i>ptag</i>            | (Optional)                                  |
| <i>instance_number</i> | (Optional)                                  |
| <i>cname</i>           | (Optional)                                  |

|  |                                    |
|--|------------------------------------|
| <i>rid</i>                                 | (Optional)                         |
| <i>stateful_ha</i>                         | (Optional)                         |
| <i>gr_ha</i>                               | (Optional)                         |
| <i>gr_planned_only</i>                     | (Optional)                         |
| <i>gr_grace_period</i>                     | (Optional)                         |
| <i>gr_state</i>                            | (Optional)                         |
| <i>gr_last_status</i>                      | (Optional)                         |
| <i>gr_helper_mode</i>                      | (Optional)                         |
| <i>support_tos0_only</i>                   | (Optional)                         |
| <i>support_opaque_lsa</i>                  | (Optional)                         |
| <i>low_mem_cond</i>                        | (Optional)                         |
| <i>is_abr</i>                              | (Optional)                         |
| <i>is_asbr</i>                             | (Optional)                         |
| <i>max_lsa_non_self_number</i>             | (Optional)                         |
| <i>max_lsa_state</i>                       | (Optional)                         |
| <i>max_lsa_warning_only</i>                | (Optional)                         |
| <i>max_lsa_current_non_self_lsa_number</i> | (Optional)                         |
| <i>max_lsa_threshold_pct</i>               | (Optional)                         |
| <i>max_lsa_ignore_time</i>                 | (Optional)                         |
| <i>max_lsa_reset_time</i>                  | (Optional)                         |
| <i>max_lsa_ignore_count</i>                | (Optional)                         |
| <i>max_lsa_current_ignore_count</i>        | (Optional)                         |
| <i>max_lsa_ignore_time_left</i>            | (Optional)                         |
| <i>max_lsa_reset_time_left</i>             | (Optional)                         |
| <i>max_lsa_permanent_ignore</i>            | (Optional)                         |
| <i>ipsec_sa_type</i>                       | (Optional) IPsec SA Type           |
| <i>ipsec_sa_algorithm</i>                  | (Optional) IPsec SA Algorithm name |
| <i>ipsec_sa_spi</i>                        | (Optional) IPsec SA SPI Value      |
| <i>ipsec_esp_sa_type</i>                   | (Optional) IPsec ESP SA Type       |

|                                    |   |
|------------------------------------|---|
| <i>ipsec_esp_sa_encr_algorithm</i> | (Optional) IPsec ESP SA ENCR Algorithm name |
| <i>ipsec_esp_sa_auth_algorithm</i> | (Optional) IPsec ESP SA AUTH Algorithm name |
| <i>ipsec_esp_sa_spi</i>            | (Optional) IPsec ESP SA SPI Value           |
| TABLE_redist                       | (Optional)                                  |
| <i>proto</i>                       | (Optional)                                  |
| <i>max_lsas</i>                    | (Optional)                                  |
| <i>warning</i>                     | (Optional)                                  |
| <i>threshold</i>                   | (Optional)                                  |
| <i>current_count</i>               | (Optional)                                  |
| <i>admin_dist</i>                  | (Optional)                                  |
| <i>ref_bw</i>                      | (Optional)                                  |
| <i>spf_start_time</i>              | (Optional)                                  |
| <i>spf_hold_time</i>               | (Optional)                                  |
| <i>spf_max_time</i>                | (Optional)                                  |
| <i>lsa_start_time</i>              | (Optional)                                  |
| <i>lsa_hold_time</i>               | (Optional)                                  |
| <i>lsa_max_time</i>                | (Optional)                                  |
| <i>min_lsa_arr_time</i>            | (Optional)                                  |
| <i>lsa_aging_pace</i>              | (Optional)                                  |
| <i>spf_max_paths</i>               | (Optional)                                  |
| <i>max_metric_adver</i>            | (Optional)                                  |
| <i>max_metric_time_left</i>        | (Optional)                                  |
| <i>max_metric_wait_bgp</i>         | (Optional)                                  |
| <i>max_metric_timeout</i>          | (Optional)                                  |
| <i>max_metric_always</i>           | (Optional)                                  |
| <i>max_metric_sum_lsa</i>          | (Optional)                                  |
| <i>max_metric_ext_lsa</i>          | (Optional)                                  |
| <i>asext_lsa_cnt</i>               | (Optional)                                  |
| <i>asext_lsa_crc</i>               | (Optional)                                  |

|                          |            |
|--------------------------|------------|
| <i>area_total</i>        | (Optional) |
| <i>area_normal</i>       | (Optional) |
| <i>area_stub</i>         | (Optional) |
| <i>area_nssa</i>         | (Optional) |
| <i>act_area_total</i>    | (Optional) |
| <i>act_area_normal</i>   | (Optional) |
| <i>act_area_stub</i>     | (Optional) |
| <i>act_area_nssa</i>     | (Optional) |
| <i>name_lookup</i>       | (Optional) |
| <i>no_discard_rt_ext</i> | (Optional) |
| <i>no_discard_rt_int</i> | (Optional) |
| <i>passive_dflt</i>      | (Optional) |
| <i>bfd_enabled</i>       | (Optional) |
| TABLE_area               | (Optional) |
| <i>aname</i>             | (Optional) |
| <i>backbone_active</i>   | (Optional) |
| <i>active</i>            | (Optional) |
| <i>age</i>               | (Optional) |
| <i>total_intf</i>        | (Optional) |
| <i>act_intf</i>          | (Optional) |
| <i>passive_intf</i>      | (Optional) |
| <i>loopback_intf</i>     | (Optional) |
| <i>gr_nbr_cnt</i>        | (Optional) |
| <i>stub</i>              | (Optional) |
| <i>stub_def_cost</i>     | (Optional) |
| <i>nssa</i>              | (Optional) |
| <i>no_redist</i>         | (Optional) |
| <i>nssa_trans</i>        | (Optional) |
| <i>no_summary</i>        | (Optional) |

|                                    |   |
|------------------------------------|---|
| <i>spf_runs</i>                    | (Optional)                                  |
| <i>last_spf_run_time</i>           | (Optional)                                  |
| <i>ipsec_sa_type</i>               | (Optional) IPsec SA Type                    |
| <i>ipsec_sa_algorithm</i>          | (Optional) IPsec SA Algorithm name          |
| <i>ipsec_sa_spi</i>                | (Optional) IPsec SA SPI Value               |
| <i>ipsec_esp_sa_type</i>           | (Optional) IPsec ESP SA Type                |
| <i>ipsec_esp_sa_encr_algorithm</i> | (Optional) IPsec ESP SA ENCR Algorithm name |
| <i>ipsec_esp_sa_auth_algorithm</i> | (Optional) IPsec ESP SA AUTH Algorithm name |
| <i>ipsec_esp_sa_spi</i>            | (Optional) IPsec ESP SA SPI Value           |
| TABLE_range                        | (Optional)                                  |
| <i>masklen</i>                     | (Optional)                                  |
| <i>state</i>                       | (Optional)                                  |
| <i>nets</i>                        | (Optional)                                  |
| <i>advertise</i>                   | (Optional)                                  |
| <i>cost</i>                        | (Optional)                                  |
| <i>filter_in</i>                   | (Optional)                                  |
| <i>filter_out</i>                  | (Optional)                                  |
| <i>lsa_cnt</i>                     | (Optional)                                  |
| <i>lsa_crc</i>                     | (Optional)                                  |
| <i>num_new_lsa_tx</i>              | (Optional)                                  |
| <i>num_new_lsa_rx</i>              | (Optional)                                  |

**Command Mode**

- /exec

## show ospfv3 border-routers

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] border-routers [ all_routes ] [
vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_br
<type> <addr> <cost> <asbr> <abr> <area> <spf_inst> [ <vlink_unresolved> ] [ TABLE_br_ubest_nh [
<ubest_nh_addr> ] [ <ubest_nh_intf> ] ] [ TABLE_br_mbest_nh [ <mbest_nh_addr> ] [ <mbest_nh_intf>
] ] ] ] ]
```

### Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information             |
| ipv6             | (Optional) Display IPv6 information         |
| ospfv3           | Display OSPFv3 status and configuration     |
| tag              | (Optional) Process tag                      |
| vrf              | (Optional) Display per-VRF information      |
| vrf-name         | (Optional) VRF name                         |
| vrf-known-name   | (Optional) Known VRF name                   |
| all              | (Optional) Display information for all VRFs |
| border-routers   | Border routers                              |
| all_routes       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| __readonly__     | (Optional)                                  |
| TABLE_ctx        | (Optional)                                  |
| ptag             | (Optional)                                  |
| cname            | (Optional)                                  |
| TABLE_br         | (Optional)                                  |
| type             | (Optional)                                  |
| addr             | (Optional)                                  |
| cost             | (Optional)                                  |
| asbr             | (Optional)                                  |
| abr              | (Optional)                                  |
| area             | (Optional)                                  |
| spf_inst         | (Optional)                                  |
| vlink_unresolved | (Optional)                                  |



|                      |            |
|----------------------|------------|
| TABLE_br_ubest_nh    | (Optional) |
| <i>ubest_nh_intf</i> | (Optional) |
| TABLE_br_mbest_nh    | (Optional) |
| <i>mbest_nh_intf</i> | (Optional) |

**Command Mode**

- /exec

## show ospfv3 database

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database [ [ [ [ router | network
| intra-area-prefix | inter-area { irouter | iprefix } | nssa-external | area-unknown | [ [ { link | link-unknown |
grace } [ <interface> ] ] ] ] [ area <area-id-ip> ] ] | external [ tag <tag_val> ] ] as-unknown [ <lsid> ] [
self-originated | adv-router <adv-id> | adv-router-name <adv-name> ] ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [ TABLE_db3_lsa [ <name> ] [ <area> ] [ <id>
] [ <advrtr> ] [ <age> ] [ <seqno> ] [ <corrupt> ] [ <rtr_num_links> ] [ <net_num_rtr> ] [ <prefix> ] [
<inter_rid> ] [ <link_if> ] [ <intra_ref_type> ] [ <intra_ref_lsid> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| database              | Link-state Database Summary                 |
| router                | (Optional) Display router LSAs              |
| network               | (Optional) Display network LSAs             |
| inter-area            | (Optional) Display inter-area LSAs          |
| iprefix               | (Optional) Display Inter-Area-Prefix LSAs   |
| irouter               | (Optional) Display Inter-Area-Router LSAs   |
| nssa-external         | (Optional) Display NSSA-external LSAs       |
| area-unknown          | (Optional) Display area-scope unknown LSAs  |
| external              | (Optional) Display AS-external LSAs         |
| as-unknown            | (Optional) Display as-scope unknown LSAs    |
| grace                 | (Optional) Display Grace LSAs               |
| link                  | (Optional) Display Link LSAs                |
| link-unknown          | (Optional) Display link-scope unknown LSAs  |
| <i>interface</i>      | (Optional) OSPF enabled interface           |

|                       |  |
|-----------------------|--|
| intra-area-prefix     | (Optional) Display Intra-Area-Prefix LSAs              |
| self-originated       | (Optional) Display only self-originated LSAs           |
| <i>lsid</i>           | (Optional) Restrict display by link state ID           |
| adv-router            | (Optional) Restrict display by Advertising router      |
| <i>advid</i>          | (Optional) Advertising router ID                       |
| adv-router-name       | (Optional) Restrict display by Advertising router name |
| <i>adv-name</i>       | (Optional) DNS Name of the Advertising router          |
| area                  | (Optional) Display only LSA's in this area             |
| <i>area-id-ip</i>     | (Optional) Area Id as an integer or ip address         |
| tag                   | (Optional) Restrict display by tag                     |
| <i>tag_val</i>        | (Optional) 32-bit tag value                            |
| <i>__readonly__</i>   | (Optional)   |
| TABLE_ctx             | (Optional)   |
| <i>rid</i>            | (Optional)   |
| <i>ptag</i>           | (Optional)   |
| <i>cname</i>          | (Optional)   |
| TABLE_db3_lsa         | (Optional)   |
| <i>name</i>           | (Optional)   |
| <i>area</i>           | (Optional)   |
| <i>id</i>             | (Optional)   |
| <i>advrtr</i>         | (Optional)   |
| <i>age</i>            | (Optional)   |
| <i>seqno</i>          | (Optional)   |
| <i>corrupt</i>        | (Optional)   |
| <i>rtr_num_links</i>  | (Optional)   |
| <i>net_num_rtr</i>    | (Optional)   |
| <i>inter_rid</i>      | (Optional)   |
| <i>link_if</i>        | (Optional)   |
| <i>intra_ref_type</i> | (Optional)   |

|                       |            |
|-----------------------|------------|
| <i>intra_ref_lsid</i> | (Optional) |
|-----------------------|------------|

**Command Mode**

- /exec

## show ospfv3 database database-summary

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database database-summary
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [
TABLE_dbsum [ TABLE_dbsum_area <area> [ TABLE_dbsum_area_lsa <area_lsa_name> <area_lsa_count>
] <area_lsa_total> ] [ TABLE_dbsum_all [ TABLE_dbsum_lsa_all <lsa_name> <lsa_count> ]
<non_self_lsa_total> <lsa_total> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| database              | Link-state Database Summary                 |
| database-summary      | Summary of database                         |
| <u>__readonly__</u>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>rid</i>            | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| TABLE_dbsum           | (Optional)                                  |
| TABLE_dbsum_area      | (Optional)                                  |
| <i>area</i>           | (Optional)                                  |
| TABLE_dbsum_area_lsa  | (Optional)                                  |
| <i>area_lsa_name</i>  | (Optional)                                  |
| <i>area_lsa_count</i> | (Optional)                                  |
| <i>area_lsa_total</i> | (Optional)                                  |
| TABLE_dbsum_all       | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| TABLE_dbsum_lsa_all       | (Optional) |
| <i>lsa_name</i>           | (Optional) |
| <i>lsa_count</i>          | (Optional) |
| <i>non_self_lsa_total</i> | (Optional) |
| <i>lsa_total</i>          | (Optional) |

**Command Mode**

- /exec

## show ospfv3 database detail

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] database [ [ router | network
| intra-area-prefix | inter-area { irouter | iprefix } | nssa-external | area-unknown | [ { link | link-unknown |
grace } [ <interface> ] ] ] [ area <area-id-ip> ] | external [ tag <tag_val> ] | as-unknown [ <lsid> ] [
self-originated | adv-router <advld> | adv-router-name <adv-name> ] detail [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <rid> <ptag> <cname> [ TABLE_db3_lsa [ <name>
] [ <area> ] [ TABLE_lsdb <age> <maxage> <wrapping> <dummy> <flush_pending> <type> [ <intf> ] <id>
<advtr> <seqno> <cksum> <len> [ <corrupt> ] [ <rtr_abr> ] [ <rtr_asbr> ] [ <rtr_translate> ] [ <rtr_vlink_end>
] [ <rtr_options> ] [ <rtr_num_links> ] [ TABLE_rlsa [ <rtr_link_type> ] [ <rtr_link_metric> ] [ <rtr_link_ifid>
] [ <rtr_link_nbr_ifid> ] [ <rtr_link_nbr_rid> ] ] [ <net_options> ] [ TABLE_nlsa [ <net_rtr> ] ] [ <ia_prefix>
] [ <ia_prefix_options> ] [ <ia_prefix_metric> ] [ <ia_rtr_options> ] [ <ia_rtr_metric> ] [ <ia_rtr_rid> ] [
<asext_prefix> ] [ <asext_options> ] [ <asext_metric_type2> ] [ <asext_metric> ] [ <asext_fwd_addr> ] [
<asext_tag> ] [ <asext_ref_lstype> ] [ <asext_ref_lsid> ] [ <link_priority> ] [ <link_options> ] [ <link_laddr>
] [ <link_num_prefix> ] [ TABLE_linklsa [ <link_prefix> ] [ <link_prefix_options> ] ] [ <intra_num_prefix>
] [ <intra_ref_lstype> ] [ <intra_ref_lsid> ] [ <intra_ref_advtr> ] [ TABLE_iaplsa [ <intra_prefix> ] [
<intra_prefix_options> ] [ <intra_prefix_metric> ] [ <corrupted_length> ] ] [ <tlv_type> ] [ <tlv_len> ] [
<tlv_data> ] [ <tlv_unknown> ] [ <gr_interval> ] [ <gr_reason> ] [ <unknown> ] [ <data_len> ] [ <data> ] ]
] ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information             |
| ipv6           | (Optional) Display IPv6 information         |
| ospfv3         | Display OSPFv3 status and configuration     |
| tag            | (Optional) Process tag                      |
| vrf            | (Optional) Display per-VRF information      |
| vrf-name       | (Optional) VRF name                         |
| vrf-known-name | (Optional) Known VRF name                   |
| all            | (Optional) Display information for all VRFs |
| database       | Link-state Database Summary                 |
| router         | (Optional) Display router LSAs              |
| network        | (Optional) Display network LSAs             |
| inter-area     | (Optional) Display inter-area LSAs          |
| iprefix        | (Optional) Display Inter-Area-Prefix LSAs   |
| irouter        | (Optional) Display Inter-Area-Router LSAs   |
| nssa-external  | (Optional) Display NSSA-external LSAs       |
| area-unknown   | (Optional) Display area-scope unknown LSAs  |

|                   |  |
|-------------------|--|
| external          | (Optional) Display AS-external LSAs                    |
| as-unknown        | (Optional) Display as-scope unknown LSAs               |
| grace             | (Optional) Display Grace LSAs                          |
| link              | (Optional) Display Link LSAs                           |
| link-unknown      | (Optional) Display link-scope unknown LSAs             |
| <i>interface</i>  | (Optional) OSPF enabled interface                      |
| intra-area-prefix | (Optional) Display Intra-Area-Prefix LSAs              |
| self-originated   | (Optional) Display only self-originated LSAs           |
| <i>lsid</i>       | (Optional) Restrict display by link state ID           |
| adv-router        | (Optional) Restrict display by Advertising router      |
| <i>advid</i>      | (Optional) Advertising router ID                       |
| adv-router-name   | (Optional) Restrict display by Advertising router name |
| <i>adv-name</i>   | (Optional) DNS Name of the Advertising router          |
| area              | (Optional) Display only LSA's in this area             |
| <i>area-id-ip</i> | (Optional) Area Id as an integer or ip address         |
| tag               | (Optional) Restrict display by tag                     |
| <i>tag_val</i>    | (Optional) 32-bit tag value                            |
| detail            | Display LSA in detail                                  |
| __readonly__      | (Optional)   |
| TABLE_ctx         | (Optional)   |
| <i>rid</i>        | (Optional)   |
| <i>ptag</i>       | (Optional)   |
| <i>cname</i>      | (Optional)   |
| TABLE_db3_lsa     | (Optional)   |
| <i>name</i>       | (Optional)   |
| <i>area</i>       | (Optional)   |
| TABLE_lsdb        | (Optional)   |
| <i>age</i>        | (Optional)   |
| <i>maxage</i>     | (Optional)   |



|                          |            |
|--------------------------|------------|
| <i>wrapping</i>          | (Optional) |
| <i>dummy</i>             | (Optional) |
| <i>flush_pending</i>     | (Optional) |
| <i>type</i>              | (Optional) |
| <i>intf</i>              | (Optional) |
| <i>id</i>                | (Optional) |
| <i>advrtr</i>            | (Optional) |
| <i>seqno</i>             | (Optional) |
| <i>cksum</i>             | (Optional) |
| <i>len</i>               | (Optional) |
| <i>corrupt</i>           | (Optional) |
| <i>rtr_abr</i>           | (Optional) |
| <i>rtr_asbr</i>          | (Optional) |
| <i>rtr_translate</i>     | (Optional) |
| <i>rtr_vlink_end</i>     | (Optional) |
| <i>rtr_options</i>       | (Optional) |
| <i>rtr_num_links</i>     | (Optional) |
| TABLE_rlsa               | (Optional) |
| <i>rtr_link_type</i>     | (Optional) |
| <i>rtr_link_metric</i>   | (Optional) |
| <i>rtr_link_ifid</i>     | (Optional) |
| <i>rtr_link_nbr_ifid</i> | (Optional) |
| <i>rtr_link_nbr_rid</i>  | (Optional) |
| <i>net_options</i>       | (Optional) |
| TABLE_nlsa               | (Optional) |
| <i>net_rtr</i>           | (Optional) |
| <i>ia_prefix_options</i> | (Optional) |
| <i>ia_prefix_metric</i>  | (Optional) |
| <i>ia_rtr_options</i>    | (Optional) |

|                             |            |
|-----------------------------|------------|
| <i>ia_rtr_metric</i>        | (Optional) |
| <i>ia_rtr_rid</i>           | (Optional) |
| <i>asext_options</i>        | (Optional) |
| <i>asext_metric_type2</i>   | (Optional) |
| <i>asext_metric</i>         | (Optional) |
| <i>asext_tag</i>            | (Optional) |
| <i>asext_ref_lstype</i>     | (Optional) |
| <i>asext_ref_lsid</i>       | (Optional) |
| <i>link_priority</i>        | (Optional) |
| <i>link_options</i>         | (Optional) |
| <i>link_num_prefix</i>      | (Optional) |
| TABLE_linklsa               | (Optional) |
| <i>link_prefix_options</i>  | (Optional) |
| <i>intra_num_prefix</i>     | (Optional) |
| <i>intra_ref_lstype</i>     | (Optional) |
| <i>intra_ref_lsid</i>       | (Optional) |
| <i>intra_ref_advrtr</i>     | (Optional) |
| TABLE_iaplsa                | (Optional) |
| <i>intra_prefix_options</i> | (Optional) |
| <i>intra_prefix_metric</i>  | (Optional) |
| <i>corrupted_length</i>     | (Optional) |
| <i>tlv_type</i>             | (Optional) |
| <i>tlv_len</i>              | (Optional) |
| <i>tlv_data</i>             | (Optional) |
| <i>tlv_unknown</i>          | (Optional) |
| <i>gr_interval</i>          | (Optional) |
| <i>gr_reason</i>            | (Optional) |
| <i>unknown</i>              | (Optional) |
| <i>data_len</i>             | (Optional) |

|             |            |
|-------------|------------|
| <i>data</i> | (Optional) |
|-------------|------------|

**Command Mode**

- /exec

## show ospfv3 interface

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] interface [ <interface> | vrf {
<vrf-name> | <vrf-known-name> | all } ] [ private ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_intf
<ifname> <admin_status> <proto_status> <addr> [ <masklen> ] [ <inst_id> ] <area> [ <if_cfg> ] <state_str>
<type_str> <cost> [ <ipsec_sa_type> ] [ <ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] [ <ipsec_esp_sa_type> ]
[ <ipsec_esp_sa_encr_algorithm> ] [ <ipsec_esp_sa_auth_algorithm> ] [ <ipsec_esp_sa_spi> ] [ <bfd_enabled>
] <index> [ <passive> ] [ <mpls> ] [ <transmit_delay> ] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid>
] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [ <nbr_adj> ] [ <gr_nbr> ] [ <hello_interval> ] [
<dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [ <hello_timer> ] [ <wait_timer> ] [ <lsu_timer> ]
[ <lsack_timer> ] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] [ <multi_area_cnt> ] [ <multi_area_adj> ] [
<state_chg_cnt> ] ] ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information             |
| ipv6           | (Optional) Display IPv6 information         |
| ospfv3         | Display OSPFv3 status and configuration     |
| tag            | (Optional) Process tag                      |
| vrf            | (Optional) Display per-VRF information      |
| vrf-name       | (Optional) VRF name                         |
| vrf-known-name | (Optional) Known VRF name                   |
| all            | (Optional) Display information for all VRFs |
| interface      | OSPF enabled interface                      |
| interface      | (Optional) OSPF enabled interface           |
| private        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| __readonly__   | (Optional)                                  |
| TABLE_ctx      | (Optional)                                  |
| ptag           | (Optional)                                  |
| cname          | (Optional)                                  |
| TABLE_intf     | (Optional)                                  |
| ifname         | (Optional)                                  |
| admin_status   | (Optional)                                  |
| proto_status   | (Optional)                                  |
| masklen        | (Optional)                                  |

|                                    |   |
|------------------------------------|---|
| <i>inst_id</i>                     | (Optional)                                  |
| <i>area</i>                        | (Optional)                                  |
| <i>if_cfg</i>                      | (Optional)                                  |
| <i>state_str</i>                   | (Optional)                                  |
| <i>type_str</i>                    | (Optional)                                  |
| <i>cost</i>                        | (Optional)                                  |
| <i>ipsec_sa_type</i>               | (Optional) IPsec SA Type                    |
| <i>ipsec_sa_algorithm</i>          | (Optional) IPsec SA Algorithm name          |
| <i>ipsec_sa_spi</i>                | (Optional) IPsec SA SPI Value               |
| <i>ipsec_esp_sa_type</i>           | (Optional) IPsec ESP SA Type                |
| <i>ipsec_esp_sa_encr_algorithm</i> | (Optional) IPsec ESP SA ENCR Algorithm name |
| <i>ipsec_esp_sa_auth_algorithm</i> | (Optional) IPsec ESP SA AUTH Algorithm name |
| <i>ipsec_esp_sa_spi</i>            | (Optional) IPsec ESP SA SPI Value           |
| <i>bfd_enabled</i>                 | (Optional)                                  |
| <i>index</i>                       | (Optional)                                  |
| <i>passive</i>                     | (Optional)                                  |
| <i>mpls</i>                        | (Optional)                                  |
| <i>transmit_delay</i>              | (Optional)                                  |
| <i>if_priority</i>                 | (Optional)                                  |
| <i>dr_rid</i>                      | (Optional)                                  |
| <i>bdr_rid</i>                     | (Optional)                                  |
| <i>nbr_total</i>                   | (Optional)                                  |
| <i>nbr_flood</i>                   | (Optional)                                  |
| <i>nbr_adj</i>                     | (Optional)                                  |
| <i>gr_nbr</i>                      | (Optional)                                  |
| <i>hello_interval</i>              | (Optional)                                  |
| <i>dead_interval</i>               | (Optional)                                  |
| <i>wait_interval</i>               | (Optional)                                  |
| <i>rxmt_interval</i>               | (Optional)                                  |

|                       |            |
|-----------------------|------------|
| <i>hello_timer</i>    | (Optional) |
| <i>wait_timer</i>     | (Optional) |
| <i>lsu_timer</i>      | (Optional) |
| <i>lsack_timer</i>    | (Optional) |
| <i>link_lsa_cnt</i>   | (Optional) |
| <i>link_lsa_crc</i>   | (Optional) |
| <i>multi_area_cnt</i> | (Optional) |
| <i>multi_area_adj</i> | (Optional) |
| <i>state_chg_cnt</i>  | (Optional) |

**Command Mode**

- /exec

## show ospfv3 interface brief

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] interface brief [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> <intf_count> TABLE_intf <ifname> <index> <area> <cost> <state_str> <nbr_total> <admin_status> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| interface             | OSPF enabled interface                      |
| brief                 | Display summary of OSPFv3 interfaces        |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>intf_count</i>     | (Optional)                                  |
| TABLE_intf            | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>index</i>          | (Optional)                                  |
| <i>area</i>           | (Optional)                                  |
| <i>cost</i>           | (Optional)                                  |
| <i>state_str</i>      | (Optional)                                  |
| <i>nbr_total</i>      | (Optional)                                  |
| <i>admin_status</i>   | (Optional)                                  |

### Command Mode

- /exec



## show ospfv3 neighbors

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] neighbors [ { { <interface> [
<neighbor> | <neighbor-name> } ] } { [ <neighbor> | <neighbor-name> ] [ vrf { <vrf-name> | <vrf-known-name>
| all } ] } ] [ __readonly__ TABLE_ctx <ptag> <cname> <nbrcount> [ TABLE_nbr <rid> <priority> <state>
<drstate> <uptime> <ifid> <intf> [ <multiarea> ] <addr> ] ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information             |
| ipv6           | (Optional) Display IPv6 information         |
| ospfv3         | Display OSPFv3 status and configuration     |
| tag            | (Optional) Process tag                      |
| vrf            | (Optional) Display per-VRF information      |
| vrf-name       | (Optional) VRF name                         |
| vrf-known-name | (Optional) Known VRF name                   |
| all            | (Optional) Display information for all VRFs |
| neighbors      | Neighbor list                               |
| interface      | (Optional) OSPF enabled interface           |
| neighbor       | (Optional) Router ID of neighbor            |
| neighbor-name  | (Optional) DNS Name of the neighbor         |
| __readonly__   | (Optional)                                  |
| TABLE_ctx      | (Optional)                                  |
| ptag           | (Optional)                                  |
| cname          | (Optional)                                  |
| nbrcount       | (Optional)                                  |
| TABLE_nbr      | (Optional)                                  |
| rid            | (Optional)                                  |
| priority       | (Optional)                                  |
| state          | (Optional)                                  |
| drstate        | (Optional)                                  |
| uptime         | (Optional)                                  |

|                  |            |
|------------------|------------|
| <i>ifid</i>      | (Optional) |
| <i>intf</i>      | (Optional) |
| <i>multiarea</i> | (Optional) |

**Command Mode**

- /exec

## show ospfv3 neighbors detail

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] neighbors [ <interface> ] [
<neighbor> ] detail [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ private ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ TABLE_nbr <rid> <addr> <area> <intf> <state> <transition> <lastchange> [ <bfd_state>
] [ <priority> ] [ <ifid> ] [ <dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [ <dbdallsent> ] [
<dbdallacked> ] [ <lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] <hellooptions> <dbdoptions>
<lastnonhello> [ <deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [ <lsutimer> ] [
<rerxmtimer> ] [ <fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [ <helpercand> ] [
<helperterm> ] [ <senddbd> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack> ] [
<sendlsreqreply> ] [ <sradsjid> ] [ <sradjflags> ] ] ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information             |
| ipv6           | (Optional) Display IPv6 information         |
| ospfv3         | Display OSPFv3 status and configuration     |
| tag            | (Optional) Process tag                      |
| vrf            | (Optional) Display per-VRF information      |
| vrf-name       | (Optional) VRF name                         |
| vrf-known-name | (Optional) Known VRF name                   |
| all            | (Optional) Display information for all VRFs |
| neighbors      | Neighbor list                               |
| interface      | (Optional) OSPF enabled interface           |
| neighbor       | (Optional) Router ID of neighbor            |
| detail         | Show detailed neighbor display              |
| private        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| __readonly__   | (Optional)                                  |
| TABLE_ctx      | (Optional)                                  |
| ptag           | (Optional)                                  |
| cname          | (Optional)                                  |
| TABLE_nbr      | (Optional)                                  |
| rid            | (Optional)                                  |
| area           | (Optional)                                  |

|                        |            |
|------------------------|------------|
| <i>intf</i>            | (Optional) |
| <i>state</i>           | (Optional) |
| <i>transition</i>      | (Optional) |
| <i>lastchange</i>      | (Optional) |
| <i>bfd_state</i>       | (Optional) |
| <i>priority</i>        | (Optional) |
| <i>ifid</i>            | (Optional) |
| <i>dr</i>              | (Optional) |
| <i>bdr</i>             | (Optional) |
| <i>master</i>          | (Optional) |
| <i>seqno</i>           | (Optional) |
| <i>dbdallsentacked</i> | (Optional) |
| <i>dbdallsent</i>      | (Optional) |
| <i>dbdallacked</i>     | (Optional) |
| <i>lsaonreqlist</i>    | (Optional) |
| <i>lsafromlastreq</i>  | (Optional) |
| <i>lsreqrxmts</i>      | (Optional) |
| <i>helloptions</i>     | (Optional) |
| <i>dbdoptions</i>      | (Optional) |
| <i>lastnonhello</i>    | (Optional) |
| <i>deadtimer</i>       | (Optional) |
| <i>pacingt看ner</i>     | (Optional) |
| <i>dbdrxmtimer</i>     | (Optional) |
| <i>reqrxmtimer</i>     | (Optional) |
| <i>lsutimer</i>        | (Optional) |
| <i>rerxmtimer</i>      | (Optional) |
| <i>fastrerxmtimer</i>  | (Optional) |
| <i>lsacktimer</i>      | (Optional) |
| <i>grtimer</i>         | (Optional) |

|                      |            |
|----------------------|------------|
| <i>helpermode</i>    | (Optional) |
| <i>helpercand</i>    | (Optional) |
| <i>helperterm</i>    | (Optional) |
| <i>senddbd</i>       | (Optional) |
| <i>sendsreq</i>      | (Optional) |
| <i>sendsu</i>        | (Optional) |
| <i>sendsurxmt</i>    | (Optional) |
| <i>sendsack</i>      | (Optional) |
| <i>sendsreqreply</i> | (Optional) |
| <i>sradjsid</i>      | (Optional) |
| <i>sradjflags</i>    | (Optional) |

**Command Mode**

- /exec

## show ospfv3 neighbors summary

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] neighbors [ <interface> ]
summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname>
TABLE_intf { <ifname> | <total> } <down> <attempt> <init> <twoway> <exstart> <exchange> <loading>
<full> <if_total> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| neighbors             | Neighbor list                               |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| summary               | Summary of neighbors                        |
| __readonly__          | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| TABLE_intf            | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>total</i>          | (Optional)                                  |
| <i>down</i>           | (Optional)                                  |
| <i>attempt</i>        | (Optional)                                  |
| <i>init</i>           | (Optional)                                  |
| <i>twoway</i>         | (Optional)                                  |
| <i>exstart</i>        | (Optional)                                  |

|                 |            |
|-----------------|------------|
| <i>exchange</i> | (Optional) |
| <i>loading</i>  | (Optional) |
| <i>full</i>     | (Optional) |
| <i>if_total</i> | (Optional) |

**Command Mode**

- /exec





- /exec

# show ospfv3 retransmission-list

```
show [ ipv6 ] ospfv3 [ <tag> ] retransmission-list { <routerid> | <router-name> } <interface> [ __readonly__
[ TABLE_ctx <ptag> <cname> [ TABLE_rxmit <nbr_rid> <intf> <nbr_addr> [ <timer_running> ] [
<timer_due> ] [ TABLE_lsa [ <type> ] [ <lsid> ] [ <advrtr> ] [ <seqno> ] [ <cksum> ] [ <age> ] ] ] ] ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information         |
| ipv6                | (Optional) Display IPv6 information     |
| ospfv3              | Display OSPFv3 status and configuration |
| tag                 | (Optional) Process tag                  |
| retransmission-list | Link state retransmission list          |
| routerid            | Neighbor router ID                      |
| router-name         | DNS Name of the router                  |
| interface           | OSPF enabled interface                  |
| __readonly__        | (Optional)                              |
| TABLE_ctx           | (Optional)                              |
| ptag                | (Optional)                              |
| cname               | (Optional)                              |
| TABLE_rxmit         | (Optional)                              |
| nbr_rid             | (Optional)                              |
| intf                | (Optional)                              |
| timer_running       | (Optional)                              |
| timer_due           | (Optional)                              |
| TABLE_lsa           | (Optional)                              |
| type                | (Optional)                              |
| lsid                | (Optional)                              |
| advrtr              | (Optional)                              |
| seqno               | (Optional)                              |
| cksum               | (Optional)                              |
| age                 | (Optional)                              |

**Command Mode**

- /exec

## show ospfv3 route

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] route [ <ipv6-prefix> [
longer-prefixes ] ] [ all_routes ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ <hdr_addr> ] [ <hdr_masklen> ] [ TABLE_route <addr> <masklen> <type> [ <in_ulib>
] <in_rib> <direct> [ <area> ] [ <tag> ] [ <vlink_unresolved> ] [ TABLE_route_ubest_nh [ <ubest_nh_addr>
] [ <ubest_nh_intf> ] [ <ubest_cost> ] [ <distance> ] [ <ubest_nh_direct> ] [ <ubest_nh_sham_link> ] [
<ubest_nh_te_tun> ] [ <ubest_nh_in_rib> ] ] [ TABLE_route_mbest_nh [ <mbest_nh_addr> ] [
<mbest_nh_intf> ] [ <mbest_cost> ] [ <mbest_nh_direct> ] [ <mbest_nh_in_rib> ] ] ] ]
```

### Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                      |
| ipv6            | (Optional) Display IPv6 information                  |
| ospfv3          | Display OSPFv3 status and configuration              |
| tag             | (Optional) Process tag                               |
| vrf             | (Optional) Display per-VRF information               |
| vrf-name        | (Optional) VRF name                                  |
| vrf-known-name  | (Optional) Known VRF name                            |
| all             | (Optional) Display information for all VRFs          |
| route           | Internal OSPF routes                                 |
| longer-prefixes | (Optional) Show exact match and more specific routes |
| all_routes      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| tag             | (Optional)   |
| __readonly__    | (Optional)   |
| TABLE_ctx       | (Optional)   |
| ptag            | (Optional)   |
| cname           | (Optional)   |
| hdr_masklen     | (Optional)   |
| TABLE_route     | (Optional)   |
| masklen         | (Optional)   |
| type            | (Optional)   |
| in_ulib         | (Optional)   |
| in_rib          | (Optional)   |

|                           |            |
|---------------------------|------------|
| <i>direct</i>             | (Optional) |
| <i>area</i>               | (Optional) |
| <i>vlink_unresolved</i>   | (Optional) |
| TABLE_route_ubest_nh      | (Optional) |
| <i>ubest_nh_intf</i>      | (Optional) |
| <i>ubest_cost</i>         | (Optional) |
| <i>distance</i>           | (Optional) |
| <i>ubest_nh_direct</i>    | (Optional) |
| <i>ubest_nh_sham_link</i> | (Optional) |
| <i>ubest_nh_te_tun</i>    | (Optional) |
| <i>ubest_nh_in_rib</i>    | (Optional) |
| TABLE_route_mbest_nh      | (Optional) |
| <i>mbest_nh_intf</i>      | (Optional) |
| <i>mbest_cost</i>         | (Optional) |
| <i>mbest_nh_direct</i>    | (Optional) |
| <i>mbest_nh_in_rib</i>    | (Optional) |

**Command Mode**

- /exec

## show ospfv3 route summary

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] route [ <ipv6-prefix> [
longer-prefixes ] ] summary [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx
<ptag> <cname> [ TABLE_route <total_routes> <total_paths> [ TABLE_route_type <path_type>
<path_routes> <path_paths> ] [ TABLE_route_masklen <masklen> <masklen_routes> <masklen_paths> ] ]
]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                      |
| ipv6                | (Optional) Display IPv6 information                  |
| ospfv3              | Display OSPFv3 status and configuration              |
| tag                 | (Optional) Process tag                               |
| vrf                 | (Optional) Display per-VRF information               |
| vrf-name            | (Optional) VRF name                                  |
| vrf-known-name      | (Optional) Known VRF name                            |
| all                 | (Optional) Display information for all VRFs          |
| route               | Internal OSPF routes                                 |
| longer-prefixes     | (Optional) Show exact match and more specific routes |
| summary             | Show route counts                                    |
| __readonly__        | (Optional)   |
| TABLE_ctx           | (Optional)   |
| ptag                | (Optional)   |
| cname               | (Optional)   |
| TABLE_route         | (Optional)   |
| total_routes        | (Optional)   |
| total_paths         | (Optional)   |
| TABLE_route_type    | (Optional)   |
| path_type           | (Optional)   |
| path_routes         | (Optional)   |
| path_paths          | (Optional)   |
| TABLE_route_masklen | (Optional)   |

|                       |            |
|-----------------------|------------|
| <i>masklen</i>        | (Optional) |
| <i>masklen_routes</i> | (Optional) |
| <i>masklen_paths</i>  | (Optional) |

**Command Mode**

- /exec

## show ospfv3 statistics

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] statistics [ vrf { <vrf-name> |
<vrf-known-name> | all } ] [ __readonly__ TABLE_stats <ptag> <cname> <last_clear> <rid_change>
<dr_elections> <older_lsa_rcv> <nbr_state_change> <nbr_dead_postpone> <nbr_dead_expire>
<nbr_bad_lsreq> <nbr_seqno_mismatch> <spf_full> <spf_summary> <spf_external> <spf_extsummary>
<rtr_generate> <rtr_refresh> <rtr_flush> <rtr_other_flush> <net_generate> <net_refresh> <net_flush>
<net_other_flush> <inter_prefix_generate> <inter_prefix_refresh> <inter_prefix_flush>
<inter_prefix_other_flush> <inter_router_generate> <inter_router_refresh> <inter_router_flush>
<inter_router_other_flush> <asext_generate> <asext_refresh> <asext_flush> <asext_other_flush>
<link_generate> <link_refresh> <link_flush> <link_other_flush> <intra_prefix_generate>
<intra_prefix_refresh> <intra_prefix_flush> <intra_prefix_other_flush> <unknown_generate>
<unknown_refresh> <unknown_flush> <unknown_other_flush> <limbo_lsa_count> <limbo_lsa_hwm>
<limbo_lsa_deleted> <limbo_lsa_revived> <limbo_runs> <limbo_lsa_last_time_hwm> [ <limbo_timer> ]
<helloq_size> <helloq_max_size> <helloq_hwm> <helloq_drops> <helloq_last_hwm_time> <floodq_size>
<floodq_max_size> <floodq_hwm> <floodq_drops> <floodq_last_hwm_time> <lsdb_add_fail> [
TABLE_buffer_detail [ <buf_size> ] [ <buf_size_huge> ] <buf_in_use> <buf_hwm> <buf_perm> <buf_alloc>
<buf_free> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| statistics            | Event counters                              |
| <u>__readonly__</u>   | (Optional)                                  |
| TABLE_stats           | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>last_clear</i>     | (Optional)                                  |
| <i>rid_change</i>     | (Optional)                                  |
| <i>dr_elections</i>   | (Optional)                                  |
| <i>older_lsa_rcv</i>  | (Optional)                                  |



|                                 |            |
|---------------------------------|------------|
| <i>nbr_state_change</i>         | (Optional) |
| <i>nbr_dead_postpone</i>        | (Optional) |
| <i>nbr_dead_expire</i>          | (Optional) |
| <i>nbr_bad_lsreq</i>            | (Optional) |
| <i>nbr_seqno_mismatch</i>       | (Optional) |
| <i>spf_full</i>                 | (Optional) |
| <i>spf_summary</i>              | (Optional) |
| <i>spf_external</i>             | (Optional) |
| <i>spf_extsummary</i>           | (Optional) |
| <i>rtr_generate</i>             | (Optional) |
| <i>rtr_refresh</i>              | (Optional) |
| <i>rtr_flush</i>                | (Optional) |
| <i>rtr_other_flush</i>          | (Optional) |
| <i>net_generate</i>             | (Optional) |
| <i>net_refresh</i>              | (Optional) |
| <i>net_flush</i>                | (Optional) |
| <i>net_other_flush</i>          | (Optional) |
| <i>inter_prefix_generate</i>    | (Optional) |
| <i>inter_prefix_refresh</i>     | (Optional) |
| <i>inter_prefix_flush</i>       | (Optional) |
| <i>inter_prefix_other_flush</i> | (Optional) |
| <i>inter_router_generate</i>    | (Optional) |
| <i>inter_router_refresh</i>     | (Optional) |
| <i>inter_router_flush</i>       | (Optional) |
| <i>inter_router_other_flush</i> | (Optional) |
| <i>asext_generate</i>           | (Optional) |
| <i>asext_refresh</i>            | (Optional) |
| <i>asext_flush</i>              | (Optional) |
| <i>asext_other_flush</i>        | (Optional) |

|                                 |            |
|---------------------------------|------------|
| <i>link_generate</i>            | (Optional) |
| <i>link_refresh</i>             | (Optional) |
| <i>link_flush</i>               | (Optional) |
| <i>link_other_flush</i>         | (Optional) |
| <i>intra_prefix_generate</i>    | (Optional) |
| <i>intra_prefix_refresh</i>     | (Optional) |
| <i>intra_prefix_flush</i>       | (Optional) |
| <i>intra_prefix_other_flush</i> | (Optional) |
| <i>unknown_generate</i>         | (Optional) |
| <i>unknown_refresh</i>          | (Optional) |
| <i>unknown_flush</i>            | (Optional) |
| <i>unknown_other_flush</i>      | (Optional) |
| <i>limbo_lsa_count</i>          | (Optional) |
| <i>limbo_lsa_hwm</i>            | (Optional) |
| <i>limbo_lsa_deleted</i>        | (Optional) |
| <i>limbo_lsa_revived</i>        | (Optional) |
| <i>limbo_runs</i>               | (Optional) |
| <i>limbo_lsa_last_time_hwm</i>  | (Optional) |
| <i>limbo_timer</i>              | (Optional) |
| <i>helloq_size</i>              | (Optional) |
| <i>helloq_max_size</i>          | (Optional) |
| <i>helloq_hwm</i>               | (Optional) |
| <i>helloq_drops</i>             | (Optional) |
| <i>helloq_last_hwm_time</i>     | (Optional) |
| <i>floodq_size</i>              | (Optional) |
| <i>floodq_max_size</i>          | (Optional) |
| <i>floodq_hwm</i>               | (Optional) |
| <i>floodq_drops</i>             | (Optional) |
| <i>floodq_last_hwm_time</i>     | (Optional) |

|                      |            |
|----------------------|------------|
| <i>lsdb_add_fail</i> | (Optional) |
| TABLE_buffer_detail  | (Optional) |
| <i>buf_size</i>      | (Optional) |
| <i>buf_size_huge</i> | (Optional) |
| <i>buf_in_use</i>    | (Optional) |
| <i>buf_hwm</i>       | (Optional) |
| <i>buf_perm</i>      | (Optional) |
| <i>buf_alloc</i>     | (Optional) |
| <i>buf_free</i>      | (Optional) |

**Command Mode**

- /exec

## show ospfv3 summary-address

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] summary-address [ private ]
[ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_ctx <ptag> <cname> <rid> [
TABLE_sum <addr> <masklen> [ <metric> ] [ <tag> ] [ <pending> ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| summary-address       | Summary-address redistribution information  |
| private               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>tag</i>            | (Optional)                                  |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>rid</i>            | (Optional)                                  |
| TABLE_sum             | (Optional)                                  |
| <i>masklen</i>        | (Optional)                                  |
| <i>metric</i>         | (Optional)                                  |
| <i>pending</i>        | (Optional)                                  |

### Command Mode

- /exec

## show ospfv3 traffic

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] traffic [ <interface> [ detail ]
| [ detail ] | [ detail ] vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_traf <ptag>
<cname> <last_clear> [ <ifname> ] <pkt_in> <pkt_out> <lsu_first_trans> <lsu_retrans> <lsu_for_lsreq>
<lsu_nbr_trans> <throttle_out> <throttle_out_token> <throttle_out_ip> <lsa_ignored> <lsa_dropped_spf>
<lsa_dropped_gr> <pkt_drops_in> <pkt_drops_out> <pkt_errors_in> <pkt_errors_out> <hello_errors_in>
<dbds_errors_in> <lsreqs_errors_in> <lsus_errors_in> <lsacks_errors_in> <pkt_unknown_in>
<pkt_unknown_out> <pkt_no_ospf_intf> <bad_version> <bad_crc> <dup_rtr_id> <dup_src_addr>
<invalid_src_addr> <invalid_dst_addr> <non_existing_nbr> <pkt_passive_intf> <wrong_area>
<invalid_pkt_len> <nbr_changed_routerid_ipaddr> <nbr_changed_interfaceid> [ <bad_auth> ] [
<bad_reserved> ] [ <pkt_no_vrf> ] <hellos_in> <dbds_in> <lsreqs_in> <lsus_in> <lsacks_in> <hellos_out>
<dbds_out> <lsreqs_out> <lsus_out> <lsacks_out> [ <hellos_in_hq> <dbds_in_hq> <lsreqs_in_flq>
<lsus_in_flq> <lsacks_in_flq> <lsas_in_dbds_in> <lsas_in_lsreqs_in> <lsas_in_lsus_in> <lsas_in_lsacks_in>
<lsas_in_dbds_out> <lsas_in_lsreqs_out> <lsas_in_lsus_out> <lsas_in_lsacks_out> <lsas_in_rxmt_lsus_out>
]]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| <i>interface</i>      | (Optional) OSPF enabled interface           |
| detail                | (Optional) Display detailed information     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| traffic               | Packet counters                             |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_traf            | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>last_clear</i>     | (Optional)                                  |
| <i>ifname</i>         | (Optional)                                  |
| <i>pkt_in</i>         | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>pkt_out</i>            | (Optional) |
| <i>lsu_first_trans</i>    | (Optional) |
| <i>lsu_retrans</i>        | (Optional) |
| <i>lsu_for_lsreq</i>      | (Optional) |
| <i>lsu_nbr_trans</i>      | (Optional) |
| <i>throttle_out</i>       | (Optional) |
| <i>throttle_out_token</i> | (Optional) |
| <i>throttle_out_ip</i>    | (Optional) |
| <i>lsa_ignored</i>        | (Optional) |
| <i>lsa_dropped_spf</i>    | (Optional) |
| <i>lsa_dropped_gr</i>     | (Optional) |
| <i>pkt_drops_in</i>       | (Optional) |
| <i>pkt_drops_out</i>      | (Optional) |
| <i>pkt_errors_in</i>      | (Optional) |
| <i>pkt_errors_out</i>     | (Optional) |
| <i>hello_errors_in</i>    | (Optional) |
| <i>dbds_errors_in</i>     | (Optional) |
| <i>lsreqs_errors_in</i>   | (Optional) |
| <i>lsus_errors_in</i>     | (Optional) |
| <i>lsacks_errors_in</i>   | (Optional) |
| <i>pkt_unknown_in</i>     | (Optional) |
| <i>pkt_unknown_out</i>    | (Optional) |
| <i>pkt_no_ospf_intf</i>   | (Optional) |
| <i>bad_version</i>        | (Optional) |
| <i>bad_crc</i>            | (Optional) |
| <i>dup_rtr_id</i>         | (Optional) |
| <i>dup_src_addr</i>       | (Optional) |
| <i>invalid_src_addr</i>   | (Optional) |
| <i>invalid_dst_addr</i>   | (Optional) |

|                                    |            |
|------------------------------------|------------|
| <i>non_existing_nbr</i>            | (Optional) |
| <i>pkt_passive_intf</i>            | (Optional) |
| <i>wrong_area</i>                  | (Optional) |
| <i>invalid_pkt_len</i>             | (Optional) |
| <i>nbr_changed_routerid_ipaddr</i> | (Optional) |
| <i>nbr_changed_interfaceid</i>     | (Optional) |
| <i>bad_auth</i>                    | (Optional) |
| <i>bad_reserved</i>                | (Optional) |
| <i>pkt_no_vrf</i>                  | (Optional) |
| <i>hellos_in</i>                   | (Optional) |
| <i>dbds_in</i>                     | (Optional) |
| <i>lsreqs_in</i>                   | (Optional) |
| <i>lsus_in</i>                     | (Optional) |
| <i>lsacks_in</i>                   | (Optional) |
| <i>hellos_out</i>                  | (Optional) |
| <i>dbds_out</i>                    | (Optional) |
| <i>lsreqs_out</i>                  | (Optional) |
| <i>lsus_out</i>                    | (Optional) |
| <i>lsacks_out</i>                  | (Optional) |
| <i>hellos_in_hq</i>                | (Optional) |
| <i>dbds_in_hq</i>                  | (Optional) |
| <i>lsreqs_in_flq</i>               | (Optional) |
| <i>lsus_in_flq</i>                 | (Optional) |
| <i>lsacks_in_flq</i>               | (Optional) |
| <i>lsas_in_dbds_in</i>             | (Optional) |
| <i>lsas_in_lsreqs_in</i>           | (Optional) |
| <i>lsas_in_lsus_in</i>             | (Optional) |
| <i>lsas_in_lsacks_in</i>           | (Optional) |
| <i>lsas_in_dbds_out</i>            | (Optional) |

|                              |            |
|------------------------------|------------|
| <i>lsas_in_lsreqs_out</i>    | (Optional) |
| <i>lsas_in_lsus_out</i>      | (Optional) |
| <i>lsas_in_lsacks_out</i>    | (Optional) |
| <i>lsas_in_rxmt_lsus_out</i> | (Optional) |

**Command Mode**

- /exec



## show ospfv3 virtual-links

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] virtual-links [ vrf { <vrf-name>
| <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> [ TABLE_vlink <name> <nbr_rid>
<if_state> <transit_area> <nh_intf> <nbr_addr> [ <transit_area_stub> ] [ <transit_area_nssa> ] <addr> [
<masklen> ] <inst_id> <area> [ <if_cfg> ] <state_str> <type_str> <cost> [ <ipsec_sa_type> ] [
<ipsec_sa_algorithm> ] [ <ipsec_sa_spi> ] [ <ipsec_esp_sa_type> ] [ <ipsec_esp_sa_encr_algorithm> ] [
<ipsec_esp_sa_auth_algorithm> ] [ <ipsec_esp_sa_spi> ] <index> [ <passive> ] [ <mpls> ] [ <transmit_delay>
] [ <if_priority> ] [ <dr_rid> ] [ <dr_addr> ] [ <bdr_rid> ] [ <bdr_addr> ] [ <nbr_total> ] [ <nbr_flood> ] [
<nbr_adj> ] [ <gr_nbr> ] [ <hello_interval> ] [ <dead_interval> ] [ <wait_interval> ] [ <rxmt_interval> ] [
<hello_timer> ] [ <wait_timer> ] [ <pacing_timer> ] [ <lsu_timer> ] [ <lsack_timer> ] [ <netlsa_throt_timer>
] [ <link_lsa_cnt> ] [ <link_lsa_crc> ] [ <state> ] [ <transition> ] [ <lastchange> ] [ <priority> ] [ <ifid> ] [
<dr> ] [ <bdr> ] [ <master> ] [ <seqno> ] [ <dbdallsentacked> ] [ <dbdallsent> ] [ <dbdallacked> ] [
<lsaonreqlist> ] [ <lsafromlastreq> ] [ <lsreqrxmts> ] [ <hellooptions> ] [ <dbdoptions> ] [ <lastnonhello> ] [
<deadtimer> ] [ <pacingtimer> ] [ <dbdrxmtimer> ] [ <reqrxmtimer> ] [ <lsutimer> ] [ <rerxmtimer> ] [
<fastrerxmtimer> ] [ <lsacktimer> ] [ <grtimer> ] [ <helpermode> ] [ <helpercand> ] [ <helperterm> ] [
<sendlbd> ] [ <sendlsreq> ] [ <sendlsu> ] [ <sendlsurxmt> ] [ <sendlsack> ] [ <sendlsreqreply> ] ] ]
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information             |
| ipv6           | (Optional) Display IPv6 information         |
| ospfv3         | Display OSPFv3 status and configuration     |
| tag            | (Optional) Process tag                      |
| vrf            | (Optional) Display per-VRF information      |
| vrf-name       | (Optional) VRF name                         |
| vrf-known-name | (Optional) Known VRF name                   |
| all            | (Optional) Display information for all VRFs |
| virtual-links  | Virtual link information                    |
| __readonly__   | (Optional)                                  |
| TABLE_ctx      | (Optional)                                  |
| ptag           | (Optional)                                  |
| cname          | (Optional)                                  |
| TABLE_vlink    | (Optional)                                  |
| name           | (Optional)                                  |
| nbr_rid        | (Optional)                                  |
| if_state       | (Optional)                                  |

|                                    |   |
|------------------------------------|---|
| <i>transit_area</i>                | (Optional)                                  |
| <i>nh_intf</i>                     | (Optional)                                  |
| <i>transit_area_stub</i>           | (Optional)                                  |
| <i>transit_area_nssa</i>           | (Optional)                                  |
| <i>masklen</i>                     | (Optional)                                  |
| <i>inst_id</i>                     | (Optional)                                  |
| <i>area</i>                        | (Optional)                                  |
| <i>if_cfg</i>                      | (Optional)                                  |
| <i>state_str</i>                   | (Optional)                                  |
| <i>type_str</i>                    | (Optional)                                  |
| <i>cost</i>                        | (Optional)                                  |
| <i>ipsec_sa_type</i>               | (Optional) IPsec SA Type                    |
| <i>ipsec_sa_algorithm</i>          | (Optional) IPsec SA Algorithm name          |
| <i>ipsec_sa_spi</i>                | (Optional) IPsec SA SPI Value               |
| <i>ipsec_esp_sa_type</i>           | (Optional) IPsec ESP SA Type                |
| <i>ipsec_esp_sa_encr_algorithm</i> | (Optional) IPsec ESP SA ENCR Algorithm name |
| <i>ipsec_esp_sa_auth_algorithm</i> | (Optional) IPsec ESP SA AUTH Algorithm name |
| <i>ipsec_esp_sa_spi</i>            | (Optional) IPsec ESP SA SPI Value           |
| <i>index</i>                       | (Optional)                                  |
| <i>passive</i>                     | (Optional)                                  |
| <i>mpls</i>                        | (Optional)                                  |
| <i>transmit_delay</i>              | (Optional)                                  |
| <i>if_priority</i>                 | (Optional)                                  |
| <i>dr_rid</i>                      | (Optional)                                  |
| <i>bdr_rid</i>                     | (Optional)                                  |
| <i>nbr_total</i>                   | (Optional)                                  |
| <i>nbr_flood</i>                   | (Optional)                                  |
| <i>nbr_adj</i>                     | (Optional)                                  |
| <i>gr_nbr</i>                      | (Optional)                                  |

|                           |            |
|---------------------------|------------|
| <i>hello_interval</i>     | (Optional) |
| <i>dead_interval</i>      | (Optional) |
| <i>wait_interval</i>      | (Optional) |
| <i>rxmt_interval</i>      | (Optional) |
| <i>hello_timer</i>        | (Optional) |
| <i>wait_timer</i>         | (Optional) |
| <i>pacing_timer</i>       | (Optional) |
| <i>lsu_timer</i>          | (Optional) |
| <i>lsack_timer</i>        | (Optional) |
| <i>netlsa_throt_timer</i> | (Optional) |
| <i>link_lsa_cnt</i>       | (Optional) |
| <i>link_lsa_crc</i>       | (Optional) |
| <i>state</i>              | (Optional) |
| <i>transition</i>         | (Optional) |
| <i>lastchange</i>         | (Optional) |
| <i>priority</i>           | (Optional) |
| <i>ifid</i>               | (Optional) |
| <i>dr</i>                 | (Optional) |
| <i>bdr</i>                | (Optional) |
| <i>master</i>             | (Optional) |
| <i>seqno</i>              | (Optional) |
| <i>dbdallsentacked</i>    | (Optional) |
| <i>dbdallsent</i>         | (Optional) |
| <i>dbdallacked</i>        | (Optional) |
| <i>lsaonreqlist</i>       | (Optional) |
| <i>lsafromlastreq</i>     | (Optional) |
| <i>lsreqrxmts</i>         | (Optional) |
| <i>helloptions</i>        | (Optional) |
| <i>dbdoptions</i>         | (Optional) |

|                       |            |
|-----------------------|------------|
| <i>lastmonhello</i>   | (Optional) |
| <i>deadtimer</i>      | (Optional) |
| <i>pacingtimer</i>    | (Optional) |
| <i>dbdrxmtimer</i>    | (Optional) |
| <i>reqrxmtimer</i>    | (Optional) |
| <i>lsutimer</i>       | (Optional) |
| <i>rerxmtimer</i>     | (Optional) |
| <i>fastrerxmtimer</i> | (Optional) |
| <i>lsacktimer</i>     | (Optional) |
| <i>grtimer</i>        | (Optional) |
| <i>helpermode</i>     | (Optional) |
| <i>helpercand</i>     | (Optional) |
| <i>helperterm</i>     | (Optional) |
| <i>senddbd</i>        | (Optional) |
| <i>sendlsreq</i>      | (Optional) |
| <i>sendlsu</i>        | (Optional) |
| <i>sendlsurxmt</i>    | (Optional) |
| <i>sendlsack</i>      | (Optional) |
| <i>sendlsreqreply</i> | (Optional) |

**Command Mode**

- /exec

## show ospfv3 virtual-links brief

```
show [ ipv6 ] ospfv3 [ <tag> ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] virtual-links brief [ vrf {
<vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_ctx <ptag> <cname> <vlink_count> [
TABLE_vlink <nbr_rid> <vlink_num> <transit_area> <cost> <if_state> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| ipv6                  | (Optional) Display IPv6 information         |
| ospfv3                | Display OSPFv3 status and configuration     |
| <i>tag</i>            | (Optional) Process tag                      |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| virtual-links         | Virtual link information                    |
| brief                 | Display summary of OSPFv3 virtual links     |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_ctx             | (Optional)                                  |
| <i>ptag</i>           | (Optional)                                  |
| <i>cname</i>          | (Optional)                                  |
| <i>vlink_count</i>    | (Optional)                                  |
| TABLE_vlink           | (Optional)                                  |
| <i>nbr_rid</i>        | (Optional)                                  |
| <i>vlink_num</i>      | (Optional)                                  |
| <i>transit_area</i>   | (Optional)                                  |
| <i>cost</i>           | (Optional)                                  |
| <i>if_state</i>       | (Optional)                                  |

### Command Mode

- /exec

## show otv isis

```
show otv isis [ <otv-isis-tag> ] [ vpn { <vrf-name> | all } ] [ process | protocol ] [ vpn { <vrf-name> | all } ]
[ __readonly__ { TABLE_process_tag <process-tag-out> <mcast-encap-type-out> { TABLE_vrf
<vrf-name-out> <system-id-out> <is-type-out> <otv-version-out> <interop-flag-out> <sap-out> <qh-out>
<mtu-out> <gr-status-out> <gr-state-out> <last-gr-status-out> <metric-send-out> <metric-accept-out>
<area-addr-out> <proc-state-out> [ <proc-state-net-out> ] [ <proc-state-vpn-out> ] [ <proc-state-mem-out>
] [ <proc-state-seq-wrap-out> ] <vrf-id-out> [ { TABLE_intf <intf-name-out> } ] [ <auth-out> ] [
<auth-chk-out> ] [ <auth-kchain-out> ] [ { TABLE_redist <max_redist> <warning> <threshold>
<current_count> } ] [ { TABLE_afi_safi <afi-safi-out> <intf-num-out> <adj-check-out> [ { TABLE_redist_proc
<redist-pib-out> <redist-rpm-out> } ] [ { TABLE_leak <dist-src-lvl-out> <dist-dest-lvl-out> <dist-leak-all-out>
<dist-rpm-out> } ] <admin-dist-out> <tib-id-out> } ] <aed-capability-out> <aed-priority-out>
<aed-srv-elected-out> <aed-state-out> <aed-elected-oper-out> <aed-backup-srv-out> <aed-backup-state-out>
<aed-backup-elected-oper-out> } } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information              |
| otv                         | Display OTV information                      |
| isis                        | Display IS-IS status and configuration       |
| <i>otv-isis-tag</i>         | (Optional) Routing process tag               |
| vpn                         | (Optional) Display VPN information           |
| <i>vrf-name</i>             | (Optional) VPN name                          |
| all                         | (Optional) Display information for all VRFs  |
| process                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED    |
| protocol                    | (Optional) Display IS-IS process information |
| __readonly__                | (Optional)                                   |
| TABLE_process_tag           | (Optional)                                   |
| <i>process-tag-out</i>      | (Optional)                                   |
| <i>mcast-encap-type-out</i> | (Optional)                                   |
| TABLE_vrf                   | (Optional)                                   |
| <i>vrf-name-out</i>         | (Optional)                                   |
| TABLE_afi_safi              | (Optional)                                   |
| <i>afi-safi-out</i>         | (Optional)                                   |
| <i>system-id-out</i>        | (Optional)                                   |
| <i>is-type-out</i>          | (Optional)                                   |

|                                |            |
|--------------------------------|------------|
| <i>otv-version-out</i>         | (Optional) |
| <i>interop-flag-out</i>        | (Optional) |
| <i>sap-out</i>                 | (Optional) |
| <i>qh-out</i>                  | (Optional) |
| <i>mtu-out</i>                 | (Optional) |
| <i>gr-status-out</i>           | (Optional) |
| <i>gr-state-out</i>            | (Optional) |
| <i>last-gr-status-out</i>      | (Optional) |
| <i>metric-send-out</i>         | (Optional) |
| <i>metric-accept-out</i>       | (Optional) |
| <i>area-addr-out</i>           | (Optional) |
| <i>proc-state-out</i>          | (Optional) |
| <i>proc-state-net-out</i>      | (Optional) |
| <i>proc-state-vpn-out</i>      | (Optional) |
| <i>proc-state-mem-out</i>      | (Optional) |
| <i>proc-state-seq-wrap-out</i> | (Optional) |
| <i>vrf-id-out</i>              | (Optional) |
| TABLE_intf                     | (Optional) |
| <i>intf-name-out</i>           | (Optional) |
| <i>auth-out</i>                | (Optional) |
| <i>auth-chk-out</i>            | (Optional) |
| <i>auth-kchain-out</i>         | (Optional) |
| TABLE_redist                   | (Optional) |
| <i>max_redist</i>              | (Optional) |
| <i>warning</i>                 | (Optional) |
| <i>threshold</i>               | (Optional) |
| <i>current_count</i>           | (Optional) |
| <i>intf-num-out</i>            | (Optional) |
| <i>adj-check-out</i>           | (Optional) |

|                                    |            |
|------------------------------------|------------|
| TABLE_redist_proc                  | (Optional) |
| <i>redist-pib-out</i>              | (Optional) |
| <i>redist-rpm-out</i>              | (Optional) |
| TABLE_leak                         | (Optional) |
| <i>dist-src-lvl-out</i>            | (Optional) |
| <i>dist-dest-lvl-out</i>           | (Optional) |
| <i>dist-leak-all-out</i>           | (Optional) |
| <i>dist-rpm-out</i>                | (Optional) |
| <i>admin-dist-out</i>              | (Optional) |
| <i>tib-id-out</i>                  | (Optional) |
| <i>aed-capability-out</i>          | (Optional) |
| <i>aed-priority-out</i>            | (Optional) |
| <i>aed-srv-elected-out</i>         | (Optional) |
| <i>aed-state-out</i>               | (Optional) |
| <i>aed-elected-oper-out</i>        | (Optional) |
| <i>aed-backup-srv-out</i>          | (Optional) |
| <i>aed-backup-state-out</i>        | (Optional) |
| <i>aed-backup-elected-oper-out</i> | (Optional) |

### Command Mode

- /exec



## show otv isis active-source

```
show otv isis [ <otv-isis-tag> ] active-source [ vlan <vlan-id> [ group <gip-addr> [ source <sip-addr> ] ] ] [
summary ] [ vpn { <vrf-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <vrf-name-out>
[ <af-string-out> ] [ TABLE_mrout <source-out> <vlan-id-out> <group-out> [ TABLE_adj
<interface-name-out> <iod-out> <site-index-out> <unicast-only-key-out> ] [ TABLE_active_source
<interface-name-out> <iod-out> <site-index-out> <unicast-only-key-out> <source-and-group-addr-out> ] ]
]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                 |
| otv                    | Display OTV information                         |
| isis                   | Display IS-IS status and configuration          |
| <i>otv-isis-tag</i>    | (Optional) Routing process tag                  |
| vpn                    | (Optional) Display VPN information              |
| <i>vrf-name</i>        | (Optional) VPN name                             |
| all                    | (Optional) All configured VPNs                  |
| active-source          | Display IS-IS Active-source information         |
| vlan                   | (Optional) Display IS-IS VLAN information       |
| <i>vlan-id</i>         | (Optional) Display IS-IS VLAN information       |
| group                  | (Optional) Display IS-IS Group information      |
| source                 | (Optional) Display IS-IS Source information     |
| <i>gip-addr</i>        | (Optional) Display single IP redistribute route |
| <i>sip-addr</i>        | (Optional) Display single IP redistribute route |
| summary                | (Optional) Display route counts                 |
| <u>__readonly__</u>    | (Optional)                                      |
| TABLE_process_tag      | (Optional)                                      |
| <i>process-tag-out</i> | (Optional)                                      |
| <i>vrf-name-out</i>    | (Optional)                                      |
| <i>af-string-out</i>   | (Optional)                                      |
| TABLE_mrout            | (Optional)                                      |
| <i>source-out</i>      | (Optional)                                      |

|                                  |            |
|----------------------------------|------------|
| <i>vlan-id-out</i>               | (Optional) |
| <i>group-out</i>                 | (Optional) |
| TABLE_adj                        | (Optional) |
| <i>interface-name-out</i>        | (Optional) |
| <i>iod-out</i>                   | (Optional) |
| <i>site-index-out</i>            | (Optional) |
| <i>unicast-only-key-out</i>      | (Optional) |
| TABLE_active_source              | (Optional) |
| <i>interface-name-out</i>        | (Optional) |
| <i>iod-out</i>                   | (Optional) |
| <i>site-index-out</i>            | (Optional) |
| <i>unicast-only-key-out</i>      | (Optional) |
| <i>source-and-group-addr-out</i> | (Optional) |

**Command Mode**

- /exec

## show otv isis adjacency

```
show otv isis [ <otv-isis-tag> ] adjacency [ <interface> ] { [ system-id <sid> ] | [ detail ] | [ summary ] } [ vpn
{ <vrf-name> | all } ] [ __readonly__ { TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out>
<adj-summary-out> <adj-interface-out> [ <adj-interface-name-out> ] [ { TABLE_process_adj
<adj-sys-name-out> <adj-sys-id-out> [ <adj-usage-out> ] [ <adj-level-out> ] <adj-state-out>
<adj-hold-time-out> <adj-intf-name-out> <adj-site-out> <adj-detail-set-out> [ { <adj-transitions-out>
<adj-flap-out> [ <adj-flap-time-out> ] <adj-ckt-type-out> <adj-ipv4-addr-out> <adj-ipv6-addr-out>
<adj-bcast-out> [ { <adj-ckt-id-out> <adj-lan-prio-out> } ] } ] <adj-resurrect-out> [ { <adj-resurrect-count-out>
<adj-resurrect-hwm-out> } ] } ] } ] [ { TABLE_lan_adj_sum <adj-summ-lan-level-out>
<adj-summ-lan-state-out> <adj-summ-lan-count-out> } ] } ] }
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                                  |
| otv                      | Display OTV information  |
| isis                     | Display IS-IS status and configuration                           |
| <i>otv-isis-tag</i>      | (Optional) Routing process tag                                   |
| vpn                      | (Optional) Display VPN information                               |
| <i>vrf-name</i>          | (Optional) VPN name  |
| all                      | (Optional) All configured VPNs                                   |
| adjacency                | Display IS-IS adjacency information                              |
| <i>interface</i>         | (Optional) IS-IS interface                                       |
| system-id                | (Optional) Hostname or System ID                                 |
| <i>sid</i>               | (Optional) Hostname or System ID (in the form of XXXX.XXXX.XXXX) |
| detail                   | (Optional) Display IS-IS adjacency detail information            |
| summary                  | (Optional) Display IS-IS adjacency summary information           |
| __readonly__             | (Optional)   |
| TABLE_process_tag        | (Optional)   |
| <i>process-tag-out</i>   | (Optional)   |
| TABLE_vrf                | (Optional)   |
| <i>vrf-name-out</i>      | (Optional)   |
| <i>adj-summary-out</i>   | (Optional)   |
| <i>adj-interface-out</i> | (Optional)   |

|                                |            |
|--------------------------------|------------|
| <i>adj-interface-name-out</i>  | (Optional) |
| TABLE_process_adj              | (Optional) |
| <i>adj-sys-name-out</i>        | (Optional) |
| <i>adj-sys-id-out</i>          | (Optional) |
| <i>adj-usage-out</i>           | (Optional) |
| <i>adj-level-out</i>           | (Optional) |
| <i>adj-state-out</i>           | (Optional) |
| <i>adj-hold-time-out</i>       | (Optional) |
| <i>adj-intf-name-out</i>       | (Optional) |
| <i>adj-site-out</i>            | (Optional) |
| <i>adj-detail-set-out</i>      | (Optional) |
| <i>adj-transitions-out</i>     | (Optional) |
| <i>adj-flap-out</i>            | (Optional) |
| <i>adj-flap-time-out</i>       | (Optional) |
| <i>adj-ckt-type-out</i>        | (Optional) |
| <i>adj-ipv4-addr-out</i>       | (Optional) |
| <i>adj-ipv6-addr-out</i>       | (Optional) |
| <i>adj-bcast-out</i>           | (Optional) |
| <i>adj-ckt-id-out</i>          | (Optional) |
| <i>adj-lan-prio-out</i>        | (Optional) |
| <i>adj-resurrect-out</i>       | (Optional) |
| <i>adj-resurrect-count-out</i> | (Optional) |
| <i>adj-resurrect-hwm-out</i>   | (Optional) |
| TABLE_lan_adj_sum              | (Optional) |
| <i>adj-summ-lan-level-out</i>  | (Optional) |
| <i>adj-summ-lan-state-out</i>  | (Optional) |
| <i>adj-summ-lan-count-out</i>  | (Optional) |

**Command Mode**

- /exec

## show otv isis aed-svr-req local

```
show otv isis [ <otv-isis-tag> ] aed-svr-req { local | remote } [ __readonly__ { TABLE_process_tag
<process-tag-out> { TABLE_vrf <vrf-name-out> [ { TABLE_aed_svr_req_local <overlay-iod-out>
<cluster-id-out> <partition-id-out> <device-id-out> <old-aed-out> <old-aed-backup-out> <new-aed-out>
<new-aed-backup-out> <site-id-out> <delete-flag-out> <version-out> <start-vlan-id-out> <end-vlan-id-out>
<step-size-out> } ] [ { TABLE_aed_svr_req_remote <overlay-iod-out> <cluster-id-out> <partition-id-out>
<device-id-out> <old-aed-out> <old-aed-backup-out> <new-aed-out> <new-aed-backup-out> <site-id-out>
<vlan-id-out> <version-out> <delete-flag-out> } ] } ] }
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information        |
| otv                       | Display OTV information                |
| isis                      | Display IS-IS status and configuration |
| <i>otv-isis-tag</i>       | (Optional) Routing process tag         |
| aed-svr-req               | Display aed svr req Info               |
| local                     | local                                  |
| remote                    | remote                                 |
| <i>__readonly__</i>       | (Optional)                             |
| TABLE_process_tag         | (Optional)                             |
| <i>process-tag-out</i>    | (Optional)                             |
| TABLE_vrf                 | (Optional)                             |
| <i>vrf-name-out</i>       | (Optional)                             |
| TABLE_aed_svr_req_local   | (Optional)                             |
| <i>overlay-iod-out</i>    | (Optional)                             |
| <i>cluster-id-out</i>     | (Optional)                             |
| <i>partition-id-out</i>   | (Optional)                             |
| <i>device-id-out</i>      | (Optional)                             |
| <i>old-aed-out</i>        | (Optional)                             |
| <i>old-aed-backup-out</i> | (Optional)                             |
| <i>new-aed-out</i>        | (Optional)                             |
| <i>new-aed-backup-out</i> | (Optional)                             |
| <i>site-id-out</i>        | (Optional)                             |

|                           |            |
|---------------------------|------------|
| <i>delete-flag-out</i>    | (Optional) |
| <i>version-out</i>        | (Optional) |
| <i>start-vlan-id-out</i>  | (Optional) |
| <i>end-vlan-id-out</i>    | (Optional) |
| <i>step-size-out</i>      | (Optional) |
| TABLE_aed_svr_req_remote  | (Optional) |
| <i>overlay-iod-out</i>    | (Optional) |
| <i>cluster-id-out</i>     | (Optional) |
| <i>partition-id-out</i>   | (Optional) |
| <i>device-id-out</i>      | (Optional) |
| <i>old-aed-out</i>        | (Optional) |
| <i>old-aed-backup-out</i> | (Optional) |
| <i>new-aed-out</i>        | (Optional) |
| <i>new-aed-backup-out</i> | (Optional) |
| <i>site-id-out</i>        | (Optional) |
| <i>vlan-id-out</i>        | (Optional) |
| <i>version-out</i>        | (Optional) |
| <i>delete-flag-out</i>    | (Optional) |

**Command Mode**

- /exec

## show otv isis database

```
show otv isis [ <otv-isis-tag> ] [ site ] database [ mgroup ] [ detail | advertise | summary ] [ <lid> ] { [
zero-sequence ] [ adjacency <adj-id> ] } [ vpn { <vrf-name> | all } ] [ __readonly__ { TABLE_process_tag
<process-tag-out> { TABLE_vrf <vrf-name-out> [ <dbase-hname-absent-out> ] [ { TABLE_process_lvl
<dbase-level-out> [ { TABLE_process_lsp <dbase-lsp-name-out> <dbase-lsp-status-out>
<dbase-lsp-absent-out> [ { <dbase-lsp-seqnum-out> <dbase-lsp-cksum-out> [ <dbase-lsp-lifetime-str-out> ]
[ <dbase-lsp-lifetime-out> ] <dbase-att-out> <dbase-partition-out> <dbase-overload-out> <dbase-istype-out>
} ] [ { <dbase-lsp-instance-out> [ { TABLE_process_tlv <dbase-lsp-tlv-name-out> [ <dbase-lsp-area-addr-out>
] [ <dbase-lsp-is-nbr-name-out> ] [ <dbase-lsp-is-nbr-metric-out> ] [ <dbase-lsp-is-nbr-ext-metric-out> ] [
<dbase-lsp-es-nbr-name-out> ] [ <dbase-lsp-es-nbr-metric-out> ] [ <dbase-lsp-es-nbr-ext-metric-out> ] [
<dbase-lsp-auth-type-out> ] [ <dbase-lsp-auth-len-out> ] [ <dbase-lsp-ext-is-name-out> ] [
<dbase-lsp-ext-is-metric-out> ] [ <dbase-lsp-ip-ri-addr-out> ] [ <dbase-lsp-ip-ri-mask-out> ] [
<dbase-lsp-ip-ri-metric-out> ] [ <dbase-lsp-ip-ri-ext-metric-out> ] [ <dbase-lsp-ip-ri-up-down-out> ] [ {
TABLE_process_nlpid <dbase-lsp-prot-support-out> } ] [ <dbase-lsp-ip-addr-out> ] [ <dbase-lsp-ipv6-addr-out>
] [ { TABLE_process_extip <dbase-lsp-extip-addr-out> <dbase-lsp-extip-prefix-len-out>
<dbase-lsp-extip-metric-out> <dbase-lsp-extip-up-down-out> } ] [ <dbase-lsp-hname-out> ] [
<dbase-lsp-hname-len-out> ] [ { TABLE_process_extipv6 <dbase-lsp-extipv6-addr-out>
<dbase-lsp-extipv6-prefix-len-out> <dbase-lsp-extipv6-metric-out> <dbase-lsp-extipv6-up-down-out>
<dbase-lsp-extipv6-ext-origin-out> } ] [ <dbase-lsp-tlv-len-out> ] [ <dbase-lsp-tlv-unknown-out> ] [ {
TABLE_process_subtlv <dbase-lsp-subtlv-name-out> [ <dbase-lsp-extis-admin-group-out> ] [
<dbase-lsp-subtlv-ip-addr-out> ] [ <dbase-lsp-extis-bw-out> ] [ <dbase-lsp-extis-pri1-out> ] [
<dbase-lsp-extis-pri1-val-out> ] [ <dbase-lsp-extis-pri2-out> ] [ <dbase-lsp-extis-pri2-val-out> ] [
<dbase-lsp-extis-te-metric-out> ] [ <dbase-lsp-ext-ipv4-pfxsid> <dbase-lsp-ext-ipv4-pfxsid-algo>
<dbase-lsp-ext-ipv4-pfxsid-flag> ] [ <dbase-lsp-ext-ipv6-pfxsid> <dbase-lsp-ext-ipv6-pfxsid-algo>
<dbase-lsp-ext-ipv6-pfxsid-flag> ] [ <dbase-lsp-subtlv-len-out> ] [ <dbase-lsp-subtlv-unknown-out> ] } ] }
] <dbase-lsp-digest-out> } ] } [ { <dbase-lsp-total-out> [ { <dbase-lsp-empty-out> <dbase-lsp-zeroseq-out>
} ] } ] } ] }
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| otv                 | Display OTV information                               |
| isis                | Display IS-IS status and configuration                |
| <i>otv-isis-tag</i> | (Optional) Routing process tag                        |
| site                | (Optional) Display IS-IS OTV site information         |
| vpn                 | (Optional) Display VPN information                    |
| <i>vrf-name</i>     | (Optional) VPN name                                   |
| all                 | (Optional) All configured VPNs                        |
| database            | Display IS-IS database information                    |
| mgroup              | (Optional) Display IS-IS GM database information      |
| <i>lid</i>          | (Optional) LSP ID in the form of XXXX.XXXX.XXXX.XX-XX |

|                                   |  |
|-----------------------------------|--|
| detail                            | (Optional) Display detailed IS-IS information  |
| advertise                         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED      |
| summary                           | (Optional) Display summary IS-IS information   |
| zero-sequence                     | (Optional) LSP with zero sequence number       |
| adjacency                         | (Optional) Adjacency filter                    |
| <i>adj-id</i>                     | (Optional) Single exact match adjacency filter |
| <i>__readonly__</i>               | (Optional)                                     |
| TABLE_process_tag                 | (Optional)                                     |
| <i>process-tag-out</i>            | (Optional)                                     |
| TABLE_vrf                         | (Optional)                                     |
| <i>vrf-name-out</i>               | (Optional)                                     |
| <i>dbase-hname-absent-out</i>     | (Optional)                                     |
| TABLE_process_lvl                 | (Optional)                                     |
| <i>dbase-level-out</i>            | (Optional)                                     |
| TABLE_process_lsp                 | (Optional)                                     |
| <i>dbase-lsp-name-out</i>         | (Optional)                                     |
| <i>dbase-lsp-status-out</i>       | (Optional)                                     |
| <i>dbase-lsp-absent-out</i>       | (Optional)                                     |
| <i>dbase-lsp-seqnum-out</i>       | (Optional)                                     |
| <i>dbase-lsp-cksum-out</i>        | (Optional)                                     |
| <i>dbase-lsp-lifetime-str-out</i> | (Optional)                                     |
| <i>dbase-lsp-lifetime-out</i>     | (Optional)                                     |
| <i>dbase-att-out</i>              | (Optional)                                     |
| <i>dbase-partition-out</i>        | (Optional)                                     |
| <i>dbase-overload-out</i>         | (Optional)                                     |
| <i>dbase-istype-out</i>           | (Optional)                                     |
| <i>dbase-lsp-instance-out</i>     | (Optional)                                     |
| TABLE_process_tlv                 | (Optional)                                     |
| <i>dbase-lsp-tlv-name-out</i>     | (Optional)                                     |



|  |            |
|--|------------|
| <i>dbase-lsp-area-addr-out</i>         | (Optional) |
| <i>dbase-lsp-is-nbr-name-out</i>       | (Optional) |
| <i>dbase-lsp-is-nbr-metric-out</i>     | (Optional) |
| <i>dbase-lsp-is-nbr-ext-metric-out</i> | (Optional) |
| <i>dbase-lsp-es-nbr-name-out</i>       | (Optional) |
| <i>dbase-lsp-es-nbr-metric-out</i>     | (Optional) |
| <i>dbase-lsp-es-nbr-ext-metric-out</i> | (Optional) |
| <i>dbase-lsp-auth-type-out</i>         | (Optional) |
| <i>dbase-lsp-auth-len-out</i>          | (Optional) |
| <i>dbase-lsp-ext-is-name-out</i>       | (Optional) |
| <i>dbase-lsp-ext-is-metric-out</i>     | (Optional) |
| <i>dbase-lsp-ip-ri-addr-out</i>        | (Optional) |
| <i>dbase-lsp-ip-ri-mask-out</i>        | (Optional) |
| <i>dbase-lsp-ip-ri-metric-out</i>      | (Optional) |
| <i>dbase-lsp-ip-ri-ext-metric-out</i>  | (Optional) |
| <i>dbase-lsp-ip-ri-up-down-out</i>     | (Optional) |
| TABLE_process_nlpid                    | (Optional) |
| <i>dbase-lsp-prot-support-out</i>      | (Optional) |
| <i>dbase-lsp-ip-addr-out</i>           | (Optional) |
| <i>dbase-lsp-ipv6-addr-out</i>         | (Optional) |
| TABLE_process_extip                    | (Optional) |
| <i>dbase-lsp-extip-addr-out</i>        | (Optional) |
| <i>dbase-lsp-extip-prefix-len-out</i>  | (Optional) |
| <i>dbase-lsp-extip-metric-out</i>      | (Optional) |
| <i>dbase-lsp-extip-up-down-out</i>     | (Optional) |
| <i>dbase-lsp-hname-out</i>             | (Optional) |
| <i>dbase-lsp-hname-len-out</i>         | (Optional) |
| TABLE_process_extipv6                  | (Optional) |
| <i>dbase-lsp-extipv6-addr-out</i>      | (Optional) |

|   |            |
|---|------------|
| <i>dbase-lsp-extipv6-prefix-len-out</i> | (Optional) |
| <i>dbase-lsp-extipv6-metric-out</i>     | (Optional) |
| <i>dbase-lsp-extipv6-up-down-out</i>    | (Optional) |
| <i>dbase-lsp-extipv6-ext-origin-out</i> | (Optional) |
| <i>dbase-lsp-tlv-len-out</i>            | (Optional) |
| <i>dbase-lsp-tlv-unknown-out</i>        | (Optional) |
| TABLE_process_subtlv                    | (Optional) |
| <i>dbase-lsp-subtlv-name-out</i>        | (Optional) |
| <i>dbase-lsp-extis-admin-group-out</i>  | (Optional) |
| <i>dbase-lsp-subtlv-ip-addr-out</i>     | (Optional) |
| <i>dbase-lsp-extis-bw-out</i>           | (Optional) |
| <i>dbase-lsp-extis-pri1-out</i>         | (Optional) |
| <i>dbase-lsp-extis-pri1-val-out</i>     | (Optional) |
| <i>dbase-lsp-extis-pri2-out</i>         | (Optional) |
| <i>dbase-lsp-extis-pri2-val-out</i>     | (Optional) |
| <i>dbase-lsp-extis-te-metric-out</i>    | (Optional) |
| <i>dbase-lsp-ext-ipv4-pfxsid</i>        | (Optional) |
| <i>dbase-lsp-ext-ipv4-pfxsid-algo</i>   | (Optional) |
| <i>dbase-lsp-ext-ipv4-pfxsid-flag</i>   | (Optional) |
| <i>dbase-lsp-ext-ipv6-pfxsid</i>        | (Optional) |
| <i>dbase-lsp-ext-ipv6-pfxsid-algo</i>   | (Optional) |
| <i>dbase-lsp-ext-ipv6-pfxsid-flag</i>   | (Optional) |
| <i>dbase-lsp-subtlv-len-out</i>         | (Optional) |
| <i>dbase-lsp-subtlv-unknown-out</i>     | (Optional) |
| <i>dbase-lsp-digest-out</i>             | (Optional) |
| <i>dbase-lsp-total-out</i>              | (Optional) |
| <i>dbase-lsp-empty-out</i>              | (Optional) |
| <i>dbase-lsp-zeroseq-out</i>            | (Optional) |

**Command Mode**

- /exec

## show otv isis ed-summary local

```
show otv isis [ <otv-isis-tag> ] ed-summary local [ __readonly__ { TABLE_process_tag <process-tag-out>
{ TABLE_vrf <vrf-name-out> [ { TABLE_ed_summary_local <site-id-out> <version-out> <fwd-ready-out>
<device-id-out> <lsp-id-out> } ] } ] }
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information        |
| otv                    | Display OTV information                |
| isis                   | Display IS-IS status and configuration |
| <i>otv-isis-tag</i>    | (Optional) Routing process tag         |
| ed-summary             | Display ED Summary Info                |
| local                  | local                                  |
| <i>__readonly__</i>    | (Optional)                             |
| TABLE_process_tag      | (Optional)                             |
| <i>process-tag-out</i> | (Optional)                             |
| TABLE_vrf              | (Optional)                             |
| <i>vrf-name-out</i>    | (Optional)                             |
| TABLE_ed_summary_local | (Optional)                             |
| <i>site-id-out</i>     | (Optional)                             |
| <i>version-out</i>     | (Optional)                             |
| <i>fwd-ready-out</i>   | (Optional)                             |
| <i>device-id-out</i>   | (Optional)                             |
| <i>lsp-id-out</i>      | (Optional)                             |

### Command Mode

- /exec

## show otv isis ed-summary remote

```
show otv isis [ <otv-isis-tag> ] ed-summary remote [ site-identifier { <site-id-mac> | <site-id-hex> } ] [
__readonly__ { TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> [ {
TABLE_ed_summary_site <site-id-out> <ref-count-out> [ { TABLE_remote <device-id-out> <aed-srv-out>
<fwd-ready-out> <version-out> <lsp-id-out> } ] } } } ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information          |
| otv                    | Display OTV information                  |
| isis                   | Display IS-IS status and configuration   |
| <i>otv-isis-tag</i>    | (Optional) Routing process tag           |
| ed-summary             | Display ED Summary Info                  |
| remote                 | remote                                   |
| site-identifier        | (Optional) site-identifier               |
| <i>site-id-mac</i>     | (Optional) Site ID in MAC address format |
| <i>site-id-hex</i>     | (Optional) Site ID in hex                |
| <i>__readonly__</i>    | (Optional)                               |
| TABLE_process_tag      | (Optional)                               |
| <i>process-tag-out</i> | (Optional)                               |
| TABLE_vrf              | (Optional)                               |
| <i>vrf-name-out</i>    | (Optional)                               |
| TABLE_ed_summary_site  | (Optional)                               |
| <i>site-id-out</i>     | (Optional)                               |
| <i>ref-count-out</i>   | (Optional)                               |
| TABLE_remote           | (Optional)                               |
| <i>device-id-out</i>   | (Optional)                               |
| <i>aed-srv-out</i>     | (Optional)                               |
| <i>fwd-ready-out</i>   | (Optional)                               |
| <i>version-out</i>     | (Optional)                               |
| <i>lsp-id-out</i>      | (Optional)                               |

**Command Mode**

- /exec

## show otv isis fast-flood

```
show otv isis [ <otv-isis-tag> ] fast-flood [ __readonly__ { TABLE_process_tag <process-tag-out> {
TABLE_vrf <vrf-name-out> <tokens-left-out> [ { TABLE_fast_flood <level-out> <on-off-out> <interval-out>
<packet-count-out> } ] } } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information        |
| otv                     | Display OTV information                |
| isis                    | Display IS-IS status and configuration |
| <i>otv-isis-tag</i>     | (Optional) Routing process tag         |
| fast-flood              | Fast flood the LSP's                   |
| <i>__readonly__</i>     | (Optional)                             |
| TABLE_process_tag       | (Optional)                             |
| <i>process-tag-out</i>  | (Optional)                             |
| TABLE_vrf               | (Optional)                             |
| <i>vrf-name-out</i>     | (Optional)                             |
| <i>tokens-left-out</i>  | (Optional)                             |
| TABLE_fast_flood        | (Optional)                             |
| <i>level-out</i>        | (Optional)                             |
| <i>on-off-out</i>       | (Optional)                             |
| <i>interval-out</i>     | (Optional)                             |
| <i>packet-count-out</i> | (Optional)                             |

### Command Mode

- /exec

# show otv isis hostname

```
show otv isis [ <otv-isis-tag> ] hostname [ detail ] [ vpn { <vrf-name> | all } ] [ __readonly__ {
TABLE_process_tag <tag-out> <hname-enabled-out> <hname-detail-out> [ { TABLE_vrf <vrf-name-out>
[ { TABLE_hname <hname-level-out> <hname-id-out> <hname-id-mine-out> <hname-name-out> } ] } ] } ]
]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information               |
| otv                      | Display OTV information                       |
| isis                     | Display IS-IS status and configuration        |
| <i>otv-isis-tag</i>      | (Optional) Routing process tag                |
| vpn                      | (Optional) Display VPN information            |
| <i>vrf-name</i>          | (Optional) VPN name                           |
| all                      | (Optional) All configured VPNs                |
| hostname                 | Display IS-IS hostname table information      |
| detail                   | (Optional) Display detailed IS-IS information |
| __readonly__             | (Optional)                                    |
| TABLE_process_tag        | (Optional)                                    |
| <i>tag-out</i>           | (Optional)                                    |
| <i>hname-enabled-out</i> | (Optional)                                    |
| <i>hname-detail-out</i>  | (Optional)                                    |
| TABLE_vrf                | (Optional)                                    |
| <i>vrf-name-out</i>      | (Optional)                                    |
| TABLE_hname              | (Optional)                                    |
| <i>hname-level-out</i>   | (Optional)                                    |
| <i>hname-id-out</i>      | (Optional)                                    |
| <i>hname-id-mine-out</i> | (Optional)                                    |
| <i>hname-name-out</i>    | (Optional)                                    |

## Command Mode

- /exec



## show otv isis interface

```
show otv isis [ <otv-isis-tag> ] interface [ brief | <interface> ] [ vpn { <vrf-name> | all } ] [ __readonly__ {
TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> [ { TABLE_interface [ {
<intfb-name-out> <intfb-type-out> <intfb-ix-out> <intfb-state-out> <intfb-ready-state-out> <intfb-cid-out>
<intfb-ckt-type-out> <intfb-mtu-out> [ { <intf-p2p-metric-lvl-1-out> <intf-p2p-prio-lvl-1-out>
<intf-p2p-adj-count-lvl-1-out> <intf-p2p-adj-up-count-lvl-1-out> } ] [ { <intf-loopback-metric-lvl-1-out>
<intf-loopback-prio-lvl-1-out> <intf-loopback-adj-count-lvl-1-out> <intf-loopback-adj-up-count-lvl-1-out>
} ] [ { <intf-bcast-metric-lvl-1-out> <intf-bcast-prio-lvl-1-out> <intf-bcast-adj-count-lvl-1-out>
<intf-bcast-adj-up-count-lvl-1-out> } ] } ] [ { <intf-name-out> <intf-status-out> } ] [ { <intf-state-out>
<intf-internal-state-out> [ <intf-cib-disabled-out> ] [ <intf-cid-invalid-out> } ] [ { <intf-ix-out> <intf-cid-out>
<intf-ckt-type-out> } ] [ <intf-passive-mask-out> ] [ <intf-passive-mask-lvl-out> ] [ <intf-mgrp-set-out> ] [
<intf-mgrp-state-out> ] [ <intf-mgrp-id-out> ] [ { TABLE_auth [ { <intf-auth-info-out> [ <intf-auth-kchain-out>
] <intf-auth-chk-info-out> } ] } ] [ <intf-p2p-type-out> ] [ { <intf-p2p-ext-local-cid-out> <intf-p2p-cid-out>
<intf-retx-intv-out> <intf-retx-throttle-out> } ] [ <intf-loopback-type-out> ] [ { <intf-lsp-intv-out>
<intf-mtu-out> [ <intf-hpad-state-out> } ] } ] [ { <intf-p2p-pad-ts-out> ] <intf-p2p-adj-count-out>
<intf-p2p-adj-up-count-out> <intf-p2p-prio-out> <intf-p2p-hello-intv-out> <intf-p2p-hello-multi-out>
<intf-p2p-hello-next-out> [ { TABLE_p2p <intf-p2p-lvl-out> <intf-p2p-adj-lvl-out> <intf-p2p-adj-up-lvl-out>
<intf-p2p-metric-lvl-out> <intf-p2p-csnp-lvl-out> <intf-p2p-csnp-nxt-lvl-out> <intf-p2p-lspid-last-lvl-out>
} ] } ] [ { <intf-bcast-type-out> [ { TABLE_bcast_pad [ { <intf-bcast-lvl-out> <intf-bcast-pad-ts-out> } ] } ]
} ] [ { TABLE_bcast_dis [ { <intf-bcast-lvl-dis-out> <intf-bcast-dis-ts-out> } ] } ] [ { TABLE_bcast_pkt
<intf-bcast-lvl-info-out> <intf-bcast-lvl-metric-out> <intf-bcast-lvl-csnp-intv-out>
<intf-bcast-lvl-csnp-next-out> <intf-bcast-lvl-iih-intv-out> <intf-bcast-lvl-iih-multi-out>
<intf-bcast-lvl-iih-next-out> } ] [ { TABLE_bcast_adj <intf-bcast-lvl-value-out> <intf-bcast-lvl-adj-out>
<intf-bcast-lvl-adj-up-out> <intf-bcast-lvl-prio-out> <intf-bcast-lvl-ctid-out> <intf-bcast-lvl-ctid-ts-out>
} ] } ] [ { TABLE_loopback <intf-loopback-lvl-out> <intf-loopback-lvl-metric-out> } ] [ <intf-unknown-out>
} ] } ] }
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information              |
| otv                 | Display OTV information                      |
| isis                | Display IS-IS status and configuration       |
| <i>otv-isis-tag</i> | (Optional) Routing process tag               |
| vpn                 | (Optional) Display VPN information           |
| <i>vrf-name</i>     | (Optional) VPN name                          |
| all                 | (Optional) All configured VPNs               |
| brief               | (Optional) Brief display of IS-IS interfaces |
| interface           | Display IS-IS interface information          |
| <i>interface</i>    | (Optional) IS-IS interface                   |
| <u>__readonly__</u> | (Optional)                                   |
| TABLE_process_tag   | (Optional)                                   |

|   |            |
|---|------------|
| <i>process-tag-out</i>                      | (Optional) |
| TABLE_vrf                                   | (Optional) |
| <i>vrf-name-out</i>                         | (Optional) |
| TABLE_interface                             | (Optional) |
| <i>intf-status-out</i>                      | (Optional) |
| <i>intf-name-out</i>                        | (Optional) |
| <i>intf-ix-out</i>                          | (Optional) |
| <i>intf-state-out</i>                       | (Optional) |
| <i>intf-cid-out</i>                         | (Optional) |
| <i>intf-ckt-type-out</i>                    | (Optional) |
| <i>intfb-name-out</i>                       | (Optional) |
| <i>intfb-type-out</i>                       | (Optional) |
| <i>intfb-ix-out</i>                         | (Optional) |
| <i>intfb-state-out</i>                      | (Optional) |
| <i>intfb-ready-state-out</i>                | (Optional) |
| <i>intfb-cid-out</i>                        | (Optional) |
| <i>intfb-ckt-type-out</i>                   | (Optional) |
| <i>intf-p2p-metric-lvl-1-out</i>            | (Optional) |
| <i>intf-p2p-prio-lvl-1-out</i>              | (Optional) |
| <i>intf-p2p-adj-count-lvl-1-out</i>         | (Optional) |
| <i>intf-p2p-adj-up-count-lvl-1-out</i>      | (Optional) |
| <i>intf-loopback-metric-lvl-1-out</i>       | (Optional) |
| <i>intf-loopback-prio-lvl-1-out</i>         | (Optional) |
| <i>intf-loopback-adj-count-lvl-1-out</i>    | (Optional) |
| <i>intf-loopback-adj-up-count-lvl-1-out</i> | (Optional) |
| <i>intf-bcast-metric-lvl-1-out</i>          | (Optional) |
| <i>intf-bcast-prio-lvl-1-out</i>            | (Optional) |
| <i>intf-bcast-adj-count-lvl-1-out</i>       | (Optional) |
| <i>intf-bcast-adj-up-count-lvl-1-out</i>    | (Optional) |

|                                   |            |
|-----------------------------------|------------|
| <i>intf-internal-state-out</i>    | (Optional) |
| <i>intf-cib-disabled-out</i>      | (Optional) |
| <i>intf-cid-invalid-out</i>       | (Optional) |
| <i>intf-passive-mask-out</i>      | (Optional) |
| <i>intf-passive-mask-lvl-out</i>  | (Optional) |
| <i>intf-mgrp-set-out</i>          | (Optional) |
| <i>intf-mgrp-state-out</i>        | (Optional) |
| <i>intf-mgrp-id-out</i>           | (Optional) |
| TABLE_auth                        | (Optional) |
| <i>intf-auth-info-out</i>         | (Optional) |
| <i>intf-auth-kchain-out</i>       | (Optional) |
| <i>intf-auth-chk-info-out</i>     | (Optional) |
| <i>intf-p2p-type-out</i>          | (Optional) |
| <i>intf-p2p-ext-local-cid-out</i> | (Optional) |
| <i>intf-p2p-cid-out</i>           | (Optional) |
| <i>intf-retx-intv-out</i>         | (Optional) |
| <i>intf-retx-throttle-out</i>     | (Optional) |
| <i>intf-loopback-type-out</i>     | (Optional) |
| <i>intf-lsp-intv-out</i>          | (Optional) |
| <i>intf-mtu-out</i>               | (Optional) |
| <i>intfb-mtu-out</i>              | (Optional) |
| <i>intf-hpad-state-out</i>        | (Optional) |
| <i>intf-p2p-pad-ts-out</i>        | (Optional) |
| <i>intf-p2p-adj-count-out</i>     | (Optional) |
| <i>intf-p2p-adj-up-count-out</i>  | (Optional) |
| <i>intf-p2p-prio-out</i>          | (Optional) |
| <i>intf-p2p-hello-intv-out</i>    | (Optional) |
| <i>intf-p2p-hello-multi-out</i>   | (Optional) |
| <i>intf-p2p-hello-next-out</i>    | (Optional) |

|                                     |            |
|-------------------------------------|------------|
| TABLE_p2p                           | (Optional) |
| <i>intf-p2p-lvl-out</i>             | (Optional) |
| <i>intf-p2p-adj-lvl-out</i>         | (Optional) |
| <i>intf-p2p-adj-up-lvl-out</i>      | (Optional) |
| <i>intf-p2p-metric-lvl-out</i>      | (Optional) |
| <i>intf-p2p-csnp-lvl-out</i>        | (Optional) |
| <i>intf-p2p-csnp-nxt-lvl-out</i>    | (Optional) |
| <i>intf-p2p-lspid-last-lvl-out</i>  | (Optional) |
| <i>intf-bcast-type-out</i>          | (Optional) |
| TABLE_bcast_pad                     | (Optional) |
| <i>intf-bcast-lvl-out</i>           | (Optional) |
| <i>intf-bcast-pad-ts-out</i>        | (Optional) |
| TABLE_bcast_dis                     | (Optional) |
| <i>intf-bcast-lvl-dis-out</i>       | (Optional) |
| <i>intf-bcast-dis-ts-out</i>        | (Optional) |
| TABLE_bcast_pkt                     | (Optional) |
| <i>intf-bcast-lvl-info-out</i>      | (Optional) |
| <i>intf-bcast-lvl-metric-out</i>    | (Optional) |
| <i>intf-bcast-lvl-csnp-intv-out</i> | (Optional) |
| <i>intf-bcast-lvl-csnp-next-out</i> | (Optional) |
| <i>intf-bcast-lvl-iih-intv-out</i>  | (Optional) |
| <i>intf-bcast-lvl-iih-multi-out</i> | (Optional) |
| <i>intf-bcast-lvl-iih-next-out</i>  | (Optional) |
| TABLE_bcast_adj                     | (Optional) |
| <i>intf-bcast-lvl-value-out</i>     | (Optional) |
| <i>intf-bcast-lvl-adj-out</i>       | (Optional) |
| <i>intf-bcast-lvl-adj-up-out</i>    | (Optional) |
| <i>intf-bcast-lvl-prio-out</i>      | (Optional) |
| <i>intf-bcast-lvl-ctid-out</i>      | (Optional) |

|                                     |            |
|-------------------------------------|------------|
| <i>intf-bcast-lvl-ctid-ts-out</i>   | (Optional) |
| TABLE_loopback                      | (Optional) |
| <i>intf-loopback-lvl-out</i>        | (Optional) |
| <i>intf-loopback-lvl-metric-out</i> | (Optional) |
| <i>intf-unknown-out</i>             | (Optional) |

**Command Mode**

- /exec

## show otv isis ip mroute

```
show otv isis [ <otv-isis-tag> ] ip mroute [ vlan <vlan-id> [ group <gip-addr> [ source <sip-addr> ] ] ] [
summary ] [ vpn { <vrf-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out> <vrf-name-out>
[ <af-string-out> ] [ TABLE_mroute <source-out> <vlan-id-out> <group-out> [ TABLE_adj
<interface-name-out> <iod-out> <site-index-out> <unicast-only-key-out> ] [ TABLE_active_source
<interface-name-out> <iod-out> <site-index-out> <unicast-only-key-out> <source-and-group-addr-out> ] ]
]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                 |
| otv                    | Display OTV information                         |
| isis                   | Display IS-IS status and configuration          |
| <i>otv-isis-tag</i>    | (Optional) Routing process tag                  |
| vpn                    | (Optional) Display VPN information              |
| <i>vrf-name</i>        | (Optional) VPN name                             |
| all                    | (Optional) All configured VPNs                  |
| ip                     | Display IS-IS IPv4 information                  |
| mroute                 | Display IS-IS multicast group information       |
| vlan                   | (Optional) Display IS-IS VLAN information       |
| <i>vlan-id</i>         | (Optional) Display IS-IS VLAN information       |
| group                  | (Optional) Display IS-IS Group information      |
| source                 | (Optional) Display IS-IS Source information     |
| <i>gip-addr</i>        | (Optional) Display single IP redistribute route |
| <i>sip-addr</i>        | (Optional) Display single IP redistribute route |
| summary                | (Optional) Display route counts                 |
| <i>__readonly__</i>    | (Optional)                                      |
| TABLE_process_tag      | (Optional)                                      |
| <i>process-tag-out</i> | (Optional)                                      |
| <i>vrf-name-out</i>    | (Optional)                                      |
| <i>af-string-out</i>   | (Optional)                                      |
| TABLE_mroute           | (Optional)                                      |

|                                  |            |
|----------------------------------|------------|
| <i>source-out</i>                | (Optional) |
| <i>vlan-id-out</i>               | (Optional) |
| <i>group-out</i>                 | (Optional) |
| TABLE_adj                        | (Optional) |
| <i>interface-name-out</i>        | (Optional) |
| <i>iod-out</i>                   | (Optional) |
| <i>site-index-out</i>            | (Optional) |
| <i>unicast-only-key-out</i>      | (Optional) |
| TABLE_active_source              | (Optional) |
| <i>interface-name-out</i>        | (Optional) |
| <i>iod-out</i>                   | (Optional) |
| <i>site-index-out</i>            | (Optional) |
| <i>unicast-only-key-out</i>      | (Optional) |
| <i>source-and-group-addr-out</i> | (Optional) |

**Command Mode**

- /exec

## show otv isis ip redistribute mroute

```
show otv isis [ <otv-isis-tag> ] ip redistribute mroute [ vlan <vlan-id> [ group <gip-addr> [ source <sip-addr>
] ] ] [ summary ] [ vpn { <vrf-name> | all } ] [ __readonly__ TABLE_process_tag <process-tag-out>
<af-string-out> <vrf-name-out> [ TABLE_mrouters <redist-ipv4-vlan> [ <redist-ipv4-mrouter-vlanid-out> ]
[ <redist-ipv4-vlanid-out> ] [ <redist-ipv4-source-addr-out> ] [ <redist-ipv4-group-addr-out> ] [
<redist-ipv4-as-lsp> ] [ <redist-ipv4-recv-lsp> ] [ <redist-ipv4-mroute-vlan-id> ] [
<redist-ipv4-mroute-src-addr> ] [ <redist-ipv4-mroute-grp-addr> ] ] [ TABLE_summary <redist-ipv4-vlan>
<redist-ipv4-group> <redist-ipv4-src-count> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                 |
| otv                    | Display OTV information                         |
| isis                   | Display IS-IS status and configuration          |
| <i>otv-isis-tag</i>    | (Optional) Routing process tag                  |
| vpn                    | (Optional) Display VPN information              |
| <i>vrf-name</i>        | (Optional) VPN name                             |
| all                    | (Optional) All configured VPNs                  |
| ip                     | Display IS-IS IPv4 information                  |
| redistribute           | Display IS-IS redistribute information          |
| vlan                   | (Optional) Display IS-IS VLAN information       |
| <i>vlan-id</i>         | (Optional) Display IS-IS VLAN information       |
| group                  | (Optional) Display IS-IS Group information      |
| source                 | (Optional) Display IS-IS Source information     |
| <i>gip-addr</i>        | (Optional) Display single IP redistribute route |
| <i>sip-addr</i>        | (Optional) Display single IP redistribute route |
| mroute                 | Display IS-IS multicast group information       |
| summary                | (Optional) Display route counts                 |
| __readonly__           | (Optional)                                      |
| TABLE_process_tag      | (Optional)                                      |
| <i>process-tag-out</i> | (Optional)                                      |
| <i>af-string-out</i>   | (Optional)                                      |
| <i>vrf-name-out</i>    | (Optional)                                      |



|                                       |            |
|---------------------------------------|------------|
| TABLE_mrouter                         | (Optional) |
| <i>redist-ipv4-vlan</i>               | (Optional) |
| <i>redist-ipv4-mrouter-vlanid-out</i> | (Optional) |
| <i>redist-ipv4-vlanid-out</i>         | (Optional) |
| <i>redist-ipv4-source-addr-out</i>    | (Optional) |
| <i>redist-ipv4-group-addr-out</i>     | (Optional) |
| <i>redist-ipv4-as-lsp</i>             | (Optional) |
| <i>redist-ipv4-recv-lsp</i>           | (Optional) |
| <i>redist-ipv4-mroute-vlan-id</i>     | (Optional) |
| <i>redist-ipv4-mroute-src-addr</i>    | (Optional) |
| <i>redist-ipv4-mroute-grp-addr</i>    | (Optional) |
| TABLE_summary                         | (Optional) |
| <i>redist-ipv4-vlan</i>               | (Optional) |
| <i>redist-ipv4-group</i>              | (Optional) |
| <i>redist-ipv4-src-count</i>          | (Optional) |

### Command Mode

- /exec

## show otv isis redistribute route

```
show otv isis [ <otv-isis-tag> ] [ mac ] redistribute route [ summary ] [ direct-mask ] [ vpn { <vrf-name> | all } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| otv                 | Display OTV information                   |
| isis                | Display IS-IS status and configuration    |
| <i>otv-isis-tag</i> | (Optional) Routing process tag            |
| vpn                 | (Optional) Display VPN information        |
| <i>vrf-name</i>     | (Optional) VPN name                       |
| all                 | (Optional) All configured VPNs            |
| redistribute        | Display IS-IS redistribute information    |
| route               | Display ISIS redistribute route           |
| mac                 | (Optional) Display IS-IS MAC information  |
| summary             | (Optional) Display route counts           |
| direct-mask         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

### Command Mode

- /exec

## show otv isis route-map statistics

```
show otv isis [ <otv-isis-tag> ] route-map statistics [ vpn { <vrf-name> | all } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information        |
| otv                 | Display OTV information                |
| isis                | Display IS-IS status and configuration |
| <i>otv-isis-tag</i> | (Optional) Routing process tag         |
| vpn                 | (Optional) Display VPN information     |
| <i>vrf-name</i>     | (Optional) VPN name                    |
| all                 | (Optional) All configured VPNs         |
| route-map           | Display IS-IS route-map information    |
| statistics          | Display IS-IS route-map statistics     |

### Command Mode

- /exec

## show otv isis route

```
show otv isis [ <otv-isis-tag> ] route [ summary | detail | is ] [ vpn { <vrf-name> | all } ] [ __readonly__ {
TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> [ <afi-safi-out> ] [ { TABLE_route
[ <route-addr-print-out> ] [ <route-absent-out> ] [ <route-prefix-out> ] [ <route-mask-len-out> ] [
<route-level-out> ] [ <route-lvl-absent-out> ] [ <route-summ-discard-addr-out> ] [
<route-summ-discard-mask-len-out> ] [ <route-discard-addr-out> ] [ <route-discard-mask-len-out> ] [
<route-mask-len-print-out> ] [ <route-lvl-out> ] [ <route-direct-print-out> ] [ <route-direct-out> ] [
<route-direct-via-out> ] [ <route-direct-if-name-out> ] [ <route-direct-metric-out> ] [ <route-direct-level-out>
] [ <route-direct-instance-out> ] [ <route-marker-out> ] [ <route-addr-valid-out> ] [ <route-no-def-prefix-out>
] [ <route-iframe-out> ] [ <route-metric-out> ] [ <route-pref-out> ] [ <route-instance-out> ] [
<route-discard-mask-out> ] [ <route-sum-prefix-out> ] [ <route-sum-prefix-len-out> ] } ] [ <route-total-out>
] [ <route-paths-total-out> ] [ <route-paths-best-out> ] [ <route-paths-backup-out> ] [ <route-sum-lvl-out> ]
] [ <route-sum-total-out> ] [ <route-sum-direct-out> ] [ <route-sum-normal-out> ] [ <route-sum-missing-out>
] [ <route-best-pend-num-out> ] [ <route-bestpaths-out> ] [ <route-path-sum-lvl-out> ] [
<route-path-sum-total-out> ] [ <route-path-sum-direct-out> ] [ <route-path-sum-normal-out> ] [
<route-backuppaths-out> ] [ <route-bestroutes-per-mask-out> ] [ <route-best-mask-val-out> ] [
<route-best-mask-count-out> ] [ <route-pend-q-count-out> ] } } }
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information             |
| otv                    | Display OTV information                     |
| isis                   | Display IS-IS status and configuration      |
| <i>otv-isis-tag</i>    | (Optional) Routing process tag              |
| vpn                    | (Optional) Display VPN information          |
| <i>vrf-name</i>        | (Optional) VPN name                         |
| all                    | (Optional) All configured VPNs              |
| is                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| route                  | Display IS-IS route information             |
| summary                | (Optional) Display route counts             |
| detail                 | (Optional) Display detail route information |
| __readonly__           | (Optional)                                  |
| TABLE_process_tag      | (Optional)                                  |
| <i>process-tag-out</i> | (Optional)                                  |
| TABLE_vrf              | (Optional)                                  |
| <i>vrf-name-out</i>    | (Optional)                                  |
| <i>afi-safi-out</i>    | (Optional)                                  |

|  |            |
|--|------------|
| TABLE_route                            | (Optional) |
| <i>route-addr-print-out</i>            | (Optional) |
| <i>route-absent-out</i>                | (Optional) |
| <i>route-lvl-absent-out</i>            | (Optional) |
| <i>route-prefix-out</i>                | (Optional) |
| <i>route-mask-len-out</i>              | (Optional) |
| <i>route-level-out</i>                 | (Optional) |
| <i>route-summ-discard-addr-out</i>     | (Optional) |
| <i>route-summ-discard-mask-len-out</i> | (Optional) |
| <i>route-discard-addr-out</i>          | (Optional) |
| <i>route-discard-mask-len-out</i>      | (Optional) |
| <i>route-mask-len-print-out</i>        | (Optional) |
| <i>route-lvl-out</i>                   | (Optional) |
| <i>route-direct-print-out</i>          | (Optional) |
| <i>route-direct-out</i>                | (Optional) |
| <i>route-direct-via-out</i>            | (Optional) |
| <i>route-direct-if-name-out</i>        | (Optional) |
| <i>route-direct-metric-out</i>         | (Optional) |
| <i>route-direct-level-out</i>          | (Optional) |
| <i>route-direct-instance-out</i>       | (Optional) |
| <i>route-marker-out</i>                | (Optional) |
| <i>route-addr-valid-out</i>            | (Optional) |
| <i>route-ifname-out</i>                | (Optional) |
| <i>route-metric-out</i>                | (Optional) |
| <i>route-pref-out</i>                  | (Optional) |
| <i>route-instance-out</i>              | (Optional) |
| <i>route-no-def-prefix-out</i>         | (Optional) |
| <i>route-discard-mask-out</i>          | (Optional) |
| <i>route-sum-prefix-out</i>            | (Optional) |

|                                      |            |
|--------------------------------------|------------|
| <i>route-sum-prefix-len-out</i>      | (Optional) |
| <i>route-total-out</i>               | (Optional) |
| <i>route-paths-total-out</i>         | (Optional) |
| <i>route-paths-best-out</i>          | (Optional) |
| <i>route-paths-backup-out</i>        | (Optional) |
| <i>route-sum-lvl-out</i>             | (Optional) |
| <i>route-sum-total-out</i>           | (Optional) |
| <i>route-sum-direct-out</i>          | (Optional) |
| <i>route-sum-normal-out</i>          | (Optional) |
| <i>route-sum-missing-out</i>         | (Optional) |
| <i>route-best-pend-num-out</i>       | (Optional) |
| <i>route-bestpaths-out</i>           | (Optional) |
| <i>route-path-sum-lvl-out</i>        | (Optional) |
| <i>route-path-sum-total-out</i>      | (Optional) |
| <i>route-path-sum-direct-out</i>     | (Optional) |
| <i>route-path-sum-normal-out</i>     | (Optional) |
| <i>route-backuppaths-out</i>         | (Optional) |
| <i>route-bestroutes-per-mask-out</i> | (Optional) |
| <i>route-best-mask-val-out</i>       | (Optional) |
| <i>route-best-mask-count-out</i>     | (Optional) |
| <i>route-pend-q-count-out</i>        | (Optional) |

**Command Mode**

- /exec

## show otv isis rrm

```
show otv isis [ <otv-isis-tag> ] rrm [ mgroup ] <interface> [ vpn { <vrf-name> | all } ] [ __readonly__
TABLE_process_tag <process-tag-out> <rrm-if-out> <rrm-if-p2p-out> <rrm-level-out> <rrm-retx-interval-out>
<rrm-retx-throttle-out> <rrm-retx-queue-len-out> <rrm-next-retx-out> <rrm-retx-queue-hwm-out>
<rrm-queue-exceed-out> <rrm-if-lsp-out> <rrm-lsp-name-out> <rrm-lsp-status-out> <rrm-lsp-absent-out>
<rrm-lsp-seqnum-out> <rrm-lsp-cksum-out> <rrm-lsp-lifetime-out> <rrm-lsp-attached-out>
<rrm-lsp-partition-out> <rrm-lsp-overload-out> <rrm-lsp-istype-out> <rrm-last-sent-time-out>
<rrm-invalid-retx-out> <rrm-invalid-db-out> <rrm-set-out> <rrm-srm-set-out> ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                                    |
| otv                           | Display OTV information  |
| isis                          | Display IS-IS status and configuration                             |
| <i>otv-isis-tag</i>           | (Optional) Routing process tag                                     |
| vpn                           | (Optional) Display VPN information                                 |
| <i>vrf-name</i>               | (Optional) VPN name  |
| all                           | (Optional) All configured VPNs                                     |
| rrm                           | Display IS-IS Retransmit-Routing-Message information               |
| mgroup                        | (Optional) Display IS-IS GM Retransmit-Routing-Message information |
| <i>interface</i>              | IS-IS interface  |
| <u>__readonly__</u>           | (Optional)   |
| TABLE_process_tag             | (Optional)   |
| <i>process-tag-out</i>        | (Optional)   |
| <i>rrm-if-out</i>             | (Optional)   |
| <i>rrm-if-p2p-out</i>         | (Optional)   |
| <i>rrm-level-out</i>          | (Optional)   |
| <i>rrm-retx-interval-out</i>  | (Optional)   |
| <i>rrm-retx-throttle-out</i>  | (Optional)   |
| <i>rrm-retx-queue-len-out</i> | (Optional)   |
| <i>rrm-next-retx-out</i>      | (Optional)   |
| <i>rrm-retx-queue-hwm-out</i> | (Optional)   |
| <i>rrm-queue-exceed-out</i>   | (Optional)   |

|                               |            |
|-------------------------------|------------|
| <i>rrm-if-lsp-out</i>         | (Optional) |
| <i>rrm-lsp-name-out</i>       | (Optional) |
| <i>rrm-lsp-status-out</i>     | (Optional) |
| <i>rrm-lsp-absent-out</i>     | (Optional) |
| <i>rrm-lsp-seqnum-out</i>     | (Optional) |
| <i>rrm-lsp-cksum-out</i>      | (Optional) |
| <i>rrm-lsp-lifetime-out</i>   | (Optional) |
| <i>rrm-lsp-attached-out</i>   | (Optional) |
| <i>rrm-lsp-partition-out</i>  | (Optional) |
| <i>rrm-lsp-overload-out</i>   | (Optional) |
| <i>rrm-lsp-istype-out</i>     | (Optional) |
| <i>rrm-last-sent-time-out</i> | (Optional) |
| <i>rrm-invalid-retx-out</i>   | (Optional) |
| <i>rrm-invalid-db-out</i>     | (Optional) |
| <i>rrm-set-out</i>            | (Optional) |
| <i>rrm-srm-set-out</i>        | (Optional) |

### Command Mode

- /exec



# show otv isis site-index

show otv isis [ <otv-isis-tag> ] site-index

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information        |
| otv                 | Display OTV information                |
| isis                | Display IS-IS status and configuration |
| <i>otv-isis-tag</i> | (Optional) Routing process tag         |
| site-index          | Display site index table               |

## Command Mode

- /exec

## show otv isis site

```
show otv isis [ <otv-isis-tag> ] site [ statistics ] [ __readonly__ { TABLE_process_tag <process-tag-out> [
<bfd-state-str-out> ] [ { TABLE_adjacency <nbr-system-id-out> <adj-state-out> <last-flap-ts-out>
<hold-time-out> <otv-fwd_ready-out> <site-id-out> <otv-version-out> <l3-ipv4-addr-out> <nbr-ip-out> } ]
[ <system-id-out> ] [ <interface-out> ] [ <vlan-id-out> ] [ <cib-out> ] [ <iib-out> ] [ { TABLE_site_groups
<overlay-name-out> <overlay-state-out> <timer-iih-out> <iih-ts-out> <iih-multi-out> } ] [ {
TABLE_site_groups_csnp <overlay-name-csnp-out> <encap-af-out> <csnp-last-out> <csnp-int-out>
<csnp-next-out> } ] [ { TABLE_site_groups_nbr <nbr-gr-system-id-out> } ] [ <traffic-lan-iih-out> ] [
<traffic-lan-iih-rcv-out> ] [ <traffic-lan-iih-xmit-out> ] [ <traffic-lan-iih-rcv-auth-err-out> ] [
<traffic-lan-iih-rcv-err-out> ] [ <traffic-csnp-out> ] [ <traffic-csnp-rcv-out> ] [ <traffic-csnp-xmit-out> ] [
<traffic-csnp-rcv-auth-err-out> ] [ <traffic-csnp-rcv-err-out> ] [ <traffic-psnp-out> ] [ <traffic-psnp-rcv-out>
] [ <traffic-psnp-xmit-out> ] [ <traffic-psnp-rcv-auth-err-out> ] [ <traffic-psnp-rcv-err-out> ] [ <traffic-lsp-out>
] [ <traffic-lsp-rcv-out> ] [ <traffic-lsp-flood-out> ] [ <traffic-lsp-rcv-auth-err-out> ] [ <traffic-lsp-rcv-err-out>
] [ <traffic-lsp-rexmit-out> ] [ <traffic-gmlsp-out> ] [ <traffic-gmlsp-rcv-out> ] [ <traffic-gmlsp-flood-out>
] [ <traffic-gmlsp-rcv-auth-err-out> ] [ <traffic-gmlsp-rcv-err-out> ] [ <traffic-gmlsp-rexmit-out> ] [
<site-spf-calc-out> ] [ <site-lsp-sourced-out> ] [ <site-lsp-refresh-out> ] [ <site-lsp-purge-out> ] }
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information              |
| otv                      | Display OTV information                      |
| isis                     | Display IS-IS status and configuration       |
| <i>otv-isis-tag</i>      | (Optional) Routing process tag               |
| site                     | Display IS-IS OTV site information           |
| statistics               | (Optional) Display IS-IS protocol statistics |
| <i>__readonly__</i>      | (Optional)                                   |
| TABLE_process_tag        | (Optional)                                   |
| <i>process-tag-out</i>   | (Optional)                                   |
| <i>bfd-state-str-out</i> | (Optional)                                   |
| <i>system-id-out</i>     | (Optional)                                   |
| <i>interface-out</i>     | (Optional)                                   |
| <i>vlan-id-out</i>       | (Optional)                                   |
| <i>cib-out</i>           | (Optional)                                   |
| <i>iib-out</i>           | (Optional)                                   |
| TABLE_adjacency          | (Optional)                                   |
| <i>nbr-system-id-out</i> | (Optional)                                   |

|   |            |
|---|------------|
| <i>adj-state-out</i>                    | (Optional) |
| <i>last-flap-ts-out</i>                 | (Optional) |
| <i>hold-time-out</i>                    | (Optional) |
| <i>otv-fwd_ready-out</i>                | (Optional) |
| <i>site-id-out</i>                      | (Optional) |
| <i>otv-version-out</i>                  | (Optional) |
| <i>l3-ipv4-addr-out</i>                 | (Optional) |
| <i>nbr-ip-out</i>                       | (Optional) |
| TABLE_site_groups                       | (Optional) |
| <i>overlay-name-out</i>                 | (Optional) |
| <i>overlay-state-out</i>                | (Optional) |
| <i>timer-iih-out</i>                    | (Optional) |
| <i>iih-ts-out</i>                       | (Optional) |
| <i>iih-multi-out</i>                    | (Optional) |
| TABLE_site_groups_csnp                  | (Optional) |
| <i>overlay-name-csnp-out</i>            | (Optional) |
| <i>encap-af-out</i>                     | (Optional) |
| <i>csnp-last-out</i>                    | (Optional) |
| <i>csnp-int-out</i>                     | (Optional) |
| <i>csnp-next-out</i>                    | (Optional) |
| TABLE_site_groups_nbr                   | (Optional) |
| <i>nbr-gr-system-id-out</i>             | (Optional) |
| <i>traffic-lan-iih-out</i>              | (Optional) |
| <i>traffic-lan-iih-rcv-out</i>          | (Optional) |
| <i>traffic-lan-iih-xmit-out</i>         | (Optional) |
| <i>traffic-lan-iih-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-lan-iih-rcv-err-out</i>      | (Optional) |
| <i>traffic-csnp-out</i>                 | (Optional) |
| <i>traffic-csnp-rcv-out</i>             | (Optional) |

|                                       |            |
|---------------------------------------|------------|
| <i>traffic-csnp-xmit-out</i>          | (Optional) |
| <i>traffic-csnp-rcv-auth-err-out</i>  | (Optional) |
| <i>traffic-csnp-rcv-err-out</i>       | (Optional) |
| <i>traffic-psnp-out</i>               | (Optional) |
| <i>traffic-psnp-rcv-out</i>           | (Optional) |
| <i>traffic-psnp-xmit-out</i>          | (Optional) |
| <i>traffic-psnp-rcv-auth-err-out</i>  | (Optional) |
| <i>traffic-psnp-rcv-err-out</i>       | (Optional) |
| <i>traffic-lsp-out</i>                | (Optional) |
| <i>traffic-lsp-rcv-out</i>            | (Optional) |
| <i>traffic-lsp-flood-out</i>          | (Optional) |
| <i>traffic-lsp-rcv-auth-err-out</i>   | (Optional) |
| <i>traffic-lsp-rcv-err-out</i>        | (Optional) |
| <i>traffic-lsp-rexmit-out</i>         | (Optional) |
| <i>traffic-gmlsp-out</i>              | (Optional) |
| <i>traffic-gmlsp-rcv-out</i>          | (Optional) |
| <i>traffic-gmlsp-flood-out</i>        | (Optional) |
| <i>traffic-gmlsp-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-gmlsp-rcv-err-out</i>      | (Optional) |
| <i>traffic-gmlsp-rexmit-out</i>       | (Optional) |
| <i>site-spf-calc-out</i>              | (Optional) |
| <i>site-lsp-sourced-out</i>           | (Optional) |
| <i>site-lsp-refresh-out</i>           | (Optional) |
| <i>site-lsp-purge-out</i>             | (Optional) |

### Command Mode

- /exec

## show otv isis spf-log

```
show otv isis [ <otv-isis-tag> ] spf-log [ detail ] [ vpn { <vrf-name> | all } ] [ __readonly__ {
TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <spflog-calc-out> <spflog-size-out>
<spflog-maxsize-out> [ { TABLE_log_detail <num-out> <ts-out> <date-out> [ { TABLE_lvl_detail <lvl-out>
<instance-out> <init-ts-out> <ts-lvl-out> } ] [ <ts-is-out> ] [ <ts-urib-out> ] [ <ts-elapsed-out> ] [ {
TABLE_lvl_second <lvls-out> <spf-node-out> <spf-cnt-out> <changed-cnt-out> <spf-reason-out> } ] } ] [
{ TABLE_log_brief <ago-time-out> [ { TABLE_lvl <lvl-out> <reason-out> <count-out> } ] [ <elapsed-ts-out>
} ] } ] }
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                |
| otv                       | Display OTV information                        |
| isis                      | Display IS-IS status and configuration         |
| <i>otv-isis-tag</i>       | (Optional) Routing process tag                 |
| vpn                       | (Optional) Display VPN information             |
| <i>vrf-name</i>           | (Optional) VPN name                            |
| all                       | (Optional) All configured VPNs                 |
| spf-log                   | Display IS-IS SPF information                  |
| detail                    | (Optional) Display detail ISIS SPF information |
| __readonly__              | (Optional)                                     |
| TABLE_process_tag         | (Optional)                                     |
| <i>process-tag-out</i>    | (Optional)                                     |
| TABLE_vrf                 | (Optional)                                     |
| <i>vrf-name-out</i>       | (Optional)                                     |
| <i>spflog-calc-out</i>    | (Optional)                                     |
| <i>spflog-size-out</i>    | (Optional)                                     |
| <i>spflog-maxsize-out</i> | (Optional)                                     |
| TABLE_log_detail          | (Optional)                                     |
| <i>num-out</i>            | (Optional)                                     |
| <i>ts-out</i>             | (Optional)                                     |
| <i>date-out</i>           | (Optional)                                     |
| TABLE_lvl_detail          | (Optional)                                     |

|                        |            |
|------------------------|------------|
| <i>lvld-out</i>        | (Optional) |
| <i>instance-out</i>    | (Optional) |
| <i>init-ts-out</i>     | (Optional) |
| <i>ts-lvl-out</i>      | (Optional) |
| <i>ts-is-out</i>       | (Optional) |
| <i>ts-urib-out</i>     | (Optional) |
| <i>ts-elapsed-out</i>  | (Optional) |
| TABLE_lvl_second       | (Optional) |
| <i>lvls-out</i>        | (Optional) |
| <i>spf-node-out</i>    | (Optional) |
| <i>spf-cnt-out</i>     | (Optional) |
| <i>changed-cnt-out</i> | (Optional) |
| <i>spf-reason-out</i>  | (Optional) |
| TABLE_log_brief        | (Optional) |
| <i>ago-time-out</i>    | (Optional) |
| TABLE_lvl              | (Optional) |
| <i>lvl-out</i>         | (Optional) |
| <i>reason-out</i>      | (Optional) |
| <i>count-out</i>       | (Optional) |
| <i>elapsed-ts-out</i>  | (Optional) |

**Command Mode**

- /exec

## show otv isis srm

```
show otv isis [ <otv-isis-tag> ] srm [ mgroup ] <interface> [ vpn { <vrf-name> | all } ] [ __readonly__
TABLE_process_tag <process-tag-out> <srm-if-out> <srm-level-out> <srm-if-flood-out> <srm-if-stopped-out>
<srm-lsp-interval-out> <srm-next-lsp-out> [ TABLE_srm_lsp <srm-lsp-name-out> <srm-lsp-status-out> [
<srm-lsp-absent-out> ] [ <srm-lsp-seqnum-out> <srm-lsp-cksum-out> ] [ <srm-lsp-lifetime-out> ] [
<srm-lsp-attached-out> <srm-lsp-partition-out> <srm-lsp-overload-out> <srm-lsp-istype-out> ] [
<srm-txlist-status> ] ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                              |
| otv                         | Display OTV information                                      |
| isis                        | Display IS-IS status and configuration                       |
| <i>otv-isis-tag</i>         | (Optional) Routing process tag                               |
| vpn                         | (Optional) Display VPN information                           |
| <i>vrf-name</i>             | (Optional) VPN name  |
| all                         | (Optional) All configured VPNs                               |
| srm                         | Display IS-IS Send-Routing-Message information               |
| mgroup                      | (Optional) Display IS-IS GM-Send-Routing-Message information |
| <i>interface</i>            | IS-IS interface  |
| <i>__readonly__</i>         | (Optional)   |
| TABLE_process_tag           | (Optional)   |
| <i>process-tag-out</i>      | (Optional)   |
| <i>srm-if-out</i>           | (Optional)   |
| <i>srm-level-out</i>        | (Optional)   |
| <i>srm-if-flood-out</i>     | (Optional)   |
| <i>srm-if-stopped-out</i>   | (Optional)   |
| <i>srm-lsp-interval-out</i> | (Optional)   |
| <i>srm-next-lsp-out</i>     | (Optional)   |
| TABLE_srm_lsp               | (Optional)   |
| <i>srm-lsp-name-out</i>     | (Optional)   |
| <i>srm-lsp-status-out</i>   | (Optional)   |

|                              |            |
|------------------------------|------------|
| <i>srm-lsp-absent-out</i>    | (Optional) |
| <i>srm-lsp-seqnum-out</i>    | (Optional) |
| <i>srm-lsp-cksum-out</i>     | (Optional) |
| <i>srm-lsp-lifetime-out</i>  | (Optional) |
| <i>srm-lsp-attached-out</i>  | (Optional) |
| <i>srm-lsp-partition-out</i> | (Optional) |
| <i>srm-lsp-overload-out</i>  | (Optional) |
| <i>srm-lsp-istype-out</i>    | (Optional) |
| <i>srm-txlist-status</i>     | (Optional) |

**Command Mode**

- /exec



## show otv isis ssn

```
show otv isis [ <otv-isis-tag> ] ssn [ mgroup ] <interface> [ vpn { <vrf-name> | all } ] [ __readonly__
TABLE_process_tag <process-tag-out> <ssn-if-out> <ssn-level-out> <ssn-psnp-capable-out>
<ssn-next-psnp-out> [ TABLE_ssn_lsp <ssn-lsp-name-out> <ssn-lsp-status-out> [ <ssn-lsp-absent-out> ] [
<ssn-lsp-seqnum-out> <ssn-lsp-cksum-out> ] [ <ssn-lsp-lifetime-out> ] [ <ssn-lsp-attached-out>
<ssn-lsp-partition-out> <ssn-lsp-overload-out> <ssn-lsp-istype-out> ] [ <ssn-txlist-status-out> ] ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information                              |
| otv                         | Display OTV information                                      |
| isis                        | Display IS-IS status and configuration                       |
| <i>otv-isis-tag</i>         | (Optional) Routing process tag                               |
| vpn                         | (Optional) Display VPN information                           |
| <i>vrf-name</i>             | (Optional) VPN name  |
| all                         | (Optional) All configured VPNs                               |
| ssn                         | Display IS-IS Send-Sequence-Number information               |
| mgroup                      | (Optional) Display IS-IS GM-Send-Sequence-Number information |
| <i>interface</i>            | IS-IS interface  |
| <i>__readonly__</i>         | (Optional)   |
| <i>TABLE_process_tag</i>    | (Optional)   |
| <i>process-tag-out</i>      | (Optional)   |
| <i>ssn-if-out</i>           | (Optional)   |
| <i>ssn-level-out</i>        | (Optional)   |
| <i>ssn-psnp-capable-out</i> | (Optional)   |
| <i>ssn-next-psnp-out</i>    | (Optional)   |
| <i>TABLE_ssn_lsp</i>        | (Optional)   |
| <i>ssn-lsp-name-out</i>     | (Optional)   |
| <i>ssn-lsp-status-out</i>   | (Optional)   |
| <i>ssn-lsp-absent-out</i>   | (Optional)   |
| <i>ssn-lsp-seqnum-out</i>   | (Optional)   |
| <i>ssn-lsp-cksum-out</i>    | (Optional)   |

|                              |            |
|------------------------------|------------|
| <i>ssn-lsp-lifetime-out</i>  | (Optional) |
| <i>ssn-lsp-attached-out</i>  | (Optional) |
| <i>ssn-lsp-partition-out</i> | (Optional) |
| <i>ssn-lsp-overload-out</i>  | (Optional) |
| <i>ssn-lsp-istype-out</i>    | (Optional) |
| <i>ssn-txlist-status-out</i> | (Optional) |

**Command Mode**

- /exec

## show otv isis statistics

```
show otv isis [ <otv-isis-tag> ] statistics [ <interface> ] [ vpn { <vrf-name> | all } ] [ __readonly__ {
TABLE_process_tag <process-tag-out> [ <stat-if-out> ] { TABLE_vrf <vrf-name-out> [ <stat-if-name-out>
] [ <stat-spf-calc-out> ] [ <stat-lsp-sourced-out> ] [ <stat-lsp-refresh-out> ] [ <stat-lsp-purge-out> ] [
<stat-dis-elections-out> ] } } ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information        |
| otv                           | Display OTV information                |
| isis                          | Display IS-IS status and configuration |
| <i>otv-isis-tag</i>           | (Optional) Routing process tag         |
| vpn                           | (Optional) Display VPN information     |
| <i>vrf-name</i>               | (Optional) VPN name                    |
| all                           | (Optional) All configured VPNs         |
| statistics                    | Display IS-IS protocol statistics      |
| <i>interface</i>              | (Optional) IS-IS interface             |
| <i>__readonly__</i>           | (Optional)                             |
| TABLE_process_tag             | (Optional)                             |
| <i>process-tag-out</i>        | (Optional)                             |
| <i>stat-if-out</i>            | (Optional)                             |
| TABLE_vrf                     | (Optional)                             |
| <i>vrf-name-out</i>           | (Optional)                             |
| <i>stat-if-name-out</i>       | (Optional)                             |
| <i>stat-spf-calc-out</i>      | (Optional)                             |
| <i>stat-lsp-sourced-out</i>   | (Optional)                             |
| <i>stat-lsp-refresh-out</i>   | (Optional)                             |
| <i>stat-lsp-purge-out</i>     | (Optional)                             |
| <i>stat-dis-elections-out</i> | (Optional)                             |

### Command Mode

- /exec

## show otv isis track-adjacency-nexthop

```
show otv isis [ <otv-isis-tag> ] track-adjacency-nexthop [ __readonly__ { TABLE_process_tag
<process-tag-out> [ { TABLE_next_hop <ip-address-out> <vrf-name-out> [ { TABLE_adjacency
<hostname-out> <interface-out> } ] } ] }
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                          |
| otv                     | Display OTV information                                  |
| isis                    | Display IS-IS status and configuration                   |
| <i>otv-isis-tag</i>     | (Optional) Routing process tag                           |
| track-adjacency-nexthop | Display IS-IS OTV adjacency nexthop tracking information |
| <i>__readonly__</i>     | (Optional)   |
| TABLE_process_tag       | (Optional)   |
| <i>process-tag-out</i>  | (Optional)   |
| TABLE_next_hop          | (Optional)   |
| <i>ip-address-out</i>   | (Optional)   |
| <i>vrf-name-out</i>     | (Optional)   |
| TABLE_adjacency         | (Optional)   |
| <i>hostname-out</i>     | (Optional)   |
| <i>interface-out</i>    | (Optional)   |

### Command Mode

- /exec

## show otv isis traffic

```
show otv isis [ <otv-isis-tag> ] traffic [ <interface> ] [ mbuf-priority ] [ vpn { <vrf-name> | all } ] [ __readonly__
{ TABLE_process_tag <process-tag-out> { TABLE_vrf <vrf-name-out> <traffic-if-out> [ <traffic-if-name-out>
] <traffic-lan-iih-out> <traffic-lan-iih-rcv-out> <traffic-lan-iih-xmit-out> <traffic-lan-iih-rcv-auth-err-out>
<traffic-lan-iih-rcv-err-out> <traffic-csnp-out> <traffic-csnp-rcv-out> <traffic-csnp-xmit-out>
<traffic-csnp-rcv-auth-err-out> <traffic-csnp-rcv-err-out> <traffic-psnp-out> <traffic-psnp-rcv-out>
<traffic-psnp-xmit-out> <traffic-psnp-rcv-auth-err-out> <traffic-psnp-rcv-err-out> <traffic-lsp-out>
<traffic-lsp-rcv-out> <traffic-lsp-flood-out> <traffic-lsp-rcv-auth-err-out> <traffic-lsp-rcv-err-out>
<traffic-lsp-rexmit-out> <traffic-gmlsp-out> <traffic-gmlsp-rcv-out> <traffic-gmlsp-flood-out>
<traffic-gmlsp-rcv-auth-err-out> <traffic-gmlsp-rcv-err-out> <traffic-gmlsp-rexmit-out> [ <traffic-xmit-err-out>
] [ <traffic-unknown-pdu-rcv-out> ] } } ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information           |
| otv                             | Display OTV information                   |
| isis                            | Display IS-IS status and configuration    |
| <i>otv-isis-tag</i>             | (Optional) Routing process tag            |
| vpn                             | (Optional) Display VPN information        |
| <i>vrf-name</i>                 | (Optional) VPN name                       |
| all                             | (Optional) All configured VPNs            |
| traffic                         | Display IS-IS traffic information         |
| <i>interface</i>                | (Optional) IS-IS interface                |
| mbuf-priority                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <u>__readonly__</u>             | (Optional)                                |
| TABLE_process_tag               | (Optional)                                |
| <i>process-tag-out</i>          | (Optional)                                |
| TABLE_vrf                       | (Optional)                                |
| <i>vrf-name-out</i>             | (Optional)                                |
| <i>traffic-if-out</i>           | (Optional)                                |
| <i>traffic-if-name-out</i>      | (Optional)                                |
| <i>traffic-lan-iih-out</i>      | (Optional)                                |
| <i>traffic-lan-iih-rcv-out</i>  | (Optional)                                |
| <i>traffic-lan-iih-xmit-out</i> | (Optional)                                |

|   |            |
|---|------------|
| <i>traffic-lan-iih-rcv-auth-err-out</i> | (Optional) |
| <i>traffic-lan-iih-rcv-err-out</i>      | (Optional) |
| <i>traffic-csnp-out</i>                 | (Optional) |
| <i>traffic-csnp-rcv-out</i>             | (Optional) |
| <i>traffic-csnp-xmit-out</i>            | (Optional) |
| <i>traffic-csnp-rcv-auth-err-out</i>    | (Optional) |
| <i>traffic-csnp-rcv-err-out</i>         | (Optional) |
| <i>traffic-psnp-out</i>                 | (Optional) |
| <i>traffic-psnp-rcv-out</i>             | (Optional) |
| <i>traffic-psnp-xmit-out</i>            | (Optional) |
| <i>traffic-psnp-rcv-auth-err-out</i>    | (Optional) |
| <i>traffic-psnp-rcv-err-out</i>         | (Optional) |
| <i>traffic-lsp-out</i>                  | (Optional) |
| <i>traffic-lsp-rcv-out</i>              | (Optional) |
| <i>traffic-lsp-flood-out</i>            | (Optional) |
| <i>traffic-lsp-rcv-auth-err-out</i>     | (Optional) |
| <i>traffic-lsp-rcv-err-out</i>          | (Optional) |
| <i>traffic-lsp-rexmit-out</i>           | (Optional) |
| <i>traffic-gmlsp-out</i>                | (Optional) |
| <i>traffic-gmlsp-rcv-out</i>            | (Optional) |
| <i>traffic-gmlsp-flood-out</i>          | (Optional) |
| <i>traffic-gmlsp-rcv-auth-err-out</i>   | (Optional) |
| <i>traffic-gmlsp-rcv-err-out</i>        | (Optional) |
| <i>traffic-gmlsp-rexmit-out</i>         | (Optional) |
| <i>traffic-xmit-err-out</i>             | (Optional) |
| <i>traffic-unknown-pdu-rcv-out</i>      | (Optional) |

### Command Mode

- /exec

## show otv isis vlan-status local

```
show otv isis [ <otv-isis-tag> ] vlan-status { local | remote } [ __readonly__ { TABLE_process_tag
<process-tag-out> { TABLE_vrf <vrf-name-out> [ { TABLE_vlan_status_local <overlay-iod-out>
<cluster-id-out> <partition-id-out> <device-id-out> <site-id-out> <fwd-ready-out> <aed-out> <backup-aed-out>
<delete-flag-out> <local-out> <remote-out> <version-out> <priority-out> <start-vlan-id-out> <end-vlan-id-out>
<step-size-out> } ] [ { TABLE_vlan_status_remote <overlay-iod-out> <cluster-id-out> <partition-id-out>
<device-id-out> <site-id-out> <fwd-ready-out> <aed-out> <backup-aed-out> <delete-flag-out> <local-out>
<remote-out> <priority-out> <vlan-id-out> <version-out> <site-index-out> <update-count-out>
<creation-time-out> <update-time-out> } ] } ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information        |
| otv                     | Display OTV information                |
| isis                    | Display IS-IS status and configuration |
| <i>otv-isis-tag</i>     | (Optional) Routing process tag         |
| vlan-status             | Display vlan status Info               |
| local                   | local                                  |
| remote                  | remote                                 |
| <i>__readonly__</i>     | (Optional)                             |
| TABLE_process_tag       | (Optional)                             |
| <i>process-tag-out</i>  | (Optional)                             |
| TABLE_vrf               | (Optional)                             |
| <i>vrf-name-out</i>     | (Optional)                             |
| TABLE_vlan_status_local | (Optional)                             |
| <i>overlay-iod-out</i>  | (Optional)                             |
| <i>cluster-id-out</i>   | (Optional)                             |
| <i>partition-id-out</i> | (Optional)                             |
| <i>device-id-out</i>    | (Optional)                             |
| <i>site-id-out</i>      | (Optional)                             |
| <i>fwd-ready-out</i>    | (Optional)                             |
| <i>aed-out</i>          | (Optional)                             |
| <i>backup-aed-out</i>   | (Optional)                             |

|                          |            |
|--------------------------|------------|
| <i>delete-flag-out</i>   | (Optional) |
| <i>local-out</i>         | (Optional) |
| <i>remote-out</i>        | (Optional) |
| <i>version-out</i>       | (Optional) |
| <i>priority-out</i>      | (Optional) |
| <i>start-vlan-id-out</i> | (Optional) |
| <i>end-vlan-id-out</i>   | (Optional) |
| <i>step-size-out</i>     | (Optional) |
| TABLE_vlan_status_remote | (Optional) |
| <i>overlay-iod-out</i>   | (Optional) |
| <i>cluster-id-out</i>    | (Optional) |
| <i>partition-id-out</i>  | (Optional) |
| <i>device-id-out</i>     | (Optional) |
| <i>site-id-out</i>       | (Optional) |
| <i>fwd-ready-out</i>     | (Optional) |
| <i>aed-out</i>           | (Optional) |
| <i>backup-aed-out</i>    | (Optional) |
| <i>delete-flag-out</i>   | (Optional) |
| <i>local-out</i>         | (Optional) |
| <i>remote-out</i>        | (Optional) |
| <i>priority-out</i>      | (Optional) |
| <i>vlan-id-out</i>       | (Optional) |
| <i>version-out</i>       | (Optional) |
| <i>site-index-out</i>    | (Optional) |
| <i>update-count-out</i>  | (Optional) |
| <i>creation-time-out</i> | (Optional) |
| <i>update-time-out</i>   | (Optional) |

**Command Mode**

- /exec





## P Show Commands

---

- [show param-list](#), on page 2382
- [show password secure-mode](#), on page 2383
- [show password strength-check](#), on page 2384
- [show pie broker](#), on page 2385
- [show pie envmon](#), on page 2386
- [show pie eventdb](#), on page 2387
- [show pie eventid](#), on page 2388
- [show pie interface](#), on page 2389
- [show platform vnic info](#), on page 2390
- [show platform vnic mapped](#), on page 2391
- [show pmap-int-br interface br](#), on page 2392
- [show pmap-int](#), on page 2393
- [show pnp lease](#), on page 2394
- [show pnp posix\\_pi configs](#), on page 2395
- [show pnp posix\\_pi tech-support](#), on page 2396
- [show pnp profiles](#), on page 2397
- [show pnp status](#), on page 2398
- [show pnp summary](#), on page 2399
- [show pnp version](#), on page 2400
- [show policy-map](#), on page 2401
- [show policy-map interface control-plane](#), on page 2406
- [show policy-map system](#), on page 2409
- [show policy-map type control-plane](#), on page 2414
- [show policy-map type network-qos](#), on page 2417
- [show port-channel capacity](#), on page 2419
- [show port-channel compatibility-parameters](#), on page 2420
- [show port-channel database](#), on page 2421
- [show port-channel fast-convergence](#), on page 2423
- [show port-channel load-balance](#), on page 2424
- [show port-channel load-balance forwarding-path1 interface src-interface](#), on page 2426
- [show port-channel load-balance forwarding-path interface](#), on page 2428
- [show port-channel load-balance hardware forwarding-path interface source](#), on page 2430
- [show port-channel rbh-distribution](#), on page 2432

- [show port-channel scale-fanout](#), on page 2433
- [show port-channel summary](#), on page 2434
- [show port-channel traffic](#), on page 2435
- [show port-channel usage](#), on page 2436
- [show port-license](#), on page 2437
- [show port-profile](#), on page 2438
- [show port-profile brief](#), on page 2440
- [show port-profile expand-interface](#), on page 2441
- [show port-profile sync-status](#), on page 2442
- [show port-profile usage](#), on page 2443
- [show port-security](#), on page 2444
- [show port-security address](#), on page 2445
- [show port-security address interface](#), on page 2446
- [show port-security interface](#), on page 2447
- [show port-security state](#), on page 2448
- [show port led-status module](#), on page 2449
- [show port naming](#), on page 2450
- [show postcard-telemetry exporter](#), on page 2451
- [show postcard-telemetry flow-profile](#), on page 2452
- [show postcard-telemetry monitor](#), on page 2453
- [show postcard-telemetry queue-profile](#), on page 2454
- [show postcard-telemetry sessions](#), on page 2455
- [show postcard-telemetry watchlist](#), on page 2456
- [show power inline](#), on page 2457
- [show power inline](#), on page 2458
- [show power inline detail](#), on page 2459
- [show power inline police](#), on page 2461
- [show power inline priority](#), on page 2462
- [show processes](#), on page 2463
- [show processes cpu](#), on page 2464
- [show processes cpu history](#), on page 2465
- [show processes cpu history data](#), on page 2466
- [show processes cpu module](#), on page 2467
- [show processes log](#), on page 2468
- [show processes log details](#), on page 2469
- [show processes log pid](#), on page 2470
- [show processes log vdc-all](#), on page 2471
- [show processes memory](#), on page 2472
- [show processes memory physical](#), on page 2473
- [show processes memory shared](#), on page 2474
- [show processes vdc](#), on page 2477
- [show processes vdc cpu](#), on page 2478
- [show processes vdc log](#), on page 2479
- [show processes vdc log details](#), on page 2480
- [show processes vdc log pid](#), on page 2481
- [show processes vdc memory](#), on page 2482

- [show pss debug](#), on page 2483
- [show ptp brief](#), on page 2484
- [show ptp clock](#), on page 2485
- [show ptp clock foreign-masters record](#), on page 2487
- [show ptp corrections](#), on page 2488
- [show ptp cost](#), on page 2489
- [show ptp counters interface](#), on page 2490
- [show ptp delay summary](#), on page 2491
- [show ptp domain data](#), on page 2492
- [show ptp interface domain](#), on page 2493
- [show ptp packet-trace](#), on page 2494
- [show ptp parent](#), on page 2495
- [show ptp port interface](#), on page 2496
- [show ptp time-property](#), on page 2498
- [show ptp unicast-negotiation](#), on page 2499

# show param-list

```
show param-list [ param-list-name <plistname> ] [ show-instance ] [ __readonly__ TABLE_param_list
<param_list_name> [ <param_list_var> ] [ <param_list_type> ] [ TABLE_instance <param_instance_name>
[ <param_instance_var> ] [ <param_instance_val> ] ] ]
```

## Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information              |
| param-list                 | Show param-list                              |
| param-list-name            | (Optional) param list name                   |
| <i>plistname</i>           | (Optional) Enter the name of the param-list  |
| show-instance              | (Optional) show instances for the param list |
| <i>__readonly__</i>        | (Optional)                                   |
| TABLE_param_list           | (Optional)                                   |
| <i>param_list_name</i>     | (Optional) Parameter List Name               |
| <i>param_list_var</i>      | (Optional) Parameter Name                    |
| <i>param_list_type</i>     | (Optional) Param Type                        |
| TABLE_instance             | (Optional)                                   |
| <i>param_instance_name</i> | (Optional) Instance Name                     |
| <i>param_instance_var</i>  | (Optional) Instance Variable Name            |
| <i>param_instance_val</i>  | (Optional) Instance Variable Value           |

## Command Mode

- /exec

# show password secure-mode

```
show password secure-mode [ __readonly__ { secure_mode <secure_mode_status> } ]
```

## Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information              |
| password                  | Password for the user                        |
| secure-mode               | secure mode for changing passwords           |
| __readonly__              | (Optional)                                   |
| secure_mode               | (Optional) run time status about xml         |
| <i>secure_mode_status</i> | (Optional) Run time status about secure mode |

## Command Mode

- /exec

# show password strength-check

```
show password strength-check [ __readonly__ { operation_status <o_status> } ]
```

## Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information                               |
| password         | Password for the user   |
| strength-check   | Strength check of password                                    |
| __readonly__     | (Optional)  |
| operation_status | (Optional) run-time information about password strength-check |
| <i>o_status</i>  | (Optional) operational status of password strength check      |

## Command Mode

- /exec

# show pie broker

show pie broker { clients | subscriptions | timers | events | event-stats }

## Syntax Description

|               |                                    |
|---------------|------------------------------------|
| show          | Show running system information    |
| pie           | Show information about pie         |
| broker        | Show information about broker      |
| clients       | Show information about pie clients |
| subscriptions | Show subscriptions                 |
| timers        | Show all timers                    |
| events        | Show all events                    |
| event-stats   | Show event stats                   |

## Command Mode

- /exec

# show pie envmon

```
show pie envmon { psu { all | <psuid> } | fan | sensor | cpu-usage | mem-usage } [ detail ] [ count <num_events> ]
```

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                  |
| pie               | Show information about pie                       |
| envmon            | Show environment monitoring insights information |
| psu               | Show power-supply insights                       |
| all               | Show all PSU insights                            |
| <i>psuid</i>      |  |
| fan               | Show fan insights                                |
| sensor            | Show sensor insights                             |
| cpu-usage         | Show cpu usage insights                          |
| mem-usage         | Show memory usage insights                       |
| detail            | (Optional) Show insights details                 |
| count             | (Optional) Show N number of events               |
| <i>num_events</i> | (Optional) 0 -- Unlimited   N -- num of events   |

## Command Mode

- /exec



# show pie eventdb

```
show pie eventdb { all | link-flaps | link-down | link-flap-rca | link-down-rca | ssd-cur | ssd-overall | dom |
dom_db | dom_xthres | cpu-usage [ insights ] | mem-usage [ insights ] | psu [ insights ] | fan [ insights ] | sensor
[ insights ] } [ detail ] [ count <num_events> ]
```

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                |
| pie               | Show information about pie                     |
| eventdb           | Show pie events from eventdb                   |
| all               | Show all classes of events                     |
| link-flaps        | Show link-flap events                          |
| link-down         | Show link-down events                          |
| link-flap-rca     | Show link-flap rca                             |
| link-down-rca     | Show link-down rca                             |
| ssd-cur           | Show SSD Current Stat events                   |
| ssd-overall       | Show SSD Overall Stat events                   |
| dom               | Show xcvr dom                                  |
| dom_db            | Show xcvr dom DB                               |
| dom_xthres        | Show xcvr dom xthres                           |
| cpu-usage         | Show cpu usage events                          |
| insights          | (Optional) Show insights events                |
| mem-usage         | Show memory usage events                       |
| psu               | Show power-supply events                       |
| fan               | Show fan events                                |
| sensor            | Show sensor events                             |
| detail            | (Optional) Show event details                  |
| count             | (Optional) Show N number of events             |
| <i>num_events</i> | (Optional) 0 -- Unlimited   N -- num of events |

## Command Mode

- /exec

# show pie eventid

show pie eventid <eventid>

## Syntax Description

|                |                                     |
|----------------|-------------------------------------|
| show           | Show running system information     |
| pie            | Show information about pie          |
| eventid        | Show information about this eventid |
| <i>eventid</i> | event id                            |

## Command Mode

- /exec

# show pie interface

show pie interface <iface> { link-flap-rca | link-down-rca | transceiver-insights } [ detail ]

## Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| pie                  | Show information about pie      |
| interface            | Interface events                |
| <i>iface</i>         | interface                       |
| link-flap-rca        | Show link-flap events           |
| link-down-rca        | Show link-down reason           |
| transceiver-insights | Show optics health              |
| detail               | (Optional) Show event details   |

## Command Mode

- /exec

## show platform vnic info

```
show platform vnic info [ __readonly__ <scheme> <total-vnics> <vnics-mapped> <vnics-unmapped>
<mgmt-int-device> <mgmt-int-mac> { TABLE_linecard_info <module> <module-vnics> } ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                    |
| platform                   | Platform specific commands                         |
| vnic                       | Virtual Network Interface Card                     |
| info                       | Show general VNIC information                      |
| <i>__readonly__</i>        | (Optional)   |
| <i>TABLE_linecard_info</i> | (Optional)   |
| <i>scheme</i>              | (Optional) VNIC scheme                             |
| <i>total-vnics</i>         | (Optional) Total number of VNICs                   |
| <i>vnics-mapped</i>        | (Optional) Total number of VNICs mapped            |
| <i>vnics-unmapped</i>      | (Optional) Total number of VNICs unmapped          |
| <i>mgmt-int-device</i>     | (Optional) Management interface                    |
| <i>mgmt-int-mac</i>        | (Optional) Management interface                    |
| <i>module</i>              | (Optional) Module                                  |
| <i>module-vnics</i>        | (Optional) Number of VNICs mapped to this linecard |

### Command Mode

- /exec

# show platform vnic mapped

```
show platform vnic mapped [ module <module-num> ] [ __readonly__ { TABLE_interface_info
<nxos-interface> <mac-address> <vnic> } ]
```

## Syntax Description

|                       |                                  |
|-----------------------|----------------------------------|
| show                  | Show running system information  |
| platform              | Platform specific commands       |
| vnic                  | Virtual Network Interface Card   |
| mapped                | Show mapped interfaces           |
| __readonly__          | (Optional)                       |
| TABLE_interface_info  | (Optional)                       |
| module                | (Optional) Enter a module number |
| <i>nxos-interface</i> | (Optional) NXOS interface        |
| <i>mac-address</i>    | (Optional) VNIC MAC-address      |
| <i>vnic</i>           | (Optional) VNIC mapping          |
| <i>module-num</i>     | (Optional) enter a module number |

## Command Mode

- /exec

## show pmap-int-br interface br

```
show pmap-int-br interface br [ __readonly__ { [ TABLE_ifvlanstr <if-vlan-str> <if-status> [ <in-pmap-qos>
] [ <out-pmap-qos> ] [ <in-pmap-que> ] [ <out-pmap-que> ] ] } ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                             |
| pmap-int-br         | Show policy maps  |
| interface           | Show service policy on interface                            |
| br                  | Brief report of all policies attached to interfaces         |
| TABLE_ifvlanstr     | (Optional) all interfaces xml sessions                      |
| <i>if-vlan-str</i>  | (Optional) ifindex or vlan id: xml key                      |
| <i>__readonly__</i> | (Optional)  |
| <i>if-status</i>    | (Optional) Interface/vlan status [active/inactive]: xml key |
| <i>in-pmap-qos</i>  | (Optional) Input QoS Policy-map name: xml key               |
| <i>out-pmap-qos</i> | (Optional) output QoS Policy-map name: xml key              |
| <i>in-pmap-que</i>  | (Optional) Input Que Policy-map name: xml key               |
| <i>out-pmap-que</i> | (Optional) Output Que Policy-map name: xml key              |

### Command Mode

- /exec

# show pmap-int

```
show pmap-int { interface [ <i>iface-list</i> ] [ input | output ] [ type <qos-or-q> ] [ detail ] |
```

## Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information               |
| pmap-int          | Show policy maps                              |
| interface         | Show service policy on interface              |
| <i>iface-list</i> | (Optional) List of Interface                  |
| input             | (Optional) Input Service policy               |
| output            | (Optional) Output Service policy              |
| type              | (Optional) Type of policy                     |
| <i>qos-or-q</i>   | (Optional)                                    |
| detail            | (Optional) Detailed QoS or Queuing statistics |

## Command Mode

- /exec

# show pnp lease

show pnp lease

## Syntax Description

|       |                                 |
|-------|---------------------------------|
| show  | Show running system information |
| pnp   | Plug and Play                   |
| lease | Show PnP lease information      |

## Command Mode

- /exec



# show pnp posix\_pi configs

show pnp posix\_pi configs

## Syntax Description

|          |                                 |
|----------|---------------------------------|
| show     | Show running system information |
| pnp      | Plug and Play                   |
| posix_pi | Posix PnP PI agent              |
| configs  | Posix PnP PI configuration      |

## Command Mode

- /exec

# show pnp posix\_pi tech-support

show pnp posix\_pi tech-support

## Syntax Description

|              |                                 |
|--------------|---------------------------------|
| show         | Show running system information |
| pnp          | Plug and Play                   |
| posix_pi     | Posix PnP PI agent              |
| tech-support | Technical Support               |

## Command Mode

- /exec

# show pnp profiles

show pnp profiles

## Syntax Description

|          |                                 |
|----------|---------------------------------|
| show     | Show running system information |
| pnp      | Plug and Play                   |
| profiles | Show POSIX PnP Profile          |

## Command Mode

- /exec

# show pnp status

show pnp status

## Syntax Description

|        |                                 |
|--------|---------------------------------|
| show   | Show running system information |
| pnp    | Plug and Play                   |
| status | Show POSIX PnP Status           |

## Command Mode

- /exec

# show pnp summary

show pnp summary

## Syntax Description

|         |                                 |
|---------|---------------------------------|
| show    | Show running system information |
| pnp     | Plug and Play                   |
| summary | Show POSIX PnP Summary          |

## Command Mode

- /exec

# show pnp version

show pnp version

## Syntax Description

|         |                                 |
|---------|---------------------------------|
| show    | Show running system information |
| pnp     | Plug and Play                   |
| version | Show POSIX PnP Version          |

## Command Mode

- /exec

# show policy-map

```
show policy-map [ { [ type qos ] [ <pmap-name-qos> ] } | { type queuing [ <pmap-name-que> ] } ] [
__readonly__ { [ <display-all> ] [ TABLE_pmap [ <pmap-key> ] [ <type-spec> ] [ <yqos-or-q> ] [ <options>
] [ <pmap-name-out> ] [ <nq-xpmap-name> ] [ <desc> ] [ <nq-desc> ] [ TABLE_cmap [ <cmap-key> ] [
<type-cmap-spec> ] [ <xqos-or-q> ] [ <cmap-name> ] [ <nq-xcmap-name> ] [ TABLE_action [ <action-key>
] [ <nq-action-key> ] [ <serv-pol-type> ] [ <serv-pol-name> ] [ <cos-list> ] [ <qos-group-list> ] [ <protocol>
] [ <nq-pause> ] [ <timeout> ] [ <nq-size-in-bytes> ] [ <nq-xoff-bytes> ] [ <nq-xon-bytes> ] [ <pfc-cos-list> ] [
<pfc_rx_only> ] [ <cc> ] [ <thresh-units> ] [ <min-thresh> ] [ <max-thresh> ] [ <drop-prob> ] [ <iod> ] [
<mtu> ] [ <set-cos> ] [ <dpp> ] [ <dctcp-threshold> ] [ <queue-limit> ] [ <inner> ] [ <dlb-disable> ] [ <cos>
] [ <exp-val-imposition> ] [ <exp-val-topmost> ] [ <dscp-enum> ] [ <dscp> ] [ <prec-enum> ] [ <prec> ] [
<disc-class> ] [ <qos-group> ] [ <tmap-from> ] [ <tmap-to> ] [ <tmap-name> ] [ <avg-rate-type> ] [ <rate-units>
] [ <shape-rate> ] [ <min-rate-type> ] [ <min-rate-units> ] [ <shape-min-rate> ] [ <max-rate-type> ] [
<max-rate-units> ] [ <shape-max-rate> ] [ <rise-threshold-units> ] [ <fall-threshold-units> ] [ <prio-level> ]
] [ <qlim-param-type> ] [ <qlim-param-val> ] [ <ooo> ] [ <size-units> ] [ <qlim-size> ] [ <qlim-enum-spec>
] [ <rdet-agg> ] [ <rdet-mode> ] [ <rdet-burst-opt> ] [ <rdet-mesh-opt> ] [ TABLE_rdet <rdet-key> [
<rdet-values> ] [ <rdet-min-thresh> ] [ <rdet-size-units> ] [ <rdet-max-thresh> ] [ <rdet-drop-prob> ] [
<rdet-weight> ] [ <rdet-cap-average> ] [ <rdet-ecn> ] [ <rdet-nonecn-mode> ] [ TABLE_rdet_nonecn
<rdet-nonecn-key> [ <rdet-nonecn-min-thresh> ] [ <rdet-nonecn-size-units> ] [ <rdet-nonecn-max-thresh> ]
] [ <rdet-nonecn-drop-prob> ] ] [ <afd-mode> ] [ TABLE_afd <afd-key> [ <afd-values> ] [ <afd-size-units> ]
] [ <afd-queue-desired> ] [ <afd-ecn> ] ] [ <pause> ] [ <size-in-bytes> ] [ <xoff-bytes> ] [ <xon-bytes> ] [
<priority-group-number> ] [ <bw-units> ] [ <bw-rate> ] [ <rem-bw-units> ] [ <rem-bw-rate> ] [
<agg-policer-name> ] [ <cir-spec> ] [ <bc-spec> ] [ <be-spec> ] [ <cir-rate-units> ] [ <cir> ] [ <bc-size-units>
] [ <bc> ] [ <pir-rate-units> ] [ <pir> ] [ <be-size-units> ] [ <be> ] [ <cnf-col-cmap> ] [ <exc-col-cmap> ] [
TABLE_police <police-key> [ <cnf-act> ] [ <exc-act> ] [ <vio-act> ] [ <set-type> ] [ <enum-spec> ] [ <set-val>
] [ <ptmap-from> ] [ <ptmap-to> ] [ <ptmap-name> ] ] [ <burst-detect-enable> ] ] ] ] }
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information            |
| policy-map           | Show policy maps                           |
| type                 | (Optional) Type of the policy-map          |
| qos                  | (Optional) type qos                        |
| queuing              | (Optional) type queuing                    |
| <i>pmap-name-qos</i> | (Optional) policy map name (type qos)      |
| <i>pmap-name-que</i> | (Optional) policy map name (type queuing)  |
| <i>__readonly__</i>  | (Optional)                                 |
| <i>display-all</i>   | (Optional) Display all kinds of class-maps |
| TABLE_pmap           | (Optional) all pmap xml sessions           |
| <i>pmap-key</i>      | (Optional) Policy-map name: xml key        |
| TABLE_rdet           | (Optional) all WRED sessions               |

|                       |   |
|-----------------------|---|
| TABLE_rdet_nonecn     | (Optional) all WRED non ECN sessions                                |
| TABLE_afd             | (Optional) all AFD sessions   |
| TABLE_police          | (Optional) all police actions                                       |
| <i>police-key</i>     | (Optional) police actions count: xml key                            |
| TABLE_cmap            | (Optional) all cmap xml sessions                                    |
| <i>cmap-key</i>       | (Optional) Class-map name: xml key                                  |
| TABLE_action          | (Optional) all actions  |
| <i>action-key</i>     | (Optional) Actions count: xml key                                   |
| <i>nq-action-key</i>  | (Optional) Actions xcount: xml key                                  |
| <i>yqos-or-q</i>      | (Optional)  |
| <i>options</i>        | (Optional) match-first option                                       |
| <i>pmap-name-out</i>  | (Optional) Policy-map name  |
| <i>desc</i>           | (Optional) Description string                                       |
| <i>nq-desc</i>        | (Optional) Description xstring                                      |
| <i>cmap-name</i>      | (Optional) Class-map name   |
| <i>nq-xpmap-name</i>  | (Optional) Policy-map xname   |
| <i>nq-xcmap-name</i>  | (Optional) Class-map xname  |
| <i>cos-list</i>       | (Optional) List of class-of-service values                          |
| <i>qos-group-list</i> | (Optional) List of qos-group values                                 |
| <i>protocol</i>       | (Optional) protocol   |
| <i>timeout</i>        | (Optional) timeout value  |
| <i>pfc-cos-list</i>   | (Optional) List of class-of-service values                          |
| <i>cc</i>             | (Optional) congestion control protocol                              |
| <i>thresh-units</i>   | (Optional) Units of threshold - pkts/bytes/kbytes/mbytes/ms/us/perc |
| <i>drop-prob</i>      | (Optional) Drop Probability at Maximum Threshold value              |
| <i>iod</i>            | (Optional) IOD value  |
| <i>mtu</i>            | (Optional) MTU value  |
| <i>set-cos</i>        | (Optional) Set CoS value  |
| <i>dpp</i>            | (Optional) Dynamic Packet Prioritization Class                      |



|                           |  |
|---------------------------|--|
| <i>dctcp-threshold</i>    | (Optional) DCTCP threshold in bytes                              |
| <i>queue-limit</i>        | (Optional) Queue size for the class                              |
| <i>pfc_rx_only</i>        | (Optional) Pause receive only mode is enabled                    |
| <i>xqos-or-q</i>          | (Optional)   |
| <i>serv-pol-type</i>      | (Optional) Type of service policy referred to                    |
| <i>serv-pol-name</i>      | (Optional) Name of policy-map referred to within this policy-map |
| <i>type-spec</i>          | (Optional) Type of policy-map specified or not                   |
| <i>type-cmap-spec</i>     | (Optional) Type of class-map specified or not                    |
| <i>inner</i>              | (Optional) Specifies if tunnel or inner keywords are mentioned   |
| <i>dlb-disable</i>        | (Optional) Disable Dynamic Load Balancing                        |
| <i>cos</i>                | (Optional) IEEE 802.1Q Class of Service value                    |
| <i>exp-val-imposition</i> | (Optional) MPLS EXP value of type imposition                     |
| <i>exp-val-topmost</i>    | (Optional) MPLS EXP value of type topmost                        |
| <i>dscp</i>               | (Optional) DSCP in IP(v4) and IPv6 packets                       |
| <i>dscp-enum</i>          | (Optional)   |
| <i>prec</i>               | (Optional) Precedence in IP(v4) and IPv6 packets                 |
| <i>prec-enum</i>          | (Optional)   |
| <i>disc-class</i>         | (Optional) Discard class   |
| <i>qos-group</i>          | (Optional) Qos-group   |
| <i>tmap-from</i>          | (Optional)   |
| <i>tmap-to</i>            | (Optional)   |
| <i>tmap-name</i>          | (Optional) Table map name  |
| <i>ptmap-from</i>         | (Optional)   |
| <i>ptmap-to</i>           | (Optional)   |
| <i>ptmap-name</i>         | (Optional) Table map name  |
| <i>avg-rate-type</i>      | (Optional) Specifies if average shape rate is specified          |
| <i>rate-units</i>         | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us         |
| <i>min-rate-type</i>      | (Optional) Specifies if minimum shape rate is specified          |
| <i>min-rate-units</i>     | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us         |

|                               |   |
|-------------------------------|---|
| <i>max-rate-type</i>          | (Optional) Specifies if maximum shape rate is specified                 |
| <i>max-rate-units</i>         | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us                |
| <i>cir-rate-units</i>         | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps           |
| <i>pir-rate-units</i>         | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps           |
| <i>prio-level</i>             | (Optional) Priority if specified  |
| <i>qlim-param-type</i>        | (Optional) Type of parameter for qlim - cos/prec/dscp/disc class/qosgrp |
| <i>qlim-param-val</i>         | (Optional) Parameter value for qlimit                                   |
| <i>qlim-size</i>              | (Optional) Queue size for qlimit  |
| <i>size-units</i>             | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>rdet-size-units</i>        | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>rdet-nonecn-size-units</i> | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>afd-size-units</i>         | (Optional) Units of queue size - bytes/kbytes/mbytes                    |
| <i>bc-size-units</i>          | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>be-size-units</i>          | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>qlim-enum-spec</i>         | (Optional) Whether qlimit parameter is specified in enum or not         |
| <i>rdet-mode</i>              | (Optional) Random-detect mode   |
| <i>rdet-nonecn-mode</i>       | (Optional) Random-detect non-ecn mode                                   |
| <i>rdet-agg</i>               | (Optional) Are the params for aggregate flow                            |
| <i>rdet-values</i>            | (Optional) List of class-of-service values for random-detect            |
| <i>rdet-drop-prob</i>         | (Optional) Random-detect drop probability                               |
| <i>rdet-weight</i>            | (Optional) Random-detect queue length weight                            |
| <i>rdet-cap-average</i>       | (Optional) Random-detect cap-average                                    |
| <i>rdet-ecn</i>               | (Optional) Random-detect ECN  |
| <i>rdet-burst-opt</i>         | (Optional) Random-detect burst optimized                                |
| <i>rdet-mesh-opt</i>          | (Optional) Random-detect mesh optimized                                 |
| <i>rdet-nonecn-drop-prob</i>  | (Optional) Random-detect non-ecn drop probability                       |
| <i>afd-mode</i>               | (Optional) AFD mode   |
| <i>afd-values</i>             | (Optional) List of class-of-service values for AFD                      |
| <i>afd-ecn</i>                | (Optional) AFD ECN  |

|                              |   |
|------------------------------|---|
| <i>pause</i>                 | (Optional) Pause value                          |
| <i>nq-pause</i>              | (Optional) NQ Pause value                       |
| <i>priority-group-number</i> | (Optional) Priority group value                 |
| <i>bw-units</i>              | (Optional) Bandwidth units                      |
| <i>rem-bw-units</i>          | (Optional) Remaining bandwidth units            |
| <i>rem-bw-rate</i>           | (Optional) Remaining bandwidth rate             |
| <i>agg-policer-name</i>      | (Optional) Aggregate policer name               |
| <i>cir-spec</i>              | (Optional) Is CIR keyword specified             |
| <i>bc-spec</i>               | (Optional) Is Committed Burst keyword specified |
| <i>be-spec</i>               | (Optional) Is Extended Burst keyword specified  |
| <i>cnf-col-cmap</i>          | (Optional) Conforming color class-map name      |
| <i>exc-col-cmap</i>          | (Optional) Exceeding color class-map name       |
| <i>enum-spec</i>             | (Optional) Is DSCP or PREC enum value specified |
| <i>cnf-act</i>               | (Optional) Conform action (Police)              |
| <i>exc-act</i>               | (Optional) Exceed action (Police)               |
| <i>vio-act</i>               | (Optional) Violate action (Police)              |
| <i>set-type</i>              | (Optional) Type of set in police action         |
| <i>set-val</i>               | (Optional) Value of set type in police action   |
| <i>ooo</i>                   | (Optional) Out-of-Order                         |
| <i>burst-detect-enable</i>   | (Optional) Burst detect feature is enabled      |

### Command Mode

- /exec



|                                    |  |
|------------------------------------|--|
| <i>acc_grp_name</i>                | (Optional)                                       |
| redirect                           | (Optional)                                       |
| <i>opt_match_redirect</i>          | (Optional) Match criteria for redirected packets |
| exception                          | (Optional)                                       |
| <i>opt_match_except</i>            | (Optional) Match criteria for exception packets  |
| protocol                           | (Optional)                                       |
| <i>opt_match_protocol</i>          | (Optional) Match criteria for protocol packets   |
| <i>set_vld_flg</i>                 | (Optional) Set valid flag                        |
| cos                                | (Optional)                                       |
| inner                              | (Optional)                                       |
| <i>cos-val</i>                     | (Optional) Set cos val                           |
| dscp                               | (Optional)                                       |
| tunnel                             | (Optional)                                       |
| <i>dscp-val</i>                    | (Optional) Set dscp val                          |
| precedence                         | (Optional)                                       |
| tunnel1                            | (Optional)                                       |
| <i>prec-val</i>                    | (Optional) Set prec val                          |
| <i>policer_show_flags</i>          | (Optional) Policer show flags                    |
| <i>level</i>                       | (Optional) syslog severity level                 |
| <i>opt_kbps_mbps_gbps_pps_cir</i>  | (Optional) Units                                 |
| percent                            | (Optional)                                       |
| <i>opt_kbps_mbps_gbps_pps_pir</i>  | (Optional) Units                                 |
| percent1                           | (Optional)                                       |
| <i>opt_kbytes_mbytes_gbytes_bc</i> | (Optional) Units                                 |
| <i>opt_kbytes_mbytes_gbytes_be</i> | (Optional) Units                                 |
| TABLE_slot                         | (Optional) all slot-num : XML output             |
| <i>slot-no-in</i>                  | (Optional) input slot no                         |
| <i>slot-no-out</i>                 | (Optional) output slot no                        |
| <i>opt_drop_transmit_conform</i>   | (Optional) Set the action                        |

|                                  |                                    |
|----------------------------------|------------------------------------|
| set-cos-transmit                 | (Optional)                         |
| <i>set-cos-val</i>               | (Optional) Conform action cos val  |
| set-dscp-transmit                | (Optional)                         |
| <i>set-dscp-val</i>              | (Optional) Conform action dscp val |
| set-prec-transmit                | (Optional)                         |
| <i>set-prec-val</i>              | (Optional) Conform action prec val |
| <i>opt_drop_transmit_exceed</i>  | (Optional) Set the action          |
| set                              | (Optional)                         |
| dscp1                            | (Optional)                         |
| dscp2                            | (Optional)                         |
| table                            | (Optional)                         |
| cir-markdown-map                 | (Optional)                         |
| <i>opt_drop_transmit_violate</i> | (Optional) Set the action          |
| set1                             | (Optional)                         |
| dscp3                            | (Optional)                         |
| dscp4                            | (Optional)                         |
| table1                           | (Optional)                         |
| pir-markdown-map                 | (Optional)                         |

**Command Mode**

- /exec

## show policy-map system

```
show policy-map system [ type { network-qos | qos [ input2 ] | queuing [ input | output ] } ] [ __readonly__
{ [ <display-all> ] [ TABLE_xpmap <xpmap-name> [ <desc> ] [ TABLE_xcmap <xcmap-name> [
TABLE_xmatch <xmatch-key> [ <xcos-list> ] [ <xqos-group-list> ] [ <xprotocol> ] ] [ TABLE_xaction
<xaction-key> [ <cos-list> ] [ <qos-group-list> ] [ <protocol> ] [ <pause> <timeout> <size-in-bytes>
<xoff-bytes> <xon-bytes> ] [ <pfc-cos-list> ] [ <pfc_rx_only> ] [ <cc> ] [ <thresh-units> ] [ <min-thresh> ]
[ <max-thresh> ] [ <drop-prob> ] [ <iod> ] [ <mtu> ] [ <set-cos> ] [ <dpp> ] [ <dctcp-threshold> ] [
<queue-limit> ] [ <stat-en-dis-enum> ] ] ] ] [ TABLE_pmap <pmap-key> <pmap-inner-outer> <in-or-out>
<yqos-or-q> [ <options> ] <pmap-name> [ <stat-status-enum> ] [ TABLE_cmap <cmap-key> [ <xqos-or-q>
] <match-opts> <cmap-name> [ TABLE_slot <slot-key> [ <slot-num> ] [ <class-pkts> ] [ <class-bytes> ] [
<class-off-rate> ] ] [ <class-drop-rate> ] [ <agg-forward> ] [ <class-agg-bytes> ] [ TABLE_match <match-key>
[ <not> ] [ <inner> ] [ <cos-list> ] [ <dscp-list> ] [ <exp-value-top> ] [ <protocol-name> ] [
<match-cmap-xqos-or-q> ] [ <match-cmap-opts> ] [ <match-cmap-name> ] ] [ TABLE_action <action-key>
[ <set-inner> ] [ <cos> ] [ <qos-group> ] [ <serv-pol-type> ] [ <serv-pol-name> ] [ <serv-pol-return-inout> ]
[ <rate-units> ] [ <shape-rate> ] [ <min-rate-type> ] [ <min-rate-units> ] [ <max-rate-type> ] [ <max-rate-units>
] [ <shape-min-rate> ] [ <shape-max-rate> ] [ <prio-level> ] [ <qlim-param-type> ] [ <qlim-param-val> ] [
<size-units> ] [ <qlim-size> ] [ <qlim-enum-spec> ] [ <bw-units> ] [ <bw-rate> ] [ <rem-bw-units> ] [
<rem-bw-rate> ] [ <rise-threshold-units> ] [ <fall-threshold-units> ] [ <rdet-agg> ] [ <rdet-mode> ] [
<rdet-burst-opt> ] [ <rdet-mesh-opt> ] [ TABLE_rdet <rdet-key> [ <rdet-values> ] [ <rdet-min-thresh> ] [
<rdet-size-units> ] [ <rdet-max-thresh> ] [ <rdet-drop-prob> ] [ <rdet-weight> ] [ <rdet-cap-average> ] ] [
<rdet-ecn> ] [ <afd-mode> ] [ TABLE_afd <afd-key> [ <afd-values> ] [ <afd-size-units> ] [
<afd-queue-desired> ] [ <afd-ecn> ] ] [ <pause> <size-in-bytes> <xoff-bytes> <xon-bytes> ] ] ] ] }
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                |
| policy-map         | Show policy maps                               |
| type               | (Optional) Type of the policy-map              |
| system             | Active policy in the system                    |
| network-qos        | (Optional) type network-qos                    |
| qos                | (Optional) type qos                            |
| input2             | (Optional) input policy                        |
| queuing            | (Optional) type queuing                        |
| input              | (Optional) input policy                        |
| output             | (Optional) output policy                       |
| __readonly__       | (Optional)                                     |
| <i>display-all</i> | (Optional) Display all network-qos policy-maps |
| TABLE_xpmap        | (Optional) all xpmap xml sessions              |
| <i>xpmap-name</i>  | (Optional) Policy-map name                     |

|                         |   |
|-------------------------|---|
| TABLE_xcmap             | (Optional) all xcmap xml sessions                                   |
| <i>xcmap-name</i>       | (Optional) Class-map name   |
| TABLE_xmatch            | (Optional) all match xml sessions                                   |
| <i>xmatch-key</i>       | (Optional) match count: xml key                                     |
| <i>xcos-list</i>        | (Optional) List of class-of-service values                          |
| <i>xqos-group-list</i>  | (Optional) List of qos-group values                                 |
| <i>xprotocol</i>        | (Optional) xprotocol  |
| TABLE_xaction           | (Optional) all network-qos actions                                  |
| <i>xaction-key</i>      | (Optional) network-qos actions count: xml key                       |
| TABLE_pmap              | (Optional) all pmap xml sessions                                    |
| <i>pmap-key</i>         | (Optional) Policy-map name: xml key                                 |
| TABLE_cmap              | (Optional) all cmap xml sessions                                    |
| <i>cmap-key</i>         | (Optional) Class-map name: xml key                                  |
| TABLE_action            | (Optional) all actions  |
| <i>action-key</i>       | (Optional) Actions count: xml key                                   |
| TABLE_match             | (Optional) all match xml sessions                                   |
| <i>match-key</i>        | (Optional) match count: xml key                                     |
| TABLE_rdet              | (Optional) all WRED sessions  |
| TABLE_afd               | (Optional) all AFD sessions   |
| <i>stat-en-dis-enum</i> | (Optional)  |
| <i>in-or-out</i>        | (Optional)  |
| <i>yqos-or-q</i>        | (Optional)  |
| <i>stat-status-enum</i> | (Optional)  |
| <i>desc</i>             | (Optional) Description string                                       |
| <i>thresh-units</i>     | (Optional) Units of threshold - pkts/bytes/kbytes/mbytes/ms/us/perc |
| <i>drop-prob</i>        | (Optional) Drop Probability at Maximum Threshold value              |
| <i>pause</i>            | (Optional) Pause value  |
| <i>pfc-cos-list</i>     | (Optional) List of class-of-service values                          |
| <i>pfc_rx_only</i>      | (Optional) Pause receive only mode enabled                          |



|                              |  |
|------------------------------|--|
| <i>timeout</i>               | (Optional) timeout value                                       |
| <i>cc</i>                    | (Optional) congestion control protocol                         |
| <i>iod</i>                   | (Optional) IOD value   |
| <i>mtu</i>                   | (Optional) MTU value   |
| <i>set-cos</i>               | (Optional) Set CoS value                                       |
| <i>dpp</i>                   | (Optional) Dynamic Packet Prioritization Class                 |
| <i>queue-limit</i>           | (Optional) Queue size for the class                            |
| <i>protocol-name</i>         | (Optional) protocol name                                       |
| <i>protocol</i>              | (Optional) protocol  |
| <i>dctcp-threshold</i>       | (Optional) DCTCP threshold in bytes                            |
| <i>cos-list</i>              | (Optional) List of class-of-service values                     |
| <i>dscp-list</i>             | (Optional) List of DSCP values                                 |
| <i>exp-value-top</i>         | (Optional) List of MPLS exp values                             |
| <i>qos-group</i>             | (Optional) QoS Group Value                                     |
| <i>qos-group-list</i>        | (Optional) List of qos-group values                            |
| <i>options</i>               | (Optional) match-first option                                  |
| <i>pmap-name</i>             | (Optional) Policy-map name                                     |
| <i>pmap-inner-outer</i>      | (Optional) Inner or Outer policy-map                           |
| <i>serv-pol-return-inout</i> | (Optional) Inner or Outer policy-map                           |
| <i>cmap-name</i>             | (Optional) Class-map name                                      |
| <i>xqos-or-q</i>             | (Optional)   |
| <i>match-opts</i>            | (Optional) Type of match in class-map                          |
| <i>match-cmap-xqos-or-q</i>  | (Optional)   |
| <i>match-cmap-opts</i>       | (Optional) Type of match in class-map                          |
| <i>not</i>                   | (Optional) Negate this match result                            |
| <i>inner</i>                 | (Optional) Specifies if tunnel or inner keywords are mentioned |
| <i>cos-list</i>              | (Optional) List of class-of-service values                     |
| <i>match-cmap-name</i>       | (Optional) class-map name                                      |
| <i>serv-pol-type</i>         | (Optional) Type of service policy referred to                  |

|                         |   |
|-------------------------|---|
| <i>serv-pol-name</i>    | (Optional) Name of policy-map referred to within this policy-map        |
| <i>set-inner</i>        | (Optional) Specifies if tunnel or inner keywords are mentioned          |
| <i>cos</i>              | (Optional) IEEE 802.1Q Class of Service value                           |
| <i>rate-units</i>       | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us                |
| <i>min-rate-type</i>    | (Optional) Specifies if minimum shape rate is specified                 |
| <i>min-rate-units</i>   | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us                |
| <i>max-rate-type</i>    | (Optional) Specifies if maximum shape rate is specified                 |
| <i>max-rate-units</i>   | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us                |
| <i>prio-level</i>       | (Optional) Priority if specified  |
| <i>qlim-param-type</i>  | (Optional) Type of parameter for qlim - cos/prec/dscp/disc class/qosgrp |
| <i>qlim-param-val</i>   | (Optional) Parameter value for qlimit                                   |
| <i>qlim-size</i>        | (Optional) Queue size for qlimit  |
| <i>size-units</i>       | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>qlim-enum-spec</i>   | (Optional) Whether qlimit parameter is specified in enum or not         |
| <i>rdet-size-units</i>  | (Optional) Units of queue size - pkts/bytes/kbytes/mbytes/ms/us/perc    |
| <i>afd-size-units</i>   | (Optional) Units of queue size - bytes/kbytes/mbytes                    |
| <i>bw-units</i>         | (Optional) Bandwidth units  |
| <i>rem-bw-units</i>     | (Optional) Remaining bandwidth units                                    |
| <i>rem-bw-rate</i>      | (Optional) Remaining bandwidth rate                                     |
| <i>rdet-values</i>      | (Optional) List of class-of-service values for random-detect            |
| <i>rdet-agg</i>         | (Optional) Are the params for aggregate flow                            |
| <i>rdet-mode</i>        | (Optional) Random-detect mode   |
| <i>rdet-drop-prob</i>   | (Optional) Random-detect drop probability                               |
| <i>rdet-weight</i>      | (Optional) Random-detect queue length weight                            |
| <i>rdet-cap-average</i> | (Optional) Random-detect cap-average                                    |
| <i>rdet-ecn</i>         | (Optional) Random-detect ECN  |
| <i>rdet-burst-opt</i>   | (Optional) Random-detect burst optimized                                |
| <i>rdet-mesh-opt</i>    | (Optional) Random-detect mesh optimized                                 |
| <i>afd-mode</i>         | (Optional) AFD mode   |

|                    |  |
|--------------------|--|
| <i>afd-values</i>  | (Optional) List of class-of-service values for afd |
| <i>afd-ecn</i>     | (Optional) AFD ECN                                 |
| <i>pause</i>       | (Optional) Pause value                             |
| <i>slot-num</i>    | (Optional) the slot number                         |
| <i>agg-forward</i> | (Optional) prints out aggregate forward            |
| TABLE_slot         | (Optional) all slot xml sessions                   |
| <i>slot-key</i>    | (Optional) slot count: xml key                     |

**Command Mode**

- /exec



|                                    |   |
|------------------------------------|---|
| exception                          | (Optional)                                      |
| <i>opt_match_except</i>            | (Optional) Match criteria for exception packets |
| protocol                           | (Optional)                                      |
| <i>opt_match_protocol</i>          | (Optional) Match criteria for protocol packets  |
| TABLE_set_action                   | (Optional) Table of set action                  |
| <i>set_vld_flg</i>                 | (Optional) Set valid flag                       |
| <i>level</i>                       | (Optional) syslog severity level                |
| <i>opt_kbps_mbps_gbps_pps_cir</i>  | (Optional) Units                                |
| percent                            | (Optional)                                      |
| <i>opt_kbps_mbps_gbps_pps_pir</i>  | (Optional) Units                                |
| percent1                           | (Optional)                                      |
| <i>opt_kbytes_mbytes_gbytes_bc</i> | (Optional) Units                                |
| <i>opt_kbytes_mbytes_gbytes_be</i> | (Optional) Units                                |
| <i>opt_drop_transmit_conform</i>   | (Optional) Set the action                       |
| set-cos-transmit                   | (Optional)                                      |
| <i>set-cos-val</i>                 | (Optional) Conform action cos val               |
| set-dscp-transmit                  | (Optional)                                      |
| <i>set-dscp-val</i>                | (Optional) Conform action dscp val              |
| set-prec-transmit                  | (Optional)                                      |
| <i>set-prec-val</i>                | (Optional) Conform action prec val              |
| <i>opt_drop_transmit_exceed</i>    | (Optional) Set the action                       |
| set                                | (Optional)                                      |
| dscp1                              | (Optional)                                      |
| dscp2                              | (Optional)                                      |
| table                              | (Optional)                                      |
| cir-markdown-map                   | (Optional)                                      |
| <i>opt_drop_transmit_violate</i>   | (Optional) Set the action                       |
| set1                               | (Optional)                                      |
| dscp3                              | (Optional)                                      |

|                           |                               |
|---------------------------|-------------------------------|
| dscp4                     | (Optional)                    |
| table1                    | (Optional)                    |
| pir-markdown-map          | (Optional)                    |
| cos                       | (Optional)                    |
| inner                     | (Optional)                    |
| <i>cos-val</i>            | (Optional) Set cos val        |
| dscp                      | (Optional)                    |
| tunnel                    | (Optional)                    |
| <i>dscp-val</i>           | (Optional) Set dscp val       |
| precedence                | (Optional)                    |
| tunnel1                   | (Optional)                    |
| <i>prec-val</i>           | (Optional) Set prec val       |
| <i>policer_show_flags</i> | (Optional) Policer show flags |

**Command Mode**

- /exec

## show policy-map type network-qos

```
show policy-map type network-qos [ <pmap-name-nq> ] [ __readonly__ { [ <display-all> ] [ TABLE_xpmap
<xpmap-name> [ <desc> ] [ TABLE_xcmap <xcmap-name> [ TABLE_xmatch <xmatch-key> [ <xcos-list>
] [ <xqos-group-list> ] [ <xprotocol> ] ] [ TABLE_action <action-key> [ <cos-list> ] [ <qos-group-list> ] [
<protocol> ] [ <pause> <timeout> <size-in-bytes> <xoff-bytes> <xon-bytes> ] [ <pfc-cos-list> ] [
<pfc_rx_only> ] [ <cc> ] [ <thresh-units> ] [ <min-thresh> ] [ <max-thresh> ] [ <drop-prob> ] [ <iod> ] [
<mtu> ] [ <set-cos> ] [ <dpp> ] [ <dctcp-threshold> ] [ <queue-limit> ] ] ] ] }
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                |
| policy-map             | Show policy maps                               |
| type                   | Type of the policy-map                         |
| <i>pmap-name-nq</i>    | (Optional) Policy-map name                     |
| network-qos            | type network-qos                               |
| <i>__readonly__</i>    | (Optional)                                     |
| <i>display-all</i>     | (Optional) Display all network-qos policy-maps |
| TABLE_xpmap            | (Optional) all xpmap xml sessions              |
| <i>xpmap-name</i>      | (Optional) Policy-map name                     |
| TABLE_xcmap            | (Optional) all xcmap xml sessions              |
| <i>xcmap-name</i>      | (Optional) Class-map name                      |
| TABLE_xmatch           | (Optional) all match xml sessions              |
| <i>xmatch-key</i>      | (Optional) match count: xml key                |
| <i>xcos-list</i>       | (Optional) List of class-of-service values     |
| <i>xqos-group-list</i> | (Optional) List of qos-group values            |
| <i>xprotocol</i>       | (Optional) xprotocol                           |
| TABLE_action           | (Optional) all actions                         |
| <i>action-key</i>      | (Optional) Actions count: xml key              |
| <i>desc</i>            | (Optional) Description string                  |
| <i>cos-list</i>        | (Optional) List of class-of-service values     |
| <i>qos-group-list</i>  | (Optional) List of qos-group values            |
| <i>protocol</i>        | (Optional) protocol                            |

|                        |   |
|------------------------|---|
| <i>pause</i>           | (Optional) Pause value  |
| <i>timeout</i>         | (Optional) timeout value  |
| <i>pfc-cos-list</i>    | (Optional) List of class-of-service values                          |
| <i>cc</i>              | (Optional) congestion control protocol                              |
| <i>thresh-units</i>    | (Optional) Units of threshold - pkts/bytes/kbytes/mbytes/ms/us/perc |
| <i>drop-prob</i>       | (Optional) Drop Probability at Maximum Threshold value              |
| <i>iod</i>             | (Optional) IOD value  |
| <i>mtu</i>             | (Optional) MTU value  |
| <i>set-cos</i>         | (Optional) Set CoS value  |
| <i>dpp</i>             | (Optional) Dynamic Packet Prioritization Class                      |
| <i>dctcp-threshold</i> | (Optional) DCTCP threshold in bytes                                 |
| <i>queue-limit</i>     | (Optional) Queue size for the class                                 |
| <i>pfc_rx_only</i>     | (Optional) Pause receive only mode is enabled                       |

**Command Mode**

- /exec



# show port-channel capacity

show port-channel capacity [ *\_\_readonly\_\_* <total> <used> <free> <percentage\_used> ]

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information        |
| port-channel           | Show port-channel information          |
| capacity               | Capacity information                   |
| <i>__readonly__</i>    | (Optional)                             |
| <i>total</i>           | (Optional) Total resource              |
| <i>used</i>            | (Optional) Used resource               |
| <i>free</i>            | (Optional) Free resource               |
| <i>percentage_used</i> | (Optional) Used resource in percentage |

## Command Mode

- /exec

# show port-channel compatibility-parameters

show port-channel compatibility-parameters [ *\_\_readonly\_\_* { *TABLE\_compatibility* <parameter> <description> } + ]

## Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information             |
| port-channel               | Show port-channel information               |
| compatibility-parameters   | Show compatibility parameters               |
| <i>__readonly__</i>        | (Optional)                                  |
| <i>TABLE_compatibility</i> | (Optional) Port-channel compatibility table |
| <i>parameter</i>           | (Optional) Compatibility parameter          |
| <i>description</i>         | (Optional) Parameter description            |

## Command Mode

- /exec

# show port-channel database

```
show port-channel database [ interface <if0> ] [ __readonly__ TABLE_interface <interface>
<last-membership-update> <total-ports> <total-up-ports> [ <first_operational-port> ] <age-of-channel> [
<time-since-last-bundle> ] [ <last-bundled-member> ] [ <time-since-last-unbundle> ] [
<last-unbundled-member> ] [ { TABLE_member <port> <mode> <port-status> } ] [ <protocol> ] ]
```

## Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information            |
| port-channel                    | Show port-channel information              |
| database                        | Show port-channel database                 |
| interface                       | (Optional) Specify a port-channel          |
| <i>if0</i>                      | (Optional)                                 |
| <i>__readonly__</i>             | (Optional)                                 |
| TABLE_interface                 | (Optional) Port-channel table              |
| <i>interface</i>                | (Optional) Port channel                    |
| <i>mode</i>                     | (Optional) channel-group mode              |
| <i>last-membership-update</i>   | (Optional) Last membership update          |
| <i>total-ports</i>              | (Optional) Total number of member ports    |
| <i>total-up-ports</i>           | (Optional) Total number of UP member ports |
| <i>first_operational-port</i>   | (Optional) First operational port          |
| TABLE_member                    | (Optional) Member ports info               |
| <i>port</i>                     | (Optional) Member port                     |
| <i>port-status</i>              | (Optional) Member port status              |
| <i>age-of-channel</i>           | (Optional) Age of port channel             |
| <i>time-since-last-bundle</i>   | (Optional) Time since last port bundled    |
| <i>last-bundled-member</i>      | (Optional) Last bundled member port        |
| <i>time-since-last-unbundle</i> | (Optional) Time since last port un-bundled |
| <i>last-unbundled-member</i>    | (Optional) Last unbundled member port      |
| <i>protocol</i>                 | (Optional) Port channel protocol           |

## Command Mode

- /exec

# show port-channel fast-convergence

show port-channel fast-convergence [ \_\_readonly\_\_ { port-channel fast-convergence <fastconvergence> } ]

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                         |
| port-channel           | Configure port channel parameters                       |
| fast-convergence       | Show port-channel fast-convergence status               |
| __readonly__           | (Optional)  |
| <i>fastconvergence</i> | (Optional) port channel fast convergence enable/disable |

## Command Mode

- /exec

## show port-channel load-balance

```
show port-channel load-balance { [ module <module> ] | { fex { all } } } [ __readonly__ [ <sys-cfg> ] + [ <sys-cfg-sel> ] [ { <module-cfg> } ] + <non-ip-val> <non-ip-sel> <ipv4-val> <ipv4-sel> [ <ipv6-val> ] [ <ipv4-encap> ] { TABLE_mod_configs [ <mod-number> ] <mod-non-ip-val> <mod-non-ip-sel> <mod-ipv4-val> <mod-ipv4-sel> [ <mod-ipv4-encap> ] } ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| port-channel          | Show port-channel information                      |
| load-balance          | Show port-channel load balance                     |
| module                | (Optional) slot                                    |
| <i>module</i>         | (Optional) Specify a module number                 |
| fex                   | FEX devices  |
| all                   | Display all configured FEX port-channel LB         |
| <u>__readonly__</u>   | (Optional)   |
| <i>sys-cfg</i>        | (Optional) system wide load balance configuraton   |
| <i>sys-cfg-sel</i>    | (Optional) system config                           |
| <i>module-cfg</i>     | (Optional) per module load balance configuraton    |
| <i>non-ip-val</i>     | (Optional) load balance setting for non-ip traffic |
| <i>non-ip-sel</i>     | (Optional) non ip select                           |
| <i>ipv4-val</i>       | (Optional) load balance setting for ipv4 traffic   |
| <i>ipv4-sel</i>       | (Optional) ip select                               |
| <i>ipv6-val</i>       | (Optional) load balance setting for ipv6 traffic   |
| <i>ipv4-encap</i>     | (Optional) encapsulation                           |
| TABLE_mod_configs     | (Optional) module configurations                   |
| <i>mod-number</i>     | (Optional) module number                           |
| <i>mod-non-ip-val</i> | (Optional) load balance setting for non-ip traffic |
| <i>mod-non-ip-sel</i> | (Optional) non ip select                           |
| <i>mod-ipv4-val</i>   | (Optional) load balance setting for ipv4 traffic   |
| <i>mod-ipv4-sel</i>   | (Optional) ip select                               |

|                       |                          |
|-----------------------|--------------------------|
| <i>mod-ipv4-encap</i> | (Optional) encapsulation |
|-----------------------|--------------------------|

**Command Mode**

- /exec

## show port-channel load-balance forwarding-path1 interface src-interface

```
show port-channel load-balance forwarding-path1 interface <ch-id> src-interface <src-if> { vlan <vlan-id> |
src-mac <src-mac> | dst-mac <dst-mac> | src-ip <src-ip> | dst-ip <dst-ip> | src-ipv6 <src-ipv6> | dst-ipv6
<dst-ipv6> | l4-src-port <l4-src-port> | l4-dst-port <l4-dst-port> | ether-type <ethertype> | ip-prot <prot> }
+ [ __readonly__ { loadbalance-algorithm <algorithm> } { outgoing-port-id <port> } ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information            |
| port-channel       | Configure port channel parameters          |
| load-balance       | Show port-channel load balance             |
| forwarding-path1   | Packet forwarding information              |
| interface          | Specify a port-channel number              |
| <i>ch-id</i>       | Port-Channel name                          |
| vlan               | VLAN - for dot1Q tagged packets at ingress |
| <i>vlan-id</i>     | VLAN ID                                    |
| src-mac            | Source MAC Address                         |
| <i>src-mac</i>     | Source MAC address                         |
| dst-mac            | Destination MAC Address                    |
| <i>dst-mac</i>     | Destination MAC address                    |
| src-ip             | Source IP address                          |
| <i>src-ip</i>      | Source IP address in format i.i.i.i        |
| dst-ip             | Destination IPv4 address                   |
| <i>dst-ip</i>      | Destination IP address in format i.i.i.i   |
| src-ipv6           | Source IPv6 address                        |
| dst-ipv6           | Destination IPv6 address                   |
| l4-src-port        | Source Port                                |
| <i>l4-src-port</i> | Source L4 port                             |
| l4-dst-port        | Destination Port                           |
| <i>l4-dst-port</i> | Destination L4 port                        |



|                       |   |
|-----------------------|---|
| ether-type            | Ethernet Type   |
| <i>ethertype</i>      | Ethernet Type   |
| src-interface         | Optional source interface (physical switch port only) |
| <i>src-if</i>         | Interface name  |
| ip-proto              | IP v4/v6 Protocol                                     |
| <i>prot</i>           | IP Protocol   |
| __readonly__          | (Optional)  |
| loadbalance-algorithm | (Optional) load balance algorithm                     |
| <i>algorithm</i>      | (Optional) algorithm                                  |
| outgoing-port-id      | (Optional) outgoing port-id                           |
| <i>port</i>           | (Optional) port                                       |

**Command Mode**

- /exec

## show port-channel load-balance forwarding-path interface

```
show port-channel load-balance forwarding-path { interface <ch-id> | hgig } { src-interface <src-if> | vlan
<vlan-id> | src-mac <src-mac> | dst-mac <dst-mac> | src-ip <src-ip> | dst-ip <dst-ip> | src-ipv6 <src-ipv6> |
dst-ipv6 <dst-ipv6> | l4-src-port <l4-src-port> | l4-dst-port <l4-dst-port> | ethertype <ethertype> | protocol
<prot> | gtp-teid <gtp-teid> | ipv6-flow-label <ipv6-flow-label> } + [ module <module> | fex <fex-range> |
hgig-tgid <tgid> ] + [ source-interface <if-id> ] [ __readonly__ { loadbalance-algorithm <algorithm> } {
outgoing-port-id <port> } ]
```

### Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                |
| port-channel       | Configure port channel parameters              |
| load-balance       | Show port-channel load balance                 |
| forwarding-path    | Packet forwarding information                  |
| interface          | Specify a port-channel number                  |
| <i>ch-id</i>       | Port-Channel name                              |
| hgig               | Higig hashing result (only with RTAG7)         |
| vlan               | VLAN of the ingress packet i.e. when available |
| <i>vlan-id</i>     |  |
| src-mac            | Source MAC Address                             |
| <i>src-mac</i>     | Source MAC address                             |
| dst-mac            | Destination MAC Address                        |
| <i>dst-mac</i>     | Destination MAC address                        |
| src-ip             | Source IPv4 address                            |
| <i>src-ip</i>      | Source IP address in format i.i.i.i            |
| dst-ip             | Destination IPv4 address                       |
| <i>dst-ip</i>      | Destination IP address in format i.i.i.i       |
| src-ipv6           | Source IPv6 address                            |
| dst-ipv6           | Destination IPv6 address                       |
| l4-src-port        | Source L4 port                                 |
| <i>l4-src-port</i> | Source L4 port                                 |
| l4-dst-port        | Destination l4 port                            |

|                        |   |
|------------------------|---|
| <i>l4-dst-port</i>     | Destination L4 port                                   |
| ethertype              | Ethertype of the packet stream                        |
| <i>ethertype</i>       |   |
| src-interface          | Optional source interface (physical switch port only) |
| <i>src-if</i>          | Interface name  |
| source-interface       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| <i>if-id</i>           | (Optional) Interface name                             |
| protocol               | Protocol  |
| <i>prot</i>            |   |
| gtp-teid               | gtp-teid  |
| <i>gtp-teid</i>        | gtp-teid  |
| ipv6-flow-label        | ipv6-flow-label                                       |
| <i>ipv6-flow-label</i> | ipv6-flow-label                                       |
| module                 | (Optional) Module #                                   |
| <i>module</i>          | (Optional)  |
| fex                    | (Optional) FEX devices                                |
| <i>fex-range</i>       | (Optional) FEX device range                           |
| hgig-tgid              | (Optional) Hgig #                                     |
| <i>tgid</i>            | (Optional)  |
| <i>__readonly__</i>    | (Optional)  |
| loadbalance-algorithm  | (Optional) load balance algorithm                     |
| <i>algorithm</i>       | (Optional) load balance algorithm                     |
| outgoing-port-id       | (Optional) outgoing port-id                           |
| <i>port</i>            | (Optional) outgoing port-id                           |

### Command Mode

- /exec

## show port-channel load-balance hardware forwarding-path interface source

```
show port-channel load-balance hardware forwarding-path { interface <ch-id> | hgig } { source-interface
<if-id> } { vlan <vlan-id> | src-mac <src-mac> | dst-mac <dst-mac> | src-ip <src-ip> | dst-ip <dst-ip> | src-ipv6
<src-ipv6> | dst-ipv6 <dst-ipv6> | l4-src-port <l4-src-port> | l4-dst-port <l4-dst-port> | ethertype <ethertype>
| protocol <prot> } + [ module <module> | fex <fex-range> | hgig-tgid <tgid> ] [ __readonly__ {
loadbalance-algorithm <algorithm> } { outgoing-port-id <port> } ]
```

### Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                |
| port-channel     | Configure port channel parameters              |
| load-balance     | Show port-channel load balance                 |
| hardware         | ASIC hardware based information                |
| forwarding-path  | Packet forwarding information                  |
| interface        | Specify a port-channel number                  |
| <i>ch-id</i>     | Port-Channel name                              |
| hgig             | Higig hashing result (only with RTAG7)         |
| source-interface | Source interface - Required paramter           |
| <i>if-id</i>     | Interface name                                 |
| vlan             | VLAN of the ingress packet i.e. when available |
| <i>vlan-id</i>   |  |
| src-mac          | Source MAC Address                             |
| <i>src-mac</i>   | Source MAC address                             |
| dst-mac          | Destination MAC Address                        |
| <i>dst-mac</i>   | Destination MAC address                        |
| src-ip           | Source IPv4 address                            |
| <i>src-ip</i>    | Source IP address in format i.i.i.i            |
| dst-ip           | Destination IPv4 address                       |
| <i>dst-ip</i>    | Destination IP address in format i.i.i.i       |
| src-ipv6         | Source IPv6 address                            |
| dst-ipv6         | Destination IPv6 address                       |

|                       |                                   |
|-----------------------|-----------------------------------|
| l4-src-port           | Source L4 port                    |
| <i>l4-src-port</i>    | Source L4 port                    |
| l4-dst-port           | Destination l4 port               |
| <i>l4-dst-port</i>    | Destination L4 port               |
| ethertype             | Ethertype of the packet stream    |
| <i>ethertype</i>      |                                   |
| protocol              | Protocol                          |
| <i>prot</i>           |                                   |
| module                | (Optional) Module #               |
| <i>module</i>         | (Optional)                        |
| fex                   | (Optional) FEX devices            |
| <i>fex-range</i>      | (Optional) FEX device range       |
| hgig-tgid             | (Optional) Hgig #                 |
| <i>tgid</i>           | (Optional)                        |
| __readonly__          | (Optional)                        |
| loadbalance-algorithm | (Optional) load balance algorithm |
| <i>algorithm</i>      | (Optional) load balance algorithm |
| outgoing-port-id      | (Optional) outgoing port-id       |
| <i>port</i>           | (Optional) outgoing port-id       |

**Command Mode**

- /exec

## show port-channel rbh-distribution

```
show port-channel rbh-distribution [ interface <if0> ] [ __readonly__ TABLE_channel <chan-id> <port> {
<rbh> } + <num_of_buckets> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| port-channel          | Show port-channel information               |
| rbh-distribution      | Show RBH distribution for member ports      |
| interface             | (Optional) Specify a port-channel interface |
| <i>if0</i>            | (Optional)                                  |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_channel         | (Optional) Port-channel table               |
| <i>chan-id</i>        | (Optional) Channel ID                       |
| <i>port</i>           | (Optional) Member port                      |
| <i>num_of_buckets</i> | (Optional) Channel ID                       |
| <i>rbh</i>            | (Optional) Channel ID                       |

### Command Mode

- /exec

# show port-channel scale-fanout

show port-channel scale-fanout [ \_\_readonly\_\_ { port-channel high-density <scalefanout> } ]

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information  |
| port-channel       | Configure port channel parameters  |
| scale-fanout       | Enable/disable port-channel scale-fanout when ports span more than 16 ASIC units |
| __readonly__       | (Optional)   |
| high-density       | (Optional) port channel high density   |
| <i>scalefanout</i> | (Optional) port channel scale fanout enable/disable                              |

## Command Mode

- /exec

## show port-channel summary

```
show port-channel [ extended-list ] summary [ interface <if0> | controller ] [ __readonly__ TABLE_channel
<group> <port-channel> <layer> <status> <type> <prtcl> [ { TABLE_member <port> <port-status> } ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| port-channel        | Show port-channel information                       |
| extended-list       | (Optional) Show port-channels from extended range   |
| summary             | Show port-channel summary                           |
| interface           | (Optional) Specify a port-channel                   |
| <i>if0</i>          | (Optional)  |
| controller          | (Optional) Show controller configured port-channels |
| __readonly__        | (Optional)  |
| TABLE_channel       | (Optional) Port-channel table                       |
| <i>group</i>        | (Optional) Channel group number                     |
| <i>port-channel</i> | (Optional) Port channel                             |
| <i>type</i>         | (Optional) Channel type                             |
| <i>prtcl</i>        | (Optional) Channel protocol                         |
| <i>status</i>       | (Optional) Channel status                           |
| <i>layer</i>        | (Optional) Channel layer info                       |
| TABLE_member        | (Optional) Member table                             |
| <i>port</i>         | (Optional) Member port                              |
| <i>port-status</i>  | (Optional) Member port status                       |

### Command Mode

- /exec



# show port-channel traffic

```
show port-channel traffic [ interface <if0> ] [ __readonly__ TABLE_channel <chanId> <port> <rx-ucst>
<tx-ucst> <rx-mcst> <tx-mcst> <rx-bcst> <tx-bcst> ]
```

## Syntax Description

|                |                                      |
|----------------|--------------------------------------|
| show           | Show running system information      |
| port-channel   | Show port-channel information        |
| traffic        | Show port-channel traffic statistics |
| __readonly__   | (Optional)                           |
| interface      | (Optional) Specify a port-channel    |
| <i>if0</i>     | (Optional)                           |
| TABLE_channel  | (Optional) Port-channel table        |
| <i>chanId</i>  | (Optional) Channel ID                |
| <i>port</i>    | (Optional) Member port               |
| <i>rx-ucst</i> | (Optional) Received unicast          |
| <i>tx-ucst</i> | (Optional) Transmitted unicast       |
| <i>rx-mcst</i> | (Optional) Received multicast        |
| <i>tx-mcst</i> | (Optional) Transmitted multicast     |
| <i>rx-bcst</i> | (Optional) Received broadcast        |
| <i>tx-bcst</i> | (Optional) Transmitted broadcast     |

## Command Mode

- /exec

# show port-channel usage

```
show port-channel usage [ __readonly__ <total-channel-number-used> { <used-range-low> [ <used-range-hi>
] } + { <unused-range-low> [ <unused-range-hi> ] } + ]
```

## Syntax Description

|                                  |   |
|----------------------------------|---|
| show                             | Show running system information               |
| port-channel                     | Show port-channel information                 |
| usage                            | Show port-channel number usage                |
| <i>__readonly__</i>              | (Optional)                                    |
| <i>total-channel-number-used</i> | (Optional) Total used number of port-channels |
| <i>used-range-low</i>            | (Optional) Used range low end value           |
| <i>used-range-hi</i>             | (Optional) Used range high end value          |
| <i>unused-range-low</i>          | (Optional) Un-used range low end value        |
| <i>unused-range-hi</i>           | (Optional) Un-used range high end value       |

## Command Mode

- /exec

# show port-license

```
show port-license [ __readonly__ <consumed_port_licenses> [ TABLE_portlicense <interface> <cookie>
<port_activation_license> ] ]
```

## Syntax Description

|                                |                                   |
|--------------------------------|-----------------------------------|
| show                           | Show running system information   |
| port-license                   | Show port license information     |
| <i>__readonly__</i>            | (Optional)                        |
| <i>consumed_port_licenses</i>  | (Optional) Consumed port licenses |
| TABLE_portlicense              | (Optional) port and licenses      |
| <i>interface</i>               | (Optional) interface name         |
| <i>cookie</i>                  | (Optional) cookie                 |
| <i>port_activation_license</i> | (Optional) license state          |

## Command Mode

- /exec

# show port-profile

```
show port-profile [ name <all_profile_name> ] [ __readonly__ TABLE_port_profile_all <profile_name> [
<profile_id> ] <type> [ <desc> ] [ <status> ] [ <max_ports> ] [ <min_ports> ] [ <inherit> ] [ <profile_cfg> ]
+ [ <cmd_depth> ] [ <cmd_key> ] [ <parent_seqno> ] [ <cmd_seqno> ] [ <cmd_attr> ] [ <form_type> ] [
<cmd_mask> ] [ <shadow_cmd> ] [ <cmd_flags> ] [ <eval_cfg> ] + [ <intf> ] + [ <cap_l3> ] [ <cap_iscsi>
] [ <ctrl_sgid> ] [ <pkt_sgid> ] [ <sys_vlans> ] [ <portgrp> ] [ <pprole> ] [ <port_binding> ] ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information          |
| port-profile                  | Show port-profile                        |
| name                          | (Optional) port-profile name             |
| <i>all_profile_name</i>       | (Optional) Enter the name of the profile |
| <i>__readonly__</i>           | (Optional)                               |
| <i>TABLE_port_profile_all</i> | (Optional)                               |
| <i>profile_name</i>           | (Optional)                               |
| <i>profile_id</i>             | (Optional)                               |
| <i>type</i>                   | (Optional)                               |
| <i>desc</i>                   | (Optional)                               |
| <i>status</i>                 | (Optional)                               |
| <i>max_ports</i>              | (Optional)                               |
| <i>min_ports</i>              | (Optional)                               |
| <i>inherit</i>                | (Optional)                               |
| <i>profile_cfg</i>            | (Optional)                               |
| <i>cmd_depth</i>              | (Optional)                               |
| <i>cmd_key</i>                | (Optional)                               |
| <i>parent_seqno</i>           | (Optional)                               |
| <i>cmd_seqno</i>              | (Optional)                               |
| <i>cmd_attr</i>               | (Optional)                               |
| <i>form_type</i>              | (Optional)                               |
| <i>cmd_mask</i>               | (Optional)                               |
| <i>shadow_cmd</i>             | (Optional)                               |

|                     |                                     |
|---------------------|-------------------------------------|
| <i>cmd_flags</i>    | (Optional)                          |
| <i>eval_cfg</i>     | (Optional)                          |
| <i>intf</i>         | (Optional)                          |
| <i>cap_l3</i>       | (Optional) L3 Profile               |
| <i>cap_iscsi</i>    | (Optional) iSCSI cap                |
| <i>ctrl_sgid</i>    | (Optional) Control Vlan Pinned Sgid |
| <i>pkt_sgid</i>     | (Optional) Packet Vlan Pinned Sgid  |
| <i>sys_vlans</i>    | (Optional) System Vlans             |
| <i>portgrp</i>      | (Optional) VMware Portgroup         |
| <i>pprole</i>       | (Optional) Port-profile Role        |
| <i>port_binding</i> | (Optional) Port-binding             |

**Command Mode**

- /exec

## show port-profile brief

```
show port-profile brief [ __readonly__ { TABLE_port_profile [ <profile_name> ] [ <type> ] [ <status> ] [
<profile_cfg_cnt> ] [ <eval_cfg_cnt> ] [ <intf_cnt> ] [ <inherit_cnt> ] [ <header_flag> ] } { TABLE_intf_count
[ <intf_type> ] [ <intf_count> ] [ <tot_header_flag> ] } ]
```

### Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| port-profile           | Show port-profile               |
| brief                  | Brief info about profiles       |
| <i>__readonly__</i>    | (Optional)                      |
| <i>profile_name</i>    | (Optional)                      |
| TABLE_port_profile     | (Optional)                      |
| <i>type</i>            | (Optional)                      |
| <i>status</i>          | (Optional)                      |
| <i>profile_cfg_cnt</i> | (Optional)                      |
| <i>eval_cfg_cnt</i>    | (Optional)                      |
| <i>intf_cnt</i>        | (Optional)                      |
| <i>inherit_cnt</i>     | (Optional)                      |
| <i>header_flag</i>     | (Optional)                      |
| TABLE_intf_count       | (Optional)                      |
| <i>intf_type</i>       | (Optional)                      |
| <i>intf_count</i>      | (Optional)                      |
| <i>tot_header_flag</i> | (Optional)                      |

### Command Mode

- /exec

# show port-profile expand-interface

```
show port-profile expand-interface [ name <all_profile_name> ] [ __readonly__ TABLE_port_profile
<profile_name> [ TABLE_interface <intf> [ <intf_cfg> ] + ] ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information              |
| port-profile            | Show port-profile                            |
| expand-interface        | Active profile config applied in a interface |
| name                    | (Optional) port-profile name                 |
| <i>all_profile_name</i> | (Optional) Enter the name of the profile     |
| <i>__readonly__</i>     | (Optional)                                   |
| TABLE_port_profile      | (Optional)                                   |
| <i>profile_name</i>     | (Optional)                                   |
| TABLE_interface         | (Optional)                                   |
| <i>intf</i>             | (Optional)                                   |
| <i>intf_cfg</i>         | (Optional)                                   |

## Command Mode

- /exec

## show port-profile sync-status

```
show port-profile sync-status [ interface <intfname> ] [ __readonly__ <intf> + [ <inherit> ] <status> + [
<sync_status> ] [ <cached_cmds> ] [ <errors> ] [ <recovery> ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| port-profile        | Show port-profile                         |
| sync-status         | Interfaces out-of-sync with port-profiles |
| interface           | (Optional) Interface name                 |
| <i>intfname</i>     | (Optional) Name of interface              |
| <i>__readonly__</i> | (Optional)                                |
| <i>intf</i>         | (Optional)                                |
| <i>status</i>       | (Optional)                                |
| <i>inherit</i>      | (Optional)                                |
| <i>sync_status</i>  | (Optional)                                |
| <i>cached_cmds</i>  | (Optional)                                |
| <i>errors</i>       | (Optional)                                |
| <i>recovery</i>     | (Optional)                                |

### Command Mode

- /exec



## show port-profile usage

```
show port-profile usage [ name <all_profile_name> ] [ __readonly__ TABLE_port_profile <profile_name>
[ TABLE_interface <interface> ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information          |
| port-profile            | Show port-profile                        |
| usage                   | List of interfaces inherited a profile   |
| name                    | (Optional) port-profile name             |
| <i>all_profile_name</i> | (Optional) Enter the name of the profile |
| <i>__readonly__</i>     | (Optional)                               |
| TABLE_port_profile      | (Optional)                               |
| TABLE_interface         | (Optional)                               |
| <i>profile_name</i>     | (Optional)                               |
| <i>interface</i>        | (Optional)                               |

### Command Mode

- /exec

# show port-security

```
show port-security [ __readonly__ [ <total_addr> ] [ <max_sys_limit> ] [ { TABLE_eth_port_sec_interfaces
<secure_port> <port_state> <max_secure_addr> <security_violation> <security_action> <current_addr>
<num_val> <num_elems> <cmdid_show_index> } ] ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| port-security                 | Show secure port information                           |
| <i>__readonly__</i>           | (Optional)   |
| <i>total_addr</i>             | (Optional) Total number of secured MAC addresses       |
| <i>max_sys_limit</i>          | (Optional) Maximum allowed MACs excluding one per port |
| TABLE_eth_port_sec_interfaces | (Optional) Displays the secured interfaces             |
| <i>secure_port</i>            | (Optional) Interface Index                             |
| <i>port_state</i>             | (Optional) Port security enabled or disabled           |
| <i>max_secure_addr</i>        | (Optional) Maximum number of secured MAC addresses     |
| <i>security_violation</i>     | (Optional) Number of security violations               |
| <i>security_action</i>        | (Optional) Security Action Shutdown/Restrict/Protect   |
| <i>current_addr</i>           | (Optional) Number of secured MAC addresses             |
| <i>num_val</i>                | (Optional) Number of Values                            |
| <i>num_elems</i>              | (Optional) Number of Elements                          |
| <i>cmdid_show_index</i>       | (Optional) Index for the Interfaces                    |

## Command Mode

- /exec

## show port-security address

```
show port-security address [ __readonly__ [ <total_addr> ] [ <max_sys_limit> ] [ {
TABLE_eth_port_sec_mac_addrs <if_index> <vlan_id> <type> <mac_addr> <remain_age> <remote_learnt>
<remote_aged> <num_elems> <cmd_addr_index> } ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| port-security                | Show secure port information                           |
| address                      | Show secure address                                    |
| <i>__readonly__</i>          | (Optional)   |
| <i>total_addr</i>            | (Optional) Total number of secured MAC addresses       |
| <i>max_sys_limit</i>         | (Optional) Maximum allowed MACs excluding one per port |
| TABLE_eth_port_sec_mac_addrs | (Optional) Displays the secured MAC addresses          |
| <i>if_index</i>              | (Optional) Interface index                             |
| <i>vlan_id</i>               | (Optional) vlan id                                     |
| <i>type</i>                  | (Optional) static/sticky/dyanmic MAC address           |
| <i>mac_addr</i>              | (Optional) mac address                                 |
| <i>remain_age</i>            | (Optional) Remaining age                               |
| <i>remote_learnt</i>         | (Optional) Remotely learnt                             |
| <i>remote_aged</i>           | (Optional) Remotely Aged Out                           |
| <i>num_elems</i>             | (Optional) Number of Elements                          |
| <i>cmd_addr_index</i>        | (Optional) Index for the interface address             |

### Command Mode

- /exec

## show port-security address interface

```
show port-security address interface <interface-id> [ __readonly__ { TABLE_eth_port_sec_mac_addr
<if_index> <vlan_id> <type> <mac_addr> <remain_age> <remote_learnt> <remote_aged> <num_elems>
<cmd_addr_index> } [ <total_addr> ] [ <max_sys_limit> ] [ <first> ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| port-security               | Show secure port information                           |
| address                     | Show secure address                                    |
| interface                   | Show secure interface                                  |
| <i>interface-id</i>         | ethernet   |
| <i>__readonly__</i>         | (Optional)   |
| TABLE_eth_port_sec_mac_addr | (Optional) Displays the secured MAC addresses          |
| <i>if_index</i>             | (Optional) Interface index                             |
| <i>vlan_id</i>              | (Optional) vlan id                                     |
| <i>type</i>                 | (Optional) static/sticky/dyanmic MAC address           |
| <i>mac_addr</i>             | (Optional) mac address                                 |
| <i>remain_age</i>           | (Optional) Remaining age                               |
| <i>remote_learnt</i>        | (Optional) Remotely learnt                             |
| <i>remote_aged</i>          | (Optional) Remotely Aged Out                           |
| <i>num_elems</i>            | (Optional) Number of Elements                          |
| <i>cmd_addr_index</i>       | (Optional) Index for the interface address             |
| <i>total_addr</i>           | (Optional) Total number of secured MAC addresses       |
| <i>max_sys_limit</i>        | (Optional) Maximum allowed MACs excluding one per port |
| <i>first</i>                | (Optional) To identify the first entry                 |

### Command Mode

- /exec

## show port-security interface

```
show port-security interface <interface-id> [ __readonly__ <port_status> <config_port_security>
<oper_port_security> <violation_mode> <aging_time> <aging_type> <max_mac_addr> <total_sec_addrs>
<conf_num_addrs> <num_sticky_addrs> <trap_count> ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| <code>port-security</code>  | Show secure port information                               |
| <code>interface</code>      | Show secure interface                                      |
| <i>interface-id</i>         | ethernet   |
| <code>__readonly__</code>   | (Optional)   |
| <i>port_status</i>          | (Optional) Secure Up/Down                                  |
| <i>config_port_security</i> | (Optional) Port Security configuration is Enabled/Disabled |
| <i>oper_port_security</i>   | (Optional) Port Security is Operationally Enabled/Disabled |
| <i>violation_mode</i>       | (Optional) Shutdown/Restrict/Protect                       |
| <i>aging_time</i>           | (Optional) Aging time in minutes                           |
| <i>aging_type</i>           | (Optional) Absolute/Inactivity                             |
| <i>max_mac_addr</i>         | (Optional) Configured Maximum                              |
| <i>total_sec_addrs</i>      | (Optional) Total number of secured MAC addresses           |
| <i>conf_num_addrs</i>       | (Optional) Number of configured MAC addresses              |
| <i>num_sticky_addrs</i>     | (Optional) Number of sticky MAC addresses                  |
| <i>trap_count</i>           | (Optional) Trap Count                                      |

### Command Mode

- /exec

# show port-security state

show port-security state [ \_\_readonly\_\_ <status> ]

## Syntax Description

|               |                               |
|---------------|-------------------------------|
| port-security | Port security related command |
| state         | port security state           |
| __readonly__  | (Optional)                    |
| <i>status</i> | (Optional) show port-security |

## Command Mode

- /exec

# show port led-status module

show port <port\_num> led-status module <module>

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| port            | port                            |
| <i>port_num</i> | port number                     |
| led-status      | led-status of the port          |
| module          | module                          |
| <i>module</i>   | module number                   |

## Command Mode

- /exec

# show port naming

show port naming

## Syntax Description

|        |                                 |
|--------|---------------------------------|
| show   | Show running system information |
| port   | Show port information           |
| naming | Show port naming information    |

## Command Mode

- /exec



# show postcard-telemetry exporter

```
show postcard-telemetry exporter [ name ] [ <exportername> ] [ __readonly__ <exporter> <description>
<dest> <vrf> <vrf_id> <vrf_resolved> <dest_udp> <source_intf> <source_ip> <seq_num> ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information              |
| postcard-telemetry  | Show POSTCARD information                    |
| exporter            | Show POSTCARD Exporter Configuration         |
| name                | (Optional) Show a specific POSTCARD Exporter |
| <i>exportername</i> | (Optional) Specify an exporter               |
| <i>__readonly__</i> | (Optional)                                   |
| <i>exporter</i>     | (Optional)                                   |
| <i>description</i>  | (Optional)                                   |
| <i>dest</i>         | (Optional)                                   |
| <i>vrf</i>          | (Optional)                                   |
| <i>vrf_id</i>       | (Optional)                                   |
| <i>vrf_resolved</i> | (Optional)                                   |
| <i>dest_udp</i>     | (Optional)                                   |
| <i>source_intf</i>  | (Optional)                                   |
| <i>source_ip</i>    | (Optional)                                   |
| <i>seq_num</i>      | (Optional)                                   |

## Command Mode

- /exec

# show postcard-telemetry flow-profile

```
show postcard-telemetry flow-profile [ name ] [ <flow-profilename> ] [ __readonly__ <flow-profile>
<description> <age> <latency> ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                  |
| postcard-telemetry      | Show POSTCARD information                        |
| flow-profile            | Show POSTCARD flow Profile Configuration         |
| name                    | (Optional) Show a specific POSTCARD flow Profile |
| <i>flow-profilename</i> | (Optional) Specify an flow Profile               |
| <i>__readonly__</i>     | (Optional)                                       |
| <i>flow-profile</i>     | (Optional)                                       |
| <i>description</i>      | (Optional)                                       |
| <i>age</i>              | (Optional)                                       |
| <i>latency</i>          | (Optional)                                       |

## Command Mode

- /exec

# show postcard-telemetry monitor

```
show postcard-telemetry monitor [ name ] [ <monitorname> [ cache [ detailed ] ] ] [ __readonly__ <monitor>
<use_count> <description> <event> <exporter> <bucket_id> <src_addr> <dest_addr> <watchlist> ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information             |
| postcard-telemetry  | Show POSTCARD information                   |
| monitor             | Show Monitor Configuration                  |
| name                | (Optional) Show a specific POSTCARD Monitor |
| <i>monitorname</i>  | (Optional) Specify a monitor                |
| cache               | (Optional) Flow monitor cache contents      |
| detailed            | (Optional) Show the entire cache contents   |
| <i>__readonly__</i> | (Optional)                                  |
| <i>monitor</i>      | (Optional)                                  |
| <i>use_count</i>    | (Optional)                                  |
| <i>description</i>  | (Optional)                                  |
| <i>event</i>        | (Optional)                                  |
| <i>exporter</i>     | (Optional)                                  |
| <i>bucket_id</i>    | (Optional)                                  |
| <i>src_addr</i>     | (Optional)                                  |
| <i>dest_addr</i>    | (Optional)                                  |
| <i>watchlist</i>    | (Optional)                                  |

## Command Mode

- /exec

# show postcard-telemetry queue-profile

```
show postcard-telemetry queue-profile [ name ] [ <queue-profilename> ] [ __readonly__ <queue-profile>
<description> <depth> <latency> ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                   |
| postcard-telemetry       | Show POSTCARD information                         |
| queue-profile            | Show POSTCARD Queue Profile Configuration         |
| name                     | (Optional) Show a specific POSTCARD Queue Profile |
| <i>queue-profilename</i> | (Optional) Specify an Queue Profile               |
| <i>__readonly__</i>      | (Optional)  |
| <i>queue-profile</i>     | (Optional)  |
| <i>description</i>       | (Optional)  |
| <i>depth</i>             | (Optional)  |
| <i>latency</i>           | (Optional)  |

## Command Mode

- /exec

# show postcard-telemetry sessions

show postcard-telemetry sessions [ <monitorname> ] [ \_\_readonly\_\_ <monitor> ]

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| postcard-telemetry  | Show POSTCARD information       |
| sessions            | Show Session Configuration      |
| <i>monitorname</i>  | (Optional) Specify a monitor    |
| <i>__readonly__</i> | (Optional)                      |
| <i>monitor</i>      | (Optional)                      |

## Command Mode

- /exec

## show postcard-telemetry watchlist

```
show postcard-telemetry watchlist [ name ] [ { <watchlistname> } ] [ __readonly__ <watchlist> <use_count>
<description> <num_aces> <ace_seq_num> <ace_action> <ace_type> <ace_sip> <ace_sip_len> <ace_dip>
<ace_dip_len> ]
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                                  |
| postcard-telemetry   | Show POSTCARD information  |
| watchlist            | Show watchlist Configuration                                     |
| name                 | (Optional) Show the configuration for a specific POSTCARD Record |
| <i>watchlistname</i> | (Optional) Specify a watchlist                                   |
| <i>__readonly__</i>  | (Optional)   |
| <i>watchlist</i>     | (Optional)   |
| <i>use_count</i>     | (Optional)   |
| <i>description</i>   | (Optional)   |
| <i>num_aces</i>      | (Optional)   |
| <i>ace_seq_num</i>   | (Optional)   |
| <i>ace_action</i>    | (Optional)   |
| <i>ace_type</i>      | (Optional)   |
| <i>ace_sip</i>       | (Optional)   |
| <i>ace_sip_len</i>   | (Optional)   |
| <i>ace_dip</i>       | (Optional)   |
| <i>ace_dip_len</i>   | (Optional)   |

### Command Mode

- /exec

# show power inline

```
show power inline <if0> [ __readonly__ { TABLE_intf_info <intf_name> <admin> <oper> <supp_pwr>
<del_pwr> <device> <class> <max> } ]
```

## Syntax Description

|                     |                                  |
|---------------------|----------------------------------|
| show                | Show running system information  |
| power               | Power over Ethernet              |
| <i>if0</i>          |                                  |
| <i>__readonly__</i> | (Optional)                       |
| TABLE_intf_info     | (Optional) Interface information |
| <i>intf_name</i>    | (Optional) Interface name        |
| <i>admin</i>        | (Optional) Port mode             |
| <i>oper</i>         | (Optional) Oper mode             |
| <i>supp_pwr</i>     | (Optional) Supplied power        |
| <i>del_pwr</i>      | (Optional) delivered power       |
| <i>device</i>       | (Optional) Device information    |
| <i>class</i>        | (Optional) POE Class             |
| <i>max</i>          | (Optional) Max power             |

## Command Mode

- /exec

# show power inline

```
show power inline [ __readonly__ { TABLE_fex_info <module_id> <avail_pwr> <used_pwr> <rem_pwr>
} { TABLE_intf_info <intf_name> <admin> <oper> <supp_pwr> <del_pwr> <device> <class> <max> } ]
```

## Syntax Description

|                  |                                  |
|------------------|----------------------------------|
| show             | Show running system information  |
| power            | Power over Ethernet              |
| __readonly__     | (Optional)                       |
| TABLE_fex_info   | (Optional) FEX information       |
| <i>module_id</i> | (Optional) FEX id                |
| <i>avail_pwr</i> | (Optional) Available power       |
| <i>used_pwr</i>  | (Optional) Used power            |
| <i>rem_pwr</i>   | (Optional) Free power            |
| TABLE_intf_info  | (Optional) Interface information |
| <i>intf_name</i> | (Optional) Interface name        |
| <i>admin</i>     | (Optional) Port mode             |
| <i>oper</i>      | (Optional) Oper mode             |
| <i>supp_pwr</i>  | (Optional) Supplied power        |
| <i>del_pwr</i>   | (Optional) delivered power       |
| <i>device</i>    | (Optional) Device information    |
| <i>class</i>     | (Optional) POE Class             |
| <i>max</i>       | (Optional) Max power             |

## Command Mode

- /exec



# show power inline detail

```
show power inline <inf> detail [ __readonly__ { TABLE_intf_detail <intf> <power_mode> <oper_status>
<device_det> <dev_type> <ieee_class> <disc_mech> <police_action> <interface_pri> <power_admin_value>
<power_drawn_src> <power_avail_dev> <consump_at_port> <power_drawn_dev> <absent_count>
<over_curr_count> <short_curr_count> <inv_sign_count> <power_denied_count> <four_pair_support>
<spare_pair_support> } ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                               |
| power                    | Power over Ethernet   |
| <i>inf</i>               |   |
| detail                   | PoE details   |
| __readonly__             | (Optional)  |
| TABLE_intf_detail        | (Optional) Interface Details                                  |
| <i>intf</i>              | (Optional) Interface  |
| <i>power_mode</i>        | (Optional) Inline Power Mode                                  |
| <i>oper_status</i>       | (Optional) Operational status                                 |
| <i>device_det</i>        | (Optional) Device Detected status                             |
| <i>dev_type</i>          | (Optional) Device Type  |
| <i>ieee_class</i>        | (Optional) IEEE Class   |
| <i>disc_mech</i>         | (Optional) Discovery mechanism used/configured                |
| <i>police_action</i>     | (Optional) Policer action                                     |
| <i>interface_pri</i>     | (Optional) Interface Priority                                 |
| <i>power_admin_value</i> | (Optional) Admin value  |
| <i>power_drawn_src</i>   | (Optional) Power drawn from the source                        |
| <i>power_avail_dev</i>   | (Optional) Power available to the device                      |
| <i>consump_at_port</i>   | (Optional) Measured at the port                               |
| <i>power_drawn_dev</i>   | (Optional) Maximum Power drawn by the device since powered on |
| <i>absent_count</i>      | (Optional) Absent Counter                                     |
| <i>over_curr_count</i>   | (Optional) Over Current Counter                               |
| <i>short_curr_count</i>  | (Optional) Short Current Counter                              |

|                           |                                      |
|---------------------------|--------------------------------------|
| <i>inv_sign_count</i>     | (Optional) Invalid Signature Counter |
| <i>power_denied_count</i> | (Optional) Power Denied Counter      |
| <i>four_pair_support</i>  | (Optional) Four-Pair PoE Supported   |
| <i>spare_pair_support</i> | (Optional) Spare Pair Power Enabled  |

**Command Mode**

- /exec

# show power inline police

```
show power inline police [ __readonly__ { TABLE_police <intf_name> <admin> <oper> <admin_police>
<oper_police> <cutoff_pwr> <oper_pwr> } ]
```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| power               | Power over Ethernet                |
| police              | Show per-port policing             |
| <i>__readonly__</i> | (Optional)                         |
| <i>TABLE_police</i> | (Optional) Police information      |
| <i>intf_name</i>    | (Optional) Interface name          |
| <i>admin</i>        | (Optional) Port mode               |
| <i>oper</i>         | (Optional) Oper mode               |
| <i>admin_police</i> | (Optional) Configured admin police |
| <i>oper_police</i>  | (Optional) Current police          |
| <i>cutoff_pwr</i>   | (Optional) Cutoff power            |
| <i>oper_pwr</i>     | (Optional) Oper power              |

## Command Mode

- /exec

# show power inline priority

show power inline priority [ *\_\_readonly\_\_* { *TABLE\_priority* <intf\_name> <admin> <oper> <priority> } ]

## Syntax Description

|                       |                                      |
|-----------------------|--------------------------------------|
| show                  | Show running system information      |
| power                 | Power over Ethernet                  |
| priority              | Show per-port priority               |
| <i>__readonly__</i>   | (Optional)                           |
| <i>TABLE_priority</i> | (Optional) Port priority information |
| <i>intf_name</i>      | (Optional) Interface name            |
| <i>admin</i>          | (Optional) Port mode                 |
| <i>oper</i>           | (Optional) Oper mode                 |
| <i>priority</i>       | (Optional) port priority             |

## Command Mode

- /exec

# show processes

```
show processes [ __readonly__ { [ TABLE_processes <pid> <state> <pc> <start_cnt> <tty> <p_type>
<process> ] } ]
```

## Syntax Description

|                  |                                    |
|------------------|------------------------------------|
| show             | Show running system information    |
| processes        | Show processes                     |
| __readonly__     | (Optional)                         |
| TABLE_processes  | (Optional) all process information |
| <i>pid</i>       | (Optional) process id              |
| <i>state</i>     | (Optional) process state           |
| <i>pc</i>        | (Optional) pc register             |
| <i>start_cnt</i> | (Optional) TBD                     |
| <i>tty</i>       | (Optional) TBD                     |
| <i>p_type</i>    | (Optional) process type            |
| <i>process</i>   | (Optional) process name            |

## Command Mode

- /exec

## show processes cpu

```
show processes cpu [ sort ] [ __readonly__ { [ TABLE_process_cpu <pid> <runtime> <invoked> <usecs>
<onesech> <process> ] [ <user_percent> ] [ <kernel_percent> ] [ <idle_percent> ] [ <fivesec_percent> ] [
<fivesec_intr_percent> ] [ <onemin_percent> ] [ <fivemin_percent> ] } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information  |
| processes                   | Show processes   |
| cpu                         | Show processes CPU Info  |
| sort                        | (Optional) Show processes CPU Info (Sorted by Cpu Util with time base) |
| __readonly__                | (Optional)   |
| TABLE_process_cpu           | (Optional) all process memory  |
| <i>pid</i>                  | (Optional) process id  |
| <i>runtime</i>              | (Optional) Runtime   |
| <i>invoked</i>              | (Optional) Invoked   |
| <i>usecs</i>                | (Optional) usecs   |
| <i>onesech</i>              | (Optional) fivesec   |
| <i>process</i>              | (Optional) name of the process   |
| <i>user_percent</i>         | (Optional) user  |
| <i>kernel_percent</i>       | (Optional) kernel  |
| <i>idle_percent</i>         | (Optional) idle  |
| <i>fivesec_percent</i>      | (Optional) five seconds cpu percent                                    |
| <i>fivesec_intr_percent</i> | (Optional) five seconds interrupt percent                              |
| <i>onemin_percent</i>       | (Optional) one minute cpu percent                                      |
| <i>fivemin_percent</i>      | (Optional) five minute cpu percent                                     |

### Command Mode

- /exec

# show processes cpu history

show processes cpu history

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| processes | Show processes                  |
| cpu       | Show processes CPU Info         |
| history   | Show processes CPU Util History |

## Command Mode

- /exec

## show processes cpu history data

show processes cpu history data [ *\_\_readonly\_\_* { [ *TABLE\_processes\_cpu\_history* <*cpu\_avg\_sec*> ] } ]

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                |
| processes                          | Show processes                                 |
| cpu                                | Show processes CPU Info                        |
| history                            | Show processes CPU Util History                |
| data                               | Display the CPU util as data, instead of graph |
| <i>__readonly__</i>                | (Optional)                                     |
| <i>TABLE_processes_cpu_history</i> | (Optional) 60 sec cpu history                  |
| <i>cpu_avg_sec</i>                 | (Optional) cpu avg for a sec                   |

### Command Mode

- /exec



## show processes cpu module

```
show processes cpu module <i0> [ __readonly__ { [ TABLE_process_cpu <pid> <runtime> <invoked>
<usecs> <oneseq> <process> ] [ <user_percent> ] [ <kernel_percent> ] [ <idle_percent> ] [ <fivesec_percent>
] [ <fivesec_intr_percent> ] [ <onemin_percent> ] [ <fivemin_percent> ] } ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information           |
| processes                   | Show processes                            |
| cpu                         | Show processes CPU Info                   |
| module                      | processes CPU Info                        |
| <i>i0</i>                   | module number                             |
| <i>__readonly__</i>         | (Optional)                                |
| <i>TABLE_process_cpu</i>    | (Optional) all process memory             |
| <i>pid</i>                  | (Optional) process id                     |
| <i>runtime</i>              | (Optional) Runtime                        |
| <i>invoked</i>              | (Optional) Invoked                        |
| <i>usecs</i>                | (Optional) usecs                          |
| <i>oneseq</i>               | (Optional) oneseq                         |
| <i>process</i>              | (Optional) name of the process            |
| <i>user_percent</i>         | (Optional) user                           |
| <i>kernel_percent</i>       | (Optional) kernel                         |
| <i>idle_percent</i>         | (Optional) idle                           |
| <i>fivesec_percent</i>      | (Optional) five seconds cpu percent       |
| <i>fivesec_intr_percent</i> | (Optional) five seconds interrupt percent |
| <i>onemin_percent</i>       | (Optional) one minute cpu percent         |
| <i>fivemin_percent</i>      | (Optional) five minute cpu percent        |

### Command Mode

- /exec

# show processes log

```
show processes log [ __readonly__ { [ TABLE_processes_log <vdc> <process> <pid> <normal_exit> <stack>
<core> <create_time> ] } ]
```

## Syntax Description

|                     |                                     |
|---------------------|-------------------------------------|
| show                | Show running system information     |
| processes           | Show processes                      |
| log                 | Show information about process logs |
| <i>__readonly__</i> | (Optional)                          |
| TABLE_processes_log | (Optional) all processes log        |
| <i>vdc</i>          | (Optional) vdc                      |
| <i>process</i>      | (Optional) vdc process name         |
| <i>pid</i>          | (Optional) pid                      |
| <i>normal_exit</i>  | (Optional) process exit             |
| <i>stack</i>        | (Optional) stack                    |
| <i>core</i>         | (Optional) core                     |
| <i>create_time</i>  | (Optional) log create time          |

## Command Mode

- /exec

# show processes log details

```
show processes log details [ __readonly__ { line_in_log_detail <line_in_file> } ]
```

## Syntax Description

|                           |                                     |
|---------------------------|-------------------------------------|
| show                      | Show running system information     |
| processes                 | Show processes                      |
| log                       | Show information about process logs |
| details                   | Show detail of all logs with stack  |
| <i>__readonly__</i>       | (Optional)                          |
| <i>line_in_log_detail</i> | (Optional)                          |
| <i>line_in_file</i>       | (Optional) each line                |

## Command Mode

- /exec

# show processes log pid

```
show processes log pid <i0> [ __readonly__ { TABLE_line_in_log_pid <line_in_file> } ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information               |
| processes                    | Show processes                                |
| log                          | Show information about process logs           |
| pid                          | Show detail log info about a specific process |
| <i>i0</i>                    | pid of the process                            |
| <i>__readonly__</i>          | (Optional)                                    |
| <i>TABLE_line_in_log_pid</i> | (Optional)                                    |
| <i>line_in_file</i>          | (Optional) each line                          |

## Command Mode

- /exec

## show processes log vdc-all

```
show processes log vdc-all [ __readonly__ { [ TABLE_processes_log_vdc_all <vdc> <process> <pid>
<normal_exit> <stack> <core> <create_time> ] } ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| TABLE_processes_log_vdc_all | (Optional) all processes log vdc all             |
| show                        | Show running system information                  |
| processes                   | Show processes                                   |
| log                         | Show information about process logs              |
| vdc-all                     | Show information about process logs in all vdc's |
| __readonly__                | (Optional)                                       |
| vdc                         | (Optional) vdc process name                      |
| process                     | (Optional) vdc process name                      |
| pid                         | (Optional) process id                            |
| normal_exit                 | (Optional) process exit                          |
| stack                       | (Optional) stack                                 |
| core                        | (Optional) core                                  |
| create_time                 | (Optional) log create time                       |

### Command Mode

- /exec

# show processes memory

```
show processes memory [ __readonly__ { TABLE_process_memory <mem_pid> <mem_alloc> <mem_limit>
<mem_used> <stack_base_ptr> <process> } ]
```

## Syntax Description

|                       |                                   |
|-----------------------|-----------------------------------|
| show                  | Show running system information   |
| processes             | Show processes                    |
| memory                | Show processes Memory Info        |
| <i>__readonly__</i>   | (Optional)                        |
| TABLE_process_memory  | (Optional) all process memory     |
| <i>mem_pid</i>        | (Optional) process id             |
| <i>mem_alloc</i>      | (Optional) allocated memory       |
| <i>mem_limit</i>      | (Optional) memory limit           |
| <i>mem_used</i>       | (Optional) memory used            |
| <i>stack_base_ptr</i> | (Optional) stack and base pointer |
| <i>process</i>        | (Optional) name of the process    |

## Command Mode

- /exec

# show processes memory physical

```
show processes memory physical [ __readonly__ { TABLE_process_physical_memory <processid> <virtual>
<physical> <rss> <processname> } ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information        |
| processes                     | Show processes                         |
| memory                        | Show processes Memory Info             |
| physical                      | Show processes physical Memory         |
| __readonly__                  | (Optional)                             |
| TABLE_process_physical_memory | (Optional) all process physical memory |
| <i>processid</i>              | (Optional) process id                  |
| <i>virtual</i>                | (Optional) virtual allocated memory    |
| <i>physical</i>               | (Optional) physical memory used        |
| <i>rss</i>                    | (Optional) rss memory                  |
| <i>processname</i>            | (Optional) name of the process         |

## Command Mode

- /exec

## show processes memory shared

```
show processes memory shared [ detail | dynamic ] [ __readonly__ TABLE_process_tag [ <process-tag-out>
] [ <process-memory-share-dynamic-component-str> ] [ <process-memory-share-dynamic-shared-memory-str>
] [ <process-memory-share-dynamic-current-size-str> ] [ <process-memory-share-dynamic-max-size-str> ]
] [ <process-memory-share-dynamic-used-str> ] [ <process-memory-share-component-str> ] [
<process-memory-share-shared-memory-str> ] [ <process-memory-share-size-str> ] [
<process-memory-share-used-str> ] [ <process-memory-share-available-str> ] [ <process-memory-share-ref-str>
] [ <process-memory-share-byte-set-address-str> ] [ <process-memory-share-byte-set-count-str> ] [
<process-memory-share-address-str> ] [ <process-memory-share-kbytes-1-str> ] [
<process-memory-share-kbytes-2-str> ] [ <process-memory-share-kbytes-3-str> ] [
<process-memory-share-count-str> ] [ { TABLE_SMMITEM <process-memory-share-smr-name> } ] [ {
TABLE_SHOWPROC <process-memory-share-table-showproc-key> [ { TABLE_SHOWONEDYNAMIC
[ <process-memory-share-component> ] [ <process-memory-share-shared-memory> ] [
<process-memory-share-current-size> ] [ <process-memory-share-max-size> ] [ <process-memory-share-used>
] ] ] [ { TABLE_ONEITEM [ <process-memory-share-proc-smr-name> ] [ <process-memory-share-smr-addr>
] [ <process-memory-share-smr-size> ] [ <process-memory-share-smr-star-char> ] [
<process-memory-share-smr-empty-char> ] [ <process-memory-share-smr-used> ] [
<process-memory-share-smr-avail> ] [ <process-memory-share-smr-ref-count> ] [
<process-memory-share-dynamic-smr-name> } ] ] [ { TABLE_ONEITEMDYNAMIC [
<process-memory-share-dynamic-smr-addr> ] [ <process-memory-share-dynamic-smr-size> ] [
<process-memory-share-dynamic-plus-char> ] [ <process-memory-share-max-mem-size-str> ] [
<process-memory-share-dynamic-smr-used> ] [ <process-memory-share-dynamic-smr-avail> ] [
<process-memory-share-dynamic-smr-ref-count> ] [ <process-memory-share-region-smr-name> } ] ] ] [
<process-memory-share-total-shm-size> ] [ <process-memory-share-total-shm-used> ] [
<process-memory-share-total-shm-avail> ] ] ]
```

### Syntax Description

|   |   |
|---|---|
| show  | Show running system information                                     |
| processes   | Display process information   |
| memory  | Display memory information  |
| shared  | Display shared memory info  |
| detail  | (Optional) Display shared memory in bytes instead of default kbytes |
| dynamic   | (Optional) Display details of dynamic shared memory segments        |
| __readonly__  | (Optional)  |
| TABLE_process_tag                                     | (Optional)  |
| <i>process-tag-out</i>                                | (Optional)  |
| <i>process-memory-share-dynamic-component-str</i>     | (Optional)  |
| <i>process-memory-share-dynamic-shared-memory-str</i> | (Optional)  |
| <i>process-memory-share-dynamic-current-size-str</i>  | (Optional)  |



|  |            |
|--|------------|
| <i>process-memory-share-dynamic-max-size-str</i> | (Optional) |
| <i>process-memory-share-dynamic-used-str</i>     | (Optional) |
| <i>process-memory-share-component-str</i>        | (Optional) |
| <i>process-memory-share-shared-memory-str</i>    | (Optional) |
| <i>process-memory-share-size-str</i>             | (Optional) |
| <i>process-memory-share-used-str</i>             | (Optional) |
| <i>process-memory-share-available-str</i>        | (Optional) |
| <i>process-memory-share-ref-str</i>              | (Optional) |
| <i>process-memory-share-byte-set-address-str</i> | (Optional) |
| <i>process-memory-share-byte-set-count-str</i>   | (Optional) |
| <i>process-memory-share-address-str</i>          | (Optional) |
| <i>process-memory-share-kbytes-1-str</i>         | (Optional) |
| <i>process-memory-share-kbytes-2-str</i>         | (Optional) |
| <i>process-memory-share-kbytes-3-str</i>         | (Optional) |
| <i>process-memory-share-count-str</i>            | (Optional) |
| TABLE_SMMITEM                                    | (Optional) |
| <i>process-memory-share-smr-name</i>             | (Optional) |
| TABLE_SHOWPROC                                   | (Optional) |
| <i>process-memory-share-table-showproc-key</i>   | (Optional) |
| TABLE_SHOWONEDYNAMIC                             | (Optional) |
| <i>process-memory-share-component</i>            | (Optional) |
| <i>process-memory-share-shared-memory</i>        | (Optional) |
| <i>process-memory-share-current-size</i>         | (Optional) |
| <i>process-memory-share-max-size</i>             | (Optional) |
| <i>process-memory-share-used</i>                 | (Optional) |
| TABLE_ONEITEM                                    | (Optional) |
| <i>process-memory-share-proc-smr-name</i>        | (Optional) |
| <i>process-memory-share-smr-addr</i>             | (Optional) |
| <i>process-memory-share-smr-size</i>             | (Optional) |

|   |            |
|---|------------|
| <i>process-memory-share-smr-star-char</i>         | (Optional) |
| <i>process-memory-share-smr-empty-char</i>        | (Optional) |
| <i>process-memory-share-smr-used</i>              | (Optional) |
| <i>process-memory-share-smr-avail</i>             | (Optional) |
| <i>process-memory-share-smr-ref-count</i>         | (Optional) |
| TABLE_ONEITEMDYNAMIC                              | (Optional) |
| <i>process-memory-share-dynamic-smr-name</i>      | (Optional) |
| <i>process-memory-share-dynamic-smr-addr</i>      | (Optional) |
| <i>process-memory-share-dynamic-smr-size</i>      | (Optional) |
| <i>process-memory-share-dynamic-plus-char</i>     | (Optional) |
| <i>process-memory-share-max-mem-size-str</i>      | (Optional) |
| <i>process-memory-share-dynamic-smr-used</i>      | (Optional) |
| <i>process-memory-share-dynamic-smr-avail</i>     | (Optional) |
| <i>process-memory-share-dynamic-smr-ref-count</i> | (Optional) |
| <i>process-memory-share-region-smr-name</i>       | (Optional) |
| <i>process-memory-share-total-shm-size</i>        | (Optional) |
| <i>process-memory-share-total-shm-used</i>        | (Optional) |
| <i>process-memory-share-total-shm-avail</i>       | (Optional) |

**Command Mode**

- /exec

# show processes vdc

```
show processes vdc <e-vdc2> [ __readonly__ { TABLE_processes_vdc <pid> <state> <pc> <start_cnt> <tty>
<p_type> <process> } ]
```

## Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| processes                  | Show processes                        |
| vdc                        | Show processes in vdc                 |
| <i>e-vdc2</i>              | Enter Virtual Device Context <vdc-id> |
| <i>__readonly__</i>        | (Optional) Read only                  |
| <i>TABLE_processes_vdc</i> | (Optional) All process information    |
| <i>pid</i>                 | (Optional) PID of process             |
| <i>state</i>               | (Optional) State of process           |
| <i>pc</i>                  | (Optional) PC in which process exists |
| <i>start_cnt</i>           | (Optional) TBD                        |
| <i>tty</i>                 | (Optional) TBD                        |
| <i>p_type</i>              | (Optional) Type of Process            |
| <i>process</i>             | (Optional) Process Name               |

## Command Mode

- /exec

## show processes vdc cpu

```
show processes vdc <e-vdc2> cpu [ __readonly__ [ TABLE_process_vdc_cpu <pid> <runtime> <invoked>
<usecs> <oneseq> <process> ] [ <user_percent> ] [ <kernel_percent> ] [ <idle_percent> ] [ <fivesec_percent>
] [ <fivesec_intr_percent> ] [ <onemin_percent> ] [ <fivemin_percent> ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information           |
| processes                    | Show processes                            |
| vdc                          | Show processes in vdc                     |
| <i>e-vdc2</i>                | Enter Virtual Device Context <vdc-id>     |
| cpu                          | Show processes CPU Info                   |
| <i>__readonly__</i>          | (Optional) Readonly table for cpu log     |
| <i>TABLE_process_vdc_cpu</i> | (Optional) All cpu process logs of vdc    |
| <i>pid</i>                   | (Optional) PID of process                 |
| <i>runtime</i>               | (Optional) Runtime                        |
| <i>invoked</i>               | (Optional) Invoked                        |
| <i>usecs</i>                 | (Optional) uSecs                          |
| <i>oneseq</i>                | (Optional) fivesec                        |
| <i>process</i>               | (Optional) Name of process                |
| <i>user_percent</i>          | (Optional) user                           |
| <i>kernel_percent</i>        | (Optional) kernel                         |
| <i>idle_percent</i>          | (Optional) idle                           |
| <i>fivesec_percent</i>       | (Optional) five seconds cpu percent       |
| <i>fivesec_intr_percent</i>  | (Optional) five seconds interrupt percent |
| <i>onemin_percent</i>        | (Optional) one minute cpu percent         |
| <i>fivemin_percent</i>       | (Optional) five minute cpu percent        |

### Command Mode

- /exec

## show processes vdc log

```
show processes vdc <e-vdc2> log [ __readonly__ { [ TABLE_processes_vdc_log <vdc> <process> <pid>
<normal_exit> <stack> <core> <create_time> ] } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information               |
| processes                      | Show processes                                |
| vdc                            | Show processes in vdc                         |
| <i>e-vdc2</i>                  | Enter Virtual Device Context <vdc-id>         |
| log                            | Show information about process logs           |
| <i>__readonly__</i>            | (Optional) Read only table                    |
| <i>TABLE_processes_vdc_log</i> | (Optional) Table for log of all VDC Processes |
| <i>pid</i>                     | (Optional) PID of process                     |
| <i>vdc</i>                     | (Optional) VDC Number                         |
| <i>process</i>                 | (Optional) Process name                       |
| <i>normal_exit</i>             | (Optional) Normal Exit status                 |
| <i>stack</i>                   | (Optional) Stack                              |
| <i>core</i>                    | (Optional) Core                               |
| <i>create_time</i>             | (Optional) Time stamp of log                  |

### Command Mode

- /exec

# show processes vdc log details

show processes vdc <e-vdc2> log details

## Syntax Description

|               |                                       |
|---------------|---------------------------------------|
| show          | Show running system information       |
| processes     | Show processes                        |
| vdc           | Show processes in vdc                 |
| <i>e-vdc2</i> | Enter Virtual Device Context <vdc-id> |
| log           | Show information about process logs   |
| details       | Show detail of all logs with stack    |

## Command Mode

- /exec

# show processes vdc log pid

show processes vdc <e-vdc2> log pid <i1>

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information               |
| processes     | Show processes                                |
| vdc           | Show processes in vdc                         |
| <i>e-vdc2</i> | Enter Virtual Device Context <vdc-id>         |
| log           | Show information about process logs           |
| pid           | Show detail log info about a specific process |
| <i>i1</i>     | pid of the process                            |

## Command Mode

- /exec

## show processes vdc memory

```
show processes vdc <e-vdc2> memory [ __readonly__ { [ TABLE_process_memory <mem_pid> <mem_alloc>
<mem_limit> <mem_used> <stack_base_ptr> <process> ] [ <sum_mem_malloced> ] } ]
```

### Syntax Description

|                       |                                       |
|-----------------------|---------------------------------------|
| show                  | Show running system information       |
| processes             | Show processes                        |
| vdc                   | Show processes in vdc                 |
| <i>e-vdc2</i>         | Enter Virtual Device Context <vdc-id> |
| memory                | Show processes Memory Info            |
| <i>__readonly__</i>   | (Optional)                            |
| TABLE_process_memory  | (Optional) all process memory         |
| <i>mem_pid</i>        | (Optional) process id                 |
| <i>mem_alloc</i>      | (Optional) allocated memory           |
| <i>mem_limit</i>      | (Optional) memory limit               |
| <i>mem_used</i>       | (Optional) memory used                |
| <i>stack_base_ptr</i> | (Optional) stack and base pointer     |
| <i>process</i>        | (Optional) name of the process        |

### Command Mode

- /exec



# show pss debug

show pss debug

## Syntax Description

|       |                                 |
|-------|---------------------------------|
| show  | Show running system information |
| pss   | display pss information         |
| debug | display pss debug configuration |

## Command Mode

- /exec

# show ptp brief

```
show ptp brief [ __readonly__ <gptp-flag> [ TABLE_ptp <ptp-ifindex> <state> [ <dot1as-capable> ] ]
<ptp-end> ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| ptp                   | Precision Time Protocol (IEEE 1588) Subsystem |
| brief                 | port states in brief                          |
| __readonly__          | (Optional) Read Only                          |
| <i>gptp-flag</i>      | (Optional) GPTP mode                          |
| TABLE_ptp             | (Optional) ptp table                          |
| <i>ptp-ifindex</i>    | (Optional) ptp ifindex                        |
| <i>state</i>          | (Optional) BMC state                          |
| <i>dot1as-capable</i> | (Optional) Dot1AS capable                     |
| <i>ptp-end</i>        | (Optional) End of table                       |

## Command Mode

- /exec

# show ptp clock

```
show ptp clock [ __readonly__ <clock-id> <domain-id> <num-ports> <priority1> <priority2> <class>
<accuracy> <scaled-log-variance> <offset-from-master> <mean-path-delay-to-master> <steps-removed>
<device-type> <encap> <slave-clock-oper> <master-clock-oper> <src-ip> <src-ipv6> <slave-only> [
<correction-threshold> ] [ <mean-path-delay-threshold> ] [ <gmTimeBaseIndicator> ] [
<last_gm_phase_change> ] [ <master_cum_scaled_rate_offset> ] [ <scaled_last_gm_freq_change> ] [
<cum_scaled_rate_offset> ] <local-clock-time> [ <bs-status> ] <clock-state> [ <asymmetric-delay-direction>
] [ <asymmetric-delay-value> ] ]
```

## Syntax Description

|                                  |  |
|----------------------------------|--|
| ptp                              | Precision Time Protocol (IEEE 1588) Subsystem                          |
| clock                            | Set local clock attributes   |
| <i>__readonly__</i>              | (Optional) Read only   |
| <i>domain-id</i>                 | (Optional) Domain Id   |
| <i>clock-id</i>                  | (Optional) Clock Id  |
| <i>priority1</i>                 | (Optional) Priority 1  |
| <i>priority2</i>                 | (Optional) Priority 2  |
| <i>num-ports</i>                 | (Optional) Number of PTP ports   |
| <i>class</i>                     | (Optional) Class   |
| <i>accuracy</i>                  | (Optional) Clock accuracy  |
| <i>scaled-log-variance</i>       | (Optional) scaled log variance   |
| <i>offset-from-master</i>        | (Optional) Offset from master  |
| <i>mean-path-delay-to-master</i> | (Optional) mean path delay to master                                   |
| <i>steps-removed</i>             | (Optional) Steps removed   |
| <i>device-type</i>               | (Optional) Device Type   |
| <i>encap</i>                     | (Optional) Encapsulation   |
| <i>src-ip</i>                    | (Optional) IPv4 address (A.B.C.D) of source (in layer-3 encapsulation) |
| <i>slave-clock-oper</i>          | (Optional) Slave clock operation                                       |
| <i>master-clock-oper</i>         | (Optional) Master clock operation                                      |
| <i>slave-only</i>                | (Optional) Slave-only mode   |
| <i>correction-threshold</i>      | (Optional) correction-threshold  |
| <i>mean-path-delay-threshold</i> | (Optional) mean-path-delay threshold                                   |

|                                      |   |
|--------------------------------------|---|
| <i>gmTimeBaseIndicator</i>           | (Optional) time base indicator for current GM                 |
| <i>last_gm_phase_change</i>          | (Optional) time difference of current and previous GM         |
| <i>master_cum_scaled_rate_offset</i> | (Optional) cumulative scaled rate offset received from master |
| <i>scaled_last_gm_freq_change</i>    | (Optional) scaled last GM frequency change                    |
| <i>cum_scaled_rate_offset</i>        | (Optional) cumulative scaled rate offset                      |
| <i>local-clock-time</i>              | (Optional) Local clock time                                   |
| <i>bs-status</i>                     | (Optional) Broadsync status enable/disable                    |
| <i>clock-state</i>                   | (Optional) PTP clock state                                    |
| <i>asymmetric-delay-direction</i>    | (Optional) PTP asymmetric delay direction                     |
| <i>asymmetric-delay-value</i>        | (Optional) PTP asymmetric delay compensation time(ns)         |

**Command Mode**

- /exec

## show ptp clock foreign-masters record

```
show ptp clock foreign-masters record [ interface <if0> ] [ __readonly__ [ TABLE_ptp <interface-name>
<clock-id> <priority1> <priority2> <class> <accuracy> <scaled-log-variance> <steps-removed> <is-gm> ]
<ptp-end> ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| ptp                        | Precision Time Protocol (IEEE 1588) Subsystem |
| clock                      | Set local clock attributes                    |
| foreign-masters            | foreign-masters                               |
| record                     | record  |
| <i>if0</i>                 | (Optional)                                    |
| <i>__readonly__</i>        | (Optional) Read only                          |
| <i>TABLE_ptp</i>           | (Optional) ptp table                          |
| <i>interface-name</i>      | (Optional) interface name                     |
| <i>clock-id</i>            | (Optional) Clock Id                           |
| <i>priority1</i>           | (Optional) Priority 1                         |
| <i>priority2</i>           | (Optional) Priority 2                         |
| <i>class</i>               | (Optional) Class                              |
| <i>accuracy</i>            | (Optional) Clock accuracy                     |
| <i>scaled-log-variance</i> | (Optional) scaled log variance                |
| <i>steps-removed</i>       | (Optional) Steps removed                      |
| <i>is-gm</i>               | (Optional) Is Grandmaster                     |
| <i>ptp-end</i>             | (Optional) End of table                       |

### Command Mode

- /exec

# show ptp corrections

```
show ptp corrections [ entries <val> ] [ __readonly__ <ptp-header> [ TABLE_ptp <intf-name> <sup-time>
<correction-val> <mean-path-delay> ] <ptp-end> ]
```

## Syntax Description

|                             |  |
|-----------------------------|--|
| <code>ptp</code>            | Precision Time Protocol (IEEE 1588) Subsystem  |
| <code>__readonly__</code>   | (Optional) Read Only                           |
| <code>corrections</code>    | Display last few corrections                   |
| <code>entries</code>        | (Optional) Latest entries to display           |
| <code>val</code>            | (Optional) Number of latest entries to display |
| <code>ptp-header</code>     | (Optional) Start of table                      |
| <code>TABLE_ptp</code>      | (Optional) ptp table                           |
| <code>intf-name</code>      | (Optional) interface name                      |
| <code>sup-time</code>       | (Optional) sup time                            |
| <code>correction-val</code> | (Optional) correction value                    |
| <code>ptp-end</code>        | (Optional) End of table                        |

## Command Mode

- /exec

## show ptp cost

```
show ptp cost [ interface <if0> ] [ __readonly__ [ TABLE_ptp <ptp-ifindex> <cost> ] <ptp-end> ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| <i>ptp</i>          | Precision Time Protocol (IEEE 1588) Subsystem |
| <i>cost</i>         | port costs                                    |
| <i>if0</i>          | (Optional)                                    |
| <i>__readonly__</i> | (Optional) Read Only                          |
| <i>TABLE_ptp</i>    | (Optional) ptp table                          |
| <i>ptp-ifindex</i>  | (Optional) ptp ifindex                        |
| <i>cost</i>         | (Optional) cost                               |
| <i>ptp-end</i>      | (Optional) End of table                       |

### Command Mode

- /exec

## show ptp counters interface

```
show ptp counters { interface <if0> | all } [ { detail | ipv4 <ip> | ipv6 <ip6> } ] [ __readonly__ [ TABLE_ptp
<interface_name> [ <accepted-ip> ] <tx-announce-pkts> <rx-announce-pkts> <tx-sync-pkts> <rx-sync-pkts>
<tx-follow-up-pkts> <rx-follow-up-pkts> <tx-delay-req-pkts> <rx-delay-req-pkts> <tx-delay-resp-pkts>
<rx-delay-resp-pkts> <tx-pdelay-req-pkts> <rx-pdelay-req-pkts> <tx-pdelay-resp-pkts> <rx-pdelay-resp-pkts>
<tx-pdelay-follow-up-pkts> <rx-pdelay-follow-up-pkts> [ <tx-mgmt-pkts> ] [ <rx-mgmt-pkts> ] [ <tx-sig-pkts>
] [ <rx-sig-pkts> ] ] <ptp-end> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| ptp                   | Precision Time Protocol (IEEE 1588) Subsystem |
| __readonly__          | (Optional) Read Only                          |
| counters              | Display PTP packet counters                   |
| interface             | Enter the port interface                      |
| all                   | Displays all information                      |
| <i>if0</i>            |   |
| detail                | (Optional) Show detail                        |
| ipv4                  | (Optional) IPv4 address for the stat info     |
| <i>ip</i>             | (Optional) IPv4 address (A.B.C.D)             |
| ipv6                  | (Optional) IPv6 address for the stat info     |
| <i>ip6</i>            | (Optional) IPv6 address (A:B::C:D)            |
| TABLE_ptp             | (Optional) ptp table                          |
| <i>interface_name</i> | (Optional) interface name                     |
| <i>accepted-ip</i>    | (Optional) Accepted IP in unicast mode        |
| <i>ptp-end</i>        | (Optional) End of table                       |

### Command Mode

- /exec



# show ptp delay summary

```
show ptp delay summary [ __readonly__ [ TABLE_ptp <intf-name-port> <device-type> <state> <link-delay>
] [ <ptp-end> ] [ <gtp-not-supported> ] ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| ptp                      | Precision Time Protocol (IEEE 1588) Subsystem |
| delay                    | delay   |
| summary                  | summary                                       |
| __readonly__             | (Optional) Read only                          |
| TABLE_ptp                | (Optional) ptp table                          |
| <i>intf-name-port</i>    | (Optional) interface name and port            |
| <i>device-type</i>       | (Optional) Device Type                        |
| <i>state</i>             | (Optional) BMC state                          |
| <i>link-delay</i>        | (Optional) link delay                         |
| <i>ptp-end</i>           | (Optional) End of table                       |
| <i>gtp-not-supported</i> | (Optional) GPTP not supported                 |

## Command Mode

- /exec

## show ptp domain data

```
show ptp domain data [ __readonly__ [ TABLE_ptp <multidom_cap> <gm_cap> <gm_convergence_time>
<def_dom> <transition_priority1> <transition_priority2> [ TABLE_ptp_domain <domain_number>
<domain_priority> <ptp_clock_class_threshold> <ptp_clock_accuracy_threshold> [ TABLE_ptp_ifindex
<ptp-ifindex> ] ] ] <ptp-end> ]
```

### Syntax Description

|                                     |  |
|-------------------------------------|--|
| ptp                                 | Precision Time Protocol (IEEE 1588) Subsystem    |
| domain                              | ptp domain number                                |
| data                                | ptp domain data                                  |
| __readonly__                        | (Optional) Read Only                             |
| TABLE_ptp                           | (Optional) ptp table                             |
| <i>multidom_cap</i>                 | (Optional) Multidomain state ENABLED/DISABLED    |
| <i>gm_cap</i>                       | (Optional) GM state ENABLE/DISABLED              |
| <i>gm_convergence_time</i>          | (Optional) ptp grandmaster convergence time      |
| <i>def_dom</i>                      | (Optional) ptp default domain                    |
| <i>transition_priority1</i>         | (Optional) ptp multi-domain transition priority1 |
| <i>transition_priority2</i>         | (Optional) ptp multi-domain transition priority2 |
| TABLE_ptp_domain                    | (Optional)                                       |
| <i>domain_number</i>                | (Optional) ptp domain number                     |
| <i>domain_priority</i>              | (Optional) ptp domain priority                   |
| <i>ptp_clock_class_threshold</i>    | (Optional) ptp domain class                      |
| <i>ptp_clock_accuracy_threshold</i> | (Optional) ptp domain accuracy                   |
| TABLE_ptp_ifindex                   | (Optional)                                       |
| <i>ptp-ifindex</i>                  | (Optional) ptp ifindex                           |
| <i>ptp-end</i>                      | (Optional) End of table                          |

### Command Mode

- /exec

# show ptp interface domain

show ptp interface domain [ \_\_readonly\_\_ [ TABLE\_ptp <ptp-ifindex> <interface-domain> ] <ptp-end> ]

## Syntax Description

|                         |   |
|-------------------------|---|
| ptp                     | Precision Time Protocol (IEEE 1588) Subsystem |
| interface               | port  |
| domain                  | ptp port domain                               |
| __readonly__            | (Optional) Read Only                          |
| TABLE_ptp               | (Optional) ptp table                          |
| <i>ptp-ifindex</i>      | (Optional) ptp ifindex                        |
| <i>interface-domain</i> | (Optional) ptp port domain                    |
| <i>ptp-end</i>          | (Optional) End of table                       |

## Command Mode

- /exec

# show ptp packet-trace

```
show ptp packet-trace [ __readonly__ <ptp-header> [ TABLE_ptp <intf-name> <sup-time> <pkt_dir>
<pkt_type> <pkt_info> ] <ptp-end> ]
```

## Syntax Description

|                   |   |
|-------------------|---|
| ptp               | Precision Time Protocol (IEEE 1588) Subsystem |
| __readonly__      | (Optional) Read Only                          |
| packet-trace      | Display last few pkt traces                   |
| <i>ptp-header</i> | (Optional) Start of table                     |
| TABLE_ptp         | (Optional) ptp table                          |
| <i>intf-name</i>  | (Optional) interface name                     |
| <i>sup-time</i>   | (Optional) sup time                           |
| <i>pkt_dir</i>    | (Optional) pkt_dir                            |
| <i>pkt_type</i>   | (Optional) pkt_type                           |
| <i>pkt_info</i>   | (Optional) pkt_info                           |
| <i>ptp-end</i>    | (Optional) End of table                       |

## Command Mode

- /exec

# show ptp parent

```
show ptp parent [ __readonly__ <clock-id> <port-num> <obs-parent-offset> <obs-parent-clk-phase-chg> [
<parent-ip> ] <gm-id> <gm-class> <gm-accuracy> <gm-scaled-log-variance> <gm-priority1> <gm-priority2>
[ TABLE-path-trace <path-trace-index> <path-trace-clock-id> ] ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| ptp                      | Precision Time Protocol (IEEE 1588) Subsystem |
| parent                   | parent clock                                  |
| __readonly__             | (Optional) Read only                          |
| clock-id                 | (Optional) Clock Id                           |
| port-num                 | (Optional) Port ID: port number               |
| obs-parent-offset        | (Optional) observed parent offset             |
| obs-parent-clk-phase-chg | (Optional) observed parent clock phase change |
| parent-ip                | (Optional) Parent clock IP                    |
| gm-id                    | (Optional) Grandmaster Id                     |
| gm-class                 | (Optional) Class                              |
| gm-accuracy              | (Optional) Clock accuracy                     |
| gm-scaled-log-variance   | (Optional) scaled log variance                |
| gm-priority1             | (Optional) GM Priority 1                      |
| gm-priority2             | (Optional) GM Priority 2                      |
| TABLE-path-trace         | (Optional) ptp path trace table               |
| path-trace-index         | (Optional) Clock Identity index               |
| path-trace-clock-id      | (Optional) Clock Identity in path trace       |

## Command Mode

- /exec

## show ptp port interface

```
show ptp port interface <if0> [ __readonly__ [ TABLE_ptp <intf-name> <clock-id> <port-num> <version>
[ <transport-mode> ] [ <accepted-ip> ] <state> <vlan> <delay-req-intv> <ann-rx-tout> <peer-mean-path-delay>
<ann-intv> <sync-intv> <delay-mechanism> [ <peer-delay-req-intv> ] [ <device-type> ] [ <encap> ] [
<prop-delay-thresh> ] [ <neighbor-rate-ratio> ] <cost> <int-domain-id> ] <ptp-end> ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| ptp                         | Precision Time Protocol (IEEE 1588) Subsystem |
| port                        | port  |
| interface                   | Enter the port interface                      |
| <i>if0</i>                  |   |
| <i>__readonly__</i>         | (Optional) Read only                          |
| <i>TABLE_ptp</i>            | (Optional) ptp table                          |
| <i>intf-name</i>            | (Optional) interface name                     |
| <i>clock-id</i>             | (Optional) Port ID: Clock Id                  |
| <i>port-num</i>             | (Optional) Port ID: port number               |
| <i>version</i>              | (Optional) version                            |
| <i>transport-mode</i>       | (Optional) Transport mode                     |
| <i>accepted-ip</i>          | (Optional) Accepted IPs                       |
| <i>state</i>                | (Optional) BMC state                          |
| <i>vlan</i>                 | (Optional) Vlan                               |
| <i>delay-req-intv</i>       | (Optional) log mean delay req interval        |
| <i>ann-rx-tout</i>          | (Optional) announce receipt timeout           |
| <i>peer-mean-path-delay</i> | (Optional) peer mean path delay               |
| <i>ann-intv</i>             | (Optional) announce interval                  |
| <i>sync-intv</i>            | (Optional) sync interval                      |
| <i>delay-mechanism</i>      | (Optional) delay mechanism                    |
| <i>peer-delay-req-intv</i>  | (Optional) peer delay req interval            |
| <i>device-type</i>          | (Optional) Device Type                        |
| <i>encap</i>                | (Optional) Encapsulation                      |

|                            |  |
|----------------------------|--|
| <i>prop-delay-thresh</i>   | (Optional) propagation delay threshold |
| <i>neighbor-rate-ratio</i> | (Optional) Neighbor rate-ratio         |
| <i>cost</i>                | (Optional) Cost                        |
| <i>int-domain-id</i>       | (Optional) domain id                   |
| <i>ptp-end</i>             | (Optional) End of Table                |

**Command Mode**

- /exec

## show ptp time-property

show ptp time-property [ \_\_readonly\_\_ <current-utc-offset-valid> <current-utc-offset> <leap-59> <leap-61> <time-traceable> <freq-traceable> <ptp-timescale> <time-source> ]

### Syntax Description

|                                 |   |
|---------------------------------|---|
| ptp                             | Precision Time Protocol (IEEE 1588) Subsystem |
| time-property                   | time property                                 |
| __readonly__                    | (Optional) Read only                          |
| <i>current-utc-offset-valid</i> | (Optional) current_utc_offset_valid           |
| <i>current-utc-offset</i>       | (Optional) current_utc_offset                 |
| <i>leap-59</i>                  | (Optional) leap-59                            |
| <i>leap-61</i>                  | (Optional) leap-61                            |
| <i>time-traceable</i>           | (Optional) time-traceable                     |
| <i>freq-traceable</i>           | (Optional) freq-traceable                     |
| <i>ptp-timescale</i>            | (Optional) ptp-timescale                      |
| <i>time-source</i>              | (Optional) time-source                        |

### Command Mode

- /exec



## show ptp unicast-negotiation

```
show ptp unicast-negotiation [ interface <if0> ] [ __readonly__ [ TABLE_ptp <interface-name> <ip-addr>
<status> <clock-id> ] <ptp-end> ]
```

### Syntax Description

|                                  |   |
|----------------------------------|---|
| <code>ptp</code>                 | Precision Time Protocol (IEEE 1588) Subsystem |
| <code>unicast-negotiation</code> | unicast-negotiation                           |
| <code>if0</code>                 | (Optional)                                    |
| <code>__readonly__</code>        | (Optional) Read only                          |
| <code>TABLE_ptp</code>           | (Optional) ptp table                          |
| <code>interface-name</code>      | (Optional) Interface name                     |
| <code>ip-addr</code>             | (Optional) IP address                         |
| <code>status</code>              | (Optional) Status                             |
| <code>clock-id</code>            | (Optional) Clock Id                           |
| <code>ptp-end</code>             | (Optional) End of table                       |

### Command Mode

- /exec

**show ptp unicast-negotiation**



## Q Show Commands

---

- [show qos dcbxp incompatibility interface](#), on page 2502
- [show qos dcbxp info](#), on page 2504
- [show qos dcbxp interface](#), on page 2505
- [show qos shared-policer](#), on page 2507
- [show queuing](#), on page 2509
- [show queuing burst-detect](#), on page 2512
- [show queuing llfc-queue](#), on page 2514
- [show queuing pfc-queue](#), on page 2515
- [show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex](#), on page 2517
- [show queuing pfc-queue snmp ifIndex](#), on page 2519
- [show queuing tabular](#), on page 2520
- [show queuing tah-pfc-queue](#), on page 2522

## show qos dcbxp incompatibility interface

```
show qos dcbxp incompatibility interface <iface-num> [ __readonly__ { [ { TABLE_local_pfc <vl_id_lpfce>
[ <lpfc> ] } ] [ { TABLE_remote_pfc <vl_id_rpfce> [ <rpfc> ] } ] [ <mtu> ] [ { TABLE_lpg <vl_id_lpg> [
<cos_list_lpg> ] [ <bandwidth_lpg> ] } ] [ { TABLE_rpg <vl_id_rpg> [ <cos_list_rpg> ] [ <bandwidth_rpg>
] } ] [ <bw> ] [ <lfcoe> ] [ <rfcoe> ] [ <liscsi> ] [ <riscsi> ] } ]
```

### Syntax Description

|                      |                                    |
|----------------------|------------------------------------|
| show                 | Show running system information    |
| dcbxp                | DCBXP                              |
| incompatibility      | incompatibility information        |
| interface            | incompatibility info for interface |
| <i>iface-num</i>     | Interface                          |
| <i>__readonly__</i>  | (Optional)                         |
| TABLE_local_pfc      | (Optional) local pfc table         |
| <i>vl_id_lpfce</i>   | (Optional) vl ID for local PFC     |
| <i>lpfc</i>          | (Optional) local pfc               |
| TABLE_remote_pfc     | (Optional) remote pfc table        |
| <i>vl_id_rpfce</i>   | (Optional) vl ID for remote PFC    |
| <i>rpfc</i>          | (Optional) remote pfc              |
| <i>mtu</i>           | (Optional) MTU Value               |
| TABLE_lpg            | (Optional) LPG Table               |
| <i>vl_id_lpg</i>     | (Optional) vl ID for LPG           |
| <i>cos_list_lpg</i>  | (Optional) cos list for LPG        |
| <i>bandwidth_lpg</i> | (Optional) bandwidth for LPG       |
| TABLE_rpg            | (Optional) RPG Table               |
| <i>vl_id_rpg</i>     | (Optional) vl ID for RPG           |
| <i>cos_list_rpg</i>  | (Optional) cos list for RPG        |
| <i>bandwidth_rpg</i> | (Optional) bandwidth for RPG       |
| <i>bw</i>            | (Optional) CIN: bandwidth/priority |
| <i>lfcoe</i>         | (Optional) local fcoe              |

|               |                         |
|---------------|-------------------------|
| <i>rfcoe</i>  | (Optional) remote fcoe  |
| <i>liscsi</i> | (Optional) local iscsi  |
| <i>riscsi</i> | (Optional) remote iscsi |

**Command Mode**

- /exec

## show qos dcbxp info

```
show qos dcbxp info [ __readonly__ { TABLE_dcbxp <intf> <pfer> <pfcc> <pgr> <pgc> <mtur> <mtuc>
<fcoer> <fcoec> <iscsir> <iscsic> } ]
```

### Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| dcbxp         | DCBXP                           |
| info          | information                     |
| __readonly__  | (Optional)                      |
| TABLE_dcbxp   | (Optional) dxcbsp info          |
| <i>intf</i>   | (Optional) Interface            |
| <i>pfer</i>   | (Optional) pfc recvd            |
| <i>pfcc</i>   | (Optional) pfc compatible       |
| <i>pgr</i>    | (Optional) pg received          |
| <i>pgc</i>    | (Optional) pg compatible        |
| <i>mtur</i>   | (Optional) mtu received         |
| <i>mtuc</i>   | (Optional) mtu compatible       |
| <i>fcoer</i>  | (Optional) fcoe received        |
| <i>fcoec</i>  | (Optional) fcoe compatible      |
| <i>iscsir</i> | (Optional) iscsi received       |
| <i>iscsic</i> | (Optional) iscsi compatible     |

### Command Mode

- /exec

## show qos dcbxp interface

```
show qos dcbxp interface [ <iface> ] [ __readonly__ [ <intf> { <info_absent> | { [ <local_pfc_cap>
<local_pfc_enable_list> ] [ <peers_pfc_cap> <peers_pfc_enable_list> ] [ <local_ets_maxtc>
<local_ets_priority_list> <local_ets_bandwidth_list> <local_ets_tsa_list> ] [ <peers_ets_maxtc>
<peers_ets_priority_list> <peers_ets_bandwidth_list> <peers_ets_tsa_list> ] [ <local_app_pri>
<local_app_type> <local_app_num> ] + [ <peers_app_pri> <peers_app_type> <peers_app_num> ] + [
<local_map_pri> <local_map_dscp> ] + [ <peers_map_pri> <peers_map_dscp> ] + } } ] + ]
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information                          |
| qos                             | QoS  |
| dcbxp                           | DCBXP  |
| interface                       | Per-interface information                                |
| <i>iface</i>                    | (Optional) Interface                                     |
| <i>__readonly__</i>             | (Optional)   |
| <i>intf</i>                     | (Optional) Interface                                     |
| <i>info_absent</i>              | (Optional) No information is present for this Interface. |
| <i>local_pfc_cap</i>            | (Optional) Number of Local Flows                         |
| <i>local_pfc_enable_list</i>    | (Optional) List of Local Flows Enabled                   |
| <i>peers_pfc_cap</i>            | (Optional) Number of Peer Flows                          |
| <i>peers_pfc_enable_list</i>    | (Optional) List of Peer Flows Enabled                    |
| <i>local_ets_maxtc</i>          | (Optional) Local ETS Maximum Traffic Classes             |
| <i>local_ets_priority_list</i>  | (Optional) Local ETS Priority List                       |
| <i>local_ets_bandwidth_list</i> | (Optional) Local ETS Bandwidth List                      |
| <i>local_ets_tsa_list</i>       | (Optional) Local ETS TSA List                            |
| <i>peers_ets_maxtc</i>          | (Optional) Peer ETS Maximum Traffic Classes              |
| <i>peers_ets_priority_list</i>  | (Optional) Peer ETS Priority List                        |
| <i>peers_ets_bandwidth_list</i> | (Optional) Peer ETS Bandwidth List                       |
| <i>peers_ets_tsa_list</i>       | (Optional) Peer ETS TSA List                             |
| <i>local_app_pri</i>            | (Optional) Local Application Priority                    |
| <i>local_app_type</i>           | (Optional) Local Application Number Type                 |

|                       |   |
|-----------------------|---|
| <i>local_app_num</i>  | (Optional) Local Application Number     |
| <i>peers_app_pri</i>  | (Optional) Peer Application Priority    |
| <i>peers_app_type</i> | (Optional) Peer Application Number Type |
| <i>peers_app_num</i>  | (Optional) Peer Application Number      |
| <i>local_map_pri</i>  | (Optional) Local Map Priority           |
| <i>local_map_dscp</i> | (Optional) Local Map DSCP Value         |
| <i>peers_map_pri</i>  | (Optional) Peer Map Priority            |
| <i>peers_map_dscp</i> | (Optional) Peer Map DSCP Value          |

**Command Mode**

- /exec



# show qos shared-policer

```
show qos shared-policer [ type qos1 ] [ <policer-name> ] [ __readonly__ { [ TABLE_policer <policer-name2>
[ <cir-spec> ] [ <bc-spec> ] [ <be-spec> ] [ <cir-rate-units> ] [ <cir> ] [ <bc-size-units> ] [ <bc> ] [
<pir-rate-units> ] [ <pir> ] [ <be-size-units> ] [ <be> ] [ <cnf-col-cmap> ] [ <exc-col-cmap> ] [ TABLE_action
<action-key> [ <cnf-act> ] [ <exc-act> ] [ <vio-act> ] [ <set-type> ] [ <enum-spec> ] [ <set-val> ] [
<tmap-from> ] [ <tmap-to> ] [ <tmap-name> ] ] ] } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                                |
| shared-policer        | Shared policer   |
| type                  | (Optional) Type of shared policer                              |
| qos1                  | (Optional) type qos  |
| <i>policer-name</i>   | (Optional) Shared policer name                                 |
| <i>__readonly__</i>   | (Optional)   |
| TABLE_policer         | (Optional) all police xml sessions                             |
| <i>policer-name2</i>  | (Optional) Policer Name  |
| TABLE_action          | (Optional) all police actions xml sessions                     |
| <i>action-key</i>     | (Optional) Count   |
| <i>cir-spec</i>       | (Optional) Is CIR keyword specified                            |
| <i>bc-spec</i>        | (Optional) Is Committed Burst keyword specified                |
| <i>be-spec</i>        | (Optional) Is Extended Burst keyword specified                 |
| <i>cir-rate-units</i> | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps  |
| <i>pir-rate-units</i> | (Optional) Units of rate - bps, kbps, mbps, gbps, ms, us, pps  |
| <i>bc-size-units</i>  | (Optional) Units of size - pkts/bytes/kbytes/mbytes/ms/us/perc |
| <i>be-size-units</i>  | (Optional) Units of size - pkts/bytes/kbytes/mbytes/ms/us/perc |
| <i>tmap-from</i>      | (Optional)   |
| <i>tmap-to</i>        | (Optional)   |
| <i>tmap-name</i>      | (Optional) Table map name                                      |
| <i>cnf-col-cmap</i>   | (Optional) Conforming color class-map name                     |
| <i>exc-col-cmap</i>   | (Optional) Exceeding color class-map name                      |
| <i>enum-spec</i>      | (Optional) Is DSCP or PREC enum value specified                |

|                 |   |
|-----------------|---|
| <i>cnf-act</i>  | (Optional) Conform action (Police)            |
| <i>exc-act</i>  | (Optional) Exceed action (Police)             |
| <i>vio-act</i>  | (Optional) Violate action (Police)            |
| <i>set-type</i> | (Optional) Type of set in police action       |
| <i>set-val</i>  | (Optional) Value of set type in police action |

**Command Mode**

- /exec

# show queuing

```
show queuing [ interface [ <if_list> ] ] [ summary ] [ module <module> ] [ __readonly__ [
TABLE_interface_mtu [ <intf_name> ] [ <mtu_val> ] ] [ TABLE_queuing_interface [ <dir> ] [ <if_name_str>
] [ <mtu_val> ] [ TABLE_qosgrp_cfg [ <qosgrp> ] [ <halqueue> ] [ <bandwidth> ] [ <priority> ] [ <cos-val>
] [ <shape-min> ] [ <shape-max> ] [ <shape-units> ] [ <buffer-size> ] [ <pause-threshold> ] [
<resume-threshold> ] [ <q-limit> ] [ <q-limit-type> ] [ <bandwidth-detail> ] [ <priority-detail> ] [
<shape-rate-detail> ] [ <q-limit-detail> ] ] [ <mc-drop-pkt> ] [ TABLE_qosgrp_egress_stats [ <eq-qosgrp>
] [ TABLE_qosgrp_egress_stats_entry [ <eq-stat-type> ] [ <eq-stat-units> ] [ <eq-uc-stat-value> ] [
<eq-ooobfc-uc-stat-value> ] [ <eq-mc-stat-value> ] ] ] [ TABLE_per_port_qos_stats [ <stat-type> ] [ <stat-units>
] [ <stat-value> ] ] [ TABLE_egress_stats_entry [ <ep-stat-type> ] [ <ep-stat-units> ] [ <ep-stat-value> ] ] [
TABLE_ingress_stats_entry [ <ip-stat-type> ] [ <ip-stat-units> ] [ <ip-stat-value> ] [ <ip-stat-value-q0> ] [
<ip-stat-value-q1> ] [ <ip-stat-value-q2> ] ] [ <tx-ppp> ] [ <rx-ppp> ] [ TABLE_pfc_stats [ <cos> ] [
<pfc-qosgrp> ] [ <pfc-pg> ] [ <tx-pause-state> ] [ <tx-pause-count> ] [ <rx-pause-state> ] [ <rx-pause-count>
] ] ] [ TABLE_qosgrp_egress_queuing [ <egr-queue-num> ] [ <egr-qosgrp> ] [ <bandwidth-percentage> ] [
<prio-level> ] [ <egr-shape-min> ] [ <egr-shape-max> ] [ <egr-shape-units> ] [ <shape-rate> ] [ <egr-cosmap>
] ] [ TABLE_qosgrp_ingress_queuing [ <ing-queue-num> ] [ <ing-qosgrp> ] [ <qlimit-percentage> ] [ <ivl>
] [ <ing-cosmap> ] [ <dscp-cnt> ] [ <qlimit-num-pages> ] [ <qlimit-num-descr> ] ] ] ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | commands to display                                |
| queuing                 | Queuing related information                        |
| interface               | (Optional) Interface for displaying queuing config |
| <i>if_list</i>          | (Optional) List of interfaces                      |
| module                  | (Optional) Slot/module                             |
| <i>module</i>           | (Optional) Slot/module number                      |
| summary                 | (Optional) summary                                 |
| <i>__readonly__</i>     | (Optional)   |
| TABLE_interface_mtu     | (Optional) mtu values of each interface            |
| <i>intf_name</i>        | (Optional) interface name                          |
| <i>mtu_val</i>          | (Optional) mtu val of interface                    |
| TABLE_queuing_interface | (Optional) Queuing information of an interface     |
| <i>dir</i>              | (Optional) Direction                               |
| <i>if_name_str</i>      | (Optional) interface name                          |
| <i>mtu_val</i>          | (Optional) mtu val of interface                    |
| TABLE_qosgrp_cfg        | (Optional) Qos-group configuration                 |
| <i>qosgrp</i>           | (Optional) Qos-group value                         |

|                                 |  |
|---------------------------------|--|
| <i>halqueue</i>                 | (Optional) Q value for innovium platform                       |
| <i>bandwidth</i>                | (Optional) WRR bandwidth                                       |
| <i>priority</i>                 | (Optional) Priority level                                      |
| <i>cos-val</i>                  | (Optional) cos value   |
| <i>shape-units</i>              | (Optional) Shape units   |
| <i>q-limit</i>                  | (Optional) Queue limit   |
| <i>q-limit-type</i>             | (Optional) Queue limit type (S-Static, D-Dynamic, U-Unlimited) |
| <i>bandwidth-detail</i>         | (Optional) bandwidth detailed output                           |
| <i>priority-detail</i>          | (Optional) priority level detailed output                      |
| <i>shape-rate-detail</i>        | (Optional) shape rate detailed output                          |
| <i>q-limit-detail</i>           | (Optional) queue limit detailed output                         |
| TABLE_qosgrp_egress_stats       | (Optional) Qos-group egress statistics                         |
| <i>eq-qosgrp</i>                | (Optional) Qos-group value                                     |
| TABLE_qosgrp_egress_stats_entry | (Optional) Qos-group egress statistics entry                   |
| <i>eq-stat-type</i>             | (Optional) Qos-group egress statistics type                    |
| <i>eq-stat-units</i>            | (Optional) Qos-group egress statistics units                   |
| TABLE_qosgrp_egress_queuing     | (Optional) Egress Queuing information                          |
| <i>egr-queue-num</i>            | (Optional) egress queue-num                                    |
| <i>egr-qosgrp</i>               | (Optional) egress qos group                                    |
| <i>bandwidth-percentage</i>     | (Optional) bandwidth in precentage                             |
| <i>prio-level</i>               | (Optional) priority level                                      |
| <i>egr-shape-units</i>          | (Optional) Egress Shape units                                  |
| <i>shape-rate</i>               | (Optional) shape rate  |
| <i>egr-cosmap</i>               | (Optional) egress cos map value                                |
| TABLE_qosgrp_ingress_queuing    | (Optional) Ingress Queuing information                         |
| <i>ing-queue-num</i>            | (Optional) ingress queue-num                                   |
| <i>ing-qosgrp</i>               | (Optional) ingress qos group                                   |
| <i>qlimit-percentage</i>        | (Optional) Queue Limit in precentage                           |
| <i>ivl</i>                      | (Optional) IVL   |

|                           |  |
|---------------------------|--|
| <i>ing-cosmap</i>         | (Optional) ingress cos map value         |
| <i>dscp-cnt</i>           | (Optional) dscp count                    |
| <i>qlimit-num-pages</i>   | (Optional) number of pages               |
| <i>qlimit-num-descr</i>   | (Optional) number of descriptions        |
| TABLE_per_port_qos_stats  | (Optional) Per-port QoS statistics       |
| <i>stat-type</i>          | (Optional) Per-port QoS statistics type  |
| <i>stat-units</i>         | (Optional) Per-port QoS statistics units |
| TABLE_egress_stats_entry  | (Optional) Egress port statistics        |
| <i>ep-stat-type</i>       | (Optional) Egress port statistics type   |
| <i>ep-stat-units</i>      | (Optional) Egress port statistics units  |
| <i>ep-stat-value</i>      | (Optional) Egress port statistics value  |
| TABLE_ingress_stats_entry | (Optional) Ingress port statistics       |
| <i>ip-stat-type</i>       | (Optional) Ingress port statistics type  |
| <i>ip-stat-units</i>      | (Optional) Ingress port statistics units |
| TABLE_pfc_stats           | (Optional) Per COS PFC statistics        |
| <i>cos</i>                | (Optional) PFC COS                       |
| <i>pfc-qosgrp</i>         | (Optional) Qos-group of the given COS    |
| <i>pfc-pg</i>             | (Optional) PG of the given COS/Qos-group |
| <i>tx-pause-state</i>     | (Optional) Tx PFC state of the given COS |
| <i>rx-pause-state</i>     | (Optional) Rx PFC state of the given COS |

**Command Mode**

- /exec

## show queuing burst-detect

```
show queuing burst-detect [ interface <if_name> [ queue <queue_num> ] ] [ module <module> ] [ last <val>
seconds ] [ detail ] [ __readonly__ [ TABLE_instance [ <if-str> ] [ <queue> ] [ <pipe> ] [ <threshold> ] [
<start-time> ] [ <peak> ] [ <peak-time> ] [ <end-depth> ] [ <end-time> ] [ <duration> ] ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | commands to display                               |
| queuing             | Queuing related information                       |
| burst-detect        | Out of Band micro-burst queue statistics          |
| interface           | (Optional) Interface                              |
| <i>if_name</i>      | (Optional) interface name                         |
| queue               | (Optional) Queue number for displaying statistics |
| <i>queue_num</i>    | (Optional) Queue number                           |
| module              | (Optional) Slot/module                            |
| <i>module</i>       | (Optional) Slot/module number                     |
| last                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED         |
| <i>val</i>          | (Optional) time in seconds                        |
| seconds             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED         |
| detail              | (Optional) detailed statistics                    |
| <i>if-str</i>       | (Optional) Interface name                         |
| <i>__readonly__</i> | (Optional) Read Only                              |
| TABLE_instance      | (Optional) Instance                               |
| <i>queue</i>        | (Optional) Queue Number                           |
| <i>pipe</i>         | (Optional) XPE-A or XPE-B                         |
| <i>threshold</i>    | (Optional) Threshold value in bytes               |
| <i>start-time</i>   | (Optional) Start time of burst                    |
| <i>peak</i>         | (Optional) Peak depth in bytes                    |
| <i>peak-time</i>    | (Optional) Peak time of burst                     |
| <i>end-depth</i>    | (Optional) End depth in bytes                     |
| <i>end-time</i>     | (Optional) End time of burst                      |

|                 |                              |
|-----------------|------------------------------|
| <i>duration</i> | (Optional) Duration of burst |
|-----------------|------------------------------|

**Command Mode**

- /exec

## show queuing llfc-queue

```
show queuing llfc-queue [ interface <if_list> ] [ module <module> ] [ detail ] [ __readonly__ [
TABLE_queuing_interface <if_name_str> [ TABLE_qosgrp_stats <eq-qosgrp> [ TABLE_qosgrp_stats_entry
<q-stat-type> [ <q-shutdown> ] [ <q-restored> ] [ <q-pkt-drained> ] [ <q-pkt-dropped> ] [ <q-total-pkt-dropped>
] [ <q-aggr-pkt-dropped> ] [ <q-ingr-pkt-dropped> ] [ <q-aggr-ingr-pkt-dropped> ] ] ] [
TABLE_qosgrp_stats_summary <qosgrp-summary> ] ] ]
```

### Syntax Description

| show                       | commands to display                                  |
|----------------------------|--|
| queuing                    | Queuing related information                          |
| llfc-queue                 | LLFC Queuing related information                     |
| interface                  | (Optional) Interface for displaying queuing config   |
| <i>if_list</i>             | (Optional) List of interfaces                        |
| module                     | (Optional) Slot/module                               |
| <i>module</i>              | (Optional) Slot/module number                        |
| detail                     | (Optional) Show detailed LLFC Queuing WD information |
| __readonly__               | (Optional)   |
| <i>if_name_str</i>         | (Optional) interface name                            |
| TABLE_queuing_interface    | (Optional) Queuing information of an interface       |
| TABLE_qosgrp_stats         | (Optional) Qos-group egress statistics               |
| <i>eq-qosgrp</i>           | (Optional) Qos-group value                           |
| TABLE_qosgrp_stats_entry   | (Optional) Qos-group egress statistics entry         |
| <i>q-stat-type</i>         | (Optional) Queue stat                                |
| TABLE_qosgrp_stats_summary | (Optional) Qos-group egress statistics summary       |
| <i>qosgrp-summary</i>      | (Optional) Qos-group summary value                   |

### Command Mode

- /exec



## show queuing pfc-queue

```
show queuing pfc-queue [ interface <if_list> ] [ module <module> ] [ detail ] [ __readonly__ <glb-wd-status>
<glb-wd-force-status> <glb-wd-timer> <glb-wd-timer-thresh> <glb-auto-restore> <glb-fixed-restore>
<glb-int-intf-multi> [ TABLE_queuing_interface <if_name_str> <wd-status> [ <disable-action> ] [ <intf-multi>
] [ <vl-bmp> ] [ <qosgrp_7_state> ] [ <qosgrp_6_state> ] [ <qosgrp_5_state> ] [ <qosgrp_4_state> ] [
<qosgrp_3_state> ] [ <qosgrp_2_state> ] [ <qosgrp_1_state> ] [ <qosgrp_0_state> ] [ TABLE_qosgrp_stats
<eq-qosgrp> <eq-qosgrp-state> <pfc-configured> <pfc-cos> TABLE_qosgrp_stats_entry <q-stat-type> [
<q-shutdown> ] [ <q-restored> ] [ <q-pkt-drained> ] [ <q-pkt-dropped> ] [ <q-pkt-drained-n-dropped> ] [
<q-aggr-pkt-dropped> ] [ <q-ing-pkt-dropped> ] [ <q-ing-aggr-pkt-dropped> ] ] ] ]
```

### Syntax Description

| show                       | commands to display  |
|----------------------------|--|
| queuing                    | Queuing related information                                |
| pfc-queue                  | PFC Queuing related information                            |
| interface                  | (Optional) Interface for displaying queuing config         |
| <i>if_list</i>             | (Optional) List of interfaces                              |
| module                     | (Optional) Slot/module                                     |
| <i>module</i>              | (Optional) Slot/module number                              |
| detail                     | (Optional) Show detailed PFC Queuing WD information        |
| <i>__readonly__</i>        | (Optional)   |
| <i>glb-wd-status</i>       | (Optional) Global watch-dog timer status                   |
| <i>glb-wd-force-status</i> | (Optional) Global watch-dog forcestatus                    |
| <i>glb-wd-timer</i>        | (Optional) Global watch-dog timer value in msec            |
| <i>glb-wd-timer-thresh</i> | (Optional) Global watch-dog timer thresh value in ms       |
| <i>glb-auto-restore</i>    | (Optional) Global auto restore multiplier value            |
| <i>glb-fixed-restore</i>   | (Optional) Global fixed restore multiplier value           |
| <i>glb-int-intf-multi</i>  | (Optional) Global internal interface multiplier value      |
| <i>disable-action</i>      | (Optional) Only generate syslog for queue stuck, no action |
| <i>intf-multi</i>          | (Optional) Interface multiplier value                      |
| <i>if_name_str</i>         | (Optional) interface name                                  |
| TABLE_queuing_interface    | (Optional) Queuing information of an interface             |
| <i>wd-status</i>           | (Optional) PFC watch-dog status                            |

|                          |  |
|--------------------------|--|
| <i>vl-bmp</i>            | (Optional) VL Bitmap                         |
| <i>qosgrp_7_state</i>    | (Optional) Qos group 7 state                 |
| <i>qosgrp_6_state</i>    | (Optional) Qos group 6 state                 |
| <i>qosgrp_5_state</i>    | (Optional) Qos group 5 state                 |
| <i>qosgrp_4_state</i>    | (Optional) Qos group 4 state                 |
| <i>qosgrp_3_state</i>    | (Optional) Qos group 3 state                 |
| <i>qosgrp_2_state</i>    | (Optional) Qos group 2 state                 |
| <i>qosgrp_1_state</i>    | (Optional) Qos group 1 state                 |
| <i>qosgrp_0_state</i>    | (Optional) Qos group 0 state                 |
| TABLE_qosgrp_stats       | (Optional) Qos-group egress statistics       |
| <i>eq-qosgrp</i>         | (Optional) Qos-group value                   |
| <i>eq-qosgrp-state</i>   | (Optional) Qos-group state                   |
| <i>pfc-configured</i>    | (Optional) PFC configuration                 |
| <i>pfc-cos</i>           | (Optional) PFC Cos value                     |
| TABLE_qosgrp_stats_entry | (Optional) Qos-group egress statistics entry |
| <i>q-stat-type</i>       | (Optional) Queue stat                        |

**Command Mode**

- /exec

# show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex

```
show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex <ifindex> [ __readonly__ [
TABLE_watchdogIfQueueTable <ifindex> [ TABLE_qosgrp_stats <eq-qosgrp> <state> <shutdowns>
<restores> <dropPkts> <totaldropPkts> <ingDropPkts> <totalIngDropPkts> ] ] ]
```

## Syntax Description

|                            |  |
|----------------------------|--|
| show                       | commands to display  |
| queuing                    | Queuing related information  |
| pfc-queue                  | PFC Queuing related information  |
| interface                  | Interface for displaying queuing config  |
| snmp                       | commands for snmp  |
| watchdogIfQueueTable       | Table  |
| ifIndex                    | port ifIndex   |
| <i>ifindex</i>             | interfaces ifIndex   |
| <i>__readonly__</i>        | (Optional)   |
| TABLE_watchdogIfQueueTable | (Optional) PFC Queuing information of an interface                                       |
| <i>ifindex</i>             | (Optional) interface ifindex   |
| TABLE_qosgrp_stats         | (Optional) Qos-group egress statistics   |
| <i>eq-qosgrp</i>           | (Optional) Qos-group value   |
| <i>state</i>               | (Optional) Queue state   |
| <i>shutdowns</i>           | (Optional) Number of times queue is shutdown   |
| <i>restores</i>            | (Optional) Number of times queue is restored   |
| <i>dropPkts</i>            | (Optional) Total Number of packets drained + dropped since last shutdown                 |
| <i>totaldropPkts</i>       | (Optional) Number of aggregate packets dropped during shutdowns                          |
| <i>ingDropPkts</i>         | (Optional) Total Number of packets dropped in the ingress direction since last shutdown  |
| <i>totalIngDropPkts</i>    | (Optional) Number of aggregate packets dropped in the ingress direction during shutdowns |

## Command Mode

- /exec

## show queuing pfc-queue snmp ifIndex

```
show queuing pfc-queue snmp ifIndex <ifidx> [ __readonly__ TABLE-cpfcWatchdogIfQueueInfoTable
<ifidx_out> <queueno_out> <q-state> <q-shutdown> <q-restored> <q-pkt-dropped> <q-aggr-pkt-dropped>
<q-ing-pkt-dropped> <q-ing-aggr-pkt-dropped> ]
```

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                          |
| queuing                            | Queuing related information                              |
| pfc-queue                          | PFC Queuing related information                          |
| snmp                               | Snmp information   |
| ifIndex                            | Interface index  |
| <i>ifidx</i>                       | Index  |
| <i>__readonly__</i>                | (Optional) Read Only                                     |
| TABLE-cpfcWatchdogIfQueueInfoTable | (Optional) SNMP table                                    |
| <i>ifidx_out</i>                   | (Optional) Interface index out                           |
| <i>queueno_out</i>                 | (Optional) Queue number out                              |
| <i>q-state</i>                     | (Optional) Queue state                                   |
| <i>q-shutdown</i>                  | (Optional) Number of times queue is shutdown             |
| <i>q-restored</i>                  | (Optional) Number of times queue is restored             |
| <i>q-pkt-dropped</i>               | (Optional) Number of packets dropped since last shutdown |
| <i>q-aggr-pkt-dropped</i>          | (Optional) Number of aggregate packets dropped           |
| <i>q-ing-pkt-dropped</i>           | (Optional) Number of Ingress packets dropped             |
| <i>q-ing-aggr-pkt-dropped</i>      | (Optional) Number of aggregate Ingress packets dropped   |

### Command Mode

- /exec

## show queuing tabular

```
show queuing tabular [ non-zero [ drop-only ] ] [ interface <if_list> ] [ module <module> ] [ __readonly__ [
TABLE_queuing_interface <if_name_str> [ <qos_group_name_0> ] [ <qos_group_name_1> ] [
<qos_group_name_2> ] [ <qos_group_name_3> ] [ <qos_group_name_4> ] [ <qos_group_name_5> ] [
<qos_group_name_6> ] [ <qos_group_name_7> ] [ <qos_group_name_cpu> ] [ <qos_group_name_span> ]
[ TABLE_queuing_counter <counter_name_str> [ <qos_group_0> ] [ <qos_group_1> ] [ <qos_group_2> ]
[ <qos_group_3> ] [ <qos_group_4> ] [ <qos_group_5> ] [ <qos_group_6> ] [ <qos_group_7> ] [
<qos_group_cpu> ] [ <qos_group_span> ] ] [ <tx_uc_pkt_qos_0> ] [ <tx_uc_byte_qos_0> ] [
<tx_uc_drop_pkt_qos_0> ] [ <tx_uc_drop_byte_qos_0> ] [ <tx_uc_ecn_pkt_qos_0> ] [
<tx_uc_ecn_byte_qos_0> ] [ <tx_oobfc_uc_pkt_qos_0> ] [ <tx_oobfc_uc_byte_qos_0> ] [
<tx_oobfc_uc_drop_pkt_qos_0> ] [ <tx_oobfc_uc_drop_byte_qos_0> ] [ <tx_fld_pkt_qos_0> ] [
<tx_fld_byte_qos_0> ] [ <tx_fld_drop_pkt_qos_0> ] [ <tx_fld_drop_byte_qos_0> ] [ <tx_mc_pkt_qos_0> ]
[ <tx_mc_byte_qos_0> ] [ <tx_mc_drop_pkt_qos_0> ] [ <tx_mc_drop_byte_qos_0> ] [ <pfc_rx_qos_0> ] [
<pfc_tx_qos_0> ] [ <qos_grp_1> ] [ <qos_grp_2> ] [ <qos_grp_3> ] [ <qos_grp_4> ] [ <qos_grp_5> ] [
<qos_grp_6> ] [ <qos_grp_7> ] [ <qos_grp_cpu> ] [ <qos_grp_span> ] [ <ing_drop_pkt> ] ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | commands to display                                |
| queuing                 | Queuing related information                        |
| tabular                 | QoS stats in tabular form                          |
| non-zero                | (Optional) Interface for non-zero stats            |
| drop-only               | (Optional) Interface for non-zero drop-only stats  |
| interface               | (Optional) Interface for displaying queuing config |
| <i>if_list</i>          | (Optional) List of interfaces                      |
| module                  | (Optional) Slot/module                             |
| <i>module</i>           | (Optional) Slot/module number                      |
| __readonly__            | (Optional)   |
| <i>if_name_str</i>      | (Optional) interface name                          |
| TABLE_queuing_interface | (Optional) Queuing information of an interface     |
| <i>counter_name_str</i> | (Optional) counter name                            |
| TABLE_queuing_counter   | (Optional) counter information of an interface     |
| <i>qos_group_name_0</i> | (Optional) QoS Group name                          |
| <i>qos_group_name_1</i> | (Optional) QoS Group name                          |
| <i>qos_group_name_2</i> | (Optional) QoS Group name                          |
| <i>qos_group_name_3</i> | (Optional) QoS Group name                          |

|                              |                                 |
|------------------------------|---------------------------------|
| <i>qos_group_name_4</i>      | (Optional) QoS Group name       |
| <i>qos_group_name_5</i>      | (Optional) QoS Group name       |
| <i>qos_group_name_6</i>      | (Optional) QoS Group name       |
| <i>qos_group_name_7</i>      | (Optional) QoS Group name       |
| <i>qos_group_name_cpu</i>    | (Optional) QoS Group name       |
| <i>qos_group_name_span</i>   | (Optional) QoS Group name       |
| <i>qos_group_span</i>        | (Optional) stats for SPAN grp   |
| <i>tx_uc_pkt_qos_0</i>       | (Optional) Tx UC packet         |
| <i>tx_uc_byte_qos_0</i>      | (Optional) Tx UC byte           |
| <i>tx_uc_drop_pkt_qos_0</i>  | (Optional) Drop UC packet       |
| <i>tx_uc_drop_byte_qos_0</i> | (Optional) Drop UC byte         |
| <i>qos_grp_span</i>          | (Optional) stats for SPAN group |

**Command Mode**

- /exec

## show queuing tah-pfc-queue

```
show queuing tah-pfc-queue [ interface <if_list> ] [ module <module> ] [ detail ] [ __readonly__ [
TABLE_queuing_interface <if_name_str> [ TABLE_qosgrp_stats <eq-qosgrp> [ TABLE_qosgrp_stats_entry
<q-stat-type> <q-shutdown> <q-restored> <q-pkt-drained> <q-pkt-dropped> <q-total-pkt-dropped>
<q-aggr-pkt-dropped> <q-ingr-pkt-dropped> <q-aggr-ingr-pkt-dropped> ] ] [ TABLE_qosgrp_stats_summary
<qosgrp-summary> ] ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | commands to display                                 |
| queuing                    | Queuing related information                         |
| tah-pfc-queue              | PFC Queuing related information                     |
| interface                  | (Optional) Interface for displaying queuing config  |
| <i>if_list</i>             | (Optional) List of interfaces                       |
| module                     | (Optional) Slot/module                              |
| <i>module</i>              | (Optional) Slot/module number                       |
| detail                     | (Optional) Show detailed PFC Queuing WD information |
| __readonly__               | (Optional)  |
| <i>if_name_str</i>         | (Optional) interface name                           |
| TABLE_queuing_interface    | (Optional) Queuing information of an interface      |
| TABLE_qosgrp_stats         | (Optional) Qos-group egress statistics              |
| <i>eq-qosgrp</i>           | (Optional) Qos-group value                          |
| TABLE_qosgrp_stats_entry   | (Optional) Qos-group egress statistics entry        |
| <i>q-stat-type</i>         | (Optional) Queue stat                               |
| TABLE_qosgrp_stats_summary | (Optional) Qos-group egress statistics summary      |
| <i>qosgrp-summary</i>      | (Optional) Qos-group summary value                  |

### Command Mode

- /exec





## R Show Commands

---

- [show radius-cfs](#), on page 2528
- [show radius-server](#), on page 2529
- [show radius-server](#), on page 2531
- [show radius-server directed-request](#), on page 2532
- [show radius-server groups](#), on page 2533
- [show radius-server sorted](#), on page 2534
- [show radius-server statistics](#), on page 2535
- [show radius status](#), on page 2537
- [show redundancy status](#), on page 2538
- [show regexp](#), on page 2540
- [show reload](#), on page 2541
- [show resource](#), on page 2542
- [show rmon](#), on page 2543
- [show role](#), on page 2545
- [show role feature-group](#), on page 2547
- [show role feature](#), on page 2548
- [show role status](#), on page 2549
- [show rollback log exec](#), on page 2550
- [show rollback status](#), on page 2551
- [show route-map](#), on page 2552
- [show route-map dynamic](#), on page 2553
- [show route-map pbr-statistics](#), on page 2554
- [show router-guard](#), on page 2555
- [show router-guard](#), on page 2556
- [show routing-context](#), on page 2557
- [show routing](#), on page 2558
- [show routing clients](#), on page 2562
- [show routing hash](#), on page 2564
- [show routing hidden-nh](#), on page 2567
- [show routing ipv6](#), on page 2568
- [show routing ipv6 clients](#), on page 2571
- [show routing ipv6 hash](#), on page 2575
- [show routing ipv6 hidden-nh](#), on page 2578

- [show routing ipv6 memory estimate](#), on page 2579
- [show routing ipv6 memory statistics](#), on page 2581
- [show routing ipv6 multicast clients](#), on page 2583
- [show routing ipv6 multicast lisp encap](#), on page 2587
- [show routing ipv6 multicast mdt encapsulation](#), on page 2588
- [show routing ipv6 multicast memory estimate](#), on page 2589
- [show routing ipv6 multicast sr](#), on page 2591
- [show routing ipv6 nhlfe](#), on page 2593
- [show routing ipv6 recursive-next-hop](#), on page 2595
- [show routing memory estimate](#), on page 2596
- [show routing memory statistics](#), on page 2598
- [show routing multicast clients](#), on page 2600
- [show routing multicast lisp encap](#), on page 2604
- [show routing multicast mdt encapsulation](#), on page 2605
- [show routing multicast memory estimate](#), on page 2607
- [show routing multicast sr](#), on page 2609
- [show routing nhlfe](#), on page 2611
- [show routing recursive-next-hop](#), on page 2613
- [show routing vxlan-hash peer-ip](#), on page 2615
- [show routing vxlan-hash peer-ipv6](#), on page 2616
- [show rscn event-tov vsan](#), on page 2617
- [show rscn pending-diff vsan](#), on page 2618
- [show rscn pending vsan](#), on page 2619
- [show rscn scr-table](#), on page 2620
- [show rscn session status vsan](#), on page 2621
- [show rscn statistics](#), on page 2622
- [show running-config](#), on page 2623
- [show running-config aaa](#), on page 2624
- [show running-config acllog](#), on page 2625
- [show running-config aclmgr](#), on page 2626
- [show running-config adjmgr](#), on page 2627
- [show running-config all](#), on page 2628
- [show running-config arp](#), on page 2629
- [show running-config assoc](#), on page 2630
- [show running-config backup](#), on page 2631
- [show running-config bfd](#), on page 2632
- [show running-config bgp](#), on page 2633
- [show running-config bloggerd](#), on page 2634
- [show running-config callhome](#), on page 2635
- [show running-config cdp](#), on page 2636
- [show running-config cert-enroll](#), on page 2637
- [show running-config cfs](#), on page 2638
- [show running-config clock\\_manager](#), on page 2639
- [show running-config config-profile](#), on page 2640
- [show running-config controller](#), on page 2641
- [show running-config copp](#), on page 2642

- [show running-config dhcp](#), on page 2643
- [show running-config diagnostic](#), on page 2644
- [show running-config diff](#), on page 2645
- [show running-config dot1x](#), on page 2646
- [show running-config ecp](#), on page 2647
- [show running-config eem](#), on page 2648
- [show running-config eigrp](#), on page 2649
- [show running-config eltm](#), on page 2650
- [show running-config epbr](#), on page 2651
- [show running-config evb](#), on page 2652
- [show running-config exclude](#), on page 2653
- [show running-config expand-port-profile](#), on page 2654
- [show running-config fabric forwarding](#), on page 2655
- [show running-config fabric multicast](#), on page 2656
- [show running-config fabricpath](#), on page 2657
- [show running-config fabricpath domain default](#), on page 2658
- [show running-config fabricpath switch-id](#), on page 2659
- [show running-config fabricpath topology](#), on page 2660
- [show running-config fcoe\\_mgr](#), on page 2661
- [show running-config fsync\\_mgr](#), on page 2662
- [show running-config hardware-telemetry](#), on page 2663
- [show running-config hsrp](#), on page 2664
- [show running-config icam](#), on page 2665
- [show running-config icmpv6](#), on page 2666
- [show running-config igmp](#), on page 2667
- [show running-config imp](#), on page 2668
- [show running-config interface](#), on page 2669
- [show running-config interface](#), on page 2670
- [show running-config ip](#), on page 2671
- [show running-config ipqos](#), on page 2672
- [show running-config ipv6](#), on page 2673
- [show running-config isis](#), on page 2674
- [show running-config l3vm](#), on page 2675
- [show running-config ldap](#), on page 2676
- [show running-config license](#), on page 2677
- [show running-config lisp](#), on page 2678
- [show running-config lldp](#), on page 2679
- [show running-config macsec](#), on page 2680
- [show running-config mfwd](#), on page 2681
- [show running-config mfwdv6](#), on page 2682
- [show running-config mld](#), on page 2683
- [show running-config mmode](#), on page 2684
- [show running-config monitor](#), on page 2685
- [show running-config mpls static](#), on page 2686
- [show running-config mpls strip](#), on page 2687
- [show running-config msdp](#), on page 2688

- [show running-config nat](#), on page 2689
- [show running-config nbm](#), on page 2690
- [show running-config ngoam](#), on page 2691
- [show running-config ntp](#), on page 2692
- [show running-config nv overlay](#), on page 2693
- [show running-config nxsdk](#), on page 2694
- [show running-config ofm](#), on page 2695
- [show running-config openflow](#), on page 2696
- [show running-config ospf](#), on page 2697
- [show running-config ospfv3](#), on page 2698
- [show running-config otv-isis](#), on page 2699
- [show running-config param-list](#), on page 2700
- [show running-config pim](#), on page 2701
- [show running-config pim6](#), on page 2702
- [show running-config poe](#), on page 2703
- [show running-config port-profile](#), on page 2704
- [show running-config port-security](#), on page 2705
- [show running-config ptp](#), on page 2706
- [show running-config radius](#), on page 2707
- [show running-config rip](#), on page 2708
- [show running-config routing ip multicast](#), on page 2709
- [show running-config routing ipv6 multicast](#), on page 2710
- [show running-config rpm](#), on page 2711
- [show running-config scheduler](#), on page 2712
- [show running-config section](#), on page 2713
- [show running-config security](#), on page 2714
- [show running-config segment-routing](#), on page 2715
- [show running-config service-reflect](#), on page 2716
- [show running-config services](#), on page 2717
- [show running-config services](#), on page 2718
- [show running-config sflow](#), on page 2719
- [show running-config sla responder](#), on page 2720
- [show running-config sla sender](#), on page 2721
- [show running-config sla twamp-server](#), on page 2722
- [show running-config snmp](#), on page 2723
- [show running-config spanning-tree](#), on page 2724
- [show running-config srte](#), on page 2725
- [show running-config switch](#), on page 2726
- [show running-config sync](#), on page 2727
- [show running-config tacacs](#), on page 2728
- [show running-config telemetry](#), on page 2729
- [show running-config track](#), on page 2730
- [show running-config tunnel-encryption](#), on page 2731
- [show running-config udd](#), on page 2732
- [show running-config vdc-all](#), on page 2733
- [show running-config vdc](#), on page 2734

- [show running-config virtual-service](#), on page 2735
- [show running-config vlan](#), on page 2736
- [show running-config vlan](#), on page 2737
- [show running-config vlan](#), on page 2738
- [show running-config vmtracker](#), on page 2739
- [show running-config vpc](#), on page 2740
- [show running-config vrf](#), on page 2741
- [show running-config vrf default](#), on page 2742
- [show running-config vrrp](#), on page 2743
- [show running-config vrrpv3](#), on page 2744
- [show running-config vshd](#), on page 2745
- [show running-config vtp](#), on page 2746
- [show running-config wwnm](#), on page 2747
- [show running-config zone](#), on page 2748
- [show running-config zone vsan](#), on page 2749

# show radius-cfs

show radius-cfs [ *\_\_readonly\_\_* [ *<distr\_status>* ] [ *<session\_status>* ] [ *<session\_db>* ] [ *<merge\_status>* ] ]

## Syntax Description

|                       |                                       |
|-----------------------|---------------------------------------|
| show                  | Show running system information       |
| radius-cfs            | Show radius cfs state                 |
| <i>__readonly__</i>   | (Optional)                            |
| <i>distr_status</i>   | (Optional) radius distribution status |
| <i>session_status</i> | (Optional) current session status     |
| <i>session_db</i>     | (Optional) status of session db       |
| <i>merge_status</i>   | (Optional) radius merge status        |

## Command Mode

- /exec

## show radius-server

```
show radius-server [ __readonly__ [ <global_secretKey> ] { <global_timeout> <retransmissionCount>
<global_deadtime> } [ <global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [
<global_testPassword> ] } { <server_count> } [ TABLE_server <server_ip> [ <auth_port> ] [ <acct_port> ]
[ <secretKey> ] [ <timeout> ] [ <retries> ] ] [ { <host0> <auth_port> <acct_port> <shared_key>
<idle_time><test_username> <test_password> } + ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                                   |
| radius-server              | Show RADIUS configuration information                             |
| <i>__readonly__</i>        | (Optional)  |
| <i>global_secretKey</i>    | (Optional) Global shared secret                                   |
| <i>global_timeout</i>      | (Optional) Global timeout for radius                              |
| <i>retransmissionCount</i> | (Optional) Retransmission count when there is no server response  |
| <i>global_deadtime</i>     | (Optional) Global deadtime  |
| <i>global_source_intf</i>  | (Optional) Radius global source interface                         |
| <i>global_idle_time</i>    | (Optional) Radius global idle-time for server monitoring          |
| <i>global_testUsername</i> | (Optional) Username of global test parameters                     |
| <i>global_testPassword</i> | (Optional) Password of global test parameters                     |
| <i>server_count</i>        | (Optional) Total number of radius servers configured              |
| TABLE_server               | (Optional)  |
| <i>server_ip</i>           | (Optional) Ip address of the server                               |
| <i>auth_port</i>           | (Optional) Authentication port used for this server               |
| <i>acct_port</i>           | (Optional) Accounting Port used for this server                   |
| <i>secretKey</i>           | (Optional) Shared secret between the server and the radius client |
| <i>timeout</i>             | (Optional) Timeout for this radius server                         |
| <i>retries</i>             | (Optional) Retry count for individual servers                     |
| <i>host0</i>               | (Optional) DNS name or IP address                                 |
| <i>auth_port</i>           | (Optional) RADIUS server's port for authentication                |
| <i>acct_port</i>           | (Optional) RADIUS server's port for accounting                    |
| <i>shared_key</i>          | (Optional) RADIUS shared secret                                   |

|                      |  |
|----------------------|--|
| <i>test_password</i> | (Optional) User password in test packets |
|----------------------|--|

**Command Mode**

- /exec



## show radius-server

```
show radius-server { <host> } [ __readonly__ { <host1> } [ <authen_port> ] [ <account_port> ] [ <share_key> ] [ <timeout> ] [ <retries> ] [ <secure_radius> ] [ <aid> ] <idle_tim> <test_user_name> <test_pwd> ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| radius-server         | Show RADIUS configuration information              |
| <i>host</i>           | DNS name or IP address                             |
| <i>__readonly__</i>   | (Optional)   |
| <i>host1</i>          | (Optional) DNS name or IP address                  |
| <i>authen_port</i>    | (Optional) RADIUS server's port for authentication |
| <i>account_port</i>   | (Optional) RADIUS server's port for accounting     |
| <i>timeout</i>        | (Optional) radius server timeout                   |
| <i>retries</i>        | (Optional) radius server retry count               |
| <i>secure_radius</i>  | (Optional) secure radius enabled or not            |
| <i>aid</i>            | (Optional) Authority identity                      |
| <i>share_key</i>      | (Optional) RADIUS shared secret                    |
| <i>test_user_name</i> | (Optional) User name in test packets               |
| <i>test_pwd</i>       | (Optional) User password in test packets           |
| <i>idle_tim</i>       | (Optional) Time interval for monitoring the server |

### Command Mode

- /exec

## show radius-server directed-request

show radius-server directed-request [ \_\_readonly\_\_ { <radius\_directedRequest\_status> } ]

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information                     |
| radius-server                        | Show RADIUS configuration information               |
| directed-request                     | Show directed server enable configuration           |
| __readonly__                         | (Optional)  |
| <i>radius_directedRequest_status</i> | (Optional) status of radius-server directed request |

### Command Mode

- /exec

## show radius-server groups

```
show radius-server groups [ <s0> ] [ __readonly__ [ <num_of_groups> ] TABLE_group <group_name> [
TABLE_server <server_ip> [ <auth_port> ] [ <acct_port> ] ] [ <dead_time> ] [ <vrf_name> ] [
<source_interface> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information   |
| radius-server           | Show RADIUS configuration information   |
| groups                  | Show RADIUS server group configuration information  |
| <i>s0</i>               | (Optional) RADIUS server group name   |
| <i>__readonly__</i>     | (Optional)  |
| <i>num_of_groups</i>    | (Optional) number of groups   |
| TABLE_group             | (Optional)  |
| <i>group_name</i>       | (Optional) name of the group  |
| TABLE_server            | (Optional)  |
| <i>server_ip</i>        | (Optional) DNS name or IP address   |
| <i>auth_port</i>        | (Optional) radius server authentication port  |
| <i>acct_port</i>        | (Optional) radius server accounting port  |
| <i>dead_time</i>        | (Optional) Time interval for which the server is marked as dead before sending a test command |
| <i>vrf_name</i>         | (Optional) name of the vrf  |
| <i>source_interface</i> | (Optional) Interface Description  |

### Command Mode

- /exec

## show radius-server sorted

```
show radius-server sorted [ __readonly__ [ <global_secretKey> ] { <global_timeout> <retransmissionCount>
<global_deadtime> } [ <global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [
<global_testPassword> ] } { <server_count> } [ TABLE_server <server_ip> [ <auth_port> ] [ <acct_port> ]
[ <secretKey> ] [ <timeout> ] [ <retries> ] ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                                   |
| radius-server              | Show RADIUS configuration information                             |
| sorted                     | Show RADIUS servers sorted by name                                |
| <i>__readonly__</i>        | (Optional)  |
| <i>global_secretKey</i>    | (Optional) Global shared secret                                   |
| <i>global_timeout</i>      | (Optional) Global timeout for radius                              |
| <i>retransmissionCount</i> | (Optional) Retransmission count when there is no server response  |
| <i>global_deadtime</i>     | (Optional) Global deadtime  |
| <i>global_source_intf</i>  | (Optional) Radius global source interface                         |
| <i>global_idle_time</i>    | (Optional) Radius global idle-time for server monitoring          |
| <i>global_testUsername</i> | (Optional) Username of global test parameters                     |
| <i>global_testPassword</i> | (Optional) Password of global test parameters                     |
| <i>server_count</i>        | (Optional) Total number of radius servers configured              |
| TABLE_server               | (Optional)  |
| <i>server_ip</i>           | (Optional) Ip address of the server                               |
| <i>auth_port</i>           | (Optional) Authentication port used for this server               |
| <i>acct_port</i>           | (Optional) Accounting Port used for this server                   |
| <i>secretKey</i>           | (Optional) Shared secret between the server and the radius client |
| <i>timeout</i>             | (Optional) Timeout for this radius server                         |
| <i>retries</i>             | (Optional) Retry count for individual servers                     |

### Command Mode

- /exec

## show radius-server statistics

```
show radius-server statistics <host0> [ __readonly__ { <server_state> [ <clock_time> { monitoring_statistics
<time_in_pstate> <ndead> <tt_in_dstate> } ] } { auth_statistics <auth_failed_transactions>
<auth_succ_transactions> <auth_req_sent> <auth_req_timedout> <auth_resp_no_match>
<auth_resp_not_processed> <auth_resp_error> } { acct_statistics <acct_failed_transactions>
<acct_succ_transactions> <acct_req_sent> <acct_req_timedout> <acct_resp_no_match>
<acct_resp_not_processed> <acct_resp_error> } } ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                                   |
| radius-server                   | Show RADIUS configuration information                             |
| statistics                      | Show RADIUS statistics  |
| <i>host0</i>                    | DNS name or IP address  |
| <i>__readonly__</i>             | (Optional)  |
| <i>server_state</i>             | (Optional) Show state of server                                   |
| <i>clock_time</i>               | (Optional) Show clock time in terms of hours, minutes and seconds |
| <i>monitoring_statistics</i>    | (Optional) Monitoring Statistics                                  |
| <i>time_in_pstate</i>           | (Optional) Time in previous state                                 |
| <i>ndead</i>                    | (Optional) Number of times dead                                   |
| <i>tt_in_dstate</i>             | (Optional) Total time in dead state                               |
| <i>auth_statistics</i>          | (Optional) Authentication Statistics                              |
| <i>acct_statistics</i>          | (Optional) Accounting Statistics                                  |
| <i>auth_failed_transactions</i> | (Optional) Authentication: Failed transactions                    |
| <i>auth_succ_transactions</i>   | (Optional) Authentication: Successful transactions                |
| <i>auth_req_sent</i>            | (Optional) Authentication: Requests sent                          |
| <i>auth_req_timedout</i>        | (Optional) Authentication: Requests timedout                      |
| <i>auth_resp_no_match</i>       | (Optional) Authentication: Responses with no matching requests    |
| <i>auth_resp_not_processed</i>  | (Optional) Authentication: Responses not processed                |
| <i>auth_resp_error</i>          | (Optional) Authentication: Responses containing errors            |
| <i>acct_failed_transactions</i> | (Optional) Accounting: Failed transactions                        |
| <i>acct_succ_transactions</i>   | (Optional) Accounting: Successful transactions                    |

|                                |  |
|--------------------------------|--|
| <i>acct_req_sent</i>           | (Optional) Accounting: Requests sent                       |
| <i>acct_req_timeout</i>        | (Optional) Accounting: Requests timeout                    |
| <i>acct_resp_no_match</i>      | (Optional) Accounting: Responses with no matching requests |
| <i>acct_resp_not_processed</i> | (Optional) Accounting: Responses not processed             |
| <i>acct_resp_error</i>         | (Optional) Accounting: Responses containing errors         |

**Command Mode**

- /exec

## show radius status

```
show radius status [ __readonly__ [ <distr_status> ] [ <session_status> ] [ <session_owner> ] [ <session_db> ] [ <last_operation> ] [ <last_operation_status> ] [ <fail_code> ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information                      |
| radius                       | Show RADIUS Information                              |
| status                       | Show RADIUS cfs distribution status                  |
| <i>__readonly__</i>          | (Optional)   |
| <i>distr_status</i>          | (Optional) radius distribution status                |
| <i>session_status</i>        | (Optional) current session status                    |
| <i>session_owner</i>         | (Optional) owner of the current distribution session |
| <i>session_db</i>            | (Optional) status of session db                      |
| <i>last_operation</i>        | (Optional) last_operation                            |
| <i>last_operation_status</i> | (Optional) status of the last operation              |
| <i>fail_code</i>             | (Optional) reason for the failure of last operation  |

### Command Mode

- /exec

## show redundancy status

```
show redundancy status [ __readonly__ <rmode_admin> <rmode_opr> <this_sup> <this_sup_rd_st>
<this_sup_sup_st> <this_sup_int_st> <oth_sup> <oth_sup_rd_st> <oth_sup_sup_st> <oth_sup_int_st>
<sys_strt_time> <sys_uptm_days> <sys_uptm_hrs> <sys_uptm_mins> <sys_uptm_secs> <kern_uptm_days>
<kern_uptm_hrs> <kern_uptm_mins> <kern_uptm_secs> <asup_uptm_days> <asup_uptm_hrs>
<asup_uptm_mins> <asup_uptm_secs> ]
```

### Syntax Description

|                        |                               |
|------------------------|-------------------------------|
| show                   |                               |
| redundancy             | Show system redundancy status |
| status                 | Current redundancy status     |
| <i>__readonly__</i>    | (Optional)                    |
| <i>rmode_admin</i>     | (Optional)                    |
| <i>rmode_opr</i>       | (Optional)                    |
| <i>this_sup</i>        | (Optional)                    |
| <i>this_sup_rd_st</i>  | (Optional)                    |
| <i>this_sup_sup_st</i> | (Optional)                    |
| <i>this_sup_int_st</i> | (Optional)                    |
| <i>oth_sup</i>         | (Optional)                    |
| <i>oth_sup_rd_st</i>   | (Optional)                    |
| <i>oth_sup_sup_st</i>  | (Optional)                    |
| <i>oth_sup_int_st</i>  | (Optional)                    |
| <i>sys_strt_time</i>   | (Optional)                    |
| <i>sys_uptm_days</i>   | (Optional)                    |
| <i>sys_uptm_hrs</i>    | (Optional)                    |
| <i>sys_uptm_mins</i>   | (Optional)                    |
| <i>sys_uptm_secs</i>   | (Optional)                    |
| <i>kern_uptm_days</i>  | (Optional)                    |
| <i>kern_uptm_hrs</i>   | (Optional)                    |
| <i>kern_uptm_mins</i>  | (Optional)                    |
| <i>kern_uptm_secs</i>  | (Optional)                    |



|                       |            |
|-----------------------|------------|
| <i>asup_uptm_days</i> | (Optional) |
| <i>asup_uptm_hrs</i>  | (Optional) |
| <i>asup_uptm_mins</i> | (Optional) |
| <i>asup_uptm_secs</i> | (Optional) |

**Command Mode**

- /exec

# show regexp

```
show { ip mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] all | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 { unicast | multicast } ] } regexp <regexp-str> [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |
| all                   | Display BGP information for all address families                |
| regexp                | Display routes matching the AS path regular expression          |
| <i>regexp-str</i>     | Regular expression to match the AS paths                        |

## Command Mode

- /exec

# show reload

show reload [ *\_\_readonly\_\_* <reload-schedule> ]

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information            |
| reload                 | Display information about scheduled reload |
| <i>__readonly__</i>    | (Optional)                                 |
| <i>reload-schedule</i> | (Optional) Reload scheduling info          |

## Command Mode

- /exec

## show resource

```
show resource [ <res-mgr-res-known-name> ] [ hidden-too | with-flags ] [ __readonly__ {
TABLE_vdc_resource_local <res_name> <min> <max> <used> <unused> <free> } ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                                  |
| resource                      | Show resource configuration for VDC                              |
| <i>res-mgr-res-known-name</i> | (Optional) Resource name   |
| hidden-too                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                        |
| with-flags                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                        |
| __readonly__                  | (Optional) Read Only   |
| TABLE_vdc_resource_local      | (Optional)   |
| <i>res_name</i>               | (Optional) Resource Name   |
| <i>min</i>                    | (Optional) Resource min configuration                            |
| <i>max</i>                    | (Optional) Resource max configuration                            |
| <i>used</i>                   | (Optional) Resource current usage for this VDC                   |
| <i>unused</i>                 | (Optional) Resource reserved for this VDC but currently not used |
| <i>free</i>                   | (Optional) Resource current free for this VDC                    |

### Command Mode

- /exec

# show rmon

```
show rmon { alarms | events | hcalarms | info | logs } [ __readonly__ [ TABLE_rmon_alarm { <alarm-str>
<ascii-buf-str> <samp-type-str> <ris-trshod-str> <fall-trshod-str> <start-enable-str> } ] [ TABLE_rmon_event
{ <ev-alaran-str> <ev-desc-str> <ev-fir-cause> <last-fired> } ] [ TABLE_rmon_hcala { <hc-alaran-str>
<hc-ascii-buf-str> <hc-sam-ty-str> <hc-ris-thresh-str> <hc-fal-thresh-str> <start-alm-str> <fail-attem-str> }
] [ TABLE_rmon_info { <max-32-64-ala-str> <max-conf-32-ala-str> <max-conf-64-ala-str> } ] [
TABLE_rmon_log { <event-id-str> <rmon-pch> [ <log-buff-str> ] <log-oid> } ] ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                |
| rmon                    | Display RMON statistics                        |
| alarms                  | Display the RMON alarm table                   |
| events                  | Display the RMON event table                   |
| hcalarms                | Display the RMON HC(High Capacity) Alarm table |
| info                    | Display the RMON info                          |
| logs                    | Display the RMON event log table               |
| __readonly__            | (Optional)                                     |
| TABLE_rmon_alarm        | (Optional)                                     |
| <i>alarm-str</i>        | (Optional)                                     |
| <i>ascii-buf-str</i>    | (Optional)                                     |
| <i>samp-type-str</i>    | (Optional)                                     |
| <i>ris-trshod-str</i>   | (Optional)                                     |
| <i>fall-trshod-str</i>  | (Optional)                                     |
| <i>start-enable-str</i> | (Optional)                                     |
| TABLE_rmon_event        | (Optional)                                     |
| <i>ev-alaran-str</i>    | (Optional)                                     |
| <i>ev-desc-str</i>      | (Optional)                                     |
| <i>ev-fir-cause</i>     | (Optional)                                     |
| <i>last-fired</i>       | (Optional)                                     |
| TABLE_rmon_hcala        | (Optional)                                     |
| <i>hc-alaran-str</i>    | (Optional)                                     |

|                            |            |
|----------------------------|------------|
| <i>hc-ascii-buf-str</i>    | (Optional) |
| <i>hc-sam-ty-str</i>       | (Optional) |
| <i>hc-ris-thresh-str</i>   | (Optional) |
| <i>hc-fal-thresh-str</i>   | (Optional) |
| <i>start-alm-str</i>       | (Optional) |
| <i>fail-attem-str</i>      | (Optional) |
| TABLE_rmon_info            | (Optional) |
| <i>max-32-64-ala-str</i>   | (Optional) |
| <i>max-conf-32-ala-str</i> | (Optional) |
| <i>max-conf-64-ala-str</i> | (Optional) |
| TABLE_rmon_log             | (Optional) |
| <i>event-id-str</i>        | (Optional) |
| <i>rmon-pch</i>            | (Optional) |
| <i>log-buff-str</i>        | (Optional) |
| <i>log-oid</i>             | (Optional) |

### Command Mode

- /exec

# show role

```
show role [ name <arg3> ] [ __readonly__ { TABLE_role <role_name> <role_description> [ <attribute_scope>
] [ <permit_vsan> ] [ <permit_vlan> ] [ <permit_vlan_id> ] [ <permit_interface> ] [ <permit_interface_slot>
] [ <permit_vrf> ] [ TABLE_vrf<permit_vrf_name> ] [ { TABLE_rule <rule_num> <rule_action> {
<rule_permission> | <rule_permission_mds> } [ <rule_featuretype> ] [ <rule_entity> } } } ]
```

## Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| role                  | Show role configuration         |
| name                  | (Optional) Enter the role name  |
| arg3                  | (Optional) Enter the role name  |
| __readonly__          | (Optional)                      |
| TABLE_role            | (Optional)                      |
| role_name             | (Optional)                      |
| role_description      | (Optional)                      |
| attribute_scope       | (Optional)                      |
| permit_vsan           | (Optional)                      |
| permit_vlan           | (Optional)                      |
| permit_vlan_id        | (Optional)                      |
| permit_interface      | (Optional)                      |
| permit_interface_slot | (Optional)                      |
| permit_vrf            | (Optional)                      |
| TABLE_rule            | (Optional)                      |
| rule_num              | (Optional)                      |
| rule_action           | (Optional)                      |
| rule_permission       | (Optional)                      |
| rule_permission_mds   | (Optional)                      |
| rule_featuretype      | (Optional)                      |
| rule_entity           | (Optional)                      |

## Command Mode

- /exec



# show role feature-group

```
show role feature-group [ name <arg4> ] [ detail ] [ __readonly__ TABLE_role_feature_group
<feature_group_name> TABLE_role_feature <feature_name> [ TABLE_role_feature_rule <feature_rule> ]
]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information                         |
| role                      | Show role configuration                                 |
| feature-group             | Role feature group                                      |
| name                      | (Optional) Enter the feature-group name                 |
| <i>arg4</i>               | (Optional) Feature-group name                           |
| detail                    | (Optional) Detailed information including feature rules |
| <i>__readonly__</i>       | (Optional)  |
| TABLE_role_feature_group  | (Optional)  |
| <i>feature_group_name</i> | (Optional)  |
| TABLE_role_feature        | (Optional)  |
| <i>feature_name</i>       | (Optional)  |
| TABLE_role_feature_rule   | (Optional)  |
| <i>feature_rule</i>       | (Optional)  |

## Command Mode

- /exec

# show role feature

```
show role feature [ name <arg5> | detail ] [ __readonly__ TABLE_role_feature <feature_name> [
TABLE_role_feature_rule <feature_rule> ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                         |
| role                    | Show role configuration                                 |
| feature                 | Role feature  |
| name                    | (Optional) Enter the feature name                       |
| <i>arg5</i>             | (Optional) Feature name                                 |
| detail                  | (Optional) Detailed information including feature rules |
| <i>__readonly__</i>     | (Optional)  |
| TABLE_role_feature      | (Optional)  |
| <i>feature_name</i>     | (Optional)  |
| TABLE_role_feature_rule | (Optional)  |
| <i>feature_rule</i>     | (Optional)  |

## Command Mode

- /exec

# show role status

show role status

## Syntax Description

|        |                                 |
|--------|---------------------------------|
| show   | Show running system information |
| role   | Show role configuration         |
| status | Display role status             |

## Command Mode

- /exec

# show rollback log exec

```
show rollback log { exec | verify } [ __readonly__ [ <log_entry> + ] ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information        |
| rollback            | Show rollback                          |
| log                 | show rollback log                      |
| exec                | show rollback execution log            |
| verify              | show rollback verify log               |
| <i>__readonly__</i> | (Optional) Read only                   |
| <i>log_entry</i>    | (Optional) log entry from rollback log |

## Command Mode

- /exec

## show rollback status

```
show rollback status [ __readonly__ <last_operation> [ <rollback_type> ] [ <name> ] [ <start_time> ] [ <end_time> ] [ <operation_status> ] ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information        |
| rollback                | show rollback                          |
| status                  | show status of last rollback operation |
| <i>__readonly__</i>     | (Optional) Read only                   |
| <i>last_operation</i>   | (Optional) last operation              |
| <i>rollback_type</i>    | (Optional) rollback type               |
| <i>name</i>             | (Optional) name                        |
| <i>start_time</i>       | (Optional) start time                  |
| <i>end_time</i>         | (Optional) end time                    |
| <i>operation_status</i> | (Optional) operation status            |

### Command Mode

- /exec

# show route-map

```
show route-map [ <route-map-name> | <route-map-cfg-name> ] [ __readonly__ TABLE_rmap <name>
<action> <seq> [ <descript> ] [ <continue> ] [ { TABLE_rmap_match <match_type> <match_stmt> } ] [ {
TABLE_rmap_set <set_type> <set_stmt> } ] ]
```

## Syntax Description

|                           |                                 |
|---------------------------|---------------------------------|
| show                      | Show running system information |
| route-map                 | Route-map information           |
| <i>route-map-name</i>     | (Optional) Route-map name       |
| <i>route-map-cfg-name</i> | (Optional) Known route-map name |
| <i>__readonly__</i>       | (Optional)                      |
| TABLE_rmap                | (Optional)                      |
| TABLE_rmap_match          | (Optional)                      |
| TABLE_rmap_set            | (Optional)                      |
| <i>name</i>               | (Optional)                      |
| <i>action</i>             | (Optional)                      |
| <i>seq</i>                | (Optional)                      |
| <i>descript</i>           | (Optional)                      |
| <i>continue</i>           | (Optional)                      |
| <i>match_type</i>         | (Optional)                      |
| <i>match_stmt</i>         | (Optional)                      |
| <i>set_type</i>           | (Optional)                      |
| <i>set_stmt</i>           | (Optional)                      |

## Command Mode

- /exec

# show route-map dynamic

```
show route-map dynamic [ <route-map-name> | <route-map-cfg-name> ] [ __readonly__ TABLE_rmap
<name> <action> <seq> [ <descript> ] [ <continue> ] [ { TABLE_rmap_match <match_type> <match_stmt>
} ] [ { TABLE_rmap_set <set_type> <set_stmt> } ] ]
```

## Syntax Description

|                           |                                 |
|---------------------------|---------------------------------|
| show                      | Show running system information |
| route-map                 | Route-map information           |
| dynamic                   | Dynamically created route-map   |
| <i>route-map-name</i>     | (Optional) Route-map name       |
| <i>route-map-cfg-name</i> | (Optional) Known route-map name |
| <i>__readonly__</i>       | (Optional)                      |
| TABLE_rmap                | (Optional)                      |
| TABLE_rmap_match          | (Optional)                      |
| TABLE_rmap_set            | (Optional)                      |
| <i>name</i>               | (Optional)                      |
| <i>action</i>             | (Optional)                      |
| <i>seq</i>                | (Optional)                      |
| <i>descript</i>           | (Optional)                      |
| <i>continue</i>           | (Optional)                      |
| <i>match_type</i>         | (Optional)                      |
| <i>match_stmt</i>         | (Optional)                      |
| <i>set_type</i>           | (Optional)                      |
| <i>set_stmt</i>           | (Optional)                      |

## Command Mode

- /exec

## show route-map pbr-statistics

```
show route-map { <pbr_rmap_name> | <pbr_rmap_cfg_name> } pbr-statistics [ __readonly__ TABLE_rmap
{ TABLE_pbr <tag> <action> <seq> <pbr_pkt_count> } <dflt_rtg_pkt_count> ]
```

### Syntax Description

|                           |                                 |
|---------------------------|---------------------------------|
| show                      | Show running system information |
| route-map                 | Route-map information           |
| <i>pbr_rmap_name</i>      | Route-map name                  |
| <i>pbr_rmap_cfg_name</i>  | Known route-map name            |
| pbr-statistics            | PBR statistics                  |
| <i>__readonly__</i>       | (Optional)                      |
| TABLE_rmap                | (Optional)                      |
| TABLE_pbr                 | (Optional)                      |
| <i>tag</i>                | (Optional)                      |
| <i>action</i>             | (Optional)                      |
| <i>seq</i>                | (Optional)                      |
| <i>pbr_pkt_count</i>      | (Optional)                      |
| <i>dflt_rtg_pkt_count</i> | (Optional)                      |

### Command Mode

- /exec



# show router-guard

```
show router-guard [ vlan <vlan_id> ] [ __readonly__ [ TABLE_vlanid { <vlanid>
<globally-enabled-switch-port> } [ TABLE_if [ <disabled-if> ] ] ] ]
```

## Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information                      |
| router-guard                        | Shows router guard config details for all interfaces |
| vlan                                | (Optional) Only for the specified VLAN               |
| <i>vlan_id</i>                      | (Optional) VLAN ID                                   |
| <i>__readonly__</i>                 | (Optional)   |
| TABLE_vlanid                        | (Optional)   |
| <i>vlanid</i>                       | (Optional)   |
| <i>globally-enabled-switch-port</i> | (Optional)   |
| TABLE_if                            | (Optional)   |
| <i>disabled-if</i>                  | (Optional)   |

## Command Mode

- /exec

# show router-guard

```
show router-guard [ vlan <vlan_id> ] [ __readonly__ [ TABLE_vlanid { <vlanid>
<globally-enabled-switch-port> } [ TABLE_if [ <disabled-if> ] ] ] ] ]
```

## Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information                      |
| router-guard                        | Shows router guard config details for all interfaces |
| vlan                                | (Optional) Only for the specified VLAN               |
| <i>vlan_id</i>                      | (Optional) VLAN ID                                   |
| <i>__readonly__</i>                 | (Optional)   |
| TABLE_vlanid                        | (Optional)   |
| <i>vlanid</i>                       | (Optional)   |
| <i>globally-enabled-switch-port</i> | (Optional)   |
| TABLE_if                            | (Optional)   |
| <i>disabled-if</i>                  | (Optional)   |

## Command Mode

- /exec

# show routing-context

show routing-context [ \_\_readonly\_\_ <routing-con> ]

## Syntax Description

|                    |                                     |
|--------------------|-------------------------------------|
| show               | Show running system information     |
| routing-context    | Display the current routing context |
| __readonly__       | (Optional)                          |
| <i>routing-con</i> | (Optional)                          |

## Command Mode

- /exec



|                                   |   |
|-----------------------------------|---|
| bind-label                        | (Optional) Display routes with this bind-label only         |
| <i>bind-lbl</i>                   | (Optional) Binding label                                    |
| next-hop                          | (Optional) Display routes with this next-hop only           |
| <i>next-hop</i>                   | (Optional) Next hop address                                 |
| next-hop-v6                       | (Optional) Display routes with this V6 next-hop only        |
| interface                         | (Optional) Display routes with this output interface only   |
| <i>interface</i>                  | (Optional) Interface Name                                   |
| updated                           | (Optional) Display routes filtered by last updated time     |
| since                             | (Optional) Display those routes updated since this time     |
| <i>stime</i>                      | (Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| until                             | (Optional) Display those routes updated until this time     |
| <i>utime</i>                      | (Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| summary                           | (Optional) Display route counts                             |
| detail                            | (Optional) Display routes in full detail                    |
| cached                            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| summary-counter-consistency-check | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <u>__readonly__</u>               | (Optional)  |
| TABLE_vrf                         | (Optional)  |
| <i>vrf-name-out</i>               | (Optional)  |
| TABLE_addrf                       | (Optional)  |
| <i>addrf</i>                      | (Optional)  |
| TABLE_prefix                      | (Optional)  |
| <i>ipprefix</i>                   | (Optional)  |
| <i>ucast-nhops</i>                | (Optional)  |
| <i>mcast-nhops</i>                | (Optional)  |
| <i>attached</i>                   | (Optional)  |
| TABLE_path                        | (Optional)  |
| <i>ipnexthop</i>                  | (Optional)  |
| <i>nexthop-vrf-name</i>           | (Optional)  |

|                        |            |
|------------------------|------------|
| <i>ifname</i>          | (Optional) |
| <i>bindlbl</i>         | (Optional) |
| <i>uptime</i>          | (Optional) |
| <i>pref</i>            | (Optional) |
| <i>metric</i>          | (Optional) |
| <i>clientname</i>      | (Optional) |
| <i>type</i>            | (Optional) |
| <i>tag</i>             | (Optional) |
| <i>stale</i>           | (Optional) |
| <i>unres</i>           | (Optional) |
| <i>hidden</i>          | (Optional) |
| <i>stale-label</i>     | (Optional) |
| <i>bgpbackuppath</i>   | (Optional) |
| <i>type2</i>           | (Optional) |
| <i>remote-sid</i>      | (Optional) |
| <i>sid-fct</i>         | (Optional) |
| <i>ubest</i>           | (Optional) |
| <i>mbest</i>           | (Optional) |
| TABLE_summary          | (Optional) |
| <i>routes</i>          | (Optional) |
| <i>paths</i>           | (Optional) |
| <i>multicast_paths</i> | (Optional) |
| TABLE_unicast          | (Optional) |
| <i>clientnameuni</i>   | (Optional) |
| <i>best-paths</i>      | (Optional) |
| <i>backup-paths</i>    | (Optional) |
| TABLE_multicast        | (Optional) |
| <i>clientnamemulti</i> | (Optional) |
| <i>best-paths</i>      | (Optional) |

|                     |            |
|---------------------|------------|
| <i>backup-paths</i> | (Optional) |
| TABLE_route_count   | (Optional) |
| <i>mask_len</i>     | (Optional) |
| <i>count</i>        | (Optional) |

**Command Mode**

- /exec

## show routing clients

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] clients [ <client> | <protocol> ] [ __readonly__ { TABLE_client <client_name> [
<stale_reason> ] <pib_index> <epid> [ <mts_sap> ] [ <mts_sap_str> ] <mru_cache_hits> <mru_cache_misses>
<pib_stale_time> <pss_created> [ <bad_l3vm_table_refcount> ] [ <pib_stale_timer> ] [ { TABLE_nib_node
<uribtibtype_contextname> [ <all_igp> ] [ <self> ] [ <all> ] [ <unib_notify_mask> ] <routes> <rnhs> <labels>
[ <convg_req_mask> ] [ <convg_send_mask> ] [ <utib_state> ] [ <pending_timer> ] [ <urib_state_invalid>
} ] [ { TABLE_msgs_rcvd <urib_mtype_str> <upib_rcvd> } ] [ { TABLE_msgs_sent <urib_mtype_str>
<upib_sent> } ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| routing               | Display routing information                       |
| vrf                   | (Optional) Display per-VRF information            |
| <i>vrf-name</i>       | (Optional) VRF name                               |
| <i>vrf-known-name</i> | (Optional) Known VRF name                         |
| vrf-all               | (Optional) Display information for all VRFs       |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED         |
| <i>topology-name</i>  | (Optional) topology name                          |
| ip                    | (Optional) Display IP information                 |
| ipv4                  | (Optional) Display IP information                 |
| unicast               | (Optional) Display unicast information            |
| clients               | Display urib client information                   |
| <i>client</i>         | (Optional) Display single urib client information |
| <i>protocol</i>       | (Optional) Display single urib client information |
| __readonly__          | (Optional)  |
| TABLE_client          | (Optional)  |
| <i>client_name</i>    | (Optional)  |
| <i>stale_reason</i>   | (Optional)  |
| <i>pib_index</i>      | (Optional)  |
| <i>epid</i>           | (Optional)  |
| <i>mts_sap</i>        | (Optional)  |



|                                |            |
|--------------------------------|------------|
| <i>mts_sap_str</i>             | (Optional) |
| <i>mru_cache_hits</i>          | (Optional) |
| <i>mru_cache_misses</i>        | (Optional) |
| <i>plib_stale_time</i>         | (Optional) |
| <i>pss_created</i>             | (Optional) |
| <i>bad_l3vm_table_refcount</i> | (Optional) |
| <i>plib_stale_timer</i>        | (Optional) |
| TABLE_nib_node                 | (Optional) |
| <i>uribtibtype_contextname</i> | (Optional) |
| <i>all_igp</i>                 | (Optional) |
| <i>self</i>                    | (Optional) |
| <i>all</i>                     | (Optional) |
| <i>unib_notify_mask</i>        | (Optional) |
| <i>routes</i>                  | (Optional) |
| <i>rnhs</i>                    | (Optional) |
| <i>labels</i>                  | (Optional) |
| <i>convg_req_mask</i>          | (Optional) |
| <i>convg_send_mask</i>         | (Optional) |
| <i>utib_state</i>              | (Optional) |
| <i>pending_timer</i>           | (Optional) |
| <i>urib_state_invalid</i>      | (Optional) |
| TABLE_msgs_rcvd                | (Optional) |
| <i>urib_mtype_str</i>          | (Optional) |
| <i>upib_rcvd</i>               | (Optional) |
| TABLE_msgs_sent                | (Optional) |
| <i>urib_mtype_str</i>          | (Optional) |
| <i>upib_sent</i>               | (Optional) |

**Command Mode**

- /exec

## show routing hash

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] hash <source> <dest> [ ip-proto <ip-proto> ] { [ gtpu-teid <gtpu-teid> ] } | { [ ttl [ <ttl>
[ dest-port <dest-port> ] ] ] } | { [ udf <value> length <length> [ dest-port <dest-port> ] ] } | { [ <src-port>
<dest-port> ] } } [ in-interface <in-interface> ] [ module <module-id> ] [ vrf { <vrf-name> | <vrf-known-name>
| <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> TABLE_hashpath <mcast>
<hashpath> <hash-val> TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> <attached> TABLE_path
<ubest> <mbest> <ipnexthop> <ifname> <pref> <metric> <uptime> <clientname> [ <type> ] [ <tag> ] [
<stale> ] [ <unres> ] [ <hidden> ] [ <stale-label> ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information   |
| routing               | Display routing information   |
| vrf                   | (Optional) Display per-VRF information  |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name   |
| vrf-all               | (Optional) Display information for all VRFs                                     |
| ip                    | (Optional) Display IP information   |
| ipv4                  | (Optional) Display IP information   |
| unicast               | (Optional) Display unicast information  |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                                       |
| <i>topology-name</i>  | (Optional) topology name  |
| hash                  | Display load-balancing hash information   |
| <i>source</i>         | Source IPv4 address of unicast flow or group address for multicast flow         |
| <i>dest</i>           | Destination IPv4 address of unicast flow or source address for multicast flow   |
| <i>src-port</i>       | (Optional) Source-port  |
| <i>dest-port</i>      | (Optional) Destination-port   |
| in-interface          | (Optional) Incoming Interface for Packet.Option valid on Tomahawk platform only |
| <i>in-interface</i>   | (Optional) Interface Name   |
| ip-proto              | (Optional) IP Protocol information for the packet                               |
| <i>ip-proto</i>       | (Optional) IP Protocol information for the packet                               |

|                             |   |
|-----------------------------|---|
| <code>gtpu-teid</code>      | (Optional) GTPu TEID for the packet             |
| <i>gtpu-teid</i>            | (Optional) GTPu TEID for the packet             |
| <code>ttl</code>            | (Optional) TTL value for the packet             |
| <i>ttl</i>                  | (Optional) TTL value for the packet             |
| <code>udf</code>            | (Optional) UDF information for the packet       |
| <i>value</i>                | (Optional) UDF value for the packet             |
| <code>length</code>         | (Optional) Length in bits from udf offset       |
| <i>length</i>               | (Optional) Enter Length in bits from udf offset |
| <code>dest-port</code>      | (Optional) Destination-port                     |
| <i>dest-port</i>            | (Optional) Destination-port                     |
| <code>module</code>         | (Optional) Module                               |
| <i>module-id</i>            | (Optional) Module                               |
| <code>__readonly__</code>   | (Optional)                                      |
| <code>TABLE_vrf</code>      | (Optional)                                      |
| <i>vrf-name-out</i>         | (Optional)                                      |
| <code>TABLE_addrf</code>    | (Optional)                                      |
| <i>addrf</i>                | (Optional)                                      |
| <code>TABLE_hashpath</code> | (Optional)                                      |
| <i>mcast</i>                | (Optional)                                      |
| <i>hashpath</i>             | (Optional)                                      |
| <i>hash-val</i>             | (Optional)                                      |
| <code>TABLE_prefix</code>   | (Optional)                                      |
| <i>ipprefix</i>             | (Optional)                                      |
| <i>ucast-nhops</i>          | (Optional)                                      |
| <i>mcast-nhops</i>          | (Optional)                                      |
| <i>attached</i>             | (Optional)                                      |
| <code>TABLE_path</code>     | (Optional)                                      |
| <i>ubest</i>                | (Optional)                                      |
| <i>mbest</i>                | (Optional)                                      |

|                    |            |
|--------------------|------------|
| <i>ipnexthop</i>   | (Optional) |
| <i>ifname</i>      | (Optional) |
| <i>pref</i>        | (Optional) |
| <i>metric</i>      | (Optional) |
| <i>uptime</i>      | (Optional) |
| <i>clientname</i>  | (Optional) |
| <i>type</i>        | (Optional) |
| <i>tag</i>         | (Optional) |
| <i>stale</i>       | (Optional) |
| <i>unres</i>       | (Optional) |
| <i>hidden</i>      | (Optional) |
| <i>stale-label</i> | (Optional) |

**Command Mode**

- /exec

# show routing hidden-nh

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] hidden-nh [ __readonly__ <uribtibtype_contextname> [ <utibtibtype_topologyname> ]
{ TABLE_hidden_nh <hidden_nh_uhn_prefix> <hidden_nh_uhn_mask_len> <pib> <rnh> <rnh_mask_len>
} ]
```

## Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information             |
| routing                         | Display routing information                 |
| vrf                             | (Optional) Display per-VRF information      |
| <i>vrf-name</i>                 | (Optional) VRF name                         |
| <i>vrf-known-name</i>           | (Optional) Known VRF name                   |
| vrf-all                         | (Optional) Display information for all VRFs |
| ip                              | (Optional) Display IP information           |
| ipv4                            | (Optional) Display IP information           |
| unicast                         | (Optional) Display unicast information      |
| topology                        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>topology-name</i>            | (Optional) topology name                    |
| hidden-nh                       | Display hidden next-hop information         |
| <i>__readonly__</i>             | (Optional)                                  |
| <i>uribtibtype_contextname</i>  | (Optional)                                  |
| <i>utibtibtype_topologyname</i> | (Optional)                                  |
| TABLE_hidden_nh                 | (Optional)                                  |
| <i>hidden_nh_uhn_prefix</i>     | (Optional)                                  |
| <i>hidden_nh_uhn_mask_len</i>   | (Optional)                                  |
| <i>pib</i>                      | (Optional)                                  |
| <i>rnh</i>                      | (Optional)                                  |
| <i>rnh_mask_len</i>             | (Optional)                                  |

## Command Mode

- /exec

## show routing ipv6

```
show routing ipv6 [ unicast ] [ topology <topology-name> ] [ l3vm-info ] [ rpf ] [ <ipv6-addr> | { <ipv6-prefix>
[ { longer-prefixes | shorter-prefixes } ] } ] [ { <ipv6-protocol> [ all ] } | { bind-label <bind-lbl> | next-hop
<next-hop> } | { interface <interface> } | { updated { [ since <stime> ] [ until <utime> ] } } ] + [ summary [
cached ] | summary-counter-consistency-check | { [ detail ] [ deleted ] } ] [ vrf { <vrf-name> |
<vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [
TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> [ <attached> ] TABLE_path [ <ubest> ] [ <mbest>
] [ <ipnexthop> ] [ <nexthop-vrf-name> ] [ <ifname> ] [ <bindlbl> ] [ <srv6-funct> ] <uptime> <pref> <metric>
<clientname> [ <type> ] [ <tag> ] [ <stale> ] [ <stalelbl> ] [ <hidden> ] [ <remote-sid> ] [ <src-ip> ] [ <sid-fct>
] [ <bsid> ] ] [ TABLE_summary <routes> <paths> [ <multicast_paths> ] [ TABLE_unicast [ <clientnameuni>
] [ <best-paths> ] [ <backup-paths> ] ] [ TABLE_multicast [ <clientnamemulti> ] [ <best-paths> ] [
<backup-paths> ] ] [ TABLE_route_count [ <mask_len> ] [ <count> ] ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| routing               | Display routing information                                     |
| ipv6                  | Display IPv6 information  |
| vrf                   | (Optional) Display per-VRF information                          |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| vrf-all               | (Optional) Display information for all VRFs                     |
| unicast               | (Optional) Display unicast information                          |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| <i>topology-name</i>  | (Optional) topology name  |
| l3vm-info             | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                       |
| rpf                   | (Optional) Display RPF information for multicast source         |
| longer-prefixes       | (Optional) Display matching routes with mask-lengths >= prefix  |
| shorter-prefixes      | (Optional) Display matching routes with mask-lengths <= prefix  |
| <i>ipv6-protocol</i>  | (Optional) Display routes for protocol (or route type)          |
| all                   | (Optional) Display routes for protocol for backup next-hops too |
| bind-label            | (Optional) Display routes with this bind-label only             |
| <i>bind-lbl</i>       | (Optional) Binding label  |
| <i>srv6-funct</i>     | (Optional) Srv6 function  |

|  |   |
|--|---|
| <i>next-hop</i>                          | (Optional) Display routes with this next-hop only           |
| <i>interface</i>                         | (Optional) Display routes with this output interface only   |
| <i>interface</i>                         | (Optional) Interface Name                                   |
| <i>updated</i>                           | (Optional) Display routes filtered by last updated time     |
| <i>since</i>                             | (Optional) Display those routes updated since this time     |
| <i>stime</i>                             | (Optional) Since this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| <i>until</i>                             | (Optional) Display those routes updated until this time     |
| <i>utime</i>                             | (Optional) Until this date/time [[CC]YY-][MM-DD-]HH:MM[:SS] |
| <i>summary</i>                           | (Optional) Display route counts                             |
| <i>cached</i>                            | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>summary-counter-consistency-check</i> | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>deleted</i>                           | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                   |
| <i>detail</i>                            | (Optional) Display routes in full detail                    |
| <i>__readonly__</i>                      | (Optional)  |
| <i>TABLE_vrf</i>                         | (Optional)  |
| <i>vrf-name-out</i>                      | (Optional)  |
| <i>TABLE_addrf</i>                       | (Optional)  |
| <i>addrf</i>                             | (Optional)  |
| <i>TABLE_prefix</i>                      | (Optional)  |
| <i>ucast-nhops</i>                       | (Optional)  |
| <i>mcast-nhops</i>                       | (Optional)  |
| <i>attached</i>                          | (Optional)  |
| <i>TABLE_path</i>                        | (Optional)  |
| <i>ubest</i>                             | (Optional)  |
| <i>mbest</i>                             | (Optional)  |
| <i>nexthop-vrf-name</i>                  | (Optional)  |
| <i>ifname</i>                            | (Optional)  |
| <i>bindlbl</i>                           | (Optional)  |
| <i>pref</i>                              | (Optional)  |

|                        |            |
|------------------------|------------|
| <i>tag</i>             | (Optional) |
| <i>metric</i>          | (Optional) |
| <i>uptime</i>          | (Optional) |
| <i>clientname</i>      | (Optional) |
| <i>type</i>            | (Optional) |
| <i>stale</i>           | (Optional) |
| <i>stalelbl</i>        | (Optional) |
| <i>hidden</i>          | (Optional) |
| <i>remote-sid</i>      | (Optional) |
| <i>sid-fct</i>         | (Optional) |
| TABLE_summary          | (Optional) |
| <i>routes</i>          | (Optional) |
| <i>paths</i>           | (Optional) |
| <i>multicast_paths</i> | (Optional) |
| TABLE_unicast          | (Optional) |
| <i>clientnameuni</i>   | (Optional) |
| <i>best-paths</i>      | (Optional) |
| <i>backup-paths</i>    | (Optional) |
| TABLE_multicast        | (Optional) |
| <i>clientnamemulti</i> | (Optional) |
| <i>best-paths</i>      | (Optional) |
| <i>backup-paths</i>    | (Optional) |
| TABLE_route_count      | (Optional) |
| <i>mask_len</i>        | (Optional) |
| <i>count</i>           | (Optional) |

**Command Mode**

- /exec



## show routing ipv6 clients

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ]
clients [ <client> | <ipv6-protocol> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__
{ TABLE_client <client_name> <pib_index> <pib_state> [ <stale_reason> ] <pib_id>
<multicast_or_unicast_pib> <mru_cache_hits> <mru_cache_misses> [ <mts_sap> ] [ <mts_sap_str> ] [
<bad_l3vm_table_refcount> ] <pib_stale_time> [ { TABLE_nib_node <u6ribtibtype_contextname> <routes>
<rnh> [ { TABLE_notiferee_mask [ <u6pib_name> ] [ <index> } ] ] [ <u6tib_state> ] [ <pending_timer> ]
[ <u6rib_state_invalid> ] [ <u6nib_notifier_all> ] [ { TABLE_notify_rcd <notify_rcd_name>
<notify_rcd_handle> [ <notifier_pib_u6pib_index> } ] ] [ { TABLE_notiferee_nib <notiferee_pib_u6pib_name>
<u6nib_notify_handle> } ] ] ] [ { TABLE_ready_client_event_queue <queue_name><queue_count> [ {
TABLE_client_event <event> <use_buf> <sched> <resend> <buf> [ <state> } ] } ] [ {
TABLE_buffer_rqst_client_event_queue <queue_name><queue_count> [ { TABLE_client_event <event>
<use_buf> <sched> <resend> <buf> [ <state> } ] } ] ] <update_ack_queue_count> [ { TABLE_update_ack
<update_ack> <update_ack_data> <update_ack_type> <update_ack_xid> } ] ] [ {
TABLE_route_buffer_used_queue <queue_name> <queue_count> [ { TABLE_clt_buf
<clt_buf><clt_buf_count><clt_buf_xid> } ] } ] [ { TABLE_rnh_buffer_used_queue <queue_name>
<queue_count> [ { TABLE_clt_buf <clt_buf><clt_buf_count><clt_buf_xid> } ] } ] [ { TABLE_msgs_rcvd
<u6rib_mtype_str><u6pib_rcvd> } ] [ { TABLE_msgs_sent <u6rib_mtype_str><u6pib_sent> } ] } ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| routing               | Display routing information                        |
| vrf                   | (Optional) Display per-VRF information             |
| <i>vrf-name</i>       | (Optional) VRF name                                |
| <i>vrf-known-name</i> | (Optional) Known VRF name                          |
| vrf-all               | (Optional) Display information for all VRFs        |
| ipv6                  | Display IPv6 information                           |
| unicast               | (Optional) Display unicast information             |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED          |
| <i>topology-name</i>  | (Optional) topology name                           |
| clients               | Display u6rib client information                   |
| <i>client</i>         | (Optional) Display single u6rib client information |
| <i>ipv6-protocol</i>  | (Optional) Display single u6rib client information |
| __readonly__          | (Optional)   |
| TABLE_client          | (Optional)   |
| <i>client_name</i>    | (Optional)   |

|                                 |            |
|---------------------------------|------------|
| <i>pib_index</i>                | (Optional) |
| <i>pib_state</i>                | (Optional) |
| <i>stale_reason</i>             | (Optional) |
| <i>pib_id</i>                   | (Optional) |
| <i>multicast_or_unicast_pib</i> | (Optional) |
| <i>mru_cache_hits</i>           | (Optional) |
| <i>mru_cache_misses</i>         | (Optional) |
| <i>mts_sap</i>                  | (Optional) |
| <i>mts_sap_str</i>              | (Optional) |
| <i>bad_l3vm_table_refcount</i>  | (Optional) |
| <i>pib_stale_time</i>           | (Optional) |
| TABLE_nib_node                  | (Optional) |
| <i>u6ribtibtype_contextname</i> | (Optional) |
| <i>routes</i>                   | (Optional) |
| <i>rnhs</i>                     | (Optional) |
| TABLE_notifeee_mask             | (Optional) |
| <i>u6pib_name</i>               | (Optional) |
| <i>index</i>                    | (Optional) |
| <i>u6tib_state</i>              | (Optional) |
| <i>pending_timer</i>            | (Optional) |
| <i>u6rib_state_invalid</i>      | (Optional) |
| <i>u6nib_notifier_all</i>       | (Optional) |
| TABLE_notify_rcd                | (Optional) |
| <i>notify_rcd_name</i>          | (Optional) |
| <i>notify_rcd_handle</i>        | (Optional) |
| <i>notifier_pib_u6pib_index</i> | (Optional) |
| TABLE_notiffee_nib              | (Optional) |
| <i>notiffee_pib_u6pib_name</i>  | (Optional) |
| <i>u6nib_notify_handle</i>      | (Optional) |

|                                      |            |
|--------------------------------------|------------|
| TABLE_ready_client_event_queue       | (Optional) |
| <i>queue_name</i>                    | (Optional) |
| <i>queue_count</i>                   | (Optional) |
| TABLE_client_event                   | (Optional) |
| <i>event</i>                         | (Optional) |
| <i>use_buf</i>                       | (Optional) |
| <i>sched</i>                         | (Optional) |
| <i>resend</i>                        | (Optional) |
| <i>buf</i>                           | (Optional) |
| <i>state</i>                         | (Optional) |
| TABLE_buffer_rqst_client_event_queue | (Optional) |
| <i>queue_name</i>                    | (Optional) |
| <i>queue_count</i>                   | (Optional) |
| TABLE_client_event                   | (Optional) |
| <i>event</i>                         | (Optional) |
| <i>use_buf</i>                       | (Optional) |
| <i>sched</i>                         | (Optional) |
| <i>resend</i>                        | (Optional) |
| <i>buf</i>                           | (Optional) |
| <i>state</i>                         | (Optional) |
| <i>update_ack_queue_count</i>        | (Optional) |
| TABLE_update_ack                     | (Optional) |
| <i>update_ack</i>                    | (Optional) |
| <i>update_ack_data</i>               | (Optional) |
| <i>update_ack_type</i>               | (Optional) |
| <i>update_ack_xid</i>                | (Optional) |
| TABLE_route_buffer_used_queue        | (Optional) |
| TABLE_clt_buf                        | (Optional) |
| TABLE_rnh_buffer_used_queue          | (Optional) |

|                 |            |
|-----------------|------------|
| TABLE_clt_buf   | (Optional) |
| TABLE_msgs_rcvd | (Optional) |
| TABLE_msgs_sent | (Optional) |

**Command Mode**

- /exec

## show routing ipv6 hash

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] hash [ mpls <ipv6-prefix> [ eos ] ] <source> <dest> [ ip-proto <ip-proto> ] { [ ipv6-flowlabel <ipv6-flowlabel> ] } { [ <src-port> <dest-port> ] } { [ ttl <ttl> [ dest-port <dest-port> ] ] } { [ udf <value> length <length> [ dest-port <dest-port> ] ] } { [ gtpu-teid <gtpu-teid> ] } [ in-interface <in-interface> ] [ module <module-id> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> [ <hash-type> ] [ <mcast> ] [ <hashpath> ] TABLE_prefix <ipprefix> <ucast-nhops> <mcast-nhops> <attached> TABLE_path [ <ubest> ] [ <mbest> ] [ <ipnexthop> ] [ <ifname> ] <uptime> <pref> <metric> <clientname> [ <type> ] [ <tag> ] [ <stale> ] [ <hidden> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| routing               | Display routing information                          |
| vrf                   | (Optional) Display per-VRF information               |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| vrf-all               | (Optional) Display information for all VRFs          |
| ipv6                  | Display IPv6 information                             |
| unicast               | (Optional) Display unicast information               |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| <i>topology-name</i>  | (Optional) topology name                             |
| hash                  | Display load-balancing hash information              |
| mpls                  | (Optional) MPLS path load-balancing hash information |
| eos                   | (Optional) Set End-of-Stack to 1                     |
| ip-proto              | (Optional) IP Protocol information for the packet    |
| <i>ip-proto</i>       | (Optional) IP Protocol information for the packet    |
| ipv6-flowlabel        | (Optional) Flow label in the IPV6 packet             |
| <i>ipv6-flowlabel</i> | (Optional) Flow label in the IPV6 packet             |
| <i>src-port</i>       | (Optional) Source-port                               |
| <i>dest-port</i>      | (Optional) Destination-port                          |
| ttl                   | (Optional) TTL value for the packet                  |
| <i>ttl</i>            | (Optional) TTL value for the packet                  |

|                           |  |
|---------------------------|--|
| <code>udf</code>          | (Optional) UDF information for the packet  |
| <code>value</code>        | (Optional) UDF value for the packet  |
| <code>length</code>       | (Optional) Length in bits from udf offset  |
| <code>length</code>       | (Optional) Enter Length in bits from udf offset                                  |
| <code>dest-port</code>    | (Optional) Destination-port  |
| <code>dest-port</code>    | (Optional) Destination-port  |
| <code>gtpu-teid</code>    | (Optional) GTPu TEID for the packet  |
| <code>gtpu-teid</code>    | (Optional) GTPu TEID for the packet  |
| <code>in-interface</code> | (Optional) Incoming Interface for Packet.Option valid on Tomahawk platform only. |
| <code>in-interface</code> | (Optional) Interface Name  |
| <code>module</code>       | (Optional) Module  |
| <code>module-id</code>    | (Optional) Module  |
| <code>__readonly__</code> | (Optional)   |
| <code>TABLE_vrf</code>    | (Optional)   |
| <code>vrf-name-out</code> | (Optional)   |
| <code>hash-type</code>    | (Optional)   |
| <code>mcast</code>        | (Optional)   |
| <code>hashpath</code>     | (Optional)   |
| <code>TABLE_prefix</code> | (Optional)   |
| <code>ipprefix</code>     | (Optional)   |
| <code>ucast-nhops</code>  | (Optional)   |
| <code>mcast-nhops</code>  | (Optional)   |
| <code>attached</code>     | (Optional)   |
| <code>TABLE_path</code>   | (Optional)   |
| <code>ubest</code>        | (Optional)   |
| <code>mbest</code>        | (Optional)   |
| <code>ifname</code>       | (Optional)   |
| <code>pref</code>         | (Optional)   |

|                   |            |
|-------------------|------------|
| <i>tag</i>        | (Optional) |
| <i>metric</i>     | (Optional) |
| <i>uptime</i>     | (Optional) |
| <i>clientname</i> | (Optional) |
| <i>type</i>       | (Optional) |
| <i>stale</i>      | (Optional) |
| <i>hidden</i>     | (Optional) |

**Command Mode**

- /exec

## show routing ipv6 hidden-nh

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] hidden-nh [ __readonly__ <uribtibtype_contextname> { TABLE_hidden_nh <nh> <nh-iod> <hidden_nh_uhn_prefix> <hidden_nh_uhn_mask_len> <pib> <rn timer> <rn timer_mask_len> } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information             |
| routing                        | Display routing information                 |
| vrf                            | (Optional) Display per-VRF information      |
| <i>vrf-name</i>                | (Optional) VRF name                         |
| <i>vrf-known-name</i>          | (Optional) Known VRF name                   |
| vrf-all                        | (Optional) Display information for all VRFs |
| ipv6                           | Display IPv6 information                    |
| unicast                        | (Optional) Display unicast information      |
| topology                       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>topology-name</i>           | (Optional) topology name                    |
| hidden-nh                      | Display hidden next-hop information         |
| <i>__readonly__</i>            | (Optional)                                  |
| <i>uribtibtype_contextname</i> | (Optional)                                  |
| TABLE_hidden_nh                | (Optional)                                  |
| <i>nh</i>                      | (Optional)                                  |
| <i>nh-iod</i>                  | (Optional)                                  |
| <i>hidden_nh_uhn_prefix</i>    | (Optional)                                  |
| <i>hidden_nh_uhn_mask_len</i>  | (Optional)                                  |
| <i>pib</i>                     | (Optional)                                  |
| <i>rn timer</i>                | (Optional)                                  |
| <i>rn timer_mask_len</i>       | (Optional)                                  |

### Command Mode

- /exec



## show routing ipv6 memory estimate

```
show routing ipv6 [ unicast ] memory estimate [ routes <route-count> next-hops <nh-count> ] [ labels ] [
__readonly__ <curr-max-MB> <curr-max-routes> <curr-max-nh> <inuse-MB> <inuse-routes> <inuse-nh>
<conf-max-MB> <conf-max-routes> <conf-max-nh> [ <est-MB> <est-routes> <est-nh> ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                    |
| routing                | Display routing information  |
| ipv6                   | Display IPv6 information   |
| unicast                | (Optional) Display unicast information                             |
| memory                 | Display u6rib memory information                                   |
| estimate               | Display u6rib memory estimate                                      |
| routes                 | (Optional) Display u6rib memory estimate for # routes              |
| <i>route-count</i>     | (Optional) Number of routes  |
| next-hops              | (Optional) Display u6rib memory estimate for # next-hops per route |
| <i>nh-count</i>        | (Optional) Number of next-hops per route                           |
| labels                 | (Optional) When the routes are associated with next hop labels     |
| <i>__readonly__</i>    | (Optional)   |
| <i>curr-max-MB</i>     | (Optional)   |
| <i>curr-max-routes</i> | (Optional)   |
| <i>curr-max-nh</i>     | (Optional)   |
| <i>inuse-MB</i>        | (Optional)   |
| <i>inuse-routes</i>    | (Optional)   |
| <i>inuse-nh</i>        | (Optional)   |
| <i>conf-max-MB</i>     | (Optional)   |
| <i>conf-max-routes</i> | (Optional)   |
| <i>conf-max-nh</i>     | (Optional)   |
| <i>est-MB</i>          | (Optional)   |
| <i>est-routes</i>      | (Optional)   |
| <i>est-nh</i>          | (Optional)   |

**Command Mode**

- /exec

## show routing ipv6 memory statistics

```
show routing ipv6 [ unicast ] memory statistics [ __readonly__ { TABLE_shrd_mem <rbuf-alloc>
<rbuf-high-water> <rbuf-max> <rbuf-numalloc> <slbs-alloc> <slbs-high-water> <slbs-max> <slbs-numalloc>
} { TABLE_u6rib_slabs <slab-name> <alloc-count> <max-allocs> <slab-size> } { TABLE_u6rib_blks
<slab-blk-name> <block-count> <max-blocks> <slab-count> } { TABLE_u6rib_routes_rnhs <ctx-name>
<user-nodes> <total-nodes> <elem-size> } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                |
| routing                 | Display routing information                    |
| ipv6                    | Display IPv6 information                       |
| unicast                 | (Optional) Display unicast routing information |
| memory                  | Display u6rib memory information               |
| statistics              | Display u6rib memory statistics                |
| <i>__readonly__</i>     | (Optional)                                     |
| TABLE_shrd_mem          | (Optional)                                     |
| TABLE_u6rib_slabs       | (Optional)                                     |
| TABLE_u6rib_blks        | (Optional)                                     |
| TABLE_u6rib_routes_rnhs | (Optional)                                     |
| <i>ctx-name</i>         | (Optional)                                     |
| <i>slab-name</i>        | (Optional)                                     |
| <i>slab-blk-name</i>    | (Optional)                                     |
| <i>rbuf-alloc</i>       | (Optional)                                     |
| <i>rbuf-high-water</i>  | (Optional)                                     |
| <i>rbuf-max</i>         | (Optional)                                     |
| <i>rbuf-numalloc</i>    | (Optional)                                     |
| <i>slbs-alloc</i>       | (Optional)                                     |
| <i>slbs-high-water</i>  | (Optional)                                     |
| <i>slbs-max</i>         | (Optional)                                     |
| <i>slbs-numalloc</i>    | (Optional)                                     |
| <i>user-nodes</i>       | (Optional)                                     |

|                    |            |
|--------------------|------------|
| <i>total-nodes</i> | (Optional) |
| <i>elem-size</i>   | (Optional) |
| <i>alloc-count</i> | (Optional) |
| <i>max-allocs</i>  | (Optional) |
| <i>slab-size</i>   | (Optional) |
| <i>block-count</i> | (Optional) |
| <i>max-blocks</i>  | (Optional) |
| <i>slab-count</i>  | (Optional) |

**Command Mode**

- /exec

## show routing ipv6 multicast clients

```
show routing ipv6 multicast clients [ <client-name> ] [ detail ] [ __readonly__ { TABLE_mpib <mpib_name>
<mpib_index> <mpib_pid> <mpib_mts_sap> <mpib_shm> <stale_timer> <join_notify> <prune_notify>
<rpf_notify> <delete_notify> <repopulate_notify> <zero-oif-notify> <non-zero-oif-notify> <attach-notify>
<non-attach-notify> <static-notify> <non-static-notify> <internal-notify>
<non-internal-notify><external-notify><non-external-notify> <otv-decap-notify>
<no-otv-decap-notify><vxlan-decap-notify> <no-vxlan-decap-notify>
<mdt-encap-notify><no-mdt-encap-notify> <mdt-decap-notify> <no-mdt-decap-notify><vpc-svi-notify>
<eor-notify> <notification_pending> [ <ssm_owner> <bidir_owner> <static_owner> <shared_only_owner>
<locally_joined_owner> <external_owner> <mdt_owner> <fabric_owner> <sticky_iif_owner>
<data_created_owner> <internal_owner> <prune_owner> <attached_owner> <otv_decap_owner>
<vxlan_decap_owner> <secondary_owner> <encap_index_owner> <force_punt_owner> <multi_route_owner>
<register_stop_owner> ] <notify_sent> <notify_fail> <notify_ack_rcvd> <add_route_req_rcvd>
<add_route_ack_sent> <add_route_ack_fail> <delete_route_req_rcvd> <delete_route_ack_sent>
<delete_route_ack_fail> <update_route_req_rcvd> <update_route_ack_sent> <update_route_ack_fail>
<update_mdt_info_req_rcvd> <update_mdt_info_ack_sent> <update_mdt_info_ack_fail>
<mts_update_route_req_rcvd> <mts_update_route_ack_sent> <mts_update_route_ack_fail>
<force_update_rcvd> <notify_member_count> <pending_mpib> <uptime> <allsync_eor_sent>
<allsync_eor_fail> <allsync_eor_send_ts> <vrf_rte_sync_eor_sent> <vrf_rte_sync_eor_fail>
<vrf_rte_sync_eor_send_ts> <allsync_eor_rte_pend_vrf> } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information              |
| routing             | Display routing information                  |
| ipv6                | Display IPv6 information                     |
| multicast           | Display multicast information                |
| clients             | Display multicast routing client information |
| <i>client-name</i>  | (Optional) Multicast routing client name     |
| detail              | (Optional) Display detailed route attributes |
| <u>__readonly__</u> | (Optional)                                   |
| TABLE_mpib          | (Optional)                                   |
| <i>mpib_name</i>    | (Optional)                                   |
| <i>mpib_index</i>   | (Optional)                                   |
| <i>mpib_pid</i>     | (Optional)                                   |
| <i>mpib_mts_sap</i> | (Optional)                                   |
| <i>mpib_shm</i>     | (Optional)                                   |
| <i>stale_timer</i>  | (Optional)                                   |

|                              |            |
|------------------------------|------------|
| <i>join_notify</i>           | (Optional) |
| <i>prune_notify</i>          | (Optional) |
| <i>rpf_notify</i>            | (Optional) |
| <i>delete_notify</i>         | (Optional) |
| <i>repopulate_notify</i>     | (Optional) |
| <i>zero-oif-notify</i>       | (Optional) |
| <i>non-zero-oif-notify</i>   | (Optional) |
| <i>attach-notify</i>         | (Optional) |
| <i>non-attach-notify</i>     | (Optional) |
| <i>static-notify</i>         | (Optional) |
| <i>non-static-notify</i>     | (Optional) |
| <i>internal-notify</i>       | (Optional) |
| <i>otv-decap-notify</i>      | (Optional) |
| <i>no-vxlan-decap-notify</i> | (Optional) |
| <i>mdt-decap-notify</i>      | (Optional) |
| <i>eor-notify</i>            | (Optional) |
| <i>notification_pending</i>  | (Optional) |
| <i>ssm_owner</i>             | (Optional) |
| <i>bidir_owner</i>           | (Optional) |
| <i>static_owner</i>          | (Optional) |
| <i>shared_only_owner</i>     | (Optional) |
| <i>locally_joined_owner</i>  | (Optional) |
| <i>external_owner</i>        | (Optional) |
| <i>mdt_owner</i>             | (Optional) |
| <i>fabric_owner</i>          | (Optional) |
| <i>sticky_iif_owner</i>      | (Optional) |
| <i>data_created_owner</i>    | (Optional) |
| <i>internal_owner</i>        | (Optional) |
| <i>prune_owner</i>           | (Optional) |

|                                  |            |
|----------------------------------|------------|
| <i>attached_owner</i>            | (Optional) |
| <i>otv_decap_owner</i>           | (Optional) |
| <i>vxlan_decap_owner</i>         | (Optional) |
| <i>secondary_owner</i>           | (Optional) |
| <i>encap_index_owner</i>         | (Optional) |
| <i>force_punt_owner</i>          | (Optional) |
| <i>multi_route_owner</i>         | (Optional) |
| <i>register_stop_owner</i>       | (Optional) |
| <i>notify_sent</i>               | (Optional) |
| <i>notify_fail</i>               | (Optional) |
| <i>notify_ack_rcvd</i>           | (Optional) |
| <i>add_route_req_rcvd</i>        | (Optional) |
| <i>add_route_ack_sent</i>        | (Optional) |
| <i>add_route_ack_fail</i>        | (Optional) |
| <i>delete_route_req_rcvd</i>     | (Optional) |
| <i>delete_route_ack_sent</i>     | (Optional) |
| <i>delete_route_ack_fail</i>     | (Optional) |
| <i>update_route_req_rcvd</i>     | (Optional) |
| <i>update_route_ack_sent</i>     | (Optional) |
| <i>update_route_ack_fail</i>     | (Optional) |
| <i>update_mdt_info_req_rcvd</i>  | (Optional) |
| <i>update_mdt_info_ack_sent</i>  | (Optional) |
| <i>update_mdt_info_ack_fail</i>  | (Optional) |
| <i>mts_update_route_req_rcvd</i> | (Optional) |
| <i>mts_update_route_ack_sent</i> | (Optional) |
| <i>mts_update_route_ack_fail</i> | (Optional) |
| <i>force_update_rcvd</i>         | (Optional) |
| <i>notify_member_count</i>       | (Optional) |
| <i>pending_mpib</i>              | (Optional) |

|                                 |            |
|---------------------------------|------------|
| <i>uptime</i>                   | (Optional) |
| <i>allsync_eor_sent</i>         | (Optional) |
| <i>allsync_eor_fail</i>         | (Optional) |
| <i>allsync_eor_send_ts</i>      | (Optional) |
| <i>vrf_rte_sync_eor_sent</i>    | (Optional) |
| <i>vrf_rte_sync_eor_fail</i>    | (Optional) |
| <i>vrf_rte_sync_eor_send_ts</i> | (Optional) |
| <i>allsync_eor_rte_pend_vrf</i> | (Optional) |

**Command Mode**

- /exec



## show routing ipv6 multicast lisp encap

```
{ show routing ipv6 multicast lisp encap } [ __readonly__ { TABLE_m6rib_list_encap <encap-index>
<source-rloc> <dest-rloc> <ref-count> } ]
```

### Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| routing                | Display routing information     |
| ipv6                   | Display IPv6 information        |
| multicast              | Display multicast information   |
| lisp                   | LISP related information        |
| encap                  | All the encap indices           |
| <i>__readonly__</i>    | (Optional)                      |
| TABLE_m6rib_list_encap | (Optional)                      |
| <i>encap-index</i>     | (Optional)                      |
| <i>source-rloc</i>     | (Optional)                      |
| <i>dest-rloc</i>       | (Optional)                      |
| <i>ref-count</i>       | (Optional)                      |

### Command Mode

- /exec

## show routing ipv6 multicast mdt encapsulation

```
show routing ipv6 multicast mdt encapsulation [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all } ] [
__readonly__ [ TABLE_vrf <vrf-name> [ TABLE_mdt <index> <group> <source> <count> <delete-pending>
]]]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| routing               | Display routing information                 |
| ipv6                  | Display IPv6 information                    |
| multicast             | Display multicast information               |
| mdt                   | Multicast Distribution Tree                 |
| encapsulation         | Encapsulation Information                   |
| detail                | (Optional) Display detailed information     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>vrf-name</i>       | (Optional)                                  |
| TABLE_mdt             | (Optional)                                  |
| <i>index</i>          | (Optional)                                  |
| <i>count</i>          | (Optional)                                  |
| <i>delete-pending</i> | (Optional)                                  |

### Command Mode

- /exec

## show routing ipv6 multicast memory estimate

```
show routing ipv6 multicast memory estimate [ groups <group-count> sources-per-group <source-count>
oifs-per-entry <oif-count> [ mdt-encap-entries <encap-entry-count> ] [ __readonly__ [ TABLE_currentmax
[ <max-mb> ] [ <max-groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] ] [ TABLE_inuse [ <used-kb>
] [ <alloc-count> ] [ <sources-per-group> ] [ <oifs-per-entry> ] [ <mdt-encap-entry> ] ] [
TABLE_configuredmax [ <max-mb> ] [ <max-groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] ] [
TABLE_estimate [ <estimate-mb> ] [ <groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] [
<mdt-encap-entry> ] ] ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information   |
| routing                  | Display routing information   |
| ipv6                     | Display IPv6 information  |
| multicast                | Display multicast information   |
| memory                   | Display mrib memory information   |
| estimate                 | Display mrib memory estimate  |
| groups                   | (Optional) Display mrib memory estimate for # groups                        |
| <i>group-count</i>       | (Optional) Number of groups   |
| sources-per-group        | (Optional) Display mrib memory estimate for # sources per group             |
| <i>source-count</i>      | (Optional) Number of sources per route                                      |
| oifs-per-entry           | (Optional) Display mrib memory estimate for # oifs per (S,G) or (*,G) entry |
| <i>oif-count</i>         | (Optional) Number of oifs per entry   |
| mdt-encap-entries        | (Optional) Display mrib memory estimate for # mdt encap entries             |
| <i>encap-entry-count</i> | (Optional) Number of mdt encap entries                                      |
| __readonly__             | (Optional)  |
| TABLE_currentmax         | (Optional)  |
| <i>max-mb</i>            | (Optional)  |
| <i>max-groups</i>        | (Optional)  |
| <i>sources-per-group</i> | (Optional)  |
| <i>oifs-per-entry</i>    | (Optional)  |
| TABLE_inuse              | (Optional)  |

|                          |            |
|--------------------------|------------|
| <i>used-kb</i>           | (Optional) |
| <i>alloc-count</i>       | (Optional) |
| <i>sources-per-group</i> | (Optional) |
| <i>oifs-per-entry</i>    | (Optional) |
| <i>mdt-encap-entry</i>   | (Optional) |
| TABLE_configuredmax      | (Optional) |
| <i>max-mb</i>            | (Optional) |
| <i>max-groups</i>        | (Optional) |
| <i>sources-per-group</i> | (Optional) |
| <i>oifs-per-entry</i>    | (Optional) |
| TABLE_estimate           | (Optional) |
| <i>estimate-mb</i>       | (Optional) |
| <i>groups</i>            | (Optional) |
| <i>sources-per-group</i> | (Optional) |
| <i>oifs-per-entry</i>    | (Optional) |
| <i>mdt-encap-entry</i>   | (Optional) |

**Command Mode**

- /exec

## show routing ipv6 multicast sr

```
show routing ipv6 multicast sr [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [ TABLE_vrf
<vrf-name> <mode> <mac-rewrite> [ TABLE_route <in-group-range> <to-group-range> <group-mask>
<in-source-range> <to-source-range> <source-mask> <udp-src-port> <udp-dest-port> <static-oif> ] ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information             |
| routing                | Display routing information                 |
| ipv6                   | Display IPv6 information                    |
| multicast              | Display multicast information               |
| sr                     | Service Reflect Rules                       |
| vrf                    | (Optional) Display per-VRF information      |
| <i>vrf-name</i>        | (Optional) VRF name                         |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                   |
| all                    | (Optional) Display information for all VRFs |
| __readonly__           | (Optional)                                  |
| TABLE_vrf              | (Optional)                                  |
| <i>vrf-name</i>        | (Optional)                                  |
| <i>mode</i>            | (Optional)                                  |
| <i>mac-rewrite</i>     | (Optional)                                  |
| TABLE_route            | (Optional)                                  |
| <i>in-group-range</i>  | (Optional)                                  |
| <i>to-group-range</i>  | (Optional)                                  |
| <i>group-mask</i>      | (Optional)                                  |
| <i>in-source-range</i> | (Optional)                                  |
| <i>to-source-range</i> | (Optional)                                  |
| <i>source-mask</i>     | (Optional)                                  |
| <i>udp-src-port</i>    | (Optional)                                  |
| <i>udp-dest-port</i>   | (Optional)                                  |
| <i>static-oif</i>      | (Optional)                                  |

**Command Mode**

- /exec

## show routing ipv6 nhlfe

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] nhlfe [ stats ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ { TABLE_vrf <vrf-name-out> [ <nhlfe-owner> <nhlfe-refcount> { TABLE_nhlable <nhlable-index> <nh-label> } <nhlfe-is-vpn> <nhlfe-owner-index> } ] <total-entries> } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information             |
| routing                  | Display routing information                 |
| vrf                      | (Optional) Display per-VRF information      |
| <i>vrf-name</i>          | (Optional) VRF name                         |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                   |
| vrf-all                  | (Optional) Display information for all VRFs |
| ipv6                     | Display IPv6 information                    |
| unicast                  | (Optional) Display unicast information      |
| topology                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>topology-name</i>     | (Optional) topology name                    |
| nhlfe                    | Display NHLFE db                            |
| stats                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>__readonly__</i>      | (Optional)                                  |
| TABLE_vrf                | (Optional)                                  |
| <i>vrf-name-out</i>      | (Optional)                                  |
| <i>nhlfe-owner</i>       | (Optional)                                  |
| <i>nhlfe-refcount</i>    | (Optional)                                  |
| TABLE_nhlable            | (Optional)                                  |
| <i>nhlable-index</i>     | (Optional)                                  |
| <i>nh-label</i>          | (Optional)                                  |
| <i>nhlfe-is-vpn</i>      | (Optional)                                  |
| <i>nhlfe-owner-index</i> | (Optional)                                  |
| <i>total-entries</i>     | (Optional)                                  |

**Command Mode**

- /exec



## show routing ipv6 recursive-next-hop

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 [ unicast ] [ topology <topology-name> ] recursive-next-hop [ <ipv6-addr> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [ TABLE_prefix <ipprefix> <uptime> TABLE_clients <client-req> [ <client-pend> ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| routing               | Display routing information                 |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| vrf-all               | (Optional) Display information for all VRFs |
| ipv6                  | Display IPv6 information                    |
| unicast               | (Optional) Display unicast information      |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>topology-name</i>  | (Optional) topology name                    |
| recursive-next-hop    | Display recursive next-hop table            |
| __readonly__          | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>vrf-name-out</i>   | (Optional)                                  |
| TABLE_addrf           | (Optional)                                  |
| <i>addrf</i>          | (Optional)                                  |
| TABLE_prefix          | (Optional)                                  |
| <i>uptime</i>         | (Optional)                                  |
| TABLE_clients         | (Optional)                                  |
| <i>client-req</i>     | (Optional)                                  |
| <i>client-pend</i>    | (Optional)                                  |

### Command Mode

- /exec

## show routing memory estimate

```
show routing [ ip | ipv4 ] [ unicast ] memory estimate [ routes <route-count> [ next-hops <nh-count>
<nh-unique> ] [ next-hops-v6 <nh6-count> <nh6-unique> ] [ next-hops-srte <srte-count> <srte-unique> ] ] [
labels ] [ __readonly__ <current_max_mb> <current_max_routes> <urib_max_nh> <used_mb>
<route_stats_alloc_count> <nhs> <configured_max_mb> <configured_max_routes> <urib_routes_max_nh>
[ <estimate_mb> <estimate_routes> <estimate_nhs> <estimate_with_mvpn_mb> <estimate_with_ospf_mb>
<estimate_with_eigrp_mb> ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information   |
| routing             | Display routing information   |
| ip                  | (Optional) Display IP information   |
| ipv4                | (Optional) Display IP information   |
| unicast             | (Optional) Display unicast information  |
| memory              | Display urib memory information   |
| estimate            | Display urib memory estimate  |
| routes              | (Optional) Display urib memory estimate for # routes                              |
| <i>route-count</i>  | (Optional) Number of routes   |
| next-hops           | (Optional) Display urib memory estimate for # next-hops per route                 |
| <i>nh-count</i>     | (Optional) Number of next-hops per route  |
| <i>nh-unique</i>    | (Optional) Number of unique next-hops (between 1 and route-count*nh-count)        |
| next-hops-v6        | (Optional) Display urib memory estimate for # V6 next-hops per route              |
| <i>nh6-count</i>    | (Optional) Number of V6 next-hops per route                                       |
| <i>nh6-unique</i>   | (Optional) Number of unique V6 next-hops (between 1 and route-count*nh6-count)    |
| next-hops-srte      | (Optional) Display urib memory estimate for # srte next-hops per route            |
| <i>srte-count</i>   | (Optional) Number of srte next-hops per route                                     |
| <i>srte-unique</i>  | (Optional) Number of unique srte next-hops (between 1 and route-count*srte-count) |
| labels              | (Optional) When the routes are associated with next hop labels                    |
| <i>__readonly__</i> | (Optional)  |

|                                |            |
|--------------------------------|------------|
| <i>current_max_mb</i>          | (Optional) |
| <i>current_max_routes</i>      | (Optional) |
| <i>urib_max_nh</i>             | (Optional) |
| <i>used_mb</i>                 | (Optional) |
| <i>route_stats_alloc_count</i> | (Optional) |
| <i>nhs</i>                     | (Optional) |
| <i>configured_max_mb</i>       | (Optional) |
| <i>configured_max_routes</i>   | (Optional) |
| <i>urib_routes_max_nh</i>      | (Optional) |
| <i>estimate_mb</i>             | (Optional) |
| <i>estimate_routes</i>         | (Optional) |
| <i>estimate_nhs</i>            | (Optional) |
| <i>estimate_with_mvpn_mb</i>   | (Optional) |
| <i>estimate_with_ospf_mb</i>   | (Optional) |
| <i>estimate_with_eigrp_mb</i>  | (Optional) |

### Command Mode

- /exec

# show routing memory statistics

```
show routing [ ip | ipv4 ] [ unicast ] memory statistics [ debug ] [ __readonly__ { TABLE_shrd_mem
<ubuf-alloc> <ubuf-high-water> <ubuf-max> <ubuf-numalloc> <rbuf-alloc> <rbuf-high-water> <rbuf-max>
<rbuf-numalloc> <slbs-alloc> <slbs-high-water> <slbs-max> <slbs-numalloc> } { TABLE_urib_slabs
<slab-name> <slab-alloc-count> <slab-max-allocs> <slab-size> } { TABLE_urib_blks <block-name>
<block-count> <max-blocks> <blks-count> } { TABLE_urib_routes_rnhs <ctx-name> <user-node>
<total-node> <elem-size> } ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information           |
| routing                | Display routing information               |
| ip                     | (Optional) Display IP information         |
| ipv4                   | (Optional) Display IP information         |
| unicast                | (Optional) Display unicast information    |
| memory                 | Display urib memory information           |
| statistics             | Display urib memory statistics            |
| debug                  | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__           | (Optional)                                |
| TABLE_shrd_mem         | (Optional)                                |
| <i>ubuf-alloc</i>      | (Optional)                                |
| <i>ubuf-high-water</i> | (Optional)                                |
| <i>ubuf-max</i>        | (Optional)                                |
| <i>ubuf-numalloc</i>   | (Optional)                                |
| <i>rbuf-alloc</i>      | (Optional)                                |
| <i>rbuf-high-water</i> | (Optional)                                |
| <i>rbuf-max</i>        | (Optional)                                |
| <i>rbuf-numalloc</i>   | (Optional)                                |
| <i>slbs-alloc</i>      | (Optional)                                |
| <i>slbs-high-water</i> | (Optional)                                |
| <i>slbs-max</i>        | (Optional)                                |
| <i>slbs-numalloc</i>   | (Optional)                                |

|                         |            |
|-------------------------|------------|
| TABLE_urib_slabs        | (Optional) |
| <i>slab-name</i>        | (Optional) |
| <i>slab-alloc-count</i> | (Optional) |
| <i>slab-max-allocs</i>  | (Optional) |
| <i>slab-size</i>        | (Optional) |
| TABLE_urib_blks         | (Optional) |
| <i>block-name</i>       | (Optional) |
| <i>block-count</i>      | (Optional) |
| <i>max-blocks</i>       | (Optional) |
| <i>blks-count</i>       | (Optional) |
| TABLE_urib_routes_rnhs  | (Optional) |
| <i>ctx-name</i>         | (Optional) |
| <i>user-node</i>        | (Optional) |
| <i>total-node</i>       | (Optional) |
| <i>elem-size</i>        | (Optional) |

**Command Mode**

- /exec

## show routing multicast clients

```
show routing [ ip | ipv4 ] multicast clients [ <client-name> ] [ detail ] [ __readonly__ { TABLE_mpib
<mpib_name> <mpib_index> <mpib_pid> <mpib_mts_sap> <mpib_shm> <stale_timer> <join_notify>
<prune_notify> <rpf_notify> <delete_notify> <repopulate_notify> <zero-oif-notify> <non-zero-oif-notify>
<attach_notify> <non-attach_notify> <static_notify> <non-static_notify> <internal_notify>
<non-internal_notify><external_notify><non-external_notify> <otv-decap_notify>
<no-otv-decap_notify><vxlan-decap_notify> <no-vxlan-decap_notify>
<mdt-encap_notify><no-mdt-encap_notify> <mdt-decap_notify> <no-mdt-decap_notify><vpc-svi_notify>
<eor_notify> <notification_pending> [ <ssm_owner> <bidir_owner> <static_owner> <shared_only_owner>
<locally_joined_owner> <external_owner> <mdt_owner> <fabric_owner> <sticky_iif_owner>
<data_created_owner> <internal_owner> <prune_owner> <attached_owner> <otv_decap_owner>
<vxlan_decap_owner> <secondary_owner> <encap_index_owner> <force_punt_owner> <multi_route_owner>
<register_stop_owner> ] <notify_sent> <notify_fail> <notify_ack_rcvd> <add_route_req_rcvd>
<add_route_ack_sent> <add_route_ack_fail> <delete_route_req_rcvd> <delete_route_ack_sent>
<delete_route_ack_fail> <update_route_req_rcvd> <update_route_ack_sent> <update_route_ack_fail>
<update_mdt_info_req_rcvd> <update_mdt_info_ack_sent> <update_mdt_info_ack_fail>
<mts_update_route_req_rcvd> <mts_update_route_ack_sent> <mts_update_route_ack_fail>
<force_update_rcvd> <notify_member_count> <pending_mpib> <uptime> <allsync_eor_sent>
<allsync_eor_fail> <allsync_eor_send_ts> <vrf_rte_sync_eor_sent> <vrf_rte_sync_eor_fail>
<vrf_rte_sync_eor_send_ts> <allsync_eor_rte_pend_vrf> } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information              |
| routing             | Display routing information                  |
| ip                  | (Optional) Display IP information            |
| ipv4                | (Optional) Display IP information            |
| multicast           | Display multicast information                |
| clients             | Display multicast routing client information |
| <i>client-name</i>  | (Optional) Multicast routing client name     |
| detail              | (Optional) Display detailed route attributes |
| __readonly__        | (Optional)                                   |
| TABLE_mpib          | (Optional)                                   |
| <i>mpib_name</i>    | (Optional)                                   |
| <i>mpib_index</i>   | (Optional)                                   |
| <i>mpib_pid</i>     | (Optional)                                   |
| <i>mpib_mts_sap</i> | (Optional)                                   |
| <i>mpib_shm</i>     | (Optional)                                   |

|                              |            |
|------------------------------|------------|
| <i>stale_timer</i>           | (Optional) |
| <i>join_notify</i>           | (Optional) |
| <i>prune_notify</i>          | (Optional) |
| <i>rpf_notify</i>            | (Optional) |
| <i>delete_notify</i>         | (Optional) |
| <i>repopulate_notify</i>     | (Optional) |
| <i>zero-oif-notify</i>       | (Optional) |
| <i>non-zero-oif-notify</i>   | (Optional) |
| <i>attach-notify</i>         | (Optional) |
| <i>non-attach-notify</i>     | (Optional) |
| <i>static-notify</i>         | (Optional) |
| <i>non-static-notify</i>     | (Optional) |
| <i>internal-notify</i>       | (Optional) |
| <i>otv-decap-notify</i>      | (Optional) |
| <i>no-vxlan-decap-notify</i> | (Optional) |
| <i>mdt-decap-notify</i>      | (Optional) |
| <i>eor-notify</i>            | (Optional) |
| <i>notification_pending</i>  | (Optional) |
| <i>ssm_owner</i>             | (Optional) |
| <i>bidir_owner</i>           | (Optional) |
| <i>static_owner</i>          | (Optional) |
| <i>shared_only_owner</i>     | (Optional) |
| <i>locally_joined_owner</i>  | (Optional) |
| <i>external_owner</i>        | (Optional) |
| <i>mdt_owner</i>             | (Optional) |
| <i>fabric_owner</i>          | (Optional) |
| <i>sticky_iif_owner</i>      | (Optional) |
| <i>data_created_owner</i>    | (Optional) |
| <i>internal_owner</i>        | (Optional) |

|                                  |            |
|----------------------------------|------------|
| <i>prune_owner</i>               | (Optional) |
| <i>attached_owner</i>            | (Optional) |
| <i>otv_decap_owner</i>           | (Optional) |
| <i>vxlان_decap_owner</i>         | (Optional) |
| <i>secondary_owner</i>           | (Optional) |
| <i>encap_index_owner</i>         | (Optional) |
| <i>force_punt_owner</i>          | (Optional) |
| <i>multi_route_owner</i>         | (Optional) |
| <i>register_stop_owner</i>       | (Optional) |
| <i>notify_sent</i>               | (Optional) |
| <i>notify_fail</i>               | (Optional) |
| <i>notify_ack_rcvd</i>           | (Optional) |
| <i>add_route_req_rcvd</i>        | (Optional) |
| <i>add_route_ack_sent</i>        | (Optional) |
| <i>add_route_ack_fail</i>        | (Optional) |
| <i>delete_route_req_rcvd</i>     | (Optional) |
| <i>delete_route_ack_sent</i>     | (Optional) |
| <i>delete_route_ack_fail</i>     | (Optional) |
| <i>update_route_req_rcvd</i>     | (Optional) |
| <i>update_route_ack_sent</i>     | (Optional) |
| <i>update_route_ack_fail</i>     | (Optional) |
| <i>update_mdt_info_req_rcvd</i>  | (Optional) |
| <i>update_mdt_info_ack_sent</i>  | (Optional) |
| <i>update_mdt_info_ack_fail</i>  | (Optional) |
| <i>mts_update_route_req_rcvd</i> | (Optional) |
| <i>mts_update_route_ack_sent</i> | (Optional) |
| <i>mts_update_route_ack_fail</i> | (Optional) |
| <i>force_update_rcvd</i>         | (Optional) |
| <i>notify_member_count</i>       | (Optional) |



|                                 |            |
|---------------------------------|------------|
| <i>pending_mplib</i>            | (Optional) |
| <i>uptime</i>                   | (Optional) |
| <i>allsync_eor_sent</i>         | (Optional) |
| <i>allsync_eor_fail</i>         | (Optional) |
| <i>allsync_eor_send_ts</i>      | (Optional) |
| <i>vrf_rte_sync_eor_sent</i>    | (Optional) |
| <i>vrf_rte_sync_eor_fail</i>    | (Optional) |
| <i>vrf_rte_sync_eor_send_ts</i> | (Optional) |
| <i>allsync_eor_rte_pend_vrf</i> | (Optional) |

**Command Mode**

- /exec

# show routing multicast lisp encap

```
{ show routing [ ip | ipv4 ] multicast lisp encap } [ __readonly__ { TABLE_mrib_list_encap <encap-index>
<source-rloc> <dest-rloc> <ref-count> } ]
```

## Syntax Description

|                       |                                   |
|-----------------------|-----------------------------------|
| show                  | Show running system information   |
| routing               | Display routing information       |
| ip                    | (Optional) Display IP information |
| ipv4                  | (Optional) Display IP information |
| multicast             | Display multicast information     |
| lisp                  | LISP related information          |
| encap                 | All the encap indices             |
| __readonly__          | (Optional)                        |
| TABLE_mrib_list_encap | (Optional)                        |
| <i>encap-index</i>    | (Optional)                        |
| <i>source-rloc</i>    | (Optional)                        |
| <i>dest-rloc</i>      | (Optional)                        |
| <i>ref-count</i>      | (Optional)                        |

## Command Mode

- /exec

## show routing multicast mdt encapsulation

```
show routing [ ip | ipv4 ] multicast mdt encapsulation [ detail ] [ vrf { <vrf-name> | <vrf-known-name> | all
} ] [ __readonly__ [ TABLE_vrf <vrf-name> [ TABLE_mdt <index> <group> <source> <count>
<delete-pending> [ TABLE_customer_route [ <source> ] [ <group> ] ] ] ] ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information             |
| routing               | Display routing information                 |
| ip                    | (Optional) Display IP information           |
| ipv4                  | (Optional) Display IP information           |
| multicast             | Display multicast information               |
| mdt                   | Multicast Distribution Tree                 |
| encapsulation         | Encapsulation Information                   |
| detail                | (Optional) Display detailed information     |
| vrf                   | (Optional) Display per-VRF information      |
| <i>vrf-name</i>       | (Optional) VRF name                         |
| <i>vrf-known-name</i> | (Optional) Known VRF name                   |
| all                   | (Optional) Display information for all VRFs |
| <i>__readonly__</i>   | (Optional)                                  |
| TABLE_vrf             | (Optional)                                  |
| <i>vrf-name</i>       | (Optional)                                  |
| TABLE_mdt             | (Optional)                                  |
| <i>index</i>          | (Optional)                                  |
| <i>group</i>          | (Optional)                                  |
| <i>source</i>         | (Optional)                                  |
| <i>count</i>          | (Optional)                                  |
| <i>delete-pending</i> | (Optional)                                  |
| TABLE_customer_route  | (Optional)                                  |
| <i>source</i>         | (Optional)                                  |
| <i>group</i>          | (Optional)                                  |

**Command Mode**

- /exec

## show routing multicast memory estimate

```
show routing [ ip | ipv4 ] multicast memory estimate [ groups <group-count> sources-per-group <source-count>
oifs-per-entry <oif-count> [ mdt-encap-entries <encap-entry-count> ] [ __readonly__ [ TABLE_currentmax
[ <max-mb> ] [ <max-groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] ] [ TABLE_inuse [ <used-kb>
] [ <alloc-count> ] [ <sources-per-group> ] [ <oifs-per-entry> ] [ <mdt-encap-entry> ] ] [
TABLE_configuredmax [ <max-mb> ] [ <max-groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] ] [
TABLE_estimate [ <estimate-mb> ] [ <groups> ] [ <sources-per-group> ] [ <oifs-per-entry> ] [
<mdt-encap-entry> ] ] ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information   |
| routing                  | Display routing information   |
| ip                       | (Optional) Display IP information   |
| ipv4                     | (Optional) Display IP information   |
| multicast                | Display multicast information   |
| memory                   | Display mrib memory information   |
| estimate                 | Display mrib memory estimate  |
| groups                   | (Optional) Display mrib memory estimate for # groups                        |
| <i>group-count</i>       | (Optional) Number of groups   |
| sources-per-group        | (Optional) Display mrib memory estimate for # sources per group             |
| <i>source-count</i>      | (Optional) Number of sources per route                                      |
| oifs-per-entry           | (Optional) Display mrib memory estimate for # oifs per (S,G) or (*,G) entry |
| <i>oif-count</i>         | (Optional) Number of oifs per entry   |
| mdt-encap-entries        | (Optional) Display mrib memory estimate for # mdt encap entries             |
| <i>encap-entry-count</i> | (Optional) Number of mdt encap entries                                      |
| <i>__readonly__</i>      | (Optional)  |
| TABLE_currentmax         | (Optional)  |
| <i>max-mb</i>            | (Optional)  |
| <i>max-groups</i>        | (Optional)  |
| <i>sources-per-group</i> | (Optional)  |
| <i>oifs-per-entry</i>    | (Optional)  |

|                          |            |
|--------------------------|------------|
| TABLE_inuse              | (Optional) |
| <i>used-kb</i>           | (Optional) |
| <i>alloc-count</i>       | (Optional) |
| <i>sources-per-group</i> | (Optional) |
| <i>oifs-per-entry</i>    | (Optional) |
| <i>mdt-encap-entry</i>   | (Optional) |
| TABLE_configuredmax      | (Optional) |
| <i>max-mb</i>            | (Optional) |
| <i>max-groups</i>        | (Optional) |
| <i>sources-per-group</i> | (Optional) |
| <i>oifs-per-entry</i>    | (Optional) |
| TABLE_estimate           | (Optional) |
| <i>estimate-mb</i>       | (Optional) |
| <i>groups</i>            | (Optional) |
| <i>sources-per-group</i> | (Optional) |
| <i>oifs-per-entry</i>    | (Optional) |
| <i>mdt-encap-entry</i>   | (Optional) |

**Command Mode**

- /exec

## show routing multicast sr

```
show routing [ ip | ipv4 ] multicast sr [ vrf { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ [
TABLE_vrf <vrf-name> <mode> <mac-rewrite> [ TABLE_route <in-group-range> <to-group-range>
<group-mask> <in-source-range> <to-source-range> <source-mask> <udp-src-port> <udp-dest-port>
<static-oif> ] ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information             |
| routing                | Display routing information                 |
| ip                     | (Optional) Display IP information           |
| ipv4                   | (Optional) Display IP information           |
| multicast              | Display multicast information               |
| sr                     | Service Reflect Rules                       |
| vrf                    | (Optional) Display per-VRF information      |
| <i>vrf-name</i>        | (Optional) VRF name                         |
| <i>vrf-known-name</i>  | (Optional) Known VRF name                   |
| all                    | (Optional) Display information for all VRFs |
| <i>__readonly__</i>    | (Optional)                                  |
| TABLE_vrf              | (Optional)                                  |
| <i>vrf-name</i>        | (Optional)                                  |
| <i>mode</i>            | (Optional)                                  |
| <i>mac-rewrite</i>     | (Optional)                                  |
| TABLE_route            | (Optional)                                  |
| <i>in-group-range</i>  | (Optional)                                  |
| <i>to-group-range</i>  | (Optional)                                  |
| <i>group-mask</i>      | (Optional)                                  |
| <i>in-source-range</i> | (Optional)                                  |
| <i>to-source-range</i> | (Optional)                                  |
| <i>source-mask</i>     | (Optional)                                  |
| <i>udp-src-port</i>    | (Optional)                                  |

|                      |            |
|----------------------|------------|
| <i>udp-dest-port</i> | (Optional) |
| <i>static-oif</i>    | (Optional) |

**Command Mode**

- /exec



# show routing nhlfe

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] nhlfe [ stats ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ __readonly__
TABLE_vrf <vrf-name-out> [ <nhlfe-owner> <nhlfe-refcount> { TABLE_nhlabel <nhlabel-index> <nh-label>
} <nhlfe-is-vpn> <nhlfe-owner-index> ] <total-entries> ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information             |
| routing                  | Display routing information                 |
| vrf                      | (Optional) Display per-VRF information      |
| <i>vrf-name</i>          | (Optional) VRF name                         |
| <i>vrf-known-name</i>    | (Optional) Known VRF name                   |
| vrf-all                  | (Optional) Display information for all VRFs |
| ip                       | (Optional) Display IP information           |
| ipv4                     | (Optional) Display IP information           |
| unicast                  | (Optional) Display unicast information      |
| topology                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>topology-name</i>     | (Optional) topology name                    |
| nhlfe                    | Display URIB NHLFE db                       |
| stats                    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED   |
| <i>__readonly__</i>      | (Optional)                                  |
| TABLE_vrf                | (Optional)                                  |
| <i>vrf-name-out</i>      | (Optional)                                  |
| <i>nhlfe-owner</i>       | (Optional)                                  |
| <i>nhlfe-refcount</i>    | (Optional)                                  |
| TABLE_nhlabel            | (Optional)                                  |
| <i>nhlabel-index</i>     | (Optional)                                  |
| <i>nh-label</i>          | (Optional)                                  |
| <i>nhlfe-is-vpn</i>      | (Optional)                                  |
| <i>nhlfe-owner-index</i> | (Optional)                                  |

|                      |            |
|----------------------|------------|
| <i>total-entries</i> | (Optional) |
|----------------------|------------|

**Command Mode**

- /exec

## show routing recursive-next-hop

```
show routing [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ip | ipv4 ] [ unicast ] [ topology
<topology-name> ] recursive-next-hop [ <ip-addr> ] [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ]
[ __readonly__ TABLE_vrf <vrf-name-out> TABLE_addrf <addrf> [ TABLE_prefix <ipprefix> <uptime>
TABLE_clients <clientname> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                      |
| routing               | Display routing information                          |
| vrf                   | (Optional) Display per-VRF information               |
| <i>vrf-name</i>       | (Optional) VRF name                                  |
| <i>vrf-known-name</i> | (Optional) Known VRF name                            |
| vrf-all               | (Optional) Display information for all VRFs          |
| ip                    | (Optional) Display IP information                    |
| ipv4                  | (Optional) Display IP information                    |
| unicast               | (Optional) Display unicast information               |
| topology              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED            |
| recursive-next-hop    | Display recursive next-hop table                     |
| <i>topology-name</i>  | (Optional) topology name                             |
| <i>ip-addr</i>        | (Optional) Display single recursive virtual next-hop |
| __readonly__          | (Optional)   |
| TABLE_vrf             | (Optional)   |
| <i>vrf-name-out</i>   | (Optional)   |
| TABLE_addrf           | (Optional)   |
| <i>addrf</i>          | (Optional) Address type                              |
| TABLE_prefix          | (Optional)   |
| <i>ipprefix</i>       | (Optional)   |
| <i>uptime</i>         | (Optional)   |
| TABLE_clients         | (Optional)   |
| <i>clientname</i>     | (Optional)   |

**Command Mode**

- /exec

## show routing vxlan-hash peer-ip

```
show routing vxlan-hash peer-ip <peer-ip> <inner-src-mac> <inner-dst-mac> [ <inner-src-ip> <inner-dst-ip>
] [ <inner-src-ip6> <inner-dst-ip6> ] [ ip-proto <ip-proto> ] [ <inner-src-port> <inner-dst-port> ] [ module
<module-id> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| routing               | Display routing information                       |
| vxlan-hash            | Display load-balancing information for vxlan      |
| peer-ip               | Peer IP address                                   |
| <i>peer-ip</i>        | Peer IP   |
| <i>inner-src-mac</i>  | Inner Source MAC Address                          |
| <i>inner-dst-mac</i>  | Inner Destination MAC Address                     |
| <i>inner-src-ip</i>   | (Optional) Inner Source IP                        |
| <i>inner-dst-ip</i>   | (Optional) Inner Destination IP                   |
| ip-proto              | (Optional) IP Protocol information for the packet |
| <i>ip-proto</i>       | (Optional) IP Protocol information for the packet |
| <i>inner-src-port</i> | (Optional) Inner Source-port                      |
| <i>inner-dst-port</i> | (Optional) Inner Destination-port                 |
| module                | (Optional) Module                                 |
| <i>module-id</i>      | (Optional) Module                                 |

### Command Mode

- /exec

## show routing vxlan-hash peer-ipv6

```
show routing vxlan-hash peer-ipv6 <peer-ipv6> <inner-src-mac> <inner-dst-mac> [ <inner-src-ip>
<inner-dst-ip> ] [ <inner-src-ip6> <inner-dst-ip6> ] [ ip-proto <ip-proto> ] [ <inner-src-port> <inner-dst-port>
] [ module <module-id> ]
```

### Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                   |
| routing               | Display routing information                       |
| vxlan-hash            | Display load-balancing information for vxlan      |
| peer-ipv6             | Peer IPv6 address                                 |
| <i>inner-src-mac</i>  | Inner Source MAC Address                          |
| <i>inner-dst-mac</i>  | Inner Destination MAC Address                     |
| <i>inner-src-ip</i>   | (Optional) Inner Source IP                        |
| <i>inner-dst-ip</i>   | (Optional) Inner Destination IP                   |
| ip-proto              | (Optional) IP Protocol information for the packet |
| <i>ip-proto</i>       | (Optional) IP Protocol information for the packet |
| <i>inner-src-port</i> | (Optional) Inner Source-port                      |
| <i>inner-dst-port</i> | (Optional) Inner Destination-port                 |
| module                | (Optional) Module                                 |
| <i>module-id</i>      | (Optional) Module                                 |

### Command Mode

- /exec

# show rscn event-tov vsan

show rscn event-tov vsan <i0>

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| event-tov | show event time out value       |
| vsan      | show event time out value       |
| <i>i0</i> | VSAN id                         |

## Command Mode

- /exec

# show rscn pending-diff vsan

show rscn pending-diff vsan <i0>

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| pending-diff | show difference b/w pending and active configuration |
| vsan         | show difference b/w pending and active configuration |
| <i>i0</i>    | VSAN id  |

## Command Mode

- /exec



# show rscn pending vsan

show rscn pending vsan <i0>

## Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| pending   | show pending configuration      |
| vsan      | show pending configuration      |
| <i>i0</i> | VSAN id                         |

## Command Mode

- /exec

# show rscn scr-table

show rscn scr-table [ vsan <i0> ]

## Syntax Description

|           |                                      |
|-----------|--------------------------------------|
| show      | Show running system information      |
| scr-table | show State Change Registration table |
| vsan      | (Optional) show table for given vsan |
| <i>i0</i> | (Optional) VSAN id range             |

## Command Mode

- /exec

# show rscn session status vsan

show rscn session status vsan <i0>

## Syntax Description

|           |                                    |
|-----------|------------------------------------|
| show      | Show running system information    |
| session   | show rscn session status           |
| status    | show rscn session status           |
| vsan      | show internals for session history |
| <i>i0</i> | VSAN id range                      |

## Command Mode

- /exec

# show rscn statistics

```
show rscn statistics { [ vsan <i0> ] | detail [ vsan <i1> ] }
```

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information           |
| statistics | show RSCN Statistics                      |
| vsan       | (Optional) show statistics for given vsan |
| <i>i0</i>  | (Optional) VSAN id range                  |
| detail     | show statistics for each type of RSCN     |
| vsan       | (Optional) show statistics for given vsan |
| <i>i1</i>  | (Optional) VSAN id range                  |

## Command Mode

- /exec

# show running-config

show running-config

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |

## Command Mode

- /exec

# show running-config aaa

show running-config aaa [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| aaa            | Display aaa configuration                    |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config acllog

show running-config acllog [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| acllog         | show running config for acllog               |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config aclmgr

show running-config aclmgr [ all | inactive-if-config ]

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                      |
| running-config     | Current operating configuration                      |
| aclmgr             | show running config for aclmgr                       |
| all                | (Optional) show running config with defaults         |
| inactive-if-config | (Optional) show running config for inactive-policies |

## Command Mode

- /exec



# show running-config adjmgr

show running-config adjmgr [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| adjmgr         | Display adjmgr information                           |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config all

show running-config all

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information               |
| running-config | Current operating configuration               |
| all            | Current operating configuration with defaults |

## Command Mode

- /exec

# show running-config arp

show running-config arp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| arp            | Display arp information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config assoc

show running-config assoc [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| assoc          | Original ID to Translated ID Association     |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config backup

show running-config { backup | flexlink } [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| running-config | Current operating configuration           |
| backup         | Show running config for Switchport Backup |
| flexlink       | Show running config for Switchport Backup |
| all            | (Optional) Show config with defaults      |

## Command Mode

- /exec

# show running-config bfd

show running-config bfd [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| bfd            | show running config for bfd                  |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config bgp

show running-config bgp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| bgp            | Display bgp information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config bloggerd

show running-config bloggerd [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| bloggerd       | Display bloggerd configuration               |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec



# show running-config callhome

show running-config callhome [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| callhome       | Display callhome configuration               |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config cdp

show running-config cdp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| cdp            | Display cdp configuration                    |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config cert-enroll

show running-config cert-enroll [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| cert-enroll    | Display certificates configuration           |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config cfs

show running-config cfs [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operation configuration              |
| cfs            | Display cfs configurations                   |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config clock\_manager

show running-config clock\_manager [ all ]

## Syntax Description

|                |  |
|----------------|--|
| running-config | Current operating configuration              |
| clock_manager  | show running config for clock manager        |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config config-profile

show running-config config-profile [ <all\_conf\_profile\_name> ]

## Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running-cfg                         |
| running-config               | show running configuration               |
| config-profile               | Display port-profile configuration       |
| <i>all_conf_profile_name</i> | (Optional) Enter the name of the profile |

## Command Mode

- /exec

# show running-config controller

show running-config controller

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |
| controller     | controller                      |

## Command Mode

- /exec

# show running-config copp

show running-config copp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| copp           | Control-Plane Policing                       |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec



# show running-config dhcp

show running-config dhcp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operation configuration              |
| dhcp           | Display dhcp snoop configurations            |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config diagnostic

show running-config diagnostic [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operating configuration                 |
| diagnostic     | Display diagnostic information                  |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show running-config diff

show running-config diff

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                               |
| running-config | Current operating configuration                               |
| diff           | Show the difference between running and startup configuration |

## Command Mode

- /exec

# show running-config dot1x

show running-config dot1x [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| dot1x          | Display dot1x configuration                  |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config ecp

show running-config ecp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operationg configuration                |
| ecp            | ECP (Edge Control Protocol)                     |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show running-config eem

show running-config eem

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Show the system running configuration        |
| eem            | Show the event manager running configuration |

## Command Mode

- /exec

# show running-config eigrp

show running-config eigrp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| eigrp          | Display eigrp information                            |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config eltm

show running-config eltm

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operation configuration |
| eltm           | Display eltm configurations     |

## Command Mode

- /exec



# show running-config epbr

show running-config epbr

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show running-cfg                |
| running-config | show running system information |
| epbr           | epbr                            |

## Command Mode

- /exec

# show running-config evb

show running-config evb [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operationg configuration                |
| evb            | EVB (Edge Virtual Bridge)                       |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show running-config exclude

show running-config exclude <feature-list> +

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| running-config      | Current operating configuration                     |
| exclude             | Exclude running configuration of specified features |
| <i>feature-list</i> | Exclude features                                    |

## Command Mode

- /exec

# show running-config expand-port-profile

show running-config expand-port-profile

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| running-config      | Current operating configuration |
| expand-port-profile | Expand port profile             |

## Command Mode

- /exec

# show running-config fabric forwarding

show running-config fabric forwarding [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                         |
| running-config | Current operationg configuration                        |
| fabric         | Fabric  |
| forwarding     | Fabric Forwarding Protocol: Host Mobility Manager (HMM) |
| all            | (Optional) Display running config with defaults clis    |

## Command Mode

- /exec

# show running-config fabric multicast

show running-config fabric multicast [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| fabric         | Fabric   |
| multicast      | Multicast information                                |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config fabricpath

show running-config fabricpath [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| fabricpath     | fabricpath information                       |
| all            | (Optional) Show running config with defaults |

## Command Mode

- /exec

# show running-config fabricpath domain default

show running-config fabricpath domain default [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| fabricpath     | fabricpath information                               |
| domain         | Enter fabricpath IS-IS domain configuration mode     |
| default        | default fabricpath domain                            |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec



# show running-config fabricpath switch-id

show running-config fabricpath switch-id [ all ]

## Syntax Description

|                |  |
|----------------|--|
| running-config | Current operating configuration              |
| fabricpath     | fabricpath information                       |
| switch-id      | fabricpath switch-id configuration           |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config fabricpath topology

show running-config fabricpath topology [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| fabricpath     | fabricpath Module Information                        |
| topology       | Fabricpath topology Information                      |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config fcoe\_mgr

show running-config fcoe\_mgr [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| fcoe_mgr       | Display fcoe_mgr configuration               |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config fsync\_mgr

show running-config fsync\_mgr [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| fsync_mgr      | Frequency Synchronization Manager            |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config hardware-telemetry

show running-config hardware-telemetry [ all ]

## Syntax Description

|                    |  |
|--------------------|--|
| running-config     | Current operating configuration              |
| hardware-telemetry | show running config for hardware-telemetry   |
| all                | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config hsrp

show running-config hsrp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show system information                             |
| running-config | System running configuration                        |
| hsrp           | HSRP running configuration                          |
| all            | (Optional) Show HSRP running configuration defaults |

## Command Mode

- /exec

# show running-config icam

show running-config icam

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show running-cfg                |
| running-config | show running system information |
| icam           | icam services                   |

## Command Mode

- /exec

# show running-config icmpv6

show running-config icmpv6 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| icmpv6         | Display icmpv6 information                           |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec



# show running-config igmp

show running-config igmp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| igmp           | Display igmp information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config imp

show running-config imp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                            |
| running-config | System running configuration                       |
| imp            | IMP running configuration                          |
| all            | (Optional) Show IMP running configuration defaults |

## Command Mode

- /exec

# show running-config interface

show running-config interface [ <if0> ] [ all ] [ expand-port-profile ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                            |
| running-config      | Current operating configuration                            |
| interface           | Interface configuration                                    |
| <i>if0</i>          | (Optional) interface type and number in module/slot format |
| all                 | (Optional) show running config with defaults               |
| expand-port-profile | (Optional) Expand port profile                             |

## Command Mode

- /exec

# show running-config interface

show running-config interface <if0> [ membership ] [ expand-port-profile ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| running-config      | Current operating configuration                 |
| interface           | Interface configuration                         |
| <i>if0</i>          | interface type and number in module/slot format |
| membership          | (Optional) Show membership information          |
| expand-port-profile | (Optional) Expand port profile                  |

## Command Mode

- /exec

# show running-config ip

show running-config ip [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| ip             | Display ip information                               |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config ipqos

show running-config ipqos [ all | inactive-if-config ]

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                      |
| running-config     | Current operating configuration                      |
| all                | (Optional) show running config with defaults         |
| inactive-if-config | (Optional) show running config for inactive-policies |

## Command Mode

- /exec

# show running-config ipv6

show running-config ipv6 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operating configuration                      |
| ipv6           | Display ipv6 information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config isis

show running-config isis [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| isis           | Display isis information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec



# show running-config l3vm

show running-config l3vm [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operationg configuration                |
| l3vm           | Display l3vm information                        |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show running-config ldap

show running-config ldap [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| ldap           | Display ldap configuration                   |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config license

show running-config license [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show   |
| running-config | show running system information              |
| license        | Display licensing configuration              |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config lisp

show running-config lisp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| lisp           | Display lisp information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config lldp

show running-config lldp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| lldp           | Display lldp configuration                   |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config macsec

show running-config macsec

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |
| macsec         | Show CTS information            |

## Command Mode

- /exec

# show running-config mfwd

show running-config { mfwd | mcastfwd } [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationng configuration                    |
| mcastfwd       | Display MCASTFWD information                         |
| mfwd           | Display MFWD information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config mfwdv6

show running-config { mfwdv6 | mcastfwdv6 } [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| mcastfwdv6     | Display IPV6 MCASTFWD information                    |
| mfwdv6         | Display IPV6 MFWD information                        |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec



# show running-config mld

show running-config mld [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| mld            | Display MLD information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config mmode

show running-config mmode [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                |
| running-config | Show running configuration                     |
| mmode          | Display maintenance mode running configuration |
| all            | (Optional) Show running config with defaults   |

## Command Mode

- /exec

# show running-config monitor

show running-config monitor [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| monitor        | Configure Ethernet SPAN sessions             |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config mpls static

show running-config mpls static [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operating configuration                 |
| mpls           | Display MPLS status and configuration           |
| static         | Static Label Bindings                           |
| all            | (Optional) Display running-config with defaults |

## Command Mode

- /exec

# show running-config mpls strip

show running-config mpls strip [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                                 |
| mpls           | MPLS information  |
| strip          | Stripping of MPLS headers                                       |
| running-config | System running configuration                                    |
| all            | (Optional) Show running configuration for STRIPCL with defaults |

## Command Mode

- /exec

# show running-config msdp

show running-config msdp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| msdp           | Display msdp information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config nat

show running-config nat [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| nat            | Display NAT configuration                    |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config nbm

show running-config nbm

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |
| nbm            | Non Blocking Multicast          |

## Command Mode

- /exec



# show running-config ngoam

show running-config ngoam [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Show running system information              |
| ngoam          | ngoam configuration                          |
| all            | (Optional) Show running config with defaults |

## Command Mode

- /exec

# show running-config ntp

show running-config ntp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show information                              |
| running-config | Show running system configuration             |
| ntp            | Show NTP information                          |
| all            | (Optional) Show all NTP running configuration |

## Command Mode

- /exec

# show running-config nv overlay

show running-config nv overlay [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                            |
| running-config | System running configuration                       |
| nv             | NVE running configuration                          |
| overlay        | NVE running configuration                          |
| all            | (Optional) Show NVE running configuration defaults |

## Command Mode

- /exec

# show running-config nxsdk

show running-config nxsdk [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operating configuration                 |
| nxsdk          | NXOS SDK  |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show running-config ofm

show running-config ofm [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                          |
| running-config | Show running system information                          |
| ofm            | Display Overlay Flow/Policy Manager information          |
| all            | (Optional) Current operating configuration with defaults |

## Command Mode

- /exec

# show running-config openflow

show running-config openflow [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| openflow       | Show running config for OpenFlow agent       |
| all            | (Optional) Show running config with defaults |

## Command Mode

- /exec

# show running-config ospf

show running-config ospf [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| ospf           | Display ospf information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config ospfv3

show running-config ospfv3 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| ospfv3         | Display ospfv3 information                           |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec



# show running-config otv-isis

show running-config otv-isis [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| otv-isis       | Display otv-isis information                         |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config param-list

show running-config param-list [ <plistname> ]

## Syntax Description

|                  |   |
|------------------|---|
| show             | Show running-cfg                            |
| running-config   | show running configuration                  |
| param-list       | Display param-list configuration            |
| <i>plistname</i> | (Optional) Enter the name of the param list |

## Command Mode

- /exec

# show running-config pim

show running-config pim [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| pim            | Display pim information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config pim6

show running-config pim6 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| pim6           | Display pim6 information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config poe

show running-config poe [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| poe            | Power over Ethernet                          |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config port-profile

show running-config port-profile [ <all\_profile\_name> ]

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running-cfg                         |
| running-config          | show running configuration               |
| port-profile            | Display port-profile configuration       |
| <i>all_profile_name</i> | (Optional) Enter the name of the profile |

## Command Mode

- /exec

# show running-config port-security

show running-config port-security [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| port-security  | Display port-security configuration          |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config ptp

show running-config ptp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| running-config | Current operating configuration              |
| ptp            | show running config for ptp                  |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec



# show running-config radius

show running-config radius [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| radius         | Display radius configuration                 |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config rip

show running-config rip [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| rip            | Display rip information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config routing ip multicast

show running-config routing { ip | ipv4 } multicast [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| routing        | Display routing information                          |
| ip             | Display IP information                               |
| ipv4           | Display IP information                               |
| multicast      | Display multicast information                        |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config routing ipv6 multicast

show running-config routing ipv6 multicast [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| routing        | Display routing information                          |
| ipv6           | Display IPv6 information                             |
| multicast      | Display multicast information                        |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config rpm

show running-config rpm [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| running-config | Current operating configuration                 |
| rpm            | Display Route Policy Manager (RPM) information  |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show running-config scheduler

show running-config scheduler [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| scheduler      | Show scheduler config or data                |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config section

show running-config section <section>

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information  |
| running-config | Current operating configuration  |
| section        | show only a particular section of running-config (in format needed for 'merge config' command) |
| <i>section</i> | the section to show, a regular expression, (use a dot for a space)                             |

## Command Mode

- /exec

# show running-config security

show running-config security [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| security       | Display security configuration               |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec



# show running-config segment-routing

show running-config segment-routing [ all ]

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information               |
| running-config  | Show running configuration                    |
| segment-routing | Display segment-routing running configuration |
| all             | (Optional) Show running config with defaults  |

## Command Mode

- /exec

# show running-config service-reflect

show running-config service-reflect

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information              |
| running-config  | Current operationg configuration             |
| service-reflect | Display NAT feature service-reflect commands |

## Command Mode

- /exec

# show running-config services

show running-config services

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show running-cfg                |
| running-config | show running system information |
| services       | services                        |

## Command Mode

- /exec

# show running-config services

show running-config services

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show running-cfg                |
| running-config | show running system information |
| services       | services                        |

## Command Mode

- /exec

# show running-config sflow

show running-config sflow [ all ]

## Syntax Description

|                |  |
|----------------|--|
| running-config | Current operating configuration              |
| sflow          | show running config for sflow                |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config sla responder

show running-config sla responder

## Syntax Description

|                |                                      |
|----------------|--------------------------------------|
| show           | show running-cfg                     |
| running-config | show running system information      |
| sla            | Service Level Agreement (SLA)        |
| responder      | Show information about sla-responder |

## Command Mode

- /exec

# show running-config sla sender

show running-config sla sender

## Syntax Description

|                |                                   |
|----------------|-----------------------------------|
| show           | show running-cfg                  |
| running-config | show running system information   |
| sla            | Service Level Agreement (SLA)     |
| sender         | Show information about sla-sender |

## Command Mode

- /exec

# show running-config sla twamp-server

show running-config sla twamp-server

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                           |
| running-config | show running system information            |
| sla            | Service Level Agreement (SLA)              |
| twamp-server   | Show IPSLA IPPM TWAMP server configuration |

## Command Mode

- /exec



# show running-config snmp

show running-config snmp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| snmp           | Display snmp configuration                   |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config spanning-tree

show running-config spanning-tree [ <all> | interface <interface\_range> ]

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information                             |
| running-config         | Current operating configuration                             |
| spanning-tree          | Show spanning tree information                              |
| <i>all</i>             | (Optional)  |
| interface              | (Optional) Specify an interface as a target for the command |
| <i>interface_range</i> | (Optional)  |

## Command Mode

- /exec

# show running-config srte

show running-config srte

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |
| srte           | SRTE                            |

## Command Mode

- /exec

# show running-config switch

show running-config { switch-profile | include-switch-profile }

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information               |
| running-config         | Current operating configuration               |
| switch-profile         | Show switch-profile information               |
| include-switch-profile | Show running and switch-profile configuration |

## Command Mode

- /exec

# show running-config sync

show running-config sync [ all ]

## Syntax Description

|                |  |
|----------------|--|
| running-config | Current operating configuration              |
| sync           | show running config for sync                 |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config tacacs

show running-config tacacs + [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running-cfg                             |
| running-config | show running system information              |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config telemetry

show running-config telemetry [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show running system configuration            |
| running-config | Current operating configuration              |
| telemetry      | Display telemetry configuration              |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config track

show running-config track [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Show the system running information                  |
| track          | Show track running configuration                     |
| all            | (Optional) Show track running configuration defaults |

## Command Mode

- /exec



# show running-config tunnel-encryption

show running-config tunnel-encryption

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                  |
| running-config    | Current operating configuration                  |
| tunnel-encryption | Show information about Tunnel Encryption Manager |

## Command Mode

- /exec

# show running-config udd

show running-config udd [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| udd            | Show udd configuration                       |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config vdc-all

show running-config vdc-all [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                           |
| running-config | Current operating configuration                           |
| vdc-all        | Display config from all VDC                               |
| all            | (Optional) Display config from all VDC including defaults |

## Command Mode

- /exec

# show running-config vdc

show running-config vdc [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| vdc            | Show Virtual Device Contexts                 |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config virtual-service

show running-config virtual-service

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information                 |
| running-config  | Current operating configuration                 |
| virtual-service | Show running config for virtualization services |

## Command Mode

- /exec

# show running-config vlan

show running-config vlan <vlan-id> [ expand-port-profile ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| running-config      | Current operating configuration                 |
| vlan                | Vlan commands                                   |
| <i>vlan-id</i>      | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| expand-port-profile | (Optional) Expand port profile                  |

## Command Mode

- /exec

# show running-config vlan

show running-config vlan

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |
| vlan           | Vlan commands                   |

## Command Mode

- /exec

# show running-config vlan

show running-config vlan <vlan-id> [ expand-port-profile ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| running-config      | Current operating configuration                 |
| vlan                | Vlan commands                                   |
| <i>vlan-id</i>      | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| expand-port-profile | (Optional) Expand port profile                  |

## Command Mode

- /exec



# show running-config vmtracker

show running-config vmtracker [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| vmtracker      | show running config for vmtracker            |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config vpc

show running-config vpc [ all ]

## Syntax Description

|                |  |
|----------------|--|
| running-config | Current operating configuration              |
| vpc            | show running config for vPC                  |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config vrf

show running-config vrf <vrf-cfg-name> [ all ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                      |
| running-config      | Current operationng configuration                    |
| vrf                 | Display VRF information                              |
| <i>vrf-cfg-name</i> | Configurable VRF name                                |
| all                 | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config vrf default

show running-config vrf default [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| running-config | Current operationg configuration                     |
| vrf            | Display VRF information                              |
| default        | Known VRF name                                       |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show running-config vrrp

show running-config vrrp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| vrrp           | Display VRRP running configuration           |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config vrrpv3

show running-config vrrpv3 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| running-config | Current operating configuration              |
| vrrpv3         | Show running config for VRRPv3               |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show running-config vshd

show running-config vshd

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| running-config | Current operating configuration |
| vshd           | Show running config for vshd    |

## Command Mode

- /exec

# show running-config vtp

show running-config vtp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                             |
| running-config | Current operating configuration                             |
| vtp            | Show running configuration for VTP                          |
| all            | (Optional) Show running configuration for VTP with defaults |

## Command Mode

- /exec



# show running-config wwnm

show running-config wwnm

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| running-config | Current running configuration             |
| wwnm           | Display WWN Manager running configuration |

## Command Mode

- /exec

# show running-config zone

show running-config zone

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| running-config | Current operating configuration           |
| zone           | Display zone server running configuration |

## Command Mode

- /exec

# show running-config zone vsan

show running-config zone vsan <vsan-id>

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                    |
| running-config | Current operating configuration                    |
| zone           | Display zone server running configuration per vsan |
| vsan           | Vsan commands                                      |
| <i>vsan-id</i> | Vsan id  |

## Command Mode

- /exec

```
show running-config zone vsan
```



## S Show Commands

---

- [show san-port-channel compatibility-parameters](#), on page 2757
- [show san-port-channel consistency](#), on page 2758
- [show san-port-channel consistency detail](#), on page 2759
- [show san-port-channel database](#), on page 2761
- [show san-port-channel summary](#), on page 2763
- [show san-port-channel usage](#), on page 2764
- [show scheduler config](#), on page 2765
- [show scheduler job](#), on page 2767
- [show scheduler logfile](#), on page 2768
- [show scheduler schedule](#), on page 2769
- [show segment-routing](#), on page 2770
- [show segment-routing clients](#), on page 2771
- [show segment-routing ipv4 connected-prefix-sid-map](#), on page 2772
- [show segment-routing mpls](#), on page 2773
- [show segment-routing mpls clients](#), on page 2774
- [show segment-routing mpls ipv4 connected-prefix-sid-map](#), on page 2775
- [show sflow](#), on page 2776
- [show sflow statistics](#), on page 2777
- [show snapshots](#), on page 2778
- [show snapshots compare](#), on page 2779
- [show snapshots compare ipv4routes](#), on page 2781
- [show snapshots compare ipv6routes](#), on page 2782
- [show snapshots compare summary](#), on page 2783
- [show snapshots dump](#), on page 2784
- [show snapshots dump](#), on page 2785
- [show snapshots sections](#), on page 2786
- [show snmp](#), on page 2787
- [show snmp community](#), on page 2790
- [show snmp context](#), on page 2791
- [show snmp engineID](#), on page 2792
- [show snmp group](#), on page 2793
- [show snmp host](#), on page 2794
- [show snmp nms-statistics](#), on page 2795

- [show snmp oid-statistics](#), on page 2796
- [show snmp sessions](#), on page 2797
- [show snmp source-interface](#), on page 2798
- [show snmp trap](#), on page 2799
- [show snmp user](#), on page 2800
- [show sockets client](#), on page 2801
- [show sockets connection](#), on page 2809
- [show sockets local-port-range](#), on page 2812
- [show sockets ns-port-kiosk](#), on page 2813
- [show sockets statistics](#), on page 2814
- [show sockets tcp keychain binding](#), on page 2824
- [show software authenticity file](#), on page 2825
- [show software authenticity keys](#), on page 2826
- [show spanning-tree](#), on page 2827
- [show spanning-tree blockedports](#), on page 2831
- [show spanning-tree bridge](#), on page 2832
- [show spanning-tree inconsistentports](#), on page 2834
- [show spanning-tree interface](#), on page 2835
- [show spanning-tree interface](#), on page 2838
- [show spanning-tree issu-impact](#), on page 2839
- [show spanning-tree mst](#), on page 2840
- [show spanning-tree mst configuration](#), on page 2845
- [show spanning-tree mst configuration digest](#), on page 2846
- [show spanning-tree mst interface](#), on page 2847
- [show spanning-tree pathcost method](#), on page 2850
- [show spanning-tree root](#), on page 2851
- [show spanning-tree summary](#), on page 2853
- [show spanning-tree summary totals](#), on page 2856
- [show sprom](#), on page 2858
- [show srte pce ipv4 peer](#), on page 2867
- [show srte policy](#), on page 2868
- [show srte policy fh](#), on page 2870
- [show srte policy proactive-policy-monitoring](#), on page 2871
- [show srte policy summary](#), on page 2872
- [show srv6 clients](#), on page 2874
- [show srv6 locator](#), on page 2876
- [show srv6 manager](#), on page 2877
- [show srv6 sid](#), on page 2879
- [show srv6 sid counters](#), on page 2880
- [show ssh key](#), on page 2881
- [show ssh server](#), on page 2882
- [show ssx details](#), on page 2883
- [show ssx exporter](#), on page 2884
- [show ssx monitor](#), on page 2885
- [show ssx record](#), on page 2886
- [show startup-config](#), on page 2887

- [show startup-config aaa](#), on page 2888
- [show startup-config acllog](#), on page 2889
- [show startup-config aclmgr](#), on page 2890
- [show startup-config adjmgr](#), on page 2891
- [show startup-config arp](#), on page 2892
- [show startup-config assoc](#), on page 2893
- [show startup-config backup](#), on page 2894
- [show startup-config bfd](#), on page 2895
- [show startup-config bgp](#), on page 2896
- [show startup-config bloggerd](#), on page 2897
- [show startup-config callhome](#), on page 2898
- [show startup-config cdp](#), on page 2899
- [show startup-config cert-enroll](#), on page 2900
- [show startup-config cfs](#), on page 2901
- [show startup-config config-profile](#), on page 2902
- [show startup-config copp](#), on page 2903
- [show startup-config dhcp](#), on page 2904
- [show startup-config diagnostic](#), on page 2905
- [show startup-config dot1x](#), on page 2906
- [show startup-config ecp](#), on page 2907
- [show startup-config eem](#), on page 2908
- [show startup-config eigrp](#), on page 2909
- [show startup-config eltm](#), on page 2910
- [show startup-config epbr](#), on page 2911
- [show startup-config evb](#), on page 2912
- [show startup-config exclude](#), on page 2913
- [show startup-config expand-port-profile](#), on page 2914
- [show startup-config fabric forwarding](#), on page 2915
- [show startup-config fabric multicast](#), on page 2916
- [show startup-config fabricpath](#), on page 2917
- [show startup-config fabricpath domain default](#), on page 2918
- [show startup-config fabricpath switch-id](#), on page 2919
- [show startup-config fabricpath topology](#), on page 2920
- [show startup-config fcoe\\_mgr](#), on page 2921
- [show startup-config fsync\\_mgr](#), on page 2922
- [show startup-config glbp](#), on page 2923
- [show startup-config hardware-telemetry](#), on page 2924
- [show startup-config hsrp](#), on page 2925
- [show startup-config icam](#), on page 2926
- [show startup-config icmpv6](#), on page 2927
- [show startup-config igmp](#), on page 2928
- [show startup-config imp](#), on page 2929
- [show startup-config interface](#), on page 2930
- [show startup-config interface](#), on page 2931
- [show startup-config ip](#), on page 2932
- [show startup-config ipqos](#), on page 2933

- [show startup-config ipv6](#), on page 2934
- [show startup-config isis](#), on page 2935
- [show startup-config l3vm](#), on page 2936
- [show startup-config ldap](#), on page 2937
- [show startup-config license](#), on page 2938
- [show startup-config lisp](#), on page 2939
- [show startup-config lldp](#), on page 2940
- [show startup-config log](#), on page 2941
- [show startup-config macsec](#), on page 2942
- [show startup-config mfwld](#), on page 2943
- [show startup-config mfwldv6](#), on page 2944
- [show startup-config mld](#), on page 2945
- [show startup-config mmode](#), on page 2946
- [show startup-config monitor](#), on page 2947
- [show startup-config mpls static](#), on page 2948
- [show startup-config mpls strip](#), on page 2949
- [show startup-config msdp](#), on page 2950
- [show startup-config nat](#), on page 2951
- [show startup-config nbm](#), on page 2952
- [show startup-config ngoam](#), on page 2953
- [show startup-config ntp](#), on page 2954
- [show startup-config nv overlay](#), on page 2955
- [show startup-config nxsdk](#), on page 2956
- [show startup-config ofm](#), on page 2957
- [show startup-config openflow](#), on page 2958
- [show startup-config ospf](#), on page 2959
- [show startup-config ospfv3](#), on page 2960
- [show startup-config otv-isis](#), on page 2961
- [show startup-config param-list](#), on page 2962
- [show startup-config pim](#), on page 2963
- [show startup-config pim6](#), on page 2964
- [show startup-config poe](#), on page 2965
- [show startup-config port-profile](#), on page 2966
- [show startup-config port-security](#), on page 2967
- [show startup-config ptp](#), on page 2968
- [show startup-config radius](#), on page 2969
- [show startup-config rip](#), on page 2970
- [show startup-config routing ip multicast](#), on page 2971
- [show startup-config routing ipv6 multicast](#), on page 2972
- [show startup-config rpm](#), on page 2973
- [show startup-config scheduler](#), on page 2974
- [show startup-config security](#), on page 2975
- [show startup-config segment-routing](#), on page 2976
- [show startup-config services](#), on page 2977
- [show startup-config sflow](#), on page 2978
- [show startup-config sla responder](#), on page 2979



- [show startup-config sla sender](#), on page 2980
- [show startup-config sla twamp-server](#), on page 2981
- [show startup-config snmp](#), on page 2982
- [show startup-config srte](#), on page 2983
- [show startup-config switch](#), on page 2984
- [show startup-config syncc](#), on page 2985
- [show startup-config tacacs](#), on page 2986
- [show startup-config telemetry](#), on page 2987
- [show startup-config track](#), on page 2988
- [show startup-config tunnel-encryption](#), on page 2989
- [show startup-config udld](#), on page 2990
- [show startup-config vdc-all](#), on page 2991
- [show startup-config vdc](#), on page 2992
- [show startup-config virtual-service](#), on page 2993
- [show startup-config vlan](#), on page 2994
- [show startup-config vlan](#), on page 2995
- [show startup-config vmtracker](#), on page 2996
- [show startup-config vpc](#), on page 2997
- [show startup-config vrf](#), on page 2998
- [show startup-config vrf default](#), on page 2999
- [show startup-config vrrpv3](#), on page 3000
- [show startup-config vshd](#), on page 3001
- [show startup-config vtp](#), on page 3002
- [show startup-config wwnm](#), on page 3003
- [show startup-config zone](#), on page 3004
- [show startup-config zone vsan](#), on page 3005
- [show summary](#), on page 3006
- [show switch-profile](#), on page 3007
- [show switch-profile](#), on page 3008
- [show switch-profile buffer](#), on page 3010
- [show switch-profile peer](#), on page 3011
- [show switch-profile status](#), on page 3012
- [show switching-mode](#), on page 3014
- [show switching-mode fabric-speed](#), on page 3015
- [show system acl](#), on page 3016
- [show system auto-collect tech-support](#), on page 3017
- [show system boottime](#), on page 3018
- [show system config reload-pending](#), on page 3019
- [show system cores](#), on page 3020
- [show system default switchport](#), on page 3021
- [show system default zone](#), on page 3022
- [show system error-id](#), on page 3023
- [show system exception-info](#), on page 3024
- [show system fabric-mode](#), on page 3025
- [show system fast-reload stabilization-timer](#), on page 3026
- [show system image-verification](#), on page 3027

- [show system inband cpu-mac log threshold, on page 3028](#)
- [show system inband queuing statistics, on page 3029](#)
- [show system inband queuing status, on page 3031](#)
- [show system login, on page 3032](#)
- [show system login failures, on page 3033](#)
- [show system memory-thresholds, on page 3034](#)
- [show system mode, on page 3035](#)
- [show system nve infra-vlans, on page 3036](#)
- [show system poap, on page 3037](#)
- [show system pss shrink status, on page 3038](#)
- [show system redundancy ha status, on page 3039](#)
- [show system redundancy status, on page 3040](#)
- [show system reset-reason, on page 3041](#)
- [show system reset-reason, on page 3042](#)
- [show system reset-reason module, on page 3043](#)
- [show system resources, on page 3044](#)
- [show system resources all-modules, on page 3046](#)
- [show system routing mode, on page 3048](#)
- [show system security, on page 3049](#)
- [show system simulate fan-presence, on page 3050](#)
- [show system standby manual-boot, on page 3051](#)
- [show system switch-mode, on page 3052](#)
- [show system uptime, on page 3053](#)
- [show system verify bios flash, on page 3054](#)
- [show system vlan reserved, on page 3055](#)

# show san-port-channel compatibility-parameters

```
show san-port-channel compatibility-parameters [ __readonly__ [ { TABLE_compatibility_params <parameter>
<description> } ] ]
```

## Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                |
| san-port-channel                  | Show san-port-channel information              |
| compatibility-parameters          | Show san-port-channel compatibility-parameters |
| <i>__readonly__</i>               | (Optional) Read Only                           |
| <i>TABLE_compatibility_params</i> | (Optional) Table with compatibility params     |
| <i>parameter</i>                  | (Optional) Compatibility parameter             |
| <i>description</i>                | (Optional) Parameter description               |

## Command Mode

- /exec

## show san-port-channel consistency

```
show san-port-channel consistency [ __readonly__ [ <msg> ] [ { [ <error_msg> ] [ <consistency_state> ] [
<module> ] [ { TABLE_inconsistent_database [ <database> ] [ { [ <total_port_channels> ] [ {
TABLE_san_port_channel_database [ <interface> ] [ <total_ports> ] [ <first_operational_port> ] [ {
TABLE_san_port_channel_member <port> <state> } ] [ <db_error_str> } ] } ] } ] } ] }
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information                        |
| san-port-channel                | Show san-port-channel information                      |
| consistency                     | Show san-port-channel distributed database consistency |
| <i>__readonly__</i>             | (Optional) Read Only                                   |
| <i>msg</i>                      | (Optional) Message string                              |
| <i>error_msg</i>                | (Optional) Prints consistency errors, if any           |
| <i>consistency_state</i>        | (Optional) Consistency state                           |
| <i>module</i>                   | (Optional) Module no                                   |
| TABLE_inconsistent_database     | (Optional) Table with details of inconsistent dbs      |
| <i>database</i>                 | (Optional) Inconsistent database                       |
| TABLE_san_port_channel_database | (Optional) san-po Table                                |
| <i>total_port_channels</i>      | (Optional) Total port channels                         |
| <i>interface</i>                | (Optional) san-port-channel interface                  |
| <i>first_operational_port</i>   | (Optional) First oper port in san-po                   |
| <i>total_ports</i>              | (Optional) Total number of ports in the san-po         |
| TABLE_san_port_channel_member   | (Optional) san-po member Table                         |
| <i>port</i>                     | (Optional) san-po member port                          |
| <i>state</i>                    | (Optional) san-po member port state                    |
| <i>db_error_str</i>             | (Optional) prints cmd errors, if any                   |

### Command Mode

- /exec

## show san-port-channel consistency detail

```
show san-port-channel consistency detail [ __readonly__ [ <sup_total_port_channels> ] [ { [ <sup_db_error_str> ] [ { TABLE_sup_san_port_channel_database <sup_interface> [ <sup_total_ports> ] [ <sup_first_operational_port> ] [ { TABLE_sup_san_port_channel_member <sup_port> <sup_state> } ] } ] } ] [ <msg> ] [ { [ <error_msg> ] [ <db_index> ] [ <module> ] [ { [ <total_port_channels> ] [ { TABLE_san_port_channel_database [ <interface> ] [ <total_ports> ] [ <first_operational_port> ] [ { TABLE_san_port_channel_member <port> <state> } ] [ <db_error_str> ] } ] } ] } ] [ <consistency_state> ] ]
```

### Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information                            |
| san-port-channel                    | Show san-port-channel information                          |
| consistency                         | Show san-port-channel distributed database consistency     |
| detail                              | Show san-port-channel distributed databases of all modules |
| __readonly__                        | (Optional) Read Only                                       |
| sup_total_port_channels             | (Optional) Authoritative po db - Total POs                 |
| TABLE_sup_san_port_channel_database | (Optional) Table with details of auth po db                |
| sup_interface                       | (Optional) san-port-channel interface                      |
| sup_first_operational_port          | (Optional) First oper port in san-po                       |
| sup_total_ports                     | (Optional) Total number of ports in the san-po             |
| TABLE_sup_san_port_channel_member   | (Optional) san-po member Table                             |
| sup_port                            | (Optional) san-po member port                              |
| sup_state                           | (Optional) san-po member port state                        |
| sup_db_error_str                    | (Optional) prints cmd errors, if any                       |
| msg                                 | (Optional) Msg string                                      |
| error_msg                           | (Optional) Prints errors, if any                           |
| db_index                            | (Optional) Database index                                  |
| module                              | (Optional) Module no                                       |
| total_port_channels                 | (Optional) Authoritative po db - Total POs                 |
| TABLE_san_port_channel_database     | (Optional) Table with details of auth po db                |
| interface                           | (Optional) san-port-channel interface                      |
| first_operational_port              | (Optional) First oper port in san-po                       |

|                               |  |
|-------------------------------|--|
| <i>total_ports</i>            | (Optional) Total number of ports in the san-po |
| TABLE_san_port_channel_member | (Optional) san-po member Table                 |
| <i>port</i>                   | (Optional) san-po member port                  |
| <i>state</i>                  | (Optional) san-po member port state            |
| <i>db_error_str</i>           | (Optional) prints cmd errors, if any           |
| <i>consistency_state</i>      | (Optional) Consistency state                   |

**Command Mode**

- /exec

## show san-port-channel database

```
show san-port-channel database [ interface <ifid> | all ] [ __readonly__ [ <error_str> ] [ {
TABLE_san_port_channel_database <interface> <admin_chan_mode> <oper_chan_mode>
<last_membership_update> [ <last_membership_update_fail_reason> ] [ <pcm_interface_flag> ] [
<vlan_interfaces> ] [ <first_operational_port> ] [ <total_ports> ] [ <total_oper_ports> ] [ {
TABLE_san_port_channel_member <port> <state> } } ] [ <cmd_error_str> ] ]
```

### Syntax Description

|   |  |
|---|--|
| show                                      | Show running system information                |
| san-port-channel                          | Show san-port-channel information              |
| database                                  | Show san-port-channel database                 |
| interface                                 | (Optional) Specify a port-channel              |
| <i>ifid</i>                               | (Optional)                                     |
| all                                       | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED      |
| <i>__readonly__</i>                       | (Optional) Read Only                           |
| <i>error_str</i>                          | (Optional) Prints errors,if any                |
| TABLE_san_port_channel_database           | (Optional) san-port-channel database Table     |
| <i>interface</i>                          | (Optional) san-po Interface                    |
| <i>admin_chan_mode</i>                    | (Optional) san-po administrative channel mode  |
| <i>oper_chan_mode</i>                     | (Optional) san-po operational channel mode     |
| <i>last_membership_update</i>             | (Optional) Last membership update status       |
| <i>last_membership_update_fail_reason</i> | (Optional) Membership update status casue      |
| <i>pcm_interface_flag</i>                 | (Optional) san-po interface flag               |
| <i>vlan_interfaces</i>                    | (Optional) san-po vlan interfaces              |
| <i>first_operational_port</i>             | (Optional) First oper port in san-po           |
| <i>total_ports</i>                        | (Optional) Total number of ports in the san-po |
| <i>total_oper_ports</i>                   | (Optional) Total oper ports in the san-po      |
| TABLE_san_port_channel_member             | (Optional) san-po member Table                 |
| <i>port</i>                               | (Optional) san-po member port                  |
| <i>state</i>                              | (Optional) san-po member port state            |
| <i>cmd_error_str</i>                      | (Optional) prints cmd errors,if any            |

**Command Mode**

- /exec



# show san-port-channel summary

```
show san-port-channel summary [ __readonly__ [ { TABLE_san_port_channel_summary <interface>
<total_ports> <total_oper_ports> <first_operational_port> } ] [ <cmd_error_str> ] ]
```

## Syntax Description

|                                       |  |
|---------------------------------------|--|
| <i>show</i>                           | Show running system information                |
| <i>san-port-channel</i>               | Show san-port-channel information              |
| <i>summary</i>                        | Show san-port-channel summary                  |
| <i>__readonly__</i>                   | (Optional) Read Only                           |
| <i>TABLE_san_port_channel_summary</i> | (Optional) san-port-channel Summary Table      |
| <i>interface</i>                      | (Optional) san-po Interface                    |
| <i>total_ports</i>                    | (Optional) Total number of ports in the san-po |
| <i>total_oper_ports</i>               | (Optional) Total oper ports in the san-po      |
| <i>first_operational_port</i>         | (Optional) First oper port in san-po           |
| <i>cmd_error_str</i>                  | (Optional) Prints cmd error,if any             |

## Command Mode

- /exec

## show san-port-channel usage

```
show san-port-channel usage [ __readonly__ [ <total_channel_numbers_used> { <used_range> } + {
<unused_range> } + ] [ <error_str> ] ]
```

### Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information               |
| san-port-channel                  | Show san-port-channel information             |
| usage                             | Show san-port-channel usages                  |
| <i>__readonly__</i>               | (Optional) Read Only                          |
| <i>total_channel_numbers_used</i> | (Optional) Total used number of port-channels |
| <i>used_range</i>                 | (Optional) Used range                         |
| <i>unused_range</i>               | (Optional) Un-used range                      |
| <i>error_str</i>                  | (Optional) Prints error if any                |

### Command Mode

- /exec

## show scheduler config

```
show scheduler config [ __readonly__ [ <terminal> ] [ <feature> ] [ <logfilesize> ] [ <emailfrom> ] [
<emailreplyto> ] [ <smtpserver> ] [ <port> ] [ <usevrf> ] [ { TABLE_userconfig <username> [ <password>
} ] ] [ { TABLE_jobconfig <jobdata> } ] [ { TABLE_scheduleconfig <schedulename> [ <scheduletype> ] [
{ TABLE_jobs <status> } ] [ <email> } ] ] ]
```

### Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| scheduler            | Show scheduler config or data   |
| config               | Display scheduler config        |
| <i>__readonly__</i>  | (Optional)                      |
| <i>terminal</i>      | (Optional) logfile terminal     |
| <i>feature</i>       | (Optional) name service         |
| <i>logfilesize</i>   | (Optional) logfilesize          |
| <i>emailfrom</i>     | (Optional) emailfrom            |
| <i>emailreplyto</i>  | (Optional) emailreplyto         |
| <i>smtpserver</i>    | (Optional) smtpserver           |
| <i>port</i>          | (Optional) port                 |
| <i>usevrf</i>        | (Optional) usevrf               |
| TABLE_userconfig     | (Optional) userconfig           |
| <i>username</i>      | (Optional) username             |
| <i>password</i>      | (Optional) password             |
| TABLE_jobconfig      | (Optional) job configs          |
| <i>jobdata</i>       | (Optional) jobdata              |
| TABLE_scheduleconfig | (Optional) schedule configs     |
| <i>schedulename</i>  | (Optional) schedulename         |
| <i>scheduletype</i>  | (Optional) scheduletype         |
| TABLE_jobs           | (Optional) jobs                 |
| <i>status</i>        | (Optional) status               |
| <i>email</i>         | (Optional) email                |

**Command Mode**

- /exec

# show scheduler job

```
show scheduler job [ name <s0> ] [ __readonly__ [ { TABLE_schedulerjobs <jobname> [ <jobdata> ] } ] ]
```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| show                | Show running system information    |
| scheduler           | Show scheduler config or data      |
| job                 | Display job information            |
| name                | (Optional) Specify the name of job |
| <i>s0</i>           | (Optional) Specify the job name    |
| <i>__readonly__</i> | (Optional)                         |
| TABLE_schedulerjobs | (Optional) schedulerjobs           |
| <i>jobname</i>      | (Optional) job name                |
| <i>jobdata</i>      | (Optional) job data                |

## Command Mode

- /exec

# show scheduler logfile

```
show scheduler logfile [ __readonly__ [ { TABLE_joblog <jobname> [ <jobstatus> ] [ <schedulename> ] [ <scheduleusername> ] [ <completiontime> ] [ <joboutput> ] } ] ]
```

## Syntax Description

|                         |                                  |
|-------------------------|----------------------------------|
| show                    | Show running system information  |
| scheduler               | Show scheduler config or data    |
| logfile                 | Display scheduler job output log |
| <i>__readonly__</i>     | (Optional)                       |
| <i>TABLE_joblog</i>     | (Optional) jobs log              |
| <i>jobname</i>          | (Optional) job name              |
| <i>jobstatus</i>        | (Optional) job status            |
| <i>schedulename</i>     | (Optional) schedulename          |
| <i>scheduleusername</i> | (Optional) scheduleusername      |
| <i>completiontime</i>   | (Optional) completiontime        |
| <i>joboutput</i>        | (Optional) joboutput             |

## Command Mode

- /exec

# show scheduler schedule

```
show scheduler schedule [ name <s0> ] [ __readonly__ [ { TABLE_schedules <schedulename> [
<scheduleusername> ] [ <scheduletype> ] [ <starttime> ] [ <lastexecetime> ] [ <lastcompletiontime> ] [
<execcount> ] [ <jobcount> ] [ { TABLE_jobs <jobname> [ <execstatus> ] } } ] ] ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information         |
| scheduler                 | Show scheduler config or data           |
| schedule                  | Display schedule information            |
| name                      | (Optional) Specify the name of schedule |
| <i>s0</i>                 | (Optional) Specify the schedule name    |
| <i>__readonly__</i>       | (Optional)                              |
| TABLE_schedules           | (Optional) schedules                    |
| <i>schedulename</i>       | (Optional) Schedule name                |
| <i>scheduleusername</i>   | (Optional) schedule username            |
| <i>scheduletype</i>       | (Optional) scheduletype                 |
| <i>starttime</i>          | (Optional) starttime                    |
| <i>lastexecetime</i>      | (Optional) last exec time               |
| <i>lastcompletiontime</i> | (Optional) lastcompletiontime           |
| <i>execcount</i>          | (Optional) execcount                    |
| <i>jobcount</i>           | (Optional) jobcount                     |
| TABLE_jobs                | (Optional) jobs                         |
| <i>jobname</i>            | (Optional) jobname                      |
| <i>execstatus</i>         | (Optional) execstatus                   |

## Command Mode

- /exec

## show segment-routing

```
show segment-routing [ detail ] [ __readonly__ <srvname> <state> <process_id> [ <srgb_min_label>
<srgb_max_label> <srgb_alloc_status> [ <oper_srgb_min_label> <oper_srgb_max_label> ] <cleanup_intvl>
<retry_intvl> [ <num_retries> ] [ <srgb_alloc_hdl> ] [ <cleanup_timer_state> <retry_timer_state> ] ] [
<ulib_reg_status> [ <ulib_pib_hdl> ] ] ]
```

### Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| segment-routing            | Show segment-routing status info      |
| detail                     | (Optional) Show detailed information  |
| __readonly__               | (Optional)                            |
| <i>srvname</i>             | (Optional) Service name               |
| <i>state</i>               | (Optional) Process state              |
| <i>process_id</i>          | (Optional) Process id                 |
| <i>srgb_min_label</i>      | (Optional) Configured SRGB min label  |
| <i>srgb_max_label</i>      | (Optional) Configured SRGB max label  |
| <i>srgb_alloc_status</i>   | (Optional) SRGB allocation status     |
| <i>oper_srgb_min_label</i> | (Optional) Operational SRGB min label |
| <i>oper_srgb_max_label</i> | (Optional) Operational SRGB max label |
| <i>cleanup_intvl</i>       | (Optional) SRGB cleanup interval      |
| <i>retry_intvl</i>         | (Optional) SRGB alloc retry interval  |
| <i>num_retries</i>         | (Optional) SRGB alloc retries done    |
| <i>srgb_alloc_hdl</i>      | (Optional) SRGB alloc handle          |
| <i>cleanup_timer_state</i> | (Optional) SRGB cleanup timer state   |
| <i>retry_timer_state</i>   | (Optional) SRGB retry timer state     |
| <i>ulib_reg_status</i>     | (Optional) ULIB registration done     |
| <i>ulib_pib_hdl</i>        | (Optional) ULIB PIB handle            |

### Command Mode

- /exec



## show segment-routing clients

```
show segment-routing clients [ __readonly__ [ { TABLE_client <client_pib_name> <client_pib_index>
<client_uuid> <client_pid> <client_sap> [ { TABLE_tib <vrf_name> <tib_name> [ <pfxsid_cleanup_status>
] } ] } ] <total_clients> ]
```

### Syntax Description

|                              |                                       |
|------------------------------|---------------------------------------|
| show                         | Show running system information       |
| segment-routing              | Show segment-routing status info      |
| clients                      | Show client info                      |
| <i>__readonly__</i>          | (Optional)                            |
| TABLE_client                 | (Optional)                            |
| <i>client_pib_name</i>       | (Optional) Client name                |
| <i>client_pib_index</i>      | (Optional) Client pib index           |
| <i>client_uuid</i>           | (Optional) Client UUID                |
| <i>client_pid</i>            | (Optional) Client PID                 |
| <i>client_sap</i>            | (Optional) Client SAP                 |
| TABLE_tib                    | (Optional)                            |
| <i>vrf_name</i>              | (Optional) VRF name                   |
| <i>tib_name</i>              | (Optional) Table name                 |
| <i>pfxsid_cleanup_status</i> | (Optional) Prefixsid Cleanup Pending? |
| <i>total_clients</i>         | (Optional) Total number of clients    |

### Command Mode

- /exec

## show segment-routing ipv4 connected-prefix-sid-map

```
show segment-routing ipv4 connected-prefix-sid-map [ __readonly__ [ { TABLE_tib <vrf_name> <tib_name>
[ { TABLE_pfxsid <prefix> <index> <absolute> <range> <valid> } ] } ] ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information            |
| segment-routing          | Show segment-routing status info           |
| ipv4                     | Show info for IPv4 address-family          |
| connected-prefix-sid-map | Show prefix-sid mapping                    |
| <i>__readonly__</i>      | (Optional)                                 |
| <i>TABLE_tib</i>         | (Optional)                                 |
| <i>vrf_name</i>          | (Optional) Vrf name                        |
| <i>tib_name</i>          | (Optional) Table name                      |
| <i>TABLE_pfxsid</i>      | (Optional)                                 |
| <i>prefix</i>            | (Optional) Prefix                          |
| <i>index</i>             | (Optional) Segment ID                      |
| <i>absolute</i>          | (Optional) Segment ID is absolute?         |
| <i>range</i>             | (Optional) Range of Segment IDs from index |
| <i>valid</i>             | (Optional) Segment ID is valid?            |

### Command Mode

- /exec

## show segment-routing mpls

```
show segment-routing mpls [ detail ] [ __readonly__ <srvname> <state> <process_id> [ <srgb_min_label>
<srgb_max_label> <srgb_alloc_status> [ <oper_srgb_min_label> <oper_srgb_max_label> ] <cleanup_intvl>
<retry_intvl> [ <num_retries> ] [ <srgb_alloc_hdl> ] [ <cleanup_timer_state> <retry_timer_state> ] [
<ulib_reg_status> [ <ulib_pib_hdl> ] ] ]
```

### Syntax Description

|                            |                                       |
|----------------------------|---------------------------------------|
| show                       | Show running system information       |
| segment-routing            | Show segment-routing status info      |
| mpls                       | Show segment-routing mpls info        |
| detail                     | (Optional) Show detailed information  |
| __readonly__               | (Optional)                            |
| <i>srvname</i>             | (Optional) Service name               |
| <i>state</i>               | (Optional) Process state              |
| <i>process_id</i>          | (Optional) Process id                 |
| <i>srgb_min_label</i>      | (Optional) Configured SRGB min label  |
| <i>srgb_max_label</i>      | (Optional) Configured SRGB max label  |
| <i>srgb_alloc_status</i>   | (Optional) SRGB allocation status     |
| <i>oper_srgb_min_label</i> | (Optional) Operational SRGB min label |
| <i>oper_srgb_max_label</i> | (Optional) Operational SRGB max label |
| <i>cleanup_intvl</i>       | (Optional) SRGB cleanup interval      |
| <i>retry_intvl</i>         | (Optional) SRGB alloc retry interval  |
| <i>num_retries</i>         | (Optional) SRGB alloc retries done    |
| <i>srgb_alloc_hdl</i>      | (Optional) SRGB alloc handle          |
| <i>cleanup_timer_state</i> | (Optional) SRGB cleanup timer state   |
| <i>retry_timer_state</i>   | (Optional) SRGB retry timer state     |
| <i>ulib_reg_status</i>     | (Optional) ULIB registration done     |
| <i>ulib_pib_hdl</i>        | (Optional) ULIB PIB handle            |

### Command Mode

- /exec

## show segment-routing mpls clients

```
show segment-routing mpls clients [ __readonly__ [ { TABLE_client <client_pib_name> <client_pib_index>
<client_uuid> <client_pid> <client_sap> [ { TABLE_tib <vrf_name> <tib_name> [ <pxsid_cleanup_status>
] } ] } ] <total_clients> ]
```

### Syntax Description

|                             |                                       |
|-----------------------------|---------------------------------------|
| show                        | Show running system information       |
| segment-routing             | Show segment-routing status info      |
| mpls                        | Show segment-routing mpls info        |
| clients                     | Show client info                      |
| <i>__readonly__</i>         | (Optional)                            |
| <i>TABLE_client</i>         | (Optional)                            |
| <i>client_pib_name</i>      | (Optional) Client name                |
| <i>client_pib_index</i>     | (Optional) Client pib index           |
| <i>client_uuid</i>          | (Optional) Client UUID                |
| <i>client_pid</i>           | (Optional) Client PID                 |
| <i>client_sap</i>           | (Optional) Client SAP                 |
| <i>TABLE_tib</i>            | (Optional)                            |
| <i>vrf_name</i>             | (Optional) VRF name                   |
| <i>tib_name</i>             | (Optional) Table name                 |
| <i>pxsid_cleanup_status</i> | (Optional) Prefixsid Cleanup Pending? |
| <i>total_clients</i>        | (Optional) Total number of clients    |

### Command Mode

- /exec

# show segment-routing mpls ipv4 connected-prefix-sid-map

```
show segment-routing mpls ipv4 connected-prefix-sid-map [ __readonly__ [ { TABLE_tib <vrf_name>
<tib_name> [ { TABLE_pfxsid <prefix> <index> <absolute> <range> <valid> } ] } ] ] ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information            |
| segment-routing          | Show segment-routing status info           |
| mpls                     | Show segment-routing mpls info             |
| ipv4                     | Show info for IPv4 address-family          |
| connected-prefix-sid-map | Show prefix-sid mapping                    |
| <i>__readonly__</i>      | (Optional)                                 |
| <i>TABLE_tib</i>         | (Optional)                                 |
| <i>vrf_name</i>          | (Optional) Vrf name                        |
| <i>tib_name</i>          | (Optional) Table name                      |
| <i>TABLE_pfxsid</i>      | (Optional)                                 |
| <i>prefix</i>            | (Optional) Prefix                          |
| <i>index</i>             | (Optional) Segment ID                      |
| <i>absolute</i>          | (Optional) Segment ID is absolute?         |
| <i>range</i>             | (Optional) Range of Segment IDs from index |
| <i>valid</i>             | (Optional) Segment ID is valid?            |

## Command Mode

- /exec

# show sflow

```
show sflow [ __readonly__ <sampling-rate> <max-sampled-size> <counter-poll-interval> <max-datagram-size>
<collector-vrf> <collector-ip> [ <source-ip> ] <collector-port> <agent-ip> [ <data-source-interface> + ] ]
```

## Syntax Description

|                              |                                    |
|------------------------------|------------------------------------|
| show                         | Show running system information    |
| sflow                        | Display sFlow global configuration |
| <i>__readonly__</i>          | (Optional) Read only               |
| <i>sampling-rate</i>         | (Optional) Sampling Rate           |
| <i>max-sampled-size</i>      | (Optional) Max Sampled Size        |
| <i>counter-poll-interval</i> | (Optional) Counter Poll Interval   |
| <i>max-datagram-size</i>     | (Optional) Max Datagram Size       |
| <i>collector-vrf</i>         | (Optional) Collector VRF           |
| <i>collector-ip</i>          | (Optional) Collector IP            |
| <i>source-ip</i>             | (Optional) Source IP               |
| <i>collector-port</i>        | (Optional) Collector Port          |
| <i>agent-ip</i>              | (Optional) Agent IP                |
| <i>data-source-interface</i> | (Optional) Data Source Interface   |

## Command Mode

- /exec

# show sflow statistics

```
show sflow statistics [ __readonly__ <total-packets> <total-samples> <processed-samples> <dropped-samples>
[ <rate-limiter-drops> ] [ <dropped-sflow-samples> ] <sent-datagrams> <dropped-datagrams> ]
```

## Syntax Description

|                              |                                    |
|------------------------------|------------------------------------|
| show                         | Show running system information    |
| sflow                        | Display sFlow global configuration |
| statistics                   | Display sFlow statistics           |
| <i>__readonly__</i>          | (Optional) Read only               |
| <i>total-packets</i>         | (Optional) Total Packets           |
| <i>total-samples</i>         | (Optional) Total Samples           |
| <i>processed-samples</i>     | (Optional) Processed Samples       |
| <i>dropped-samples</i>       | (Optional) Dropped Samples         |
| <i>rate-limiter-drops</i>    | (Optional) Rate-Limiter Drops      |
| <i>dropped-sflow-samples</i> | (Optional) Dropped sflow Samples   |
| <i>sent-datagrams</i>        | (Optional) Sent Datagrams          |
| <i>dropped-datagrams</i>     | (Optional) Dropped Datagrams       |

## Command Mode

- /exec

# show snapshots

show snapshots [ \_\_readonly\_\_ TABLE\_snapshot <snap\_name> <snap\_ctime> <description> ]

## Syntax Description

|                    |                                 |
|--------------------|---------------------------------|
| show               | Show running system information |
| snapshots          | Snapshots present on the switch |
| __readonly__       | (Optional)                      |
| TABLE_snapshot     | (Optional)                      |
| <i>snap_name</i>   | (Optional) snapshot name        |
| <i>snap_ctime</i>  | (Optional) snapshot create time |
| <i>description</i> | (Optional) snapshot description |

## Command Mode

- /exec



# show snapshots compare

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> [ __readonly__ TABLE_feature
<feat_name> [ <feat_state1> <feat_state2> ] [ TABLE_element <elemkey1> <elemval1> [ <elemkey2>
<elemval2> ] [ <elemkey3> <elemval3> ] [ <elemkey4> <elemval4> ] [ <elemstate1> <elemstate2> ] [
TABLE_value <tag> <val1> <val2> ] [ TABLE_subrow <subrowkey> <subrowval> [ <substate1> <substate2>
] [ TABLE_subvalue <tag> <val1> <val2> ] ] ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information         |
| snapshots               | Snapshots present on the switch         |
| compare                 | Compare two snapshots                   |
| <i>snapshot-name-T1</i> | Name of a snapshot taken at interval T1 |
| <i>snapshot-name-T2</i> | Name of a snapshot taken at interval T2 |
| <i>__readonly__</i>     | (Optional)                              |
| TABLE_feature           | (Optional)                              |
| <i>feat_name</i>        | (Optional) feature name                 |
| <i>feat_state1</i>      | (Optional) feature state in snapshot1   |
| <i>feat_state2</i>      | (Optional) feature state in snapshot2   |
| TABLE_element           | (Optional)                              |
| <i>elemkey1</i>         | (Optional) element key1                 |
| <i>elemval1</i>         | (Optional) element value1               |
| <i>elemkey2</i>         | (Optional) element key2                 |
| <i>elemval2</i>         | (Optional) element value2               |
| <i>elemkey3</i>         | (Optional) element key3                 |
| <i>elemval3</i>         | (Optional) element value3               |
| <i>elemkey4</i>         | (Optional) element key4                 |
| <i>elemval4</i>         | (Optional) element value4               |
| <i>elemstate1</i>       | (Optional) element state in snapshot 1  |
| <i>elemstate2</i>       | (Optional) element state in snapshot 2  |
| TABLE_value             | (Optional)                              |
| <i>tag</i>              | (Optional) element tag                  |

|                  |   |
|------------------|---|
| <i>val1</i>      | (Optional) element value for tag in snapshot1 |
| <i>val2</i>      | (Optional) element value for tag in snapshot2 |
| TABLE_subrow     | (Optional)                                    |
| <i>subrowkey</i> | (Optional) subrow key                         |
| <i>subrowval</i> | (Optional) subrow value                       |
| <i>substate1</i> | (Optional) subrow state in snapshot 1         |
| <i>substate2</i> | (Optional) subrow state in snapshot 2         |
| TABLE_subvalue   | (Optional)                                    |
| <i>tag</i>       | (Optional) subrow tag                         |
| <i>val1</i>      | (Optional) subrow value for tag in snapshot1  |
| <i>val2</i>      | (Optional) subrow value for tag in snapshot2  |

**Command Mode**

- /exec

## show snapshots compare ipv4routes

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> ipv4routes [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] [ TABLE_prefix <prefix>
<missing_snapshot> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information         |
| snapshots               | Snapshots present on the switch         |
| compare                 | Compare two snapshots                   |
| <i>snapshot-name-T1</i> | Name of a snapshot taken at interval T1 |
| <i>snapshot-name-T2</i> | Name of a snapshot taken at interval T2 |
| ipv4routes              | Compare ipv4 route information          |
| <i>__readonly__</i>     | (Optional)                              |
| TABLE_summary           | (Optional)                              |
| <i>item_desc</i>        | (Optional) item description             |
| <i>summary_val1</i>     | (Optional) summary value in snapshot1   |
| <i>summary_val2</i>     | (Optional) summary value in snapshot2   |
| <i>changed</i>          | (Optional) changed flag                 |
| TABLE_prefix            | (Optional)                              |
| <i>prefix</i>           | (Optional) route prefix                 |
| <i>missing_snapshot</i> | (Optional) missing in snapshot name     |

### Command Mode

- /exec

# show snapshots compare ipv6routes

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> ipv6routes [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] [ TABLE_prefix <prefix>
<missing_snapshot> ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information         |
| snapshots               | Snapshots present on the switch         |
| compare                 | Compare two snapshots                   |
| <i>snapshot-name-T1</i> | Name of a snapshot taken at interval T1 |
| <i>snapshot-name-T2</i> | Name of a snapshot taken at interval T2 |
| ipv6routes              | Compare ipv6 route information          |
| <i>__readonly__</i>     | (Optional)                              |
| TABLE_summary           | (Optional)                              |
| <i>item_desc</i>        | (Optional) item description             |
| <i>summary_val1</i>     | (Optional) summary value in snapshot1   |
| <i>summary_val2</i>     | (Optional) summary value in snapshot2   |
| <i>changed</i>          | (Optional) changed flag                 |
| TABLE_prefix            | (Optional)                              |
| <i>prefix</i>           | (Optional) route prefix                 |
| <i>missing_snapshot</i> | (Optional) missing in snapshot name     |

## Command Mode

- /exec

## show snapshots compare summary

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> summary [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information         |
| snapshots               | Snapshots present on the switch         |
| compare                 | Compare two snapshots                   |
| <i>snapshot-name-T1</i> | Name of a snapshot taken at interval T1 |
| <i>snapshot-name-T2</i> | Name of a snapshot taken at interval T2 |
| summary                 | Compare summary information             |
| <i>__readonly__</i>     | (Optional)                              |
| <i>TABLE_summary</i>    | (Optional)                              |
| <i>item_desc</i>        | (Optional) item description             |
| <i>summary_val1</i>     | (Optional) summary value in snapshot1   |
| <i>summary_val2</i>     | (Optional) summary value in snapshot2   |
| <i>changed</i>          | (Optional) changed flag                 |

### Command Mode

- /exec

# show snapshots dump

```
show snapshots dump <snapshot-name> <section-name> [ __readonly__ TABLE_snapshot <file_name>
<snap_name> ]
```

## Syntax Description

|                           |                                   |
|---------------------------|-----------------------------------|
| show                      | Show running system information   |
| snapshots                 | Snapshots present on the switch   |
| dump                      | Dump contents of snapshot         |
| <i>snapshot-name</i>      | Name of a snapshot                |
| <i>section-name</i>       | Name of snapshot section          |
| <code>__readonly__</code> | (Optional)                        |
| TABLE_snapshot            | (Optional)                        |
| <i>file_name</i>          | (Optional) snapshot XML file name |
| <i>snap_name</i>          | (Optional) snapshot name          |

## Command Mode

- /exec

# show snapshots dump

show snapshots dump <snapshot-name> [ \_\_readonly\_\_ TABLE\_snapshot <file\_name> <snap\_name> ]

## Syntax Description

|                      |                                   |
|----------------------|-----------------------------------|
| show                 | Show running system information   |
| snapshots            | Snapshots present on the switch   |
| dump                 | Dump contents of snapshot         |
| <i>snapshot-name</i> | Name of a snapshot                |
| __readonly__         | (Optional)                        |
| TABLE_snapshot       | (Optional)                        |
| <i>file_name</i>     | (Optional) snapshot XML file name |
| <i>snap_name</i>     | (Optional) snapshot name          |

## Command Mode

- /exec

# show snapshots sections

show snapshots sections [ *\_\_readonly\_\_* *TABLE\_snapsection* <sectname> <sectcmd> <sectrow> <sectkey1> <sectkey2> ]

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information          |
| snapshots                | Snapshots present on the switch          |
| sections                 | User-specified snapshot sections         |
| <i>__readonly__</i>      | (Optional)                               |
| <i>TABLE_snapsection</i> | (Optional)                               |
| <i>sectname</i>          | (Optional) snapshot section name         |
| <i>sectcmd</i>           | (Optional) snapshot section show command |
| <i>sectrow</i>           | (Optional) snapshot section row id       |
| <i>sectkey1</i>          | (Optional) snapshot section key1         |
| <i>sectkey2</i>          | (Optional) snapshot section key2         |

## Command Mode

- /exec



# show snmp

```
show snmp [ __readonly__ <sys_contact> <sys_location> <snmp_input_packets> <bad_snmp_version>
<unknown_community_name> <illegal_community_name> <encoding_Err> <req_var_nums> <alt_var_nums>
<get_req_in> <getnext_req_in> <set_req_in> <noname_pdu_in> <badval_pdu_in> <ro_pdu_in>
<genral_err_in> <get_resp_in> <unknown_ctx> <snmp_output_packets> <trap_pdu> <toobig_err>
<noname_pdu_out> <badval_pdu_out> <genral_err_out> <get_req_out> <getnext_req_out> <set_req_out>
<get_resp_out> <silent_drops> [ <max_pkt_size> ] [ { TABLE_snmp_community <community_name>
<grouporaccess> <context> <aclfilter> } ] [ { TABLE_snmp_users <user> <auth> <priv> [ { TABLE_groups
<group> } ] [ <acl_filter> ] [ <engineID> } ] ] <tcp_auth_status> [ <port_mon_status> [ <policy_name>
<pol_admin_status> <plo_oper_status> <pol_port_type> [ TABLE_policies <counter> <threshold> <interval>
<rising_threshold> <rising_event> <falling_threshold> <falling_event> <pmon_config> ] ] ] [ <protocol_status>
] [ { TABLE_snmp_contexts <context_name> <proto_instanceid> <vrf> <topology> [ <vlan> | <MST> } ]
] ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                          |
| snmp                          | show snmp information                                    |
| <i>__readonly__</i>           | (Optional) Read Only                                     |
| TABLE_snmp_community          | (Optional) Table that displays the community information |
| TABLE_snmp_users              | (Optional) Table that displays the user information      |
| TABLE_groups                  | (Optional) Table that displays the group information     |
| TABLE_policies                | (Optional) Table that displays the policy information    |
| TABLE_snmp_contexts           | (Optional) Table that displays the context information   |
| <i>sys_contact</i>            | (Optional) System Contact                                |
| <i>sys_location</i>           | (Optional) System Location                               |
| <i>snmp_input_packets</i>     | (Optional) SNMP input packets                            |
| <i>bad_snmp_version</i>       | (Optional) bad snmp version in Input SNMP packets        |
| <i>unknown_community_name</i> | (Optional) unknown community name in Input SNMP packets  |
| <i>illegal_community_name</i> | (Optional) Illegal community name in Input SNMP packets  |
| <i>encoding_Err</i>           | (Optional) Encoding Errors in Input SNMP packets         |
| <i>req_var_nums</i>           | (Optional) number of requested variables                 |
| <i>alt_var_nums</i>           | (Optional) number of altered variable                    |
| <i>get_req_in</i>             | (Optional) GET request in Input SNMP packets             |
| <i>getnext_req_in</i>         | (Optional) GET-NEXT request in Input SNMP packets        |

|                            |   |
|----------------------------|---|
| <i>set_req_in</i>          | (Optional) SET request in Input SNMP packets          |
| <i>noname_pdu_in</i>       | (Optional) NONAME PDU in Input SNMP packets           |
| <i>badval_pdu_in</i>       | (Optional) Bad value PDU in Input SNMP packets        |
| <i>ro_pdu_in</i>           | (Optional) Read only PDU in Input SNMP packets        |
| <i>genral_err_in</i>       | (Optional) Genral Error in Input SNMP packets         |
| <i>get_resp_in</i>         | (Optional) Get Response PDU in Input SNMP packets     |
| <i>unknown_ctx</i>         | (Optional) Unknown context Name in Input SNMP packets |
| <i>snmp_output_packets</i> | (Optional) SNMP Output Packets                        |
| <i>trap_pdu</i>            | (Optional) Trap PDU in Output SNMP Packets            |
| <i>toobig_err</i>          | (Optional) Too Big errors in Output SNMP Packets      |
| <i>noname_pdu_out</i>      | (Optional)  |
| <i>badval_pdu_out</i>      | (Optional) NoName PDU in Output SNMP Packets          |
| <i>genral_err_out</i>      | (Optional) Genral Error in Output SNMP Packets        |
| <i>get_req_out</i>         | (Optional) GET request in Output SNMP Packets         |
| <i>getnext_req_out</i>     | (Optional) GET-NEXTrequest in Output SNMP Packets     |
| <i>set_req_out</i>         | (Optional) SET request in Output SNMP packets         |
| <i>get_resp_out</i>        | (Optional) Get Response PDU in Output SNMP Packets    |
| <i>silent_drops</i>        | (Optional) Silent Drop packets                        |
| <i>max_pkt_size</i>        | (Optional) Maximum packet size                        |
| <i>community_name</i>      | (Optional) community name                             |
| <i>grouporaccess</i>       | (Optional) Group name                                 |
| <i>context</i>             | (Optional) context Name                               |
| <i>aclfilter</i>           | (Optional) Acl filter name                            |
| <i>user</i>                | (Optional) User name                                  |
| <i>auth</i>                | (Optional) Auth type                                  |
| <i>priv</i>                | (Optional) Priv Type                                  |
| <i>group</i>               | (Optional) Group name                                 |
| <i>acl_filter</i>          | (Optional) acl filter                                 |
| <i>engineID</i>            | (Optional) engine id for the user                     |

|                          |                                      |
|--------------------------|--------------------------------------|
| <i>tcp_auth_status</i>   | (Optional) TCP authentication status |
| <i>port_mon_status</i>   | (Optional) Port monitor status       |
| <i>policy_name</i>       | (Optional) policy name               |
| <i>pol_admin_status</i>  | (Optional) Policy Admin status       |
| <i>plo_oper_status</i>   | (Optional) Police oper status        |
| <i>pol_port_type</i>     | (Optional) policy port type          |
| <i>counter</i>           | (Optional) counters                  |
| <i>threshold</i>         | (Optional) Threshold                 |
| <i>interval</i>          | (Optional) Interval                  |
| <i>rising_threshold</i>  | (Optional) Rising threshold          |
| <i>rising_event</i>      | (Optional) Rising Event              |
| <i>falling_threshold</i> | (Optional) Falling threshold         |
| <i>falling_event</i>     | (Optional) Falling Event             |
| <i>pmon_config</i>       | (Optional) PMON configured           |
| <i>protocol_status</i>   | (Optional) Protocol Enable status    |
| <i>context_name</i>      | (Optional) context name              |
| <i>proto_instanceid</i>  | (Optional) Protocol instance ID      |
| <i>vrf</i>               | (Optional) VRF Name                  |
| <i>topology</i>          | (Optional) Topology                  |
| <i>vlan</i>              | (Optional) VLAN name                 |
| <i>MST</i>               | (Optional) MST name                  |

**Command Mode**

- /exec

# show snmp community

```
show snmp community [ __readonly__ { TABLE_snmp_community <community_name> <grouporaccess>
<context> <aclfilter> } ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information              |
| snmp                  | show snmp information                        |
| community             | show snmp community strings                  |
| __readonly__          | (Optional) Read Only                         |
| TABLE_snmp_community  | (Optional) contains all snmp community names |
| <i>community_name</i> | (Optional) community name                    |
| <i>grouporaccess</i>  | (Optional) group or access name              |
| <i>context</i>        | (Optional) context name                      |
| <i>aclfilter</i>      | (Optional) acl filter name                   |

## Command Mode

- /exec

# show snmp context

```
show snmp context [ __readonly__ { TABLE_snmp_contexts <context_name> <proto_instanceid> <vrf>
<topology> [ <vlan> | <MST> ] } ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information          |
| snmp                    | show snmp information                    |
| context                 | show snmp context mapping entries        |
| __readonly__            | (Optional)                               |
| TABLE_snmp_contexts     | (Optional) All SNMP Contexts Entries     |
| <i>context_name</i>     | (Optional) SNMP context Name             |
| <i>proto_instanceid</i> | (Optional) Name of the protocol instance |
| <i>vrf</i>              | (Optional) VRF name                      |
| <i>topology</i>         | (Optional) Name of the Topology          |
| <i>vlan</i>             | (Optional) VLAN Name                     |
| <i>MST</i>              | (Optional)                               |

## Command Mode

- /exec

# show snmp engineID

show snmp engineID [ \_\_readonly\_\_ <engineIDHex> <engineIDDec> ]

## Syntax Description

|                    |                                     |
|--------------------|-------------------------------------|
| show               | Show running system information     |
| snmp               | show snmp information               |
| engineID           | show snmp engineID                  |
| __readonly__       | (Optional)                          |
| <i>engineIDHex</i> | (Optional) SNMP engineID in HEX     |
| <i>engineIDDec</i> | (Optional) SNMP engineID in Decimal |

## Command Mode

- /exec

# show snmp group

```
show snmp group [ __readonly__ { TABLE_role <role_name> <role_description> [ <attribute_scope> ] [
<permit_vsan> ] [ <permit_vlan> ] [ <permit_vlan_id> ] [ <permit_interface> ] [ <permit_interface_slot> ]
[ <permit_vrf> ] [ TABLE_vrf<permit_vrf_name> ] [ { TABLE_rule [ <rule_num> ] [ <rule_action> ] {
<rule_permission> | <rule_permission_mds> } [ <rule_featuretype> ] [ <rule_entity> ] } } ]
```

## Syntax Description

|                              |                                 |
|------------------------------|---------------------------------|
| show                         | Show running system information |
| snmp                         | show snmp information           |
| group                        | show snmp group                 |
| <i>__readonly__</i>          | (Optional) Read Only            |
| TABLE_role                   | (Optional) Table displays role  |
| <i>role_name</i>             | (Optional) Role Name            |
| <i>role_description</i>      | (Optional) Role Description     |
| <i>attribute_scope</i>       | (Optional) Role scope           |
| <i>permit_vsan</i>           | (Optional) permitted vsan       |
| <i>permit_vlan</i>           | (Optional)                      |
| <i>permit_vlan_id</i>        | (Optional)                      |
| <i>permit_interface</i>      | (Optional)                      |
| <i>permit_interface_slot</i> | (Optional)                      |
| <i>permit_vrf</i>            | (Optional)                      |
| TABLE_rule                   | (Optional)                      |
| <i>rule_num</i>              | (Optional)                      |
| <i>rule_action</i>           | (Optional)                      |
| <i>rule_permission</i>       | (Optional)                      |
| <i>rule_permission_mds</i>   | (Optional)                      |
| <i>rule_featuretype</i>      | (Optional)                      |
| <i>rule_entity</i>           | (Optional)                      |

## Command Mode

- /exec

# show snmp host

```
show snmp host [ __readonly__ { TABLE_host <host><port><version><level><type><secname> [ [ <vrf>
] [ TABLE_vrf_filters <vrf_filter> ] [ <src_intf> ] ] } ]
```

## Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                                    |
| snmp                     | show snmp information  |
| host                     | show snmp hosts  |
| <i>__readonly__</i>      | (Optional) Read Only   |
| <i>TABLE_host</i>        | (Optional) displays the list of hosts configured for snmp requests |
| <i>TABLE_vrf_filters</i> | (Optional) displays the host vrf filters                           |
| <i>vrf</i>               | (Optional) VRF Name  |
| <i>vrf_filter</i>        | (Optional) vrf filters   |
| <i>src_intf</i>          | (Optional) source interface  |

## Command Mode

- /exec



# show snmp nms-statistics

```
show snmp nms-statistics [ __readonly__ <header> [ <nms_stats> ] ]
```

## Syntax Description

|                  |                                  |
|------------------|----------------------------------|
| show             | Show running system information  |
| snmp             | Show snmp information            |
| nms-statistics   | Show SNMP NMS statistics         |
| __readonly__     | (Optional) Read Only             |
| <i>header</i>    | (Optional) NMS Statistics header |
| <i>nms_stats</i> | (Optional) NMS Statistics        |

## Command Mode

- /exec

## show snmp oid-statistics

```
show snmp oid-statistics [ last-access ] [ __readonly__ <header> { TABLE_snmp_gen <oid_stats> |
TABLE_snmp_la <oid_last_access_stats> } ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                         |
| snmp                         | Show snmp information                                   |
| oid-statistics               | Show SNMP oid statistics                                |
| last-access                  | (Optional) Show SNMP oid statistics of last-access      |
| __readonly__                 | (Optional) Read Only                                    |
| <i>header</i>                | (Optional) OID Statistics header                        |
| TABLE_snmp_gen               | (Optional) contains all snmp oid statistics             |
| <i>oid_stats</i>             | (Optional) OID Statistics                               |
| TABLE_snmp_la                | (Optional) contains all snmp oid last access statistics |
| <i>oid_last_access_stats</i> | (Optional) OID Last Access Statistics                   |

### Command Mode

- /exec

# show snmp sessions

show snmp sessions [ \_\_readonly\_\_ { TABLE\_session <dest> } ]

## Syntax Description

|               |                                       |
|---------------|---------------------------------------|
| show          | Show running system information       |
| snmp          | show snmp information                 |
| sessions      | show snmp sessions                    |
| __readonly__  | (Optional) Read Only                  |
| TABLE_session | (Optional) table displays destination |
| <i>dest</i>   | (Optional) destination                |

## Command Mode

- /exec

# show snmp source-interface

```
show snmp source-interface [ __readonly__ { <trap_srcintf> <informs_srcintf> } ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                            |
| snmp                   | show snmp information                                      |
| source-interface       | show source-interface through which notifications are sent |
| __readonly__           | (Optional) Read Only                                       |
| <i>trap_srcintf</i>    | (Optional) Displays the source interface for traps         |
| <i>informs_srcintf</i> | (Optional) Displays the source interface for informs       |

## Command Mode

- /exec

# show snmp trap

```
show snmp trap [ __readonly__ { TABLE_snmp_trap <trap_type><description><isEnabled> } ]
```

## Syntax Description

|                 |                                      |
|-----------------|--------------------------------------|
| show            | Show running system information      |
| snmp            | show snmp information                |
| trap            | show snmp traps                      |
| __readonly__    | (Optional) Read Only                 |
| TABLE_snmp_trap | (Optional) All snmp traps configured |

## Command Mode

- /exec

# show snmp user

```
show snmp user [ <s0> [ engineID <s1> ] ] [ __readonly__ [ { TABLE_snmp_users <user> <auth> <priv> [ <group> ] + [ <acl_filter> ] [ <engineID> } ] ] ]
```

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                                      |
| snmp              | show snmp information  |
| user              | show SNMPv3 users  |
| <i>s0</i>         | (Optional) Name of the user  |
| engineID          | (Optional) engineID  |
| <i>s1</i>         | (Optional) Target's SNMP engineID(colon separated) for SNMPv3 inform |
| __readonly__      | (Optional) Read Only   |
| TABLE_snmp_users  | (Optional) table displays the snmp users                             |
| <i>user</i>       | (Optional) user name   |
| <i>auth</i>       | (Optional) auth type   |
| <i>priv</i>       | (Optional) priv type   |
| <i>group</i>      | (Optional) group belongs to  |
| <i>acl_filter</i> | (Optional) acl filter  |
| <i>engineID</i>   | (Optional) engineID for specific user                                |

## Command Mode

- /exec

## show sockets client

```

show sockets client { [ pid <pid> ] [ tcp | udp | raw ] [ detail ] [ kstack-ns-all ] } [ __readonly__ [
TABLE_total_clients [ <socket-type> <total-clients> ] [ <no-total-clients> ] ] [ TABLE_cl_sk { <prefix>
<client-name> <pid> <No-of-clients> } [ <fast-tcp-mts-ctrl-q> ] [ { <cancel-requests> <cancel-unblocks>
<cancel-misses> <select-drops> <select-wakes> } ] [ TABLE_det [ { <fd> <client-id> [ <mts-sap> ] } ] ] [
TABLE_st [ <soc-calls> ] [ <bind-calls> ] [ <listen-calls> ] [ <accept-calls> ] [ <acc-dispat-err> ] [
<connect-calls> ] [ <connec-dispatch> ] [ <recvmsg-dispatch> ] [ <recv-dis-nblock> ] [ <recvmsg-call> ] [
<brecv-dispatch> ] [ <fsendmsg-calls> ] [ <sendmsg-dispatch> ] [ <sendmsg-calls> ] [ <msendmsg-calls> ]
[ <select-calls> ] [ <select-dispatch> ] [ <select-need-work> ] [ <sh-calls> ] [ <close-calls> ] [ <fcntl-calls>
] [ <iocctl-calls> ] [ <setsock-calls> ] [ <getsock-calls> ] [ <getsockname-calls> ] [ <getpeer-calls> ] [
<fork-calls> ] [ <execve-calls> ] [ <dup-calls> ] [ <can-calls> ] [ <can-miss> ] [ <can-unblk-sele> ] [
<soc-ha-calls> ] [ <pfork-client> ] [ <read-fd> ] [ <write-fd> ] [ <read-fd-set> ] [ <write-fd-set> ] [
<fast-tcp-send-req> ] [ <fast-tcp-send-suc> ] [ <fast-tcp-ack> ] ] [ TABLE_sterr [ <sock-err> ] [
<sock-nodev-err> ] [ <bind-err> ] [ <lis-err> ] [ <accept-err> ] [ <connect-err> ] [ <recvmsg-err> ] [
<brecvmsg-err> ] [ <fsendmsg-err> ] [ <sendmsg-err> ] [ <msndmsg-err> ] [ <select-err> ] [ <sel-nomem-err>
] [ <shut-err> ] [ <close-err> ] [ <fcntl-err> ] [ <iocctl-err> ] [ <setsock-err> ] [ <getsock-err> ] [ <getsockname-err>
] [ <getpeername-err> ] [ <fork-err> ] [ <execve-err> ] [ <dup-err> ] [ <psoc-vrf-err> ] [ <psoc-nosoc-err> ]
[ <psoc-sock-null-err> ] [ <psoc-socre-err> ] [ <pbind-nsock-err> ] [ <pbd-getsockaddr> ] [ <pbind-sobind-err>
] [ <plisten-nsoc-err> ] [ <pplis-solis-err> ] [ <pacc-nsoc-err> ] [ <pacc-no-nsoc-err> ] [ <pacc-soc-null-err>
] [ <pacc-copy-err> ] [ <pacc-no-acc-err> ] [ <pacc-woublo-err> ] [ <pacc-connabo-err> ] [
<pacc-cond-wait-err> ] [ <pacc-so-err-err> ] [ <pacc-err-err> ] [ <pcon-no-soc-err> ] [ <pcon-ealready-err>
] [ <pconn-getsock> ] [ <pconn-socon-err> ] [ <pconn-einpro-err> ] [ <pconn-con-wait-err> ] [
<pSEND-no-soc-err> ] [ <pSEND-inval-ioV> ] [ <pSEND-getsock-err> ] [ <pSEND-msg-ctrl-err> ] [
<pSEND-sockarg-err> ] [ <pSEND-pru-sosend> ] [ <precv-nosock-err> ] [ <precv-inval-ioVlen> ] [
<precv-pru-sorecv> ] [ <precv-cp-msg-err> ] [ <precv-cp-msg-nlen> ] [ <precv-cp-data-err> ] [
<pbrEcv-rcvmsg-err> ] [ <pshut-no-soc-err> ] [ <psetsock-val-err> ] [ <psetsock-inv-val> ] [ <psetsock-no-soc-err>
] [ <psetsock-sosetopt> ] [ <pgetsock-no-socerr> ] [ <pgetsock-cp-err> ] [ <pgetsock-val-err> ] [ <pgetsock-sogt-err>
] [ <pgetsoc-no-soc-err> ] [ <pgetsoc-cp-err> ] [ <pgetsoc-pru-soc-err> ] [ <pgetsoc-cpout-err> ] [
<pgtprne-no-soc-err> ] [ <pgtprne-enot-err> ] [ <pgtprne-cp-err> ] [ <pgtprne-pru-pradd> ] [
<pgtprne-cpout-err> ] [ <pclose-no-soc-err> ] [ <pclose-socnull-err> ] [ <pclose-p-cls2-err> ] [
<pfcntl-no-soc-err> ] [ <pfcntl-soc-null> ] [ <pfcntl-enotsup> ] [ <pfcntl-einval-err> ] [ <pioctl-no-soc-err>
] [ <pioctl-enotsup> ] [ <pioctl-pru-cntl> ] [ <pfork-enomem-err> ] [ <pdup-no-soc-err> ] [ <pudp-soc-null-err>
] [ <ha-nomem-err> ] [ <ha-tlv-err> ] [ <ha-soc-arg-err> ] [ <ha-cli-tlv-err> ] [ <ha-pss-upd-err> ] [
<ha-no-soc-err> ] [ <ha-soc-tlv-err> ] [ <ha-soc-pss-upd> ] [ <ha-inpcb-tlv> ] [ <ha-inpcb-pssky> ] [
<ha-ip-mopt-tlv> ] [ <ha-ip-mopt-pss> ] [ <ha-ip6-mopt-tlv> ] [ <ha-ip6-mopt-pss> ] [ <ha-tcpb-tlv> ] [
<ha-tcpb-pss> ] [ <ft-tcp-wblock> ] [ <ft-send-p-sndmsg> ] [ <ft-ack-rcv-no-soc> ] [ <!xc-tgid-err> ] ] [
TABLE_sp_cl [ <can-requests> <can-unblocks> <can-misses> <sel-drops> <sel-wakes> ] ] ] ]

```

### Syntax Description

|            |  |
|------------|--|
| show       | Show running system information                        |
| sockets    | Display sockets status and configuration               |
| client     | Display sockets client information                     |
| pid        | (Optional) Display specific client process information |
| <i>pid</i> | (Optional) Display client process <pid>                |

|                     |   |
|---------------------|---|
| tcp                 | (Optional) Display TCP clients                    |
| udp                 | (Optional) Display UDP clients                    |
| raw                 | (Optional) Display RAW clients                    |
| detail              | (Optional) Display socket details                 |
| kstack-ns-all       | (Optional) Show kernel clients for all namespaces |
| __readonly__        | (Optional)  |
| TABLE_total_clients | (Optional) Total no of client sockets             |
| socket-type         | (Optional) Sockets type                           |
| total-clients       | (Optional) total clients                          |
| no-total-clients    | (Optional) number of total clients                |
| TABLE_cl_sk         | (Optional) Display Client sockets                 |
| prefix              | (Optional) Prefix to the sockets                  |
| client-name         | (Optional) Display socket client info             |
| pid                 | (Optional) Display client process <pid>           |
| No-of-clients       | (Optional) Number of socket clients               |
| fast-tcp-mts-ctrl-q | (Optional) Fast tcp mts control queue             |
| cancel-requests     | (Optional) cancel requests                        |
| cancel-unblocks     | (Optional) cancel unblocks                        |
| cancel-misses       | (Optional) cancel misses                          |
| select-drops        | (Optional) select drops                           |
| select-wakes        | (Optional) select wakes                           |
| TABLE_det           | (Optional) Display Socket client Details          |
| fd                  | (Optional) Client socket fd                       |
| client-id           | (Optional) Client socket id                       |
| mts-sap             | (Optional) socket mts addr sap                    |
| TABLE_st            | (Optional) Sock detail Ctrl statistics            |
| soc-calls           | (Optional) sockets calls                          |
| bind-calls          | (Optional) socket bind calls                      |
| listen-calls        | (Optional) socket listen calls                    |



|                          |  |
|--------------------------|--|
| <i>accept-calls</i>      | (Optional) socket accept calls           |
| <i>acc-dispat-err</i>    | (Optional) socket accept dispatch error  |
| <i>connect-calls</i>     | (Optional) socket connect calls          |
| <i>connec-dispatch</i>   | (Optional) socket dispatch calls         |
| <i>recvmsg-dispatch</i>  | (Optional) receive msg dispatch          |
| <i>recv-dis-nblock</i>   | (Optional) receive dispatch nonblock     |
| <i>recvmsg-call</i>      | (Optional) receive message call          |
| <i>brecv-dispatch</i>    | (Optional) broadcast receive dispatch    |
| <i>fsendmsg-calls</i>    | (Optional) forward send message dispatch |
| <i>sendmsg-dispatch</i>  | (Optional) send message dispatch         |
| <i>sendmsg-calls</i>     | (Optional) send message calls            |
| <i>msendmsg-calls</i>    | (Optional) multicast send message calls  |
| <i>select-calls</i>      | (Optional) select calls                  |
| <i>select-dispatch</i>   | (Optional) select dispatch               |
| <i>select-need-work</i>  | (Optional) select need work              |
| <i>sh-calls</i>          | (Optional) show calls                    |
| <i>close-calls</i>       | (Optional) close calls                   |
| <i>fctl-calls</i>        | (Optional) fcntl calls                   |
| <i>ioctl-calls</i>       | (Optional) ioctl calls                   |
| <i>setsock-calls</i>     | (Optional) setsock calls                 |
| <i>getsock-calls</i>     | (Optional) getsock calls                 |
| <i>getsockname-calls</i> | (Optional) get socket name calls         |
| <i>getpeer-calls</i>     | (Optional) get peer calls                |
| <i>fork-calls</i>        | (Optional) fork calls                    |
| <i>execve-calls</i>      | (Optional) execve calls                  |
| <i>dup-calls</i>         | (Optional) duplicate calls               |
| <i>can-calls</i>         | (Optional) cancel calls                  |
| <i>can-miss</i>          | (Optional) cancel miss                   |
| <i>can-unblk-sele</i>    | (Optional) cancel unblock select         |

|                          |   |
|--------------------------|---|
| <i>soc-ha-calls</i>      | (Optional) socket ha calls                        |
| <i>pfork-client</i>      | (Optional) pfork client                           |
| <i>read-fd</i>           | (Optional) socket read fd                         |
| <i>write-fd</i>          | (Optional) socket write fd                        |
| <i>read-fd-set</i>       | (Optional) socket read fd set                     |
| <i>write-fd-set</i>      | (Optional) socket write fd set                    |
| <i>fast-tcp-send-req</i> | (Optional) socket fast tcp send request           |
| <i>fast-tcp-send-suc</i> | (Optional) socket fast tcp send success           |
| <i>fast-tcp-ack</i>      | (Optional) socket fast tcp ack                    |
| TABLE_sterr              | (Optional) Client Socket Error Statistics         |
| <i>sock-err</i>          | (Optional) socket error                           |
| <i>sock-nodev-err</i>    | (Optional) socket nodev error                     |
| <i>bind-err</i>          | (Optional) socket bind error                      |
| <i>lis-err</i>           | (Optional) socket listen error                    |
| <i>accept-err</i>        | (Optional) socket accept error                    |
| <i>connect-err</i>       | (Optional) socket connect error                   |
| <i>recvmsg-err</i>       | (Optional) socket receive message error           |
| <i>brcvmsg-err</i>       | (Optional) socket broadcast receive message error |
| <i>fsendmsg-err</i>      | (Optional) socket forward send message error      |
| <i>sendmsg-err</i>       | (Optional) socket send message error              |
| <i>msndmsg-err</i>       | (Optional) socket multicast send message error    |
| <i>select-err</i>        | (Optional) socket select error                    |
| <i>sel-nomem-err</i>     | (Optional) socket select no member error          |
| <i>shut-err</i>          | (Optional) socket shutdown error                  |
| <i>close-err</i>         | (Optional) socket close error                     |
| <i>fcntl-err</i>         | (Optional) socket fcntl error                     |
| <i>ioctl-err</i>         | (Optional) socket ioctl error                     |
| <i>setsoc-err</i>        | (Optional) set socket error                       |
| <i>getsoc-err</i>        | (Optional) get socket error                       |

|                           |   |
|---------------------------|---|
| <i>getsocname-err</i>     | (Optional) get socket name error        |
| <i>getpeername-err</i>    | (Optional) get peer name error          |
| <i>fork-err</i>           | (Optional) socket fork error            |
| <i>execve-err</i>         | (Optional) socket execve error          |
| <i>dup-err</i>            | (Optional) socket duplicate error       |
| <i>psoc-vrf-err</i>       | (Optional) psocket vrf error            |
| <i>psoc-nosoc-err</i>     | (Optional) psocket nosoc error          |
| <i>psoc-sock-null-err</i> | (Optional) psocket socket null error    |
| <i>psoc-socre-err</i>     | (Optional) psocket socre error          |
| <i>pbind-nsock-err</i>    | (Optional) pbind nsock error            |
| <i>pbd-getsocaddr</i>     | (Optional) pbd getsocaddr               |
| <i>pbind-sobind-err</i>   | (Optional) pbind sobind error           |
| <i>plisten-nsoc-err</i>   | (Optional) plisten nsoc error           |
| <i>plis-solis-err</i>     | (Optional) plisten socket listen error  |
| <i>pacc-nsoc-err</i>      | (Optional) paccept new socket error     |
| <i>pacc-no-nsoc-err</i>   | (Optional) paccept no new socket error  |
| <i>pacc-sock-null-err</i> | (Optional) paccept socket null error    |
| <i>pacc-copy-err</i>      | (Optional) paccept copy error           |
| <i>pacc-no-acc-err</i>    | (Optional) paccept no accept error      |
| <i>pacc-woublo-err</i>    | (Optional) paccept would block error    |
| <i>pacc-connabo-err</i>   | (Optional) paccept connect abort error  |
| <i>pacc-cond-wait-err</i> | (Optional) paccept condition wait error |
| <i>pacc-so-err-err</i>    | (Optional) paccept socket error         |
| <i>pacc-err-err</i>       | (Optional) paccept error                |
| <i>pcon-no-soc-err</i>    | (Optional) pconnect no socket error     |
| <i>pcon-ealready-err</i>  | (Optional) pconnect ready error         |
| <i>pconn-getsock</i>      | (Optional) pconnect get socket          |
| <i>pconn-socon-err</i>    | (Optional) pconnect socket on error     |
| <i>pconn-einpro-err</i>   | (Optional) pconnect einprogress error   |

|                            |  |
|----------------------------|--|
| <i>pconn-con-wait-err</i>  | (Optional) pconnect condition wait error     |
| <i>psend-no-soc-err</i>    | (Optional) psend no socket error             |
| <i>psend-inval-iov</i>     | (Optional) psend invalidate iov              |
| <i>psend-getsoc-err</i>    | (Optional) psend getsocket error             |
| <i>psend-msg-ctrl-err</i>  | (Optional) psend message control error       |
| <i>psend-sockarg-err</i>   | (Optional) psend socket argument error       |
| <i>psend-pru-sosend</i>    | (Optional) psend pru socket send             |
| <i>precv-nosock-err</i>    | (Optional) preceive no socket error          |
| <i>precv-inval-iovlen</i>  | (Optional) preceive invalidate iovlen        |
| <i>precv-pru-sorecv</i>    | (Optional) preceive pru so receive           |
| <i>precv-cp-msg-err</i>    | (Optional) preceive copy message error       |
| <i>precv-cp-msg-nlen</i>   | (Optional) preceive copy message new length  |
| <i>precv-cp-data-err</i>   | (Optional) preceive copy data error          |
| <i>pbrecv-rcvmsg-err</i>   | (Optional) preceive receive message error    |
| <i>pshut-no-soc-err</i>    | (Optional) pshutdown no socket error         |
| <i>psetsoc-val-err</i>     | (Optional) pset socket value error           |
| <i>psetsoc-inv-val</i>     | (Optional) pset socket invalidate error      |
| <i>psetsoc-no-soc-err</i>  | (Optional) pset socket no socket error       |
| <i>psetsoc-sosetopt</i>    | (Optional) pset socket set opt               |
| <i>pgetsoc-no-socerr</i>   | (Optional) pget socket no socket error       |
| <i>pgetsoc-cp-err</i>      | (Optional) pget socket copy error            |
| <i>pgetsoc-val-err</i>     | (Optional) pget socket validate error        |
| <i>pgetsoc-sogt-err</i>    | (Optional) pget socket sogt error            |
| <i>pgetsoc-no-soc-err</i>  | (Optional) pget socket no socket error       |
| <i>pgetsoc-cp-err</i>      | (Optional) pget socket copy error            |
| <i>pgetsoc-pru-soc-err</i> | (Optional) pget socket pru socket error      |
| <i>pgetsoc-cpout-err</i>   | (Optional) pget socket copy out error        |
| <i>pgtprne-no-soc-err</i>  | (Optional) pget peer name no socket error    |
| <i>pgtprne-enot-err</i>    | (Optional) pget peer name enot connect error |

|                           |  |
|---------------------------|--|
| <i>pgtprne-cp-err</i>     | (Optional) pget peer name copy error       |
| <i>pgtprne-pru-pradd</i>  | (Optional) pget peer name pru peer address |
| <i>pgtprne-cpout-err</i>  | (Optional) pget peer name copy out error   |
| <i>pclose-no-soc-err</i>  | (Optional) pclose no socket error          |
| <i>pclose-socnull-err</i> | (Optional) pclose socket null error        |
| <i>pclose-p-cls2-err</i>  | (Optional) pclose p close2 error           |
| <i>pfcntl-no-soc-err</i>  | (Optional) pfcntl no socket error          |
| <i>pfcntl-soc-null</i>    | (Optional) pfcntl socket null              |
| <i>pfcntl-enotsup</i>     | (Optional) pfcntl enotsupport errors       |
| <i>pfcntl-einval-err</i>  | (Optional) pfcntl invalidate error         |
| <i>pioctl-no-soc-err</i>  | (Optional) pioctl no socket error          |
| <i>pioctl-enotsup</i>     | (Optional) pioctl enotsup                  |
| <i>pioctl-pru-cntl</i>    | (Optional) pioctl pru cntl                 |
| <i>pfork-enomem-err</i>   | (Optional) pfork eno-memory error          |
| <i>pdup-no-soc-err</i>    | (Optional) pudp no socket error            |
| <i>pdup-soc-null-err</i>  | (Optional) pudp socket null error          |
| <i>ha-nomem-err</i>       | (Optional) ha no memory error              |
| <i>ha-tlv-err</i>         | (Optional) ha tlv error                    |
| <i>ha-soc-arg-err</i>     | (Optional) ha socket argument error        |
| <i>ha-cli-tlv-err</i>     | (Optional) ha cli tlv error                |
| <i>ha-pss-upd-err</i>     | (Optional) ha pss udp error                |
| <i>ha-no-soc-err</i>      | (Optional) ha no socket error              |
| <i>ha-soc-tlv-err</i>     | (Optional) ha socket tlv error             |
| <i>ha-soc-pss-upd</i>     | (Optional) ha socket pss udp               |
| <i>ha-inpcb-tlv</i>       | (Optional) ha inpcb tlv value              |
| <i>ha-inpcb-pssky</i>     | (Optional) ha inpcb pssky value            |
| <i>ha-ip-mopt-tlv</i>     | (Optional) ha ip mopt tlv value            |
| <i>ha-ip-mopt-pss</i>     | (Optional) ha ip mopt pss value            |
| <i>ha-ip6-mopt-tlv</i>    | (Optional) ha ip6 mopt tlv value           |

|                          |  |
|--------------------------|--|
| <i>ha-ip6-mopt-pss</i>   | (Optional) ha ip6 mopt pss value                     |
| <i>ha-tcpb-tlv</i>       | (Optional) ha socket update tcpb to tlv error        |
| <i>ha-tcpb-pss</i>       | (Optional) ha socket update tcpb psskey update error |
| <i>ft-tcp-wblock</i>     | (Optional) fast tcp send would block error           |
| <i>ft-send-p-sndmsg</i>  | (Optional) fast tcp send p_sendmsg errors            |
| <i>ft-ack-rcv-no-soc</i> | (Optional) fast ack receive no socket                |
| <i>lxc-tgid-err</i>      | (Optional) Containers tgid err                       |
| TABLE_sp_cl              | (Optional) Sock specific Ctrl statistics             |
| <i>can-requests</i>      | (Optional) socket control cancel request             |
| <i>can-unblocks</i>      | (Optional) socket cancel unblocks                    |
| <i>can-misses</i>        | (Optional) socket cancel misses                      |
| <i>sel-drops</i>         | (Optional) select drops                              |
| <i>sel-wakes</i>         | (Optional) select wakes                              |

**Command Mode**

- /exec

## show sockets connection

```
show sockets connection [ pid <pid> | tcp | udp | raw ] [ local { <srcIP> | <srcIP6> } ] [ foreign { <dstIP> | <dstIP6> } ] [ detail ] [ keydetails ] [ __readonly__ ] [ { TABLE_sockets <protocol> [ <total-conn-count> ] [ { TABLE_conn <afi> [ <laddr> ] [ <lport> ] [ <faddr> ] [ <fport> ] [ <prot> ] [ <type> ] [ <ttl> ] [ <tos> ] [ <options> ] [ <state> ] [ <rcv-count> ] [ <rcv-hiwat> ] [ <rcv-lowat> ] [ <rcv-flags> ] [ <snd-count> ] [ <snd-hiwat> ] [ <snd-lowat> ] [ <snd-flags> ] [ <iss> ] [ <snd-una> ] [ <snd-nxt> ] [ <snd_wnd> ] [ <irs> ] [ <rcv-nxt> ] [ <rcv-wnd> ] [ <snd-cwnd> ] [ <ooo_pkt_rcv> ] [ <ooo_pkt_drpd> ] [ <ooo_pkt_rqc> ] [ <rtt> ] [ <rttvar> ] [ <krtd> ] [ <rttmin> ] [ <mss> ] [ <dur> ] [ <tcp-state> ] [ <flags> ] [ <md5-cnt> ] [ <md5-host> ] [ <md5-err> ] [ <tcp-count> ] [ <udp-count> ] [ <raw-count> ] [ <vrf-name> ] [ <intf> } ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information                                       |
| sockets                 | Display sockets status and configuration                              |
| connection              | Display connection information  |
| pid                     | (Optional) Display specific client process connection status          |
| <i>pid</i>              | (Optional) Display client process connection status <pid>             |
| tcp                     | (Optional) Display all TCP connections                                |
| udp                     | (Optional) Display all UDP connections                                |
| raw                     | (Optional) Display all raw connections                                |
| local                   | (Optional) Display all TCP connections with specified local address   |
| <i>srcIP</i>            | (Optional) Display all TCP connections with specified local address   |
| foreign                 | (Optional) Display all TCP connections with specified foreign address |
| <i>dstIP</i>            | (Optional) Display all TCP connections with specified foreign address |
| detail                  | (Optional) Display detailed connection information                    |
| keydetails              | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                             |
| __readonly__            | (Optional)  |
| TABLE_sockets           | (Optional) sockets table  |
| <i>protocol</i>         | (Optional) socket protocol  |
| <i>total-conn-count</i> | (Optional) socket connection table                                    |
| TABLE_conn              | (Optional)  |
| <i>afi</i>              | (Optional) socket family  |

|                    |  |
|--------------------|--|
| <i>prot</i>        | (Optional) socket protocol                                       |
| <i>tcp-state</i>   | (Optional) socket tcp state                                      |
| <i>rcv-count</i>   | (Optional) socket connection receive count                       |
| <i>laddr</i>       | (Optional) socket connection laddr                               |
| <i>lport</i>       | (Optional) socket connection lport                               |
| <i>faddr</i>       | (Optional) socket connection faddr                               |
| <i>fport</i>       | (Optional) socket connection fport                               |
| <i>intf</i>        | (Optional) socket connection interface                           |
| <i>vrf-name</i>    | (Optional) socket vrf name                                       |
| <i>snd-count</i>   | (Optional) socket connection send count                          |
| <i>type</i>        | (Optional) socket connection type                                |
| <i>ttl</i>         | (Optional) socket connection ttl                                 |
| <i>tos</i>         | (Optional) socket connection tos                                 |
| <i>options</i>     | (Optional) socket connection option                              |
| <i>state</i>       | (Optional) socket connection state                               |
| <i>iss</i>         | (Optional) socket connection iss                                 |
| <i>snd-una</i>     | (Optional) socket connection send unavailable                    |
| <i>snd-nxt</i>     | (Optional) socket connection send next                           |
| <i>snd_wnd</i>     | (Optional) socket connection send window                         |
| <i>irs</i>         | (Optional) socket connection irs                                 |
| <i>rcv-nxt</i>     | (Optional) socket connection receive next                        |
| <i>rcv-wnd</i>     | (Optional) socket connection receive window                      |
| <i>snd-cwnd</i>    | (Optional) socket connection close sent window                   |
| <i>ooo_pkt_rcv</i> | (Optional) socket connection out-of-order packet received        |
| <i>ooo_pkt_drp</i> | (Optional) socket connection out-of-order packet dropped         |
| <i>ooo_pkt_rqc</i> | (Optional) socket connection out-of-order reassembly queue count |
| <i>srtt</i>        | (Optional) socket connection srtt                                |
| <i>rtt</i>         | (Optional) socket connection rtt                                 |
| <i>rttvar</i>      | (Optional) socket connection rttvar                              |



|                  |  |
|------------------|--|
| <i>krtt</i>      | (Optional) socket connection krtt          |
| <i>rttmin</i>    | (Optional) socket connection rtt mintues   |
| <i>mss</i>       | (Optional) socket connection mss           |
| <i>dur</i>       | (Optional) socket connection duration      |
| <i>flags</i>     | (Optional) socket connection flags         |
| <i>md5-cnt</i>   | (Optional) socket connection md5 count     |
| <i>md5-host</i>  | (Optional) socket connection md5 host      |
| <i>md5-err</i>   | (Optional) socket connection md5 error     |
| <i>rcv-hiwat</i> | (Optional) socket connection receive hiwat |
| <i>rcv-lowat</i> | (Optional) socket connection receive lowat |
| <i>rcv-flags</i> | (Optional) socket connection receive flags |
| <i>snd-hiwat</i> | (Optional) socket connection send hiwat    |
| <i>snd-lowat</i> | (Optional) socket connection send lowat    |
| <i>snd-flags</i> | (Optional) socket connection send flags    |
| <i>tcp-count</i> | (Optional) socket connection tcp count     |
| <i>udp-count</i> | (Optional) socket connection udp count     |
| <i>raw-count</i> | (Optional) socket connection raw count     |

**Command Mode**

- /exec

## show sockets local-port-range

```
show sockets local-port-range [ __readonly__ <kstack_local_port_range_start> <kstack_local_port_range_end>
<netstack_local_port_range_start> <netstack_local_port_range_end> <nat_local_port_range_start>
<nat_local_port_range_end> ]
```

### Syntax Description

|  |  |
|--|--|
| show                                   | Show running system information            |
| sockets                                | Display sockets status and configuration   |
| local-port-range                       | Display local port range                   |
| <i>__readonly__</i>                    | (Optional)                                 |
| <i>kstack_local_port_range_start</i>   | (Optional) Kstack local port range start   |
| <i>kstack_local_port_range_end</i>     | (Optional) Kstack local port range end     |
| <i>netstack_local_port_range_start</i> | (Optional) Netstack local port range start |
| <i>netstack_local_port_range_end</i>   | (Optional) Netstack local port range end   |
| <i>nat_local_port_range_start</i>      | (Optional) Nat local port range start      |
| <i>nat_local_port_range_end</i>        | (Optional) Nat local port range end        |

### Command Mode

- /exec

## show sockets ns-port-kiosk

```
show sockets ns-port-kiosk [ __readonly__ [ TABLE_port_kiosk { <client-process-id> <client-name> } [
TABLE_port_state_pro_name { <entry-counter> [ <listening-port> ] [ <fwd-port> ] [ <tcp-state> ] [ <mts-sap>
] [ <protocol-name> } ] ] ] ]
```

### Syntax Description

|                                  |   |
|----------------------------------|---|
| show                             | Show running system information                       |
| sockets                          | Display sockets status and configuration              |
| ns-port-kiosk                    | Display port kiosk for netstack socket clients        |
| <i>__readonly__</i>              | (Optional)  |
| <i>TABLE_port_kiosk</i>          | (Optional) Sockets ns port kiosk information          |
| <i>client-process-id</i>         | (Optional) Client Process ID                          |
| <i>client-name</i>               | (Optional) Client Name                                |
| <i>TABLE_port_state_pro_name</i> | (Optional) Sockets ns port state protocol information |
| <i>entry-counter</i>             | (Optional) Table Entry Counter                        |
| <i>listening-port</i>            | (Optional) Listening Port                             |
| <i>fwd-port</i>                  | (Optional) FWD Port                                   |
| <i>tcp-state</i>                 | (Optional) TCP State                                  |
| <i>mts-sap</i>                   | (Optional) MTS SAP                                    |
| <i>protocol-name</i>             | (Optional) Protocol Name                              |

### Command Mode

- /exec

## show sockets statistics

```

show sockets statistics [ all | tcp | tcp6 | tcpsum | udp | udp6 | udpsum | raw | raw6 | rawsum ] [ __readonly__
[ { TABLE_stat [ <rx-total> ] [ <rx-bad-csum> ] [ <rx-bad-offset> ] [ <rx-too-short> ] [ <rx-bad-md5> ] [
<rx-inseq-pack> ] [ <rx-inseq-bytes> ] [ <rx-dup-pack> ] [ <rx-dup-bytes> ] [ <rx-partdup-pack> ] [
<rx-partdup-bytes> ] [ <rx-oo-pack> ] [ <rx-oo-bytes> ] [ <rx-oo-drop-cnt> ] [ <rx-afterwin-pack> ] [
<rx-afterwin-bytes> ] [ <rx-afterclose-pack> ] [ <rx-winprobe-pack> ] [ <rx-winupdate-pack> ] [
<rx-dupack-pack> ] [ <rx-dupack-unsent-pack> ] [ <rx-ack-pack> ] [ <rx-ack-bytes> ] [ <rx-rcv-memdrop>
] [ <rx-dig-mssing> ] [ <rx-dig-unexpected> ] [ <rx-dig-notused> ] [ <rx-dig-valid> ] [ <rx-dig-invalid> ] [
<rx-get-passwd-fail> ] [ <rx-md5-mbuf-exded> ] [ <rx-uspec-src-recv> ] [ <rx-pkt-too-short> ] [ <rx-sin-finest>
] [ <rx-black-hole-syn> ] [ <rx-black-hole> ] [ <rx-drop-no-inpcb> ] [ <rx-drop-notcpcb> ] [
<rx-drp-sock-closed> ] [ <rx-syn-with-rst> ] [ <rx-syn-drop> ] [ <rx-bandlim> ] [ <rx-forged-pkt> ] [
<rx-drp-mbcast> ] [ <rx-drp-syn-add> ] [ <rx-drp-syn-recvd> ] [ <rx-drp-cc-sent> ] [ <rx-drp-rst-ccsent> ] [
<rx-frecv-enqueue> ] [ <rx-frecv-enqueue-fail> ] [ <rx-ftcp-cant-rcv-more> ] [ <rx-ftcp-data-ack-toapp-fail>
] [ <rx-ftcp-data-ack-toapp> ] [ <tx-total> ] [ <tx-urg> ] [ <tx-ctrl> ] [ <tx-data-pack> ] [ <tx-data-bytes> ] [
<tx-reasm-pack> ] [ <tx-reasm-bytes> ] [ <tx-ackonly-pack> ] [ <tx-winprobe-pack> ] [ <tx-winupdate-bytes>
] [ <tx-encrypt> ] [ <tx-unencrypt> ] [ <tx-md5rst> ] [ <tx-conn-init> ] [ <tx-conn-accepted> ] [ <tx-conn-estd>
] [ <closed> ] [ <dropped> ] [ <emb-dropped> ] [ <tx-rxmt-timeout> ] [ <tx-rxmt-timeout-dropped> ] [
<tx-ka-timeout> ] [ <tx-ka-probe> ] [ <tx-ka-drop> ] [ <gen-seg-timed> ] [ <gen-rtt-updated> ] [ <gen-delack>
] [ <gen-persist-timeout> ] [ <gen-paws-drop> ] [ <gen-predack> ] [ <gen-preddat> ] [ <gen-pcb-cachemiss>
] [ <gen-cache-drtt> ] [ <gen-cache-drttvar> ] [ <gen-cached-ssthresh> ] [ <gen-usedrtt> ] [ <gen-usedrttvar>
] [ <gen-usedssthresh> ] [ <gen-persistdrop> ] [ <gen-badsyn> ] [ <gen-mturesent> ] [ <gen-list-endrop> ] [
<gen-rpm-bind-synsock> ] [ <gen-rpm-bindsynadd> ] [ <gen-rpm-bindlookup> ] [ <gen-rpm-bindsetsock>
] [ <gen-rpm-unbind-getpass> ] [ <gen-rpm-unbinduser1> ] [ <gen-rpm-unbinduser2> ] [
<gen-rpm-unbindrollover> ] [ <gen-rpm-unbind-synfree> ] [ <gen-rpm-unbind-tpfree> ] [ <syn-sc-added> ]
[ <syn-retransmitted> ] [ <syn-dupsyn> ] [ <syn-dropped> ] [ <syn-completed> ] [ <syn-bucket-overflow> ]
[ <syn-cache-overflow> ] [ <syn-sc-reset> ] [ <syn-sc-stale> ] [ <syn-sc-aborted> ] [ <syn-sc-badack> ] [
<syn-sc-unreach> ] [ <syn-sc-zonefail> ] [ <syn-sc-sendcookie> ] [ <syn-sc-recvcookie> ] [ <syn-sc-crosshits>
] [ <syn-sc-supsyncrosshits> ] [ <syn-sc-removecrosshits> ] [ <udp-rx-version> ] [ <udp-rx-total> ] [
<udp-rx-bad-csum> ] [ <udp-rx-no-csum> ] [ <udp-rx-too-short> ] [ <udp-rx-bad-len> ] [ <udp-rx-no-port>
] [ <udp-rx-no-port-bcast> ] [ <udp-rx-no-port-mcast> ] [ <udp-rx-full-socket-drop> ] [ <udp-tx-total> ] [
<raw-rx-version> ] [ <raw-rx-rcvd> ] [ <raw-rx-no-port> ] [ <raw-rx-full-socket-drop> ] [ <raw-tx-sent> ] [
<inpcb-tot-alloc> ] [ <inpcb-tot-bind> ] [ <inpcb-tot-laddr> ] [ <inpcb-tot-connect> ] [ <inpcb-tot-disconnect>
] [ <inpcb-tot-detach> ] [ <inpcb-tot-detach-noinc> ] [ <inpcb-tot-detach-rort> ] [ <inpcb-tot-rtfree> ] [
<inpcb-tot-setsock-addr> ] [ <inpcb-tot-setpeeraddr> ] [ <inpcb-tot-notify> ] [ <inpcb-tot-lookup-npacl-deny>
] [ <inpcb-tot-lookup-npacl-allow> ] [ <inpcb-tot-inshash-ipv4> ] [ <inpcb-tot-inshash-ipv6> ] [
<inpcb-tot-brehash-ipv4> ] [ <inpcb-tot-brehash-ipv6> ] [ <inpcb-tot-bremhash> ] [ <inpcb-err-allocnomem>
] [ <inpcb-err-bindeinavl> ] [ <inpcb-err-eaddrinuse> ] [ <inpcb-err-eagain> ] [ <inpcb-err-eagain2> ] [
<inpcb-err-eaddrnotavail> ] [ <inpcb-err-eafnosupport> ] [ <inpcb-err-enomem> ] [ <inpcb-err-ehostunreach>
] [ <inpcb-err-laddr-enoent> ] [ <inpcb-err-laddr-ehostunreach2> ] [ <inpcb-err-connectladdr> ] [
<inpcb-err-connect-eaddrinuse> ] [ <inpcb-err-connbind> ] [ <inpcb-err-sockaddressnomem> ] [
<inpcb-err-sockaddressreconnreset> ] [ <inpcb-err-peeraddr-enomem> ] [ <inpcb-err-econnrest> ] [
<inpcb-err-respond-enobufs> ] [ <inpcb-err-binshash-enobufs> ] [ <in6pcb-tot-setport> ] [ <in6pcb-tot-bind>
] [ <in6pcb-tot-laddr> ] [ <in6pcb-tot-connect> ] [ <in6pcb-tot-disconnect> ] [ <in6pcb-tot-detach> ] [
<in6pcb-tot-sockaddr> ] [ <in6pcb-tot-peeraddr> ] [ <in6pcb-tot-notify> ] [ <in6pcb-tot-lookuplocal> ] [
<in6pcb-tot-hashnpacli-deny> ] [ <in6pcb-err-setportagain> ] [ <in6pcb-err-setportagain2> ] [
<in6pcb-err-seteagain3> ] [ <in6pcb-bind-eafnosupport> ] [ <in6pcb-err-bindeaddrinuse> ] [
<in6pcb-err-bindeaddrinuse2> ] [ <in6pcb-err-bindeaddrinuse3> ] [ <in6pcb-err-bindeaddrinuse4> ] [
<in6pcb-err-bindsetport> ] [ <in6pcb-err-bindeagain> ] [ <in6pcb-err-laddr-eafnosupport> ] [
<in6pcb-err-eaddrnotavail> ] [ <in6pcb-err-laddr-enomem> ] [ <in6pcb-err-laddr-ehostreach> ] [

```

```
<in6pcb-err-laddr-ehostunreach2> ] [ <in6pcb-err-laddr-ehostunreach3> ] [ <in6pcb-err-laddr-ehostunreach4>
] [ <in6pcb-err-laddr-enxio> ] [ <in6pcb-err-connladdr> ] [ <in6pcb-err-conneaddrinuse> ] [
<in6pcb-err-connbind> ] [ <in6pcb-err-sockaddr-enomem> ] [ <in6pcb-err-v4maps-enomem> ] [
<in6pcb-err-setsock-noinp> ] [ <in6pcb-err-setpeer-noinp> ] [ <in6pcb-err-sockaddr-noinp> ] [
<in6pcb-err-peeraddr-noinp> ] [ <in6pcb-err-notify-einavl> ] [ <in6pcb-err-ctloutput-nosoopt> ] } } ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                  |
| sockets                | Display sockets status and configuration                         |
| statistics             | Display sockets statistics                                       |
| all                    | (Optional) Display TCP/UDP/RAW v4/v6 protocols statistics        |
| tcp                    | (Optional) Display TCP v4 protocol statistics                    |
| tcp6                   | (Optional) Display TCP v6 protocol statistics                    |
| tcpsum                 | (Optional) Display sum of TCP v4 and TCP v6 protocols statistics |
| udp                    | (Optional) Display UDP v4 protocol statistics                    |
| udp6                   | (Optional) Display UDP v6 protocol statistics                    |
| udpsum                 | (Optional) Display sum of UDP v4 and UDP v6 protocols statistics |
| raw                    | (Optional) Display RAW v4 protocol statistics                    |
| raw6                   | (Optional) Display RAW v6 protocol statistics                    |
| rawsum                 | (Optional) Display sum of RAW v4 and RAW v6 protocols statistics |
| __readonly__           | (Optional)   |
| TABLE_stat             | (Optional) sockets statistics table                              |
| <i>rx-total</i>        | (Optional) total packets received                                |
| <i>rx-bad-csum</i>     | (Optional) packets received with ccksum errs                     |
| <i>rx-bad-offset</i>   | (Optional) packets received with bad offset                      |
| <i>rx-too-short</i>    | (Optional) packets received too short                            |
| <i>rx-bad-md5</i>      | (Optional) Recieved bad digest                                   |
| <i>rx-inseq-pack</i>   | (Optional) packets received in sequence                          |
| <i>rx-inseq-bytes</i>  | (Optional) bytes received in sequence                            |
| <i>rx-dup-pack</i>     | (Optional) duplicate-only packets received                       |
| <i>rx-dup-bytes</i>    | (Optional) duplicate-only bytes received                         |
| <i>rx-partdup-pack</i> | (Optional) packets with some duplicate data                      |

|                              |   |
|------------------------------|---|
| <i>rx-partdup-bytes</i>      | (Optional) dup. bytes in part-dup. packets      |
| <i>rx-oo-pack</i>            | (Optional) out-of-order packets received        |
| <i>rx-oo-bytes</i>           | (Optional) out-of-order bytes received          |
| <i>rx-oo-drop-cnt</i>        | (Optional) out-of-order drop count              |
| <i>rx-afterwin-pack</i>      | (Optional) packets with data after window       |
| <i>rx-afterwin-bytes</i>     | (Optional) bytes rcvd after window              |
| <i>rx-afterclose-pack</i>    | (Optional) packets rcvd after close             |
| <i>rx-winprobe-pack</i>      | (Optional) rcvd window probe packets            |
| <i>rx-winupdate-pack</i>     | (Optional) rcvd window update packets           |
| <i>rx-dupack-pack</i>        | (Optional) rcvd duplicate acks                  |
| <i>rx-dupack-unsent-pack</i> | (Optional) rcvd acks for unsent data            |
| <i>rx-ack-pack</i>           | (Optional) rcvd ack packets                     |
| <i>rx-ack-bytes</i>          | (Optional) bytes acked by rcvd acks             |
| <i>rx-rcv-memdrop</i>        | (Optional) packets dropped for lack of memory   |
| <i>rx-dig-mssing</i>         | (Optional) digest missing                       |
| <i>rx-dig-unexpected</i>     | (Optional) digest unexpected                    |
| <i>rx-dig-notused</i>        | (Optional) digest not used                      |
| <i>rx-dig-valid</i>          | (Optional) digest valid                         |
| <i>rx-dig-invalid</i>        | (Optional) digest invalid                       |
| <i>rx-get-passwd-fail</i>    | (Optional) get pass failed for RST              |
| <i>rx-md5-mbuf-exded</i>     | (Optional) md5 passwd exceeds mbuf              |
| <i>rx-uspec-src-recv</i>     | (Optional) Dropped Unspecified src pkt recieved |
| <i>rx-pkt-too-short</i>      | (Optional) Dropped Packet too short             |
| <i>rx-sin-finest</i>         | (Optional) Dropped packet set with SYN/FIN      |
| <i>rx-black-hole-syn</i>     | (Optional) Dropped black hole SYN               |
| <i>rx-black-hole</i>         | (Optional) Dropped black hole                   |
| <i>rx-drop-no-inpcb</i>      | (Optional) Dropped no inpcb                     |
| <i>rx-drop-notpcb</i>        | (Optional) Dropped no tcpcb                     |
| <i>rx-drp-sock-closed</i>    | (Optional) Dropped socket closed                |

|                                    |   |
|------------------------------------|---|
| <i>rx-syn-with-rst</i>             | (Optional) Dropped SYN with reset             |
| <i>rx-syn-drop</i>                 | (Optional) Dropped SYN                        |
| <i>rx-bandlim</i>                  | (Optional) Dropped Bandlim rst open port      |
| <i>rx-forged-pkt</i>               | (Optional) Dropped Same src/dst               |
| <i>rx-drp-mbcast</i>               | (Optional) Dropped Broadcast/Multicast        |
| <i>rx-drp-syn-add</i>              | (Optional) Dropped Adding SYN failed          |
| <i>rx-drp-syn-recvd</i>            | (Optional) ACK recvd not for our SYN          |
| <i>rx-drp-cc-sent</i>              | (Optional) Dropped cc sent                    |
| <i>rx-drp-rst-ccsent</i>           | (Optional) Dropped cc sent with reset         |
| <i>rx-frecv-enqueue</i>            | (Optional) Fast recv packets enqueued         |
| <i>rx-frecv-enqueue-fail</i>       | (Optional) Fast recv enqueue failed           |
| <i>rx-ftcp-cant-rcv-more</i>       | (Optional) Fast TCP can not recv more         |
| <i>rx-ftcp-data-ack-toapp-fail</i> | (Optional) Fast TCP data ACK to app failed    |
| <i>rx-ftcp-data-ack-toapp</i>      | (Optional) Fast TCP data ACK to app           |
| <i>tx-total</i>                    | (Optional) total packets sent                 |
| <i>tx-urg</i>                      | (Optional) packets sent with URG only         |
| <i>tx-ctrl</i>                     | (Optional) control (SYN FIN RST) packets sent |
| <i>tx-data-pack</i>                | (Optional) data packets sent                  |
| <i>tx-data-bytes</i>               | (Optional) data bytes sent                    |
| <i>tx-reasm-pack</i>               | (Optional) data packets retransmitted         |
| <i>tx-reasm-bytes</i>              | (Optional) data bytes retransmitted           |
| <i>tx-ackonly-pack</i>             | (Optional) ack-only packets sent              |
| <i>tx-winprobe-pack</i>            | (Optional) window probes sent                 |
| <i>tx-winupdate-bytes</i>          | (Optional) window update-only packets sent    |
| <i>tx-encrypt</i>                  | (Optional) Encrypted packets sent             |
| <i>tx-unencrypt</i>                | (Optional) Unencrypted packets sent           |
| <i>tx-md5rst</i>                   | (Optional) No of encrypted RST packets        |
| <i>tx-conn-init</i>                | (Optional) connections initiated              |
| <i>tx-conn-accepted</i>            | (Optional) connections accepted               |

|                                |  |
|--------------------------------|--|
| <i>tx-conn-estd</i>            | (Optional) connections established             |
| <i>closed</i>                  | (Optional) conn. closed (includes drops)       |
| <i>dropped</i>                 | (Optional) connections dropped                 |
| <i>emb-dropped</i>             | (Optional) embryonic connections dropped       |
| <i>tx-rxmt-timeout</i>         | (Optional) total rxmt timeout                  |
| <i>tx-rxmt-timeout-dropped</i> | (Optional) connections dropped in rxmt timeout |
| <i>tx-ka-timeout</i>           | (Optional) keepalive timeouts                  |
| <i>tx-ka-probe</i>             | (Optional) keepalive probes sent               |
| <i>tx-ka-drop</i>              | (Optional) connections dropped in keepalive    |
| <i>gen-seg-timed</i>           | (Optional) segs where we tried to get rtt      |
| <i>gen-rtt-updated</i>         | (Optional) times we succeeded to get rtt       |
| <i>gen-delack</i>              | (Optional) delayed acks sent                   |
| <i>gen-persist-timeout</i>     | (Optional) persist timeouts                    |
| <i>gen-paws-drop</i>           | (Optional) segments dropped due to PAWS        |
| <i>gen-predack</i>             | (Optional) hdr predict ok for acks             |
| <i>gen-preddat</i>             | (Optional) hdr predict ok for data pkts        |
| <i>gen-pcb-cachemiss</i>       | (Optional) PCB cache miss                      |
| <i>gen-cache-drtt</i>          | (Optional) times cached RTT in route updated   |
| <i>gen-cache-drttvar</i>       | (Optional) times cached rttvar updated         |
| <i>gen-cached-ssthresh</i>     | (Optional) times cached ssthresh updated       |
| <i>gen-usedrtt</i>             | (Optional) times RTT initialized from route    |
| <i>gen-usedrttvar</i>          | (Optional) times RTTVAR initialized from rt    |
| <i>gen-usedssthresh</i>        | (Optional) times ssthresh initialized from rt  |
| <i>gen-persistdrop</i>         | (Optional) timeout in persist state            |
| <i>gen-badsyn</i>              | (Optional) bogus SYN, e.g. premature ACK       |
| <i>gen-mturesent</i>           | (Optional) resends due to MTU discovery        |
| <i>gen-list-endrop</i>         | (Optional) listen queue overflows              |
| <i>gen-rpm-bind-synsock</i>    | (Optional) rpm bind in synsock                 |
| <i>gen-rpm-bindsynadd</i>      | (Optional) rpm bind in synadd                  |



|                               |   |
|-------------------------------|---|
| <i>gen-rpm-bindlookup</i>     | (Optional) rpm bind in lookup               |
| <i>gen-rpm-bindsetsock</i>    | (Optional) rpm bind in setsock              |
| <i>gen-rpm-unbind-getpass</i> | (Optional) rpm unbind get pass              |
| <i>gen-rpm-unbinduser1</i>    | (Optional) rpm unbind by user               |
| <i>gen-rpm-unbinduser2</i>    | (Optional) rpm unbind by user1              |
| <i>gen-rpm-unbindrollover</i> | (Optional) rpm unbind during rollover       |
| <i>gen-rpm-unbind-synfree</i> | (Optional) rpm unbind in syn free           |
| <i>gen-rpm-unbind-tpfree</i>  | (Optional) rpm unbind in tp free            |
| <i>syn-sc-added</i>           | (Optional) entry added to syncache          |
| <i>syn-retransmitted</i>      | (Optional) syncache entry was retransmitted |
| <i>syn-dupsyn</i>             | (Optional) duplicate SYN packet             |
| <i>syn-dropped</i>            | (Optional) could not reply to packet        |
| <i>syn-completed</i>          | (Optional) successful extraction of entry   |
| <i>syn-bucket-overflow</i>    | (Optional) syncache per-bucket limit hit    |
| <i>syn-cache-overflow</i>     | (Optional) syncache cache limit hit         |
| <i>syn-sc-reset</i>           | (Optional) RST removed entry from syncache  |
| <i>syn-sc-stale</i>           | (Optional) timed out or listen socket gone  |
| <i>syn-sc-aborted</i>         | (Optional) syncache entry aborted           |
| <i>syn-sc-badack</i>          | (Optional) removed due to bad ACK           |
| <i>syn-sc-unreach</i>         | (Optional) ICMP unreachable received        |
| <i>syn-sc-zonefail</i>        | (Optional) zalloc() failed                  |
| <i>syn-sc-sendcookie</i>      | (Optional) SYN cookie sent                  |
| <i>syn-sc-recvcookie</i>      | (Optional) SYN cookie received              |
| <i>syn-sc-crosshits</i>       | (Optional) crosshits on the SC blocks       |
| <i>syn-sc-supsyncrosshits</i> | (Optional) crosshits dup SYN on SC block    |
| <i>syn-sc-removecrosshits</i> | (Optional) crosshits on SC blocks to remove |
| <i>udp-rx-version</i>         | (Optional) udp sockets version              |
| <i>udp-rx-total</i>           | (Optional) total udp packets                |
| <i>udp-rx-bad-csum</i>        | (Optional) udp checksum error               |

|                                     |  |
|-------------------------------------|--|
| <i>udp-rx-no-csum</i>               | (Optional) udp no checksum                 |
| <i>udp-rx-too-short</i>             | (Optional) udp packets drops               |
| <i>udp-rx-bad-len</i>               | (Optional) udp bad length                  |
| <i>udp-rx-no-port</i>               | (Optional) udp no port                     |
| <i>udp-rx-no-port-bcast</i>         | (Optional) udp no port broadcast           |
| <i>udp-rx-no-port-mcast</i>         | (Optional) udp no port multicast           |
| <i>udp-rx-full-socket-drop</i>      | (Optional) udp dropped full socket         |
| <i>udp-tx-total</i>                 | (Optional) udp total packets               |
| <i>raw-rx-version</i>               | (Optional) raw sockets version             |
| <i>raw-rx-rcvd</i>                  | (Optional) raw sockets connection received |
| <i>raw-rx-no-port</i>               | (Optional) raw socket no port              |
| <i>raw-rx-full-socket-drop</i>      | (Optional) raw socket full sockets drop    |
| <i>raw-tx-sent</i>                  | (Optional) raw socket connection sent      |
| <i>inpcb-tot-alloc</i>              | (Optional) inpcb allocation                |
| <i>inpcb-tot-bind</i>               | (Optional) inpcb bind                      |
| <i>inpcb-tot-laddr</i>              | (Optional) inpcb laddr                     |
| <i>inpcb-tot-connect</i>            | (Optional) inpcb connect                   |
| <i>inpcb-tot-disconnect</i>         | (Optional) inpcb disconnect                |
| <i>inpcb-tot-detach</i>             | (Optional) inpcb detach                    |
| <i>inpcb-tot-detach-noinc</i>       | (Optional) inpcb detaach no increment      |
| <i>inpcb-tot-detach-rort</i>        | (Optional) inpcb detach no return          |
| <i>inpcb-tot-rtfree</i>             | (Optional) inpcb rt free                   |
| <i>inpcb-tot-setsock-addr</i>       | (Optional) inpcb set socket address        |
| <i>inpcb-tot-setpeeraddr</i>        | (Optional) inpcb set peer address          |
| <i>inpcb-tot-notify</i>             | (Optional) inpcb notify                    |
| <i>inpcb-tot-lookup-npacl-deny</i>  | (Optional) inpcb lookup hash npacl deny    |
| <i>inpcb-tot-lookup-npacl-allow</i> | (Optional) inpcb lookup npacl allow        |
| <i>inpcb-tot-inshash-ipv4</i>       | (Optional) inpcb inshash ipv4              |
| <i>inpcb-tot-inshash-ipv6</i>       | (Optional) inpcb inshash ipv6              |

|                                      |  |
|--------------------------------------|--|
| <i>inpcb-tot-brehash-ipv4</i>        | (Optional) inpcb brehash ipv4                        |
| <i>inpcb-tot-brehash-ipv6</i>        | (Optional) inpcb brehash ipv6                        |
| <i>inpcb-tot-bremhash</i>            | (Optional) inpcb brehash                             |
| <i>inpcb-err-allocnomem</i>          | (Optional) inpcb allocation no memory error          |
| <i>inpcb-err-bindeinavl</i>          | (Optional) inpcb bind inval error                    |
| <i>inpcb-err-eaddrinuse</i>          | (Optional) inpcb eaddr in use error                  |
| <i>inpcb-err-eagain</i>              | (Optional) inpcb eagain error                        |
| <i>inpcb-err-eagain2</i>             | (Optional) inpcb eagain2 error                       |
| <i>inpcb-err-eaddrnotavail</i>       | (Optional) inpcb eaddr not availableerror            |
| <i>inpcb-err-eafnosupport</i>        | (Optional) inpcb eaf no support error                |
| <i>inpcb-err-enomem</i>              | (Optional) inpcb no-memory error                     |
| <i>inpcb-err-ehostunreach</i>        | (Optional) inpcb ehost unreachable error             |
| <i>inpcb-err-laddr-enixio</i>        | (Optional) inpcb laddr enxio error                   |
| <i>inpcb-err-laddr-ehostunreach2</i> | (Optional) inpcb laddr ehost unreachable2 error      |
| <i>inpcb-err-connectladdr</i>        | (Optional) inpcb connect laddr error                 |
| <i>inpcb-err-connect-eaddrinuse</i>  | (Optional) inpcb connect eaddress in use error       |
| <i>inpcb-err-connbind</i>            | (Optional) inpcb connect bind error                  |
| <i>inpcb-err-sockaddrenomem</i>      | (Optional) inpcb socket address no memory error      |
| <i>inpcb-err-sockadreconnreset</i>   | (Optional) inpcb socket address econnect reset error |
| <i>inpcb-err-peeraddr-enomem</i>     | (Optional) inpcb peer address no memory error        |
| <i>inpcb-err-econnrest</i>           | (Optional) inpcb connection rest error               |
| <i>inpcb-err-respond-enobufs</i>     | (Optional) inpcb respond no buffer error             |
| <i>inpcb-err-binshash-enobufs</i>    | (Optional) inpcb binshash no buffer error            |
| <i>in6pcb-tot-setport</i>            | (Optional) in6pcb set port error                     |
| <i>in6pcb-tot-bind</i>               | (Optional) in6pcb bind                               |
| <i>in6pcb-tot-laddr</i>              | (Optional) in6pcb laddr                              |
| <i>in6pcb-tot-connect</i>            | (Optional) in6pcb connect                            |
| <i>in6pcb-tot-disconnect</i>         | (Optional) in6pcb disconnect                         |
| <i>in6pcb-tot-detach</i>             | (Optional) in6pcb detach                             |

|                                       |  |
|---------------------------------------|--|
| <i>in6pcb-tot-sockaddr</i>            | (Optional) in6pcb socket address                 |
| <i>in6pcb-tot-peeraddr</i>            | (Optional) in6pcb peer address                   |
| <i>in6pcb-tot-notify</i>              | (Optional) in6pcb notify                         |
| <i>in6pcb-tot-lookuplocal</i>         | (Optional) in6pcb lookup local                   |
| <i>in6pcb-tot-hashnpacl-deny</i>      | (Optional) in6pcb hash npacl deny                |
| <i>in6pcb-err-setporteagain</i>       | (Optional) in6pcb set port again error           |
| <i>in6pcb-err-setporteagain2</i>      | (Optional) in6pcb set port again2 error          |
| <i>in6pcb-err-seteagain3</i>          | (Optional) in6pcb set port again3 error          |
| <i>in6pcb-bind-eafnosupport</i>       | (Optional) in6pcb bind eaf no support error      |
| <i>in6pcb-err-bindeaddrinuse</i>      | (Optional) in6pcb bind address in use error      |
| <i>in6pcb-err-bindeaddrinuse2</i>     | (Optional) in6pcb bind address in use2 error     |
| <i>in6pcb-err-bindeaddrinuse3</i>     | (Optional) in6pcb bind address in use3 error     |
| <i>in6pcb-err-bindeaddrinuse4</i>     | (Optional) in6pcb bind address in use4 error     |
| <i>in6pcb-err-bindsetport</i>         | (Optional) in6pcb bind setport error             |
| <i>in6pcb-err-bindeagain</i>          | (Optional) in6pcb bind again error               |
| <i>in6pcb-err-laddr-eafnosupport</i>  | (Optional) in6pcb laddr eaf no support error     |
| <i>in6pcb-err-eaddrnotavail</i>       | (Optional) in6pcb address not available error    |
| <i>in6pcb-err-laddr-enomem</i>        | (Optional) in6pcb laddr no memory error          |
| <i>in6pcb-err-laddr-ehostreach</i>    | (Optional) in6pcb laddr host reach error         |
| <i>in6pcb-err-laddr-ehostunreach2</i> | (Optional) in6pcb laddr host reach2 error        |
| <i>in6pcb-err-laddr-ehostunreach3</i> | (Optional) in6pcb laddr host reach3 error        |
| <i>in6pcb-err-laddr-ehostunreach4</i> | (Optional) in6pcb laddr host reach4 error        |
| <i>in6pcb-err-laddr-enixio</i>        | (Optional) in6pcb laddr enxio error              |
| <i>in6pcb-err-connladdr</i>           | (Optional) in6pcb connect laddr error            |
| <i>in6pcb-err-conneaddrinuse</i>      | (Optional) in6pcb connect eaddress in use error  |
| <i>in6pcb-err-connbind</i>            | (Optional) in6pcb connect bind error             |
| <i>in6pcb-err-sockaddr-enomem</i>     | (Optional) in6pcb socket address no memory error |
| <i>in6pcb-err-v4maps-enomem</i>       | (Optional) in6pcb v4maps no memory error         |
| <i>in6pcb-err-setsock-noinp</i>       | (Optional) in6pcb set socket noinp error         |

|                                     |  |
|-------------------------------------|--|
| <i>in6pcb-err-setpeer-noinp</i>     | (Optional) in6pcb set peer noinp error               |
| <i>in6pcb-err-sockaddr-noinp</i>    | (Optional) in6pcb socket address noinp error         |
| <i>in6pcb-err-peeraddr-noinp</i>    | (Optional) in6pcb peer address noinp error           |
| <i>in6pcb-err-notify-einavl</i>     | (Optional) in6pcb notify egress available error      |
| <i>in6pcb-err-ctloutput-nosoopt</i> | (Optional) in6pcb control output no socket opt error |

**Command Mode**

- /exec

# show sockets tcp keychain binding

```
show sockets tcp keychain binding [ __readonly__ { TABLE_keychain <keychain> <handle> <ref_count>
} ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information          |
| sockets             | Display sockets status and configuration |
| tcp                 | TCP information                          |
| keychain            | Keychain information                     |
| binding             | Binding information regarding RPM        |
| <i>__readonly__</i> | (Optional)                               |
| TABLE_keychain      | (Optional) all sockets tcp keychains     |
| <i>keychain</i>     | (Optional) xml keychain information      |
| <i>handle</i>       | (Optional) xml handle information        |
| <i>ref_count</i>    | (Optional) xml refcount information      |

## Command Mode

- /exec

## show software authenticity file

```
show software authenticity { file <uri0> | running } [ __readonly__ [ TABLE_filekey <image> <image_type>
<signer_cname> [ <signer_org_unit> ] <signer_org_name> <cert_serial_num> <hash_algo> <signature_algo>
[ <key_version> ] [ <verifier_name> <verifier_version> ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | show information                              |
| software                | signifies information about current software  |
| authenticity            | signifies image signature                     |
| file                    | show verification information of a file       |
| <i>uri0</i>             | file to be verified                           |
| running                 | Show running image information                |
| <i>__readonly__</i>     | (Optional)                                    |
| TABLE_filekey           | (Optional) file signer information            |
| <i>image</i>            | (Optional) Image                              |
| <i>image_type</i>       | (Optional) Image type                         |
| <i>signer_cname</i>     | (Optional) Signer Common Name                 |
| <i>signer_org_unit</i>  | (Optional) Signer Organization Unit           |
| <i>signer_org_name</i>  | (Optional) Signer Organization Name           |
| <i>cert_serial_num</i>  | (Optional) Certificate Serial Number          |
| <i>hash_algo</i>        | (Optional) Hash Algorithm Used                |
| <i>signature_algo</i>   | (Optional) Signature Algorithm Used           |
| <i>key_version</i>      | (Optional) key version used to sign this file |
| <i>verifier_name</i>    | (Optional) verifier Image                     |
| <i>verifier_version</i> | (Optional) Verifier version                   |

### Command Mode

- /exec

## show software authenticity keys

```
show software authenticity keys [ __readonly__ [ TABLE_sh_keys <key_num> <key_type> <pub_key_algo>
<modulus> <exponent> <key_version> [ <product_name> ] ] ]
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | show information                             |
| software             | signifies information about current software |
| authenticity         | signifies image signature                    |
| keys                 | show installed verification keys             |
| <i>__readonly__</i>  | (Optional)                                   |
| <i>TABLE_sh_keys</i> | (Optional) table of device keys              |
| <i>key_num</i>       | (Optional) Key number                        |
| <i>key_type</i>      | (Optional) Type of key record                |
| <i>pub_key_algo</i>  | (Optional) Public key algorithm              |
| <i>modulus</i>       | (Optional) Key Modulus                       |
| <i>exponent</i>      | (Optional) Key exponent                      |
| <i>key_version</i>   | (Optional) Key version                       |
| <i>product_name</i>  | (Optional) Product name                      |

### Command Mode

- /exec



## show spanning-tree

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] [ __readonly__ TABLE_tree <tree_id>
<tree_tree_type> <tree_protocol> <port_count> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> <stp_active> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdus_in>
<bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prest> ] ] } | { show spanning-tree [ vlan <vlan-id> |
bridge-domain <bd-id> ] { <verbosity> | active } + [ __readonly__ TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <port_count> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> <stp_active> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> TABLE_port <if_index> <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdus_in>
<bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prest> ] ] }
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| spanning-tree       | Show spanning tree information                        |
| vlan                | (Optional) VLAN Switch Spanning Trees                 |
| bridge-domain       | (Optional) Bridge-Domain Switch Spanning Trees        |
| <i>vlan-id</i>      | (Optional) vlan range, Example: 1,3-5,7,9-11          |
| <i>bd-id</i>        | (Optional) Bridge-Domain range, Example: 2,4-5,7,9-11 |
| <i>verbosity</i>    | verbosity   |
| active              | Report on active interfaces only                      |
| <u>__readonly__</u> | (Optional) Read Only                                  |

|  |   |
|--|---|
| <i>TABLE_tree</i>                      | (Optional)  |
| <i>tree_id</i>                         | (Optional) Tree Id                                |
| <i>tree_tree_type</i>                  | (Optional) Tree Type                              |
| <i>tree_protocol</i>                   | (Optional) Tree Protocol                          |
| <i>port_count</i>                      | (Optional) Number of Ports in Tree                |
| <i>bridge_mac</i>                      | (Optional) Bridge Mac                             |
| <i>bridge_priority</i>                 | (Optional) Bridge Priority                        |
| <i>tree_designated_root</i>            | (Optional) Designated Root Mac                    |
| <i>tree_designated_root_priority</i>   | (Optional) Designated Root Priority               |
| <i>stp_active</i>                      | (Optional) Spanning Tree State                    |
| <i>root_path_cost</i>                  | (Optional) Root Path Cost                         |
| <i>root_port_if_index</i>              | (Optional) Root Port                              |
| <i>root_port_priority</i>              | (Optional) Root Port Priority                     |
| <i>root_port_number</i>                | (Optional) Root Port Number                       |
| <i>topology_change</i>                 | (Optional) Topology Change flag is set ?          |
| <i>topology_change_detected</i>        | (Optional) Topology Change detected flag is set ? |
| <i>topology_change_count</i>           | (Optional) Topology Change Count                  |
| <i>topology_change_time_since_last</i> | (Optional) Time since last TC                     |
| <i>tc_initiator_if_index</i>           | (Optional) Topology Change initiator port         |
| <i>max_age</i>                         | (Optional) Max Age                                |
| <i>hello_time</i>                      | (Optional) Hello Time                             |
| <i>forward_delay</i>                   | (Optional) Forward delay                          |
| <i>bridge_max_age</i>                  | (Optional) Configured Bridge Max Age              |
| <i>bridge_hello_time</i>               | (Optional) Configured Hello Time                  |
| <i>bridge_forward_delay</i>            | (Optional) Configured Forward Delay               |
| <i>hold_time</i>                       | (Optional) Configured Hold Time                   |
| <i>hello_timer</i>                     | (Optional) Hello Timer Value                      |
| <i>topology_change_timer</i>           | (Optional) Topology Change Timer Value            |
| <i>tcn_timer</i>                       | (Optional) TCN Timer Value                        |

|                                      |  |
|--------------------------------------|--|
| <i>aging_timer</i>                   | (Optional) Ageing Timer Value                        |
| <i>disabled</i>                      | (Optional) Number of ports Disabled                  |
| <i>blocking</i>                      | (Optional) Number of ports Blocking                  |
| <i>listening</i>                     | (Optional) Number of ports Listening                 |
| <i>learning</i>                      | (Optional) Number of ports Learning                  |
| <i>forwarding</i>                    | (Optional) Number of ports Forwarding                |
| <i>invalid</i>                       | (Optional) Number of ports Invalid                   |
| TABLE_port                           | (Optional)   |
| <i>if_index</i>                      | (Optional) Interface                                 |
| <i>vpc</i>                           | (Optional) STP Port memembr of MCT/VPC PO            |
| <i>port_info_tree_id</i>             | (Optional) Tree Id                                   |
| <i>state</i>                         | (Optional) STP Port State                            |
| <i>role</i>                          | (Optional) STP Port Role                             |
| <i>port_priority</i>                 | (Optional) Port priority                             |
| <i>port_number</i>                   | (Optional) Port Number                               |
| <i>port_protocol</i>                 | (Optional) Tree Protocol                             |
| <i>port_tree_type</i>                | (Optional) Tree Type                                 |
| <i>path_cost</i>                     | (Optional) Cost configured on this port              |
| <i>port_designated_root</i>          | (Optional) Designated Root Mac                       |
| <i>port_designated_root_priority</i> | (Optional) Designated Root Priority                  |
| <i>designated_cost</i>               | (Optional) Designated cost                           |
| <i>designated_bridge</i>             | (Optional) Designated bridge mac                     |
| <i>designated_bridge_priority</i>    | (Optional) Designated bridge priority                |
| <i>designated_port</i>               | (Optional) Designated Port Id                        |
| <i>tc_acknowledge</i>                | (Optional) Is topology change acknowledge flag set ? |
| <i>forward_transition_count</i>      | (Optional) Port transitions to Forwarding            |
| <i>self_looped</i>                   | (Optional) Is Port self looped ?                     |
| <i>inconsistency</i>                 | (Optional) PVST+ Inconsistency Error Flags           |
| <i>bpdu_in</i>                       | (Optional) BPDUs received on this stp port           |

|                            |   |
|----------------------------|---|
| <i>bpdus_out</i>           | (Optional) BPDUs send on this stp port              |
| <i>port_fast</i>           | (Optional) Port Fast configured on port             |
| <i>link_type</i>           | (Optional) Link type configured on this port        |
| <i>port_guard</i>          | (Optional) Port Guard mode of port                  |
| <i>bpdu_guard</i>          | (Optional) Bpdu Guard mode configured               |
| <i>bpdu_filter</i>         | (Optional) Bpdu Filter mode configured              |
| <i>oper_portfast</i>       | (Optional) Is portfast enabled ?                    |
| <i>oper_p2p</i>            | (Optional) Is port P2P ?                            |
| <i>oper_loopguard</i>      | (Optional) Is loopguard enabled ?                   |
| <i>oper_bpduguard</i>      | (Optional) Is bpduguard enabled ?                   |
| <i>oper_bpdufilter</i>     | (Optional) Is bpdufilter enabled ?                  |
| <i>int_bpdufilter</i>      | (Optional) Is internal bpdufilter enabled ?         |
| <i>forward_delay_timer</i> | (Optional) Forward Delay timer                      |
| <i>hold_timer</i>          | (Optional) Hold Timer                               |
| <i>message_age</i>         | (Optional) Message age timer                        |
| <i>peer</i>                | (Optional) STP protocol of the peer                 |
| <i>dispute</i>             | (Optional) Is port Disputed ?                       |
| <i>pvstsim_inc_timer</i>   | (Optional) PVST Simulation Inconsistency Hold Timer |
| <i>boundary</i>            | (Optional) Is port boundary ?                       |
| <i>prestd</i>              | (Optional) Is port Pre STD MST ?                    |
| <i>simulate_pvst</i>       | (Optional) Is port is pvst simulate mode ?          |
| <i>oper_networkport</i>    | (Optional) Is network port enabled ?                |
| <i>simulate_pvst_cfg</i>   | (Optional) PVST Simulation configured on port       |

### Command Mode

- /exec

## show spanning-tree blockedports

```
{ show spanning-tree [ vlan <vlan-id> ] blockedports [ __readonly__ [ TABLE_tree [ <port_info_tree_id> ]
[ TABLE_port [ <if_index> ] ] ] [ <tree_type> ] [ <num_ports> ] ] }
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information              |
| spanning-tree            | Show spanning tree information               |
| vlan                     | (Optional) VLAN Switch Spanning Trees        |
| __readonly__             | (Optional)                                   |
| TABLE_tree               | (Optional)                                   |
| <i>port_info_tree_id</i> | (Optional) Tree name                         |
| TABLE_port               | (Optional)                                   |
| <i>if_index</i>          | (Optional) Port name                         |
| <i>tree_type</i>         | (Optional) Tree Type                         |
| <i>num_ports</i>         | (Optional) Number of Ports                   |
| <i>vlan-id</i>           | (Optional) vlan range, Example: 1,3-5,7,9-11 |
| blockedports             | Show blocked ports                           |

### Command Mode

- /exec

## show spanning-tree bridge

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] bridge [ priority [ system-id ] ] [ __readonly__
{ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <bridge_mac> <bridge_priority>
<bridge_forward_delay> <bridge_max_age> <bridge_hello_time> } ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] bridge [ { detail | brief } ] [ __readonly__ { TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <bridge_mac> <bridge_priority> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> } ] } | { show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] bridge [ { address
| forward-time | hello-time | id | max-age | protocol } ] [ __readonly__ { TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <bridge_mac> <bridge_priority> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> } ] }
```

### Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                                 |
| spanning-tree  | Show spanning tree information                                  |
| vlan           | (Optional) VLAN Switch Spanning Trees                           |
| bridge-domain  | (Optional) Bridge-Domain Switch Spanning Trees                  |
| <i>vlan-id</i> | (Optional) vlan range, Example: 1,3-5,7,9-11                    |
| <i>bd-id</i>   | (Optional) Bridge-Domain range, Example: 2,4-5,7,9-11           |
| bridge         | Status and configuration of this bridge                         |
| address        | (Optional) Mac address of this bridge                           |
| forward-time   | (Optional) Forward delay interval                               |
| hello-time     | (Optional) Hello time   |
| id             | (Optional) Spanning tree bridge identifier                      |
| max-age        | (Optional) Max age  |
| protocol       | (Optional) Spanning tree protocol                               |
| brief          | (Optional) Brief summary of the status and configuration output |
| detail         | (Optional) Detailed of the status and configuration             |
| priority       | (Optional) Bridge priority of this bridge                       |
| system-id      | (Optional) Spanning tree priority with system id extension      |
| __readonly__   | (Optional) Read Only  |
| TABLE_tree     | (Optional)  |
| <i>tree_id</i> | (Optional) Tree Id  |

|                             |                                      |
|-----------------------------|--------------------------------------|
| <i>tree_tree_type</i>       | (Optional) Tree Type                 |
| <i>tree_protocol</i>        | (Optional) Tree Protocol             |
| <i>bridge_mac</i>           | (Optional) Bridge Mac                |
| <i>bridge_priority</i>      | (Optional) Bridge Priority           |
| <i>bridge_forward_delay</i> | (Optional) Configured Forward Delay  |
| <i>bridge_max_age</i>       | (Optional) Configured Bridge Max Age |
| <i>bridge_hello_time</i>    | (Optional) Configured Hello Time     |

**Command Mode**

- /exec

## show spanning-tree inconsistentports

```
{ show spanning-tree [ vlan <vlan-id> ] inconsistentports [ __readonly__ [ TABLE_tree <port_info_tree_id>
<if_index> <inconsistency> ] [ <tree_type> ] [ <num_ports> ] ] }
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information              |
| spanning-tree            | Show spanning tree information               |
| vlan                     | (Optional) VLAN Switch Spanning Trees        |
| <i>vlan-id</i>           | (Optional) vlan range, Example: 1,3-5,7,9-11 |
| inconsistentports        | Show inconsistent ports                      |
| <i>__readonly__</i>      | (Optional)                                   |
| TABLE_tree               | (Optional)                                   |
| <i>port_info_tree_id</i> | (Optional) Tree name                         |
| <i>if_index</i>          | (Optional) Port name                         |
| <i>inconsistency</i>     | (Optional) Inconsistency type                |
| <i>tree_type</i>         | (Optional) Tree Type                         |
| <i>num_ports</i>         | (Optional) Number of Ports                   |

### Command Mode

- /exec



## show spanning-tree interface

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] interface <interface-id> [ __readonly__ {
TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role> <port_priority> <port_number>
<port_protocol> <port_tree_type> <path_cost> <port_designated_root> <port_designated_root_priority>
<designated_cost> <designated_bridge> <designated_bridge_priority> <designated_port> <tc_acknowledge>
<forward_transition_count> <self_looped> <inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type>
<port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard>
<oper_bpdufilter> <int_bpdufilter> <oper_networkport> <forward_delay_timer> <hold_timer> <message_age>
<peer> <dispute> <pvstsim_inc_timer> [ <boundary> ] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prest>
] ] } | { show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] interface <interface-id> { <verbosity>
| active } + [ __readonly__ { TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role>
<port_priority> <port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdus_in>
<bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> <oper_networkport>
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prest> ] ] }
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                       |
| spanning-tree            | Show spanning tree information                        |
| vlan                     | (Optional) VLAN Switch Spanning Trees                 |
| bridge-domain            | (Optional) Bridge-Domain Switch Spanning Trees        |
| <i>vlan-id</i>           | (Optional) vlan range, Example: 1,3-5,7,9-11          |
| <i>bd-id</i>             | (Optional) Bridge-Domain range, Example: 2,4-5,7,9-11 |
| interface                | Spanning Tree interface status and configuration      |
| <i>interface-id</i>      |   |
| <i>verbosity</i>         | verbosity   |
| active                   | Report on active instances only                       |
| <u>__readonly__</u>      | (Optional) Read Only                                  |
| TABLE_port               | (Optional)  |
| <i>if_index</i>          | (Optional) Interface                                  |
| <i>vpc</i>               | (Optional) STP Port memembr of MCT/VPC PO             |
| <i>port_info_tree_id</i> | (Optional) Tree Id                                    |
| <i>state</i>             | (Optional) STP Port State                             |

|                                      |  |
|--------------------------------------|--|
| <i>role</i>                          | (Optional) STP Port Role                             |
| <i>port_priority</i>                 | (Optional) Port priority                             |
| <i>port_number</i>                   | (Optional) Port Number                               |
| <i>port_protocol</i>                 | (Optional) Tree Protocol                             |
| <i>port_tree_type</i>                | (Optional) Tree Type                                 |
| <i>path_cost</i>                     | (Optional) Cost configured on this port              |
| <i>port_designated_root</i>          | (Optional) Designated Root Mac                       |
| <i>port_designated_root_priority</i> | (Optional) Designated Root Priority                  |
| <i>designated_cost</i>               | (Optional) Designated cost                           |
| <i>designated_bridge</i>             | (Optional) Designated bridge mac                     |
| <i>designated_bridge_priority</i>    | (Optional) Designated bridge priority                |
| <i>designated_port</i>               | (Optional) Designated Port Id                        |
| <i>tc_acknowledge</i>                | (Optional) Is topology change acknowledge flag set ? |
| <i>forward_transition_count</i>      | (Optional) Port transitions to Forwarding            |
| <i>self_looped</i>                   | (Optional) Is Port self looped ?                     |
| <i>inconsistency</i>                 | (Optional) PVST+ Inconsistency Error Flags           |
| <i>bpdu_in</i>                       | (Optional) BPDUs received on this stp port           |
| <i>bpdu_out</i>                      | (Optional) BPDUs send on this stp port               |
| <i>port_fast</i>                     | (Optional) Port Fast configured on port              |
| <i>link_type</i>                     | (Optional) Link type configured on this port         |
| <i>port_guard</i>                    | (Optional) Port Guard mode of port                   |
| <i>bpdu_guard</i>                    | (Optional) Bpdu Guard mode configured                |
| <i>bpdu_filter</i>                   | (Optional) Bpdu Filter mode configured               |
| <i>oper_portfast</i>                 | (Optional) Is portfast enabled ?                     |
| <i>oper_p2p</i>                      | (Optional) Is port P2P ?                             |
| <i>oper_loopguard</i>                | (Optional) Is loopguard enabled ?                    |
| <i>oper_bpduguard</i>                | (Optional) Is bpduguard enabled ?                    |
| <i>oper_bpdufilter</i>               | (Optional) Is bpdufilter enabled ?                   |
| <i>int_bpdufilter</i>                | (Optional) Is internal bpdufilter enabled ?          |

|                            |   |
|----------------------------|---|
| <i>forward_delay_timer</i> | (Optional) Forward Delay timer                      |
| <i>hold_timer</i>          | (Optional) Hold Timer                               |
| <i>message_age</i>         | (Optional) Message age timer                        |
| <i>peer</i>                | (Optional) STP protocol of the peer                 |
| <i>dispute</i>             | (Optional) Is port Disputed ?                       |
| <i>pvstsim_inc_timer</i>   | (Optional) PVST Simulation Inconsistency Hold Timer |
| <i>boundary</i>            | (Optional) Is port boundary ?                       |
| <i>prestd</i>              | (Optional) Is port Pre STD MST ?                    |
| <i>simulate_pvst</i>       | (Optional) Is port is pvst simulate mode ?          |
| <i>oper_networkport</i>    | (Optional) Is network port enabled ?                |
| <i>simulate_pvst_cfg</i>   | (Optional) PVST Simulation configured on port       |

**Command Mode**

- /exec

## show spanning-tree interface

```
{ show spanning-tree [ vlan <vlan-id> ] interface <interface-id> { cost | inconsistency | edge | priority | rootcost
| state } [ __readonly__ [ TABLE_vlan_interface_info <tree_name> [ <cost> ] [ <edge> ] [ <inconsistency>
] [ <priority> ] [ <rootcost> ] [ <state> ] ] ] }
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                  |
| spanning-tree             | Show spanning tree information                   |
| vlan                      | (Optional) VLAN Switch Spanning Trees            |
| <i>vlan-id</i>            | (Optional) vlan range, Example: 1,3-5,7,9-11     |
| interface                 | Spanning Tree interface status and configuration |
| <i>interface-id</i>       |  |
| cost                      | Port path cost                                   |
| inconsistency             | Port inconsistency state                         |
| edge                      | Edge Port configuration                          |
| priority                  | Port priority                                    |
| rootcost                  | Path cost to root                                |
| state                     | Port spanning tree state                         |
| __readonly__              | (Optional)                                       |
| TABLE_vlan_interface_info | (Optional)                                       |
| <i>tree_name</i>          | (Optional) Spanning tree name                    |
| <i>cost</i>               | (Optional) Path cost                             |
| <i>edge</i>               | (Optional) Portfast enabled or not               |
| <i>inconsistency</i>      | (Optional) Port inconsistency                    |
| <i>priority</i>           | (Optional) Port Priority                         |
| <i>rootcost</i>           | (Optional) Designated Cost                       |
| <i>state</i>              | (Optional) Port state                            |

### Command Mode

- /exec

## show spanning-tree issu-impact

```
show spanning-tree issu-impact [ __readonly__ [ TABLE_topology <tc_detected> <tc_name> <no_of_tc>
<time> <tc_string> ] [ TABLE_BA_ports <port_name> ] [ <criteria1> ] [ <criteria2> ] [
TABLE_non_edge_ports <port> <vlan> <role> <sts> <tree> <instance> ] [ <criteria3> ] ]
```

### Syntax Description

|                             |                                      |
|-----------------------------|--------------------------------------|
| show                        | Show running system information      |
| spanning-tree               | Show spanning tree information       |
| issu-impact                 | Show whether STP meets ISSU criteria |
| <i>__readonly__</i>         | (Optional)                           |
| <i>TABLE_topology</i>       | (Optional)                           |
| <i>tc_detected</i>          | (Optional)                           |
| <i>tc_name</i>              | (Optional)                           |
| <i>no_of_tc</i>             | (Optional)                           |
| <i>time</i>                 | (Optional)                           |
| <i>tc_string</i>            | (Optional)                           |
| <i>TABLE_BA_ports</i>       | (Optional)                           |
| <i>port_name</i>            | (Optional)                           |
| <i>TABLE_non_edge_ports</i> | (Optional)                           |
| <i>port</i>                 | (Optional)                           |
| <i>vlan</i>                 | (Optional)                           |
| <i>role</i>                 | (Optional)                           |
| <i>sts</i>                  | (Optional)                           |
| <i>tree</i>                 | (Optional)                           |
| <i>instance</i>             | (Optional)                           |
| <i>criteria1</i>            | (Optional)                           |
| <i>criteria2</i>            | (Optional)                           |
| <i>criteria3</i>            | (Optional)                           |

### Command Mode

- /exec

## show spanning-tree mst

```
{ show spanning-tree mst [ <mst-id> ] [ __readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol>
<port_count> <bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority>
<stp_active> <root_path_cost> <root_port_if_index> <root_port_priority> <root_port_number>
<topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> <ist-master-id-mac> <ist-master-prio> <ist-path-cost> <remaining-hops> <max-hops>
<txholdcount> <tree-vlan-map> TABLE_port <if_index> <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdus_in>
<bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> <boundary>
[ <simulate_pvst_cfg> ] <simulate_pvst> <prestd> [ <designated_ist_master> ] [
<designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ] } | { show spanning-tree mst
[ <mst-id> ] detail [ __readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <port_count>
<bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority> <stp_active>
<root_path_cost> <root_port_if_index> <root_port_priority> <root_port_number> <topology_change>
<topology_change_detected> <topology_change_count> <topology_change_time_since_last>
<tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age> <bridge_hello_time> <max_age>
<hello_time> <forward_delay> <hold_time> <hello_timer> <topology_change_timer> <tcn_timer>
<aging_timer> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <ist-master-id-mac>
<ist-master-prio> <ist-path-cost> <remaining-hops> <max-hops> <txholdcount> <tree-vlan-map> TABLE_port
<if_index> <port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol>
<port_tree_type> <path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost>
<designated_bridge> <designated_bridge_priority> <designated_port> <tc_acknowledge>
<forward_transition_count> <self_looped> <inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type>
<port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard>
<oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ] <forward_delay_timer> <hold_timer>
<message_age> <peer> <dispute> <pvstsim_inc_timer> <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst>
<prestd> [ <designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [
<vlan-map> ] ] }
```

### Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information                   |
| spanning-tree | Show spanning tree information                    |
| mst           | Multiple spanning trees                           |
| <i>mst-id</i> | (Optional) MST instance range, example: 0-3,5,7-9 |
| detail        | Detailed information                              |
| __readonly__  | (Optional) Read Only                              |
| TABLE_tree    | (Optional)  |

|  |   |
|--|---|
| <i>tree_id</i>                         | (Optional) Tree Id                                |
| <i>tree_tree_type</i>                  | (Optional) Tree Type                              |
| <i>tree_protocol</i>                   | (Optional) Tree Protocol                          |
| <i>port_count</i>                      | (Optional) Number of Ports in Tree                |
| <i>bridge_mac</i>                      | (Optional) Bridge Mac                             |
| <i>bridge_priority</i>                 | (Optional) Bridge Priority                        |
| <i>tree_designated_root</i>            | (Optional) Designated Root Mac                    |
| <i>tree_designated_root_priority</i>   | (Optional) Designated Root Priority               |
| <i>stp_active</i>                      | (Optional) Spanning Tree State                    |
| <i>root_path_cost</i>                  | (Optional) Root Path Cost                         |
| <i>root_port_if_index</i>              | (Optional) Root Port                              |
| <i>root_port_priority</i>              | (Optional) Root Port Priority                     |
| <i>root_port_number</i>                | (Optional) Root Port Number                       |
| <i>topology_change</i>                 | (Optional) Topology Change flag is set ?          |
| <i>topology_change_detected</i>        | (Optional) Topology Change detected flag is set ? |
| <i>topology_change_count</i>           | (Optional) Topology Change Count                  |
| <i>topology_change_time_since_last</i> | (Optional) Time since last TC                     |
| <i>tc_initiator_if_index</i>           | (Optional) Topology Change initiator port         |
| <i>max_age</i>                         | (Optional) Max Age                                |
| <i>hello_time</i>                      | (Optional) Hello Time                             |
| <i>forward_delay</i>                   | (Optional) Forward delay                          |
| <i>bridge_max_age</i>                  | (Optional) Configured Bridge Max Age              |
| <i>bridge_hello_time</i>               | (Optional) Configured Hello Time                  |
| <i>bridge_forward_delay</i>            | (Optional) Configured Forward Delay               |
| <i>hold_time</i>                       | (Optional) Configured Hold Time                   |
| <i>hello_timer</i>                     | (Optional) Hello Timer Value                      |
| <i>topology_change_timer</i>           | (Optional) Topology Change Timer Value            |
| <i>tcn_timer</i>                       | (Optional) TCN Timer Value                        |
| <i>aging_timer</i>                     | (Optional) Ageing Timer Value                     |

|                                      |   |
|--------------------------------------|---|
| <i>disabled</i>                      | (Optional) Number of ports Disabled       |
| <i>blocking</i>                      | (Optional) Number of ports Blocking       |
| <i>listening</i>                     | (Optional) Number of ports Listening      |
| <i>learning</i>                      | (Optional) Number of ports Learning       |
| <i>forwarding</i>                    | (Optional) Number of ports Forwarding     |
| <i>invalid</i>                       | (Optional) Number of ports Invalid        |
| <i>ist-master-id-mac</i>             | (Optional) IST Master ID MAC address      |
| <i>ist-master-prio</i>               | (Optional) IST Master ID priority         |
| <i>ist-path-cost</i>                 | (Optional) IST path cost                  |
| <i>remaining-hops</i>                | (Optional) Remaining hops                 |
| <i>max-hops</i>                      | (Optional) Max Hops                       |
| <i>txholdcount</i>                   | (Optional) TX Hold count                  |
| <i>tree-vlan-map</i>                 | (Optional) Bitmap of vlans mapped to tree |
| TABLE_port                           | (Optional)                                |
| <i>if_index</i>                      | (Optional) Interface                      |
| <i>state</i>                         | (Optional) STP Port State                 |
| <i>role</i>                          | (Optional) STP Port Role                  |
| <i>port_priority</i>                 | (Optional) Port priority                  |
| <i>port_number</i>                   | (Optional) Port Number                    |
| <i>port_info_tree_id</i>             | (Optional) Tree Id                        |
| <i>port_tree_type</i>                | (Optional) Tree Type                      |
| <i>port_protocol</i>                 | (Optional) Tree Protocol                  |
| <i>path_cost</i>                     | (Optional) Cost configured on this port   |
| <i>port_designated_root</i>          | (Optional) Designated Root Mac            |
| <i>port_designated_root_priority</i> | (Optional) Designated Root Priority       |
| <i>designated_cost</i>               | (Optional) Designated cost                |
| <i>designated_bridge</i>             | (Optional) Designated bridge mac          |
| <i>designated_bridge_priority</i>    | (Optional) Designated bridge priority     |
| <i>designated_port</i>               | (Optional) Designated Port Id             |



|                                       |  |
|---------------------------------------|--|
| <i>tc_acknowledge</i>                 | (Optional) Is topology change acknowledge flag set ? |
| <i>forward_transition_count</i>       | (Optional) Port transitions to Forwarding            |
| <i>self_looped</i>                    | (Optional) Is Port self looped ?                     |
| <i>inconsistency</i>                  | (Optional) PVST+ Inconsistency Error Flags           |
| <i>bpdu_in</i>                        | (Optional) BPDUs received on this stp port           |
| <i>bpdu_out</i>                       | (Optional) BPDUs send on this stp port               |
| <i>port_fast</i>                      | (Optional) Port Fast configured on port              |
| <i>link_type</i>                      | (Optional) Link type configured on this port         |
| <i>port_guard</i>                     | (Optional) Port Guard mode of port                   |
| <i>bpdu_guard</i>                     | (Optional) Bpdu Guard mode configured                |
| <i>bpdu_filter</i>                    | (Optional) Bpdu Filter mode configured               |
| <i>oper_portfast</i>                  | (Optional) Is portfast enabled ?                     |
| <i>oper_p2p</i>                       | (Optional) Is port P2P ?                             |
| <i>oper_loopguard</i>                 | (Optional) Is loopguard enabled ?                    |
| <i>oper_bpduguard</i>                 | (Optional) Is bpduguard enabled ?                    |
| <i>oper_bpdufilter</i>                | (Optional) Is bpdufilter enabled ?                   |
| <i>int_bpdufilter</i>                 | (Optional) Is internal bpdufilter enabled ?          |
| <i>forward_delay_timer</i>            | (Optional) Forward Delay timer                       |
| <i>hold_timer</i>                     | (Optional) Hold Timer                                |
| <i>message_age</i>                    | (Optional) Message age timer                         |
| <i>peer</i>                           | (Optional) STP protocol of the peer                  |
| <i>boundary</i>                       | (Optional) Is port boundary ?                        |
| <i>simulate_pvst</i>                  | (Optional) Is port is pvst simulate mode ?           |
| <i>dispute</i>                        | (Optional) Is port Disputed ?                        |
| <i>pvstsim_inc_timer</i>              | (Optional) PVST Simulation Inconsistency Hold Timer  |
| <i>prestd</i>                         | (Optional) Is port Pre STD MST ?                     |
| <i>designated_ist_master</i>          | (Optional) Ist master mac                            |
| <i>designated_ist_master_priority</i> | (Optional) Ist master priority                       |
| <i>designated_ist_cost</i>            | (Optional) Ist master path cost                      |

|                          |   |
|--------------------------|---|
| <i>vlan-map</i>          | (Optional) Bitmap of vlans mapped to port     |
| <i>oper_networkport</i>  | (Optional) Is network port enabled ?          |
| <i>simulate_pvst_cfg</i> | (Optional) PVST Simulation configured on port |

**Command Mode**

- /exec

## show spanning-tree mst configuration

```
{ show spanning-tree mst configuration [ __readonly__ <stp-mode> <name> <rev-id> {
TABLE_instance_to_vlan_map <mst_id> <vlan_bit_map> } [ <pvlan-sync> ] ] }
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information          |
| spanning-tree              | Show spanning tree information           |
| mst                        | Multiple spanning trees                  |
| configuration              | MST current region configuration         |
| __readonly__               | (Optional) Read Only                     |
| <i>stp-mode</i>            | (Optional) Spanning Tree operating mode  |
| <i>name</i>                | (Optional) Configuration name            |
| <i>rev-id</i>              | (Optional) Configuration revision number |
| TABLE_instance_to_vlan_map | (Optional) Instance to vlan mapping Info |
| <i>mst_id</i>              | (Optional) MST Instance ID               |
| <i>vlan_bit_map</i>        | (Optional) VLAN Bitmap                   |
| <i>pvlan-sync</i>          | (Optional) pvlan synchronization         |

### Command Mode

- /exec

## show spanning-tree mst configuration digest

```
{ show spanning-tree mst configuration digest [ __readonly__ <stp-mode> <name> <rev-id> <digest>
<prestd-digest> [ <pvlan-sync> ] ] }
```

### Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                    |
| spanning-tree        | Show spanning tree information                     |
| mst                  | Multiple spanning trees                            |
| configuration        | MST current region configuration                   |
| digest               | Display MST configuration digest                   |
| <i>__readonly__</i>  | (Optional) Read Only                               |
| <i>stp-mode</i>      | (Optional) Spanning Tree operating mode            |
| <i>name</i>          | (Optional) Configuration name                      |
| <i>rev-id</i>        | (Optional) Configuration revision number           |
| <i>digest</i>        | (Optional) MST region configuration digest         |
| <i>prestd-digest</i> | (Optional) MST region configuration pre-std digest |
| <i>pvlan-sync</i>    | (Optional) pvlan synchronization                   |

### Command Mode

- /exec

## show spanning-tree mst interface

```
{ show spanning-tree mst [ <mst-id> ] interface <interface-id> [ __readonly__ TABLE_port <if_index>
<port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol> <port_tree_type>
<path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost> <designated_bridge>
<designated_bridge_priority> <designated_port> <tc_acknowledge> <forward_transition_count> <self_looped>
<inconsistency> <bpdu_in> <bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter>
<oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [
<oper_networkport> ] <forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> [
<pvstsim_inc_timer> ] <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst> <prestd> [
<designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ]
} | { show spanning-tree mst [ <mst-id> ] interface <interface-id> detail [ __readonly__ TABLE_port <if_index>
<port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol> <port_tree_type>
<path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost> <designated_bridge>
<designated_bridge_priority> <designated_port> <tc_acknowledge> <forward_transition_count> <self_looped>
<inconsistency> <bpdu_in> <bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter>
<oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [
<oper_networkport> ] <forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> [
<pvstsim_inc_timer> ] <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst> <prestd> [
<designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ]
}
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                   |
| spanning-tree            | Show spanning tree information                    |
| mst                      | Multiple spanning trees                           |
| <i>mst-id</i>            | (Optional) MST instance range, example: 0-3,5,7-9 |
| interface                | Spanning Tree interface status and configuration  |
| <i>interface-id</i>      | Specify an interface as a target for the command  |
| detail                   | Detailed information                              |
| __readonly__             | (Optional) Read Only                              |
| TABLE_port               | (Optional)  |
| <i>if_index</i>          | (Optional) Interface                              |
| <i>port_info_tree_id</i> | (Optional) Tree Id                                |
| <i>state</i>             | (Optional) STP Port State                         |
| <i>role</i>              | (Optional) STP Port Role                          |
| <i>port_priority</i>     | (Optional) Port priority                          |
| <i>port_number</i>       | (Optional) Port Number                            |

|                                      |  |
|--------------------------------------|--|
| <i>port_tree_type</i>                | (Optional) Tree Type                                 |
| <i>port_protocol</i>                 | (Optional) Tree Protocol                             |
| <i>path_cost</i>                     | (Optional) Cost configured on this port              |
| <i>port_designated_root</i>          | (Optional) Designated Root Mac                       |
| <i>port_designated_root_priority</i> | (Optional) Designated Root Priority                  |
| <i>designated_cost</i>               | (Optional) Designated cost                           |
| <i>designated_bridge</i>             | (Optional) Designated bridge mac                     |
| <i>designated_bridge_priority</i>    | (Optional) Designated bridge priority                |
| <i>designated_port</i>               | (Optional) Designated Port Id                        |
| <i>tc_acknowledge</i>                | (Optional) Is topology change acknowledge flag set ? |
| <i>forward_transition_count</i>      | (Optional) Port transitions to Forwarding            |
| <i>self_looped</i>                   | (Optional) Is Port self looped ?                     |
| <i>inconsistency</i>                 | (Optional) PVST+ Inconsistency Error Flags           |
| <i>bp dus_in</i>                     | (Optional) BPDUs received on this stp port           |
| <i>bp dus_out</i>                    | (Optional) BPDUs send on this stp port               |
| <i>port_fast</i>                     | (Optional) Port Fast configured on port              |
| <i>link_type</i>                     | (Optional) Link type configured on this port         |
| <i>port_guard</i>                    | (Optional) Port Guard mode of port                   |
| <i>bp du_guard</i>                   | (Optional) Bpdu Guard mode configured                |
| <i>bp du_filter</i>                  | (Optional) Bpdu Filter mode configured               |
| <i>oper_portfast</i>                 | (Optional) Is portfast enabled ?                     |
| <i>oper_p2p</i>                      | (Optional) Is port P2P ?                             |
| <i>oper_loopguard</i>                | (Optional) Is loopguard enabled ?                    |
| <i>oper_bp duguard</i>               | (Optional) Is bp duguard enabled ?                   |
| <i>oper_bp dufilter</i>              | (Optional) Is bp dufilter enabled ?                  |
| <i>int_bp dufilter</i>               | (Optional) Is internal bp dufilter enabled ?         |
| <i>forward_delay_timer</i>           | (Optional) Forward Delay timer                       |
| <i>hold_timer</i>                    | (Optional) Hold Timer                                |
| <i>message_age</i>                   | (Optional) Message age timer                         |

|                                       |   |
|---------------------------------------|---|
| <i>peer</i>                           | (Optional) STP protocol of the peer                 |
| <i>boundary</i>                       | (Optional) Is port boundary ?                       |
| <i>simulate_pvst</i>                  | (Optional) Is port is pvst simulate mode ?          |
| <i>dispute</i>                        | (Optional) Is port Disputed ?                       |
| <i>prestd</i>                         | (Optional) Is port Pre STD MST ?                    |
| <i>designated_ist_master</i>          | (Optional) Ist master mac                           |
| <i>designated_ist_master_priority</i> | (Optional) Ist master priority                      |
| <i>designated_ist_cost</i>            | (Optional) Ist master path cost                     |
| <i>vlan-map</i>                       | (Optional) Bitmap of vlans mapped to port           |
| <i>oper_networkport</i>               | (Optional) Is network port enabled ?                |
| <i>pvstsim_inc_timer</i>              | (Optional) PVST Simulation Inconsistency Hold Timer |
| <i>simulate_pvst_cfg</i>              | (Optional) PVST Simulation configured on port       |

#### Command Mode

- /exec

# show spanning-tree pathcost method

```
{ show spanning-tree pathcost method [ __readonly__ <stp-pathcost-method> [ <stp-operpathcost-method> ] ] }
```

## Syntax Description

|                                |                                     |
|--------------------------------|-------------------------------------|
| show                           | Show running system information     |
| spanning-tree                  | Show spanning tree information      |
| pathcost                       | Show Spanning pathcost options      |
| method                         | Default pathcost calculation method |
| <i>__readonly__</i>            | (Optional)                          |
| <i>stp-pathcost-method</i>     | (Optional) STP Pathcost Method      |
| <i>stp-operpathcost-method</i> | (Optional) STP Pathcost Method      |

## Command Mode

- /exec



## show spanning-tree root

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] root [ priority [ system-id ] ] [ __readonly__
TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <tree_designated_root>
<tree_designated_root_priority> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <max_age> <hello_time> <forward_delay> ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] root [ { address | cost | forward-time | hello-time | id | max-age | port } ] [
__readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <tree_designated_root>
<tree_designated_root_priority> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <max_age> <hello_time> <forward_delay> ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] root [ { detail | brief } ] [ __readonly__ TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <tree_designated_root> <tree_designated_root_priority> <root_path_cost>
<root_port_if_index> <root_port_priority> <root_port_number> <max_age> <hello_time> <forward_delay>
] } }
```

### Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                            |
| spanning-tree  | Show spanning tree information                             |
| vlan           | (Optional) VLAN Switch Spanning Trees                      |
| bridge-domain  | (Optional) Bridge-Domain Switch Spanning Trees             |
| <i>vlan-id</i> | (Optional) vlan range, Example: 1,3-5,7,9-11               |
| <i>bd-id</i>   | (Optional) Bridge-Domain range, Example: 2,4-5,7,9-11      |
| root           | Status and configuration of the root bridge                |
| address        | (Optional) Mac address of this bridge                      |
| cost           | (Optional) Path cost from this bridge to the root          |
| forward-time   | (Optional) Forward delay interval                          |
| hello-time     | (Optional) Hello time                                      |
| id             | (Optional) Spanning tree bridge identifier                 |
| max-age        | (Optional) Max age   |
| port           | (Optional) Root port                                       |
| brief          | (Optional) Brief summary of interface information          |
| detail         | (Optional) Detailed information                            |
| priority       | (Optional) Bridge priority of this bridge                  |
| system-id      | (Optional) Spanning tree priority with system id extension |
| __readonly__   | (Optional) Read Only                                       |

|                                      |                                     |
|--------------------------------------|-------------------------------------|
| TABLE_tree                           | (Optional)                          |
| <i>tree_id</i>                       | (Optional) Tree Id                  |
| <i>tree_tree_type</i>                | (Optional) Tree Type                |
| <i>tree_protocol</i>                 | (Optional) Tree Protocol            |
| <i>tree_designated_root</i>          | (Optional) Designated Root Mac      |
| <i>tree_designated_root_priority</i> | (Optional) Designated Root Priority |
| <i>root_path_cost</i>                | (Optional) Root Path Cost           |
| <i>root_port_if_index</i>            | (Optional) Root Port                |
| <i>root_port_priority</i>            | (Optional) Root Port Priority       |
| <i>root_port_number</i>              | (Optional) Root Port Number         |
| <i>max_age</i>                       | (Optional) Max Age                  |
| <i>hello_time</i>                    | (Optional) Hello Time               |
| <i>forward_delay</i>                 | (Optional) Forward delay            |

**Command Mode**

- /exec

## show spanning-tree summary

```
show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] summary [ __readonly__ <stp-mode> [
<stp_tree_root_info> <tree_type> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> ] + [ <stp_root_bmp_info> <stp_root_tree_type> <tree_root_bmp>
<stp_l2gstp_bmp_info> <stp_l2gstp_tree_type> [ <stp_l2gstp_bmp> ] ] <stp_global_info> <pcost_method>
<oper_pcost_method> <port_fast> <bpdu_guard> <bpdu_filter> <oper_loopguard> <bridge_assurance>
<networkport_default> <simulate_pvst> <max-hops> <peer_switch_cfg> <oper_peer_switch>
<stp_l2gstp_domain_id> <stp_lite> [ TABLE_tree <stp_tree_summary> <summary_tree_type> <disabled>
<blocking> <listening> <learning> <forwarding> <invalid> <port_count> ] [ <stp_summary_totals>
<total_tree_type> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <port_count> ] ]
```

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information                       |
| spanning-tree                        | Show spanning tree information                        |
| vlan                                 | (Optional) VLAN Switch Spanning Trees                 |
| bridge-domain                        | (Optional) Bridge-Domain Switch Spanning Trees        |
| <i>vlan-id</i>                       | (Optional) vlan range, Example: 1,3-5,7,9-11          |
| <i>bd-id</i>                         | (Optional) Bridge-Domain range, Example: 2,4-5,7,9-11 |
| summary                              | Summary of port states                                |
| <i>__readonly__</i>                  | (Optional) Read Only                                  |
| <i>stp-mode</i>                      | (Optional) Spanning Tree operating mode               |
| <i>stp_tree_root_info</i>            | (Optional) STP Tree Root info marker                  |
| <i>tree_type</i>                     | (Optional) Tree Type                                  |
| <i>bridge_mac</i>                    | (Optional) Bridge Mac                                 |
| <i>bridge_priority</i>               | (Optional) Bridge Priority                            |
| <i>tree_designated_root</i>          | (Optional) Designated Root Mac                        |
| <i>tree_designated_root_priority</i> | (Optional) Designated Root Priority                   |
| <i>stp_root_bmp_info</i>             | (Optional) STP root bitmap info marker                |
| <i>stp_root_tree_type</i>            | (Optional) Tree Type                                  |
| <i>tree_root_bmp</i>                 | (Optional) STP tree root bmp                          |
| <i>stp_l2gstp_bmp_info</i>           | (Optional) L2 Gateway STP bitmap marker               |
| <i>stp_l2gstp_tree_type</i>          | (Optional) Tree Type                                  |

|                             |   |
|-----------------------------|---|
| <i>stp_l2gstp_bmp</i>       | (Optional) L2 Gateway STP bitmap            |
| <i>stp_global_info</i>      | (Optional) STP global info marker           |
| <i>pcost_method</i>         | (Optional) STP pathcost method              |
| <i>oper_pcost_method</i>    | (Optional) STP oper pathcost method         |
| <i>port_fast</i>            | (Optional) Port Fast configured on port     |
| <i>bpdu_guard</i>           | (Optional) Bpdu Guard mode configured       |
| <i>bpdu_filter</i>          | (Optional) Bpdu Filter mode configured      |
| <i>oper_loopguard</i>       | (Optional) Is loopguard enabled ?           |
| <i>bridge_assurance</i>     | (Optional) Bridge Assurance                 |
| <i>networkport_default</i>  | (Optional) Network Port default             |
| <i>simulate_pvst</i>        | (Optional) Is port is pvst simulate mode ?  |
| <i>max-hops</i>             | (Optional) Max Hops                         |
| <i>peer_switch_cfg</i>      | (Optional) peer switch configuration status |
| <i>oper_peer_switch</i>     | (Optional) peer switch operational status   |
| <i>stp_l2gstp_domain_id</i> | (Optional) L2 Gateway STP Domain ID         |
| <i>stp_lite</i>             | (Optional) STP-Lite                         |
| TABLE_tree                  | (Optional)                                  |
| <i>stp_tree_summary</i>     | (Optional) STP Tree Summary                 |
| <i>summary_tree_type</i>    | (Optional) Tree Type                        |
| <i>disabled</i>             | (Optional) Number of ports Disabled         |
| <i>blocking</i>             | (Optional) Number of ports Blocking         |
| <i>listening</i>            | (Optional) Number of ports Listening        |
| <i>learning</i>             | (Optional) Number of ports Learning         |
| <i>forwarding</i>           | (Optional) Number of ports Forwarding       |
| <i>invalid</i>              | (Optional) Number of ports Invalid          |
| <i>port_count</i>           | (Optional) Number of Ports in Tree          |
| <i>stp_summary_totals</i>   | (Optional) Total num STP trees              |
| <i>total_tree_type</i>      | (Optional) Tree Type                        |
| <i>disabled</i>             | (Optional) Number of ports Disabled         |

|                   |                                       |
|-------------------|---------------------------------------|
| <i>blocking</i>   | (Optional) Number of ports Blocking   |
| <i>listening</i>  | (Optional) Number of ports Listening  |
| <i>learning</i>   | (Optional) Number of ports Learning   |
| <i>forwarding</i> | (Optional) Number of ports Forwarding |
| <i>invalid</i>    | (Optional) Number of ports Invalid    |
| <i>port_count</i> | (Optional) Number of Ports in Tree    |

**Command Mode**

- /exec

## show spanning-tree summary totals

```
show spanning-tree summary totals [ __readonly__ <stp-mode> <stp_tree_root_info> <tree_type>
<bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority> <stp_root_bmp_info>
<stp_root_tree_type> <tree_root_bmp> <stp_l2gstp_bmp_info> <stp_l2gstp_tree_type> <stp_l2gstp_bmp>
<stp_global_info> <pcost_method> <oper_pcost_method> <port_fast> <bpdu_guard> <bpdu_filter>
<oper_loopguard> <bridge_assurance> <networkport_default> <simulate_pvst> <max-hops>
<peer_switch_cfg> <oper_peer_switch> <stp_l2gstp_domain_id> <stp_lite> <stp_summary_totals>
<total_tree_type> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <port_count> ]
```

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information         |
| spanning-tree                        | Show spanning tree information          |
| summary                              | Summary of port states                  |
| totals                               | Only show totals                        |
| <i>__readonly__</i>                  | (Optional) Read Only                    |
| <i>stp-mode</i>                      | (Optional) Spanning Tree operating mode |
| <i>stp_tree_root_info</i>            | (Optional) STP Tree Root info marker    |
| <i>tree_type</i>                     | (Optional) Tree Type                    |
| <i>bridge_mac</i>                    | (Optional) Bridge Mac                   |
| <i>bridge_priority</i>               | (Optional) Bridge Priority              |
| <i>tree_designated_root</i>          | (Optional) Designated Root Mac          |
| <i>tree_designated_root_priority</i> | (Optional) Designated Root Priority     |
| <i>stp_root_bmp_info</i>             | (Optional) STP root bitmap info marker  |
| <i>stp_root_tree_type</i>            | (Optional) Tree Type                    |
| <i>tree_root_bmp</i>                 | (Optional) STP tree root bmp            |
| <i>stp_l2gstp_bmp_info</i>           | (Optional) L2 Gateway STP bitmap marker |
| <i>stp_l2gstp_tree_type</i>          | (Optional) Tree Type                    |
| <i>stp_l2gstp_bmp</i>                | (Optional) L2 Gateway STP bitmap        |
| <i>stp_global_info</i>               | (Optional) STP global info marker       |
| <i>pcost_method</i>                  | (Optional) STP pathcost method          |
| <i>oper_pcost_method</i>             | (Optional) STP oper pathcost method     |
| <i>port_fast</i>                     | (Optional) Port Fast configured on port |

|                             |   |
|-----------------------------|---|
| <i>bpduguard</i>            | (Optional) Bpdu Guard mode configured       |
| <i>bpdufilter</i>           | (Optional) Bpdu Filter mode configured      |
| <i>operloopguard</i>        | (Optional) Is loopguard enabled ?           |
| <i>bridgeassurance</i>      | (Optional) Bridge Assurance                 |
| <i>networkportdefault</i>   | (Optional) Network Port default             |
| <i>simulatepvst</i>         | (Optional) Is port is pvst simulate mode ?  |
| <i>maxhops</i>              | (Optional) Max Hops                         |
| <i>peerswitchcfg</i>        | (Optional) peer switch configuration status |
| <i>operpeerswitch</i>       | (Optional) peer switch operational status   |
| <i>stp_l2gstp_domain_id</i> | (Optional) L2 Gateway STP Domain ID         |
| <i>stp_lite</i>             | (Optional) STP-Lite                         |
| <i>stp_summary_totals</i>   | (Optional) Total num STP trees              |
| <i>total_tree_type</i>      | (Optional) Tree Type                        |
| <i>disabled</i>             | (Optional) Number of ports Disabled         |
| <i>blocking</i>             | (Optional) Number of ports Blocking         |
| <i>listening</i>            | (Optional) Number of ports Listening        |
| <i>learning</i>             | (Optional) Number of ports Learning         |
| <i>forwarding</i>           | (Optional) Number of ports Forwarding       |
| <i>invalid</i>              | (Optional) Number of ports Invalid          |
| <i>port_count</i>           | (Optional) Number of Ports in Tree          |

### Command Mode

- /exec

## show sprom

```
show sprom { backplane <i0> | module <module> <i1> | xbar <santa-cruz-range> <i2> | powersupply <i3>
| fan <i4> | sup | stby-sup | all | all2 | backplane2 | module2 <module2> | powersupply2 <i5> | sup2 } [
__readonly__ [ cmn_block { <blk_sig_cb> <blk_ver_cb> <blk_length_cb> <blk_checksum_cb> <eeprom_size>
<blk_count> <fru_major_type> <fru_minor_type> <oem_string> <prd_num> <serial_num> <part_num>
<part_rev> <mfg_dev> <hw_rev> <mfg_bits> <eng_use> <snmp_oid> <power_consump> <rma_code>
<clei_code> <vid> } ] [ sup_specific_block { <blk_sig_ssb> <blk_ver_ssb> <blk_length_ssb>
<blk_checksum_ssb> <feature_bits> <hw_changes_bits> <card_index> <mac_addresses> <no_of_macs>
<no_of_epld> [ TABLE_epld_ssb <epld_name_ssb> <epld_ver_ssb> ] <port_type_num> { TABLE_sensor_ssb
<sensor_num_ssb> <maj_thres_ssb> <min_thres_ssb> } <max_connector_power> <cooling_req> <amb_temp>
} ] [ lc_specific_block { <blk_sig_lc> <blk_ver_lc> <blk_length_lc> <blk_checksum_lc> <feature_bits>
<hw_changes_bits> <card_index> <mac_addresses> <no_of_macs> <no_of_epld> [ TABLE_epld_lc
<epld_name_lc> <epld_ver_lc> ] <port_type_num> { TABLE_sensor_lc <sensor_num_lc> <maj_thres_lc>
<min_thres_lc> } <max_connector_power> <cooling_req> <amb_temp> } ] [ ps_specific_block {
<blk_sig_psb> <blk_ver_psb> <blk_length_psb> <blk_checksum_psb> <feature_bits> <current_110v>
<current_220v> <stackmib_oid> } ] [ fan_specific_block { <blk_sig_fsb> <blk_ver_fsb> <blk_length_fsb>
<blk_checksum_fsb> <feature_bits> <hw_change_bits> <stackmib_oid> <cooling_capacity> <amb_temp>
} ] [ ch_specific_block { <blk_sig_csb> <blk_ver_csb> <blk_length_csb> <blk_checksum_csb> <feature_bits>
<hw_changes_bits> <stackmib_oid> <mac_addresses> <no_of_macs> <oem_enterprise> <oem_mib_offset>
<max_connector_power> } ] [ temp_sensor_block { <blk_sig_tsb> <blk_ver_tsb> <blk_length_tsb>
<blk_checksum_tsb> <no_of_sensors> { TABLE_sensor_tsb <sensor_num_tsb> <maj_thres_tsb>
<min_thres_tsb> } } ] [ wwn_specific_block { <blk_sig_wwnb> <blk_ver_wwnb> <blk_length_wwnb>
<blk_checksum_wwnb> { TABLE_wwn_usage_wsb <wwn_usage_bits> } } ] [ lic_specific_block {
<blk_sig_licb> <blk_ver_licb> <blk_length_licb> <blk_checksum_licb> { TABLE_lic_usage_lsb
<lic_usage_bits> } } ] [ second_serial_block { <blk_sig_sn2b> <blk_ver_sn2b> <blk_length_sn2b>
<blk_checksum_sn2b> <serial_num_sn2b> } ] [ psu_common_block { <format_version> <internal_info_offset>
<chassis_info_offset> <board_info_offset> <product_info_offset> <multirecord_info_offset> <checksum>
} ] [ psu_board_info_block { <format_version> <length> <language_code> <mfg_date> <mfg_type>
<mfg_info> <name_type> <product_name> <snum_type> <snum> <part_type> <partnum> <fruid_type>
<fruid> <bom_hw_pid_info> <partnum_rev> <fab_revision> <vid> <clei_len> <clei> <eof_marker> <csum>
} ] [ psu_product_info_block { <format_version> <length> <language_code> <mfg_type> <mfg_info>
<name_type> <product_name> <part_type> <partnum> <product_ver_type> <sw_certification> <snum_type>
<snum> <asset_type> <asset_string> <fruid_type> <fruid> <partnumrev> <vid> <eof_marker> <csum> } ]
[ psu_record_info_block { <record_type> <record_info> <record_len> <record_csum> <header_csum>
<record_identifier> <format_ver> <standby_pwr_budget> <psu_class> <psu_watts> } ] ]
```

### Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information            |
| sprom         | show SPROM contents                        |
| backplane     | show backplane clock module sprom contents |
| <i>i0</i>     | please enter instance of backplane sprom   |
| module        | show linecard module sprom contents        |
| <i>module</i> | please enter module number                 |
| <i>i1</i>     | please enter instance of module sprom      |



|                         |  |
|-------------------------|--|
| xbar                    | show xbar fabric sprom contents        |
| <i>santa-cruz-range</i> | please enter the xbar number           |
| <i>i2</i>               | please enter sprom instance number     |
| powersupply             | show powersupply sprom contents        |
| <i>i3</i>               | please enter powersupply number        |
| fan                     | show fan module sprom contents         |
| <i>i4</i>               | please enter fan number                |
| sup                     | show supervisor sprom contents         |
| stby-sup                | show standby supervisor sprom contents |
| all                     | show all sproms contents               |
| all2                    | All sprom contents                     |
| backplane2              | Backplane sprom contents               |
| module2                 | Linecard sprom contents                |
| <i>module2</i>          | Linecard module number                 |
| powersupply2            | Powersupply sprom contents             |
| <i>i5</i>               | Powersupply module number              |
| sup2                    | Supervisor sprom contents              |
| <i>__readonly__</i>     | (Optional)                             |
| <i>cmn_block</i>        | (Optional)                             |
| <i>blk_sig_cb</i>       | (Optional)                             |
| <i>blk_ver_cb</i>       | (Optional)                             |
| <i>blk_length_cb</i>    | (Optional)                             |
| <i>blk_checksum_cb</i>  | (Optional)                             |
| <i>eeeprom_size</i>     | (Optional)                             |
| <i>blk_count</i>        | (Optional)                             |
| <i>fru_major_type</i>   | (Optional)                             |
| <i>fru_minor_type</i>   | (Optional)                             |
| <i>oem_string</i>       | (Optional)                             |
| <i>prd_num</i>          | (Optional)                             |

|                            |            |
|----------------------------|------------|
| <i>serial_num</i>          | (Optional) |
| <i>part_num</i>            | (Optional) |
| <i>part_rev</i>            | (Optional) |
| <i>mfg_dev</i>             | (Optional) |
| <i>hw_rev</i>              | (Optional) |
| <i>mfg_bits</i>            | (Optional) |
| <i>eng_use</i>             | (Optional) |
| <i>snmp_oid</i>            | (Optional) |
| <i>power_consump</i>       | (Optional) |
| <i>rma_code</i>            | (Optional) |
| <i>clei_code</i>           | (Optional) |
| <i>vid</i>                 | (Optional) |
| <i>ch_specific_block</i>   | (Optional) |
| <i>blk_sig_csb</i>         | (Optional) |
| <i>blk_ver_csb</i>         | (Optional) |
| <i>blk_length_csb</i>      | (Optional) |
| <i>blk_checksum_csb</i>    | (Optional) |
| <i>feature_bits</i>        | (Optional) |
| <i>hw_changes_bits</i>     | (Optional) |
| <i>stackmib_oid</i>        | (Optional) |
| <i>mac_addresses</i>       | (Optional) |
| <i>no_of_macs</i>          | (Optional) |
| <i>oem_enterprise</i>      | (Optional) |
| <i>oem_mib_offset</i>      | (Optional) |
| <i>max_connector_power</i> | (Optional) |
| <i>sup_specific_block</i>  | (Optional) |
| <i>blk_sig_ssb</i>         | (Optional) |
| <i>blk_ver_ssb</i>         | (Optional) |
| <i>blk_length_ssb</i>      | (Optional) |

|                            |            |
|----------------------------|------------|
| <i>blk_checksum_ssb</i>    | (Optional) |
| <i>feature_bits</i>        | (Optional) |
| <i>hw_changes_bits</i>     | (Optional) |
| <i>card_index</i>          | (Optional) |
| <i>mac_addresses</i>       | (Optional) |
| <i>no_of_mac</i>           | (Optional) |
| <i>no_of_epld</i>          | (Optional) |
| TABLE_epld_ssb             | (Optional) |
| <i>epld_name_ssb</i>       | (Optional) |
| <i>epld_ver_ssb</i>        | (Optional) |
| <i>port_type_num</i>       | (Optional) |
| TABLE_sensor_ssb           | (Optional) |
| <i>sensor_num_ssb</i>      | (Optional) |
| <i>maj_thres_ssb</i>       | (Optional) |
| <i>min_thres_ssb</i>       | (Optional) |
| <i>max_connector_power</i> | (Optional) |
| <i>cooling_req</i>         | (Optional) |
| <i>amb_temp</i>            | (Optional) |
| lc_specific_block          | (Optional) |
| <i>blk_sig_lc</i>          | (Optional) |
| <i>blk_ver_lc</i>          | (Optional) |
| <i>blk_length_lc</i>       | (Optional) |
| <i>blk_checksum_lc</i>     | (Optional) |
| <i>feature_bits</i>        | (Optional) |
| <i>hw_changes_bits</i>     | (Optional) |
| <i>card_index</i>          | (Optional) |
| <i>mac_addresses</i>       | (Optional) |
| <i>no_of_mac</i>           | (Optional) |
| <i>no_of_epld</i>          | (Optional) |

|                            |            |
|----------------------------|------------|
| TABLE_epld_lc              | (Optional) |
| <i>epld_name_lc</i>        | (Optional) |
| <i>epld_ver_lc</i>         | (Optional) |
| <i>port_type_num</i>       | (Optional) |
| TABLE_sensor_lc            | (Optional) |
| <i>sensor_num_lc</i>       | (Optional) |
| <i>maj_thres_lc</i>        | (Optional) |
| <i>min_thres_lc</i>        | (Optional) |
| <i>max_connector_power</i> | (Optional) |
| <i>cooling_reqt</i>        | (Optional) |
| <i>amb_temp</i>            | (Optional) |
| ps_specific_block          | (Optional) |
| <i>blk_sig_psb</i>         | (Optional) |
| <i>blk_ver_psb</i>         | (Optional) |
| <i>blk_length_psb</i>      | (Optional) |
| <i>blk_checksum_psb</i>    | (Optional) |
| <i>feature_bits</i>        | (Optional) |
| <i>current_110v</i>        | (Optional) |
| <i>current_220v</i>        | (Optional) |
| <i>stackmib_oid</i>        | (Optional) |
| fan_specific_block         | (Optional) |
| <i>blk_sig_fsb</i>         | (Optional) |
| <i>blk_ver_fsb</i>         | (Optional) |
| <i>blk_length_fsb</i>      | (Optional) |
| <i>blk_checksum_fsb</i>    | (Optional) |
| <i>feature_bits</i>        | (Optional) |
| <i>hw_change_bits</i>      | (Optional) |
| <i>stackmib_oid</i>        | (Optional) |
| <i>cooling_capacity</i>    | (Optional) |

|                          |            |
|--------------------------|------------|
| <i>amb_temp</i>          | (Optional) |
| temp_sensor_block        | (Optional) |
| <i>blk_sig_tsb</i>       | (Optional) |
| <i>blk_ver_tsb</i>       | (Optional) |
| <i>blk_length_tsb</i>    | (Optional) |
| <i>blk_checksum_tsb</i>  | (Optional) |
| <i>no_of_sensors</i>     | (Optional) |
| TABLE_sensor_tsb         | (Optional) |
| <i>sensor_num_tsb</i>    | (Optional) |
| <i>maj_thres_tsb</i>     | (Optional) |
| <i>min_thres_tsb</i>     | (Optional) |
| wwn_specific_block       | (Optional) |
| <i>blk_sig_wwnb</i>      | (Optional) |
| <i>blk_ver_wwnb</i>      | (Optional) |
| <i>blk_length_wwnb</i>   | (Optional) |
| <i>blk_checksum_wwnb</i> | (Optional) |
| TABLE_wwn_usage_wsb      | (Optional) |
| <i>wwn_usage_bits</i>    | (Optional) |
| lic_specific_block       | (Optional) |
| <i>blk_sig_licb</i>      | (Optional) |
| <i>blk_ver_licb</i>      | (Optional) |
| <i>blk_length_licb</i>   | (Optional) |
| <i>blk_checksum_licb</i> | (Optional) |
| TABLE_lic_usage_lsb      | (Optional) |
| <i>lic_usage_bits</i>    | (Optional) |
| second_serial_block      | (Optional) |
| <i>blk_sig_sn2b</i>      | (Optional) |
| <i>blk_ver_sn2b</i>      | (Optional) |
| <i>blk_length_sn2b</i>   | (Optional) |

|                                |            |
|--------------------------------|------------|
| <i>blk_checksum_sn2b</i>       | (Optional) |
| <i>serial_num_sn2b</i>         | (Optional) |
| <i>psu_common_block</i>        | (Optional) |
| <i>format_version</i>          | (Optional) |
| <i>internal_info_offset</i>    | (Optional) |
| <i>chassis_info_offset</i>     | (Optional) |
| <i>board_info_offset</i>       | (Optional) |
| <i>product_info_offset</i>     | (Optional) |
| <i>multirecord_info_offset</i> | (Optional) |
| <i>checksum</i>                | (Optional) |
| <i>psu_board_info_block</i>    | (Optional) |
| <i>format_version</i>          | (Optional) |
| <i>length</i>                  | (Optional) |
| <i>language_code</i>           | (Optional) |
| <i>mfg_date</i>                | (Optional) |
| <i>mfg_type</i>                | (Optional) |
| <i>mfg_info</i>                | (Optional) |
| <i>name_type</i>               | (Optional) |
| <i>product_name</i>            | (Optional) |
| <i>snum_type</i>               | (Optional) |
| <i>snum</i>                    | (Optional) |
| <i>part_type</i>               | (Optional) |
| <i>partnum</i>                 | (Optional) |
| <i>fruid_type</i>              | (Optional) |
| <i>fruid</i>                   | (Optional) |
| <i>bom_hw_pid_info</i>         | (Optional) |
| <i>partnum_rev</i>             | (Optional) |
| <i>fab_revision</i>            | (Optional) |
| <i>vid</i>                     | (Optional) |

|                               |            |
|-------------------------------|------------|
| <i>clei_len</i>               | (Optional) |
| <i>clei</i>                   | (Optional) |
| <i>eof_marker</i>             | (Optional) |
| <i>csum</i>                   | (Optional) |
| <i>psu_product_info_block</i> | (Optional) |
| <i>format_version</i>         | (Optional) |
| <i>length</i>                 | (Optional) |
| <i>language_code</i>          | (Optional) |
| <i>mfg_type</i>               | (Optional) |
| <i>mfg_info</i>               | (Optional) |
| <i>name_type</i>              | (Optional) |
| <i>product_name</i>           | (Optional) |
| <i>part_type</i>              | (Optional) |
| <i>partnum</i>                | (Optional) |
| <i>product_ver_type</i>       | (Optional) |
| <i>sw_certification</i>       | (Optional) |
| <i>snum_type</i>              | (Optional) |
| <i>snum</i>                   | (Optional) |
| <i>asset_type</i>             | (Optional) |
| <i>asset_string</i>           | (Optional) |
| <i>fruid_type</i>             | (Optional) |
| <i>fruid</i>                  | (Optional) |
| <i>partnumrev</i>             | (Optional) |
| <i>vid</i>                    | (Optional) |
| <i>eof_marker</i>             | (Optional) |
| <i>csum</i>                   | (Optional) |
| <i>psu_record_info_block</i>  | (Optional) |
| <i>record_type</i>            | (Optional) |
| <i>record_info</i>            | (Optional) |

|                           |            |
|---------------------------|------------|
| <i>record_len</i>         | (Optional) |
| <i>record_csum</i>        | (Optional) |
| <i>header_csum</i>        | (Optional) |
| <i>record_identifier</i>  | (Optional) |
| <i>format_ver</i>         | (Optional) |
| <i>standby_pwr_budget</i> | (Optional) |
| <i>psu_class</i>          | (Optional) |
| <i>psu_watts</i>          | (Optional) |

**Command Mode**

- /exec



## show srte pce ipv4 peer

```
show srte pce ipv4 peer [ <pce_address> ] [ __readonly__ [ TABLE_peer <pce_address> <pcc_address>
<precedence> <state> ] ]
```

### Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information             |
| srte                | Show Segment-Routing Traffic Eng commands   |
| pce                 | Show PCC related information                |
| ipv4                | Show ipv4 pcc information                   |
| peer                | Show PCE peers                              |
| <i>pce_address</i>  | (Optional) PCE address of the peer          |
| <i>__readonly__</i> | (Optional)                                  |
| TABLE_peer          | (Optional) Table with a list of peers       |
| <i>pce_address</i>  | (Optional) Address of the PCE               |
| <i>pcc_address</i>  | (Optional) Address of the PCC               |
| <i>precedence</i>   | (Optional) Configured precedence of the PCE |
| <i>state</i>        | (Optional) State of the PCE connection      |

### Command Mode

- /exec

## show srte policy

```
show srte policy [ { <policy_name_val> } | { color <color_val> endpoint { <end_point_val> | <ipv6-addr>
} } | { policy-id <policy_id_val> } ] [ holddown ] [ detail ] [ __readonly__ [ TABLE_policy <policy_name>
[ <source> ] <end_point> <state> <col> { <binding_label> | <binding_sid> } <policy_id> [ <policy_owner>
] [ <flags> ] [ <holddown_time> ] [ TABLE_pref <pref> [ TABLE_paths { <exp_path_name> |
<deleg_pce_addr> } [ TABLE_index <index> [ { <label> | <sid> } ] ] [ <proactive_monitoring_session_id>
] [ <proactive_monitoring_session_state> ] ] ] ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information               |
| srte                   | Show Segment-Routing Traffic Eng commands     |
| policy                 | Show existing policies                        |
| color                  | (Optional) Show policies with the color       |
| endpoint               | (Optional) Show Policies with the destination |
| <i>end_point_val</i>   | (Optional) Endpoint for the policy            |
| <i>policy_name_val</i> | (Optional) Policy name of the policy          |
| <i>color_val</i>       | (Optional) Color of the policy                |
| <i>policy_id_val</i>   | (Optional) Policy_id of the policy            |
| policy-id              | (Optional) Show Policy for the policy-id      |
| holddown               | (Optional) Show Policies that are in holddown |
| detail                 | (Optional) Display detailed information       |
| __readonly__           | (Optional)                                    |
| TABLE_policy           | (Optional) Table with a list of policies      |
| <i>policy_name</i>     | (Optional) Unique name for the policy         |
| <i>end_point</i>       | (Optional) Endpoint for the policy            |
| <i>source</i>          | (Optional) Source address of the policy       |
| <i>state</i>           | (Optional) State of the policy                |
| <i>col</i>             | (Optional) Color of the policy                |
| <i>binding_label</i>   | (Optional) Binding label of the policy        |
| <i>binding_sid</i>     | (Optional) Binding sid of the policy          |
| <i>policy_id</i>       | (Optional) Policy ID                          |

|   |  |
|---|--|
| <i>policy_owner</i>                       | (Optional) Policy Owners                                     |
| <i>flags</i>                              | (Optional) Policy Flags                                      |
| <i>holddown_time</i>                      | (Optional) Time when the policy was put in holddown          |
| TABLE_pref                                | (Optional) Table with a list of candidate path based on pref |
| <i>pref</i>                               | (Optional) Preference for candidate paths                    |
| TABLE_paths                               | (Optional) Table with a list of exp path for pref            |
| <i>exp_path_name</i>                      | (Optional) Name of the explicit-path                         |
| <i>deleg_pce_addr</i>                     | (Optional) Delegated PCE Address                             |
| TABLE_index                               | (Optional) Table with a list of index for the exp path       |
| <i>index</i>                              | (Optional) Index for the explicit path                       |
| <i>label</i>                              | (Optional) Label for the explicit path                       |
| <i>proactive_monitoring_session_id</i>    | (Optional) Proactive monitoring session ID                   |
| <i>proactive_monitoring_session_state</i> | (Optional) Proactive monitoring session state                |

**Command Mode**

- /exec

# show srte policy fh

```
show srte policy fh [ __readonly__ [ TABLE_fh [ { <label> | <srv6sid> | <ipv4endpt> } <type> <state> ] [
TABLE_index [ <index> <ip_addr> <mask_len> ] ] ] ]
```

## Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information               |
| srte             | Show Segment-Routing Traffic Eng commands     |
| policy           | Show existing policies                        |
| fh               | Show existing policies firsthop state         |
| __readonly__     | (Optional)                                    |
| TABLE_fh         | (Optional) Table with a list of first hops    |
| <i>label</i>     | (Optional) First hop label                    |
| <i>srv6sid</i>   | (Optional) First hop SRv6 SID                 |
| <i>ipv4endpt</i> | (Optional) First hop IPv4 ENDPT               |
| <i>type</i>      | (Optional) First hop type                     |
| <i>state</i>     | (Optional) First hop state                    |
| TABLE_index      | (Optional) Table with index for the first hop |
| <i>index</i>     | (Optional) Index for the first hop            |
| <i>ip_addr</i>   | (Optional) Monitored address                  |
| <i>mask_len</i>  | (Optional) Mask length                        |

## Command Mode

- /exec



## show srte policy summary

```
show srte policy summary [ __readonly__ <total_policies> <adminup_policies> <admindown_policies>
<operup_policies> <operdown_policies> <total_candipath> <active_candipath> <inactive_candipath>
<total_fh> <label_fh> <ip_fh> <ipv6_fh> <label_fh_up> <label_fh_down> <ip_fh_up> <ip_fh_down>
<ipv6_fh_up> <ipv6_fh_down> ]
```

### Syntax Description

|                           |  |
|---------------------------|--|
| show                      | Show running system information                          |
| srte                      | Show Segment-Routing Traffic Eng commands                |
| policy                    | Show existing policies                                   |
| summary                   | Show policy summary info                                 |
| <i>__readonly__</i>       | (Optional)   |
| <i>total_policies</i>     | (Optional) Count of total srte policies                  |
| <i>adminup_policies</i>   | (Optional) Count of total admin up srte policies         |
| <i>admindown_policies</i> | (Optional) Count of total admin down srte policies       |
| <i>operup_policies</i>    | (Optional) Count of total operational up srte policies   |
| <i>operdown_policies</i>  | (Optional) Count of total operational dpwn srte policies |
| <i>total_candipath</i>    | (Optional) Count of total srte candidate paths           |
| <i>active_candipath</i>   | (Optional) Count of total active srte candidate paths    |
| <i>inactive_candipath</i> | (Optional) Count of total inactive srte candidate paths  |
| <i>total_fh</i>           | (Optional) Count of total srte first hops                |
| <i>label_fh</i>           | (Optional) Count of total srte label first hops          |
| <i>ip_fh</i>              | (Optional) Count of total srte ip first hop              |
| <i>ipv6_fh</i>            | (Optional) Count of total srte ipv6 first hop            |
| <i>label_fh_up</i>        | (Optional) Count of total up srte label first hops       |
| <i>label_fh_down</i>      | (Optional) Count of total down srte label first hops     |
| <i>ip_fh_up</i>           | (Optional) Count of total up srte ip first hop           |
| <i>ip_fh_down</i>         | (Optional) Count of total down srte ip first hop         |
| <i>ipv6_fh_up</i>         | (Optional) Count of total up srte ipv6 first hop         |
| <i>ipv6_fh_down</i>       | (Optional) Count of total down srte ipv6 first hop       |

### Command Mode

- /exec

## show srv6 clients

```
show srv6 clients [ __readonly__ TABLE_client <name> <id> <state> <createtime> <modifytime> <pid>
<epid> <notifysid> <mtsqh> <mtssap> [ TABLE_msgs_rcvd <Register> <State_Change> <SID_add>
<SID_del> ] [ TABLE_msgs_sent <Locator_add> <Locator_del> <Loc_Down_Pending> <Locator_Down>
<Sid_add_ack> <Sid_del_ack> <Sid_add> <Sid_del> <Encap_add> <Encap_del> ] ]
```

### Syntax Description

|                        |                                 |
|------------------------|---------------------------------|
| show                   | Show running system information |
| srv6                   | srv6                            |
| clients                | Sid Manager Client              |
| <i>__readonly__</i>    | (Optional)                      |
| <i>TABLE_client</i>    | (Optional) all clients          |
| <i>name</i>            | (Optional)                      |
| <i>id</i>              | (Optional)                      |
| <i>state</i>           | (Optional)                      |
| <i>createtime</i>      | (Optional)                      |
| <i>modifytime</i>      | (Optional)                      |
| <i>pid</i>             | (Optional)                      |
| <i>epid</i>            | (Optional)                      |
| <i>notifysid</i>       | (Optional)                      |
| <i>mtsqh</i>           | (Optional)                      |
| <i>mtssap</i>          | (Optional)                      |
| <i>TABLE_msgs_rcvd</i> | (Optional)                      |
| <i>Register</i>        | (Optional)                      |
| <i>State_Change</i>    | (Optional)                      |
| <i>SID_add</i>         | (Optional)                      |
| <i>SID_del</i>         | (Optional)                      |
| <i>TABLE_msgs_sent</i> | (Optional)                      |
| <i>Locator_add</i>     | (Optional)                      |
| <i>Locator_del</i>     | (Optional)                      |



|                         |            |
|-------------------------|------------|
| <i>Loc_Down_Pending</i> | (Optional) |
| <i>Locator_Down</i>     | (Optional) |
| <i>Sid_add_ack</i>      | (Optional) |
| <i>Sid_del_ack</i>      | (Optional) |
| <i>Sid_add</i>          | (Optional) |
| <i>Sid_del</i>          | (Optional) |
| <i>Encap_add</i>        | (Optional) |
| <i>Encap_del</i>        | (Optional) |

**Command Mode**

- /exec

# show srv6 locator

```
show srv6 locator [ detail ] [ __readonly__ [ TABLE_locator <locname> <locid> <locprefix> <locstate> [
sid-count ] [ loc-created ] [ loc-modified ] [ mod-reason ] ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| srv6                | srv6                            |
| locator             | Locator DB                      |
| detail              | (Optional) Locator details      |
| __readonly__        | (Optional)                      |
| TABLE_locator       | (Optional) all locators         |
| <i>locname</i>      | (Optional)                      |
| <i>locprefix</i>    | (Optional)                      |
| <i>locid</i>        | (Optional)                      |
| <i>locstate</i>     | (Optional)                      |
| <i>sid-count</i>    | (Optional)                      |
| <i>loc-created</i>  | (Optional)                      |
| <i>loc-modified</i> | (Optional)                      |
| <i>mod-reason</i>   | (Optional)                      |

## Command Mode

- /exec

# show srv6 manager

```
show srv6 manager [ __readonly__ { parameters <enabled> [ src_address <configured> ] } { summary
<nblocator> <nblocup> <nbsid> } { capabilities { { end-functions [ TABLE_endfunct <efunct-name> ] } {
transit-functions [ TABLE_tfunct <tfunct-name> ] } { security [ TABLE_secrule <sec-rule> ] } [ max-sid
<max-sid-count> ] [ sid-holdtime-sec <sid-hold> ] } } ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information          |
| srv6                 | srv6                                     |
| manager              | Manager                                  |
| __readonly__         | (Optional)                               |
| parameters           | (Optional) SRv6 parameters               |
| <i>enabled</i>       | (Optional) Operational status of SRv6    |
| src_address          | (Optional) Source address                |
| summary              | (Optional) SRv6 summary                  |
| <i>nblocator</i>     | (Optional) Number of locators            |
| <i>nblocup</i>       | (Optional) Number of locator in UP state |
| <i>nbsid</i>         | (Optional) Number of SID                 |
| capabilities         | (Optional) Platform capabilities         |
| end-functions        | (Optional) End functions                 |
| TABLE_endfunct       | (Optional) All end functions             |
| <i>efunct-name</i>   | (Optional)                               |
| transit-functions    | (Optional) Transit functions             |
| TABLE_tfunct         | (Optional) All transit function          |
| <i>tfunct-name</i>   | (Optional)                               |
| security             | (Optional) Security                      |
| TABLE_secrule        | (Optional) All security rules            |
| <i>sec-rule</i>      | (Optional)                               |
| max-sid              | (Optional) Maximum number of sid         |
| <i>max-sid-count</i> | (Optional)                               |

|                  |  |
|------------------|--|
| sid-holdtime-sec | (Optional) Time we wait before reusing a function id |
| <i>sid-hold</i>  | (Optional)   |

**Command Mode**

- /exec

# show srv6 sid

```
show srv6 sid [ <ipv6-addr> ] [ detail ] [ __readonly__ [ TABLE_loc <sidlocname> [ { TABLE_sid <sidaddr>
<sidfunc> <sidctx> <sidowner> <sidstate> <sidrewrite> [ det-ctx ] [ loc-name ] [ alloc-type ] [ sidmgr-addsidrte
] [ created ] [ modified ] } ] ] ]
```

## Syntax Description

|                         |                                 |
|-------------------------|---------------------------------|
| show                    | Show running system information |
| srv6                    | srv6                            |
| sid                     | SID DB                          |
| detail                  | (Optional) Print SID details    |
| __readonly__            | (Optional)                      |
| TABLE_loc               | (Optional) Locator              |
| <i>sidlocname</i>       | (Optional)                      |
| TABLE_sid               | (Optional) SID                  |
| <i>sidfunc</i>          | (Optional)                      |
| <i>sidctx</i>           | (Optional)                      |
| <i>sidowner</i>         | (Optional)                      |
| <i>sidstate</i>         | (Optional)                      |
| <i>sidrewrite</i>       | (Optional)                      |
| <i>det-ctx</i>          | (Optional)                      |
| <i>loc-name</i>         | (Optional)                      |
| <i>alloc-type</i>       | (Optional)                      |
| <i>sidmgr-addsidrte</i> | (Optional)                      |
| <i>created</i>          | (Optional)                      |
| <i>modified</i>         | (Optional)                      |

## Command Mode

- /exec

## show srv6 sid counters

```
show srv6 sid <ipv6-addr> counters [ __readonly__ <counter-sid> <counter-sid-type> <counter-rx-packets>
<counter-rx-bytes> <counter-tx-packets> <counter-tx-bytes> ]
```

### Syntax Description

|                           |                                 |
|---------------------------|---------------------------------|
| show                      | Show running system information |
| srv6                      | srv6                            |
| sid                       | SID DB                          |
| counters                  | Print SID counters              |
| <i>__readonly__</i>       | (Optional)                      |
| <i>counter-sid</i>        | (Optional)                      |
| <i>counter-sid-type</i>   | (Optional)                      |
| <i>counter-rx-packets</i> | (Optional)                      |
| <i>counter-rx-bytes</i>   | (Optional)                      |
| <i>counter-tx-packets</i> | (Optional)                      |
| <i>counter-tx-bytes</i>   | (Optional)                      |

### Command Mode

- /exec

# show ssh key

```
show ssh key [ { dsa [ md5 ] | rsa [ md5 ] | ecdsa [ [ md5 ] } ] [ __readonly__ { TABLE_sessions <key_type>
<key_time> <key_data> <key_bitcount> <key_fingerprint> } ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information           |
| ssh                    | Show SSH information                      |
| key                    | Show ssh keys                             |
| dsa                    | (Optional) Show dsa ssh keys              |
| rsa                    | (Optional) Show rsa ssh keys              |
| ecdsa                  | (Optional) Show ecdsa ssh keys            |
| md5                    | (Optional) Show Fingerprint in MD5 Format |
| __readonly__           | (Optional)                                |
| TABLE_sessions         | (Optional) ssh key                        |
| <i>key_type</i>        | (Optional) keys type                      |
| <i>key_time</i>        | (Optional) timestamp                      |
| <i>key_data</i>        | (Optional) ssh key data                   |
| <i>key_bitcount</i>    | (Optional) bitcount                       |
| <i>key_fingerprint</i> | (Optional) fingerprint                    |

## Command Mode

- /exec

# show ssh server

```
show ssh server [ __readonly__ { operation_status <o_status> } ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| ssh                     | Show SSH information                        |
| server                  | Show whether ssh server is enabled or not   |
| <i>__readonly__</i>     | (Optional)                                  |
| <i>operation_status</i> | (Optional) run-time information about ssh   |
| <i>o_status</i>         | (Optional) operational status of ssh server |

## Command Mode

- /exec



# show ssx details

```
show ssx details [ __readonly__ [ TABLE_ssx_details <system-id><arp-timer-running> [ TABLE_slot [ <slot> ] <asic-instance><asic-slice><io-srcid> [ <packets-sent> ] ] ] ]
```

## Syntax Description

|                   |                               |
|-------------------|-------------------------------|
| ssx               | Display SSX information       |
| details           | Show SSX details              |
| __readonly__      | (Optional) Read Only          |
| TABLE_ssx_details | (Optional) SSX details table  |
| TABLE_slot        | (Optional) Slot table for EOR |
| slot              | (Optional) Slot number        |

## Command Mode

- /exec

# show ssx exporter

```
show ssx exporter { all | <exportername> } [ __readonly__ [ TABLE_ssx_exporters <exporter-name> {
<src-ip><src-udp-port><dest-ip><dest-udp-port><vrf><mtu><dscp> | <dest-intf> } ] ]
```

## Syntax Description

|                     |                                |
|---------------------|--------------------------------|
| ssx                 | Display SSX information        |
| exporter            | Show exporter details          |
| all                 | All sessions                   |
| <i>exportername</i> | SSX Exporter to display        |
| <i>__readonly__</i> | (Optional) Read Only           |
| TABLE_ssx_exporters | (Optional) SSX Exporters table |

## Command Mode

- /exec

## show ssx monitor

```
show ssx monitor { all | <monitorname> } [ __readonly__ [ TABLE_ssx_monitors <monitor-name>
<globally-applied><status><exportername><recordname> ] ]
```

### Syntax Description

|                    |                               |
|--------------------|-------------------------------|
| ssx                | Display SSX information       |
| monitor            | Show monitor details          |
| all                | All sessions                  |
| <i>monitorname</i> | SSX Monitor to display        |
| __readonly__       | (Optional) Read Only          |
| TABLE_ssx_monitors | (Optional) SSX monitors table |

### Command Mode

- /exec

# show ssx record

```
show ssx record { all | <recordname> } [ __readonly__ [ TABLE_ssx_records <record-name> [
TABLE_stats_type <stats-type> ] <interval> ] ]
```

## Syntax Description

|                                |   |
|--------------------------------|---|
| <code>ssx</code>               | Display SSX information                 |
| <code>record</code>            | Show record details                     |
| <code>all</code>               | All sessions                            |
| <i>recordname</i>              | SSX Record to display                   |
| <code>__readonly__</code>      | (Optional) Read Only                    |
| <code>TABLE_ssx_records</code> | (Optional) SSX records table            |
| <code>TABLE_stats_type</code>  | (Optional) SSX records stats type table |
| <i>interval</i>                | (Optional) SSX interval                 |

## Command Mode

- /exec

# show startup-config

show startup-config

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Current startup configuration   |

## Command Mode

- /exec

# show startup-config aaa

show startup-config aaa

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| aaa            | Display aaa configuration       |

## Command Mode

- /exec

# show startup-config acllog

show startup-config acllog [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Displaying the startup configuration         |
| acllog         | show startup config for acllog               |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config aclmgr

show startup-config aclmgr [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Display the startup configuration            |
| aclmgr         | show startup config for aclmgr               |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec



# show startup-config adjmgr

show startup-config adjmgr [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| adjmgr         | Display adjmgr information                           |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config arp

show startup-config arp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| arp            | Display arp information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config assoc

show startup-config assoc [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Current saved configuration                  |
| assoc          | Original ID to Translated ID Association     |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config backup

show startup-config { backup | flexlink } [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| startup-config | System startup-config commands            |
| backup         | Show startup config for Switchport Backup |
| flexlink       | Show startup config for Switchport Backup |
| all            | (Optional) Show config with defaults      |

## Command Mode

- /exec

# show startup-config bfd

show startup-config bfd [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                      |
| startup-config | Display the startup configuration            |
| bfd            | show startup config for bfd                  |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config bgp

show startup-config bgp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| bgp            | Display bgp information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config bloggerd

show startup-config bloggerd [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | show startup-cfg                              |
| startup-config | show system startup configuration information |
| bloggerd       | Display bloggerd configuration                |
| all            | (Optional) show startup config with defaults  |

## Command Mode

- /exec

# show startup-config callhome

show startup-config callhome

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| callhome       | Display callhome configuration  |

## Command Mode

- /exec



# show startup-config cdp

show startup-config cdp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | show startup-cfg                              |
| startup-config | show system startup configuration information |
| cdp            | Display cdp configuration                     |
| all            | (Optional) show startup config with defaults  |

## Command Mode

- /exec

# show startup-config cert-enroll

show startup-config cert-enroll

## Syntax Description

|                |                                    |
|----------------|------------------------------------|
| show           | show startup-cfg                   |
| startup-config | show startup system information    |
| cert-enroll    | Display certificates configuration |

## Command Mode

- /exec

# show startup-config cfs

show startup-config cfs [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Current startup configuration                |
| cfs            | Display cfs configurations                   |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config config-profile

show startup-config config-profile [ <all\_conf\_profile\_name> ]

## Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show startup-config                      |
| startup-config               | Current startup configuration            |
| config-profile               | Display port-profile configuration       |
| <i>all_conf_profile_name</i> | (Optional) Enter the name of the profile |

## Command Mode

- /exec

# show startup-config copp

show startup-config copp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | System startup-config commands               |
| copp           | Control-Plane Policing                       |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config dhcp

show startup-config dhcp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Current startup configuration                |
| dhcp           | Display dhcp snoop configurations            |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config diagnostic

show startup-config diagnostic [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Contents of startup configuration               |
| diagnostic     | Diagnostic configuration                        |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show startup-config dot1x

show startup-config dot1x

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| dot1x          | Display dot1x configuration     |

## Command Mode

- /exec



# show startup-config ecp

show startup-config ecp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Current startup configuration                   |
| ecp            | ECP (Edge Control Protocol)                     |
| all            | (Optional) Display startup config with defaults |

## Command Mode

- /exec

# show startup-config eem

show startup-config eem

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Show the system startup configuration        |
| eem            | Show the event manager startup configuration |

## Command Mode

- /exec

# show startup-config eigrp

show startup-config eigrp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| eigrp          | Display eigrp information                            |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config eltm

show startup-config eltm

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Current startup configuration   |
| eltm           | Display eltm configurations     |

## Command Mode

- /exec

# show startup-config epbr

show startup-config epbr

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| epbr           | epbr                            |

## Command Mode

- /exec

# show startup-config evb

show startup-config evb [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Current startup configuration                   |
| evb            | EVB (Edge Virtual Bridge)                       |
| all            | (Optional) Display startup config with defaults |

## Command Mode

- /exec

# show startup-config exclude

show startup-config exclude <feature-list> +

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                     |
| startup-config      | Current startup configuration                       |
| exclude             | Exclude startup configuration of specified features |
| <i>feature-list</i> | Exclude features                                    |

## Command Mode

- /exec

# show startup-config expand-port-profile

show startup-config expand-port-profile

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| startup-config      | System startup-config commands  |
| expand-port-profile | Expand port profile             |

## Command Mode

- /exec



# show startup-config fabric forwarding

show startup-config fabric forwarding [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                         |
| startup-config | Current startup configuration                           |
| fabric         | Fabric  |
| forwarding     | Fabric Forwarding Protocol: Host Mobility Manager (HMM) |
| all            | (Optional) Display running config with defaults clis    |

## Command Mode

- /exec

# show startup-config fabric multicast

show startup-config fabric multicast [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| fabric         | Fabric   |
| multicast      | Multicast information                                |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config fabricpath

show startup-config fabricpath

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | System startup-config commands  |
| fabricpath     | fabricpath information          |

## Command Mode

- /exec

# show startup-config fabricpath domain default

show startup-config fabricpath domain default [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| fabricpath     | fabricpath information                               |
| domain         | Enter fabricpath IS-IS domain configuration mode     |
| default        | default fabricpath domain                            |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config fabricpath switch-id

show startup-config fabricpath switch-id

## Syntax Description

|                |                                    |
|----------------|------------------------------------|
| startup-config | Current startup configuration      |
| fabricpath     | fabricpath information             |
| switch-id      | fabricpath switch-id configuration |

## Command Mode

- /exec

# show startup-config fabricpath topology

show startup-config fabricpath topology [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| fabricpath     | fabricpath Module Information                        |
| topology       | Fabricpath topology Information                      |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config fcoe\_mgr

show startup-config fcoe\_mgr

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| fcoe_mgr       | Display fcoe_mgr configuration  |

## Command Mode

- /exec

# show startup-config fsync\_mgr

show startup-config fsync\_mgr [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | System startup-config commands               |
| fsync_mgr      | Frequency Synchronization Manager            |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec



# show startup-config glbp

show startup-config glbp

## Syntax Description

|                |                              |
|----------------|------------------------------|
| show           | Show system information      |
| startup-config | System startup configuration |
| glbp           | GLBP startup configuration   |

## Command Mode

- /exec

# show startup-config hardware-telemetry

show startup-config hardware-telemetry [ all ]

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show system information                      |
| startup-config     | Current startup configuration                |
| hardware-telemetry | show startup config for hardware-telemetry   |
| all                | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config hsrp

show startup-config hsrp

## Syntax Description

|                |                              |
|----------------|------------------------------|
| show           | Show system information      |
| startup-config | System startup configuration |
| hsrp           | HSRP startup configuration   |

## Command Mode

- /exec

# show startup-config icam

show startup-config icam

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| icam           | icam services                   |

## Command Mode

- /exec

# show startup-config icmpv6

show startup-config icmpv6 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| icmpv6         | Display icmpv6 information                           |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config igmp

show startup-config igmp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| igmp           | Display igmp information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config imp

show startup-config imp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                    |
| startup-config | Current startup configuration                      |
| imp            | Display imp information                            |
| all            | (Optional) Display start config with defaults clis |

## Command Mode

- /exec

# show startup-config interface

show startup-config interface [ <if0> ] [ expand-port-profile ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                            |
| startup-config      | Current startup configuration                              |
| interface           | Interface configuration                                    |
| <i>if0</i>          | (Optional) interface type and number in module/slot format |
| expand-port-profile | (Optional) Expand port profile                             |

## Command Mode

- /exec



# show startup-config interface

show startup-config interface <if0> [ membership ] [ expand-port-profile ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| startup-config      | Current startup configuration                   |
| interface           | Interface configuration                         |
| <i>if0</i>          | interface type and number in module/slot format |
| membership          | (Optional) Show membership information          |
| expand-port-profile | (Optional) Expand port profile                  |

## Command Mode

- /exec

# show startup-config ip

show startup-config ip [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| ip             | Display ip information                               |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config ipqos

show startup-config ipqos [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Display the startup configuration            |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config ipv6

show startup-config ipv6 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| ipv6           | Display ipv6 information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config isis

show startup-config isis [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| isis           | Display isis information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config l3vm

show startup-config l3vm [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Current startup configuration                   |
| l3vm           | Display l3vm information                        |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show startup-config ldap

show startup-config ldap

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| ldap           | Display ldap configuration      |

## Command Mode

- /exec

# show startup-config license

show startup-config license [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show startup-cfg                             |
| startup-config | show startup system information              |
| license        | Display licensing configuration              |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec



# show startup-config lisp

show startup-config lisp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| lisp           | Display lisp information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config lldp

show startup-config lldp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | show startup-cfg                              |
| startup-config | show system startup configuration information |
| lldp           | Display lldp configuration                    |
| all            | (Optional) show startup config with defaults  |

## Command Mode

- /exec

# show startup-config log

```
show startup-config { log | mdp-log } [ bootstrap ]
```

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                                     |
| startup-config | Current startup configuration                                       |
| mdp-log        | Displays execution log of last used mdp ascii startup configuration |
| log            | Displays execution log of last used ascii startup configuration     |
| bootstrap      | (Optional) Bootstrap config replay execution log                    |

## Command Mode

- /exec

# show startup-config macsec

show startup-config macsec

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | show startup system information |
| macsec         | Show CTS information            |

## Command Mode

- /exec

# show startup-config mfwd

```
show startup-config { mfwd | mcastfwd } [ all ]
```

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| mcastfwd       | Display MCASTFWD information                         |
| mfwd           | Display MFWD information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config mfwdv6

show startup-config { mfwdv6 | mcastfwdv6 } [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| mcastfwdv6     | Display IPV6 MCASTFWD information                    |
| mfwdv6         | Display IPV6 MFWD information                        |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config mld

show startup-config mld [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| mld            | Display MLD information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config mmode

show startup-config mmode [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                |
| startup-config | Show startup configuration                     |
| mmode          | Display maintenance mode startup configuration |
| all            | (Optional) Show startup config with defaults   |

## Command Mode

- /exec



# show startup-config monitor

show startup-config monitor

## Syntax Description

|                |                                  |
|----------------|----------------------------------|
| show           | Show running system information  |
| startup-config | Current startup configuration    |
| monitor        | Configure Ethernet SPAN sessions |

## Command Mode

- /exec

# show startup-config mpls static

show startup-config mpls static [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Current operating configuration                 |
| mpls           | Display MPLS status and configuration           |
| static         | Static Label Bindings                           |
| all            | (Optional) Display running-config with defaults |

## Command Mode

- /exec

# show startup-config mpls strip

show startup-config mpls strip [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                                 |
| mpls           | MPLS information  |
| strip          | Stripping of MPLS headers                                       |
| startup-config | System startup configuration                                    |
| all            | (Optional) Show startup configuration for STRIPCL with defaults |

## Command Mode

- /exec

# show startup-config msdp

show startup-config msdp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| msdp           | Display msdp information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config nat

show startup-config nat [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                      |
| startup-config | Display the startup configuration            |
| nat            | show startup config for nat                  |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config nbm

show startup-config nbm

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Current startup configuration   |
| nbm            | Non Blocking Multicast          |

## Command Mode

- /exec

# show startup-config ngoam

show startup-config ngoam

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Show startup system information |
| ngoam          | ngoam configuration             |

## Command Mode

- /exec

# show startup-config ntp

show startup-config ntp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show information                              |
| startup-config | Show startup system configuration             |
| ntp            | Show NTP information                          |
| all            | (Optional) Show all NTP startup configuration |

## Command Mode

- /exec



# show startup-config nv overlay

show startup-config nv overlay [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                  |
| startup-config | System startup configuration             |
| nv             | NVE startup configuration                |
| overlay        | NVE startup configuration                |
| all            | (Optional) Show NVE config with defaults |

## Command Mode

- /exec

# show startup-config nxsdk

show startup-config nxsdk [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Display the startup configuration               |
| nxsdk          | NXOS SDK  |
| all            | (Optional) Display running config with defaults |

## Command Mode

- /exec

# show startup-config ofm

show startup-config ofm [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show system information                           |
| startup-config | System startup configuration                      |
| ofm            | Overlay Flow/Policy Manager startup configuration |
| all            | (Optional) Show config with defaults              |

## Command Mode

- /exec

# show startup-config openflow

show startup-config openflow [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Current startup configuration                |
| openflow       | Show startup config for OpenFlow             |
| all            | (Optional) Show startup config with defaults |

## Command Mode

- /exec

# show startup-config ospf

show startup-config ospf [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| ospf           | Display ospf information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config ospfv3

show startup-config ospfv3 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| ospfv3         | Display ospfv3 information                           |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config otv-isis

show startup-config otv-isis [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| otv-isis       | Display otv-isis information                         |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config param-list

show startup-config param-list [ <plistname> ]

## Syntax Description

|                  |   |
|------------------|---|
| show             | Show startup-cfg                            |
| startup-config   | show startup configuration                  |
| param-list       | Display param-list configuration            |
| <i>plistname</i> | (Optional) Enter the name of the param list |

## Command Mode

- /exec



# show startup-config pim

show startup-config pim [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| pim            | Display pim information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config pim6

show startup-config pim6 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| pim6           | Display pim6 information                             |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config poe

show startup-config poe [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Current saved configuration                  |
| poe            | Power over Ethernet                          |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config port-profile

show startup-config port-profile [ <all\_profile\_name> ]

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show startup-config                      |
| startup-config          | Current startup configuration            |
| port-profile            | Display port-profile configuration       |
| <i>all_profile_name</i> | (Optional) Enter the name of the profile |

## Command Mode

- /exec

# show startup-config port-security

show startup-config port-security [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show startup-cfg                             |
| startup-config | show startup system information              |
| port-security  | Display port-security configuration          |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config ptp

show startup-config ptp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | show system information                                     |
| startup-config | show startup system information                             |
| ptp            | Show startup configuration for ptp                          |
| all            | (Optional) Show startup configuration for PTP with defaults |

## Command Mode

- /exec

# show startup-config radius

show startup-config radius

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| radius         | Display radius configuration    |

## Command Mode

- /exec

# show startup-config rip

show startup-config rip [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| rip            | Display rip information                              |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec



# show startup-config routing ip multicast

```
show startup-config routing { ip | ipv4 } multicast [ all ]
```

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| routing        | Display routing information                          |
| ip             | Display IP information                               |
| ipv4           | Display IP information                               |
| multicast      | Display multicast information                        |
| all            | (Optional) Display startup config with defaults clis |

## Command Mode

- /exec

# show startup-config routing ipv6 multicast

show startup-config routing ipv6 multicast [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| routing        | Display routing information                          |
| ipv6           | Display IPv6 information                             |
| multicast      | Display multicast information                        |
| all            | (Optional) Display startup config with defaults clis |

## Command Mode

- /exec

# show startup-config rpm

show startup-config rpm [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | Current startup configuration                   |
| rpm            | Display Route Policy Manager (RPM) information  |
| all            | (Optional) Display startup config with defaults |

## Command Mode

- /exec

# show startup-config scheduler

show startup-config scheduler [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | show startup-cfg                              |
| startup-config | show system startup configuration information |
| scheduler      | Show scheduler config or data                 |
| all            | (Optional) show startup config with defaults  |

## Command Mode

- /exec

# show startup-config security

show startup-config security

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| security       | Display security configuration  |

## Command Mode

- /exec

# show startup-config segment-routing

show startup-config segment-routing [ all ]

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information               |
| startup-config  | Show startup configuration                    |
| segment-routing | Display segment-routing startup configuration |
| all             | (Optional) Show startup config with defaults  |

## Command Mode

- /exec

# show startup-config services

show startup-config services

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |
| services       | services                        |

## Command Mode

- /exec

# show startup-config sflow

show startup-config { sflow } [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                      |
| startup-config | Current startup configuration                |
| sflow          | show startup config for sflow                |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec



# show startup-config sla responder

show startup-config sla responder

## Syntax Description

|                |                                      |
|----------------|--------------------------------------|
| show           | show startup-cfg                     |
| startup-config | show startup system information      |
| sla            | Service Level Agreement (SLA)        |
| responder      | Show information about sla-responder |

## Command Mode

- /exec

# show startup-config sla sender

show startup-config sla sender

## Syntax Description

|                |                                   |
|----------------|-----------------------------------|
| show           | show startup-cfg                  |
| startup-config | show startup system information   |
| sla            | Service Level Agreement (SLA)     |
| sender         | Show information about sla-sender |

## Command Mode

- /exec

# show startup-config sla twamp-server

show startup-config sla twamp-server

## Syntax Description

|                |                                     |
|----------------|-------------------------------------|
| show           | show startup-cfg                    |
| startup-config | show startup system information     |
| sla            | Service Level Agreement (SLA)       |
| twamp-server   | Show information about twamp-server |

## Command Mode

- /exec

# show startup-config snmp

show startup-config snmp [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show startup-cfg                             |
| startup-config | show startup system information              |
| snmp           | Display snmp configuration                   |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config srte

show startup-config srte

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Current operating configuration |
| srte           | SRTE                            |

## Command Mode

- /exec

# show startup-config switch

show startup-config { switch-profile | include-switch-profile }

## Syntax Description

|                        |   |
|------------------------|---|
| show                   | Show running system information               |
| startup-config         | System startup configuration                  |
| switch-profile         | Show switch-profile information               |
| include-switch-profile | Show startup and switch-profile configuration |

## Command Mode

- /exec

# show startup-config sync

show startup-config sync [ all ]

## Syntax Description

|                |  |
|----------------|--|
| startup-config | Current startup configuration                |
| sync           | show startup config for sync                 |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config tacacs

show startup-config tacacs +

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | show startup-cfg                |
| startup-config | show startup system information |

## Command Mode

- /exec



# show startup-config telemetry

show startup-config telemetry [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | show startup system configuration            |
| startup-config | show startup system information              |
| telemetry      | Display telemetry configuration              |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config track

show startup-config track

## Syntax Description

|                |                                       |
|----------------|---------------------------------------|
| show           | Show running system information       |
| startup-config | Show the system startup configuration |
| track          | Show the track startup configuration  |

## Command Mode

- /exec

# show startup-config tunnel-encryption

show startup-config tunnel-encryption

## Syntax Description

|                   |  |
|-------------------|--|
| show              | Show running system information                  |
| startup-config    | show startup system information                  |
| tunnel-encryption | Show information about Tunnel Encryption Manager |

## Command Mode

- /exec

# show startup-config udd

show startup-config udd

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Current startup configuration   |
| udd            | Show udd configuration          |

## Command Mode

- /exec

# show startup-config vdc-all

show startup-config vdc-all

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | Current startup configuration   |
| vdc-all        | Display config from all VDC     |

## Command Mode

- /exec

# show startup-config vdc

show startup-config vdc [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information              |
| startup-config | Current saved configuration                  |
| vdc            | Show Virtual Device Contexts                 |
| all            | (Optional) show startup config with defaults |

## Command Mode

- /exec

# show startup-config virtual-service

show startup-config virtual-service

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information                 |
| startup-config  | System startup-config commands                  |
| virtual-service | Show startup config for virtualization services |

## Command Mode

- /exec

# show startup-config vlan

show startup-config vlan

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| startup-config | System startup-config commands  |
| vlan           | Vlan commands                   |

## Command Mode

- /exec



# show startup-config vlan

show startup-config vlan <vlan-id>

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                 |
| startup-config | System startup-config commands                  |
| vlan           | Vlan commands                                   |
| <i>vlan-id</i> | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |

## Command Mode

- /exec

# show startup-config vmtracker

show startup-config vmtracker [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                        |
| startup-config | System startup configuration                   |
| vmtracker      | Show VMTracker configuration                   |
| all            | (Optional) Show VMTracker config with defaults |

## Command Mode

- /exec

# show startup-config vpc

show startup-config vpc [ all ]

## Syntax Description

|                |  |
|----------------|--|
| startup-config | Current startup configuration                |
| vpc            | show startup config for vPC                  |
| all            | (Optional) show running config with defaults |

## Command Mode

- /exec

# show startup-config vrf

show startup-config vrf <vrf-cfg-name> [ all ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                      |
| startup-config      | Current startup configuration                        |
| vrf                 | Display VRF information                              |
| <i>vrf-cfg-name</i> | Configurable VRF name                                |
| all                 | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config vrf default

show startup-config vrf default [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                      |
| startup-config | Current startup configuration                        |
| vrf            | Display VRF information                              |
| default        | Known VRF name                                       |
| all            | (Optional) Display running config with defaults clis |

## Command Mode

- /exec

# show startup-config vrrpv3

show startup-config vrrpv3 [ all ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show system information                                |
| startup-config | System startup configuration                           |
| vrrpv3         | VRRPv3 startup configuration                           |
| all            | (Optional) show startup config of VRRPv3 with defaults |

## Command Mode

- /exec

# show startup-config vshd

show startup-config vshd

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show startup system information |
| startup-config | Current startup configuration   |
| vshd           | Show startup config for vshd    |

## Command Mode

- /exec

# show startup-config vtp

show startup-config vtp [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information                             |
| startup-config | System startup-config commands                              |
| vtp            | Show startup configuration for VTP                          |
| all            | (Optional) Show startup configuration for VTP with defaults |

## Command Mode

- /exec



# show startup-config wwnm

show startup-config wwnm

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| startup-config | Current startup configuration             |
| wwnm           | Display WWN Manager startup configuration |

## Command Mode

- /exec

# show startup-config zone

show startup-config zone

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information           |
| startup-config | Current startup configuration             |
| zone           | Display zone server startup configuration |

## Command Mode

- /exec

# show startup-config zone vsan

show startup-config zone vsan <vsan-id>

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                    |
| startup-config | Current startup configuration                      |
| zone           | Display zone server startup configuration per vsan |
| vsan           | Vsan commands                                      |
| <i>vsan-id</i> | Vsan id  |

## Command Mode

- /exec

# show summary

```
show { ip mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] all | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 [ { unicast | multicast } ] ] } summary [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                                 |
| ip                    | Display IP information  |
| bgp                   | Display BGP status and configuration                            |
| mbgp                  | Display MBGP status and configuration                           |
| vrf                   | (Optional) Virtual Router Context                               |
| <i>vrf-name</i>       | (Optional) VRF name   |
| <i>vrf-known-name</i> | (Optional) Known VRF name                                       |
| summary               | Display summarized information of BGP state                     |
| ipv4                  | (Optional) Display BGP information for IPv4 address family      |
| unicast               | (Optional) Display BGP information for unicast address family   |
| multicast             | (Optional) Display BGP information for multicast address family |
| all                   | Display BGP information for all address families                |

## Command Mode

- /exec

# show switch-profile

```
show switch-profile [ __readonly__ <profile_name> <cfg_rev> ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| switch-profile      | Show switch-profiles            |
| <i>__readonly__</i> | (Optional)                      |
| <i>profile_name</i> | (Optional)                      |
| <i>cfg_rev</i>      | (Optional)                      |

## Command Mode

- /exec

# show switch-profile

```
show switch-profile [ <profile-name> ] { session-history | status commit } [ __readonly__ <prof-name>
TABLE_session <session_index> <start_usec> <start_time> <end_usec> <end_time> <revision_number>
<session_type> <session_subtype> <peer_triggered> [ <profile_status> ] [ <local_status> ] [ <local_error>
] [ <peer_address> ] [ <peer_sync_status> ] [ <merge_flags> ] [ <remote_status> ] [ <remote_error> ] ]
```

## Syntax Description

|                         |                                   |
|-------------------------|-----------------------------------|
| show                    | Show running system information   |
| switch-profile          | Show switch-profile               |
| session-history         | Switch-profile session-history    |
| <i>profile-name</i>     | (Optional) switch-profile name    |
| status                  | Switch-profile sync status        |
| commit                  | Switch-profile last commit status |
| <i>__readonly__</i>     | (Optional)                        |
| <i>prof-name</i>        | (Optional)                        |
| TABLE_session           | (Optional)                        |
| <i>session_index</i>    | (Optional)                        |
| <i>start_usec</i>       | (Optional)                        |
| <i>start_time</i>       | (Optional)                        |
| <i>end_usec</i>         | (Optional)                        |
| <i>end_time</i>         | (Optional)                        |
| <i>revision_number</i>  | (Optional)                        |
| <i>session_type</i>     | (Optional)                        |
| <i>session_subtype</i>  | (Optional)                        |
| <i>peer_triggered</i>   | (Optional)                        |
| <i>profile_status</i>   | (Optional)                        |
| <i>local_status</i>     | (Optional)                        |
| <i>local_error</i>      | (Optional)                        |
| <i>peer_address</i>     | (Optional)                        |
| <i>peer_sync_status</i> | (Optional)                        |

|                      |            |
|----------------------|------------|
| <i>merge_flags</i>   | (Optional) |
| <i>remote_status</i> | (Optional) |
| <i>remote_error</i>  | (Optional) |

**Command Mode**

- /exec

# show switch-profile buffer

```
show switch-profile [ <profile-name> ] buffer [ __readonly__ <prof-name> [ TABLE_commands <seq_no>
[ <cmd> ] + ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| switch-profile      | Show switch-profile             |
| buffer              | buffered commands               |
| <i>profile-name</i> | (Optional) switch-profile name  |
| <i>__readonly__</i> | (Optional)                      |
| <i>prof-name</i>    | (Optional)                      |
| TABLE_commands      | (Optional)                      |
| <i>seq_no</i>       | (Optional)                      |
| <i>cmd</i>          | (Optional)                      |

## Command Mode

- /exec



## show switch-profile peer

```
show switch-profile [ <profile-name> ] peer [ <dest-ip> ] [ details ] [ __readonly__ <prof-name> [ <rev> ] [ <peer_address> ] [ <peer_sync_status> ] [ <merge_flags> ] [ <remote_status> ] [ <remote_error> ] [ <cmd> ] + ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                  |
| switch-profile          | Show switch-profile                              |
| <i>profile-name</i>     | (Optional) switch-profile name                   |
| peer                    | peer info  |
| <i>dest-ip</i>          | (Optional) IPv4 address (A.B.C.D) of destination |
| details                 | (Optional) information in detail                 |
| <i>__readonly__</i>     | (Optional)                                       |
| <i>prof-name</i>        | (Optional)                                       |
| <i>rev</i>              | (Optional)                                       |
| <i>peer_address</i>     | (Optional)                                       |
| <i>peer_sync_status</i> | (Optional)                                       |
| <i>merge_flags</i>      | (Optional)                                       |
| <i>remote_status</i>    | (Optional)                                       |
| <i>remote_error</i>     | (Optional)                                       |
| <i>cmd</i>              | (Optional)                                       |

### Command Mode

- /exec

## show switch-profile status

```
show switch-profile [ <profile-name> ] status [ __readonly__ <prof-name> <start_usec> <start_time>
<end_usec> <end_time> <revision_number> <session_type> [ <session_subtype> ] <peer_triggered>
<profile_status> <local_status> <local_error> [ <peer_address> ] [ <peer_sync_status> ] [ <merge_flags> ]
[ <remote_status> ] [ <remote_error> ] ]
```

### Syntax Description

|                         |                                 |
|-------------------------|---------------------------------|
| show                    | Show running system information |
| switch-profile          | Show switch-profile             |
| status                  | Switch-profile sync status      |
| <i>profile-name</i>     | (Optional) switch-profile name  |
| <i>__readonly__</i>     | (Optional)                      |
| <i>prof-name</i>        | (Optional)                      |
| <i>start_usec</i>       | (Optional)                      |
| <i>start_time</i>       | (Optional)                      |
| <i>end_usec</i>         | (Optional)                      |
| <i>end_time</i>         | (Optional)                      |
| <i>revision_number</i>  | (Optional)                      |
| <i>session_type</i>     | (Optional)                      |
| <i>session_subtype</i>  | (Optional)                      |
| <i>peer_triggered</i>   | (Optional)                      |
| <i>profile_status</i>   | (Optional)                      |
| <i>local_status</i>     | (Optional)                      |
| <i>local_error</i>      | (Optional)                      |
| <i>peer_address</i>     | (Optional)                      |
| <i>peer_sync_status</i> | (Optional)                      |
| <i>merge_flags</i>      | (Optional)                      |
| <i>remote_status</i>    | (Optional)                      |
| <i>remote_error</i>     | (Optional)                      |

### Command Mode

- /exec

# show switching-mode

```
show switching-mode [ __readonly__ { <switching-mode> } { TABLE_swtpmoduinfo <moduleno> <opmode> } ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| switching-mode        | Show the operating switching mode               |
| __readonly__          | (Optional)                                      |
| <i>switching-mode</i> | (Optional) switching mode description           |
| TABLE_swtpmoduinfo    | (Optional) the xml switching module information |
| <i>moduleno</i>       | (Optional) Module Number                        |
| <i>opmode</i>         | (Optional) Operation Mode                       |

## Command Mode

- /exec

# show switching-mode fabric-speed

```
show switching-mode fabric-speed [ __readonly__ TABLE_switching_mode_fabric_speed <fabric-speed-desc> ]
```

## Syntax Description

|                                   |  |
|-----------------------------------|--|
| show                              | Show running system information                              |
| switching-mode                    | Show the operating switching mode                            |
| fabric-speed                      | Show the fabric speed  |
| __readonly__                      | (Optional)   |
| TABLE_switching_mode_fabric_speed | (Optional) the xml switching_mode_fabric_speed configuration |
| <i>fabric-speed-desc</i>          | (Optional) fabric speed description                          |

## Command Mode

- /exec

# show system acl

```
show system acl [ __readonly__ TABLE_system_acl <protocol> [ TABLE_type <type> <acl_name> <inout> ] ]
```

## Syntax Description

|                  |                                 |
|------------------|---------------------------------|
| show             | Show running system information |
| system           | System management commands      |
| acl              | ACL parameters                  |
| __readonly__     | (Optional)                      |
| TABLE_system_acl | (Optional)                      |
| <i>protocol</i>  | (Optional) protocol             |
| TABLE_type       | (Optional)                      |
| <i>type</i>      | (Optional) type                 |
| <i>acl_name</i>  | (Optional)                      |
| <i>inout</i>     | (Optional) Traffic direction    |

## Command Mode

- /exec

# show system auto-collect tech-support

show system auto-collect tech-support [ *\_\_readonly\_\_* <result> ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                                  |
| system              | System management commands                                       |
| auto-collect        | Auto collection of information                                   |
| tech-support        | Collect tech-support in case of service causing supervisor reset |
| <i>__readonly__</i> | (Optional)   |
| <i>result</i>       | (Optional) show tech collection enable status                    |

## Command Mode

- /exec

# show system boottime

```
show system boottime [ __readonly__ { TABLE_uptimeinf <slot> <starttime> <daysup> <hoursup>
<minutesup> <secondsup> } ]
```

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information        |
| system          | System-related show commands           |
| boottime        | Show platform boot time of each module |
| __readonly__    | (Optional)                             |
| TABLE_uptimeinf | (Optional) Show uptime info            |
| slot            | (Optional) Slot                        |
| starttime       | (Optional) Start Time                  |
| daysup          | (Optional) Days Up                     |
| hoursup         | (Optional) Hours Up                    |
| minutesup       | (Optional) Minutes Up                  |
| secondsup       | (Optional) Seconds Up                  |

## Command Mode

- /exec



# show system config reload-pending

```
show system config reload-pending [ __readonly__ { TABLE_reload_pending <cmds_list> } ]
```

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information         |
| system               | System-related show commands            |
| config               | Config commands which require reload    |
| reload-pending       | Commands which require a reload         |
| __readonly__         | (Optional)                              |
| TABLE_reload_pending | (Optional) reload pending commands list |
| cmds_list            | (Optional) cmds_list                    |

## Command Mode

- /exec

# show system cores

show system cores [ \_\_readonly\_\_ { <content> } ]

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| system         | System-related show commands    |
| cores          | Displays core transfer option   |
| __readonly__   | (Optional)                      |
| <i>content</i> | (Optional) Core transfer option |

## Command Mode

- /exec

# show system default switchport

```
show system default switchport [ __readonly__ <sys_def_port_state> <sys_def_trunk_mode>
<sys_def_link_fail_syslog_level> <sys_def_tx_credit_queue_type> ]
```

## Syntax Description

|                                       |   |
|---------------------------------------|---|
| show                                  | Show running system information                             |
| <i>__readonly__</i>                   | (Optional) read only  |
| <i>sys_def_port_state</i>             | (Optional) System default port state                        |
| <i>sys_def_trunk_mode</i>             | (Optional) System default trunk mode                        |
| <i>sys_def_link_fail_syslog_level</i> | (Optional) System default link failure syslog logging level |
| <i>sys_def_tx_credit_queue_type</i>   | (Optional) System default tx credit queue type              |
| system                                | System-related show commands                                |
| default                               | Show system default values                                  |
| switchport                            | Show default values for switchport attributes               |

## Command Mode

- /exec

# show system default zone

show system default zone

## Syntax Description

|         |                                 |
|---------|---------------------------------|
| show    | Show running system information |
| system  | System-related show commands    |
| default | Show system default values      |
| zone    | Show default values for zone    |

## Command Mode

- /exec

# show system error-id

```
show system error-id { list | <i0> } [ __readonly__ <errorid> <facility> <desc> ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| system              | System-related show commands          |
| error-id            | Show description about errors         |
| list                | Show description about all error IDs  |
| <i>i0</i>           | Show description about specific error |
| <i>__readonly__</i> | (Optional)                            |
| <i>errorid</i>      | (Optional)                            |
| <i>facility</i>     | (Optional)                            |
| <i>desc</i>         | (Optional)                            |

## Command Mode

- /exec

## show system exception-info

```
show system exception-info [ __readonly__ { TABLE_exception { <second> <panic_data> <register_data>
<stack_pointer> <stack_depth> <stack_timestamp> <stacl_magic> <hdr_length> <stack_data> <pre_usec>
<pre_sec> <int_t> <reason> <service> <version> } } ]
```

### Syntax Description

|                        |                                     |
|------------------------|-------------------------------------|
| show                   | Show running system information     |
| system                 | System-related show commands        |
| exception-info         | Show last exception log information |
| __readonly__           | (Optional)                          |
| TABLE_exception        | (Optional)                          |
| <i>second</i>          | (Optional) Time of exception        |
| <i>panic_data</i>      | (Optional) Panic information dump   |
| <i>register_data</i>   | (Optional) CPU register dump        |
| <i>stack_pointer</i>   | (Optional) Current Stack-pointer    |
| <i>stack_depth</i>     | (Optional) Current Stack-depth      |
| <i>stack_timestamp</i> | (Optional) Stack dump timestamp     |
| <i>stacl_magic</i>     | (Optional) Stack Magic              |
| <i>hdr_length</i>      | (Optional) Hdr length               |
| <i>stack_data</i>      | (Optional) Stack Dump               |
| <i>pre_usec</i>        | (Optional)                          |
| <i>pre_sec</i>         | (Optional)                          |
| <i>int_t</i>           | (Optional)                          |
| <i>reason</i>          | (Optional) Reason                   |
| <i>service</i>         | (Optional) Service                  |
| <i>version</i>         | (Optional) Version                  |

### Command Mode

- /exec

# show system fabric-mode

show system fabric-mode [ \_\_readonly\_\_ TABLE\_system\_fabric\_mode <system-fabric-mode-desc> ]

## Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                     |
| system                         | Show system information                             |
| fabric-mode                    | Show the fabric operation mode information          |
| __readonly__                   | (Optional)  |
| TABLE_system_fabric_mode       | (Optional) the xml system_fabric_mode configuration |
| <i>system-fabric-mode-desc</i> | (Optional) system fabric mode description           |

## Command Mode

- /exec

# show system fast-reload stabilization-timer

show system fast-reload stabilization-timer [ *\_\_readonly\_\_* { *<timer\_val>* } ]

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information  |
| system              | System management commands   |
| fast-reload         | fast-reload software   |
| stabilization-timer | Network stabilization time in seconds before fast-reload can be executed after the previous reload |
| <i>__readonly__</i> | (Optional) Read Only   |
| <i>timer_val</i>    | (Optional) XML attribute for timer value   |

## Command Mode

- /exec



# show system image-verification

```
show system image-verification [ __readonly__ { [ TABLE_system_image_verification <Str1> ] } ]
```

## Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information         |
| system                          | Show system information                 |
| image-verification              | image signature verification status     |
| __readonly__                    | (Optional)                              |
| TABLE_system_image_verification | (Optional) table for image verification |
| <i>Str1</i>                     | (Optional) status of image verification |

## Command Mode

- /exec

# show system inband cpu-mac log threshold

```
show system inband cpu-mac log threshold [ __readonly__ { <rx_threshold> } { <tx_threshold> } { <throttle> } ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information           |
| system              | System-related show commands              |
| inband              | Show Inband related information           |
| cpu-mac             | Show CPU-MACs related information         |
| log                 | Show log information                      |
| threshold           | Show inband threshold                     |
| <i>__readonly__</i> | (Optional)                                |
| <i>rx_threshold</i> | (Optional) Registered RX PPS Threshold    |
| <i>tx_threshold</i> | (Optional) Registered TX PPS Threshold    |
| <i>throttle</i>     | (Optional) Registered Throttle in seconds |

## Command Mode

- /exec

## show system inband queuing statistics

```
show system inband queuing statistics [ __readonly__ { TABLE_sys_inband_queue_stats <inbandpktunmap>
<inbandpktbpdqueue> <inbandpktmapq0> <inbandpktmapq1> <klmpktmapbpdu> <klmpktmaparp>
<klmpktmapq0> <klmpktmapq1> <klmpktmapveobc> <queuename> [ TABLE_bpdu_stats { <pmrcvpkts>
<pmdroppkts> <pmcongested> <rcvbuf> <sndbuf> <pmnodrop> } ] [ TABLE_q_stats { <indexstat>
<ipmrcvpkts> <ipmdroppkts> <ipmcongested> <ircvbuf> <isndbuf> <ipmnodrop> } ] ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information           |
| system                       | System-related show commands              |
| inband                       | Inband Commands                           |
| queuing                      | Inband Queuing commands                   |
| statistics                   | Inband statistics                         |
| <i>__readonly__</i>          | (Optional)                                |
| TABLE_sys_inband_queue_stats | (Optional) System Inband Statistics       |
| <i>inbandpktunmap</i>        | (Optional) Inband packets unmapped        |
| <i>inbandpktbpdqueue</i>     | (Optional) Inband packets mapped to bpdu  |
| <i>inbandpktmapq0</i>        | (Optional) Inband packets mapped to q0    |
| <i>inbandpktmapq1</i>        | (Optional) Inband packets mapped to q1    |
| <i>klmpktmapbpdu</i>         | (Optional) In KLM packets mapped to bpdu  |
| <i>klmpktmaparp</i>          | (Optional) In KLM packets mapped to arp   |
| <i>klmpktmapq0</i>           | (Optional) In KLM packets mapped to q0    |
| <i>klmpktmapq1</i>           | (Optional) In KLM packets mapped to q1    |
| <i>klmpktmapveobc</i>        | (Optional) In KLM packets mapped to veobc |
| <i>queuename</i>             | (Optional) Inband queue name              |
| TABLE_bpdu_stats             | (Optional) BPDU Statistics                |
| <i>pmrcvpkts</i>             | (Optional) BPDU Receive Packets           |
| <i>pmdroppkts</i>            | (Optional) BPDU Drop Packets              |
| <i>pmcongested</i>           | (Optional) BPDU Congested                 |
| <i>rcvbuf</i>                | (Optional) BPDU Receive Buffer            |
| <i>sndbuf</i>                | (Optional) BPDU Send Buffer               |

|                      |                                  |
|----------------------|----------------------------------|
| <i>pmnoproduct</i>   | (Optional) BPDU No drop          |
| TABLE_q_stats        | (Optional) Queue Statistics      |
| <i>indexstat</i>     | (Optional) Queue Index           |
| <i>ipmrecvpkts</i>   | (Optional) Queue receive packets |
| <i>ipmdroppkts</i>   | (Optional) Queue drop packets    |
| <i>ipmcongested</i>  | (Optional) Queue Congested       |
| <i>ircvbuf</i>       | (Optional) Queue receive buffer  |
| <i>isndbuf</i>       | (Optional) Queue send buffer     |
| <i>ipmnooproduct</i> | (Optional) Queue no drop         |

**Command Mode**

- /exec

## show system inband queuing status

```
show system inband queuing status [ __readonly__ [ { TABLE_sys_inband_queue_status <pminbandalgo>
<pminbandweigh0> <pminbandweigh1> <pminbandweigh2> } ] ]
```

### Syntax Description

|                                      |                                      |
|--------------------------------------|--------------------------------------|
| show                                 | Show running system information      |
| system                               | System-related show commands         |
| inband                               | Inband Commands                      |
| queuing                              | Inband Queuing commands              |
| status                               | Selective Packet Discard Information |
| <i>__readonly__</i>                  | (Optional)                           |
| <i>TABLE_sys_inband_queue_status</i> | (Optional) System Inband Status      |
| <i>pminbandalgo</i>                  | (Optional) Queuing Algorithm         |
| <i>pminbandweigh0</i>                | (Optional) BPDU Weight               |
| <i>pminbandweigh1</i>                | (Optional) Q0 Weight                 |
| <i>pminbandweigh2</i>                | (Optional) Q1 Weight                 |

### Command Mode

- /exec

# show system login

```
show system login [ __readonly__ [ [ <acc_list> ] [ <attempts> ] ] [ <within> <block_for> <time> ] [ <fail_count> ] [ <switch_mode> ] ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                 |
| system              | System-related show commands                    |
| login               | Display Secure Login Configurations and State   |
| <i>__readonly__</i> | (Optional)                                      |
| <i>acc_list</i>     | (Optional) Appiled ACL's                        |
| <i>attempts</i>     | (Optional) Number of login failures             |
| <i>within</i>       | (Optional) Number of login failures within time |
| <i>block_for</i>    | (Optional) Login disabled for time              |
| <i>time</i>         | (Optional) Time remaining to re-enable login    |
| <i>fail_count</i>   | (Optional) Login failure count                  |
| <i>switch_mode</i>  | (Optional) Mode of operation                    |

## Command Mode

- /exec

# show system login failures

```
show system login failures [ __readonly__ [ { TABLE_loginStats <username> <port> <remote_addr>
<app_name> <time> } ] ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                    |
| system                  | System-related show commands                       |
| login                   | Secure Login                                       |
| failures                | Display Login failures in the current watch period |
| <i>__readonly__</i>     | (Optional)   |
| <i>TABLE_loginStats</i> | (Optional)   |
| <i>username</i>         | (Optional) User name                               |
| <i>port</i>             | (Optional) Login port number                       |
| <i>remote_addr</i>      | (Optional) Remote address                          |
| <i>app_name</i>         | (Optional) Application name                        |
| <i>time</i>             | (Optional) Login time                              |

## Command Mode

- /exec

## show system memory-thresholds

```
show system memory-thresholds [ __readonly__ <critical_mem_threshold> <severe_mem_threshold>
<minor_mem_threshold> ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information             |
| <i>__readonly__</i>           | (Optional)                                  |
| <i>critical_mem_threshold</i> | (Optional) Critical System Memory Threshold |
| <i>severe_mem_threshold</i>   | (Optional) Severe System Memory Threshold   |
| <i>minor_mem_threshold</i>    | (Optional) Minor System Memory Threshold    |
| system                        | System management commands                  |
| memory-thresholds             | Set memory thresholds on the card           |

### Command Mode

- /exec



# show system mode

```
show system mode [ __readonly__ <system_mode> [ <timer_state> ] ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| system              | System configuration commands   |
| mode                | Show system mode                |
| <i>__readonly__</i> | (Optional)                      |
| <i>system_mode</i>  | (Optional) system mode          |
| <i>timer_state</i>  | (Optional) timer state          |

## Command Mode

- /exec

# show system nve infra-vlans

```
show system nve infra-vlans [ __readonly__ [ current_active_vlan <active_vlan_output> ] { available_infra_vlan
<available_vlan_output> } ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information             |
| system                       | System-related show commands                |
| nve                          | Show NVE information                        |
| infra-vlans                  | Show NVE infra-vlans related information    |
| __readonly__                 | (Optional)                                  |
| current_active_vlan          | (Optional) Current Active Infra Vlan        |
| <i>active_vlan_output</i>    | (Optional) Current active infra vlan output |
| available_infra_vlan         | (Optional) Available Infra Vlan             |
| <i>available_vlan_output</i> | (Optional) Available Infra Vlan output      |

## Command Mode

- /exec

# show system poap

```
show system poap [ __readonly__ { [ TABLE_show_system_poap <Str1> ] } ]
```

## Syntax Description

|                        |                                  |
|------------------------|----------------------------------|
| show                   | Show running system information  |
| system                 | Show system information          |
| poap                   | Show information related to POAP |
| __readonly__           | (Optional)                       |
| TABLE_show_system_poap | (Optional) table for poap        |
| <i>Str1</i>            | (Optional) status of poap        |

## Command Mode

- /exec

## show system pss shrink status

```
show system pss shrink status [ details ] [ __readonly__ { [ <summary> ] [ TABLE_per_vdc <vdc_id> [
TABLE_detail_events <service> <vdc> <event> ] ] [ TABLE_events <service> <vdc> <event> ] } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                    |
| system              | System-related show commands                       |
| pss                 | Displays last pss shrink status                    |
| shrink              | Displays last pss shrink status                    |
| status              | Displays last pss shrink status                    |
| details             | (Optional) Displays last pss shrink status details |
| __readonly__        | (Optional)   |
| <i>summary</i>      | (Optional) PSS shrink summary                      |
| TABLE_per_vdc       | (Optional)   |
| <i>vdc_id</i>       | (Optional) VDC id                                  |
| TABLE_detail_events | (Optional) PSS shrink events                       |
| <i>service</i>      | (Optional) Service name                            |
| <i>vdc</i>          | (Optional) VDC number                              |
| <i>event</i>        | (Optional) PSS evnets                              |
| TABLE_events        | (Optional) PSS shrink events                       |
| <i>service</i>      | (Optional) Service name                            |
| <i>vdc</i>          | (Optional) VDC number                              |
| <i>event</i>        | (Optional) PSS evnets                              |

### Command Mode

- /exec

## show system redundancy ha status

```
show system redundancy ha status [ __readonly__ { [ TABLE_ha_status <vdc_id> <this_sup_internal_state>
<other_sup_internal_state> ] } ]
```

### Syntax Description

|                                 |                                    |
|---------------------------------|------------------------------------|
| show                            | Show running system information    |
| system                          | System-related show commands       |
| redundancy                      | redundancy status                  |
| ha                              | vdc redundancy status              |
| status                          | all vdc redundancy status          |
| <i>__readonly__</i>             | (Optional)                         |
| <i>TABLE_ha_status</i>          | (Optional) HA status for all vdcs  |
| <i>vdc_id</i>                   | (Optional) vdc id                  |
| <i>this_sup_internal_state</i>  | (Optional) This Supervisor State   |
| <i>other_sup_internal_state</i> | (Optional) Remote Supervisor State |

### Command Mode

- /exec

## show system redundancy status

```
show system redundancy status [ __readonly__ { <rdn_mode_admin> <rdn_mode_oper> <this_sup>
<this_sup_rdn_state> <this_sup_sup_state> <this_sup_internal_state> [ <other_sup> ] [ <other_sup_rdn_state>
] [ <other_sup_sup_state> ] [ <other_sup_internal_state> } } ]
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information        |
| system                          | System-related show commands           |
| redundancy                      | redundancy status                      |
| status                          | Current redundancy status              |
| <i>__readonly__</i>             | (Optional) readonly                    |
| <i>rdn_mode_admin</i>           | (Optional) Redundancy Mode Admin       |
| <i>rdn_mode_oper</i>            | (Optional) Redundancy Mode Operational |
| <i>this_sup</i>                 | (Optional) This Supervisor             |
| <i>this_sup_rdn_state</i>       | (Optional) Redundancy State            |
| <i>this_sup_sup_state</i>       | (Optional) Supervisor State            |
| <i>this_sup_internal_state</i>  | (Optional) Supervisor State            |
| <i>other_sup</i>                | (Optional) Other Supervisor            |
| <i>other_sup_sup_state</i>      | (Optional) Supervisor State            |
| <i>other_sup_rdn_state</i>      | (Optional) Redundancy tate             |
| <i>other_sup_internal_state</i> | (Optional) Supervisor State            |

### Command Mode

- /exec

# show system reset-reason

```
show system reset-reason <s0> <santa-cruz-range> [ __readonly__ { TABLE_xbarreason <slot> { TABLE_rr
<time> <reason> <service> <version> } } ]
```

## Syntax Description

|                         |                                     |
|-------------------------|-------------------------------------|
| show                    | Show running system information     |
| system                  | System-related show commands        |
| reset-reason            | Show last reset reason              |
| <i>s0</i>               | Show xbar module reset reason       |
| <i>santa-cruz-range</i> | please enter the xbar module number |
| <i>__readonly__</i>     | (Optional)                          |
| TABLE_xbarreason        | (Optional) Reset reason info        |
| <i>slot</i>             | (Optional) slot                     |
| TABLE_rr                | (Optional) reset reason             |
| <i>time</i>             | (Optional) time                     |
| <i>reason</i>           | (Optional) reset reason             |
| <i>service</i>          | (Optional) service name             |
| <i>version</i>          | (Optional) version                  |

## Command Mode

- /exec

# show system reset-reason

```
show system reset-reason [ __readonly__ { TABLE_reason <slot> { TABLE_rr <time> <reason> <service>
<version> } } ]
```

## Syntax Description

|                |                                 |
|----------------|---------------------------------|
| show           | Show running system information |
| system         | System-related show commands    |
| reset-reason   | Show last reset reason          |
| __readonly__   | (Optional)                      |
| TABLE_reason   | (Optional) Reset reason info    |
| <i>slot</i>    | (Optional) slot                 |
| TABLE_rr       | (Optional) reset reason         |
| <i>time</i>    | (Optional) time                 |
| <i>reason</i>  | (Optional) reset reason         |
| <i>service</i> | (Optional) service name         |
| <i>version</i> | (Optional) version              |

## Command Mode

- /exec



# show system reset-reason module

```
show system reset-reason module <module> [ __readonly__ { TABLE_reason <slot> { TABLE_rr <time>
<reason> <service> <version> } } ]
```

## Syntax Description

|                     |                                   |
|---------------------|-----------------------------------|
| show                | Show running system information   |
| system              | System-related show commands      |
| reset-reason        | Show last reset reason            |
| module              | Show per module reset-reason code |
| <i>module</i>       | please enter module number        |
| <i>__readonly__</i> | (Optional)                        |
| TABLE_reason        | (Optional) Reset reason info      |
| <i>slot</i>         | (Optional) slot                   |
| TABLE_rr            | (Optional) reset reason           |
| <i>time</i>         | (Optional) time                   |
| <i>reason</i>       | (Optional) reset reason           |
| <i>service</i>      | (Optional) service name           |
| <i>version</i>      | (Optional) version                |

## Command Mode

- /exec

## show system resources

```
show system resources [ __readonly__ { [ <load_avg_1min> ] [ <load_avg_5min> ] [ <load_avg_15min> ]
[ <processes_total> ] [ <processes_running> ] [ <cpu_state_user> ] [ <cpu_state_kernel> ] [ <cpu_state_idle>
] [ TABLE_cpu_usage <cpuid> <user> <kernel> <idle> ] [ <memory_usage_total> ] [ <memory_usage_used>
] [ <memory_usage_free> ] [ <vm_total> ] [ <vm_free> ] [ <mem_buffers> ] [ <mem_cached> ] [
<current_memory_status> ] }
```

### Syntax Description

|                           |                                      |
|---------------------------|--------------------------------------|
| <i>show</i>               | Show running system information      |
| <i>system</i>             | System-related show commands         |
| <i>resources</i>          | Show system resources                |
| <i>__readonly__</i>       | (Optional)                           |
| <i>TABLE_cpu_usage</i>    | (Optional) All Cpu Usage Information |
| <i>load_avg_1min</i>      | (Optional) Load Average 1 Min        |
| <i>load_avg_5min</i>      | (Optional) Load Average 5 Min        |
| <i>load_avg_15min</i>     | (Optional) Load Average 15 Min       |
| <i>processes_total</i>    | (Optional) Total processes           |
| <i>processes_running</i>  | (Optional) Running Processes         |
| <i>cpu_state_user</i>     | (Optional) CPU State User            |
| <i>cpu_state_kernel</i>   | (Optional) CPU State Kernel          |
| <i>cpu_state_idle</i>     | (Optional) CPU State Idle            |
| <i>cpuid</i>              | (Optional) CPU id                    |
| <i>user</i>               | (Optional) user time                 |
| <i>kernel</i>             | (Optional) kernel time               |
| <i>idle</i>               | (Optional) idle time                 |
| <i>memory_usage_total</i> | (Optional) Memory Usage Total        |
| <i>memory_usage_used</i>  | (Optional) Memory Usage Used         |
| <i>memory_usage_free</i>  | (Optional) Memory Usage Free         |
| <i>vm_total</i>           | (Optional) Kernal VMemory Total      |
| <i>vm_free</i>            | (Optional) Kernal VMemory Free       |
| <i>mem_buffers</i>        | (Optional) Kernal Buffers            |

|                              |                                  |
|------------------------------|----------------------------------|
| <i>mem_cached</i>            | (Optional) Kernal Cached         |
| <i>current_memory_status</i> | (Optional) Current Memory Status |

**Command Mode**

- /exec

## show system resources all-modules

```
show system resources all-modules [ __readonly__ { [ <load_avg_1min> ] [ <load_avg_5min> ] [
<load_avg_15min> ] [ <processes_total> ] [ <processes_running> ] [ <cpu_state_user> ] [ <cpu_state_kernel>
] [ <cpu_state_idle> ] [ TABLE_cpu_usage <cpuid> <user> <kernel> <idle> ] [ <memory_usage_total> ] [
<memory_usage_used> ] [ <memory_usage_free> ] [ <current_memory_status> } ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information                 |
| system                       | System-related show commands                    |
| resources                    | Show system resources                           |
| all-modules                  | Show system resources for all available modules |
| <i>__readonly__</i>          | (Optional)                                      |
| <i>TABLE_cpu_usage</i>       | (Optional) All Cpu Usage Information            |
| <i>load_avg_1min</i>         | (Optional) Load Average 1 Min                   |
| <i>load_avg_5min</i>         | (Optional) Load Average 5 Min                   |
| <i>load_avg_15min</i>        | (Optional) Load Average 15 Min                  |
| <i>processes_total</i>       | (Optional) Total processes                      |
| <i>processes_running</i>     | (Optional) Running Processes                    |
| <i>cpu_state_user</i>        | (Optional) CPU State User                       |
| <i>cpu_state_kernel</i>      | (Optional) CPU State Kernel                     |
| <i>cpu_state_idle</i>        | (Optional) CPU State Idle                       |
| <i>cpuid</i>                 | (Optional) CPU id                               |
| <i>user</i>                  | (Optional) user time                            |
| <i>kernel</i>                | (Optional) kernel time                          |
| <i>idle</i>                  | (Optional) idle time                            |
| <i>memory_usage_total</i>    | (Optional) Memory Usage Total                   |
| <i>memory_usage_used</i>     | (Optional) Memory Usage Used                    |
| <i>memory_usage_free</i>     | (Optional) Memory Usage Free                    |
| <i>current_memory_status</i> | (Optional) Current Memory Status                |

### Command Mode

- /exec

## show system routing mode

```
show system routing mode [ __readonly__ TABLE_system_routing_mode { [ <configured-sys-routing-mode>
] [ <applied-sys-routing-mode> ] [ <svi-hardware-flood-mode> ] [ <routing-perf-mode> ] [
<mrouting-perf-mode> ] } ]
```

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | Show running system information                                |
| system                             | Show system information  |
| routing                            | Show routing related information                               |
| mode                               | Show mode related information                                  |
| <i>__readonly__</i>                | (Optional)   |
| <i>TABLE_system_routing_mode</i>   | (Optional) the xml system_routing_mode configuration           |
| <i>configured-sys-routing-mode</i> | (Optional) Configured system routing mode description          |
| <i>applied-sys-routing-mode</i>    | (Optional) Applied system routing mode description             |
| <i>svi-hardware-flood-mode</i>     | (Optional) Configured SVI hardware flood mode description      |
| <i>routing-perf-mode</i>           | (Optional) Applied System Routing Performance Mode description |
| <i>mrouting-perf-mode</i>          | (Optional) Applied System Mrouting Performance Mode            |

### Command Mode

- /exec

# show system security

```
show system security [ common-criteria ] [ __readonly__ { [ <common_criteria_o_status> ] } ]
```

## Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information                                |
| system                          | System Management commands                                     |
| security                        | Security Management commands                                   |
| common-criteria                 | (Optional) Show if common-criteria mode is enabled or disabled |
| __readonly__                    | (Optional)   |
| <i>common_criteria_o_status</i> | (Optional) operational status of common-criteria               |

## Command Mode

- /exec

# show system simulate fan-presence

show system simulate fan-presence

## Syntax Description

|              |                                 |
|--------------|---------------------------------|
| show         | Show running system information |
| system       | System management commands      |
| simulate     | Simulate Fan Presence           |
| fan-presence | Simulate Fan Presence           |

## Command Mode

- /exec



# show system standby manual-boot

```
show system standby manual-boot [ __readonly__ { <content> } ]
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information                       |
| system              | System-related show commands                          |
| standby             | Displays system standby manual boot option            |
| manual-boot         | Displays system standby manual boot option            |
| <i>__readonly__</i> | (Optional)  |
| <i>content</i>      | (Optional) Displays system standby manual boot option |

## Command Mode

- /exec

# show system switch-mode

show system switch-mode [ *\_\_readonly\_\_* <*op\_mode*> ]

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show running system information             |
| system              | System-related show commands                |
| switch-mode         | Show current operational mode of the switch |
| <i>__readonly__</i> | (Optional)                                  |
| <i>op_mode</i>      | (Optional) Operational Mode                 |

## Command Mode

- /exec

# show system uptime

```
show system uptime [ __readonly__ { <sys_st_time> <sys_up_days> <sys_up_hrs> <sys_up_mins>
<sys_up_secs> <kn_up_days> <kn_up_hrs> <kn_up_mins> <kn_up_secs> [ <as_up_days> ] [ <as_up_hrs>
] [ <as_up_mins> ] [ <as_up_secs> ] } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                  |
| system              | System-related show commands                     |
| uptime              | Show how long the system has been up and running |
| <i>__readonly__</i> | (Optional) readonly                              |
| <i>sys_st_time</i>  | (Optional) System Start Time                     |
| <i>sys_up_days</i>  | (Optional) System Uptime Days                    |
| <i>sys_up_hrs</i>   | (Optional) System Uptime Hours                   |
| <i>sys_up_mins</i>  | (Optional) System Uptime Minutes                 |
| <i>sys_up_secs</i>  | (Optional) System Uptime Seconds                 |
| <i>kn_up_days</i>   | (Optional) Kernel Uptime Days                    |
| <i>kn_up_hrs</i>    | (Optional) Kernel Uptime Hours                   |
| <i>kn_up_mins</i>   | (Optional) Kernel Uptime Minutes                 |
| <i>kn_up_secs</i>   | (Optional) Kernel Uptime Seconds                 |
| <i>as_up_days</i>   | (Optional) Active Sup Uptime Days                |
| <i>as_up_hrs</i>    | (Optional) Active Sup Uptime Hours               |
| <i>as_up_mins</i>   | (Optional) Active Sup Uptime Minutes             |
| <i>as_up_secs</i>   | (Optional) Active Sup Uptime Seconds             |

## Command Mode

- /exec

## show system verify bios flash

```
show system verify bios { flash <i0> [ module <module> ] | protection <i1> [ module <module1> ] } [
__readonly__ { <return> <verify_result> <protection_status> } ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information        |
| system                   | System-related show commands           |
| verify                   | Verify commands                        |
| bios                     | Verify bios                            |
| flash                    | verify bios flash or protection status |
| <i>i0</i>                | Select primary or alternate flash      |
| module                   | (Optional) Module number               |
| <i>module</i>            | (Optional) Enter module number         |
| protection               | verify bios flash or protection status |
| <i>i1</i>                | Select primary or alternate flash      |
| module                   | (Optional) Module number               |
| <i>module1</i>           | (Optional) Enter module number         |
| <i>__readonly__</i>      | (Optional)                             |
| <i>return</i>            | (Optional)                             |
| <i>verify_result</i>     | (Optional)                             |
| <i>protection_status</i> | (Optional)                             |

### Command Mode

- /exec

# show system vlan reserved

```
show system vlan reserved [ __readonly__ { TABLE_vlan <current_reserved_vlan_start>
<current_reserved_vlan_end> [ <future_reserved_vlan_start> ] [ <future_reserved_vlan_end> ] } ]
```

## Syntax Description

|                                    |   |
|------------------------------------|---|
| show                               | Show running system information                       |
| system                             | system wide configuration                             |
| vlan                               | VLAN status   |
| reserved                           | Show system VLAN allocation                           |
| <i>__readonly__</i>                | (Optional) Read Only                                  |
| <i>TABLE_vlan</i>                  | (Optional)  |
| <i>current_reserved_vlan_start</i> | (Optional) System current running reserved vlan start |
| <i>current_reserved_vlan_end</i>   | (Optional) System current running reserved vlan end   |
| <i>future_reserved_vlan_start</i>  | (Optional) System future running reserved vlan start  |
| <i>future_reserved_vlan_end</i>    | (Optional) System future running reserved vlan end    |

## Command Mode

- /exec

show system vlan reserved



## T Show Commands

---

- [show table-map](#), on page 3064
- [show tacacs-server](#), on page 3065
- [show tacacs-server](#), on page 3066
- [show tacacs-server directed-request](#), on page 3067
- [show tacacs-server groups](#), on page 3068
- [show tacacs-server sorted](#), on page 3069
- [show tacacs-server statistics](#), on page 3070
- [show tech-support](#), on page 3072
- [show tech-support aaa](#), on page 3073
- [show tech-support acl](#), on page 3074
- [show tech-support aclmgr](#), on page 3075
- [show tech-support aclmgr compressed](#), on page 3076
- [show tech-support aclqos](#), on page 3077
- [show tech-support aclqos compressed](#), on page 3078
- [show tech-support adjmgr](#), on page 3079
- [show tech-support all](#), on page 3080
- [show tech-support all binary](#), on page 3081
- [show tech-support analytics](#), on page 3082
- [show tech-support analytics](#), on page 3083
- [show tech-support arp](#), on page 3084
- [show tech-support ascii-cfg](#), on page 3085
- [show tech-support assoc\\_mgr](#), on page 3086
- [show tech-support backup](#), on page 3087
- [show tech-support bcm](#), on page 3088
- [show tech-support bfd](#), on page 3089
- [show tech-support bgp](#), on page 3090
- [show tech-support biosd](#), on page 3091
- [show tech-support bloggerd-all](#), on page 3092
- [show tech-support bloggerd](#), on page 3093
- [show tech-support bootvar](#), on page 3094
- [show tech-support brief](#), on page 3095
- [show tech-support callhome](#), on page 3096
- [show tech-support cdp](#), on page 3097

- [show tech-support cert-enroll](#), on page 3098
- [show tech-support cfs](#), on page 3099
- [show tech-support cli](#), on page 3100
- [show tech-support clis](#), on page 3101
- [show tech-support clock\\_manager](#), on page 3102
- [show tech-support commands](#), on page 3103
- [show tech-support controller](#), on page 3104
- [show tech-support copp](#), on page 3105
- [show tech-support cores](#), on page 3106
- [show tech-support dcbx](#), on page 3107
- [show tech-support details](#), on page 3108
- [show tech-support device-alias](#), on page 3109
- [show tech-support dhclient](#), on page 3110
- [show tech-support dhcp](#), on page 3111
- [show tech-support dme](#), on page 3112
- [show tech-support dot1x](#), on page 3113
- [show tech-support dpvm](#), on page 3114
- [show tech-support ecp](#), on page 3115
- [show tech-support eem](#), on page 3116
- [show tech-support eigrp](#), on page 3117
- [show tech-support eltm](#), on page 3118
- [show tech-support epbr](#), on page 3119
- [show tech-support epp](#), on page 3120
- [show tech-support ethpm](#), on page 3121
- [show tech-support ethport](#), on page 3122
- [show tech-support evb](#), on page 3123
- [show tech-support fabric forwarding](#), on page 3124
- [show tech-support fabric multicast](#), on page 3125
- [show tech-support fabricpath isis](#), on page 3126
- [show tech-support fabricpath topology](#), on page 3127
- [show tech-support fast-reload](#), on page 3128
- [show tech-support fc2](#), on page 3129
- [show tech-support fcdomain](#), on page 3130
- [show tech-support fcns](#), on page 3131
- [show tech-support fcoe](#), on page 3132
- [show tech-support fcs](#), on page 3133
- [show tech-support feature](#), on page 3134
- [show tech-support fib-all](#), on page 3135
- [show tech-support fib module](#), on page 3136
- [show tech-support fips](#), on page 3137
- [show tech-support flogi](#), on page 3138
- [show tech-support forwarding l2 multicast](#), on page 3139
- [show tech-support forwarding l2 multicast vdc-all](#), on page 3140
- [show tech-support forwarding l2 unicast](#), on page 3141
- [show tech-support forwarding l3 multicast](#), on page 3142
- [show tech-support forwarding l3 multicast detail vdc-all](#), on page 3143



- [show tech-support forwarding l3 multicast detail](#), on page 3144
- [show tech-support forwarding l3 multicast vdc-all](#), on page 3145
- [show tech-support forwarding l3 unicast](#), on page 3146
- [show tech-support forwarding l3 unicast detail](#), on page 3147
- [show tech-support forwarding l3 unicast detail vdc-all](#), on page 3148
- [show tech-support forwarding l3 unicast vdc-all](#), on page 3149
- [show tech-support forwarding mpls](#), on page 3150
- [show tech-support forwarding multicast](#), on page 3151
- [show tech-support forwarding multicast nat](#), on page 3152
- [show tech-support forwarding srv6](#), on page 3153
- [show tech-support frequency synchronization](#), on page 3154
- [show tech-support fspf](#), on page 3155
- [show tech-support fsync\\_mgr](#), on page 3156
- [show tech-support gold](#), on page 3157
- [show tech-support gpixm](#), on page 3158
- [show tech-support ha](#), on page 3159
- [show tech-support ha module](#), on page 3160
- [show tech-support ha\\_short](#), on page 3161
- [show tech-support ha standby](#), on page 3162
- [show tech-support hardware-telemetry](#), on page 3163
- [show tech-support hsrp](#), on page 3164
- [show tech-support hsrp brief](#), on page 3165
- [show tech-support icam](#), on page 3166
- [show tech-support icmpv6](#), on page 3167
- [show tech-support im](#), on page 3168
- [show tech-support imp](#), on page 3169
- [show tech-support inband counters](#), on page 3170
- [show tech-support include-time](#), on page 3171
- [show tech-support install](#), on page 3172
- [show tech-support interface-vlan](#), on page 3173
- [show tech-support interfaces all](#), on page 3174
- [show tech-support ip](#), on page 3175
- [show tech-support ip igmp](#), on page 3176
- [show tech-support ip igmp snooping](#), on page 3177
- [show tech-support ip msdp](#), on page 3178
- [show tech-support ip pim](#), on page 3179
- [show tech-support ipqos](#), on page 3180
- [show tech-support ipv6](#), on page 3181
- [show tech-support ipv6 mfwd](#), on page 3182
- [show tech-support ipv6 mld](#), on page 3183
- [show tech-support ipv6 mld snooping](#), on page 3184
- [show tech-support ipv6 multicast](#), on page 3185
- [show tech-support ipv6 pim](#), on page 3186
- [show tech-support isis](#), on page 3187
- [show tech-support issu](#), on page 3188
- [show tech-support kstack](#), on page 3189

- [show tech-support l2](#), on page 3190
- [show tech-support l2fm](#), on page 3191
- [show tech-support l2fm clients](#), on page 3192
- [show tech-support l2fm detail](#), on page 3193
- [show tech-support l2fm l2dbg](#), on page 3194
- [show tech-support l2fm l2dbg](#), on page 3195
- [show tech-support l2rib](#), on page 3196
- [show tech-support l3vm](#), on page 3197
- [show tech-support l3vpn](#), on page 3198
- [show tech-support lacp](#), on page 3199
- [show tech-support ldap](#), on page 3200
- [show tech-support license](#), on page 3201
- [show tech-support lim](#), on page 3202
- [show tech-support lisp](#), on page 3203
- [show tech-support lldp](#), on page 3204
- [show tech-support logging](#), on page 3205
- [show tech-support m2rib](#), on page 3206
- [show tech-support macsec](#), on page 3207
- [show tech-support macsec detail](#), on page 3208
- [show tech-support mfwd](#), on page 3209
- [show tech-support mmode](#), on page 3210
- [show tech-support module](#), on page 3211
- [show tech-support module all](#), on page 3212
- [show tech-support monitor](#), on page 3213
- [show tech-support monitor erspan](#), on page 3214
- [show tech-support monitorc-all](#), on page 3215
- [show tech-support mpls manager](#), on page 3216
- [show tech-support mpls oam](#), on page 3217
- [show tech-support mpls static](#), on page 3218
- [show tech-support mpls strip](#), on page 3219
- [show tech-support mpls switching](#), on page 3220
- [show tech-support mpls fwd](#), on page 3221
- [show tech-support multicast-vxlan-evpn](#), on page 3222
- [show tech-support multicast](#), on page 3223
- [show tech-support mvpn](#), on page 3224
- [show tech-support nat](#), on page 3225
- [show tech-support nbm](#), on page 3226
- [show tech-support nbm group](#), on page 3227
- [show tech-support netflow](#), on page 3228
- [show tech-support netstack](#), on page 3229
- [show tech-support netstack detail](#), on page 3230
- [show tech-support nexus9000v](#), on page 3231
- [show tech-support ngoam](#), on page 3232
- [show tech-support npacl](#), on page 3233
- [show tech-support npv](#), on page 3234
- [show tech-support ns](#), on page 3235

- [show tech-support ntp](#), on page 3236
- [show tech-support nve](#), on page 3237
- [show tech-support nxapi](#), on page 3238
- [show tech-support nxsdk](#), on page 3239
- [show tech-support object-store](#), on page 3240
- [show tech-support ofm](#), on page 3241
- [show tech-support openflow](#), on page 3242
- [show tech-support openflow platform](#), on page 3243
- [show tech-support ospf](#), on page 3244
- [show tech-support ospfv3](#), on page 3245
- [show tech-support otv isis](#), on page 3246
- [show tech-support page](#), on page 3247
- [show tech-support patch](#), on page 3248
- [show tech-support pbr](#), on page 3249
- [show tech-support pfstat](#), on page 3250
- [show tech-support pixm-all](#), on page 3251
- [show tech-support pixm](#), on page 3252
- [show tech-support pixmc-all](#), on page 3253
- [show tech-support pktmgr](#), on page 3254
- [show tech-support platform-sdk](#), on page 3255
- [show tech-support platform](#), on page 3256
- [show tech-support plcmgr](#), on page 3257
- [show tech-support pltfm-config](#), on page 3258
- [show tech-support pnp](#), on page 3259
- [show tech-support poe](#), on page 3260
- [show tech-support port-channel](#), on page 3261
- [show tech-support port-client-all](#), on page 3262
- [show tech-support port-profile](#), on page 3263
- [show tech-support port-security](#), on page 3264
- [show tech-support port](#), on page 3265
- [show tech-support private-vlan](#), on page 3266
- [show tech-support pss](#), on page 3267
- [show tech-support ptp](#), on page 3268
- [show tech-support radius](#), on page 3269
- [show tech-support rib](#), on page 3270
- [show tech-support rip](#), on page 3271
- [show tech-support routing](#), on page 3272
- [show tech-support routing ipv6](#), on page 3273
- [show tech-support routing ipv6 multicast](#), on page 3274
- [show tech-support routing multicast](#), on page 3275
- [show tech-support rpm](#), on page 3276
- [show tech-support rscn](#), on page 3277
- [show tech-support sal](#), on page 3278
- [show tech-support san-port-channel](#), on page 3279
- [show tech-support san](#), on page 3280
- [show tech-support satmgr](#), on page 3281

- [show tech-support security](#), on page 3282
- [show tech-support segment-routing](#), on page 3283
- [show tech-support services](#), on page 3284
- [show tech-support session-mgr](#), on page 3285
- [show tech-support sflow](#), on page 3286
- [show tech-support single-gerichio](#), on page 3287
- [show tech-support sksd](#), on page 3288
- [show tech-support sla responder](#), on page 3289
- [show tech-support sla sender](#), on page 3290
- [show tech-support sla twamp-server](#), on page 3291
- [show tech-support slowdrain](#), on page 3292
- [show tech-support smm](#), on page 3293
- [show tech-support snmp](#), on page 3294
- [show tech-support sockets](#), on page 3295
- [show tech-support spm](#), on page 3296
- [show tech-support srte](#), on page 3297
- [show tech-support statsclient](#), on page 3298
- [show tech-support stp](#), on page 3299
- [show tech-support sup-filesys](#), on page 3300
- [show tech-support super-bridging](#), on page 3301
- [show tech-support sysmgr](#), on page 3302
- [show tech-support tacacs](#), on page 3303
- [show tech-support telemetry](#), on page 3304
- [show tech-support track](#), on page 3305
- [show tech-support trm](#), on page 3306
- [show tech-support tunnel-encryption](#), on page 3307
- [show tech-support tunnel](#), on page 3308
- [show tech-support u2rib](#), on page 3309
- [show tech-support udld](#), on page 3310
- [show tech-support usd-all](#), on page 3311
- [show tech-support vdc](#), on page 3312
- [show tech-support virtual-service](#), on page 3313
- [show tech-support vlan](#), on page 3314
- [show tech-support vmtracker](#), on page 3315
- [show tech-support vpc](#), on page 3316
- [show tech-support vrrp](#), on page 3317
- [show tech-support vrrp brief](#), on page 3318
- [show tech-support vrrpv3](#), on page 3319
- [show tech-support vsan](#), on page 3320
- [show tech-support vshd](#), on page 3321
- [show tech-support vtp](#), on page 3322
- [show tech-support vvlan](#), on page 3323
- [show tech-support vxlan-evpn](#), on page 3324
- [show tech-support vxlan](#), on page 3325
- [show tech-support vxlan platform](#), on page 3326
- [show tech-support xbar](#), on page 3327

- [show tech-support xml](#), on page 3328
- [show tech-support xos](#), on page 3329
- [show tech-support zone](#), on page 3330
- [show telemetry control database](#), on page 3331
- [show telemetry data collector brief](#), on page 3337
- [show telemetry dynamic configuration](#), on page 3338
- [show telemetry event collector stats](#), on page 3340
- [show telemetry pipeline stats](#), on page 3342
- [show telemetry port-counters](#), on page 3344
- [show telemetry syslog-filter](#), on page 3346
- [show telemetry transport](#), on page 3347
- [show telemetry transport](#), on page 3350
- [show telemetry usability](#), on page 3354
- [show telemetry yang direct-path cisco-nxos-device](#), on page 3355
- [show telnet server](#), on page 3356
- [show terminal](#), on page 3357
- [show terminal lock](#), on page 3358
- [show terminal output xml version](#), on page 3359
- [show time-range](#), on page 3360
- [show time-stamp running-config last-changed](#), on page 3362
- [show topology](#), on page 3363
- [show topology isl](#), on page 3364
- [show topology isl](#), on page 3365
- [show topology isl](#), on page 3366
- [show trace callhome](#), on page 3367
- [show track](#), on page 3368
- [show track brief](#), on page 3370
- [show troubleshoot l2 mac vlan](#), on page 3372
- [show troubleshoot l2 port-channel](#), on page 3373
- [show troubleshoot l3 vrf](#), on page 3374
- [show trunk protocol](#), on page 3375
- [show ttag brief](#), on page 3376
- [show ttag brief](#), on page 3377
- [show tunnel-encryption info global](#), on page 3378
- [show tunnel-encryption policy](#), on page 3379
- [show tunnel-encryption session](#), on page 3380
- [show tunnel-encryption statistics](#), on page 3382
- [show tunnel-profile](#), on page 3384

# show table-map

```
show table-map [ <tmap-name> | <default-tmap-enum-name> ] [ __readonly__ { [ TABLE_tmap <tmap-name>
[ <desc> ] [ <def-value> ] [ <def-copy> ] [ <def-ignore> ] [ TABLE_list <frm-list> <to-val> ] ] } ]
```

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                              |
| table-map                     | Table maps   |
| TABLE_tmap                    | (Optional) all tmap xml sessions                             |
| <i>tmap-name</i>              | (Optional) Show a particular table map                       |
| <i>default-tmap-enum-name</i> | (Optional)   |
| <code>__readonly__</code>     | (Optional)   |
| <i>desc</i>                   | (Optional) Description string                                |
| <i>def-value</i>              | (Optional) Unspecified entries will default to this value    |
| <i>def-copy</i>               | (Optional) Map unspecified values to equivalent output value |
| <i>def-ignore</i>             | (Optional) Ignore unspecified values                         |
| TABLE_list                    | (Optional) table map lists                                   |
| <i>frm-list</i>               | (Optional) Original list of values which are to be mapped    |
| <i>to-val</i>                 | (Optional) To value  |

## Command Mode

- /exec

## show tacacs-server

```
show tacacs-server [ __readonly__ [ <global_secretKey> ] { <global_timeout> <global_deadtime> } [
<global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [ <global_testPassword> ] } {
<server_count> } [ TABLE_server <server_ip> <port> [ <secretKey> ] [ <timeout> ] ] [ { <host0>
<tacacs_port> <shared_key> <idle_time><test_username> <test_password> } + ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                                   |
| tacacs-server              | Show TACACS+ configuration information                            |
| <i>__readonly__</i>        | (Optional)  |
| <i>global_secretKey</i>    | (Optional) Global shared secret                                   |
| <i>global_timeout</i>      | (Optional) Global timeout for tacacs                              |
| <i>global_deadtime</i>     | (Optional) Global deadtime  |
| <i>global_source_intf</i>  | (Optional) Tacacs global source interface                         |
| <i>global_idle_time</i>    | (Optional) Tacacs global idle-time for server monitoring          |
| <i>global_testUsername</i> | (Optional) Username of global test parameters                     |
| <i>global_testPassword</i> | (Optional) Password of global test parameters                     |
| <i>server_count</i>        | (Optional) Total number of tacacs servers configured              |
| TABLE_server               | (Optional)  |
| <i>server_ip</i>           | (Optional) Ip address of the server                               |
| <i>port</i>                | (Optional) Port used for this server                              |
| <i>secretKey</i>           | (Optional) Shared secret between the server and the tacacs client |
| <i>timeout</i>             | (Optional) Timeout for this tacacs server                         |
| <i>host0</i>               | (Optional) DNS name or IP address                                 |
| <i>tacacs_port</i>         | (Optional) TACACS+ server port                                    |
| <i>shared_key</i>          | (Optional) TACACS+ shared secret                                  |
| <i>test_password</i>       | (Optional) User password in test packets                          |

### Command Mode

- /exec

## show tacacs-server

```
show tacacs-server { <host0> } [ __readonly__ { <host1> } ] [ <tac_port> ] [ <tac_shared_key> ] [ <time_out> ] [ <conn_type> ] [ <tac_idle_time> ] [ <test_user_name> ] <test_pwd> ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                    |
| tacacs-server         | Show TACACS+ configuration information             |
| <i>host0</i>          | DNS name or IP address                             |
| <i>__readonly__</i>   | (Optional)   |
| <i>host1</i>          | (Optional) DNS name or IP address                  |
| <i>tac_port</i>       | (Optional) TACACS+ server port                     |
| <i>tac_shared_key</i> | (Optional) TACACS+ shared secret                   |
| <i>time_out</i>       | (Optional) radius server timeout                   |
| <i>conn_type</i>      | (Optional) TACACS+ connection type                 |
| <i>test_user_name</i> | (Optional) User name in test packets               |
| <i>test_pwd</i>       | (Optional) User password in test packets           |
| <i>tac_idle_time</i>  | (Optional) Time interval for monitoring the server |

### Command Mode

- /exec



# show tacacs-server directed-request

```
show tacacs-server directed-request [ __readonly__ { <tacacs_directedRequest_status> } ]
```

## Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information                     |
| tacacs-server                        | Show TACACS+ configuration information              |
| directed-request                     | Show directed server enable configuration           |
| __readonly__                         | (Optional)  |
| <i>tacacs_directedRequest_status</i> | (Optional) status of tacacs-server directed request |

## Command Mode

- /exec

## show tacacs-server groups

```
show tacacs-server groups [ <s0> ] [ __readonly__ [ <num_of_groups> ] [ TABLE_group <group_name> [
TABLE_server <server_ip> [ <port> ] ] [ <dead_time> ] [ <vrf_name> ] [ <source_interface> ] ] ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information   |
| tacacs-server           | Show TACACS+ configuration information  |
| groups                  | Show TACACS+ server group configuration information   |
| <i>s0</i>               | (Optional) TACACS+ server group name  |
| <i>__readonly__</i>     | (Optional)  |
| <i>num_of_groups</i>    | (Optional) number of groups   |
| TABLE_group             | (Optional)  |
| <i>group_name</i>       | (Optional) name of the group  |
| TABLE_server            | (Optional)  |
| <i>server_ip</i>        | (Optional) DNS name or IP address   |
| <i>port</i>             | (Optional) TACACS+ server port  |
| <i>dead_time</i>        | (Optional) Time interval for which the server is marked as dead before sending a test command |
| <i>vrf_name</i>         | (Optional) name of the vrf  |
| <i>source_interface</i> | (Optional) Interface Description  |

### Command Mode

- /exec

## show tacacs-server sorted

```
show tacacs-server sorted [ __readonly__ [ <global_secretKey> ] { <global_timeout> <global_deadtime> }
[ <global_source_intf> ] [ <global_idle_time> ] { [ <global_testUsername> ] [ <global_testPassword> ] } {
<server_count> } [ TABLE_server <server_ip> <port> [ <secretKey> ] [ <timeout> ] ] ]
```

### Syntax Description

|                            |   |
|----------------------------|---|
| show                       | Show running system information                                   |
| tacacs-server              | Show TACACS+ configuration information                            |
| sorted                     | Show TACACS+ servers sorted by server name                        |
| <i>__readonly__</i>        | (Optional)  |
| <i>global_secretKey</i>    | (Optional) Global shared secret                                   |
| <i>global_timeout</i>      | (Optional) Global timeout for tacacs                              |
| <i>global_deadtime</i>     | (Optional) Global deadtime  |
| <i>global_source_intf</i>  | (Optional) Tacacs global source interface                         |
| <i>global_idle_time</i>    | (Optional) Tacacs global idle-time for server monitoring          |
| <i>global_testUsername</i> | (Optional) Username of global test parameters                     |
| <i>global_testPassword</i> | (Optional) Password of global test parameters                     |
| <i>server_count</i>        | (Optional) Total number of tacacs servers configured              |
| TABLE_server               | (Optional)  |
| <i>server_ip</i>           | (Optional) Ip address of the server                               |
| <i>port</i>                | (Optional) Port used for this server                              |
| <i>secretKey</i>           | (Optional) Shared secret between the server and the tacacs client |
| <i>timeout</i>             | (Optional) Timeout for this tacacs server                         |

### Command Mode

- /exec

## show tacacs-server statistics

```
show tacacs-server statistics { <host0> } [ __readonly__ { <server_state> [ <clock_time> { monitoring_statistics
<time_in_pstate> <ndead> <tt_in_dstate> } ] } { auth_statistics <auth_failed_transactions>
<auth_succ_transactions> <auth_req_sent> <auth_req_timedout> <auth_resp_no_match>
<auth_resp_not_processed> <auth_resp_error> } { autho_statistics <autho_failed_transactions>
<autho_succ_transactions> <autho_req_sent> <autho_req_timedout> <autho_resp_no_match>
<autho_resp_not_processed> <autho_resp_error> } { acct_statistics <acct_failed_transactions>
<acct_succ_transactions> <acct_req_sent> <acct_req_timedout> <acct_resp_no_match>
<acct_resp_not_processed> <acct_resp_error> } ]
```

### Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                                   |
| tacacs-server                   | Show TACACS+ configuration information                            |
| statistics                      | Show TACACS statistics  |
| <i>host0</i>                    | DNS name or IP address  |
| <i>__readonly__</i>             | (Optional)  |
| <i>server_state</i>             | (Optional) Show state of server                                   |
| <i>clock_time</i>               | (Optional) Show clock time in terms of hours, minutes and seconds |
| monitoring_statistics           | (Optional) Monitoring Statistics                                  |
| <i>time_in_pstate</i>           | (Optional) Time in previous state                                 |
| <i>ndead</i>                    | (Optional) Number of times dead                                   |
| <i>tt_in_dstate</i>             | (Optional) Total time in dead state                               |
| auth_statistics                 | (Optional) Authentication Statistics                              |
| autho_statistics                | (Optional) Authorization Statistics                               |
| acct_statistics                 | (Optional) Accounting Statistics                                  |
| <i>auth_failed_transactions</i> | (Optional) Authentication: Failed transactions                    |
| <i>auth_succ_transactions</i>   | (Optional) Authentication: Successful transactions                |
| <i>auth_req_sent</i>            | (Optional) Authentication: Requests sent                          |
| <i>auth_req_timedout</i>        | (Optional) Authentication: Requests timedout                      |
| <i>auth_resp_no_match</i>       | (Optional) Authentication: Responses with no matching requests    |
| <i>auth_resp_not_processed</i>  | (Optional) Authentication: Responses not processed                |
| <i>auth_resp_error</i>          | (Optional) Authentication: Responses containing errors            |

|                                  |   |
|----------------------------------|---|
| <i>autho_failed_transactions</i> | (Optional) Authorization: Failed transactions                 |
| <i>autho_succ_transactions</i>   | (Optional) Authorization: Successful transactions             |
| <i>autho_req_sent</i>            | (Optional) Authorization: Requests sent                       |
| <i>autho_req_timedout</i>        | (Optional) Authorization: Requests timedout                   |
| <i>autho_resp_no_match</i>       | (Optional) Authorization: Responses with no matching requests |
| <i>autho_resp_not_processed</i>  | (Optional) Authorization: Responses not processed             |
| <i>autho_resp_error</i>          | (Optional) Authorization: Responses containing errors         |
| <i>acct_failed_transactions</i>  | (Optional) Accounting: Failed transactions                    |
| <i>acct_succ_transactions</i>    | (Optional) Accounting: Successful transactions                |
| <i>acct_req_sent</i>             | (Optional) Accounting: Requests sent                          |
| <i>acct_req_timedout</i>         | (Optional) Accounting: Requests timedout                      |
| <i>acct_resp_no_match</i>        | (Optional) Accounting: Responses with no matching requests    |
| <i>acct_resp_not_processed</i>   | (Optional) Accounting: Responses not processed                |
| <i>acct_resp_error</i>           | (Optional) Accounting: Responses containing errors            |

**Command Mode**

- /exec

# show tech-support

show tech-support [ time-optimized ] [ forced ] [ debug-enable ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information  |
| tech-support   | Gather information for troubleshooting                                     |
| time-optimized | (Optional) Gather tech-support faster, requires more memory and disk space |
| forced         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                                  |
| debug-enable   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                                  |

## Command Mode

- /exec

# show tech-support aaa

show tech-support aaa

## Syntax Description

|              |  |
|--------------|--|
| show         | show tech-support                      |
| tech-support | Gather information for troubleshooting |
| aaa          | Display aaa information                |

## Command Mode

- /exec

# show tech-support acl

```
show tech-support acl [ { commands | detail [ commands ] } ]
```

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                |
| tech-support | Gather information for troubleshooting                         |
| acl          | Show information for acl technical support                     |
| commands     | (Optional) Show commands run as part of acl technical support  |
| detail       | (Optional) Show detailed information for acl technical support |
| commands     | (Optional) Show commands run as part of acl technical support  |

## Command Mode

- /exec



# show tech-support aclmgr

show tech-support aclmgr [ detail ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| aclmgr       | ACL commands                           |
| detail       | (Optional) Detailed Tech Support       |

## Command Mode

- /exec

# show tech-support aclmgr compressed

show tech-support aclmgr compressed <uri0> [ detail ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information          |
| tech-support | Gather information for troubleshooting   |
| aclmgr       | ACL commands                             |
| compressed   | Save compressed aclqos technical support |
| <i>uri0</i>  | Enter filename to store                  |
| detail       | (Optional) Detailed Tech Support         |

## Command Mode

- /exec

# show tech-support aclqos

show tech-support aclqos

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information               |
| tech-support | Gather information for troubleshooting        |
| aclqos       | Show information for aclqos technical support |

## Command Mode

- /exec

# show tech-support aclqos compressed

show tech-support aclqos compressed <uri0>

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information               |
| tech-support | Gather information for troubleshooting        |
| aclqos       | Show information for aclqos technical support |
| compressed   | Save compressed aclqos technical support      |
| <i>uri0</i>  | Enter filename to store                       |

## Command Mode

- /exec

# show tech-support adjmgr

show tech-support adjmgr [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| adjmgr       | Display Adjmgr information             |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support all

show tech-support all [ space-optimized ] [ time-optimized ]

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information  |
| tech-support    | Gather information for troubleshooting                                     |
| all             | Gather detailed information for troubleshooting                            |
| space-optimized | (Optional) Gather tech-support info. using less memory and disk space      |
| time-optimized  | (Optional) Gather tech-support faster, requires more memory and disk space |

## Command Mode

- /exec

# show tech-support all binary

show tech-support all binary <uri0>

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information   |
| tech-support | Gather information for troubleshooting  |
| all          | Gather detailed information for troubleshooting   |
| binary       | Gather tech support for all applications in binary format   |
| <i>uri0</i>  | Select destination filesystem to save the binary output (NOTE: The output file name will be automatically generated and cannot be chosen) |

## Command Mode

- /exec

# show tech-support analytics

show tech-support analytics [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| analytics    | Show Analytics tech-support information |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec



# show tech-support analytics

show tech-support analytics [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| analytics    | Show Analytics tech-support information |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support arp

show tech-support arp [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| arp          | Display ARP information                |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support ascii-cfg

show tech-support ascii-cfg

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                            |
| tech-support | Show information for technical support personnel           |
| ascii-cfg    | Show ascii-cfg information for technical support personnel |

## Command Mode

- /exec

# show tech-support assoc\_mgr

show tech-support assoc\_mgr

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                           |
| tech-support | Gather information for troubleshooting                    |
| assoc_mgr    | Gather detailed information for assoc_mgr troubleshooting |

## Command Mode

- /exec

# show tech-support backup

show tech-support { backup | flexlink }

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                                   |
| tech-support | Gather information for troubleshooting                            |
| backup       | Gather detailed information for Switchport Backup troubleshooting |
| flexlink     | Gather detailed information for Switchport Backup troubleshooting |

## Command Mode

- /exec

# show tech-support bcm

show tech-support bcm

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| bcm          | bcm hardware info                      |

## Command Mode

- /exec

# show tech-support bfd

show tech-support bfd

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| bfd          | BFD commands                           |

## Command Mode

- /exec

# show tech-support bgp

show tech-support bgp [ brief | detailed ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| bgp          | Display BGP status and configuration   |
| brief        | (Optional) Brief information           |
| detailed     | (Optional) Detailed information        |

## Command Mode

- /exec



# show tech-support biosd

show tech-support biosd

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| tech-support | Gather information for troubleshooting       |
| biosd        | Gather bios install log for trouble shooting |

## Command Mode

- /exec

# show tech-support bloggerd-all

show tech-support bloggerd-all

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information   |
| tech-support | Gather information for troubleshooting                                    |
| bloggerd-all | Gather detailed information for bloggerd troubleshooting from ALL modules |

## Command Mode

- /exec

# show tech-support bloggerd

show tech-support bloggerd

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| tech-support | Gather information for troubleshooting                   |
| bloggerd     | Gather detailed information for bloggerd troubleshooting |

## Command Mode

- /exec

# show tech-support bootvar

show tech-support bootvar

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                         |
| tech-support | Gather information for troubleshooting                  |
| bootvar      | Gather detailed information for bootvar troubleshooting |

## Command Mode

- /exec

# show tech-support brief

show tech-support brief

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system summary information        |
| tech-support | Gather information for troubleshooting         |
| brief        | Gather summary information for troubleshooting |

## Command Mode

- /exec

# show tech-support callhome

show tech-support callhome

## Syntax Description

|              |  |
|--------------|--|
| show         | show tech-support                      |
| tech-support | Gather information for troubleshooting |
| callhome     | callhome troubleshooting information   |

## Command Mode

- /exec

# show tech-support cdp

show tech-support cdp

## Syntax Description

|              |   |
|--------------|---|
| show         | show running system information             |
| tech-support | Gather information for troubleshooting      |
| cdp          | Gather information for CDP trouble shooting |

## Command Mode

- /exec

# show tech-support cert-enroll

show tech-support cert-enroll

## Syntax Description

|              |  |
|--------------|--|
| show         | show commands                          |
| tech-support | Gather information for troubleshooting |
| cert-enroll  | Display certificates information       |

## Command Mode

- /exec



# show tech-support cfs

```
show tech-support cfs [ { commands | name <cfs-dyn-app-name> [ commands1 ] } ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information   |
| tech-support            | Gather information for troubleshooting                                    |
| cfs                     | Gather detailed information for cfs troubleshooting                       |
| commands                | (Optional) CFS show tech commands   |
| name                    | (Optional) Gather detailed information of cfs for a specified application |
| <i>cfs-dyn-app-name</i> | (Optional) Registered name of the local application                       |
| commands1               | (Optional) CFS application show tech commands                             |

## Command Mode

- /exec

# show tech-support cli

show tech-support cli

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information               |
| tech-support | Gather information for troubleshooting        |
| cli          | Gather information for parser troubleshooting |

## Command Mode

- /exec

# show tech-support clis

show tech-support clis [ brief ] [ commands ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                                     |
| tech-support | Gather information for troubleshooting                              |
| clis         | Gather information for CLI Server troubleshooting                   |
| brief        | (Optional) Detailed information                                     |
| commands     | (Optional) Show commands executed as part of show tech-support clis |

## Command Mode

- /exec

# show tech-support clock\_manager

show tech-support clock\_manager

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information                               |
| tech-support  | Gather information for troubleshooting                        |
| clock_manager | Gather detailed information for clock manager troubleshooting |

## Command Mode

- /exec

# show tech-support commands

show tech-support commands

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| commands     | Show commands executed as part of show tech-support commands |

## Command Mode

- /exec

# show tech-support controller

show tech-support controller

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                   |
| tech-support | Gather information for troubleshooting            |
| controller   | Gather information for Controller troubleshooting |

## Command Mode

- /exec

# show tech-support copp

show tech-support copp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| tech-support | Gather information for trouble shooting      |
| copp         | Gather information for copp trouble shooting |

## Command Mode

- /exec

# show tech-support cores

```
show tech-support cores [ filename { <uri0> | <uri1> [ vrf <vrf-known-name> ] } [ archive { <core-count> | all } ] ]
```

## Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information  |
| tech-support          | Gather information for troubleshooting   |
| cores                 | Debugging information for process crashes  |
| filename              | (Optional) Create a file with the process crash debugging information and latest core files. Default is show_tech_cores.tar.gz |
| <i>uri0</i>           | (Optional) Destination file system, path, and filename   |
| <i>uri1</i>           | (Optional) Destination file system, path, and filename   |
| vrf                   | (Optional) Enter the vrf name  |
| <i>vrf-known-name</i> | (Optional) VRF name  |
| archive               | (Optional) Gather core files from the logflash archive not just the current ones to place in the compressed file               |
| <i>core-count</i>     | (Optional) Number of most recent archived core files to gather from logflash   |
| all                   | (Optional) Attempt to gather all archived core files from logflash   |

## Command Mode

- /exec



# show tech-support dcbx

show tech-support dcbx

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                |
| tech-support | Gather information for troubleshooting         |
| dcbx         | Gather detailed information for DCBX component |

## Command Mode

- /exec

# show tech-support details

show tech-support details [ space-optimized ] [ time-optimized ] [ debug-enable ]

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information  |
| tech-support    | Gather information for troubleshooting                                     |
| details         | Gather detailed information for troubleshooting                            |
| space-optimized | (Optional) Gather tech-support info. using less memory and disk space      |
| time-optimized  | (Optional) Gather tech-support faster, requires more memory and disk space |
| debug-enable    | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                                  |

## Command Mode

- /exec

# show tech-support device-alias

show tech-support device-alias

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                 |
| tech-support | Gather information for troubleshooting          |
| device-alias | Show device-alias technical support information |

## Command Mode

- /exec

# show tech-support dhclient

show tech-support dhclient

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for trouble shooting          |
| dhclient     | Gather information for dhclient trouble shooting |

## Command Mode

- /exec

# show tech-support dhcp

show tech-support dhcp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| tech-support | Gather information for troubleshooting               |
| dhcp         | Gather detailed information for dhcp troubleshooting |

## Command Mode

- /exec

# show tech-support dme

show tech-support dme [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                    |
| tech-support | Gather information for troubleshooting                             |
| dme          | Gather detailed information for dme troubleshooting                |
| commands     | (Optional) Show commands executed as part of show tech-support dme |

## Command Mode

- /exec

# show tech-support dot1x

show tech-support dot1x

## Syntax Description

|              |  |
|--------------|--|
| show         | show tech-support                      |
| tech-support | Gather information for troubleshooting |
| dot1x        | Display dot1x information              |

## Command Mode

- /exec

# show tech-support dpvm

show tech-support dpvm

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information             |
| tech-support | Gather information for troubleshooting      |
| dpvm         | Show information for dpvm technical support |

## Command Mode

- /exec



# show tech-support ecp

show tech-support ecp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ecp          | ECP (Edge Control Protocol)            |

## Command Mode

- /exec

# show tech-support eem

show tech-support eem

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| eem          | Show EEM tech-support information       |

## Command Mode

- /exec

# show tech-support eigrp

show tech-support eigrp [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| eigrp        | Display EIGRP status and configuration |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support eltm

show tech-support eltm [ detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | show tech-support                       |
| tech-support | Gather information for trouble-shooting |
| eltm         | eltm debug info                         |
| detail       | (Optional) Detailed information         |

## Command Mode

- /exec

# show tech-support epbr

show tech-support epbr

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| epbr         | EPBR                                    |

## Command Mode

- /exec

# show tech-support epp

show tech-support epp

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| epp          | Gather detailed information for EPP troubleshooting |

## Command Mode

- /exec

# show tech-support ethpm

show tech-support ethpm

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                       |
| tech-support | Gather information for troubleshooting                |
| ethpm        | Gather detailed information for ETHPM troubleshooting |

## Command Mode

- /exec

# show tech-support ethport

show tech-support ethport

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                         |
| tech-support | Gather information for troubleshooting                  |
| ethport      | Gather detailed information for ETHPORT troubleshooting |

## Command Mode

- /exec



# show tech-support evb

show tech-support evb

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| evb          | EVB (Edge Virtual Bridge)              |

## Command Mode

- /exec

# show tech-support fabric forwarding

show tech-support fabric forwarding

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                         |
| tech-support | Gather information for troubleshooting                  |
| fabric       | Fabric  |
| forwarding   | Fabric Forwarding Protocol: Host Mobility Manager (HMM) |

## Command Mode

- /exec

# show tech-support fabric multicast

show tech-support fabric multicast

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| fabric       | Fabric                                 |
| multicast    | Multicast information                  |

## Command Mode

- /exec

# show tech-support fabricpath isis

show tech-support fabricpath isis [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| fabricpath   | fabricpath information                  |
| isis         | Fabricpath IS-IS information            |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support fabricpath topology

show tech-support fabricpath topology [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                            |
| tech-support | Gather information for troubleshooting                     |
| fabricpath   | Gather detailed information for Fabricpath troubleshooting |
| topology     | Gather detailed information for Topology troubleshooting   |
| brief        | (Optional) Brief information                               |

## Command Mode

- /exec

# show tech-support fast-reload

show tech-support fast-reload

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                            |
| tech-support | Gather information for troubleshooting                     |
| fast-reload  | Gather information for troubleshooting fast-reload timings |

## Command Mode

- /exec

# show tech-support fc2

show tech-support fc2 [ commands ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                               |
| tech-support | Gather information for troubleshooting                        |
| fc2          | Show information for fc2 technical support                    |
| commands     | (Optional) Show commands run as part of fc2 technical support |

## Command Mode

- /exec

# show tech-support fcdomain

show tech-support fcdomain [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                    |
| tech-support | Gather information for troubleshooting                             |
| fcdomain     | Gather detailed information for fcdomain troubleshooting           |
| commands     | (Optional) Show commands run as part of fcdomain technical support |

## Command Mode

- /exec



# show tech-support fcns

show tech-support fcns [ vsan <i0> ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                    |
| tech-support | Gather information for troubleshooting                             |
| fcns         | Show information for fcns technical support                        |
| vsan         | (Optional) Show technical support information for a specified vsan |
| <i>i0</i>    | (Optional) VSAN id range   |

## Command Mode

- /exec

# show tech-support fcoe

show tech-support fcoe

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for troubleshooting           |
| fcoe         | Gather information for FCOE mgr trouble shooting |

## Command Mode

- /exec

# show tech-support fcs

show tech-support fcs

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| fcs          | Gather detailed information for fcs troubleshooting |

## Command Mode

- /exec

# show tech-support feature

show tech-support feature [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information  |
| tech-support | Gather information for troubleshooting                                 |
| feature      | Gather detailed information for feature troubleshooting                |
| commands     | (Optional) Show commands executed as part of show tech-support feature |

## Command Mode

- /exec

# show tech-support fib-all

show tech-support fib-all

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| fib-all      | Gather detailed information for FC/FCoE FIB from all modules |

## Command Mode

- /exec

# show tech-support fib module

show tech-support fib module <module>

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information                             |
| tech-support  | Gather information for troubleshooting                      |
| fib           | Gather detailed information for FC/FCoE FIB troubleshooting |
| module        | Gather info related to a fib                                |
| <i>module</i> | Enter module number   |

## Command Mode

- /exec

# show tech-support fips

show tech-support fips

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information            |
| tech-support | Gather information for troubleshooting     |
| fips         | show tech support information for security |

## Command Mode

- /exec

# show tech-support flogi

show tech-support flogi

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                       |
| tech-support | Gather information for troubleshooting                |
| flogi        | Gather detailed information for flogi troubleshooting |

## Command Mode

- /exec



# show tech-support forwarding l2 multicast

show tech-support forwarding l2 multicast

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| l2           | layer 2 debug information    |
| multicast    | multicast                    |

## Command Mode

- /exec

# show tech-support forwarding l2 multicast vdc-all

show tech-support forwarding l2 multicast vdc-all

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| l2           | layer 2 debug information    |
| multicast    | multicast                    |
| vdc-all      | vdc-all                      |

## Command Mode

- /exec

# show tech-support forwarding l2 unicast

show tech-support forwarding l2 unicast [ module <module> ]

## Syntax Description

|               |   |
|---------------|---|
| show          | show tech-support                       |
| tech-support  | Gather information for trouble-shooting |
| forwarding    | Forwarding debug info                   |
| l2            | layer 2 debug info                      |
| unicast       | unicast                                 |
| module        | (Optional) Slot number                  |
| <i>module</i> | (Optional) Module Number                |

## Command Mode

- /exec

# show tech-support forwarding l3 multicast

show tech-support forwarding l3 multicast

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| l3           | layer 3 debug information    |
| multicast    | multicast                    |

## Command Mode

- /exec

# show tech-support forwarding l3 multicast detail vdc-all

show tech-support forwarding l3 multicast detail vdc-all

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| l3           | layer 3 debug information    |
| multicast    | multicast                    |
| detail       | detail                       |
| vdc-all      | vdc-all                      |

## Command Mode

- /exec

# show tech-support forwarding l3 multicast detail

show tech-support forwarding l3 multicast detail

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| l3           | layer 3 debug information    |
| multicast    | multicast                    |
| detail       | detail                       |

## Command Mode

- /exec

# show tech-support forwarding l3 multicast vdc-all

show tech-support forwarding l3 multicast vdc-all

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| l3           | layer 3 debug information    |
| multicast    | multicast                    |
| vdc-all      | vdc-all                      |

## Command Mode

- /exec

# show tech-support forwarding l3 unicast

show tech-support forwarding l3 unicast [ module <module> ] [ list ]

## Syntax Description

|               |  |
|---------------|--|
| show          |  |
| tech-support  | tech-support information                             |
| forwarding    | forwarding debug information                         |
| l3            | layer 3 debug information                            |
| unicast       | unicast  |
| module        | (Optional) module                                    |
| <i>module</i> | (Optional) module number                             |
| list          | (Optional) list the commands, without executing them |

## Command Mode

- /exec



# show tech-support forwarding l3 unicast detail

show tech-support forwarding l3 unicast detail [ module <module> ] [ list ]

## Syntax Description

|               |  |
|---------------|--|
| show          |  |
| tech-support  | tech-support information                             |
| forwarding    | forwarding debug information                         |
| l3            | layer 3 debug information                            |
| unicast       | unicast  |
| detail        | detailed show tech including platform commands       |
| module        | (Optional) module                                    |
| <i>module</i> | (Optional) module number                             |
| list          | (Optional) list the commands, without executing them |

## Command Mode

- /exec

# show tech-support forwarding l3 unicast detail vdc-all

show tech-support forwarding l3 unicast detail vdc-all [ module <module> ]

## Syntax Description

|               |  |
|---------------|--|
| show          |  |
| tech-support  | tech-support information                       |
| forwarding    | forwarding debug information                   |
| l3            | layer 3 debug information                      |
| unicast       | unicast  |
| detail        | detailed show tech including platform commands |
| vdc-all       | vdc-all  |
| module        | (Optional) module                              |
| <i>module</i> | (Optional) module number                       |

## Command Mode

- /exec

# show tech-support forwarding l3 unicast vdc-all

show tech-support forwarding l3 unicast vdc-all [ module <module> ]

## Syntax Description

|               |                              |
|---------------|------------------------------|
| show          |                              |
| tech-support  | tech-support information     |
| forwarding    | forwarding debug information |
| l3            | layer 3 debug information    |
| unicast       | unicast                      |
| vdc-all       | vdc-all                      |
| module        | (Optional) module            |
| <i>module</i> | (Optional) module number     |

## Command Mode

- /exec

# show tech-support forwarding mpls

show tech-support forwarding mpls [ module <module> ] [ evpn ]

## Syntax Description

|               |                                      |
|---------------|--------------------------------------|
| show          |                                      |
| tech-support  | tech-support information             |
| forwarding    | forwarding debug information         |
| mpls          | mpls related information             |
| module        | (Optional) module                    |
| <i>module</i> | (Optional) module number             |
| evpn          | (Optional) evpn related tech support |

## Command Mode

- /exec

# show tech-support forwarding multicast

show tech-support forwarding multicast [ module <module> ]

## Syntax Description

|               |                              |
|---------------|------------------------------|
| show          |                              |
| tech-support  | tech-support information     |
| forwarding    | forwarding debug information |
| multicast     | multicast                    |
| module        | (Optional) module            |
| <i>module</i> | (Optional) module number     |

## Command Mode

- /exec

# show tech-support forwarding multicast nat

show tech-support forwarding multicast nat

## Syntax Description

|              |                              |
|--------------|------------------------------|
| show         |                              |
| tech-support | tech-support information     |
| forwarding   | forwarding debug information |
| multicast    | multicast                    |
| nat          | Inat/Enat debug information  |

## Command Mode

- /exec

## show tech-support forwarding srv6

show tech-support forwarding srv6 [ module <module> ]

### Syntax Description

|               |                              |
|---------------|------------------------------|
| show          |                              |
| tech-support  | tech-support information     |
| forwarding    | forwarding debug information |
| srv6          | srv6 debug information       |
| module        | (Optional) module            |
| <i>module</i> | (Optional) module number     |

### Command Mode

- /exec

# show tech-support frequency synchronization

show tech-support frequency synchronization

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information   |
| tech-support    | Gather information for troubleshooting                                    |
| frequency       | Gather detailed information for frequency synchronization troubleshooting |
| synchronization | Gather detailed information for frequency synchronization troubleshooting |

## Command Mode

- /exec



# show tech-support fspf

show tech-support fspf [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                |
| tech-support | Gather information for troubleshooting                         |
| fspf         | Show information for fspf technical support                    |
| commands     | (Optional) Show commands run as part of fspf technical support |

## Command Mode

- /exec

# show tech-support fsync\_mgr

show tech-support fsync\_mgr [ detail ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for trouble shooting          |
| fsync_mgr    | Gather information for fsync_mgr troubleshooting |
| detail       | (Optional) Show more details                     |

## Command Mode

- /exec

# show tech-support gold

show tech-support gold

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| gold         | Show gold tech-support information      |

## Command Mode

- /exec

# show tech-support gpixm

show tech-support gpixm

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                             |
| tech-support | Gather information for troubleshooting                      |
| gpixm        | Gather detailed information for GLOBAL-PIXM troubleshooting |

## Command Mode

- /exec

# show tech-support ha

show tech-support ha [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information  |
| tech-support | Gather information for troubleshooting                                     |
| ha           | Gather detailed information for HA troubleshooting                         |
| commands     | (Optional) Show commands executed as part of show tech-support ha commands |

## Command Mode

- /exec

# show tech-support ha module

show tech-support ha module <module>

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information                    |
| tech-support  | Gather information for troubleshooting             |
| ha            | Gather detailed information for HA troubleshooting |
| module        | Gather info related to a module                    |
| <i>module</i> | Enter module number                                |

## Command Mode

- /exec

# show tech-support ha\_short

show tech-support ha\_short [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information  |
| tech-support | Gather information for troubleshooting                                     |
| ha_short     | Gather shortened version of HA tech-support for troubleshooting            |
| commands     | (Optional) Show commands executed as part of show tech-support ha commands |

## Command Mode

- /exec

# show tech-support ha standby

show tech-support ha standby [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information  |
| tech-support | Gather information for troubleshooting                                     |
| ha           | Gather detailed information for HA troubleshooting                         |
| standby      | Gather detailed information for HA troubleshooting from standby supervisor |
| commands     | (Optional) Show commands executed as part of show tech-support ha commands |

## Command Mode

- /exec



# show tech-support hardware-telemetry

show tech-support hardware-telemetry

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information        |
| tech-support       | Gather information for troubleshooting |
| hardware-telemetry | Hardware Telemetry Information         |

## Command Mode

- /exec

# show tech-support hsrp

show tech-support hsrp

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| hsrp         | Show hsrp tech-support information      |

## Command Mode

- /exec

# show tech-support hsrp brief

show tech-support hsrp brief

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| hsrp         | Show hsrp tech-support information      |
| brief        | Show tech-support information in brief  |

## Command Mode

- /exec

# show tech-support icam

show tech-support icam [ detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| icam         | icam - TCAM Analytics                   |
| detail       | (Optional) Show more details            |

## Command Mode

- /exec

# show tech-support icmpv6

show tech-support icmpv6 [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| icmpv6       | Display Icmpv6 information             |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support im

show tech-support im

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                    |
| tech-support | Gather information for troubleshooting             |
| im           | Gather detailed information for IM troubleshooting |

## Command Mode

- /exec

# show tech-support imp

show tech-support imp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| imp          | IMP commands                           |

## Command Mode

- /exec

# show tech-support inband counters

show tech-support inband counters

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information               |
| tech-support | Gather information for troubleshooting        |
| inband       | Gather all information about inband data path |
| counters     | Gather all counters in inband data path       |

## Command Mode

- /exec



# show tech-support include-time

show tech-support include-time

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                    |
| tech-support | Gather information for troubleshooting                             |
| include-time | Gather tech-support and capture time taken to execute each command |

## Command Mode

- /exec

# show tech-support install

show tech-support install

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                               |
| tech-support | Gather information for trouble shooting                       |
| install      | Gather detailed information for rpm/package install operation |

## Command Mode

- /exec

# show tech-support interface-vlan

show tech-support interface-vlan

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                                |
| tech-support   | Gather information for troubleshooting                         |
| interface-vlan | Gather detailed information for interface-vlan troubleshooting |

## Command Mode

- /exec

# show tech-support interfaces all

show tech-support interfaces all

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                            |
| tech-support | Gather information for troubleshooting                     |
| interfaces   | Gather information for interfaces troubleshooting          |
| all          | Gather detailed information for interfaces troubleshooting |

## Command Mode

- /exec

# show tech-support ip

show tech-support ip [ brief | static-routes ]

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information        |
| tech-support  | Gather information for troubleshooting |
| ip            | Display IP information                 |
| brief         | (Optional) Brief information           |
| static-routes | (Optional) Static-Routes information   |

## Command Mode

- /exec

# show tech-support ip igmp

show tech-support ip igmp [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ip           | Display IP information                 |
| igmp         | Display IGMP status and configuration  |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support ip igmp snooping

show tech-support ip igmp snooping [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ip           | Display IP information                 |
| igmp         | Display IGMP status and configuration  |
| snooping     | IGMP Snooping information              |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support ip msdp

show tech-support ip msdp [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ip           | Display IP information                 |
| msdp         | Display MSDP status and configuration  |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec



# show tech-support ip pim

show tech-support ip pim [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ip           | Display IP information                 |
| pim          | PIM global configuration commands      |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support ipqos

show tech-support ipqos [ server-only ] [ all ] [ snmp ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information   |
| tech-support | Gather information for troubleshooting  |
| server-only  | (Optional) Dump the tech-support information only from IP QoS Manager server only             |
| all          | (Optional) Dump the tech-support information IP QoS Manager plus brief summary of system      |
| snmp         | (Optional) Dump the tech-support information only from IP QoS Manager server only (SNMP only) |

## Command Mode

- /exec

# show tech-support ipv6

show tech-support ipv6 [ brief | static-routes ]

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information        |
| tech-support  | Gather information for troubleshooting |
| ipv6          | Display IPv6 information               |
| brief         | (Optional) Brief information           |
| static-routes | (Optional) Static-Routes information   |

## Command Mode

- /exec

# show tech-support ipv6 mfwd

show tech-support ipv6 mfwd [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| tech-support | Gather information for troubleshooting       |
| ipv6         | Display IPv6 information                     |
| mfwd         | Display MCASTFWD v6 status and configuration |
| brief        | (Optional) Brief information                 |

## Command Mode

- /exec

# show tech-support ipv6 mld

show tech-support ipv6 mld [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for troubleshooting           |
| ipv6         | Display IPv6 information                         |
| mld          | Display Multicast Listener Discovery information |
| brief        | (Optional) Brief information                     |

## Command Mode

- /exec

# show tech-support ipv6 mld snooping

show tech-support ipv6 mld snooping [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for troubleshooting           |
| ipv6         | Display IPv6 information                         |
| mld          | Display Multicast Listener Discovery information |
| snooping     | MLD Snooping information                         |
| brief        | (Optional) Brief information                     |

## Command Mode

- /exec

# show tech-support ipv6 multicast

show tech-support ipv6 multicast

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ipv6         | Display IPv6 information               |
| multicast    | Display V6 Multicast information       |

## Command Mode

- /exec

# show tech-support ipv6 pim

show tech-support ipv6 pim [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ipv6         | Display IPv6 information               |
| pim          | PIM6 global configuration commands     |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec



# show tech-support isis

show tech-support isis [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| isis         | IS-IS events                            |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support issu

show tech-support issu [ commands ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information   |
| tech-support | Gather information for troubleshooting                                      |
| issu         | Gather detailed information for issu troubleshooting                        |
| commands     | (Optional) Show commands executed as part of show tech-support issu command |

## Command Mode

- /exec

# show tech-support kstack

show tech-support kstack

## Syntax Description

|              |                          |
|--------------|--------------------------|
| show         |                          |
| tech-support | tech-support information |
| kstack       | kstack information       |

## Command Mode

- /exec

# show tech-support l2

show tech-support l2

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                         |
| tech-support | Gather information for troubleshooting                  |
| l2           | Gather detailed information for layer 2 troubleshooting |

## Command Mode

- /exec

# show tech-support l2fm

show tech-support l2fm

## Syntax Description

|              |   |
|--------------|---|
| show         | show tech-support                       |
| tech-support | Gather information for trouble-shooting |
| l2fm         | l2fm debug info                         |

## Command Mode

- /exec

# show tech-support l2fm clients

show tech-support l2fm clients [ module <module> ]

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information                          |
| tech-support  | Gather information for troubleshooting                   |
| l2fm          | l2fm debug info  |
| clients       | debug info of l2fm clients only running on linecard(mtm) |
| module        | (Optional) Slot number                                   |
| <i>module</i> | (Optional) Module Number                                 |

## Command Mode

- /exec

# show tech-support l2fm detail

show tech-support l2fm detail [ module <module> ]

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information           |
| tech-support  | Gather information for troubleshooting    |
| l2fm          | l2fm debug info                           |
| detail        | All info related to l2fm                  |
| module        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>module</i> | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

## Command Mode

- /exec

# show tech-support l2fm l2dbg

show tech-support l2fm l2dbg [ module <module> ]

## Syntax Description

|               |  |
|---------------|--|
| show          | show tech-support  |
| tech-support  | Gather information for trouble-shooting                      |
| l2fm          | l2fm debug info  |
| l2dbg         | tech support capturing additional debug info for l2fm(l2dbg) |
| module        | (Optional) Slot number                                       |
| <i>module</i> | (Optional) Module Number                                     |

## Command Mode

- /exec



# show tech-support l2fm l2dbg

show tech-support l2fm l2dbg [ module <module> ]

## Syntax Description

|               |  |
|---------------|--|
| show          | show tech-support  |
| tech-support  | Gather information for trouble-shooting                      |
| l2fm          | l2fm debug info  |
| l2dbg         | tech support capturing additional debug info for l2fm(l2dbg) |
| module        | (Optional) Slot number                                       |
| <i>module</i> | (Optional) Module Number                                     |

## Command Mode

- /exec

# show tech-support l2rib

show tech-support l2rib

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| l2rib        | Display L2RIB information              |

## Command Mode

- /exec

# show tech-support l3vm

show tech-support l3vm [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| l3vm         | Display VRF information                |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support l3vpn

show tech-support l3vpn [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| l3vpn        | BGP l3vpn information                  |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support lacp

show tech-support lacp [ all ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                                       |
| tech-support | Gather information for troubleshooting                                |
| lacp         | Gather detailed information for LACP component                        |
| all          | (Optional) Gather detailed information of LACP and related components |

## Command Mode

- /exec

# show tech-support ldap

show tech-support ldap

## Syntax Description

|              |  |
|--------------|--|
| show         | show tech-support                      |
| tech-support | Gather information for troubleshooting |
| ldap         | Display ldap information               |

## Command Mode

- /exec

# show tech-support license

show tech-support license

## Syntax Description

|              |  |
|--------------|--|
| show         | show commands                          |
| tech-support | Gather information for troubleshooting |
| license      | Display licensing information          |

## Command Mode

- /exec

# show tech-support lim

show tech-support lim

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| lim          | Gather detailed information for LIM troubleshooting |

## Command Mode

- /exec



# show tech-support lisp

show tech-support lisp [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| lisp         | LISP show commands                     |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support lldp

show tech-support lldp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| tech-support | Gather information for troubleshooting               |
| lldp         | Gather detailed information for LLDP troubleshooting |

## Command Mode

- /exec

# show tech-support logging

show tech-support logging

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                         |
| tech-support | Gather information for troubleshooting                  |
| logging      | Show information on logging for technical support staff |

## Command Mode

- /exec

# show tech-support m2rib

show tech-support m2rib

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                       |
| tech-support | Gather information for troubleshooting                |
| m2rib        | Gather detailed information for M2RIB troubleshooting |

## Command Mode

- /exec

# show tech-support macsec

show tech-support macsec

## Syntax Description

|              |   |
|--------------|---|
| tech-support | Gather information for troubleshooting        |
| macsec       | Gather information for macsec troubleshooting |

## Command Mode

- /exec

# show tech-support macsec detail

show tech-support macsec detail [ module <module> ]

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information           |
| tech-support  | Gather information for troubleshooting    |
| macsec        | macsec debug info                         |
| detail        | All info related to MACsec                |
| module        | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| <i>module</i> | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |

## Command Mode

- /exec

# show tech-support mfwd

show tech-support mfwd [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information           |
| tech-support | Gather information for troubleshooting    |
| mfwd         | Display MCASTFWD status and configuration |
| brief        | (Optional) Brief information              |

## Command Mode

- /exec

# show tech-support mmode

show tech-support mmode

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| tech-support | Gather information for troubleshooting       |
| mmode        | Gather information for troubleshooting mmode |

## Command Mode

- /exec



# show tech-support module

show tech-support module <module>

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information        |
| tech-support  | Gather information for troubleshooting |
| module        | Gather info related to a module        |
| <i>module</i> | Enter module number                    |

## Command Mode

- /exec

# show tech-support module all

show tech-support module all

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for troubleshooting           |
| module       | Gather info related to a module                  |
| all          | Gather info related to all modules in the system |

## Command Mode

- /exec

# show tech-support monitor

show tech-support monitor

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                         |
| tech-support | Gather information for troubleshooting                  |
| monitor      | Gather detailed information for monitor troubleshooting |

## Command Mode

- /exec

# show tech-support monitor erspan

show tech-support monitor erspan

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                |
| tech-support | Gather information for troubleshooting                         |
| monitor      | Gather detailed information for monitor troubleshooting        |
| erspan       | Gather detailed information for erspan session troubleshooting |

## Command Mode

- /exec

# show tech-support monitorc-all

show tech-support monitorc-all

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                             |
| tech-support | Gather information for troubleshooting                      |
| monitorc-all | Gather detailed information for LC MONITORC troubleshooting |

## Command Mode

- /exec

# show tech-support mpls manager

```
{ show tech-support mpls manager }
```

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| mpls         | MPLS                                   |
| manager      | MPLS-Mgr                               |

## Command Mode

- /exec

# show tech-support mpls oam

show tech-support mpls oam

## Syntax Description

|              |                                       |
|--------------|---------------------------------------|
| show         | Show running system information       |
| tech-support | Gather MPLS OAM information           |
| mpls         | Display MPLS status and configuration |
| oam          | Gather MPLS OAM information           |

## Command Mode

- /exec

# show tech-support mpls static

show tech-support mpls static [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                             |
| tech-support | Gather information for troubleshooting                      |
| mpls         | Display MPLS status and configuration                       |
| static       | Display STATIC configuration and status for troubleshooting |
| brief        | (Optional) Brief information                                |

## Command Mode

- /exec



# show tech-support mpls strip

show tech-support mpls strip

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| tech-support | Gather information for trouble shooting      |
| mpls         | MPLS   |
| strip        | Gather MPLS label strip troubleshooting info |

## Command Mode

- /exec

# show tech-support mpls switching

show tech-support mpls switching

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information           |
| tech-support | Gather MPLS switching information         |
| mpls         | Display MPLS status and configuration     |
| switching    | Display the MPLS label switching database |

## Command Mode

- /exec

# show tech-support mpls fwd

show tech-support mpls fwd [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| mplsfwd      | Display MPLS forwarding information    |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support multicast-vxlan-evpn

show tech-support multicast-vxlan-evpn

## Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information         |
| tech-support         | Gather information for trouble shooting |
| multicast-vxlan-evpn | Multicast VxLAN EVPN feature            |

## Command Mode

- /exec

# show tech-support multicast

show tech-support [ ip | ipv4 ] multicast

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ip           | (Optional) Display IP information      |
| ipv4         | (Optional) Display IP information      |
| multicast    | Display V4 Multicast information       |

## Command Mode

- /exec

# show tech-support mvpn

show tech-support mvpn [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| mvpn         | Display Multicast VPN information      |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support nat

show tech-support nat

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information            |
| tech-support | Gather information for troubleshooting     |
| nat          | Gather information for troubleshooting NAT |

## Command Mode

- /exec

# show tech-support nbm

show tech-support nbm [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble-shooting |
| nbm          | Non Blocking Multicast                  |
| brief        | (Optional) Minimal information          |

## Command Mode

- /exec



# show tech-support nbm group

show tech-support nbm group <grp> [ source <src> ] [ vrf { <vrf-name> | <nbm-vrf-known-name> | all } ]

## Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information         |
| tech-support              | Gather information for trouble-shooting |
| nbm                       | Non Blocking Multicast                  |
| group                     | Multicast group                         |
| <i>grp</i>                | Multicast group address                 |
| source                    | (Optional) Source IP address            |
| <i>src</i>                | (Optional) Source unicast IP address    |
| vrf                       | (Optional) Display per-VRF information  |
| all                       | (Optional) Display all VRFs             |
| <i>vrf-name</i>           | (Optional) VRF name                     |
| <i>nbm-vrf-known-name</i> | (Optional) NBM VRF Name                 |

## Command Mode

- /exec

# show tech-support netflow

show tech-support netflow [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| netflow      | Show NetFlow tech-support information   |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support netstack

show tech-support netstack

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                 |
| tech-support | Gather information for troubleshooting          |
| netstack     | Gather information for NETSTACK troubleshooting |

## Command Mode

- /exec

# show tech-support netstack detail

show tech-support netstack detail

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| tech-support | Gather information for troubleshooting                   |
| netstack     | Gather information for NETSTACK troubleshooting          |
| detail       | Gather detailed information for NETSTACK troubleshooting |

## Command Mode

- /exec

# show tech-support nexus9000v

show tech-support nexus9000v

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information   |
| tech-support | Gather information for trouble shooting   |
| nexus9000v   | Gather information for Nexus 9000v virtualization infrastructure trouble shooting |

## Command Mode

- /exec

# show tech-support ngoam

show tech-support ngoam

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble-shooting |
| ngoam        | ngoam                                   |

## Command Mode

- /exec

# show tech-support npacl

show tech-support npacl [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| npacl        | Display npacl information              |
| brief        | (Optional) Brief npacl information     |

## Command Mode

- /exec

# show tech-support npv

show tech-support npv

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for troubleshooting           |
| npv          | Show information for NPV technical support staff |

## Command Mode

- /exec



# show tech-support ns

show tech-support ns

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                |
| tech-support | Gather information for troubleshooting         |
| ns           | Gather detailed information for northstar asic |

## Command Mode

- /exec

# show tech-support ntp

show tech-support ntp

## Syntax Description

|              |   |
|--------------|---|
| show         | show running system information             |
| tech-support | Gather information for trouble shooting     |
| ntp          | Gather information for NTP trouble shooting |

## Command Mode

- /exec

# show tech-support nve

show tech-support nve

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| nve          | Display NVE information                 |

## Command Mode

- /exec

# show tech-support nxapi

show tech-support nxapi

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                       |
| tech-support | Gather information for troubleshooting                |
| nxapi        | Gather detailed information for nxapi troubleshooting |

## Command Mode

- /exec

# show tech-support nxsdk

show tech-support nxsdk

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| nxsdk        | NXOS SDK                               |

## Command Mode

- /exec

# show tech-support object-store

show tech-support object-store

## Syntax Description

|              |   |
|--------------|---|
| show         | Show Object Store   |
| tech-support | Gather information for troubleshooting                              |
| object-store | Gather information from object store for Controller troubleshooting |

## Command Mode

- /exec

# show tech-support ofm

show tech-support ofm [ server-only ] [ flow-interface ] [ all ]

## Syntax Description

|                |   |
|----------------|---|
| show           | Show running system information   |
| tech-support   | Gather information for troubleshooting  |
| server-only    | (Optional) Dump the tech-support information only from Overlay Flow Manager server only |
| flow-interface | (Optional) Dump the tech-support info for OFM ELTM IFTMC and SDK components             |
| all            | (Optional) Dump the tech-support information OFM plus brief summary of system           |

## Command Mode

- /exec

# show tech-support openflow

show tech-support openflow [ brief | detailed ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| openflow     | Show tech support for OpenFlow          |
| brief        | (Optional) Brief information            |
| detailed     | (Optional) Detailed information         |

## Command Mode

- /exec



# show tech-support openflow platform

show tech-support openflow platform

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| openflow     | openflow component                     |
| platform     | openflow platform components           |

## Command Mode

- /exec

# show tech-support ospf

show tech-support ospf [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| ospf         | Display OSPF status and configuration  |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support ospfv3

show tech-support ospfv3 [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for troubleshooting  |
| ospfv3       | Display OSPFv3 status and configuration |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support otv isis

show tech-support otv isis [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| otv          | IS-IS events                            |
| isis         | IS-IS events                            |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support page

show tech-support page [ time-optimized ] [ forced ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information  |
| tech-support   | Gather information for troubleshooting                                     |
| page           | Page through the output  |
| time-optimized | (Optional) Gather tech-support faster, requires more memory and disk space |
| forced         | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                                  |

## Command Mode

- /exec

# show tech-support patch

show tech-support patch

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                       |
| tech-support | Gather information for troubleshooting                |
| patch        | Gather detailed information for patch troubleshooting |

## Command Mode

- /exec

# show tech-support pbr

{ show tech-support pbr }

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                |
| tech-support | Gather information for troubleshooting         |
| pbr          | Display Policy Based Routing (PBR) information |

## Command Mode

- /exec

# show tech-support pfstat

show tech-support pfstat

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                        |
| tech-support | Gather information for troubleshooting                 |
| pfstat       | Gather detailed information for pfstat troubleshooting |

## Command Mode

- /exec



# show tech-support pixm-all

show tech-support pixm-all

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| tech-support | Gather information for troubleshooting               |
| pixm-all     | Gather detailed information for PIXM troubleshooting |

## Command Mode

- /exec

# show tech-support pixm

show tech-support pixm

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                |
| tech-support | Gather information for troubleshooting                         |
| pixm         | Gather detailed information for vdc-local-PIXM troubleshooting |

## Command Mode

- /exec

# show tech-support pixmc-all

show tech-support pixmc-all

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                          |
| tech-support | Gather information for troubleshooting                   |
| pixmc-all    | Gather detailed information for LC PIXMC troubleshooting |

## Command Mode

- /exec

# show tech-support pktmgr

show tech-support pktmgr [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| pktmgr       | Display Packet Manager information     |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support platform-sdk

show tech-support platform-sdk

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| platform-sdk | Gather detailed information for platform-sdk troubleshooting |

## Command Mode

- /exec

# show tech-support platform

show tech-support platform

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| platform     | Get platform related information       |

## Command Mode

- /exec

# show tech-support plcmgr

show tech-support plcmgr [ detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                   |
| tech-support | Gather information for troubleshooting            |
| plcmgr       | Policy Manager                                    |
| detail       | (Optional) Print more details (e.g. messages,etc) |

## Command Mode

- /exec

# show tech-support pltfm-config

show tech-support pltfm-config

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| pltfm-config | Gather detailed information for pltfm-config troubleshooting |

## Command Mode

- /exec



# show tech-support pnp

show tech-support pnp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information          |
| tech-support | Gather information for troubleshooting   |
| pnp          | Show Technical support for Plug and Play |

## Command Mode

- /exec

# show tech-support poe

show tech-support poe

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information             |
| tech-support | Gather information for troubleshooting      |
| poe          | Gather information for PoE trouble shooting |

## Command Mode

- /exec

# show tech-support port-channel

show tech-support port-channel

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| port-channel | Gather detailed information for port channel troubleshooting |

## Command Mode

- /exec

# show tech-support port-client-all

show tech-support port-client-all

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                                |
| tech-support    | Gather information for troubleshooting                         |
| port-client-all | Gather detailed information for LC port client troubleshooting |

## Command Mode

- /exec

# show tech-support port-profile

show tech-support port-profile

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| tech-support | Gather information for troubleshooting               |
| port-profile | Gather information for troubleshooting port-profiles |

## Command Mode

- /exec

# show tech-support port-security

show tech-support port-security

## Syntax Description

|               |   |
|---------------|---|
| show          | Show running system information         |
| tech-support  | Gather information for trouble shooting |
| port-security | Port security related command           |

## Command Mode

- /exec

# show tech-support port

show tech-support port

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| port         | Gather detailed information for port manager troubleshooting |

## Command Mode

- /exec

# show tech-support private-vlan

show tech-support private-vlan

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                              |
| tech-support | Gather information for troubleshooting                       |
| private-vlan | Gather detailed information for private-vlan troubleshooting |

## Command Mode

- /exec



# show tech-support pss

show tech-support pss

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| pss          | Gather detailed information for PSS troubleshooting |

## Command Mode

- /exec

# show tech-support ptp

show tech-support ptp

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| ptp          | Gather detailed information for PTP troubleshooting |

## Command Mode

- /exec

# show tech-support radius

show tech-support radius

## Syntax Description

|              |  |
|--------------|--|
| show         | show tech-support                      |
| tech-support | Gather information for troubleshooting |
| radius       | Display radius information             |

## Command Mode

- /exec

# show tech-support rib

show tech-support rib

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| rib          | Gather detailed information for rib troubleshooting |

## Command Mode

- /exec

# show tech-support rip

show tech-support rip [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| rip          | Display RIP routing protocol status    |
| brief        | (Optional) Brief information           |

## Command Mode

- /exec

# show tech-support routing

show tech-support routing [ ip | ipv4 ] [ unicast ] [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                |
| tech-support | Gather information for troubleshooting         |
| routing      | Display routing information                    |
| ip           | (Optional) Display IP information              |
| ipv4         | (Optional) Display IP information              |
| unicast      | (Optional) Display unicast routing information |
| brief        | (Optional) Brief information                   |

## Command Mode

- /exec

# show tech-support routing ipv6

show tech-support routing ipv6 [ unicast ] [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                |
| tech-support | Gather information for troubleshooting         |
| routing      | Display routing information                    |
| ipv6         | Display IPv6 information                       |
| unicast      | (Optional) Display unicast routing information |
| brief        | (Optional) Brief information                   |

## Command Mode

- /exec

# show tech-support routing ipv6 multicast

show tech-support routing ipv6 multicast [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| routing      | Display routing information            |
| ipv6         | Display IPv6 information               |
| multicast    | Display V6 Multicast information       |
| brief        | (Optional) Display brief information   |

## Command Mode

- /exec



# show tech-support routing multicast

show tech-support routing [ ip | ipv4 ] multicast [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| routing      | Display routing information            |
| ip           | (Optional) Display IP information      |
| ipv4         | (Optional) Display IP information      |
| multicast    | Display V4 Multicast information       |
| brief        | (Optional) Display brief information   |

## Command Mode

- /exec

# show tech-support rpm

```
{ show tech-support rpm }
```

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                |
| tech-support | Gather information for troubleshooting         |
| rpm          | Display Route Policy Manager (RPM) information |

## Command Mode

- /exec

# show tech-support rscn

show tech-support rscn [ vsan <i0> ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                    |
| tech-support | Gather information for troubleshooting                             |
| vsan         | (Optional) Show technical support information for a specified vsan |
| <i>i0</i>    | (Optional) VSAN id range   |

## Command Mode

- /exec

# show tech-support sal

show tech-support sal

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| sal          | Show SAL tech-support information       |

## Command Mode

- /exec

# show tech-support san-port-channel

show tech-support san-port-channel

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                                  |
| tech-support     | Gather information for troubleshooting                           |
| san-port-channel | Gather detailed information for san port channel troubleshooting |

## Command Mode

- /exec

# show tech-support san

show tech-support san

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information             |
| tech-support | Gather information for troubleshooting      |
| san          | Gather information for SAN trouble shooting |

## Command Mode

- /exec

# show tech-support satmgr

show tech-support satmgr

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                        |
| tech-support | Gather information for troubleshooting                 |
| satmgr       | Gather detailed information for satmgr troubleshooting |

## Command Mode

- /exec

# show tech-support security

show tech-support security

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information            |
| tech-support | Gather information for troubleshooting     |
| security     | show tech support information for security |

## Command Mode

- /exec



# show tech-support segment-routing

show tech-support segment-routing

## Syntax Description

|                 |                                 |
|-----------------|---------------------------------|
| show            | Show running system information |
| tech-support    | Gather tech-support information |
| segment-routing | Segment-routing tech-support    |

## Command Mode

- /exec

# show tech-support services

show tech-support services [ detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| services     | Services                                |
| detail       | (Optional) Show more details            |

## Command Mode

- /exec

# show tech-support session-mgr

show tech-support session-mgr

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                        |
| tech-support | Gather information for troubleshooting                 |
| session-mgr  | Gather information for troubleshooting session manager |

## Command Mode

- /exec

# show tech-support sflow

show tech-support sflow

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information               |
| tech-support | Gather information for troubleshooting        |
| sflow        | Gather detailed information for sflow feature |

## Command Mode

- /exec

# show tech-support single-jericho

show tech-support single-jericho

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                                |
| tech-support   | Gather information for troubleshooting                         |
| single-jericho | Gather detailed information for single-jericho troubleshooting |

## Command Mode

- /exec

# show tech-support sksd

show tech-support sksd

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| sksd         | show tech support information for sksd |

## Command Mode

- /exec

# show tech-support sla responder

show tech-support sla responder [ brief | detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| sla          | Service Level Agreement (SLA)           |
| responder    | Configure sla-responder tech support    |
| brief        | (Optional) Show less details            |
| detail       | (Optional) Show more details            |

## Command Mode

- /exec

# show tech-support sla sender

show tech-support sla sender [ brief | detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| sla          | Service Level Agreement (SLA)           |
| sender       | Configure sla-sender tech support       |
| brief        | (Optional) Show less details            |
| detail       | (Optional) Show more details            |

## Command Mode

- /exec



# show tech-support sla twamp-server

show tech-support sla twamp-server [ brief | detail ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| sla          | Service Level Agreement (SLA)           |
| twamp-server | Configure sla-twamp-server tech support |
| brief        | (Optional) Show less details            |
| detail       | (Optional) Show more details            |

## Command Mode

- /exec

# show tech-support slowdrain

show tech-support slowdrain [ commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information  |
| tech-support | Gather information for troubleshooting   |
| slowdrain    | Gather detailed information for slowdrain troubleshooting                        |
| commands     | (Optional) Show commands executed as part of show tech-support slowdrain command |

## Command Mode

- /exec

# show tech-support smm

show tech-support smm

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| smm          | Shared memory                          |

## Command Mode

- /exec

# show tech-support snmp

show tech-support snmp

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| snmp         | Gather info related to snmp            |

## Command Mode

- /exec

# show tech-support sockets

show tech-support sockets [ brief ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information          |
| tech-support | Gather information for troubleshooting   |
| sockets      | Display sockets status and configuration |
| brief        | (Optional) Brief information             |

## Command Mode

- /exec

# show tech-support spm

show tech-support spm [ <application> ] [ detail ]

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                   |
| tech-support       | Gather information for troubleshooting            |
| spm                | Service Policy Manager                            |
| <i>application</i> | (Optional) Specify an application                 |
| detail             | (Optional) Print more details (e.g. messages,etc) |

## Command Mode

- /exec

# show tech-support srte

show tech-support srte

## Syntax Description

|              |                                 |
|--------------|---------------------------------|
| show         | Show running system information |
| tech-support | Gather SRTE information         |
| srte         | Segment-Routing Traffic Eng     |

## Command Mode

- /exec

# show tech-support statsclient

show tech-support statsclient [ module <module> ]

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information              |
| tech-support  | Gather information for troubleshooting       |
| statsclient   | Gather statsclient tech-support              |
| module        | (Optional) Gather info related to one module |
| <i>module</i> | (Optional) Enter module number               |

## Command Mode

- /exec



# show tech-support stp

show tech-support stp

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| stp          | Gather detailed information for STP troubleshooting |

## Command Mode

- /exec

# show tech-support sup-filesys

show tech-support sup-filesys

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| sup-filesys  | File-sys related issue                 |

## Command Mode

- /exec

# show tech-support super-bridging

show tech-support super-bridging

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information                                |
| tech-support   | Gather information for troubleshooting                         |
| super-bridging | Gather detailed information for super-bridging troubleshooting |

## Command Mode

- /exec

# show tech-support sysmgr

show tech-support sysmgr [ commands ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                                       |
| tech-support | Gather information for troubleshooting                                |
| sysmgr       | Gather detailed information for sysmgr troubleshooting                |
| commands     | (Optional) Show commands executed as part of show tech-support sysmgr |

## Command Mode

- /exec

# show tech-support tacacs

show tech-support tacacs +

## Syntax Description

|              |  |
|--------------|--|
| show         | show tech-support                      |
| tech-support | Gather information for troubleshooting |

## Command Mode

- /exec

# show tech-support telemetry

show tech-support telemetry

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                  |
| tech-support | Gather information for troubleshooting           |
| telemetry    | Gather information for telemetry troubleshooting |

## Command Mode

- /exec

# show tech-support track

show tech-support track

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| track        | Show track tech-support information     |

## Command Mode

- /exec

# show tech-support trm

show tech-support trm

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| trm          | Tenant Routed Multicast information    |

## Command Mode

- /exec



# show tech-support tunnel-encryption

show tech-support tunnel-encryption [ detail ]

## Syntax Description

|                   |  |
|-------------------|--|
| tech-support      | Gather information for troubleshooting                   |
| tunnel-encryption | Gather information for Tunnel-Encryption troubleshooting |
| detail            | (Optional) Detailed information                          |

## Command Mode

- /exec

# show tech-support tunnel

show tech-support tunnel [ { commands | detail [ commands1 ] } ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information  |
| tech-support | Gather information for troubleshooting                                     |
| tunnel       | Gather detailed information for tunnel troubleshooting                     |
| commands     | (Optional) Lists commands under 'show tunnel tech-support' command         |
| detail       | (Optional) Gather detailed information for tunnel troubleshooting          |
| commands1    | (Optional) Lists commands under 'Show tech-support tunnel detail' commands |

## Command Mode

- /exec

# show tech-support u2rib

show tech-support u2rib

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                       |
| tech-support | Gather information for troubleshooting                |
| u2rib        | Gather detailed information for U2RIB troubleshooting |

## Command Mode

- /exec

# show tech-support udd

show tech-support udd

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| udd          | Gather detailed information for udd troubleshooting |

## Command Mode

- /exec

# show tech-support usd-all

show tech-support usd-all [ time-optimized ]

## Syntax Description

|                |  |
|----------------|--|
| show           | Show running system information  |
| tech-support   | Gather information for troubleshooting                                     |
| usd-all        | Gather detailed information for LC USD troubleshooting                     |
| time-optimized | (Optional) Gather tech-support faster, requires more memory and disk space |

## Command Mode

- /exec

# show tech-support vdc

show tech-support vdc

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| vdc          | Gather detailed information for VDC troubleshooting |

## Command Mode

- /exec

# show tech-support virtual-service

show tech-support virtual-service

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information                                 |
| tech-support    | Gather information for trouble shooting                         |
| virtual-service | Gather information for virtualization services trouble shooting |

## Command Mode

- /exec

# show tech-support vlan

show tech-support vlan

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| tech-support | Gather information for troubleshooting               |
| vlan         | Gather detailed information for VLAN troubleshooting |

## Command Mode

- /exec



# show tech-support vmtracker

show tech-support vmtracker

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information        |
| tech-support | Gather information for troubleshooting |
| vmtracker    | VMTRACKER commands                     |

## Command Mode

- /exec

# show tech-support vpc

show tech-support vpc

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| vpc          | Gather detailed information for VPC troubleshooting |

## Command Mode

- /exec

# show tech-support vrrp

show tech-support vrrp

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information             |
| tech-support | Gather information for troubleshooting      |
| vrrp         | Show information for vrrp technical support |

## Command Mode

- /exec

# show tech-support vrrp brief

show tech-support vrrp brief

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                      |
| tech-support | Gather information for troubleshooting               |
| vrrp         | Show information for vrrp technical support          |
| brief        | Show information for vrrp technical support in brief |

## Command Mode

- /exec

# show tech-support vrrpv3

show tech-support vrrpv3 [ detail ]

## Syntax Description

|              |   |
|--------------|---|
| vrrpv3       | VRRPv3 configuration commands           |
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| detail       | (Optional) Detailed output              |

## Command Mode

- /exec

# show tech-support vsan

show tech-support vsan [ <i>i0</i> | commands ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                |
| tech-support | Gather information for troubleshooting                         |
| vsan         | Gather detailed information for vsan troubleshooting           |
| <i>i0</i>    | (Optional) VSAN id range                                       |
| commands     | (Optional) Show commands run as part of vsan technical support |

## Command Mode

- /exec

# show tech-support vshd

show tech-support vshd

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information             |
| tech-support | Show information for technical support      |
| vshd         | Show vshd information for technical support |

## Command Mode

- /exec

# show tech-support vtp

show tech-support vtp

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                     |
| tech-support | Gather information for troubleshooting              |
| vtp          | Gather detailed information for vtp troubleshooting |

## Command Mode

- /exec



# show tech-support vwan

show tech-support vwan

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                            |
| tech-support | Gather information for troubleshooting                     |
| vwan         | Gather detailed information for Voice VLAN troubleshooting |

## Command Mode

- /exec

# show tech-support vxlan-evpn

show tech-support vxlan-evpn

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| vxlan-evpn   | VxLAN evpn feature                      |

## Command Mode

- /exec

# show tech-support vxlan

show tech-support vxlan

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| vxlan        | VxLAN feature                           |

## Command Mode

- /exec

# show tech-support vxlan platform

show tech-support vxlan platform

## Syntax Description

|              |  |
|--------------|--|
| show         | Show tech-support                      |
| tech-support | Gather information for troubleshooting |
| vxlan        | VxLAN components                       |
| platform     | VxLAN platform components              |

## Command Mode

- /exec

# show tech-support xbar

show tech-support xbar

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for trouble shooting |
| xbar         | Show xbar tech-support information      |

## Command Mode

- /exec

# show tech-support xml

show tech-support xml

## Syntax Description

|              |   |
|--------------|---|
| show         | show running system information             |
| tech-support | Gather information for trouble shooting     |
| xml          | Gather information for xml trouble shooting |

## Command Mode

- /exec

# show tech-support xos

show tech-support xos [ brief ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information         |
| tech-support | Gather information for troubleshooting  |
| xos          | Cross-OS Library Information and Traces |
| brief        | (Optional) Brief information            |

## Command Mode

- /exec

# show tech-support zone

show tech-support zone [ [ commands ] [ vsan <i0> ] ]

## Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information                                    |
| tech-support | Gather information for troubleshooting                             |
| zone         | Show information for zoneserver technical support                  |
| vsan         | (Optional) Show technical support information for a specified vsan |
| commands     | (Optional) Show tech-support commands for zoneserver               |
| <i>i0</i>    | (Optional) VSAN id range   |

## Command Mode

- /exec



## show telemetry control database

```

show telemetry control { database [ subscriptions | destination-groups | destinations | [ { [ sensor-paths |
sensor-groups ] [ detail ] } ] ] | stats } [ __readonly__ [ <subscription_db_size> ] [ { TABLE_subscriptions
<subscription_id> <data_collector_type> } ] [ <sensor_grp_db_size> ] [ { TABLE_sensor_grp
<snsr_grp_row_idx> <snsr_grp_id> <snsr_grp_type> <snsr_grp_collector_type> <snsr_grp_timer_interval>
<snsr_grp_timer_status> <snsr_grp_sub_count> <snsr_grp_sub_id> <snsr_grp_dc_cur_time>
<snsr_grp_dc_min_time> <snsr_grp_dc_max_time> <snsr_grp_enc_cur_time> <snsr_grp_enc_min_time>
<snsr_grp_enc_max_time> <snsr_grp_trans_cur_time> <snsr_grp_trans_min_time>
<snsr_grp_trans_max_time> <snsr_grp_stream_cur_time> <snsr_grp_stream_min_time>
<snsr_grp_stream_max_time> <snsr_grp_stream_col_id_drop> <snsr_grp_stream_last_col_id_drop>
<snsr_grp_stream_col_drop> } ] [ <sensor_path_db_size> ] [ { TABLE_sensor_path <path_row_idx>
<path_subscribed> <path_group_count> <path_secondary_group_count> <path_level> <path_name>
<path_grp_id> <path_query_condition> <path_filter_condition> <path_gpb_cur_enc_size>
<path_gpb_min_enc_size> <path_gpb_max_enc_size> <path_json_cur_enc_size> <path_json_min_enc_size>
<path_json_max_enc_size> <path_cgpb_cur_enc_size> <path_cgpb_min_enc_size>
<path_cgpb_max_enc_size> <path_dc_cur_time> <path_dc_min_time> <path_dc_max_time>
<path_enc_cur_time> <path_enc_min_time> <path_enc_max_time> <path_trans_cur_time>
<path_trans_min_time> <path_trans_max_time> <path_stream_cur_time> <path_stream_min_time>
<path_stream_max_time> <path_sub_id> } ] [ <destination_group_db_size> ] [ { TABLE_destination_group
<destination_group_id> <destination_group_refcount> <destination_group_use_vrf>
<destination_group_filter_filename> <destination_group_filter_md5hash> <destination_group_md5_checksum>
<destination_group_file_modified> <destination_group_file_synced> } ] [ <destination_db_size> ] [ {
TABLE_destinations <destination_ip> <destination_port> <destination_encoding> <destination_transport>
<destination_refcount> } ] [ db_statistics <chunk_alloc_fail> <sensor_path_chunk_create_fail>
<sensor_group_chunk_create_fail> <destination_chunk_create_fail> <destination_group_chunk_create_fail>
<subscription_chunk_create_fail> <sensor_path_db_create_fail> <sensor_group_db_create_fail>
<destination_db_create_fail> <destination_group_db_create_fail> <subscription_db_create_fail>
<sensor_path_db_insert_fail> <sensor_group_db_insert_fail> <destination_db_insert_fail>
<destination_group_db_insert_fail> <subscription_db_insert_fail> <sensor_path_db_delete_fail>
<sensor_group_db_delete_fail> <destination_db_delete_fail> <destination_group_db_delete_fail>
<subscription_db_delete_fail> <sensor_path_delete_in_use> <sensor_group_delete_in_use>
<destination_delete_in_use> <destination_group_delete_in_use> <delete_destination_in_use_fail>
<sensor_path_sensor_group_list_create_fail> <sensor_path_prop_list_create_fail>
<sensor_path_secondary_sensor_path_list_create_fail> <sensor_path_secondary_sensor_group_list_create_fail>
<sensor_group_sensor_path_list_create_fail> <sensor_group_subscription_list_create_fail>
<destination_group_subscription_list_create_fail> <destination_group_destination_list_create_fail>
<destination_destination_group_list_create_fail> <subscription_sensor_group_list_create_fail>
<subscription_destination_group_list_create_fail> <sensor_group_sensor_path_list_delete_fail>
<sensor_group_subscription_list_delete_fail> <sensor_group_subscription_unsupported_data_source_fail>
<destination_group_subscription_list_delete_fail> <destination_group_destination_list_delete_fail>
<subscription_sensor_group_list_delete_fail> <subscription_destination_group_list_delete_fail>
<destination_destination_group_list_delete_fail> <destination_delete_from_destination_group_fail>
<destination_group_delete_from_subscription_fail> <sensor_group_delete_from_subscription_fail>
<sensor_path_delete_from_sensor_group_fail> <get_encode_cb_fail> <get_transport_cb_fail> ] ]

```

### Syntax Description

|           |                                 |
|-----------|---------------------------------|
| show      | Show running system information |
| telemetry | Show telemetry info             |

|                                |  |
|--------------------------------|--|
| control                        | Show telemetry control                               |
| database                       | Show database  |
| subscriptions                  | (Optional) Show subscriptions                        |
| destination-groups             | (Optional) Show destination-groups                   |
| destinations                   | (Optional) Show destinations                         |
| sensor-paths                   | (Optional) Show sensor-paths                         |
| sensor-groups                  | (Optional) Show sensor-groups                        |
| detail                         | (Optional) Show completed id                         |
| stats                          | Show stats   |
| __readonly__                   | (Optional)   |
| TABLE_sensor_grp               | (Optional) Sensor group table                        |
| <i>sensor_grp_db_size</i>      | (Optional) Sensor group DB size                      |
| <i>snsr_grp_row_idx</i>        | (Optional) Sensor Group Row Idx                      |
| <i>snsr_grp_id</i>             | (Optional) Sensor Group Id                           |
| <i>snsr_grp_type</i>           | (Optional) Sensor Group Type                         |
| <i>snsr_grp_collector_type</i> | (Optional) Sensor Group Collector Type               |
| <i>snsr_grp_timer_interval</i> | (Optional) Sensor Group Timer Interval in ms         |
| <i>snsr_grp_timer_status</i>   | (Optional) Sensor Group Timer Status                 |
| <i>snsr_grp_sub_count</i>      | (Optional) Sensor Group Sub Count                    |
| <i>snsr_grp_sub_id</i>         | (Optional) Sensor Group Sub Id                       |
| <i>snsr_grp_dc_cur_time</i>    | (Optional) Sensor Group Data collection Current Time |
| <i>snsr_grp_dc_min_time</i>    | (Optional) Sensor Group Data collection Minimum Time |
| <i>snsr_grp_dc_max_time</i>    | (Optional) Sensor Group Data collection Maximum Time |
| <i>snsr_grp_enc_cur_time</i>   | (Optional) Sensor Group Encoding Current Time        |
| <i>snsr_grp_enc_min_time</i>   | (Optional) Sensor Group Encoding Minimum Time        |
| <i>snsr_grp_enc_max_time</i>   | (Optional) Sensor Group Encoding Maximum Time        |
| <i>snsr_grp_trans_cur_time</i> | (Optional) Sensor Group Transport Current Time       |
| <i>snsr_grp_trans_min_time</i> | (Optional) Sensor Group Transport Minimum Time       |
| <i>snsr_grp_trans_max_time</i> | (Optional) Sensor Group Transport Maximum Time       |

|   |  |
|---|--|
| <i>snsr_grp_stream_cur_time</i>         | (Optional) Sensor Group Streaming Current Time               |
| <i>snsr_grp_stream_min_time</i>         | (Optional) Sensor Group Streaming Minimum Time               |
| <i>snsr_grp_stream_max_time</i>         | (Optional) Sensor Group Streaming Maximum Time               |
| <i>snsr_grp_stream_col_id_drop</i>      | (Optional) Sensor Group Stream collection id Drop            |
| <i>snsr_grp_stream_last_col_id_drop</i> | (Optional) Sensor Group Stream last collection id Drop       |
| <i>snsr_grp_stream_col_drop</i>         | (Optional) Sensor Group Stream number of collections dropped |
| TABLE_sensor_path                       | (Optional) Sensor path table                                 |
| <i>sensor_path_db_size</i>              | (Optional) Sensor path DB size                               |
| <i>path_row_idx</i>                     | (Optional) Sensor Path row index                             |
| <i>path_subscribed</i>                  | (Optional) Sensor path subscribed to events                  |
| <i>path_group_count</i>                 | (Optional) Sensor path group subscriptions                   |
| <i>path_secondary_group_count</i>       | (Optional) Sensor path secondary group subscriptions         |
| <i>path_level</i>                       | (Optional) Sensor path level                                 |
| <i>path_name</i>                        | (Optional) Sensor path name                                  |
| <i>path_grp_id</i>                      | (Optional) Sensor path group ID                              |
| <i>path_query_condition</i>             | (Optional) Sensor path query condition                       |
| <i>path_filter_condition</i>            | (Optional) Sensor path filter condition                      |
| <i>path_gpb_cur_enc_size</i>            | (Optional) Sensor path gpb current encoded size              |
| <i>path_gpb_min_enc_size</i>            | (Optional) Sensor path gpb min encoded size                  |
| <i>path_gpb_max_enc_size</i>            | (Optional) Sensor path gpb max encoded size                  |
| <i>path_json_cur_enc_size</i>           | (Optional) Sensor path json current encoded size             |
| <i>path_json_min_enc_size</i>           | (Optional) Sensor path json min encoded size                 |
| <i>path_json_max_enc_size</i>           | (Optional) Sensor path json max encoded size                 |
| <i>path_cgpb_cur_enc_size</i>           | (Optional) Sensor path cgpb current encoded size             |
| <i>path_cgpb_min_enc_size</i>           | (Optional) Sensor path cgpb min encoded size                 |
| <i>path_cgpb_max_enc_size</i>           | (Optional) Sensor path cgpb max encoded size                 |
| <i>path_dc_cur_time</i>                 | (Optional) sensor path last collection time                  |
| <i>path_dc_min_time</i>                 | (Optional) sensor path min collection time                   |
| <i>path_dc_max_time</i>                 | (Optional) sensor path max collection time                   |

|  |   |
|--|---|
| <i>path_enc_cur_time</i>                 | (Optional) sensor path last encode time                           |
| <i>path_enc_min_time</i>                 | (Optional) sensor path min encode time                            |
| <i>path_enc_max_time</i>                 | (Optional) sensor path max encode time                            |
| <i>path_trans_cur_time</i>               | (Optional) sensor path last transport time                        |
| <i>path_trans_min_time</i>               | (Optional) sensor path min transport time                         |
| <i>path_trans_max_time</i>               | (Optional) sensor path min transport time                         |
| <i>path_stream_cur_time</i>              | (Optional) sensor path last stream time                           |
| <i>path_stream_min_time</i>              | (Optional) sensor path min stream time                            |
| <i>path_stream_max_time</i>              | (Optional) sensor path max stream time                            |
| <i>path_sub_id</i>                       | (Optional) Sensor path Sub Id                                     |
| TABLE_destination_group                  | (Optional) Destination group table                                |
| <i>destination_group_id</i>              | (Optional) Destination group ID                                   |
| <i>destination_group_db_size</i>         | (Optional) Destination group DB size                              |
| <i>destination_group_use_vrf</i>         | (Optional) Destination group vrf                                  |
| <i>destination_group_refcount</i>        | (Optional) Destination group subscription count                   |
| <i>destination_group_filter_filename</i> | (Optional) Destination group filter file name                     |
| <i>destination_group_filter_md5hash</i>  | (Optional) Destination group filter file original md5 hash        |
| <i>destination_group_md5_checksum</i>    | (Optional) Destination group filter file current md5 hash         |
| <i>destination_group_file_modified</i>   | (Optional) Destination group filter file modified locally         |
| <i>destination_group_file_synced</i>     | (Optional) Destination group filter file sync status with standby |
| TABLE_destinations                       | (Optional) Destination table                                      |
| <i>destination_db_size</i>               | (Optional) Destination DB size                                    |
| <i>destination_ip</i>                    | (Optional) Destination IP address                                 |
| <i>destination_port</i>                  | (Optional) Destination IP port                                    |
| <i>destination_encoding</i>              | (Optional) Destination encoding                                   |
| <i>destination_transport</i>             | (Optional) Destination transport                                  |
| <i>destination_refcount</i>              | (Optional) Destination subscription count                         |
| TABLE_subscriptions                      | (Optional) Subscription table                                     |
| <i>subscription_id</i>                   | (Optional) Subscription ID  |

|  |  |
|--|--|
| <i>subscription_db_size</i>                | (Optional) Subscription DB size                |
| <i>data_collector_type</i>                 | (Optional) Data collector type                 |
| <i>db_statistics</i>                       | (Optional) DB Statistics                       |
| <i>chunk_alloc_fail</i>                    | (Optional) Chunk Alloc Fail                    |
| <i>sensor_path_chunk_create_fail</i>       | (Optional) Sensor Path Chunk Create Fail       |
| <i>sensor_group_chunk_create_fail</i>      | (Optional) Sensor Group Chunk Create Fail      |
| <i>destination_chunk_create_fail</i>       | (Optional) Destination Chunk Create Fail       |
| <i>destination_group_chunk_create_fail</i> | (Optional) Destination Group Chunk Create Fail |
| <i>subscription_chunk_create_fail</i>      | (Optional) Subscription Chunk Create Fail      |
| <i>sensor_path_db_create_fail</i>          | (Optional) Sensor Path Db Create Fail          |
| <i>sensor_group_db_create_fail</i>         | (Optional) Sensor Group Db Create Fail         |
| <i>destination_db_create_fail</i>          | (Optional) Destination Db Create Fail          |
| <i>destination_group_db_create_fail</i>    | (Optional) Destination Group Db Create Fail    |
| <i>subscription_db_create_fail</i>         | (Optional) Subscription Db Create Fail         |
| <i>sensor_path_db_insert_fail</i>          | (Optional) Sensor Path Db Insert Fail          |
| <i>sensor_group_db_insert_fail</i>         | (Optional) Sensor Group Db Insert Fail         |
| <i>destination_db_insert_fail</i>          | (Optional) Destination Db Insert Fail          |
| <i>destination_group_db_insert_fail</i>    | (Optional) Destination Group Db Insert Fail    |
| <i>subscription_db_insert_fail</i>         | (Optional) Subscription Db Insert Fail         |
| <i>sensor_path_db_delete_fail</i>          | (Optional) Sensor Path Db Delete Fail          |
| <i>sensor_group_db_delete_fail</i>         | (Optional) Sensor Group Db Delete Fail         |
| <i>destination_db_delete_fail</i>          | (Optional) Destination Db Delete Fail          |
| <i>destination_group_db_delete_fail</i>    | (Optional) Destination Group Db Delete Fail    |
| <i>subscription_db_delete_fail</i>         | (Optional) Subscription Db Delete Fail         |
| <i>sensor_path_delete_in_use</i>           | (Optional) Sensor Path Delete In Use           |
| <i>sensor_group_delete_in_use</i>          | (Optional) Sensor Group Delete In Use          |
| <i>destination_delete_in_use</i>           | (Optional) Destination Delete In Use           |
| <i>destination_group_delete_in_use</i>     | (Optional) Destination Group Delete In Use     |
| <i>delete_destination_in_use_fail</i>      | (Optional) Delete Destination In Use Fail      |

|   |   |
|---|---|
| <i>sensor_path_sensor_group_list_create_fail</i>              | (Optional) Sensor Path Sensor Group List Create Fail              |
| <i>sensor_path_prop_list_create_fail</i>                      | (Optional) Sensor Path Prop List Create Fail                      |
| <i>sensor_path_secondary_sensor_path_list_create_fail</i>     | (Optional) Sensor Path Secondary Sensor Path List Create Fail     |
| <i>sensor_path_secondary_sensor_group_list_create_fail</i>    | (Optional) Sensor Path Secondary Sensor Group List Create Fail    |
| <i>sensor_group_sensor_path_list_create_fail</i>              | (Optional) Sensor Group Sensor Path List Create Fail              |
| <i>sensor_group_subscription_list_create_fail</i>             | (Optional) Sensor Group Subscription List Create Fail             |
| <i>destination_group_subscription_list_create_fail</i>        | (Optional) Destination Group Subscription List Create Fail        |
| <i>destination_group_destination_list_create_fail</i>         | (Optional) Destination Group Destination List Create Fail         |
| <i>destination_destination_group_list_create_fail</i>         | (Optional) Destination Destination Group List Create Fail         |
| <i>subscription_sensor_group_list_create_fail</i>             | (Optional) Subscription Sensor Group List Create Fail             |
| <i>subscription_destination_group_list_create_fail</i>        | (Optional) Subscription Destination Group List Create Fail        |
| <i>sensor_group_sensor_path_list_delete_fail</i>              | (Optional) Sensor Group Sensor Path List Delete Fail              |
| <i>sensor_group_subscription_list_delete_fail</i>             | (Optional) Sensor Group Subscription List Delete Fail             |
| <i>sensor_group_subscription_unsupported_data_source_fail</i> | (Optional) Sensor Group Subscription Unsupported Data Source Fail |
| <i>destination_group_subscription_list_delete_fail</i>        | (Optional) Destination Group Subscription List Delete Fail        |
| <i>destination_group_destination_list_delete_fail</i>         | (Optional) Destination Group Destination List Delete Fail         |
| <i>subscription_sensor_group_list_delete_fail</i>             | (Optional) Subscription Sensor Group List Delete Fail             |
| <i>subscription_destination_group_list_delete_fail</i>        | (Optional) Subscription Destination Group List Delete Fail        |
| <i>destination_destination_group_list_delete_fail</i>         | (Optional) Destination Destination Group List Delete Fail         |
| <i>destination_delete_from_destination_group_fail</i>         | (Optional) Destination Delete From Destination Group Fail         |
| <i>destination_group_delete_from_subscription_fail</i>        | (Optional) Destination Group Delete From Subscription Fail        |
| <i>sensor_group_delete_from_subscription_fail</i>             | (Optional) Sensor Group Delete From Subscription Fail             |
| <i>sensor_path_delete_from_sensor_group_fail</i>              | (Optional) Sensor Path Delete From Sensor Group Fail              |
| <i>get_encode_cb_fail</i>                                     | (Optional) Get Encode Cb Fail                                     |
| <i>get_transport_cb_fail</i>                                  | (Optional) Get Transport Cb Fail                                  |

**Command Mode**

- /exec

## show telemetry data collector brief

```
show telemetry data collector { brief | details } [ __readonly__ [ { TABLE_data_collector_brief <dcb_row_idx>
<dcb_collector_type> <dcb_success_count> <dcb_fail_count> <dcb_skip_count> } ] [ {
TABLE_data_collector_details <dcd_row_idx> <dcd_success_count> <dcd_fail_count> <dcd_skip_count>
<dcd_path_name> <dcd_grp_id> } ] ]
```

### Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information            |
| telemetry                    | Show telemetry info                        |
| data                         | Show telemetry data info                   |
| collector                    | Show telemetry data collector info         |
| brief                        | Show component level data collection stats |
| details                      | Show path level data collection stats      |
| __readonly__                 | (Optional)                                 |
| TABLE_data_collector_brief   | (Optional) Data collector brief            |
| <i>dcb_row_idx</i>           | (Optional) Data collector brief index      |
| <i>dcb_collector_type</i>    | (Optional) Data collector type             |
| <i>dcb_success_count</i>     | (Optional) Data collector success count    |
| <i>dcb_fail_count</i>        | (Optional) Data collector fail count       |
| <i>dcb_skip_count</i>        | (Optional) Data collector skip count       |
| TABLE_data_collector_details | (Optional) Data collector details          |
| <i>dcd_row_idx</i>           | (Optional) Data collector row index        |
| <i>dcd_success_count</i>     | (Optional) Data collector success count    |
| <i>dcd_fail_count</i>        | (Optional) Data collector fail count       |
| <i>dcd_skip_count</i>        | (Optional) Data collector skip count       |
| <i>dcd_path_name</i>         | (Optional) Data collector path name        |
| <i>dcd_grp_id</i>            | (Optional) Data collector group ID         |

### Command Mode

- /exec

# show telemetry dynamic configuration

```
show telemetry dynamic configuration [ __readonly__ [ <subscription_id> ] [ { TABLE_destination_groups
<dst_grp_row_idx> <dst_grp_id> } ] [ { TABLE_sensor_groups <snsr_grp_row_idx> <snsr_grp_id>
<snsr_grp_sample_interval> } ] [ <destination_group_id> ] [ { TABLE_destinations <destination_ip>
<destination_port> <destination_encoding> <destination_transport> } ] [ <snsr_grp_id> ] [ {
TABLE_sensor_path <path_row_idx> <path_name> } ] ]
```

## Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show information                       |
| telemetry                       | Show telemetry info                    |
| dynamic                         | Show telemetry dynamic configuration   |
| configuration                   | Show telemetry dynamic configuration   |
| <i>__readonly__</i>             | (Optional)                             |
| <i>subscription_id</i>          | (Optional) Subscription ID             |
| TABLE_destination_groups        | (Optional) Destination group table     |
| <i>dst_grp_row_idx</i>          | (Optional) Destination group row index |
| <i>dst_grp_id</i>               | (Optional) Destination group ID        |
| TABLE_sensor_groups             | (Optional) Sensor group table          |
| <i>snsr_grp_row_idx</i>         | (Optional) Sensor group row index      |
| <i>snsr_grp_id</i>              | (Optional) Sensor group ID             |
| <i>snsr_grp_sample_interval</i> | (Optional) Sample interval             |
| <i>destination_group_id</i>     | (Optional) Destination group ID        |
| TABLE_destinations              | (Optional) Destination table           |
| <i>destination_ip</i>           | (Optional) Destination IP address      |
| <i>destination_port</i>         | (Optional) Destination IP port         |
| <i>destination_encoding</i>     | (Optional) Destination encoding        |
| <i>destination_transport</i>    | (Optional) Destination transport       |
| <i>snsr_grp_id</i>              | (Optional) Sensor Group Id             |
| TABLE_sensor_path               | (Optional) Sensor path table           |
| <i>path_row_idx</i>             | (Optional) Sensor Path row index       |
| <i>path_name</i>                | (Optional) Sensor path name            |



### Command Mode

- /exec

## show telemetry event collector stats

```
show telemetry event collector { stats | errors } [ __readonly__ [ { TABLE_event_collector_stats <ec_row_idx>
<ec_collection_count> <ec_last_collection_ts> <ec_sensor_path> <ec_sensor_grp_id> } ] [ {
event_collector_errors <event_sub_init_fail> <event_data_enq_fail> <event_sub_fail>
<pending_sub_list_create_fail> <sub_hash_table_create_fail> <sub_hash_table_destroy_fail>
<sub_hash_table_insert_fail> <sub_hash_table_remove_fail> } ] ]
```

### Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information                  |
| telemetry                           | Show telemetry info                              |
| event                               | Show telemetry event info                        |
| collector                           | Show telemetry event collector info              |
| stats                               | Show all tm stat info                            |
| errors                              | Show all tm error info                           |
| <i>__readonly__</i>                 | (Optional)                                       |
| <i>event_collector_errors</i>       | (Optional) Event collection failure              |
| <i>event_sub_init_fail</i>          | (Optional) Event Sub Init Fail                   |
| <i>event_data_enq_fail</i>          | (Optional) Event Data Enqueue Fail               |
| <i>event_sub_fail</i>               | (Optional) Event Subscription Fail               |
| <i>pending_sub_list_create_fail</i> | (Optional) Pending Subscription List Create Fail |
| <i>sub_hash_table_create_fail</i>   | (Optional) Subscription Hash Table Create Fail   |
| <i>sub_hash_table_destroy_fail</i>  | (Optional) Subscription Hash Table Destroy Fail  |
| <i>sub_hash_table_insert_fail</i>   | (Optional) Subscription Hash Table Insert Fail   |
| <i>sub_hash_table_remove_fail</i>   | (Optional) Subscription Hash Table Remove Fail   |
| <i>TABLE_event_collector_stats</i>  | (Optional) Event collector stats table           |
| <i>ec_row_idx</i>                   | (Optional) Event collector row index             |
| <i>ec_collection_count</i>          | (Optional) Event collection count                |
| <i>ec_last_collection_ts</i>        | (Optional) Last event collection timestamp       |
| <i>ec_sensor_path</i>               | (Optional) Event collection sensor path          |
| <i>ec_sensor_grp_id</i>             | (Optional) Event collection group ID             |

### Command Mode

- /exec

## show telemetry pipeline stats

```
show telemetry pipeline stats [ __readonly__ { main_statistics { timers <start_fail> } { data_collector
<dnode_create_fail> } } { event_collector <enode_create_fail> <node_add_fail> <invalid_data> } { memory
<allowed_limit> <occupied_mem> } } { queue_statistics { TABLE_queue <queue_name> <actual_size>
<current_size> <max_size> <full_count> <enqueue_error> <dequeue_error> } } ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information        |
| telemetry                | Show telemetry info                    |
| pipeline                 | Show telemetry pipeline info           |
| stats                    | Show all telemetry pipeline stats      |
| <i>__readonly__</i>      | (Optional)                             |
| <i>main_statistics</i>   | (Optional) Main Statistics             |
| <i>timers</i>            | (Optional) Timers Statistics           |
| <i>start_fail</i>        | (Optional) Timers start failure        |
| <i>data_collector</i>    | (Optional) Data collector Statistics   |
| <i>dnode_create_fail</i> | (Optional) Data Node creation failure  |
| <i>event_collector</i>   | (Optional) Event collector Statistics  |
| <i>enode_create_fail</i> | (Optional) Event Node creation failure |
| <i>node_add_fail</i>     | (Optional) Node add failure            |
| <i>invalid_data</i>      | (Optional) Invalid data                |
| <i>memory</i>            | (Optional) Memory Statistics           |
| <i>allowed_limit</i>     | (Optional) Allowed memory limit        |
| <i>occupied_mem</i>      | (Optional) Occupied memory             |
| <i>queue_statistics</i>  | (Optional) Queue Statistics            |
| <i>TABLE_queue</i>       | (Optional) Queue table                 |
| <i>queue_name</i>        | (Optional) Queue name                  |
| <i>actual_size</i>       | (Optional) Actual size                 |
| <i>current_size</i>      | (Optional) Current size                |
| <i>max_size</i>          | (Optional) Maximum size                |

|                      |                          |
|----------------------|--------------------------|
| <i>full_count</i>    | (Optional) Full count    |
| <i>enqueue_error</i> | (Optional) Enqueue error |
| <i>dequeue_error</i> | (Optional) Dequeue error |

**Command Mode**

- /exec

## show telemetry port-counters

```
show telemetry port-counters [ interface <if_name> ] [ __readonly__ [ { TABLE_port_counters <if_name>
<portPacketInIpv4> <portInIpv4> <portPacketOutIpv4> <portOutIpv4> <portPacketInIpv4Pps>
<portInIpv4Bps> <portPacketOutIpv4Pps> <portOutIpv4Bps> <portPacketInIpv6> <portInIpv6>
<portPacketOutIpv6> <portOutIpv6> <portPacketInIpv6Pps> <portInIpv6Bps> <portPacketOutIpv6Pps>
<portOutIpv6Bps> } ] ]
```

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show information                                  |
| telemetry                   | Show telemetry info                               |
| port-counters               | Show telemetry port-counters                      |
| interface                   | (Optional) Show telemetry port-counters interface |
| <i>if_name</i>              | (Optional) Physical interface                     |
| <i>__readonly__</i>         | (Optional)  |
| <i>if_name</i>              | (Optional) Interface index                        |
| TABLE_port_counters         | (Optional) port-counters table                    |
| <i>portPacketInIpv4</i>     | (Optional) counter portPacketInIpv4               |
| <i>portInIpv4</i>           | (Optional) counter portInIpv4                     |
| <i>portPacketOutIpv4</i>    | (Optional) counter portPacketOutIpv4              |
| <i>portOutIpv4</i>          | (Optional) counter portOutIpv4                    |
| <i>portPacketInIpv4Pps</i>  | (Optional) counter portPacketInIpv4Pps            |
| <i>portInIpv4Bps</i>        | (Optional) counter portInIpv4Bps                  |
| <i>portPacketOutIpv4Pps</i> | (Optional) counter portPacketOutIpv4Pps           |
| <i>portOutIpv4Bps</i>       | (Optional) counter portOutIpv4Bps                 |
| <i>portPacketInIpv6</i>     | (Optional) counter portPacketInIpv6               |
| <i>portInIpv6</i>           | (Optional) counter portInIpv6                     |
| <i>portPacketOutIpv6</i>    | (Optional) counter portPacketOutIpv6              |
| <i>portOutIpv6</i>          | (Optional) counter portOutIpv6                    |
| <i>portPacketInIpv6Pps</i>  | (Optional) counter portPacketInIpv6Pps            |
| <i>portInIpv6Bps</i>        | (Optional) counter portInIpv6Bps                  |
| <i>portPacketOutIpv6Pps</i> | (Optional) counter portPacketOutIpv6Pps           |

|                       |                                   |
|-----------------------|-----------------------------------|
| <i>portOutIpv6Bps</i> | (Optional) counter portOutIpv6Bps |
|-----------------------|-----------------------------------|

**Command Mode**

- /exec

# show telemetry syslog-filter

```
show telemetry syslog-filter [ __readonly__ [ { TABLE_syslog_filter_table <syslog_filter_row_idx>
<syslog_filter_path> } ] ]
```

## Syntax Description

|                                  |                                 |
|----------------------------------|---------------------------------|
| show                             | Show running system information |
| telemetry                        | Show telemetry info             |
| syslog-filter                    | syslog filter information       |
| <i>__readonly__</i>              | (Optional)                      |
| <i>TABLE_syslog_filter_table</i> | (Optional) syslog filter table  |
| <i>syslog_filter_row_idx</i>     | (Optional) row index            |
| <i>syslog_filter_path</i>        | (Optional) syslog filter path   |

## Command Mode

- /exec





|                                      |   |
|--------------------------------------|---|
| <i>retries_dropped</i>               | (Optional) Number of retries dropped      |
| <i>retry_buffer_size</i>             | (Optional) Retry buffer size              |
| TABLE_transport_session              | (Optional) Transport session information  |
| <i>session_idx</i>                   | (Optional) Session Id                     |
| <i>dstgrp_idx</i>                    | (Optional) Destination group Id           |
| <i>ip_addr</i>                       | (Optional) Transport IP address           |
| <i>port_no</i>                       | (Optional) Transport port                 |
| <i>dest_info</i>                     | (Optional) Destination information        |
| <i>transport_security_cert_fname</i> | (Optional) Transport security file name   |
| <i>transport_last_connected</i>      | (Optional) Transport last connected       |
| <i>transport_last_disconnected</i>   | (Optional) Transport last disconnected    |
| <i>transport_errors_count</i>        | (Optional) Transport errors count         |
| <i>transport_last_tx_error</i>       | (Optional) Transport last tx error        |
| <i>proxy_server_port</i>             | (Optional) Proxy server and port          |
| <i>proxy_username</i>                | (Optional) Proxy username                 |
| TABLE_transport_stats                | (Optional) Transport sessions' stats info |
| <i>t_stats_id</i>                    | (Optional) Transport Session id           |
| <i>t_stats_dstgrp_id</i>             | (Optional) Transport Session DstGrp id    |
| transport_statistics                 | (Optional) Transport statistics           |
| connect_statistics                   | (Optional) Connection statistics          |
| <i>connect_count</i>                 | (Optional) Connection count               |
| <i>last_connected</i>                | (Optional) Last connected timestamp       |
| <i>disconnect_count</i>              | (Optional) Disconnect count               |
| <i>last_disconnected</i>             | (Optional) Last disconnected timestamp    |
| trans_statistics                     | (Optional) Transport statistics           |
| <i>compression</i>                   | (Optional) Compression status             |
| <i>source_interface_name</i>         | (Optional) Source interface name          |
| <i>source_interface_ip</i>           | (Optional) Source interface ip            |
| <i>transmit_count</i>                | (Optional) Transmission count             |

|                             |   |
|-----------------------------|---|
| <i>last_tx_time</i>         | (Optional) Last Transmission time         |
| <i>min_tx_time</i>          | (Optional) Minimum transmission time      |
| <i>max_tx_time</i>          | (Optional) Maximum transmission time      |
| <i>avg_tx_time</i>          | (Optional) Average transmission time      |
| <i>cur_tx_time</i>          | (Optional) Current transmission time      |
| TABLE_transport_errors      | (Optional) Transport sessions' error info |
| <i>t_errors_id</i>          | (Optional) Transport Session id           |
| <i>t_errors_dstgrp_id</i>   | (Optional) Transport Session DstGrp id    |
| connect_errors              | (Optional) Connection errors              |
| <i>connect_errors_count</i> | (Optional) Connection error count         |
| trans_errors                | (Optional) Transport errors               |
| <i>trans_errors_count</i>   | (Optional) Transport error count          |
| <i>last_tx_error</i>        | (Optional) Last transport error           |
| <i>last_tx_return_code</i>  | (Optional) Last transport return code     |

**Command Mode**

- /exec

## show telemetry transport

```
show telemetry transport [ { <session_id> [ { stats | errors | kafka-info } ] | kafka } ] [ __readonly__ [ {
TABLE_transport_info <session_idx> [ <dstgrp_idx> ] [ <ip_address> ] [ <port> ] [ <dest_info> ] [
<encoding_type> ] <transport_type> <transport_status> [ <transport_security_cert_fname> ] [
<transport_last_connected> ] [ <transport_last_disconnected> ] [ <transport_errors_count> ] [
<transport_last_tx_error> ] [ <proxy_server_port> ] [ <proxy_username> } ] ] [ <t_session_id> ] [ {
transport_statistics [ { connect_statistics <connect_count> <last_connected> <disconnect_count>
<last_disconnected> } ] { trans_statistics <compression> <source_interface_name> <source_interface_ip>
<transmit_count> <last_tx_time> <min_tx_time> <max_tx_time> <avg_tx_time> <cur_tx_time> } } ] [ {
transport_errors { connect_errors <connect_errors_count> } { trans_errors <trans_errors_count> <last_tx_error>
[ <last_tx_return_code> } ] } ] [ TABLE_transport_kafka <row_idx> [ <broker> ] [ <topic> ] [
<kafka_msg_count> } ] ] [ <kafka_producer_name> ] [ <kafka_producer_request_size> ] [
<kafka_producer_request_timeout> ] [ <kafka_lib_version> ] [ { transport_retry_stats <ts_event_retry_bytes>
<ts_event_retry_size> <ts_timer_retry_bytes> <ts_timer_retry_size> <ts_retries_sent> <ts_retries_dropped>
} ] [ <retry_buffer_size> ] [ <event_retry_bytes> ] [ <timer_retry_bytes> ] [ <retries_sent> ] [ <retries_dropped>
] [ { TABLE_transport_kafka_all <k_ss_idx> [ <kafka_broker> ] [ <kafka_producer> ] [ <kafka_encoding>
] [ <kafka_topic> ] [ <kafka_status> } ] } ] ]
```

### Syntax Description

|                           |   |
|---------------------------|---|
| show                      | Show running system information           |
| telemetry                 | Show telemetry info                       |
| transport                 | Show telemetry transport info             |
| <i>session_id</i>         | (Optional) Session id                     |
| stats                     | (Optional) Show all tm stat info          |
| errors                    | (Optional) Show all tm error info         |
| kafka                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| kafka-info                | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__              | (Optional)                                |
| TABLE_transport_info      | (Optional) Transport information          |
| TABLE_transport_kafka     | (Optional) Transport Kafka information    |
| TABLE_transport_kafka_all | (Optional) Transport Kafka information    |
| <i>session_idx</i>        | (Optional) Session Id                     |
| <i>row_idx</i>            | (Optional) Session Id                     |
| <i>k_ss_idx</i>           | (Optional) Session Id                     |
| <i>broker</i>             | (Optional) Kafka broker name              |
| <i>topic</i>              | (Optional) Kafka topic name               |

|                                      |   |
|--------------------------------------|---|
| <i>kafka_msg_count</i>               | (Optional) Transport Kafka msgs         |
| <i>kafka_broker</i>                  | (Optional) Kafka broker name            |
| <i>kafka_producer</i>                | (Optional) Kafka producer name          |
| <i>kafka_encoding</i>                | (Optional) Kafka encoding type          |
| <i>kafka_topic</i>                   | (Optional) Kafka topic                  |
| <i>kafka_status</i>                  | (Optional) Kafka connection status      |
| <i>dstgrp_idx</i>                    | (Optional) Destination group Id         |
| <i>ip_address</i>                    | (Optional) Transport IP address         |
| <i>port</i>                          | (Optional) Transport port               |
| <i>dest_info</i>                     | (Optional) Destination information      |
| <i>encoding_type</i>                 | (Optional) Encoding type                |
| <i>transport_type</i>                | (Optional) Transport type               |
| <i>transport_status</i>              | (Optional) Transport status             |
| <i>transport_security_cert_fname</i> | (Optional) Transport security file name |
| <i>transport_last_connected</i>      | (Optional) Transport last connected     |
| <i>transport_last_disconnected</i>   | (Optional) Transport last disconnected  |
| <i>transport_errors_count</i>        | (Optional) Transport errors count       |
| <i>transport_last_tx_error</i>       | (Optional) Transport last tx error      |
| <i>proxy_server_port</i>             | (Optional) Proxy server and port        |
| <i>proxy_username</i>                | (Optional) Proxy username               |
| <i>transport_statistics</i>          | (Optional) Transport statistics         |
| <i>t_session_id</i>                  | (Optional) Transport Session id         |
| <i>connect_statistics</i>            | (Optional) Connection statistics        |
| <i>connect_count</i>                 | (Optional) Connection count             |
| <i>last_connected</i>                | (Optional) Last connected timestamp     |
| <i>disconnect_count</i>              | (Optional) Disconnect count             |
| <i>last_disconnected</i>             | (Optional) Last disconnected timestamp  |
| <i>trans_statistics</i>              | (Optional) Transport statistics         |
| <i>compression</i>                   | (Optional) Compression status           |

|                                    |   |
|------------------------------------|---|
| <i>source_interface_name</i>       | (Optional) Source interface name              |
| <i>source_interface_ip</i>         | (Optional) Source interface ip                |
| <i>transmit_count</i>              | (Optional) Transmission count                 |
| <i>last_tx_time</i>                | (Optional) Last Transmission time             |
| <i>min_tx_time</i>                 | (Optional) Minimum transmission time          |
| <i>max_tx_time</i>                 | (Optional) Maximum transmission time          |
| <i>avg_tx_time</i>                 | (Optional) Average transmission time          |
| <i>cur_tx_time</i>                 | (Optional) Current transmission time          |
| transport_errors                   | (Optional) Transport errors                   |
| connect_errors                     | (Optional) Connection errors                  |
| <i>connect_errors_count</i>        | (Optional) Connection error count             |
| trans_errors                       | (Optional) Transport errors                   |
| <i>trans_errors_count</i>          | (Optional) Transport error count              |
| <i>last_tx_error</i>               | (Optional) Last transport error               |
| <i>last_tx_return_code</i>         | (Optional) Last transport return code         |
| transport_retry_stats              | (Optional) Retry Statistics                   |
| <i>ts_event_retry_bytes</i>        | (Optional) Event Retry buffer size            |
| <i>ts_timer_retry_bytes</i>        | (Optional) Timer Retry buffer size            |
| <i>ts_event_retry_size</i>         | (Optional) Event Retry number of messages     |
| <i>ts_timer_retry_size</i>         | (Optional) Timer Retry number of messages     |
| <i>ts_retries_sent</i>             | (Optional) Number of retries sent             |
| <i>ts_retries_dropped</i>          | (Optional) Number of retries dropped          |
| <i>event_retry_bytes</i>           | (Optional) Event Retry buffer size            |
| <i>timer_retry_bytes</i>           | (Optional) Timer Retry buffer size            |
| <i>retries_sent</i>                | (Optional) Number of retries sent             |
| <i>retries_dropped</i>             | (Optional) Number of retries dropped          |
| <i>retry_buffer_size</i>           | (Optional) Retry buffer size                  |
| <i>kafka_producer_name</i>         | (Optional) Kafka producer name                |
| <i>kafka_producer_request_size</i> | (Optional) Kafka producer request size(bytes) |

|                                       |   |
|---------------------------------------|---|
| <i>kafka_producer_request_timeout</i> | (Optional) Kafka producer request timeout(ms) |
| <i>kafka_lib_version</i>              | (Optional) Kafka library version              |

**Command Mode**

- /exec

# show telemetry usability

```
show telemetry usability { all | environment | interface | vxlan | resources } [ __readonly__ [ {
TABLE_path_labels <label_row_idx> <label_name> <label_path_name> <label_query_type>
<label_query_condition> } ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information               |
| telemetry                    | Show telemetry info                           |
| usability                    | Usability path information                    |
| all                          | show all the usability path query information |
| environment                  | show environment query information            |
| interface                    | show interface query information              |
| vxlan                        | show vxlan query information                  |
| resources                    | show system resources query information       |
| __readonly__                 | (Optional)                                    |
| TABLE_path_labels            | (Optional) Ease of use path table             |
| <i>label_row_idx</i>         | (Optional) row index                          |
| <i>label_name</i>            | (Optional) label name                         |
| <i>label_path_name</i>       | (Optional) actual path configured             |
| <i>label_query_type</i>      | (Optional) query type                         |
| <i>label_query_condition</i> | (Optional) actual query condition             |

## Command Mode

- /exec



## show telemetry yang direct-path cisco-nxos-device

```
show telemetry yang direct-path cisco-nxos-device [ __readonly__ [ { TABLE_path_list <list_row_idx>
<path_name> } ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                |
| telemetry              | Show telemetry info                            |
| yang                   | yang direct path information                   |
| direct-path            | yang direct path information                   |
| cisco-nxos-device      | show cisco nxos device direct path information |
| <i>__readonly__</i>    | (Optional)                                     |
| <i>TABLE_path_list</i> | (Optional) direct path list                    |
| <i>list_row_idx</i>    | (Optional) direct path row index               |
| <i>path_name</i>       | (Optional) direct path name                    |

### Command Mode

- /exec

# show telnet server

show telnet server [ \_\_readonly\_\_ { operation\_status <o\_status> } ]

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information                |
| telnet           | Show telnet server configuration               |
| server           | Show telnet server configuration               |
| __readonly__     | (Optional)                                     |
| operation_status | (Optional) run-time information about telnet   |
| <i>o_status</i>  | (Optional) operational status of telnet server |

## Command Mode

- /exec

# show terminal

```
show terminal [ __readonly__ { <terminal_tty> } { <terminal_type> } { <terminal_length> } {
<terminal_width> } { <session_timeout> } { <evnt_mgr_cli_evnt_bypass> } { <redirection_mode> } {
<acc_log_all_commands> } [ <vlan_mutex_value> ] { <vlan_batch_mode> } ]
```

## Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information           |
| terminal                        | Display terminal configuration parameters |
| <i>__readonly__</i>             | (Optional)                                |
| <i>terminal_tty</i>             | (Optional)                                |
| <i>terminal_type</i>            | (Optional)                                |
| <i>terminal_length</i>          | (Optional)                                |
| <i>terminal_width</i>           | (Optional)                                |
| <i>session_timeout</i>          | (Optional)                                |
| <i>evnt_mgr_cli_evnt_bypass</i> | (Optional)                                |
| <i>redirection_mode</i>         | (Optional)                                |
| <i>acc_log_all_commands</i>     | (Optional)                                |
| <i>vlan_mutex_value</i>         | (Optional)                                |
| <i>vlan_batch_mode</i>          | (Optional)                                |

## Command Mode

- /exec

# show terminal lock

```
show terminal lock [ __readonly__ <owner_pid> <user_name> <session> <state> [ <reason> ]
<lock_acqrd_time> <lock_expiry_timeout> ]
```

## Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                |
| terminal                   | Display terminal configuration parameters      |
| lock                       | Display the session holding the terminal lock  |
| <i>__readonly__</i>        | (Optional)                                     |
| <i>owner_pid</i>           | (Optional) PID of the process holding the lock |
| <i>user_name</i>           | (Optional) User holding the lock               |
| <i>session</i>             | (Optional) Terminal holding the lock           |
| <i>state</i>               | (Optional) Status of the lock                  |
| <i>reason</i>              | (Optional) Reason for the lock                 |
| <i>lock_acqrd_time</i>     | (Optional) Time when the lock got acquired     |
| <i>lock_expiry_timeout</i> | (Optional) Lock expiry timeout                 |

## Command Mode

- /exec

# show terminal output xml version

```
show terminal output xml version [ __readonly__ { xml_version <version> } ]
```

## Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| terminal            | Display                         |
| output              | Display                         |
| xml                 | Display                         |
| version             | Display                         |
| <i>__readonly__</i> | (Optional)                      |
| <i>xml_version</i>  | (Optional) xml version          |
| <i>version</i>      | (Optional) version              |

## Command Mode

- /exec

## show time-range

```
show time-range [ <name> ] [ __readonly__ TABLE_timerange <timerange_name> <active> [ TABLE_seqno
<seqno> { { absolute [ <start_abs_h> <start_abs_m> <start_abs_s> <start_abs_d> <start_abs_mon>
<start_abs_y> ] [ <end_abs_h> <end_abs_m> <end_abs_s> <end_abs_d> <end_abs_mon> <end_abs_y> ]
} | { periodic { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday | daily | weekdays |
weekend } + <start_per_h> <start_per_m> <start_per_s> [ <eday> ] <end_per_h> <end_per_m> <end_per_s>
} | { <remark> } } ] ] ]
```

### Syntax Description

|                       |                                 |
|-----------------------|---------------------------------|
| show                  | Show running system information |
| time-range            | Define time range entries       |
| <i>name</i>           | (Optional) Time range name      |
| <i>__readonly__</i>   | (Optional)                      |
| TABLE_timerange       | (Optional)                      |
| <i>timerange_name</i> | (Optional)                      |
| <i>active</i>         | (Optional) active               |
| TABLE_seqno           | (Optional)                      |
| <i>seqno</i>          | (Optional) Sequence number      |
| absolute              | (Optional)                      |
| periodic              | (Optional)                      |
| <i>remark</i>         | (Optional)                      |
| <i>start_abs_h</i>    | (Optional)                      |
| <i>start_abs_m</i>    | (Optional)                      |
| <i>start_abs_s</i>    | (Optional)                      |
| <i>start_abs_d</i>    | (Optional)                      |
| <i>start_abs_mon</i>  | (Optional)                      |
| <i>start_abs_y</i>    | (Optional)                      |
| <i>end_abs_h</i>      | (Optional)                      |
| <i>end_abs_m</i>      | (Optional)                      |
| <i>end_abs_s</i>      | (Optional)                      |
| <i>end_abs_d</i>      | (Optional)                      |

|                    |                                  |
|--------------------|----------------------------------|
| <i>end_abs_mon</i> | (Optional)                       |
| <i>end_abs_y</i>   | (Optional)                       |
| Monday             | (Optional) Monday                |
| Tuesday            | (Optional) Tuesday               |
| Wednesday          | (Optional) Wednesday             |
| Thursday           | (Optional) Thursday              |
| Friday             | (Optional) Friday                |
| Saturday           | (Optional) Saturday              |
| Sunday             | (Optional) Sunday                |
| daily              | (Optional) Every day of the week |
| weekdays           | (Optional) Monday thru Friday    |
| weekend            | (Optional) Saturday and Sunday   |
| <i>start_per_h</i> | (Optional)                       |
| <i>start_per_m</i> | (Optional)                       |
| <i>start_per_s</i> | (Optional)                       |
| <i>eday</i>        | (Optional) Day of the week       |
| <i>end_per_h</i>   | (Optional)                       |
| <i>end_per_m</i>   | (Optional)                       |
| <i>end_per_s</i>   | (Optional)                       |

**Command Mode**

- /exec

# show time-stamp running-config last-changed

show time-stamp running-config last-changed [ *\_\_readonly\_\_* <*run\_config\_change\_time*> ]

## Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information              |
| time-stamp                    | Time running-config last changed             |
| running-config                | Current operating configuration              |
| last-changed                  | Running configuration last changed           |
| <i>__readonly__</i>           | (Optional) Read only                         |
| <i>run_config_change_time</i> | (Optional) Running-cfg last change timestamp |

## Command Mode

- /exec



# show topology

show topology [ vsan <i0> ]

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information        |
| topology  | Show information of connected switches |
| vsan      | (Optional) Enter VSAN                  |
| <i>i0</i> | (Optional) VSAN id                     |

## Command Mode

- /exec

# show topology isl

```
show topology isl [ [ san-port-channel <i1> ] [ detail ] ]
```

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information              |
| topology         | Show information of connected switches       |
| isl              | Show isl                                     |
| san-port-channel | (Optional) Specify the san-port-channel      |
| <i>i1</i>        | (Optional) san-port-channel number           |
| detail           | (Optional) Gives detailed information on isl |

## Command Mode

- /exec

# show topology isl

```
show topology isl [ [ vsan <i0> ] [ detail ] ]
```

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information              |
| topology  | Show information of connected switches       |
| isl       | Show isl                                     |
| vsan      | (Optional) Specify the vsan id               |
| <i>i0</i> | (Optional) VSAN id range                     |
| detail    | (Optional) Gives detailed information on isl |

## Command Mode

- /exec

# show topology isl

show topology isl [ detail ]

## Syntax Description

|          |  |
|----------|--|
| show     | Show running system information              |
| topology | Show information of connected switches       |
| isl      | Show isl                                     |
| detail   | (Optional) Gives detailed information on isl |

## Command Mode

- /exec

# show trace callhome

show trace callhome

## Syntax Description

|          |  |
|----------|--|
| show     | Show XOS trace information                         |
| trace    | Show logging configuration and contents of logfile |
| callhome | Show callhome logging configuration                |

## Command Mode

- /exec

## show track

```
show track { [ <object-id> | interface | ip { route | sla } | ipv6 routev6 | list boolean and | list boolean or | list
threshold weight | list threshold percentage ] } [ dynamic ] [ __readonly__ { <show_track_start> {
TABLE_track_detail <st_obj_id> <st_obj_ms_up> <st_obj_ms_down> <st_obj_type> [ <st_obj_instance>
] <st_obj_param> <st_obj_timer_value> [ <st_obj_state> ] [ <st_obj_chg_cnt> ] [ <st_last_chg_time> ] [
<st_threshold_info> ] [ <st_track_list_obj> ] + [ <st_vrf> ] [ <st_ipsla_rcode> ] [ <st_ipsla_rtt> ] [
<show_track_clnt_hdr> ] [ <show_track_clnt_start> ] [ { TABLE_track_clnt_info <st_client_name> [
<st_client_iface> ] [ <st_client_group_id> ] [ <st_client_detail> } ] ] [ <show_track_clnt_end> ] [
<st_track_list_info> ] + <st_obj_up_delay> <st_obj_down_delay> } <show_track_end> } ]
```

### Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Negate a command or set its defaults           |
| track                   | Tracking information                           |
| dynamic                 | (Optional) Entry created by client through API |
| <i>object-id</i>        | (Optional) Tracked object                      |
| interface               | (Optional) Interface objects                   |
| ip                      | (Optional) IPv4 Protocol objects               |
| route                   | (Optional) route (ipv4) objects                |
| sla                     | (Optional) Service Level Agreement objects     |
| ipv6                    | (Optional) IPv6 Protocol objects               |
| routev6                 | (Optional) route (ipv6) objects                |
| list                    | (Optional) Tracklist objects                   |
| boolean                 | (Optional) Boolean Traclist                    |
| and                     | (Optional) AND boolean objects                 |
| or                      | (Optional) OR boolean objects                  |
| threshold               | (Optional) Threshold parameters                |
| weight                  | (Optional) Threshold weight                    |
| percentage              | (Optional) Threshold percentage                |
| __readonly__            | (Optional) Read only                           |
| <i>show_track_start</i> | (Optional) Show track start                    |
| TABLE_track_detail      | (Optional) Track table detail                  |
| <i>st_obj_id</i>        | (Optional) Object id                           |

|                              |  |
|------------------------------|--|
| <i>st_obj_type</i>           | (Optional) Object Type                   |
| <i>st_obj_ms_up</i>          | (Optional) Is MS UP                      |
| <i>st_obj_ms_down</i>        | (Optional) Is MS DOWN                    |
| <i>st_obj_instance</i>       | (Optional) Object instance               |
| <i>st_obj_param</i>          | (Optional) Object parameter              |
| <i>st_obj_timer_value</i>    | (Optional) Current value of timer        |
| <i>st_obj_state</i>          | (Optional) Object status                 |
| <i>st_obj_chg_cnt</i>        | (Optional) Count of Object state changes |
| <i>st_last_chg_time</i>      | (Optional) Timestamp of last change      |
| <i>st_threshold_info</i>     | (Optional) Threshold Parameters          |
| <i>st_track_list_obj</i>     | (Optional) Objects part of this list     |
| <i>st_vrf</i>                | (Optional) VRF                           |
| <i>st_ipsla_rcode</i>        | (Optional) IP SLA Return Code            |
| <i>st_ipsla_rtt</i>          | (Optional) IP SLA RTT                    |
| <i>show_track_clnt_hdr</i>   | (Optional) Tracked by:                   |
| <i>show_track_clnt_start</i> | (Optional) Show track client start       |
| TABLE_track_clnt_info        | (Optional) Track client info             |
| <i>st_client_name</i>        | (Optional) Tracking client name          |
| <i>st_client_iface</i>       | (Optional) Tracking client interface     |
| <i>st_client_group_id</i>    | (Optional) Client group id               |
| <i>st_client_detail</i>      | (Optional) Tracking client detail        |
| <i>show_track_clnt_end</i>   | (Optional) End of track client           |
| <i>st_track_list_info</i>    | (Optional) Track list info               |
| <i>st_obj_up_delay</i>       | (Optional) Delay up notification         |
| <i>st_obj_down_delay</i>     | (Optional) Delay down notification       |
| <i>show_track_end</i>        | (Optional) End of Track                  |

**Command Mode**

- /exec

## show track brief

```
show track { [ <object-id> | interface | ip { route | sla } | ipv6 routev6 | list boolean and | list boolean or | list
threshold weight | list threshold percentage ] } [ dynamic ] brief [ __readonly__ { <show_track_brf_start>
<show_track_brf_all_begin> { TABLE_track_brief<st_brf_obj_id><st_brf_obj_type><st_brf_obj_instance>
<st_brf_obj_param><st_brf_obj_state><st_brf_last_chg_time> } <show_track_brf_end> } ]
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Negate a command or set its defaults           |
| track                           | Tracking information                           |
| dynamic                         | (Optional) Entry created by client through API |
| <i>object-id</i>                | (Optional) Tracked object                      |
| interface                       | (Optional) Interface objects                   |
| ip                              | (Optional) IPv4 Protocol objects               |
| route                           | (Optional) route (ipv4) objects                |
| sla                             | (Optional) Service Level Agreement objects     |
| ipv6                            | (Optional) IPv6 Protocol objects               |
| routev6                         | (Optional) route (ipv6) objects                |
| list                            | (Optional) Tracklist objects                   |
| boolean                         | (Optional) Boolean Traclist                    |
| and                             | (Optional) AND boolean objects                 |
| or                              | (Optional) OR boolean objects                  |
| threshold                       | (Optional) Threshold parameters                |
| weight                          | (Optional) Threshold weight                    |
| percentage                      | (Optional) Threshold percentage                |
| brief                           | Brief output                                   |
| <i>__readonly__</i>             | (Optional) Read only                           |
| <i>show_track_brf_start</i>     | (Optional) Show track brief start              |
| <i>show_track_brf_all_begin</i> | (Optional) Start of all brief                  |
| TABLE_track_brief               | (Optional) Track table brief                   |
| <i>st_brf_obj_id</i>            | (Optional) Object id                           |



|                             |                                     |
|-----------------------------|-------------------------------------|
| <i>st_brf_obj_type</i>      | (Optional) Object Type              |
| <i>st_brf_obj_instance</i>  | (Optional) Object instance          |
| <i>st_brf_obj_param</i>     | (Optional) Object parameter         |
| <i>st_brf_obj_state</i>     | (Optional) Object status            |
| <i>st_brf_last_chg_time</i> | (Optional) Timestamp of last change |
| <i>show_track_brf_end</i>   | (Optional) End of Group             |

**Command Mode**

- /exec

# show troubleshoot l2 mac vlan

show troubleshoot l2 mac <mac-addr> vlan <vlan-id> [ detail ]

## Syntax Description

|                 |  |
|-----------------|--|
| show            | Show running system information                            |
| troubleshoot    | Display troubleshoot data dump                             |
| l2              | Display l2 information                                     |
| mac             | MAC address  |
| <i>mac-addr</i> | address  |
| vlan            | Vlan ID  |
| <i>vlan-id</i>  | vlan number  |
| detail          | (Optional) Print detailed debugging info for mac/interface |

## Command Mode

- /exec

# show troubleshoot l2 port-channel

```
show troubleshoot l2 port-channel [ interface <ch-id> ]
```

## Syntax Description

|              |                                 |
|--------------|---------------------------------|
| show         | Show running system information |
| troubleshoot | Display troubleshoot data dump  |
| l2           | Display l2 information          |
| port-channel | Switched Port Channel           |
| interface    | (Optional) Interface            |
| <i>ch-id</i> | (Optional) Port-Channel name    |

## Command Mode

- /exec

## show troubleshoot l3 vrf

```
show troubleshoot l3 { ipv4 { <dip4-prefix> | <ip-prefix> } [ src-ip <sip4-prefix> ] | ipv6 { <dip6-prefix> | <ip6-prefix> } [ src-ip <sip6-prefix> ] } vrf <vrf-name>
```

### Syntax Description

|                    |   |
|--------------------|---|
| show               |   |
| troubleshoot       | Display troubleshoot data dump                        |
| l3                 | Display l3 information                                |
| ipv4               | Choose IPv4 address                                   |
| ipv6               | Choose IPv6 address                                   |
| <i>dip4-prefix</i> | Display single exact match route for Destination IP   |
| <i>ip-prefix</i>   | Display single exact match route, specify prefix/mask |
| vrf                | check routes for a specific VRF                       |
| <i>vrf-name</i>    | vrf name  |
| src-ip             | (Optional) Source IP for routing hash CLI             |
| <i>sip4-prefix</i> | (Optional) Source IPv4 address                        |

### Command Mode

- /exec

# show trunk protocol

show trunk protocol [ *\_\_readonly\_\_* <trunk\_protocol\_status> ]

## Syntax Description

|                              |                                  |
|------------------------------|----------------------------------|
| show                         | Show running system information  |
| trunk                        | Show trunk information           |
| protocol                     | Show trunk protocol information  |
| <i>__readonly__</i>          | (Optional)                       |
| <i>trunk_protocol_status</i> | (Optional) trunk protocol status |

## Command Mode

- /exec

# show ttag brief

```
show ttag brief [ __readonly__ [ TABLE_ttag <ttag-ifindex> <state> ] <ttag-end> ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| <code>ttag</code>         | enable ingress packet with ttag on this interface |
| <code>brief</code>        | ttag port in brief list                           |
| <code>__readonly__</code> | (Optional) Read Only                              |
| <code>TABLE_ttag</code>   | (Optional) ttag table                             |
| <code>ttag-ifindex</code> | (Optional) ttag ifindex                           |
| <code>state</code>        | (Optional) TTAG state                             |
| <code>ttag-end</code>     | (Optional) End of table                           |

## Command Mode

- /exec

# show ttag brief

```
show ttag brief [ __readonly__ { TABLE_ttag <ttag-ifindex> <state> } <ttag-end> ]
```

## Syntax Description

|                           |   |
|---------------------------|---|
| <code>ttag</code>         | enable ingress packet with ttag on this interface |
| <code>brief</code>        | ttag port in brief list                           |
| <code>__readonly__</code> | (Optional) Read Only                              |
| <code>TABLE_ttag</code>   | (Optional) ttag table                             |
| <code>ttag-ifindex</code> | (Optional) ttag ifindex                           |
| <code>ttag-end</code>     | (Optional) End of table                           |
| <code>state</code>        | (Optional) TTAG state                             |

## Command Mode

- /exec

# show tunnel-encryption info global

```
show tunnel-encryption info global [ __readonly__ { TABLE_tem_info_global <policy_mode> <sci_list>
<num_active_peers> } ]
```

## Syntax Description

|                              |  |
|------------------------------|--|
| show                         | Show running system information            |
| tunnel-encryption            | Show Tunnel-encryption manager information |
| info                         | Show information                           |
| global                       | Show tunnel global information             |
| <i>__readonly__</i>          | (Optional)                                 |
| <i>TABLE_tem_info_global</i> | (Optional)                                 |
| <i>policy_mode</i>           | (Optional) Global Policy Mode              |
| <i>sci_list</i>              | (Optional) SCI List                        |
| <i>num_active_peers</i>      | (Optional) Numbers of Active Peers         |

## Command Mode

- /exec



## show tunnel-encryption policy

```
show tunnel-encryption policy [ <policy_name> ] [ __readonly__ { TABLE_tun_enc_policy <name>
<cipher_suite> <window_size> <conf_offset> <security_policy> <sak-expiry-time> <include_icv_indicator>
} ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information             |
| tunnel-encryption            | Show Tunnel-encryption manager information  |
| policy                       | Show Tunnel-Encryption policy information   |
| <i>policy_name</i>           | (Optional) Name of Tunnel-encryption Policy |
| <i>__readonly__</i>          | (Optional)                                  |
| TABLE_tun_enc_policy         | (Optional)                                  |
| <i>name</i>                  | (Optional) Tunnel-Encryption Policy Name    |
| <i>cipher_suite</i>          | (Optional) Cipher Suite                     |
| <i>window_size</i>           | (Optional) Window Size                      |
| <i>conf_offset</i>           | (Optional) Confidentiality Offset           |
| <i>security_policy</i>       | (Optional) Security Policy                  |
| <i>sak-expiry-time</i>       | (Optional) SAK expiry on time interval      |
| <i>include_icv_indicator</i> | (Optional) Include ICV indicator in MKPDUs  |

### Command Mode

- /exec

## show tunnel-encryption session

```
show tunnel-encryption session [ peer-ip <peer_ipaddress_v4> ] [ detail ] [ __readonly__ [ TABLE_tem_session
<PeerAddr> <PolicyName> <KCName> <RxStatus> <TxStatus> ] [ TABLE_tem_session_detail <PeerAddr>
<PolicyName> <KCName> <CKN> <RxStatus> <TxStatus> <peersci> <rxsa_latest_an> <rxsa_old_an>
<rxsa_cs> <rxsa_winsize> <txsa_an> <txsa_cs> <txsa_ckn> <last_rx_flap> <last_tx_flap>
<last_sak_rekey_time> ] ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information               |
| tunnel-encryption        | Show Tunnel-Encryption Manager information    |
| session                  | Show session information                      |
| peer-ip                  | (Optional) Specify peer-address               |
| <i>peer_ipaddress_v4</i> | (Optional) IP Address in format A.B.C.D       |
| detail                   | (Optional) Show sessions detailed information |
| <i>__readonly__</i>      | (Optional)                                    |
| TABLE_tem_session        | (Optional)                                    |
| <i>PeerAddr</i>          | (Optional) Peer-address                       |
| <i>PolicyName</i>        | (Optional) Policy name for Peer               |
| <i>KCName</i>            | (Optional) KeyChain name for Peer             |
| <i>CKN</i>               | (Optional) Active CKN                         |
| <i>RxStatus</i>          | (Optional) Rx Session status for Peer         |
| <i>TxStatus</i>          | (Optional) Tx Session status for Peer         |
| TABLE_tem_session_detail | (Optional)                                    |
| <i>peersci</i>           | (Optional) Peer SCI list                      |
| <i>rxsa_latest_an</i>    | (Optional) RxSA Latest AN                     |
| <i>rxsa_old_an</i>       | (Optional) RxSA Old AN                        |
| <i>rxsa_cs</i>           | (Optional) RxSA Cipher-suite                  |
| <i>rxsa_winsize</i>      | (Optional) RxSA Replay Window-size            |
| <i>txsa_an</i>           | (Optional) TxSA AN                            |
| <i>txsa_cs</i>           | (Optional) TxSA Cipher-Suite                  |
| <i>txsa_ckn</i>          | (Optional) TxSA CKN                           |

|                            |                                      |
|----------------------------|--------------------------------------|
| <i>last_rx_flap</i>        | (Optional) Last Rx session flap time |
| <i>last_tx_flap</i>        | (Optional) Last Tx session flap time |
| <i>last_sak_rekey_time</i> | (Optional) Last SAK rekey            |

**Command Mode**

- /exec

## show tunnel-encryption statistics

```
show tunnel-encryption statistics [ peer-ip <peer_ipaddress_v4> ] [ __readonly__ [ TABLE_statistics
<PeerAddr> [ TABLE_rx_sa_an <rx_sa_an> [ <in_pkts_unchecked> ] [ <in_pkts_delayed> ] [ <in_pkts_late>
] [ <in_pkts_ok> ] [ <in_pkts_invalid> ] [ <in_pkts_not_valid> ] [ <in_pkts_not_using_sa> ] [
<in_pkts_unused_sa> ] [ <in_pkts_decrypted> ] [ <in_octets_decrypted> ] [ <in_octets_validated> ] ] [
TABLE_tx_sa_an <tx_sa_an> [ <out_pkts_encrypted_protected> ] [ <out_pkts_too_long> ] [
<out_pkts_untagged> ] [ <out_octets_encrypted_protected> ] ] ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| show                        | Show running system information              |
| tunnel-encryption           | Show Tunnel-Encryption Manager information   |
| statistics                  | Show Tunnel-Encryption statistics            |
| peer-ip                     | (Optional) Specify peer-address              |
| <i>peer_ipaddress_v4</i>    | (Optional) IP Address in format A.B.C.D      |
| <i>__readonly__</i>         | (Optional)                                   |
| TABLE_statistics            | (Optional) Tunnel-Encryption secy statistics |
| <i>PeerAddr</i>             | (Optional) Peer-address                      |
| TABLE_rx_sa_an              | (Optional) Tunnel-Encryption RxSA statistics |
| <i>rx_sa_an</i>             | (Optional) Rx SA AN                          |
| <i>in_pkts_unchecked</i>    | (Optional) In Pkts Unchecked                 |
| <i>in_pkts_delayed</i>      | (Optional) In Pkts Delayed                   |
| <i>in_pkts_late</i>         | (Optional) In Pkts Late                      |
| <i>in_pkts_ok</i>           | (Optional) In Pkts OK                        |
| <i>in_pkts_invalid</i>      | (Optional) In Pkts Invalid                   |
| <i>in_pkts_not_valid</i>    | (Optional) In Pkts not Valid                 |
| <i>in_pkts_not_using_sa</i> | (Optional) In Pkts not using SA              |
| <i>in_pkts_unused_sa</i>    | (Optional) In Pkts Unused SA                 |
| <i>in_pkts_decrypted</i>    | (Optional) In Pkts Decrypted                 |
| <i>in_octets_decrypted</i>  | (Optional) In Octets Decrypted               |
| <i>in_octets_validated</i>  | (Optional) In Octets Validated               |
| TABLE_tx_sa_an              | (Optional) Tunnel-Encryption TxSA statistics |

|                                       |   |
|---------------------------------------|---|
| <i>tx_sa_an</i>                       | (Optional) Tx SA AN                       |
| <i>out_pkts_encrypted_protected</i>   | (Optional) Out Pkts Encrypted Protected   |
| <i>out_pkts_too_long</i>              | (Optional) Out Pkts too Long              |
| <i>out_pkts_untagged</i>              | (Optional) Out Pkts SA not in use         |
| <i>out_octets_encrypted_protected</i> | (Optional) Out octets Encrypted Protected |

**Command Mode**

- /exec

# show tunnel-profile

```
show tunnel-profile [ <profile-name> ] [ __readonly__ [ TABLE_tunnel <profile-name> <encap-type> <status>
[ <num_of_routes> <num_of_err_routes> <num_of_policies> <src-vtep> <src-intf> ] [ [ <destination> ] [
<erspan-sess-all> ] [ <erspan-sess-id> ] <num_of_terminate_intf> <terminate_intf> ] ] ]
```

## Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information             |
| tunnel-profile               | Tunnel Profile                              |
| <i>profile-name</i>          | (Optional) Name of the Tunnel Profile       |
| <i>__readonly__</i>          | (Optional)                                  |
| TABLE_tunnel                 | (Optional) Tunnel profile Table             |
| <i>profile-name</i>          | (Optional) Tunnel profile name              |
| <i>num_of_routes</i>         | (Optional) number of static routes          |
| <i>num_of_err_routes</i>     | (Optional) number of tunnel routes in error |
| <i>encap-type</i>            | (Optional) Encap type of the profile        |
| <i>status</i>                | (Optional) Tunnel profile status            |
| <i>num_of_policies</i>       | (Optional) number of flow policies          |
| <i>src-vtep</i>              | (Optional) Source VTEP IP                   |
| <i>src-intf</i>              | (Optional) Source Interface                 |
| <i>destination</i>           | (Optional) Destination                      |
| <i>erspan-sess-all</i>       | (Optional) ERSPAN Session ID all            |
| <i>erspan-sess-id</i>        | (Optional) ERSPAN Session ID                |
| <i>num_of_terminate_intf</i> | (Optional) number of terminate interfaces   |
| <i>terminate_intf</i>        | (Optional) terminate interfaces             |

## Command Mode

- /exec



## U Show Commands

---

- [show uddl](#), on page 3386
- [show uddl global](#), on page 3388
- [show uddl neighbors](#), on page 3389
- [show upgrade history](#), on page 3390
- [show user-account](#), on page 3391
- [show username keypair](#), on page 3392
- [show username passphrase timevalues](#), on page 3393
- [show userpassphrase](#), on page 3394
- [show userpassphrase](#), on page 3395
- [show users](#), on page 3396

## show uddld

```
show uddld [ <if0> ] [ __readonly__ TABLE_interface <interface> <mib-port-status> <mib-oper-status>
<mib-aggressive-mode> <admin-port-mode> <operational-port-mode> <current-bidirectional-state>
<current-operational-state> <no-multiple-neighbor-detected> <message-interval> <timeout-interval>
TABLE_entry [ <entry-number> ] [ <expiration-time> ] [ <device-id> ] [ <neighbor-state> ] [ <device-name>
] [ <port-id> ] [ <neighbor-echo-device-number> ] [ <neighbor-echo-device-name> ] [
<neighbor-echo-port-number> ] [ <neighbor-echo-port-id> ] [ <neighbor-message-interval> ] [
<neighbor-timeout-interval> ] [ <cdp-device-name> ] [ <pkt-xmt-rec-time> ] + [ <pc-index> ] ]
```

### Syntax Description

|                                      |   |
|--------------------------------------|---|
| show                                 | Show running system information   |
| uddld                                | UDLD status and configuration on one or all interfaces                            |
| <i>if0</i>                           | (Optional) Enter an interface name if only one single interface status is desired |
| <i>__readonly__</i>                  | (Optional)  |
| TABLE_interface                      | (Optional)  |
| <i>interface</i>                     | (Optional) Interface ID   |
| <i>mib-port-status</i>               | (Optional) Port MIB enable status   |
| <i>mib-oper-status</i>               | (Optional) Port MIB Operational status  |
| <i>mib-aggressive-mode</i>           | (Optional) Port MIB aggressive mode   |
| <i>admin-port-mode</i>               | (Optional) Port enable administration configuration setting                       |
| <i>operational-port-mode</i>         | (Optional) Port enable operational state  |
| <i>current-bidirectional-state</i>   | (Optional) Current bidirectional state  |
| <i>current-operational-state</i>     | (Optional) Current operational state  |
| <i>no-multiple-neighbor-detected</i> | (Optional) No multiple neighbor detected  |
| <i>message-interval</i>              | (Optional) UDLD probe message interval  |
| <i>timeout-interval</i>              | (Optional) UDLD detection timeout interval  |
| TABLE_entry                          | (Optional) Neighbor entry info  |
| <i>entry-number</i>                  | (Optional) Neighbor entry number  |
| <i>expiration-time</i>               | (Optional) Expiration time  |
| <i>device-id</i>                     | (Optional) Device ID  |
| <i>neighbor-state</i>                | (Optional) Current neighbor state   |



|                                    |  |
|------------------------------------|--|
| <i>device-name</i>                 | (Optional) Device name                     |
| <i>port-id</i>                     | (Optional) Port ID                         |
| <i>neighbor-echo-device-number</i> | (Optional) Echo device number              |
| <i>neighbor-echo-device-name</i>   | (Optional) Echo device name                |
| <i>neighbor-echo-port-number</i>   | (Optional) Echo port number                |
| <i>neighbor-echo-port-id</i>       | (Optional) Echo port ID                    |
| <i>neighbor-message-interval</i>   | (Optional) UDLD probe message interval     |
| <i>neighbor-timeout-interval</i>   | (Optional) UDLD detection timeout interval |
| <i>cdp-device-name</i>             | (Optional) CDP Device name                 |
| <i>pkt-xmt-rec-time</i>            | (Optional) Last UDLD packet send/recv time |
| <i>pc-index</i>                    | (Optional) Port channel index              |

**Command Mode**

- /exec

# show udd global

show udd global [ \_\_readonly\_\_ <udd-global-mode> <message-interval> ]

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                        |
| udd                     | UDLD protocol  |
| global                  | UDLD global status and configuration on all interfaces |
| __readonly__            | (Optional)   |
| <i>udd-global-mode</i>  | (Optional) UDLD global configuration setting           |
| <i>message-interval</i> | (Optional) UDLD probe message interval                 |

## Command Mode

- /exec

# show udd neighbors

show udd neighbors [ *\_\_readonly\_\_* *TABLE\_entry* <local-port-id> <neighbor-echo-device-name> <device-id> <neighbor-echo-port-id> <neighbor-state> ]

## Syntax Description

|                                  |                                   |
|----------------------------------|-----------------------------------|
| show                             | Show running system information   |
| udd                              | UDLD protocol                     |
| neighbors                        | UDLD neighbor interfaces          |
| <i>__readonly__</i>              | (Optional)                        |
| <i>TABLE_entry</i>               | (Optional)                        |
| <i>local-port-id</i>             | (Optional) Local port ID          |
| <i>neighbor-echo-device-name</i> | (Optional) Echo device name       |
| <i>device-id</i>                 | (Optional) Device ID              |
| <i>neighbor-echo-port-id</i>     | (Optional) Echo port ID           |
| <i>neighbor-state</i>            | (Optional) Current neighbor state |

## Command Mode

- /exec

# show upgrade history

```
show upgrade history [ __readonly__ { [ TABLE_installHistory <installHistoryStr> ] } ]
```

## Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                   |
| upgrade                  | Show the upgrade history                          |
| history                  | Show the upgrade history of software and firmware |
| __readonly__             | (Optional)  |
| TABLE_installHistory     | (Optional) Upgrade History table                  |
| <i>installHistoryStr</i> | (Optional)  |

## Command Mode

- /exec

## show user-account

```
show user-account [ <s0> ] [ __readonly__ TABLE_template <usr_name> [ <expire_date> ] { TABLE_role
<role> } [ <remote_login> ] [ <sshkey_info> ] { [ TABLE_keys <ssh_keys> ] } ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                                    |
| TABLE_template      | (Optional)   |
| TABLE_role          | (Optional)   |
| TABLE_keys          | (Optional)   |
| __readonly__        | (Optional)   |
| <i>usr_name</i>     | (Optional) Name of the user  |
| <i>expire_date</i>  | (Optional) Expiry date for this user account(in YYYY-MM-DD format) |
| <i>role</i>         | (Optional) role/s which the user is to be assigned to              |
| <i>remote_login</i> | (Optional) Remote account information for a remote user            |
| <i>sshkey_info</i>  | (Optional) SSH key information of user                             |
| <i>ssh_keys</i>     | (Optional) SSH key pairs of the user                               |
| user-account        | Show user information  |
| <i>s0</i>           | (Optional) User name   |

### Command Mode

- /exec

# show username keypair

```
show username <s0> keypair [ __readonly__ { TABLE_sessions <t_type> <t_time> <t_keys> <t_bitcount>
<t_fingerprint> } ]
```

## Syntax Description

|                      |                                 |
|----------------------|---------------------------------|
| show                 | Show running system information |
| username             | Show user information.          |
| keypair              | Show SSH keypairs               |
| <i>s0</i>            | user name                       |
| __readonly__         | (Optional)                      |
| TABLE_sessions       | (Optional) username keypair     |
| <i>t_type</i>        | (Optional) keys type            |
| <i>t_time</i>        | (Optional) timestamp            |
| <i>t_keys</i>        | (Optional) ssh key              |
| <i>t_bitcount</i>    | (Optional) bitcount             |
| <i>t_fingerprint</i> | (Optional) fingerprint          |

## Command Mode

- /exec

## show username passphrase timevalues

```
show username <username> passphrase timevalues [ __readonly__ [ timevalues [ <tvalue> ] ] [
passphrase_change <last_passphrase_change> ] [ Default_lifetime <def_ltime> ] [ Default_warntime
<def_wrntime> ] [ Default_gracetime <def_gtime> ] ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                          |
| username                      | Configure user information.                              |
| <i>username</i>               | user name  |
| passphrase                    | user passphrase  |
| timevalues                    | passphrase lifetime, warningtime and gracetime           |
| <i>__readonly__</i>           | (Optional)   |
| timevalues                    | (Optional) Timevalues of the Passphrase                  |
| <i>tvalue</i>                 | (Optional) Absolute time values of the Passphrase        |
| passphrase_change             | (Optional) passphrase last change date                   |
| <i>last_passphrase_change</i> | (Optional) absolute last passphrase change date          |
| Default_lifetime              | (Optional) Default Lifetime of the Passphrase            |
| <i>def_ltime</i>              | (Optional) Absolute life time value of the passphrase    |
| Default_warntime              | (Optional) Default Warningtime of the Passphrase         |
| <i>def_wrntime</i>            | (Optional) Absolute warning time value of the Passphrase |
| Default_gracetime             | (Optional) Default Grace time of the Passphrase          |
| <i>def_gtime</i>              | (Optional) Absolute Grace time value of the Passphrase   |

### Command Mode

- /exec

# show userpassphrase

```
show userpassphrase { default-lifetime | default-warntime | default-gracetime | timevalues } [ __readonly__
[ Default_warntime <def_wrntime> ] [ Default_gracetime <def_gtime> ] [ Default_lifetime <def_ltime> ] ]
```

## Syntax Description

|                    |  |
|--------------------|--|
| show               | Show running system information                          |
| userpassphrase     | user passphrase  |
| default-lifetime   | passphrase default lifetime                              |
| default-warntime   | passphrase default warningtime                           |
| default-gracetime  | passphrase default gracetime                             |
| timevalues         | passphrase lifetime, warning time and gracetime          |
| __readonly__       | (Optional)   |
| Default_warntime   | (Optional) Default Warningtime of the Passphrase         |
| <i>def_wrntime</i> | (Optional) Absolute warning time value of the Passphrase |
| Default_gracetime  | (Optional) Default Grace time of the Passphrase          |
| <i>def_gtime</i>   | (Optional) Absolute Grace time value of the Passphrase   |
| Default_lifetime   | (Optional) Default Lifetime of the Passphrase            |
| <i>def_ltime</i>   | (Optional) Absolute life time value of the passphrase    |

## Command Mode

- /exec



# show userpassphrase

```
show userpassphrase { min-length | max-length | length } [ __readonly__ [ Minimum_length <min_length>
] [ Maximum_length <max_length> ] ]
```

## Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information                 |
| userpassphrase    | user passphrase                                 |
| min-length        | passphrase minimum length                       |
| max-length        | passphrase maximum length                       |
| length            | passphrase min and max length                   |
| __readonly__      | (Optional)                                      |
| Minimum_length    | (Optional) minimum length of the passphrase     |
| <i>min_length</i> | (Optional) Absolute value of the Minimum length |
| Maximum_length    | (Optional) Maximum length of the passphrase     |
| <i>max_length</i> | (Optional) Absolute value of max length         |

## Command Mode

- /exec

# show users

```
show users [ __readonly__ { TABLE_sessions <u_name> <t_terminal> <t_time> <t_idle> <p_pid>
<c_comment> } ]
```

## Syntax Description

|                   |   |
|-------------------|---|
| show              | Show running system information             |
| users             | Show the current users logged in the system |
| __readonly__      | (Optional)                                  |
| TABLE_sessions    | (Optional) users table                      |
| <i>u_name</i>     | (Optional) user name                        |
| <i>t_terminal</i> | (Optional) terminal                         |
| <i>t_time</i>     | (Optional) time                             |
| <i>t_idle</i>     | (Optional) idle                             |
| <i>p_pid</i>      | (Optional) pid                              |
| <i>c_comment</i>  | (Optional) comment                          |

## Command Mode

- /exec



## V Show Commands

---

- [show vdc](#), on page 3399
- [show vdc current-vdc](#), on page 3401
- [show vdc fcoe-vlan-range](#), on page 3402
- [show vdc resource](#), on page 3403
- [show vdc resource](#), on page 3404
- [show vdc resource template](#), on page 3405
- [show version](#), on page 3406
- [show version epld](#), on page 3408
- [show version image](#), on page 3409
- [show version module](#), on page 3410
- [show version module epld](#), on page 3411
- [show virtual-service](#), on page 3412
- [show virtual-service storage pool list](#), on page 3415
- [show virtual-service tech-support](#), on page 3416
- [show virtual-service utilization name](#), on page 3417
- [show virtual-service version](#), on page 3418
- [show vlan](#), on page 3419
- [show vlan access-list](#), on page 3421
- [show vlan access-map](#), on page 3425
- [show vlan all-ports](#), on page 3426
- [show vlan counters](#), on page 3427
- [show vlan dot1Q tag native](#), on page 3428
- [show vlan fcoe](#), on page 3429
- [show vlan filter](#), on page 3430
- [show vlan id](#), on page 3431
- [show vlan id counters](#), on page 3433
- [show vlan id vn-segment](#), on page 3435
- [show vlan name](#), on page 3436
- [show vlan private-vlan](#), on page 3438
- [show vlan private-vlan type](#), on page 3439
- [show vlan xbrief](#), on page 3440
- [show vlan xsummary](#), on page 3441
- [show vmtracker](#), on page 3442

- [show vmtracker certificate](#), on page 3444
- [show vmtracker fabric auto-config](#), on page 3445
- [show vmtracker status](#), on page 3446
- [show vpc](#), on page 3447
- [show vpc](#), on page 3450
- [show vpc consistency-parameters](#), on page 3451
- [show vpc consistency-parameters vlans](#), on page 3452
- [show vpc fabric-ports](#), on page 3453
- [show vpc orphan-ports](#), on page 3454
- [show vpc peer-keepalive](#), on page 3455
- [show vpc role](#), on page 3456
- [show vpc statistics peer-keepalive](#), on page 3457
- [show vpc statistics vpc](#), on page 3458
- [show vpc virtual-peerlink dest reachable](#), on page 3459
- [show vpc virtual-peerlink vlan consistency](#), on page 3460
- [show vrf](#), on page 3461
- [show vrf](#), on page 3462
- [show vrrp](#), on page 3464
- [show vrrp bfd-sessions](#), on page 3467
- [show vrrpv3](#), on page 3468
- [show vrrs client](#), on page 3472
- [show vrrs pathway](#), on page 3473
- [show vrrs server](#), on page 3474
- [show vrrs tag](#), on page 3475
- [show vsan](#), on page 3476
- [show vsan membership](#), on page 3477
- [show vsan membership interface](#), on page 3478
- [show vsan usage](#), on page 3479
- [show vtp counters](#), on page 3480
- [show vtp interface](#), on page 3481
- [show vtp password](#), on page 3482
- [show vtp status](#), on page 3483

# show vdc

```
{ show vdc [ <e-vdc2> ] [ feature-set | detail | membership [ all | status | module <module> ] | shared membership
] [ __readonly__ [ detail2 ] [ <swmode> ] { TABLE_vdc <vdc_id> <vdc_name> <state> <mac> <hap> <sw>
<boot_order> [ <prio> <prio_per> ] [ <create_time> ] [ <reload_count> ] [ <restart_count> ] [ <restart_time>
] [ <restart_reason> ] <vtype> <lc-support> [ TABLE_fs <fs_id> <fs_name> ] [ TABLE_port <port-list> ]
} ] }
```

## Syntax Description

|                     |   |
|---------------------|---|
| show                | Show Virtual Device Contexts  |
| vdc                 | Show Virtual Device Contexts  |
| <i>e-vdc2</i>       | (Optional) Enter Virtual Device Context <vdc-id>                                |
| detail              | (Optional) Show detailed vdc information  |
| membership          | (Optional) Show vdc interface membership information                            |
| shared              | (Optional) Show the shared interfaces in a vdc                                  |
| membership          | (Optional) Show the shared interfaces in a vdc                                  |
| module              | (Optional) Show vdc interface membership information for a specific module only |
| <i>module</i>       | (Optional) Show vdc interface membership information for a specific module only |
| status              | (Optional) Show vdc related port-status   |
| feature-set         | (Optional) Show vdc feature-set information                                     |
| all                 | (Optional) Show offline modules as well   |
| <u>__readonly__</u> | (Optional) Read Only  |
| detail2             | (Optional)  |
| <i>swmode</i>       | (Optional)  |
| TABLE_vdc           | (Optional)  |
| <i>vdc_id</i>       | (Optional) vdc-id   |
| TABLE_port          | (Optional)  |
| <i>port-list</i>    | (Optional) port membership for VDC  |
| <i>vdc_name</i>     | (Optional) vdc-name   |
| <i>state</i>        | (Optional) state  |
| <i>mac</i>          | (Optional) mac address for VDC  |

|                       |                       |
|-----------------------|-----------------------|
| <i>hap</i>            | (Optional) hap policy |
| <i>sw</i>             | (Optional) sw policy  |
| <i>vtype</i>          | (Optional)            |
| <i>lc-support</i>     | (Optional)            |
| <i>create_time</i>    | (Optional)            |
| <i>reload_count</i>   | (Optional)            |
| <i>restart_count</i>  | (Optional)            |
| <i>restart_time</i>   | (Optional)            |
| <i>restart_reason</i> | (Optional)            |
| TABLE_fs              | (Optional)            |
| <i>fs_id</i>          | (Optional) fs id      |
| <i>fs_name</i>        | (Optional)            |
| <i>boot_order</i>     | (Optional)            |
| <i>prio</i>           | (Optional)            |
| <i>prio_per</i>       | (Optional)            |

### Command Mode

- /exec

## show vdc current-vdc

```
show vdc current-vdc [ __readonly__ <mode> <name> ]
```

### Syntax Description

|              |                                     |
|--------------|-------------------------------------|
| show         | Show Virtual Device Contexts        |
| vdc          | Show Virtual Device Contexts        |
| current-vdc  | Show which vdc you are currently in |
| __readonly__ | (Optional) Read Only                |
| <i>mode</i>  | (Optional) cli mode                 |
| <i>name</i>  | (Optional) vdc name                 |

### Command Mode

- /exec

# show vdc fcoe-vlan-range

```
show vdc fcoe-vlan-range [ __readonly__ <fcoe-vdc> [ <fcoe-vlans> ] [ <sharing-vdcs> ] ]
```

## Syntax Description

|                     |                              |
|---------------------|------------------------------|
| show                | Show Virtual Device Contexts |
| vdc                 | Show Virtual Device Contexts |
| fcoe-vlan-range     | vlans reserved for FCoE      |
| __readonly__        | (Optional) Read Only         |
| <i>fcoe-vdc</i>     | (Optional)                   |
| <i>sharing-vdcs</i> | (Optional)                   |
| <i>fcoe-vlans</i>   | (Optional)                   |

## Command Mode

- /exec



## show vdc resource

```
show vdc <id> resource [ <res-mgr-res-known-name> ] [ __readonly__ { TABLE_vdc_resource_single_vdc
<res_name> <min> <max> <used> <unused> <free> } ]
```

### Syntax Description

|                               |  |
|-------------------------------|--|
| show                          | Show running system information                                  |
| vdc                           | Show Virtual Device Contexts                                     |
| <i>id</i>                     | Enter Virtual Device Context <vdc-id>                            |
| resource                      | Show resource configuration for VDC                              |
| <i>res-mgr-res-known-name</i> | (Optional) Resource name   |
| <i>__readonly__</i>           | (Optional) Read Only   |
| <i>res_name</i>               | (Optional) Resource Name   |
| <i>min</i>                    | (Optional) Resource min configuration                            |
| <i>max</i>                    | (Optional) Resource max configuration                            |
| <i>used</i>                   | (Optional) Resource current usage for this VDC                   |
| <i>unused</i>                 | (Optional) Resource reserved for this VDC but currently not used |
| <i>free</i>                   | (Optional) Resource current free for this VDC                    |
| TABLE_vdc_resource_single_vdc | (Optional)   |

### Command Mode

- /exec

## show vdc resource

```
show vdc resource [ <res-mgr-res-known-name> ] [ detail | hidden-too | with-flags ] + [ __readonly__ {
TABLE_resource <resource_name> <total_used> <total_unused> <total_free> <total_avail> <total> [
TABLE_vdc_resource_across_vdcs <vdc_name> <min> <max> <used> <unused> <free> } } ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                                     |
| vdc                            | Show Virtual Device Contexts  |
| resource                       | Show resource configuration across VDCs                             |
| <i>res-mgr-res-known-name</i>  | (Optional) Resource name  |
| detail                         | (Optional) Show detail resource configuration                       |
| hidden-too                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                           |
| with-flags                     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED                           |
| __readonly__                   | (Optional) Read Only  |
| TABLE_resource                 | (Optional)  |
| <i>resource_name</i>           | (Optional) Resource Name  |
| <i>total_used</i>              | (Optional) Resource current usage for all VDC                       |
| <i>total_unused</i>            | (Optional) Resources currently reserved but not used across all VDC |
| <i>total_free</i>              | (Optional) Resource current free for all VDC                        |
| <i>total_avail</i>             | (Optional) Resource current available across all VDC                |
| <i>total</i>                   | (Optional) Resources grand total                                    |
| TABLE_vdc_resource_across_vdcs | (Optional)  |
| <i>vdc_name</i>                | (Optional) VDC name   |
| <i>min</i>                     | (Optional) Resource min configuration                               |
| <i>max</i>                     | (Optional) Resource max configuration                               |
| <i>used</i>                    | (Optional) Resource current usage for this VDC                      |
| <i>unused</i>                  | (Optional) Resource reserved for this VDC but currently not used    |
| <i>free</i>                    | (Optional) Resource current free for this VDC                       |

### Command Mode

- /exec

# show vdc resource template

```
show vdc resource template [ <res-mgr-template-known-name-all> ] [ __readonly__ TABLE_template
<template_name> { TABLE_resource <resource_name> <min> <max> } ]
```

## Syntax Description

|  |                                       |
|--|---------------------------------------|
| show                                   | Show running system information       |
| vdc                                    | Show Virtual Device Contexts          |
| resource                               | Show resource configuration for VDC   |
| template                               | Resource template configuration       |
| <i>res-mgr-template-known-name-all</i> | (Optional) Resource template name     |
| <i>__readonly__</i>                    | (Optional) Read Only                  |
| TABLE_template                         | (Optional)                            |
| <i>template_name</i>                   | (Optional) Resource Template Name     |
| TABLE_resource                         | (Optional)                            |
| <i>resource_name</i>                   | (Optional) Resource Name              |
| <i>min</i>                             | (Optional) Resource min configuration |
| <i>max</i>                             | (Optional) Resource max configuration |

## Command Mode

- /exec

## show version

```
show version [ __readonly__ <header_str> <bios_ver_str> [ <epld_ver_str> ] [ <loader_ver_str> ]
<kickstart_ver_str> <release_type> <nxos_ver_str> [ <sys_ver_str> ] <bios_cmpl_time> <kick_file_name>
<nxos_file_name> <kick_cmpl_time> <nxos_cmpl_time> <kick_tmstamp> <nxos_tmstamp> [ <isan_file_name>
] [ <isan_cmpl_time> ] [ <isan_tmstamp> ] [ <boot_lxc_mode> ] <chassis_id> [ <module_id> ] <cpu_name>
<memory> <mem_type> <proc_board_id> <host_name> <bootflash_size> [ <slot0_size> ] [ <slot1_size> ]
<kern_uptm_days> <kern_uptm_hrs> <kern_uptm_mins> <kern_uptm_secs> [ <rr_usecs> ] [ <rr_ctime> ]
<rr_reason> <rr_sys_ver> <rr_service> <plugins> <manufacturer> [ TABLE_smu_list <install_smu_id> +
] [ TABLE_package_list <package_id> + ] ]
```

### Syntax Description

|                          |                           |
|--------------------------|---------------------------|
| show                     |                           |
| version                  | Show the software version |
| <i>__readonly__</i>      | (Optional)                |
| <i>header_str</i>        | (Optional)                |
| <i>bios_ver_str</i>      | (Optional)                |
| <i>epld_ver_str</i>      | (Optional)                |
| <i>loader_ver_str</i>    | (Optional)                |
| <i>kickstart_ver_str</i> | (Optional)                |
| <i>nxos_ver_str</i>      | (Optional)                |
| <i>release_type</i>      | (Optional)                |
| <i>sys_ver_str</i>       | (Optional)                |
| <i>bios_cmpl_time</i>    | (Optional)                |
| <i>kick_file_name</i>    | (Optional)                |
| <i>nxos_file_name</i>    | (Optional)                |
| <i>kick_cmpl_time</i>    | (Optional)                |
| <i>nxos_cmpl_time</i>    | (Optional)                |
| <i>kick_tmstamp</i>      | (Optional)                |
| <i>nxos_tmstamp</i>      | (Optional)                |
| <i>isan_file_name</i>    | (Optional)                |
| <i>isan_cmpl_time</i>    | (Optional)                |
| <i>isan_tmstamp</i>      | (Optional)                |

|                       |                         |
|-----------------------|-------------------------|
| <i>boot_lxc_mode</i>  | (Optional)              |
| <i>chassis_id</i>     | (Optional)              |
| <i>module_id</i>      | (Optional)              |
| <i>cpu_name</i>       | (Optional)              |
| <i>memory</i>         | (Optional)              |
| <i>mem_type</i>       | (Optional)              |
| <i>proc_board_id</i>  | (Optional)              |
| <i>host_name</i>      | (Optional)              |
| <i>bootflash_size</i> | (Optional)              |
| <i>slot0_size</i>     | (Optional)              |
| <i>slot1_size</i>     | (Optional)              |
| <i>kern_uptm_days</i> | (Optional)              |
| <i>kern_uptm_hrs</i>  | (Optional)              |
| <i>kern_uptm_mins</i> | (Optional)              |
| <i>kern_uptm_secs</i> | (Optional)              |
| <i>rr_usecs</i>       | (Optional)              |
| <i>rr_ctime</i>       | (Optional)              |
| <i>rr_reason</i>      | (Optional)              |
| <i>rr_sys_ver</i>     | (Optional)              |
| <i>rr_service</i>     | (Optional)              |
| <i>plugins</i>        | (Optional)              |
| <i>manufacturer</i>   | (Optional)              |
| TABLE_smu_list        | (Optional)              |
| <i>install_smu_id</i> | (Optional)              |
| TABLE_package_list    | (Optional)              |
| <i>package_id</i>     | (Optional) Package name |

**Command Mode**

- /exec

# show version epld

```
show version epld <uri0> [ __readonly__ <image-info> [ { TABLE_module_info <module-type> <model>
<epld-device> <version> } ] ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information            |
| version             | Show the software version                  |
| epld                | Show EPLD versions available in EPLD image |
| <i>uri0</i>         | Local URI containing EPLD Image            |
| <i>__readonly__</i> | (Optional)                                 |
| <i>image-info</i>   | (Optional) image file info                 |
| TABLE_module_info   | (Optional)                                 |
| <i>module-type</i>  | (Optional) module type                     |
| <i>model</i>        | (Optional) model                           |
| <i>epld-device</i>  | (Optional) epld device                     |
| <i>version</i>      | (Optional) version                         |

## Command Mode

- /exec

# show version image

```
show version image <uri0> [ __readonly__ <md5_str> <img_file_name> [ <bios_ver_str> ] <sys_ver_str>
<img_cmpl_time> [ <img_tmstamp> ] ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information            |
| version              | Show the software version                  |
| image                | Show the software version of a given image |
| <i>uri0</i>          | Enter URI                                  |
| <i>__readonly__</i>  | (Optional)                                 |
| <i>md5_str</i>       | (Optional)                                 |
| <i>img_file_name</i> | (Optional)                                 |
| <i>bios_ver_str</i>  | (Optional)                                 |
| <i>sys_ver_str</i>   | (Optional)                                 |
| <i>img_cmpl_time</i> | (Optional)                                 |
| <i>img_tmstamp</i>   | (Optional)                                 |

## Command Mode

- /exec

# show version module

```
show version module <module> [ __readonly__ { TABLE_version <slot> <type> <sw> <interim> <bios> } ]
```

## Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| version             | Show the software version             |
| module              | Show the software version of a Module |
| <i>module</i>       | Enter module number                   |
| <i>__readonly__</i> | (Optional)                            |
| TABLE_version       | (Optional) Show version info          |
| <i>slot</i>         | (Optional) Slot                       |
| <i>type</i>         | (Optional) image type                 |
| <i>sw</i>           | (Optional) SW version                 |
| <i>interim</i>      | (Optional) SW interim version         |
| <i>bios</i>         | (Optional) BIOS version               |

## Command Mode

- /exec



## show version module epld

```
show version module <module> epld [ __readonly__ { [ <header_info> ] [ <module> ] [ <mi_iofpga> <version> ] [ <io_fpga> <version> ] [ <mi_iofpga2> <version> ] [ <mi_iofpga3> <version> ] [ <mi_iofpga4> <version> ] [ <mi_iofpga5> <version> ] [ <mi_iofpga6> <version> ] [ <mi_iofpga7> <version> ] [ <mi_iofpga8> <version> ] [ <cpu_iofpga> <version> ] [ <db_fpga> <version> ] } ]
```

### Syntax Description

|                     |                                       |
|---------------------|---------------------------------------|
| show                | Show running system information       |
| version             | Show the software version             |
| module              | Show the software version of a Module |
| <i>module</i>       | Enter module number                   |
| epld                | Show a module's current EPLD versions |
| <i>__readonly__</i> | (Optional)                            |
| <i>header_info</i>  | (Optional)                            |
| <i>module</i>       | (Optional)                            |
| <i>mi_iofpga</i>    | (Optional)                            |
| <i>io_fpga</i>      | (Optional)                            |
| <i>mi_iofpga2</i>   | (Optional)                            |
| <i>mi_iofpga3</i>   | (Optional)                            |
| <i>mi_iofpga4</i>   | (Optional)                            |
| <i>mi_iofpga5</i>   | (Optional)                            |
| <i>mi_iofpga6</i>   | (Optional)                            |
| <i>mi_iofpga7</i>   | (Optional)                            |
| <i>mi_iofpga8</i>   | (Optional)                            |
| <i>cpu_iofpga</i>   | (Optional)                            |
| <i>db_fpga</i>      | (Optional)                            |
| <i>version</i>      | (Optional)                            |

### Command Mode

- /exec

## show virtual-service

```
show virtual-service [ { list } | { global } | { detail [ name <virt_serv_name> ] } | { core [ name
<virt_serv_name_core> ] } ] [ __readonly__ [ <infrastructure_major_version> <infrastructure_minor_version>
<total_virtual_services_installed> <total_virtual_services_activated> <machine_types_supported>
<machine_types_disabled> <maximum_vcpus_per_virtual_service> TABLE_resource_limits <media_name>
<quota> <committed> <available> ] [ TABLE_list <name> <status> <package_name> ] [ TABLE_detail
<name> <state> <package_name> <ova_path> <application_name> <application_version>
<application_description> <key_type> <signing_method> <licensing_name> <licensing_version>
<disk_reservation> <memory_reservation> <cpu_reservation> TABLE_attached_devices <type> <name>
<alias> ] [ TABLE_core <name> <name_core> ] ]
```

### Syntax Description

|  |   |
|--|---|
| show                                     | Show running system information                       |
| virtual-service                          | Display virtualization service information            |
| global                                   | (Optional) Virtual service global information         |
| list                                     | (Optional) List virtual services                      |
| detail                                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED             |
| core                                     | (Optional) Core information                           |
| name                                     | (Optional) Information for a specific virtual service |
| <i>virt_serv_name</i>                    | (Optional) Name of a virtual service                  |
| <i>virt_serv_name_core</i>               | (Optional) Name of a virtual service                  |
| <i>__readonly__</i>                      | (Optional) Read Only                                  |
| <i>infrastructure_major_version</i>      | (Optional) Infrastructure major version               |
| <i>infrastructure_minor_version</i>      | (Optional) Infrastructure minor version               |
| <i>total_virtual_services_installed</i>  | (Optional) Total virtual services installed           |
| <i>total_virtual_services_activated</i>  | (Optional) Total virtual services activated           |
| <i>maximum_vcpus_per_virtual_service</i> | (Optional) Maximum VCPUs per virtual service          |
| <i>machine_types_supported</i>           | (Optional) Machine types supported                    |
| <i>machine_types_disabled</i>            | (Optional) Machine types disabled                     |
| TABLE_resource_limits                    | (Optional) Virtual service global resource limits     |
| <i>media_name</i>                        | (Optional) Resource name                              |
| <i>quota</i>                             | (Optional) Resource Virtualization quota              |

|                                |   |
|--------------------------------|---|
| <i>committed</i>               | (Optional) Resource Virtualization committed  |
| <i>available</i>               | (Optional) Resource Virtualization available  |
| TABLE_list                     | (Optional) Virtual service list table         |
| <i>name</i>                    | (Optional) Virtual service name               |
| <i>status</i>                  | (Optional) Virtual service status             |
| <i>package_name</i>            | (Optional) Virtual service package name       |
| TABLE_detail                   | (Optional) Virtual service detail table       |
| <i>name</i>                    | (Optional) Virtual service name               |
| <i>package_name</i>            | (Optional) Virtual service package name       |
| <i>application_name</i>        | (Optional) Name of the application            |
| <i>application_version</i>     | (Optional) Version of the application         |
| <i>application_description</i> | (Optional) Description of the application     |
| <i>key_type</i>                | (Optional) Virtual service key type           |
| <i>signing_method</i>          | (Optional) Method used to sign the package    |
| <i>licensing_name</i>          | (Optional) Name of the license                |
| <i>licensing_version</i>       | (Optional) Version of the license             |
| <i>ova_path</i>                | (Optional) Virtual service OVA path           |
| <i>state</i>                   | (Optional) Virtual service state              |
| <i>disk_reservation</i>        | (Optional) Virtual service disk reservation   |
| <i>memory_reservation</i>      | (Optional) Virtual service memory reservation |
| <i>cpu_reservation</i>         | (Optional) Virtual service CPU reservation    |
| TABLE_attached_devices         | (Optional) Attached devices table             |
| <i>type</i>                    | (Optional) Type of the attached device        |
| <i>name</i>                    | (Optional) Name of the attached device        |
| <i>alias</i>                   | (Optional) Alias for the attached device      |
| TABLE_core                     | (Optional) Virtual service core table         |
| <i>name</i>                    | (Optional) Virtual service name               |
| <i>name_core</i>               | (Optional) Name of core                       |

**Command Mode**

- /exec

## show virtual-service storage pool list

```
show virtual-service storage pool list [ __readonly__ [ TABLE_storage <pool_name> <pool_type> <pool_path> ] ]
```

### Syntax Description

|                      |   |
|----------------------|---|
| show                 | Show running system information                         |
| virtual-service      | Display virtualization service storage pool information |
| storage              | Storage information about virtual service               |
| pool                 | Storage pool information about virtual service          |
| list                 | List storage pool for virtual service                   |
| <i>__readonly__</i>  | (Optional) Read Only                                    |
| <i>TABLE_storage</i> | (Optional) Virtual service storage pool list table      |
| <i>pool_name</i>     | (Optional) Virtual service storage pool name            |
| <i>pool_type</i>     | (Optional) Virtual service storage pool type            |
| <i>pool_path</i>     | (Optional) Virtual service storage pool path            |

### Command Mode

- /exec

# show virtual-service tech-support

show virtual-service tech-support

## Syntax Description

|                 |   |
|-----------------|---|
| show            | Show running system information                                 |
| virtual-service | Gather information for virtualization services trouble shooting |
| tech-support    | Gather information for trouble shooting                         |

## Command Mode

- /exec

## show virtual-service utilization name

```
show virtual-service utilization name <virt_serv_name> [ __readonly__ [ TABLE_cpu <request> <actual>
<state> ] [ TABLE_memory <allocation> <used> ] [ TABLE_storage <name> <alias> <capacity> <used>
<available> <usage> ] ]
```

### Syntax Description

|                       |  |
|-----------------------|--|
| show                  | Show running system information                        |
| virtual-service       | Display virtualization service utilization information |
| utilization           | Utilization information about virtual service          |
| name                  | Utilization of a virtual service                       |
| <i>virt_serv_name</i> | Name of a virtual service                              |
| <i>__readonly__</i>   | (Optional) Read Only                                   |
| TABLE_storage         | (Optional) Virtual service storage utilization         |
| <i>name</i>           | (Optional) storage device name                         |
| <i>alias</i>          | (Optional) storage device alias                        |
| <i>capacity</i>       | (Optional) Capacity 1k blocks                          |
| <i>used</i>           | (Optional) Used 1k blocks                              |
| <i>available</i>      | (Optional) Available 1k blocks                         |
| <i>usage</i>          | (Optional) Usage                                       |
| TABLE_memory          | (Optional) Virtual service memory utilization          |
| <i>allocation</i>     | (Optional) Memory allocation                           |
| <i>used</i>           | (Optional) Memory used                                 |
| TABLE_cpu             | (Optional) Virtual service cpu utilization             |
| <i>request</i>        | (Optional) Requested Application Utilization           |
| <i>actual</i>         | (Optional) Actual Application Utilization              |
| <i>state</i>          | (Optional) CPU state                                   |

### Command Mode

- /exec

## show virtual-service version

```
show virtual-service version { { installed } | { name <virt_serv_name> installed } } [ __readonly__
<virt_service_name> <application_name> <application_version> ]
```

### Syntax Description

|                            |  |
|----------------------------|--|
| show                       | Show running system information                    |
| virtual-service            | Display virtualization service version information |
| version                    | Version information about virtual service          |
| installed                  | Installed version                                  |
| name                       | Version of a virtual service                       |
| <i>virt_serv_name</i>      | Name of a virtual service                          |
| <i>__readonly__</i>        | (Optional) Read Only                               |
| <i>virt_service_name</i>   | (Optional) Virtual service name                    |
| <i>application_name</i>    | (Optional) Application name                        |
| <i>application_version</i> | (Optional) Application version                     |

### Command Mode

- /exec



# show vlan

```
show vlan [ controller ] [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbrief <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <vlanshowinfo-mtu-hdr> { TABLE_mtuintfo <vlanshowinfo-vlanid>
<vlanshowinfo-media-type> <vlanshowinfo-vlanmode> } [ <vlanshowrspan-hdr1> ] [
<vlanshowrspan-vlantype> ] [ <vlanshowrspan-hdr2> ] [ <vlanshowrspan-vlanbitmap> ] [ <pvlan-hdr> ] [
<pvlan-section> ] [ <pvlan-stby> ] <show-end> [ <true-end> ] ]
```

## Syntax Description

|                                 |   |
|---------------------------------|---|
| show                            | Show running system information                   |
| vlan                            | VLAN status                                       |
| controller                      | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED         |
| __readonly__                    | (Optional) Read Only                              |
| TABLE_vlanbrief                 | (Optional) VLAN brief table format                |
| TABLE_mtuintfo                  | (Optional) MTU information table format           |
| <i>vlanshowbr-hdr</i>           | (Optional) VLAN brief header                      |
| <i>vlanshowbr-vlanid</i>        | (Optional) VLAN brief VLAN ID                     |
| <i>vlanshowbr-vlanid-utf</i>    | (Optional) VLAN brief VLAN ID                     |
| <i>vlanshowbr-vlanname</i>      | (Optional) VLAN brief VLAN name                   |
| <i>vlanshowbr-vlanstate</i>     | (Optional) VLAN brief VLAN state                  |
| <i>vlanshowbr-shutstate</i>     | (Optional) VLAN brief shutdown state              |
| <i>vlanshowplist-ifidx</i>      | (Optional) Port list ifindex                      |
| <i>vlanshowinfo-mtu-hdr</i>     | (Optional) Vlan info mtu header                   |
| <i>vlanshowinfo-vlanid</i>      | (Optional) Vlan info VLAN ID                      |
| <i>vlanshowinfo-media-type</i>  | (Optional) Select media type                      |
| <i>vlanshowinfo-vlanmode</i>    | (Optional) VLAN brief VLAN mode                   |
| <i>vlanshowrspan-hdr1</i>       | (Optional) RSPAN VLAN header for one VLAN         |
| <i>vlanshowrspan-hdr2</i>       | (Optional) RSPAN VLAN header for multiple VLANs   |
| <i>vlanshowrspan-vlantype</i>   | (Optional) RSPAN VLAN one VLAN rspan or non-rspan |
| <i>vlanshowrspan-vlanbitmap</i> | (Optional) RSPAN VLAN multiple VLANs              |
| <i>show-end</i>                 | (Optional) Show vlan end marker                   |

|                      |  |
|----------------------|--|
| <i>true-end</i>      | (Optional) Show vlan end marker            |
| <i>pvlan-hdr</i>     | (Optional) private vlan section            |
| <i>pvlan-section</i> | (Optional) private vlan section            |
| <i>pvlan-stby</i>    | (Optional) private vlan section on standby |

**Command Mode**

- /exec

## show vlan access-list

```
show vlan access-list <name> [ <inp_seqno> ] [ __readonly__ TABLE_vacl <vacl_name> [ <vacl_seqno> ]
[ TABLE_list <ip_ipv6_mac> <acl_name> [ TABLE_seqno <seqno> { <permitdeny> [ <proto_str> | <proto>
| <ip> | <ipv6> ] } <src_any> | <src_ip_prefix> | <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> |
<src_ipv6_addr> <src_ipv6_mask> | <mac_src> <mac_src_wild> | <src_addrgrp> } [ <src_port_op> [
<src_port1_str> ] { <src_port1_num> } [ <src_port2_str> | <src_port2_num> ] | <src_portgrp> ] { <dest_any>
| <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> | <dest_ipv6_prefix> | <dest_ipv6_addr>
<dest_ipv6_mask> | <mac_dest> <mac_dest_wild> | <dest_addrgrp> } [ <dest_port_op> [ <dest_port1_str>
] { <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] | <dest_portgrp> ] [ { <icmp_type> [
<icmp_code> ] | <icmp_str> } | { <icmpv6_type> [ <icmpv6_code> ] | <icmpv6_str> } ] [ <igmp_type> |
<igmp_type_str> ] [ [ <precedence> | <precedence_str> ] [ <tos> | <tos_str> ] ] [ <dscp> [ <dscp_mask> ] |
<dscp_str> ] ] [ <ttl> ] ] [ <log> ] [ <telemetry_queue> ] [ <telemetry_path> ] [ <udfs> ] [ <capture_session>
] [ <fragments> ] [ <plen_op> <plen1> [ <plen2> ] ] [ <urg> ] [ <ack> ] [ <psh> ] [ <rst> ] [ <syn> ] [ <fin>
] [ <established> ] [ <http-method> | <http_opt_str> ] [ <tcp-option-length> ] [ <tcp-flags-mask> ] [
<flow_label> ] [ <timerange> ] [ <eth_proto> | <eth_proto_str> ] [ <vlan> ] [ <cos> ] [ <match_count> ] [ [
TABLE_match <module> <module_match_count> ] ] [ <nve_vni> ] [ <nve_vni> ] [ <label1> [ <label2>
<label3> <label4> ] ] <remark> } ] [ <action> <actionid> ] ] ]
```

### Syntax Description

|                     |                                 |
|---------------------|---------------------------------|
| show                | Show running system information |
| vlan                | VLAN status                     |
| access-list         | Vlan access list                |
| <i>name</i>         | List name                       |
| <i>inp_seqno</i>    | (Optional) Sequence number      |
| <i>vacl_name</i>    | (Optional) List name            |
| <i>__readonly__</i> | (Optional)                      |
| <i>vacl_seqno</i>   | (Optional) Sequence number      |
| TABLE_vacl          | (Optional)                      |
| TABLE_list          | (Optional)                      |
| <i>ip_ipv6_mac</i>  | (Optional) IP/iPV6/MAC          |
| <i>acl_name</i>     | (Optional) Access list name     |
| <i>seqno</i>        | (Optional) Sequence number      |
| <i>permitdeny</i>   | (Optional) Permit/deny          |
| <i>proto</i>        | (Optional) A protocol number    |
| TABLE_seqno         | (Optional)                      |
| <i>proto_str</i>    | (Optional) Protocol name        |

|                       |                                      |
|-----------------------|--------------------------------------|
| <i>ip</i>             | (Optional) IP                        |
| <i>ipv6</i>           | (Optional) IPV6                      |
| <i>src_any</i>        | (Optional) SRCAny                    |
| <i>dest_any</i>       | (Optional) DESTAny                   |
| <i>src_ip_prefix</i>  | (Optional) Source IP prefix          |
| <i>src_ip_addr</i>    | (Optional) Source IP address         |
| <i>src_ip_mask</i>    | (Optional) Source IP mask            |
| <i>mac_src</i>        | (Optional) Source MAC address        |
| <i>mac_src_wild</i>   | (Optional) Source MAC mask           |
| <i>dest_ip_prefix</i> | (Optional) Destination IP prefix     |
| <i>dest_ip_addr</i>   | (Optional) Destination IP address    |
| <i>dest_ip_mask</i>   | (Optional) Destination IP mask       |
| <i>mac_dest</i>       | (Optional) Destination MAC address   |
| <i>mac_dest_wild</i>  | (Optional) Destination MAC mask      |
| <i>src_port_op</i>    | (Optional) Source Port operator      |
| <i>dest_port_op</i>   | (Optional) Destination Port operator |
| <i>src_port1_str</i>  | (Optional) Source port name          |
| <i>src_port1_num</i>  | (Optional) Source port number        |
| <i>src_port2_str</i>  | (Optional) Source port name          |
| <i>src_port2_num</i>  | (Optional) Source port number        |
| <i>dest_port1_str</i> | (Optional) Destination port name     |
| <i>dest_port1_num</i> | (Optional) Destination port number   |
| <i>dest_port2_str</i> | (Optional) Destination port name     |
| <i>dest_port2_num</i> | (Optional) Destination port number   |
| <i>icmp_type</i>      | (Optional) ICMP type                 |
| <i>icmp_code</i>      | (Optional) ICMP code                 |
| <i>icmp_str</i>       | (Optional) ICMP message              |
| <i>icmpv6_type</i>    | (Optional) ICMP type                 |
| <i>icmpv6_code</i>    | (Optional) ICMP code                 |

|                          |                               |
|--------------------------|-------------------------------|
| <i>icmpv6_str</i>        | (Optional) ICMP message       |
| <i>igmp_type</i>         | (Optional) IGMP type          |
| <i>igmp_type_str</i>     | (Optional) IGMP type String   |
| <i>precedence</i>        | (Optional) precedence         |
| <i>precedence_str</i>    | (Optional) precedence string  |
| <i>tos</i>               | (Optional) tos                |
| <i>tos_str</i>           | (Optional) tos string         |
| <i>dscp</i>              | (Optional) dscp               |
| <i>dscp_mask</i>         | (Optional) dscp mask          |
| <i>dscp_str</i>          | (Optional) dscp string        |
| <i>udfs</i>              | (Optional) udfs string        |
| <i>ttl</i>               | (Optional) ttl                |
| <i>capture_session</i>   | (Optional) capture session    |
| <i>log</i>               | (Optional) Log                |
| <i>telemetry_queue</i>   | (Optional) telemetry_queue    |
| <i>telemetry_path</i>    | (Optional) telemetry_path     |
| <i>fragments</i>         | (Optional) Fragments          |
| <i>urg</i>               | (Optional) URG                |
| <i>ack</i>               | (Optional) ACK                |
| <i>psh</i>               | (Optional) PSH                |
| <i>rst</i>               | (Optional) RST                |
| <i>syn</i>               | (Optional) SYN                |
| <i>fin</i>               | (Optional) FIN                |
| <i>established</i>       | (Optional) ESTABLISHED        |
| <i>http-method</i>       | (Optional) http-method        |
| <i>http_opt_str</i>      | (Optional) http_option string |
| <i>tcp-option-length</i> | (Optional) TCP Option size    |
| <i>tcp-flags-mask</i>    | (Optional) TCP Flags mask     |
| <i>flow_label</i>        | (Optional) IPv6 flow label    |

|                           |   |
|---------------------------|---|
| <i>timerange</i>          | (Optional) Time-range   |
| <i>eth_proto</i>          | (Optional) MAC protocol number  |
| <i>eth_proto_str</i>      | (Optional) MAC protocol name  |
| <i>vlan</i>               | (Optional) VLAN number  |
| <i>cos</i>                | (Optional) CoS value  |
| <i>match_count</i>        | (Optional) Number of packets matching the ACL   |
| TABLE_match               | (Optional)  |
| <i>module</i>             | (Optional) Module name  |
| <i>module_match_count</i> | (Optional) Number of packets matching the ACL   |
| <i>nve_vni</i>            | (Optional) nve vni  |
| <i>remark</i>             | (Optional) Remark String  |
| <i>src_addrgrp</i>        | (Optional) Source address group   |
| <i>dest_addrgrp</i>       | (Optional) Destination address group  |
| <i>src_portgrp</i>        | (Optional) Source port group  |
| <i>dest_portgrp</i>       | (Optional) Destination port group   |
| <i>plen_op</i>            | (Optional) Source Port operator   |
| <i>plen1</i>              | (Optional) Packet length minimum  |
| <i>plen2</i>              | (Optional) packet length maximum  |
| <i>label1</i>             | (Optional) mpls label one   |
| <i>label2</i>             | (Optional) mpls label two   |
| <i>label3</i>             | (Optional) mpls label three   |
| <i>label4</i>             | (Optional) mpls label four  |
| <i>action</i>             | (Optional) Action   |
| <i>actionid</i>           | (Optional) redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63><br>set-erspan-gre-proto: <1-65535> |

**Command Mode**

- /exec

# show vlan access-map

```
show vlan access-map [ <name> ] [ __readonly__ [ TABLE_vacl <vacl_name> [ TABLE_seqno [ <seqno>
] [ <ip_ipv6_mac> { <match_name> } + [ <action_drop> ] [ <action_log> ] [ <action_telemetry_queue> ] [
<action_telemetry_path> ] [ <action_fwd> ] [ <action_capture> ] [ <action_redirect> <intf> ] ] [ <statistics>
] ] ] ]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information               |
| vlan                          | VLAN status                                   |
| access-map                    | List VLAN access maps                         |
| <i>name</i>                   | (Optional) List name                          |
| <i>vacl_name</i>              | (Optional) List name                          |
| <i>__readonly__</i>           | (Optional)                                    |
| <i>seqno</i>                  | (Optional) Sequence number                    |
| TABLE_vacl                    | (Optional)                                    |
| TABLE_seqno                   | (Optional)                                    |
| <i>ip_ipv6_mac</i>            | (Optional) IP/iPV6/MAC                        |
| <i>match_name</i>             | (Optional) Access list name                   |
| <i>action_drop</i>            | (Optional) DROP                               |
| <i>action_log</i>             | (Optional) LOG                                |
| <i>action_telemetry_queue</i> | (Optional) telemetry_queue                    |
| <i>action_telemetry_path</i>  | (Optional) telemetry_path                     |
| <i>action_fwd</i>             | (Optional) FWD                                |
| <i>action_capture</i>         | (Optional) CAPTURE                            |
| <i>action_redirect</i>        | (Optional) REDIRECT                           |
| <i>intf</i>                   | (Optional) Interface traffic is redirected to |
| <i>statistics</i>             | (Optional) STATISTICS                         |

## Command Mode

- /exec

# show vlan all-ports

```
show vlan all-ports [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefallports <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <show-end> [ <true-end> ] ]
```

## Syntax Description

|                              |                                      |
|------------------------------|--------------------------------------|
| show                         | Show running system information      |
| vlan                         | VLAN status                          |
| all-ports                    | Show all ports on VLAN               |
| __readonly__                 | (Optional) Read Only                 |
| TABLE_vlanbriefallports      | (Optional) VLAN brief table format   |
| <i>vlanshowbr-hdr</i>        | (Optional) VLAN brief header         |
| <i>vlanshowbr-vlanid</i>     | (Optional) VLAN brief VLAN ID        |
| <i>vlanshowbr-vlanid-utf</i> | (Optional) VLAN brief VLAN ID        |
| <i>vlanshowbr-vlanname</i>   | (Optional) VLAN brief VLAN name      |
| <i>vlanshowbr-vlanstate</i>  | (Optional) VLAN brief VLAN state     |
| <i>vlanshowbr-shutstate</i>  | (Optional) VLAN brief shutdown state |
| <i>vlanshowplist-ifidx</i>   | (Optional) Port list ifindex         |
| <i>show-end</i>              | (Optional) Show vlan end marker      |
| <i>true-end</i>              | (Optional) Show vlan end marker      |

## Command Mode

- /exec



## show vlan counters

```
show vlan counters [ __readonly__ { TABLE_vlancounters <vlanshowbr-vlanid> [ <l2_ing_ucast_b> ] [
<l2_ing_ucast_p> ] [ <l2_ing_mcast_b> ] [ <l2_ing_mcast_p> ] [ <l2_ing_bcast_b> ] [ <l2_ing_bcast_p> ]
[ <l2_egr_ucast_b> ] [ <l2_egr_ucast_p> ] [ <l3_ucast_rcv_b> ] [ <l3_ucast_rcv_p> ] [ <total_rcv_b> ] [
<total_rcv_p> ] [ <total_sent_b> ] [ <total_sent_p> ] } ]
```

### Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information         |
| vlan               | Vlan commands                           |
| counters           | display counters                        |
| __readonly__       | (Optional) Read Only                    |
| TABLE_vlancounters | (Optional) vlan counters table format   |
| vlanshowbr-vlanid  | (Optional) VLAN brief VLAN ID           |
| l2_ing_ucast_b     | (Optional) L2 Ingress unicast octets    |
| l2_ing_ucast_p     | (Optional) L2 Ingress unicast packets   |
| l2_ing_mcast_b     | (Optional) L2 Ingress multicast octets  |
| l2_ing_mcast_p     | (Optional) L2 Ingress multicast packets |
| l2_ing_bcast_b     | (Optional) L2 Ingress broadcast octets  |
| l2_ing_bcast_p     | (Optional) L2 Ingress broadcast packets |
| l2_egr_ucast_b     | (Optional) L2 Egress unicast octets     |
| l2_egr_ucast_p     | (Optional) L2 Egress unicast packets    |
| l3_ucast_rcv_b     | (Optional) L3 unicast octets in         |
| l3_ucast_rcv_p     | (Optional) L3 unicast packets in        |
| total_rcv_b        | (Optional) Total octets in              |
| total_rcv_p        | (Optional) Total packets in             |
| total_sent_b       | (Optional) Total octets out             |
| total_sent_p       | (Optional) Total packets out            |

### Command Mode

- /exec

# show vlan dot1Q tag native

show vlan dot1Q tag native [ *\_\_readonly\_\_* <*tag\_native\_mode*> ]

## Syntax Description

|                        |                                     |
|------------------------|-------------------------------------|
| show                   | Show running system information     |
| vlan                   | VTP VLAN status                     |
| dot1Q                  | Display dot1q parameters            |
| tag                    | Display tag parameters              |
| native                 | Display native vlan tagging         |
| <i>__readonly__</i>    | (Optional) Read Only                |
| <i>tag_native_mode</i> | (Optional) Native vlan tagging mode |

## Command Mode

- /exec

# show vlan fcoe

```
show vlan fcoe [ <vlan-id> ] [ __readonly__ { TABLE_assoc <orig-id> <tran-id> <assoc-state> } ]
```

## Syntax Description

|                    |   |
|--------------------|---|
| show               | Show running system information                                       |
| fcoe               | FCOE Congiguration  |
| vlan               | Original VLAN Status  |
| __readonly__       | (Optional) Read Only  |
| TABLE_assoc        | (Optional) Association Table Format                                   |
| <i>vlan-id</i>     | (Optional) VLAN ID <1-4094>   |
| <i>orig-id</i>     | (Optional) Enter original VLAN-ID being associated with translated ID |
| <i>tran-id</i>     | (Optional) Enter VSAN-ID being associated with VLAN-ID                |
| <i>assoc-state</i> | (Optional) Show Association Status                                    |

## Command Mode

- /exec

# show vlan filter

```
show vlan filter [ access-map <name> | vlan <vlan> ] [ __readonly__ TABLE_vlan_filter <vacl_name>
<configured_vlans> ]
```

## Syntax Description

|                         |  |
|-------------------------|--|
| show                    | Show running system information                          |
| vlan                    | VLAN status  |
| filter                  | Information about VLAN filters                           |
| access-map              | (Optional) Show the VLANs where an access-map is applied |
| <i>name</i>             | (Optional) List name                                     |
| vlan                    | (Optional) Show the access-map applied to a VLAN         |
| <i>vlan</i>             | (Optional) VLAN number                                   |
| <i>__readonly__</i>     | (Optional)   |
| TABLE_vlan_filter       | (Optional)   |
| <i>vacl_name</i>        | (Optional) List name                                     |
| <i>configured_vlans</i> | (Optional) VLAN numbers                                  |

## Command Mode

- /exec

## show vlan id

```
show vlan id <vlan-id> [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefid <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <vlanshowinfo-mtu-hdr> { TABLE_mtuinfoid <vlanshowinfo-vlanid>
<vlanshowinfo-media-type> <vlanshowinfo-vlanmode> } [ <vlanshow-vlanerrbitmap> ] [
<vlanshowrspan-hdr1> ] [ <vlanshowrspan-vlantype> ] [ <vlanshowrspan-hdr2> ] [
<vlanshowrspan-vlanbitmap> ] [ <pvlan-hdr> ] [ <pvlan-id-section> ] [ <pvlan-stby> ] [ <is-vtp-manageable>
] [ <is-internal> ] [ <is-reserved> ] [ <is-rspan> ] [ <is-dynamic-gvrp> ] <show-end> [ <true-end> ] ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                   |
| vlan                           | VLAN status                                       |
| id                             | VLAN status by VLAN id                            |
| <i>vlan-id</i>                 | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19   |
| <i>__readonly__</i>            | (Optional) Read Only                              |
| TABLE_vlanbriefid              | (Optional) VLAN brief table format                |
| TABLE_mtuinfoid                | (Optional) MTU information table format           |
| <i>vlanshowbr-hdr</i>          | (Optional) VLAN brief header                      |
| <i>vlanshowbr-vlanid</i>       | (Optional) VLAN brief VLAN ID                     |
| <i>vlanshowbr-vlanid-utf</i>   | (Optional) VLAN brief VLAN ID                     |
| <i>vlanshowbr-vlanname</i>     | (Optional) VLAN brief VLAN name                   |
| <i>vlanshowbr-vlanstate</i>    | (Optional) VLAN brief VLAN state                  |
| <i>vlanshowbr-shutstate</i>    | (Optional) VLAN brief shutdown state              |
| <i>vlanshowplist-ifidx</i>     | (Optional) Port list ifindex                      |
| <i>vlanshowinfo-mtu-hdr</i>    | (Optional) Vlan info mtu header                   |
| <i>vlanshowinfo-vlanid</i>     | (Optional) Vlan info VLAN ID                      |
| <i>vlanshowinfo-media-type</i> | (Optional) Select media type                      |
| <i>vlanshowinfo-vlanmode</i>   | (Optional) VLAN brief VLAN mode                   |
| <i>vlanshow-vlanerrbitmap</i>  | (Optional) VLAN error bitmap                      |
| <i>vlanshowrspan-hdr1</i>      | (Optional) RSPAN VLAN header for one VLAN         |
| <i>vlanshowrspan-hdr2</i>      | (Optional) RSPAN VLAN header for multiple VLANs   |
| <i>vlanshowrspan-vlantype</i>  | (Optional) RSPAN VLAN one VLAN rspan or non-rspan |

|                                 |  |
|---------------------------------|--|
| <i>vlanshowrspan-vlanbitmap</i> | (Optional) RSPAN VLAN multiple VLANs       |
| <i>show-end</i>                 | (Optional) Show vlan end marker            |
| <i>true-end</i>                 | (Optional) Show vlan end marker            |
| <i>pvlan-hdr</i>                | (Optional) private vlan section            |
| <i>pvlan-id-section</i>         | (Optional) private id vlan section         |
| <i>pvlan-stby</i>               | (Optional) private vlan section on standby |
| <i>is-vtp-manageable</i>        | (Optional) VTP Manageable VLAN flag        |
| <i>is-internal</i>              | (Optional) Internal VLAN flag              |
| <i>is-reserved</i>              | (Optional) Reserved VLAN flag              |
| <i>is-rspan</i>                 | (Optional) RSPAN VLAN flag                 |
| <i>is-dynamic-gvrp</i>          | (Optional) Dynamic GVRP VLAN flag          |

**Command Mode**

- /exec

## show vlan id counters

```
show vlan id <vlan-id> counters [ __readonly__ { TABLE_vlancounters <vlanshowbr-vlanid> [
<l2_ing_ucast_b> ] [ <l2_ing_ucast_p> ] [ <l2_ing_mcast_b> ] [ <l2_ing_mcast_p> ] [ <l2_ing_bcast_b> ]
[ <l2_ing_bcast_p> ] [ <l2_egr_ucast_b> ] [ <l2_egr_ucast_p> ] [ <l3_ucast_rcv_b> ] [ <l3_ucast_rcv_p> ]
[ <total_rcv_b> ] [ <total_rcv_p> ] [ <total_sent_b> ] [ <total_sent_p> ] } ]
```

### Syntax Description

|                          |   |
|--------------------------|---|
| show                     | Show running system information                 |
| vlan                     | Vlan commands                                   |
| id                       | VLAN status by VLAN id                          |
| counters                 | display counters                                |
| <i>vlan-id</i>           | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| <u>__readonly__</u>      | (Optional) Read Only                            |
| TABLE_vlancounters       | (Optional) vlan counters table format           |
| <i>vlanshowbr-vlanid</i> | (Optional) VLAN brief VLAN ID                   |
| <i>l2_ing_ucast_b</i>    | (Optional) L2 Ingress unicast octets            |
| <i>l2_ing_ucast_p</i>    | (Optional) L2 Ingress unicast packets           |
| <i>l2_ing_mcast_b</i>    | (Optional) L2 Ingress multicast octets          |
| <i>l2_ing_mcast_p</i>    | (Optional) L2 Ingress multicast packets         |
| <i>l2_ing_bcast_b</i>    | (Optional) L2 Ingress broadcast octets          |
| <i>l2_ing_bcast_p</i>    | (Optional) L2 Ingress broadcast packets         |
| <i>l2_egr_ucast_b</i>    | (Optional) L2 Egress unicast octets             |
| <i>l2_egr_ucast_p</i>    | (Optional) L2 Egress unicast packets            |
| <i>l3_ucast_rcv_b</i>    | (Optional) L3 unicast octets in                 |
| <i>l3_ucast_rcv_p</i>    | (Optional) L3 unicast packets in                |
| <i>total_rcv_b</i>       | (Optional) Total octets in                      |
| <i>total_rcv_p</i>       | (Optional) Total packets in                     |
| <i>total_sent_b</i>      | (Optional) Total octets out                     |
| <i>total_sent_p</i>      | (Optional) Total packets out                    |

### Command Mode

- /exec



# show vlan id vn-segment

```
show vlan id <vlan-id> vn-segment [ __readonly__ <vlanshowinfo-segid-hdr> { TABLE_seginfoid
<vlanshowinfo-seg-vlanid> <vlanshowinfo-segment-id> } <show-end> [ <true-end> ] ]
```

## Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                 |
| vlan                           | VLAN status                                     |
| id                             | VLAN status by VLAN id                          |
| vn-segment                     | Show vn-segment mapping                         |
| <i>vlan-id</i>                 | VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| <i>__readonly__</i>            | (Optional) Read Only                            |
| <i>TABLE_seginfoid</i>         | (Optional) Segment id information table format  |
| <i>vlanshowinfo-segid-hdr</i>  | (Optional) Vlan info segment id header          |
| <i>vlanshowinfo-seg-vlanid</i> | (Optional) Vlan info VLAN ID                    |
| <i>vlanshowinfo-segment-id</i> | (Optional) Vlan info SEGMENT ID                 |
| <i>show-end</i>                | (Optional) Show vlan end marker                 |
| <i>true-end</i>                | (Optional) Show vlan end marker                 |

## Command Mode

- /exec

## show vlan name

```
show vlan name <vname> [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefname <vlanshowbr-vlanid>
<vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate> <vlanshowbr-shutstate> [
<vlanshowplist-ifidx> + ] } <vlanshowinfo-mtu-hdr> { TABLE_mtuinfofname <vlanshowinfo-vlanid>
<vlanshowinfo-media-type> <vlanshowinfo-vlanmode> } [ <vlanshowrspan-hdr1> ] [
<vlanshowrspan-vlantype> ] [ <vlanshowrspan-hdr2> ] [ <vlanshowrspan-vlanbitmap> ] <show-end> [
<true-end> ] ]
```

### Syntax Description

|                          |  |
|--------------------------|--|
| show                     | Show running system information                          |
| vlan                     | VLAN status  |
| name                     | VLAN status by VLAN name                                 |
| vname                    | A vlan name with size 32 (128 if long vlan name enabled) |
| __readonly__             | (Optional) Read Only                                     |
| TABLE_vlanbriefname      | (Optional) VLAN brief table format                       |
| TABLE_mtuinfofname       | (Optional) MTU information table format                  |
| vlanshowbr-hdr           | (Optional) VLAN brief header                             |
| vlanshowbr-vlanid        | (Optional) VLAN brief VLAN ID                            |
| vlanshowbr-vlanid-utf    | (Optional) VLAN brief VLAN ID                            |
| vlanshowbr-vlanname      | (Optional) VLAN brief VLAN name                          |
| vlanshowbr-vlanstate     | (Optional) VLAN brief VLAN state                         |
| vlanshowbr-shutstate     | (Optional) VLAN brief shutdown state                     |
| vlanshowplist-ifidx      | (Optional) Port list ifindex                             |
| vlanshowinfo-mtu-hdr     | (Optional) Vlan info mtu header                          |
| vlanshowinfo-vlanid      | (Optional) Vlan info VLAN ID                             |
| vlanshowinfo-media-type  | (Optional) Select media type                             |
| vlanshowinfo-vlanmode    | (Optional) VLAN brief VLAN mode                          |
| vlanshowrspan-hdr1       | (Optional) RSPAN VLAN header for one VLAN                |
| vlanshowrspan-hdr2       | (Optional) RSPAN VLAN header for multiple VLANs          |
| vlanshowrspan-vlantype   | (Optional) RSPAN VLAN one VLAN rspan or non-rspan        |
| vlanshowrspan-vlanbitmap | (Optional) RSPAN VLAN multiple VLANs                     |

|                 |                                 |
|-----------------|---------------------------------|
| <i>show-end</i> | (Optional) Show vlan end marker |
| <i>true-end</i> | (Optional) Show vlan end marker |

**Command Mode**

- /exec

## show vlan private-vlan

```
show vlan [ id <vlan-id> ] private-vlan [ __readonly__ [ { TABLE_pvlan_primary <vlan-key> [ <primary>
] [ <secondary> ] <pvlan-type> [ <ports> + ] } ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                            |
| vlan                | VLAN status  |
| id                  | (Optional) VLAN status by VLAN id                          |
| <i>vlan-id</i>      | (Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| private-vlan        | Private VLAN information                                   |
| <i>__readonly__</i> | (Optional) Read Only                                       |
| TABLE_pvlan_primary | (Optional) Pvlan primary vlan table                        |
| <i>vlan-key</i>     | (Optional) Vlan key  |
| <i>primary</i>      | (Optional) Primary VLAN                                    |
| <i>secondary</i>    | (Optional) Secondary VLAN                                  |
| <i>pvlan-type</i>   | (Optional) PVLAN Type                                      |
| <i>ports</i>        | (Optional) Port list                                       |

### Command Mode

- /exec

## show vlan private-vlan type

```
show vlan [ id <vlan-id> ] private-vlan type [ __readonly__ [ { TABLE_pvlantype <vlan-num> <pvlan-type> } ] ]
```

### Syntax Description

|                     |  |
|---------------------|--|
| show                | Show running system information                            |
| vlan                | VLAN status  |
| id                  | (Optional) VLAN status by VLAN id                          |
| <i>vlan-id</i>      | (Optional) VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19 |
| private-vlan        | Private VLAN information                                   |
| type                | Private VLAN type information                              |
| <i>__readonly__</i> | (Optional) Read Only                                       |
| TABLE_pvlantype     | (Optional) Pvlan type table                                |
| <i>vlan-num</i>     | (Optional) vlan  |
| <i>pvlan-type</i>   | (Optional) PVLAN Type                                      |

### Command Mode

- /exec

## show vlan xbrief

```
show vlan xbrief [ controller | cli ] [ __readonly__ <vlanshowbr-hdr> { TABLE_vlanbriefxbrief
<vlanshowbr-vlanid> <vlanshowbr-vlanid-utf> <vlanshowbr-vlanname> <vlanshowbr-vlanstate>
<vlanshowbr-shutstate> [ <vlanshowplist-ifidx> + ] } <show-end> [ <true-end> ] ]
```

### Syntax Description

|                              |   |
|------------------------------|---|
| show                         | Show running system information           |
| vlan                         | VLAN status                               |
| xbrief                       | All VLAN status in brief                  |
| controller                   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| cli                          | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__                 | (Optional) Read Only                      |
| TABLE_vlanbriefxbrief        | (Optional) VLAN brief table format        |
| <i>vlanshowbr-hdr</i>        | (Optional) VLAN brief header              |
| <i>vlanshowbr-vlanid</i>     | (Optional) VLAN brief VLAN ID             |
| <i>vlanshowbr-vlanid-utf</i> | (Optional) VLAN brief VLAN ID             |
| <i>vlanshowbr-vlanname</i>   | (Optional) VLAN brief VLAN name           |
| <i>vlanshowbr-vlanstate</i>  | (Optional) VLAN brief VLAN state          |
| <i>vlanshowbr-shutstate</i>  | (Optional) VLAN brief shutdown state      |
| <i>vlanshowplist-ifidx</i>   | (Optional) Port list ifindex              |
| <i>show-end</i>              | (Optional) Show vlan end marker           |
| <i>true-end</i>              | (Optional) Show vlan end marker           |

### Command Mode

- /exec

# show vlan xsummary

```
show vlan xsummary [ __readonly__ <vlansum-all-vlan> <vlansum-vtp-vlan> <vlansum-ext-vlan>
<vlansum-max-supported-vlan> <vlansum-carved-vlan> <show-end> [ <true-end> ] ]
```

## Syntax Description

|                                   |   |
|-----------------------------------|---|
| show                              | Show running system information                         |
| vlan                              | VLAN status   |
| xsummary                          | VLAN summary information                                |
| <i>__readonly__</i>               | (Optional) Read Only                                    |
| <i>vlansum-all-vlan</i>           | (Optional) Show vlan summary Total                      |
| <i>vlansum-vtp-vlan</i>           | (Optional) Show vlan summary Number of normal vlans     |
| <i>vlansum-ext-vlan</i>           | (Optional) Show vlan summary Number of extended vlans   |
| <i>vlansum-max-supported-vlan</i> | (Optional) Show vlan summary Max supported vlans        |
| <i>vlansum-carved-vlan</i>        | (Optional) Show vlan summary Number of carved sdn vlans |
| <i>show-end</i>                   | (Optional) Show vlan end marker                         |
| <i>true-end</i>                   | (Optional) Show vlan end marker                         |

## Command Mode

- /exec

## show vmtracker

```
show vmtracker [ connection <conn_name> ] { { info { { [ interface <intf_id> ] { summary | detail | host |
vm | port-group } } | { vxlan-segment | vxlan-vms } } } | event-history } [ __readonly__ [ TABLE_info
<intf_name> <host_or_ip> <vmnic> <vm_name> <vm_state> <port_group> <pg_type> <vlan_range>
<virt_wire_name> <multicast_ip> <vdn_id> <vtep_ip> <event_time> <event_msg> ] [ TABLE_evt <event_id>
<event_time> <event_msg> ] ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| <code>__readonly__</code>   | (Optional)                                       |
| <code>TABLE_info</code>     | (Optional)                                       |
| <code>intf_name</code>      | (Optional)                                       |
| <code>host_or_ip</code>     | (Optional)                                       |
| <code>vmnic</code>          | (Optional)                                       |
| <code>vm_name</code>        | (Optional)                                       |
| <code>vm_state</code>       | (Optional)                                       |
| <code>port_group</code>     | (Optional)                                       |
| <code>pg_type</code>        | (Optional)                                       |
| <code>vlan_range</code>     | (Optional)                                       |
| <code>virt_wire_name</code> | (Optional)                                       |
| <code>multicast_ip</code>   | (Optional)                                       |
| <code>vdn_id</code>         | (Optional)                                       |
| <code>vtep_ip</code>        | (Optional)                                       |
| <code>event_time</code>     | (Optional)                                       |
| <code>event_msg</code>      | (Optional)                                       |
| <code>TABLE_evt</code>      | (Optional)                                       |
| <code>event_id</code>       | (Optional)                                       |
| <code>event_time</code>     | (Optional)                                       |
| <code>event_msg</code>      | (Optional)                                       |
| <code>show</code>           | Show running system information                  |
| <code>vmtracker</code>      | Show vmtracker info                              |
| <code>connection</code>     | (Optional) Show vmtracker configured connections |



|                  |   |
|------------------|---|
| <i>conn_name</i> | (Optional) Show vmtracker Connection name             |
| info             | Display vmtracker information                         |
| interface        | (Optional) Display vmtracker interface information    |
| <i>intf_id</i>   | (Optional) Interface name to display                  |
| summary          | Display a summary of vmtracker information            |
| detail           | Display vmtracker information details                 |
| host             | Display vmtracker host information                    |
| vm               | Display vmtracker related Virtual Machine information |
| port-group       | Display vmtracker related port-group information      |
| vxlan-segment    | Print all segment info                                |
| vxlan-vm         | Print all vm info                                     |
| event-history    | Display vmtracker related event-history               |

**Command Mode**

- /exec

# show vmtracker certificate

show vmtracker certificate [ \_\_readonly\_\_ TABLE\_cert <certificate> ]

## Syntax Description

|                    |   |
|--------------------|---|
| __readonly__       | (Optional)                                      |
| TABLE_cert         | (Optional) The entire certificate, line by line |
| <i>certificate</i> | (Optional) A line of the certificate in xml     |
| show               | Show running system information                 |
| vmtracker          | VMTRACKER commands                              |
| certificate        | Show the default certificate used               |

## Command Mode

- /exec

## show vmtracker fabric auto-config

```
show vmtracker fabric auto-config [ interface <intf_id> ] [ vlan <vlan_id> ] [ status { success | pending |
failure | skipped } ] [ __readonly__ { <oper_status> } ] [ TABLE_autoconfig <interface_name>
<port_group_name> <vlan_range> <config_status> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| <i>__readonly__</i>    | (Optional)  |
| <i>oper_status</i>     | (Optional) fabric auto-config enabled or disabled               |
| TABLE_autoconfig       | (Optional)  |
| <i>interface_name</i>  | (Optional) interface to the UCS                                 |
| <i>port_group_name</i> | (Optional) port-channel of this interface                       |
| <i>vlan_range</i>      | (Optional) vlans learned  |
| <i>config_status</i>   | (Optional) status of auto-config over this interface            |
| show                   | Show running system information                                 |
| vmtracker              | VMTRACKER commands  |
| fabric                 | VM Tracker Fabric paramters                                     |
| auto-config            | VM Tracker Fabric AutoConfiguration                             |
| interface              | (Optional) Display vmtracker interface information              |
| <i>intf_id</i>         | (Optional) Interface name to display                            |
| vlan                   | (Optional) vlan to display                                      |
| <i>vlan_id</i>         | (Optional) VLAN ID 1-4094 or range(s) like: 1-5, 10 or 2-5,7-19 |
| status                 | (Optional) Auto-config status                                   |
| success                | (Optional) Success  |
| pending                | (Optional) Pending  |
| failure                | (Optional) Failure  |
| skipped                | (Optional) Skipped  |

### Command Mode

- /exec

# show vmtracker status

```
show vmtracker [ connection <conn_name> ] status [ __readonly__ { TABLE_connection <name> <host_or_ip>
<conn_status> } ]
```

## Syntax Description

|                     |  |
|---------------------|--|
| <i>__readonly__</i> | (Optional)                                       |
| TABLE_connection    | (Optional)                                       |
| <i>name</i>         | (Optional)                                       |
| <i>host_or_ip</i>   | (Optional)                                       |
| <i>conn_status</i>  | (Optional)                                       |
| show                | Show running system information                  |
| vmtracker           | Show vmtracker info                              |
| connection          | (Optional) Show vmtracker configured connections |
| <i>conn_name</i>    | (Optional) Show vmtracker Connection name        |
| status              | Show vmtracker connection status                 |

## Command Mode

- /exec

## show vpc

```
show vpc [ brief ] [ __readonly__ <vpc-domain-id> [ <vpc-l2mp-switch-id> ] <vpc-peer-status>
<vpc-peer-status-reason> <vpc-peer-keepalive-status> [ <vpc-peer-l2mp-status> ] <vpc-peer-consistency> {
[ <vpc-peer-consistency-reason> ] [ <vpc-per-vlan-peer-consistency> ] <vpc-peer-consistency-status> }
<vpc-type-2-consistency> { [ <vpc-type-2-consistency-reason> ] <vpc-type-2-consistency-status> } <vpc-role>
<num-of-vpcs> [ <track-obj> ] [ <peer-gateway> ] [ <peer-gateway-excluded-vlans> ]
<dual-active-excluded-vlans> <vpc-graceful-consistency-check-status> [ <vpc-auto-recovery-status> ] [
<vpc-delay-restore-status> ] [ <vpc-delay-restore-svi-status> ] [ <vpc-delay-peer-link-status> ]
<operational-l3-peer> [ <vpc-scale-high-status> ] [ <fp-enhanced-load-balancing> ] [
<vpc-per-vlan-peer-consistency> ] [ <virtual-peerlink> ] [ <vpc-peer-link-hdr> [ { TABLE_peerlink
<peer-link-id> <peerlink-ifindex> <peer-link-port-state> <peer-up-vlan-bitset> } ] <vpc-end> ] [ <vpc-hdr>
[ <vpc-is-es> ] [ <vpc-not-es> ] [ { TABLE_vpc <vpc-id> <vpc-ifindex> <vpc-port-state>
<phy-port-if-removed><vpc-thru-peerlink> <vpc-consistency> { [ <vpc-consistency-reason> ] [
<vpc-consistency-status> ] } <up-vlan-bitset> <es-attr> } ] <vpc-end> ] ]
```

### Syntax Description

|                             |  |
|-----------------------------|--|
| vpc                         | Virtual Port Channel configuration                   |
| brief                       | (Optional) Brief display of vPC status               |
| __readonly__                | (Optional) Read Only                                 |
| TABLE_peerlink              | (Optional) vPC peerlink table                        |
| TABLE_vpc                   | (Optional) vPC table                                 |
| vpc-domain-id               | (Optional) vPC domain id                             |
| vpc-l2mp-switch-id          | (Optional) vPC+ switch ID                            |
| vpc-peer-status             | (Optional) vPC peer status                           |
| vpc-peer-status-reason      | (Optional) vPC peer status reason                    |
| vpc-peer-keepalive-status   | (Optional) vpc peer keepalive status                 |
| vpc-peer-l2mp-status        | (Optional) vPC fabricpath status                     |
| vpc-role                    | (Optional) vPC role                                  |
| peer-gateway                | (Optional) Peer gateway status                       |
| peer-gateway-excluded-vlans | (Optional) peer-gateway excluded VLANs               |
| dual-active-excluded-vlans  | (Optional) dual-active excluded VLANs                |
| fp-enhanced-load-balancing  | (Optional) Fabricpath enhanced load balancing status |
| num-of-vpcs                 | (Optional) Number of vPCs configured                 |
| track-obj                   | (Optional) Track object for vPC                      |

|  |  |
|--|--|
| <i>vpc-graceful-consistency-check-status</i> | (Optional) vPC graceful consistency check                |
| <i>vpc-consistency</i>                       | (Optional) vPC global configuration consistency          |
| <i>vpc-consistency-reason</i>                | (Optional) vPC consistency reason                        |
| <i>vpc-consistency-status</i>                | (Optional) vPC consistency reason                        |
| <i>vpc-peer-consistency</i>                  | (Optional) vPC global configuration consistency          |
| <i>vpc-peer-consistency-reason</i>           | (Optional) vPC consistency reason                        |
| <i>vpc-peer-consistency-status</i>           | (Optional) vPC consistency reason                        |
| <i>vpc-per-vlan-peer-consistency</i>         | (Optional) vPC per-vlan global configuration consistency |
| <i>vpc-type-2-consistency</i>                | (Optional) vPC type-2 configuration consistency status   |
| <i>vpc-type-2-consistency-reason</i>         | (Optional) vPC type-2 configuration consistency reason   |
| <i>vpc-type-2-consistency-status</i>         | (Optional) vPC type-2 configuration consistency status   |
| <i>operational-l3-peer</i>                   | (Optional) Operational Layer 3 peer status               |
| <i>virtual-peerlink</i>                      | (Optional) Virtual peerlink status                       |
| <i>vpc-scale-high-status</i>                 | (Optional) vPC scale high status                         |
| <i>vpc-hdr</i>                               | (Optional) Start of vPC table                            |
| <i>vpc-is-es</i>                             | (Optional) Flag to indicate vPC+ complex                 |
| <i>vpc-not-es</i>                            | (Optional) Flag to indicate vPC complex                  |
| <i>vpc-peer-link-hdr</i>                     | (Optional) Start of vPC peer-link table                  |
| <i>vpc-port-state</i>                        | (Optional) vPC port state                                |
| <i>vpc-end</i>                               | (Optional) End of table                                  |
| <i>vpc-id</i>                                | (Optional) vPC id  |
| <i>vpc-ifindex</i>                           | (Optional) vPC ifindex                                   |
| <i>peer-link-id</i>                          | (Optional) peer link id                                  |
| <i>peerlink-ifindex</i>                      | (Optional) peer link ifindex                             |
| <i>peer-link-port-state</i>                  | (Optional) peer-link port state                          |
| <i>peer-up-vlan-bitset</i>                   | (Optional) peer link UP VLAN bitset                      |
| <i>up-vlan-bitset</i>                        | (Optional) vPC UP VLAN bitset                            |
| <i>es-attr</i>                               | (Optional) vPC+ attributes                               |
| <i>vpc-auto-recovery-status</i>              | (Optional) Auto-recovery status                          |

|                                     |                                     |
|-------------------------------------|-------------------------------------|
| <i>vpc-delay-restore-status</i>     | (Optional) Delay-restore status     |
| <i>vpc-delay-restore-svi-status</i> | (Optional) Delay-restore-svi status |
| <i>vpc-delay-peer-link-status</i>   | (Optional) Delay-peer-link status   |

**Command Mode**

- /exec

# show vpc

```
show vpc { <vpc-number> | brief vpc <vpc-number> } [ __readonly__ [ <vpc-hdr> ] [ <vpc-is-es> ] [ <vpc-not-es> ] [ TABLE_vpc <vpc-id> <vpc-ifindex> <vpc-port-state> <phy-port-if-removed><vpc-thru-peerlink> <vpc-consistency> { [ <vpc-consistency-reason> ] [ <vpc-consistency-status> ] } <up-vlan-bitset> <es-attr> ] <vpc-end> ]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| vpc                           | Virtual Port Channel configuration              |
| brief                         | Brief display of vPC status                     |
| <i>vpc-number</i>             | Enter a Virtual Port Channel number             |
| <i>__readonly__</i>           | (Optional) Read Only                            |
| <i>vpc-hdr</i>                | (Optional) Start of vPC table                   |
| <i>vpc-is-es</i>              | (Optional) Flag to indicate vPC+ complex        |
| <i>vpc-not-es</i>             | (Optional) Flag to indicate vPC complex         |
| TABLE_vpc                     | (Optional) vPC table                            |
| <i>vpc-id</i>                 | (Optional) vPC id                               |
| <i>vpc-ifindex</i>            | (Optional) vPC ifindex                          |
| <i>vpc-port-state</i>         | (Optional) vPC port state                       |
| <i>vpc-consistency</i>        | (Optional) vPC global configuration consistency |
| <i>vpc-consistency-reason</i> | (Optional) vPC consistency reason               |
| <i>vpc-consistency-status</i> | (Optional) vPC consistency reason               |
| <i>up-vlan-bitset</i>         | (Optional) vPC UP VLAN bitset                   |
| <i>es-attr</i>                | (Optional) vPC+ attributes                      |
| <i>vpc-end</i>                | (Optional) End of table                         |

## Command Mode

- /exec



# show vpc consistency-parameters

```
show vpc consistency-parameters { global | vni | interface <if> | vpc <vpc-num> } [ __readonly__
TABLE_vpc_consistency <vpc-param-name> <vpc-param-type> <vpc-param-local-val> <vpc-param-peer-val>
]
```

## Syntax Description

|                              |                                     |
|------------------------------|-------------------------------------|
| vpc                          | Virtual Port Channel configuration  |
| consistency-parameters       | Show vPC Consistency Parameters     |
| global                       | Global Parameters                   |
| vni                          | Show vPC Consistency Parameters vni |
| <i>if</i>                    |                                     |
| <i>vpc-num</i>               | Enter a Virtual Port Channel number |
| <i>__readonly__</i>          | (Optional) Read Only                |
| <i>TABLE_vpc_consistency</i> | (Optional) vPC table                |
| <i>vpc-param-name</i>        | (Optional)                          |
| <i>vpc-param-type</i>        | (Optional)                          |
| <i>vpc-param-local-val</i>   | (Optional)                          |
| <i>vpc-param-peer-val</i>    | (Optional)                          |

## Command Mode

- /exec

## show vpc consistency-parameters vlans

```
show vpc consistency-parameters vlans [ vnseg ] [ __readonly__ TABLE_vpc_consistency <vpc-param-name>
<vpc-param-type> [ <reason_code> ] [ <syserr> ] <vpc-pass-vlans> [ <reason_code> ] ]
```

### Syntax Description

|                        |   |
|------------------------|---|
| vpc                    | Virtual Port Channel configuration        |
| consistency-parameters | Show vPC Consistency Parameters           |
| vlans                  | vlans                                     |
| vnseg                  | (Optional) Display vlan to vn-segment map |
| __readonly__           | (Optional) Read Only                      |
| TABLE_vpc_consistency  | (Optional) vPC table                      |
| <i>vpc-param-name</i>  | (Optional)                                |
| <i>vpc-param-type</i>  | (Optional)                                |
| <i>vpc-pass-vlans</i>  | (Optional)                                |
| <i>syserr</i>          | (Optional) vPC consistency reason         |
| <i>reason_code</i>     | (Optional) vPC consistency reason         |

### Command Mode

- /exec

# show vpc fabric-ports

```
show vpc fabric-ports [ __readonly__ [ { TABLE_fabric_ports <vpc-fabric-ports> } ] ]
```

## Syntax Description

|                         |   |
|-------------------------|---|
| vpc                     | Virtual Port Channel configuration                  |
| fabric-ports            | Show ports that are part of uplink virtual-peerlink |
| __readonly__            | (Optional) Read Only                                |
| TABLE_fabric_ports      | (Optional) vPC fabric ports table                   |
| <i>vpc-fabric-ports</i> | (Optional) description of the port                  |

## Command Mode

- /exec

## show vpc orphan-ports

```
show vpc orphan-ports [ __readonly__ [ { TABLE_orphan_ports <vpc-vlan> <vpc-orphan-ports> } ] ]
```

### Syntax Description

|                    |   |
|--------------------|---|
| vpc                | Virtual Port Channel configuration                        |
| orphan-ports       | Show ports that are not part of vPC but have common VLANs |
| __readonly__       | (Optional) Read Only                                      |
| TABLE_orphan_ports | (Optional) vPC orphan ports table                         |
| vpc-vlan           | (Optional) port vlan                                      |
| vpc-orphan-ports   | (Optional) description of the port                        |

### Command Mode

- /exec

## show vpc peer-keepalive

```
show vpc peer-keepalive [ __readonly__ <vpc-peer-keepalive-status> <vpc-keepalive-dest>
<vpc-keepalive-send-interface> <vpc-keepalive-receive-interface> <vpc-keepalive-send-tstamp>
<vpc-keepalive-receive-tstamp> <vpc-peer-keepalive-up-time> <vpc-keepalive-send-status>
<vpc-keepalive-receive-status> <vpc-keepalive-lastupdate> [ <vpc-keepalive-dest> ] <vpc-keepalive-interval>
<vpc-keepalive-timeout> <vpc-keepalive-hold-timeout> <vpc-keepalive-vrf> <vpc-keepalive-udp-port>
<vpc-keepalive-tos> ]
```

### Syntax Description

|  |   |
|--|---|
| vpc                                    | Virtual Port Channel configuration              |
| peer-keepalive                         | vPC keepalive status                            |
| __readonly__                           | (Optional) Read Only                            |
| <i>vpc-peer-keepalive-status</i>       | (Optional) vpc peer keepalive status            |
| <i>vpc-keepalive-dest</i>              | (Optional) vPC keepalive destination ip address |
| <i>vpc-keepalive-send-status</i>       | (Optional) vPC keepalive send status            |
| <i>vpc-keepalive-receive-status</i>    | (Optional) vPC keepalive receive status         |
| <i>vpc-peer-keepalive-up-time</i>      | (Optional) keepalive- alive time                |
| <i>vpc-keepalive-send-tstamp</i>       | (Optional) vPC keepalive last send timestamp    |
| <i>vpc-keepalive-send-interface</i>    | (Optional) vPC keepalive send interface         |
| <i>vpc-keepalive-receive-tstamp</i>    | (Optional) vPC keepalive last receive timestamp |
| <i>vpc-keepalive-receive-interface</i> | (Optional) vPC keepalive receive interface      |
| <i>vpc-keepalive-lastupdate</i>        | (Optional) vPC keepalive last update from peer  |
| <i>vpc-keepalive-interval</i>          | (Optional) vPC keepalive timeout                |
| <i>vpc-keepalive-timeout</i>           | (Optional) vPC keepalive interval               |
| <i>vpc-keepalive-hold-timeout</i>      | (Optional) hold timeout                         |
| <i>vpc-keepalive-vrf</i>               | (Optional) vrf name                             |
| <i>vpc-keepalive-udp-port</i>          | (Optional) udp port                             |
| <i>vpc-keepalive-tos</i>               | (Optional) tos value                            |

### Command Mode

- /exec

# show vpc role

```
show vpc role [ __readonly__ <vpc-peer-status> <vpc-peer-status-reason> [ <vpc-current-role> ] [
<vpc-es-current-role> ] <dual-active-detected> <vpc-system-mac> <vpc-system-prio> <vpc-local-system-mac>
<vpc-local-system-prio><vpc-local-role-prio> <vpc-peer-system-mac>
<vpc-peer-system-prio><vpc-peer-role-prio> ]
```

## Syntax Description

|                               |   |
|-------------------------------|---|
| vpc                           | Virtual Port Channel configuration      |
| role                          | vPC role status                         |
| __readonly__                  | (Optional) Read Only                    |
| <i>vpc-peer-status</i>        | (Optional) vPC peer status              |
| <i>vpc-peer-status-reason</i> | (Optional) vPC peer status reason       |
| <i>vpc-current-role</i>       | (Optional) vPC role                     |
| <i>vpc-es-current-role</i>    | (Optional) vPC role                     |
| <i>dual-active-detected</i>   | (Optional) Dual active detection status |
| <i>vpc-system-mac</i>         | (Optional) vPC system mac               |
| <i>vpc-local-system-mac</i>   | (Optional) vPC local system mac         |
| <i>vpc-peer-system-mac</i>    | (Optional) vPC peer system mac          |
| <i>vpc-system-prio</i>        | (Optional) vPC system priority          |

## Command Mode

- /exec

## show vpc statistics peer-keepalive

```
show vpc statistics peer-keepalive [ __readonly__ <vpc-peer-keepalive-status> <vpc-keepalive-counters-tx>
<vpc-keepalive-counters-rx> <vpc-keepalive-avg-rx-interval> <vpc-keepalive-peer-state-changes> ]
```

### Syntax Description

|   |  |
|---|--|
| vpc                                     | Virtual Port Channel configuration       |
| statistics                              | Statistics                               |
| peer-keepalive                          | peer keepalive module related statistics |
| __readonly__                            | (Optional) Read Only                     |
| <i>vpc-peer-keepalive-status</i>        | (Optional) vpc peer keepalive status     |
| <i>vpc-keepalive-counters-tx</i>        | (Optional) tx counters                   |
| <i>vpc-keepalive-counters-rx</i>        | (Optional) rx counters                   |
| <i>vpc-keepalive-avg-rx-interval</i>    | (Optional) avg rx interval in ms         |
| <i>vpc-keepalive-peer-state-changes</i> | (Optional) peer state changes            |

### Command Mode

- /exec

# show vpc statistics vpc

show vpc statistics { vpc <vpc\_num> | peer-link }

## Syntax Description

|                |                                    |
|----------------|------------------------------------|
| vpc            | Virtual Port Channel configuration |
| statistics     | Statistics                         |
| <i>vpc_num</i> | Virtual Port Channel number        |
| peer-link      | stats for peer-link                |

## Command Mode

- /exec



# show vpc virtual-peerlink dest reachable

show vpc virtual-peerlink dest reachable

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information        |
| vpc              | vPC related information                |
| virtual-peerlink | virtual-peerlink Related show commands |
| dest             | dest info                              |
| reachable        | dest reachability                      |

## Command Mode

- /exec

# show vpc virtual-peerlink vlan consistency

show vpc virtual-peerlink vlan consistency

## Syntax Description

|                  |  |
|------------------|--|
| show             | Show running system information        |
| vpc              | vPC related information                |
| virtual-peerlink | virtual-peerlink Related show commands |
| vlan             | vlan info for vPC                      |
| consistency      | vlan vni consistency                   |

## Command Mode

- /exec

# show vrf

show vrf [ <vrf-name> | <vrf-known-name> | all ]

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| vrf                   | Display VRF information                         |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| all                   | (Optional) Display VRF information for all VRFs |

## Command Mode

- /exec

# show vrf

```
show vrf [ <vrf-name> | <vrf-known-name> | all ] [ order id ] [ detail ] [ passive ] [ __readonly__ TABLE_vrf
<vrf_name> <vrf_id> <vrf_state> [ <vrf_reason> ] [ <vrf_pend> ] [ <vpnid> <rd> [ <vni> ] <max_routes>
<mid_threshold> ] [ { TABLE_tib <tib_id> <tib_af> <tib_nonce> <tib_state> [ <tib_reason> ] [ <tib_pend>
} ] ] ]
```

## Syntax Description

|                       |   |
|-----------------------|---|
| show                  | Show running system information                 |
| vrf                   | Display VRF information                         |
| <i>vrf-name</i>       | (Optional) VRF name                             |
| <i>vrf-known-name</i> | (Optional) Known VRF name                       |
| all                   | (Optional) Display VRF information for all VRFs |
| order                 | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED       |
| id                    | (Optional) Order by ID                          |
| detail                | (Optional) Display VRF detail information       |
| passive               | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED       |
| __readonly__          | (Optional)                                      |
| TABLE_vrf             | (Optional)                                      |
| TABLE_tib             | (Optional)                                      |
| <i>vrf_name</i>       | (Optional)                                      |
| <i>vrf_id</i>         | (Optional)                                      |
| <i>vrf_state</i>      | (Optional)                                      |
| <i>vrf_reason</i>     | (Optional)                                      |
| <i>vrf_pend</i>       | (Optional)                                      |
| <i>vpnid</i>          | (Optional)                                      |
| <i>rd</i>             | (Optional)                                      |
| <i>max_routes</i>     | (Optional)                                      |
| <i>mid_threshold</i>  | (Optional)                                      |
| <i>tib_id</i>         | (Optional)                                      |
| <i>tib_af</i>         | (Optional)                                      |

|                   |            |
|-------------------|------------|
| <i>tib_nonce</i>  | (Optional) |
| <i>tib_state</i>  | (Optional) |
| <i>tib_reason</i> | (Optional) |
| <i>tib_pend</i>   | (Optional) |
| <i>vni</i>        | (Optional) |

**Command Mode**

- /exec

## show vrrp

```
show vrrp [ [ summary ] | { [ statistics | detail ] [ interface <interface_id> ] [ vr <vr_id> ] [ master | backup |
init ] + } ] [ __readonly__ [ [ TABLE_vrrp_group <sh_if_index> <sh_group_id> <sh_group_type>
<sh_group_state> <sh_group_preempt> <sh_vip_addr> { [ TABLE_sec_vip_addr <sh_sec_vip_addr> ] }
<sh_priority> [ <sh_cfg_priority> <sh_fwd_thr_lower> <sh_fwd_thr_upper> ] <sh_adv_interval> [
<sh_auth_text> ] [ <sh_vmac> ] [ <sh_master_router> ] [ <sh_native_track_intf> <sh_native_track_priotiry>
] { [ TABLE_vrrp_track <sh_track_object_id> <sh_decrement_priority> <sh_track_object_state> ] } [
<sh_bfd_status> <sh_bfd_session> ] ] [ { TABLE_vrrp_statistics [ <if_index> ] [ <grp_id> ] [ <grp_type> ]
[ <master_cnt> ] [ <adv_pkts> ] [ <adv_intv_mismatch> ] [ <auth_failure> ] [ <ttl_err> ] [ <zero_pri_adv_rcvd>
] [ <zero_pri_adv_sent> ] [ <type_fl_mismatch> ] [ <addr_mismatch> ] [ <inv_auth> ] [ <auth_mismatch>
] [ <inv_pkt_len> ] } ] [ <total_num_of_grp> ] [ <init_grps> ] [ <backup_grps> ] [ <master_grps> ] [
<vrrp_enabled_ifs> ] [ <mts_rx> ] [ <mts_tx> ] [ <pkt_rx> ] [ <pkt_tx> ] ] + ]
```

### Syntax Description

|                         |   |
|-------------------------|---|
| show                    | Show running system information             |
| vrrp                    | Show vrrp information                       |
| summary                 | (Optional) Show vrrp summary                |
| statistics              | (Optional) Show vrrp statistics             |
| detail                  | (Optional) Show detailed information        |
| interface               | (Optional) Show vrrp info for the interface |
| <i>interface_id</i>     | (Optional)                                  |
| vr                      | (Optional) Show vrrp info for the group     |
| <i>vr_id</i>            | (Optional) [1-255] enter IPv4 vr group      |
| master                  | (Optional) Groups in Master state           |
| backup                  | (Optional) Groups in Backup state           |
| init                    | (Optional) Groups in Init state             |
| __readonly__            | (Optional) Read only                        |
| TABLE_vrrp_group        | (Optional) Group detail table               |
| <i>sh_if_index</i>      | (Optional) Interface type and number        |
| <i>sh_group_id</i>      | (Optional) Group number                     |
| <i>sh_group_type</i>    | (Optional) Group type                       |
| <i>sh_group_state</i>   | (Optional) VRRP group state                 |
| <i>sh_group_preempt</i> | (Optional) Group preemption statue          |

|                                 |   |
|---------------------------------|---|
| <i>sh_vip_addr</i>              | (Optional) Virtual IP Address                     |
| TABLE_sec_vip_addr              | (Optional) Secondary virtual ip address table     |
| <i>sh_sec_vip_addr</i>          | (Optional) Secondary virtual ip address           |
| <i>sh_priority</i>              | (Optional) Priority of VRRP group                 |
| <i>sh_auth_text</i>             | (Optional) Authentication text                    |
| <i>sh_cfg_priority</i>          | (Optional) Configured priority of VRRP group      |
| <i>sh_fwd_thr_lower</i>         | (Optional) Lower forwarding threshold             |
| <i>sh_fwd_thr_upper</i>         | (Optional) Upper forwarding threshold             |
| <i>sh_adv_interval</i>          | (Optional) Advertisement interval                 |
| <i>sh_vmac</i>                  | (Optional) Virtual MAC                            |
| <i>sh_master_router</i>         | (Optional) Master router                          |
| <i>sh_native_track_intf</i>     | (Optional) Native tracked interface               |
| <i>sh_native_track_priotiry</i> | (Optional) Decrement priority for Native tracking |
| TABLE_vrrp_track                | (Optional) VRRP tracking table                    |
| <i>sh_track_object_id</i>       | (Optional) Object id of tracking object           |
| <i>sh_decrement_priority</i>    | (Optional) Decrement priority                     |
| <i>sh_track_object_state</i>    | (Optional) Tracking object state                  |
| <i>sh_bfd_status</i>            | (Optional) BFD status                             |
| <i>sh_bfd_session</i>           | (Optional) BFD session status                     |
| TABLE_vrrp_statistics           | (Optional) VRRP statistics table                  |
| <i>if_index</i>                 | (Optional) Interface type and number              |
| <i>grp_id</i>                   | (Optional) Group number                           |
| <i>grp_type</i>                 | (Optional) Group type                             |
| <i>master_cnt</i>               | (Optional) VRRP Master                            |
| <i>adv_pkts</i>                 | (Optional) Advertisement pkts                     |
| <i>adv_intv_mismatch</i>        | (Optional) Advertisement interval mismatch        |
| <i>auth_failure</i>             | (Optional) Auth failure                           |
| <i>ttl_err</i>                  | (Optional) TTL error                              |
| <i>zero_pri_adv_rcvd</i>        | (Optional) Zero pri adv received                  |

|                          |  |
|--------------------------|--|
| <i>zero_pri_adv_sent</i> | (Optional) Zero pri adv sent                 |
| <i>type_fl_mismatch</i>  | (Optional) Invalid type field                |
| <i>addr_mismatch</i>     | (Optional) Address mismatch                  |
| <i>inv_auth</i>          | (Optional) Invalid auth type                 |
| <i>auth_mismatch</i>     | (Optional) Authentication mismatch           |
| <i>inv_pkt_len</i>       | (Optional) Invalid pkt length                |
| <i>total_num_of_grp</i>  | (Optional) Total Number of Groups Configured |
| <i>init_grps</i>         | (Optional) Init groups                       |
| <i>backup_grps</i>       | (Optional) Backup groups                     |
| <i>master_grps</i>       | (Optional) Master groups                     |
| <i>vrrp_enabled_ifs</i>  | (Optional) Number of VRRP enabled interfaces |
| <i>mts_rx</i>            | (Optional) Total MTS Rx                      |
| <i>mts_tx</i>            | (Optional) Total MTS Tx                      |
| <i>pkt_rx</i>            | (Optional) Total Pkt Rx                      |
| <i>pkt_tx</i>            | (Optional) Total Pkt Tx                      |

### Command Mode

- /exec



## show vrrp bfd-sessions

```
show vrrp bfd-sessions [ interface <interface-id> [ to <ipaddress> ] ] [ __readonly__ TABLE_bfd_sess
<interface> { <src_addr> | <src_addr_v6> } { <dst_addr> | <dst_addr_v6> } <session_state> <ref_count>
<displayed_interface> { TABLE_groups <group_id> <vrrp_state> <bfd_status> <operation> <time> } ]
```

### Syntax Description

|                            |                                     |
|----------------------------|-------------------------------------|
| show                       | Show running system information     |
| vrrp                       | Show vrrp information               |
| bfd-sessions               | BFD sessions                        |
| interface                  | (Optional) Groups on this interface |
| <i>interface-id</i>        | (Optional) Interface                |
| to                         | (Optional) To IP address            |
| <i>ipaddress</i>           | (Optional) Sessions to IP address   |
| <i>__readonly__</i>        | (Optional)                          |
| TABLE_bfd_sess             | (Optional)                          |
| <i>interface</i>           | (Optional) Interface                |
| <i>src_addr</i>            | (Optional) IPv4 Source address      |
| <i>dst_addr</i>            | (Optional) IPv4 Destination address |
| <i>session_state</i>       | (Optional) Session state            |
| <i>ref_count</i>           | (Optional) Ref count                |
| <i>displayed_interface</i> | (Optional) Displayed interface      |
| TABLE_groups               | (Optional)                          |
| <i>group_id</i>            | (Optional) Group id                 |
| <i>vrrp_state</i>          | (Optional) VRRP STATE               |
| <i>bfd_status</i>          | (Optional) BFD STATE                |
| <i>operation</i>           | (Optional) Operation                |
| <i>time</i>                | (Optional) Time                     |

### Command Mode

- /exec

## show vrrpv3

```
show vrrpv3 [ brief | detail | statistics ] [ <intf> [ <group_num> ] ] [ <opt_v4_or_v6> ] [ all ] [ __readonly__
[ <global_drops> ] [ { TABLE_istats [ <i_intf> ] [ <i_drops> ] [ <ttl> ] [ <checksum> ] [ <version> ] [
<type> ] [ <length> ] [ <badid> ] [ <other> } ] ] [ { TABLE_grp [ <intf> ] [ <id> ] [ <af> ] [ <desc> ] [ <state>
] [ <duration> ] [ <vip> ] [ { TABLE_sec [ <addr> ] [ <prefix> } ] ] [ <vmac> ] [ <adv> ] [ <owner> ] [
<preempt> ] [ <delay> ] [ <delay_rem> ] [ <priority> ] [ <cfg_priority> ] [ <m_addr> ] [ <m_priority> ] [
<m_adv> ] [ <m_expire> ] [ <down> ] [ <down_expire> ] [ <t_id> ] [ <t_dec_prio> ] [ <t_state> ] [ <adv_sent>
] [ <adv_err> ] [ <adv_rcvd> ] [ <v2adv_sent> ] [ <v2adv_err> ] [ <v2adv_rcvd> ] [ <drops> ] [ <incompat>
] [ <conflict> ] [ <bad_count> ] [ <bad_addr> ] [ <bad_config> ] [ <bad_advert> ] [ <bad_state> ] [ <bad_other>
] [ <init_master> ] [ <init_master_time> ] [ <init_backup> ] [ <init_backup_time> ] [ <back_master> ] [
<back_master_time> ] [ <master_back> ] [ <master_back_time> ] [ <mast_init> ] [ <mast_init_time> ] [
<back_init> ] [ <back_init_time> } ] ] ] + [ { TABLE_vbrief [ <intf_b> ] [ <id_b> ] [ <af_b> ] [ <priority_b>
] [ <down_b> ] [ <owner_b> ] [ <preempt_b> ] [ <state_b> ] [ <m_addr_b> ] [ <vip_b> } ] ] ] ]
```

### Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| vrrpv3       | VRRPv3 Show commands                         |
| all          | (Optional) All VRRPV3 information            |
| brief        | (Optional) Brief output                      |
| detail       | (Optional) Detail output                     |
| statistics   | (Optional) Statistics output                 |
| opt_v4_or_v6 | (Optional) Enter ipv4 or ipv6                |
| intf         | (Optional) Interface                         |
| group_num    | (Optional) Group Number                      |
| __readonly__ | (Optional)                                   |
| TABLE_istats | (Optional) Interface-level VRRPv3 statistics |
| TABLE_grp    | (Optional) VRRP Groups                       |
| TABLE_sec    | (Optional) Secondary Addresses               |
| TABLE_vbrief | (Optional) VRRP Brief                        |
| global_drops | (Optional) Total dropped packets             |
| i_intf       | (Optional) Interface                         |
| i_drops      | (Optional) Total dropped packets             |
| ttl          | (Optional) Invalid TTL/Hop limit             |
| checksum     | (Optional) Invalid checksum                  |

|                     |  |
|---------------------|--|
| <i>version</i>      | (Optional) Invalid version               |
| <i>type</i>         | (Optional) Invalid message type          |
| <i>length</i>       | (Optional) Invalid length                |
| <i>badid</i>        | (Optional) Invalid group ID              |
| <i>other</i>        | (Optional) Other                         |
| <i>intf</i>         | (Optional) Interface                     |
| <i>id</i>           | (Optional) Group ID                      |
| <i>af</i>           | (Optional) Address family                |
| <i>desc</i>         | (Optional) Description                   |
| <i>state</i>        | (Optional) Group state                   |
| <i>duration</i>     | (Optional) Time in current state         |
| <i>vip</i>          | (Optional) Primary virtual IP address    |
| <i>addr</i>         | (Optional) Secondary virtual IP address  |
| <i>prefix</i>       | (Optional) Secondary vIP prefix          |
| <i>vmac</i>         | (Optional) Virtual MAC address           |
| <i>adv</i>          | (Optional) Advertisement interval        |
| <i>preempt</i>      | (Optional) Preemption status             |
| <i>owner</i>        | (Optional) Owner mode                    |
| <i>delay</i>        | (Optional) Preemption delay              |
| <i>delay_rem</i>    | (Optional) Preemption delay remaining    |
| <i>priority</i>     | (Optional) Priority                      |
| <i>cfg_priority</i> | (Optional) Configured priority           |
| <i>m_addr</i>       | (Optional) Group master router address   |
| <i>m_priority</i>   | (Optional) Group master priority         |
| <i>m_adv</i>        | (Optional) Master advertisement interval |
| <i>m_expire</i>     | (Optional) Master expiration             |
| <i>down</i>         | (Optional) Master down interval          |
| <i>down_expire</i>  | (Optional) Master down expiration        |
| <i>t_id</i>         | (Optional) Tracking object ID            |

|                         |   |
|-------------------------|---|
| <i>t_dec_prio</i>       | (Optional) Priority to decrement          |
| <i>t_state</i>          | (Optional) Tracking object state          |
| <i>adv_sent</i>         | (Optional) Advertisements sent            |
| <i>adv_err</i>          | (Optional) Advertisement errors           |
| <i>adv_rcvcd</i>        | (Optional) Advertisements received        |
| <i>v2adv_sent</i>       | (Optional) Advertisements sent (v2)       |
| <i>v2adv_err</i>        | (Optional) Advertisement errors (v2)      |
| <i>v2adv_rcvcd</i>      | (Optional) Advertisements received (v2)   |
| <i>drops</i>            | (Optional) Total dropped packets          |
| <i>incompat</i>         | (Optional) v2, Incompatible               |
| <i>conflict</i>         | (Optional) Address owner conflicts        |
| <i>bad_count</i>        | (Optional) Invalid address count          |
| <i>bad_addr</i>         | (Optional) Invalid IP address             |
| <i>bad_config</i>       | (Optional) Invalid IP address config      |
| <i>bad_advert</i>       | (Optional) Invalid advertisement interval |
| <i>bad_state</i>        | (Optional) Invalid group state            |
| <i>bad_other</i>        | (Optional) Other                          |
| <i>init_master</i>      | (Optional) Init to Master                 |
| <i>init_master_time</i> | (Optional) Last Occurrence                |
| <i>init_backup</i>      | (Optional) Init to Backup                 |
| <i>init_backup_time</i> | (Optional) Last Occurrence                |
| <i>back_master</i>      | (Optional) Backup to Master               |
| <i>back_master_time</i> | (Optional) Last Occurrence                |
| <i>master_back</i>      | (Optional) Master to Backup               |
| <i>master_back_time</i> | (Optional) Last Occurrence                |
| <i>mast_init</i>        | (Optional) Master to Init                 |
| <i>mast_init_time</i>   | (Optional) Last Occurrence                |
| <i>back_init</i>        | (Optional) Backup to Init                 |
| <i>back_init_time</i>   | (Optional) Last Occurrence                |

|                   |  |
|-------------------|--|
| <i>intf_b</i>     | (Optional) Interface                   |
| <i>id_b</i>       | (Optional) Group ID                    |
| <i>af_b</i>       | (Optional) Address family              |
| <i>priority_b</i> | (Optional) Priority                    |
| <i>down_b</i>     | (Optional) Master down interval        |
| <i>owner_b</i>    | (Optional) Owner mode                  |
| <i>preempt_b</i>  | (Optional) Preemption status           |
| <i>state_b</i>    | (Optional) Group state                 |
| <i>m_addr_b</i>   | (Optional) Group master router address |
| <i>vip_b</i>      | (Optional) Primary virtual IP address  |

**Command Mode**

- /exec

# show vrrs client

```
show vrrs client [ <cname> ] [ __readonly__ { TABLE_client <name> <id> <all> <priority> { TABLE_tags <tname> } } ]
```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| vrrs                | VRRS Show commands                 |
| show                | Show running system information    |
| client              | Information about VRRS clients     |
| <i>cname</i>        | (Optional) VRRS client name        |
| <i>__readonly__</i> | (Optional)                         |
| TABLE_client        | (Optional) VRRS clients            |
| TABLE_tags          | (Optional) VRRS tags               |
| <i>name</i>         | (Optional) VRRS client name        |
| <i>id</i>           | (Optional) VRRS client id          |
| <i>priority</i>     | (Optional) Priority                |
| <i>all</i>          | (Optional) Client follows all tags |
| <i>tname</i>        | (Optional) VRRS tag name           |

## Command Mode

- /exec

# show vrrs pathway

```
show vrrs pathway [ <intf> ] [ __readonly__ { TABLE_pws <name> <state> <vrrs_push_state> <vmac>
<vmac_state> <vmac_dbg> [ <pvmac> ] [ <pvmac_state> ] [ <pvmac_dbg> ] <af> [ <desc> ] <opt> <eval>
[ { TABLE_vips <addr> [ <flags> ] } } ] ]
```

## Syntax Description

|                        |   |
|------------------------|---|
| vrrs                   | VRRS Show commands                      |
| show                   | Show running system information         |
| pathway                | Information about VRRS pathways         |
| <i>intf</i>            | (Optional) Interface                    |
| <i>__readonly__</i>    | (Optional)                              |
| TABLE_pws              | (Optional) Show VRRS pathways           |
| TABLE_vips             | (Optional) Pathway vIP addresses        |
| <i>name</i>            | (Optional) Pathway name                 |
| <i>state</i>           | (Optional) Pathway state                |
| <i>vrrs_push_state</i> | (Optional) VRRS push state              |
| <i>vmac</i>            | (Optional) Virtual MAC address          |
| <i>vmac_state</i>      | (Optional) Virtual MAC state            |
| <i>vmac_dbg</i>        | (Optional) Virtual MAC debug flags      |
| <i>pvmac</i>           | (Optional) Previous Virtual MAC address |
| <i>pvmac_state</i>     | (Optional) Previous MAC state           |
| <i>pvmac_dbg</i>       | (Optional) Previous MAC debug flags     |
| <i>af</i>              | (Optional) Pathway address-family       |
| <i>desc</i>            | (Optional) Pathway description          |
| <i>opt</i>             | (Optional) Option flags                 |
| <i>eval</i>            | (Optional) Eval flags                   |
| <i>addr</i>            | (Optional) Virtual IP address           |
| <i>flags</i>           | (Optional) Virtual IP address flags     |

## Command Mode

- /exec

# show vrrs server

```
show vrrs server [ __readonly__ { TABLE_srv <name> <af> <intf> <state> <vmac> <vip> [ { TABLE_tag
<tag> } ] } ]
```

## Syntax Description

|              |  |
|--------------|--|
| vrrs         | VRRS Show commands                               |
| show         | Show running system information                  |
| server       | Information about VRRS servers                   |
| __readonly__ | (Optional)                                       |
| TABLE_srv    | (Optional) VRRS Servers                          |
| TABLE_tag    | (Optional) VRRS tags associated with each server |
| <i>name</i>  | (Optional) VRRS server name                      |
| <i>af</i>    | (Optional) Address-family                        |
| <i>intf</i>  | (Optional) Interface                             |
| <i>state</i> | (Optional) VRRS server state                     |
| <i>vmac</i>  | (Optional) Virtual MAC address                   |
| <i>vip</i>   | (Optional) Virtual IP address                    |
| <i>tag</i>   | (Optional) VRRS tag                              |

## Command Mode

- /exec



# show vrrs tag

```
show vrrs tag [ <tagname> ] [ __readonly__ { TABLE_tag <name> <server> [ { TABLE_client <id> <client>
<all> } ] } ]
```

## Syntax Description

|                     |                                    |
|---------------------|------------------------------------|
| vrrs                | VRRS Show commands                 |
| show                | Show running system information    |
| tag                 | Information about VRRS tags        |
| <i>tagname</i>      | (Optional) VRRS tag                |
| <i>__readonly__</i> | (Optional)                         |
| TABLE_tag           | (Optional) Known VRRS tags         |
| TABLE_client        | (Optional) VRRS clients listening  |
| <i>name</i>         | (Optional) VRRS tag name           |
| <i>server</i>       | (Optional) VRRS server name        |
| <i>id</i>           | (Optional) VRRS client id          |
| <i>client</i>       | (Optional) VRRS client name        |
| <i>all</i>          | (Optional) Client follows all tags |

## Command Mode

- /exec

# show vsan

```
show vsan [ <id_in> ] [ __readonly__ { TABLE_vsan <id> { [ <name> <state> <interop_mode>
<load_balancing> <operational_state> ] | <inactive_vsan_name> | <evfp_control_vsan_name> } } ]
```

## Syntax Description

|                               |                                  |
|-------------------------------|----------------------------------|
| show                          | Show running system information  |
| vsan                          | Vsan commands                    |
| <i>id_in</i>                  | (Optional) VSAN ID range         |
| <i>__readonly__</i>           | (Optional) Read Only             |
| TABLE_vsan                    | (Optional) Table of VSAN's       |
| <i>id</i>                     | (Optional) VSAN ID               |
| <i>name</i>                   | (Optional) VSAN name             |
| <i>state</i>                  | (Optional) VSAN state            |
| <i>interop_mode</i>           | (Optional) Interoperability mode |
| <i>load_balancing</i>         | (Optional) Load balancing        |
| <i>operational_state</i>      | (Optional) Operational state     |
| <i>inactive_vsan_name</i>     | (Optional) Isolated VSAN         |
| <i>evfp_control_vsan_name</i> | (Optional) EVFP isolated VSAN    |

## Command Mode

- /exec

# show vsan membership

```
show vsan [ <id_in> ] membership [ __readonly__ { TABLE_vsan <id> [ <inactive_vsan_name> ] [
<evfp_control_vsan_name> ] [ TABLE_interface <name> ] } ]
```

## Syntax Description

|                               |                                      |
|-------------------------------|--------------------------------------|
| show                          | Show running system information      |
| vsan                          | Vsan commands                        |
| <i>id_in</i>                  | (Optional) VSAN ID range             |
| membership                    | VSAN membership information          |
| <i>__readonly__</i>           | (Optional) Read Only                 |
| TABLE_vsan                    | (Optional) VSAN table                |
| <i>id</i>                     | (Optional) VSAN ID                   |
| <i>inactive_vsan_name</i>     | (Optional) Isolated VSAN             |
| <i>evfp_control_vsan_name</i> | (Optional) EVFP isolated VSAN        |
| TABLE_interface               | (Optional) List of interface members |
| <i>name</i>                   | (Optional) Interface name            |

## Command Mode

- /exec

## show vsan membership interface

```
show vsan membership interface <if_in> [ __readonly__ { TABLE_interface <name> <vsan_id_memb> [
<inactive_vsan_name> | <evfp_control_vsan_name> ] <allowed_vsan_list> } ]
```

### Syntax Description

|                               |   |
|-------------------------------|---|
| show                          | Show running system information               |
| vsan                          | Vsan commands                                 |
| membership                    | VSAN membership information                   |
| interface                     | Show interface status and information         |
| <i>if_in</i>                  | Interface range                               |
| <i>__readonly__</i>           | (Optional) Read Only                          |
| <i>TABLE_interface</i>        | (Optional) Interface VSAN table               |
| <i>name</i>                   | (Optional) Interface Name                     |
| <i>vsan_id_memb</i>           | (Optional) VSAN ID to which interface belongs |
| <i>inactive_vsan_name</i>     | (Optional) Isolated VSAN                      |
| <i>evfp_control_vsan_name</i> | (Optional) EVFP isolated VSAN                 |
| <i>allowed_vsan_list</i>      | (Optional) Allowed VSAN list                  |

### Command Mode

- /exec

## show vsan usage

```
show vsan usage [ __readonly__ { <num_vsans_configured> <configured_range_of_vsans>
<vsans_available_to_configure> } ]
```

### Syntax Description

|                                     |  |
|-------------------------------------|--|
| show                                | Show running system information              |
| vsan                                | Vsan commands                                |
| usage                               | show VSAN usage in the system                |
| <i>__readonly__</i>                 | (Optional) Read Only                         |
| <i>num_vsans_configured</i>         | (Optional) Total VSAN's configured           |
| <i>configured_range_of_vsans</i>    | (Optional) Range of VSAN's configured        |
| <i>vsans_available_to_configure</i> | (Optional) VSAN range available to configure |

### Command Mode

- /exec

## show vtp counters

```
show vtp counters [ __readonly__ <start> <summary_rx> <subset_rx> <request_rx> <summary_tx>
<subset_tx> <request_tx> <num_config_rev_error> <num_config_digest_error> <num_v1_summary_error>
[ { TABLE_pruning_counters <if_index> <join_tx> <join_rx> <summary_adv_v1_rx> } ] ]
```

### Syntax Description

|                                |   |
|--------------------------------|---|
| show                           | Show running system information                                   |
| vtp                            | VTP information   |
| counters                       | VTP statistics  |
| <i>__readonly__</i>            | (Optional) Read Only  |
| <i>start</i>                   | (Optional) Start  |
| <i>summary_rx</i>              | (Optional) Summary advertisements received                        |
| <i>subset_rx</i>               | (Optional) Subset advertisements received                         |
| <i>request_rx</i>              | (Optional) Request advertisements received                        |
| <i>summary_tx</i>              | (Optional) Summary advertisements transmitted                     |
| <i>subset_tx</i>               | (Optional) Subset advertisements transmitted                      |
| <i>request_tx</i>              | (Optional) Request advertisements transmitted                     |
| <i>num_config_rev_error</i>    | (Optional) Number of config revision errors                       |
| <i>num_config_digest_error</i> | (Optional) Number of config digest errors                         |
| <i>num_v1_summary_error</i>    | (Optional) Number of V1 summary errors                            |
| TABLE_pruning_counters         | (Optional) Pruning counters in table format                       |
| <i>if_index</i>                | (Optional) Trunk  |
| <i>join_tx</i>                 | (Optional) Join Transmitted                                       |
| <i>join_rx</i>                 | (Optional) Join Received  |
| <i>summary_adv_v1_rx</i>       | (Optional) Summary advts received from non-pruning-capable device |

### Command Mode

- /exec

# show vtp interface

```
show vtp interface [ <interface_range> ] [ __readonly__ [ <start> ] { TABLE_vtp_interface <if_index>
<status> } ]
```

## Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                        |
| vtp                    | VTP information  |
| interface              | VTP interface status and configuration                 |
| <i>interface_range</i> | (Optional) Enter interfaces                            |
| <i>__readonly__</i>    | (Optional) Read Only                                   |
| <i>start</i>           | (Optional) Start                                       |
| TABLE_vtp_interface    | (Optional) VTP interface configuration in table format |
| <i>if_index</i>        | (Optional) Trunk                                       |
| <i>status</i>          | (Optional) VTP interface status                        |

## Command Mode

- /exec

# show vtp password

```
show vtp password [ domain <domain-id> ] [ __readonly__ <start> <passwd> <password-type> <secret-key> ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                  |
| vtp                  | VTP information                                  |
| password             | VTP password                                     |
| domain               | (Optional) VTP administrative domain             |
| <i>domain-id</i>     | (Optional) Domain index(Domain-id)               |
| <i>__readonly__</i>  | (Optional) Read Only                             |
| <i>start</i>         | (Optional) Start                                 |
| <i>passwd</i>        | (Optional) VTP Domain Password                   |
| <i>password-type</i> | (Optional) Password Type (1=plaintext, 2=hidden) |
| <i>secret-key</i>    | (Optional) Secret Key for the password           |

## Command Mode

- /exec



## show vtp status

```
show vtp status [ __readonly__ <start> <version> <config_rev> <max_vlan_supported_local>
<num_current_vlans> <oper_mode> <domain_name> <pruning_mode> <oper_pruning_mode> <v2_mode>
<trap_enabled> <md5_digest> <last_modified_ip> <last_modified_time> <running-version> <updater_id>
<updater_reason> ]
```

### Syntax Description

|                                 |  |
|---------------------------------|--|
| show                            | Show running system information            |
| vtp                             | VTP information                            |
| status                          | VTP domain status                          |
| <i>__readonly__</i>             | (Optional) Read Only                       |
| <i>start</i>                    | (Optional) Start                           |
| <i>version</i>                  | (Optional) VTP version                     |
| <i>config_rev</i>               | (Optional) Configuration Revision          |
| <i>max_vlan_supported_local</i> | (Optional) Maximum VLANs supported locally |
| <i>num_current_vlans</i>        | (Optional) Number of existing VLANs        |
| <i>oper_mode</i>                | (Optional) VTP Mode                        |
| <i>domain_name</i>              | (Optional) VTP Domain Name                 |
| <i>pruning_mode</i>             | (Optional) Pruning Mode                    |
| <i>oper_pruning_mode</i>        | (Optional) Operational Pruning Mode        |
| <i>v2_mode</i>                  | (Optional) VTP v2 Mode                     |
| <i>trap_enabled</i>             | (Optional) trap enabled                    |
| <i>md5_digest</i>               | (Optional) MD5 Digest                      |
| <i>last_modified_ip</i>         | (Optional) Configuration last modified by  |
| <i>last_modified_time</i>       | (Optional) Configuration last modified at  |
| <i>running-version</i>          | (Optional) VTP Version Running             |
| <i>updater_id</i>               | (Optional) Local Updater id                |
| <i>updater_reason</i>           | (Optional) Local Updater id reason         |

### Command Mode

- /exec

**show vtp status**



## W Show Commands

---

- [show wred-queue qos-group-map](#), on page 3486
- [show wrr-queue qos-group-map](#), on page 3487
- [show wrr-unicast-bandwidth](#), on page 3488
- [show wwn oui](#), on page 3489
- [show wwn status](#), on page 3490
- [show wwn switch](#), on page 3491
- [show wwn test](#), on page 3492
- [show wwn vsan-wwn](#), on page 3494

# show wred-queue qos-group-map

```
show wred-queue qos-group-map [ __readonly__ TABLE_wred_queue_qos_group_map
<wred-queue><qos-group-map> ]
```

## Syntax Description

|                                |  |
|--------------------------------|--|
| show                           | Show running system information              |
| wred-queue                     | Show WRED qos-group information              |
| qos-group-map                  | Display mapping of the qos-group information |
| __readonly__                   | (Optional)                                   |
| TABLE_wred_queue_qos_group_map | (Optional) XML show wred-queue qos-group-map |

## Command Mode

- /exec

## show wrr-queue qos-group-map

```
show wrr-queue qos-group-map [ __readonly__ <mcast_queue_id> [ TABLE_wrr_queue <wrr_queue> [
TABLE_qos_group <qos_group> ] ] ]
```

### Syntax Description

|                        |  |
|------------------------|--|
| show                   | Show running system information                                  |
| wrr-queue              | Display mapping of traffic priority (CoS) values to L3 Multicast |
| qos-group-map          | Show wrr-queue qos-group-map                                     |
| <i>__readonly__</i>    | (Optional)   |
| <i>mcast_queue_id</i>  | (Optional) MCAST Queue ID  |
| <i>TABLE_wrr_queue</i> | (Optional) Table wrr queue                                       |
| <i>wrr_queue</i>       | (Optional) Traffic priority values                               |
| <i>TABLE_qos_group</i> | (Optional) Table qos group                                       |
| <i>qos_group</i>       | (Optional) QoS-Group-Map   |

### Command Mode

- /exec

## show wrr unicast-bandwidth

show wrr unicast-bandwidth [ \_\_readonly\_\_ TABLE\_wrr\_unicast\_bandwidth <unicast-bandwidth> ]

### Syntax Description

|                             |   |
|-----------------------------|---|
| show                        | Show running system information           |
| wrr                         | unicast bandwidth configuration           |
| unicast-bandwidth           | rate in percentage of data rate           |
| __readonly__                | (Optional)                                |
| TABLE_wrr_unicast_bandwidth | (Optional) XML show wrr unicast-bandwidth |
| <i>unicast-bandwidth</i>    | (Optional) unicast bandwidth value        |

### Command Mode

- /exec

# show wwn oui

```
show wwn oui [ __readonly__ [ TABLE_oui <oui> [ <vendor> ] [ <type> ] ] ]
```

## Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| wwn           | show wwn information            |
| oui           | Show oui database               |
| __readonly__  | (Optional) Read Only            |
| TABLE_oui     | (Optional) show wwn oui table   |
| <i>oui</i>    | (Optional) oui of the switch    |
| <i>vendor</i> | (Optional) Switch vendor name   |
| <i>type</i>   | (Optional) Default/Static       |

## Command Mode

- /exec

## show wwn status

```
show wwn status [ { backplane-prom | block-id <i0> | non-volatile-pss | volatile-pss } ] [ __readonly__ [
TABLE_status <type> <configured> <available> <avbl_percent> <resd> <alarm> ] [ <wwn_start> <wwn_end>
<num_of_wwn> <allocated_wwn> <available_wwn> <alloc_status> ] ]
```

### Syntax Description

|                  |   |
|------------------|---|
| show             | Show running system information           |
| wwn              | show wwn information                      |
| status           | Show overall WWN Usage and Alarm Status   |
| backplane-prom   | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| block-id         | (Optional) Enter a block id.              |
| i0               | (Optional) Enter a block id.              |
| non-volatile-pss | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| volatile-pss     | THIS KEYWORD OR VARIABLE IS NOT SUPPORTED |
| __readonly__     | (Optional) Read Only                      |
| TABLE_status     | (Optional) show wwn status table          |
| type             | (Optional) WWN Type                       |
| configured       | (Optional) Number of Configured WWNs      |
| available        | (Optional) Number of Available WWNs       |
| avbl_percent     | (Optional) Available % of WWNs            |
| resd             | (Optional) Reserved WWNs                  |
| alarm            | (Optional) Alarm State                    |
| wwn_start        | (Optional) Start value of WWN-range       |
| wwn_end          | (Optional) End value of WWN-range         |
| num_of_wwn       | (Optional) Total Number of WWNs           |
| allocated_wwn    | (Optional) Number of Allocated WWNs       |
| available_wwn    | (Optional) Number of Available WWNs       |
| alloc_status     | (Optional) Block Allocation Status        |

### Command Mode

- /exec



# show wwn switch

```
show wwn switch [ __readonly__ { <sw_wwn> } ]
```

## Syntax Description

|               |                                 |
|---------------|---------------------------------|
| show          | Show running system information |
| wwn           | show wwn information            |
| switch        | Show switch WWN                 |
| __readonly__  | (Optional) Read Only            |
| <i>sw_wwn</i> | (Optional) The Switch WWN       |

## Command Mode

- /exec

## show wwn test

```
show wwn test { get_swwn_from_pwwn <wwn0> | get_pwwn_from_swwn <wwn1> if_index <i0> |
get_ifindex_from_fwwn <wwn2> | get_ifindex_from_pwwn <wwn3> | validate_pwwn_given_swwn <wwn4>
pwwn <wwn5> | get_all_pwwn_for_slot <i1> | get_kc_type_given_swwn <wwn6> pwwn <wwn7> |
get_ifindex_from_pwwn_swwn <wwn8> pwwn <wwn9> }
```

### Syntax Description

|                          |                                    |
|--------------------------|------------------------------------|
| show                     | show running system information    |
| wwn                      | show wwn information               |
| test                     | show wwn information for testing   |
| get_swwn_from_pwwn       | show switch wwn from port wwn      |
| <i>wwn0</i>              | port wwn                           |
| get_pwwn_from_swwn       | show port wwn from switch wwn      |
| <i>wwn1</i>              | switch wwn                         |
| if_index                 | interface index                    |
| <i>i0</i>                | Interface index                    |
| get_ifindex_from_fwwn    | show ifindex from fabric wwn       |
| <i>wwn2</i>              | fabric wwn                         |
| get_ifindex_from_pwwn    | show ifindex from port wwn         |
| <i>wwn3</i>              | port wwn                           |
| validate_pwwn_given_swwn | validate port wwn for given swwn   |
| <i>wwn4</i>              | switch wwn                         |
| pwwn                     | port wwn                           |
| <i>wwn5</i>              | port wwn                           |
| get_all_pwwn_for_slot    | show all port wwn for a given slot |
| <i>i1</i>                | Slot number                        |
| get_kc_type_given_swwn   | show KC type                       |
| <i>wwn6</i>              | switch wwn                         |
| pwwn                     | port wwn                           |
| <i>wwn7</i>              | port wwn                           |

|                            |                                      |
|----------------------------|--------------------------------------|
| get_ifindex_from_pwwn_swwn | show ifindex for given pwwn and swwn |
| wwn8                       | switch wwn                           |
| pwwn                       | port wwn                             |
| wwn9                       | port wwn                             |

**Command Mode**

- /exec

## show wwn vsan-wwn

```
show wwn vsan-wwn [ __readonly__ [ TABLE_wwnvsan <vsan_id> <wwn_conf> ] ]
```

### Syntax Description

|                 |                                   |
|-----------------|-----------------------------------|
| show            | Show running system information   |
| wwn             | show wwn information              |
| vsan-wwn        | Show all user configured vsan wwn |
| __readonly__    | (Optional) Read Only              |
| TABLE_wwnvsan   | (Optional) vsan-wwn table         |
| <i>vsan_id</i>  | (Optional) VSAN ID                |
| <i>wwn_conf</i> | (Optional) wwn configured by user |

### Command Mode

- /exec



## X Show Commands

---

- [show xml server logging configuration, on page 3496](#)
- [show xml server status, on page 3497](#)

# show xml server logging configuration

show xml server logging configuration

## Syntax Description

|               |  |
|---------------|--|
| show          | Show running system information                    |
| xml           | Show xmlagent logging configuration                |
| server        | xml agent server                                   |
| logging       | Show logging configuration and contents of logfile |
| configuration | Show facility logging configuration                |

## Command Mode

- /exec

## show xml server status

```
show xml server status [ __readonly__ { operational_status <o_status> } { maximum_sessions_configured
<max_session> } [ { TABLE_sessions <session_id> <user_name> <start_time> <sap_id> <timeout>
<time_remaining_to_timeout> <ip_addr> } ] ]
```

### Syntax Description

|                                    |  |
|------------------------------------|--|
| show                               | to display xml agent information         |
| xml                                | xml agent                                |
| server                             | xml agent server                         |
| status                             | display xml agent information            |
| <i>__readonly__</i>                | (Optional)                               |
| <i>operational_status</i>          | (Optional) run-time info about xml       |
| <i>o_status</i>                    | (Optional) operational status of the xml |
| <i>maximum_sessions_configured</i> | (Optional) the max session configured    |
| <i>max_session</i>                 | (Optional) max sessions number           |
| <i>TABLE_sessions</i>              | (Optional) all xml sessions              |
| <i>session_id</i>                  | (Optional) one xml session id            |
| <i>user_name</i>                   | (Optional) the xml session user name     |
| <i>start_time</i>                  | (Optional) the xml session start time    |
| <i>sap_id</i>                      | (Optional) the mts sap id                |
| <i>timeout</i>                     | (Optional) inactivity timeout value      |
| <i>time_remaining_to_timeout</i>   | (Optional) time remaining to timeout     |
| <i>ip_addr</i>                     | (Optional) ip address of the session     |

### Command Mode

- /exec

show xml server status





## Z Show Commands

---

- [show zone-attribute-group, on page 3500](#)
- [show zone, on page 3501](#)
- [show zone active, on page 3502](#)
- [show zone analysis, on page 3503](#)
- [show zone ess, on page 3504](#)
- [show zone member, on page 3505](#)
- [show zone name, on page 3507](#)
- [show zone name active, on page 3508](#)
- [show zone name pending, on page 3509](#)
- [show zone pending-diff, on page 3510](#)
- [show zone pending, on page 3511](#)
- [show zone policy, on page 3512](#)
- [show zone smart-zoning auto-conv log errors, on page 3513](#)
- [show zone smart-zoning auto-conv status vsan, on page 3514](#)
- [show zone statistics, on page 3515](#)
- [show zone statistics vsan, on page 3516](#)
- [show zone status, on page 3517](#)
- [show zone vsan, on page 3518](#)
- [show zone vsan, on page 3519](#)
- [show zoneset, on page 3520](#)

# show zone-attribute-group

```
show zone-attribute-group [ [ name <s0> ] [ [ pending ] [ vsan <i0> ] ] ]
```

## Syntax Description

|                      |  |
|----------------------|--|
| show                 | Show running system information                                      |
| zone-attribute-group | Attribute-group show commands  |
| name                 | (Optional) Show attributes of a specified attribute-group            |
| <i>s0</i>            | (Optional) Enter the name of attr_group                              |
| pending              | (Optional) Show attributes of a specified attribute-group in session |
| vsan                 | (Optional) Show attr_groups belonging to the specified VSAN          |
| <i>i0</i>            | (Optional) VSAN id range   |

## Command Mode

- /exec

# show zone

show zone

## Syntax Description

|      |                                 |
|------|---------------------------------|
| show | Show running system information |
|------|---------------------------------|

## Command Mode

- /exec

# show zone active

show zone active [ vsan <i0> ]

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                       |
| active    | Show zones which are part of active zoneset           |
| vsan      | (Optional) Show zones belonging to the specified VSAN |
| <i>i0</i> | (Optional) VSAN id range                              |

## Command Mode

- /exec

# show zone analysis

show zone analysis [ pending ] { active vsan <i0> | vsan1 <i1> | zoneset <s0> vsan2 <i2> }

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                          |
| analysis  | Show analysis  |
| pending   | (Optional) Show zoneset analysis in the pending database |
| active    | Show active zoneset analysis                             |
| vsan      | Show active zoneset analysis in the specified VSAN       |
| <i>i0</i> | VSAN id range  |
| vsan1     | Show analysis in the specified VSAN                      |
| <i>i1</i> | VSAN id range  |
| zoneset   | Show zoneset analysis                                    |
| <i>s0</i> | Zoneset name   |
| vsan2     | Show zoneset analysis in the specified VSAN              |
| <i>i2</i> | VSAN id range  |

## Command Mode

- /exec

# show zone ess

show zone ess [ vsan <i0> ]

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                          |
| ess       | Show ESS info  |
| vsan      | (Optional) Show ESS info belonging to the specified VSAN |
| <i>i0</i> | (Optional) VSAN id range                                 |

## Command Mode

- /exec

## show zone member

```
show zone member { fcalias <s0> [ [ active ] [ vsan <i0> ] ] | fcid <fcid1> [ [ lun <lun2> ] [ [ active ] [ vsan1
<i3> ] ] ] | pwwn <wwn4> [ [ lun1 <lun5> ] [ [ active ] [ vsan2 <i6> ] ] ] | device-alias <s7> [ [ lun2 <lun8>
] [ [ active ] [ vsan3 <i9> ] ] ] }
```

### Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information   |
| member       | Show all zones in which the given member is part of                     |
| fcalias      | Alias Name  |
| <i>s0</i>    | Enter the name of fcalias   |
| active       | (Optional) Show zones from active database                              |
| vsan         | (Optional) Displays only those zones which belong to the specified VSAN |
| <i>i0</i>    | (Optional) VSAN id range  |
| fcid         | FCID  |
| <i>fcid1</i> | Enter FCID  |
| lun          | (Optional) LUN  |
| <i>lun2</i>  | (Optional) Enter LUN  |
| active       | (Optional) Show zones from active database                              |
| vsan1        | (Optional) Displays only those zones which belong to the specified VSAN |
| <i>i3</i>    | (Optional) VSAN id range  |
| pwwn         | WWN   |
| <i>wwn4</i>  | Enter Port WWN  |
| lun1         | (Optional) LUN  |
| <i>lun5</i>  | (Optional) Enter LUN  |
| active       | (Optional) Show zones from active database                              |
| vsan2        | (Optional) Displays only those zones which belong to the specified VSAN |
| <i>i6</i>    | (Optional) VSAN id range  |
| device-alias | Device-Alias  |

|               |   |
|---------------|---|
| <i>s7</i>     | Enter device-alias  |
| <i>lun2</i>   | (Optional) LUN  |
| <i>lun8</i>   | (Optional) Enter LUN  |
| <i>active</i> | (Optional) Show zones from active database                              |
| <i>vsan3</i>  | (Optional) Displays only those zones which belong to the specified VSAN |
| <i>i9</i>     | (Optional) VSAN id range  |

**Command Mode**

- /exec



# show zone name

show zone name <s0>

## Syntax Description

|      |                                  |
|------|----------------------------------|
| show | Show running system information  |
| name | Show members of a specified zone |
| s0   | Enter the name of zone           |

## Command Mode

- /exec

## show zone name active

show zone name <s0> active [ vsan <i0> ]

### Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                       |
| name      | Show members of a specified zone                      |
| <i>s0</i> | Enter the name of zone                                |
| active    | Show zones which are part of active zoneset           |
| vsan      | (Optional) Show zones belonging to the specified VSAN |
| <i>i0</i> | (Optional) VSAN id range                              |

### Command Mode

- /exec

# show zone name pending

```
show zone name <s0> pending [ { active [ vsan <i0> ] | vsan1 <i1> } ]
```

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                        |
| name      | Show members of a specified zone                       |
| <i>s0</i> | Enter the name of zone                                 |
| pending   | Show members of a specified zone in session            |
| active    | (Optional) Show zones which are part of active zoneset |
| vsan      | (Optional) Show zones belonging to the specified VSAN  |
| <i>i0</i> | (Optional) VSAN id range                               |
| vsan1     | (Optional) Show zones belonging to the specified VSAN  |
| <i>i1</i> | (Optional) VSAN id range                               |

## Command Mode

- /exec

# show zone pending-diff

show zone pending-diff [ vsan <i0> ]

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information                                 |
| pending-diff | Zone Server pending changes                                     |
| vsan         | (Optional) Show pending changes belonging to the specified VSAN |
| <i>i0</i>    | (Optional) VSAN id range  |

## Command Mode

- /exec

# show zone pending

```
show zone pending [ { active [ vsan <i0> ] | vsan1 <i1> } ]
```

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information                        |
| pending   | Show members of a specified zone in session            |
| active    | (Optional) Show zones which are part of active zoneset |
| vsan      | (Optional) Show zones belonging to the specified VSAN  |
| <i>i0</i> | (Optional) VSAN id range                               |
| vsan1     | (Optional) Show zones belonging to the specified VSAN  |
| <i>i1</i> | (Optional) VSAN id range                               |

## Command Mode

- /exec

# show zone policy

show zone policy [ { pending [ vsan <i0> ] | vsan1 <i1> } ]

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                               |
| policy    | Show zone policies  |
| pending   | (Optional) Show zone policies pending                         |
| vsan      | (Optional) Show zone policies pending in specified VSAN       |
| <i>i0</i> | (Optional) VSAN id range                                      |
| vsan1     | (Optional) Show zone policies belonging to the specified VSAN |
| <i>i1</i> | (Optional) VSAN id range                                      |

## Command Mode

- /exec

# show zone smart-zoning auto-conv log errors

show zone smart-zoning auto-conv log errors

## Syntax Description

|              |   |
|--------------|---|
| show         | Show running system information               |
| smart-zoning | Show smart-zoning commands                    |
| auto-conv    | Show auto-convert status                      |
| log          | Show logged messages                          |
| errors       | Show error-logs for smart-zoning auto-convert |

## Command Mode

- /exec

## show zone smart-zoning auto-conv status vsan

show zone smart-zoning auto-conv status vsan <i0>

### Syntax Description

|              |  |
|--------------|--|
| show         | Show running system information              |
| smart-zoning | Show smart-zoning commands                   |
| auto-conv    | Show previous auto-convert status            |
| status       | Show previous auto-convert status            |
| vsan         | Show previous auto-convert status for a VSAN |
| <i>i0</i>    | VSAN id range                                |

### Command Mode

- /exec



# show zone statistics

show zone statistics

## Syntax Description

|            |                                 |
|------------|---------------------------------|
| show       | Show running system information |
| statistics | Show zone server statistics     |

## Command Mode

- /exec

# show zone statistics vsan

show zone statistics vsan <i0>

## Syntax Description

|            |   |
|------------|---|
| show       | Show running system information                 |
| statistics | Show zone server statistics                     |
| vsan       | Show statistics belonging to the specified VSAN |
| <i>i0</i>  | VSAN id range                                   |

## Command Mode

- /exec

# show zone status

```
show zone status [ { vsan <i0> | global } ]
```

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                       |
| status    | Show zone server current status                       |
| vsan      | (Optional) Show zone server current status for a VSAN |
| global    | (Optional) Show zone server global values             |
| <i>i0</i> | (Optional) VSAN id range                              |

## Command Mode

- /exec

# show zone vsan

show zone vsan <i0>

## Syntax Description

|           |  |
|-----------|--|
| show      | Show running system information            |
| vsan      | Show zones belonging to the specified VSAN |
| <i>i0</i> | VSAN id range                              |

## Command Mode

- /exec

# show zone vsan

```
show zone [ name <s0> ] vsan <i0>
```

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information             |
| name      | (Optional) Show members of a specified zone |
| <i>s0</i> | (Optional) Enter the name of zone           |
| vsan      | Show zones belonging to the specified VSAN  |
| <i>i0</i> | VSAN id range                               |

## Command Mode

- /exec

# show zoneset

```
show zoneset [ [ name <s0> ] [ [ pending ] [ [ brief ] [ [ active ] [ vsan <i0> ] ] ] ] ]
```

## Syntax Description

|           |   |
|-----------|---|
| show      | Show running system information                           |
| zoneset   | Zoneset show commands                                     |
| name      | (Optional) Show members of a specified zoneset            |
| <i>s0</i> | (Optional) Enter the name of zoneset                      |
| pending   | (Optional) Show members of a specified zoneset in session |
| brief     | (Optional) Show members in brief mode                     |
| active    | (Optional) Show only active zonesets                      |
| vsan      | (Optional) Show zonesets belonging to the specified VSAN  |
| <i>i0</i> | (Optional) VSAN id range                                  |

## Command Mode

- /exec



## PART II

# XML Support

- [Commands with XML/JSON Support, on page 3523](#)







## Commands with XML/JSON Support

---

- [XML Support for Show Commands, on page 3524](#)

# XML Support for Show Commands

Table 1:

| Show Commands                                      | XML Support |
|--|-------------|
| show aaa accounting                                | yes         |
| show aaa authentication                            | yes         |
| show aaa authentication login                      | yes         |
| show aaa authentication login ascii-authentication | yes         |
| show aaa authentication login error-enable         | yes         |
| show aaa authentication login invalid-username-log | yes         |
| show aaa authorization                             | yes         |
| show aaa bypass-user                               | yes         |
| show aaa client radius statistics                  | yes         |
| show aaa groups                                    | yes         |
| show aaa local user blocked                        | yes         |
| show aaa server radius statistics                  | yes         |
| show aaa user default-role                         | yes         |
| show access-list                                   | yes         |
| show access-list database                          | yes         |
| show access-list resource                          | yes         |
| show access-lists                                  | yes         |
| show accounting log                                | yes         |
| show accounting log all                            | yes         |
| show accounting log last-index                     | yes         |
| show accounting log nvram                          | yes         |
| show accounting log nvram last-index               | yes         |
| show accounting log nvram start-seqnum             | yes         |
| show accounting log start-seqnum                   | yes         |
| show acl status                                    | yes         |

| Show Commands                      | XML Support |
|------------------------------------|-------------|
| show amt process                   | yes         |
| show amt vrf all                   | yes         |
| show archive log config            | yes         |
| show arp access-lists              | yes         |
| show background                    | yes         |
| show banner exec                   | yes         |
| show banner motd                   | yes         |
| show bash-shell                    | yes         |
| show bfd addrmap                   | yes         |
| show bfd clients                   | yes         |
| show bfd discrmap                  | yes         |
| show bfd intfipmap                 | yes         |
| show bfd neighbors                 | yes         |
| show bfd scalar                    | yes         |
| show bfd session                   | yes         |
| show bfd-app session status        | no          |
| show bgp                           | no          |
| show bgp                           | yes         |
| show bgp bmp server                | yes         |
| show bgp community                 | yes         |
| show bgp convergence               | yes         |
| show bgp convergence private       | no          |
| show bgp dampening dampened        | yes         |
| show bgp dampening flap-statistics | yes         |
| show bgp dampening parameters      | yes         |
| show bgp event-history             | no          |
| show bgp evi                       | yes         |
| show bgp extcommunity              | yes         |

| Show Commands                      | XML Support |
|------------------------------------|-------------|
| show bgp l3vpn                     | yes         |
| show bgp neighbors                 | yes         |
| show bgp neighbors commands        | yes         |
| show bgp neighbors flap-statistics | yes         |
| show bgp neighbors paths           | yes         |
| show bgp paths                     | yes         |
| show bgp peer                      | yes         |
| show bgp peer-template             | yes         |
| show bgp prefix-list               | yes         |
| show bgp private                   | no          |
| show bgp private attr              | no          |
| show bgp private damp              | no          |
| show bgp private debug history     | no          |
| show bgp process                   | yes         |
| show bgp received-paths            | yes         |
| show bgp regexp                    | yes         |
| show bgp self-originated           | yes         |
| show bgp sessions                  | yes         |
| show bgp statistics                | yes         |
| show bgp summary                   | yes         |
| show boot                          | yes         |
| show boot auto-copy                | yes         |
| show boot auto-copy list           | yes         |
| show boot current                  | yes         |
| show boot mode                     | yes         |
| show boot order                    | yes         |
| show boot timings                  | no          |
| show boot variables                | yes         |

| Show Commands   | XML Support |
|---|-------------|
| show callhome   | yes         |
| show callhome destination-profile                               | yes         |
| show callhome destination-profile profile                       | yes         |
| show callhome destination-profile profile CiscoTAC-1            | yes         |
| show callhome destination-profile profile full-txt-destination  | yes         |
| show callhome destination-profile profile short-txt-destination | yes         |
| show callhome transport   | yes         |
| show callhome transport-email                                   | yes         |
| show callhome user-def-cmds                                     | yes         |
| show catena   | yes         |
| show catena analytics   | yes         |
| show cdp  | yes         |
| show cdp all  | yes         |
| show cdp global   | yes         |
| show cdp neighbors  | yes         |
| show cdp neighbors detail                                       | yes         |
| show cdp traffic interface2                                     | yes         |
| show cdp traffic interface2 all                                 | yes         |
| show cfs application  | yes         |
| show cfs lock   | yes         |
| show cfs merge status   | yes         |
| show cfs peers  | yes         |
| show cfs regions  | yes         |
| show cfs status   | yes         |
| show checkpoint   | yes         |
| show checkpoint summary   | yes         |
| show class-map  | yes         |
| show class-map type control-plane                               | yes         |

| Show Commands   | XML Support |
|---|-------------|
| show class-map type network-qos                                   | yes         |
| show cli alias  | yes         |
| show cli dynamic integers   | yes         |
| show cli dynamic strings  | yes         |
| show cli dynamic-cmd  | no          |
| show cli history  | no          |
| show cli interface table  | no          |
| show cli list   | no          |
| show cli syntax   | no          |
| show cli variables  | yes         |
| show clock  | yes         |
| show config-profile   | yes         |
| show config-profile applied                                       | yes         |
| show config-replace log exec                                      | yes         |
| show config-replace status  | yes         |
| show config-template  | yes         |
| show configuration session  | yes         |
| show configuration session global-info                            | yes         |
| show configuration session status                                 | yes         |
| show configuration session summary                                | yes         |
| show consistency-checker copp                                     | no          |
| show consistency-checker egress-xlate private-vlan                | no          |
| show consistency-checker fex-interfaces fex                       | no          |
| show consistency-checker forwarding ipv6                          | yes         |
| show consistency-checker forwarding show forwarding inconsistency | yes         |
| show consistency-checker forwarding single-route ipv4 vrf         | no          |
| show consistency-checker gwmacdb                                  | no          |
| show consistency-checker hardware-telemetry inband brief          | no          |

| Show Commands   | XML Support |
|---|-------------|
| show consistency-checker hardware-telemetry postcard brief    | no          |
| show consistency-checker kim                                  | no          |
| show consistency-checker kim interface                        | no          |
| show consistency-checker l2 multicast group source vlan       | no          |
| show consistency-checker l2-tahoe mac-address                 | no          |
| show consistency-checker l2-tahoe module                      | no          |
| show consistency-checker l2-tahoe switchport interface        | no          |
| show consistency-checker l3 multicast source vrf              | no          |
| show consistency-checker l3-interface module                  | no          |
| show consistency-checker link-state fabric-ieth               | no          |
| show consistency-checker link-state module                    | no          |
| show consistency-checker membership port-channels             | no          |
| show consistency-checker membership vlan                      | no          |
| show consistency-checker pacl extended ingress ip interface   | no          |
| show consistency-checker pacl extended ingress ip module      | no          |
| show consistency-checker pacl extended ingress ipv6 interface | no          |
| show consistency-checker pacl extended ingress ipv6 module    | no          |
| show consistency-checker pacl extended ingress mac interface  | no          |
| show consistency-checker pacl extended ingress mac module     | no          |
| show consistency-checker pacl module                          | no          |
| show consistency-checker pacl port-channels                   | no          |
| show consistency-checker port-state                           | no          |
| show consistency-checker port-state fabric-ieth               | no          |
| show consistency-checker racl extended egress ip interface    | no          |
| show consistency-checker racl extended egress ipv6 interface  | no          |
| show consistency-checker racl extended ingress ip interface   | no          |
| show consistency-checker racl extended ingress ip module      | no          |
| show consistency-checker racl extended ingress ipv6 interface | no          |

| Show Commands  | XML Support |
|--|-------------|
| show consistency-checker racl extended ingress ipv6 module | no          |
| show consistency-checker racl module                       | no          |
| show consistency-checker racl port-channels                | no          |
| show consistency-checker racl svi interface                | no          |
| show consistency-checker segment-routing mpls ip mask vrf  | no          |
| show consistency-checker selective-qinq                    | no          |
| show consistency-checker selective-qinq interface          | no          |
| show consistency-checker stp-state vlan                    | no          |
| show consistency-checker vacl                              | no          |
| show consistency-checker vacl extended ingress ip vlan     | no          |
| show consistency-checker vacl extended ingress ipv6 vlan   | no          |
| show consistency-checker vacl extended ingress mac vlan    | no          |
| show consistency-checker vpc                               | no          |
| show consistency-checker vxlan config-check                | no          |
| show consistency-checker vxlan flood_list                  | no          |
| show consistency-checker vxlan infra                       | no          |
| show consistency-checker vxlan l2 module                   | no          |
| show consistency-checker vxlan l3 vrf start                | no          |
| show consistency-checker vxlan mh mac-addresses            | no          |
| show consistency-checker vxlan mh pathlist                 | no          |
| show consistency-checker vxlan pv                          | no          |
| show consistency-checker vxlan qinq-qinvni                 | no          |
| show consistency-checker vxlan selective-qinvni            | no          |
| show consistency-checker vxlan selective-qinvni interface  | no          |
| show consistency-checker vxlan vlan                        | no          |
| show consistency-checker vxlan xconnect                    | no          |
| show controller accounting log                             | no          |
| show copp diff profile profile2                            | no          |



| Show Commands                                 | XML Support |
|---|-------------|
| show copp profile                             | yes         |
| show copp status                              | yes         |
| show copyright                                | yes         |
| show cores                                    | yes         |
| show crypto ca certificates                   | yes         |
| show crypto ca certstore                      | yes         |
| show crypto ca crl                            | yes         |
| show crypto ca remote-certstore               | yes         |
| show crypto ca trustpoints                    | yes         |
| show crypto ca trustpool                      | yes         |
| show crypto ca trustpool last download status | yes         |
| show crypto ca trustpool policy               | yes         |
| show crypto certificatemap                    | yes         |
| show crypto key mypubkey rsa                  | yes         |
| show crypto ssh-auth-map                      | yes         |
| show cts                                      | yes         |
| show current                                  | no          |
| show dampening interface                      | yes         |
| show diagnostic bootup level                  | yes         |
| show diagnostic content module                | yes         |
| show diagnostic description module test all   | yes         |
| show diagnostic events                        | yes         |
| show diagnostic ondemand setting              | yes         |
| show diagnostic result module                 | yes         |
| show diagnostic result module all             | yes         |
| show diagnostic simulation module             | yes         |
| show diagnostic status module                 | yes         |
| show diff rollback-patch                      | yes         |

| Show Commands                                  | XML Support |
|--|-------------|
| show dot1q-tunnel                              | yes         |
| show dot1q-tunnel interface                    | yes         |
| show dot1x                                     | yes         |
| show dot1x all                                 | yes         |
| show dot1x all details                         | yes         |
| show dot1x all statistics                      | yes         |
| show dot1x all summary                         | yes         |
| show dot1x interface                           | yes         |
| show dot1x interface client statistics         | yes         |
| show dot1x interface client statistics address | yes         |
| show dot1x supplicant interface                | no          |
| show ecp                                       | yes         |
| show elam report                               | no          |
| show email                                     | yes         |
| show encryption service stat                   | yes         |
| show environment                               | yes         |
| show errdisable detect                         | yes         |
| show errdisable flap                           | no          |
| show evb                                       | yes         |
| show evb hosts                                 | yes         |
| show evb vsi                                   | yes         |
| show event manager environment                 | yes         |
| show event manager event-types                 | yes         |
| show event manager events action-log           | yes         |
| show event manager history events              | yes         |
| show event manager policy-state                | yes         |
| show event manager script system               | yes         |
| show event manager system-policy               | yes         |

| Show Commands                        | XML Support |
|--------------------------------------|-------------|
| show fabric database dci             | yes         |
| show fabric database host            | yes         |
| show fabric database host statistics | yes         |
| show fabric database host summary    | yes         |
| show fabric database profile-map     | yes         |
| show fabric database static-host     | yes         |
| show fabric database statistics      | yes         |
| show fabric forwarding host-db       | yes         |
| show fabric forwarding ip local      | yes         |
| show fabric forwarding ipv6 local    | yes         |
| show fabric multicast                | yes         |
| show fabric multicast event-history  | no          |
| show fabric multicast globals        | yes         |
| show fabric multicast ipv4 l2 vni    | yes         |
| show fabric multicast ipv4 rp        | no          |
| show fabric multicast statistics     | no          |
| show fabric multicast vrf            | yes         |
| show fc2 bind                        | yes         |
| show fc2 classf                      | yes         |
| show fc2 exchange                    | yes         |
| show fc2 exchresp                    | yes         |
| show fc2 flogi                       | yes         |
| show fc2 nport                       | yes         |
| show fc2 plogi                       | yes         |
| show fc2 plogi_pwwn                  | yes         |
| show fc2 port brief                  | yes         |
| show fc2 port drops                  | yes         |
| show fc2 port state                  | yes         |

| Show Commands                   | XML Support |
|---------------------------------|-------------|
| show fc2 socket                 | yes         |
| show fc2 sockexch               | yes         |
| show fc2 socknotify             | yes         |
| show fc2 socknport              | yes         |
| show fc2 vsan                   | yes         |
| show fcdroplatency              | yes         |
| show fcoe                       | yes         |
| show fcoe database              | yes         |
| show fcoe-npv issu-impact       | yes         |
| show fctimer                    | yes         |
| show fctimer D_S_TOV            | yes         |
| show fctimer E_D_TOV            | yes         |
| show fctimer F_S_TOV            | yes         |
| show fctimer last action status | yes         |
| show fctimer pending            | yes         |
| show fctimer pending-diff       | yes         |
| show fctimer R_A_TOV            | yes         |
| show fctimer session status     | yes         |
| show fctimer status             | yes         |
| show fctimer vsan               | yes         |
| show feature                    | yes         |
| show feature-set                | yes         |
| show feature-set services       | yes         |
| show fhrp                       | yes         |
| show fhrp verbose               | yes         |
| show file                       | yes         |
| show fips status                | yes         |
| show flow cache                 | yes         |

| Show Commands   | XML Support |
|---|-------------|
| show flow exporter  | yes         |
| show flow filter  | yes         |
| show flow interface   | yes         |
| show flow monitor   | yes         |
| show flow profile   | yes         |
| show flow record  | yes         |
| show flow rtp   | yes         |
| show flow rtp timeout   | yes         |
| show flow system  | yes         |
| show flow timeout   | yes         |
| show flow tracer  | yes         |
| show forwarding   | no          |
| show forwarding adjacency   | yes         |
| show forwarding distribution clients                                    | yes         |
| show forwarding distribution fib-state                                  | yes         |
| show forwarding distribution ip igmp snooping                           | yes         |
| show forwarding distribution ipv6 multicast route                       | yes         |
| show forwarding distribution l2 multicast                               | yes         |
| show forwarding distribution lisp counters                              | yes         |
| show forwarding distribution lisp vrf enabled                           | yes         |
| show forwarding distribution multicast                                  | yes         |
| show forwarding distribution multicast client                           | yes         |
| show forwarding distribution multicast client-ack-db                    | yes         |
| show forwarding distribution multicast download                         | no          |
| show forwarding distribution multicast mfib                             | yes         |
| show forwarding distribution multicast outgoing-interface-list          | yes         |
| show forwarding distribution multicast outgoing-interface-list L2_PRIME | yes         |
| show forwarding distribution multicast resp-ack-timer-msgs              | no          |

| Show Commands                                       | XML Support |
|---|-------------|
| show forwarding distribution multicast route        | yes         |
| show forwarding distribution multicast vxlan dsg-db | no          |
| show forwarding distribution nve overlay-vlan       | yes         |
| show forwarding distribution peer-id                | yes         |
| show forwarding distribution trace                  | no          |
| show forwarding ecmp                                | yes         |
| show forwarding ecmp recursive                      | yes         |
| show forwarding interfaces                          | yes         |
| show forwarding ipv6 adjacency                      | yes         |
| show forwarding ipv6 inconsistency                  | yes         |
| show forwarding ipv6 multicast route                | yes         |
| show forwarding ipv6 route                          | yes         |
| show forwarding kvfib cache on                      | no          |
| show forwarding l2 multicast                        | yes         |
| show forwarding l2vpn label vpls                    | yes         |
| show forwarding l2vpn label xconnect                | yes         |
| show forwarding l2vpn vlan                          | yes         |
| show forwarding mpls                                | yes         |
| show forwarding mpls drop-stats                     | yes         |
| show forwarding mpls ecmp                           | yes         |
| show forwarding mpls eompls                         | yes         |
| show forwarding mpls eompls ir                      | yes         |
| show forwarding mpls option_b                       | yes         |
| show forwarding mpls srte module                    | yes         |
| show forwarding mpls summary                        | yes         |
| show forwarding multicast outgoing-interface-list   | yes         |
| show forwarding multicast route                     | yes         |
| show forwarding multicast-sr loopback interface     | yes         |

| Show Commands                                    | XML Support |
|--|-------------|
| show forwarding nve l2 ingress-replication-peers | yes         |
| show forwarding nve l3 adjacency tunnel          | yes         |
| show forwarding nve l3 adjacency v6-tunnel       | yes         |
| show forwarding nve l3 ecmp                      | yes         |
| show forwarding nve l3 peers                     | yes         |
| show forwarding nve underlay-interfaces          | yes         |
| show forwarding otv                              | yes         |
| show forwarding security group-tag               | yes         |
| show forwarding security mac                     | yes         |
| show forwarding trace                            | yes         |
| show forwarding trace profile                    | no          |
| show forwarding trace profile funcstats          | yes         |
| show fte event                                   | yes         |
| show fte exporter                                | yes         |
| show fte monitor                                 | yes         |
| show fte record                                  | yes         |
| show guestshell                                  | yes         |
| show hardware                                    | yes         |
| show hardware access-list lou resource threshold | yes         |
| show hardware access-list resource pooling       | yes         |
| show hardware access-list tcam                   | yes         |
| show hardware capacity                           | no          |
| show hardware capacity eobc                      | yes         |
| show hardware capacity fabric-utilization        | yes         |
| show hardware capacity forwarding                | no          |
| show hardware capacity interface                 | yes         |
| show hardware capacity module                    | yes         |
| show hardware capacity power                     | yes         |

| Show Commands  | XML Support |
|--|-------------|
| show hardware fabricpath mac-learning module   | yes         |
| show hardware feature-capability   | yes         |
| show hardware flow aging   | no          |
| show hardware flow entry address type  | no          |
| show hardware flow etrap   | yes         |
| show hardware flow ip  | no          |
| show hardware flow ipv6  | no          |
| show hardware flow l2  | no          |
| show hardware flow mpls  | no          |
| show hardware flow sampler   | no          |
| show hardware flow utilization   | no          |
| show hardware forwarding interface statistics mode                                   | yes         |
| show hardware forwarding memory health detail  | yes         |
| show hardware forwarding memory health summary                                       | yes         |
| show hardware ip verify  | yes         |
| show hardware profile buffer monitor show hardware profile buffer monitor internal   | yes         |
| show hardware profile forwarding-mode  | no          |
| show hardware profile latency monitor sampling show hardware profile latency monitor | yes         |
| show hardware profile module   | yes         |
| show hardware profile packet-drop  | yes         |
| show hardware profile status   | yes         |
| show hardware profile tcam region  | yes         |
| show hardware qos afd profile  | yes         |
| show hardware qos burst-detect max-records   | yes         |
| show hardware qos eoq stats-class  | yes         |
| show hardware qos include ipg  | yes         |
| show hardware qos ing-pg-hdrm-reserve  | yes         |
| show hardware qos ing-pg-no-min  | yes         |



| Show Commands   | XML Support |
|---|-------------|
| show hardware qos ing-pg-share                        | yes         |
| show hardware qos min-buffer                          | yes         |
| show hardware qos ns-buffer-profile                   | yes         |
| show hardware qos ns-mcq3-alias                       | yes         |
| show hardware rate-limiter                            | yes         |
| show hardware rate-limiter span-egress                | yes         |
| show hardware rl snmp class-id                        | yes         |
| show hardware rl snmp global class-id                 | yes         |
| show hardware rl snmp local snmp-index class-id       | yes         |
| show hostname   | yes         |
| show hosts  | yes         |
| show hsrp   | yes         |
| show hsrp anycast                                     | no          |
| show hsrp anycast interface vlan                      | no          |
| show hsrp anycast remote-db                           | no          |
| show hsrp anycast summary                             | no          |
| show hsrp bfd-sessions                                | yes         |
| show hsrp delay                                       | yes         |
| show hsrp mgo   | yes         |
| show hsrp summary                                     | yes         |
| show icam entries acl module inst                     | yes         |
| show icam health                                      | yes         |
| show icam itd   | yes         |
| show icam prediction entries acl module inst          | yes         |
| show icam prediction resource acl_team mod inst trend | yes         |
| show icam prediction resource module inst             | yes         |
| show icam prediction scale                            | yes         |
| show icam resource module inst                        | yes         |

| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show icam scale                     | yes         |
| show ieth-header-decode             | no          |
| show imp client                     | no          |
| show imp client sa                  | no          |
| show inband-telemetry exporter      | yes         |
| show inband-telemetry flow-profile  | yes         |
| show inband-telemetry monitor       | yes         |
| show inband-telemetry queue-profile | yes         |
| show inband-telemetry record        | yes         |
| show inband-telemetry sessions      | yes         |
| show inband-telemetry watchlist     | yes         |
| show incompatibility system         | yes         |
| show incompatibility-all system     | yes         |
| show install                        | yes         |
| show install all failed-standby     | yes         |
| show install all failure-reason     | yes         |
| show install all impact             | no          |
| show install all impact epld        | yes         |
| show install all status             | no          |
| show install all time-stats         | no          |
| show install epld status            | yes         |
| show install log                    | yes         |
| show install mode                   | yes         |
| show install packages               | yes         |
| show install patches                | yes         |
| show interface                      | yes         |
| show interface bbcredit             | yes         |
| show interface brief                | yes         |

| Show Commands                           | XML Support |
|---|-------------|
| show interface cable-diagnostics-tdr    | yes         |
| show interface capabilities             | yes         |
| show interface counters                 | yes         |
| show interface counters brief           | yes         |
| show interface counters detailed        | yes         |
| show interface counters detailed all    | yes         |
| show interface counters detailed all    | no          |
| show interface counters detailed all    | yes         |
| show interface counters detailed cached | yes         |
| show interface counters details         | yes         |
| show interface counters errors          | yes         |
| show interface counters errors          | no          |
| show interface counters snmp            | yes         |
| show interface counters storm-control   | yes         |
| show interface counters table           | yes         |
| show interface counters table verbose   | yes         |
| show interface counters trunk           | yes         |
| show interface dampening                | yes         |
| show interface debounce                 | yes         |
| show interface description              | yes         |
| show interface detail-counters          | yes         |
| show interface eltm lif-info            | no          |
| show interface fcoe                     | yes         |
| show interface fec                      | yes         |
| show interface flowcontrol              | yes         |
| show interface hardware-mappings        | no          |
| show interface mac-address              | yes         |
| show interface priority-flow-control    | yes         |

| Show Commands                         | XML Support |
|---------------------------------------|-------------|
| show interface private-vlan mapping   | yes         |
| show interface pruning                | yes         |
| show interface snmp-ifindex           | yes         |
| show interface status                 | yes         |
| show interface status err-disabled    | yes         |
| show interface status err-vlans       | yes         |
| show interface switchport             | yes         |
| show interface switchport backup      | yes         |
| show interface transceiver            | yes         |
| show interface transceiver fex-fabric | yes         |
| show interface trunk                  | yes         |
| show interface trunk vsan             | yes         |
| show interface untagged-cos           | yes         |
| show interface vlan mapping           | yes         |
| show inventory                        | yes         |
| show ip adjacency                     | yes         |
| show ip amt relay                     | yes         |
| show ip amt route                     | yes         |
| show ip amt tunnel                    | yes         |
| show ip arp                           | yes         |
| show ip arp anycast topo-info         | yes         |
| show ip arp client                    | yes         |
| show ip arp controller-statistics     | yes         |
| show ip arp esi                       | yes         |
| show ip arp inspection                | yes         |
| show ip arp inspection interfaces     | yes         |
| show ip arp inspection log            | yes         |
| show ip arp inspection statistics     | yes         |

| <b>Show Commands</b>                           | <b>XML Support</b> |
|--|--------------------|
| show ip arp inspection vlan                    | yes                |
| show ip arp l2 statistics interface            | yes                |
| show ip arp multihoming-statistics             | yes                |
| show ip arp off-list                           | yes                |
| show ip arp open-flow error-statistics         | yes                |
| show ip arp statistics                         | yes                |
| show ip arp suppression topo-info              | yes                |
| show ip arp suppression-cache                  | yes                |
| show ip arp tunnel-statistics                  | yes                |
| show ip arp vpc-statistics                     | yes                |
| show ip as-path-access-list                    | yes                |
| show ip client                                 | yes                |
| show ip community-list                         | yes                |
| show ip debug                                  | no                 |
| show ip dhcp global statistics                 | yes                |
| show ip dhcp option82 suboption info interface | yes                |
| show ip dhcp relay                             | yes                |
| show ip dhcp relay address                     | yes                |
| show ip dhcp relay information trusted-sources | yes                |
| show ip dhcp relay statistics                  | yes                |
| show ip dhcp snooping                          | yes                |
| show ip dhcp snooping binding                  | no                 |
| show ip dhcp snooping statistics               | no                 |
| show ip dhcp status                            | yes                |
| show ip dns source-interface                   | yes                |
| show ip dns source-interface vrf all           | yes                |
| show ip eigrp                                  | yes                |
| show ip eigrp accounting                       | yes                |

| Show Commands  | XML Support |
|--|-------------|
| show ip eigrp detail                                       | no          |
| show ip eigrp event-history                                | no          |
| show ip eigrp event-history bfd                            | no          |
| show ip eigrp interfaces                                   | yes         |
| show ip eigrp route-map statistics                         | yes         |
| show ip eigrp traffic                                      | yes         |
| show ip extcommunity-list                                  | yes         |
| show ip fib adjacency                                      | yes         |
| show ip fib distribution                                   | no          |
| show ip fib distribution capture                           | yes         |
| show ip fib distribution clients                           | yes         |
| show ip fib distribution mroute                            | yes         |
| show ip fib distribution multicast                         | yes         |
| show ip fib distribution multicast outgoing-interface-list | yes         |
| show ip fib distribution state                             | yes         |
| show ip ftp source-interface                               | yes         |
| show ip ftp source-interface vrf all                       | yes         |
| show ip http source-interface                              | yes         |
| show ip http source-interface vrf all                      | yes         |
| show ip igmp event-history                                 | no          |
| show ip igmp groups  | yes         |
| show ip igmp interface                                     | yes         |
| show ip igmp local-groups                                  | yes         |
| show ip igmp policy statistics reports                     | yes         |
| show ip igmp snooping                                      | yes         |
| show ip igmp snooping event-history                        | no          |
| show ip igmp snooping explicit-tracking                    | yes         |
| show ip igmp snooping filter details                       | yes         |

| Show Commands                           | XML Support |
|---|-------------|
| show ip igmp snooping groups            | yes         |
| show ip igmp snooping lookup-mode       | yes         |
| show ip igmp snooping mac-oif           | yes         |
| show ip igmp snooping mrouter           | yes         |
| show ip igmp snooping pw vlan brief     | yes         |
| show ip igmp snooping querier           | yes         |
| show ip igmp snooping report statistics | yes         |
| show ip igmp snooping statistics        | yes         |
| show ip igmp vrf all                    | yes         |
| show ip interface                       | yes         |
| show ip lisp                            | no          |
| show ip lisp data-cache                 | no          |
| show ip lisp locator-hash               | no          |
| show ip lisp map-cache                  | no          |
| show ip lisp statistics                 | no          |
| show ip lisp translate-cache            | no          |
| show ip load-sharing                    | yes         |
| show ip local policy                    | yes         |
| show ip logging                         | yes         |
| show ip mbgp                            | no          |
| show ip mbgp community                  | no          |
| show ip mbgp dampening                  | no          |
| show ip mbgp extcommunity               | no          |
| show ip mbgp flap-statistics            | no          |
| show ip mbgp neighbors                  | no          |
| show ip mbgp nexthop                    | no          |
| show ip mbgp nexthop-database           | no          |
| show ip mbgp prefix-list                | no          |

| Show Commands                               | XML Support |
|---|-------------|
| show ip mbgp received-paths                 | no          |
| show ip mroute                              | yes         |
| show ip msdp count                          | yes         |
| show ip msdp event-history                  | no          |
| show ip msdp mesh-group                     | yes         |
| show ip msdp peer                           | yes         |
| show ip msdp policy statistics sa-policy in | yes         |
| show ip msdp rpf                            | yes         |
| show ip msdp sa                             | yes         |
| show ip msdp sources                        | yes         |
| show ip msdp statistics                     | yes         |
| show ip msdp summary                        | yes         |
| show ip nat max                             | yes         |
| show ip nat statistics                      | yes         |
| show ip nat timeout                         | yes         |
| show ip nat translations                    | yes         |
| show ip nat-alias                           | yes         |
| show ip ospf                                | yes         |
| show ip ospf border-routers                 | yes         |
| show ip ospf database                       | yes         |
| show ip ospf database database-summary      | yes         |
| show ip ospf database detail                | yes         |
| show ip ospf event-history                  | no          |
| show ip ospf event-history detail           | no          |
| show ip ospf interface                      | yes         |
| show ip ospf interface brief                | yes         |
| show ip ospf lsa-content-changed-list       | yes         |
| show ip ospf neighbors                      | yes         |



| Show Commands                                 | XML Support |
|---|-------------|
| show ip ospf neighbors detail                 | yes         |
| show ip ospf neighbors summary                | yes         |
| show ip ospf policy statistics                | yes         |
| show ip ospf request-list                     | yes         |
| show ip ospf retransmission-list              | yes         |
| show ip ospf route                            | yes         |
| show ip ospf route summary                    | yes         |
| show ip ospf segment-routing adj-sid-database | yes         |
| show ip ospf segment-routing global-block     | yes         |
| show ip ospf segment-routing sid-database     | yes         |
| show ip ospf sham-links                       | yes         |
| show ip ospf sham-links brief                 | yes         |
| show ip ospf statistics                       | yes         |
| show ip ospf summary-address                  | yes         |
| show ip ospf traffic                          | yes         |
| show ip ospf virtual-links                    | yes         |
| show ip ospf virtual-links brief              | yes         |
| show ip pim config-sanity                     | yes         |
| show ip pim df                                | yes         |
| show ip pim event-history                     | no          |
| show ip pim fabric info                       | yes         |
| show ip pim fabric legacy-vlans               | yes         |
| show ip pim group-range                       | yes         |
| show ip pim host-proxy                        | yes         |
| show ip pim interface                         | yes         |
| show ip pim mdt                               | yes         |
| show ip pim mdt bgp                           | yes         |
| show ip pim mdt history interval              | yes         |

| Show Commands  | XML Support |
|--|-------------|
| show ip pim mdt receive                              | yes         |
| show ip pim mdt send                                 | yes         |
| show ip pim neighbor                                 | yes         |
| show ip pim oif-list                                 | yes         |
| show ip pim policy statistics                        | yes         |
| show ip pim policy statistics jp                     | yes         |
| show ip pim route                                    | yes         |
| show ip pim rp                                       | yes         |
| show ip pim rp-hash                                  | yes         |
| show ip pim statistics                               | yes         |
| show ip pim vrf                                      | yes         |
| show ip ping source-interface                        | yes         |
| show ip ping source-interface vrf all                | yes         |
| show ip policy                                       | yes         |
| show ip prefix-list                                  | yes         |
| show ip process                                      | yes         |
| show ip rip  | yes         |
| show ip rip interface                                | yes         |
| show ip rip neighbor                                 | yes         |
| show ip rip policy statistics redistribute           | yes         |
| show ip rip route                                    | yes         |
| show ip rip statistics                               | yes         |
| show ip route  | yes         |
| show ip rsvp   | yes         |
| show ip sla application                              | yes         |
| show ip sla configuration                            | yes         |
| show ip sla enhanced-history collection-statistics   | yes         |
| show ip sla enhanced-history distribution-statistics | yes         |

| Show Commands                               | XML Support |
|---|-------------|
| show ip sla group schedule                  | yes         |
| show ip sla history                         | yes         |
| show ip sla reaction-configuration          | yes         |
| show ip sla reaction-trigger                | yes         |
| show ip sla responder                       | yes         |
| show ip sla statistics                      | yes         |
| show ip sla twamp connection detail         | yes         |
| show ip sla twamp connection requests       | yes         |
| show ip sla twamp session                   | yes         |
| show ip sla twamp standards                 | yes         |
| show ip ssh source-interface                | yes         |
| show ip ssh source-interface vrf all        | yes         |
| show ip static-route                        | yes         |
| show ip tcp mss                             | yes         |
| show ip telnet source-interface             | yes         |
| show ip telnet source-interface vrf all     | yes         |
| show ip tftp source-interface               | yes         |
| show ip tftp source-interface vrf all       | yes         |
| show ip traceroute source-interface         | yes         |
| show ip traceroute source-interface vrf all | yes         |
| show ip traffic                             | yes         |
| show ip udp relay                           | yes         |
| show ip udp relay interface                 | yes         |
| show ip udp relay object-group              | yes         |
| show ip verify source                       | yes         |
| show ipv6 adjacency                         | yes         |
| show ipv6 adjacency aggregate-prefix        | yes         |
| show ipv6 adjacency subnet-prefix           | yes         |

| Show Commands                        | XML Support |
|--------------------------------------|-------------|
| show ipv6 amt tunnel                 | yes         |
| show ipv6 bgp                        | no          |
| show ipv6 bgp community              | no          |
| show ipv6 bgp dampening              | no          |
| show ipv6 bgp extcommunity           | no          |
| show ipv6 bgp flap-statistics        | no          |
| show ipv6 bgp neighbors              | no          |
| show ipv6 bgp nexthop                | no          |
| show ipv6 bgp nexthop-database       | no          |
| show ipv6 bgp received-paths         | no          |
| show ipv6 bgp regexp                 | no          |
| show ipv6 bgp summary                | no          |
| show ipv6 client                     | yes         |
| show ipv6 dhcp guard policy          | yes         |
| show ipv6 dhcp relay                 | yes         |
| show ipv6 dhcp relay statistics      | yes         |
| show ipv6 eigrp route-map statistics | yes         |
| show ipv6 fragments                  | yes         |
| show ipv6 icmp                       | yes         |
| show ipv6 icmp global traffic        | yes         |
| show ipv6 icmp interface             | yes         |
| show ipv6 icmp l2 statistics         | yes         |
| show ipv6 icmp nd local-proxy stats  | yes         |
| show ipv6 icmp off-list              | yes         |
| show ipv6 icmp vaddr                 | yes         |
| show ipv6 icmp vpc-statistics        | yes         |
| show ipv6 interface                  | yes         |
| show ipv6 lisp data-cache            | no          |

| Show Commands                      | XML Support |
|------------------------------------|-------------|
| show ipv6 local policy             | yes         |
| show ipv6 mld groups               | yes         |
| show ipv6 mld local-groups         | yes         |
| show ipv6 mroute                   | yes         |
| show ipv6 mtu                      | yes         |
| show ipv6 nd ra dns search-list    | yes         |
| show ipv6 nd ra dns server         | yes         |
| show ipv6 nd rguard policy         | yes         |
| show ipv6 neighbor binding         | no          |
| show ipv6 neighbor binding mac     | no          |
| show ipv6 neighbor static          | yes         |
| show ipv6 pim df                   | yes         |
| show ipv6 pim event-history        | no          |
| show ipv6 pim fabric info          | yes         |
| show ipv6 pim fabric legacy-vlans  | yes         |
| show ipv6 pim group-range          | yes         |
| show ipv6 pim interface            | yes         |
| show ipv6 pim neighbor             | yes         |
| show ipv6 pim oif-list             | yes         |
| show ipv6 pim policy statistics jp | yes         |
| show ipv6 pim route                | yes         |
| show ipv6 pim rp                   | yes         |
| show ipv6 pim rp-hash              | yes         |
| show ipv6 pim statistics           | yes         |
| show ipv6 pim vrf                  | yes         |
| show ipv6 policy                   | yes         |
| show ipv6 prefix-list              | yes         |
| show ipv6 process                  | yes         |

| Show Commands                                | XML Support |
|--|-------------|
| show ipv6 rguard statistics                  | yes         |
| show ipv6 rip policy statistics redistribute | yes         |
| show ipv6 route                              | yes         |
| show ipv6 routers                            | yes         |
| show ipv6 snooping capture-policy            | yes         |
| show ipv6 snooping counters vlan             | yes         |
| show ipv6 snooping events                    | yes         |
| show ipv6 snooping features                  | yes         |
| show ipv6 snooping messages                  | yes         |
| show ipv6 snooping policies                  | yes         |
| show ipv6 snooping policy                    | yes         |
| show ipv6 snooping pss database              | yes         |
| show ipv6 static-route                       | yes         |
| show ipv6 traffic                            | yes         |
| show isis                                    | yes         |
| show isis adjacency                          | yes         |
| show isis csnp                               | yes         |
| show isis database                           | yes         |
| show isis distribute-ls                      | yes         |
| show isis dynamic-flooding                   | yes         |
| show isis event-history                      | no          |
| show isis hostname                           | yes         |
| show isis interface                          | yes         |
| show isis ipv6 redistribute route            | yes         |
| show isis ipv6 route                         | yes         |
| show isis ipv6 route-map statistics          | yes         |
| show isis ipv6 summary-address               | yes         |
| show isis lslib                              | no          |

| Show Commands                         | XML Support |
|---------------------------------------|-------------|
| show isis lsp free-list               | no          |
| show isis mesh-group                  | yes         |
| show isis non tlv overflow-list       | no          |
| show isis redistribute route          | yes         |
| show isis route                       | yes         |
| show isis route-map statistics        | yes         |
| show isis rrm                         | yes         |
| show isis segment-routing mapcache    | yes         |
| show isis segment-routing remote-srgb | yes         |
| show isis segment-routing sids        | yes         |
| show isis spf-log                     | yes         |
| show isis srm                         | yes         |
| show isis ssn                         | yes         |
| show isis statistics                  | yes         |
| show isis summary-address             | yes         |
| show isis topology                    | yes         |
| show isis traffic                     | yes         |
| show itd                              | yes         |
| show itd session device-group         | yes         |
| show itd statistics                   | yes         |
| show itd vrf                          | yes         |
| show key chain                        | yes         |
| show key chain mode decrypt           | yes         |
| show keystore                         | yes         |
| show kim inconsistency                | no          |
| show kubernetes containers            | no          |
| show l2 mroute                        | yes         |
| show l2 multicast ftag                | yes         |

| Show Commands                          | XML Support |
|--|-------------|
| show l2 multicast trees                | yes         |
| show l2 route                          | yes         |
| show l2fwder l2rib info                | no          |
| show l2fwder statistics                | no          |
| show l2rib clients                     | yes         |
| show l2rib producers                   | yes         |
| show l2rib registrations               | yes         |
| show l2route cmcast topology           | yes         |
| show l2route evpn ead all              | yes         |
| show l2route evpn ethernet-segment esi | yes         |
| show l2route evpn fl all               | yes         |
| show l2route evpn fl evi               | yes         |
| show l2route evpn imet all             | yes         |
| show l2route evpn imet evi             | yes         |
| show l2route evpn mac all              | yes         |
| show l2route evpn mac evi              | yes         |
| show l2route evpn mac-ip all           | yes         |
| show l2route evpn mac-ip evi           | yes         |
| show l2route evpn path-list all        | yes         |
| show l2route evpn startup-route all    | yes         |
| show l2route evpn startup-route evi    | yes         |
| show l2route fl topology               | yes         |
| show l2route peerid                    | yes         |
| show l2route summary                   | yes         |
| show l2route topology                  | yes         |
| show lacp counters                     | yes         |
| show lacp interface                    | yes         |
| show lacp issu-impact                  | yes         |



| Show Commands                        | XML Support |
|--------------------------------------|-------------|
| show lacp neighbor                   | yes         |
| show lacp port-channel               | yes         |
| show lacp system-identifier          | yes         |
| show lcmd stats interface            | no          |
| show ldap-search-map                 | yes         |
| show ldap-server                     | yes         |
| show ldap-server groups              | yes         |
| show ldap-server statistics          | yes         |
| show license                         | yes         |
| show license brief                   | yes         |
| show license default                 | yes         |
| show license feature package mapping | yes         |
| show license file                    | yes         |
| show license host-id                 | yes         |
| show license tech support            | no          |
| show license usage                   | yes         |
| show line                            | yes         |
| show line console                    | yes         |
| show line console connected          | yes         |
| show line console user-input-string  | yes         |
| show lisp ddt                        | no          |
| show lisp ddt queue                  | no          |
| show lisp ddt referral-cache         | no          |
| show lisp dynamic-eid                | no          |
| show lisp elp                        | no          |
| show lisp negative-prefix            | no          |
| show lisp proxy-itr                  | no          |
| show lisp site                       | no          |

| Show Commands                      | XML Support |
|------------------------------------|-------------|
| show lisp site instance-id         | no          |
| show lldp all                      | yes         |
| show lldp dcbox interface          | yes         |
| show lldp entry                    | yes         |
| show lldp interface                | yes         |
| show lldp neighbors                | yes         |
| show lldp neighbors detail         | yes         |
| show lldp neighbors system-detail  | yes         |
| show lldp portid-subtype           | yes         |
| show lldp timers                   | yes         |
| show lldp tlv-select               | yes         |
| show lldp traffic                  | yes         |
| show lldp traffic interface        | yes         |
| show lldp traffic interface all    | yes         |
| show locator-led status            | yes         |
| show logging                       | no          |
| show logging console               | no          |
| show logging dropcount             | no          |
| show logging info                  | yes         |
| show logging ip access-list cache  | yes         |
| show logging ip access-list status | yes         |
| show logging last                  | no          |
| show logging level                 | yes         |
| show logging level                 | no          |
| show logging level aaa             | no          |
| show logging level acllog          | no          |
| show logging level aclmgr          | no          |
| show logging level adbm            | no          |

| <b>Show Commands</b>                     | <b>XML Support</b> |
|--|--------------------|
| show logging level adjmgr                | no                 |
| show logging level amt                   | no                 |
| show logging level arp                   | no                 |
| show logging level ascii-cfg             | no                 |
| show logging level assoc_mgr             | no                 |
| show logging level backup                | no                 |
| show logging level bfd                   | no                 |
| show logging level bgp                   | no                 |
| show logging level bloggerd              | no                 |
| show logging level bootvar               | no                 |
| show logging level callhome              | no                 |
| show logging level capability            | no                 |
| show logging level catena                | no                 |
| show logging level cdp                   | no                 |
| show logging level cert_enroll           | no                 |
| show logging level cfs                   | no                 |
| show logging level clis                  | no                 |
| show logging level clk_mgr               | no                 |
| show logging level confcheck             | no                 |
| show logging level copp                  | no                 |
| show logging level core                  | no                 |
| show logging level cts                   | no                 |
| show logging level dhcp_snoop            | no                 |
| show logging level diagnostic diagclient | no                 |
| show logging level diagnostic diagmgr    | no                 |
| show logging level dot1x                 | no                 |
| show logging level ecp                   | no                 |
| show logging level eigrp                 | no                 |

| Show Commands                           | XML Support |
|---|-------------|
| show logging level eltm                 | no          |
| show logging level epp                  | no          |
| show logging level ethdstats            | no          |
| show logging level ethpm                | no          |
| show logging level evb                  | no          |
| show logging level evmc                 | no          |
| show logging level evmed                | no          |
| show logging level evms                 | no          |
| show logging level fabric forwarding    | no          |
| show logging level fabricpath isis      | no          |
| show logging level fabricpath switch-id | no          |
| show logging level fcoe_mgr             | no          |
| show logging level feature-mgr          | no          |
| show logging level fs-daemon            | no          |
| show logging level gpixm                | no          |
| show logging level hardware-telemetry   | no          |
| show logging level hsrp                 | no          |
| show logging level icam                 | no          |
| show logging level im                   | no          |
| show logging level imp                  | no          |
| show logging level interface-vlan       | no          |
| show logging level ip igmp              | no          |
| show logging level ip msdp              | no          |
| show logging level ip sla responder     | no          |
| show logging level ip sla sender        | no          |
| show logging level ip sla twamp-server  | no          |
| show logging level ipconf               | no          |
| show logging level ipfib                | no          |

| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show logging level ipqos            | no          |
| show logging level ipv6 icmp        | no          |
| show logging level iscm             | no          |
| show logging level isis             | no          |
| show logging level keystore         | no          |
| show logging level l2fm             | no          |
| show logging level l3vm             | no          |
| show logging level lacp             | no          |
| show logging level ldap             | no          |
| show logging level license          | no          |
| show logging level lim              | no          |
| show logging level lisp             | no          |
| show logging level lldp             | no          |
| show logging level m2rib            | no          |
| show logging level mfdm             | no          |
| show logging level mfw              | no          |
| show logging level mmode            | no          |
| show logging level module           | no          |
| show logging level monitor          | no          |
| show logging level mpls ldp         | no          |
| show logging level mpls manager     | no          |
| show logging level mpls switching   | no          |
| show logging level mpls traffic-eng | no          |
| show logging level mvsh             | no          |
| show logging level nat              | no          |
| show logging level nbm              | no          |
| show logging level netstack         | no          |
| show logging level nfm              | no          |

| Show Commands                     | XML Support |
|-----------------------------------|-------------|
| show logging level ngmvpn         | no          |
| show logging level ngoam          | no          |
| show logging level npv            | no          |
| show logging level ntp            | no          |
| show logging level nve            | no          |
| show logging level nxsdk          | no          |
| show logging level openflow       | no          |
| show logging level ospf           | no          |
| show logging level ospfv3         | no          |
| show logging level otv            | no          |
| show logging level pfstat         | no          |
| show logging level pim            | no          |
| show logging level pixm           | no          |
| show logging level pktmgr         | no          |
| show logging level platform       | no          |
| show logging level plbm           | no          |
| show logging level plcmgr         | no          |
| show logging level pltfm_config   | no          |
| show logging level plugin         | no          |
| show logging level poap           | no          |
| show logging level poed           | no          |
| show logging level port           | no          |
| show logging level port-channel   | no          |
| show logging level port-profile   | no          |
| show logging level port-resources | no          |
| show logging level port-security  | no          |
| show logging level private-vlan   | no          |
| show logging level ptp            | no          |

| Show Commands                             | XML Support |
|---|-------------|
| show logging level radius                 | no          |
| show logging level res_mgr                | no          |
| show logging level rip                    | no          |
| show logging level routing ipv6 multicast | no          |
| show logging level routing multicast      | no          |
| show logging level rpm                    | no          |
| show logging level rsvp                   | no          |
| show logging level sal                    | no          |
| show logging level san-port-channel       | no          |
| show logging level scheduler              | no          |
| show logging level security               | no          |
| show logging level segment-routing        | no          |
| show logging level session-mgr            | no          |
| show logging level sflow                  | no          |
| show logging level smartc                 | no          |
| show logging level smm                    | no          |
| show logging level snmpd                  | no          |
| show logging level snmpmib_proc           | no          |
| show logging level spanning-tree          | no          |
| show logging level spm                    | no          |
| show logging level stripcl                | no          |
| show logging level sysmgr                 | no          |
| show logging level tacacs                 | no          |
| show logging level telemetry              | no          |
| show logging level template_manager       | no          |
| show logging level track                  | no          |
| show logging level tunnel                 | no          |
| show logging level u2rib                  | no          |

| Show Commands                      | XML Support |
|------------------------------------|-------------|
| show logging level u6rib           | no          |
| show logging level udld            | no          |
| show logging level ufdm            | no          |
| show logging level urib            | no          |
| show logging level vdc_mgr         | no          |
| show logging level virtual-service | no          |
| show logging level vlan_mgr        | no          |
| show logging level vmm             | no          |
| show logging level vmtracker       | no          |
| show logging level vpc             | no          |
| show logging level vrrp-cfg        | no          |
| show logging level vrrp-eng        | no          |
| show logging level vrrpv3          | no          |
| show logging level vsan            | no          |
| show logging level vshd            | no          |
| show logging level vtp             | no          |
| show logging level wwn             | no          |
| show logging level xbar            | no          |
| show logging logfile               | no          |
| show logging logfile duration      | no          |
| show logging logfile last-index    | no          |
| show logging logfile start-seqn    | no          |
| show logging logfile start-time    | no          |
| show logging loopback              | no          |
| show logging module                | no          |
| show logging monitor               | no          |
| show logging nvram                 | yes         |
| show logging onboard               | no          |



| Show Commands                                | XML Support |
|--|-------------|
| show logging onboard kernel-trace            | no          |
| show logging origin-id                       | no          |
| show logging pending                         | no          |
| show logging pending-diff                    | no          |
| show logging rate-limit                      | no          |
| show logging rfc-strict                      | no          |
| show logging server                          | yes         |
| show logging session status                  | no          |
| show logging source-interface                | no          |
| show logging status                          | no          |
| show logging timestamp                       | no          |
| show login on-failure log                    | yes         |
| show login on-successful log                 | yes         |
| show mac address-table                       | yes         |
| show mac address-table aging-time            | yes         |
| show mac address-table count                 | yes         |
| show mac address-table count es              | yes         |
| show mac address-table learning-mode         | yes         |
| show mac address-table limit                 | yes         |
| show mac address-table limit user-defined    | yes         |
| show mac address-table loop-detect           | yes         |
| show mac address-table multicast             | yes         |
| show mac address-table notification mac-move | yes         |
| show mac scalar                              | yes         |
| show mac-list                                | yes         |
| show macsec mka                              | yes         |
| show macsec mka session                      | yes         |
| show macsec mka statistics                   | yes         |

| Show Commands                            | XML Support |
|--|-------------|
| show macsec policy                       | yes         |
| show macsec secy statistics              | yes         |
| show maintenance maint-delay             | yes         |
| show maintenance on-reload reset-reasons | yes         |
| show maintenance profile                 | yes         |
| show maintenance snapshot-delay          | yes         |
| show maintenance timeout                 | yes         |
| show module                              | yes         |
| show module bandwidth-fairness           | yes         |
| show module uptime                       | yes         |
| show monitor                             | yes         |
| show monitor session                     | yes         |
| show mpls extended-ecmp                  | no          |
| show mpls forwarding statistics          | yes         |
| show mpls interfaces                     | yes         |
| show mpls interfaces detail              | yes         |
| show mpls interfaces statistics          | yes         |
| show mpls ip bindings                    | yes         |
| show mpls ip bindings summary            | yes         |
| show mpls ip ttl                         | yes         |
| show mpls label range                    | yes         |
| show mpls load-sharing                   | yes         |
| show mpls oam echo statistics            | yes         |
| show mpls static binding                 | yes         |
| show mpls static trace                   | no          |
| show mpls strip labels                   | yes         |
| show mpls switching                      | yes         |
| show mpls switching clients              | yes         |

| Show Commands                         | XML Support |
|---------------------------------------|-------------|
| show mvpn bgp mdt                     | yes         |
| show mvpn mdt encap                   | yes         |
| show mvpn mdt route                   | yes         |
| show mvr groups                       | yes         |
| show mvr interface                    | yes         |
| show mvr members                      | yes         |
| show mvr members count                | yes         |
| show mvr members vlan                 | yes         |
| show mvr receiver-ports               | yes         |
| show mvr source-ports                 | yes         |
| show nat itd                          | yes         |
| show nbm defaults                     | yes         |
| show nbm flow-policy                  | yes         |
| show nbm flows                        | yes         |
| show nbm flows static                 | yes         |
| show nbm flows statistics             | yes         |
| show nbm flows summary                | yes         |
| show nbm host-policy all              | yes         |
| show nbm host-policy applied receiver | yes         |
| show nbm host-policy applied sender   | yes         |
| show nbm interface bandwidth          | yes         |
| show ngoam interface statistics       | yes         |
| show ngoam loopback                   | yes         |
| show ngoam mct-stats                  | yes         |
| show ngoam pathtrace                  | yes         |
| show ngoam probe                      | yes         |
| show ngoam traceroute statistics      | yes         |
| show ngoam xconnect session           | yes         |

| Show Commands                     | XML Support |
|-----------------------------------|-------------|
| show npv external-interface-usage | yes         |
| show npv flogi-table              | yes         |
| show npv status                   | yes         |
| show npv traffic-map              | yes         |
| show ntp access-groups            | yes         |
| show ntp authentication-keys      | yes         |
| show ntp authentication-status    | yes         |
| show ntp information              | yes         |
| show ntp logging-status           | yes         |
| show ntp peer-status              | yes         |
| show ntp peers                    | yes         |
| show ntp rts-update               | yes         |
| show ntp session status           | yes         |
| show ntp source                   | yes         |
| show ntp source-interface         | yes         |
| show ntp statistics               | yes         |
| show ntp status                   | yes         |
| show ntp trusted-keys             | yes         |
| show nve adjacency mpls           | yes         |
| show nve bfd neighbors            | yes         |
| show nve core-links               | yes         |
| show nve ethernet-segment         | yes         |
| show nve evi                      | yes         |
| show nve interface                | yes         |
| show nve mpls                     | yes         |
| show nve multisite dci-links      | yes         |
| show nve multisite fabric-links   | yes         |
| show nve peers                    | yes         |

| Show Commands                         | XML Support |
|---------------------------------------|-------------|
| show nve peers interface counters     | yes         |
| show nve peers mpls                   | yes         |
| show nve peers vni interface counters | yes         |
| show nve replication-servers          | yes         |
| show nve vni                          | yes         |
| show nve vni counters                 | yes         |
| show nve vni ingress-replication      | yes         |
| show nve vni peer-vtep                | yes         |
| show nve vrf                          | yes         |
| show nve vxlan-params                 | yes         |
| show nxapi                            | yes         |
| show nxapi syntax                     | no          |
| show nxapi-server logs                | no          |
| show object-group                     | yes         |
| show openflow hardware capabilities   | no          |
| show openflow switch                  | yes         |
| show openflow switch flows            | no          |
| show ospfv3                           | yes         |
| show ospfv3 border-routers            | yes         |
| show ospfv3 database                  | yes         |
| show ospfv3 database database-summary | yes         |
| show ospfv3 database detail           | yes         |
| show ospfv3 event-history             | no          |
| show ospfv3 event-history detail      | no          |
| show ospfv3 interface                 | yes         |
| show ospfv3 interface brief           | yes         |
| show ospfv3 neighbors                 | yes         |
| show ospfv3 neighbors detail          | yes         |

| Show Commands                   | XML Support |
|---------------------------------|-------------|
| show ospfv3 neighbors summary   | yes         |
| show ospfv3 policy statistics   | no          |
| show ospfv3 request-list        | yes         |
| show ospfv3 retransmission-list | yes         |
| show ospfv3 route               | yes         |
| show ospfv3 route summary       | yes         |
| show ospfv3 statistics          | yes         |
| show ospfv3 summary-address     | yes         |
| show ospfv3 traffic             | yes         |
| show ospfv3 virtual-links       | yes         |
| show ospfv3 virtual-links brief | yes         |
| show otv                        | no          |
| show param-list                 | yes         |
| show password secure-mode       | yes         |
| show password strength-check    | yes         |
| show plb                        | yes         |
| show plb analytics              | yes         |
| show plb vrf                    | yes         |
| show pmap-int                   | no          |
| show pmap-int-br interface br   | yes         |
| show pnp lease                  | no          |
| show pnp posix_pi configs       | no          |
| show pnp posix_pi tech-support  | no          |
| show pnp profiles               | no          |
| show pnp status                 | no          |
| show pnp summary                | no          |
| show pnp version                | no          |
| show policy-map                 | yes         |

| Show Commands  | XML Support |
|--|-------------|
| show policy-map interface control-plane                                  | yes         |
| show policy-map system   | yes         |
| show policy-map type control-plane                                       | yes         |
| show policy-map type network-qos   | yes         |
| show port naming   | no          |
| show port-channel capacity   | yes         |
| show port-channel compatibility-parameters                               | yes         |
| show port-channel database   | yes         |
| show port-channel fast-convergence                                       | yes         |
| show port-channel load-balance   | yes         |
| show port-channel load-balance forwarding-path interface                 | yes         |
| show port-channel load-balance forwarding-path1 interface src-interface  | yes         |
| show port-channel load-balance hardware forwarding-path interface source | yes         |
| show port-channel rbh-distribution                                       | yes         |
| show port-channel scale-fanout   | yes         |
| show port-channel summary  | yes         |
| show port-channel traffic  | yes         |
| show port-channel usage  | yes         |
| show port-license  | yes         |
| show port-profile  | yes         |
| show port-profile brief  | yes         |
| show port-profile expand-interface                                       | yes         |
| show port-profile sync-status  | yes         |
| show port-profile usage  | yes         |
| show port-security   | yes         |
| show port-security address   | yes         |
| show port-security address interface                                     | yes         |
| show port-security interface   | yes         |

| Show Commands                         | XML Support |
|---------------------------------------|-------------|
| show port-security state              | yes         |
| show postcard-telemetry exporter      | yes         |
| show postcard-telemetry flow-profile  | yes         |
| show postcard-telemetry monitor       | yes         |
| show postcard-telemetry queue-profile | yes         |
| show postcard-telemetry sessions      | yes         |
| show postcard-telemetry watchlist     | yes         |
| show power inline                     | yes         |
| show power inline police              | yes         |
| show power inline priority            | yes         |
| show privilege                        | yes         |
| show processes                        | yes         |
| show processes cpu                    | yes         |
| show processes cpu history            | no          |
| show processes cpu history data       | yes         |
| show processes cpu module             | yes         |
| show processes log                    | yes         |
| show processes log details            | yes         |
| show processes log pid                | yes         |
| show processes log vdc-all            | yes         |
| show processes memory                 | yes         |
| show processes memory physical        | yes         |
| show processes memory shared          | yes         |
| show processes vdc                    | yes         |
| show processes vdc cpu                | yes         |
| show processes vdc log                | yes         |
| show processes vdc log details        | no          |
| show processes vdc log pid            | no          |



| Show Commands  | XML Support |
|--|-------------|
| show processes vdc memory  | yes         |
| show processes version   | yes         |
| show pss debug   | no          |
| show ptp brief   | yes         |
| show ptp clock   | yes         |
| show ptp clock foreign-masters record                              | yes         |
| show ptp corrections   | yes         |
| show ptp cost  | yes         |
| show ptp counters interface  | yes         |
| show ptp delay summary   | yes         |
| show ptp domain data   | yes         |
| show ptp interface domain  | yes         |
| show ptp packet-trace  | yes         |
| show ptp parent  | yes         |
| show ptp port interface  | yes         |
| show ptp time-property   | yes         |
| show qos dcbxp incompatibility interface                           | yes         |
| show qos dcbxp info  | yes         |
| show qos dcbxp interface   | yes         |
| show qos shared-policer  | yes         |
| show queuing   | yes         |
| show queuing burst-detect  | yes         |
| show queuing pfc-queue   | yes         |
| show queuing pfc-queue interface snmp watchdogIfQueueTable ifIndex | yes         |
| show queuing pfc-queue snmp ifIndex                                | yes         |
| show queuing tabular   | yes         |
| show queuing tah-pfc-queue   | yes         |
| show radius status   | yes         |

| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show radius-cfs                     | yes         |
| show radius-server                  | yes         |
| show radius-server directed-request | yes         |
| show radius-server groups           | yes         |
| show radius-server sorted           | yes         |
| show radius-server statistics       | yes         |
| show redundancy status              | yes         |
| show regexp                         | no          |
| show reload                         | yes         |
| show resource                       | yes         |
| show rmon                           | yes         |
| show role                           | yes         |
| show role feature                   | yes         |
| show role feature-group             | yes         |
| show rollback log exec              | yes         |
| show rollback status                | yes         |
| show route-map                      | yes         |
| show route-map pbr-statistics       | yes         |
| show router-guard                   | yes         |
| show routing                        | yes         |
| show routing clients                | yes         |
| show routing event-history          | no          |
| show routing hash                   | yes         |
| show routing hidden-nh              | yes         |
| show routing ipv6                   | yes         |
| show routing ipv6 clients           | yes         |
| show routing ipv6 event-history     | no          |
| show routing ipv6 hash              | yes         |

| Show Commands                               | XML Support |
|---|-------------|
| show routing ipv6 hidden-nh                 | yes         |
| show routing ipv6 memory estimate           | yes         |
| show routing ipv6 memory statistics         | yes         |
| show routing ipv6 multicast                 | yes         |
| show routing ipv6 multicast clients         | yes         |
| show routing ipv6 multicast event-history   | no          |
| show routing ipv6 multicast memory estimate | yes         |
| show routing ipv6 nexthop info              | no          |
| show routing ipv6 nhlfe                     | yes         |
| show routing ipv6 recursive-next-hop        | yes         |
| show routing memory estimate                | yes         |
| show routing memory statistics              | yes         |
| show routing multicast                      | yes         |
| show routing multicast clients              | yes         |
| show routing multicast event-history        | no          |
| show routing multicast lisp encap           | yes         |
| show routing multicast mdt encapsulation    | yes         |
| show routing multicast memory estimate      | yes         |
| show routing multicast sr                   | yes         |
| show routing nhlfe                          | yes         |
| show routing recursive-next-hop             | yes         |
| show routing unresolved-next-hop            | no          |
| show routing vxlan-hash peer-ip             | no          |
| show routing vxlan-hash peer-ipv6           | no          |
| show routing-context                        | yes         |
| show running-config                         | no          |
| show running-config aaa                     | no          |
| show running-config aclog                   | no          |

| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show running-config aclmgr          | no          |
| show running-config aclmgr active   | no          |
| show running-config adjmgr          | no          |
| show running-config all             | no          |
| show running-config analytics       | no          |
| show running-config arp             | no          |
| show running-config assoc           | no          |
| show running-config backup          | no          |
| show running-config bfd             | no          |
| show running-config bgp             | no          |
| show running-config bloggerd        | no          |
| show running-config callhome        | no          |
| show running-config catena          | no          |
| show running-config cdp             | no          |
| show running-config cert-enroll     | no          |
| show running-config cfs             | no          |
| show running-config clock_manager   | no          |
| show running-config config-profile  | no          |
| show running-config config-template | no          |
| show running-config controller      | no          |
| show running-config copp            | no          |
| show running-config dhcp            | no          |
| show running-config diagnostic      | no          |
| show running-config diff            | no          |
| show running-config dot1x           | no          |
| show running-config ecp             | no          |
| show running-config eem             | no          |
| show running-config eigrp           | no          |

| Show Commands                                 | XML Support |
|---|-------------|
| show running-config eltm                      | no          |
| show running-config evb                       | no          |
| show running-config exclude fabricpath        | no          |
| show running-config expand-port-profile       | no          |
| show running-config fabric forwarding         | no          |
| show running-config fabric multicast          | no          |
| show running-config fabricpath                | no          |
| show running-config fabricpath domain default | no          |
| show running-config fabricpath switch-id      | no          |
| show running-config fabricpath topology       | no          |
| show running-config fcoe_mgr                  | no          |
| show running-config hardware-telemetry        | no          |
| show running-config hsrp                      | no          |
| show running-config icam                      | no          |
| show running-config icmpv6                    | no          |
| show running-config igmp                      | no          |
| show running-config imp                       | no          |
| show running-config interface                 | no          |
| show running-config interface explicit        | no          |
| show running-config ip                        | no          |
| show running-config ipqos                     | no          |
| show running-config ipqos active              | no          |
| show running-config ipv6                      | no          |
| show running-config isis                      | no          |
| show running-config l3vm                      | no          |
| show running-config ldap                      | no          |
| show running-config license                   | no          |
| show running-config lisp                      | no          |

| Show Commands                        | XML Support |
|--------------------------------------|-------------|
| show running-config lldp             | no          |
| show running-config macsec           | no          |
| show running-config mmode            | no          |
| show running-config monitor          | no          |
| show running-config mpls ldp         | no          |
| show running-config mpls static      | no          |
| show running-config mpls strip       | no          |
| show running-config mpls traffic-eng | no          |
| show running-config msdp             | no          |
| show running-config mts              | no          |
| show running-config nat              | no          |
| show running-config nbm              | no          |
| show running-config netflow          | no          |
| show running-config ngoam            | no          |
| show running-config ntp              | no          |
| show running-config nv overlay       | no          |
| show running-config nxsdk            | no          |
| show running-config openflow         | no          |
| show running-config ospf             | no          |
| show running-config ospfv3           | no          |
| show running-config otn              | no          |
| show running-config otn-isis         | no          |
| show running-config param-list       | no          |
| show running-config pim              | no          |
| show running-config pim6             | no          |
| show running-config plb-services     | no          |
| show running-config poe              | no          |
| show running-config port-profile     | no          |

| Show Commands                              | XML Support |
|--|-------------|
| show running-config port-security          | no          |
| show running-config ptp                    | no          |
| show running-config radius                 | no          |
| show running-config rip                    | no          |
| show running-config routing ip multicast   | no          |
| show running-config routing ipv6 multicast | no          |
| show running-config rpm                    | no          |
| show running-config rsvp                   | no          |
| show running-config scheduler              | no          |
| show running-config section                | no          |
| show running-config security               | no          |
| show running-config segment-routing        | no          |
| show running-config services               | no          |
| show running-config sflow                  | no          |
| show running-config sla responder          | no          |
| show running-config sla sender             | no          |
| show running-config sla twamp-server       | no          |
| show running-config smart-channel          | no          |
| show running-config snmp                   | no          |
| show running-config spanning-tree          | no          |
| show running-config srte                   | no          |
| show running-config switch                 | no          |
| show running-config tacacs                 | no          |
| show running-config telemetry              | no          |
| show running-config track                  | no          |
| show running-config udd                    | no          |
| show running-config vdc                    | no          |
| show running-config vdc-all                | no          |

| Show Commands   | XML Support |
|---|-------------|
| show running-config virtual-service                     | no          |
| show running-config vlan                                | no          |
| show running-config vmtracker                           | no          |
| show running-config vpc                                 | no          |
| show running-config vrf                                 | no          |
| show running-config vrf default                         | no          |
| show running-config vrrp                                | no          |
| show running-config vrrpv3                              | no          |
| show running-config vshd                                | no          |
| show running-config vtp                                 | no          |
| show running-config wwnm                                | no          |
| show san-port-channel compatibility-parameters          | yes         |
| show san-port-channel consistency                       | yes         |
| show san-port-channel consistency detail                | yes         |
| show san-port-channel database                          | yes         |
| show san-port-channel summary                           | yes         |
| show san-port-channel usage                             | yes         |
| show scheduler config                                   | yes         |
| show scheduler job                                      | yes         |
| show scheduler logfile                                  | yes         |
| show scheduler schedule                                 | yes         |
| show segment-routing                                    | yes         |
| show segment-routing clients                            | yes         |
| show segment-routing ipv4 connected-prefix-sid-map      | yes         |
| show segment-routing mpls                               | yes         |
| show segment-routing mpls clients                       | yes         |
| show segment-routing mpls ipv4 connected-prefix-sid-map | yes         |
| show sflow  | yes         |



| <b>Show Commands</b>              | <b>XML Support</b> |
|-----------------------------------|--------------------|
| show sflow statistics             | yes                |
| show smart-channel                | yes                |
| show snapshots                    | yes                |
| show snapshots compare            | yes                |
| show snapshots compare ipv4routes | yes                |
| show snapshots compare ipv6routes | yes                |
| show snapshots compare summary    | yes                |
| show snapshots dump               | yes                |
| show snapshots sections           | yes                |
| show snmp                         | yes                |
| show snmp community               | yes                |
| show snmp context                 | yes                |
| show snmp engineID                | yes                |
| show snmp group                   | yes                |
| show snmp host                    | yes                |
| show snmp nms-statistics          | yes                |
| show snmp oid-statistics          | yes                |
| show snmp pss                     | no                 |
| show snmp roledebug               | no                 |
| show snmp sessions                | yes                |
| show snmp source-interface        | yes                |
| show snmp trap                    | yes                |
| show snmp user                    | yes                |
| show sockets client               | yes                |
| show sockets connection           | yes                |
| show sockets local-port-range     | yes                |
| show sockets ns-port-kiosk        | yes                |
| show sockets statistics           | yes                |

| Show Commands                               | XML Support |
|---|-------------|
| show sockets tcp keychain binding           | yes         |
| show spanning-tree                          | yes         |
| show spanning-tree blockedports             | yes         |
| show spanning-tree bridge                   | yes         |
| show spanning-tree inconsistentports        | yes         |
| show spanning-tree interface                | yes         |
| show spanning-tree issu-impact              | yes         |
| show spanning-tree mst                      | yes         |
| show spanning-tree mst configuration        | yes         |
| show spanning-tree mst configuration digest | yes         |
| show spanning-tree mst interface            | yes         |
| show spanning-tree pathcost method          | yes         |
| show spanning-tree root                     | yes         |
| show spanning-tree summary                  | yes         |
| show spanning-tree summary totals           | yes         |
| show sprom                                  | yes         |
| show srte pce ipv4 peer                     | yes         |
| show srte policy                            | yes         |
| show srte policy fh                         | yes         |
| show ssh key                                | yes         |
| show ssh server                             | yes         |
| show ssx details                            | yes         |
| show ssx exporter                           | yes         |
| show ssx monitor                            | yes         |
| show ssx record                             | yes         |
| show startup-config                         | no          |
| show startup-config aaa                     | no          |
| show startup-config aclog                   | no          |

| Show Commands                           | XML Support |
|---|-------------|
| show startup-config aclmgr              | no          |
| show startup-config adjmgr              | no          |
| show startup-config analytics           | no          |
| show startup-config arp                 | no          |
| show startup-config assoc               | no          |
| show startup-config backup              | no          |
| show startup-config bfd                 | no          |
| show startup-config bgp                 | no          |
| show startup-config bloggerd            | no          |
| show startup-config callhome            | no          |
| show startup-config catena              | no          |
| show startup-config cdp                 | no          |
| show startup-config cert-enroll         | no          |
| show startup-config cfs                 | no          |
| show startup-config config-profile      | no          |
| show startup-config copp                | no          |
| show startup-config dhcp                | no          |
| show startup-config diagnostic          | no          |
| show startup-config dot1x               | no          |
| show startup-config ecp                 | no          |
| show startup-config eem                 | no          |
| show startup-config eigrp               | no          |
| show startup-config eltm                | no          |
| show startup-config evb                 | no          |
| show startup-config exclude             | no          |
| show startup-config expand-port-profile | no          |
| show startup-config fabric forwarding   | no          |
| show startup-config fabric multicast    | no          |

| Show Commands                                 | XML Support |
|---|-------------|
| show startup-config fabricpath                | no          |
| show startup-config fabricpath domain default | no          |
| show startup-config fabricpath switch-id      | no          |
| show startup-config fabricpath topology       | no          |
| show startup-config fcoe_mgr                  | no          |
| show startup-config glbp                      | no          |
| show startup-config hardware-telemetry        | no          |
| show startup-config hsrp                      | no          |
| show startup-config icam                      | no          |
| show startup-config icmpv6                    | no          |
| show startup-config igmp                      | no          |
| show startup-config imp                       | no          |
| show startup-config interface                 | no          |
| show startup-config ip                        | no          |
| show startup-config ipqos                     | no          |
| show startup-config ipv6                      | no          |
| show startup-config isis                      | no          |
| show startup-config l3vm                      | no          |
| show startup-config ldap                      | no          |
| show startup-config license                   | no          |
| show startup-config lisp                      | no          |
| show startup-config lldp                      | no          |
| show startup-config log                       | no          |
| show startup-config macsec                    | no          |
| show startup-config mmode                     | no          |
| show startup-config monitor                   | no          |
| show startup-config mpls ldp                  | no          |
| show startup-config mpls static               | no          |

| Show Commands                              | XML Support |
|--|-------------|
| show startup-config mpls strip             | no          |
| show startup-config mpls traffic-eng       | no          |
| show startup-config msdp                   | no          |
| show startup-config mts                    | no          |
| show startup-config nat                    | no          |
| show startup-config nbm                    | no          |
| show startup-config netflow                | no          |
| show startup-config ngoam                  | no          |
| show startup-config ntp                    | no          |
| show startup-config nv overlay             | no          |
| show startup-config nx sdk                 | no          |
| show startup-config openflow               | no          |
| show startup-config ospf                   | no          |
| show startup-config ospfv3                 | no          |
| show startup-config otv                    | no          |
| show startup-config otv-isis               | no          |
| show startup-config param-list             | no          |
| show startup-config pim                    | no          |
| show startup-config pim6                   | no          |
| show startup-config plb-services           | no          |
| show startup-config poe                    | no          |
| show startup-config port-profile           | no          |
| show startup-config port-security          | no          |
| show startup-config ptp                    | no          |
| show startup-config radius                 | no          |
| show startup-config rip                    | no          |
| show startup-config routing ip multicast   | no          |
| show startup-config routing ipv6 multicast | no          |

| Show Commands                        | XML Support |
|--------------------------------------|-------------|
| show startup-config rpm              | no          |
| show startup-config rsvp             | no          |
| show startup-config scheduler        | no          |
| show startup-config security         | no          |
| show startup-config segment-routing  | no          |
| show startup-config services         | no          |
| show startup-config sflow            | no          |
| show startup-config sla responder    | no          |
| show startup-config sla sender       | no          |
| show startup-config sla twamp-server | no          |
| show startup-config smart-channel    | no          |
| show startup-config snmp             | no          |
| show startup-config srte             | no          |
| show startup-config switch           | no          |
| show startup-config tacacs           | no          |
| show startup-config telemetry        | no          |
| show startup-config track            | no          |
| show startup-config udd              | no          |
| show startup-config vdc              | no          |
| show startup-config vdc-all          | no          |
| show startup-config virtual-service  | no          |
| show startup-config vlan             | no          |
| show startup-config vmtracker        | no          |
| show startup-config vpc              | no          |
| show startup-config vrf              | no          |
| show startup-config vrf default      | no          |
| show startup-config vrrpv3           | no          |
| show startup-config vshd             | no          |

| Show Commands                               | XML Support |
|---|-------------|
| show startup-config vtp                     | no          |
| show startup-config wwnm                    | no          |
| show summary                                | no          |
| show switch-profile                         | yes         |
| show switch-profile buffer                  | yes         |
| show switch-profile peer                    | yes         |
| show switch-profile status                  | yes         |
| show switch-scope controller                | no          |
| show switching-mode                         | yes         |
| show switching-mode fabric-speed            | yes         |
| show system acl                             | yes         |
| show system auto-collect tech-support       | yes         |
| show system boottime                        | yes         |
| show system clis event-history              | no          |
| show system config reload-pending           | yes         |
| show system cores                           | yes         |
| show system default switchport              | yes         |
| show system dme status                      | yes         |
| show system error-id                        | yes         |
| show system exception-info                  | yes         |
| show system fabric-mode                     | yes         |
| show system fast-reload stabilization-timer | yes         |
| show system image-verification              | yes         |
| show system inband queuing statistics       | yes         |
| show system inband queuing status           | yes         |
| show system login                           | yes         |
| show system login failures                  | yes         |
| show system memory-thresholds               | yes         |

| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show system mode                    | yes         |
| show system nve infra-vlans         | yes         |
| show system poap                    | yes         |
| show system pss shrink status       | yes         |
| show system redundancy ha status    | yes         |
| show system redundancy status       | yes         |
| show system reset-reason            | yes         |
| show system reset-reason module     | yes         |
| show system resources               | no          |
| show system resources               | yes         |
| show system resources all-modules   | yes         |
| show system routing mode            | yes         |
| show system security                | yes         |
| show system simulate fan-presence   | no          |
| show system standby manual-boot     | yes         |
| show system switch-mode             | yes         |
| show system uptime                  | yes         |
| show system verify bios flash       | yes         |
| show system vlan reserved           | yes         |
| show table-map                      | yes         |
| show tacacs-server                  | yes         |
| show tacacs-server directed-request | yes         |
| show tacacs-server groups           | yes         |
| show tacacs-server sorted           | yes         |
| show tacacs-server statistics       | yes         |
| show tech-support                   | no          |
| show tech-support aaa               | no          |
| show tech-support aclmgr            | no          |



| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show tech-support aclmgr compressed | no          |
| show tech-support aclqos            | no          |
| show tech-support aclqos compressed | no          |
| show tech-support adjmgr            | no          |
| show tech-support all               | no          |
| show tech-support all binary        | no          |
| show tech-support analytics         | no          |
| show tech-support arp               | no          |
| show tech-support ascii-cfg         | no          |
| show tech-support assoc_mgr         | no          |
| show tech-support backup            | no          |
| show tech-support bcm               | no          |
| show tech-support bfd               | no          |
| show tech-support bgp               | no          |
| show tech-support biosd             | no          |
| show tech-support bloggerd          | no          |
| show tech-support bloggerd-all      | no          |
| show tech-support bootvar           | no          |
| show tech-support brief             | no          |
| show tech-support callhome          | no          |
| show tech-support cdp               | no          |
| show tech-support cert-enroll       | no          |
| show tech-support cfs               | no          |
| show tech-support cli               | no          |
| show tech-support clis              | no          |
| show tech-support clock_manager     | no          |
| show tech-support commands          | no          |
| show tech-support controller        | no          |

| Show Commands  | XML Support |
|--|-------------|
| show tech-support copp                                   | no          |
| show tech-support dcbx                                   | no          |
| show tech-support details                                | no          |
| show tech-support dhclient                               | no          |
| show tech-support dhcp                                   | no          |
| show tech-support dme                                    | no          |
| show tech-support dot1x                                  | no          |
| show tech-support ecp                                    | no          |
| show tech-support eem                                    | no          |
| show tech-support eigrp                                  | no          |
| show tech-support eltm                                   | no          |
| show tech-support ethpm                                  | no          |
| show tech-support ethport                                | no          |
| show tech-support evb                                    | no          |
| show tech-support fabric forwarding                      | no          |
| show tech-support fabric multicast                       | no          |
| show tech-support fabricpath isis                        | no          |
| show tech-support fabricpath topology                    | no          |
| show tech-support fast-reload                            | no          |
| show tech-support fc2                                    | no          |
| show tech-support fcoe                                   | no          |
| show tech-support fips                                   | no          |
| show tech-support forwarding l2 multicast                | no          |
| show tech-support forwarding l2 multicast vdc-all        | no          |
| show tech-support forwarding l2 unicast                  | no          |
| show tech-support forwarding l3 multicast                | no          |
| show tech-support forwarding l3 multicast detail         | no          |
| show tech-support forwarding l3 multicast detail vdc-all | no          |

| Show Commands  | XML Support |
|--|-------------|
| show tech-support forwarding l3 multicast vdc-all      | no          |
| show tech-support forwarding l3 unicast                | no          |
| show tech-support forwarding l3 unicast detail         | no          |
| show tech-support forwarding l3 unicast detail vdc-all | no          |
| show tech-support forwarding l3 unicast vdc-all        | no          |
| show tech-support forwarding mpls                      | no          |
| show tech-support forwarding multicast                 | no          |
| show tech-support gold                                 | no          |
| show tech-support gpixm                                | no          |
| show tech-support ha                                   | no          |
| show tech-support ha module                            | no          |
| show tech-support ha standby                           | no          |
| show tech-support ha_short                             | no          |
| show tech-support hardware-telemetry                   | no          |
| show tech-support hsrp                                 | no          |
| show tech-support hsrp brief                           | no          |
| show tech-support icam                                 | no          |
| show tech-support icmpv6                               | no          |
| show tech-support im                                   | no          |
| show tech-support imp                                  | no          |
| show tech-support inband counters                      | no          |
| show tech-support include-time                         | no          |
| show tech-support install                              | no          |
| show tech-support interface-vlan                       | no          |
| show tech-support ip                                   | no          |
| show tech-support ip igmp                              | no          |
| show tech-support ip igmp snooping                     | no          |
| show tech-support ip msdp                              | no          |

| Show Commands                    | XML Support |
|----------------------------------|-------------|
| show tech-support ip pim         | no          |
| show tech-support ip rsvp        | no          |
| show tech-support ipqos          | no          |
| show tech-support ipv6           | no          |
| show tech-support ipv6 mld       | no          |
| show tech-support ipv6 multicast | no          |
| show tech-support ipv6 pim       | no          |
| show tech-support isis           | no          |
| show tech-support issu           | no          |
| show tech-support kstack         | no          |
| show tech-support l2             | no          |
| show tech-support l2fm           | no          |
| show tech-support l2fm clients   | no          |
| show tech-support l2fm detail    | no          |
| show tech-support l2fm l2dbg     | no          |
| show tech-support l2rib          | no          |
| show tech-support l3vm           | no          |
| show tech-support l3vpn          | no          |
| show tech-support lacp           | no          |
| show tech-support ldap           | no          |
| show tech-support license        | no          |
| show tech-support lim            | no          |
| show tech-support lisp           | no          |
| show tech-support lldp           | no          |
| show tech-support logging        | no          |
| show tech-support m2rib          | no          |
| show tech-support macsec         | no          |
| show tech-support macsec detail  | no          |

| Show Commands                          | XML Support |
|--|-------------|
| show tech-support mfwd                 | no          |
| show tech-support mmode                | no          |
| show tech-support module               | no          |
| show tech-support module all           | no          |
| show tech-support monitor              | no          |
| show tech-support monitor erspan       | no          |
| show tech-support monitorc-all         | no          |
| show tech-support mpls ldp             | no          |
| show tech-support mpls manager         | no          |
| show tech-support mpls static          | no          |
| show tech-support mpls strip           | no          |
| show tech-support mpls switching       | no          |
| show tech-support mpls traffic-eng     | no          |
| show tech-support mpls fwd             | no          |
| show tech-support multicast            | no          |
| show tech-support multicast-vxlan-evpn | no          |
| show tech-support mvpn                 | no          |
| show tech-support nat                  | no          |
| show tech-support nbm                  | no          |
| show tech-support nbm group            | no          |
| show tech-support netflow              | no          |
| show tech-support netstack             | no          |
| show tech-support netstack detail      | no          |
| show tech-support ngoam                | no          |
| show tech-support npacl                | no          |
| show tech-support npv                  | no          |
| show tech-support ns                   | no          |
| show tech-support ntp                  | no          |

| Show Commands                       | XML Support |
|-------------------------------------|-------------|
| show tech-support nve               | no          |
| show tech-support nxapi             | no          |
| show tech-support nxsdk             | no          |
| show tech-support object-store      | no          |
| show tech-support openflow          | no          |
| show tech-support openflow platform | no          |
| show tech-support ospf              | no          |
| show tech-support ospfv3            | no          |
| show tech-support otv               | no          |
| show tech-support page              | no          |
| show tech-support patch             | no          |
| show tech-support pbr               | no          |
| show tech-support pfstat            | no          |
| show tech-support pixm              | no          |
| show tech-support pixm-all          | no          |
| show tech-support pixmc-all         | no          |
| show tech-support pktmgr            | no          |
| show tech-support platform-sdk      | no          |
| show tech-support plb-services      | no          |
| show tech-support plcmgr            | no          |
| show tech-support pltfm-config      | no          |
| show tech-support pnp               | no          |
| show tech-support poe               | no          |
| show tech-support port              | no          |
| show tech-support port-channel      | no          |
| show tech-support port-client-all   | no          |
| show tech-support port-profile      | no          |
| show tech-support port-security     | no          |

| Show Commands                            | XML Support |
|--|-------------|
| show tech-support private-vlan           | no          |
| show tech-support ptp                    | no          |
| show tech-support radius                 | no          |
| show tech-support rip                    | no          |
| show tech-support routing                | no          |
| show tech-support routing ipv6           | no          |
| show tech-support routing ipv6 multicast | no          |
| show tech-support routing multicast      | no          |
| show tech-support rpm                    | no          |
| show tech-support sal                    | no          |
| show tech-support san                    | no          |
| show tech-support san-port-channel       | no          |
| show tech-support satmgr                 | no          |
| show tech-support security               | no          |
| show tech-support segment-routing        | no          |
| show tech-support services               | no          |
| show tech-support session-mgr            | no          |
| show tech-support sflow                  | no          |
| show tech-support single-gericho         | no          |
| show tech-support sksd                   | no          |
| show tech-support sla responder          | no          |
| show tech-support sla sender             | no          |
| show tech-support sla twamp-server       | no          |
| show tech-support smartc                 | no          |
| show tech-support smm                    | no          |
| show tech-support snmp                   | no          |
| show tech-support sockets                | no          |
| show tech-support spm                    | no          |

| Show Commands                     | XML Support |
|-----------------------------------|-------------|
| show tech-support srte            | no          |
| show tech-support statsclient     | no          |
| show tech-support stp             | no          |
| show tech-support sup-filesys     | no          |
| show tech-support sysmgr          | no          |
| show tech-support tacacs          | no          |
| show tech-support telemetry       | no          |
| show tech-support track           | no          |
| show tech-support tunnel          | no          |
| show tech-support u2rib           | no          |
| show tech-support udld            | no          |
| show tech-support usd-all         | no          |
| show tech-support vdc             | no          |
| show tech-support virtual-service | no          |
| show tech-support vlan            | no          |
| show tech-support vmtracker       | no          |
| show tech-support vpc             | no          |
| show tech-support vrrp            | no          |
| show tech-support vrrp brief      | no          |
| show tech-support vrrpv3          | no          |
| show tech-support vsan            | no          |
| show tech-support vshd            | no          |
| show tech-support vtp             | no          |
| show tech-support vvlan           | no          |
| show tech-support vxlan           | no          |
| show tech-support vxlan platform  | no          |
| show tech-support vxlan-evpn      | no          |
| show tech-support xbar            | no          |



| Show Commands                               | XML Support |
|---|-------------|
| show tech-support xml                       | no          |
| show tech-support xos                       | no          |
| show telemetry control database             | yes         |
| show telemetry data collector brief         | yes         |
| show telemetry event collector stats        | yes         |
| show telemetry pipeline stats               | yes         |
| show telemetry transport                    | yes         |
| show telemetry usability                    | yes         |
| show telnet server                          | yes         |
| show terminal                               | yes         |
| show terminal output xml version            | yes         |
| show time-range                             | yes         |
| show time-stamp running-config last-changed | yes         |
| show trace callhome                         | no          |
| show track                                  | yes         |
| show track brief                            | yes         |
| show troubleshoot l2 mac vlan               | no          |
| show troubleshoot l3 vrf                    | no          |
| show trunk protocol                         | yes         |
| show ttag brief                             | yes         |
| show udd                                    | yes         |
| show udd global                             | yes         |
| show udd neighbors                          | yes         |
| show user-account                           | yes         |
| show username keypair                       | yes         |
| show username passphrase timevalues         | yes         |
| show userpassphrase                         | yes         |
| show users                                  | yes         |

| Show Commands                          | XML Support |
|--|-------------|
| show vdc                               | yes         |
| show vdc current-vdc                   | yes         |
| show vdc fcoe-vlan-range               | yes         |
| show vdc resource                      | yes         |
| show vdc resource template             | yes         |
| show version                           | yes         |
| show version epld                      | yes         |
| show version image                     | yes         |
| show version module                    | yes         |
| show version module epld               | yes         |
| show virtual-service                   | yes         |
| show virtual-service storage pool list | yes         |
| show virtual-service tech-support      | no          |
| show virtual-service utilization name  | yes         |
| show virtual-service version           | yes         |
| show vlan                              | yes         |
| show vlan access-list                  | yes         |
| show vlan access-map                   | yes         |
| show vlan all-ports                    | yes         |
| show vlan counters                     | yes         |
| show vlan dot1Q tag native             | yes         |
| show vlan fcoe                         | yes         |
| show vlan filter                       | yes         |
| show vlan id                           | yes         |
| show vlan id counters                  | yes         |
| show vlan id vn-segment                | yes         |
| show vlan name                         | yes         |
| show vlan private-vlan type            | yes         |

| Show Commands                              | XML Support |
|--|-------------|
| show vlan xbrief                           | yes         |
| show vlan xsummary                         | yes         |
| show vmtracker                             | yes         |
| show vmtracker certificate                 | yes         |
| show vmtracker fabric auto-config          | yes         |
| show vmtracker status                      | yes         |
| show vpc                                   | yes         |
| show vpc consistency-parameters            | yes         |
| show vpc consistency-parameters vlans      | yes         |
| show vpc fabric-ports                      | yes         |
| show vpc orphan-ports                      | yes         |
| show vpc peer-keepalive                    | yes         |
| show vpc role                              | yes         |
| show vpc statistics peer-keepalive         | yes         |
| show vpc statistics vpc                    | no          |
| show vpc virtual-peerlink dest reachable   | no          |
| show vpc virtual-peerlink vlan consistency | no          |
| show vrf                                   | yes         |
| show vrf                                   | no          |
| show vrrp                                  | yes         |
| show vrrp bfd-sessions                     | yes         |
| show vrrpv3                                | yes         |
| show vrrs client                           | yes         |
| show vrrs pathway                          | yes         |
| show vrrs pathway address                  | no          |
| show vrrs server                           | yes         |
| show vrrs tag                              | yes         |
| show vsan                                  | yes         |

| Show Commands                         | XML Support |
|---------------------------------------|-------------|
| show vsan membership                  | yes         |
| show vsan membership interface        | yes         |
| show vsan usage                       | yes         |
| show vtp counters                     | yes         |
| show vtp interface                    | yes         |
| show vtp password                     | yes         |
| show vtp status                       | yes         |
| show wred-queue qos-group-map         | yes         |
| show wrr unicast-bandwidth            | yes         |
| show wrr-queue qos-group-map          | yes         |
| show wwn status                       | yes         |
| show wwn switch                       | yes         |
| show wwn test                         | no          |
| show wwn vsan-wwn                     | yes         |
| show xml server logging configuration | no          |
| show xml server status                | yes         |