# Preface

This preface includes the following sections:


- Audience, on page i
- Document Conventions, on page i
- Related Documentation for Cisco Nexus 9000 Series Switches, on page ii
- Documentation Feedback, on page ii
- Communications, services, and additional information, on page ii


## Audience

This publication is for network administrators who install, configure, and maintain Cisco Nexus switches.

## Document Conventions

Command descriptions use the following conventions:

| Convention | Description |
|---|---|
| **bold** | Bold text indicates the commands and keywords that you enter literally as shown. |
| *Italic* | Italic text indicates arguments for which you supply the values. |
| [x] | Square brackets enclose an optional element (keyword or argument). |
| [x \| y] | Square brackets enclosing keywords or arguments that are separated by a vertical bar indicate an optional choice. |
| {x \| y} | Braces enclosing keywords or arguments that are separated by a vertical bar indicate a required choice. |
| [x {y \| z}] | Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element. |

| Convention | Description |
|---|---|
| `variable` | Indicates a variable for which you supply values, in context where italics cannot be used. |
| string | A nonquoted set of characters. Do not use quotation marks around the string or the string includes the quotation marks. |

Examples use the following conventions:

| Convention | Description |
|---|---|
| `screen font` | Terminal sessions and information the switch displays are in screen font. |
| **`boldface screen font`** | Information that you must enter is in boldface screen font. |
| *italic screen font* | Arguments for which you supply values are in italic screen font. |
| < > | Nonprinting characters, such as passwords, are in angle brackets. |
| [ ] | Default responses to system prompts are in square brackets. |
| !, # | An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line. |

# Related Documentation for Cisco Nexus 9000 Series Switches

The entire Cisco Nexus 9000 Series switch documentation set is available at the following URL:

https://www.cisco.com/en/US/products/ps13386/tsd_products_support_series_home.html

# Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to nexus9k-docfeedback@cisco.com. We appreciate your feedback.

# Communications, services, and additional information

- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business impact you're looking for with the technologies that matter, visit Cisco Services.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions, and services, visit Cisco DevNet.
- To obtain general networking, training, and certification titles, visit Cisco Press.
- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

# Cisco Bug Search Tool

Cisco Bug Search Tool (BST) is a gateway to the Cisco bug-tracking system, which maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. The BST provides you with detailed defect information about your products and software.

# Documentation feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.